



Speak Easy™ Instruction Manual V00

Speak Easy™ Deer Model No. 7754
(Includes: Remote, Speaker Unit, and Lanyard)

Speak Easy™ Predator Model No. 3758

PLEASE READ CAREFULLY BEFORE USE

IMPORTANT

For your protection, please carefully read these warnings, precautions and safety/operating instructions completely before operating this product. Follow these instructions closely and keep this manual for future reference.

WARNING

- To reduce the risk of fire, electrical shock or product damage/failure,
 - Do not expose unit with the battery door open to rain, moisture, dripping or splashing. Do not open or close the battery door with wet hand. Completely wipe off water on unit and door before opening.
 - Do not lay product on moist ground or submerge in water.
 - **DO NOT OPEN CASE HOUSING. UNINSULATED, 'DANGEROUS VOLTAGE' WITHIN PRODUCTS ENCLOSURE. DO NOT REMOVE HOUSING COVER. THERE ARE NO USER-SERVICEABLE PARTS INSIDE, REFER SERVICING TO PRIMOS® CUSTOMER SERVICE.**
 - Only use batteries as specified in this user manual and install according to correct polarization. Failure to follow may result in leaking or exploding batteries, damage to product, fire or personal injury. Do not handle damaged or leaking batteries.
 - Do not expose to extreme heat. Do not leave product and/or batteries exposed in direct sunlight inside a vehicle, or other contained environment for a long period of time.
 - Only use accessories as recommended in this manual

WARNING

Primos® game calls are so accurate you might attract other hunters, as well as game. The user of this product assumes all risk of injury in association with the use of this product.

MODIFICATION WARNING

You are cautioned that any changes or modifications not expressly approved in this manual could void your warranty of this equipment.

OPERATING TEMPERATURE

- Recommended storage temperature range -10°F to 140°F
- Recommended operating temperature range 20°F to 120°F

WARNING

To avoid possible product damage and/or injury, NEVER INSTALL DIFFERENT TYPES OF BATTERIES in the product at the same time. Failure to follow may result in leaking or exploding batteries, damage to product, fire or personal injury. Do not handle damaged or leaking batteries.

BATTERY INSTALLATION (1 AAA & 4 AA Batteries Not Included)

REMOTE	Remove battery cover and install 1 AAA battery following polarity instructions in battery compartment. Reinstall battery cover and tighten with screw driver or coin.
SPEAKER	Remove battery cover and install 4 AA batteries following polarity instructions in battery compartment. Reinstall battery cover and tighten with screw driver or coin.

OPERATION INSTRUCTIONS

IMPORTANT NOTE: Check your local and state hunting laws for legal and recommended use of electronic game calls.

Turn power on both speaker and remote before using.

NOTE: Remote control buttons are designed to activate command when button is completely pressed down on the remote.




ON/STOP/OFF BUTTON [Located on upper right of remote] Press to turn Power ON. Press and hold button down 5 second to turn POWER OFF. Press to STOP sound when sound is playing.

PLAY SOUND [Six sound buttons in center of remote] Press desired sound button. Note: When signal is sent to speaker LED in upper left corner will flash 3 times.

STOP SOUND [Located on upper right of remote] – Press ON/STOP/OFF button to stop sound at anytime. Note: When signal is sent to speaker LED in upper left corner will flash 3 times.

VOLUME – Press UP/DOWN volume button at anytime to select between 5 volume settings (1 lowest & 5 loudest). Note: When signal is sent to speaker LED in upper left corner will flash 3 times.



POWER BUTTON – Standard ON/OFF functionality

LED LIGHT – Indicates power is on Speaker.

ATTACHING REMOTE TO SPEAKER

NOTE: Attaching remote to speaker is designed for storage. Primos does not recommend transporting remote attached to speaker in and out of the field without extra attachment security protection as remote can be bumped and detach from speaker.

1. Line up raised are on back of remote with matching recessed area on speaker.
2. Insert raised area on remote into recessed area and rotate remote 90 degrees to lock into position.
3. To remove, reverse these steps.



SPEAKER PLACEMENT

Place speaker within 40 yards of your location. Position speaker facing away from your location attached to a tree, branch, brush, etc using attachment strap. Hunting Tip: Keeping speaker within 25 yards allows for closer shots. Also place speaker to side of your location so animal is looking to the side of you and not in direct alignment with you.

IMPORTANT NOTE: If speaker is placed at long distances, on the ground, in thick cover, in under brush, or has obstructions between remote and speaker always check remote function with speaker. If remote does not operate speaker, raise speaker off ground or decrease speaker distance.

CARING FOR YOUR CALLER

Your caller contains sensitive electronic components that can be permanently damaged if exposed to excessive shock or vibration. To minimize the risk of damage to your unit, avoid dropping your unit and operating it in high-shock and high-vibration environments.

- Do not store your unit where prolonged exposure to extreme temperatures can occur, because it can cause permanent damage.
- Do not expose to prolonged exposure to moisture. This can cause this unit to malfunction.
- Never use a hard or sharp object to operate this unit or damage may result.

Cleaning the Unit:

The Speak Easy™ Caller is constructed of high-quality materials and does not require user maintenance other than cleaning. Clean the outer casings using a cloth dampened with a mild detergent solution, and then wipe dry and allow to air dry.

Avoid chemical cleaners and solvents that can damage plastic components or faux fur body cover and tail.

Caution: The caller is water resistant - not waterproof.

TROUBLE SHOOTING

Check batteries in speaker and remote control if caller is not functioning properly.

Remote is not controlling speaker properly. Move remote closer to speaker until remote properly controls speaker.

If speaker continues to function incorrectly, call Customer Service at 601-879-9323 or email service@primos.com.

FCC STATEMENT

Changes not expressly approved by Primos could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an output on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation

ONE YEAR SERVICE GUARANTEE
1 YEAR LIMITED WARRANTY

Terms:

You MUST keep a receipt for “Proof of Purchase” for any warranty claims on your product. More details below.

Please contact the Primos® Customer Service Team with any comments, questions, problems or return requests. Call (601) 879-9323 or email service@primos.com.

RETURN THIS PRODUCT TO PRIMOS® HUNTING
DO NOT SEND BACK TO THE STORE

604 First Street, Flora, MS 39071 • Office 601-879-9323 • Orders 1-800-523-2395 • Fax 601-879-9324 • primos.com

In the event warranty service is needed, please contact Primos® Customer Service to obtain a Return Merchandise Authorization (RMA) number. Once you have secured a RMA number, you will be required to:

1. Write RMA number in large / visible print on outside of package.
2. Remove batteries from product and pack in well-padded or highly protective box. Primos® will NOT be responsible for damage incurred in returning product for repair / replacement.
3. Include Proof of Purchase.
ANY ITEM RETURNED WITHOUT PROOF OF PURCHASE WILL NOT BE ACCEPTED.
4. Send product prepaid to: Primos® Hunting, Customer Service Department, 604 First Street, Flora, MS 39071.

For warranty or service information, email service@primos.com or call Customer Service at (601) 879-9323.

DISCLAIMERS

Primos® makes no representations or warranties, either expressed or implied, by or concerning any content of these written materials or software, or for damages resulting from the use of the information contained therein. Primos® reserves the right to alter the features and contents of this publication, hardware or software without obligation or advance notice.

Warranty does not extend to any accessories used with this product.

Primos® is not responsible if you use this product for illegal purposes.

Primos® shall not be obligated to perform preventative maintenance, installation, deinstallation, or maintenance.

The illustrations in this manual are for instructional purposes only and may not represent actual product exactly.