

## Pronto Intelligent Access Point

**Quick Start Guide** 



## **Step 1: Package Contents**

Unbox and verify the following contents:

- Pronto Point AP
- Auxiliary tool for installation
- Pronto Intelligence AP Quick Installation Guide
- 1 RJ45 Ethernet Cable

## Step 2: Hardware Installation

- Power on your computer
- Connect one end of ethernet cable to POE switch port and the other end to Pronto Intelligent AP's WAN port and power on the AP
- Ensure that the Power LED is on (LED will glow in orange)
- Ensure that the Wireless LED is on (LED will glow in blue)



## Step 3: Access Point Configuration

- Connect one end of the RJ45 Ethernet cable to the POE switch and other end to the Ethernet port of the computer
- Ensure that the Network Connection is enabled on your computer
- Assign an IP address within the range (192.168.0.2-254) e.g. 192.168.0.10 to your computer
- Management IP for the AP is 192.168.0.1
- To configure the AP, open a web browser in your computer and type the following URL. http://192.168.0.1
- A login screen will appear. By default, the username of the AP is admin and password is pronto. You can set desired password after logging into the AP
- Configure the AP, as you desire
- By default the AP will broadcast unsecured ESSID as **Pronto**. The AP has provision
  to setup 4 ESSIDs and also to setup security for each one of them. Please refer the
  detailed User Manual at **www.prontonetworks.com**
- Connect Internet back-haul to POE switch
- Connect your computer to default **Pronto** ESSID and access Internet
- Congratulations!! Your AP is configured successfully... Enjoy surfing Internet on Wi-Fi

I . This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.