



HPRO-4G

PLS-63W
Certification

Users' Guide

Document # 1193-30xx
Revision

CONFIDENTIAL

SENSITIVITY LEVEL: **YELLOW**

Document Number 1193-30xx

This document contains confidential and proprietary information of Quake Global corporation. It may be used by recipient only for the purpose for which it was transmitted and will be returned upon request or when no longer needed by recipient. Disclosure to unauthorized third parties or duplication without the express written permission of Quake Global is prohibited. © 2022 QUAKE GLOBAL, INC. - All rights reserved.

Revision History

DATE	REV	ECO#	REASON
10/11/2018	A	02498	Initial release
10/23/2018	B	02516	Application installation instructions and ip67 test instructions added. Added instructions on assigning a static IP address.
08/10/2022			Added set up instructions for PLS63-W testing.

CONFIDENTIAL

Confidential

Information classified Confidential - Do not copy (See last page for obligations)

Table of Contents

1	INTRODUCTION.....	4
1.1	Prerequisites.....	4
1.1.1	Available from Quake	4
1.1.2	Recommended Minimum Support Equipment.....	4
2	SETUP	5
2.1	Hardware	5
2.1.1	Terminal Setup.....	6
2.1.1.1	Option 1: Serial Connection	6
2.1.1.2	Option 2: Ethernet Connection (Do not perform if serial connection used)	8
2.1.1.2.1	Setting the Host Static IP	8
2.1.1.2.2	Establishing the Connection with Tera Term.....	10
2.1.1.2.3	Enabling Ethernet.....	12
	IF Connection does not start type.....	12
3	FCC 15B TESTING	14
4	TESTING	15
4.1	Cell Testing - Sending AT Commands	15
4.2	GPS Testing.....	16
4.3	Wi-Fi Testing.....	17
4.4	BT testing.....	21

Confidential

Information classified Confidential - Do not copy (See last page for obligations)

Table of Figures

Figure 1 Interface and Antenna Cable Connections	5
Figure 4 DB9 Serial Connection	6
Figure 5 Create Connection	7
Figure 6 Set Baud Serial Port Configuration	7
Figure 7 Open Network and Sharing Center	8
Figure 8 Changing the Adapter Settings	8
Figure 9 Adapter Properties.....	9
Figure 10 IPv4 Settings.....	9
Figure 11 Setting the IP Address.....	10
Figure 12 Create Connection	11
Figure 13 Connection Refused.....	11
Figure 20 FCC part 15b setup.....	14

Table of Tables

Table 1 Quake Provided Support Equipment	4
--	---

Confidential

CONFIDENTIAL

Information classified Confidential - Do not copy (See last page for obligations)

1 Introduction

The HPRO set up instructions demonstrates basic functionality of the HPRO device. With these steps the user can test functionality of the various hardware functions and features. The primary purpose of these instructions is to assist with the following:

- CE/FCC Testing
- Cellular Testing
- Reliability and Environmental Testing

This User's Guide describes the following activities:

- Connecting the device to support equipment.
- Configuring minimal support equipment.
- Executing and operating the HPRO to get desirable outputs.

1.1 Prerequisites

The user of this guide should be comfortable working with low-voltage circuits, connecting wires and have a basic understand of serial ports, Ethernet, and operating terminal emulation software from a windows PC.

1.1.1 Available from Quake

Quake Part Number	Description
1193-5000 or 1193-5001	RED, AS-SHIPPED, HPRO-4G-B
1193-0217	1193-0217 RED, ASSY, CABLE, TEST, QCONNECT
	ANTENNA, GPS

Table 1 Quake Provided Support Equipment

1.1.2 Recommended Minimum Support Equipment

- USB-to-Serial Adapter
- Terminal Software, for example, Tera Term or equivalent. <https://osdn.net/projects/ttssh2/releases/>
- 12-24 VDC power source capable of supplying 2A, a 12V automotive battery is recommended
- E-SIM provisioned and activated, nano-sim slot provisioned.

2 Setup

The following instructions will describe the very basic hardware and software setup of the device and connection to minimal support equipment elements.

2.1 Hardware

The Terminal requires, two connections, an antenna connection, consisting of GNSS antenna and, connection to a power source and communication interface via the supplied interface cable. The evaluation kit provides the appropriate interface cable and antenna for these connections.




Figure 1 Interface and Antenna Cable Connections

2.1.1 Terminal Setup

The terminal may be used with a serial connection, and/or an Ethernet Connection. Both methods are described here. Quake recommends the Serial Connection method due to its simplicity. Users running QConnectATECerts with a desire to operate the Ethernet connection will need to initially connect via a Serial Connection to enable the Ethernet interface. Choose the method that best suits your use case, or, refer to the specific use cases described elsewhere in this document for guidance.

2.1.1.1 Option 1: Serial Connection

Once the Hardware is connected properly, connect the DB-9 RS-232 terminal interface cable to a host PC using a serial-to-USB adapter. Do not turn the supply 'ON' or make the final battery connection just yet.




Figure 2 DB9 Serial Connection

On the host PC, utilize terminal emulation software such as TeraTerm to open a serial connection to the HPro-4G terminal. If you do not have terminal emulation software download and install TeraTerm using the link and instructions provided at the beginning of this document.

When TeraTerm launches, select 'Serial' in the connection dialog and the appropriate adapter from the dropdown dialog box.




Figure 3 Create Connection

From the Setup -> Serial Port... menu item in Tera Term, set the port to 115200kbps and 8 bits, 1 stop bit.




Figure 4 Set Baud Serial Port Configuration

Turn on the power supply or connect to an external battery.

Proceed to Cell OR
Proceed to WiFi OR
Proceed to GPS

2.1.1.2 Option 2: Ethernet Connection (Do not perform if serial connection used)

Configuring for an Ethernet application requires the additional step of setting the host static IP address. While the terminal is provisioned with a static IP address, the host PC will need a static IP address. Follow the instructions below to set a Windows host with a static IP address.

2.1.1.2.1 Setting the Host Static IP

To set a static IP address on a windows host open the network and file sharing center from the system tray:




Figure 5 Open Network and Sharing Center

Next, from the Network and Sharing Center, select 'Change adapter settings'.




Figure 6 Changing the Adapter Settings

Locate the Ethernet adapter you intend to connect the device to, right-click and select 'Properties'.




Figure 7 Adapter Properties

Locate and select the 'Internet Protocol Version 4 (TCP/IPv4)' settings and click 'Properties'





Figure 8 IPv4 Settings

Set Properties as shown below, then click 'OK'.



General

You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings.

☐ Obtain an IP address automatically

☒ Use the following IP address:

IP address: 192 . 168 . 35 . 51

Subnet mask: 255 . 255 . 255 . 0

Default gateway: . . .

☐ Obtain DNS server address automatically

☒ Use the following DNS server addresses:

Preferred DNS server: . . .

Alternate DNS server: . . .

☐ Validate settings upon exit

Advanced...

Figure 9 Setting the IP Address

The Windows host now has a static IP address.

2.1.1.2.2 Establishing the Connection with Tera Term

Connect the RJ45 Ethernet cable from the device to the host PC with a static IP address as shown above. Turn the supply 'ON' or make the final battery connection to power the unit ON.

Wait approximately 30 – 60 seconds for the device to complete its boot process before continuing.

On the host PC, utilize terminal emulation software such as TeraTerm to open a TCP/IP connection to the QConnect terminal. If you do not have terminal emulation software download and install TeraTerm using the link and instructions provided at the beginning of this document.

When TeraTerm launches, select 'TCP/IP' in the connection dialog and the appropriate adapter from the dropdown dialog box. You must use 192.168.35.10 for the Host address as shown below.




Figure 10 Create Connection

If you receive the prompt below, everything appears to be properly configured and you've waited 60-90 seconds, you may need to manually enable the Ethernet port using the Serial Connection.




Figure 11 Connection Refused

2.1.1.2.3 Enabling Ethernet

If you are receiving 'Connection refused' as shown above it's likely your device is running a variant of the Test App which, by default, leaves the Ethernet port OFF. To turn it on, first, connect via the Serial Port using the instructions: [Option 1: Serial Connection](#).

1. Edit /etc/network/interfaces file, file contents should look similar to:

vi /etc/network/interfaces

```
auto lo
iface lo inet loopback

auto eth0
iface eth0 inet static
address 192.168.10.11
netmask 255.255.255.0
```

(It is important that the address on the HPro-4G match the address on the computer – you may not need to change anything.)

(Step 3 may also not be necessary, but it will not hurt anything to run again.)

2. run the command: **modprobe fec**

3. finally: **ifup eth0**

at this point ethernet should be working.

they can check by using the ifconfig command. Example:

```
# ifup eth0
Micrel KSZ8061 2188000.ethernet-1:00: attached PHY driver [Micrel KSZ8061] (mii_bus:phy_addr=
2188000.ethernet-1:00, irq=-1)
IPv6: ADDRCONF(NETDEV_UP): eth0: link is not ready
# fec 2188000.ethernet eth0: Link is Up - 100Mbps/Full - flow control rx/tx
IPv6: ADDRCONF(NETDEV_CHANGE): eth0: link becomes ready

# ifconfig
eth0      Link encap:Ethernet  HWaddr 1A:15:01:B4:A4:1A
          inet addr:192.168.10.11  Bcast:0.0.0.0  Mask:255.255.255.0
          inet6 addr: fe80::1815:1ff:feb4:a41a/64 Scope:Link
          UP BROADCAST RUNNING MULTICAST  MTU:1500  Metric:1
          RX packets:22 errors:0 dropped:0 overruns:0 frame:0
          TX packets:6 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:1000
          RX bytes:2447 (2.3 KiB)  TX bytes:508 (508.0 B)

lo        Link encap:Local Loopback
          inet addr:127.0.0.1  Mask:255.0.0.0
          inet6 addr: ::1/128 Scope:Host
          UP LOOPBACK RUNNING  MTU:65536  Metric:1
          RX packets:0 errors:0 dropped:0 overruns:0 frame:0
          TX packets:0 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:1
          RX bytes:0 (0.0 B)  TX bytes:0 (0.0 B)

# echo "ethernet is now up"
ethernet is now up
# ping 192.168.10.10
PING 192.168.10.10 (192.168.10.10): 56 data bytes
64 bytes from 192.168.10.10: seq=0 ttl=128 time=4.359 ms
64 bytes from 192.168.10.10: seq=1 ttl=128 time=2.269 ms

--- 192.168.10.10 ping statistics ---
2 packets transmitted, 2 packets received, 0% packet loss
round-trip min/avg/max = 2.269/3.314/4.359 ms
^C# ifconfig "ethernet is now working and fully functional"
ifconfig: ethernet is now : error fetching interface information: Device not found
# echo "ethernet is now working and fully functional"
ethernet is now working and fully functional
```

IF Connection does not start type

Ps-> and check is you have ssh activated

If not go to :cd /etc/init.d

./S50ssh start

and then

./S50sshd restart

Then connect to ssh and paste a message related to the picture

```

lucasubuntu@jericho: ~$ ssh 192.168.35.10
@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@
@   WARNING: REMOTE HOST IDENTIFICATION HAS CHANGED!   @
@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@
IT IS POSSIBLE THAT SOMEONE IS DOING SOMETHING NASTY!
Someone could be eavesdropping on you right now (man-in-the-middle attack)!
It is also possible that a host key has just been changed.
The fingerprint for the ECDSA key sent by the remote host is
SHA256:zh9wz90e1TDkuadf3/0Eq03IMoghkSTf3zZeKiiP5lk.
Please contact your system administrator.
Add correct host key in /home/lucasubuntu/.ssh/known_hosts to get rid of this message.
Offending ECDSA key in /home/lucasubuntu/.ssh/known_hosts:3
  remove with:
  ssh-keygen -f "/home/lucasubuntu/.ssh/known_hosts" -R "192.168.35.10"
ECDSA host key for 192.168.35.10 has changed and you have requested strict checking.
Host key verification failed.

```

Pasted underneath

and then go to tera term and change the date and time from the unit.

type:

date +%Y%m%d -s "20081128"

Depending on the type of testing, support equipment may, or may not be required.

Sub System	Required Equipment	Optional Equipment
GPIO		Switch box to set GPIO high/low
Analog		Switch box to set ADC 1 and 2 from 0 to 32VDC
Cellular	SIM Card and Cellular Antenna w/sense	
GNSS/GPS	GNSS Antenna w/sense	
CAN Ports	CAN source (Q4000 or equivalent)	
Ethernet	PC	Dedicated PC running iperf
Bluetooth	BT Peripheral	
Wi-Fi	Router	

To exit the Monitor Test type '!' or the exclamation mark. The cell and wi-fi module will be detached and shutdown.

3 FCC 15b Testing

For FCC Testing the terminal can be connected as shown below with automotive 12V battery and external antenna.




Figure 12 FCC part 15b setup

Ensure you have Tera Term installed on a laptop and follow the instructions for either [Option 1: Serial Connection](#) or [Option 2: Ethernet Connection](#).

4 Testing

This section describes setting up the device for testing Cell, Wi-Fi, BT and GPS.

4.1 Cell Testing - Sending AT Commands


Connect to the device using terminal software in Serial mode [Option 1: Serial Connection](#)

At the login prompt, enter 'root' for user and '**certs**' for password (without quotation marks).

- Open Ethernet port on Tera term, by clicking on file , then click new connection.

1)Host:[root@192.168.35.10](#) and service : SSH

2)Click ok



3)User Name: **root**

4)password:**certs**

If connection is failing type on TeraTerm serial: **ifup - a**
Return to ethernet window and repeat steps 1 and 2

type:

- **echo 89 > /sys/class/gpio/export**
- **echo out > /sys/class/gpio/gpio89/direction**
- **echo 1 > /sys/class/gpio/gpio89/value**
- **sleep 1**
- **echo 0 > /sys/class/gpio/gpio89/value**

When the USB ports come up, type:

- **microcom /dev/ttyACM2**

Type:

AT+CFUN=1,0

AT+COPS=0


```
lucasubuntu@jbravo-nb:~$ ssh root@192.168.35.10
root@192.168.35.10's password:
# echo 89 > /sys/class/gpio/export
# echo out > /sys/class/gpio/gpio89/direction
# echo 1 > /sys/class/gpio/gpio89/value
# sleep 1
# echo 0 > /sys/class/gpio/gpio89/value
# microcom /dev/ttyACM2
AT+CFUN=1,0
OK
AT+COPS=0
OK
```

(Any other desired AT commands can be entered from microcom mode)

Connect call box, run tests


Ctrl+'x' to quit microcom mode

4.2 GPS Testing

- Open Ethernet port on Tera term, by clicking on file , then click new connection.

1)Host:[root@192.168.35.10](ssh://root@192.168.35.10) and service : SSH

2)Click ok



Tera Term: New connection

☒ TCP/IP Host: root@192.168.35.10

☒ History TCP port#: 22

Service: ☐ Telnet ☒ SSH SSH version: SSH2

☐ Other IP version: AUTO

☐ Serial Port:

OK Cancel Help

3)User Name: **root**

4)password:**certs**

If connection is failing type on TeraTerm serial: **ifup - a**

Return to ethernet window and repeat steps 1 and 2

Type:

- **gpsmon**

It should show an image like this:


```
tcp://localhost:2947      NMEA0183>
Time: 2022-07-14T02:22:01.000Z Lat: 32 49.456860' N Lon: 117 07.213350' W
topbits":1,"cycle":
| GPGSV GLGSV GNGLL GNRMC GNVTG GNGGA GNGSA |
|
PRN  Az El S/N      Time: 022201.00      Time: 022200.00
 1 300 47 48      Latitude: 3249.45686 N      Latitude: 3249.45685
 3 310 21 40      Longitude: 11707.21335 W      Longitude: 11707.21332
 4 255 14 36      Speed: 0.017      Altitude: 97.5
 8 229 5 0        Course:      Quality: 2 Sats: 12
10 106 23 46      Status: A      FAA: D      HDOP: 0.58
21 259 58 47      MagVar:      Geoid: -33.7
22 26 57 49      RMC      GGA
25 67 9 0
26 153 8 35
31 126 68 51
32 47 36 46
46 201 50 47
GSV      GSA + PPS      GST
(68) $GPGSV,4,2,14,10,23,106,46,21,58,259,47,22,57,026,49,25,09,067,*78
```

4.3 Wi-Fi Testing

- Open Ethernet port on Tera term, by clicking on file , then click new connection.

1)Host:root@192.168.35.10 and service : SSH

2)Click ok



- 3) User Name: **root**
- 4) password: **certs**

If connection is failing type on TeraTerm serial: **ifup - a**
Return to ethernet window and repeat steps 1 and 2

5) type: **ls**

Preparation:

Make sure that wifiTest is available in the list of application installed by typing 'ls'

```
192.168.35.10 - Tera Term VT
File Edit Setup Control Window Help
^C
# ls
HCMQconnect_deploy.md5  HMQconnect_install.tar  install.sh  macmanagercli  wifiTest
HCMQconnect_deploy.tar  QConnectHteFull         iwdevices.txt  pppOn.sh
```

If the device does not have the wifiTest file, please contact Quake Global.

The HPRO-4G will only be tested for the 2.4 GHz band, the following instructions are for continuous test:

This script should **only be run once**. Navigate to the 'root' directory (default location after login/pass). For general transmit functions, from the # prompt:

Type the following:

- **./wifiTest inter**
 - **start**
 - **cOn**
1. Enter "**cCh X Y Z**" where **X** is the channel, **Y** is the band, **Z** is the bandwidth [SEE EXAMPLE BELOW FOR REFERENCE]
 - a. For the selection of low/mid/high channels, type the bolded text below:
 - To select Low Channel: **cCh 1 0 0**
 - To select Mid Channel: **cCh 6 0 0**
 - To select High Channel: **cCh 11 0 0**
 2. Enter "**cPow X Y**" where **X** is the power set, **Y** is for the antenna selection, range is 0-3, 0 is Auto, 1 for Ant1, 2 for Ant2 and 3 for both.
 - a. This **only needs to be configured once**, the power range is in 0-20000 where 20000 is 20 dBm, for this setting go use the command:
 - i. **cPow 16500 0**
 3. Enter "**cTxOn X Y**" where **X** is the rate 11b/g/n and **Y** is the BW (20 or 40 MHz)
 - a. Lowest setting for 2.4 GHz band is 11b 1 MBPS
 - i. **cTxOn 0 0**
 4. Enter "**cTxOff**" to turn off the transmitter.

To setup for next configuration: Return to **step 1**

To change channels: Go to **step 1** then skip to **step 3** to transmit, if power output is to remain the same.

Condensed version with an example of the output:

Low Channel:

```
linux prompt>>./wifiTest inter
```

```
>start
>cOn
>cCh 1 0 0
>cPow 16500 0
>cTxOn 0 0
```

EXPECTED OUTPUT:

```
Calibrator:: Starting TX Simulation (delay=200, rate=13, size=500, mode=0
data_type=0, BW=0, gi=1, opt1=0x0,
opt2=0x0
src=00:11:22:33:44:55
dst=01:02:03:04:05:06) ...
>cTxOff
```

Mid Channel:

```
linux prompt>>./wifiTest inter
```

```
>start
>cOn
>cCh 6 0 0
>cPow 16500 0
>cTxOn 0 0
```

EXPECTED OUTPUT:

```
Calibrator:: Starting TX Simulation (delay=200, rate=13, size=500, mode=0
data_type=0, BW=0, gi=1, opt1=0x0,
opt2=0x0
src=00:11:22:33:44:55
dst=01:02:03:04:05:06) ...
>cTxOff
```

High Channel:

```
linux prompt>>./wifiTest inter
```

```
>start
>cOn
>cCh 11 0 0
>cPow 16500 0
>cTxOn 0 0
```

EXPECTED OUTPUT:

```
Calibrator:: Starting TX Simulation (delay=200, rate=13, size=500, mode=0
```

```
opt2=0x0  
  
data_type=0, BW=0, gi=1, opt1=0x0,  
src=00:11:22:33:44:55  
dst=01:02:03:04:05:06) ...  
  
>cTxOff
```

To change between channels:

```
linux prompt>>./wifiTest inter
```

```
>start  
>cOn  
>cCh 1 0 0  
>cPow 16500 0  
>cTxOn 0 0
```

EXPECTED OUTPUT:

```
Calibrator:: Starting TX Simulation (delay=200, rate=13, size=500, mode=0  
data_type=0, BW=0, gi=1, opt1=0x0,  
opt2=0x0  
src=00:11:22:33:44:55  
dst=01:02:03:04:05:06) ...
```

```
>cTxOff  
>cCh 6 0 0  
>cTxOn 00
```

EXPECTED OUTPUT:

```
Calibrator:: Starting TX Simulation (delay=200, rate=13, size=500, mode=0  
data_type=0, BW=0, gi=1, opt1=0x0,  
opt2=0x0  
src=00:11:22:33:44:55  
dst=01:02:03:04:05:06) ...
```

For antenna locations, see it marked in red on the top cover of the device:




4.4 BT testing

- Open Ethernet port on Tera term, by clicking on file , then click new connection.

1)Host:[root@192.168.35.10](#) and service : SSH

2)Click ok



3)User Name: **root**

4)password:**certs**

If connection is failing type on TeraTerm serial: **ifup - a**
Return to ethernet window and repeat steps 1 and 2

Type:

- **cd /usr/share/wl18xx/**
- **./btup.sh**
- **./bt_test.sh -c 1 -t**

This will start a Bluetooth transmit test in channel 1, bt_test is a bash script with the following options:

Usage: **./bt_test.sh -c [channel] [-t] [-r]**

Bluetooth Transmit on 2.4GHz:

- c channel select (0-78)**
- t transmit**
- r receive**
- h help menu**

This will ensure that all radio devices are on a continuous transmit state, the cell module will be connected to a call box.

CONFIDENTIALITY OBLIGATIONS

This document contains sensitive information and is classified “**CONFIDENTIAL**”.

Its distribution is subject to the recipient’s signature of a Non-Disclosure Agreement (NDA).

At all times you should comply with the following security rules (Refer to the NDA for detailed obligations):

This document may not be altered in any way that removes or obscures the Confidentiality notices.

Keep this document locked away.

Additional copies can be provided on a “need to know basis”, please contact your QUAKE account manager.

Please read carefully:

Information in this document is provided solely in connection with Quake Global, Inc. (“QUAKE”) products. QUAKE™ reserves the right to make changes, corrections, modifications or improvements to this document and the products and services described herein at any time, without notice.

All QUAKE products are sold pursuant to QUAKE’s terms and conditions of sale. Purchasers are solely responsible for the choice, selection and use of QUAKE products and services described herein, and QUAKE assumes no liability whatsoever relating to the choice, selection or use of QUAKE products and services described herein. No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted under this document. If any part of this document refers to any third-party products or services, it shall not be deemed a license grant by QUAKE for the use of such third-party products or services, or any intellectual property contained therein or considered as a warranty covering the use in any manner whatsoever of such third-party products or services or any intellectual property contained therein.

UNLESS OTHERWISE SET FORTH IN QUAKE’S TERMS AND CONDITIONS OF SALE, QUAKE DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY WITH RESPECT TO THE USE AND/OR SALE OF QUAKE PRODUCTS INCLUDING, WITHOUT LIMITATION, IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE (AND THEIR EQUIVALENTS UNDER THE LAWS OF ANY JURISDICTION), OR INFRINGEMENT OF ANY PATENT, COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHT. UNLESS EXPRESSLY APPROVED IN WRITING BY AN AUTHORIZED QUAKE REPRESENTATIVE, QUAKE PRODUCTS ARE NOT RECOMMENDED, AUTHORIZED OR WARRANTED FOR USE IN MILITARY, AIRCRAFT, SPACE, LIFE SAVING OR LIFE SUSTAINING APPLICATIONS, NOR IN PRODUCTS OR SYSTEMS WHERE FAILURE OR MALFUNCTION MAY RESULT IN PERSONAL INJURY, DEATH OR SEVERE PROPERTY OR ENVIRONMENTAL DAMAGE.

Resale of QUAKE products with provisions different from the statements and/or technical features set forth in this document shall immediately void any warranty granted by QUAKE for the QUAKE product or service described herein and shall not create or extend in any manner whatsoever, any liability to QUAKE.

QUAKE™ and the QUAKE logo are registered trademarks of Quake Global. Information in this document supersedes and replaces all information previously supplied.

© 2022 QUAKE GLOBAL, INC. - All rights reserved

www.quakeglobal.com