

Product Name: CT101
Document Title: CT101 Install Guide
Document Type Code: IBIE
Part Number: 1202-003-002

18jun12 hl edits mtf
15jun12 hl edits mtf
31may12 edits hl mtf
14feb12 edits ch mtf
13feb12 initial release mtf
check phone # and web address

Blank page remove
before binding

Install Guide CT101




Radio Thermostat Company of America

⚠ Caution

- Your thermostat is a precise instrument, handle it with care.
- Turn off electricity to the HVAC system before installing or servicing thermostat or any part of the system.
- Do not turn electricity back on until work is completed.
- Do not short (jumper) across electric terminals at the control on the furnace or air conditioner to test the system. This may damage the thermostat.
- All wiring must conform to local codes and ordinances.
- This thermostat is designed for use with 4AA alkaline batteries and/or 24 volt AC C wire (or a 12-24 AC or DC source) and millivolt gas systems. Each thermostat relay load should be limited to 1.0 amp; higher amperage may cause damage to the thermostat.

⚠ Caution

To avoid electrical shock and to prevent damage to the furnace, air conditioner, and thermostat, **disconnect the power supply** before beginning work. This can be done at the circuit breaker.



TOOLS

You will need a small Phillips screwdriver and a drill with 3/16-in. (4.8mm) bit for wall mounts.


LOCATION

Replacement installations - mount the CT101 in place of the old thermostat.

A new location will require moving your wiring.

For new installations and relocating the CT101 - follow the guidelines listed below:

- Locate the thermostat on an inside wall, about 5 ft. (1.5m) above the floor, and in a room that is used often.
- Do not install it where there are unusual heating conditions, such as: in direct sunlight; near a lamp, radio, television, radiator register, fireplace; near hot water pipes in a wall; or near a stove on the other side of a wall.
- Do not locate in unusual cooling conditions, such as: on a wall separating an unheated room; or in a draft from a stairwell, door, or window.
- Do not locate in a damp area. This can lead to corrosion that will shorten thermostat life.
- Do not locate where air circulation is poor, such as: in a corner, an alcove; behind an open door.
- Do not install the CT101 until all construction and painting has been completed.
- This thermostat does not require leveling.



REMOVE OLD UNIT

⚠ Switch OFF electricity to the HEATING and COOLING systems.


Then follow these steps:

- Remove cover from old thermostat. Most are snap-on types and simply pull off. Some have locking screws on the side or front. These must be loosened. DO NOT remove wires. Note the letters printed near the terminals. Attach labels (enclosed) to each wire for identification.

⚠ Caution

Read instructions carefully before removing any wiring from existing thermostat. Wires must be labeled before they are removed. THERE IS NO STANDARD COLOR CODE. When removing wires from their terminals, ignore the color of the wires and LABEL THEM by the lettered terminal where they were screwed.

- Label the wires one at a time. You must label all the wires before you proceed.
- With all wires labeled, remove them from the old unit.
- Make sure the wires do not fall back inside the wall. You can wind them around a pencil to keep them from falling.
- Loosen all screws on the old thermostat and remove it from the wall.




What wires do you have?

Make sure your wires are labeled. This may require you to find the 'other end' connection for each wire on your heating or air conditioning equipment and read the label there. Refer to the Wire Reference page at end of install section for better understanding of wire labels from different HVAC system makers.

⚠️ IMPORTANT: The CT101 runs on 4 AA alkaline batteries and/or the C wire if available. If you do not have a C wire you can run a new wire from the HVAC or use a standard 12-24V [AC or DC] wall transformer. A constant power source is required when using a radio module.

⚠️ IMPORTANT: If you have both RH and RC you need to remove the jumper wire between these 2 terminals.


Prepare Wires




Wire Terminals

Please follow these guidelines for safe and secure wire connections:


- You will need at least 2.6" of wire for each of your connections to the CT101.
- If you do not have enough wire, splice additional wire to allow enough slack.
- Terminals accept wires from 16-22awg.
- Fan out wires below the hole as shown.
- Remove insulation 1/8" from the tip of each wire.
- When handling, take care not to damage the labels for each wire.




Find the step-by-step diagram for your system




Go To Page 13



Go To Page 13



Go To Page 14




Go To Page 14


- Select the reference page with your wiring diagram and set-up information below.

- The C-wire is optional but preferred for all installations [shown dotted in diagrams].


- Hot Water systems accessories are on Page 16



Go To Page 15



Go To Page 15



Go To Page 16

- If your combination of wires is not above you can use the wiring table at the end if the install section to determine your connections, contact customer support for help.

- “Fan out” wires as illustrated with CT101 below the wall opening. As in the example: fan out the wires so that the C wire is above the C terminal, the W above the W. This allows the CT101 to fit snug to the wall.

⚠ Caution

Do not allow wires to touch each other or parts on thermostat.


- Position the Wires behind the CT101 and up over the terminal area.
- Do not bunch wires behind the CT101. Feed any slack back into the wall opening.

Connect Your Wires

- Connect labeled wires only to a terminal with the same letter label.
- Insert the wire in the terminal well and tighten the screw securely.




NOTE: If you wish you can mount the CT101 to the wall first, and then connect the wires.

- The CT101 can be externally powered with a power source rated from 12V to 24V, AC or DC, at 300ma or greater. If used, connect to the C and RH terminals (no polarity).



Mount the CT101 to Wall


1. Hold the CT101 against the wall, with the wires coming over the top; above terminal block. The CT101 will cover the hole in the wall.
2. Position CT101 for best appearance.
3. Attach the CT101 to the wall with the screws provided.
4. If you are mounting the CT101 to sheet rock or if you are using the old mounting holes, use the plastic anchors provided.
5. Mark first and drill a 3/16-in.(4.8mm) hole for the insert at each screw location, then mount the unit.



Screw to wall

HVAC Selection


- Set the **HVAC TYPE** switch in the **NORM** position if you have conventional natural gas, propane, oil, or electric heat. If you have a HEAT PUMP system set the **HVAC TYPE** switch to **HP**. They are located in the battery compartment.
- Set the **HEAT TYPE** switch in the **GAS** position if you have normal gas or oil heat or if you have a heat pump with gas or oil auxiliary heat. Put the **HEAT SOURCE** in the **ELEC** position if you have normal electric heat or if you have a heat pump with electric auxiliary heat.



Install 4 AA Batteries

- Install 4 AA alkaline batteries [required] following the marked polarity in the battery compartments. Put the battery in negative end first against the spring, then push the positive end in.

▲ IMPORTANT: Press the RESET button (under top cover) to implement the HVAC switch selections.



- With all the wires connected it is time to turn the AC power back on. Do this at the breaker you used to switch it off. The CT101 will power-up in the OFF mode. Your CT101 is not configured to operate your HVAC system yet. You must now configure your thermostat for your HVAC system.

! Caution

Special Thermostat Battery Cautions

Always replace the batteries as soon as the “Low Batt” flashes. The thermostat is a battery powered device. You must be responsible to replace batteries before they run out. Failure to replace batteries can result in overheating or excessive cooling of your house.

- Even if the “Low Batt” indicator does not flash, you should always replace the batteries at least once a year. Replacing the batteries also helps to prevent leakage that can corrode and damage the thermostat.
- If you are leaving your home for a month or more, you should replace the batteries as a precaution against battery failure in your absence.
- Always use new alkaline batteries.
- Failing to replace the batteries, when necessary, could cause the thermostat to lose power or malfunction. If the thermostat loses power, then the thermostat will not control the temperature which could result in your HVAC system not functioning as you intended and lead to possible damage from overheating or excessive cooling.
- If the thermostat batteries fail with the heat OFF, this can result in NO HEAT and possible frozen or broken pipes and water damage.
- If the thermostat batteries fail with the cool OFF, this can result in NO COOL and could cause possible damage or excessive temperatures.

BATTERY WARNING

Do Not Mix Old And New Batteries.


Do Not Mix Alkaline, Standard (Carbon - Zinc),
Or Rechargeable (Nickel - Cadmium) Batteries

DO NOT DISPOSE OF BATTERIES IN FIRE. BATTERIES
MAY EXPLODE OR LEAK.

HVAC Setup on Screen

⚠️ IMPORTANT: Make sure the CT101 is powered up and the mode is set to OFF. HVAC selection switches must be set first [pg 8].

- With mode in OFF press MENU and touch HVAC SET UP.
- Use +/- icons to select HVAC SET UP number on screen. The LCD display will show your selection and indicate the number of stages you have selected. During setup, 2nd stage will blink when both heat and cool have 2nd stages.



If you have a Normal HVAC system and you want fast temperature recovery...

- HEAT and COOL select 1
- 2 stage HEAT, 1 stage COOL select 2
- 1 stage HEAT, 2 stage COOL select 3
- 2 stage HEAT, 2 stage COOL select 4

If you have a HEAT PUMP HVAC system...

- HEAT PUMP with no AUX heat select A
- 2stage HEAT PUMP with no AUX select b
- HEAT PUMP with AUX heat select C
- HEAT PUMP with 2stage AUX heat select d
- 2stg HEAT PUMP with AUX heat select E
- 2stg HEAT PUMP with 2stg AUX heat select F

⚠️ Caution

Do not change the HVAC setup or HVAC selection switches if the thermostat is included to Z-Wave network. The HVAC system must be changed, first EXCLUDE the thermostat from the network, change the HVAC setup, and INCLUDE the thermostat to the network.

Test Installation

Follow these procedures to verify you have correctly installed the CT101.

TO CHECK FAN (If you connected the G wire):

Touch the fan icon on the HOME screen to turn the fan **ON**.

Verify that air is blowing from the system.

Touch the fan icon again to return to **AUTO**.

TO CHECK HEAT

Set the mode to **HEAT** by pressing the MODE button until **HEAT** is displayed.

Touch the temperature display to bring up the MANUAL screen.

Touch the **+** icon and raise the target temp to 90°F; allow the system 2 minutes to respond.

Verify that heat is blowing from the system. Return the Target Temperature to a nominal setting. Return mode to **OFF** by pressing the mode button.

If you have a heat pump, leave it off for 4 minutes before checking COOL.

TO CHECK COOL (do not operate AC if the outside temp is below 65°F)


Set the mode to **COOL** by pressing the MODE button until **COOL** is displayed.

Touch the **-** icon and lower cool Target Temperature to 50°F.

Allow the system 5 minutes to respond.

Verify that cool air is blowing from the system.

Return mode to **OFF** by pressing the mode button.




Congratulations, you have successfully installed your unit. Please proceed to the OPERATING Guide to initialize the CT101.

▲ IMPORTANT: If you have labeled and connected your wires and followed the correct HVAC setup, and your system still does not operate, contact technical support.

STATEMENT OF USE: This thermostat can be used with 4AA batteries, 24VAC (C wire), 24VAC adapter, heating and cooling systems and also millivolt heating. It cannot be used with line voltage systems. This thermostat is digital and your desired heat or cool temperatures can easily be set on the large touch screen with the +/- buttons. A minimum 4 minute off time protects the compressor from damage.

This thermostat runs on 4AA batteries. The CT101 can be externally powered with a power source rated from 12V to 24V, AC or DC, at 300ma or greater. If used, connect to the C and RH terminals (no polarity). The 24VAC "C" wire is the other side of the 24VAC heating transformer and can be found where the other thermostat wires connect at the wall or at the furnace. Do not use the common or ground side of the line voltage.



Step-by-step wiring diagrams

WIRES
C W RH

3 Wire Heat GAS MILLIVOLT or 24VAC system


STEP 1 - Connect the R (or RH) wire to the RH terminal. This connects the heat power.

STEP 2 - Connect the W wire to the W terminal. This connects the heat.

STEP 3 - Connect the C wire to the C terminal. Your heater is now connected to the CT101.



Please Go To Page 6



WIRES
C W RH G

4 Wire Heat

STEP 1 - Connect the R (or RH) wire to the RH terminal. This connects the heat power.


STEP 2 - Connect the W wire to the W terminal. This connects the heat.

STEP 3 - Connect the G wire to the G terminal on the thermostat. This connects the fan.

STEP 4 - Connect the C wire to the C terminal. Your system is now connected to the CT101.



Please Go To Page 6



WIRING

5 Wire Heat/Cool

STEP 1 - Connect the W wire to the W terminal. This connects the heat.

STEP 2 - Connect the Y wire to the Y terminal. This connects the cooling compressor.

STEP 3 - Connect the RH or R wire to the RH terminal. This connects the power.


STEP 4 - Connect the G wire to the G terminal on the thermostat.

This connects the fan.

STEP 5 - Connect the C wire to the C terminal.

Your HVAC system is now connected to the CT101.

← Please Go To Page 6



WIRING

6 Wire HEAT/Cool

STEP 1 - Connect the W wire to the W terminal. This connects the heat.

STEP 2 - Connect the Y wire to the Y terminal. This connects to the cooling compressor.

STEP 3 - Disconnect the Rc and Rh terminals by placing the Rc-Rh switch in the UP position.

STEP 4 - Connect the RH wire to the RH and the RC wire to the RC terminals. This connects power.

STEP 5 - Connect the G wire to the G terminal. This connects the fan.

STEP 6 - Connect the C wire to the C terminal.


Your HVAC system is now connected to the CT101.

← Please Go To Page 6

WIRING

Multi-stage Heat and Multi-stage Cool

The CT101 can handle up to 2 stages of HEAT and 2 stages of



COOL.

STEP 1 - Connect the W, W2 wires to the W terminals.

This connects the stages of HEAT.

STEP 2 - Connect the Y and Y2 wires to the Y terminals.

This connects the stages of COOL.

STEP 3 - STEP 5 - Connect the RH or R wire to the RH terminal.

This connects the power.


STEP 4 - Connect the G wire to the G terminal.

This connects the fan.

STEP 5 - Connect the C wire to the C terminal.

Your HVAC system is now connected to the CT101.

← Please Go To Page 6



Wires: **C B or O Y R G**

4 Wire Heat Pump (heat/cool) without Auxiliary Heat

STEP 1 - Connect O wire to the O terminal or B wire to the B. This connects the change-over valve.

If you have both O and B - connect only the O wire to the O terminal and DO NOT connect B to B terminal (see wire reference under Trane for B wire terminal).

STEP 2 - Connect the Y wire to Y terminal. This connects the compressor.

STEP 3 - Connect the R wire to RH. This connects the power.

STEP 4 - Connect the G wire to the G. This connects the fan.


STEP 5 - Connect the C wire to the C terminal.

Your HVAC system is now connected to the CT101.

← Please Go To Page 6

Wires: **C O or B AUXn Yn RH G**

Multi-stage Heat Pump with Multi-stage



Aux Heat

The CT101 can handle up to 2 stages of Pump compression and 2 stages of AUX heat.

STEP 1 - Connect O wire to the O terminal **or** B wire to the B. This connects the change-over valve.

If you have both O and B - connect only the O wire to the O terminal and DO NOT connect B to B terminal (see wire reference under Trane for B wire terminal).

STEP 2 - Connect the AUX 1, AUX 2, to the AUX 1 and 2 respectively.

This connects the auxiliary heat.

STEP 3 - Connect the Y and Y2 wires to the Y terminals.

This connects the compressor.

STEP 4 - Connect the R wire to RH terminal. This connects the power.


STEP 5 - Connect the G wire to G terminal. This connects the fan.

STEP 6 - Connect the C wire to the C terminal.

Your HVAC system is now connected to the CT101.



Please Go To Page 6




Accessory Wiring -


Zoned Hot Water Heat -

For Solenoid valve or Motor valve connect the wires based on diagrams below to the correct terminal on the CT80. USE ONLY IN HEAT MODE. The third wire on your valve may be called 6, Y, or G (see page 18). As always the CT80 must be powered by 24vac

FOR 3WIRE ZONED
HOT WATER



MOTOR VALVE



SOLENOID VALVE

Wire Reference Table

Possible Wires What They Control

R or V or VR	RH and RC Single power for HEAT and COOL
RH or 4	RH Power for HEAT (RH not connected to RC jumper clip removed)
RC	RC Power for COOL (RH not connected to RC jumper clip removed)
W	W Heat control
W2	W2 2nd stage HEAT or heat pump auxiliary heat
W3	W3 3rd stage HEAT or 2nd stage of 2 stage auxiliary heat
Y	Y COOL control or 1st stage compression for heat pump
Y2	Y2 2nd stage COOL control or 2nd stage compression for a heat pump
G or F	G FAN control
C or X	C 24VAC power (to power thermostat) NOTE: TRANE uses B for this connection
H	H External Humidifier
DH	DH External De-Humidifier
EX	EX external fresh air baffle
B	B Heat pump changeover (cool to heat, powered in heat)
O	O Heat pump changeover (heat to cool, powered in cool)
B and O	⚠️ IMPORTANT: If there are both B and O wires (Trane pump products) DO NOT CONNECT B to B terminal, connect B to C terminal. If not a Trane product tape off B .
E	n/a Emergency heat (do not connect, tape off)
L	n/a System monitor (do not connect, tape off)
T	n/a Outdoor sensor (do not connect, tape off)

Wire Reference cont.

<i>Possible Wires</i>	<i>What They Control</i>
Lennox Heat Pump	
V or VR or R	RH Power for HEAT
M or Y	Y COOL control
Y or W or W2	W2 2nd stage HEAT
F or G	G Fan control
R or O	O
X or X2 or C	C

Trane Products [American Standard]

B C 24VAC power (to power thermostat)

W or W1 W2 2nd stage HEAT

X2 Emergency heat (do not connect, tape off)

3 Wire

Solenoid Valves

R

RH (power)

W

A (heat ON)

Y or G (the 3rd wire)

W (heat OFF)

Zoned Hot Water

2 wire

Your Wires Thermostat Terminal

R RH

W

3 Wire

Motor Driven Valves

R or 5 RH (power)

W or 4 W (heat ON)

Y or G or 6 (the 3rd wire) A (heat OFF)

FCC Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

BATTERY WARNING

Do Not Mix Old And New Batteries.

Do Not Mix Alkaline, Standard (Carbon - Zinc), Or Rechargeable (Nickel - Cadmium) Batteries

DO NOT DISPOSE OF BATTERIES IN FIRE. BATTERIES MAY EXPLODE OR LEAK.