

MAGNASTAR C-2000 DIGITAL AIRBORNE TELEPHONE SYSTEM**7.0 PROGRAMMING THE MAGNASTAR SYSTEM****7.1 HANDSET CONFIGURATION SCREENS**

This section provides detailed information in support of the C-2000 user guide to help the installer with the configuration programming of the MagnaStar system. Included in this section are a flow chart of the maintenance set-up screens and descriptions of the handset set-up screens. These screens apply to ARTU software version ARTCC40B.

7.1.1 CONFIGURATION SCREEN FLOW CHART

A flow chart of the MagnaStar maintenance screens is shown in this section. The flow chart is intended to provide a reference guide to help the installers quickly find the location of individual configuration screens. The flow chart includes both the set-up maintenance screens and the aircall screens.

MAGNASTAR C-2000 DIGITAL AIRBORNE TELEPHONE SYSTEM




Figure 7.1.1.A. Configuration Screen Flow Chart

MAGNASTAR C-2000 DIGITAL AIRBORNE TELEPHONE SYSTEM




Figure 7. .B. Configuration Screen Flow Chart con't.

MAGNASTAR C-2000 DIGITAL AIRBORNE TELEPHONE SYSTEM




Figure 7.1.1.C. Configuration Screen Flow Chart con't.

MAGNASTAR C-2000 DIGITAL AIRBORNE TELEPHONE SYSTEM

7.1.2 DETAILED CONFIGURATION SCREENS

The following section provides information about the individual configuration screens. This section is intended to provide the installer with a visual reference to the configuration screens and is supplemental information to the user guide. However it is not intended as a replacement for the user guide.

7.1.2.1 Services Screen

The following screen is the Services screen. Whenever a digital handset is in the "on-hook" configuration, the following screen will be displayed. This screen displays the calling feature that the system is configured to support; i.e. including Inplane, Air-to-Ground, GroundCell, SATCOM or HF Radio. The current default link will be highlighted. This screen may also display the text "Messages" to indicate that there are aircall number(s) stored in memory. The inplane, station aircall and station terminal ID numbers may also be displayed on the Services screen.

```

Services
Inplane
Air-Ground
GroundCell
Satcom
HF Radio
-----
Messages
Inplane: ____
TermID: ____
      (____)
      ____-____
  
```

7.1.2.2 Main Menu

Taking the handset "off-hook" will place the user at the main menu screen. The main menu screen provides the user with all the calling options. Additionally, the set-up and aircall options are reached from the main menu.

A digital handset has a built in Hall Effect switch which is activated by a magnet. If a digital handset is taken out of a holder that is equipped with a magnet, then the main menu screen will appear after five seconds. However, during this five second period the main menu screen is active and numbers or functions can be selected even though the screen may not have changed. If a digital handset holder does not have a magnet, the handset must be taken "off-hook" by pressing the "+" key.


```

Air-Ground
Voice --->1
Inplane ->2
FAX ----->3
Modem --->4
Satcom -->6
HF Radio >7
Aircalls >8
Setup --->9
GTE Oper >0
Spd Dial >*
  
```

MAGNASTAR C-2000 DIGITAL AIRBORNE TELEPHONE SYSTEM


7.1.2.3 Checking Handset Setup Information Screens

The following screen progressions show how to check the handset "setup" information. These screens do not require the user to start a maintenance session.



7.1.2.4 Starting a Maintenance Session

The following screen progressions show how to establish a "maintenance session". A maintenance session is required to perform any changes to a handset or the system configuration. The passcode can be installation dependent. The factory default passcode is 0000.



MAGNASTAR C-2000 DIGITAL AIRBORNE TELEPHONE SYSTEM

7.1.2.5 Maintenance Screen #1

The first maintenance screen allows the user to change the passcode, change the billing mode, enter handset phone numbers (inplane, aircall and terminal ID's), enter speed dial numbers *510 -*549 and change the AIU setup.

```

Passcode
Change >1
Charge
Direct >2
Credit >3
Phone # >4
Speed Dial
Setup ->*
Delete >5
AIU ---->6
More ---->+
Main ---->#
    
```

7.1.2.5.1 Changing the Passcode and Billing Mode

The billing mode appears below the passcode change selection. The current value for the billing mode, either Direct or Credit, is highlighted. To change the billing mode, select the appropriate number. The selection will be verified by a change in the highlighted option type.

The following screen progressions show how to change the passcode. The system does not ask for reverification of the passcode once "+" has been entered for OK.

```

Passcode
Change >1
Charge
Direct >2
Credit >3
Phone # >4
Speed Dial
Setup ->*
Delete >5
AIU ---->6
More ---->+
Main ---->#
    
```

Select
1
-->

```

Please
Enter
Your
New
Passcode
_____

OK ---->+
Clear -->*
    
```

Enter a new
passcode.

Then enter

```

We cannot
process
your
request at
this time.

Invalid
Passcode
    
```

This is the
screen that
will appear
if an invalid
passcode is
entered when
starting a
maintenance
session
<---

MAGNASTAR C-2000 DIGITAL AIRBORNE TELEPHONE SYSTEM

7.1.2.5.2 Inplane Numbers

The following screen progressions show how to enter an inplane number and corresponding label. Inplane numbers are used to make seat to seat calls. Inplane numbers can vary from 0-9 and an eight character label can be associated with each inplane number.

```

Passcode
Change >1
Charge
Direct >2
Credit >3
Phone # >4
Speed Dial
Setup ->*
Delete >5
AIU ---->6
More ---->+
Main ---->#
    
```

Select
4
-->

```

Inplane >1
Aircall >2
Satcom ->3

To Disable
Call
Waiting >4

Go Back >#
    
```

Select
1
-->

```

Available
Inplane
Numbers

>1 >2 >3
>4 >5 >6
>7 >8 >9
>0

More ---->+
Go Back >#
    
```

Select an inplane number from the available list. The selected number will be highlighted

Select + to enter an inplane label

Enter Label

Press * to move Cursor.

Press # when finished.

```

You may
enter an 8
character
label.

^

Cursor ->*
OK ---->#
Help ---->0
    
```

Press 0 for a help screen
---->

```

Press '5'
to pick a
character
list.

Press '6'
or '4' to
move up or
down the
list.

Go Back >#
    
```

There are four character lists (A,a,0, /) from which to choose.

MAGNASTAR C-2000 DIGITAL AIRBORNE TELEPHONE SYSTEM

7.1.2.5.3 Aircall Numbers

The following screen progressions show how to enter an aircall number. The procedure to enter a station or aircraft aircall number are the same. A station aircall number applies only to the associated handset that the aircall number is programmed. An aircraft aircall number applies to all the handsets in system. The installer must know the aircall PIN number in order to enter this number. The aircall PIN will only be valid for a particular aircall number. Aircall and associated PIN numbers must be obtained from GTE Airfone. An error screen is shown if an invalid aircall PIN number is entered. The screen progressions also show how to cancel an aircall number. An aircraft aircall number is a system function and need only be programmed from one handset.

```

Passcode
Change >1
Charge
Direct >2
Credit >3
Phone # >4
Speed Dial
Setup ->*
Delete >5
AIU ---->6
More ---->+
Main ---->#
    
```

Select
4
-->

```

Inplane >1
AirCall >2
Satcom -->3

To Disable
Call
Waiting >4

Go Back >#
    
```

Select
2
-->

```

Aircalls
Station >1
Aircraft
----->2
Cancel
Aircalls
Station >3
Aircraft
----->4

More ---->+
Go Back >#
    
```

Select Aircraft or Station to enter an aircall number.

Select Aircraft or Station to cancel an aircall number.

```

Pass Your
Airfone
Calling
Card Thru
Slot on
Right

Keypad
Entry ->+
Exit ---->#
    
```

Select
+
for
keypad
entry
-->

```

Enter Your
AirCall
Number

(212)
429-0000

OK ---->+
Clear -->*
    
```

Enter
aircall
number.

Press
+
-->

```

Please
Enter
Your
PIN

0175

OK ---->+
Clear -->*
    
```

Enter
PIN
number

Press
+
-->

```

Station
AirCall
Number
Updated.

Registered
to receive
messages
from the
ground.
    
```

This screen shows the results when an invalid PIN number is entered. -->

```

Card
Invalid

Pass Card
thru
Slot -->

Keypad
Entry ->+
Exit ---->#
    
```

This screen shows the message displayed after an aircall number is cancelled. -->

```


Station
AirCall
Number
Cancelled.

No longer
registered
to receive
messages
from the
ground.
    
```

MAGNASTAR C-2000 DIGITAL AIRBORNE TELEPHONE SYSTEM

7.1.2.5.3.1 Disabling a Handset From Ringing with an Aircraft Aircall Number

It is possible to disable any number of individual handsets from ringing (including the CAS output) when an aircraft aircall number is programmed in the system. Each handset that is not to respond to an aircraft aircall number must be programmed as such. The following screen progressions show the steps necessary to cancel an aircraft aircall response from an individual handset.



7.1.2.5.3.2 Direct Call Pickup

It is possible to configure the MagnaStar system for direct pickup of calls to the aircraft. A direct call pickup will automatically dial the ground party when the handset is taken off hook. The following screen progressions shown are for the direct call pickup feature. The Direct Call Pickup is a system function and need only be programmed from one handset.

