

Table of Contents

1. General Information	4
1.1 Introduction	4
1.2 Reader/Controller Types	4
1.3 Box Content	5
1.4 Ancillary Equipment	5
2. Technical Specifications	7
2.1 Key Features	8
Reader	9
Controller	9
3. Installation	10
3.1 Mounting the AYC- F/G/M60	10
4. Wiring Instructions	11
5. Reader Functionality	14
5.1 Transmit Mode	14
5.2 Programming the AYC-F/G/M60 Series	14
Programming Menu	15
Entering Programming Mode	16
Exiting Programming Mode	16
Selecting Keypad Transmission Format	16
Keypad Transmission Format Option Number	17
Selecting Proximity Card Transmission Format	22
Changing the Programming Code	25
Changing the Facility Code	25
Setting the Backlight and Format the Reader	26
Return to Factory Default Settings	26
Replacing a Lost Programming Code	27
6. Controller Functionality	28
6.1 Normal, Secure, and Master Users	28
Normal User	28
Secure User	29
Master User	29
6.2 Modes of Operation	29
Normal Mode	29
Bypass Mode	29
Secure Mode	30

Changing the Modes of Operation	30
6.3 Auxiliary Input & Output	31
6.4 Door Alarms.....	31
6.5 Internal Case and Back Tamper.....	32
6.6 Lockout Feature (Keypad / Card Tamper).....	32
6.7 Request to Exit (REX) Function.....	32
6.8 Secure Application Appurtenances.....	33
6.9 Programming the AYC- F/G/M60.....	33
Programming Menu.....	34
Entering Programming Mode.....	34
Exiting Programming Mode.....	35
Changing Lock Strike Code	35
Changing Auxiliary Code.....	36
Changing the Programming Code	37
Changing the Normal / Secure Code.....	37
Changing the Normal / Bypass Code and Door Chime Settings.....	38
Setting Fail Safe/Secure Operation, Tamper Siren and Lock Strike Release Time.....	39
Second Digit	39
Third and Fourth Digits	39
Defining the Auxiliary Input and Output	40
Auxiliary Mode.....	40
Auxiliary Settings	40
Quick Reference Guide for Auxiliary Mode Setting.....	41
Detailed Reference Guide	42
Setting the Lockout Feature	46
Setting the backlight behavior and format the reader.....	47
Enrolling Primary and Secondary Codes.....	47
Deleting Primary and Secondary Codes.....	51
Relay Codes Assignment.....	53
Relay Code Assignment using Search Method	54
Pin Code Length / Factory Default Settings.....	55
Replacing a Lost Programming Code	56
Replacing a Lost Normal / Secure Code	56
Appendix A. Limited Warranty.....	57
Appendix B. Technical Support	60

1. General Information

1.1 Introduction

The AYC-F/G/M60 series is a vandal-resistant, waterproof, standalone, convertible integrated reader and controller. The AYC-F/G/M60 series automatically determines whether to function as a reader or as a controller. If the unit is connected to a standard access control unit, then it functions as a reader. If the unit is connected to Rosslare's secure application appurtenances such as the PS-A25T, PS-C25T or PS-C25TU, it functions as a secured controller.

For information on how the unit functions as a reader, see Reader Functionality on page 14. For information on how the unit functions as a controller, see Controller Functionality on page 28. All of the units are water resistant and suitable for indoor or outdoor mounting. As a controller, the units accept up to 500 users, and allow entry via a personal identification number (PIN) and/or by presenting a proximity card. The pin code length for the controller has several options. The pin code length can be a set number of 4, 5 or 6 digits or it can be a 4-8 digits option. This manual contains the following information: Installation, Wiring instructions, and Operation Instructions.

1.2 Reader/Controller Types

The different types of units of this series are:

- Type 54 has PIN only
- Type 60 has PIN and Proximity card

	Backlight	Keypad Type	Proximity
AYC-F/G/M54	✓	Standard	✗
AYC-F/G/M60	✓	Standard	✓

Upon power-on reset, the AYC-F/G/M60 searches for the presence of Rosslare's secure application appurtenances. If a secure application appurtenance is detected, then the AYC-F/G/M60 is automatically configured as a secure access control unit. This is indicated by two short beeps. If the secured controller is not detected, it is automatically configured as a reader, indicated by one short beep.

1.3 Box Content

Before beginning verify that all of the following is in the box. If anything is missing, please report the discrepancy to your nearest Rosslare office.

- One AYC- F/G/M60 unit
- Installation kit
- Installation and operating instructions
- secure application appurtenance (optional for controller)

1.4 Ancillary Equipment

The following equipment is required to complete your installation:

Reader

- **Compatible host controller (not supplied)** - UL listed access control unit, i.e., model AC-215U

Controller

- **Secure Application Appurtenances**
such as the PS-A25T, PS-C25T or PS-C25TU secure controllers

This unit connects to the following:

- Electric lock strike mechanism or a magnetic lock device, which implements fail safe (power to lock) or fail secure (power to open) functions.
- Request to Exit (REX) button—normally open type. Switch is closed when pressed.
- Door monitor switch.

Rosslare accessories can be found on www.rosslaresecurity.com.

Specifications**AYC- F/G/M60****Electrical Characteristics**

Power supply type	Linear type – recommended
Operating voltage range	5 - 16VDC (when used as a controller, provided by the secure application appurtenance)
Input current standby (12VDC)	105mA
Input current max (16VDC)	140mA
LED control input	Dry contact N.O.
Tamper output	Open collector, active low, 32mA max sink current
Cable distance to host controller	Up to 500ft (150 meters) using an 18AWG cable
Max proximity card read range*	1.77 inches (45mm)
Proximity card modulation	ASK/FSK at 125 KHz
Proximity card compatibility	EM/HID cards
Card Transmit format (Reader)	26-bit Wiegand, or Clock & Data
Keypad Transmit Format (Reader)	Programmable PIN code formats
LED indicators	Two tri-colored LEDs
Communication	Data1/C1, Data0/C2—open collector, 5V termination

Specifications

AYC- F/G/M60

Environmental Characteristics

Operating temp. range	-22 to 150° F (-30 to 65° C)
Operating humidity	0 – 95% (non-condensing)
Outdoor usage	Weather-resistant, meets IP-65, epoxy potted, suitable for outdoor use

Mechanical

Size (Height x Width x Depth)	F: 4.72 x 3 x 0.827 inches (120 x 76 x 21 mm) G: 5.39 x 1.73 x 0.83 inches (137 x 44 x 21 mm) M: XXXXXXXX (XXXXXX)
Weight	F: 1.05 lb (480g) G: 0.35 lb (160g) M: XXXXXX

*Measured using Rosslare proximity card (AT-14) or equivalent.
Range also depends on electrical environment and proximity to metal.

2.1 Key Features

The key features for the AYC- F/G/M60 series are:

- Built-In Proximity Card Reader (125 KHz ASK/FSK Modulation) (for 60 series only)
- Patented, programmable Blue backlit keypad
- Optical back tamper sensor and open controller tamper output.
- Lockout feature on wrong entry (Keypad / Card Tamper)
- Internal buzzer provides audible interface feedback
- Two status / programming Interface LEDs (tri-colored)
- Fully potted construction for outdoor use
- Comes with mounting template for easier installation
- Comes with an installation kit that includes a security screw and a security screw tool

Reader

- Programmable keypad transmission format
- LED control input
- Programmable facility code
- Programmable Proximity Card Transmission Format
 - Clock & Data
 - 26-Bit Wiegand
 - Card + PIN

Controller

- Bi-directional secure communication with Rosslares' secure application appurtenance
- Three User Levels
 - Normal User
 - Secure User
 - Master User
- "Code Search" feature that helps make maintaining user codes easier
- Three Modes of Operation
 - Normal Mode
 - Bypass Mode
 - Secure Mode
- Request-to-Exit (REX) signal from Rosslares' secure application appurtenance
- Chime Bell and Siren features are available with secure application appurtenance
- Programmable Lock Strike Release, Siren, and Alarm Delay timers
- Programmable Auxiliary input with versatile functions.
- Programmable Auxiliary output functions
- Programmable PIN code length.

3. Installation

3.1 Mounting the AYC- F/G/M60

Before starting, select the location to mount the AYC- F/G/M60. This location should be at shoulder height. Drill holes into the back of the unit according to how you want to mount the AYC- F/G/M60. For US Gang Box installation, there are two-hole indicators on the back of the metal cover specifically aligned for the US Gang Box (A, in diagram below). For a four screw custom installation, there are four indicators on the back (B in diagram below). [This is Q-box need F/G/M boxes drawings]




Figure 1 Drilling mounting holes

When the unit is used as a reader, route the interface cable from the AYC- F/G/M60 to the Controller. When the unit is used as a secured controller, route the interface cable from the AYC- F/G/M60 to Rosslares' secure application appurtenance.

A linear type power supply is recommended, when using the unit as a controller.

Screw the AYC- F/G/M60 back cover to its mounting location. Return the AYC- F/G/M60 front cover to the mounted back plate. Secure the front cover by using the supplied security screw in the controllers Installation Kit. An L-Shaped tool is provided for use when tightening the security screw.

4. Wiring Instructions

The unit is supplied with a 22-inch pigtail, having a 6-conductor cable. To connect the unit to the controller, perform the following: Prepare the unit's cable by cutting the cable jacket back 1¼ inches and strip the wire ½ inch. Prepare the controller cable by cutting the cable jacket back 1¼ inches and strip the wire ½ inch. Splice the unit's pigtail wires to the corresponding controller wires and cover each connection.

Refer to the wire color table below, and to the wiring diagrams provided on the following pages.

Reader	Controller	Color	Functionality
5~16 VDC	5~16 VDC	Red	+DC Input
Shield / Ground	Shield / Ground	Black	Ground
Data 1 / Clock	C 1	White	Communication
Data 0 / Data	C 2	Green	Communication
LEDCTL	AUX. IN	Brown	LED Control / Auxiliary Input
Tamper	Tamper	Purple	Tamper

If the tamper output is used, connect the purple wire to the correct input on the controller when used as a reader, or to a zone input of an intruder alarm system when used as a controller. Trim and cover all unused conductors.



Note:

- The individual wires from the unit are color-coded according to the Wiegand standard.
- When using a separate Power Supply for the Reader, this Power Supply and that of the Controller must have a common ground.
- The Reader's cable shield wire should preferably be attached to an earth ground, or a signal ground connection at the panel, or power supply end of the cable. This configuration is best for shielding the Reader cable from external interference

Wiring diagram #1 (below) shows the wiring for the Controller Application using a Dual Relay Secure Application Appurtenance.




Figure 2 Controller Application Wiring Diagram #1

Wiring diagram #2 (below) shows the auxiliary output connection using internal power.




Figure 3 Controller Application Wiring Diagram #2

Wiring diagram #3 (below) shows the auxiliary output connection using the external power.




Figure 4 Controller Application Wiring Diagram #3




Figure 5: Reader Application Wiring Diagram #4

5. Reader Functionality



The AYC- F/G/M60 series can function both as a reader and as a controller. If the unit is connected to standard access controller, it functions as a reader, indicated by one beep immediately after power-on reset.

The following explains how the AYC- F/G/M60 series functions as a reader.

5.1 Transmit Mode

When the AYC- F/G/M60 is in Transmit Mode, it is ready to receive data from a presented Proximity Card or an entered PIN code.

When the reader is in Transmit Mode, the Transmit LED is red and the Program LED is off.

Mode/Transmit			Door/Program
	Red		

When a Proximity Card or Keyboard entry is being transmitted, the Transmit LED will flash green.

Keyboard data can be sent via one of eight different Keypad Transmission Formats. For more information, see Selecting Keypad Transmission Format on page 16.

Proximity Cards presented to the reader are always sent in either 26-Bit Wiegand, Clock & Data or, Wiegand Card + PIN format. See Selecting Proximity Card Transmission Format on page 22 for more information.

5.2 Programming the AYC- F/G/M60 Series

Programming the AYC- F/G/M60 series is done solely via the unit's keypad driven Programming Menu System. To reach the Programming Menu System the AYC- F/G/M60 must first be placed into Programming Mode. During the F/G/M60's manufacturing process certain codes and settings are pre-programmed. These settings are called the "Default Factory Settings".

The table below shows the names of all the AYC- F/G/M60 Menus.

Programming Menu

Default Factory Settings are marked by a "*" sign.

Menu Description	Default
1 Selecting Keypad Transmission Format	
Single Key, 6-Bit Wiegand (Rosslare Format)	*
Single Key, 6-Bit Wiegand with Nibble + Parity Bits	
Single Key, 8-Bit Wiegand, Nibbles Complemented	
4 Keys Binary + Facility Code, 26-Bit Wiegand	
1 to 5 Keys + Facility Code, 26-Bit Wiegand	
6 Keys BCD and Parity Bits, 26-Bit Wiegand	
Single Key, 3x4 Matrix Keypad	
1 to 8 Keys BCD, Clock & Data	
Single key, 4-bit Wiegand	
2 Selecting Card Transmission Format	
26-Bit Wiegand	*
Clock & Data	
Wiegand Card + PIN	
3 Changing the Programming Code	1234
4 Changing the Facility Code	0
6 Setting the Backlight	
always off	*
always on	
10 sec. backlight after key press otherwise off	
10 sec. backlight after key press otherwise dimmed	
Setting Reader Format	
ASK	
FSK	
ASK + FSK	
0 Return to Factory Default Settings	

Entering Programming Mode

- 1) Press the # key 4 times.
 - Transmit LED will turn off. **Mode/Transmit** **Door/Program**
 - Program LED will turn red. **Red**
- 2) Enter your 4 digit Programming Code. If the Programming Code is valid, the door LED will turn green and the AYC- F/G/M60 will be in Programming Mode. **Mode/Transmit** **Door/Program**
Green



Note:

- The factory 4-digit Programming Code is 1234.
- If a Programming Code is not entered within 30 seconds, the AYC- F/G/M60 will return to Transmit Mode.

Exiting Programming Mode

- 1) To exit the Programming Mode at any time press #:
 - You will hear a beep **Mode/Transmit** **Door/Program**
 - The Program LED will be off **Red**
 - The Transmit LED will turn red
- 2) This indicates that the AYC- F/G/M60 has returned to Transmit Mode.
- 3) Wrong entries may reset the reader back to Transmit Mode. While in Programming Mode if no key is pressed for 30 seconds the AYC- F/G/M60 will exit Programming Mode and return to Transmit Mode.

Selecting Keypad Transmission Format

The AYC- F/G/M60 has eight different keypad transmission formats to select from. Follow the steps below to select the appropriate keypad transmission format that you wish to use.

- 1) Enter Programming Mode. **Mode/Transmit** **Door/Program**
Green

- 2) Press "1" to enter.
 - The Transmit LED will turn Red.
- 1

Mode/Transmit Door/Program

Red Green
- 3) Enter the appropriate option no. for the keypad transmission format that you wish to select (see table below).
 - If an incorrect option no. is entered the reader will return to Transmit Mode and the keypad transmission format will remain unchanged
 - 4) Look on the next page for more information on keypad transmission formats.
 - 5) System returns to Transmit Mode.
 - You will hear three beeps.
 - The Program LED will turn off
 - The Transmit LED will turn red
- ?

Mode/Transmit Door/Program

Red



Note:

- Only one keypad transmission format can be active at any one time.
- When using the keypad transmission format "1 to 8 keys BCD, Clock & Data" (Option 8) an additional input is required to specify the number of keys in the PIN code.

Keypad Transmission Format Option Number

See the table below to determine the Option Number for the Keypad Transmission Format you wish to select

Keypad Transmission Format	Option Number
Single Key, 6-Bit Wiegand (Rosslare Format)	1*
Single Key, 6-Bit Wiegand with Nibble + Parity Bits	2
Single Key, 8-Bit Wiegand, Nibbles Complemented	3
4 Keys Binary + Facility Code, 26-Bit Wiegand	4
1 to 5 Keys + Facility Code, 26-Bit Wiegand	5
6 Keys BCD and Parity Bits, 26-Bit Wiegand	6

Single Key, 3x4 Matrix Keypad	7
1 to 8 Keys BCD, Clock & Data Single Key	8
Single key, 4-bit Weigand	9

* Option 1 is the default factory setting.

More information on each of the different keypad transmission formats is available below and on the following pages.

Option 1: Single Key, 6-Bit Wiegand (Rosslare Format)

Each key press immediately sends 4 bits with 2 parity bits added. Even parity for the first 3 bits and odd parity for the last 3 bits.

0= 1 1010 0 = "A" in Hexadecimal	6= 1 0110 0
1= 0 0001 0	7= 1 0111 1
2= 0 0010 0	8= 1 1000 1
3= 0 0011 1	9= 1 1001 0
4= 1 0100 1	*= 1 1011 1 = "B" in Hexadecimal
5= 1 0101 0	#= 0 1100 1 = "C" in Hexadecimal

Option 2: Single Key, 6-Bit Wiegand Nibble and Parities

Each key press immediately sends 4 bits with 2 parity bits added. Even parity for the first 3 bits and odd parity for the last 3 bits.

0 = 0 0000 1	6 = 1 0110 0
1 = 0 0001 0	7 = 1 0111 1
2 = 0 0010 0	8 = 1 1000 1
3 = 0 0011 1	9 = 1 1001 0
4 = 1 0100 1	* = 1 1010 0 = "A" in Hexadecimal
5 = 1 0101 0	# = 1 1011 1 = "B" in Hexadecimal

Option 3: Single Key, 8-Bit Wiegand Nibbles Complemented

Inverts the most significant bits in the message leaving the least 4 significant bits as Binary-Coded Decimal (BCD) representation of the key. The host system receives an 8-bit message.

0 = 11110000

6 = 10010110

1 = 11100001

7 = 10000111

2 = 11010010

8 = 01111000

3 = 11000011

9 = 01101001

4 = 10110100

* = 01011010 = "A" in Hexadecimal

5 = 10100101

= 01001011 = "B" in Hexadecimal

Option 4: 4 Keys Binary + Facility Code, 26-Bit Wiegand

Buffers 4 keys and outputs keypad data with a three digit facility code like a standard 26-Bit card output.

The facility code is set in Programming Menu number four and can be in the range 000 to 255. The factory default setting for the facility code is 000. (See Changing the Facility Code on page 25 for more information).

The keypad PIN code is 4-digit long and can range between 0000 and 9999. On the fourth key press of the 4 digit PIN code, the data is sent across the Wiegand Data lines as binary data in the same format as a 26-Bit Card.

If the "*" key or the "#" key are pressed during PIN code entry, the keypad will clear the PIN code entry buffer, generate a beep and is ready to receive a new 4 digit keypad PIN code.

If the entry of the 4 digits keypad PIN code is disrupted and no number key is pressed within 5 seconds, the keypad will clear the PIN code entry buffer, generate a beep and is ready to receive a new 4 digits keypad PIN code.

(EP) FFFF FFFF AAAA AAAA AAAA AAAA (OP)

Where:

EP = Even parity for first 12 bits.

OP = Odd parity for last 12 bits.

F = 8-Bit Facility Code.

A = 16-Bit code generated from keyboard.

Option 5: 1 to 5 Keys + Facility Code, 26-Bit Wiegand

Buffers up to 5 keys and outputs keypad data with a facility code like a 26-Bit card output.

The facility code is set in Programming Menu number four and can be in the range 000 to 255. The factory default setting for the facility code is 000. (See Changing the Facility Code on page 25 for more information.) The keypad PIN code can be one to five digits long and can range between 1 and 65,535. When entering a keypad PIN code that is less than 5 digits long, the "#" key must be pressed to signify the end of PIN code entry. For keypad PIN codes that are 5 digits long, on the fifth key press of the 5 digit PIN code, the data is sent across the Wiegand Data lines as binary data in the same format as a 26-Bit Card.

If the "*" key is pressed during PIN code entry or a PIN code greater than 65,535 is entered, the keypad will clear the PIN code entry buffer, generate a beep and is ready to receive a new 5 digit keypad PIN code.

If the entry of the 1 to 5 digit keypad PIN code is disrupted and no number key or "#" key is pressed within 5 seconds, the keypad will clear the PIN code entry buffer, generate a medium length beep and is ready to receive a new 1 to 5 digit keypad PIN code.

(EP) FFFF FFFF AAAA AAAA AAAA AAAA (OP)

Where:

EP = Even parity for first 12 bits.

OP = Odd parity for last 12 bits.

F = 8-Bit Facility Code.

A = 16-Bit code generated from keyboard.

Option 6: 6 Keys BCD and parity bits, 26-Bit Wiegand

Sends buffer of 6 keys, adds parity and sends a 26-Bit Binary-Coded Decimal (BCD) message. Each key is a four bit equivalent of the decimal number.

The keypad PIN code must be 6 key presses long. On the sixth key press of the 6 digit PIN code, the data is sent across the Wiegand Data lines as a BCD message.

If the entry of the 6 digit keypad PIN code is disrupted and no number key is pressed within 5 seconds, the keypad will clear the PIN code entry buffer, generate a medium length beep and is ready to receive a new 6 digit keypad PIN code.

(EP) AAAA BBBB CCCC DDDD EEEE FFFF (OP)

Where:

EP = Even parity for first 12 bits.

OP = Odd parity for last 12 bits.

A = The first key entered.

D = Fourth key entered

B = Second key entered

E = Fifth key entered.

C = Third key entered

F = Sixth key entered

Option 7: Single Key, 3x4 Matrix Keypad (MD-P64)

This unique mode is intended to let the host controller scan the AYC- F/G/M60 keypad while still keeping the proximity card readers 26-Bit Wiegand or Clock & Data formats active.

An optional interface board must be used between the AYC- F/G/M60 and the host system. Each key press is immediately sent on DATA0 as an ASCII character at a baud rate of 9600 bits per second.

When a key is pressed DATA1 is pulled "low" until the key is released at which point DATA1 will be set to "high". This allows the controller to detect the duration of the key press.

The MD-P64 interface unit outputs the data received to 7 outputs emulating a keyboard. The interface unit will not affect any data that it receives from the proximity reader whether it is 26-Bit Wiegand or Clock & Data.

Key pressed = ASCII Value

0 = '0' (0x30 hex)

6 = '6' (0x36 hex)

1 = '1' (0x31 hex)

7 = '7' (0x37 hex)

2 = '2' (0x32 hex)

8 = '8' (0x38 hex)

3 = '3' (0x33 hex)

9 = '9' (0x39 hex)

4 = '4' (0x34 hex)

* = '*' (0x2A hex)

5 = '5' (0x35 hex)

= '#' (0x23 hex)

Option 8: 1 to 8 Keys BCD, Clock & Data

Buffers up to 8 keys and outputs keypad data without a facility code like standard Clock and Data card output.

The keypad PIN code can be one to eight digits long. The PIN code length is selected while programming the reader for Option 8. The reader will transmit the data when it receives the last key press of the PIN code. The data is sent across the two data output lines as binary data in Clock & Data format.

If the "*" key or the "#" key are pressed during PIN code entry, the keypad will clear the PIN code entry buffer, generate a beep and is ready to receive a new keypad PIN code.

If the entry of the digit keypad PIN code is disrupted and no number key or "#" key is pressed within 5 seconds, the keypad will clear the PIN code entry buffer, generate a medium length beep and is ready to receive a new keypad PIN code.



Note:

- When using the keypad transmission format "1 to 8 keys BCD, Clock & Data" (Option 8) an additional input is required to specify the number of keys in the PIN code.

Option 9: Single Key, 4-bit Wiegand

Each key press immediately sends 4 bits of data, with no parity bits added.

0= 0000

1= 0001

2= 0010

3= 0011

4= 0100

5= 0101

6= 0110

7= 0111

8= 1000

9= 1001

*= 1010 ="A" in Hexadecimal

#=1011 ="B" in Hexadecimal

Selecting Proximity Card Transmission Format

The AYC- F/G/M60 has three different proximity card formats to select from. Follow the steps below to select the appropriate Proximity Card reader transmission format that you wish to use.

-
- 1) Enter Programming Mode. Mode/Transmit Door/Program
Green

 - 2) Press "2" to enter Menu 2. 2
 - The Transmit LED will turn red. Mode/Transmit Door/Program
Red Green

 - 3) Enter the appropriate option number for the proxy card transmission format that you wish to select (options below). If an incorrect option is entered the reader will return to Transmit Mode and the keypad transmission format will remain unchanged.

 - 4) System returns to Transmit Mode
 - You will hear three beeps.
 - The Program LED will turn off
 - The Transmit LED will turn redMode/Transmit Door/Program
Red

Proximity Card Transmission Format Option Number:

Option 1: 26-Bit Wiegand

Option 2: Clock & Data

Option 3: Wiegand Card + PIN

"Wiegand Card + PIN" Transmission Format

This unique mode is intended to let host controllers get card and keypad data simultaneously. This option overrules the selected Keypad Transmission Format and sends the keypad data as described below.

After a card is presented to AYC- F/G/M60, the program LED starts to flash in Green and indicates that AYC- F/G/M60 is waiting for the PIN code. If the entry of one to five digit keypad PIN code is disturbed and no digit key or # key is pressed within 5 seconds, the keypad will clear the card buffer and the PIN code entry buffer, generate a medium length beep and be ready to receive a new card.

The keypad PIN code can be one to five digits long in the range of 0 to 99,999. When entering a keypad PIN code, the # key must be pressed to signify the end of the PIN entry. When pressing the # key press, the data is sent by the Wiegand data lines. If the * key is pressed, the keypad will clear the card buffer and the PIN code entry buffer, generate a medium length beep and is ready to receive a new card.

AYC- F/G/M60 output card data in 26-Bit Wiegand with the following keypad data in 26-Bit Wiegand format.

Card Data: (EP) AAAA AAAA AAAA BBBB BBBB BBBB (OP)

Where: EP =Even parity for first 12 A bits.

OP =Odd parity for last B 12 bits.

PIN Data: (EP) 0000 AAAA BBBB CCCC DDDD EEEE (OP)

Where:

A = The first key entered.

D = Fourth key entered

B = Second key entered

E = Fifth key entered.

C = Third key entered

EP =Even parity for first 12 bits.

OP =Odd parity for last 12 bits.

If the PIN code is less than 5 digits, all the most significant nibbles are filled with 0.

Example: (EP) 0000 0000 0000 0000 AAAA BBBB (OP)

Where:

A = The first key entered.

B =Second key entered

EP =Even parity for first 12 bits.

OP =Odd parity for last 12 bits.

Changing the Programming Code

- 1) Enter Programming Mode. Mode/Transmit Door/Program Green
- 2) Press "3" to enter Menu 3.

3

Mode/Transmit Door/Program Green
 - The Transmit LED will turn red.
- 3) Enter the new 4 digit code you wish to set as the Programming Code ? ? ? ?
- 4) System returns to Transmit Mode
 - You will hear three beeps Mode/Transmit Door/Program Red
 - The Program LED will turn off
 - The Transmit LED will turn red



Note:

- Programming Code can not be erased, i.e. the code 0000 is invalid and will not erase the Programming Code.
- The factory default 4-digit Programming Code is 1234.

Changing the Facility Code

- 1) Enter Programming Mode. Mode/Transmit Door/Program Green
- 2) Press "4" to enter Menu 4.

4



Mode/Transmit Door/Program Red Green
 - The Transmit LED will turn red.
- 3) Enter the new 3-digit code you wish to set as the Facility Code
- 4) System returns to Transmit Mode
 - You will hear three beeps Mode/Transmit Door/Program Red
 - The Program LED will turn off
 - The Transmit LED will turn red

**Note:**

- Facility Code can be in the range of 000 to 255.
- The default Facility Code is 0.

Setting the Backlight and Reader Format

- 1) Enter Programming Mode
- 2) Press "6" to enter menu 6
The Transmit LED will turn red
- 3) Enter the appropriate option number for the backlight option that you wish to select
 "10" for always off
 "11" for always on
 "12" for 10 sec. backlight after a key is pressed otherwise off
 "13" for 10 sec. backlight after a key is pressed otherwise dimmed
 Enter the appropriate option number for the Reader Format
 "61" for ASK
 "62" for FSK
 "63" for ASK + FSK (Default)
- 4) System returns to Transmit Mode
You will hear three beeps
The Transmit LED will turn red.

**Return to Factory Default Settings****Warning:**

- You must be very careful before using this command! This will erase the entire memory and return all codes to their factory default setting.

- 1) Enter Programming Mode. **Mode/Transmit** **Door/Program**
Green
- 2) Press "0" to enter Menu 0.

-
- The Transmit LED will Flash red.
 - The Program LED will flash red.



- 3) Enter your 4 digit programming code

?	?	?	?
---	---	---	---
- If the Programming Code is valid, all memory will be erased, you will hear three beeps and the controller will return to Normal Mode
 - If the Programming Code is invalid you will hear a long beep and the controller will return to Normal Mode without erasing the memory of the controller

Replacing a Lost Programming Code

In the event that the Programming Code is forgotten, the AYC-Qx4 may be reprogrammed in the field using the following instructions:

- 1) Remove power from the reader.
- 2) Activate tamper by removing the reader from the wall or removing the reader's case.
- 3) Apply power to the reader.
- 4) You now have 10 seconds to enter Programming Mode using the factory default Programming Code 1234.

6. Controller Functionality

The AYC- F/G/M60 series can function both as a reader and as a controller. If the unit is connected to Rosslares' secure application appurtenance, it functions as a controller indicated by two beeps immediately after power-on reset.

The lock strike output and Request to Exit input are not located on the AYC- F/G/M60 unit, eliminating the possibility of unauthorized entry to the restricted area.

The following explains how the AYC- F/G/M60 series functions as a controller.

6.1 Normal, Secure, and Master Users

The AYC- F/G/M60 accepts up to 500 users and provides entry via the use of PIN codes and/or Proximity cards. Each user is provided with two code memory slots, Memory Slot 1 (Primary Code) and Memory Slot 2 (Secondary Code).

The pin code length has several options. The pin code length can be a set number of 4, 5 or 6 digits or it can be a 4-8 digits option. When choosing the 4-8 digit option, please note that you should either enter zeros before the code, or press pound at the end (for example if your code is 12345, enter either **00012345** or **12345#**).



Note:

- Entering a code refers to either PIN or CARD depending on the model you have.

The way in which the two memory slots are programmed determines a user's access level and also determines the way in which the AYC- F/G/M60 grants access in its three modes of operation. There are three user levels:

Normal User

A Normal User only has a Primary Code and is only granted access when the AYC- F/G/M60 is in Normal or Bypass Mode.

Secure User

A Secure User must have a Primary and Secondary Code programmed; the two codes must not be the same. The Secure User can gain access when the AYC- F/G/M60 is in any of its three modes of operation. In Normal Mode the Secure User must use their Primary Code to gain entry. In Secure Mode the Secure User must present both their Primary and Secondary Codes in order to gain entry.

Master User

A Master User must have both Primary and Secondary Codes programmed with the same code. The Master User can gain access during any mode of operation by presenting their PIN code and/or Proximity card once to the controller. (The Master User is convenient but is less secure than a Secure User.)

6.2 Modes of Operation



The AYC- F/G/M60 has three modes of operation:

Normal Mode

MODE LED is green

Normal Mode is the default mode.

In Normal mode the door is locked until a Primary Code is presented to the controller. Special codes such as **Lock Strike Code** and **Auxiliary Code** are active in Normal mode. (See pages 35-36 for more information)

Mode/Transmit   Door/Program
Green

Bypass Mode

MODE LED is orange

In Bypass Mode, access to the

premises is dependent on whether the controller's Lock Strike Relay is programmed for Fail Safe Operation or Fail Secure Operation. When the Lock Strike is programmed for Fail Secure Operation, the door is locked until the "*" button is pressed. When the Lock Strike is programmed for Fail Safe Operation, the door is constantly unlocked.

Mode/Transmit   Door/Program
Orange

Secure Mode

MODE LED is red

Only Secure and Master Users can access the premises during the Secured Mode.


A Secure User must enter their Primary and Secondary Codes to gain entry. After entering their Primary Code the Door LED will flash green for 10 seconds, during which the Secondary Code must be entered. A Master User only needs to present their code once to gain entry.


Changing the Modes of Operation

Changing from Normal Mode to Secure Mode

The default factory setting for the Normal / Secure code is 3838.

- 1) Enter the Normal / Secure code
 - Mode LED will flash red
- 2) Press the "#" key to confirm the mode change.
 - Mode LED will turn red

Mode/Transmit  Door/Program
Red

Mode/Transmit  Door/Program
Green

Mode/Transmit  Door/Program
Red

Mode/Transmit  Door/Program
Red

Changing from Secure Mode to Normal Mode

The default factory setting for the Normal / Secure code is 3838.

- 1) Enter the Normal / Secure code
 - Mode LED will flash green
- 2) Press the "#" key to confirm the mode change.
 - Mode LED will turn green

Mode/Transmit  Door/Program
Red


Mode/Transmit  Door/Program
Green

Mode/Transmit  Door/Program
Green

Changing from Normal Mode to Bypass Mode

See Changing the Normal / Bypass Code and Door Chime Settings on page 38 to create/modify the Normal / Bypass code.

- 1) Enter the 4 digit Normal / Bypass code
 - Mode LED will flash Orange
- 2) Press the "#" key to confirm the mode change.
 - Mode LED will turn orange

Mode/Transmit  Door/Program
Green

Mode/Transmit  Door/Program
Orange

Mode/Transmit  Door/Program
Orange


Changing from Bypass Mode to Normal Mode

See Changing the Normal / Bypass Code and Door Chime Settings on page 38 to create/modify the Normal / Bypass code.

- 1) Enter the 4 digit Normal / Bypass code
 - Mode LED will flash green
- 2) Press the "#" key to confirm the mode change.
 - Mode LED will turn green

Mode/Transmit  Door/Program
Orange

Mode/Transmit  Door/Program
Green

Mode/Transmit  Door/Program
Green

6.3 Auxiliary Input & Output

For optimum usability in different applications, the controller's auxiliary input and output can be configured in ten different modes of operation.

6.4 Door Alarms

Door alarms can be generated by connecting the Auxiliary Input to a Door Position Switch. Either Door-Forced or Door-Ajar conditions are supported, as well as, a configurable delay timer for each alarm type. Only one Door-alarm is enabled at any one

time. Door alarms may activate auxiliary output and siren depending on the auxiliary settings.

6.5 Internal Case and Back Tamper

In case the unit is forcibly opened or it is removed from the wall, a tamper event is triggered. A tamper output opens sending a signal to the connected Alarm system (purple wire) the event closes when the tamper is closed (case is re-closed or re-attached to the wall).

The tamper event can also activate the auxiliary output if the controller is in Auxiliary Mode 3. Refer to the Quick Reference Guide for Auxiliary Mode Setting table, on page 41 below.

6.6 Lockout Feature (Keypad / Card Tamper)

In case the controller is presented with wrong codes (PIN or Card), consecutively several times the unit goes into lockout mode. When a lockout occurs, the controller's reader and keypad are de-activated so no codes can be entered until the set lockout period expires.

During Lockout, Mode LED is Off, Door LED flashes Red, and the controller beeps every two seconds.

6.7 Request to Exit (REX) Function

The REX Button is connected to Rosslares' secure application appurtenance. The REX Button must be located inside the premises to be secured and is used to open the door without the use of a PIN code. It is usually located in a convenient location, e.g. inside the door or at a receptionist's desk. The function of the REX Button depends on whether the Lock Strike Relay is programmed for Fail Safe Operation or Fail Secure Operation.

Fail Secure Operation: From the moment the REX Button is pressed, the door will be unlocked until the **Lock Strike Release Time** has

passed. After this time, the door will be locked even if the REX Button has not been released.

Fail Safe Operation: From the moment the REX Button is pressed, the door will be unlocked until the REX Button is released, plus the **Lock Strike Release Time**. In this case the **Lock Strike Relay** only begins its count down once the REX Button has been released.

6.8 Secure Application Appurtenances

Rosslares' secure application appurtenances are designed for use with Rosslare's secured series stand alone access control units, including AYC- F/G/M60. It is designed to operate indoors and installed within the secured premises.

The AYC- F/G/M60 must be used with one of Rosslares' secure application appurtenances, which provide Lock Strike output and Request to Exit (REX) Input.

Both units communicate through a proprietary Rosslare protocol, which provides a secure link between the AYC- F/G/M60 and the appurtenances unit. This in turn activates the door lock.

The units also function as the power supply for the AYC- F/G/M60; it also contains a speaker connection for all sounder abilities.

For more information see the specific Appurtenances Manual.

6.9 Programming the AYC- F/G/M60

Programming the AYC- F/G/M60 is done solely via the unit's keypad driven Programming Menu System. To reach the Programming Menu System the AYC- F/G/M60 must first be placed into Programming mode. See Entering Programming Mode on page 34 for more information. During the AYC- F/G/M60's manufacturing process certain codes and settings are pre-programmed. These settings are the called the **Default Factory Settings**. The table below shows the names of all the AYC- F/G/M60 Menus. It also shows of all the AYC- F/G/M60's default factory codes and settings.

Programming Menu

Menu No.	Menu Description	Default			
		4 digit	5 digit	6 digit	4-8 digits
1	Changing Lock Strike Code	2580	25802	258025	25802580
2	Changing Auxiliary Code	0852	08520	085208	08520852
3	Changing Program Code	1234	12341	123412	12341234
4	Changing Normal/Secure Code	3838	38383	383838	38383838
5	Changing Normal/Bypass Code			N/A	
6	Changing Door Release Time			0004	
	Defining auxiliary inputs/outputs			2004	
	Set Lockout			4000	
	Backlight Behavior			5100	
7	Enrolling PIN Code				
8	Deleting PIN Code				
9	Code assignment with strike/auxiliary				
0	Return to factory defaults / Change PIN code Length				

You will find a complete description and instructions for each of the above menu items on the following pages.

Entering Programming Mode

- 1) Press the # key twice within 2 seconds.
 - Mode LED will turn off.
 - Door LED will turn red.

Mode/Transmit Door/Program Red

[?] [?] [?] [?]
- 2) Enter your Programming Code
 - Door LED will turn green and the AYC- F/G/M60 will be in Programming Mode.

Mode/Transmit Door/Program Green

**Note:**

- The AYC- F/G/M60 must be in Normal Mode to enter the Programming mode.
- The factory four-digit Programming Code is 1234.
- If a Programming Code is not entered within five seconds, the AYC- F/G/M60 will return to Normal mode.

Exiting Programming Mode

- 1) Press the “#” key two times within 2 seconds
 - You will hear 3 beeps. **Mode/Transmit** **Door/Program Green**
 - The Door LED will turn off and the Mode LED will return to Normal.
- 2) Wrong entries may reset the controller back to Normal mode.
- 3) While in Programming mode, if no key is pressed for one minute the AYC- F/G/M60 will exit Programming mode and return to Normal mode. **Mode/Transmit** **Door/Program Green**

Changing Lock Strike Code

The Lock Strike Code is mainly used as a method to quickly test the Lock Strike Relay during installation.

When the first user is added to the controller, the default Lock Strike Code will automatically be deleted. Once the code is programmed again, it will not be deleted with the entry of additional User Codes.

- 1) Enter Programming mode. **Mode/Transmit** **Door/Program Green**
- 2) Press “1” to enter Menu 1.
 - The Mode LED will turn red. **Mode/Transmit** **Door/Program Green**
- 3) Enter the new code you wish to set as the Lock Strike Code.

- 4) System returns to Normal mode. **Mode/Transmit** **Door/Program**
Green
- You will hear three beeps.



Note:

- Lock Strike Code does not work in the Secure Mode.
- Wrong entries will return the controller to Normal Mode.
- Code 0000 will erase the Lock Strike Code.
- The factory Default 4-digit Lock Strike code is 2580.

Changing Auxiliary Code

The Auxiliary Code is mainly used as a method to quickly test the Auxiliary Relay during installation.

When the first user is added to the controller, the default Auxiliary Code will automatically be deleted. Once the code is programmed again, it will not be deleted with the entry of additional User Codes.

- Enter Programming mode.
- Press "2" to enter Menu 2.

Mode/Transmit **Door/Program**
Green

2

- The Mode LED will turn orange.

Mode/Transmit **Door/Program**
Orange Green

- Enter the new code you wish to set as the auxiliary Code.
- System returns to Normal mode.

? ? ? ?

- You will hear three beeps.

Mode/Transmit **Door/Program**
Green



Note:

- Auxiliary code does not work in the Secure Mode.
- Wrong entries will return the controller to Normal Mode.
- Code 0000 will erase the Auxiliary Code.
- The factory Default 4-digit Auxiliary Code is 0852.

Changing the Programming Code

- 1) Enter Programming mode. **Mode/Transmit** **Door/Program**
Green
- 2) Press "3" to enter Menu 3. **3**
 - The Mode LED will turn green. **Mode/Transmit** **Door/Program**
Green Green
- 3) Enter the new code you wish to set as Programming Code **[?] [?] [?] [?]**
- 4) System returns to Normal mode. **Mode/Transmit** **Door/Program**
Green

 - You will hear three beeps.



Note:

- Programming Code cannot be erased, i.e. the code 0000 is not valid and will not erase the Programming Code.
- The factory four digit programming code is 1234.

Changing the Normal / Secure Code

- 1) Enter Programming mode. **Mode/Transmit** **Door/Program**
Green
- 2) Press "4" to enter Menu 4. **4**
 - The Mode LED will flash red. **Mode/Transmit** **Door/Program**
Red Green
- 3) Enter the new code you wish to set as Normal / Secure Code **[?] [?] [?] [?]**
- 4) System returns to Normal mode. **Mode/Transmit** **Door/Program**
Green

 - You will hear three beeps



Note:

- Code 0000 will erase the Normal / Secure Code.
- This code is disabled in case the Auxiliary Input is set to toggle between Normal and Secure access modes.
- Default Normal/Secure code is 3838

Changing the Normal / Bypass Code and Door Chime Settings

- 1) Enter Programming mode. Mode/Transmit Door/Program
Green
- 2) Press "5" to enter Menu 5
- 5
- The Mode LED will flash orange.
- 3) Hereafter, are four different ways to program the normal / bypass code and door chime.
- a. Disable both Bypass Code and the door chime. Enter the code 0000. 0 0 0 0
- b. Disable Bypass Code and enable the door chime. Enter the code 0001. 0 0 0 1
- c. Enable Bypass Code and disable the door chime. Enter any code ending with 0. ? ? ? 0
- d. Enable Bypass Code and enable the door chime. Enter a code not ending with 0. ? ? ? ~~0~~
- 4) System returns to its normal mode.
- You will hear three beeps. Mode/Transmit Door/Program
Green
 - The Door LED will turn off.
 - The Mode LED will turn green.

Setting Fail Safe/Secure Operation, Tamper Siren and Lock Strike Release Time

- 1) Enter Programming mode. Mode/Transmit Door/Program Green
- 2) Press "6" to enter Menu 6 **6**

- The Mode LED will flash green. Mode/Transmit Door/Program Green

- 3) Construct a code using instructions hereafter. **[?] [?] [?] [?]**

First Digit

For *fail secure* operation, the first digit is set to 0.

For *failsafe* operation, the first digit is set to 1.


Second Digit

Siren Time in minutes (1-9, 0-disabled)

Third and Fourth Digits

Enter the number of seconds (from 1 to 99) that you want the Lock Strike to be released.

For example, 0312 means Fail Secure Operation, a 3-minute Siren, and a 12-second Lock Strike release time.



- 4) System returns to its normal mode.
- You will hear three beeps. Mode/Transmit Door/Program Green
 - The Door LED will turn off.
 - The Mode LED will turn green.



Note:

- Default value is 0004 which corresponds to Fail Secure operation, no siren, and 4-seconds Lock Strike release time.

Quick Reference Guide for Auxiliary Mode Setting

Auxiliary Mode	Auxiliary Input Function	Auxiliary Output Activated by	Auxiliary Relay	Auxiliary Settings (in seconds)
0	AUX REX	Valid code or AUX REX	N.O.	01 to 99 Aux. relay release time 00 Aux. relay toggle
1	Normal/Secure switch	Valid code	N.O.	01 to 99 Aux. relay release time 00 Aux. relay toggle
2	Normal/Secure switch	Star button (★)	N.O.	01 to 99 Aux. relay release time 00 Aux. relay toggle
3	Normal/Secure switch	Tamper event	N.C.	01 to 99 Aux. relay release time 00 Aux. relay tamper activated
4	Normal/Secure switch	Direct shunt	N.O.	01 to 99 Shunt time
5	Door Monitor	Shunt	N.C.	01 to 99 Maximum shunt time
6	Door Monitor	Forced door	N.C.	01 to 99 Forced delay
7	Door Monitor	Door ajar	N.C.	01 to 99 Ajar delay
8	LED control - Green	Valid code	N.O.	01 to 99 Aux. relay release time 00 Aux. relay toggle
9	LED control - Red	Valid code	N.O.	01 to 99 Aux. relay release time 00 Aux. relay toggle

Detailed Reference Guide

The following are brief descriptions of each auxiliary mode. To implement the features of each mode, refer to Defining the Auxiliary Input and Output, page 40.

Auxiliary Mode 0

Auxiliary input function: Activates the auxiliary output

Auxiliary output activated by: Valid user code, Auxiliary code, Auxiliary input

E.g. In auxiliary mode 0, the controller can function as a two-door controller. The auxiliary relay is to be attached to the lock on the second door. The auxiliary setting defines the door open time for the second door. The auxiliary input is to be attached to the REX pushbutton for the second door. Door Monitor input feature for the second door is not enabled when using this mode.

Auxiliary Mode 1

Auxiliary input function: Toggles normal/secure modes

Auxiliary output activated by: Valid user code, Auxiliary code

E.g. In auxiliary mode 1, the controller can function as a two-door controller. The auxiliary relay is to be attached to the lock on the second door. REX feature for the second door is not enabled when using this mode.

The auxiliary setting defines the door open time for the second door. The auxiliary input can switch the mode of operation of the controller between normal and secure mode. By connecting a switch timer or alarm system output to the auxiliary input, the controller can be automatically switched from normal mode (during office hours) to secure mode (after office hours).

Auxiliary Mode 2

Auxiliary input function: Toggles normal/secure modes

Auxiliary output activated by: Asterisk Button (*)

E.g. In auxiliary mode 2, the auxiliary relay can function as a general purpose time switch that can be activated when the Asterisk button (*) is depressed. The auxiliary setting establishes for how long the auxiliary relay is to be activated. The auxiliary input can switch the mode of operation of the controller between normal and secure mode. By connecting a switch timer or alarm system output to the auxiliary input, the controller can be automatically switched from normal mode (during office hours) to secure mode (after office hours).

Auxiliary Mode 3

Auxiliary input function: Toggles normal/secure modes

Auxiliary output activated by: Alarms

E.g. In auxiliary mode 3, the auxiliary output is activated if the controller is tampered; that is, if the case is forcibly opened or removed from the wall. The auxiliary input can switch the mode of operation of the controller between normal and secure mode. By connecting a switch timer or alarm system output to the auxiliary input, the controller can be automatically switched from normal mode (during office hours) to secure mode (after office hours).

Auxiliary Mode 4

Auxiliary input function: Toggles normal/secure modes

Auxiliary output activated by: direct shunt (explanation below)

E.g. In auxiliary mode 4, the controller is capable of bypassing an alarm zone by shunting an alarm system's door sensor. The auxiliary output is to be wired in parallel to the door sensor output. When in use, the auxiliary output is normally open and the door sensor functions normally. When a valid code is entered, the auxiliary relay shunts the door sensor for the duration of the shunt time, as defined by the auxiliary setting. If the door is left open longer than the shunt time, an alarm will be triggered.

Auxiliary Mode 5

Auxiliary input function: Door Monitor

Auxiliary output activated by: Shunt (explanation below)

E.g. In auxiliary mode 5, the controller is capable of shunting an alarm system. In this mode, the auxiliary input is to be wired to the magnetic contact switch on the door. The auxiliary relay is wired to the alarm system. Without a valid code entered, the auxiliary relay will match the condition of the magnetic contact switch; if the door opens, the auxiliary relay will open; if the door closes, the auxiliary relay will close. When a valid code is entered, a count down for maximum shunt time, as defined by the auxiliary setting, begins; if the door is not closed before the maximum shunt time, the alarm will be triggered.

Auxiliary Mode 6

Auxiliary input function: Door Monitor

Auxiliary output activated by: Forced entry

E.g. In auxiliary mode 6, the controller can trigger the auxiliary relay if the door has been forced. If the Siren Settings is enabled the siren will be activated.

In this mode, the auxiliary input functions as a door monitor switch and is wired to the magnetic contact switch on the door. The auxiliary relay is to be wired to the alarm system. If the door is forced open, the controller will wait for the period of the forced door delay time to elapse and then, it will activate the auxiliary relay. The auxiliary setting sets the forced door delay period.

Auxiliary Mode 7

Auxiliary input function: Door Monitor

Auxiliary output activated by: Door Ajar (door held open)

E.g. In auxiliary mode 7, the controller can trigger the auxiliary relay, if it detects that the door has been held open (ajar) too long. In this mode the auxiliary input functions as a door monitor switch and is wired to the magnetic contact switch on the door. The auxiliary relay is to be wired to the alarm system. If the door is

opened, the controller will wait for the door ajar delay time to elapse and if the door does not close prior to the end of this period, the controller will activate the auxiliary relay. The auxiliary setting defines the door-ajar time.

Auxiliary Mode 8

Auxiliary input function: Green LED control

Auxiliary output activated by: Valid user code, Auxiliary code
E.g. In auxiliary mode 8, the controller can function as a two-door controller and also provide indicator functionality control. The auxiliary relay is connected to the lock on the second door. The auxiliary setting defines the door open time for the second door. The auxiliary input is used to control the Door indicator. If the auxiliary input is open, the indicator will flash green; if the auxiliary input is closed, the Door indicator will flash red.



Note:

1. This mode takes control of the Door indicator LED.
2. The indicator LED will not be lit when:
3. A valid code is entered
4. While in secure mode, when waiting for secondary code.

Auxiliary Mode 9

Auxiliary input function: Red LED control

Auxiliary output activated by: Valid user code, Auxiliary code
E.g. In auxiliary mode 9, the controller can function as a two-door controller and also provide indicator functionality control. The auxiliary relay is connected to the lock on the second door. The auxiliary setting defines the door open time for the second door. The auxiliary input is used to control the indicator. If the auxiliary input is open the Door indicator will flash red; if the auxiliary input is closed the Door indicator will flash green.



Note:

1. This mode takes control of the Door indicator LED.
2. The indicator LED will not be lit when:
3. A valid code is entered
4. While in secure mode, when waiting for secondary code.

Setting the Lockout Feature

In case the controller is presented with wrong codes, consecutively several times the unit goes into lockout mode. When a lockout occurs, the controller keypad and reader are locked so no codes can be entered until the set lockout period expires. During Lockout, Mode LED is Off, Door LED flashes Red, and the controller beeps every two seconds. The default setting for the Lockout Feature is 4000 (Lockout Disabled)



Note:

1. Using the lockout feature is highly recommended, especially when selecting to use short PIN code length (4 or 5 digits).

- 1) Enter the Programming Mode.

Mode/Transmit Door/Program Green

- 2) Press 6 to enter Menu 6.

6


- The Mode LED will flash green

Mode/Transmit Door/Program Green Green

- 3) Construct a code using the following instructions:

Set the number of wrong code attempts, which will cause Lockout between 0 and 9 attempts.

Sets the Duration of the lockout, between 00 and 99, the value is multiplied by ten, resulting in 0-990 seconds.



Setting the backlight behavior

The controller allows you to define the way the units' Backlight will work.

To define the Backlight operation:

- 1) Enter the programming mode.
- 2) Depress 6 to enter Menu 6.
 - The Mode indicator will flash green.
- 3) Construct a code using the following instructions: the backlight and Led option and the type of activity are
 - "50" - Backlight Off
 - "51" - Backlight On (default)
 - "52" - Backlight Off, activated on any key press for ten seconds.
 - "53" - Backlight Dimmed, backlight activated on any key press for ten seconds.
- 4) Under Menu 6, format the controller using the following instructions:
 - "61" ASK
 - "62" FSK
 - "63" ASK + FSK (Default)



Enrolling Primary and Secondary Codes

Primary Codes

- Primary Codes can only be enrolled to an empty User Slot, i.e. a slot where there is no existing Primary Code.
- Primary Codes must be unique, i.e. one user's Primary Code may not be the same as other users Primary Code.
- Primary Codes cannot be the same as any system codes, such as the Normal / Secure Code or Lock Strike Code.
- Users who hold a Primary Code can gain entry only during Normal mode.

Secondary Codes

- Secondary Codes can only be enrolled to User Slot that already has a Primary Code enrolled but no Secondary Code.
- Secondary Codes do not have to be unique, i.e. multiple users can all hold the same Secondary Code.
- Secondary Codes cannot be the same as any system codes, such as the Normal / Secure Code or Lock Strike Codes.
- Users who hold Secondary Codes can gain entry in any Mode of Operation.













Enrolling Primary and Secondary Codes

There are two methods to enroll Primary and Secondary codes, the Standard Method and the Code Search Method.

- The Standard Method is mainly used when the User Slot number for the user you wish to program is known. You can program both Primary and Secondary Codes using the Standard method. (See Enrolling Primary and Secondary Codes using the Standard Method on page 48.)
- The Code Search Method is mainly used when enrolling a user's Secondary Code and the User Slot Code is unknown.

The Code Search method only works if a user's Primary Code is already enrolled but the Secondary Code is not. (See Enrolling Secondary Codes using the Code Search Method on page 50.)



Enrolling Primary and Secondary Codes using the Standard Method

-
- 1) Enter the Programming Mode. **Mode/Transmit**  **Door/Program**  **Green**
- 2) Press 7 to enter Menu 7.  **Mode/Transmit**  **Door/Program**  **Orange**
- The Door LED will turn orange
- 3) Enter the 3-digit User Slot number between 001 and 500 that you wish to enroll a Primary or Secondary code to. For example, User Slot 003 represents User #3. 
- If the selected slot has no Primary Code, the Mode LED will flash green, indicating that the controller is ready to accept a Primary Code. **Mode/Transmit**  **Door/Program**  **Orange**
 - If the selected slot already has a Primary Code but no Secondary Code, the Mode LED will flash red, indicating that the controller is ready to accept a Secondary Code. **Mode/Transmit**  **Door/Program**  **Orange**
 - If the selected slot already has a Primary and Secondary Code, you will hear a long beep and the controller will return to Normal Mode.
- 4) Enter the PIN Code you wish to assign as the Primary or Secondary Code for this slot number. **Mode/Transmit**  **Door/Program**  **Green**



If the code entered is valid the Mode LED will stop flashing and then the controller is ready for you to enter the next 3-digit slot number (refer to step 2) that you want to assign a code to, or press the “#” key to move to the next slot number. If you do not wish to continue enrolling codes, press the “#” key twice and the controller will return to Normal mode.



Enrolling Secondary Codes using the Code Search Method



The Code Search feature enables you to quickly enroll a Secondary Code to a user who already has a Primary Code.

- 1) Enter the Programming Mode. **Mode/Transmit**  **Door/Program**  **Green**



- 2) Press 7 to enter Menu 7. 

- The Door LED will turn orange **Mode/Transmit**  **Door/Program**  **Orange**

- 3) Enter 000 as the 3-digit User Slot number.   

- The Door LED will flash orange. **Mode/Transmit**  **Door/Program**  **Orange**

The controller is now waiting for the Primary Code of the User to whom you want to add a Secondary Code.

- 4) Enter the Primary Code belonging to the user for whom you wish to add a Secondary Code.
- The Mode LED will flash red. **Mode/Transmit**  **Door/Program**  **Red** **Orange**

If the Primary Code entered is not valid, you will hear a long beep and the AYC- F/G/M60 will continue to wait for a valid Primary Code.










- 5) Enter the Code to be used as the Secondary Code.
- If the Secondary Code is valid, the controller will beep three times and return to Normal Mode.
 - If the Secondary Code is invalid the controller will sound a long beep, and the AYC- F/G/M60 will continue to wait for a valid Secondary Code to be entered.

Deleting Primary and Secondary Codes

There are two methods to delete Primary and Secondary codes: the Standard Method and the Code Search Method.

When deleting a User Slot, both the Primary Code and the Secondary code are erased.

Deleting Primary and Secondary Codes using the Standard Method

- 1) Enter the Programming Mode. Mode/Transmit   Door/Program Green
- 2) Press 8 to enter Menu 8. 
 - The Door LED will turn orange
 - The Mode LED will turn redMode/Transmit   Door/Program Red Orange
- 3) Enter the 3-digit User Slot code you wish to delete. 
 - The Mode LED will flash red indicating the controller is waiting for the Programming Code to confirm the deletion. If the User Slot is empty, you will hear a long beep and the AYC- F/G/M60 will return to Normal Mode.Mode/Transmit   Door/Program Red Orange
- 4) Enter your programming code to confirm the deletion. 

If the programming code is valid, three beeps will be heard and the controller will return to its normal mode.











If the programming code is invalid, a long beep will be heard and the controller will return to its normal mode.









Note:

- It is recommended that a record be kept of added and deleted users so that it will be easier to keep track of which user slots are empty and which user slots are not.

Deleting Primary and Secondary Codes using the Code Search Method

- 1) Enter the Programming Mode.
Mode/Transmit  Door/Program  Green
- 2) Press 8 to enter Menu 8.

 - The Door LED will turn orange
 - The Mode LED will turn redMode/Transmit  Door/Program  Orange
- 3) Enter 000 as the 3-digit User Slot number.

 - The Mode LED will turn red.
 - The Door LED will flash orange.Mode/Transmit  Door/Program  Orange

The controller is now waiting for the Primary Code of the User you want to delete.

- 4) Enter the 4-8 digit PIN Code of the Primary Code belonging to the user you want to delete.

 - The Mode LED will flash red
 - The Door LED will flash orangeMode/Transmit  Door/Program  Orange

- 5) Enter your Programming Code to confirm the deletion.

If the Programming Code is valid, you will hear three beeps and the unit will return to Normal Mode.

If the Programming Code is invalid, you will hear a long beep and the unit will return to Normal Mode.



Note:







- It is recommended that a record be kept of added and deleted users so that it will be easier to keep track of which user slots are empty and which user slots are not.

Relay Codes Assignment

When a primary code is enrolled for any user, the user is authorized to activate the Lock Strike relay. However, different user codes may be set to operate the auxiliary relay instead or operate both the Lock strike and auxiliary relay. Assignment of such codes is achievable for any valid user code entered in the controller.

There are two methods to assign relay codes to users: a standard method and a search method.











Relay Code Assignment using Standard Method

- 1) Enter the programming mode.

- 2) Depress 9 to enter Menu 9.

 - The Mode LED will turn green.

 - The Door LED will turn orange.
- 3) Enter the 3-digit user slot for code assignment.

 - The Mode LED will flash green.
- 4) Enter the assignment digit for the current user slot:
 - 1 will activate the Lock Strike relay only default

 - 2 will activate the Auxiliary relay only

 - 3 will activate the Lock Strike and Auxiliary relays.

If the assignment code is valid, the Mode indicator will stop flashing.

The controller is now waiting for another slot number. Depress the # key to move to the next slot or enter a new slot number. If you do not wish to continue, depress the # key twice and the controller will return to its normal mode.

Relay Code Assignment using Search Method

- 1) Enter the programming mode.
Mode/Transmit  **Door/Program** 
Green
 - 2) Depress 9 to enter Menu 9.
Mode/Transmit 
 - The Mode LED will turn green.
 - The Door LED will turn orange.**Mode/Transmit**  **Door/Program** 
Green Orange
 - 3) Enter 000 for user slot access.

 - The Door LED will flash orange.**Mode/Transmit**   **Door/Program**
Green Orange
- The controller is now waiting for the primary code of the user.
- 4) Enter the primary code belonging to the user.
Mode/Transmit   **Door/Program**
Green Orange
 - The Mode LED will flash green.
 - 5) Enter the assignment digit for the current user slot:
 - 1 will activate the Lock Strike relay only default
 - 2 will activate the Auxiliary relay only
 - 3 will activate the Lock Strike and Auxiliary relays.

If the assignment digit is *valid*, three beeps will be heard and the controller will return to its normal mode.



If the assignment digit is *invalid*, a long beep will sound and the controller will wait for another assignment digit to be entered.

Pin Code Length / Factory Default Settings



Warning:



- You must be very careful before using this command! Changing the pin code length will also erase the entire memory contents, including all user and special codes, and return all codes to their factory-default settings

- Enter the Programming Mode. **Mode/Transmit**  **Door/Program**  **Green**
- Select the desired pin code length as follows:
 - 00 - Returns to factory defaults and sets a 4 digit code.
 - 05 - Returns to factory defaults and sets a 5 digit code.
 - 06 - Returns to factory defaults and sets a 6 digit code.
 - 08 - Returns to factory defaults and sets a 4-8 digit code.



Note:

- When choosing the 4-8 option, please note that you should either enter zeros before the code, or press pound at the end (for example if your code is 12345, enter either 00012345 or 12345#).

- Both the Mode and Door LEDs will flash red. **Mode/Transmit**  **Door/Program**  **Red Red**
- Enter your 4-8 digits Programming Code. **Mode/Transmit** **Door/Program**
 - If the Programming Code is valid, all memory will be erased. You will hear three beeps and the controller will return to Normal Mode.
 - If the Programming Code is invalid you will hear a long beep and the controller will return to Normal Mode without erasing the memory contents.

Replacing a Lost Programming Code



Note:

- The AYC- F/G/M60 must be in Normal mode, otherwise this will not work. Make sure that the Mode LED is green before proceeding.

- 1) Remove power from the Power Supply Unit.
- 2) Press the REX Button on the Power Supply Unit.
- 3) Apply power to the unit with REX button pressed.
- 4) Release the REX Button.
- 5) You now have 15 seconds to program a new Programming code into the Access Control unit using the default code based on the PIN code length you chose (see Programming Menu on page 34), before the controller reverts to the existing code.

Replacing a Lost Normal / Secure Code



Note:

- The AYC- F/G/M60 must be in Secure Mode, otherwise this will not work. Make sure that the Mode LED is red before proceeding.

- 1) Remove power from the Power Supply Unit.
- 2) Press the REX Button on the Power Supply Unit.
- 3) Apply power to the unit with the REX button pressed.
- 4) Release the REX Button.
- 5) You now have 15 seconds to program a new Normal / Secure code into the Access Control unit using the default code based on the PIN code length you chose (see Programming Menu on page 34), before the controller reverts to the existing code.

Appendix A. Limited Warranty

ROSSLARE ENTERPRISES LIMITED S (Rosslare) FIVE YEARS LIMITED WARRANTY is applicable worldwide. This warranty supersedes any other warranty. Rosslare's FIVE YEARS LIMITED WARRANTY is subject to the following conditions:

Warranty

Warranty of Rosslare's products extends to the original purchaser (Customer) of the Rosslare product and is not transferable.

Products Covered By This Warranty and Duration

ROSSLARE ENTERPRISES LTD. AND / OR SUBSIDIARIES (ROSSLARE) warrants that the AYC-Qx4, metal convertible reader / secured controller family as listed above, to be free from defects in materials and assembly in the course of normal use and service. The warranty period commences with the date of shipment to the original purchaser and extends for a period of 5 years (60 Months).

Warranty Remedy Coverage

In the event of a breach of warranty, ROSSLARE will credit Customer with the price of the Product paid by Customer, provided that the warranty claim is delivered to ROSSLARE by the Customer during the warranty period in accordance with the terms of this warranty. Unless otherwise requested by ROSSLARE ENTERPRISES LTD. AND / OR SUBSIDIARIES representative, return of the failed product(s) is not immediately required. If ROSSLARE has not contacted the Customer within a sixty (60) day holding period following the delivery of the warranty claim, Customer will not be required to return the failed product(s). All returned Product(s), as may be requested at ROSSLARE ENTERPRISES LTD. AND /OR SUBSIDIARY'S sole discretion, shall become the property of ROSSLARE ENTERPRISES LTD. AND /OR SUBSIDIARIES.

To exercise the warranty, the user must contact Rosslare Enterprises Ltd. to obtain an RMA number after which, the product must be returned to the Manufacturer freight prepaid and insured

In the event ROSSLARE chooses to perform a product evaluation within the sixty (60) day holding period and no defect is found, a minimum US\$ 50.00 or equivalent charge will be applied to each Product for labor required in the evaluation.

Rosslare will repair or replace, at its discretion, any product that under normal conditions of use and service proves to be defective in material or workmanship. No charge will be applied for labor or parts with respect to defects covered by this warranty, provided that the work is done by Rosslare or a Rosslare authorized service center.

Exclusions and Limitations

ROSSLARE shall not be responsible or liable for any damage or loss resulting from the operation or performance of any Product or any systems in which a Product is incorporated. This warranty shall not extend to any ancillary equipment not furnished by ROSSLARE, which is attached to or used in conjunction with a Product, nor to any Product that is used with any ancillary equipment, which is not furnished by ROSSLARE.

This warranty does not cover expenses incurred in the transportation, freight cost to the repair center, removal or reinstallation of the product, whether or not proven defective. Specifically excluded from this warranty are any failures resulting from Customer's improper testing, operation, installation, or damage resulting from use of the Product in other than its normal and customary manner, or any maintenance, modification, alteration, or adjustment or any type of abuse, neglect, accident, misuse, improper operation, normal wear, defects or damage due to lightning or other electrical discharge. This warranty does not cover repair or replacement where normal use has exhausted the life of a part or instrument, or any modification or abuse of, or tampering with, the Product if Product disassembled or repaired in such a manner as to adversely affect performance or prevent adequate inspection and testing to verify any warranty claim.

ROSSLARE does not warrant the installation, maintenance, or service of the Product. Service life of the product is dependent upon the care it receives and the conditions under which it has to operate.

In no event shall Rosslare be liable for incidental or consequential damages.

Limited Warranty Terms

THIS WARRANTY SETS FORTH THE FULL EXTENT OF ROSSLARE ENTERPRISES LTD. AND IT'S SUBSIDIARY'S WARRANTY

THE TERMS OF THIS WARRANTY MAY NOT BE VARIED BY ANY PERSON, WHETHER OR NOT PURPORTING TO REPRESENT OR ACT ON BEHALF OF ROSSLARE.

THIS LIMITED WARRANTY IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES. ALL OTHER WARRANTIES EXPRESSED OR IMPLIED, INCLUDING WITHOUT LIMITATION, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE SPECIFICALLY EXCLUDED.

IN NO EVENT SHALL ROSSLARE BE LIABLE FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT, OR FOR ANY OTHER INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES, INCLUDING BUT NOT LIMITED TO LOSS OF USE, LOSS OF TIME, COMMERCIAL LOSS, INCONVENIENCE, AND LOSS OF PROFITS, ARISING OUT OF THE INSTALLATION, USE, OR INABILITY TO USE SUCH PRODUCT, TO THE FULLEST EXTENT THAT ANY SUCH LOSS OR DAMAGE MAY BE DISCLAIMED BY LAW.

THIS WARRANTY SHALL BECOME NULL AND VOID IN THE EVENT OF A VIOLATION OF THE PROVISIONS OF THIS LIMITED WARRANTY.

FCC NOTE

This device complied with Part15of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

Appendix B. Technical Support

Asia Pacific, Middle East, Africa

Rosslare Security Products Headquarters
905-912 Wing Fat Industrial Bldg,
12 Wang Tai Road,
Kowloon Bay Hong Kong
Tel: +852 2795-5630
Fax: +852 2795-1508
E-mail: support.apac@rosslaresecurity.com

United States and Canada

1600 Hart Court, Suite 103
Southlake, TX, USA 76092
Toll Free: +1-866-632-1101
Local: +1-817-305-0006
Fax: +1-817-305-0069
E-mail: support.na@rosslaresecurity.com

Europe

Global Technical Support & Training Center
HaMelecha 22
Rosh HaAyin, Israel 48091
Tel: +972 3 938-6838
Fax: +972 3 938-6830
E-mail: support.eu@rosslaresecurity.com

South America

Pringles 868, 1640 Martinez
Buenos Aires
Argentina
Tel: +54 11 4798-0095
Fax: +54 11 4798-2228
E-mail: support.la@rosslaresecurity.com

Web Site: www.rosslaresecurity.com