



Outdoor Access Point Release 106.0

User Guide

Part Number: 800-71621-001 Rev A
Published: 20 June 2017

www.ruckuswireless.com

Copyright Notice and Proprietary Information

Copyright 2017. Ruckus Wireless, Inc. All rights reserved.

No part of this documentation may be used, reproduced, transmitted, or translated, in any form or by any means, electronic, mechanical, manual, optical, or otherwise, without prior written permission of Ruckus Wireless, Inc. ("Ruckus"), or as expressly provided by under license from Ruckus.

Destination Control Statement

Technical data contained in this publication may be subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

Disclaimer

THIS DOCUMENTATION AND ALL INFORMATION CONTAINED HEREIN ("MATERIAL") IS PROVIDED FOR GENERAL INFORMATION PURPOSES ONLY. RUCKUS AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THE MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT AND FITNESS FOR A PARTICULAR PURPOSE, OR THAT THE MATERIAL IS ERROR-FREE, ACCURATE OR RELIABLE. RUCKUS RESERVES THE RIGHT TO MAKE CHANGES OR UPDATES TO THE MATERIAL AT ANY TIME.

Limitation of Liability

IN NO EVENT SHALL RUCKUS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES, OR DAMAGES FOR LOSS OF PROFITS, REVENUE, DATA OR USE, INCURRED BY YOU OR ANY THIRD PARTY, WHETHER IN AN ACTION IN CONTRACT OR TORT, ARISING FROM YOUR ACCESS TO, OR USE OF, THE MATERIAL.

Trademarks

Ruckus Wireless, Ruckus, the bark logo, BeamFlex, ChannelFly, Dynamic PSK, FlexMaster, Simply Better Wireless, SmartCell, SmartMesh, SmartZone, Unleashed, ZoneDirector and ZoneFlex are trademarks of Ruckus Wireless, Inc. in the United States and other countries. All other product or company names may be trademarks of their respective owners.

About This Guide

This guide describes how to configure and manage Release 100.4 Ruckus Wireless Outdoor Access Points (APs). This guide is written for those responsible for managing network equipment. Consequently, it assumes that the reader has basic working knowledge of local area networking, wireless networking, and wireless devices.

NOTE By downloading this software and subsequently upgrading Ruckus Wireless APs to base image 100.0.0 and later, please be advised that:

- The ZoneDirector periodically connects to Ruckus and Ruckus collects the ZoneDirector serial number, software version and build number. Ruckus transmits a file back to the ZoneDirector and this is used to display the current status of the ZoneDirector Support Contract.
- The AP may send a query to Ruckus containing the AP's serial number. This allows your AP to autonomously connect with a wireless LAN controller operated by your choice of cloud service provider. Ruckus may transmit the Fully Qualified Domain Name (FQDN) or IP address of the controller that the AP will subsequently attempt to join back to the AP.
- Please be advised that this information may be transferred and stored outside of your country of residence where data protection standards may be different.

NOTE This guide assumes that the Ruckus Wireless Outdoor APs have already been installed as described in the corresponding *Quick Setup Guide*, *Getting Started Guide*, *Mounting Guide* or *Installation Guide*. Refer to the *Quick Setup Guide*, *Getting Started Guide*, *Mounting Guide* or *Installation Guide* that shipped with your product for model-specific instructions.

NOTE If release notes are available for your product and the information there differs from the information in this guide, follow the instructions in the release notes.

Most user guides and release notes are available in Adobe Acrobat Reader Portable Document Format (PDF) or HTML on the Ruckus Wireless Support website: <https://support.ruckuswireless.com/documents>.

Safety Warnings

WARNING! Only trained and qualified personnel should be allowed to install, replace, or service this equipment. The professional installer is responsible for the proper installation and configuration of this AP. The AP installation must comply with local regulatory requirements, especially with those regulating operation near military and/or weather radar systems.

WARNING! Installation of this equipment must comply with local and national electrical codes.

WARNING! Do not operate your wireless device near unshielded blasting caps or in an explosive environment unless the device has been modified to be especially qualified for such use.

WARNING! In order to comply with FCC radio frequency (RF) exposure limits, antennas should be located at a minimum of 7.9 inches (20 cm) or more from the body of all persons.

WARNING! Ruckus Wireless strongly recommends that you wear eye protection before mounting the AP.

CAUTION! Make sure that you form a 80mm - 130mm (3"-5") drip loop in any cable that is attached to the AP or the building. This will prevent water from running along the cable and entering the AP or the building where the cable terminates.

CAUTION! Be sure that grounding is available and that it meets local and national electrical codes. For additional lightning protection, use lightning rods and lightning arrestors.

NOTE Allowable external antenna types and antenna gains may be limited by local regulatory requirements.

Related Documentation

In addition to this User Guide, each Ruckus Wireless AP documentation set includes the following:

- *Quick Setup Guide/Getting Started Guide/Mounting Guide/Installation Guide*: Provides essential installation and configuration information to help you get the AP up and running within minutes.
- *Online Help*: Provides instructions for performing tasks using the AP's web interface. Online help is accessible from within the web interface.
- *Release Notes*: Provide information about the current software release, including new features, enhancements, and known issues.

NOTE For information on configuration and management of Ruckus Wireless access points supported by SmartZone (SZ) or ZoneDirector (ZD) controllers, or FlexMaster server, refer to their respective user documents.

Contents

Copyright Notice and Proprietary Information.....	2
About This Guide.....	3
Safety Warnings.....	4
Related Documentation.....	5

1 Introduction

Overview of the Ruckus Wireless AP.....	8
Installing the Access Point.....	8
Controller Discovery and Standalone Operation.....	9
Getting to Know the Access Point Features.....	10
7781-CM.....	10
7782.....	16
7782-E.....	18
7782-N.....	21
7782-S.....	23
T300.....	25
T300e.....	28
T301n.....	32
T301s.....	35
T610.....	38
T610s.....	43
T710.....	46
T710s.....	51

2 Navigating the Web Interface

Navigating the Web Interface.....	56
When Using a Dual-Band AP.....	57

3 Configuration

Configuring the AP for Management by ZoneDirector.....	58
Configuring the AP for Management by a SmartZone Controller.....	58
Configuring the Access Point for Standalone Operation or Management by FlexMaster.....	58
Configuring Device Settings.....	59
Configuring Internet Settings.....	61
Configuring Local Subnets.....	67

Configuring Wireless Settings.....	69
Configuring Ethernet Ports.....	87
Configuring Hotspot Service.....	93

4 Administration

Managing the Access Point.....	100
Viewing Current Device Settings.....	100
Viewing Current Internet Connection Settings.....	100
Viewing Current Local Subnet Settings.....	101
Viewing Common Wireless Settings.....	102
Viewing Associated Wireless Clients.....	103
Changing the Administrative Login Settings.....	104
Enabling Other Management Access Options.....	105
Working with Event Logs and Syslog Servers.....	111
Upgrading the Firmware.....	113
Rebooting the AP and Cable Modem.....	115
Resetting the AP to Factory Defaults.....	116
Running Diagnostics.....	117
Where to Find More Information.....	118
Appendix A: Support for Bluetooth Low Energy Devices	
Appendix B: Configuring Link Aggregation (LACP) for AP Backhaul	

Overview of the Ruckus Wireless AP

Congratulations on your purchase of a Ruckus Wireless access point!

Ruckus Wireless APs are the industry's most easy to use, yet robust and feature-rich Wi-Fi APs designed to bring power and simplicity together for large-scale outdoor deployments.

Your Ruckus Wireless AP uses BeamFlex, a patented antenna technology from Ruckus Wireless that allows wireless signals to navigate around interference, extend wireless signal range, and increase speeds and capacity for wireless networks. The BeamFlex antenna system consists of an array of high-gain directional antenna elements that allow Ruckus Wireless APs to find quality signal paths in a changing environment, and sustain the baseline performance required for supporting data, audio and video applications.

Your Ruckus Wireless AP can be deployed in standalone mode with or without a FlexMaster (FM) manager, or as part of the Ruckus Wireless Smart WLAN system, in which it can be managed by ZoneDirector (ZD), SmartCell Gateway (SCG), SmartZone (SZ), and virtual SmartZone (vSZ) controllers.

NOTE For more information on the Ruckus Wireless system, including ZoneDirector, SmartZone, FlexMaster, BeamFlex, and other Ruckus Wireless technologies, visit www.ruckuswireless.com

Installing the Access Point

This User Guide assumes that the Ruckus Wireless outdoor APs have already been installed and have already been initially configured as described in the corresponding *Quick Setup Guide*, *Getting Started Guide*, *Mounting Guide* or *Installation Guide*.

NOTE DO NOT connect the AP to your live network when first connecting the AP to an administrative computer. If you connect it to a live network with an active DHCP server, then the AP can acquire a new IP address from DHCP and you will be unable to access it via the default IP address (192.168.0.1). If the AP has a new IP address, then reset the AP to the factory configuration as described in the corresponding mounting or installation guide.

Because of different mounting and wiring procedures, each outdoor AP model has its own *Quick Setup Guide*, *Getting Started Guide*, *Mounting Guide* or *Installation Guide*. Refer to the guide(s) that shipped with your product for model-specific installation instructions. These documents are available from support.ruckuswireless.com.

Controller Discovery and Standalone Operation

Ruckus Wireless Access Points can operate in either standalone mode, be managed by FlexMaster server, or be managed by any of the Ruckus controller products.

How Standalone APs Learn Controller Addresses

If your AP will be managed by a controller, you will need some way to ensure that the AP can discover the controller on the network. There are several different ways to do this, and the specific controller user documents contain more details on discovery for that particular controller product family.

This section provides a brief overview of the options available for controller discovery.

Ruckus Cloud

Ruckus APs discover Ruckus Cloud controllers by querying the Ruckus Cloud AP Registrar (ap-registrar.ruckuswireless.com) via HTTPS to learn the Ruckus Cloud address. APs will search for a Ruckus Cloud controller more frequently after initial boot up, and less frequently after the first 14 days.

Standalone APs will query the Registrar with the following frequency:

Table 1: How often APs query the Registrar to learn Ruckus Cloud controller addresses

Query Frequency	AP Uptime
15 seconds	< 1 hour
5 minutes	1 hours ~ 48 hours
1 hour	2 days ~ 14 days
12 hours	14 days ~ forever

SmartZone

APs discover SmartZone controllers using any of the following methods:

- mDNS discovery on local IP subnet
- DHCP Option 43 sub-option 6
- DHCPv6 Option 17 sub-option 6
- DHCPv6 Option 52
- DNS entry named "ruckuscontroller.<local domain>"
- AP CLI command "set scg ip"

ZoneDirector

APs discover ZoneDirector controllers using any of the following methods:

Introduction

Getting to Know the Access Point Features

- IP subnet broadcast
- DHCP Option 43 sub-option 3
- DHCPv6 Option 17 sub-option 3
- DHCPv6 Option 52
- DNS entry named "zonedirector.<local domain>"
- AP CLI command "set director ip"

Getting to Know the Access Point Features

This section identifies the physical features of each Ruckus Wireless AP model that is discussed in this guide. Ruckus Wireless recommends that you become familiar with these features.

NOTE This guide does not include information on Ruckus Wireless Indoor APs, or the 7731 or P300 Wireless Bridges. For information on those Ruckus AP models, along with Ruckus Wireless ZoneDirector and SmartZone controllers, FlexMaster, and other product lines, refer to their respective user documentation available from support.ruckuswireless.com.

This release supports the following outdoor AP models:

- [7781-CM](#) on page 10
- [7782](#) on page 16
- [7782-E](#) on page 18
- [7782-N](#) on page 21
- [7782-S](#) on page 23
- [T300](#) on page 25
- [T300e](#) on page 28
- [T301n](#) on page 32
- [T301s](#) on page 35
- [T610](#) on page 38
- [T610s](#) on page 43
- [T710](#) on page 46
- [T710s](#) on page 51

7781-CM

The 7781-CM is a Dual Band 802.11n Outdoor Access Point with integrated DOCSIS 3.0 Cable Modem.

NOTE The 100.x AP base images support standalone mode and FlexMaster (FM) WLAN manager operation. The SmartZone-compatible images only support SCG, vSCG, and SZ controllers. The ZD-compatible images only support ZD controllers.

NOTE The 7781-CM requires a minimum of AP base image 100.0.0 and later to operate, or SCG 1.1.1 and later, vSCG 2.5 and later, RuckOS 3.2 and later, or ZoneDirector 9.5.1 and later to operate.

The following figures identify the 7781-CM AP with integrated Cable Modem AP (7781-CM) external features.

- The 901-7781-US01 and 901-7781-WW01 DOCSIS 7781-CM and the 901-7781-JP21 JCTEA DOCSIS 7781-CM include a shroud and cable clamps to mount the 7781-CM on strand support cables.
- The 901-7781-WW11 EuroDOCSIS 7781-CM does not include a shroud or cable clamps, and are mounted using customer-supplied mounting brackets.




Figure 1: 7781-CM connectors

Table 2: 7781-CM connectors

Label	Description
Ethernet Port (under blanking cap)	RJ-45 port that supports 10/100/1000Mbps connections and provides 802.3af-compliant (15.4W) Power over Ethernet (PoE) output power to external devices. PoE output (and internal CM heater, if equipped) are only supported when the 7781-CM receives Power Over Cable (POC) from the HFC cable plant.

Introduction

Getting to Know the Access Point Features

Label	Description
Reset Button (under blanking cap)	Refer to the 7781-CM Cable Modem Access Point Installation Guide to access the reset button and either reboot the AP or reset the AP to factory defaults.
DC Connector (under blanking cap)	In addition to the power supplied by the coaxial cable from the cable modem termination system (CMTS) equipment, the 7781-CM can also be DC powered for configuration before field deployment.
Coaxial Cable Connector B	Connects to the CMTS at the headend using a tap on the plant, and provides AC POC to the 7781-CM. For more information, refer to the 7781-CM Cable Modem Access Point Installation Guide.



Figure 2: 7781-CM LEDs

Reading the 7781-CM LEDs

The six dual-purpose LEDs are used both by the CM part and the AP part of the 7781-CM:

- When LED 1 (green LED) is lit, the LEDs are in Access Point mode.
- When LED 2 (white LED) is lit, the LEDs are in Cable Modem mode.

While the 7781-CM is booting up, the LEDs are in CM mode. Once bootup is completed, the LEDs alternate between CM and AP modes.

NOTE The 7781-CM LEDs turn off after a while. This is normal operation.

LED Boot Sequence

1. All LEDs blink for a few seconds.
2. LED 2 (white) stays solid on.
3. LEDs 3, 4, 5 and 6 (blue, middle green, yellow and red) blink in sequence.
4. LEDs 4, 5 and 6 (middle green, yellow and red) blink together for a few seconds.
5. LED 3 (blue) goes solid when the link to the AP is established.
6. LED 6 (red) flashes as CM tries to acquire downstream.
 - LED 6 (red) goes solid when downstream is acquired.
 - LED 3 (blue) flashes to indicate communication across the AP link.
7. LED 5 (yellow) comes on solid when upstream acquired.
8. LED 4 (middle green) on indicates that cable modem came on-line successfully.

LED Online/Steady State

- LED 1 (green) on indicates AP mode.
- LED 2 (white) on indicates CM mode.
- LEDs 3, 4, 5 and 6 (blue, middle green, yellow and red) are on.

The LEDs alternate between CM and AP modes.

NOTE The 7781-CM LEDs turn off after a while. This is normal operation.

Reading LEDs in Access Point Mode

In AP mode, LED 1 (green LED) is lit.

NOTE The LEDs do not indicate whether the AP is in standalone mode or if ZoneDirector is managing the AP. To check if ZoneDirector is managing the AP, log into the ZoneDirector web interface, go to the Monitor > Access Points page, and then search

Introduction

Getting to Know the Access Point Features

for the AP's MAC address. If you are unable to find the AP, then it is very likely in standalone mode. If you have multiple ZoneDirector devices on the network, make sure you check each one of them.

For Cable Operators, APs will typically be in ZoneDirector mode after initial boot. If the AP is unable to reach the ZoneDirector on initial boot, it remains in standalone mode.

The following table provides a summary of AP mode LED behavior.

Table 3: 7781-CM LED behavior in AP Standalone and ZoneDirector modes

LED	State	AP Standalone Mode	AP ZoneDirector Mode
1	Solid Green	On = AP Mode.	On = AP Mode.
2	OFF	Off = Not AP Mode.	Off = Not AP Mode.
3	Solid Blue	At least one 5GHz wireless client is associated with the access point and signal strength is weak.	If AP is RAP, at least one MAP is associated. If AP is MAP it is associated with a RAP. Signal strength is weak.
4	Flashing Green	5GHz WLAN is up but no clients.	5GHz WLAN is up but no clients.
	Solid Green	At least one 5GHz wireless client is associated with the access point and signal strength is strong.	If AP is RAP, at least one MAP is associated. If AP is MAP it is associated with a RAP. Signal strength is strong.
5	Solid Yellow	At least one 2.4GHz wireless client is associated with the access point and signal strength is weak.	At least one 2.4GHz wireless client is associated with the access point and signal strength is weak.

LED	State	AP Standalone Mode	AP ZoneDirector Mode
6	Flashing Red	2.4GHz WLAN is up but no clients.	2.4GHz WLAN is up but no clients.
	Solid Red	At least one 2.4GHz wireless client is associated with the access point and signal strength is strong.	At least one 2.4GHz wireless client is associated with the access point and signal strength is strong.

Reading LEDs in Cable Modem Mode

In CM mode, LED 2 (white LED) is always lit. Refer to the following table for a summary of CM mode LED behavior.

Table 4: 7781-CM LED behavior in CM mode

LED	State	Meaning
1	OFF	Off = Not CM Mode.
2	Solid White	On = CM Mode.
3	Solid Blue	Link
4	Solid Green	On line
5	Solid Yellow	Upstream acquired
6	Flashing Red	Searching for downstream
	Solid Red	Downstream acquired

Powering Options

The 7781-CM supports both DC power or AC power over cable (POC). Normally 12 VDC power is only used at the depot or when debugging. 40 to 90 VAC POC is only used when the 7781-CM is mounted on a cable strand and powered via an F-type coaxial cable connected to the HFC cable plant.

The customer-ordered 1.5A 12 VDC power supply part number is 902-0169-xyyy, where xx = Country and yy = revision.

NOTE The 7781-CM does not provide PoE output or support internal heater operation when powered by 12 VDC.

Introduction

Getting to Know the Access Point Features

Cable Modem Heater

The 901-7781-US01, 901-7781-JP21 and 901-7781-WW01 7781-CM includes a built-in heater for the cable modem that permits operation at extremely low temperatures. The heater is typically on below -10° C (14° F). The heater is powered by POC only. When the 7781-CM is powered by 12 VDC, the heater is disabled.

The 901-7781-WW11 EuroDOCSIS 7781-CM does not include a built-in heater.

7781-CM Operation

Refer to the *7781-CM Cable Modem Access Point Installation Guide* for information on Cable Modem configuration and operation.

7782

The 7782 is a carrier-class dual-band 2.4/5GHz 802.11n Access Point designed for high-density outdoor applications.

NOTE The standalone AP 100.x base images support standalone mode and FlexMaster (FM) WLAN manager operation. The SmartZone-compatible AP images only support SCG, vSCG, and SZ controllers. The ZD-compatible images only support ZD controllers.

NOTE The 7782 requires a minimum of AP base image 100.0 and later to operate, or SCG 1.1.1 and later, vSCG 2.5 and later, SZ 3.2 and later, or ZD 9.5.1 and later to operate.

The following figure identifies the connectors and LEDs on the 7782 Omni AP. The table below describes the LEDs and connectors.




Figure 3: 7782 connectors and LEDs - bottom view

Table 5: 7782 LED and connector descriptions

Label	Description
PoE IN RJ45 data connector	Supports 10/100/1000Mbps connections, connects to the network and receives 802.at Power over Ethernet (PoE) from the Ruckus Wireless 60W PoE injector.
PoE OUT RJ45 data connector	Supports 10/100/1000Mbps connections and PoE out. If the AP is powered using AC or the Ruckus Wireless PoE injector (ordered separately), then this port can supply 802.3af (up to 25W) PoE to a connected PoE-capable device (for example, a 3G/4G small cell radio or an IP-based surveillance camera). For devices requiring more than 15.4W, use short (less than 10 feet or 3m) Ethernet cables. In high-temperature environments, the amount of power available is to be determined.
Reset button	This button is inside the PoE OUT cable gland. Refer to the <i>7782 Outdoor Access Point Installation Guide</i> to access the reset button and reset the AP.
AC IN power connector	You can use AC to supply power to the AP, in addition to using PoE.

Introduction

Getting to Know the Access Point Features

Label	Description
STATUS LED	<p>When the AP is operating in standalone mode:</p> <ul style="list-style-type: none">• Amber: The WLAN service is up and at least one wireless client is associated with the AP.• Flashing amber: The WLAN service is up and no wireless clients are currently associated with the AP. <p>When the AP is being managed by Ruckus Wireless ZoneDirector:</p> <ul style="list-style-type: none">• Green: The AP is part of a mesh network (either as Root AP or Mesh AP) and is connected to an uplink with good signal. If mesh networking is disabled but the WLAN service is available, the Status LED is also green.• Fast flashing green: The AP is part of a mesh network (as Mesh AP) and is connected to an uplink with fair signal.• Slow flashing green: This Mesh AP is searching for an uplink or is attempting to establish communication with ZoneDirector.• Off: Mesh networking is disabled and the WLAN service is unavailable.
POWER LED	<ul style="list-style-type: none">• Off: No power is available, or the AP is not connected to a power source.• Red: The AP is powering on.• Green: The AP is connected to a power source and has completed its power-on sequence.

7782-E


The 7782-E is a carrier-class dual-band 2.4/5GHz 802.11n Access Point with external antenna connectors designed for high-density outdoor applications.

NOTE The 100.x AP base images support standalone mode and FlexMaster (FM) WLAN manager operation. The RuckOS-compatible images only support SCG, vSCG, and SZ controllers. The ZD-compatible images only support ZD controllers.

NOTE The 7782-E requires a minimum of AP base image 100.0 and later to operate, or SCG 1.1.1 and later, vSCG 2.5 and later, RuckOS 3.2 and later, or ZD 9.5.1 and later to operate.

The following figures identify the connectors and LEDs on the bottom and top of the 7782-E External Antenna AP, respectively.

If you want to extend the range of your wireless network, then you can connect external high gain antennas to the standard N-type radio frequency (RF) antenna connectors on the top panel of the AP. The antennas must have a gain of less than 9dBi to comply with FCC and CE regulations.



Introduction

Getting to Know the Access Point Features

Figure 4: 7782-E connectors and LEDs - bottom view




Figure 5: 7782-E AP top-panel N-type connectors

Table 6: 7782-E top-panel N-type connectors

Label	Description
5GHz connectors: ANT 0, ANT 1 and ANT 2	<p>These 5GHz 50-ohm female connectors can be used with up to three external antennas for operator-defined coverage areas and point-to-point deployments.</p> <ul style="list-style-type: none">• When you are connecting two 5GHz antennas to the AP, use the ANT 0 and ANT 2 5GHz connectors.• When you are connecting three 5GHz antennas to the AP, use the all three ANT 0, ANT 1 and ANT 2 5GHz connectors.

Label	Description
2.4GHz connectors: ANT 0, ANT 1 and ANT 2	<p>These 2.4GHz 50-ohm female connectors can be used with up to three external antennas for operator-defined coverage areas and point-to-point deployments.</p> <ul style="list-style-type: none"> • When you are connecting two 2.4GHz antennas to the AP, use the ANT 0 and ANT 2 2.4GHz connectors. • When you are connecting three 2.4GHz antennas to the AP, use the all three ANT 0, ANT 1 and ANT 2 2.4GHz connectors.
GPS connector	<p>This 50-ohm female N-type connector is used for a standard powered external GPS antenna. The factory-supplied GPS antenna kit complies with all 7782-E AP requirements. If you are installing a customer-supplied antenna and extension cable, then keep the cable short or use low-loss cable to avoid excess signal attenuation. The 7782-E supplies 3.3 VDC to the GPS antenna; make sure that a customer-supplied GPS antenna does not require more than 150mA.</p>

7782-N

The 7782-N is a carrier-class dual-band 2.4/5GHz 802.11n Access Point with narrow beam sector antenna designed for high-density outdoor applications.

NOTE The 100.x AP base images support standalone mode and FlexMaster (FM) WLAN manager operation. The RuckOS-compatible images only support SCG, vSCG, and SZ controllers. The ZD-compatible images only support ZD controllers.

NOTE The 7782-N requires a minimum of AP base image 100.0.0 and later to operate, or SCG 1.1.1 and later, vSCG 2.5 and later, RuckOS 3.2 and later, or ZD 9.5.1 and later to operate.

The following figure identifies the connectors and LEDs on the 7782-N 30-Degree Narrow Sector AP. The table below describes the LEDs and connectors.

Introduction

Getting to Know the Access Point Features




Figure 6: 7782-N connectors and LEDs - bottom view

Table 7: 7782-N LED and connector descriptions

Label	Description
PoE IN RJ45 data connector	Supports 10/100/1000Mbps connections, connects to the network and receives 802.3af Power over Ethernet (PoE) from the Ruckus Wireless 60W PoE injector.
PoE OUT RJ45 data connector	Supports 10/100/1000Mbps connections and PoE out. If the AP is powered using AC or the Ruckus Wireless PoE injector (ordered separately), then this port can supply 802.3af (up to 25W) PoE to a connected PoE-capable device (for example, a 3G/4G small cell radio or an IP-based surveillance camera). For devices requiring more than 15.4W, use short (less than 10 feet or 3m) Ethernet cables. In high-temperature environments, the amount of power available is to be determined.
Reset button	This button is inside the PoE OUT cable gland. Refer to the <i>7782 Outdoor Access Point Installation Guide</i> to access the reset button and reset the AP.
AC IN power connector	You can use AC to supply power to the AP, in addition to using PoE.

Label	Description
STATUS LED	<p>When the AP is operating in standalone mode:</p> <ul style="list-style-type: none"> • Amber: The WLAN service is up and at least one wireless client is associated with the AP. • Flashing amber: The WLAN service is up and no wireless clients are currently associated with the AP. <p>When the AP is being managed by Ruckus Wireless ZoneDirector:</p> <ul style="list-style-type: none"> • Green: The AP is part of a mesh network (either as Root AP or Mesh AP) and is connected to an uplink with good signal. If mesh networking is disabled but the WLAN service is available, the Status LED is also green. • Fast flashing green: The AP is part of a mesh network (as Mesh AP) and is connected to an uplink with fair signal. • Slow flashing green: This Mesh AP is searching for an uplink or is attempting to establish communication with ZoneDirector. • Off: Mesh networking is disabled and the WLAN service is unavailable.
POWER LED	<ul style="list-style-type: none"> • Off: No power is available, or the AP is not connected to a power source. • Red: The AP is powering on. • Green: The AP is connected to a power source and has completed its power-on sequence.

7782-S

The 7782-S is a carrier-class dual-band 2.4/5GHz 802.11n Access Point with wide beam sector antenna designed for high-density outdoor applications.

NOTE The 100.x AP base images support standalone mode and FlexMaster (FM) WLAN manager operation. The RuckOS-compatible images only support SCG, vSCG, and SZ controllers. The ZD-compatible images only support ZD controllers.

NOTE The 7782-S requires a minimum of AP base image 100.0.0 and later to operate, or SCG 1.1.1 and later, vSCG 2.5 and later, RuckOS 3.2 and later, or ZD 9.5.1 and later to operate.

The following figure identifies the connectors and LEDs on the 7782-S 120-Degree Sector AP. The table below describes the LEDs and connectors.

Introduction

Getting to Know the Access Point Features




Figure 7: 7782-S connectors and LEDs - bottom view

Table 8: 7782-S LED and connector descriptions

Label	Description
PoE IN RJ45 data connector	Supports 10/100/1000Mbps connections, connects to the network and receives 802.at Power over Ethernet (PoE) from the Ruckus Wireless 60W PoE injector.
PoE OUT RJ45 data connector	Supports 10/100/1000Mbps connections and PoE out. If the AP is powered using AC or the Ruckus Wireless PoE injector (ordered separately), then this port can supply 802.3af (up to 25W) PoE to a connected PoE-capable device (for example, a 3G/4G small cell radio or an IP-based surveillance camera). For devices requiring more than 15.4W, use short (less than 10 feet or 3m) Ethernet cables. In high-temperature environments, the amount of power available is to be determined.
Reset button	This button is inside the PoE OUT cable gland. Refer to the <i>7782 Outdoor Access Point Installation Guide</i> to access the reset button and reset the AP.
AC IN power connector	You can use AC to supply power to the AP, in addition to using PoE.

Label	Description
STATUS LED	<p>When the AP is operating in standalone mode:</p> <ul style="list-style-type: none"> • Amber: The WLAN service is up and at least one wireless client is associated with the AP. • Flashing amber: The WLAN service is up and no wireless clients are currently associated with the AP. <p>When the AP is being managed by Ruckus Wireless ZoneDirector:</p> <ul style="list-style-type: none"> • Green: The AP is part of a mesh network (either as Root AP or Mesh AP) and is connected to an uplink with good signal. If mesh networking is disabled but the WLAN service is available, the Status LED is also green. • Fast flashing green: The AP is part of a mesh network (as Mesh AP) and is connected to an uplink with fair signal. • Slow flashing green: This Mesh AP is searching for an uplink or is attempting to establish communication with ZoneDirector. • Off: Mesh networking is disabled and the WLAN service is unavailable.
POWER LED	<ul style="list-style-type: none"> • Off: No power is available, or the AP is not connected to a power source. • Red: The AP is powering on. • Green: The AP is connected to a power source and has completed its power-on sequence.

T300

The T300 is a dual-band 802.11ac outdoor access point designed for high density public venues such as airports, conventions centers, plazas & malls, and other dense urban environments.

NOTE The T300 requires a minimum of AP base image 100.0.0 and later to operate, or SCG 2.5.1 and later, vSCG 3.0 and later, RuckOS 3.2 and later, or ZD 9.8.1 and later to operate. DO NOT connect the T300 AP to a Ruckus Wireless Controller with ZD 9.8.0 or earlier, or to SCG 2.5.0 or earlier.

The following figure identifies the LEDs and connectors on the AP. The table below describes these LEDs and other elements.

Introduction

Getting to Know the Access Point Features




Figure 8: T300 LEDs and other elements

Table 9: T300 LED and other element descriptions

No.	Label	Description
1	Earth ground screw	Use this screw to attach an earth ground to the AP as required by local regulations.

No.	Label	Description
2	5G LED	<ul style="list-style-type: none"> • Off: The WLAN service is down. • Amber: The WLAN is up, but no clients or downlink MAPs are associated/connected. • Green: The WLAN is up and at least one client is associated. No downlink MAPs are connected. • Slow flashing green (one flash every two seconds): The WLAN is up and at least one downlink MAP is connected. No clients are associated. • Fast flashing green (two flashes every second): The WLAN is up, at least one downlink MAP is connected, and at least one client is associated.
3	2.4G LED	<ul style="list-style-type: none"> • Off: The WLAN service is down. • Green: The WLAN is up and at least one client is associated. • Amber: The WLAN is up. No clients are associated.
4	AIR LED	<ul style="list-style-type: none"> • Off: The AP is operating in standalone mode or operating as a root AP (RAP) or a non-mesh AP. • Green: The AP is functioning as a Mesh AP (MAP), and the wireless signal to its uplink AP is good. • Fast flashing green (two flashes every second): The AP is functioning as a Mesh AP (MAP), and the wireless signal to its uplink AP is fair. • Slow flashing green (one flash every two seconds): Mesh networking is enabled, but the AP is still searching for a mesh uplink.

Introduction

Getting to Know the Access Point Features

No.	Label	Description
5	DIR LED	<ul style="list-style-type: none">• Off: The AP is not being managed by a Ruckus Wireless controller (standalone mode).• Green: The AP is being managed by a Ruckus Wireless controller.• Slow flashing green (one flash every two seconds): The AP is being managed by a Ruckus Wireless controller, but is currently unable to communicate with the controller.• Fast flashing green (two flashes every second): The AP is being managed by a Ruckus Wireless controller and is currently receiving configuration settings (provisioning) or an image update.
6	PWR LED	<ul style="list-style-type: none">• Off: Off.• Red: Boot up in process.• Flashing Green: No routable IP address.• Green: On.
7	PoE IN RJ45 data connector	Supports 10/100/1000Mbps connections, and receives Power over Ethernet (PoE). <hr/> NOTE The T300 can be powered by any 802.3af PSE device. Refer to the Ruckus Wireless T300 data sheet for recommended PoE accessories. <hr/>
8	RESET button	This button resets the AP to its factory defaults, and is mounted under the RESET/PoE IN RJ-45 waterproof gland.

T300e

The T300e is a dual-band 802.11ac outdoor access point with external antenna connectors.

NOTE The 100.x AP base images support standalone mode and FlexMaster (FM) WLAN manager operation. The RuckOS-compatible images only support SCG, vSCG, and SZ controllers. The ZD-compatible images only support ZD controllers.

NOTE The T300 requires a minimum of AP base image 100.0.0 and later to operate, or SCG 2.5.1 and later, vSCG 3.0 and later, RuckOS 3.2 and later, or ZD 9.8.1 and later

to operate. DO NOT connect the T300 AP to a Ruckus Wireless Controller with ZD 9.8.0 or earlier, or to SCG 2.5.0 or earlier.

The following figure identifies the LEDs and connectors on the AP. The table below describes these LEDs and other elements.




Figure 9: T300 LEDs and other elements

Table 10: T300 LED and other element descriptions

No.	Label	Description
1	Earth ground screw	Use this screw to attach an earth ground to the AP as required by local regulations.

Introduction

Getting to Know the Access Point Features

No.	Label	Description
2	5G LED	<ul style="list-style-type: none">• Off: The WLAN service is down. Amber: The WLAN is up, but no clients or downlink MAPs are associated/connected.• Green: The WLAN is up and at least one client is associated. No downlink MAPs are connected. Slow flashing green (one flash every two seconds): The WLAN is up and at least one downlink MAP is connected. No clients are associated.• Fast flashing green (two flashes every second): The WLAN is up, at least one downlink MAP is connected, and at least one client is associated.
3	2.4G LED	<ul style="list-style-type: none">• Off: The WLAN service is down.• Green: The WLAN is up and at least one client is associated.• Amber: The WLAN is up. No clients are associated.
4	AIR LED	<ul style="list-style-type: none">• Off: The AP is operating in standalone mode or operating as a root AP (RAP) or a non-mesh AP.• Green: The AP is functioning as a Mesh AP (MAP), and the wireless signal to its uplink AP is good.• Fast flashing green (two flashes every second): The AP is functioning as a Mesh AP (MAP), and the wireless signal to its uplink AP is fair.• Slow flashing green (one flash every two seconds): Mesh networking is enabled, but the AP is still searching for a mesh uplink.

No.	Label	Description
5	DIR LED	<ul style="list-style-type: none"> Off: The AP is not being managed by a Ruckus Wireless controller (standalone mode). Green: The AP is being managed by a Ruckus Wireless controller. Slow flashing green (one flash every two seconds): The AP is being managed by a Ruckus Wireless controller, but is currently unable to communicate with the controller. Fast flashing green (two flashes every second): The AP is being managed by a Ruckus Wireless controller and is currently receiving configuration settings (provisioning) or an image update.
6	PWR LED	<ul style="list-style-type: none"> Off: Off. Red: Boot up in process. Flashing Green: No routable IP address. Green: On.
7	PoE IN RJ45 data connector	<p>Supports 10/100/1000Mbps connections, and receives Power over Ethernet (PoE).</p> <hr/> <p>NOTE The T300 can be powered by any 802.3af PSE device. Refer to the Ruckus Wireless T300 data sheet for recommended PoE accessories.</p> <hr/>
8	RESET button	This button resets the AP to its factory defaults, and is mounted under the RESET/PoE IN RJ-45 waterproof gland.

The following figure identifies the 5GHz RF connectors on the AP. The table below describes these RF connectors. If you want to extend the range of your wireless network, then you can connect external high gain antennas to the standard N-type radio frequency (RF) antenna connectors on the top panel of the AP. The antennas must have a gain of less than 9dBi to comply with FCC and CE regulations.

Introduction

Getting to Know the Access Point Features




Figure 10: T300e RF connectors

Table 11: T300e N-type RF connectors

Label	Description
5GHz connectors	These 5GHz 50-ohm female connectors can be used with up to two external antennas for operator-defined coverage areas and point-to-point deployments.

T301n

The T301n is a dual-band 802.11ac outdoor access point with narrow beam sector antenna designed for high density outdoor applications.

NOTE The 100.x AP base images support standalone mode and FlexMaster (FM) WLAN manager operation. The RuckOS-compatible images only support SCG, vSCG, and SZ controllers. The ZD-compatible images only support ZD controllers.

NOTE The T301n requires a minimum of AP base image 100.0.0 and later to operate, or SCG 2.5.1 and later, vSCG 3.0 and later, RuckOS 3.2 and later, or ZD 9.8.1 and later to operate. **DO NOT** connect the T301n AP to a Ruckus Wireless Controller with ZD 9.8.0 or earlier, or to SCG 2.5.0 or earlier.

The following figure identifies the LEDs and connectors on the AP. The table below describes these LEDs and other elements.




Figure 11: T301n LEDs and other elements

Table 12: T301n LED and other element descriptions

No.	Label	Description
1	Earth ground screw	Use this screw to attach an earth ground to the AP as required by local regulations.

Introduction

Getting to Know the Access Point Features

No.	Label	Description
2	5G LED	<ul style="list-style-type: none">• Off: The WLAN service is down. Amber: The WLAN is up, but no clients or downlink MAPs are associated/connected.• Green: The WLAN is up and at least one client is associated. No downlink MAPs are connected. Slow flashing green (one flash every two seconds): The WLAN is up and at least one downlink MAP is connected. No clients are associated.• Fast flashing green (two flashes every second): The WLAN is up, at least one downlink MAP is connected, and at least one client is associated.
3	2.4G LED	<ul style="list-style-type: none">• Off: The WLAN service is down.• Green: The WLAN is up and at least one client is associated.• Amber: The WLAN is up. No clients are associated.
4	AIR LED	<ul style="list-style-type: none">• Off: The AP is operating in standalone mode or operating as a root AP (RAP) or a non-mesh AP.• Green: The AP is functioning as a Mesh AP (MAP), and the wireless signal to its uplink AP is good.• Fast flashing green (two flashes every second): The AP is functioning as a Mesh AP (MAP), and the wireless signal to its uplink AP is fair.• Slow flashing green (one flash every two seconds): Mesh networking is enabled, but the AP is still searching for a mesh uplink.

No.	Label	Description
5	DIR LED	<ul style="list-style-type: none"> • Off: The AP is not being managed by a Ruckus Wireless controller (standalone mode). • Green: The AP is being managed by a Ruckus Wireless controller. Slow flashing green (one flash every two seconds): The AP is being managed by a Ruckus Wireless controller, but is currently unable to communicate with the controller. • Fast flashing green (two flashes every second): The AP is being managed by a Ruckus Wireless controller and is currently receiving configuration settings (provisioning) or an image update.
6	PWR LED	<ul style="list-style-type: none"> • Off: Off. • Red: Boot up in process. • Flashing Green: No routable IP address. • Green: On.
7	PoE IN RJ45 data connector	<p>Supports 10/100/1000Mbps connections, and receives Power over Ethernet (PoE).</p> <hr/> <p>NOTE The T301n can be powered by any 802.3af PSE device. Refer to the Ruckus Wireless T301n data sheet for recommended PoE accessories.</p> <hr/>
8	RESET button	<p>This button resets the AP to its factory defaults, and is mounted under the RESET/PoE IN RJ-45 waterproof gland.</p>

T301s

The T301s is a dual-band 802.11ac outdoor access point with wide beam sector antenna designed for high density outdoor applications.

NOTE The 100.x AP base images support standalone mode and FlexMaster (FM) WLAN manager operation. The RuckOS-compatible images only support SCG, vSCG, and SZ controllers. The ZD-compatible images only support ZD controllers.

NOTE The T301s requires a minimum of AP base image 100.0.0 and later to operate, or SCG 2.5.1 and later, vSCG 3.0 and later, RuckOS 3.2 and later, or ZD 9.8.1 and later

Introduction

Getting to Know the Access Point Features

to operate. DO NOT connect the T301s AP to a Ruckus Wireless Controller with ZD 9.8.0 or earlier, or to SCG 2.5.0 or earlier.

The following figure identifies the LEDs and connectors on the AP. The table below describes these LEDs and other elements.




Figure 12: T301s LEDs and other elements

Table 13: T301s LED and other element descriptions

No.	Label	Description
1	Earth ground screw	Use this screw to attach an earth ground to the AP as required by local regulations.

No.	Label	Description
2	5G LED	<ul style="list-style-type: none"> • Off: The WLAN service is down. Amber: The WLAN is up, but no clients or downlink MAPs are associated/connected. • Green: The WLAN is up and at least one client is associated. No downlink MAPs are connected. Slow flashing green (one flash every two seconds): The WLAN is up and at least one downlink MAP is connected. No clients are associated. • Fast flashing green (two flashes every second): The WLAN is up, at least one downlink MAP is connected, and at least one client is associated.
3	2.4G LED	<ul style="list-style-type: none"> • Off: The WLAN service is down. • Green: The WLAN is up and at least one client is associated. • Amber: The WLAN is up. No clients are associated.
4	AIR LED	<ul style="list-style-type: none"> • Off: The AP is operating in standalone mode or operating as a root AP (RAP) or a non-mesh AP. • Green: The AP is functioning as a Mesh AP (MAP), and the wireless signal to its uplink AP is good. • Fast flashing green (two flashes every second): The AP is functioning as a Mesh AP (MAP), and the wireless signal to its uplink AP is fair. • Slow flashing green (one flash every two seconds): Mesh networking is enabled, but the AP is still searching for a mesh uplink.

Introduction

Getting to Know the Access Point Features

No.	Label	Description
5	DIR LED	<ul style="list-style-type: none">• Off: The AP is not being managed by a Ruckus Wireless controller (standalone mode).• Green: The AP is being managed by a Ruckus Wireless controller. Slow flashing green (one flash every two seconds): The AP is being managed by a Ruckus Wireless controller, but is currently unable to communicate with the controller.• Fast flashing green (two flashes every second): The AP is being managed by a Ruckus Wireless controller and is currently receiving configuration settings (provisioning) or an image update.
6	PWR LED	<ul style="list-style-type: none">• Off: Off.• Red: Boot up in process.• Flashing Green: No routable IP address.• Green: On.
7	PoE IN RJ45 data connector	Supports 10/100/1000Mbps connections, and receives Power over Ethernet (PoE). <hr/> NOTE The T301s can be powered by any 802.3af PSE device. Refer to the Ruckus Wireless T301s data sheet for recommended PoE accessories. <hr/>
8	RESET button	This button resets the AP to its factory defaults, and is mounted under the RESET/PoE IN RJ-45 waterproof gland.

T610

The T610 is a carrier grade dual-band concurrent 802.11ac Wave 2 outdoor access point with 4x4:4 spatial streams, 11ac Wave 2 MU-MIMO support, and dual GbE ports. The T610 supports PoE in, 160/80+80 MHz channelization, and LACP Ethernet port aggregation.

NOTE The T610 requires a minimum of standalone AP base image 104.1 and later, or SmartZone 3.4.2 and later, or ZoneDirector 9.13.3 and later to operate.




Figure 13: T610 Top view

The T610 can use the link aggregation control protocol (LACP) to control the bonding of two 1Gbps physical Ethernet ports together to form a single logical channel. Refer to [Appendix B: Configuring Link Aggregation \(LACP\) for AP Backhaul](#) on page 121 for instructions on bonding the two Ethernet ports using LACP.

The following figure identifies the LEDs and connectors on the AP. The table below describes these LEDs and other elements.

Introduction

Getting to Know the Access Point Features




Figure 14: T610 bottom view

Table 14: T610 LED and other element descriptions

Label	Description
Eth 1/PoE IN/RESET	<p>RJ-45 Ethernet port: Supports 10/100/1000Mbps connections, and receives Power over Ethernet (PoE).</p> <hr/> <p>CAUTION! Do not use any PoE injector not tested and approved by Ruckus Wireless to power the T610 Access Point.</p> <hr/> <p>CAUTION! Do not plug PoE IN power into the non-PoE port.</p> <hr/> <p>CAUTION! If using a PoE switch to supply power to the T610, 30W MUST be reserved for the T610 on the switch. Failure to ensure a 30W supply may result in unpredictable operation of the access point.</p> <hr/> <p>Reset button: This button resets the AP to its factory defaults, and is mounted under the Eth 1/PoE IN/RESET RJ-45 waterproof gland.</p>

Label	Description
Eth Port 2	RJ-45 Ethernet Port: Supports 10/100/1000Mbps connections (no PoE).
PWR	<ul style="list-style-type: none"> • Off: Off. • Red: Boot up in process. • Flashing Green: No routable IP address. • Green: On.
CTL	<p>Controller LED:</p> <ul style="list-style-type: none"> • Off: The AP is not being managed by a Ruckus Wireless controller (standalone mode). • Green: The AP is being managed by a Ruckus Wireless controller. • Slow flashing green (one flash every two seconds): The AP is being managed by a controller, but is currently unable to communicate with the controller. • Fast flashing green (two flashes every second): The AP is being managed by a controller and is currently receiving configuration settings (provisioning) or an image update.
AIR	<p>AIR LED:</p> <ul style="list-style-type: none"> • Off: The AP is operating in standalone mode or operating as a root AP (RAP) or a non-mesh AP. • Green: The AP is functioning as a Mesh AP (MAP), and the wireless signal to its uplink AP is good. • Fast flashing green (two flashes every second): The AP is functioning as a Mesh AP (MAP), and the wireless signal to its uplink AP is fair. • Slow flashing green (one flash every two seconds): Mesh networking is enabled, but the AP is still searching for a mesh uplink.
2.4G	<p>2.4 GHz radio LED:</p> <ul style="list-style-type: none"> • Off: The WLAN service is down. • Green: The WLAN is up and at least one client is associated. • Amber: The WLAN is up. No clients are associated.

Introduction

Getting to Know the Access Point Features

Label	Description
5G	5 GHz radio LED: <ul style="list-style-type: none">• Off: The WLAN service is down.• Amber: The WLAN is up, but no clients or downlink MAPs are associated/connected.• Green: The WLAN is up and at least one client is associated. No downlink MAPs are connected.• Slow flashing green (one flash every two seconds): The WLAN is up and at least one downlink MAP is connected. No clients are associated.• Fast flashing green (two flashes every second): The WLAN is up, at least one downlink MAP is connected, and at least one client is associated.
USB	USB port for IoT devices, Zigbee dongle, 4G/LTE dongle, etc.

T610 Power Modes

The following table lists the T610's power modes and the corresponding feature set under the different power modes. When both power sources are available on an AP, then DC power will take priority and override PoE power. When the AP is connected to a PoE switch the max power requested by the AP is captured in the second column, and rest of the columns describe the operational capability for each mode.

NOTE The dBm transmit power values below are per chain.

Table 15: T610 Power Modes

PoE Mode	Power Level	5 GHz Radio	2.4 GHz Radio	1G Eth (PoE) Port	1G Eth Port	USB	160/80+80
802.3af	12.95 W	4 x 4 20 dBm	2 x 4 18 dBm	Enabled	Disabled	Disabled	N/A
802.3at/ injector	25.0 W	4 x 4 20 dBm	4 x 4 22 dBm	Enabled	Enabled	Enabled	

T610s

The T610s is the 120-degree sector antenna variant of the T610 outdoor AP.

NOTE The T610s requires a minimum of standalone AP base image 104.1 and later, or SmartZone 3.4.2 and later, or ZoneDirector 9.13.3 and later to operate.




Figure 15: T610s Top view

The T610s can use the link aggregation control protocol (LACP) to control the bonding of two 1Gbps physical Ethernet ports together to form a single logical channel. Refer to [Appendix B: Configuring Link Aggregation \(LACP\) for AP Backhaul](#) on page 121 for instructions on bonding the two Ethernet ports using LACP.

The following figure identifies the LEDs and connectors on the AP. The table below describes these LEDs and other elements.

Introduction

Getting to Know the Access Point Features




Figure 16: T610s bottom view

Table 16: T610s LED and other element descriptions

Label	Description
Eth 1/PoE IN/RESET	<p>RJ-45 Ethernet port: Supports 10/100/1000Mbps connections, and receives Power over Ethernet (PoE).</p> <hr/> <p>CAUTION! Do not use any PoE injector not tested and approved by Ruckus Wireless to power the T610s Access Point.</p> <hr/> <p>CAUTION! Do not plug PoE IN power into the non-PoE port.</p> <hr/> <p>CAUTION! If using a PoE switch to supply power to the T610s, 30W MUST be reserved for the T610s on the switch. Failure to ensure a 30W supply may result in unpredictable operation of the access point.</p> <hr/> <p>Reset button: This button resets the AP to its factory defaults, and is mounted under the Eth 1/PoE IN/RESET RJ-45 waterproof gland.</p>

Label	Description
Eth Port 2	RJ-45 Ethernet Port: Supports 10/100/1000Mbps connections (no PoE).
PWR	<ul style="list-style-type: none"> • Off: Off. • Red: Boot up in process. • Flashing Green: No routable IP address. • Green: On.
CTL	<p>Controller LED:</p> <ul style="list-style-type: none"> • Off: The AP is not being managed by a Ruckus Wireless controller (standalone mode). • Green: The AP is being managed by a Ruckus Wireless controller. • Slow flashing green (one flash every two seconds): The AP is being managed by a controller, but is currently unable to communicate with the controller. • Fast flashing green (two flashes every second): The AP is being managed by a controller and is currently receiving configuration settings (provisioning) or an image update.
AIR	<p>AIR LED:</p> <ul style="list-style-type: none"> • Off: The AP is operating in standalone mode or operating as a root AP (RAP) or a non-mesh AP. • Green: The AP is functioning as a Mesh AP (MAP), and the wireless signal to its uplink AP is good. • Fast flashing green (two flashes every second): The AP is functioning as a Mesh AP (MAP), and the wireless signal to its uplink AP is fair. • Slow flashing green (one flash every two seconds): Mesh networking is enabled, but the AP is still searching for a mesh uplink.
2.4G	<p>2.4 GHz radio LED:</p> <ul style="list-style-type: none"> • Off: The WLAN service is down. • Green: The WLAN is up and at least one client is associated. • Amber: The WLAN is up. No clients are associated.

Introduction

Getting to Know the Access Point Features

Label	Description
5G	5 GHz radio LED: <ul style="list-style-type: none">• Off: The WLAN service is down.• Amber: The WLAN is up, but no clients or downlink MAPs are associated/connected.• Green: The WLAN is up and at least one client is associated. No downlink MAPs are connected.• Slow flashing green (one flash every two seconds): The WLAN is up and at least one downlink MAP is connected. No clients are associated.• Fast flashing green (two flashes every second): The WLAN is up, at least one downlink MAP is connected, and at least one client is associated.
USB	USB port for IoT devices, Zigbee dongle, 4G/LTE dongle, etc.

T610s Power Modes

The following table lists the T610's power modes and the corresponding feature set under the different power modes. When both power sources are available on an AP, then DC power will take priority and override PoE power. When the AP is connected to a PoE switch the max power requested by the AP is captured in the second column, and rest of the columns describe the operational capability for each mode.

NOTE The dBm transmit power values below are per chain.

Table 17: T610s Power Modes

PoE Mode	Power Level	5 GHz Radio	2.4 GHz Radio	1G Eth (PoE) Port	1G Eth Port	USB	160/80+80
802.3af	12.95 W	4 x 4 20 dBm	2 x 4 18 dBm	Enabled	Disabled	Disabled	N/A
802.3at/ injector	25.0 W	4 x 4 20 dBm	4 x 4 22 dBm	Enabled	Enabled	Enabled	

T710


The T710 is a carrier grade dual-band concurrent 802.11ac Wave 2 outdoor access point with 4x4:4 spatial streams, dual GbE ports and an SFP fiber interface. The T710

supports PoE in, PoE out, Ethernet port aggregation, and hot-swappable SFP fiber optic module.

NOTE The T710 requires a minimum of standalone AP base image 104.0 and later, or SmartZone 3.4 and later, or ZoneDirector 9.13 and later to operate.

The T710 can use the link aggregation control protocol (LACP) to control the bonding of two 1Gbps physical Ethernet ports together to form a single logical channel. Refer to [Appendix B: Configuring Link Aggregation \(LACP\) for AP Backhaul](#) on page 121 for instructions on bonding the two Ethernet ports using LACP.

The following figure identifies the LEDs and connectors on the AP. The table below describes these LEDs and other elements.



Introduction

Getting to Know the Access Point Features

Figure 17: T710 LEDs and other elements

Table 18: T710 LED and other element descriptions

No.	Label	Description
1	SFP	<p>SFP Fiber port: To connect to fiber backhaul, plug an SFP Optic module into the Fiber port. The SFP module is hot-swappable and can be removed with fingers or simple tools.</p> <hr/> <p>NOTE Recommended modules specified to work with this system are: Finisar GPON FTGN2117P2TUN, Finisar EPON FTEN2217P1CUN-BC, Finisar 1000BaseLX FTLF1318P3BTL, Xavi XO-3901 GPON ONT.</p> <hr/> <p>NOTE The fiber cable must be a single diameter cable, not a zipcord.</p> <hr/>
2	PoE IN/RESET	<p>PoE IN RJ-45 Ethernet port: Supports 10/100/1000Mbps connections, and receives Power over Ethernet (PoE).</p> <hr/> <p>CAUTION! Do not use any PoE injector not tested and approved by Ruckus Wireless to power the T710 Access Point.</p> <hr/> <p>CAUTION! Do not plug PoE IN power into the PoE OUT port.</p> <hr/> <p>CAUTION! If using PoE OUT, it is MANDATORY to use the custom Ruckus supplied PoE injector (part #902-0180-XX00), or to use AC power.</p> <hr/> <p>CAUTION! If using a PoE switch to supply power to the T710, 30W MUST be reserved for the T710 on the switch. Failure to ensure a 30W supply may result in unpredictable operation of the access point. Additionally, if using a PoE switch, the T710's PoE OUT port cannot be used to power additional devices.</p> <hr/> <p>Reset button: This button resets the AP to its factory defaults, and is mounted under the PoE IN/RESET RJ-45 waterproof gland.</p> <hr/>

No.	Label	Description
3	PoE OUT	PoE OUT RJ-45 Ethernet port: Supports 10/100/1000Mbps connections. If using AC power or the custom Ruckus PoE injector, the PoE OUT port can be used to power additional devices.
4	PWR	<ul style="list-style-type: none"> • Off: Off. • Red: Boot up in process. • Flashing Green: No routable IP address. • Green: On.
5	CTL	<p>Controller LED:</p> <ul style="list-style-type: none"> • Off: The AP is not being managed by a Ruckus Wireless controller (standalone mode). • Green: The AP is being managed by a Ruckus Wireless controller. • Slow flashing green (one flash every two seconds): The AP is being managed by a controller, but is currently unable to communicate with the controller. • Fast flashing green (two flashes every second): The AP is being managed by a controller and is currently receiving configuration settings (provisioning) or an image update.
6	AIR	<p>AIR LED:</p> <ul style="list-style-type: none"> • Off: The AP is operating in standalone mode or operating as a root AP (RAP) or a non-mesh AP. • Green: The AP is functioning as a Mesh AP (MAP), and the wireless signal to its uplink AP is good. • Fast flashing green (two flashes every second): The AP is functioning as a Mesh AP (MAP), and the wireless signal to its uplink AP is fair. • Slow flashing green (one flash every two seconds): Mesh networking is enabled, but the AP is still searching for a mesh uplink.

Introduction

Getting to Know the Access Point Features

No.	Label	Description
7	2.4G	2.4 GHz radio LED: <ul style="list-style-type: none">• Off: The WLAN service is down.• Green: The WLAN is up and at least one client is associated.• Amber: The WLAN is up. No clients are associated.
8	5G	5 GHz radio LED: <ul style="list-style-type: none">• Off: The WLAN service is down.• Amber: The WLAN is up, but no clients or downlink MAPs are associated/connected.• Green: The WLAN is up and at least one client is associated. No downlink MAPs are connected.• Slow flashing green (one flash every two seconds): The WLAN is up and at least one downlink MAP is connected. No clients are associated.• Fast flashing green (two flashes every second): The WLAN is up, at least one downlink MAP is connected, and at least one client is associated.
9	AC	AC power connector: Assemble the AC power connector as described in the <i>T710 Quick Setup Guide</i> .

T710 PoE Power Considerations

Please take note of the following Power Over Ethernet (PoE) considerations:

- The T710 does NOT support 802.3af PoE power. Power must be supplied using either the Ruckus supplied PoE injector, or an 802.3at PoE switch/injector, or AC power.
- If using the PoE OUT port on the T710/T710s, it is MANDATORY to use the custom Ruckus supplied 60W PoE injector (part #902-0180-XX00), or to use AC power.
- If using a PoE switch to supply power to the T710, the PoE switch must be capable of supporting a PoE+ (802.3at) powered device. It is recommended to reserve 30W for the T710 on the switch, to account for inefficiencies and losses.


T710s

The T710s is the sector antenna variant of the T710.

NOTE The T710s requires a minimum of standalone AP base image 104.0 and later to operate, or SmartZone 3.4 and later, or ZoneDirector 9.13 and later to operate.

The T710s can use the link aggregation control protocol (LACP) to control the bonding of two 1Gbps physical Ethernet ports together to form a single logical channel. Refer to [Appendix B: Configuring Link Aggregation \(LACP\) for AP Backhaul](#) on page 121 for instructions on bonding the two Ethernet ports using LACP.

The following figure identifies the LEDs and connectors on the AP. The table below describes these LEDs and other elements.



Introduction

Getting to Know the Access Point Features

Figure 18: T710s LEDs and other elements

Table 19: T710s LED and other element descriptions

No.	Label	Description
1	SFP	<p>SFP Fiber port: To connect to fiber backhaul, plug an SFP Optic module into the Fiber port. The SFP module is hot-swappable and can be removed with fingers or simple tools.</p> <hr/> <p>NOTE Recommended modules specified to work with this system are: Finisar GPON FTGN2117P2TUN, Finisar EPON FTEN2217P1CUN-BC, Finisar 1000BaseLX FTLF1318P3BTL, Xavi XO-3901 GPON ONT.</p> <hr/> <p>NOTE The fiber cable must be a single diameter cable, not a zipcord.</p> <hr/>
2	PoE IN/RESET	<p>PoE IN RJ-45 Ethernet port: Supports 10/100/1000Mbps connections, and receives Power over Ethernet (PoE).</p> <hr/> <p>CAUTION! Do not use any PoE injector not tested and approved by Ruckus Wireless to power the T710s Access Point.</p> <hr/> <p>CAUTION! Do not plug PoE IN power into the PoE OUT port.</p> <hr/> <p>CAUTION! If using PoE OUT, it is MANDATORY to use the custom Ruckus supplied PoE injector (part #902-0180-XX00), or to use AC power.</p> <hr/> <p>CAUTION! If using a PoE switch to supply power to the T710s, 30W MUST be reserved for the T710 on the switch. Failure to ensure a 30W supply may result in unpredictable operation of the access point. Additionally, if using a PoE switch, the T710's PoE OUT port cannot be used to power additional devices.</p> <hr/> <p>Reset button: This button resets the AP to its factory defaults, and is mounted under the PoE IN/RESET RJ-45 waterproof gland.</p> <hr/>

No.	Label	Description
3	PoE OUT	PoE OUT RJ-45 Ethernet port: Supports 10/100/1000Mbps connections. If using AC power or the custom Ruckus PoE injector, the PoE OUT port can be used to power additional devices.
4	PWR	<ul style="list-style-type: none"> • Off: Off. • Red: Boot up in process. • Flashing Green: No routable IP address. • Green: On.
5	CTL	<p>Controller LED:</p> <ul style="list-style-type: none"> • Off: The AP is not being managed by a Ruckus Wireless controller (standalone mode). • Green: The AP is being managed by a Ruckus Wireless controller. • Slow flashing green (one flash every two seconds): The AP is being managed by a controller, but is currently unable to communicate with the controller. • Fast flashing green (two flashes every second): The AP is being managed by a controller and is currently receiving configuration settings (provisioning) or an image update.
6	AIR	<p>AIR LED:</p> <ul style="list-style-type: none"> • Off: The AP is operating in standalone mode or operating as a root AP (RAP) or a non-mesh AP. • Green: The AP is functioning as a Mesh AP (MAP), and the wireless signal to its uplink AP is good. • Fast flashing green (two flashes every second): The AP is functioning as a Mesh AP (MAP), and the wireless signal to its uplink AP is fair. • Slow flashing green (one flash every two seconds): Mesh networking is enabled, but the AP is still searching for a mesh uplink.

Introduction

Getting to Know the Access Point Features

No.	Label	Description
7	2.4G	2.4 GHz radio LED: <ul style="list-style-type: none">• Off: The WLAN service is down.• Green: The WLAN is up and at least one client is associated.• Amber: The WLAN is up. No clients are associated.
8	5G	5 GHz radio LED: <ul style="list-style-type: none">• Off: The WLAN service is down.• Amber: The WLAN is up, but no clients or downlink MAPs are associated/connected.• Green: The WLAN is up and at least one client is associated. No downlink MAPs are connected.• Slow flashing green (one flash every two seconds): The WLAN is up and at least one downlink MAP is connected. No clients are associated.• Fast flashing green (two flashes every second): The WLAN is up, at least one downlink MAP is connected, and at least one client is associated.
9	AC	AC power connector: Assemble the AC power connector as described in the <i>T710s Quick Setup Guide</i> .

T710 PoE Power Considerations

Please take note of the following Power Over Ethernet (PoE) considerations:

- The T710 does NOT support 802.3af PoE power. Power must be supplied using either the Ruckus supplied PoE injector, or an 802.3at PoE switch/injector, or AC power.
- If using the PoE OUT port on the T710/T710s, it is MANDATORY to use the custom Ruckus supplied 60W PoE injector (part #902-0180-XX00), or to use AC power.
- If using a PoE switch to supply power to the T710, the PoE switch must be capable of supporting a PoE+ (802.3at) powered device. It is recommended to reserve 30W for the T710 on the switch, to account for inefficiencies and losses.

Introduction

Getting to Know the Access Point Features

Navigating the Web Interface

2

Navigating the Web Interface

You manage the AP through a web browser-based interface that you can access from any networked computer.




Figure 19: Elements of the Ruckus Wireless AP Web Interface

Table 20: Ruckus Wireless AP web interface elements

No.	Element	Description
1	Menu	Under each category (Status, Configuration, etc.) are options that, when clicked, open the related workspace in the area to the right.
2	Tabs	Contains additional options for the configuration page. For example, the Configuration > Wireless page includes one tab for common wireless configuration and eight tabs, one for each of the available WLANs.
3	LOGOUT Button	Click this button to log out of the AP.
4	Help Button	Click this button to open a help window with information related specifically to the options currently displayed in the workspace.

No.	Element	Description
5	Workspace	This large area displays features, options and indicators relevant to your menu bar choices.

When Using a Dual-Band AP

If your Ruckus Wireless AP model is dual-band, then note that elements on the web interface menu are slightly different from single-band Ruckus Wireless AP models.

Dual-band APs have one 2.4GHz radio (for 802.11b/g/n clients) and one 5GHz radio (for 802.11a/n/ac clients). The wireless settings for these two radios need to be configured separately, which is why the dual-band AP web interface has the **Radio 2.4G** and **Radio 5G** menu items, instead of a single **Wireless** menu item in single-band models.

The following figure highlights the differences between single-band and dual-band Ruckus Wireless AP menus.




Figure 20: Menu items are slightly different in single-band APs (left) and dual-band APs (right)

Configuring the AP for Management by ZoneDirector

When your Ruckus Wireless network is managed by a ZoneDirector controller, you can manage APs using the controller rather than individually logging into each AP's web interface.

If ZoneDirector is installed on the network, then follow the instructions in the *ZoneDirector User Guide* and connect the AP to your network. The AP finds the ZD, and then downloads the ZD-compatible AP firmware from the ZD controller.

NOTE The AP must have some way of obtaining an IP address (IPv4 DHCP or IPv6 Auto Configuration).

Configuring the AP for Management by a SmartZone Controller

When your Ruckus Wireless network is managed by a SmartZone controller, you can manage APs using the controller rather than individually logging into each AP's web interface.

If SmartZone controllers are installed on the network, then follow the instructions in the *SmartZone Admin Guide* to configure the controller, and then connect the AP to your network. The AP finds the SZ controller and then downloads the SZ-compatible AP firmware from the controller.

NOTE The AP must have some way of obtaining an IP address (IPv4 DHCP or IPv6 Auto Configuration).

Configuring the Access Point for Standalone Operation or Management by FlexMaster

If the AP is to be run in a standalone mode or is to be managed by a FlexMaster manager, then continue with this section.

This section provides instructions for configuring Ruckus Wireless APs in a standalone configuration or when the AP is to be managed by a FlexMaster manager.

In this section:

- [Configuring Device Settings](#) on page 59
- [Configuring Internet Settings](#) on page 61

- [Configuring Local Subnets](#) on page 67
- [Configuring Wireless Settings](#) on page 69
- [Configuring Ethernet Ports](#) on page 87
- [Configuring Hotspot Service](#) on page 93

Configuring Device Settings

Device settings refer to the device name, location, service provider login, and other settings. (Some settings are only available on certain AP models.)

To configure the AP device settings:

1. Go to **Configuration > Device**.

The screenshot shows the configuration interface for a Ruckus T710 Multimedia Hotzone Wireless AP. The page title is "Configuration :: Device". On the left, there is a navigation menu with sections: Status (Device, Internet, Local Subnets, Radio 2.4G, Radio 5G), Configuration (Device, Internet, Local Subnets, Radio 2.4G, Radio 5G, Ethernet Ports, Hotspot), Maintenance (Upgrade, Reboot / Reset, Support Info), and Administration (Management, Diagnostics, Log). The main content area contains the following settings:

- Device Name:** RuckusAP
- Device Location:** [Empty text box]
- Coordinate Source:** GPS Manual
- LED Control:** Disable Status LED(s)
- PoE OUT Port:** Enable PoE OUT port (power output functionality requires custom PoE injector)
- Temperature Update:** 30 (30 - 7200) seconds
- Service Provider Login:**
 - Username: super
 - Current Password: [Empty text box]
 - New Password: [Empty text box]
 - Confirm New Password: [Empty text box]
- Login remote authentication:**
 - TACACS+ State:

At the bottom of the form, there are two buttons: "Update Settings" and "Restore previous settings". The footer of the page includes the Ruckus logo and the text "Ruckus T710 Multimedia Hotzone Wireless AP" and "© Copyright 2015 Ruckus Wireless".

Figure 21: The Configuration > Device page

2. In **Device Name**, type a new name for the device or leave as is to accept the default device name (RuckusAP). The device name identifies this AP among other devices on the network.
3. Configure the following optional settings as desired:
 - Enter **Device Location** to keep track of the physical location of the AP.
 - If the AP has a GPS antenna, then select the method of entering the GPS coordinates. In **Coordinate Source**, select **GPS** to have the GPS antenna automatically determine and enter the GPS coordinates, or select **Manual** to enter the GPS coordinates manually.

Configuration

Configuring the Access Point for Standalone Operation or Management by FlexMaster

NOTE If you selected **Manual**, then enter GPS Coordinates to record the physical location of the AP.

- Under **LED Control** (specific models only), check the **Disable Status LED(s)** box to turn off the status LEDs. This can be useful when the AP is installed in a public location, to avoid drawing attention to the AP.
 - Enable **Internal Heater** and **PoE OUT Port** (specific models only) if needed.
 - In **Temperature Update** (specific models only), enter the interval (in seconds) to report the internal temperature of the device.
4. Under **Service Provider Login**, change the login information as required:
 - **Username:** Type the name that you want to use for logging into the web interface. The default user name is **super**.
 - **Current Password:** When you are changing the password, enter the existing password here.
 - **New Password:** When you are changing the password, enter the new password. The default password is **sp-admin**. The password must consist of six to 32 alphanumeric characters only.
 - **Confirm New Password:** Retype the new password to confirm.
 5. Under **Login remote authentication**, click the **TACACS+ State** box to enable the TACACS+ server interface, if required.

NOTE Terminal Access Controller Access-Control System Plus (TACACS+) is an AAA protocol used to authenticate administrator login to this device. Users can be authenticated/authorized to monitor, operate or configure this device. Default is *disabled*. Administrators can be assigned any of the following three administration privilege levels:

- **Super Admin** (Perform all configuration and management tasks)
- **Operator Admin** (Change settings affecting single APs only)
- **Monitoring Admin** (Monitoring and viewing operation status only)

If the TACACS+ server state is enabled, then configure the TACACS+ server parameters:

- **TACACS+ server:** IPv4 or IPv6 server address.
 - **TACACS+ port:** 49 is the default, but it can be set to any available TCP port.
 - **TACACS+ Service:** Login name.
 - **Share Key:** TACACS+ Password.
 - **Confirm Share Key:** retype the TACACS+ Password.
6. Click **Update Settings** to save and apply your changes.

Configuring Internet Settings

Internet settings define how the AP connects to your local area network and to the Internet.

This section describes how to view and configure the AP's Internet settings.

Topics discussed include:

- [VLAN Settings Overview](#) on page 61
- [Configuring an NTP Server](#) on page 62
- [Configuring the Management VLAN](#) on page 62
- [Default IP Addressing Behavior](#) on page 62
- [Obtaining and Assigning an IP Address](#) on page 62
- [Configuring L2TP Connection Settings](#) on page 66




Figure 22: The Configuration > Internet page

VLAN Settings Overview

A Ruckus Wireless AP is in many ways like a network switch that supports virtual LAN segmentation on both its wired and wireless interfaces.

Like many advanced switches, Ruckus APs conform to the IEEE 802.1Q standard -- the standard that defines virtual LANs. In an 802.1Q switch, the concept of VLANs is always present. If a packet arrives without an 802.1Q header, it is assigned to the *native VLAN* or *untag VLAN*.

Configuration

Configuring the Access Point for Standalone Operation or Management by FlexMaster

Each of the AP's wireless interfaces can be assigned a single VLAN. When a packet enters the AP through its wireless interface, the packet is assigned to the Access VLAN configured on the **Configuration > Wireless** page (by default, 1).

AP Ethernet ports however, can be configured to pass all VLAN traffic (Trunk Ports) or multiple specific VLANs (General ports).

The VLAN displayed in the web interface shows the AP's view of the VLAN environment; when a packet arrives at an AP's Ethernet port, the port's VLAN configuration helps determine if the packet is accepted or not (VLAN membership), and assigns a default VLAN (untagged VLAN) if the packet contains no 802.1Q header.

In general, if your network has VLANs deployed already, you should apply VLAN configuration to Ruckus APs so that the configuration across the network is consistent.

Configuring an NTP Server

A network time protocol (NTP) server should be configured to ensure that the AP maintains the correct time. The default Ruckus Wireless NTP Server (ntp.ruckuswireless.com) can be used if you do not have an NTP server on your network.

If you want the AP to use a different NTP server, you can do so by going to **Configuration > Internet**, entering the host name in NTP Server at the top of the page, and then clicking **Update Settings**.

Configuring the Management VLAN

CAUTION! Changing the Management VLAN causes you to be immediately disconnected from the web interface if the computer you are using is not on the same VLAN. Do not change the Management VLAN unless your admin PC is on the same VLAN, or you are disconnected and unable to connect again without factory resetting the AP.

If you want to place this AP's management traffic into a management VLAN, enter the VLAN ID in the **Management VLAN** field and click **Update Settings**.

Default IP Addressing Behavior

By default, the AP is configured to automatically obtain an IPv4 address from a DHCP server on the network.

If the AP does not detect a DHCP server, it automatically assigns itself the static IP address **192.168.0.1** (or **192.168.100.2** for Cable Modem APs) to make it easier for you to configure and deploy it on your network.

For IPv6, the Auto Configuration setting serves the same purpose as DHCP. The default static IPv6 address is **fc00::1**.

Obtaining and Assigning an IP Address

There are three methods of assigning IP addresses to the AP:

- [DHCP/Auto Configuration](#) on page 63

- [Configuring a Static IP](#) on page 65
- [PPPoE](#) on page 65

DHCP/Auto Configuration

If you leave the AP at its default configuration, then it attempts to obtain an IPv4 address from a DHCP server on the network.

In an IPv6 network environment, the AP attempts to obtain an IPv6 address from an IPv6 Auto Configuration server.

Refer to the following:

- [Renewing and Releasing DHCP](#) on page 63
- [Configuring IPv4 Auto or Manual Configuration](#) on page 64
- [Configuring IPv6 Auto Configuration](#) on page 64

Renewing and Releasing DHCP

This task should be performed only if you have access to the DHCP server or have some way to determine what IP address has been assigned to the AP. It serves as a troubleshooting technique when IP addresses to one or more networked devices prove to be unusable or in conflict with others, or when the AP loses its DHCP-assigned IP address for some reason.

1. Go to **Status > Internet**.




Figure 23: Renew or Release DHCP

2. Review the current settings.

Configuration

Configuring the Access Point for Standalone Operation or Management by FlexMaster

3. If the current *Connection Type* is **dhcp**, then you are able to see the currently-assigned IP address and subnet mask listed below.
 - To force the AP to release its DHCP-assigned IP address, click **Release DHCP**. This disconnects the user from web interface as the system reverts to its default IP address. Log in to the device using the default IP address (**192.168.0.1** (or **192.168.100.2** for Cable Modem APs) and click **Renew DHCP** to request a new lease from the DHCP server.
 - Click **Renew DHCP** to request a new IP address lease from the DHCP server.

NOTE The IP address may or may not change depending on the lease time offered to this device.

4. Click **Update Settings** to save your changes.

Configuring IPv4 Auto or Manual Configuration

If you leave the AP at its default configuration, it attempts to obtain an IPv4 address from a DHCP server on the network.

1. Go to **Configuration > Internet**.
2. In **IPv4 Connection Type**, select **DHCP**.
3. In **IPv4 DNS Mode**, select **Auto** or **Manual**.
 - When you select **Auto**, the AP automatically searches for an IPv4 DNS server.
 - When you select **Manual**, also make the following entries:
 - **IPv4 Primary DNS Server**: The IP address of the primary Domain Name System (DNS) server.
 - **IPv4 Secondary DNS Server**: The IP address of the secondary DNS server.

4. Click **Update Settings** to save your changes

Configuring IPv6 Auto Configuration

In an IPv6 network environment, the AP attempts to obtain an IPv6 address from an IPv6 Auto Configuration server.

1. Go to **Configuration > Internet**.
2. In **IPv6 Connection Type**, select **Auto Configuration**.
3. In **IPv6 Primary DNS Server**, enter the IP address of the primary IPv6 DNS server.
4. In **IPv6 Secondary DNS Server**, enter the IP address of the secondary IPv6 DNS server.
5. Click **Update Settings** to save your changes

Configuring a Static IP

Unless you are able to determine the IP address assigned to the AP by the DHCP/Auto Configuration server, it can be useful for anyone needing administrative access to configure a static IP address.

1. Go to **Configuration > Internet**.

NOTE You can configure static addresses for IPv4, IPv6 or both. The AP maintains both sets of IP address settings if both are configured.

2. In **IPv4 Connection Type** or **IPv6 Connection Type**, select **Static IP**.
3. When the **Internet Connection Settings** options appear, you can make changes to the following settings:
 - (IPv6 only) **IPv6 Primary DNS Server**: The IP address of the primary IPv6 DNS server.
 - (IPv6 only) **IPv6 Secondary DNS Server**: The IP address of the secondary IPv6 DNS server.
 - **IPv4/IPv6 Address**: Enter the static IP address that you want to assign to the AP in either IPv4 (dot-decimal) or IPv6 (colon-separated) format.
 - **IPv4 Subnet Mask** or **IPv6 Prefix Length**: Enter the subnet mask or prefix length for the network.
 - **IPv4/IPv6 Gateway**: Enter the gateway IP address of the Internet interface.
4. (IPv4 only) In **IPv4 DNS Mode**, select **Auto** or **Manual**.
 - When you select **Auto**, the AP automatically searches for an IPv4 DNS server.
 - When you select **Manual**, also make the following entries:
 - **IPv4 Primary DNS Server**: The IP address of the primary DNS server.
 - **IPv4 Secondary DNS Server**: The IP address of the secondary DNS server.
5. Click **Update Settings** to save your changes.

PPPoE

Point to Point Protocol over Ethernet (PPPoE) is a Layer 2 protocol which uses the PPP (Point to Point) protocol to connect a client system to a server system over a one to one network link.

All traffic for a PPPoE connected client must go through the PPPoE server to reach the client. A PPPoE server can therefore be used to route, NAT, firewall, and perform QoS traffic shaping.

If a PPPoE server is used to distribute Internet access to subscribers, the AP can be configured with a PPPoE username and password to authenticate with the PPPoE server.

PPPoE is available only for the IPv4 connection type; PPPoE is not supported in IPv6 environments.

Configuration

Configuring the Access Point for Standalone Operation or Management by FlexMaster

1. Go to **Configuration > Internet**.
2. Under **IPv4 Connection Type**, select **PPPoE**.
3. Enter a **PPPoE Username**.
4. Enter a **PPPoE Password**.
5. Retype the password in **PPPoE Password Confirmation**.
6. Click **Update Settings** to save your changes.

Configuring L2TP Connection Settings

You can implement transparent bridging with Ruckus Wireless APs by using L2TP (Layer 2 Tunneling Protocol) tunneling. By tunneling traffic from a Ruckus Wireless AP to a centralized data center, access controllers with policy enforcement software can apply rules and services. In a typical WLAN implementation, these rules include a captive portal to authenticate users' credentials.

In the case of L2TP, the Ruckus Wireless AP functions as a remote bridge. As such, it forwards traffic into PPP sessions over the L2TP tunnel. This implementation ensures that you have complete visibility into MAC addresses of users, as individual Wi-Fi clients are essentially placed (bridged) onto the ISP's core network.

1. Go to **Configuration > Internet**.
2. In **L2TP Connection**, click **Enable**.

The screenshot shows the configuration page for the Ruckus T710 Multimedia Hotzone Wireless AP, specifically the 'Internet' configuration section. The 'L2TP Connection' section is expanded, showing the following settings:

- L2TP Connection:** Enable Disable
- L2TP Connection Settings:**
 - L2TP Network Server IP Address: 0.0.0.0
 - L2TP Network Server Password: [Empty field]
 - PPP/L2TP Username: [Empty field]
 - PPP/L2TP Password: [Empty field]
 - L2TP Tunnel Untag VLAN ID: 1
 - Close Wlan When Tunnel Fails: Enable Disable

At the bottom of the configuration area, there are buttons for 'Update Settings' and 'Restore previous settings'. The page footer includes the Ruckus logo and the text 'Ruckus T710 Multimedia Hotzone Wireless AP' and '© Copyright 2015 Ruckus Wireless'.

Figure 24: L2TP Connection

3. In **L2TP Network Server IP Address**, type the IP address of the L2TP network server (LNS) to which the device connects.
4. In **L2TP Network Server Password**, type the L2TP server password.

5. If your network requires PPP authentication, configure the following fields for L2TP/PPP authentication:
 - **PPP/L2TP Username:** Type your PPP user name.
 - **PPP/L2TP Password:** Type the password for the account.
 - **L2TP Tunnel Untag VLAN ID:** Enter the Untag VLAN ID for the L2TP tunnel.
6. In **Close WLAN When Tunnel Fail**, select **Enable** if you want to disable the WLAN when the tunnel connection is lost. This prevents clients from remaining seemingly connected to the WLAN but without Internet connectivity.
7. Click **Update Settings** to save your changes.

Configuring Local Subnets

Ruckus Wireless APs can be configured to provide routing/network address translation (NAT) functionality using the Local Subnets feature.

When a Local Subnet is enabled, the standalone AP serves as a gateway router that can manage its own subnets, providing DHCP server and DNS cache functions for both wired and wireless clients. These clients can be assigned private IP addresses from a user-defined address pool. Traffic from the client station in private address space appears on the outside as if generated by the AP itself. In this way, the AP performs Layer 3 packet forwarding not only for Hotspot/WISPr usage, but for standard usage as well.

Up to four IP subnets can be configured per AP, each with its own VLAN and address range which cannot conflict with one another.

1. Go to **Configuration > Local Subnets**. The **Local Subnet 1** through **Local Subnet 4** tabs allow you to configure each of the four subnets independently.

Configuration

Configuring the Access Point for Standalone Operation or Management by FlexMaster




Figure 25: Configuring local subnets and enabling router mode

2. Click **Enabled** next to **Subnet**. The local subnet configuration options appear.
3. In **Local IP Address**, enter an IP address for the gateway. The default address for Subnet 1 is **192.168.40.1**. This address can be used to access the AP's web interface for configuration and monitoring from devices connected to this subnet.
4. In **Subnet Mask**, typically you would want to leave the setting at its default value (255.255.255.0) for a Class C subnet with an address pool of up to 254 addresses. An error appears if you enter an invalid IP/netmask combination.
5. In **DHCP Server**, click **Enabled** if you want to enable DHCP for this subnet. Starting Address and Maximum DHCP Users fields appear.
6. In **Starting Address**, enter an address in the same subnet as the Local IP Address (for example, 192.168.40.2).
7. In **Maximum DHCP Users**, enter the maximum number of clients that can be assigned addresses by DHCP in this subnet (valid values are 1-253 if the default subnet mask is used).
8. In **Access VLAN**, enter a VLAN ID to segment client traffic arriving from this subnet from other network traffic. (Example: If you use the default 192.168.40.1 address range, you might want to use "40" as the VLAN for this subnet.)
9. Click **Update Settings** to save your changes. The local subnet is created immediately and can now be applied to WLANs or Ethernet ports from their respective configuration pages.

Configuring Wireless Settings

This section describes how to configure the wireless settings of the AP.

There are two types of wireless settings that you need to configure:

- [Configuring Common Wireless Settings](#) on page 69: Includes the wireless mode, country code, and advanced wireless settings, such as the wireless transmit power and wireless protection mode. These settings are applied to all WLANs.
- [Configuring Wireless # \(WLAN Number\) Settings](#) on page 74: The Wireless # (WLAN number) tabs (Wireless 1 through Wireless 8 on the 2.4GHz radio and Wireless 9 through Wireless 16 on the 5GHz radio) provide settings for customizing each WLAN individually.

Configuring Common Wireless Settings

Common wireless settings are settings that are applied to all WLANs.

On single-radio APs, go to **Configuration > Wireless**. On dual-radio APs, you configure these settings for the 2.4GHz and 5GHz radios independently by going to **Configuration > Radio 2.4G** or **Configuration > Radio 5G**.

1. Go to **Configuration > Wireless/Radio 2.4G/Radio 5G**. The **Configuration > Wireless > Common** page appears.




Figure 26: Typical Configuration > Radio 2.4G > Common page

2. Make changes to the common wireless settings listed in the table below.

Configuration

Configuring the Access Point for Standalone Operation or Management by FlexMaster

Table 21: Common Wireless Settings

Setting	Description
Radio Network	(Dual-radio APs only) Allows you to change the name of the 2.4GHz and 5GHz radios (default: Radio 2.4G and Radio 5G).
Wireless Mode	<p>On single radio APs: The wireless mode options include the following:</p> <ul style="list-style-type: none">• Auto-Select: Allows both 802.11g- and 802.11b-compliant devices to connect to the network. This is the default setting.• 2.4GHz 54Mbps (For faster 802.11g devices only): Allows only 802.11g-compliant devices to join the network.• 2.4GHz 11Mbps (For slower 802.11b devices only): Allows only 802.11b-compliant devices to join the network. <p>On dual-radio 802.11n/ac APs:</p> <p>On dual radio 802.11n/ac APs, the wireless mode is determined by radio; that is, for the 2.4GHz radio, the mode is automatically set to 2.4GHz (802.11b/g/n), while for the 5GHz radio, the mode is automatically set to 5GHz (802.11a/n/ac).</p>
Channel	This option lets you select the channel used by the network. You can choose SmartSelect, or choose a specific channel. If you choose SmartSelect, then the AP automatically selects the best channel (encountering the least interference) to transmit the signal.
Channel Width	On 802.11n/ac APs, the option to choose 40 MHz channel width theoretically provides double the data capacity of a 20 MHz channel. However, more channel width means fewer channels available, and more interference with other wireless signals. On 802.11ac APs, the option to choose 80 MHz channel width theoretically provides four times the data capacity of a 20 MHz channel. However, more channel width means fewer channels available, and more interference with other wireless signals.

Setting	Description
Country Code	<p>This option (if enabled) lets you select your country or region code.</p> <hr/> <p>CAUTION! Selecting the incorrect country or region may result in violation of applicable laws. If you purchased the AP in the United States of America, you do not need to set the country code manually. Ruckus Wireless devices that are sold in the USA are preconfigured with the correct country code and this setting is non-configurable.</p>
Advanced Settings	<p>Refer to Reviewing Common Advanced Settings on page 73.</p>
External Antenna	<p>NOTE This option only appears if you are using a Ruckus Wireless AP with external antenna ports, such as the 7782-E or the T300e AP.</p> <hr/> <p>Some Ruckus Wireless APs provide external antenna port(s), in case you want to attach external antenna(s) to extend the range of your wireless network. To enable the AP to use the external antenna(s), select the Enabled option in this section. This option is disabled by default.</p>
External Antenna Gain	<p>NOTE This option only appears if you are using a Ruckus Wireless AP with external antenna ports, such as the 7782-E or the T300e AP.</p> <hr/> <p>Set the external antenna gain as required to comply with local and regional regulations.</p>

Configuration

Configuring the Access Point for Standalone Operation or Management by FlexMaster

Setting	Description
AeroScout RFID	<p>(Some APs only.) If you are using AeroScout RFID Tags in your organization to locate assets or personnel, then you can use your Ruckus Wireless AP to relay location or presence data from the AeroScout Tags to the AeroScout Engine via Wi-Fi. To enable the AP to relay AeroScout data, select Enabled. To check the status of the AeroScout communication agent (which relays location data from AeroScout Tags to the AeroScout Engine), go to the Status > Wireless page. Refer to Viewing Common Wireless Settings on page 102 for more information. For other AeroScout-related configuration, refer to the AeroScout documentation that was shipped with your AeroScout Tag and AeroScout Engine.</p> <hr/> <p>NOTE If ZoneDirector exists on the network, you can enable AeroScout RFID tag detection on all its managed APs at once. Refer to the <i>ZoneDirector User Guide</i> for more information.</p> <hr/>
Ekahau RFID	<p>(Some APs only.) If you are using an Ekahau Real Time Location System (RTLS) in your organization, then you can use your Ruckus Wireless AP to relay location or presence data to the Ekahau Real Time Location System RTLS Controller (ERC).</p> <ul style="list-style-type: none">• Select Enabled to support Ekahau RFID tag detection.• If you have enabled Ekahau, then complete the following:<ul style="list-style-type: none">• ERC IP Address: Enter an IP address for the Ekahau Real Time Location System RTLS Controller.• ERC port: 65538 is the default, but it can be set to any available TCP port used by the Ekahau Real Time Location System RTLS Controller. <p>For other Ekahau-related configuration, refer to the Ekahau documentation that was shipped with your Ekahau Real Time Location System RTLS Controller.</p> <hr/> <p>NOTE If ZoneDirector exists on the network, you can enable Ekahau RFID tag detection on all its managed APs at once. Refer to the <i>ZoneDirector User Guide</i> for more information.</p> <hr/>

3. Click **Update Settings** to save your changes.

Reviewing Common Advanced Settings

Advanced wireless settings should only be changed by an experienced administrator.

Incorrect settings can severely impact wireless performance. It is recommended that the default settings be retained for best performance.

NOTE To fully benefit from the AP's capabilities, it is advisable not to change these values unless absolutely necessary.

1. On the **Configuration > Wireless/Radio 2.4G/Radio 5G** page, click **Edit Common Settings**. The **Configuration > Wireless > Advanced > Common** page appears.




Figure 27: The Configuration > Wireless > Advanced > Common page

2. Configure the advanced settings listed in the following table as required.

Table 22: Advanced wireless common settings

Option	Description
Transmit Power	The default setting is Full. Select the level of transmit power from the drop-down menu. This option sets the maximum transmit power level relative to the predefined power (this value differs according to the current country code).
5.8 GHz Channels	(Only available in certain countries selected using the Country Code option.) Select Enable to activate the optional 5.8GHz channels (disabled by default).

Configuration

Configuring the Access Point for Standalone Operation or Management by FlexMaster

Option	Description
Protection Mode	<p>(Disabled by default.) When you activate protection, you control how 802.11 devices know when they should communicate with another device. This is important in a mixed environment of both 802.11b and 802.11g/n/ac clients.</p> <hr/> <p>CAUTION! Activating this option (and configuring the settings) boosts the interoperability of 802.11b and 802.11g/n/ac devices but severely decreases performance.</p> <hr/> <ul style="list-style-type: none">• CTS-only: Choose this option to force all destination devices to acknowledge their ability to receive data when a transmission is initiated. Use this option for compliance with the Wi-Fi Alliance certification.• RTS-CTS: Choose this option to force both sending and receiving devices to confirm a data exchange on both ends before proceeding.

3. Click **Update Settings** to save and apply the changes.

Configuring Wireless # (WLAN Number) Settings

The AP provides up to eight wireless LANs per radio that can be individually configured to provide different kinds of services for different wireless clients, traffic types, or user groups.

Each WLAN can be configured with separate security settings, VLANs, access controls and rate limiting policies, among other settings.

1. Go to **Configuration > Wireless/Radio 2.4G/Radio 5G**. The **Configuration > Wireless > Common** page appears.
2. Click one of the eight **Wireless #** (WLAN number) tabs. The selected **Configuration > Wireless > Wireless #** (WLAN number) page appears.




Figure 28: Typical Configuration > Wireless > Wireless # (WLAN number) page

- Review the WLAN options listed in the table below, and then make changes as required.

Table 23: WLAN options

Option	Description
Wireless Network	This wireless network name is only used for management, and is not visible to wireless clients.
Wireless Availability	This option controls whether or not the wireless network is available to users (Enabled or Disabled).
Broadcast SSID	This option controls whether or not (Enabled or Disabled) the WLAN SSID is visible to anyone looking for wireless networks. Disabling (hiding) the SSID requires the user to use the correct SSID before they can connect to your network.
SSID	This is the publicly-broadcast name of your wireless network. SSIDs can contain up to 32 alphanumeric characters and are case-sensitive. The maximum SSID length can only contain between 2 and 32 characters, including characters from ! (char 33) to ~ (char 126).

Configuration

Configuring the Access Point for Standalone Operation or Management by FlexMaster

Option	Description
Threshold Settings	This button opens a page where you can configure the Protection Mode you activated on the Configuration > Wireless > Advanced > Wireless # (WLAN number) page. If Protection Mode is not active, ignore this option. For more information, refer to Setting Threshold Options on page 83.
Rate Limiting	This button opens a page where you can configure upload and download limits per station. For more information, refer to Rate Limiting on page 85.
Access Control	This button opens a page where you can configure access controls for the WLAN. For more information, refer to Controlling Access to the Wireless Network on page 85.
Packet Forward	<ul style="list-style-type: none">• Isolated: Selecting Isolated causes the traffic from this WLAN to terminate at the AP.• Bridge to WAN: The default setting, Bridge to WAN forwards packets arriving on this WLAN to the WAN (uplink) port and eventually to their external destinations using Layer 2 forwarding.• Local Subnet NAT and Route to WAN: This setting allows routing of wireless packets to their destinations using Layer 3 network address translation (NAT).• Bridge to L2TP Tunnel: Uses Layer 2 Tunneling Protocol to deliver packets encapsulated with an L2TP header in UDP datagrams.
Hotspot Service	Select a Hotspot configuration from the list to enable Hotspot service on this WLAN, after you have configured it from the Configuration > Hotspot page. Refer to Configuring Hotspot Service on page 93.
Local Subnet	This option appears if you have selected Local Subnet NAT and Route to WAN under Packet Forwarding , and allows you to choose which subnet this WLAN's traffic is part of. You must have previously configured a subnet from the Configuration > Local Subnets page before it becomes available here.
Access VLAN	Enter a VLAN ID to segment all traffic arriving from this WLAN to a specified VLAN. Default is 1.

Option	Description
Dynamic VLAN	This setting is available only with WPA encryption and 802.1X authentication. Dynamic VLAN allows the dynamic assignment of VLANs to clients based on RADIUS attributes. Enable this option only if your RADIUS server is configured to segment clients using dynamic VLAN.
Insert DHCP Option 82	When this option is enabled on an SSID, additional information is encapsulated in DHCP option 82 and inserted into DHCP request packets. Current format of option 82 is: <div style="background-color: #f0f0f0; padding: 5px; margin: 5px 0;"> <pre>Circuit ID sub-option: WLAN:<IFNAME>:<VLAN>:<SSID>:<MODEL>: <HOSTNAME>:<DEVMAC></pre> </div> This option supports the ability for a service provider to allocate IP addresses intelligently by considering information on the origin of the IP allocation request.
Client Fingerprinting	When this option is enabled the AP attempts to identify client devices by their operating system, device type and host name, if available.
Encryption Method	By default, all data exchanges on your wireless network are not encrypted, but you can select an encryption method in this option, and use the extra workspace features that appear to fine-tune the encryption settings.
<hr/> <p>CAUTION! Ruckus Wireless strongly recommends using WPA as the encryption method as WEP has been proven to be easily circumvented. For more information, see either Using WEP on page 77 or Using WPA on page 79.</p> <hr/>	

- When you are finished, click **Update Settings** to save and apply the changes. A confirmation message appears at the top of this page.

Using WEP

Wired Equivalent Privacy (WEP) is a security algorithm for 802.11 wireless networks designed to provide data confidentiality comparable to that of a wired network.

WEP uses a pre-shared key for encrypting data frames that is shared among all users of the wireless network. For this reason and others, WEP has been discredited as a security mechanism and should be avoided in favor of WPA if at all possible.

Configuration

Configuring the Access Point for Standalone Operation or Management by FlexMaster

NOTE WEP encryption has been proven to be easily circumvented. Therefore, Ruckus Wireless recommends using WPA whenever possible, and only use WEP if your client devices do not support WPA.

NOTE Using WEP encryption limits the performance of this WLAN to 802.11g rates, and other WLANs are unaffected. If you select WEP encryption for a WLAN, wireless devices that are capable of faster 802.11n transfer rates are limited to 802.11g rates.

1. Go to **Configuration > Wireless/Radio 2.4G/Radio 5G**. The **Configuration > Wireless > Common** page appears.
2. Click the **Wireless # (WLAN number)** tab that you want to configure. The selected **Configuration > Wireless > Wireless # (WLAN number)** page appears.




Figure 29: WEP settings

3. In the **Encryption Method** menu, select **WEP**. An additional set of WEP-specific encryption options appears.
4. Review the encryption settings listed in the table below, and then make changes as required.

Table 24: WEP Options

Encryption Setting	Description
Authentication Mode	<i>Open</i> is the only authentication mode available with WEP encryption.

Encryption Setting	Description
Encryption Strength	<ul style="list-style-type: none"> • 64 bit: Specify the key with 10 hexadecimal digits or 5 ASCII characters. • 128 bit: Specify the key with 26 hexadecimal digits or 13 ASCII characters. The 128-bit cryptography is stronger privacy protection for your network and is recommended if you use WEP.
Key Entry Method	<ul style="list-style-type: none"> • Hexadecimal: The encryption key only accepts hexadecimal characters (0-9, A-F). • ASCII Text: The encryption key accepts ASCII characters.
WEP Key	Enter the key manually according to the Key Entry Method and Encryption Strength settings.
Key Index	Choose the index, from “1” to “4”, that the WEP key is to be stored in.

5. Click **Update Settings** to save and apply the changes. A confirmation message appears at the top of the page.

Using WPA

Wi-Fi Protected Access (WPA) and Wi-Fi Protected Access II (WPA2) are two security protocols developed by the Wi-Fi Alliance in response to the weaknesses of WEP.

Selecting WPA as the Encryption Method allows you to choose WPA version, WPA Authentication and WPA Algorithm. This section discusses WPA-PSK (pre-shared key). For information on WPA-Enterprise (WPA-802.1X), see [Customizing 802.1X Settings](#) on page 82.

WPA-PSK (also known as WPA-Personal) allows automatic key generation based on a single passphrase. WPA-PSK provides strong security for small and medium organizations and does not require a RADIUS server, but may not be supported on older wireless devices. In some cases, the older devices can be upgraded with adapters to take advantage of WPA-PSK.

When you configure the WLAN with WPA-PSK, wireless users are not able to connect to your WLAN unless their devices support WPA-PSK and are configured with the same passphrase.

Configuration

Configuring the Access Point for Standalone Operation or Management by FlexMaster

1. Go to **Configuration > Wireless/Radio 2.4/Radio 5G**. The **Configuration > Wireless > Common** page appears.
2. Click the **Wireless #** (WLAN number) tab that you want to configure. The selected **Configuration > Wireless > Wireless # (WLAN number)** page appears.
3. Click the **Encryption Method** menu, and select **WPA**. An additional set of WPA-specific options appear.




Figure 30: WPA settings

4. Review the encryption settings listed in the following table, and then make changes as required.

Table 25: WPA Encryption settings

Encryption Setting	Description
WPA Version	<p>Your options are WPA2 or WPA+WPA2.</p> <ul style="list-style-type: none"> • WPA2 provides stronger wireless security than WPA (Wi-Fi Protected Access) and is the recommended option. However, older wireless clients may not be compatible with WPA2. For example, WPA2 support on Windows XP requires a Microsoft patch and is only available on Windows XP with Service pack 2 or later. • WPA+WPA2 allows both WPA and WPA2 devices to operate on the same WLAN.

Encryption Setting	Description
WPA Authentication	<ul style="list-style-type: none"> • PSK (Pre-Shared Key) mode is suitable for home or personal use. • 802.1x mode uses a RADIUS server to verify user identity. • Auto mode offers both options to the wireless client. <p>For more information on how to configure the 802.1X mode, refer to Customizing 802.1X Settings on page 82.</p>
WPA Algorithm	<ul style="list-style-type: none"> • AES: AES (Advanced Encryption Standard) replaces TKIP (Temporal Key Integrity Protocol) as the default (and recommended) encryption algorithm for modern wireless LANs. Temporal Key Integrity Protocol is an older encryption algorithm that provides stronger security than a shared WEP key, but not as strong as the newer AES algorithm. • Auto (TKIP+AES): Auto allows both encryption algorithms to be used on the same WLAN. When Auto is selected, the wireless client decides whether TKIP or AES is used. Note however that allowing TKIP reduces the performance of the WLAN (as broadcast packets are limited to slower transfer rates), and is therefore not recommended.
Passphrase	<p>Enter a new passphrase between 8 and 32 characters long, using any combination of printable characters (letters, numbers, hyphens and underscores).</p>

5. Click **Update Settings** to save and apply the changes. A confirmation message appears at the top of the page.

Configuration

Configuring the Access Point for Standalone Operation or Management by FlexMaster

Customizing 802.1X Settings

If you choose WPA as the encryption method, then you have the option to set up the AP to act as an 802.1X proxy, using external authentication sources such as a RADIUS server.

NOTE Do not customize these options unless you are an experienced network administrator or are under the guidance of an IT/support professional.

In 802.1X authentication, the supplicant sends access request messages along with credentials, such as user name/password or digital certificate, to an authenticator, which forwards the credentials to the authentication server for verification. The supplicant (client device) remains in an unauthorized state until verification has been received. In unauthorized state, only 802.1X traffic is allowed; all other traffic, such as DHCP and HTTP traffic, is dropped. For its wireless interfaces, the AP can serve as the authenticator communicating between the supplicant and the authentication server.

1. Go to **Configuration > Wireless/Radio 2.4G/Radio 5G**. The **Configuration > Wireless > Common** page appears.
2. Click a **Wireless #** (WLAN number) tab to configure. The selected **Configuration > Wireless > Wireless # (WLAN number)** page appears.
3. In the **Encryption Method** menu, select **WPA**. The basic set of WPA-specific encryption options appears on the page.
4. In **WPA Authentication** select the required WPA authentication type:
 - **WPA2** provides stronger wireless security than WPA (Wi-Fi Protected Access) and is the recommended option. However, older wireless clients may not be compatible with WPA2. For example, WPA2 support on Windows XP requires a Microsoft patch and is only available on Windows XP with Service pack 2 or later.
 - **WPA+WPA2** allows both WPA and WPA2 devices to operate on the same WLAN.
5. Select **802.1x** as the **WPA Authentication** mode. Additional options appear.

The screenshot displays the configuration interface for a Ruckus T710 Multimedia Hotzone Wireless AP. The page is titled "Ruckus T710 Multimedia Hotzone Wireless AP" and includes a "LOGOUT" button in the top right corner. The left sidebar contains navigation menus for "Status", "Configuration", "Maintenance", and "Administration". The main content area is divided into several sections:

- Dynamic VLAN:** Includes radio buttons for "Enabled" and "Disabled".
- Insert DHCP option 82?** Includes radio buttons for "Enabled" and "Disabled".
- Option 82 subOption:** Includes checkboxes for "Subopt-1 with format" (selected), "Subopt-2 with format", "Subopt-150 with VLAN ID", and "Subopt-151 with format".
- Client Fingerprinting?** Includes radio buttons for "Enabled" and "Disabled".
- Encryption Method:** A dropdown menu set to "WPA".
- WPA Version:** Radio buttons for "WPA2" (selected), "WPA+WPA2", "WPA", and "802.1x".
- WPA Authentication:** Radio buttons for "PSK", "802.1x" (selected), and "Auto".
- WPA Algorithms:** Radio buttons for "AES" (selected) and "Auto (TKIP+AES)".
- Radius NAS-ID:** A text input field.
- Authentication Server:** Labeled as "** Required **", it includes fields for "IP address", "Port", and "Server Secret".
- Accounting Server:** Labeled as "** Optional **", it includes fields for "IP address", "Port", and "Server Secret".

At the bottom of the configuration area, there are buttons for "Update Settings" and "Restore previous settings". The footer of the page includes the Ruckus logo and the text "Ruckus T710 Multimedia Hotzone Wireless AP" and "© Copyright 2015 Ruckus Wireless".

Figure 31: 802.1X settings

6. In **WPA Algorithm** select one of the following:
 - **AES:** AES (Advanced Encryption Standard) replaces TKIP (Temporal Key Integrity Protocol) as the default (and recommended) encryption algorithm for modern wireless LANs.
 - **Auto (TKIP+AES):** Auto allows both encryption algorithms to be used on the same WLAN. When Auto is selected, the wireless client decides whether TKIP or AES is used. Note however that allowing TKIP reduces the performance of the WLAN (as broadcast packets are limited to slower transfer rates), and is therefore not recommended.
7. Configure the following settings to customize your 802.1X authentication:
 - **Radius NAS-ID:** Enter the Network ID assigned to your AP in the RADIUS server Client list.
 - **Authentication Server** (required): Enter the information needed to establish a connection between the AP and the RADIUS server.
 - **Accounting Server** (optional): Enter the information needed to establish this connection.
8. Click **Update Settings** to save and apply the changes. A confirmation message appears at the top of this page.

NOTE Ruckus Wireless APs do not support arbitrary rate values for 802.1X clients (if client rate limiting attributes are configured on the RADIUS server). Ruckus Wireless APs support only those WLAN rate limiting values that can be set using the AP web interface. If the rate returned by the RADIUS server does not match one of these values exactly, it is approximated.

Setting Threshold Options

Threshold options consist of Beacon Interval, Data Beacon Rate and RTS/CTS Threshold.

The following options allow you to fine-tune the "Protection Mode" behavior, set previously on the **Configuration > Wireless > Advanced > Common** page. After activating a Protection Mode, you can open each Wireless tab and customize the threshold settings, which determine what is put into effect and when.

CAUTION! Do not customize these options unless you are an experienced network administrator or are under the guidance of an IT/support professional.

1. Go to **Configuration > Wireless or Configuration > Radio 2.4G or Configuration > Radio 5G**. The **Configuration > Wireless > Common** page appears.
2. Click the tab for the **Wireless #** (WLAN number) that you want to configure. The **Configuration > Wireless > Wireless [#]** page appears.

Configuration

Configuring the Access Point for Standalone Operation or Management by FlexMaster

3. Look for **Threshold Settings**, and then click **Edit Settings**. The **Configuration > Wireless > Advanced > Wireless [#]** page appears.




Figure 32: Threshold settings

4. Review the options listed in the following table, and then make any needed changes.

Table 26: Threshold options

Option	Description
Beacon Interval	(The default value is 100.) The value indicates the frequency interval of the beacon in milliseconds. A beacon is a broadcast packet sent by the AP to synchronize the wireless network.
Data Beacon Rate (DTIM)	(The default value is 1.) The value indicates the interval of the Delivery Traffic Indication Message (DTIM). This is a countdown field that the device uses to inform its clients of the next window for listening to broadcast or multicast messages.
RTS/CTS Threshold	(The default value is 65535.) This option determines at what packet length the RTS/CTS function is triggered. A lower threshold may be necessary in an environment with excessive signal noise or hidden nodes, but may result in some performance degradation.

5. Click **Update Settings** to save and apply the changes. A confirmation message appears at the top of the page.

You have completed configuring the threshold options. To reopen the previous page, click the **Go back to Wireless Configuration** link.

Rate Limiting

Use Rate Limiting settings to control per-client traffic limits.

1. Go to **Configuration > Wireless** or **Configuration > Radio 2.4G** or **Configuration > Radio 5G**.
2. Select the WLAN number that you want to configure from the tabs at the top of the page.
3. Click the **Edit Settings** button next to **Rate Limiting**. The **Rate Limiting** page appears.
4. Set the maximum **Downlink** and **Uplink** rate per station.
5. The table under the **Downlink** and **Uplink** selections updates to show the maximum transfer rate per station for each traffic type.
6. Click **Update Settings** to save your changes.

You have completed configuring the rate limiting options. To reopen the previous page, click the **Go back to Wireless Configuration** link.




Figure 33: Limit per station traffic rates on a specific WLAN

Controlling Access to the Wireless Network

Access Control Lists (ACLs) allow you to specify which stations are allowed to join (associate with) your wireless networks.

Access controls can be configured for each WLAN from its respective Wireless # (WLAN number) tab.

Access Control List (ACL) Options

Configure ACL options to allow or deny WLAN access to specific clients by MAC address.

The **Access Control** page contains the following options:

- **Disable WLAN access restrictions:** The MAC-address-based restrictions on which stations can join the WLAN are disabled, so any station can join. If the WLAN uses

Configuration

Configuring the Access Point for Standalone Operation or Management by FlexMaster

encryption, then the station must still supply the correct encryption passphrase. When this option is selected, the **Access Controls** table is hidden.

- **Allow only stations listed in the Access Control Table:** Only stations entered into the access-controls table are allowed, but all others are disallowed. To add MAC addresses, see [Changing Access Controls for a WLAN](#) on page 86.
- **Deny only stations listed in the Access Control Table:** Stations entered into the access-controls table are disallowed but all others are allowed. To add MAC addresses, see [Changing Access Controls for a WLAN](#) on page 86.




Figure 34: Access Control page

Changing Access Controls for a WLAN

Change access controls by adding MAC addresses to the Access Control Table.

By default, the **Disable WLAN access restrictions** option is selected, which allows any wireless station to gain access to the wireless network. If you want to change this setting, follow the instructions below.

1. Go to **Configuration > Wireless/Radio 2.4G/Radio 5G**.
2. Click the **Wireless #** (WLAN number) tab for which you want to configure the access control settings.
3. Click the **Edit Settings** button next to **Access Control**.
4. Select the radio button for the desired access control (allow or deny). The **Access Controls Table** appears.




Figure 35: Access control settings

5. To add a MAC address to the Access Control table, click the **Add new entry** button.
6. Fill out the **Address** text boxes: Six text boxes appear in which you enter the desired MAC address, in hexadecimal digit form, two characters in each box. Allowable hex-digit characters are 0-9, a-f, and A-F.
7. Click **Update** to save your changes. Assuming all parameters you entered are acceptable, that row is added to the table. You have completed adding an entry to the MAC address table.
8. If you have additional MAC addresses you want included, then click **Add new entry**, and then repeat these steps until you have entered all the stations you want. There is a limit of 128 rows.

Removing a MAC Address

To remove a MAC address from the ACL table, click the **Cancel** button in the **Remove** column, and then click **Update**.

The ACL table refreshes, and the MAC address that you deleted disappears from the table.

Configuring Ethernet Ports

The Ethernet Ports configuration page allows you to define how the AP's Ethernet ports behave.

You can disable ports entirely, define trunking and packet forwarding behavior, configure 802.1X authentication settings, and individually configure VLAN settings for each port from this page.

1. Go to **Configuration > Ethernet Ports**.

Configuration

Configuring the Access Point for Standalone Operation or Management by FlexMaster




Figure 36: The Configuration > Ethernet Ports page

2. Review the following table and make changes as needed for each of the ports labeled Port 1 through Port 4 (depending on AP model), which correspond to the AP's Ethernet ports.

Table 27: Configuring Ethernet ports

Setting	Description
Enable	All Ethernet ports are enabled by default. Unchecking this box next to a port disables that port entirely. If you do not want to provide wired access through the AP, uncheck (clear) the Enable box next to each LAN port.
Port Type	See Setting Ethernet Port Type on page 90 for more detailed information. <ul style="list-style-type: none">• Trunk port: This port passes all VLAN traffic.• Access Port: This port provides network access.• General Port: User-defined VLAN membership.

Setting	Description
Packet Forward	<p>Isolated: Selecting Isolated causes the traffic from this port to terminate at the AP.</p> <p>Bridge to WAN: The default setting, Bridge to WAN forwards packets arriving on this port to the WAN (uplink) port and eventually to their external destinations using Layer 2 forwarding.</p> <p>Local Subnet NAT and Route to WAN: This setting allows routing of packets to their destinations using Layer 3 network address translation (NAT).</p> <p>Bridge to L2TP Tunnel: Uses Layer 2 Tunneling Protocol to deliver packets encapsulated with an L2TP header in UDP datagrams.</p>
Local Subnet	<p>This option appears if you have selected Local Subnet and Route to WAN under Packet Forwarding, and you have selected Access Port as the port type. This option allows you to select which subnet this port's traffic is part of. You must have previously configured a subnet from the Configuration > Local Subnets page before it becomes available here.</p>
802.1X	<p>Configure the port as an 802.1X authenticator or supplicant. The following options are available:</p> <ul style="list-style-type: none"> • Disabled: No 802.1X controls are applied to this port. • Authenticator (Port-based): Only one of the attached MAC hosts must be authorized for all hosts to be granted access to the network. • Authenticator (MAC-based): Each MAC host is individually authenticated. • Supplicant: The port acts as a supplicant to an upstream authenticator. Configure a port as Supplicant if the port is a Trunk Port used to connect the AP to a LAN switch. <p>See Working with 802.1X on Wired Ethernet Ports on page 92 for more information.</p>
VLAN	<p>Untag ID: Enter a valid VLAN ID in this field to segment traffic arriving on this port to a specific VLAN. Default is 1. Valid VLAN entries are 1-4094.</p> <p>Members: Displays the VLAN membership of the port. (Membership is configurable only for the General port type.)</p> <p>Refer to VLAN Settings Overview on page 61 for more information.</p>

Configuration

Configuring the Access Point for Standalone Operation or Management by FlexMaster

Setting	Description
Insert DHCP Option 82	<p>When this option is enabled for an Ethernet port, additional information is encapsulated in DHCP option 82 and inserted into DHCP request packets.</p> <p>Current format of option 82 is:</p> <pre>Circuit ID sub-option: ETH:<IFNAME>:<VLAN>;N/A:<MODEL>:<HOSTNAME>:<DEVMAC></pre> <p>This option supports the ability for a service provider to allocate IP addresses intelligently by considering information on the origin of the IP allocation request.</p>
Client Fingerprinting	<p>When this option is Enabled, the AP attempts to identify client devices by their operating system, device type and host name, if available.</p>

3. Review the following table and make changes as needed for all of the Ethernet ports.

Table 28: All Ethernet port options

Setting	Description
Authentication Server (required)	Enter the authentication server IP address, port, and server secret for all Ethernet ports. Only available if 802.1X Authenticator are enabled (includes any packet forward selection).
Accounting Server (optional)	Enter the accounting server IP address, port, and server secret for all Ethernet ports. Only available if 802.1X Authenticator are enabled (includes any packet forward selection).
Supplicant User Name and Supplicant Password	Enter the 802.1X supplicant user name and password for all Ethernet ports. Only available if 802.1X Trunk port and Supplicant are enabled (includes any packet forward selection).

4. Click **Update Settings** to save your changes.

Setting Ethernet Port Type

Configure the Ethernet port type to define the port's VLAN behavior.

Ruckus Wireless AP Ethernet ports can be configured as one of the following port types:

- [Trunk Port](#) on page 91
- [Access Port](#) on page 91

- [General Port](#) on page 91

Trunk Port

Trunk Ports forward and receive tagged and untagged frames and are used for bridging switch ports together.

The Trunk port is a member of all VLANs that exist on the switch, and all VLAN-tagged traffic arriving on the port is seen. If an untagged frame is received on a Trunk port, the frame is associated with the *Untag VLAN* (also known as the *native VLAN*, by default, 1).

If a port is configured as a Trunk port, the Untag ID field can be used to define the Untag VLAN--the VLAN that the switch uses for forwarding and filtering when a frame arrives without an 802.1Q header.

Access Port

Access Ports are used to provide network access.

Traffic arriving on different Access Ports can be segmented into different logical networks (VLANs) using the Untag VLAN ID field. Access Ports are members of only one VLAN--the VLAN that is configured in the **Untag VLAN** field.

General Port

The General Port can be configured to support multiple tagged VLANs and one untagged VLAN.

As Trunk Ports by definition include all VLANs as members, the General Port is the only port type for which membership is user configurable for multiple VLANs.

Working with Port-Based VLANs

The AP provides options for segmenting all incoming traffic (both wireless and wired Ethernet traffic) into specific VLANs.

There are two ways to segment incoming traffic into VLANs:

- Each of the wireless interfaces (SSIDs) can be configured with a specific Access VLAN ID: (Configuration > Wireless > Wireless # (WLAN number) > Access VLAN).
- Each of the LAN ports can be configured with an Untag VLAN ID (Configuration > Ethernet Ports > VLAN > Untag ID).

For Ethernet ports, the behavior of the Untag VLAN ID depends on the Port Type selected. If the port is configured as a Trunk port, it includes all VLANs (1-4094) in its membership. The VLAN Untag ID field (default = 1) can be used to redefine the Native VLAN for the port.

If the Ethernet port is configured as an Access Port, it can be configured with only one Untag VLAN ID and its membership includes only that one VLAN.

If the Ethernet port is configured as a General Port, it can be configured to include multiple VLANs in its membership and one Untag VLAN.

Configuration

Configuring the Access Point for Standalone Operation or Management by FlexMaster

Working with 802.1X on Wired Ethernet Ports

This section provides an overview of the 802.1X (WPA-Enterprise) settings for AP Ethernet ports.

802.1X authentication consists of the following three components:

- **Supplicant:** The supplicant sends access request messages along with credentials, such as user name/password or digital certificate, to an authenticator, which forwards the credentials to the authentication server for verification.
- **Authenticator:** The authenticator challenges the identity of the supplicant, then passes its credentials to the AAA server. If the credentials are accepted the supplicant is allowed access.
- **Authentication Server (AAA Server):** The AAA server verifies the supplicant's credentials and permits or rejects its request for access.

For wired 802.1X, a Ruckus AP's Ethernet port can be configured as either an *Authenticator* or as a *Supplicant*, depending on which port type is selected. The following tables describe the 802.1X roles available by port type.

Table 29: Authenticator support by port type

	Trunk Port	Access Port	General Port
Port-based mode	X	X	X
MAC-based mode		X	

Table 30: Supplicant support by port type

	Trunk Port	Access Port	General Port
Supplicant	X		

The following considerations apply:

- A single port cannot be configured as both an Authenticator and Supplicant at the same time.
- Only one port per AP can be configured as a Supplicant.
- If the AP is connecting to a switch port with 802.1X authentication enabled, the AP's port type should be configured as a Trunk Port and its role should be configured as Supplicant. The switch port should be configured as a Trunk port in Port-based Authenticator mode.
- If there are multiple devices connected to an AP port (through a downstream switch), the port can be configured as either Port-based or MAC-based Authenticator. In Port-based mode, only one of the attached MAC hosts must be authorized for all hosts to be granted access to the network. In MAC-based mode, each MAC host is individually authenticated.
- If a Trunk Port is configured as a Supplicant, a user name and password must be entered to authenticate the port to the 802.1X-aware LAN switch.

- If an Access Port is configured as an Authenticator, the administrator must define the RADIUS server that the Authenticator communicates with. All Ethernet ports of a single AP are configured with the same RADIUS server.

Enable MAC authentication bypass

If MAC authentication bypass is enabled, the port first attempts to authenticate the attached device by MAC address, and if that fails, it tries to authenticate the device using 802.1X.

Configuring Hotspot Service

Hotspot service can be deployed on standalone Ruckus Wireless APs through the web interface.

At a minimum, you must configure a login redirect URL and a RADIUS server to which users are authenticated. Additional options and controls are provided on subsequent pages.

1. Go to **Configuration > Hotspot**.




Figure 37: Minimum configuration settings for providing Hotspot service

2. Click **Enabled** next to **Hotspot Service**.
3. Review the settings in the following table, and make changes as needed.

Configuration

Configuring the Access Point for Standalone Operation or Management by FlexMaster

Table 31: Hotspot configuration settings

Setting	Description
Redirect unauth. user to	Redirect unauthenticated users to the specified URL (login page).
After user is authenticated	Select where you want to redirect the user after successful authentication. <ul style="list-style-type: none">• Redirect to the above URL: return to the login URL configured above.• Redirect to the URL the user intended to visit: upon successful authentication, go directly to the URL that the user originally entered (typically the browser's home page).• Redirect to: specify a URL to which users are redirected after authentication. This can be used to redirect users to a "Login Successful" page, or a page that offers connection time information or a Logout button.
Primary RADIUS Server	Enter the IP address of the primary RADIUS server against which users are authenticated (required).
Secondary RADIUS Server	Enter the IP address of the secondary RADIUS server, if one is available (optional).
RADIUS Server Secret	Enter the shared secret for communication with the RADIUS server (required).

4. Click **Update Settings** to save your changes.

You have completed the minimum settings for providing Hotspot service on this AP. Additional configuration options are available using the **Edit Settings** buttons on the page: [Customizing Hotspot Optional Settings](#) on page 94.

Customizing Hotspot Optional Settings

Optional Hotspot settings include a number of options for fine-tuning your Hotspot service, such as maximum session time, grace period, accounting update interval, and so on.

1. Go to **Configuration > Hotspot**.

2. Click the **Edit Settings** button next to **More Options**. The **More Options** page appears.




Figure 38: Configuring optional Hotspot options

3. Configure the following Hotspot options as required:

Table 32: Optional Hotspot settings

Setting	Description
Temporarily block user after ___ unsuccessful login attempts	Specify the maximum number of repeated authentication failures allowed.
Redirect temp. blocked user to	Enter a redirect URL to which blocked users are redirected.
MAC Authentication	If enabled, the Hotspot service attempts to authenticate users based on their MAC addresses if the local Hotspot authentication has failed. An optional MAC authentication password can be entered. If no password is specified, the system uses the client's MAC address as the password.

Configuration

Configuring the Access Point for Standalone Operation or Management by FlexMaster

Setting	Description
Acct Delay Time	This attribute indicates how many seconds the client has been trying to send this record, and can be subtracted from the time of arrival on the server to find the approximate time of the event generating this Accounting-Request. When enabled, this attribute appears in accounting request packets with a starting value of "0", incremented each retry packet. When disabled, this attribute is not included in any accounting request packet.
NAS ID	Specify the Network Access Server identifier of this device. The NAS-ID attribute is sent in RADIUS access and accounting request messages. It can also be used as location identification when NAS-IP-Address cannot be used for this purpose.
WISPr Location ID	Specify the Hotspot location identifier. This value is provided in the RADIUS access and accounting requests. It is recommended that the value is in the form of <pre>"isocc=<ISO_Country_Code>, cc=<E.164_Country_Code>, ac=<E.164_Area_Code>, network=<SSID/ZONE>"</pre>
WISPr Location Name	Specify the hotspot location and operator's name. This value is provided in the RADIUS access and accounting requests. It is recommended that the value is in the form of <pre>"<HOTSPOT_OPERATOR_NAME>,<Location>"</pre>
Location Description	Specify the description of location. This value is provided in the HTTP redirection.
Accounting Update Interval	Specify the interval for RADIUS accounting requests.
Interim Redirect Interval	Specify the interval after which users are redirected to the login URL.
Maximum Session Time	Enter the maximum session time in minutes.
Grace Period	Specify the maximum time that a user may disconnect from the Hotspot service and return without the need to login again.

Setting	Description
RADIUS Disconnect Port	UDP port to listen to for accepting RADIUS disconnect requests.
Swap Input and Output Counters	Swap the value of input counters (packets, octets and giga words) and output counters in RADIUS accounting requests. This option is mainly for backward compatibility with existing ChilliSpot deployments.
Encode User Password	Encode user password with challenge string, if UAM secret is not specified; otherwise, encode user password with both challenge string and UAM secret.
UAM Shared Secret	The UAM Shared Secret is the shared secret between this AP and the HTTP server for the Redirection URL. This setting is optional.

4. Click **Update Settings** to save your changes.

Creating a Hotspot Walled Garden

You can use the Hotspot Walled Garden rules to designate network destinations (host address or subnet) that users can access without going through authentication.

A Walled Garden is a limited environment to which an unauthenticated user is given access for the purpose of setting up an account. After the account is established, the user is allowed out of the Walled Garden.

URLs are resolved to an IP address (up to four). Users may not be able to click through to other URLs presented on a page, if that page is hosted on a server with a different IP address. Avoid using common URLs that are translated into many IP addresses (such as www.yahoo.com), as users may be redirected to reauthenticate when they navigate through the page.

1. Go to **Configuration > Hotspot**.
2. Click **Walled Garden/Edit Settings**.
3. Click **Add new entry**. A field entitled **Walled Garden Host** appears.

Configuration

Configuring the Access Point for Standalone Operation or Management by FlexMaster




Figure 39: The Walled Garden hosts table

4. In **Walled Garden Host**, enter a host name, IP address, network segment (for example, 192.168.1.0/24) or a domain name. If a domain name is entered, it is resolved every five minutes.
5. Click **Update** to save your entry.

You can create up to 64 entries in the Walled Garden Hosts table.

Removing Hotspot Walled Garden Entries

Use the following procedure to remove entries from the hotspot Walled Garden table.

1. Click the check box next to the entry you want to remove, under the **Remove?** column.
2. Click **Update**. The entry is removed from the list.

Allowing Unrestricted Hotspot Access by MAC Address

This setting allows specific client MAC addresses to access the hotspot WLAN without requiring authentication.

MAC addresses listed in this table are allowed to bypass authentication to the hotspot WLAN.

1. Go to **Configuration > Hotspot**.
2. Click **Unrestricted Clients/Edit Settings**.
3. Click **Add new entry**, and enter the MAC address of a client in the fields provided.

Ruckus T710 Multimedia Hotzone Wireless AP LOGOUT

Configure :: Hotspot :: Unrestricted Clients Need Help?

Your parameters were saved

Unrestricted Clients Table

MAC Address	Remove?
00:01:02:03:04:05	<input type="checkbox"/>
01:02:03:04:05:06	<input type="checkbox"/>

[Add new entry](#) [Restore previous settings](#)

[Go back to Hotspot Configuration](#)

Status
Device
Internet
Local Subnets
Radio 2.4G
Radio 5G

Configuration
Device
Internet
Local Subnets
Radio 2.4G
Radio 5G
Ethernet Ports
Hotspot

Maintenance
Upgrade
Reboot / Reset
Support Info

Administration
Management
Diagnostics
Log

 **Ruckus T710 Multimedia Hotzone Wireless AP** © Copyright 2015 Ruckus Wireless

Figure 40: Configuring Hotspot unrestricted clients table

4. Click **Update** to save your changes.

Managing the Access Point

This section provides instructions for managing standalone Ruckus Wireless APs using the AP web interface.

For information on managing your Ruckus Wireless network using SmartZone or ZoneDirector controller, or FlexMaster server, refer to the relevant *User Guide*, available from the Ruckus Wireless Support website: support.ruckuswireless.com.

Viewing Current Device Settings

The **Status > Device** page displays a general overview of the AP's current status, including device name, MAC address, serial number, current software (image) version, and so on.

The screenshot shows the web interface for a Ruckus T710 Multimedia Hotzone Wireless AP. The page title is "Ruckus T710 Multimedia Hotzone Wireless AP" and it includes a "LOGOUT" button. The main content area is titled "Status :: Device" and contains the following information:

- Device Name: RuckusAP
- Device Location:
- Coordinate Source: gps
- GPS Coordinates: 37.411588, -122.019848
- PoE OUT Port: 'PoE OUT' port is disabled
- Power Consumption Mode: Unknown
- MAC Address: 74:3E:2B:06:8C:A0
- Serial Number: 521504909373
- Software Version: 104.0.0.101.98
- Internal Temperature: 30(C) 86(F) Tue Nov 24 18:09:48 2015 (GMT)
- Uptime: 10 mins 10 secs
- Current Time (GMT): Tue Nov 24 18:09:48 2015

Below this information is a "LAN Port Status" table with a "Refresh" button. The table has the following columns: Port, Interface, 802.1X, Logical Link, Physical Link, and Label.

Port	Interface	802.1X	Logical Link	Physical Link	Label
0	eth0	None	Up	Up 1000Mbps full	10/100/1000 PoE
1	eth1	None	Down	Down	10/100/1000
2	eth2	None	Down	Down	1000 SFP

The footer of the page includes the Ruckus logo and the text "Ruckus T710 Multimedia Hotzone Wireless AP" and "© Copyright 2015 Ruckus Wireless".

Figure 41: The Status > Device page

Viewing Current Internet Connection Settings

The **Status - Internet** page displays information on the AP's network settings; that is, the settings that allow the AP to communicate with your local network and the Internet.

Information includes IP address, gateway, DNS server, NTP server and connection type (method of obtaining an IP address -- DHCP or static IP).

Ruckus T710 Multimedia Hotzone Wireless AP LOGOUT

Status
 Device
 Internet
 Local Subnets
 Radio 2.4G
 Radio 5G

Configuration
 Device
 Internet
 Local Subnets
 Radio 2.4G
 Radio 5G
 Ethernet Ports
 Hotspot

Maintenance
 Upgrade
 Reboot / Reset
 Support Info

Administration
 Management
 Diagnostics
 Log

Status :: Internet Enable Auto-update Need Help?

Connection Status: ✔ Up
 MAC Address: 74:3e:2b:06:bca0
 NTP Server: ntp.ruckuswireless.com

IPv4 Status:
 Connection Type: dhcp
 IPv4 Address: 192.168.0.1
 IPv4 Subnet Mask: 255.255.255.0
 IPv4 Gateway: 0.0.0.0
 Primary DNS Server:
 Secondary DNS Server:
 DHCP Actions: Renew DHCP Release DHCP

IPv6 Status:
 Connection Type: autoconfig
 IPv6 Address: fe80::763e:2bff:fe06:bca0/64
 fc00::1/7
 IPv6 Gateway:
 Primary DNS Server:
 Secondary DNS Server:

Ruckus WIRELESS Ruckus T710 Multimedia Hotzone Wireless AP © Copyright 2015 Ruckus Wireless

Figure 42: The Status > Internet page

Viewing Current Local Subnet Settings

The **Status > Local Subnets** page can be used to view the router (local subnet) configurations and list of any clients connected to those subnets.

If you want to make changes to any of these settings, then go to **Configuration > Local Subnets**. Refer to [Configuring Local Subnets](#) on page 67 for more information.

Ruckus T710 Multimedia Hotzone Wireless AP LOGOUT

Status
 Device
 Internet
 Local Subnets
 Radio 2.4G
 Radio 5G

Configuration
 Device
 Internet
 Local Subnets
 Radio 2.4G
 Radio 5G
 Ethernet Ports
 Hotspot

Maintenance
 Upgrade
 Reboot / Reset
 Support Info

Administration
 Management
 Diagnostics
 Log

Status :: Local Subnet Enable Auto-update Need Help?

Local Subnet 1 | Local Subnet 2 | Local Subnet 3 | Local Subnet 4

Subnet: ✔ Enabled
 Local IP Address: 192.168.40.1
 MAC Address: 74:3e:2b:06:bca1

DHCP Server: ✔ Enabled
 Starting IP Address: 192.168.40.2
 Ending IP Address: 192.168.40.101

Access VLAN: 1

DHCP Clients Table
 No current DHCP clients

Ruckus WIRELESS Ruckus T710 Multimedia Hotzone Wireless AP © Copyright 2015 Ruckus Wireless

Administration

Managing the Access Point

Figure 43: The Status > Local Subnet page

Viewing Common Wireless Settings

If you want to view the current common wireless settings that the AP is using, go to the **Status > Wireless** page (on dual-band APs, go to **Status > 2.4G** or **Status > 5G**).

The following table lists the descriptions of each common wireless setting.




Figure 44: The Status > Wireless (Radio 2.4G/5G) > Common page

Table 33: Common Wireless settings

Setting	Description
Wireless Mode	<p>Shows the wireless mode that the AP is currently using. Possible values include:</p> <ul style="list-style-type: none">• Auto Select: (For 802.11b/g APs only) Allows both 802.11g- and 802.11b-compliant devices to connect to the network. This is the default setting.• 2.4GHz 54 Mbps: Allows 11g devices only.• 2.4GHz 11 Mbps: Allows 11b devices only.• 11ng: Operates with 802.11n, 802.11g and 802.11b devices in the 2.4Ghz spectrum only.• 11na: Operates with 802.11n and 802.11a devices in the 5GHz spectrum only.

Setting	Description
Channel	Shows the wireless channel that the AP is currently using. If you set the wireless channel to SmartSelect, this field shows the value Channel # [SmartSelect] .
Channel Width	11n/ac devices only. Displays whether the channel width is set to 20MHz or 40MHz.
Country Code	Shows the country code that the AP has been set to use. CAUTION! Verify that the AP is using the correct country code to make sure it uses only the allowed radio channels in your region. Selecting the incorrect country code may result in violation of applicable laws.
AeroScout RFID tag detection (some APs)	Shows Enabled if you enabled AeroScout RFID tag detection. The default setting is Disabled.
AeroScout Engine communication daemon (some APs)	Shows Up if the communication agent on the AP is able to relay location data from AeroScout Tags to the AeroScout Engine. If the communication agent is unable to relay data or AeroScout tag detection is disabled, this field shows Down .
Ekahau Engine communication daemon (some APs)	Shows Enabled if you have enabled Ekahau RFID tag detection. Default is disabled.
ERC IP (some APs)	Ekahau Real Time Location System RTLS Controller IP address.
ERC Port (some APs)	TCP port used by the Ekahau Real Time Location System RTLS Controller.

If you want to make changes to any of these settings, go to the **Configuration > Wireless** page. Refer to [Configuring Wireless Settings](#) on page 69 for more information.

Viewing Associated Wireless Clients

A usage-monitoring capability has been built into the AP to help you monitor wireless clients that are associated with your wireless network.

1. Go to **Status > Wireless**. The **Status > Wireless** page appears.

Administration

Managing the Access Point

NOTE If you are using a dual-band Ruckus Wireless AP, go to **Status > Radio 2.4G** or **Status > Radio 5G**.

2. Click any of the **Wireless #** (WLAN number) tabs. Wireless clients that are associated with this particular wireless LAN appear under **Connected Devices**.




Figure 45: Viewing connected devices

Changing the Administrative Login Settings

Configure admin settings using the **Configuration > Device** page.

The default user name is **super** and the default password is **sp-admin**. To prevent unauthorized users from logging in to the web interface using these default administrator login settings, Ruckus Wireless recommends that you change the default web interface password immediately after your first login.

1. Go to **Configuration > Device**.




Figure 46: The Configuration > Device page

2. Under **Service Provider Login**, change the default administrator login settings.
 - In **Username**, type a new user name to log in to the web interface. The default user name is **super**.
 - In **Current Password**, enter the existing password.
 - In **New Password**, type a new password to replace the default password **sp-admin**. The password must consist of six to 32 alphanumeric characters only.
 - In **Confirm New Password**, retype the new password.
3. Click **Update Settings**. The message **Your parameters were saved** appears. You have completed changing the default login settings. The next time you log in to the web interface, make sure you use these updated login settings.

Enabling Other Management Access Options

In addition to managing the AP via a web browser through HTTPS, several other management access options are available on the AP. These options include management access via HTTP, Telnet, and SSH.

You can also view and set up the connection to a Ruckus Wireless FlexMaster server under the **TR-069/SNMP Management Choice** options. If your Ruckus Wireless device is to be managed by FlexMaster, then the FlexMaster information (server URL and contact interval) is preconfigured before you receive your Ruckus wireless device.

Administration

Managing the Access Point

NOTE If you are configuring the AP to be managed by FlexMaster, remember to point it to the FlexMaster server after you configure the management access options. For more information, refer to [Pointing the AP to FlexMaster](#) on page 110.

1. Go to **Administration > Management**. The **Management** page appears.

The screenshot displays the 'Administration :: Management' page for a Ruckus T710 Multimedia Hotzone Wireless AP. The page is divided into a left sidebar with navigation menus (Status, Configuration, Maintenance, Administration) and a main content area. The main content area contains the following configuration options:

- Network Profile: 4bss
- Telnet Access? Enabled Disabled
- Telnet Port: 23
- SSH Access? Enabled Disabled
- SSH Port: 22
- HTTP Access? Enabled Disabled
- HTTP Port: 80
- HTTPS Access? Enabled Disabled
- HTTPS Port: 443
- Certificate Verification: PASSED
- Controller Discovery Agent (LWAPP)? Enabled Disabled
- SmartCellGateway Agent? Enabled Disabled
- Cloud Discovery Agent (FQDN) Enabled Disabled
- Set Controller Address (Reboot to take effect) Enabled Disabled
- PoE Operating Mode: AUTO
- TR069 / SNMP Management Choice: Auto (SNMP and TR069 will work together.)

Figure 47: The Administration > Management page

2. Review the access options listed in the following table, and then make changes as needed.

Table 34: Management Access Options

Option	Description
Telnet Access	By default, this option is disabled (inactive).
Telnet Port	This field lists the default Telnet port of 23 — only if Telnet is active. You can manually change this port number, if required.
SSH Access	By default, this option is enabled (active).

Option	Description
SSH Port	This field lists the default SSH port of 22—only if SSH is active. You can manually change this port number if required.
HTTP Access	This option is disabled by default.
HTTP Port	This field lists the default HTTP port of 80, if HTTP has been activated. You can manually change this port number if required.
HTTPS Access	By default this option is enabled. This connection mode requires a security certificate, a copy of which has been pre-installed in the device.
HTTPS Port	This field lists the default HTTPS port of 443—only if HTTPS has been activated. You can manually change this port number if required.
Certification Verification	This notes whether the security certificate linked to the HTTPS settings has been passed or not.
Controller Discovery Agent (LWAPP)	<ul style="list-style-type: none">• Enabled (default) -- Lightweight Access Point Protocol controller discovery on.• Disabled -- LWAPP controller discovery off.
SmartCell Gateway Agent	<ul style="list-style-type: none">• Enabled (default) -- Ruckus SmartZone (SZ) and SmartCell Gateway (SCG) controller discovery on.• Disabled -- SZ/SCG discovery off.
Cloud Discovery Agent (FQDN)	<ul style="list-style-type: none">• Enabled (default) -- Fully Qualified Domain Name cloud discovery on; requires enabled LWAPP controller discovery Enabled.• Disabled -- FQDN cloud discovery off.

Administration

Managing the Access Point

Option	Description
Set Controller Address	<ul style="list-style-type: none">• Enabled -- The AP uses an IP address to search for the primary and/or secondary controller. When Set Controller Address is Enabled, enter the required primary controller IP address and the optional secondary controller IP address.• Disabled (default) -- The AP does not use IP address(es) to search for controllers.
PoE Operating Mode (some APs)	AUTO = allow the AP to decide if it is to operate off of 802.3at or 802.3af power over Ethernet, or 802.3af PoE = force the AP to operate off of 802.3af power over Ethernet. Default = AUTO.

3. If you want to use TR-069 or SNMP to manage the AP, then configure the settings listed in the following table.

Table 35: TR-069 and SNMP Management Options

Option	Description
Auto	Enables the Ruckus Wireless device to be managed by either SNMP server, Ruckus Wireless ZoneDirector, or Ruckus Wireless FlexMaster.
SNMP only	Only allow SNMP management.
FlexMaster only	Only allow FlexMaster management.
DHCP Discovery	URL of server providing DHCP.
FlexMaster Server URL	URL of the FlexMaster server.
Digest-authentication Username/Digest-authentication password	This information is automatically generated by the AP and used for authentication with FlexMaster. Change this value only if you want the AP to connect to another access control server (ACS).

Option	Description
Periodic FlexMaster Inform Interval	Interval at which the device should attempt to contact FlexMaster. Default = 15 minutes.

- Click **Update Settings** to save your changes. A confirmation message appears at the top of the page.

You have completed configuring the management access options.

NOTE Remember to open any relevant firewall ports between the AP and the firmware upgrade/management server. For example, if HTTPS is used for firmware upgrades, open TCP port 443 on the firewall to allow connections through port 443. If FlexMaster server is used, open TCP ports 80 and 443 for HTTP/HTTPS communications, and TCP port 8082 for AP wake-up commands.

Viewing FlexMaster Management Status

If you configure the AP to be managed by FlexMaster, you can view the **TR-069 Status** section on the **Administration > Management** page.




Figure 48: TR-069 status information

The following table lists the TR-069 status information that the AP provides.

Table 36: TR-069 status information

Status Information	Description
Currently Using URL	Shows the FlexMaster server IP address or URL with which the AP is currently registered.

Administration

Managing the Access Point

Status Information	Description
Last Attempted Contact	Shows the date and time of the AP's last attempt to contact FlexMaster. Date and time are specified in GMT (or UTC), which are accurate if a Network Time Protocol (NTP) server is configured.
Last Successful Contact	Shows the date and time of the AP's last successful contact with FlexMaster.
Last Contact Result	Shows the result of the last attempt to contact FlexMaster (success or failure, and failure error code if applicable).
Current Time	Shows the current date and time as known to the AP. This timestamp is accurate if an NTP server is configured on the AP. If there is no NTP server configured, this timestamp is useful as a reference for comparison of the timestamps for Last attempted contact and Last successful contact .

Pointing the AP to FlexMaster

Your Ruckus Wireless device is required to "call home" to register with your FlexMaster; FlexMaster does not initiate initial contact.

To register successfully with FlexMaster, your Ruckus Wireless device must know the FlexMaster server's URL, thus entered on the device. You need TCP ports 80 and 443 between APs and FlexMaster when traversing Layer 3/firewall boundaries.

1. Go to **Administration > Management**.
2. Under **TR-069/SNMP Management Choice**, click **Auto**.
3. In **FlexMaster Server URL**, type the URL of the FlexMaster server.
4. Toggle the **Periodic FlexMaster Inform Interval** drop-down list to select how frequently the device checks the FlexMaster server for any pending configuration changes available for that Ruckus Wireless unit. On the FlexMaster side, this field is referred to as the Periodic Inform Interval.
5. Click **Update Settings** to save your changes.

After the AP registers with FlexMaster, this **Administration > Management** page will show the communication status between the AP and FlexMaster.

Working with Event Logs and Syslog Servers

AP event logs can be viewed in your browser, or set for automatic delivery to a syslog server.

Both the **Maintenance > Support Info** and **Administration > Log** pages can be used to view the AP's current log file text. You can use the former to send the log to Ruckus Wireless support or save it to a local file, and use the latter to configure automatic delivery of log files to a syslog server.

Enabling Logging and Sending Event Logs to a Syslog Server

If you have a syslog server on the network, you can configure the AP to send the device logs to the server. Enable logging (if disabled) and configure the AP to send logs to the syslog server.

1. Go to **Administration > Log**. The **Administration > Log** page appears.




Figure 49: The Administration > Log page

2. Look for **Log Status**, and then click **Enabled**.
3. After enabling logging, configure the following options:
 - **Syslog Server Address:** To enable the AP to send messages to a syslog server as they appear, enter the IP address of the syslog server.
 - **Syslog Server Port:** By default, the syslog port number is 514. If the syslog server is using a different port, enter that port number in this field.
4. Click **Update Settings** to save and apply your changes.

Sending a Copy of the Log File to Ruckus Wireless Support

The Support Info log consists of the configuration and run-time status of the AP and can be useful for troubleshooting.

You have three options for sending a copy of the current log file to Ruckus Wireless Support:

- Save a copy to your local PC, then attach it to an e-mail message and send it to support.
 - Set up a connection to an FTP site.
 - Set up a connection to a TFTP site.
1. Go to **Maintenance > Support Info**. The **Maintenance > Support Info** page appears.
 2. To upload a copy of the support info file to an FTP or TFTP server, click the **Transfer Method TFTP** or **FTP** option.
 3. In **Server Address**, enter the FTP or TFTP server IP address.
 4. In **Filename**, enter a name for the file that you are saving.

NOTE Remember to add a .TXT file extension to the file name, especially if you are using Internet Explorer as your web Admin "host."

5. If you selected the FTP option, then also enter a **Username** and **Password**.
6. Click **Upload Now**.

Saving a Copy of the Log File to Your Computer

You can save a copy of the current log to your own computer, if needed.

1. Go to **Maintenance > Support Info**. The **Maintenance > Support Info** workspace appears.
2. Click the **Transfer Method Save to Local Computer** option. Up to three links appear next to Download (supportinfo.txt, cmsupportinfo.txt and/or tr069info.txt).
3. Click the **supportinfo.txt** link. A new window (or tab) opens with the content of the log file displayed.

NOTE The *cmsupportinfo.txt* file includes support information for an AP with integral cable modem (such as 7781CM), and the *tr069info.txt* file includes support information for an AP being managed by FlexMaster.

4. Choose **Save As** or **Save Page As** from your browser's File menu.
5. When the **"Save as..."** dialog box appears, find a convenient location on your local computer to save the file, and change the file extension from .html to .txt.
6. Click **Save** to save the log file to your computer.

Upgrading the Firmware

You can use the web interface to check for software updates/upgrades for the firmware image built into the AP.

You can then apply these updates to the device in one of two ways: (1) manual updating on an as-needed basis or (2) automating a regularly scheduled update.

Before starting, decide which option you want to take:

- Automate a regularly scheduled update.
- Run a one-time manual update right now.

By default, the automatic upgrade option is disabled.

To upgrade the firmware image, go to **Maintenance > Upgrade**. When the **Maintenance > Upgrade** options appear, decide which upgrade method to use.

The screenshot shows the web interface for a Ruckus T710 Multimedia Hotzone Wireless AP. The page title is "Maintenance :: Upgrade". On the left, there is a navigation menu with sections: Status (Device, Internet, Local Subnets, Radio 2.4G, Radio 5G), Configuration (Device, Internet, Local Subnets, Radio 2.4G, Radio 5G, Ethernet Ports, Hotspot), Maintenance (Upgrade, Reboot / Reset, Support Info), and Administration (Management, Diagnostics, Log). The main content area has a "Logout" button in the top right and a "Need Help?" button. Below the title, there are radio buttons for "Upgrade Method": TFTP, FTP (selected), Web, and Local. Under "FTP Options", there are input fields for "Firmware Server" (fwupdate1.ruckuswireless.com), "Port" (21), "Image Control File" (t710_9991_cntrl.rcks), "Username" (t710), and "Password" (masked with asterisks). Below these is an "Auto Upgrade?" section with radio buttons for "Enabled" and "Disabled" (selected). A red-bordered box contains a warning: "Changes made to this area apply to the Automatic Firmware Update settings as well. WARNING: Upgrading the firmware could take a few minutes and your network will not be available during this time. Please do NOT remove power from your device until the upgrade finishes." At the bottom of the form are three buttons: "Perform Upgrade", "Save parameters only", and "Restore previous settings". The footer of the page includes the Ruckus logo and "Ruckus T710 Multimedia Hotzone Wireless AP" along with a copyright notice: "© Copyright 2015 Ruckus Wireless".

Figure 50: The Maintenance > Upgrade page

Each of the upgrade options listed on the Upgrade page are discussed in the following sections.

- [Upgrading Manually via FTP or TFTP](#) on page 114
- [Upgrading Manually via the Web](#) on page 114
- [Upgrading Manually via Local File](#) on page 114
- [Scheduling Automatic Upgrades](#) on page 114

Upgrading Manually via FTP or TFTP

Use this procedure to manually upgrade the AP using FTP or TFTP.

1. In the **Upgrade Method** options, click **FTP** (default) or **TFTP**.
2. Click the **host name** field, and then type the URL of the server. Or click the **IP address** field, and then type the IP address of the server. Remember to start the URL with ftp://.

CAUTION! Do not change any of the **Image Control File**, **Username** or **Password** entries.

3. Click **Perform Upgrade**. A status bar appears during the upgrade process.

After the upgrade is completed, you must manually reboot the AP.

Upgrading Manually via the Web

Use this procedure to manually upgrade the AP via the web.

1. In the **Upgrade Method** options, click **Web**.
2. If instructed to choose a different URL than the default value, type the URL of the download website in **URL**. Remember to start the URL with http://.
3. Click **Perform Upgrade**. A status bar appears during the upgrade process.

After the upgrade is completed, you must manually reboot the AP.

Upgrading Manually via Local File

If you have downloaded an AP firmware image, use this procedure to manually upgrade to the new image using the local file.

1. In the **Upgrade Method**, select **Local**.
2. Click **Choose File** and locate the file on your local computer.
3. Select the file and click **Open**.
4. Click **Perform Upgrade**. Status messages appear during the upgrade and reboot process.

Scheduling Automatic Upgrades

Use this procedure to set the AP to automatically search for and install the latest firmware at a specified interval.

1. In the **Upgrade Method** options, click the button for your preferred choice.
2. Enter the appropriate information in the **Host name** or **IP address** field.

NOTE Do not change any of the **Image Control File**, **Username** or **Password** entries.

3. Verify that the **Auto Upgrade** option is set to **Enabled**.

4. Toggle the Interval to **Check for Software Upgrade** drop-down list to select your preferred interval.
5. Choose whether to reboot immediately after upgrading, or schedule the reboot for a specific time of day using the **Schedule Reboot Time After Upgrade** list. Choosing **Any Time** (the default value) results in the AP performing a reboot immediately after the automatic upgrade is successful.
6. You have two options at this point:
 - Click **Perform Upgrade**, which starts the process and the clock. The next upgrade occurs at the selected interval.
 - Click **Save parameters only**. The clock starts right away, and the actual upgrade occurs at the first effective interval.

After you click one of these two options, a status bar appears during the upgrade process.

When the upgrade is complete, the AP automatically reboots at the time you specified in Step 5.

Rebooting the AP and Cable Modem

You can use the web interface to prompt the AP to reboot, which restarts the AP without changing any of the current settings. If your AP is equipped with an integral cable modem (such as a 7781CM), then you can use the AP web interface to prompt the CM to reboot, which restarts the CM without changing any of the current settings.

NOTE Please note that rebooting the AP or CM disrupts network communications in any currently active WLANs.

1. Go to **Maintenance > Reboot/Reset**. The **Maintenance > Reboot/Reset** page appears.

Administration

Managing the Access Point




Figure 51: The Maintenance > Reboot/Reset screen

2. To reboot the AP, click **Reboot AP with current settings/Reboot Now**. After a brief pause, you are logged out of the AP.
3. To reboot the CM, click **Reboot Cable Modem/Reboot Now**. After a brief pause, you are logged out of the AP.
4. After approximately one minute, you should be able to log back into the AP, which verifies that the reboot was successful. You can also check the LEDs on the AP to verify the status of the device.

NOTE The 7781CM AP with integral cable modem can also be remotely reset using the OID and CLI commands described in the *7781CM Installation Guide*.

Resetting the AP to Factory Defaults

You can use the web interface to restore an inoperative AP to its factory default settings, which completely erases the configuration currently active in the device. Note that this disrupts all wireless network communications through this device.

CAUTION! DO NOT reset the AP to factory defaults unless you are directed to do so by Ruckus Wireless support staff or by a network administrator. Do this only if you are able to immediately reconnect the restored AP to your computer, to reconfigure it for Wi-Fi network use — as detailed in [Configuring Wireless Settings](#) on page 69.


1. Go to **Maintenance > Reboot/Reset**. The **Maintenance > Reboot/Reset** page appears.
2. Click **Reset now (next to Reset the AP to factory settings)**.
3. When the confirmation warning appears, read the message and click **OK** if you are certain that you want to restore the AP to factory defaults.

After a brief pause, you are automatically logged out of the AP. You must now disconnect the AP from the switch (and the network) and reconnect it to your computer, as described in the associated *AP Installation Guide*. At this time, you can restore the network settings, then replace it in your site for full network use.

Running Diagnostics

Two network connection diagnostic tools, ping and traceroute, have been built into the AP to help you check network connections from the web interface.

1. Go to **Administration > Diagnostics**. The **Administration > Diagnostics** page appears. Two options are available:
 - Ping
 - Traceroute
2. Click the text field by the option you want to activate, and type the network address of a site you wish to connect to.
3. Click **Run test**.
4. The results appear in the text field below each option.



Administration

Where to Find More Information

Figure 52: Running Ping and Traceroute tools

Where to Find More Information

If you have questions that this User Guide does not address, visit the Ruckus Wireless Support Portal at <http://support.ruckuswireless.com>.

The Support Portal hosts the latest versions of user documentation. You can also find answers to frequently asked questions (FAQs) for each Ruckus Wireless product type.

Administration

Where to Find More Information

Appendix A: Support for Bluetooth Low Energy Devices

Some Ruckus Wireless APs, such as the T610, support customer-supplied, low-power (1W or less), Bluetooth Low Energy (BLE) devices, such as BLE beacons.

The BLE devices plug into a USB port on the AP, and the AP can be configured to turn power to the USB port either on or off.

The Ruckus Wireless APs with USB ports supporting BLE devices can provide power to the BLE device. The BLE devices perform whatever tasks they are designed to do without interference from or control (other than supplying USB power) by the Ruckus Wireless network equipment.

Appendix B: Configuring Link Aggregation (LACP) for AP Backhaul

LACP provides a means of aggregating multiple Ethernet ports into one logical link, thereby increasing the maximum uplink throughput beyond the limits of a single port.

Some Ruckus APs, including the R610, R710, R720, T610, and T710, can use link aggregation control protocol (LACP) as defined in the 802.1ax (formerly 802.3ad) standard to control the bonding of two 1Gbps physical Ethernet ports together to form a single 2Gbps logical link.

The following APs support LACP:

- R610
- R710
- R720
- T610/T610s
- T710/T710s

Link Aggregation and When To Use It

Beginning with 802.11ac "Wave 2," some higher capacity APs such as the R710 have become capable of passing wireless traffic in excess of 1Gbps. This only occurs in extreme cases, such as during concurrent dual-band operation over the widest possible channels and highest possible modulation and coding scheme (MCS) rates in each band, with all traffic flowing in the same direction. In such cases, a single Gigabit Ethernet backhaul will saturate and limit the AP's capacity to less than 1Gbps.

To alleviate this backhaul limitation, link aggregation can be used to bond multiple Gigabit Ethernet links into a single, high capacity logical link. The AP's link partner, typically an Ethernet switch, must also support LACP and be configured to use this feature.

Wi-Fi client capabilities and data demands should be considered before deploying LACP for AP backhaul. For the vast majority of enterprise WLANs, single Gigabit backhaul for APs is more than sufficient.

Configuring LACP

LACP is configurable via the AP CLI on T710. The set bond command is used with the following syntax:

```
set bond <profile> {options}
+++++
** <profile>: bond0, ...
** options:
  - lacp-rate [0,1], 0 for slow, 1 for fast
  - xmit-hash [0,1,2], 0 for L(ayer2), 1 for L3+4, 2
```

Appendix B: Configuring Link Aggregation (LACP) for AP Backhaul

```
for L2+3
  - {add|delete} <ethX>
  ++++++
```

Profile (profile) – “bond0” is the only valid profile name.

Options:

- LACP rate (lACP-rate) defines the rate at which the AP asks its link partner (usually the switch) to transmit LACP control packets (LACPDUs). A faster rate allows the link end-points to respond quicker to any changes on the physical interface (for instance, failover in case of one of the ports is disconnected) at the expense of more overhead. The slow (default) rate is adequate for the vast majority of Enterprise WLAN cases.
- Slow (lACP-rate 0) (default) requests link partner to transmit LACPDUs every 30 seconds.
- Fast (lACP-rate 1) requests link partner to transmit LACPDUs every one second.
- Transmit hash (xmit-hash) defines how the AP chooses to distribute packets between the two physical Ethernet links which comprise the bonded link. Network topology and expected traffic flows should be considered when choosing which transmit hash option to use so as to spread traffic as evenly as possible between the two physical links.
- Layer 2 (xmit-hash 0) (default) uses the source & destination MAC addresses in the packet to determine which physical link the packet is sent over. This is a fully-compliant 802.3ad option.
- Layer 3 & Layer 4 (xmit-hash 1) uses source & destination IP addresses as well as source & destination ports. This policy uses upper layer protocol information, when available, to generate the hash. This allows packets destined for a particular network peer to be distributed across both physical links, although a single connection is limited to one of the physical links.

For fragmented packets, layer 4 information is omitted.

This algorithm is not fully 802.3ad compliant.

- Layer 2 & Layer 3 (xmit-hash 2) uses source & destination MAC addresses as well as source & destination IP addresses. This algorithm places all traffic to a particular network peer on the same physical link. For non-IP traffic, the formula is the same as for the layer2 transmit hash policy. This policy is intended to provide a more balanced distribution of traffic than layer2 alone, especially in environments where a layer3 gateway device is required to reach most destinations. This algorithm is 802.3ad compliant.
- Add or Delete (add|delete) are used to explicitly define which physical Ethernet ports (ethx) are part of the bond interface (bond0). At a bare minimum, to enable LACP on the AP this option must be used to add both physical ports to the bond interface.

Examples

Enable with defaults:

```
:set bond bond0 add eth0
```

```
:set bond bond0 add eth1
```

Enable and modify LACP rate & distribution algorithm:

```
:set bond bond0 add eth0
```

```
:set bond bond0 add eth1
```

```
:set bond bond0 xmit-hash 1
```

```
:set bond bond0 lacp-rate 1
```

Apply VLANs untag ID to bonded interface:

```
:set interface bond0 type trunk untag 777
```

Caveats

- As of this writing, the controller and AP web UIs do not expose LACP settings or configuration. If an AP is configured via AP CLI to bond its Ethernet ports, then any per-Ethernet port settings in the web UI are ignored by the AP.
- Link aggregation between Ethernet and SFP port is not supported.



Copyright © 2017. Ruckus Wireless, Inc.
350 West Java Drive, Sunnyvale, CA

www.ruckuswireless.com