



Ruckus Wireless™ ZoneDirector™ Command Line Interface

Reference Guide

Current as of ZoneDirector firmware version 9.6.2

Part Number 800-70497-001 Rev B
Published December 2013

www.ruckuswireless.com

Contents

About This Guide

Conventions	i
Documentation Comments	ii

1 Understanding the ZoneDirector Command Line Interface

Introduction	2
Accessing the Command Line Interface	2
Requirements	2
Step 1: Connecting the Administrative Computer to ZoneDirector	2
Connecting ZoneDirector 1100	3
Connecting ZoneDirector 3000/5000	3
Step 2: Start and Configure the Telnet/SSH Client	3
Step 3: Log Into the CLI	6
Using the Help Command	8
Using the ? Command	8
Top-Level Commands	9

2 Viewing Current Configuration

Show Commands Overview	11
Show AAA Commands	11
Show DHCP Commands	13
Show Access Point Commands	14
Show AP Group Commands	20
Show AP Policy Commands	24
Show System Configuration Commands	24
Show Performance Commands	26
Show System Information Commands	28
Show Ethernet Info Commands	29
Show Technical Support Commands	30
Show Management ACL Commands	32
Show Static Route Commands	34
Show WLAN Commands	35

Show WLAN Group Commands	39
Show L2 Access Control List Commands	40
Show L3 Access Control List Commands	42
Show Hotspot Commands	44
Show Role Commands	53
Show User Commands	54
Show Currently Active Clients Commands	55
Show Mesh Commands	58
Show Dynamic PSK Commands	59
Show Dynamic Certificate Commands	60
Show Guest Pass Commands	60
Show Rogue Device Commands	61
Show Events and Activities Commands	61
Show Alarm Commands	62
Show License Commands	63
Show USB Software Commands	63
Show Session-Timeout Commands	64
Show Active Wired Client Commands	64
Monitor AP MAC Commands	65
Monitor Currently Active Client Commands	67
Monitor Sysinfo Commands	68

3 Configuring Controller Settings

Configuration Commands Overview	71
General Config Commands	71
Configure Context Show Commands	71
Configure AAA Server Commands	73
Configure DHCP Server Commands	86
Configure Admin Commands	88
Admin Authentication Commands	90
Configure Access Points	91
Radio 2.4/5 GHz Commands	96
AP Port Setting Commands	106
Configure AP Policy Commands	115
Configure AP Group Commands	124

Radio 2.4/5 GHz Commands	127
QoS Commands	134
Model-Specific Commands	135
AP Group Membership	141
Model-Specific Port Settings	142
Configure Certificate Commands	153
Configure Hotspot Redirect Settings	154
Configure Layer 2 Access Control Commands	156
Configure Layer 3 Access Control Commands	162
Layer 3 IPv6 Access Control List Commands	171
Configure Precedence Policy Commands	173
Configure Device Policy Commands	175
Configure Load Balancing Commands	179
Configure STP Commands	183
Configure System Commands	184
Interface Commands	185
Smart Redundancy Commands	190
Management Interface Commands	191
SNMPv2 Commands	195
SNMPv3 Commands	196
Syslog Settings Commands	198
Management Access Control List Commands	201
QoS Commands	203
Management ACL Commands	211
Configure UPNP Settings	215
Configure Zero-IT Settings	216
Configure Dynamic PSK Expiration	216
Configure WLAN Settings Commands	217
Configure WLAN Group Settings Commands	261
Configure Role Commands	267
Configure User Commands	274
Configure Guest Access Commands	279
Guest Access Restriction Commands	285
IPv6 Guest Restrict Access Commands	290
Configure Hotspot Commands	297
Hotspot Access Restriction Commands	312
Configure Hotspot 2.0 Commands	316

Configure Mesh Commands	334
Configure Alarm Commands	339
Configure Alarm-Event Settings	345
Configure Services Commands	348
Configure WIPS Commands	358

4 Using Debug Commands

Debug Commands Overview	361
General Debug Commands	361
Show Commands	365
Accessing a Remote AP CLI	370
Working with Debug Logs and Log Settings	371
Remote Troubleshooting	384
AP Core Dump Collection	385
Script Execution	386

Index

About This Guide

This *Ruckus Wireless ZoneDirector Command Line Interface Reference Guide* contains the syntax and commands for configuring and managing ZoneDirector from a command line interface.

This guide is written for service operators and system administrators who are responsible for managing, configuring, and troubleshooting Ruckus Wireless devices. Consequently, it assumes a basic working knowledge of local area networks, wireless networking, and wireless devices.



NOTE: If a release note is shipped with ZoneDirector your Ruckus Wireless product and the information there differs from the information in this guide, follow the instructions in the release note.

Most user guides and release notes are available in Adobe Acrobat Reader Portable Document Format (PDF) or HTML on the Ruckus Wireless Support Web site at:

<http://support.ruckuswireless.com/>

Conventions

[Table 1](#) and [Table 2](#) list the text and notice conventions that are used throughout this guide.

Table 1. Text Conventions

Convention	Description	Example
monospace	Represents information as it appears on screen	[Device name]>
monospace bold	Represents information that you enter	[Device name]> set ipaddr 10.0.0.12
default font bold	Keyboard keys, software buttons, and field names	On the Start menu, click All Programs .
<i>italics</i>	Screen or page names	Click Advanced Settings . The <i>Advanced Settings</i> page appears.

Table 2. Notice Conventions

Icon	Notice Type	Description
	Information	Information that describes important features or instructions
	Caution	Information that alerts you to potential loss of data or potential damage to an application, system, or device
	Warning	Information that alerts you to potential personal injury

Documentation Comments

Ruckus Wireless is interested in improving its documentation and welcomes your comments and suggestions. You can email your comments to Ruckus Wireless at:

docs@ruckuswireless.com

When contacting us, please include the following information:

- Document title
- Document part number (on the cover page)
- Page number (if appropriate)

For example:

- Ruckus Wireless ZoneDirector Command Line Interface Reference Guide
- Part number: 800-70497-001 Rev B
- Page 88

Please note that we can only respond to comments and questions about Ruckus Wireless product documentation at this email address. Questions related to technical support or sales should be directed in the first instance to your network supplier.

Understanding the ZoneDirector Command Line Interface

In This Chapter

Introduction	2
Accessing the Command Line Interface	2
Using the Help Command	8
Using the ? Command	8
Top-Level Commands	9

Introduction

The Ruckus Wireless ZoneDirector command line interface (CLI) is a software tool that enables you to configure and manage ZoneDirector, Ruckus Wireless's wireless LAN controller.

Using the command line interface, you can issue commands from an operating system prompt, such as the Microsoft Windows command prompt or a Linux operating system terminal. Each command performs a specific action for configuring device settings or returning information about the status of a specific device feature.

Accessing the Command Line Interface

This section describes the requirements and the procedure for accessing the ZoneDirector CLI.

Requirements

To access the ZoneDirector CLI, you will need the following:

- A computer that you want to designate as administrative computer
- A network connection to ZoneDirector, or
- An RS-232 serial cable (type depends on the ZoneDirector model):
 - If you are using ZoneDirector 3000/5000, you need an RS-232 serial to Ethernet cable.
 - If you are using ZoneDirector 1100, you need a DB-9 RS-232 to RS-232 cable.
- A Telnet or SSH (secure shell) client program

Step 1: Connecting the Administrative Computer to ZoneDirector

The ZoneDirector Command Line Interface can be accessed in one of two ways:

- [Using Telnet or SSH](#)
- [Using a Serial Connection](#)

Using Telnet or SSH

1. Ensure that the administrative computer and ZoneDirector are on the same subnet or broadcast domain.
2. Continue to ["Step 2: Start and Configure the Telnet/SSH Client"](#).

Using a Serial Connection

The steps for connecting the administrative computer directly to ZoneDirector using a serial cable depend on the ZoneDirector model that you are using. Refer to the relevant section below.

- [Connecting ZoneDirector 1100](#)
- [Connecting ZoneDirector 3000/5000](#)



NOTE: Before continuing, make sure that both the administrative computer and ZoneDirector are both powered on.

Connecting ZoneDirector 1100

1. Connect one end of the RS-232 cable to the port labeled *Console* on ZoneDirector.
2. Connect the other end of the RS-232 cable to a COM port on the administrative computer.

Connecting ZoneDirector 3000/5000

1. Connect the RJ-45 end of the cable to the port labeled *Console* on ZoneDirector.
2. Connect the RS-232 end of the cable to a COM port on the administrative computer.

Step 2: Start and Configure the Telnet/SSH Client

Before starting this procedure, make sure that your Telnet/SSH client is already installed on the administrative computer.



NOTE: The following procedure uses PuTTY, a free and open source Telnet/SSH client, for accessing the ZoneDirector CLI. If you are using a different Telnet/SSH client, the procedure may be slightly different (although the connection settings should be the same). For more information on PuTTY, visit www.putty.org.

See the following section depending on your connection method:

- [Using Telnet or SSH](#)
- [Using a Serial Connection](#)

Using Telnet or SSH


To start and configure the Telnet/SSH client

1. Start PuTTY. The PuTTY Configuration dialog box appears, showing the *Session* screen.
2. In *Connection type*, select **Telnet or SSH**.



NOTE: Telnet access is disabled by default for security reasons. SSH is the recommended access method and you will not be allowed to access the ZoneDirector CLI via Telnet unless you have specifically enabled Telnet access. You can enable Telnet server from the ZoneDirector Web interface by going to **Configure > System > Network Management** and selecting **Enable Telnet Server**.

Figure 1. Selecting SSH as the connection type



3. Enter the ZoneDirector IP address in the **Host Name (or IP address)** field.
4. Click **Open**. The PuTTY console appears and displays the login prompt.

Using a Serial Connection


To start and configure the Telnet/SSH client

1. Start PuTTY. The PuTTY Configuration dialog box appears, showing the Session screen.
2. In Connection type, select **Serial** if you are connecting via serial cable.

Understanding the ZoneDirector Command Line Interface


Accessing the Command Line Interface

Figure 2. Select Serial as the connection type



3. Under Category, click **Connection** > **Serial**. The serial connection options appear on the right side of the dialog box, displaying PuTTY's default serial connection settings.

Figure 3. PuTTY's default serial connection settings




4. Configure the serial connection settings as follows:

- **Serial line to connect to:** Type the COM port name to which you connected the RS-232 cable.
- **Bits per second:** 115200
- **Data bits:** 8
- **Stop bits:** 1
- **Parity:** None


- Flow control: None

Figure 4. PuTTY's serial connection settings for connecting to ZoneDirector



5. Click **Open**. The PuTTY console appears and displays the login prompt.

Figure 5. The PuTTY console displaying the login prompt



You have completed configuring the Telnet/SSH client to connect to ZoneDirector.

Step 3: Log Into the CLI

1. At the login as prompt, press <Enter> once.
1. At the Please login prompt, type **admin**, and then press <Enter>.

2. At the Password prompt, type **admin**, and then press <Enter>. The Ruckus Wireless ZoneDirector CLI welcome message and the **ruckus** prompt appears.

You are now logged into the ZoneDirector CLI as a user with limited privileges. As a user with limited privileges, you can view a history of commands that were previously executed and ping a device. If you want to run more commands, you can switch to privileged mode by entering **enable** at the root prompt.

To view a list of commands that are available at the root level, enter **help** or **?**.



NOTE: You can tell if you are logged into the CLI in limited or privileged mode by looking at the **ruckus** prompt. If you are in limited mode, the prompt appears as **ruckus>** (with a *greater than* sign). If you are in privileged mode, the prompt appears as **ruckus#** (with a *pound* sign).



NOTE: To enable privileged mode when another user session is enabled, use the <force> option with the enable command to force disconnect of the previous user session. (i.e., **enable force**).

Using the Help Command

To display all commands that the Ruckus Wireless CLI supports, use the `help` command.



CAUTION: Entering the `help` command into the CLI prints a long list of commands on the screen. If you only want to view the commands that are available from within a specific context, use the `?` command. See ["Using the ? Command"](#) below for more information.

Using the ? Command

To display commands that are available within a specific context, use the `?` command.

Example

To display commands within the `debug` context, enter the following command:

```
ruckus# debug
ruckus(debug)# ?

  help      Shows available commands.
  history   Shows a list of previously run commands.
  quit      Exits the debug context.
  fw_upgrade Upgrades the controller's firmware.
  delete-
  station
  <MAC>
  restart-ap Restarts a device.
  <MAC>
  wlaninfo  Configures and enables debugging of WLAN
             service settings.
  show      Contains commands that can be executed from
             within the context.
  ps        Displays information about all processes that
             are running (ps -aux).
  save_debug_ Saves debug information.
  info <IP-
  ADDR>
  <FILE-NAME>
  remote_ap_c Executes AP CLI command in remote AP.
  li
  save-config Upload the configuration to the designated
  <IP-ADDR>  TFTP site.
  <FILE-NAME>
  logs      Contains commands that can be executed from
             within the context.
```

no	Contains commands that can be executed from within the context.
remote-troubleshooting	Troubleshooting commands group.
collect_ap_coredump	Enable AP core dump collection.
script	Manages system script for debug.

Top-Level Commands

The following table lists the top-level CLI commands available in privileged mode.

exit	End the CLI session.
help	Show available commands.
quit	End the CLI session
history	Show a list of previously run commands.
disable	Disable privileged commands.
ping <IP-ADDR/DOMAIN-NAME>	Send ICMP echo packets to an IP/IPv6 address or domain name.
reboot	Reboot the controller
set-factory	Reset the controller to factory defaults.
config	Enter the config context.
debug	Enter the debug context.
show	Display system options and settings.
session-timeout <NUMBER>	Set the CLI session timeout.
monitor	Begin system status monitoring.

Viewing Current Configuration

In This Chapter

Show Commands Overview	11
Show AAA Commands	11
Show DHCP Commands	13
Show Access Point Commands	14
Show AP Group Commands	20
Show AP Policy Commands	24
Show System Configuration Commands	24
Show Performance Commands	26
Show System Information Commands	28
Show Ethernet Info Commands	29
Show Technical Support Commands	30
Show Management ACL Commands	32
Show Static Route Commands	34
Show WLAN Commands	35
Show WLAN Group Commands	39
Show L2 Access Control List Commands	40
Show L3 Access Control List Commands	42
Show Hotspot Commands	44
Show Role Commands	53
Show User Commands	54
Show Currently Active Clients Commands	55
Show Mesh Commands	58
Show Dynamic PSK Commands	59
Show Dynamic Certificate Commands	60
Show Guest Pass Commands	60
Show Rogue Device Commands	61
Show Events and Activities Commands	61
Show Alarm Commands	62
Show USB Software Commands	63
Show License Commands	63
Show Session-Timeout Commands	64
Show Active Wired Client Commands	64
Monitor AP MAC Commands	65
Monitor Currently Active Client Commands	67
Monitor Sysinfo Commands	68

Viewing Current Configuration

Show Commands Overview

Show Commands Overview

Show commands display the controller's current settings such as system status and system configuration settings, along with the status and configurations of the controller's WLAN services, users, roles, AAA servers, access points, connected clients, AP groups and WLAN groups, etc.

Monitor commands allow the administrator to enter monitoring mode to view status and configuration changes as they occur.

Show AAA Commands

Use the `show aaa` commands to display information about the authentication, authorization and accounting servers (AAA) servers that have been added to the controller.

show aaa all

To display a list of all AAA servers that have been added to the controller, use the following command:

```
show aaa all
```

Syntax Description

show	Display information
aaa	Display AAA server information
all	All AAA servers

Defaults

None.

Example

```
ruckus# show aaa all
AAA:
ID:
1:
Name= Local Database
Type= Local

2:
Name= Guest Accounts
Type= Guest

3:
Name= RADIUS Accounting
Type= RADIUS Accounting server
```

```
Primary RADIUS Accounting:  
IP Address= 192.168.11.7  
Port= 1813  
Secret= secret  
Secondary RADIUS Accounting:  
Status= Disabled  
  
4:  
Name= Ruckus RADIUS  
Type= RADIUS server  
Auth Method=  
Primary RADIUS:  
IP Address= 192.168.11.99  
Port= 1812  
Secret= secret  
Secondary RADIUS:  
Status= Disabled  
  
5:  
Name= Ruckus AD  
Type= Active Directory  
IP Address= 192.168.11.17  
Port= 389  
Windows Domain Name= domain.ruckuswireless.com  
Global Catalog= Disabled  
Admin DN=domain  
Admin Password=password  
  
ruckus#
```

show aaa name

To display information about a specific AAA server that has been added to the controller, use the following command:

```
show aaa name <WORD>
```

Syntax Description

show	Display information
aaa name	Display information about the specified AAA server name
<WORD>	Name of the AAA server

Viewing Current Configuration

Show DHCP Commands

Defaults None.

Example

```
ruckus# show aaa name "Ruckus RADIUS"
AAA:
ID:
4:
Name= Ruckus RADIUS
Type= RADIUS server
Auth Method=
Primary RADIUS:
IP Address= 192.168.11.99
Port= 1812
Secret= secret
Secondary RADIUS:
Status= Disabled

ruckus#
```

Show DHCP Commands

Use the `show dhcp` commands to display the current settings for any DHCP servers configured for DHCP relay agent use.

show dhcp all

To display a list of all AAA servers that have been added to the controller, use the following command:

```
show dhcp all
```

Syntax Description

show	Display information
dhcp	Display information about the specified DHCP server name
all	Display a list of all DHCP servers

Defaults None.

Example

```
ruckus# show dhcp all
DHCP servers for DHCP relay agent:
ID:
1:
```

```
Name= DHCP Server 1
Description=
IP Address= 192.168.11.1
IP Address=
```

```
ruckus#
```

show dhcp name

To display a list of all AAA servers that have been added to the controller, use the following command:

```
show dhcp name <WORD>
```

Syntax Description

show	Display information
dhcp	Display information about the specified DHCP server name
name	Display the DHCP server specified
<WORD>	Name of the DHCP server

Defaults

None.

Example

```
ruckus# show dhcp name "DHCP Server 1"
DHCP servers for DHCP relay agent:
ID:
 1:
  Name= DHCP Server 1
  Description=
  IP Address= 192.168.11.1
  IP Address=
```



```
ruckus#
```

Show Access Point Commands

Use the `show ap` commands to display the current settings of managed devices, including their network address settings, device names, radio settings, and others.

Viewing Current Configuration

Show Access Point Commands

show ap all

To display a summary of all devices that have been approved, use the following command:

```
show ap all
```

Syntax Description

show	Display information
ap	Show device information
all	All devices that have been approved by the controller

Defaults

None.

Example

```
ruckus# show ap all
AP:
ID:
1:
MAC Address= 04:4f:aa:0c:b1:00
Model= zf7962
Approved= Yes
Device Name= 7962 - MAP
Description= 7962 MAP (Living Room)
Location= Living Room
GPS=
Group Name= System Default
Radio a/n:
Channelization= Auto
Channel= Auto
WLAN Services enabled= Yes
5.8GHz Channels = Disabled
Tx. Power= Auto
WLAN Group Name= Default
Radio b/g/n:
Channelization= Auto
Channel= Auto
WLAN Services enabled= Yes
5.8GHz Channels = Disabled
Tx. Power= Auto
WLAN Group Name= Default
Override global ap-model port configuration= No
Network Setting:
Protocol mode= IPv4 and IPv6
```

```
Device IP Settings= Keep AP's Setting
IP Type= DHCP
IP Address= 192.168.11.6
Netmask= 255.255.255.0
Gateway= 192.168.11.1
Primary DNS Server=
Secondary DNS Server=

Device IPv6 Settings= Keep AP's Setting
IPv6 Type= Auto Configuration
IPv6 Address= fc00::1
IPv6 Prefix Length= 7
IPv6 Gateway=
IPv6 Primary DNS Server=
IPv6 Secondary DNS Server=
Mesh:
Status= Enabled
Mode= Auto
Uplink:
Status= Smart

2:
MAC Address= 00:24:82:3f:14:60
Model= zf7363
Approved= Yes
Device Name= 7363 - RAP
Description= 7363 - RAP (Study)
Location= Study
GPS=
Group Name= System Default
Radio a/n:
Channelization= Auto
Channel= Auto
WLAN Services enabled= Yes
5.8GHz Channels = Disabled
Tx. Power= Auto
WLAN Group Name= Default
Radio b/g/n:
Channelization= Auto
Channel= Auto
WLAN Services enabled= Yes
5.8GHz Channels = Disabled
```

Viewing Current Configuration

Show Access Point Commands

```
Tx. Power= Auto
WLAN Group Name= Default
Override global ap-model port configuration= No
Network Setting:
Protocol mode= IPv4 and IPv6
Device IP Settings= Keep AP's Setting
IP Type= DHCP
IP Address= 192.168.11.3
Netmask= 255.255.255.0
Gateway= 192.168.11.1
Primary DNS Server= 192.168.11.1
Secondary DNS Server=

Device IPv6 Settings= Keep AP's Setting
IPv6 Type= Auto Configuration
IPv6 Address=
IPv6 Prefix Length= 7
IPv6 Gateway=
IPv6 Primary DNS Server=
IPv6 Secondary DNS Server=
Mesh:
Status= Enabled
Mode= Auto
Uplink:
Status= Smart
```

ruckus#

show ap devname

To display information about a specific device using its device name, use the following command:

```
show ap devname <WORD>
```

Syntax Description

show	Display information
ap devname	Show information about the specified device name
<WORD>	The name of the device

Defaults

None.

Example

```
ruckus# show ap devname "7962 - MAP"
AP:
ID:
1:
MAC Address= 04:4f:aa:0c:b1:00
Model= zf7962
Approved= Yes
Device Name= 7962 - MAP
Description= 7962 MAP (Living Room)
Location= Living Room
GPS=
Group Name= System Default
Radio a/n:
Channelization= Auto
Channel= Auto
WLAN Services enabled= Yes
5.8GHz Channels = Disabled
Tx. Power= Auto
WLAN Group Name= Default
Radio b/g/n:
Channelization= Auto
Channel= Auto
WLAN Services enabled= Yes
5.8GHz Channels = Disabled
Tx. Power= Auto
WLAN Group Name= Default
Override global ap-model port configuration= No
Network Setting:
Protocol mode= IPv4 and IPv6
Device IP Settings= Keep AP's Setting
IP Type= DHCP
IP Address= 192.168.11.6
Netmask= 255.255.255.0
Gateway= 192.168.11.1
Primary DNS Server=
Secondary DNS Server=

Device IPv6 Settings= Keep AP's Setting
IPv6 Type= Auto Configuration
IPv6 Address= fc00::1
IPv6 Prefix Length= 7
IPv6 Gateway=
```

Viewing Current Configuration

Show Access Point Commands

```
IPv6 Primary DNS Server=
IPv6 Secondary DNS Server=
Mesh:
Status= Enabled
Mode= Auto
Uplink:
Status= Smart

ruckus#
```

show ap mac

To search for the device that matches the specified MAC address, use the following command:

```
show ap mac <MAC>
```

Syntax Description

show	Display information
ap mac	Display information about the device with the specified MAC address
<MAC>	The MAC address of the device

Defaults

None.

Example

```
ruckus# show ap mac 04:4f:aa:0c:b1:00
AP:
ID:
1:
MAC Address= 04:4f:aa:0c:b1:00
Model= zf7962
Approved= Yes
Device Name= 7962 - MAP
Description= 7962 MAP (Living Room)
Location= Living Room
GPS=
Group Name= System Default
Radio a/n:
Channelization= Auto
Channel= Auto
WLAN Services enabled= Yes
5.8GHz Channels = Disabled
```

```
Tx. Power= Auto
WLAN Group Name= Default
Radio b/g/n:
Channelization= Auto
Channel= Auto
WLAN Services enabled= Yes
5.8GHz Channels = Disabled
Tx. Power= Auto
WLAN Group Name= Default
Override global ap-model port configuration= No
Network Setting:
Protocol mode= IPv4 and IPv6
Device IP Settings= Keep AP's Setting
IP Type= DHCP
IP Address= 192.168.11.6
Netmask= 255.255.255.0
Gateway= 192.168.11.1
Primary DNS Server=
Secondary DNS Server=

Device IPv6 Settings= Keep AP's Setting
IPv6 Type= Auto Configuration
IPv6 Address= fc00::1
IPv6 Prefix Length= 7
IPv6 Gateway=
IPv6 Primary DNS Server=
IPv6 Secondary DNS Server=
Mesh:
Status= Enabled
Mode= Auto
Uplink:
Status= Smart

ruckus#
```

Show AP Group Commands

Use the show ap-group commands to display Access Point Group settings.

Viewing Current Configuration

Show AP Group Commands

show ap-group all

To display all AP groups and their settings (including the default AP group), use the following command:

```
show ap-group all
```

Syntax Description

show	Display information
ap-group	Display access point group information
all	All AP groups

Defaults

None.

Example

```
ruckus# show ap-group all
APGROUP:
  ID:
  1:
    Name= System Default
    Description= System default group for Access Points
    Radio 11bgn:
      Channelization= Auto
      Channel= Auto
      Enable auto channel selection which select from 1,6,11= Yes
      Tx. Power= Auto
      11N only Mode= Auto
      WLAN Group= Default
    Radio 11an:
      Channelization= Auto
      Channel= Auto
      Tx. Power= Auto
      11N only Mode= Auto
      WLAN Group= Default
    Members:
      MAC= 04:4f:aa:0c:b1:00
      MAC= 00:24:82:3f:14:60
      MAC= 74:91:1a:2b:ff:a0
```

```
APGROUP:  
ID:  
2:  
Name= ap group 2  
Description=  
Radio 11bgn:  
Channelization= Auto  
Channel= Auto  
Enable auto channel selection which select from 1,6,11= Yes  
Tx. Power= Auto  
11N only Mode= Auto  
WLAN Group= Default  
Radio 11an:  
Channelization= Auto  
Channel= Auto  
Tx. Power= Auto  
11N only Mode= Auto  
WLAN Group= Default  
Members:
```

```
APGROUP:  
ID:  
3:  
Name= ap group 1  
Description=  
Radio 11bgn:  
Channelization= Auto  
Channel= Auto  
Enable auto channel selection which select from 1,6,11= Yes  
Tx. Power= Auto  
11N only Mode= Auto  
WLAN Group= Default  
Radio 11an:  
Channelization= Auto  
Channel= Auto
```

Viewing Current Configuration

Show AP Group Commands

```
    Tx. Power= Auto
    11N only Mode= Auto
    WLAN Group= Default
    Members:
```

```
ruckus#
```

show ap-group name

To display details about a specific AP group, use the following command:

```
show ap-group name <WORD>
```

Syntax Description

show	Display information
ap-group name	Display information about the AP group with the specified name
<WORD>	The name of the AP group

Defaults

None.

Example

```
ruckus# show ap-group name "System Default"
APGROUP:
  ID:
  1:
  Name= System Default
  Description= System default group for Access Points
  Radio 11bgn:
    Channelization= Auto
    Channel= Auto
    Enable auto channel selection which select from 1,6,11= Yes
  Tx. Power= Auto
  11N only Mode= Auto
  WLAN Group= Default
  Radio 11an:
    Channelization= Auto
    Channel= Auto
  Tx. Power= Auto
  11N only Mode= Auto
  WLAN Group= Default
  Members:
```

```
MAC= 04:4f:aa:0c:b1:00
MAC= 00:24:82:3f:14:60
MAC= 74:91:1a:2b:ff:a0
```

```
ruckus#
```

Show AP Policy Commands

Use the `show ap-policy` command to display global access point policies that have been configured on the controller.

show ap-policy

```
show ap-policy
```

Example

```
ruckus# show ap-policy
Automatically approve all join requests from APs= Enabled
Limited ZD Discovery:
Status= Disabled
Management VLAN:
Status= Keep AP's setting
Balances the number of clients across adjacent APs= Disabled
Max. clients for 11BG radio= 100
Max. clients for 11N radio= 100
LWAPP message MTU= 1450
ruckus#
```

Show System Configuration Commands

Use the `show config` commands to display the controller's system configuration settings.

show config

To display the current system configuration settings, including network addressing, management VLAN, country code, logging, AAA servers, WLAN services, WLAN groups, AP list, SNMP, and ACLs, etc., use the following command:

```
show config
```

Viewing Current Configuration

Show System Configuration Commands

Syntax Description

show	Display information
config	Display system configuration settings

Defaults

None.

Example

```
ruckus# show config
Protocol Mode= IPv4-Only
Device IP Address:
Mode= Manual
IP Address= 192.168.11.100
Netmask= 255.255.255.0
Gateway Address= 192.168.11.1
Primary DNS= 192.168.11.1
Secondary DNS= 168.115.1.1

Management VLAN:
Status= Disabled
VLAN ID= 1

Country Code:
Code= United States

Identity:
Name= ruckus

NTP:
Status= Enabled
Address= ntp.ruckuswireless.com

Log:
Status= Disabled
Address=

Tunnel MTU:
Tunnel MTU= 1500

Telnet Server:
Status= Disabled

FTP Server:
Status= Enabled
```

```
Anonymous Status= Enabled

FlexMaster:
Status= Disabled
Address= flexmaster
Interval= 15

AAA:
ID:
1:
Name= Local Database
Type= Local
...
...
ruckus#
```

Show Performance Commands

Use the show performance commands to display performance details on an AP radio or client station.

show performance

Use the following command to display performance details:

```
show performance
```

show performance ap-radio2-4

Use the following command to display performance details for the AP's 2.4 GHz radio.

```
show performance ap-radio2-4 mac <MAC>
```

Syntax Description

show performance	Display performance information
ap-radio2-4	Display AP 2.4 GHz radio performance
mac <MAC>	The MAC address of the AP

Defaults

None.

Example

```
ruckus# show performance ap-radio2-4 mac c4:10:8a:1f:d1:f0
AP performance:
1:
Radio b/g/n:
```

Viewing Current Configuration

Show Performance Commands

```
MAC Address= c4:10:8a:1f:d1:f0
Estimated Capacity= 9930
Downlink= 67
Uplink= 0
RF pollution= 11
Associated clients= 1
Other APs= 0
ruckus#
```

show performance ap-radio5

Use the following command to display performance details for the AP's 5 GHz radio:
show performance ap-radio5 mac <MAC>

Syntax Description

show performance	Display performance information
ap-radio5	Display AP 5 GHz radio performance
mac <MAC>	The MAC address of the AP

Defaults

None.

Example

```
ruckus# show performance ap-radio5 mac c4:10:8a:1f:d1:f0
AP performance:
1:
    Radio a/n:
    MAC Address= c4:10:8a:1f:d1:f0
    Estimated Capacity= 20891
    Downlink= 77
    Uplink= 2
    RF pollution= 3
    Associated clients= 1
    Other APs= 0
ruckus#
```

show performance station

Use the following command to display performance details for a connected client/station:

```
show performance station mac <MAC>
```

Syntax Description

show performance	Display performance information
station	Display station performance
mac <MAC>	The MAC address of the station

Defaults

None.

Example

```
ruckus# show performance station mac 00:22:fb:ad:1b:2e
Station performance:
    MAC Address= 00:22:fb:ad:1b:2e
    Estimated Capacity= 61401
    Downlink= 76
    Uplink= 18
ruckus#
```

Show System Information Commands

Use the `show sysinfo` commands to display the controller's system information.

show sysinfo

To display an overview of the system status, including system, devices, usage summary, user activities, system activities, used access points, and support information, use the following command:

```
show sysinfo
```

Syntax Description

show	Display information
sysinfo	Display an overview of various system statuses

Defaults

None.

Example

```
ruckus# show sysinfo
System Overview:
Name= ruckus
IP Address= 192.168.11.100
MAC Address= 00:13:11:01:01:01
Uptime= 11d 22h 37m
Model= ZD1112
Licensed APs= 12
Serial Number= 000000000011
```

Viewing Current Configuration

Show Ethernet Info Commands

```
Version= 9.3.0.0 build 80

Devices Overview:
Number of APs= 2
Number of Client Devices= 1
Number of Rogue Devices= 0

Usage Summary:
Usage of 1 hr:
Max. Concurrent Users= 1
Bytes Transmitted= 407.13K
Number of Rogue Devices= 0
Usage of 24 hr:
Max. Concurrent Users= 2
Bytes Transmitted= 678.94M
Number of Rogue Devices= 2

Memory Utilization:
Used Bytes= 69971968
Used Percentage= 54%
Free Bytes= 59187200
Free Percentage= 46%

ruckus#
```

Show Ethernet Info Commands

Use the show ethinfo command to display current system Ethernet status.

show ethinfo

show ethinfo

Syntax Description

show	Display information
ethinfo	Display the current system Ethernet status

Defaults

None.

Example

```
ruckus# show ethinfo
System Ethernet Overview:
```

```
Port  0:  
  Interface= eth0  
  MAC Address= 00:13:11:01:01:01  
  Physical Link= up  
  Speed= 1000Mbps  
Port  1:  
  Interface= eth1  
  MAC Address= 00:13:11:01:01:02  
  Physical Link= up  
  Speed= 100Mbps  
  
ruckus#
```

Show Technical Support Commands

Use the following commands to display information that Ruckus Wireless may need when providing technical support.

show techsupport

To display system information required by Technical Support, use the following command:

```
show techsupport
```

Syntax Description

show	Display information
techsupport	Display information about the controller that may be required by Ruckus Wireless Technical Support

Defaults

None.

Example

```
ruckus# show techsupport  
System Overview:  
Name= ruckus  
IP Address= 192.168.11.100  
MAC Address= 00:13:11:01:01:01  
Uptime= 11d 22h 46m  
Model= ZD1112  
Licensed APs= 12  
Serial Number= 000000000011  
Version= 9.3.0.0 build 80
```

Viewing Current Configuration

Show Technical Support Commands

Devices Overview:

Number of APs= 2

Number of Client Devices= 1

Number of Rogue Devices= 0

Usage Summary:

Usage of 1 hr:

Max. Concurrent Users= 1

Bytes Transmitted= 697.85K

Number of Rogue Devices= 0

Usage of 24 hr:

Max. Concurrent Users= 2

Bytes Transmitted= 679.21M

Number of Rogue Devices= 2

Memory Utilization:

Used Bytes= 70119424

Used Percentage= 54%

Free Bytes= 59039744

Free Percentage= 46%

Protocol Mode= IPv4-Only

Device IP Address:

Mode= Manual

IP Address= 192.168.11.100

Netmask= 255.255.255.0

Gateway Address= 192.168.11.1

Primary DNS= 192.168.11.1

Secondary DNS= 168.95.1.1

Management VLAN:

Status= Disabled

VLAN ID=

Country Code:

Code= United States

Identity:

Name= ruckus

NTP:

```
Status= Enabled
Address= ntp.ruckuswireless.com

Log:
Status= Disabled
Address=

Tunnel MTU:
Tunnel MTU= 1500

Telnet Server:
Status= Disabled

FTP Anonymous Access:
Status= Enabled

FlexMaster:
Status= Disabled
Address= flexmaster
Interval= 15

AAA:
ID:
1:
Name= Local Database
Type= Local

...
...
ruckus#
```

Show Management ACL Commands

Use the `mgmt-acl` and `mgmt-acl-ipv6` commands to display information about the management access control lists configured on the controller.

show mgmt-acl all

To display all management ACLs that have been configured on the controller, use the following command:

```
show mgmt-acl all
```

Viewing Current Configuration

Show Management ACL Commands

show mgmt-acl name

To display information about a specific management ACL, use the following command:

```
show mgmt-acl name <NAME>
```

show mgmt-acl-ipv6 all

To display all management ACLs that have been configured on the controller, use the following command:

```
show mgmt-acl-ipv6 all
```

show mgmt-acl-ipv6 name

To display information about a specific management ACL, use the following command:

```
show mgmt-acl-ipv6 name <NAME>
```

Syntax Description

show	Display information
mgmt-acl	Display management ACL settings
mgmt-acl-ipv6	Display IPv6 management ACL settings
all	All configured management ACLs
name	Display information about a specific management ACL
<NAME>	The name of the management ACL

Defaults

None.

Example

```
ruckus# show mgmt-acl all
Management ACL:
Name= New Name
Restriction Type= range
IP range= 192.168.11.1-192.168.11.253

Name= Remote 1
Restriction Type= single
IP address= 172.17.17.150

Name= Remote admin 2
Restriction Type= single
IP address= 172.17.16.12
```

```
ruckus#
```

Show Static Route Commands

Use the `static-route` commands to display information about static routes configured on the controller.

show static-route all

To display all static route information, use the following command:

```
show static-route all
```

show static-route name

```
show static-route name <NAME>
```

show static-route-ipv6 all

```
show static-route-ipv6 all
```

show static-route-ipv6 name

```
show static-route-ipv6 name <NAME>
```

Syntax Description

<code>show</code>	Display information
<code>static-route</code>	Display static route settings
<code>static-route-ipv6</code>	Display IPv6 static route settings
<code>all</code>	All configured static routes
<code>name</code>	Display information about a specific configured static route
<code><NAME></code>	The name of the static route entry

Defaults

None.

Example

```
ruckus# show static-route all
Static Route:
ID= 1
Name= Static Route 1
IP subnet= 192.168.11.1/24
IP gateway= 192.168.11.1
```

Viewing Current Configuration

Show WLAN Commands

```
ruckus#
```

Show WLAN Commands

Use the following commands to display information about available WLANs on the controller.

show wlan all

To display all available WLAN services (SSIDs), use the following command:

```
show wlan all
```

Syntax Description

show	Display information
wlan	Display WLAN services (SSIDs) settings
all	All available WLANs/SSIDs

Defaults

None.

Example

```
ruckus# show wlan all
WLAN Service:
ID:
1:
NAME = Ruckus1
Tx. Rate of Management Frame(2.4GHz) = 2.0Mbps
Beacon Interval = 100ms
SSID = Ruckus1
Description = Ruckus WPA WLAN
Type = Standard Usage
Authentication = open
Encryption = wpa2
Algorithm = aes
Passphrase = testing123
Web Authentication = Disabled
Authentication Server = Disabled
Tunnel Mode = Disabled
Background Scanning = Enabled
Max. Clients = 100
Client Isolation = None
Zero-IT Activation = Enabled
```

```
Priority = High
Load Balancing = Enabled
Dynamic PSK = Enabled
Rate Limiting Uplink = Disabled
Rate Limiting Downlink = Disabled
Auto-Proxy configuration:
Status = Disabled
Inactivity Timeout:
Status = Enabled
Timeout = 500 Minutes
VLAN = Disabled
Dynamic VLAN = Disabled
Closed System = Disabled
ofdm-only State = Disabled
DHCP Option82 State= Disabled
BSS Minrate = Disabled
PMK Cache Time = 720 Minutes
NAS-ID Type = wlan-bssid
PAP Message Authenticator = Enabled
Send EAP-Failure = Disabled
L2/MAC = No ACLS
L3/L4/IP Address = No ACLS
L3/L4/IPv6 Address = No ACLS
```

ruckus#

show wlan name

To display information about the specified WLAN service (SSID), use the following command:

```
show wlan name <NAME>
```

Syntax Description

show	Display information
wlan name	Display information about the specified WLAN name
<NAME>	The name of the WLAN

Defaults

None.

Example

ruckus# **show wlan name Ruckus1**

Viewing Current Configuration

Show WLAN Commands

```
WLAN Service:  
ID:  
1:  
NAME = Ruckus1  
Tx. Rate of Management Frame(2.4GHz) = 2.0Mbps  
Beacon Interval = 100ms  
SSID = Ruckus1  
Description = Ruckus WPA WLAN  
Type = Standard Usage  
Authentication = open  
Encryption = wpa2  
Algorithm = aes  
Passphrase = testing123  
Web Authentication = Disabled  
Authentication Server = Disabled  
Tunnel Mode = Disabled  
Background Scanning = Enabled  
Max. Clients = 100  
Client Isolation = None  
Zero-IT Activation = Enabled  
Priority = High  
Load Balancing = Enabled  
Dynamic PSK = Enabled  
Rate Limiting Uplink = Disabled  
Rate Limiting Downlink = Disabled  
Auto-Proxy configuration:  
Status = Disabled  
Inactivity Timeout:  
Status = Enabled  
Timeout = 500 Minutes  
VLAN = Disabled  
Dynamic VLAN = Disabled  
Closed System = Disabled  
ofdm-only State = Disabled  
DHCP Option82 State= Disabled  
BSS Minrate = Disabled  
PMK Cache Time = 720 Minutes  
NAS-ID Type = wlan-bssid  
PAP Message Authenticator = Enabled  
Send EAP-Failure = Disabled  
L2/MAC = No ACLS  
L3/L4/IP Address = No ACLS
```

L3/L4/IPv6 Address = No ACLS

ruckus#

show wlan name stations

To display a list of wireless stations associated with the specified WLAN service, use the following command:

```
show wlan name <NAME> stations
```

Syntax Description

show	Display information
wlan name	Display information about the specified WLAN name
<NAME>	The name of the WLAN
stations	Display stations associated with the WLAN

Defaults

None.

Example

```
ruckus# show wlan name Ruckus1 stations
Clients List:
Client:
MAC Address= 6c:62:6d:1b:e3:00
User Name=
IP Address= 192.168.11.11
IPv6 Address=
Access Point= 04:4f:aa:0c:b1:00
WLAN= Ruckus1
Channel= 6
Signal (dB)= 51

Client:
MAC Address= 00:22:fb:ad:1b:2e
User Name=
IP Address= 192.168.11.7
IPv6 Address=
Access Point= 04:4f:aa:0c:b1:00
WLAN= Ruckus1
Channel= 153
Signal (dB)= 0

ruckus#
```

Viewing Current Configuration

Show WLAN Group Commands

Show WLAN Group Commands

Use the following commands to display information about the WLAN groups that exist on the controller.

show wlan-group all

To display a list of existing WLAN groups, use the following command:

```
show wlan-group all
```

Syntax Description

show	Display information
wlan-group	Display information about the specified WLAN group
all	Show all WLAN groups

Defaults

None.

Example

```
ruckus# show wlan-group all
WLAN Group:
ID:
1:
Name= Default
Description= Default WLANs for Access Points
WLAN Service:
WLAN1:
NAME= Ruckus1
VLAN=
WLAN2:
NAME= Ruckus2
VLAN=

2:
Name= Guest WLAN Group
Description= 1st floor APs only
WLAN Service:
WLAN1:
NAME= Ruckus-Guest
VLAN=
```

```
ruckus#
```

show wlan-group name

To display information about the specified WLAN group name, use the following command:

```
show wlan-group name <WORD>
```

Syntax Description

show	Display information
wlan-group name	Display information about the specified WLAN group name
<WORD>	The name of the WLAN group

Defaults

None.

Example

```
ruckus# show wlan-group name Default
WLAN Group:
ID:
1:
Name= Default
Description= Default WLANS for Access Points
WLAN Service:
WLAN1:
NAME= Ruckus1
VLAN=
WLAN2:
NAME= Ruckus2
VLAN=


ruckus#
```

Show L2 Access Control List Commands

Use the `show l2acl` commands to display Layer 2 access control list rules that have been added to the controller.

show l2acl all

To display all Layer 2 access control list (ACL) rules that have been added to the controller and their settings, use the following command:

Viewing Current Configuration

Show L2 Access Control List Commands

```
show l2acl all
```

Syntax Description

show	Display information
l2acl	Display L2 ACL information
all	All L2 ACL

Defaults

None.

Example

```
ruckus# show l2acl all
L2/MAC ACL:
ID:
1:
Name= System
Description= System
Restriction: Deny only the stations listed below
Stations:
2:
Name= blocked-sta-list
Description=
Restriction: Deny only the stations listed below
Stations:
```

show l2acl name

To display the settings of a specific L2 ACL rule that has been added to the controller, use the following command:

```
show l2acl name <WORD>
```

Syntax Description

show	Display information
l2acl	Display L2 ACL information
name	Display information about the specified L2 ACL rule name
<WORD>	Name of the L2 ACL rule

Defaults

None.

Example

```
ruckus# show l2acl name 1
L2/MAC ACL:
ID:
```

```
2:  
Name= 1  
Description=  
Restriction: Deny only the stations listed below  
Stations:  
MAC Address= 00:33:22:45:34:88
```

Show L3 Access Control List Commands

Use the `show l3acl` commands to display Layer 3 access control list rules that have been added to the controller.

show l3acl all

To display all Layer 3 access control list (ACL) rules that have been added to the controller and their settings, use the following command:

```
show l3acl all
```

show l3acl-ipv6 all

To display all IPv6 Layer 3 access control list (ACL) rules that have been added to the controller and their settings, use the following command:

```
show l3acl-ipv6 all
```

Syntax Description

<code>show</code>	Display information
<code>l3acl</code>	Display L3 ACL information
<code>l3acl-ipv6</code>	Display IPv6 L3 ACL information
<code>all</code>	All L3 ACL

Defaults

None.

Example

```
ruckus# show l3acl all  
L3/L4/IP ACL:  
ID:  
4:  
Name= test2  
Description= test2  
Default Action if no rule is matched= Deny all by default  
Rules:  
Order= 1  
Description=
```

Viewing Current Configuration

Show L3 Access Control List Commands

```
Type= Allow
Destination Address= Any
Destination Port= 53
Protocol= Any
Order= 2
Description=
Type= Allow
Destination Address= Any
Destination Port= 67
Protocol= Any
Order= 3
Description=
Type= Allow
Destination Address= 8.8.8.8/24
Destination Port= 25
Protocol= 6
```

show l3acl name

To display the settings of a specific L3 ACL rule that has been added to the controller, use the following command:

```
show l3acl name <WORD>
```

show l3acl-ipv6 name

To display the settings of a specific IPv6 L3 ACL rule that has been added to the controller, use the following command:

```
show l3acl-ipv6 name <WORD>
```

Syntax Description

show	Display information
l3acl	Display L3 ACL information
l3acl-ipv6	Display IPv6 L3 ACL information
name	Display information about the specified L3 ACL rule
<WORD>	Name of the L3 ACL rule

Defaults

None.

Example

```
ruckus# show l3acl name test2
```

L3/L4/IP ACL:

ID:

```
4:  
Name= test2  
Description= test2  
Default Action if no rule is matched= Allow all by default  
Rules:  
Order= 1  
Description=  
Type= Allow  
Destination Address= Any  
Destination Port= 53  
Protocol= Any  
Order= 2  
Description=  
Type= Allow  
Destination Address= Any  
Destination Port= 67  
Protocol= Any  
Order= 3  
Description=  
Type= Allow  
Destination Address= 8.8.8.8/24  
Destination Port= 25  
Protocol= 6
```

Show Hotspot Commands

Use the `show hotspot` commands to display the controller's hotspot configuration settings.

show hotspot all

To display a list of all hotspot services that have been created on the controller, use the following command:

```
show hotspot all
```

Syntax Description

show	Display information
hotspot	Display hotspot information
all	All available hotspots

Defaults

None.

Viewing Current Configuration

Show Hotspot Commands

Example

```
ruckus# show hotspot all
Hotspot:
ID:
1:
Name= New Name
Login Page Url= myhotspot.com
Start Page= redirect to the URL that the user intends to visit.
Session Timeout= Disabled
Idle Timeout= Disabled
Authentication Server= Local Database
Accounting Server= Disabled
Location ID=
Location Name=
Walled Garden 1=
Walled Garden 2=
Walled Garden 3=
Walled Garden 4=
Walled Garden 5=
IPv4 Rules:

IPv6 Rules:

ID:
2:
Name= New name2
Login Page Url= myhotspot.com
Start Page= redirect to the URL that the user intends to visit.
Session Timeout= Disabled
Idle Timeout= Disabled
Authentication Server= Local Database
Accounting Server= Disabled
Location ID=
Location Name=
Walled Garden 1=
Walled Garden 2=
Walled Garden 3=
Walled Garden 4=
Walled Garden 5=
IPv4 Rules:
Order= 1
Description= 10.9.5.55
Type= Deny
```

Destination Address= Any
Destination Port= Any
Protocol= Any

IPv6 Rules:

show hotspot name

To display information about the specific hotspot service, use the following command:

```
show hotspot name <WORD>
```

If the hotspot name includes a space, you must put the name in quotation marks (for example, "hotspot name").

Syntax Description

show	Display information
hotspot name	Display hotspot information
<WORD>	The name of the hotspot

Defaults

None.

Example

```
ruckus# show hotspot name "New name2"
Hotspot:
ID:
2:
Name= New name2
Login Page Url= myhotspot.com
Start Page= redirect to the URL that the user intends to visit.
Session Timeout= Disabled
Idle Timeout= Disabled
Authentication Server= Local Database
Accounting Server= Disabled
Location ID=
Location Name=
Walled Garden 1=
Walled Garden 2=
Walled Garden 3=
Walled Garden 4=
Walled Garden 5=
IPv4 Rules:
Order= 1
Description= 10.9.5.55
Type= Deny
```

Viewing Current Configuration

Show Hotspot Commands

```
Destination Address= Any
Destination Port= Any
Protocol= Any
```

IPv6 Rules:

show hs20op all

To display information about all Hotspot 2.0 Operators, use the following command:

```
show hs20op all
```

Syntax Description

show	Display information
hs20op	Display Hotspot 2.0 Operator
all	Display all HS2.0 operators

Defaults

None.

Example

```
ruckus# show hs20op all
Hotspot 2.0 Operator:
ID:
1:
NAME= operator1
Description=
Venue Group= Unspecified
Venue Type= Unspecified
ASRA Option:
Status= Disabled
Internet Option= Disabled
Access Network Type= Private
IPv4 Address Type= Not Available
IPv6 Address Type= Not Available
HESSID=
Friendly Name List:
Service Provider Profiles:
ID= 1
Name= provider1
WAN Metrics:
Enable Symmetric Link= Disabled
WAN at Capability= Disabled
Link Status= Link Up
WAN Downlink Load= 0
```

```
WAN Downlink Speed= 0
WAN Uplink Load= 0
WAN Uplink Speed= 0
Load Measurement Duration= 0
Connection Capability:
  Description= ICMP
    IP Protocol= 1
    Port Number= 0
    Status= Closed
  Description= FTP
    IP Protocol= 6
    Port Number= 20
    Status= Closed
  Description= SSH
    IP Protocol= 6
    Port Number= 22
    Status= Closed
  Description= HTTP
    IP Protocol= 6
    Port Number= 80
    Status= Closed
  Description= Used by TLS VPNs
    IP Protocol= 6
    Port Number= 443
    Status= Closed
  Description= Used by PPTP VPNs
    IP Protocol= 6
    Port Number= 1723
    Status= Closed
  Description= VoIP
    IP Protocol= 6
    Port Number= 5060
    Status= Closed
  Description= Used by IKEv2 (IPSec VPN)
    IP Protocol= 17
    Port Number= 500
    Status= Closed
  Description= VoIP
    IP Protocol= 17
    Port Number= 5060
    Status= Closed
  Description= May be used by IKEv2 (IPSec VPN)
```

Viewing Current Configuration

Show Hotspot Commands

```
IP Protocol= 17
Port Number= 4500
Status= Closed
Description= ESP, used by IPSec VPNs
IP Protocol= 50
Port Number= 0
Status= Closed
Additional Connection Capability:
Advanced GAS Settings:
GAS query response buffering time= 1000
GAS DOS detection= Disabled
GAS DOS maximum request number= 200
Hotspot 2.0 Capability:
Operating Class Indication= Unspecified
```

ruckus#

show hs20op name

To display information about the named Hotspot 2.0 Operator, use the following command:

```
show hs20op name <WORD>
```

Syntax Description

show	Display information
hs20op name	Display specific Hotspot 2.0 Operator
<WORD>	The name of the HS2.0 operator

Defaults

None.

Example

```
ruckus# show hs20op name operator1
Hotspot 2.0 Operator:
ID:
1:
NAME= operator1
Description=
Venue Group= Unspecified
Venue Type= Unspecified
ASRA Option:
Status= Disabled
Internet Option= Disabled
```

```
Access Network Type= Private
IPv4 Address Type= Not Available
IPv6 Address Type= Not Available
HESSID=
Friendly Name List:
Service Provider Profiles:
  ID= 1
    Name= provider1
WAN Metrics:
  Enable Symmetric Link= Disabled
  WAN at Capability= Disabled
  Link Status= Link Up
  WAN Downlink Load= 0
  WAN Downlink Speed= 0
  WAN Uplink Load= 0
  WAN Uplink Speed= 0
  Load Measurement Duration= 0
Connection Capability:
  Description= ICMP
    IP Protocol= 1
    Port Number= 0
    Status= Closed
  Description= FTP
    IP Protocol= 6
    Port Number= 20
    Status= Closed
  Description= SSH
    IP Protocol= 6
    Port Number= 22
    Status= Closed
  Description= HTTP
    IP Protocol= 6
    Port Number= 80
    Status= Closed
  Description= Used by TLS VPNs
    IP Protocol= 6
    Port Number= 443
    Status= Closed
  Description= Used by PPTP VPNs
    IP Protocol= 6
    Port Number= 1723
    Status= Closed
```

Viewing Current Configuration

Show Hotspot Commands

```
        Description= VoIP
        IP Protocol= 6
        Port Number= 5060
        Status= Closed
Description= Used by IKEv2 (IPSec VPN)
        IP Protocol= 17
        Port Number= 500
        Status= Closed
Description= VoIP
        IP Protocol= 17
        Port Number= 5060
        Status= Closed
Description= May be used by IKEv2 (IPSec VPN)
        IP Protocol= 17
        Port Number= 4500
        Status= Closed
Description= ESP, used by IPSec VPNs
        IP Protocol= 50
        Port Number= 0
        Status= Closed
        Additional Connection Capability:
Advanced GAS Settings:
        GAS query response buffering time= 1000
        GAS DOS detection= Disabled
        GAS DOS maximum request number= 200
Hotspot 2.0 Capability:
        Operating Class Indication= Unspecified
```

ruckus#

show hs20sp all

To display information about the Hotspot 2.0 Service Provider, use the following command:

```
show hs20sp all
```

Syntax Description

show	Display information
hs20sp	Display Hotspot 2.0 Service Provider
all	Display all HS2.0 Service Providers

Defaults

None.

Example

```
ruckus# show hs20sp all
Hotspot 2.0 Service Provider:
ID:
1:
NAME= provider1
Description=
Realm List:
Domain Name List:
Roaming Consortium List:
3GPP Cellular Network information:
```

```
ruckus#
```

show hs20sp name

To display information about a specific Hotspot 2.0 Service Provider, use the following command:

```
show hs20sp name <WORD>
```

Syntax Description

show	Display information
hs20sp name	Display specific Hotspot 2.0 Service Provider
<WORD>	The name of the HS2.0 Service Provider

Defaults

None.

Example

```
ruckus# show hs20sp name provider1
Hotspot 2.0 Service Provider:
ID:
1:
NAME= provider1
Description=
Realm List:
Domain Name List:
Roaming Consortium List:
3GPP Cellular Network information:
```

```
ruckus#
```

Viewing Current Configuration

Show Role Commands

Show Role Commands

Use the `show role` commands to display details about roles that have been created on the controller.

show role all

To display a list of all roles that have been created on the controller, use the following command:

```
show role all
```

Syntax Description

show	Display information
role	Display role information
all	All roles that have been created

Defaults

None.

Example

```
ruckus# show role all
Role:
ID:
1:
Name= Default
Description= Allow Access to All WLANs
Group Attributes=
Guest Pass Generation= Allowed
ZoneDirector Administration= Disallowed
Allow All WLANs= Allow access to all WLANs.
```

show role name

To display information about the specific role, use the following command:

```
show role name <WORD>
```

Syntax Description

show	Display information
role name	Display role information
<WORD>	The name of the role

Defaults

None.

Example

```
ruckus# show role name Default
Role:
ID:
1:
Name= Default
Description= Allow Access to All WLANs
Group Attributes=
Guest Pass Generation= Allowed
ZoneDirector Administration= Disallowed
Allow All WLANs= Allow access to all WLANs.
```

Show User Commands

Use the `show user` commands to display details about user accounts that exist on the controller.

show user all

To display a list of all existing user accounts, use the following command:

```
show user all
```

Syntax Description

<code>show</code>	Display information
<code>user</code>	Display user information
<code>all</code>	All existing user accounts

Defaults

None.

Example

```
ruckus# show user all
User:
ID:
1:
User Name= test22
Full Name= test11
Password= test1234
Role= Default
```

show user name

To display information about the specific user, use the following command:

```
show user name <user_name>
```

Viewing Current Configuration

Show Currently Active Clients Commands

Syntax Description	
show	Display information
user name	Display user information
<WORD>	The name of the user

Defaults	
	None.

Example	
	<pre>ruckus# show user name test22 User: ID: 1: User Name= test22 Full Name= test11 Password= test1234 Role= Default</pre>

Show Currently Active Clients Commands

Use the `show current-active-clients` commands to display a list of wireless clients that are associated with the APs that the controller manages.

show current-active-clients all

To display a list of all existing user accounts, use the following command:

```
show current-active-clients all
```

Syntax Description	
show	Display information
current-active-clients	Display currently active wireless clients
all	All active wireless clients

Defaults	
	None.

Example	
	<pre>ruckus# show current-active-clients all Current Active Clients: Clients: Mac Address= 00:22:fb:5c:e2:32 User/IP= 172.18.30.2 User/IPv6= Access Point= 04:4f:aa:13:30:f0</pre>

```
BSSID= 04:4f:aa:13:30:fa
Connect Since=2011/03/01 02:48:22
Auth Method= OPEN
WLAN= 11jojoe
VLAN= None
Channel= 6
Radio= 802.
Signal= 0
Status= Authorized

Last 300 Events/Activities:
Activity:
Date/Time= 2011/03/01 02:49:05
Severity= Low
User=
Activities= User[00:22:fb:5c:e2:32] joins WLAN[11jojoe] from
AP[04:4f:aa:13:30:f0]
Activity:
Date/Time= 2011/03/01 02:48:22
Severity= Low
User=
Activities= User[00:22:fb:5c:e2:32] joins WLAN[11jojoe] from
AP[04:4f:aa:13:30:f0]
...
...
ruckus#
```

show current-active-clients mac

To display information about the specific active client, use the following command:

```
show current-active-clients mac <MAC>
```

Syntax Description

show	Display information
current-active-clients mac	Display currently active wireless clients
<MAC>	The MAC address of the wireless client

Defaults

None.

Example

```
ruckus# show current-active-clients mac 6c:62:6d:1b:e3:00
Current Active Clients:
```

Viewing Current Configuration

Show Currently Active Clients Commands

Clients:

```
Mac Address= 6c:62:6d:1b:e3:00
User/IP= 192.168.11.11
User/IPv6=
Access Point= 04:4f:aa:0c:b1:00
BSSID= 04:4f:aa:0c:b1:08
Connect Since=2012/01/10 06:22:44
Auth Method= OPEN
WLAN= Ruckus1
VLAN= None
Channel= 6
Radio= 802.11gn
Signal= 53
Status= Authorized
Received from client= 20746 pkts / 6274531 bytes
Transmitted to client= 25777 pkts / 6714433 bytes
Tx. drops due to retry failure= 1 pkts
```

Last 300 Events/Activities:

Activitiy:

```
Date/Time= 2012/01/10 06:22:44
```

Severity= Low

User=

```
Activities= User[6c:62:6d:1b:e3:00] joins WLAN[Ruckus1] from
AP[7962 - MAP@04:4f:aa:0c:b1:00]
```

Activitiy:

```
Date/Time= 2012/01/09 18:52:28
```

Severity= Low

User=

```
Activities= User[6c:62:6d:1b:e3:00] disconnects from WLAN[Ruckus1]
at AP[7363 - RAP@00:24:82:3f:14:60]
```

Activitiy:

```
Date/Time= 2012/01/08 06:08:52
```

Severity= Low

User=

```
Activities= AP[7363 - RAP@00:24:82:3f:14:60] radio [11g/n] detects
User[6c:62:6d:1b:e3:00] in WLAN[Ruckus1] roams from AP[7962 -
MAP@04:4f:aa:0c:b1:00]
```

...

...

ruckus#

Show Mesh Commands

Use the `show mesh` commands to display the controller's mesh network configuration and topology.

show mesh info

To display a list of all mesh networks that have been formed, use the following command:

```
show mesh info
```

Syntax Description

show	Display information
mesh	Display mesh network information
info	Show mesh information

Defaults

None.

Example

```
ruckus# show mesh info
Mesh Settings:
Mesh Status= Enabled
Mesh Name(ESSID)= Mesh-000000000311
Mesh Passphrase= GdxW5CUgrn_SEHOPyCSxv_cQHSca MH-OpnRGfX sRvwXBjL-
wUsD6eeK8CMEZfm
Mesh Hop Detection:
Status= Disabled
Mesh Downlinks Detection:
Status= Disabled
Tx. Rate of Management Frame=2Mbps
Beacon Interval= 200ms
ruckus#
```

show mesh topology

To display the topology of existing mesh networks, use the following command:

```
show mesh topology
```

Syntax Description

show	Display information
mesh	Display mesh network information
topology	Show mesh topology

Viewing Current Configuration

Show Dynamic PSK Commands

Defaults None.

Example

```
ruckus# show mesh topology
Mesh Topology(Mesh-000000000311):
Root Access Points= 00:24:82:3b:14:60
Signal (dB) Downlink=/ Uplink=
Description= 7363 - RAP (Study)
Channel= 153 (11an)
IP Address= 192.168.11.3
Mesh Access Points= 04:4f:ab:0c:b1:00
Signal (dB) Downlink= 28 / Uplink= 30
Description= 7962 MAP (Living Room)
Channel= 153
IP Address= 192.168.11.6

ruckus#
```

Show Dynamic PSK Commands

Use the `show dynamic-psks` commands to display information about Dynamic PSKs that have been generated. Use the following command:

```
show dynamic-psks
```

Syntax Description

<code>show</code>	Display information
<code>dynamic-psks</code>	Display dynamic PSKs that have been generated

Defaults None.

Example

```
ruckus# show dynamic-psks
Generated Dynamic PSKs:
DPSK:
User= BatchDPSK_User_1
Mac Address= 00:00:00:00:00:00
Created= 2011/03/01 03:30:01
Expired= Unlimited
DPSK:
User= BatchDPSK_User_2
Mac Address= 00:00:00:00:00:00
Created= 2011/03/01 03:30:02
```

```
Expired= Unlimited
DPSK:
User= DPSK-User-2
Mac Address= 00:11:22:33:44:55
Created= 2011/03/01 03:30:47
Expired= Unlimited
```

Show Dynamic Certificate Commands

Use the `show dynamic-certs` commands to display information about Dynamic certificates that have been generated. Use the following command:

```
show dynamic-certs
```

Syntax Description	<code>show</code> Display information <code>dynamic-certs</code> Display dynamic certificates that have been generated
---------------------------	---

Defaults	None.
-----------------	-------

Example	ruckus# show dynamic-certs Generated Dynamic Certs:
----------------	---

Show Guest Pass Commands

Use the `show guest-passes` commands to display information about guest passes that have been generated. Use the following command:

```
show guest-passes
```

Syntax Description	<code>show</code> Display information <code>guest-passes</code> Display guest passes that have been generated
---------------------------	--

Defaults	None.
-----------------	-------

Example	ruckus# show guest-passes Generated Guest Passes: ID: Guest Name= John Doe Remarks= Expires= 2012/01/11 08:32:15 Re-auth=
----------------	--

Viewing Current Configuration

Show Rogue Device Commands

```
Creator= ruckus
Sharable= No
Wlan= Ruckus-Guest
```

```
ruckus#
```

Show Rogue Device Commands

Use the `show rogue-devices` commands to display information about rogue devices that the controller has detected on the network. Use the following command:

```
show rogue-devices
```

Syntax Description

<code>show</code>	Display information
<code>rogue-devices</code>	Display rogues devices that have been detected on the network

Defaults

None.

Example

```
ruckus# show rogue-devices
Current Active Rogue Devices:
Rogue Devices:
Mac Address= 00:25:c4:52:1c:a1
Channel= 6
Radio= 802.11bg
Type= AP
Encryption= Open
SSID= V54-HOME001
Last Detected= 2011/03/01 02:03:43
```

Known/Recognized Rogue Devices:

Show Events and Activities Commands

Use the `show events-activities` commands to display information events and network activities that have been recorded by the controller. Use the following command:

```
show events-activities
```

Syntax Description

<code>show</code>	Display information
-------------------	---------------------

events-activities Display a list of events and activities records by the controller

Defaults None.

Example

```
ruckus# show events-activities
ruckus# show events-activities
Last 300 Events/Activities:
Activitiy:
Date/Time= 2012/01/10 08:33:17
Severity= Low
User=
Activities= Admin[ruckus] logs in from [192.168.11.7]
Activitiy:
Date/Time= 2012/01/10 08:32:00
Severity= Low
User=
Activities= WLAN[Ruckus-Guest] with BSSID[04:4f:aa:4c:b1:08]
configuration has been updated on radio [11g/n] of AP[7962 - MAP@04:4f:aa:0c:b1:00]
Activitiy:
Date/Time= 2012/01/10 08:32:00
Severity= Low
User=
...
...
```

Show Alarm Commands

Use the `show alarm` commands to display alarms that have been generated by the controller. Use the following command:

```
show alarm
```

Syntax Description

<code>show</code>	Display information
<code>alarm</code>	Display a list of alarms that have been generated by the controller

Defaults None.

Example

```
ruckus# show alarm
```

Viewing Current Configuration

Show License Commands

```
Last 300 Alarms:  
Alarms:  
  Date/Time= 2013/03/27 15:36:59  
  Name= AP Lost Contact  
  Severity= High  
  Activities= Lost contact with AP[7372 - MAP@c0:c5:20:3b:91:f0]  
Alarms:  
  Date/Time= 2013/03/18 14:44:21  
  Name= ZD warm restart  
  Severity= Medium  
  Activities= System warm restarted with [user reboot].  
...  
...  
ruckus#
```

Show License Commands

Use the `show license` commands to display the controller's license information, including the model number, the maximum number of APs that it can support, and the maximum number of wireless clients that managed APs can support. Use the following command:

```
show license
```

Syntax Description

<code>show</code>	Display information
<code>license</code>	Display the controller's license information

Defaults

None.

Example

```
ruckus# show license  
License:  
  Model= ZD1112  
  Max. AP Number= 12  
  Max. Client Number= 1250  
ruckus#
```

Show USB Software Commands

Use the `show usb-software` command to display current USB software package information.

show usb-software

```
show usb-software
```

Syntax Description

show	Display information
usb-software	Display USB software package information

Defaults

None.

Example

```
ruckus# show usb-software  
Sorry, the USB Software hasn't been found.  
ruckus#
```

Show Session-Timeout Commands

Use the `show session-timeout` command to display the current session timeout interval.

show session-timeout

```
show session-timeout
```

Syntax Description

show	Display information
session-timeout	Display the current session timeout interval

Defaults

None.

Example

```
ruckus# show session-timeout  
Current session timeout interval is 30 minutes  
ruckus#
```

Show Active Wired Client Commands

Use the `show active-wired-client` commands to display information about currently active wired clients.

show active-wired-client all

```
show active-wired-client all
```

Viewing Current Configuration

Monitor AP MAC Commands

show active-wired-client mac

```
show active-wired-client mac <MAC>
```

Syntax Description

show	Display information
active-wired-client	Display the currently active wired client information
all	Show all wired clients
mac	Show a specific client information by MAC address
<MAC>	The MAC address of the specific client

Defaults

None.

Example

```
ruckus# show active-wired-client all
```

```
Current Active Wired Clients:
```

```
ruckus#
```

Monitor AP MAC Commands

Use the `monitor ap mac` command to monitor details on a specific access point.

monitor ap mac

```
monitor ap mac <MAC>
```

Syntax Description

monitor	Begin monitoring mode
ap mac	Designate the access point to begin monitoring
<MAC>	The MAC address of the specific access point

Defaults

None.

Example

```
ruckus# monitor ap mac 04:4f:aa:0c:b1:00
```

```
-----  
-----  
ID MAC Approved Device-Name Description  
104:4f:aa:0c:b1:00 Yes7962 - MAP7962 MAP (Living)
```

IPv4-ADDRMASK GATEWAYPRI-DNS
192.168.11.6 255.255.255.0192.168.11.1

Radio-TypeRX-Packets (M) /RX-Bytes (G) TX-Packets (M) /TX-Bytes (G)
Retries (%)

Radio a/n 36.9/2.028.6/2.00.0

Radio-TypeRX-Packets (M) /RX-Bytes (G) TX-Packets (M) /TX-Bytes (G)
Retries (%)

Radio b/g/n 37.8/2.012.4/2.00.3

Status Mode LocationUplink-Status
EnabledAuto Living Room Smart

ID MAC Approved Device-Name Description
104:4f:aa:0c:b1:00 Yes7962 - MAP7962 MAP (Living

IPv4-ADDRMASK GATEWAYPRI-DNS
192.168.11.6 255.255.255.0192.168.11.1

Radio-TypeRX-Packets (M) /RX-Bytes (G) TX-Packets (M) /TX-Bytes (G)
Retries (%)

Radio a/n 36.9/2.028.6/2.00.0

Radio-TypeRX-Packets (M) /RX-Bytes (G) TX-Packets (M) /TX-Bytes (G)
Retries (%)

Radio b/g/n 37.8/2.012.4/2.00.3

Status Mode LocationUplink-Status
EnabledAuto Living Room Smart

ID MAC Approved Device-Name Description
104:4f:aa:0c:b1:00 Yes7962 - MAP7962 MAP (Living

IPv4-ADDRMASK GATEWAYPRI-DNS
192.168.11.6 255.255.255.0192.168.11.1

Viewing Current Configuration

Monitor Currently Active Client Commands

```
-----  
-----  
Radio-TypeRX-Packets (M) /RX-Bytes (G) TX-Packets (M) /TX-Bytes (G)  
Retries (%)
```

```
Radio a/n 36.9/2.028.6/2.00.0
```

```
Radio-TypeRX-Packets (M) /RX-Bytes (G) TX-Packets (M) /TX-Bytes (G)  
Retries (%)
```

```
Radio b/g/n 37.8/2.012.4/2.00.3
```

```
-----  
-----  
Status Mode LocationUplink-Status
```

```
EnabledAuto Living Room Smart
```

```
-----  
-----  
ruckus#
```

Monitor Currently Active Client Commands

Use the `monitor current-active-clients` command to monitor details on a specific client.

monitor current-active-clients

```
monitor current-active-clients mac <MAC>
```

Syntax Description

```
monitor          Begin monitoring mode
```

```
current-active-  Designate the currently active client to begin monitoring  
clients mac
```

```
<MAC>           The MAC address of the specific client
```

Defaults

None.

Example

```
ruckus# monitor current-active-clients mac 00:22:fb:ad:1b:2e
```

```
-----  
-----  
04:4f:aa:0c:b1:00 192.168.11.7 Ruckus1 None Authorized
```

```
04:4f:aa:0c:b1:0c153 11an43 OPEN
```

```
44.3/6.743.2/17.0 36
```

```
ruckus#
```

Monitor Sysinfo Commands

Use the `monitor sysinfo` command to monitor system information.

monitor sysinfo

```
monitor sysinfo
```

Syntax Description

<code>monitor</code>	Begin monitoring mode
----------------------	-----------------------

<code>sysinfo</code>	Display the system information
----------------------	--------------------------------

Example

```
ruckus# monitor sysinfo
```

```
IPv4-ADDR IPv6-ADDR MAC Uptime Model MAX-APs  
192.168.11.100NULL 00:13:11:01:01:01 12d 1h 29mZD111212
```

```
Number-of-APs Number-of-ClientsNumber-of-Rogues Name  
2 10ruckus
```

```
Usage of 1 hr|Usage of 24 hr  
Max-Concurrent-Users TX-BytesRogues | Max-Concurrent-Users TX-  
BytesRogues  
12.33M 02297.58M 2
```

```
Used-Bytes Used-Percentage Free-BytesFree-Percentage  
71675904 55% 57483264 45%
```

Viewing Current Configuration

Monitor Sysinfo Commands

```
-----  
-----  
-----  
IPv4-ADDR IPv6-ADDR MAC Uptime Model MAX-APs  
192.168.11.100NULL 00:13:11:01:01:01 12d 1h 29mZD111212  
-----  
-----
```

Number-of-APs	Number-of-Clients	Number-of-Rogues	Name
2	10ruckus		

```
-----  
-----
```

Usage of 1 hr		Usage of 24 hr
Max-Concurrent-Users	TX-Bytes	Rogues
Bytes	Rogues	Max-Concurrent-Users
12.39M	02297.64M	2

```
-----  
-----
```

Used-Bytes	Used-Percentage	Free-Bytes	Free-Percentage
71675904	55%	57483264	45%

```
-----  
-----  
-----
```

Configuring Controller Settings

In This Chapter

Configuration Commands Overview	71
General Config Commands	71
Configure Context Show Commands	71
Configure AAA Server Commands	73
Configure DHCP Server Commands	86
Configure Admin Commands	88
Configure Access Points	91
Configure AP Policy Commands	115
Configure AP Group Commands	124
Configure Certificate Commands	153
Configure Hotspot Redirect Settings	154
Configure Layer 2 Access Control Commands	156
Configure Layer 3 Access Control Commands	162
Configure Precedence Policy Commands	173
Configure Device Policy Commands	175
Configure Load Balancing Commands	179
Configure STP Commands	183
Configure System Commands	184
Configure UPNP Settings	215
Configure Zero-IT Settings	216
Configure Dynamic PSK Expiration	216
Configure WLAN Settings Commands	217
Configure WLAN Group Settings Commands	261
Configure Role Commands	267
Configure User Commands	274
Configure Guest Access Commands	279
Configure Hotspot Commands	297
Configure Mesh Commands	334
Configure Alarm Commands	339
Configure Services Commands	348

Configuration Commands Overview

This section describes the commands that you can use to configure ZoneDirector via the `config` context. From the privileged commands context, type `config` to enter the configuration context. To show a list of commands available from within the config context, type `help` or `?`.

General Config Commands

The following section describes general configuration commands can be executed from within the config context.

help

Shows available commands.

history

Shows a list of previously run commands.

abort

Exits the config context without saving changes.

end

Saves changes, and then exits the config context.

exit

Saves changes, and then exits the config context.

quit

Exits the debug context without saving changes.

Configure Context Show Commands

Use the following `show` commands to display configured settings within the config context.

show aaa

Displays a list of available AAA servers.

show dhcp

Displays a list of available DHCP servers.

show admin

Displays information about the administrator settings.

show mgmt-acl

Displays a list of all management access controls.

show mgmt-acl-ipv6

Displays a list of IPv6 management access controls.

show static-route

Displays a list of all static route entries.

show static-route-ipv6

Shows the static route for IPv6.

show ap

Displays a list of all approved devices.

show l2acl

Displays a list of L2 Access Control Lists.

show l3acl

Displays a list of L3/L4/IP ACL.

show l3acl-ipv6

Displays a list of L3/L4/IPv6 ACL.

show prece

Displays a list of Precedence Policies.

show dvcpcy

Displays a list of Device Policies.

show load-balancing

Displays information about Load balancing.

show wlan

Displays a list of all WLAN services (Names).

show wlan-group

Displays a list of existing WLAN groups.

show role

Displays a list of roles.

show user

Displays a list of users.

show hotspot

Displays a list of hotspot entries.

show ap-group

Displays all AP groups.

show ap-policy

Displays the ap policy settings.

show usb-software

Displays USB Software Package information.

Configure AAA Server Commands

This section describes the commands that you can use to configure AAA server entries on the controller. The following commands can be executed from within the `config-aaa` context. To show a list of commands available from within the `aaa` context, type `help` or `?`.

aaa

To create or configure an AAA server, use the following command:

```
aaa <WORD>
```

Syntax Description

aaa	Create or edit AAA server entry
<WORD>	The name of the AAA server

Defaults

None.

Example

```
ruckus(config)# aaa ruckus-auth-02
The AAA server 'ruckus-auth-02' has been loaded. To save the AAA
server, type 'end' or 'exit'.
ruckus(config-aaa)# end
The AAA server 'ruckus-auth-02' has been updated and saved.
Your changes have been saved.
ruckus(config)#

```

no aaa

To delete an AAA server from the list of AAA servers, use the following command:

```
no aaa <WORD>
```

Syntax Description

no aaa	Delete AAA server entry
<WORD>	The name of the AAA server

Defaults

None.

Example

```
ruckus(config)# no aaa ruckus-auth-02
The AAA server 'ruckus-auth-02' has been deleted.
ruckus(config)#

```

name

To set the AAA server name, use the following command from within the config-aaa context:

```
name <WORD>
```

Configuring Controller Settings

Configure AAA Server Commands

Syntax Description

name	Set the name of the AAA server
<WORD>	The name of the AAA server

Defaults

None.

Example

```
ruckus(config)# aaa radius2
```

The AAA server 'radius2' has been loaded. To save the AAA server, type 'end' or 'exit'.

```
ruckus(config-aaa)# name active_directory
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-aaa)# show
```

AAA:

ID:

3:

Name= active_directory
Type= Active Directory
IP Address= 192.168.7.4
Port= 389
Windows Domain Name=
Global Catalog= Disabled
Admin DN=
Admin Password=

```
ruckus(config-aaa)# end
```

The AAA server 'active_directory' has been updated and saved.

Your changes have been saved.

```
ruckus(config)#
```

type

To set the AAA server type, use the following command (from within the config-aaa context):

```
type [ad|ldap|radius-auth|radius-acct]
```

Syntax Description

type ad	Set the AAA server type to ActiveDirectory
type ldap	Set the AAA server type to LDAP
type radius-auth	Set the AAA server type to RADIUS
type tacplus-auth	Set the AAA server type to TACACS+

```
type radius-acct Set the AAA server type to RADIUS Accounting
```

Defaults None.

Example

```
ruckus(config)# aaa ruckus-auth-02
The AAA server 'ruckus-auth-02' has been loaded. To save the AAA
server, type 'end' or 'exit'.
ruckus(config-aaa)# type ad
The command was executed successfully. To save the changes, type
'end' or 'exit'.
ruckus(config-aaa)# end
The AAA server 'ruckus-auth-02' has been updated and saved.
Your changes have been saved.
ruckus(config)#
```

auth-method

To set the authentication method to PAP or CHAP, use the following command:

```
auth-method [pap|chap]
```

Syntax Description

auth-method	Set the RADIUS authentication method to PAP or CHAP
[pap chap]	

Defaults None.

Example

```
ruckus(config)# aaa radius1
The AAA server 'radius1' has been loaded. To save the AAA server,
type 'end' or 'exit'.
ruckus(config-aaa)# auth-method pap
The command was executed successfully. To save the changes, type
'end' or 'exit'.
ruckus(config-aaa)# end
The AAA server 'radius1' has been updated and saved.
Your changes have been saved.
ruckus(config)#
```

ip-addr

To set the AAA server's IP address, use the following command:

```
ip-addr <IP-ADDR>
```

Configuring Controller Settings

Configure AAA Server Commands

Syntax Description

ip-addr	Set the AAA server IP address
---------	-------------------------------

<IP-ADDR>	Set to this IP address
-----------	------------------------

Defaults

None.

Example

```
ruckus(config)# aaa radius
```

The AAA server 'radius' has been loaded. To save the AAA server, type 'end' or 'exit'.

```
ruckus(config-aaa)# ip-addr 192.168.0.7
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-aaa)# end
```

The AAA server 'radius' has been updated and saved.

Your changes have been saved.

```
ruckus(config)#
```

ip-addr port

To set the AAA server's IP address and port number, use the following command:

```
ip-addr <IP-ADDR> port <PORT-NUM>
```

Syntax Description

ip-addr	Set the AAA server IP address
---------	-------------------------------

<IP-ADDR>	Set to this IP address
-----------	------------------------

port	Set the AAA server's port number
------	----------------------------------

<PORT-NUM>	Set the AAA server's port number to this port
------------	---

Defaults

None.

Example

```
ruckus(config)# aaa radius
```

The AAA server 'radius' has been loaded. To save the AAA server, type 'end' or 'exit'.

```
ruckus(config-aaa)# ip-addr 192.168.0.7 port 1812
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-aaa)# end
```

The AAA server 'radius' has been updated and saved.

Your changes have been saved.

```
ruckus(config)#
```

tacplus-service

To set the TACACS+ service name, use the following command:

```
tacplus-service <WORD>
```

Syntax Description

tacplus-service	Configure the TACPLUS service name with length (1-64 bytes).
<WORD>	Name of the TACPLUS service.

Example

```
ruckus(config)# aaa tacplus1
The AAA server 'tacplus1' has been created. To save the AAA server,
type 'end' or 'exit'.
ruckus(config-aaa)# type tacplus-auth
The command was executed successfully. To save the changes, type
'end' or 'exit'.
ruckus(config-aaa)# ip-addr 192.168.4.6
The command was executed successfully. To save the changes, type
'end' or 'exit'.
ruckus(config-aaa)# tacplus-service tacplus-service-1
The command was executed successfully. To save the changes, type
'end' or 'exit'.
ruckus(config-aaa)# tacplus-secret mysecret
The command was executed successfully. To save the changes, type
'end' or 'exit'.
ruckus(config-aaa)# end
The AAA server 'tacplus1' has been updated and saved.
Your changes have been saved.
ruckus(config)#

```

domain-name

To set the Windows/Base domain name, use the following command:

```
domain-name <WORD>
```

Syntax Description

domain-name	Configure the Windows/Base domain name
<WORD>	Set the Windows/Base domain name to this domain name

Defaults

None.

Example	<pre>ruckus(config-aaa)# domain-name company.com</pre> <p>The command was executed successfully. To save the changes, type 'end' or 'exit'.</p>
----------------	---

no ad-global-catalog

To disable Global Catalog support, use the following command:

```
no ad-global-catalog
```

Syntax Description	<pre>no ad-global-catalog</pre> Disable Global Catalog support
---------------------------	--

Defaults	None.
-----------------	-------

Example	<pre>ruckus(config-aaa)# no ad-global-catalog</pre> <p>The command was executed successfully. To save the changes, type 'end' or 'exit'.</p>
----------------	--

ad-global-catalog

To enable Global Catalog support, use the following command:

```
ad-global-catalog
```

Syntax Description	<pre>ad-global-catalog</pre> Enable Global Catalog support
---------------------------	--

Defaults	None.
-----------------	-------

Example	<pre>ruckus(config-aaa)# ad-global-catalog</pre> <p>The command was executed successfully. To save the changes, type 'end' or 'exit'.</p>
----------------	---

admin-dn

To set the admin domain name, use the following command:

```
admin-dn <WORD>
```

Syntax Description	<pre>admin-dn</pre> Set the admin domain name
---------------------------	---

	<WORD>	Set to this domain name
Defaults	None.	
Example	ruckus(config-aaa) # admin-dn domain_of_admin The command was executed successfully. To save the changes, type 'end' or 'exit'.	

admin-password

To set the admin password, use the following command:

```
admin-password <WORD>
```

Syntax Description	admin-password	Set the admin password
	<WORD>	Set to this password
Defaults	None.	
Example	ruckus(config-aaa) # admin-password test1234 The command was executed successfully. To save the changes, type 'end' or 'exit'.	

key-attribute

To set the LDAP key attribute, use the following command:

```
key-attribute <WORD>
```

Syntax Description	key-attribute	Set the LDAP key attribute
	<WORD>	Set to this attribute
Defaults	None.	
Example	ruckus(config-aaa) # key-attribute mycompany The command was executed successfully. To save the changes, type 'end' or 'exit'.	

search-filter

To set the LDAP search filter, use the following command:

```
search-filter <WORD>
```

Syntax Description	
	search-filter Set the LDAP search filter
	<WORD> Set to this filter

Defaults	None.
Example	

Example	<pre>ruckus(config-aaa)# search-filter stringofsearch</pre> <p>The command was executed successfully. To save the changes, type 'end' or 'exit'.</p>
---------	--

radius-secret

To set the AAA server's shared secret, use the following command:

```
radius-secret <WORD>
```

Syntax Description	
	radius-secret RADIUS server secret
	<WORD> Set the RADIUS server secret to this secret

Defaults	None.
Example	

Example	<pre>ruckus(config-aaa)# radius-secret mysecret</pre> <p>The command was executed successfully. To save the changes, type 'end' or 'exit'.</p>
---------	--

tacplus-secret

To set the TACPLUS server's shared secret, use the following command:

```
tacplus-secret <WORD>
```

Syntax Description	
	tacplus-secret TACPLUS server secret
	<WORD> Set the TACPLUS server secret to this secret

Example	<pre>ruckus(config)# aaa tacplus1</pre> <p>The AAA server 'tacplus1' has been created. To save the AAA server, type 'end' or 'exit'.</p> <pre>ruckus(config-aaa)# ip-addr 192.168.4.7</pre>

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-aaa)# type tacplus-auth
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-aaa)# tacplus-service service1
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-aaa)# tacplus-secret mysecret
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-aaa)# show
```

AAA:

 ID:

 :

 Name= tacplus1

 Type= TACPLUS Auth

 TACPLUS AUTH:

 IP Address= 192.168.4.7

 Port= 49

 TACPLUS SERVICE = service1

 Secret= *****

```
ruckus(config-aaa)# end
```

The AAA server 'tacplus1' has been updated and saved.

Your changes have been saved.

```
ruckus(config)#
```

Backup RADIUS server AAA Commands

The following commands are used to enable and configure a backup (secondary) RADIUS server.

backup

To enable a backup RADIUS server, use the following command:

```
  backup
```

Syntax Description

backup	Enables secondary RADIUS server
--------	---------------------------------

Example

ruckus(config)# aaa radius

Configuring Controller Settings

Configure AAA Server Commands

The AAA server 'radius' has been loaded. To save the AAA server, type 'end' or 'exit'.

```
ruckus(config-aaa)# backup  
The command was executed successfully. To save the changes, type  
'end' or 'exit'.  
ruckus(config-aaa)# show  
AAA:  
ID:  
6:  
Name= radius  
Type= RADIUS server  
Auth Method= pap  
Primary RADIUS:  
IP Address= 192.168.0.7  
Port= 1812  
Secret= secret  
Secondary RADIUS:  
Status= Enabled  
IP Address= 192.168.0.8  
Port= 1812  
Secret= secret  
Failover Policy:  
Request Timeout= 10 Seconds  
Max. Number of Retries= 2 Times  
Reconnect Primary= 500 Minutes  
ruckus(config-aaa)# end  
The AAA server 'radius' has been updated and saved.  
Your changes have been saved.  
ruckus(config)#
```

backup-ip-addr

To set the IP address of the secondary RADIUS server, enter the following command:

```
backup-ip-addr <IP-ADDR>
```

Syntax Description

backup-ip-addr	Sets the IP address of the secondary RADIUS server
<IP-ADDR>	Set to this IP address

Example

```
ruckus(config)# aaa radius
```

The AAA server 'radius' has been loaded. To save the AAA server, type 'end' or 'exit'.

ruckus(config-aaa)# **backup-ip-addr 192.168.0.8**

The command was executed successfully. To save the changes, type 'end' or 'exit'.

ruckus(config-aaa)# **end**

The AAA server 'radius' has been updated and saved.

Your changes have been saved.

ruckus(config)#

backup-radius-secret

To set the shared secret of the secondary RADIUS server, enter the following command:

backup-radius-secret <WORD>

Syntax Description

backup-radius- secret Sets the secret of the secondary RADIUS server

<WORD> Set to this secret

Defaults

None.

Example

ruckus(config)# **aaa radius**

The AAA server 'radius' has been loaded. To save the AAA server, type 'end' or 'exit'.

ruckus(config-aaa)# **backup**

The command was executed successfully. To save the changes, type 'end' or 'exit'.

ruckus(config-aaa)# **backup-radius-secret secret**

The command was executed successfully. To save the changes, type 'end' or 'exit'.

ruckus(config-aaa)# **end**

The AAA server 'radius' has been updated and saved.

Your changes have been saved.

ruckus(config)#

no backup

To disable the backup RADIUS server, use the following command:

no backup

Configuring Controller Settings

Configure AAA Server Commands

Syntax Description

no backup	Disable backup RADIUS server
-----------	------------------------------

Defaults

None.

Example

```
ruckus(config-aaa)# no backup
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

request-timeout

To set the failover request timeout (2~20 seconds), use the following command:

```
request-timeout <NUMBER>
```

Syntax Description

request-timeout	Set failover request timeout
-----------------	------------------------------

<NUMBER>	Number of seconds (2~20 seconds) for failover request timeout
----------	---

Defaults

None.

Example

```
ruckus(config-aaa)# request-timeout 10
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

retry-count

To set the failover retry count (2~10 times), use the following command:

```
retry-count <NUMBER>
```

Syntax Description

retry-count	Set failover retry count
-------------	--------------------------

<NUMBER>	Number of attempts (2~10 times) for failover retry count
----------	--

Defaults

None.

Example

```
ruckus(config-aaa)# retry-count 5
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

reconnect-primary-interval

To set the failover reconnect to primary interval (1~86400 minutes), use the following command:

```
reconnect-primary-interval <NUMBER>
```

Syntax Description

reconnect-primary-interval	Set interval for reconnecting to primary AAA server after failover
<NUMBER>	Number of minutes (1~86400 minutes) after which reconnect to primary is attempted

Defaults

None.

Example

```
ruckus(config-aaa)# reconnect-primary-interval 600
The command was executed successfully. To save the changes, type
'end' or 'exit'.
ruckus(config-aaa) #
```

Configure DHCP Server Commands

This section describes the commands that you can use to configure DHCP server entries on the controller. These DHCP server entries are used by the DHCP Relay feature, if enabled for a tunneled WLAN. The following commands can be executed from within the config-dhcp context.

dhcp

Use the `dhcp` command from within the config context to create or edit a DHCP server entry.

```
dhcp <WORD>
```

Syntax Description

dhcp	Configure the DHCP server settings
<WORD>	Name of the DHCP server entry

Defaults

none

Example

```
ruckus(config)# dhcp dhcp_server_2
```

Configuring Controller Settings

Configure DHCP Server Commands

```
The DHCP server 'dhcp_server_2' has been created. To save the DHCP
server, type 'end' or 'exit'.
ruckus(config-dhcp)# first 192.168.11.99
The command was executed successfully. To save the changes, type
'end' or 'exit'.
ruckus(config-dhcp)# show
DHCP servers for DHCP relay agent:
    ID:
    :
        Name= dhcp_server_2
        Description=
        IP Address= 192.168.11.99

ruckus(config-dhcp)# end
The DHCP server 'dhcp_server_2' has been updated and saved.
Your changes have been saved.
ruckus(config)# show dhcp
DHCP servers for DHCP relay agent:
    ID:
    1:
        Name= DHCP Server 1
        Description=
        IP Address= 192.168.11.1
        IP Address=

    2:
        Name= dhcp_server_2
        Description=
        IP Address= 192.168.11.99
        IP Address=

ruckus(config)#

```

no dhcp

Use the no dhcp command to delete a DHCP server entry.

```
no dhcp <WORD>
```

Example

```
ruckus(config)# no dhcp dhcp_server_2
The DHCP server 'dhcp_server_2' has been deleted.
ruckus(config)#

```

show

Displays a list of available DHCP servers.

```
show
```

name

Sets the DHCP server name.

```
name <WORD>
```

description

Sets the DHCP server description.

```
description <WORD>
```

first

Sets the DHCP server's first IP address.

```
first <IP-ADDR>
```

second

Sets the DHCP server's second IP address.

```
second <IP-ADDR>
```

no second

Deletes the DHCP server's second IP address.

```
no second <IP-ADDR>
```

Configure Admin Commands

Use the `admin` commands to enter the config-admin context to set the admin user name, password and admin authentication server settings.

admin

To enter the config-admin context and configure administrator preference, use the following command:

```
admin
```

Example

```
ruckus(config)# admin
ruckus(config-admin)
```

Configuring Controller Settings

Configure Admin Commands

name

To set the administrator user name, use the following command:

```
name <WORD>
```

Syntax Description

name	Configure the admin name setting
<WORD>	Set the admin name to this name

Defaults

admin

Example

```
ruckus(config)# admin
ruckus(config-admin)# name admin
The command was executed successfully. To save the changes, type
'end' or 'exit'.
ruckus(config-admin)# end
The administrator preferences have been updated.
Your changes have been saved.
ruckus(config)#

```

name password

To set the admin name and password at the same time, use the following command:

```
name <WORD> password <WORD>
```

Syntax Description

name	Configure the admin name setting
<WORD>	Set the admin name to this name
password	Configure the admin password
<WORD>	Set the admin password to this password

Defaults

admin

Example

```
ruckus(config)# admin
ruckus(config-admin)# name admin password admin
The command was executed successfully. To save the changes, type
'end' or 'exit'.
ruckus(config-admin)# end
The administrator preferences have been updated.
Your changes have been saved.

```

```
ruckus(config) #
```

Admin Authentication Commands

Use the `auth-server` commands to set the administrator authentication options with an external authentication server.

auth-server

To enable administrator authentication with a remote server and set the authentication server, use the following command:

```
auth-server <WORD>
```

Syntax Description

<code>auth-server</code>	Admin authentication with an external server
<code><WORD></code>	Set the authentication server to this server

Defaults

None.

Example

```
ruckus(config-admin) # auth-server radius
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-admin) #
```

no auth-server

To disable administrator authentication with a remote server, use the following command:

```
no auth-server
```

Syntax Description

<code>no auth-server</code>	Disable admin authentication with an external server
-----------------------------	--

Defaults

None.

Example

```
ruckus(config-admin) # no auth-server
```

The command was executed successfully.

Configuring Controller Settings

Configure Access Points

auth-server with-fallback

To enable fallback authentication (for use when the remote server is unavailable), use the following command:

```
auth-server <WORD> with-fallback
```

Syntax Description

auth-server	Admin authentication with an external server
<WORD>	Set the auth-server to this server
with-fallback	Enable fallback authentication if the remote authentication server is unavailable

Defaults

None.

Example

```
ruckus(config-admin)# auth-server radius with-fallback
The command was executed successfully. To save the changes, type
'end' or 'exit'.
ruckus(config-admin)# show
Administrator Name/Password:
Name= admin
Password= admin
Authenticate:
Mode= Authenticate with authentication server 'radius'
Fallback= Enabled

ruckus(config-admin)#

```

Configure Access Points

The following commands can be used from within the config-ap context to configure a specific Access Point.

ap

To enter the config-ap context, enter the following command:

```
ap <MAC>
```

Syntax Description

ap	Access Point
<MAC>	MAC address of the access point for configuration

Defaults

None.

Example

```
ruckus(config)# ap 04:4f:aa:0c:b1:00  
The AP '04:4f:aa:0c:b1:00' has been loaded. To save the AP, type  
'end' or 'exit' .  
ruckus(config-ap)#
```

no ap

To delete an AP from the list of approved devices, use the following command:

```
no ap <MAC>
```

Syntax Description

no ap	Delete Access Point
<MAC>	MAC address of the access point

Defaults

None.

Example

```
ruckus(config)# no ap 04:4f:aa:0c:b1:00  
The AP '04:4f:aa:0c:b1:00' has been deleted.  
ruckus(config)#
```

devname

To set the device name, use the following command:

```
devname <WORD>
```

Syntax Description

devname	Device name
<WORD>	Set the device name to this name

Defaults

None.

Example

```
ruckus(config)# ap 04:4f:aa:0c:b1:00  
The AP '04:4f:aa:0c:b1:00' has been loaded. To save the AP, type  
'end' or 'exit' .  
ruckus(config-ap)# devname 7962  
The command was executed successfully. To save the changes, type  
'end' or 'exit' .  
ruckus(config-ap)# end  
The device information has been updated.  
Your changes have been saved.
```

Configuring Controller Settings

Configure Access Points

```
ruckus(config) #
```

no devname

To delete the device's name, use the following command:

```
no devname
```

description

To set the device description, use the following command:

```
description <WORD>
```

Syntax Description

description	Device description
<WORD>	Set the device description to this text

Defaults

None.

Example

```
ruckus(config-ap-00:13:92:00:33:1C) # description this-is-the-device-description
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-ap) #
```

no description

To delete the device's description, use the following command:

```
no description
```

gps

To set the device GPS coordinates, use the following command:

```
gps <GPS-COORDINATE>
```

Syntax Description

gps	Set the device GPS coordinates
<GPS-COORDINATE>	Enter the device's GPS coordinates for the latitude and longitude. Use a comma (,) to separate the latitude and longitude. The first coordinate is for the latitude. The second coordinate is for the longitude. Ex. A,B or -37,38.

Defaults

None.

Example

```
ruckus(config-ap)# gps 37.3,-122  
The command was executed successfully. To save the changes, type  
'end' or 'exit'.  
ruckus(config-ap)#[/pre>
```

no gps

To delete the device's GPS coordinates, use the following command:

```
no gps
```

location

To set the device location, use the following command:

```
location <WORD>
```

Syntax Description

location	Device location
<WORD>	Set the device location to this address

Defaults

None.

Example

```
ruckus(config-ap)# location sunnyvale-office  
The command was executed successfully. To save the changes, type  
'end' or 'exit'.  
ruckus(config-ap)#[/pre>
```

no location

To delete the device's location, use the following command:

```
no location
```

group

To set the AP group for this AP, use the following command:

```
group [name <WORD>] | system-default
```

Syntax Description

group	Set the AP group that this AP is a member of
name	Set the AP to be a member of the named AP group
<WORD>	The name of the AP group
system-default	Set the AP as a member of the system default AP group

Configuring Controller Settings

Configure Access Points

Defaults system-default

Example

```
ruckus(config-ap)# group system-default
The command was executed successfully. To save the changes, type
'end' or 'exit'.
ruckus(config-ap)#+
```

ip

To set the AP's IPv4 address, use the following command from within the config-ap context:

```
ip [enable|disable] addr <IP-ADDR> <NET-MASK> name-server <DNS-
ADDR> mode [dhcp|static|keep]
```

Syntax Description

ip	Set the AP's IPv4 addressing
enable	Enable IPv4 addressing
disable	Disable IPv4 addressing
addr	Set the AP's IPv4 address
<IP-ADDR>	The IPv4 address
<NET-MASK>	The IPv4 netmask
name-server	Set the device's DNS servers. Use a space () to separate primary and secondary DNS servers
<DNS-ADDR>	The IP address of the DNS server
mode	Set the device's IP addressing mode (DHCP, static or "keep AP's setting")
dhcp	Set the device's IP address mode to DHCP
static	Set the device's IP address mode to static
keep	Set the device to use its current network settings

Defaults none

Example

```
ruckus(config-ap)# ip enable mode dhcp
The command was executed successfully. To save the changes, type
'end' or 'exit'.
ruckus(config-ap)#+
```

ipv6

To set the AP's IPv6 address, use the following command from within the config-ap context:

```
ipv6 [enable] addr <IPv6-ADDR> <IPv6-PREFIX-LENGTH> name-server  
<DNS-ADDR> mode [auto|manual|keep]
```

Syntax Description

ipv6	Set the AP's IPv6 addressing
enable	Enable IPv6 addressing
addr	Set the AP's IPv6 address
<IPv6-ADDR>	The IPv6 address
<IPv6-PREFIX-LENGTH>	The IPv6 prefix length. Use a space () to separate the IPv6 address and prefix length
name-server	Set the device's DNS servers. Use a space () to separate primary and secondary DNS servers
<DNS-ADDR> [<DNS-ADDR>]	The IP address of the DNS server
mode	Set the device's IP addressing mode (auto, manual or "keep AP's setting")
auto	Set the device's IPv6 address mode to auto
manual	Set the device's IPv6 address mode to manual
keep	Set the device to use its current network settings

Defaults

none

Example

```
ruckus(config-ap)# ipv6 enable mode auto  
The command was executed successfully. To save the changes, type  
'end' or 'exit'.  
ruckus(config-ap) #
```

no ipv6

To disable the AP's IPv6 mode, use the following command:

```
no ipv6
```

Radio 2.4/5 GHz Commands

Use the `radio 2.4` or `radio 5` commands to configure the 2.4/5 GHz radio settings independently.

Configuring Controller Settings

Configure Access Points

radio

Use the radio command from within the config-ap context to configure the 2.4GHz or 5GHz radios independently.

```
radio [2.4|5] <arguments>
```

Syntax Description

2.4	Configure the 2.4 GHz radio
5	Configure the 5 GHz radio
channelization [auto <NUMBER>]	Set channel width to 20 MHz, 40 MHz or Auto
channel [auto <NUMBER>]	Set channel to Auto or manually set channel
tx-power [auto full min nu m <1-10>]	Set transmit power to auto, full, min, or a number (-1dB~- 10dB)
admission-control <VALUE>	Set the radio to use the specified call admission control airtime usage limit (%)
channel-range <NUMBER-LIST>	Set the allowed list of channels for the specified radio.
wlan-group <WORD>	Set the AP radio as a member of a WLAN group
wlan-service	Enable WLAN service on this radio
extant-gain <NUMBER>	Set external antenna gain (on APs that support external antennas) (dBi)

Defaults

channelization: Auto
channel: Auto
wlan-group: Default
wlan-service: Enable
tx-power: Auto

Example

```
ruckus(config-ap)# radio 2.4 channelization auto
The command was executed successfully. To save the changes, type
'end' or 'exit'.
ruckus(config-ap)# radio 2.4 channel auto
The command was executed successfully. To save the changes, type
'end' or 'exit'.
ruckus(config-ap)# radio 2.4 wlan-group Default
The command was executed successfully. To save the changes, type
'end' or 'exit'.
ruckus(config-ap)# radio 2.4 wlan-service
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-ap)# radio 2.4 tx-power auto
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-ap)# end
```

The device information has been updated.

Your changes have been saved.

```
ruckus(config)#
```

no radio

Use the no radio 2.4 or no radio 5 command from within the config-ap context to disable AP group overrides for the 2.4GHz or 5GHz radio settings.

```
no radio [2.4|5] <arguments>
```

Syntax Description

no radio	Disable override of 2.4/5GHz radio settings
2.4	Disable 2.4GHz radio override settings
5	Disable 5GHz radio override settings
wlan-service	Disable override of WLAN service settings.
channel-range-override	Disables override of channel range settings.
channel-override	Disables override of channel settings.
channelization-override	Disables override of 5GHz channelization settings.
tx-power-override	Disables override of Tx power.
wlan-group-override	Disables override of WLAN group settings
admission-control	Disables call admission control on the radio
admission-control-override	Disables override of call admission control settings
wlan-service	Disables override of WLAN service settings
channel-range-override	Disables override of channel range settings

Example

```
ruckus(config-ap)# no radio 2.4 tx-power-override
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-ap)#
```

Configuring Controller Settings

Configure Access Points

mesh mode

Use the `mesh mode` command from within the config-ap context to configure the AP's mesh mode settings.

```
mesh mode [auto|root-ap|mesh-ap|disable]
```

Syntax Description

mesh mode	Configure the AP's mesh mode
auto	Set mesh mode to Auto
root-ap	Configure AP as a Root AP
mesh-ap	Configure AP as a Mesh AP
disable	Disable mesh

Defaults

Auto.

Example

```
ruckus(config-ap)# mesh mode auto  
The command was executed successfully. To save the changes, type  
'end' or 'exit'.  
ruckus(config-ap)#[/pre>
```

mesh uplink-selection

Use the `mesh uplink-selection` command from within the config-ap context to configure the AP's mesh uplink selection settings.

```
mesh uplink-selection [auto|manual] <add-mac>|<del-mac> <MAC>
```

Syntax Description

mesh uplink-selection	Configure the AP's mesh uplink selection mode
auto	Set mesh uplink selection to Auto
manual	Set mesh uplink selection to manual
add-mac	Add a manual uplink selection AP
del-mac	Delete a manual uplink selection AP
<MAC>	The MAC address of the uplink AP

Defaults

Auto.

Example

```
ruckus(config-ap)# mesh uplink-selection manual add-mac  
00:24:82:3f:14:60
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-ap) #
```

Example

```
ruckus(config-ap) # mesh uplink-selection auto
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-ap) #
```

status-leds

To enable or disable the AP's status LEDs, use the following command:

```
status-leds [enable|disable]
```

Defaults

Enabled.

Syntax Description

status-leds	Configure status LEDs
enable	Override group config, enable status LEDs
disable	Override group config, disable status LEDs

Example

```
ruckus(config-ap) # status-leds disable
```

```
ruckus(config-ap) #
```

no status-leds-override

To disable override of status LEDs for this AP, use the following command:

```
no status-leds-override
```

poe-out

To enable or disable the AP's PoE Out port, use the following command:

```
poe-out [enable|disable]
```

Defaults

Disabled.

Syntax Description

poe-out	Configure PoE Out port
enable	Override group config, enable PoE Out port
disable	Override group config, disable PoE Out port

Configuring Controller Settings

Configure Access Points

Example

```
ruckus(config-ap)# poe-out enable  
ruckus(config-ap)#{/pre>
```

no poe-out-override

To disable override of the PoE out port settings, use the following command:

```
no poe-out-override
```

no usb-software override

To disable the override of the AP USB software package, use the following command:

```
no usb-software override
```

external-antenna

To configure the AP's external antenna settings, use the following command:

```
external-antenna [2.4GHz(11BG) | 5GHz(11NA)] [enable|disable]  
[gain <MAC>] [2-antennas | 3-antennas]
```

Syntax Description

2.4GHz (11BG)	Configure external 2.4GHz antenna
5GHz (11NA)	Configure external 5GHz antenna
enable disable	Enable/disable external antenna
gain	Set external antenna gain for 2.4/5GHz radio
2-antennas	Select two external antennas for the specified radio
3-antennas	Select three external antennas for the specified radio

no external-antenna-override

To disable override of the external antenna, use the following command:

```
no external-antenna-override
```

internal-heater

To enable or disable the AP's internal heater, use the following command:

```
internal-heater [enable|disable]
```

Defaults

Disabled.

Syntax Description

internal-heater	Configure internal heater
enable	Override group config, enable internal heater
disable	Override group config, disable internal heater

Example

```
ruckus(config-ap)# internal-heater enable  
ruckus(config-ap)#[/pre]
```

no internal-heater-override

To disable override of the internal heater for this AP, use the following command:

```
no internal-heater-override
```

cband-channels

To enable or disable the 5.8 GHz C-band channels, use the following command:

```
cband-channels [enable|disable]
```

Defaults

Disabled.

Syntax Description

cband-channels	Configure C-band channels
enable	Override group config, enable C-band channels
disable	Override group config, disable C-band channels

Example

```
ruckus(config-ap)# cband-channels enable  
ruckus(config-ap)#[/pre]
```

no cband-channels-override

To disable override of the 5.8 GHz channels, use the following command:

```
no cband-channels-override
```

usb-software

To set the AP USB software package vendor ID (VID) and product ID (PID), use the following command:

```
usb-software <VID-PID>
```

Configuring Controller Settings

Configure Access Points

no usb-software

To delete a USB software package from the list of USB software packages, use the following command:

```
no usb-software
```

ipmode

To set the AP's IP mode, use the following command:

```
ipmode <WORD>
```

Defaults

Dual-stack IPv4/IPv6 mode

Syntax Description

ipmode	Configure IP addressing mode
ipv4	Set to IPv4 only mode
ipv6	Set to IPv6 only mode
dual	Set to dual-stack IPv4/IPv6 mode

Example

```
ruckus(config-ap)# ipmode dual
ruckus(config-ap) #
```

no ipmode-override

To disable the override of the IP mode, use the following command:

```
no ipmode-override
```

radio-band

To set the radio band of the AP, use the following command:

```
radio-band <WORD>
```

This command is available only on APs that support band switching between 2.4GHz and 5GHz radio band modes.

Syntax Description

radio-band	Configure radio band mode
<WORD>	Set to 2.4 or 5 GHz radio mode

Example

```
ruckus(config-ap)# radio-band 5
Your changes have been saved.
ruckus(config-ap) #
```

no radio-band-override

To disable AP radio band override settings, use the following command:

```
no radio-band-override
```

venue-name

To set the venue name of the AP, use the following command:

```
venue-name [language] <WORD>
```

Syntax Description

venue-name	Set the venue name for the AP
[language]	Set the language of the venue name. Valid languages are: English, Chinese, Czech, Danish, Dutch, French, German, Japanese, Spanish, Swedish, Turkish)
<WORD>	Set the venue name to the name specified

Example

```
ruckus(config-ap)# venue-name english venue1
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-ap) #
```

no venue-name

To remove a venue name entry, use the following command:

```
no venue-name [language]
```

Example

```
ruckus(config-ap)# no venue-name english
```

The entry 'English' has been removed. To save the changes, type 'end' or 'exit'.

```
ruckus(config-ap) #
```

show

To display the AP's current configuration settings, use the following command:

```
show
```

Example

```
ruckus(config)# ap 04:4f:aa:0c:b1:00
```

The AP '04:4f:aa:0c:b1:00' has been loaded. To save the AP, type 'end' or 'exit'.

```
ruckus(config-ap)# show
```

```
AP:
```

Configuring Controller Settings

Configure Access Points

```
ID:  
2:  
    MAC Address= 04:4f:aa:0c:b1:00  
    Model= zf7962  
    Approved= Yes  
    Device Name= 7962 - Mesh  
    Description=  
    Location=  
    GPS=  
    CERT = Normal  
    Group Name= System Default  
    Channel Range:  
        A/N=  
        36,40,44,48,52,56,60,64,100,104,108,112,116,120,124,128,132,136,1  
        49,153,157,161 (Disallowed= )  
        B/G/N= 1,2,3,4,5,6,7,8,9,10,11,12,13 (Disallowed= )  
    Radio a/n:  
        Channelization= Auto  
        Channel= Auto  
        WLAN Services enabled= Yes  
        Tx. Power= Auto  
        WLAN Group Name= Default  
        Call Admission Control= OFF  
    Radio b/g/n:  
        Channelization= Auto  
        Channel= Auto  
        WLAN Services enabled= Yes  
        Tx. Power= Auto  
        WLAN Group Name= Default  
        Call Admission Control= OFF  
    Override global ap-model port configuration= No  
    Network Setting:  
        Protocol mode= Use Parent Setting  
        Device IP Settings= Keep AP's Setting  
        IP Type= DHCP  
        IP Address= 192.168.11.60  
        Netmask= 255.255.255.0  
        Gateway= 192.168.11.1  
        Primary DNS Server=  
        Secondary DNS Server=
```

```
Device IPv6 Settings= Keep AP's Setting
IPv6 Type= Auto Configuration
IPv6 Address= fc00::1
IPv6 Prefix Length= 7
IPv6 Gateway=
IPv6 Primary DNS Server=
IPv6 Secondary DNS Server=
Mesh:
Status= Enabled
Mode= Auto
Uplink:
Status= Smart
Venue Name List:

ruckus (config-ap) #
```

AP Port Setting Commands

To override AP group configuration settings and configure the AP's Ethernet ports individually, you must first enter the `config-ap-model` context from within the `config-ap` context.

port-setting

Use the following command to enter the `config-ap-model` context and override AP group settings to configure AP ports individually:

```
port-setting
```

Defaults

None

Syntax Description

<code>port-setting</code>	Configure AP port settings
<code>no lan <NUMBER></code>	Disable the AP LAN port
<code>no dot1x <authsvr> <acctsrv> <mac-auth-bypass></code>	Disable authentication server, accounting server, or MAC auth bypass for the AP's 802.1X settings
<code>lan <NUMBER> {Arguments}</code>	Configure the AP LAN port.

Configuring Controller Settings

Configure Access Points

dot1x <authsvr> <acctsrv> <mac-auth-bypass>	Enable authentication server, accounting server, or MAC auth bypass for the AP's 802.1X settings
authsvr <WORD>	Enter the RADIUS server name
acctsrv <WORD>	Enter the RADIUS accounting server name
mac-auth-bypass	Enable MAC authentication bypass for the 802.1X-enabled port

Example

```
ruckus(config-ap)# port-setting  
ruckus(config-ap-model) #
```

abort

To exit the port-setting context without saving changes, use the **abort** command.

```
abort
```

Syntax Description

abort	Exit the context without saving changes
-------	---

Defaults

None.

Example

```
ruckus(config-ap-model) # abort  
No changes have been saved.  
ruckus(config-ap) #
```

end

To save changes, and then exit the port-setting context, use the following command:

```
end
```

Syntax Description

end	Save changes, and then exit the context
-----	---

Defaults

None.

Example

```
ruckus(config-ap-model) # end  
ruckus(config-ap) #
```

exit

To save changes, and then exit the config-ap-model context, use the following command:

```
exit
```

Syntax Description

exit	Save changes, and then exit the context
------	---

Defaults

None.

Example

```
ruckus(config-ap-model)# exit  
ruckus(config-ap)#
```

quit

To exit the config-ap-model context without saving changes, use the quit command.

```
quit
```

Syntax Description

quit	Exit the context without saving changes
------	---

Defaults

None.

Example

```
ruckus(config-ap-model)# quit  
No changes have been saved.  
ruckus(config-ap)#
```

show

To display the current port settings, use the following command:

```
show
```

Syntax Description

show	Display the current port settings
------	-----------------------------------

Defaults

None.

Example

```
ruckus(config)# ap 04:4f:aa:0c:b1:00
```

Configuring Controller Settings

Configure Access Points

```
ruckus(config-ap)# port-setting
ruckus(config-ap-model)# show
PORTS:
  LAN ID:
    1:
      Enable LAN = Yes
      LAN Type= trunk
      Untag ID= 1
      Members= 1-4094
      Guest VLAN=
      Enable Dynamic VLAN= Disabled
      802.1X= disabled
      DHCP opt82= Disabled
      MLD Snooping= Disabled
      IGMP Snooping= Enabled
    2:
      Enable LAN = Yes
      LAN Type= trunk
      Untag ID= 1
      Members= 1-4094
      Guest VLAN=
      Enable Dynamic VLAN= Disabled
      802.1X= disabled
      DHCP opt82= Disabled
      MLD Snooping= Disabled
      IGMP Snooping= Enabled
ruckus(config-ap-model)#

```

lan

To enable the LAN port, use the following command:

```
lan <NUMBER>
```

Syntax Description

lan	Enable the LAN port
<NUMBER>	Specify the LAN port to enable

Defaults

Enabled.

Example

```
ruckus(config-ap-model)# lan 1
ruckus(config-ap-model)#

```

no lan

To disable the LAN port, use the following command:

```
no lan <NUMBER>
```

Syntax Description

no lan	Disable the LAN port
<NUMBER>	Specify the LAN port to disable

Defaults

None.

Example

```
ruckus(config-ap-model)# no lan 1
ruckus(config-ap-model)#

```

lan uplink

To sets the AP port type (Trunk, Access or General), use the following command:

```
lan <NUMBER> uplink <WORD>
```

Syntax Description

lan uplink	Set the LAN port type
<NUMBER>	Specify the LAN port to configure
uplink	Set the port type to the specified type
<WORD>	LAN port type (Trunk port, Access port, General port)

Defaults

For all APs other than 7025: Trunk

For 7025 LAN 5: Trunk

For 7025 LAN 1-LAN 4: Access

Example

```
ruckus(config-ap-model)# lan 1 uplink access
ruckus(config-ap-model)#

```

lan untag

To set the LAN port untag VLAN ID (native VLAN, for Trunk ports), use the following command:

```
lan <NUMBER> untag <NUMBER>
```

Configuring Controller Settings

Configure Access Points

Syntax Description	
lan untag	Set the LAN port untag VLAN ID
<NUMBER>	Specify the LAN port to configure
<NUMBER>	Set the untag VLAN ID (1~4094)

Defaults	1
Example	<pre>ruckus(config-ap-model)# lan 1 untag 1 ruckus(config-ap-model)# </pre>

lan member

To set the LAN port VLAN membership (only General ports have configurable membership; Trunk ports are members of all VLANs, and Access port membership must be the same as the Untag VLAN), use the following command:

```
lan <NUMBER> member <NUMBER>
```

Syntax Description	
lan member	Set the LAN port VLAN membership
<NUMBER>	Specify the LAN port to configure
<NUMBER>	Set the VLAN membership (1~4094, range separated by hyphen, multiple VLANs separated by commas)

Defaults	1
Example	<pre>ruckus(config-ap-model)# lan 1 uplink general ruckus(config-ap-model)# lan 1 member 1-10,100,200 ruckus(config-ap-model)# show PORTS: LAN ID: 1: Enable LAN = Yes LAN Type= general Untag ID= 12 Members= 1-10,100,200 802.1X= disabled DHCP opt82= Disabled LAN ID: 2: </pre>

```
Enable LAN = Yes
LAN Type= trunk
Untag ID= 1
Members= 1-4094
802.1X= disabled
DHCP opt82= Disabled
ruckus(config-ap-model) #
```

lan opt82

To enable or disable DHCP option 82 for a LAN port, use the following command:

```
lan <NUMBER> opt82 [enabled|disabled]
```

Syntax Description

opt82	Enable or disable DHCP option 82
enabled	Enable option 82
disabled	Disable option 82

Defaults

Disabled

Example

```
ruckus(config-ap-model) # lan 1 opt82 enable
ruckus(config-ap-model) #
```

lan guest-vlan

To set the AP port to use the specified Guest VLAN ID, use the following command:

```
lan <NUMBER> guest-vlan <NUMBER>
```

lan dvlan

To enable dynamic VLAN for the port, use the following command:

```
lan <NUMBER> dvlan
```

lan dvlan disabled

To disable dynamic VLAN for the port, use the following command:

```
lan <NUMBER> dvlan disabled
```

lan dvlan enabled

To enable dynamic VLAN for the port, use the following command:

```
lan <NUMBER> dvlan enabled
```

Configuring Controller Settings

Configure Access Points

lan dot1x

To configure 802.1X settings for a LAN port, use the following command:

```
lan <NUMBER> dot1x [disable|supplicant|auth-port-based|auth-mac-based]
```

Syntax Description

lan dot1x	Configure 802.1X settings for this port
<NUMBER>	LAN port number to configure
disabled	Disable 802.1X
supplicant	Configure this LAN port as an 802.1X supplicant
auth-port-based	Configure this LAN port as an 802.1X authenticator (port-based)
auth-mac-based	Configure this LAN port as an 802.1X authenticator (MAC-based)

Defaults

Disabled

Example

```
ruckus(config-ap-model)# lan 1 dot1x supplicant  
ruckus(config-ap-model) #
```

dot1x authsvr

To configure 802.1X authentication server, use the following command:

```
dot1x authsvr <WORD>
```

Syntax Description

dot1x authsvr	Configure 802.1X authentication server
<WORD>	Name of AAA server

Defaults

None

Example

```
ruckus(config-ap-model)# dot1x authsvr radius  
ruckus(config-ap-model) #
```

dot1x acctsvr

To configure 802.1X accounting server, use the following command:

```
dot1x acctsvr <WORD>
```

Syntax Description	dot1x acctsvr <WORD>	Configure 802.1X accounting server Name of AAA server
---------------------------	-------------------------	--

Defaults	None
-----------------	------

Example	ruckus(config-ap-model)# dot1x acctsvr radius-acct ruckus(config-ap-model) #
----------------	--

dot1x mac-auth-bypass

To configure 802.1X MAC authentication bypass, use the following command:

```
dot1x mac-auth-bypass
```

Syntax Description	dot1x mac-auth-bypass	Enable 802.1X MAC authentication bypass
---------------------------	-----------------------	---

Defaults	Disabled
-----------------	----------

Example	ruckus(config-ap-model)# dot1x mac-auth-bypass ruckus(config-ap-model) #
----------------	--

dot1x supplicant username

To configure 802.1X supplicant user name, use the following command:

```
dot1x supplicant username <WORD>
```

Syntax Description	dot1x supplicant username <WORD>	Configure 802.1X supplicant user name Set the 802.1X supplicant user name
---------------------------	-------------------------------------	--

Defaults	None
-----------------	------

Example	ruckus(config-ap-model)# dot1x supplicant username john doe ruckus(config-ap-model) #
----------------	---

dot1x supplicant password

To configure 802.1X supplicant password, use the following command:

Configuring Controller Settings

Configure AP Policy Commands

```
dot1x supplicant password <WORD>
```

Syntax Description

dot1x supplicant password	Configure 802.1X supplicant password
<WORD>	Set the 802.1X supplicant password

Defaults

None

Example

```
ruckus(config-ap-model)# dot1x supplicant password test123  
ruckus(config-ap-model)#[/pre]
```

dot1x supplicant mac

To set the 802.1X supplicant user name and password as the AP's MAC address, use the following command:

```
dot1x supplicant mac
```

Syntax Description

dot1x supplicant mac	Set the supplicant user name and password as the AP's MAC address
----------------------	---

Defaults

None

Example

```
ruckus(config-ap-model)# dot1x supplicant mac  
ruckus(config-ap-model)#[/pre]
```

Configure AP Policy Commands

Use the `ap-policy` commands to configure global AP policies such as automatic AP approval, limited ZD discovery, management VLAN, load balancing across APs and max clients per AP radio. To run these commands, you must first enter the `config-ap-policy` context.

ap-policy

To enter the `ap-policy` context and configure global AP policies, enter the following command:

```
ap-policy
```

Syntax Description	ap-policy	Enter config-ap-policy context and configure global AP policies
---------------------------	-----------	---

Defaults	None.
-----------------	-------

Example	ruckus(config)# ap-policy ruckus(config-ap-policy)#
----------------	---

show

To display the current device policy, use the following command:

show

Syntax Description	show	Display the current AP policy settings
---------------------------	------	--

Defaults	None.
-----------------	-------

Example	ruckus(config-ap-policy)# show Automatically approve all join requests from APs= Enabled Limited ZD Discovery: Status= Disabled Management VLAN: Status= Keep AP's setting Balances the number of clients across adjacent APs= Disabled LWAPP message MTU= 1450 Auto Recovery= 30 minutes ruckus(config-ap-policy)#
----------------	---

ap-management-vlan

To enable the AP management VLAN and set to either “keep AP’s setting” or to the specified VLAN ID, use the following command:

ap-management-vlan [keeping] <NUMBER>

Syntax Description	ap-management-vlan	Enable and configure the global AP management VLAN
	keeping	Sets management VLAN to “Keep AP’s setting”

Configuring Controller Settings

Configure AP Policy Commands

<NUMBER>	Set management VLAN to the number specified
----------	---

Defaults	None.
-----------------	-------

Example	ruckus(config-ap-policy)# ap-management-vlan keeping The command was executed successfully. ruckus(config-ap-policy)#[/td>
----------------	---

no ap-management-vlan

To disable the AP management VLAN, use the following command:

```
no ap-management-vlan
```

Syntax Description	no ap-management- Disable the AP management VLAN vlan
---------------------------	--

Defaults	None. ruckus(config-ap-policy)# no ap-management-vlan
-----------------	---

Example	The command was executed successfully. ruckus(config-ap-policy)#[/td>
----------------	--

ap-auto-approve

To enable the automatic approval of join requests from devices, use the following command:

```
ap-auto-approve
```

Syntax Description	ap-auto-approve Enable the automatic approval of join requests from devices
---------------------------	---

Defaults	None.
-----------------	-------

Example	ruckus(config-ap-policy)# ap-auto-approve The AP automatically approve policy has been updated.
----------------	---

no ap-auto-approve

To disable the automatic approval of join requests from devices, use the following command:

```
no ap-auto-approve
```

Syntax Description

no ap-auto-approve	Disable the automatic approval of join requests from devices
--------------------	--

Defaults

None.

Example

```
ruckus(config-ap-policy)# no ap-auto-approve
The AP automatically approve policy has been updated.
ruckus(config-ap-policy)#

```

limited-zd-discovery

To configure devices to connect to a specific ZoneDirector and to set the primary and secondary ZoneDirector's IP addresses, use the following command:

```
limited-zd-discovery <zd-addr|zd-ip> <PRIMARY> <SECONDARY>
```

Syntax Description

limited-zd-discovery	Configure devices to connect to a specific ZoneDirector
zd-addr	Set ZoneDirector's IP/IPv6/FQDN address
zd-ip	Set ZoneDirector's IP/IPv6 address
<PRIMARY>	Address of primary ZD
<SECONDARY>	Address of secondary ZD

Defaults

Disabled.

Example

```
ruckus(config-ap-policy)# limited-zd-discovery zd-addr
192.168.11.100 192.168.11.200
The Limited ZoneDirector discovery function has been updated.
ruckus(config-ap-policy)# show
Automatically approve all join requests from APs= Enabled
Limited ZD Discovery:
Status= Enabled
Primary ZoneDirector ADDR= 192.168.11.100
SecondaryZoneDirector ADDR= 192.168.11.200

```

Configuring Controller Settings

Configure AP Policy Commands

```
Prefer Primary ZoneDirector = false
Management VLAN:
Status= Disabled
Balances the number of clients across adjacent APs= Disabled
Max. clients for 11BG radio= 100
Max. clients for 11N radio= 100
LWAPP message MTU= 1450
ruckus(config-ap-policy) #
```

limited-zd-discovery prefer-primary-zd

To force the AP to prefer the primary ZoneDirector when connected (and periodically attempt to reconnect to the primary ZD when disconnected from it), use the following command:

```
limited-zd-discovery prefer-primary-zd
```

Example

```
ruckus(config-ap-policy) # limited-zd-discovery prefer-primary-zd
The Limited ZoneDirector discovery function has been updated.
ruckus(config-ap-policy) #
```

no limited-zd-discovery

To disable limited ZD discovery, use the following command:

```
no limited-zd-discovery
```

Syntax Description

no limited-zd-	Disable limited ZD discovery
discovery	

Defaults

Disabled.

Example

```
ruckus(config-ap-policy) # no limited-zd-discovery
The Limited ZoneDirector discovery function has been updated.
ruckus(config-ap-policy) #
```

limited-zd-discovery keep-ap-setting

To disallow ZoneDirector modifying AP's original primary/secondary ZD settings, use the following command:

```
limited-zd-discovery keep-ap-setting
```

Example

```
ruckus(config-ap-policy)# limited-zd-discovery keep-ap-setting  
The Limited ZoneDirector discovery function has been updated.  
ruckus(config-ap-policy)#[/pre>
```

ap-max-clients

To set the maximum number of wireless clients that can associate with each device, use the following command:

```
ap-max-clients [11bg|11n] <NUMBER>
```

Syntax Description

ap-max-clients	Set the maximum number of clients per AP
11bg	Set the max clients for the 11bg (2.4 GHz) radio
11n	Set the max clients for the 11n (5 GHz) radio
<NUMBER>	Set to this number

Defaults

None.

Example

```
ruckus(config-ap-policy)# ap-max-clients 11n 99  
The Max clients of AP management has been updated.  
ruckus(config-ap-policy)#[/pre>
```

ap-load-balancing

To enable load balancing across adjacent APs, use the following command:

```
ap-load-balancing
```

Syntax Description

ap-load-balancing	Enable load balancing across adjacent APs
-------------------	---

Defaults

Disabled.

Example

```
ruckus(config-ap-policy)# ap-load-balancing  
The load balancing of AP management has been updated.  
ruckus(config-ap-policy)#[/pre>
```

Configuring Controller Settings

Configure AP Policy Commands

no ap-load-balancing

To disable load balancing across adjacent APs, use the following command:

```
no ap-load-balancing
```

Syntax Description

no ap-load-balancing	Disable load balancing across adjacent APs
----------------------	--

Defaults

Disabled.

Example

```
ruckus(config-ap-policy)# no ap-load-balancing
The load balancing of AP management has been updated.
ruckus(config-ap-policy)#

```

lwapp-message-mtu

To configure the LWAPP message MTU size, use the following command:

```
lwapp-message-mtu <NUMBER>
```

Syntax Description

lwapp-message-mtu	Configure LWAPP message maximum transmit unit size
<NUMBER>	Set the LWAPP MTU to this number (600~1450)

Defaults

1450

Example

```
ruckus(config-ap-policy)# lwapp-message-mtu 1450
The AP Policy has been updated.
ruckus(config-ap-policy)#

```

auto-recovery

To set the value of auto recovery time (minutes) for AP reboot if AP can't connect to ZoneDirector, use the following command:

```
auto-recovery <NUMBER>
```

no auto-recovery

To disable AP auto recovery, use the following command:

```
no auto-recovery
```

vlan-qos

To configure the traffic class [Voice | Video | Data | Background] to the specific VLAN ID at the specific interface, use the following command:

```
vlan-qos <VID> <Traffic Class> <Interface Name>
```

Syntax Description

vlan-qos	Configure VLAN QOS settings
<VID>	VLAN ID
<Traffic Class>	Specify traffic classification (voice, video, data, background)
<Interface Name>	Specify interface name

Defaults

Disabled

Example

```
ruckus(config-ap-policy)# vlan-qos 10 voice eth0  
The VLAN QoS function has been updated.  
ruckus(config-ap-policy) #
```

no vlan-qos

To disable QOS for the specific interface, use the following command:

```
no vlan-qos <VID> <Interface Name>
```

Syntax Description

no vlan-qos	Disable VLAN's QOS settings
<VID>	VLAN ID
<Interface Name>	Specify interface name

Defaults

Disabled

Example

```
ruckus(config-ap-policy)# no vlan-qos all eth0  
The VLAN QoS function has been updated.  
ruckus(config-ap-policy) #
```

move-ap

To enter the config-ap-policy-move-ap context, use the following command:

```
move-ap
```

Example

```
ruckus(config-ap-policy)# move-ap
```

Configuring Controller Settings

Configure AP Policy Commands

```
ruckus (config-ap-policy-move-ap) #
```

move-ap

To move an AP to the specific Primary ZD/[Secondary ZD] address from within the config-ap-policy-move-ap context, use the following command:

```
move-ap <MAC | index range> <ADDR> [<ADDR>]
```

no move-ap

To remove the address settings of move-AP from the selected APs, use the following command:

```
no move-ap <MAC | index range>
```

no move-ap-group

To remove the AP Group Name settings of move-AP from the selected APs, use the following command:

```
no move-ap-group <MAC> | <index range>
```

move-ap-group

To move an AP to the specific ZD with AP Group Name, use the following command:

```
move-ap-group <MAC | index range> <AP-GROUP-NAME>
```

no move-ap-group

To remove the AP Group Name settings of move-AP from the selected APs, use the following command:

```
no move-ap-group <MAC> | <index range>
```

timeout

To configure recovering of the APs' original Primary/Secondary ZD address if the AP can't find the desired Primary/Secondary ZD after timeout(minutes), use the following command:

```
timeout <NUMBER>
```

Syntax Description

timeout	Enter the timeout value (minutes) for recovering APs' original primary/secondary ZD IP.
<NUMBER>	Timeout value in minutes.

Example

```
ruckus (config-ap-policy-move-ap) # timeout 60
```

```
Your changes have been saved.  
ruckus(config-ap-policy-move-ap) #
```

import-aplist

To import an AP list from backup files on a TFTP server, use the following command:

```
import-aplist <IP-ADDR> <FILE-NAME>
```

exit

Saves changes, and then exits the config-ap-policy-move-ap context.

abort

Exits the config-ap-policy-move-ap context without saving changes.

quit

Exits the config-ap-policy-move-ap context without saving changes.

show

Displays the AP policy settings.

Example

```
ruckus(config-ap-policy) # show  
Automatically approve all join requests from APs= Enabled  
Limited ZD Discovery:  
    Status= Disabled  
Management VLAN:  
    Status= Keep AP's setting  
Balances the number of clients across adjacent APs= Disabled  
Auto Recovery= 30 minutes  
ruckus(config-ap-policy) #
```

Configure AP Group Commands

This section describes the commands that you can use to configure AP groups on the controller. The following commands can be executed from within the config-apgrp context. To show a list of commands available from within the context, type help or ?.

Configuring Controller Settings

Configure AP Group Commands

ap-group

To create a new AP group or configure an existing AP group and enter the config-apgrp context, enter the following command:

```
ap-group <WORD>
```

Syntax Description

ap-group	Configure an AP group
<WORD>	Name of the AP group

Defaults

"System Default"

Example

```
ruckus(config)# ap-group "System Default"
```

The AP group entry 'System Default' has been loaded. To save the AP group, type 'end' or 'exit'.

```
ruckus(config-apgrp) #
```

no ap-group

To delete an AP group from the list, enter the following command:

```
no ap-group <WORD>
```

Syntax Description

no ap-group	Delete an AP group
<WORD>	Name of the AP group

Defaults

None

Example

```
ruckus(config)# no ap-group apgrp2
```

The AP Group 'apgrp2' has been removed.

```
ruckus(config) #
```

show

Displays current AP group configuration settings.

```
show
```

Defaults

None

Example

```
ruckus(config)# ap-group apgroup1
```

```
The AP group 'apgroup1' has been created. To save the AP group,  
type 'end' or 'exit'.  
ruckus(config-apgrp)# show  
APGROUP:  
    ID:  
    :  
        Name= apgroup1  
        Description=  
        Radio 11bgn:  
            Channelization= Auto  
            Channel= Auto  
            Enable auto channel selection which select from 1,6,11= Yes  
            Tx. Power= Auto  
            11N only Mode= Auto  
            WLAN Group= Default  
            Call Admission Control= OFF  
        Radio 11an:  
            Channelization= Auto  
            Channel= Auto  
            Tx. Power= Auto  
            11N only Mode= Auto  
            WLAN Group= Default  
            Call Admission Control= OFF  
    Members:  
ruckus(config-apgrp) #
```

description

To set the AP group description, use the following command:

```
description <WORD>
```

no description

To delete the AP group description, use the following command:

```
no description
```

ipmode

To set the IP addressing mode of the AP group, use the following command:

```
ipmode <WORD>
```

Syntax Description

ipmode	Set the IP addressing mode
--------	----------------------------

Configuring Controller Settings

Configure AP Group Commands

<WORD>	IPv4, IPv6 or dual
--------	--------------------

Example

```
ruckus(config-apgrp) # ipmode dual  
ruckus(config-apgrp) #
```

no ipmode-override

To disable the override of IP mode, use the following command:

```
no ipmode-override
```

Radio 2.4/5 GHz Commands

Use the `radio 2.4` or `radio 5` commands to configure the 2.4/5 GHz radios on all APs within an AP group.

radio

To configure radio settings for the 2.4 GHz or 5 GHz radios of an AP group, use the following command:

```
radio [2.4|5] <arguments>
```

Syntax Description

radio	Configure AP group radio settings
2.4	Configure 2.4 GHz radio
5	Configure 5 GHz radio
no	Disables settings for the specified radios in the AP group
channel	Set radio channel (Auto or number)
channelization	Set radio channel width (Auto, 20MHz or 40MHz)
auto-channel-selection [four-channel three-channel]	Set auto channel selection to four-channel (1,5,9,13) or three-channel (1,6,11)
tx-power	Set radio transmit power (Auto, Full, 1/2, 1/4, 1/8, Min) or <NUMBER> (-1dB~10dB)
11n-only	Set radio 11n-only mode to Auto or N-only
wlan-group	Set radio to the specified WLAN group
admission-control	Set the radio to use the specific call admission control airtime usage limit (%)

Defaults

Channel: Auto

Channelization: Auto
Auto-Channel Selection: Three-channel
TX Power: Auto
11n-only: Auto
WLAN group: Default
Admission Control: Off

Example

```
ruckus(config)# ap-group "System Default"
The AP group entry 'System Default' has been loaded. To save the
AP group, type 'end' or 'exit'.
ruckus(config-apgrp)# radio 2.4 channel auto
The command was executed successfully. To save the changes, type
'end' or 'exit'.
ruckus(config-apgrp)# radio 5 channelization auto
The command was executed successfully. To save the changes, type
'end' or 'exit'.
ruckus(config-apgrp)# radio 5 11n-only N-only
The command was executed successfully. To save the changes, type
'end' or 'exit'.
ruckus(config-apgrp)# radio 5 wlan-group Default
The command was executed successfully. To save the changes, type
'end' or 'exit'.
ruckus(config-apgrp)# radio 2.4 tx-power Num 1
The command was executed successfully. To save the changes, type
'end' or 'exit'.
ruckus(config-apgrp)# show
APGROUP:
ID:
1:
Name= System Default
Description= System default group for Access Points
Radio 11bgn:
Channelization= Auto
Channel= Auto
Enable auto channel selection which select from 1,6,11= Yes
Tx. Power= -1dB
11N only Mode= Auto
WLAN Group= Default
Radio 11an:
Channelization= Auto
Channel= Auto
Tx. Power= Auto
```

Configuring Controller Settings

Configure AP Group Commands

```
11N only Mode= N-only
WLAN Group= Default
Members:
MAC= 04:4f:aa:0c:b1:00
MAC= 00:24:82:3f:14:60
MAC= 74:91:1a:2b:ff:a0
MAC= 00:1f:41:2a:2b:10

ruckus(config-apgrp)# end
The AP group 'System Default' has been updated.
Your changes have been saved.
ruckus(config)#
```

radio 2.4 channel auto

Sets the 2.4GHz radio to use 'Auto' channel.

radio 2.4 channel number <NUMBER>

Sets the 2.4GHz radio to use the specified channel.

radio 2.4 channelization auto

Sets the 2.4GHz radio to use 'Auto' channelization.

radio 2.4 channelization number <NUMBER>

Sets the 2.4GHz radio to use the specified channelization.

radio 2.4 auto-channel-selection four-channel

Enables the auto channel selection which always select from 1,5,9,13.

radio 2.4 auto-channel-selection three-channel

Enables the auto channel selection which always select from 1,6,11.

radio 2.4 tx-power Auto

Sets the 2.4GHz radio to use 'Auto' Tx. power setting.

radio 2.4 tx-power Full

Sets the 2.4GHz radio to use the specified Tx. power setting.

radio 2.4 tx-power 1/2

Sets the 2.4GHz radio to use the specified Tx. power setting.

radio 2.4 tx-power 1/4

Sets the 2.4GHz radio to use the specified Tx. power setting.

radio 2.4 tx-power 1/8

Sets the 2.4GHz radio to use the specified Tx. power setting.

radio 2.4 tx-power Min

Sets the 2.4GHz radio to use the specified Tx. power setting.

radio 2.4 tx-power Num

Sets the 2.4GHz radio to use the specified Tx by number from 1-10 (-1dB ~ -10dB).

radio 2.4 11n-only Auto

Sets the 2.4GHz radio to use 'Auto' 11N only mode.

radio 2.4 11n-only N-only

Sets the 2.4GHz radio to use the specified 11N only mode.

radio 2.4 wlan-group <WORD>

Assigns the 2.4GHz radio to the specified WLAN group.

radio 2.4 admission-control <VALUE>

Sets the 2.4GHz radio to use the specific call admission control airtime usage limit(%).

radio 2.4 channel-range <NUMBER-LIST>

Sets the allowed list of channels used in 2.4GHz radio.

radio 5 indoor channel auto

Sets the 5GHz radio (indoor) to use 'Auto' channel.

radio 5 indoor channel number <NUMBER>

Sets the 5GHz radio (indoor) to use the specified channel.

radio 5 indoor channel-range <NUMBER-LIST>

Sets the allowed list of indoor channels used in 5GHz radio.

radio 5 outdoor channel auto

Sets the 5GHz radio (outdoor) to use 'Auto' channel.

radio 5 outdoor channel number <NUMBER>

Sets the 5GHz radio (outdoor) to use the specified channel.

radio 5 outdoor channel-range <NUMBER-LIST>

Sets the allowed list of outdoor channels used in 5GHz radio.

radio 5 channel auto

Sets the 5GHz radio to use 'Auto' channel.

radio 5 channel number <NUMBER>

Sets the 5GHz radio to use the specified channel.

radio 5 channelization auto

Sets the 5GHz radio to use 'Auto' channelization.

radio 5 channelization number <NUMBER>

Sets the 5GHz radio to use the specified channelization.

radio 5 tx-power Auto

Sets the 5GHz radio to use 'Auto' Tx. power setting.

radio 5 tx-power Full

Sets the 5GHz radio to use the specified Tx. power setting.

radio 5 tx-power 1/2

Sets the 5GHz radio to use the specified Tx. power setting.

radio 5 tx-power 1/4

Sets the 5GHz radio to use the specified Tx. power setting.

radio 5 tx-power 1/8

Sets the 5GHz radio to use the specified Tx. power setting.

radio 5 tx-power Min

Sets the 5GHz radio to use the specified Tx. power setting.

radio 5 tx-power Num

Sets the 5GHz radio to use the specified Tx by number from 1-10 (-1dB ~ -10dB).

radio 5 11n-only Auto

Sets the 5GHz radio to use 'Auto' 11N only mode.

radio 5 11n-only N-only

Sets the 5GHz radio to use the specified 11N only mode.

radio 5 wlan-group <WORD>

Assigns the 5GHz radio to the specified WLAN group.

radio 5 admission-control <VALUE>

Sets the 5GHz radio to use the specific call admission control airtime usage limit(%).

no radio 2.4 channelization-override

Disables the override of the 2.4GHz channelization settings.

no radio 2.4 channel-range-override

Disables the override of the 2.4GHz channel range settings.

no radio 2.4 channel-override

Disables the override of the 2.4GHz channel settings.

no radio 2.4 tx-power-override

Disables the override of the 2.4GHz Tx. power settings.

no radio 2.4 11n-only-override

Disables the override of the 2.4GHz 11N only mode settings.

no radio 2.4 wlan-group-override

Disables the override of the 2.4GHz WLAN group settings.

no radio 2.4 admission-control

Disables call admission control function on the 2.4GHz radio.

no radio 2.4 admission-control-override

Disables the override of the 2.4GHz call admission control settings.

no radio 5 indoor channel-range-override

Disables the override of the 5GHz indoor channel range settings.

no radio 5 indoor channel-override

Disables the override of the 5GHz indoor channel settings.

no radio 5 outdoor channel-range-override

Disables the override of the 5GHz outdoor channel range settings.

no radio 5 outdoor channel-override

Disables the override of the 5GHz outdoor channel settings.

no radio 5 channelization-override

Disables the override of the 5GHz channelization settings.

no radio 5 tx-power-override

Disables the override of the 5GHz Tx. power settings.

no radio 5 11n-only-override

Disables the override of the 5GHz 11N only mode settings.

no radio 5 wlan-group-override

Disables the override of the 5GHz WLAN group settings.

no radio 5 admission-control

Disables call admission control function on the 5GHz radio.

no radio 5 admission-control-override

Disables the override of the 5GHz call admission control settings.

QoS Commands

Use the following commands to configure QoS settings for the AP group.

qos

Contains commands that can be executed from within the context.

qos mld-query

Contains commands that can be executed from within the context.

qos mld-query v1

Enables the mld-query v1.

qos mld-query v2

Enables the mld-query v2.

qos igmp-query

Contains commands that can be executed from within the context.

qos igmp-query v2

Enables the igmp-query v2.

qos igmp-query v3

Enables the igmp-query v3.

qos query-interval

Sets the query interval to the specified value.

```
qos query-interval <VALUE>
```

no qos mld-query v1

Disables the mld-query v1.

Configuring Controller Settings

Configure AP Group Commands

no qos mld-query v2

Disables the mld-query v2.

no qos igmp-query v2

Disables the igmp-query v2.

no qos igmp-query v3

Disables the igmp-query v3.

Model-Specific Commands

The following commands are used to configure model-specific settings for all APs of a certain model within an AP group.

no model-setting

To discard the model settings for this specified model, use the following command:

```
no model-setting <WORD>
```

model

To configure model-specific settings for all APs of a certain model within an AP group, use the following command:

```
model <WORD> <arguments>
```

Syntax Description

model	Configure AP group model-specific settings
<WORD>	Enter the AP model name (e.g., zf2942, zf2741, zf7025, zf7341, zf7343, zf7363, zf7761cm, zf7762, zf7762-s, zf7762-t, zf7762-ac, zf7762-s-ac, zf7762-t-ac, zf7942, zf7962).
port-setting	Configures the port setting for the specified AP model. Enters config-apgrp-port context. See "Configure AP Group Model-Specific Port Settings" for more information.
status-leds	Configures the status LEDs for the specified AP model (enable, disable).
external-antenna	Configures external antenna settings. See "Configure AP Group Model-Specific Antenna Settings" .
spectra-analysis	Configures spectrum analysis per radio (2.4Ghz / 5GHz, enable / disable).

radio-band	Sets the radio band for the AP group (APs with radio band selection only).
max-clients <NUMBER>	Sets the maximum clients for the AP.
usb-software <VID-PID>	Selects the USB Software Vendor ID and Product ID for the AP.
poe-out	Configures the PoE Out ports for the specified AP model (enable, disable).
internal-heater	Configures the internal heater for the specified AP model (enable, disable).
cband-channels	Configures the C-band (5.8 GHz) channels for the specified AP model (enable, disable). (UK country code only)

Defaults	Status LEDs: Enabled PoE Out: Disabled Internal Heater: Disabled C-band channels: Disabled
-----------------	---

Example	ruckus(config-apgrp) # model zf7343 status-leds enable ruckus(config-apgrp) # end The AP group 'System Default' has been updated. Your changes have been saved. ruckus(config) #
----------------	--

no model override

To disable model-specific override of status LEDs, radio band, PoE-out, internal heater, C-band channels, external antennas and port settings, use the following command:

```
no model <WORD> <arguments>
```

Syntax Description	no model <WORD>	Disable AP group model-specific override settings Enter the AP model name (e.g., zf2741,zf2741-ext,zf2942,zf7025,zf7055,zf7321,zf7321-u,zf7341,zf7343,zf7352,zf7363,zf7372,zf7372-e,zf7351,zf7761cm,zf7762,zf7762-ac,zf7762-n,zf7762-s,zf7762-s-ac,zf7762-t,zf7781cm,zf7781cm-e,zf7781cm-s,zf7781fn,zf7781fn-e,zf7781fn-s,zf7781-m,zf7782,zf7782-e,zf7782-n,zf7782-s,zf7962,zf7982,sc8800-s,sc8800-s-ac).
---------------------------	--------------------	--

Configuring Controller Settings

Configure AP Group Commands

port-setting	Disables the override of the port settings for the specified AP model.
status-leds-override	Disables the override of the status LEDs for this specified AP model.
external-antenna-override	Disables the override of external antenna settings for this specified AP model.
radio-band-override	Disables the override of the radio band for this specified AP model.
usb-software-override	Disables the override of the USB software for this specified AP model.
poe-out-override	Disables the override of the PoE out port for this specified AP model.
internal-heater-override	Disables the override of the internal heater for this specified AP model.
cband-channels-override	Disables the override of the 5.8GHz channels for this specified AP model.

Example

```
ruckus(config-apgrp) # no model zf7363 status-leds-override
ruckus(config-apgrp) #
```

Configure AP Group Model-Specific Antenna Settings

Use the `model <WORD> external-antenna` commands from within the `config-apgrp` context to configure model-specific external antenna settings for all APs of the specified model within the AP group. The following commands are available from within this context.

external-antenna 2.4Ghz(11BG) enable	Enables the external antenna setting for the 2.4GHz(11BG) radio.
external-antenna 2.4Ghz(11BG) disable	Disables the external antenna setting for the 2.4GHz(11BG) radio.
external-antenna 2.4Ghz(11BG) gain	Sets the external antenna gain for the 2.4GHz(11BG) radio.
external-antenna 2.4Ghz(11BG) 2-antennas	Selects the two external antennas for the 2.4GHz(11BG) radio.
external-antenna 2.4Ghz(11BG) 3-antennas	Selects the three external antennas for the 2.4GHz(11BG) radio.

external-antenna 2.4Ghz (11NG) enable	Enables the external antenna setting for the 2.4GHz(11NG) radio.
external-antenna 2.4Ghz (11NG) disable	Disables the external antenna setting for the 2.4GHz(11NG) radio.
external-antenna 2.4Ghz (11NG) gain	Sets the external antenna gain for the 2.4GHz(11NG) radio.
external-antenna 2.4Ghz (11NG) 2- antennas	Selects the two external antennas for the 2.4GHz(11NG) radio.
external-antenna 2.4Ghz (11NG) 3- antennas	Selects the three external antennas for the 2.4GHz(11NG) radio.
external-antenna 5Ghz (11NA) enable	Enables the external antenna setting for the 5GHz(11NA) radio.
external-antenna 5Ghz (11NA) disable	Disables the external antenna setting for the 5GHz(11NA) radio.
external-antenna 5Ghz (11NA) gain	Sets the external antenna gain for the 5GHz(11NA) radio.
external-antenna 5Ghz (11NA) 2- antennas	Selects the two external antennas for the 2.4GHz(11NA) radio.
external-antenna 5Ghz (11NA) 3- antennas	Selects the three external antennas for the 2.4GHz(11NA) radio.
external-antenna 5Ghz (11A) enable	Enables the external antenna setting for the 5GHz(11A) radio.
external-antenna 5Ghz (11A) disable	Disables the external antenna setting for the 5GHz(11A) radio.
external-antenna 5Ghz (11A) gain	Sets the external antenna gain for the 5GHz(11A) radio.
external-antenna 5Ghz (11A) 2- antennas	Selects the two external antennas for the 2.4GHz(11A) radio.
external-antenna 5Ghz (11A) 3- antennas	Selects the three external antennas for the 2.4GHz(11A) radio.

Configuring Controller Settings

Configure AP Group Commands

Configure AP Group Model-Specific Port Settings

Use the `model <WORD> port-setting` command (from the `config-apgrp` context) to enter the `config-apgrp-port` context and configure model-specific port settings for all APs of the specified model within the AP group. The following commands are available from within this context.

<code>port-setting</code>	Enters the port-setting context.
<code>no port-setting</code>	Disables the override of the global AP mode configuration.
<code>help</code>	Shows available commands.
<code>history</code>	Shows a list of previously run commands.
<code>abort</code>	Exits the <code>config-apgrp-port</code> context without saving changes.
<code>end</code>	Saves changes, and then exits the <code>config-apgrp-port</code> context.
<code>exit</code>	Saves changes, and then exits the <code>config-apgrp-port</code> context.
<code>quit</code>	Exits the <code>config-apgrp-port</code> context without saving changes.
<code>show</code>	Displays <code>config-apgrp-port</code> context.
<code>lan <NUMBER></code>	Enables the AP Ethernet port.
<code>lan <NUMBER> uplink <WORD></code>	Sets the AP port to use the specified type (trunk, access or general).
<code>lan <NUMBER> untag <NUMBER></code>	Sets the AP port to use the specified VLAN ID(1-4094).
<code>lan <NUMBER> member <NUMBER></code>	Sets the AP port to use the specified members(1-4094).
<code>lan <NUMBER> opt82 enabled</code>	Enables the AP port DHCP option 82 settings.
<code>lan <NUMBER> opt82 disabled</code>	Disables the AP port DHCP option 82 settings.
<code>lan <NUMBER> dot1x disabled</code>	Disables the AP port 802.1X settings.
<code>lan <NUMBER> dot1x supplicant</code>	Sets the AP port to 802.1X supplicant.
<code>lan <NUMBER> dot1x auth-port-based</code>	Sets the AP port to port-based 802.1X.
<code>lan <NUMBER> dot1x auth-mac-based</code>	Sets the AP port to mac-based 802.1X.
<code>lan <NUMBER> guest-vlan <WORD></code>	Sets the AP port to use the specified guest VLAN ID(1-4094).

lan <NUMBER> dvlan	Enables the AP port dynamic VLAN settings.
enabled	
lan <NUMBER> dvlan	Disables the AP port dynamic VLAN settings.
disabled	
lan <NUMBER> qos mld-snooping	Enables the AP port MLD Snooping setting.
lan <NUMBER> qos igmp-snooping	Enables the AP port IGMP Snooping setting.
dot1x supplicant mac	Sets the username and password to use AP MAC address for AP 802.1X supplicant.
dot1x supplicant user-name <WORD>	Sets the username for AP 802.1X supplicant.
dot1x supplicant user-name <WORD> password <WORD>	Sets the password for AP 802.1X supplicant.
dot1x authsvr <WORD>	Sets the authentication server for AP 802.1X.
dot1x acctsvr <WORD>	Sets the accounting server for AP 802.1X.
dot1x mac-auth-bypass	Enables MAC authentication bypass (Use device MAC address as username and password).
no lan <NUMBER>	Disables the AP Ethernet port.
no dot1x authsvr	Disables the auth server settings.
no lan <NUMBER> qos mld-snooping	Disables the AP port MLD Snooping setting.
no lan <NUMBER> qos igmp-snooping	Disables the AP port IGMP snooping setting.
no dot1x authsvr	Disables the authentication server settings.
no dot1x acctsvr	Disables the accounting server settings.
no dot1x mac-auth-bypass	Disables the MAC authentication bypass.

Example

```
ruckus(config-apgrp) # model zf7321 port-setting
ruckus(config-apgrp-port) # show
PORTS:
  LAN ID:
    1:
      Enable LAN = Yes
      LAN Type= trunk
      Untag ID= 1
```

Configuring Controller Settings

Configure AP Group Commands

```
Members= 1-4094
Guest VLAN=
Enable Dynamic VLAN= Disabled
802.1X= disabled
DHCP opt82= Disabled
MLD Snooping= Disabled
IGMP Snooping= Enabled
ruckus(config-apgrp-port) #
```

AP Group Membership

Use the following commands to configure AP group membership (move APs into or out of the current AP group, from within the config-apgrp context).

member

Adds the AP to the specified AP group .

member add

Adds the AP to the specified AP group .

member add mac

To add the AP to the specified AP group, use the following command:

```
member add mac <WORD>
```

member mac

To move the AP to the specified AP group, use the following command:

```
member mac <WORD>
```

member mac move-to

To move the AP to the specified AP group, use the following command:

```
member mac <WORD> move-to
```

member mac move-to system-default

To move the AP to the System Default AP group, use the following command:

```
member mac <WORD> move-to system-default
```

member mac move-to name

To move the AP to the specified AP group, use the following command:

```
member mac <WORD> move-to name <WORD>
```

Model-Specific Port Settings

This section describes the commands that you can use to configure port settings for all APs of a specific model within an AP group. The following commands can be executed from within the config-apgrp-port context. To show a list of commands available from within the context, type help or ?.

model port-setting

To configure the port settings for all APs of a specific model within an AP group, and enter the config-apgrp-port context, use the following command:

```
model <WORD> port-setting
```

Syntax Description

model	Configure AP group model-specific settings
<WORD>	Enter the AP model name (e.g., zf2942, zf2741, zf7025, zf7341, zf7343, zf7363, zf7761cm, zf7762, zf7762-s, zf7762-t, zf7762-ac, zf7762-s-ac, zf7762-t-ac, zf7942, zf7962).
port-setting	Configures the port setting for the specified AP model. Enters config-apgrp-port context.

Example

```
ruckus(config)# ap-group "System Default"
```

The AP group entry 'System Default' has been loaded. To save the AP group, type 'end' or 'exit'.

```
ruckus(config-apgrp)# model zf7025 port-setting
ruckus(config-apgrp-port) #
```

abort

To exit the config-apgrp-port context without saving changes, use the following command:

```
abort
```

Syntax Description

abort	Exit the context without saving changes
-------	---

Defaults

None.

Configuring Controller Settings

Configure AP Group Commands

Example

```
ruckus(config-apgrp-port)# abort  
ruckus(config-apgrp)#
```

end

To save changes, and then exit the config-apgrp-port context, use the following command:

```
end
```

Syntax Description

end	Save changes, and then exit the context
-----	---

Defaults

None.

Example

```
ruckus(config-apgrp-port)# end  
ruckus(config-apgrp)#
```

exit

To save changes, and then exit the config-apgrp-port context, use the following command:

```
exit
```

Syntax Description

exit	Save changes, and then exit the context
------	---

Defaults

None.

Example

```
ruckus(config-apgrp-port)# exit  
ruckus(config-apgrp)#
```

quit

To exit the config-apgrp-port context without saving changes, use the following command:

```
quit
```

Syntax Description

quit	Exit the context without saving changes
------	---

Defaults None.

Example

```
ruckus(config-apgrp-port)# quit
ruckus(config-apgrp)#
```

show

To show a device's port state, use the following command:

```
show
```

Syntax Description

show	Display the device's port state
------	---------------------------------

Defaults None.

Example

```
ruckus(config-apgrp)# model zf7962 port-setting
ruckus(config-apgrp-port)# show
PORTS:
LAN ID:
1:
Enable LAN = Yes
LAN Type= trunk
Untag ID= 1
Members= 1-4094
802.1X= disabled
DHCP opt82= Disabled
LAN ID:
2:
Enable LAN = Yes
LAN Type= trunk
Untag ID= 1
Members= 1-4094
802.1X= disabled
DHCP opt82= Disabled
ruckus(config-apgrp-port) #
```

no lan

To disable a LAN port on APs in an AP group, use the following command:

```
no lan <NUMBER>
```

Configuring Controller Settings

Configure AP Group Commands

Syntax Description

no lan	Disable a specific port
<NUMBER>	Disable this port

Defaults

Enabled.

Example

```
ruckus(config-apgrp-port)# no lan 2  
ruckus(config-apgrp-port)#[/pre]
```

lan

To enable a LAN port on APs in an AP group, use the following command:

```
lan <NUMBER>
```

Syntax Description

lan	Enable a specific port
<NUMBER>	Enable this port

Defaults

Enabled.

Example

```
ruckus(config-apgrp-port)# lan 2  
ruckus(config-apgrp-port)#[/pre]
```

lan uplink

To set port type, use the following command:

```
lan <NUMBER> uplink <WORD>
```

Syntax Description

lan	Configure a specific port
<NUMBER>	Configure this port
uplink	Set the port type
<WORD>	Port type (Trunk port, Access port, General port)

Defaults

All AP ports other than ZF 7025: Trunk

ZF 7025 port 5: Trunk

ZF 7025 LAN 1-LAN 4: Access

Example

```
ruckus(config-apgrp)# model zf7962 port-setting
ruckus(config-apgrp-port)# lan 2 uplink access
ruckus(config-apgrp-port)# show
PORTS:
LAN ID:
1:
Enable LAN = Yes
LAN Type= trunk
Untag ID= 1
Members= 1-4094
802.1X= disabled
DHCP opt82= Disabled
LAN ID:
2:
Enable LAN = Yes
LAN Type= access
Untag ID= 1
Members= 1
802.1X= disabled
DHCP opt82= Disabled
ruckus(config-apgrp-port)#

```

lan untag

To configure untag VLAN settings for a model-specific port, use the following command:

```
lan <NUMBER> untag <NUMBER>
```

Syntax Description

lan untag	Configure port untag VLAN
<NUMBER>	Configure this port
<NUMBER>	Set untag VLAN to this number

Defaults

1

Example

```
ruckus(config-apgrp-port)# lan 2 untag 20
ruckus(config-apgrp-port)#

```

Configuring Controller Settings

Configure AP Group Commands

lan member

To set the LAN port VLAN membership (only General ports have configurable membership; Trunk ports are members of all VLANs, and Access port membership must be the same as the Untag VLAN), use the following command:

```
lan <NUMBER> member <NUMBER>
```

Syntax Description

lan member	Set the LAN port VLAN membership
<NUMBER>	Specify the LAN port to configure
<NUMBER>	Set the VLAN membership (1~4094, range separated by hyphen, multiple VLANs separated by commas)

Defaults

1

Example

```
ruckus(config-apgrp-port)# lan 2 uplink general
ruckus(config-apgrp-port)# lan 2 member 1-10,100,200
ruckus(config-apgrp-port)# show
PORTS:
LAN ID:
1:
Enable LAN = Yes
LAN Type= trunk
Untag ID= 1
Members= 1-4094
802.1X= disabled
DHCP opt82= Disabled
LAN ID:
2:
Enable LAN = Yes
LAN Type= general
Untag ID= 20
Members= 1-10,100,200
802.1X= disabled
DHCP opt82= Disabled
ruckus(config-apgrp-port) #
```

lan opt82

To enable or disable DHCP option 82 for a LAN port, use the following command:

```
lan <NUMBER> opt82 [enable|disable]
```

Syntax Description

lan opt82	Enable or disable DHCP option 82
enable	Enable option 82
disable	Disable option 82

Defaults

Disabled

Example

```
ruckus(config-apgrp-port)# lan 2 opt82 enable
ruckus(config-apgrp-port)#{
```

dot1x

To enable 802.1X on ports of all APs of a specific model in an AP group, use the following command:

```
model <WORD> dot1x
lan <NUMBER> dot1x [disable|supplicant|auth-port-based|auth-
mac-based|guest-vlan<NUMBER>|dvlan]
```

Syntax Description

lan dot1x	Configure 802.1X settings for this port
<NUMBER>	LAN port number to configure
disable	Disable 802.1X
supplicant	Configure this LAN port as an 802.1X supplicant
auth-port-based	Configure this LAN port as an 802.1X authenticator (port-based)
auth-mac-based	Configure this LAN port as an 802.1X authenticator (MAC-based)

Defaults

Disabled

Example

```
ruckus(config-apgrp)# model zf7025 port-setting
ruckus(config-apgrp-port)# lan 1 dot1x supplicant
ruckus(config-apgrp-port)# show
PORTS:
LAN ID:
1:
Enable LAN = Yes
LAN Type= access
Untag ID= 1
Members= 1
```

Configuring Controller Settings

Configure AP Group Commands

```
802.1X= supp
DHCP opt82= Disabled
```

dot1x authsvr

To configure 802.1X authentication server, use the following command:

```
dot1x authsvr <WORD>
```

Syntax Description

dot1x authsvr	Configure 802.1X authentication server
<WORD>	Name of AAA server

Defaults

None

Example

```
ruckus(config-apgrp-port)# dot1x authsvr radius
ruckus(config-apgrp-port) #
```

dot1x acctsvr

To configure 802.1X accounting server, use the following command:

```
dot1x acctsvr <WORD>
```

Syntax Description

dot1x acctsvr	Configure 802.1X accounting server
<WORD>	Name of AAA server

Defaults

None

Example

```
ruckus(config-apgrp-port)# dot1x acctsvr radius-acct
ruckus(config-apgrp-port) #
```

dot1x mac-auth-bypass

To configure 802.1X MAC authentication bypass, use the following command:

```
dot1x mac-auth-bypass
```

Syntax Description

dot1x mac-auth-bypass	Enable 802.1X MAC authentication bypass
-----------------------	---

Defaults Disabled

Example

```
ruckus(config-apgrp-port)# dot1x mac-auth-bypass
ruckus(config-apgrp-port)#+
```

dot1x supplicant username

To configure 802.1X supplicant user name, use the following command:

```
dot1x supplicant username <WORD>
```

Syntax Description

dot1x supplicant username	Configure 802.1X supplicant user name
<WORD>	Set the 802.1X supplicant user name

Defaults None

Example

```
ruckus(config-apgrp-port)# dot1x supplicant username johndoe
ruckus(config-apgrp-port)#+
```

dot1x supplicant password

To configure 802.1X supplicant password, use the following command:

```
dot1x supplicant password <WORD>
```

Syntax Description

dot1x supplicant password	Configure 802.1X supplicant password
<WORD>	Set the 802.1X supplicant password

Defaults None

Example

```
ruckus(config-apgrp-port)# dot1x supplicant password test123
ruckus(config-apgrp-port)#+
```

dot1x supplicant mac

To set the 802.1X supplicant user name and password as the AP's MAC address, use the following command:

```
dot1x supplicant mac
```

Configuring Controller Settings

Configure AP Group Commands

Syntax Description	dot1x supplicant mac	Set the supplicant user name and password as the AP's MAC address
Defaults	None	
Example	ruckus(config-apgrp-port)# dot1x supplicant mac ruckus(config-apgrp-port) #	

no dot1x

To disable 802.1X settings for an AP model, use the following command:

```
no dot1x [authsvr] [acctsvr] [mac-auth-bypass]
```

Syntax Description	no dot1x	Disable dot1x settings for the AP
	authsvr	Disable authentication server
	acctsvr	Disable accounting server
	mac-auth-bypass	Disable MAC authentication bypass
Defaults	None	

Example	ruckus(config-apgrp-port)# no dot1x authsvr ruckus(config-apgrp-port) #
----------------	--

lan guest-vlan

To set the AP port to use the specified guest VLAN ID(1-4094), use the following command:

```
lan <NUMBER> guest-vlan <WORD>
```

lan dvlan

To enable/disable dynamic VLAN for the AP port, use the following command:

```
lan <NUMBER> dvlan [enabled | disabled]
```

lan qos

To set the AP port QoS settings, use the following command:

```
lan <NUMBER> qos
```

lan qos mld-snooping

To enable MLD snooping for the port, use the following command:

```
lan <NUMBER> qos mld-snooping
```

lan qos igmp-snooping

To enable IGMP snooping for the port, use the following command:

```
lan <NUMBER> qos igmp-snooping
```

no lan qos

To disable QoS settings for the port, use the following command:

```
no lan <NUMBER> qos
```

no lan qos mld-snooping

To disable MLD snooping on the port, use the following command:

```
no lan <NUMBER> qos mld-snooping
```

no lan qos igmp-snooping

To disable IGMP snooping on the port, use the following command:

```
no lan <NUMBER> qos igmp-snooping
```

no dot1x

To disable 802.1x settings for the port, use the following command:

```
no dot1x
```

no dot1x authsvr

To disable the authentication server settings, use the following command

```
no dot1x authsvr
```

no dot1x acctsvr

To disable the accounting server settings, use the following command:

```
no dot1x acctsvr
```

no dot1x mac-auth-bypass

To disable MAC authentication bypass, use the following command:

```
no dot1x mac-auth-bypass
```

Configuring Controller Settings

Configure Certificate Commands

Configure Certificate Commands

Use the config-certificate commands to restore the default ZoneDirector certificate or to regenerate the private key. To run these commands, you must first enter the config-certificate context.

quit

To exit the config-certificate context without saving changes, use the **quit** command.

```
quit
```

Syntax Description

quit	Exit the certificate settings without saving changes
------	--

Defaults

None.

Example

```
ruckus(config-certificate)# quit
```

No changes have been saved.

restore

To restore the default ZoneDirector certificate and private key, use the following command.

```
restore
```

Syntax Description

restore	Restore the default ZoneDirector certificate and private key. The restore process will be completed after ZoneDirector is rebooted.
---------	---

Defaults

None.

Example

```
ruckus(config-certificate)# restore
```

ZoneDirector will restart now to apply the changes in the certificate settings. If you want to configure other settings, log in again after ZoneDirector has completed restarting.

re-generate-private-key

To regenerate the ZoneDirector private key, use the following command:

```
re-generate-private-key {1024|2048}
```

Syntax Description

re-generate-private-key	Regenerate the ZoneDirector private key
{1024 2048}	Specify the length of the private key as either 1024 or 2048.

Defaults

None.

Example

```
ruckus(config-certificate)# re-generate-private-key 1024  
ZoneDirector will restart now to apply the changes in the certificate  
settings. If you want to configure other settings, log in again  
after ZoneDirector has completed restarting.  
The operation doesn't execute successfully. Please try again.
```

Configure Hotspot Redirect Settings

To configure Hotspot redirect settings, use the following command:

hotspot_redirect_https

To enable Hotspot redirect, use the following command:

```
hotspot_redirect_https
```

Defaults

None.

Example

```
ruckus(config)# hotspot_redirect_https  
/bin/hotspot_redirect_https enable  
ruckus(config)#[/pre]
```

no hotspot_redirect_https

To disable Hotspot redirect, use the following command:

```
no hotspot_redirect_https
```

Defaults

None.

Example

```
ruckus(config)# no hotspot_redirect_https  
/bin/hotspot_redirect_https disable  
ruckus(config)#[/pre]
```

Configuring Controller Settings

Configure Hotspot Redirect Settings

no blocked-client

To remove a blocked client from the blocked clients list, use the following command:

```
no blocked-client <MAC>
```

Defaults

None.

Example

```
ruckus(config)# no blocked-client dc:2b:61:13:f7:72
```

```
The L2 ACL 'dc:2b:61:13:f7:72' has been deleted.
```

```
ruckus(config)#
```

Configure Layer 2 Access Control Commands

Use the `layer2 access control` commands to configure the Layer 2 Access Control List settings. To run these commands, you must first enter the `config-12acl` context.

To enter the `config-12acl` context, run this command:

```
ruckus# config  
ruckus(config)# 12acl L2ACL-policy  
ruckus(config-12acl-L2ACL-policy)#
```

abort

To exit the `config-12acl` context without saving changes, use the following command:

```
abort
```

Syntax Description	abort	Exit the config-12acl context without saving changes
---------------------------	-------	--

Defaults	None.
-----------------	-------

Example	<pre>ruckus(config-12-acl)# abort No changes have been saved. ruckus(config)#</pre>
----------------	--

end

To save changes, and then exit the `config-12acl` context, use the following command:

```
end
```

Syntax Description	end	Save changes and exit the config-12acl context
---------------------------	-----	--

Defaults	None.
-----------------	-------

Example	<pre>ruckus(config-12-acl)# end The L2 ACL entry has saved successfully. Your changes have been saved. ruckus(config)#</pre>
----------------	---

Configuring Controller Settings

Configure Layer 2 Access Control Commands

exit

To save changes, and then exit the config-l2acl context, use the following command:

```
exit
```

Syntax Description

exit	Save changes and exit the config-l2acl context
------	--

Defaults

None.

Example

```
ruckus(config-l2-acl)# exit  
The L2 ACL entry has saved successfully.  
Your changes have been saved.  
ruckus(config)#
```

quit

To exit the config-l2acl context without saving changes, use the following command:

```
quit
```

Syntax Description

quit	Exit the config-l2acl context without saving changes
------	--

Defaults

None.

Example

```
ruckus(config-l2-acl)# abort  
No changes have been saved.  
ruckus(config)#
```

show

To displays the L2 ACL settings, use the show command. You must run this command from within the config-l2acl context.

```
show
```

Syntax Description

show	Display the Layer 2 access control list settings
------	--

Defaults

None.

Example

```
ruckus(config-12-acl) # show
L2/MAC ACL:
ID:
3:
Name= test
Description=
Restriction: Deny only the stations listed below
Stations:
MAC Address= 00:01:02:34:44:55
MAC Address= 00:01:02:34:44:56
```

no acl

To delete an L2 ACL, use the following command:

```
no acl {ACL name}
```

Syntax Description

no acl	Delete an existing ACL
{ACL name}	Delete this ACL

Defaults

None.

Example

```
ruckus# config
ruckus(config)# no acl L2_ACL_NAME
The L2 ACL 'L2_ACL_NAME' has been deleted.
```

acl

To create a new L2 ACL entry or update an existing entry, use the following command:

```
acl {ACL name}
```

Syntax Description

acl	Create a new ACL
{ACL name}	Assign this name to the new ACL

Defaults

None.

Example

```
ruckus# config
ruckus(config)# 12acl L2_ACL_NAME
The L2 ACL entry 'L2_ACL_NAME' has been created.
ruckus(config-12acl-L2_ACL_NAME) #
```

Configuring Controller Settings

Configure Layer 2 Access Control Commands

name

To rename an L2 ACL entry, use the following command:

```
name <WORD>
```

Syntax Description

name	Sets the L2 ACL entry name.
<WORD>	Rename the ACL to this name.

Defaults

None.

Example

```
ruckus# config
ruckus(config)# 12acl L2_ACL_NAME
The L2 ACL entry 'L2_ACL_NAME' has been created.
ruckus(config-12acl-L2_ACL_NAME)# name L2_ACL_New_Name
The command was executed successfully.
```

description

To set the description of an L2 ACL entry, use the following command:

```
description <WORD>
```

Syntax Description

description <WORD>	Set the L2 ACL description.
--------------------	-----------------------------

Defaults

None.

Example

```
ruckus# config
ruckus(config)# 12acl L2_ACL_NAME
The L2 ACL entry 'L2_ACL_NAME' has been created.
ruckus(config-12acl-L2_ACL_NAME)# description Description-123
The command was executed successfully.
```

add-mac

To add a MAC address to the L2 ACL, use the following command:

```
add-mac <MAC>
```

Syntax Description

add mac	Add a MAC address to the ACL
<MAC>	Add this MAC address

Defaults	None.
Example	<pre>ruckus# config ruckus(config)# 12acl L2_ACL_NAME The L2 ACL entry 'L2_ACL_NAME' has been created. ruckus(config-12acl-L2_ACL_NAME)# add mac 00:11:22:33:44:55 The station '00:11:22:33:44:55' has been added to the ACL. ruckus(config-12acl-L2_ACL_NAME) #</pre>

mode allow

To set the ACL mode to 'allow', use the following command:

```
mode allow
```

Syntax Description	mode allow Set the ACL mode to allow
Defaults	None.
Example	<pre>ruckus# config ruckus(config)# 12acl L2_ACL_NAME The L2 ACL entry 'L2_ACL_NAME' has been created. ruckus(config-12acl-L2_ACL_NAME)# mode allow The command was executed successfully.</pre>
Syntax Description	mode allow Set the ACL mode to deny
Defaults	None.
Example	<pre>ruckus# config ruckus(config)# 12acl L2_ACL_NAME The L2 ACL entry 'L2_ACL_NAME' has been created. ruckus(config-12acl-L2_ACL_NAME)# mode deny The command was executed successfully.</pre>

Configuring Controller Settings

Configure Layer 2 Access Control Commands

del-mac

To delete a MAC address from an L2 ACL, use the following command:

```
del-mac <MAC>
```

Syntax Description

del-mac	Delete a MAC address from the ACL
<MAC>	Delete this <MAC>

Defaults

None.

Example

```
ruckus(config-l2-acl)# del-mac 00:01:02:34:44:55
The station '00:01:02:34:44:55' has been removed from the ACL.
ruckus(config-l2-acl)# del-mac 00:01:02:34:44:55
The station '00:01:02:34:44:55' could not be found. Please check
the spelling, and then try again.
```

Configure Layer 3 Access Control Commands

Use the `l3acl` commands to configure the Layer 3 Access Control List settings. To run these commands, you must first enter the `config-l3acl` or `config-l3acl-ipv6` context.

l3acl

To enter the `config-l3acl` context, run this command:

```
l3acl <WORD>
```

Syntax Description

<code>l3acl</code>	Create or configure a Layer 3 Access Control List
<code><WORD></code>	Name of the L3 ACL

Defaults

None.

Example

```
ruckus(config)# l3acl "ACL 1"  
The L3/L4/IP ACL entry 'ACL 1' has been created.  
ruckus(config-l3acl) #
```

l3acl-ipv6

To enter the `config-l3acl-ipv6` context, run this command:

```
l3acl-ipv6 <WORD>
```

Syntax Description

<code>l3acl-ipv6</code>	Create or configure a Layer 3 Access Control List
<code><WORD></code>	Name of the L3 ACL

Defaults

None.

Example

```
ruckus(config)# l3acl-ipv6 "ACL 2"  
The L3/L4/IPv6 ACL entry 'ACL 2' has been created.  
ruckus(config-l3acl-ipv6) #
```

no l3acl

To delete an L3/L4 ACL entry, use the following command:

```
no l3acl <WORD>
```

Configuring Controller Settings

Configure Layer 3 Access Control Commands

Syntax Description

no l3acl	Delete a Layer 3 ACL
<WORD>	Name of the L3 ACL

Defaults

None.

Example

```
ruckus(config)# no l3acl "ACL test"  
The L3/L4/IP ACL 'ACL test' has been deleted.  
ruckus(config)#[/pre>
```

abort

To exit the config-l3acl context without saving changes, use the following command:

```
abort
```

Syntax Description

abort	Exit the context without saving changes
-------	---

Defaults

None.

Example

```
ruckus(config-l3acl)# abort  
No changes have been saved.  
ruckus(config)#[/pre>
```

end

To save changes, and then exit the config-l3acl context, use the following command:

```
end
```

Syntax Description

end	Save changes and exit the context
-----	-----------------------------------

Defaults

None.

Example

```
ruckus(config-l3acl)# end  
The L3/L4/IP ACL entry has saved successfully.  
Your changes have been saved.  
ruckus(config)#[/pre>
```

exit

To save changes, and then exit the config-l3acl context, use the following command:

```
exit
```

Syntax Description

exit	Save changes and exit the context
------	-----------------------------------

Defaults

None.

Example

```
ruckus# config-l3acl
ruckus(config-l3acl)# exit
Your changes have been saved.
```

quit

To exit the config-l3acl context without saving changes, use the following command:

```
quit
```

Syntax Description

quit	Exit the context without saving changes
------	---

Defaults

None.

Example

```
ruckus(config-l3acl)# quit
No changes have been saved.
ruckus(config)#
```

show

To display the L3ACL settings, use the show command. You must run this command from within the config-l3acl context.

```
show
```

Syntax Description

show	Display the Layer 3 access control list settings
------	--

Defaults

None.

Example

```
ruckus(config-l3acl)# show
L3/L4/IP ACL:
```

Configuring Controller Settings

Configure Layer 3 Access Control Commands

```
ID:  
3:  
Name= test_newname  
Description= justfortestCLI  
Default Action if no rule is matched= Deny all by default  
Rules:  
Order= 1  
Description=  
Type= Allow  
Destination Address= Any  
Destination Port= 53  
Protocol= Any  
Order= 2  
Description=  
Type= Allow  
Destination Address= Any  
Destination Port= 67  
Protocol= Any
```

name

To set the name of an L3/L4/IP ACL entry, use the following command:

```
name <WORD>
```

Syntax Description

name	Set the name of an L3/L4/IP ACL entry
<WORD>	Name of the L3/L4/IP ACL entry

Defaults

None.

Example

```
ruckus(config-l3acl)# name test_newname
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

description

To set the description of an L3/L4/IP ACL entry, use the following command:

```
description <WORD>
```

Syntax Description

description	Set the L3/L4/IP ACL entry description
<WORD>	Set to this description

Defaults None.

Example

```
ruckus(config-l3acl)# description justfortestCLI
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

mode allow

To set the ACL mode to 'allow', use the following command:

```
mode allow
```

Syntax Description

mode	Set the ACL mode
allow	Set the mode to 'allow'

Defaults None.

Example

```
ruckus(config-l3acl)# mode allow
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

mode deny

To set the ACL mode to 'deny', use the following command:

```
mode deny
```

Syntax Description

mode	Set the ACL mode
deny	Set the mode to 'deny'

Defaults None.

Example

```
ruckus(config-l3acl)# mode deny
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

no rule-order

To delete a rule from the L3/L4/IP ACL, use the following command:

```
no rule-order <NUMBER>
```

Configuring Controller Settings

Configure Layer 3 Access Control Commands

Syntax Description

no rule-order	Delete a rule from the L3/L4/IP ACL
<NUMBER>	Delete this rule ID

Defaults

None.

Example

```
ruckus(config-l3acl)# no rule-order 3  
The rule '3' has been removed from the ACL.
```

rule-order

To create or modify a rule in the L3/L4/IP ACL, use the following command:

```
rule-order <NUMBER>
```

Syntax Description

rule-order	Create a new rule or modify an existing one
<NUMBER>	Create or modify this rule ID

Defaults

None.

Example

For example, to set the current rule as the third ACL rule to apply, use the following command:

```
ruckus(config-l3acl)# rule-order 3  
ruckus(config-l3acl-rule)#
```

Layer 3 Access Control Rule Commands

Use the l3acl-rule commands to configure the Layer 3/Layer 4/IP Access Control List rules. To run these commands, you must first enter the config-l3acl-rule context. To enter the config-l3acl-rule context, run this command:

```
rule-order <NUMBER>
```

end

To save changes, and then exit the config-l3acl-rule context, use the following command:

```
end
```

Syntax Description

end	Save changes, and then exit the context
-----	---

Defaults

None.

Example	ruckus(config-l3acl-rule)# end ruckus(config-l3acl)#
----------------	--

exit

To save changes, and then exit the config-l3acl-rule context, use the following command:

```
exit
```

Syntax Description	exit	Save changes, and then exit the context
---------------------------	------	---

Defaults	None.
-----------------	-------

Example	ruckus(config-l3acl-rule)# exit ruckus(config-l3acl)#
----------------	---

order

To set the L3/L4/IP ACL rule order, use the following command:

```
order <NUMBER>
```

Example	ruckus(config-l3acl-rule)# order 1 The command was executed successfully. To save the changes, type 'end' or 'exit'. ruckus(config-l3acl-rule) #
----------------	--

description

To set the description of an L3/L4/IP ACL rule, use the following command:

```
description <WORD>
```

Syntax Description	description	Set the L3/L4/IP ACL rule description
	<WORD>	Set to this description

Defaults	None.
-----------------	-------

Example	ruckus(config-l3acl-rule)# description thirdl3rule
----------------	---

Configuring Controller Settings

Configure Layer 3 Access Control Commands

The command was executed successfully. To save the changes, type 'end' or 'exit'.

type allow

To set the ACL rule type to 'allow', use the following command:

```
type allow
```

Syntax Description

type	Set the ACL rule type
allow	Set the rule type to 'allow'

Defaults

None.

Example

```
ruckus(config-l3acl-rule)# type allow
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

type deny

To set the ACL rule type to 'deny', use the following command:

```
type deny
```

Syntax Description

type	Set the ACL rule type
deny	Set the rule type to 'deny'

Defaults

None.

Example

```
ruckus(config-l3acl-rule)# type deny
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

destination address

To set the destination address of the rule, use the following command:

```
destination address <IP-ADDR/WORD>
```

Syntax Description

destination address	Set the destination address of the rule
IP-ADDR/WORD	Set the destination to this IP address

Defaults	None.
Example	<pre>ruckus(config-l3acl-rule)# destination address 192.168.1.22</pre> <p>The destination IP address is invalid. Please enter 'Any' or check the IP address(for example:192.168.0.1/24), and then please try again.</p> <pre>ruckus(config-l3acl-rule)# destination address 192.168.1.22/24</pre> <p>The command was executed successfully. To save the changes, type 'end' or 'exit'.</p>

destination port

To set the destination port of the rule, use the following command:

destination port <NUMBER/WORD>

Syntax Description	destination port	Set the destination port of the rule
	<NUMBER/WORD>	Set the destination to this port number

Defaults	None.
Example	ruckus(config-l3acl-rule)# destination port 580 The command was executed successfully. To save the changes, type ctrl-Z and hit Enter.

protocol

To set the protocol for the rule, use the following command:

protocol <NUMBER/WORD>

Syntax Description	Protocol	Description
protocol		Set the protocol for the rule
<NUMBER/WORD>		Set to this protocol

Defaults	None.
Example	<pre>ruckus(config-13acl-rule)# protocol tcp The protocol must be a number between 0 and 254. ruckus(config-13acl-rule)# protocol Any The command was executed successfully. To save the changes, type 'end' or 'exit'.</pre>

Configuring Controller Settings

Configure Layer 3 Access Control Commands

show

To display L3/L4/IP ACL settings, use the following command:

```
show
```

Layer 3 IPv6 Access Control List Commands

Use the `l3acl-ipv6` command to configure the IPv6 Layer 3/Layer 4/IP Access Control List. To run these commands, you must first enter the `config-l3acl` context.

l3acl-ipv6

To enter the `config-l3acl-ipv6` context, run this command:

```
l3acl-ipv6 <NUMBER>
```

abort

Exits the `config-l3acl-ipv6` context without saving changes.

end

Saves changes, and then exits the `config-l3acl-ipv6` context.

exit

Saves changes, and then exits the `config-l3acl-ipv6` context.

quit

Exits the `config-l3acl-ipv6` context without saving changes.

name

Sets the L3/L4/IPv6 ACL entry name.

description

Sets the L3/L4/IPv6 ACL entry description.

mode allow

Sets the ACL mode to 'allow'.

mode deny

Sets the ACL mode to 'deny'.

no rule-order

Deletes a rule name from the L3/L4/IPv6 ACL.

rule-order

Creates a new L3/L4/IPv6 ACL rule or modifies an existing entry rule.

Configure L3 IPv6 Rule Commands

Use the `l3acl-ipv6-rule` commands to configure the IPv6 Layer 3/Layer 4/IP Access Control List rules. To run these commands, you must first enter the `config-l3acl-ipv6-rule` context. To enter the `config-l3acl-ipv6-rule` context, run this command:

```
rule-order <NUMBER>
```

end

Saves changes, and then exits the `config-l3acl-ipv6-rule` context.

exit

Saves changes, and then exits the `config-l3acl-ipv6-rule` context.

order

Sets the L3/L4/IPv6 ACL rule order.

description

Sets the L3/L4/IPv6 ACL rule description.

type allow

Sets the ACL rule type to 'allow'.

type deny

Sets the ACL rule type to 'deny'.

Configuring Controller Settings

Configure Precedence Policy Commands

destination

Contains commands that can be executed from within the context.

destination address

Sets the destination address of a L3/L4/IPv6 ACL rule.

destination port

Sets the destination port of a L3/L4/IPv6 ACL rule.

protocol

Sets the protocol of a L3/L4/IPv6 ACL rule.

icmpv6-type Any

Sets the icmpv6 type of a L3/L4/IPv6 ACL rule.

icmpv6-type number

Sets the icmpv6 type of a L3/L4/IPv6 ACL rule.

show

Displays L3/L4/IPv6 ACL settings.

Configure Precedence Policy Commands

Use the `prece` commands to configure precedence policy settings. Precedence policies are used to define the order in which VLAN and rate limiting policies are applied when the WLAN settings, AAA server configuration or Device Policy settings conflict.

To run these commands, you must first enter the `config-prece` context.

prece

To create or modify a precedence policy, use the following command:

```
prece <WORD>
```

Enters the `config-prece` context. To save changes and exit the context, type `exit` or `end`. To exit the context without saving changes, type `abort`.

Example

```
ruckus (config) # prece precedence1
```

The Precedence Policy entry 'precedence1' has been created.
ruckus(config-prece)#

name

Sets the Precedence Policy entry name.

description

Sets the Precedence Policy entry description.

Configure Precedence Policy Rule Commands

Use the following commands to configure precedence policy rules.

rule

Creates a new Precedence Policy rule or modifies an existing entry rule. Enters the config-prece-rule context.

```
rule <NUMBER>
```

Syntax Description

rule	Create a rule and enter the rule creation context.
<NUMBER>	Enter the rule number (1-2). Each precedence policy can have up to two rules.
description	Sets the Precedence Policy rule description.
order <WORD>	Sets the order of a Precedence Policy rule. The default order is AAA, Device Policy, WLAN.
show	Displays precedence policy settings.

Example

```
ruckus(config)# prece precedence1
The Precedence Policy entry 'precedence1' has been created.
ruckus(config-prece)# rule 1
ruckus(config-prece-rule)# order "Device Policy" "WLAN" "AAA"
The command was executed successfully. To save the changes, type
/end' or 'exit'.
ruckus(config-prece-rule)# end
ruckus(config-prece)# show
Precedence Policy:
  ID:
  :
  Name= precedence1
  Description=
```

Configuring Controller Settings

Configure Device Policy Commands

```
Rules:  
1:  
    Description=  
    Attribute = vlan  
    Order = Device Policy,WLAN,AAA  
2:  
    Description=  
    Attribute = rate-limit  
    Order = AAA,Device Policy,WLAN  
  
ruckus(config-prece) #  
ruckus(config-prece) # end  
The Precedence Policy entry has saved successfully.  
Your changes have been saved.
```

no prece

To delete a precedence policy entry, use the following command:

```
no prece <WORD>
```

Configure Device Policy Commands

Use the device policy commands to configure access control and rate limiting policies based on client type. To run these commands, you must first enter the `config-dvc-pcy` context.

dvcpcy

To create a device policy or edit an existing device policy, enter the following command:

```
dvcpcy <WORD>
```

Syntax Description

show	Display device policy settings.
name <WORD>	Set the device policy entry name.
description <WORD>	Sets the device policy entry description.
mode <WORD>	Sets the device policy entry default mode (allow or deny).
no <NUMBER>	Delete a rule.
rule <NUMBER>	Create or modify a rule. Enter the <code>config-dvc-pcy</code> rule context. You can create up to nine rules per access policy (one for each OS/Type).

Defaults	None.
Example	<pre>ruckus(config)# dvcpcy devpcy1 The Device Policy entry 'devpcy1' has been loaded. To save the Device Policy entry, type end or exit. ruckus(config-dvc-pcy)# name device_policy_1 The command was executed successfully. To save the changes, type 'end' or 'exit'. ruckus(config-dvc-pcy)# description "deny ios" The command was executed successfully. To save the changes, type 'end' or 'exit'. ruckus(config-dvc-pcy)# rule 1 ruckus(config-dvc-pcy-rule)# type deny The command was executed successfully. To save the changes, type 'end' or 'exit'. ruckus(config-dvc-pcy-rule)# devinfo "Apple IOS" The command was executed successfully. To save the changes, type 'end' or 'exit'. ruckus(config-dvc-pcy-rule)# vlan none The command was executed successfully. To save the changes, type 'end' or 'exit'. ruckus(config-dvc-pcy-rule)# rate-limit uplink 10 downlink 10 The command was executed successfully. To save the changes, type 'end' or 'exit'. ruckus(config-dvc-pcy-rule)# end ruckus(config-dvc-pcy)# show Device Policy: ID: 1: Name= device_policy_1 Description= deny ios Default Mode= deny Rules: 1: Description= OS/Type = Apple ios Type= deny VLAN = Any Rate Limiting Uplink = 10.00Mbps Rate Limiting Downlink = 10.00Mbps ruckus(config-dvc-pcy)# end</pre>

Configuring Controller Settings

Configure Device Policy Commands

```
The Device Policy entry has saved successfully.
```

```
Your changes have been saved.
```

```
ruckus(config)# show dvcpcy
```

```
Device Policy:
```

```
  ID:
```

```
    2:
```

```
      Name= device_policy_1
```

```
      Description= deny iOS
```

```
      Default Mode= deny
```

```
      Rules:
```

```
        1:
```

```
          Description=
```

```
          OS/Type = Apple iOS
```

```
          Type= deny
```

```
          VLAN = Any
```

```
          Rate Limiting Uplink = 10.00Mbps
```

```
          Rate Limiting Downlink = 10.00Mbps
```

```
ruckus(config)#
```

rule

Use the rule command from within the config-dvc-pcy context to create or edit a device policy rule and enter the config-dvc-pcy-rule context. Up to 9 rules can be created per device policy.

Syntax Description

rule	Create or edit a device policy rule. Enter the config-dvc-pcy-rule context.
description <WORD>	Set the Device Policy rule description.
devinfo <WORD>	Set the operating system type of a device policy rule.
type <WORD>	Set the device policy rule type (allow or deny).
vlan <NUMBER>	Set the VLAN ID to the number specified or "none."
rate-limit uplink <NUMBER> downlink <NUMBER>	Set the rate limiting uplink and downlink speeds in mbps (valid values are 0.10, 0.20~20 in increments of 0.25 mbps).
no rate-limit	Set rate limiting to disabled.

Example

```
ruckus(config-dvc-pcy) # rule 2
ruckus(config-dvc-pcy-rule) # description "rate limit gaming devices"
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-dvc-pcy-rule) # devinfo "Gaming"
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-dvc-pcy-rule) # type allow
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-dvc-pcy-rule) # vlan none
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-dvc-pcy-rule) # rate-limit uplink 0.1 downlink 0.1
The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-dvc-pcy-rule) # end
ruckus(config-dvc-pcy) # show
Device Policy:
ID:
2:
  Name= device_policy_1
  Description= deny iOS
  Default Mode= deny
  Rules:
    1:
      Description=
      OS/Type = Apple iOS
      Type= deny
      VLAN = Any
      Rate Limiting Uplink = 10.00Mbps
      Rate Limiting Downlink = 10.00Mbps
    2:
      Description= rate limit gaming devices
      OS/Type = Gaming
      Type= allow
      VLAN = Any
      Rate Limiting Uplink = 0.10Mbps
      Rate Limiting Downlink = 0.10Mbps
```

Configuring Controller Settings

Configure Load Balancing Commands

```
ruckus (config-dvc-pcy) #
```

no dvcpcy

To delete a device policy, use the following command:

```
no dvcpcy <WORD>
```

Configure Load Balancing Commands

Use the load-balancing commands to configure the controller's load balancing settings. To run these commands, you must first enter the config-load-balancing context.

load-balancing

To enable load-balancing and enter the config-load-balancing context, use the following command:

```
load-balancing
```

Example

```
ruckus (config) # load-balancing  
ruckus (config-load-balancing) #
```

abort

To exit the config-load-balancing context without saving changes, use the abort command.

```
abort
```

Syntax Description

abort	Exit the service settings without saving changes
-------	--

Defaults

None.

end

To save changes, and then exit the config-load-balancing context, use the following command:

```
end
```

Syntax Description

end	Save changes, and then exit the context
-----	---

Defaults	None.
-----------------	-------

exit

To save changes, and then exit the config-load-balancing context, use the following command:

```
exit
```

Syntax Description

exit	Save changes, and then exit the context
------	---

Defaults

None.

quit

To exit the config-load-balancing context without saving changes, use the **quit** command.

```
quit
```

Syntax Description

quit	Exit the context without saving changes
------	---

Defaults

None.

adj-threshold

To configure the adjacent threshold for load balancing, use the following command:

```
adj-threshold [wifi0|wifi1] <NUMBER>
```

Syntax Description

adj-threshold	Configure the adjacent threshold for load balancing
wifi0, wifi1	Configure this interface
<NUMBER>	Set the adjacent threshold value (1~100)

Defaults

Wifi0: 38

Wifi1: 50

weak-bypass

To configure the weak bypass for load balancing, use the following command:

```
weak-bypass [wifi0|wifi1] <NUMBER>
```

Configuring Controller Settings

Configure Load Balancing Commands

Syntax Description

weak-bypass	Configure the weak bypass for load balancing
wifi0, wifi1	Configure this interface
<NUMBER>	Set the weak-bypass value (1~100)

Defaults

20

strong-bypass

To configure the strong bypass for load balancing, use the following command:

```
strong-bypass [wifi0|wifi1] <NUMBER>
```

Syntax Description

strong-bypass	Configure the strong bypass for load balancing
wifi0, wifi1	Configure this interface
<NUMBER>	Set the strong-bypass value (1~100)

Defaults

50

act-threshold

To configure the activation threshold for load balancing, use the following command:

```
act-threshold [wifi0|wifi1] <NUMBER>
```

Syntax Description

act-threshold	Configure the activation threshold for load balancing.
wifi0, wifi1	Configure this interface.
<NUMBER>	Set the activation threshold value (1~100).

Example

```
ruckus(config-load-balancing) # act-threshold wifi0 50
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-load-balancing) #
```

new-trigger

To configure new trigger threshold (1-100), use the following command:

```
new-trigger [wifi0|wifi1] <NUMBER>
```

Syntax Description

new-trigger	Configure a new trigger threshold for the specified interface.
wifi0, wifi1	Configure this interface.
<NUMBER>	Set the new trigger threshold value (1~100).

Example

ruckus(config-load-balancing) # **new-trigger wifi0 3**

The command was executed successfully. To save the changes, type 'end' or 'exit'.

ruckus(config-load-balancing) #

headroom

To configure headroom settings for the specified interface, use the following command:

headroom [wifi0|wifi1] <NUMBER>

Syntax Description

headroom	Configure headroom for the specified interface.
wifi0, wifi1	Configure this interface.
<NUMBER>	Set the headroom value (1~100).

Example

ruckus(config-load-balancing) # **headroom wifi0 3**

The command was executed successfully. To save the changes, type 'end' or 'exit'.

ruckus(config-load-balancing) #

show

To display the current service settings, use the following command:

show

Syntax Description

show	Display the current service settings
------	--------------------------------------

Defaults

None.

Example

ruckus(config-load-balancing) # **show**

Load Balancing:

Status= Disabled

Radio:

0:

Configuring Controller Settings

Configure STP Commands

```
AdjacentThreshold= 50
WeakBypass= 33
StrongBypass= 55
ActivationThreshold= 1
NewTrigger= 3
Headroom= 3

1:
AdjacentThreshold= 43
WeakBypass= 35
StrongBypass= 55
ActivationThreshold= 10
NewTrigger= 3
Headroom= 3

ruckus(config-load-balancing) #
```

no load-balancing

To disable load balancing settings, use the following command:

```
no load-balancing
```

Configure STP Commands

stp

To enable Spanning Tree Protocol, use the following command:

```
stp
```

no stp

To disable Spanning Tree Protocol, use the following:

```
no stp
```

Configure System Commands

Use the `sys` or `system` command to configure the controller's system settings, including its host name, FlexMaster server, NTP server, SNMP, and QoS settings. To run these commands, you must first enter the `config-sys` context.

system

To enter the `config-sys` context and configure system settings, use the following command:

```
system
```

Example

```
ruckus(config)# system
ruckus(config-sys) #
```

dot11-country-code

To set the controller's country code, use the following command:

```
dot11-country-code <COUNTRY-CODE>
```

Syntax Description

dot11-country- code	Configure the controller's country code setting
<COUNTRY-CODE>	Set the country code to this value

Defaults

None.

Example

To set the country code to US, enter the following command:

```
ruckus# config
ruckus(config)# system
ruckus(config-sys)# dot11-country-code US
The country code settings have been updated.
ruckus(config-sys) #
```

hostname

To set the system hostname, use the following command:

```
hostname
```

Syntax Description

hostname	Set the controller's system hostname
----------	--------------------------------------

Configuring Controller Settings

Configure System Commands

Defaults None

Example ruckus(config-sys)# **hostname ruckus-xjoe**

The system identity/hostname settings have been updated.

Interface Commands

Use the **interface** commands to configure the controller's IP address and VLAN settings. To run these commands, you must first enter the **config-sys-if** context.

interface

To enter the **config-sys-if** context and configure IP address and VLAN settings, use the following command:

```
interface
```

Example ruckus(config-sys)# **interface**

```
rukus(config-sys-if) #
```

ip enable

To enable IPv4 addressing, use the following command:

```
ip enable
```

ip route gateway

To set the controller's gateway IP address, use the following command:

```
ip route gateway <GATEWAY-ADDR>
```

Syntax Description

ip route gateway	Configure the controller's gateway IP address
<GATEWAY-ADDR>	Set the controller' gateway IP address to this value

Defaults None.

Example ruckus# **config**

```
rukus(config)# system
```

```
rukus(config-sys)# interface
```

```
rukus(config-sys-if)# ip route gateway 192.168.0.1
```

The command was executed successfully.

ip name-server

To set the controller's DNS servers, use the ip name-server command. Use a space to separate the primary and secondary DNS servers.

```
ip name-server <DNS-ADDR> [<DNS-ADDR>]
```

Syntax Description

ip name-server	Configure the controller's DNS server address or addresses
DNS-ADDR	Set the DNS server address to this value. If entering primary and secondary DNS server addresses, use a space to separate the two addresses.

Defaults

None.

Example

```
ruckus# config
ruckus(config)# system
ruckus(config-sys)# interface
ruckus(config-sys-if)# ip name-server 192.168.0.1
The command was executed successfully.
```

ip addr

To set the controller's IP address and netmask, use the following command:

```
ip addr <IP-ADDR> <NET-MASK>
```

Use a space to separate the IP address and netmask.

Syntax Description

ip addr	Configure the controller's IP address and netmask
<IP-ADDR>	Set the controller's IP address to this value
<NET-MASK>	Set the controller's netmask to this value

Defaults

None.

Example

```
ruckus# config
ruckus(config)# system
ruckus(config-sys)# interface
ruckus(config-sys-if)# ip addr 192.168.0.1 255.255.255.0
The command was executed successfully.
```

ip mode

To set the controller's IP address mode, use the following command:

Configuring Controller Settings

Configure System Commands

```
ip mode <dhcp|static>
```

Syntax Description

ip mode	Configure the controller's IP address mode
dhcp	Set the controller's IP address mode to DHCP
static	Set the controller's IP address mode to static

Defaults

None.

Example

To set the controller's IP address mode to DHCP, enter the following command:

```
ruckus# config
ruckus(config)# system
ruckus(config-sys)# interface
ruckus(config-sys-if)# ip mode dhcp
The command was executed successfully.
```

show

To display the current management interface settings, use the following command:

```
show
```

Syntax Description

show	Display the current management interface settings
------	---

Defaults

None.

Example

```
ruckus# config
ruckus(config)# system
ruckus(config-sys)# interface
ruckus(config-sys-if)# show
Protocol Mode= IPv4-Only
Device IP Address:
Mode= Manual
IP Address= 192.168.11.100
Netmask= 255.255.255.0
Gateway Address= 192.168.11.1
Primary DNS= 192.168.11.1
Secondary DNS= 168.95.1.1

Management VLAN:
Status= Disabled
```

```
VLAN ID=  
  
ruckus(config-sys-if) #
```

ipv6 enable

To enable IPv6 addressing, use the following command:

```
ipv6 enable
```

ipv6 route gateway

To set the controller's IPv6 gateway addressing, use the following command:

```
ipv6 route gateway <GATEWAY-ADDR>
```

ipv6 name-server

To set the IPv6 DNS server, use the following command:

```
name-server <DNS-ADDR> [<DNS-ADDR>]
```

ipv6 addr

To set the IPv6 addressing, use the following command:

```
addr <IPv6-ADDR> <IPv6-PREFIX>
```

ipv6 mode

To set the IPv6 address mode, use the following command:

```
ipv6 mode [auto|manual]
```

vlan

To enable the management VLAN and set the VLAN ID, use the following command:

```
vlan <NUMBER>
```

no ip

To disable IPv4 addressing, use the following command:

```
no ip
```

no ipv6

To disable IPv6 addressing, use the following command:

```
no ipv6
```

Configuring Controller Settings

Configure System Commands

no ntp

To disable the NTP client, use the following command:

```
no ntp
```

Syntax Description

no ntp	Disable the NTP client on the controller.
--------	---

Defaults

Enabled. The default NTP server addresss is `ntp.ruckuswireless.com`.

Example

```
ruckus(config-sys)# no ntp
```

The NTP settings have been updated.

ntp

To enable the NTP client, use the following command:

```
ntp <IP-ADDR/DOMAIN-NAME>
```

Syntax Description

ntp	Enable the NTP client
-----	-----------------------

<IP-ADDR/DOMAIN-NAME>	Set the NTP server address to this IP address/domain name
-----------------------	---

Defaults

None.

Example

```
ruckus(config-sys)# ntp 192.168.2.21
```

The NTP settings have been updated.

```
ruckus(config-sys)# ntp sohu.com
```

The NTP settings have been updated.

ftp-anon

To enable FTP anonymous access, use the following command:

```
ftp-anon
```

no ftp-anon

To disable FTP anonymous access, use the following command:

```
no ftp-anon
```

ftp

Enable FTP server.

no ftp

Disable FTP server.

kt-hotspot

To set KT hotspot authentication message encrypt key, use the following command:

```
kt-hotspot <ENCRYPT-KEY> [<LOGOUT-URL>] [<AUTH-PORT>] [<IP-  
ADDR>]
```

Syntax Description

kt-hotspot	Enable KT hotspot. Use a space () to separate the logout URL, authentication port and receive authentication message public IP address if ZD set up internal network. It will take effect after system reboot.
ENCRYPT-KEY	Set the KT hotspot encryption key
LOGOUT-URL	Set the KT hotspot logout URL
AUTH-PORT	Set the KT hotspot authentication port
IP-ADDR	Set the KT hotspot public IP address

Defaults

None.

Example

```
ruckus(config-sys)# kt-hotspot key123 logout.url.com 223  
192.0.11.100
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-sys) #
```

no kt-hotspot

Disables KT web authentication. Takes effect after system reboot.

Smart Redundancy Commands

To configure the Smart Redundancy settings, you must first enter the config-sys-smart-redundancy context from within the config-sys context.

smart-redundancy

To enter the config-sys-smart-redundancy context and configure Smart Redundancy settings, use the following command:

```
smart-redundancy
```

Example

```
ruckus# config
```

Configuring Controller Settings

Configure System Commands

```
ruckus(config)# system
ruckus(config-sys)# smart-redundancy
ruckus(config-sys-smart-redundancy)#
```

no smart-redundancy

Disables the smart redundancy settings.

peer-addr

To configure the Smart Redundancy peer IP address, use the following command

```
peer-addr <IP-ADDR>
```

secret

To configure the Smart Redundancy shared secret, use the following command:

```
secret <WORD>
```

show

To displays information about smart redundancy, use the following command:

```
show
```

Management Interface Commands

To configure management interface settings, you must first enter the config-sys-mgmt-if context from the config-sys context.

mgmt-if

To enter the config-sys-mgmt-if context and configure the management interface settings, use the following command:

```
mgmt-if
```

Syntax Description

mgmt-if	Configure the management interface settings
---------	---

Defaults

None.

Example

```
ruckus(config-sys)# mgmt-if
ruckus(config-sys-mgmt-if)#+
```

no mgmt-if

To disable the management interface, use the following command:

```
no mgmt-if
```

Syntax Description

no mgmt-if	Disable the management interface
------------	----------------------------------

Defaults

None.

Example

```
ruckus(config-sys)# no mgmt-if  
The management interface has been updated.
```

ip addr

To set the management interface IP address, use the following command:

```
ip addr <IP-ADDR> <NET-MASK>
```

gateway

To set the management interface gateway address, use the following command:

```
gateway <GATEWAY-ADDR>
```

no gateway

To disable the management interface gateway address, use the following command:

```
no gateway
```

vlan

To enable the management VLAN and set the VLAN ID, use the following command:

```
vlan <NUMBER>
```

mgmt-if-ipv6

To enter the config-sys-mgmt-if-ipv6 context and configure the management interface settings, use the following command:

```
mgmt-if-ipv6
```

Syntax Description

mgmt-if-ipv6	Configure the management interface settings
--------------	---

Defaults

None.

Configuring Controller Settings

Configure System Commands

Example

```
ruckus(config-sys) # mgmt-if-ipv6  
ruckus(config-sys-mgmt-if-ipv6) #
```

no mgmt-if-ipv6

To disable the management interface, use the following command:

```
no mgmt-if-ipv6
```

Syntax Description

no mgmt-if-ipv6	Disable the management interface
-----------------	----------------------------------

Defaults

None.

Example

```
ruckus(config-sys) # no mgmt-if-ipv6
```

The management interface has been updated.

ipv6 addr

To set the management interface IP address, use the following command:

```
ip addr <IPv6-ADDR> <IPv6-PREFIX>
```

gateway

To set the management interface gateway address, use the following command:

```
gateway <GATEWAY-ADDR>
```

no gateway

To disable the management interface gateway address, use the following command:

```
no gateway
```

vlan

To enable the management VLAN and set the VLAN ID, use the following command:

```
vlan <NUMBER>
```

flexmaster

To set the FlexMaster server address and the periodic inform interval, use the following command:

```
flexmaster <IP-ADDR/DOMAIN-NAME> interval <NUMBER>
```

Syntax Description

flexmaster	Configure the FlexMaster server settings
------------	--

<IP-ADDR/DOMAIN- NAME>	Set to this URL or IP address
interval	Configure the periodic inform interval
<NUMBER>	Set to this interval (in minutes)

Defaults None.

Example ruckus(config-sys)# **flexmaster http://172.18.30.118 interval 30**
The FlexMaster Management settings have been updated.

no flexmaster

To disable FlexMaster management of the controller, use the following command:

```
no flexmaster
```

Syntax Description no flexmaster Disable FlexMaster management of the controller

Defaults None

Example ruckus(config-sys)# **no flexmaster**
FlexMaster Management has been disabled.

northbound

To enable northbound portal interface support and set the northbound portal password, use the following command:

```
northbound password <WORD>
```

Defaults Disabled

Example ruckus(config-sys)# **northbound password pass123**
The northbound portal interface settings have been updated.

no northbound

To disable northbound portal interface support, use the following command:

```
no northbound
```

Example ruckus(config-sys)# **no northbound**
Northbound portal interface has been disabled.

Configuring Controller Settings

Configure System Commands

SNMPv2 Commands

Use the following commands to configure SNMPv2 settings. To use these commands, you must first enter the config-sys-snmpv2 context.

snmpv2

To configure the SNMPv2 settings, use the following command:

```
snmpv2
```

Executing this command enters the config-sys-snmpv2 context.

Syntax Description

snmpv2	Configure the SNMPv2 settings
--------	-------------------------------

Example

```
ruckus(config-sys)# snmpv2  
ruckus(config-sys-snmpv2) #
```

contact

To enable SNMPv2 agent and set the system contact, use the following command:

```
contact <WORD>
```

location

To enable SNMPv2 agent and set the system location, use the following command:

```
location <WORD>
```

ro-community

To set the read-only (RO) community name, use the following command:

```
ro-community <WORD>
```

Syntax Description

ro-community	Configure the read-only community name
<WORD>	Set the read-only community name to this value

Defaults

public

Example

```
ruckus(config-sys-snmpv2) # ro-community private-123  
The command was executed successfully
```

rw-community

To set the read-write (RW) community name, use the following command:

`rw-community <WORD>`

This command must be entered from within the `snmp-agent` context.

Syntax Description

<code>rw-community</code>	Configure the read-write community name
<code><WORD></code>	Set the read-write community name to this value

Defaults

`private`

Example

`ruckus(config-sys-snmpv2) # rw-community private-123`

The command was executed successfully. To save the changes, type 'end' or 'exit'.

show

To display SNMPv2 agent and SNMP trap settings, use the `show` command.

SNMPv3 Commands

Use the following commands to configure SNMPv3 settings. To use these commands, you must first enter the `config-sys-snmpv3` context.

snmpv3

To configure the SNMPv3 settings, use the following command:

`snmpv3`

Executing this command enters the `config-sys-snmpv3` context.

Syntax Description

<code>snmpv3</code>	Configure the SNMPv3 settings
---------------------	-------------------------------

Defaults

`ruckus(config-sys) # snmpv3`

`ruckus(config-sys-snmpv3) #`

ro-user

To set the SNMPv3 Read Only User, use the following command:

`ro-user <WORD> [MD5 | SHA] <WORD> [DES | AES | NONE] <WORD>`

rw-user

To set the SNMPv3 Read Write User, use the following command:

`rw-user <WORD> [MD5 | SHA] <WORD> [DES | AES | NONE] <WORD>`

Configuring Controller Settings

Configure System Commands

snmp-trap-format

To set the SNMP trap format to SNMPV2 or SNMPV3, use the following command:

```
snmp-trap-format [SNMPv2 | SNMPv3]
```

Syntax Description

snmp-trap-format	Set the SNMP trap format
[SNMPv2 SNMPv3]	Set to either SNMPv2 or SNMPv3

Defaults

SNMPv2

Example

```
ruckus(config-sys)# snmp-trap-format SNMPV2
```

The SNMP trap settings have been updated.

snmpv2-trap

To enable the SNMPv2 trap and set the IP address of the trap server, use the following command:

```
snmpv2-trap <NUMBER> <IP/IPv6-ADDR>
```

Syntax Description

snmpv2-trap	Enable the SNMPv2 trap and set the trap server's IP address
<NUMBER>	Assign the trap receiver ID (1-4)
<IP/IPv6-ADDR>	Set the trap receiver IP address

Defaults

None

Example

```
ruckus(config-sys)# snmpv2-trap 1 192.168.10.22
```

The SNMP trap settings have been updated.

snmpv3-trap

To enable and configure the SNMPv3 trap parameters, use the following command:

```
snmpv3-trap <user_name> <snmp_trap_server_ip> [MD5 | SHA]  
<auth_pass_phrase> [DES <privacy_phrase>|AES <privacy_phrase>|  
None]
```

Syntax Description

snmpv3-trap	Enable the SNMPv3 trap and configure the trap parameters
<user_name>	Trap user name
<snmp_trap_server_ip>	Trap server IP address

[MD5 SHA]	Authentication method
<auth_pass_phrase>	Authentication passphrase
>	
[DES <privacy_phrase> AES <privacy_phrase> None]	Privacy method and privacy phrase

Defaults None

Example ruckus(config-sys)#**snmpv3-trap test1234 192.168.0.22 MD5 test1234 DES test4321**
The command was executed successfully.

no snmp-trap-ap

To disable SNMP trap server configuration for AP, use the following command:

```
no snmp-trap-ap
```

Example ruckus(config-sys)#**no snmp-trap-ap**
The SNMP AP trap settings have been updated.

Syslog Settings Commands

Use the `syslog` commands to configure the controller's syslog notification settings. To run these commands, you must first enter the `config-sys` context.

no syslog

To disable syslog notification, use the following command:

```
no syslog
```

Syntax Description `no syslog` Disable syslog notification

Defaults Disabled.

Example ruckus# **config**

Configuring Controller Settings

Configure System Commands

```
ruckus(config)# system  
ruckus(config-sys)# no syslog  
The command was executed successfully.
```

syslog

To enable syslog notifications and enter the config-sys-syslog context, use the following command:

```
syslog
```

server

To set the syslog server address, use the following command:

```
server <IP-ADDR>
```

Syntax Description

server	Set the syslog server IP address.
<IPADDR>	Send syslog notifications to this IP address.

Defaults

Disabled.

facility

To set the facility name, use the following command:

```
facility <FACILITY NAME>
```

Syntax Description

facility <FACILITY NAME>	Sets the syslog facility name (local0 - local7)
--------------------------	---

Defaults

Disabled.

priority

To set the syslog priority level, use the following command:

```
priority <PRIORITY LEVEL>
```

Syntax Description

priority <PRIORITY LEVEL>	Sets the syslog priority level (emerg, alert, crit, err, warning, notice, info, debug).
---------------------------	---

Defaults

Disabled.

ap-facility

To set the AP syslog facility name, use the following command:

```
ap-facility <FACILITY-NAME>
```

Syntax Description

ap-facility	Sets the AP syslog facility name (local0 - local7).
<FACILITY-NAME>	

Defaults

Disabled.

ap-priority

To set the AP syslog priority level, use the following command:

```
ap-priority <PRIORITY LEVEL>
```

Syntax Description

ap-priority	Sets the AP syslog priority level (emerg, alert, crit, err, warning, notice, info, debug).
<PRIORITY LEVEL>	
<IPADDR>	Send syslog notifications to this IP address.

Defaults

Disabled.

Example

```
ruckus# config
ruckus(config)# system
ruckus(config-sys)# syslog
ruckus(config-sys-syslog)# server 192.168.3.10
The syslog settings have been updated.
ruckus(config-sys-syslog)# facility local0
The syslog settings have been updated.
ruckus(config-sys-syslog)# priority emerg
The syslog settings have been updated.
ruckus(config-sys-syslog)# ap-facility local0
The syslog settings have been updated.
ruckus(config-sys-syslog)# ap-priority emerg
The syslog settings have been updated.
ruckus(config-sys-syslog)# end
The syslog settings have been updated.
Your changes have been saved.
ruckus(config-sys)#

```

Configuring Controller Settings

Configure System Commands

bypasscna

Use the following command to bypass Apple Captive Network Assistance (CNA) on iDevices and OS X machines.

```
bypasscna <WLAN-TYPE>
```

Syntax Description

bypasscna	Bypass Apple Captive Network Assistance (CNA) on iDevices and OS X machines
<WLAN-TYPE>	Enter the WLAN service type (web-auth, guestaccess, wispr)

Example

```
ruckus(config-sys)# bypasscna web-auth
```

no bypasscna

To disable the ignore Apple CNA feature, use the following command:

```
no bypasscna
```

Example

```
ruckus(config-sys)# no bypasscna
```

no syslog-ap

To disable external syslog server configuration for AP, use the following command:

```
no syslog-ap
```

Example

```
ruckus(config-sys)#no syslog-ap
```

The AP syslog settings have been updated.

Management Access Control List Commands

Use the following commands to create or configure management ACLs and enter the config-sys-mgmt-acl or config-sys-mgmt-acl-ipv6 contexts. These commands must be used from the config-sys context.

no mgmt-acl

To delete a management ACL for IPv4, use the following command:

```
no mgmt-acl <WORD>
```

mgmt-acl

To create or configure a management ACL, use the following command:

```
mgmt-acl <WORD>
```

Executing this command enters the config-mgmt-acl context.

Syntax Description

mgmt-acl	Create or configure a management ACL
<WORD>	Create or configure this management ACL

Defaults

None.

Example

```
ruckus(config-sys)# mgmt-acl mac11
```

The management ACL 'mac11' has been created. To save the Management ACL, type 'end' or 'exit'.

```
ruckus(config-mgmt-acl)#
```

no mgmt-acl-ipv6

To delete a management ACL for IPv6, use the following command:

```
no mgmt-acl-ipv6 <WORD>
```

mgmt-acl-ipv6

To create or configure an IPv6 management ACL, use the following command:

```
mgmt-acl-ipv6 <WORD>
```

Executing this command enters the config-mgmt-acl-ipv6 context.

Syntax Description

mgmt-acl-ipv6	Create or configure a management ACL
<WORD>	Create or configure this management ACL

Defaults

None.

Example

```
ruckus(config-sys)# mgmt-acl-ipv6 mac11
```

The management ACL 'mac11' has been created. To save the Management ACL, type 'end' or 'exit'.

```
ruckus(config-mgmt-acl-ipv6)#
```

exit

Saves changes, and then exits the config-mgmt-acl context.

Configuring Controller Settings

Configure System Commands

end

Saves changes, and then exits the config-mgmt-acl context.

quit

Exits the config-mgmt-acl context without saving changes.

abort

Exits the config-mgmt-acl context without saving changes.

name

To set the management ACL name, use the following command:

```
name <WORD>
```

restrict-type

To set the management ACL restriction type, use the following command:

```
restrict-type [single ip-addr <IP-ADDR> | range ip-range <IP-  
ADDR> <IP-ADDR> | subnet ip-subnet <IP-ADDR> <IP-SUBNET>]
```

Syntax Description

restrict-type	Set the management ACL restriction type (single/range)
single ip-addr	Set management ACL restriction type to single
range	Sets the management ACL restriction type to range.
ip-range	Sets the IP address range for management ACL. Use a space () to separate addresses.
subnet ip-subnet	Sets the subnet for management acl IP address. Use a space () to separate IP address and Netmask (128.0.0.0 to 255.255.255.252).

show

To display management ACL settings, use the show command.

QoS Commands

Use the following commands to configure QoS settings on the controller. These commands must be executed from the config-sys context.

no qos

To disable QoS on the controller, use the following command:

```
no qos
```

Syntax Description	no qos	Disable QoS on the controller
--------------------	--------	-------------------------------

Defaults	None.
----------	-------

Example	<pre>ruckus(config-sys)# no qos</pre> <p>Changes are saved!</p> <p>System QoS function has been disabled.</p>
---------	---

qos

To enable and configure Quality of Service settings on the controller, use the following command:

```
qos
```

Executing this command enters the `config-sys-qos` context. The following commands can be executed from within the `qos` context.

Example	<pre>ruckus(config-sys)# qos</pre> <pre>ruckus(config-sys-qos) #</pre>
---------	--

heuristics video inter-packet-gap

Use the following command to set the QoS heuristics video inter-packet gap minimum/maximum values:

```
heuristics video inter-packet-gap min <NUMBER> max <NUMBER>
```

heuristics video packet-length

Use the following command to set the heuristics video packet-length values:

```
heuristics video packet-length min <NUMBER> max <NUMBER>
```

heuristics voice inter-packet-gap

Use the following command to set the heuristics voice inter-packet-gap values:

```
heuristics voice inter-packet-gap min <NUMBER> max <NUMBER>
```

heuristics voice packet-length

Use the following command to set the heuristics voice packet-length values:

```
heuristics voice packet-length min <NUMBER> max <NUMBER>
```

heuristics classification video packet-octet-count

Use the following command to set the heuristics classification video packet-octet-count value:

```
heuristics classification video packet-octet-count <NUMBER>
```

heuristics classification voice packet-octet-count

Use the following command to set the heuristics classification voice packet-octet-count value:

```
heuristics classification voice packet-octet-count <NUMBER>
```

heuristics no-classification video packet-octet-count

Use the following command to set the heuristics no-classification video packet-octet-count value

```
heuristics no-classification video packet-octet-count <NUMBER>
```

heuristics no-classification voice packet-octet-count

Use the following command to set the heuristics no-classification voice packet-octet-count value

```
heuristics no-classification voice packet-octet-count <NUMBER>
```

tos classification video

Use the following command to set the TOS classification video value:

```
tos classification video <WORD>
```

tos classification voice

Use the following command to set the TOS classification voice value:

```
tos classification voice <WORD>
```

tos classification data

Use the following command to set the TOS classification data value:

```
tos classification data <WORD>
```

tos classification background

Use the following command to set the TOS classification background value:

```
tos classification background <WORD>
```

show

Use the following command to display the system QoS settings:

```
show
```

tunnel-mtu

To set the tunnel MTU, use the following command:

```
tunnel-mtu <NUMBER>
```

Syntax Description

tunnel-mtu	Set the tunnel MTU
------------	--------------------

Defaults

None.

Example

```
ruckus(config-sys)# tunnel-mtu 1500
```

The Tunnel MTU settings have been updated.

```
ruckus(config-sys)#
```

bonjour

To enable bonjour service, use the following command:

```
bonjour
```

Defaults

Disabled.

Example

```
ruckus(config-sys)# bonjour
```

The bonjour service settings have been updated.

```
ruckus(config-sys)#
```

no bonjour

To disable bonjour service, use the following command:

```
no bonjour
```

telnetd

To enable the telnet server, use the following command:

```
telnetd
```

Syntax Description

telnetd	Enable the telnet server
---------	--------------------------

Configuring Controller Settings

Configure System Commands

Defaults None.

Example

```
ruckus(config-sys)# telnetd
The telnet server settings have been updated.
ruckus(config-sys)#

```

no telnetd

To disable the telnet server, use the following command:

```
telnetd
```

Syntax Description

no telnetd	Disable the telnet server
------------	---------------------------

Defaults None.

Example

```
ruckus(config-sys)# no telnetd
The telnet server settings have been updated.
ruckus(config-sys)#

```

static-route

To create and configure static route settings, use the following command:

```
static-route <WORD>
```

Syntax Description

static-route	Create and configure a static route
name <WORD>	Set the name of the static route
subnet <IP-SUBNET>	Set the subnet for the destination network. Use a slash (/) to separate IP address and subnet
gateway <GATEWAY-ADDR>	Set the gateway address
show	Show a list of all static routes

Defaults None.

Example

```
ruckus(config-sys)# static-route route1
The static route 'route1' has been created. To save the static route, type 'end' or 'exit'.
ruckus(config-static-route)# subnet 192.168.11.1/24
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-static-route) # gateway 192.168.11.1
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-static-route) # show
```

Static Route:

ID=

Name= route1

IP subnet= 192.168.11.1/24

IP gateway= 192.168.11.1

```
ruckus(config-static-route) #
```

no static-route

To delete a static route, use the following command:

```
no static-route
```

static-route-ipv6

To create and configure IPv6 static route settings, use the following command:

```
static-route-ipv6 <WORD>
```

Syntax Description

static-route-ipv6	Create and configure a static route
name <WORD>	Set the name of the static route
prefix <IPv6-PREFIX>	Set the subnet for the destination network. Use a slash (/) to separate IP address and prefix length
gateway <GATEWAY-ADDR>	Set the gateway address
show	Show a list of all static routes

Defaults

None.

Example

```
ruckus(config-sys) # static-route route1
```

The static route 'route1' has been created. To save the static route, type 'end' or 'exit'.

```
ruckus(config-static-route) # subnet 192.168.11.1/24
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

Configuring Controller Settings

Configure System Commands

```
ruckus(config-static-route)# gateway 192.168.11.1  
The command was executed successfully. To save the changes, type  
'end' or 'exit'.  
ruckus(config-static-route)# show  
Static Route:  
ID=  
Name= route1  
IP subnet= 192.168.11.1/24  
IP gateway= 192.168.11.1  
  
ruckus(config-static-route) #
```

no static-route-ipv6

To delete an IPv6 static route, use the following command:

```
no static-route-ipv6 <WORD>
```

show

Use the following command to display system configuration information:

```
show
```

support-entitle

Use the following command to manually download entitlement file:

```
support-entitle
```

no snmpv2

To disable the SNMPv2 agent, use the following command:

```
no snmpv2
```

Syntax Description

no snmpv2	Disables the SNMPv3 agent
-----------	---------------------------

Defaults

None.

Example

```
ruckus(config-sys)# no snmpv2
```

The SNMP v2 agent settings have been updated.

no snmpv3

To disable the SNMPv3 agent, use the following command:

```
no snmpv3
```

Syntax Description

no snmpv3	Disables the SNMPv3 agent
-----------	---------------------------

Defaults

None.

Example

```
ruckus(config-sys)# no snmpv3
```

The SNMP v3 agent settings have been updated.

no snmp-trap

To disable the SNMP trap notifications, use the following command:

```
no snmp-trap <NUMBER>
```

Syntax Description

no snmp-trap	Disables SNMP trap notification by index
--------------	--

Defaults

None.

Example

```
ruckus(config-sys)# no snmp-trap 1
```

The SNMP trap settings have been updated.

no snmpv2-trap

To disable the SNMP trap notifications, use the following command:

```
no snmp-trap <NUMBER>
```

Syntax Description

no snmpv2-trap	Disables SNMP trap notification by index
----------------	--

Defaults

None.

Example

```
ruckus(config-sys)# no snmpv2-trap 1
```

The SNMP trap settings have been updated.

no snmpv3-trap

To disable the SNMPv3 trap notification, use the following command:

Configuring Controller Settings

Configure System Commands

```
no snmpv3-trap <NUMBER>
```

Syntax Description

no snmpv3-trap	Disables SNMP trap notification by index
----------------	--

Defaults

None.

Example

```
ruckus(config-sys)# no snmpv3-trap 1
The SNMP trap settings have been updated.
```

snmp-trap

To set the SNMP trap format, use the following command:

```
snmp-trap {trap server address}
```

Syntax Description

snmp-trap	Enable SNMP trap notifications
-----------	--------------------------------

{trap server address}	Set the trap server address to this IP address or host name
-----------------------	---

Defaults

None.

Example

```
ruckus# config
ruckus(config)# system
ruckus(config-sys)# snmp-trap 192.168.0.3
```

Management ACL Commands

Use the `mgmt-acl` commands to configure the management ACL settings. To run these commands, you must first enter the `config-mgmt-acl` context.

abort

To exit the `config-mgmt-acl` context without saving changes, use the `abort` command.

```
abort
```

Syntax Description

abort	Exit the context without saving changes
-------	---

Defaults

Disabled.

Example

```
ruckus(config-mgmt-acl)# abort  
No changes have been saved.  
ruckus(config-sys)#
```

end

To save changes, and then exit the config-services context, use the following command:

```
end
```

Syntax Description

end	Save changes, and then exit the context
-----	---

Defaults

Disabled.

Example

```
ruckus(config-mgmt-acl)# end  
The management ACL 'mac12' has been updated and saved.  
Your changes have been saved.  
ruckus(config-sys)#
```

exit

To save changes, and then exit the config-services context, use the following command:

```
exit
```

Syntax Description

exit	Save changes, and then exit the context
------	---

Defaults

Disabled.

Example

```
ruckus(config-mgmt-acl)# exit  
The management ACL 'mac12' has been updated and saved.  
Your changes have been saved.  
ruckus(config-sys)#
```

quit

To exit the config-mgmt-acl context without saving changes, use the abort command.

```
quit
```

Configuring Controller Settings

Configure System Commands

Syntax Description	
	<code>quit</code> Exit the context without saving changes

Defaults	Disabled.

Example	
	<pre>ruckus(config-mgmt-acl)# quit No changes have been saved. ruckus(config-sys)#</pre>

name

To set the management ACL name, use the following command:

```
name <WORD>
```

Syntax Description	
	<code>name</code> Set the management ACL name
	<code><WORD></code> Set to this name

Defaults	Disabled.

Example	
	<pre>ruckus(config-mgmt-acl)# name mac12 The command was executed successfully. To save the changes, type 'end' or 'exit'.</pre>

restrict-type single ip-addr

To set the management ACL restriction type to a single IP address, use the following command:

```
restrict-type single ip-addr <ip_address>
```

Syntax Description	
	<code>restrict-type</code> Set the management ACL restriction type to a single IP
	<code>single ip-addr</code> address
	<code><ip_address></code> Set to this IP address only

Defaults	Disabled.

Example	
	<pre>ruckus(config-mgmt-acl)# restrict-type single ip-addr 192.168.110.22 The command was executed successfully. To save the changes, type 'end' or 'exit'.</pre>

restrict-type subnet ip-subnet

To set the management ACL restriction type to certain subnets, use the following command:

```
restrict-type subnet ip-subnet <IP-SUBNET> <IP-SUBNET>
```

Syntax Description

restrict-type subnet ip-subnet	Set the management ACL restriction type to a single IP address
<IP-SUBNET>	Set to this subnet

Defaults

Disabled.

Example

```
ruckus(config-mgmt-acl)#restrict-type subnet ip-subnet  
172.30.110.26 255.255.254.0
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

restrict-type range ip-range

To set the management ACL restriction type to an IP address range, use the following command:

```
restrict-type range ip-range <ip_address> <ip_address>
```

Syntax Description

restrict-type range ip-range	Set the management ACL restriction type to a single IP address
<ip_address>	Set to this IP address range. The first <ip_address> is for the start

Defaults

Disabled.

Example

```
ruckus(config-mgmt-acl)#restrict-type range ip-range  
172.30.110.28 172.30.110.39
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

show

To display the current management ACL settings, use the following command:

```
show
```

Syntax Description

show	Display the current management ACL settings
------	---

Configuring Controller Settings

Configure UPNP Settings

Defaults Disabled.

Example

```
ruckus(config-mgmt-acl) # show
Management ACL:
ID:
:
Name= mac12
Restriction Type= range
IP range= 172.30.110.28-172.30.110.39
```

Configure UPNP Settings

Use the following commands to enable or disable Universal Plug and Play:

upnp

upnp

Syntax Description

upnp	Enable UPnP
------	-------------

Defaults None.

Example

```
ruckus(config)# upnp
UPnP Service is enabled
/bin/upnp enable
ruckus(config) #
```

no upnp

no upnp

Syntax Description

no upnp	Enable UPnP
---------	-------------

Defaults None.

Example

```
ruckus(config)# no upnp
UPnP Service is disabled
/bin/upnp disable
ruckus(config) #
```

Configure Zero-IT Settings

To configure Zero-IT settings, use the following commands.

zero-it

To configure Zero-IT settings, use the following command:

```
zero-it [local | name <WORD>]
```

zero-it-auth-server

To configure Zero-IT settings, use the following command:

```
zero-it-auth-server [local | name <WORD>]
```

Syntax Description

zero-it	Set Zero-IT authentication server
zero-it-auth-server	Set Zero-IT authentication server
local	Set the Zero-IT authentication server to local database
name	Set the Zero-IT authentication server to an external AAA server
<WORD>	Name of AAA server

Defaults

None.

Example

```
ruckus(config)# zero-it-auth-server name radius
The Authentication Server of Zero IT Activation has been updated.
ruckus(config) #
```

Example

```
ruckus(config)# zero-it-auth-server local
The Authentication Server of Zero IT Activation has been updated.
ruckus(config) #
zero-it-auth-server
```

Configure Dynamic PSK Expiration

The following section lists commands for configuring Dynamic Pre-Shared Keys.

Configuring Controller Settings

Configure WLAN Settings Commands

dynamic-psk-expiration

To set DPSK expiration, use the following command:

```
dynamic-psk-expiration <TIME>
```

Syntax Description

dynamic-psk-expiration	Set DPSK expiration
<TIME>	Set DPSK expiration to this time limit (one-day, one-week, two-weeks, one-month, two-months, three-months, half-a-year, one-year, two-years)
unlimited	Set DPSKs to never expire

Defaults

None.

Example

```
ruckus(config)# dynamic-psk-expiration unlimited
The Dynamic psk expiration value has been updated.
ruckus(config)#
```

Configure WLAN Settings Commands

Use the config-wlan commands to configure the WLAN settings, including the WLAN's description, SSID, and its security settings. To run these commands, you must first enter the config-wlan context.

wlan

To create a WLAN or configure an existing WLAN, use the following command:

```
wlan <WORD/NAME>
```

Executing this command enters the config-wlan context.

Syntax Description

wlan	Configure a WLAN
<WORD/NAME>	Name of the WLAN service

Defaults

None.

Example

```
ruckus(config)# wlan ruckus2
The WLAN service 'ruckus2' has been created. To save the WLAN
service, type 'end' or 'exit'.
ruckus(config-wlan) #
```

abort

Exits the config-wlan context without saving changes.

end

Saves changes, and then exits the config-wlan context.

exit

Saves changes, and then exits the config-wlan context.

quit

Exits the config-wlan context without saving changes.

description

To set the WLAN service description, use the following command:

```
description <WORD>
```

Syntax Description

description	Configure the WLAN description
<WORD>	Set the WLAN description this value

Defaults

None.

Example

```
ruckus(config-wlan)# description ruckustestwlan2
The command was executed successfully. To save the changes, type
'end' or 'exit'.
ruckus(config-wlan) #
```

called-station-id-type

To set the called station ID type to, use the following command:

```
called-station-id-type [wlan-bssid | ap-mac]
```

Syntax Description

wlan-bssid	Set the called station ID type to 'BSSID:SSID'
ap-mac	Set the called station ID type to 'APMAC:SSID'

Defaults

wlan-bssid

Configuring Controller Settings

Configure WLAN Settings Commands

Example

```
ruckus(config-wlan)# called-station-id-type wlan-bssid  
The command was executed successfully. To save the changes, type  
'end' or 'exit'.
```

ssid

To set the WLAN service's SSID or network name, use the following command:

```
ssid <SSID>
```

Syntax Description

ssid	Configure the WLAN service's SSID
<SSID>	Set the SSID to this value

Defaults

None.

Example

```
ruckus(config-wlan)# ssid ruckus2  
The command was executed successfully. To save the changes, type  
'end' or 'exit'.  
ruckus(config-wlan) #
```

beacon-interval

To set the beacon interval for mesh links, use the following command:

```
beacon-interval <NUMBER>
```

Syntax Description

beacon-interval	Set the beacon interval for the WLAN
<NUMBER>	Enter the beacon interval (100~1000 TUs)

Defaults

100

Example

```
ruckus(config-wlan)# beacon-interval 100  
The command was executed successfully. To save the changes, type  
'end' or 'exit'.  
ruckus(config-wlan) #
```

mgmt-tx-rate

To set the transmit rate for management frames, use the following command:

```
mgmt-tx-rate <RATE>
```

Syntax Description	mgmt-tx-rate <RATE>	Set the max transmit rate for management frames Set the transmit rate (in Mbps).
---------------------------	------------------------	---

Defaults	2
-----------------	---

Example	ruckus(config-wlan) # mgmt-tx-rate 2 The command was executed successfully. To save the changes, type 'end' or 'exit'. ruckus(config-wlan) #
----------------	---

name

To set the name of the WLAN, use the following command:

```
name <NAME>
```

Syntax Description	name <NAME>	Set the WLAN name Set to this name
---------------------------	----------------	---------------------------------------

Defaults	None.
-----------------	-------

Example	ruckus(config-wlan) # name ruckus2 The command was executed successfully. To save the changes, type 'end' or 'exit'. ruckus(config-wlan) #
----------------	---

type

To configure the WLAN type, use the following command:

```
type [standard-usage | guest-access | hotspot <WORD> | hs20 <WORD>]
```

Syntax Description	type standard-usage guest-access hotspot <WORD> hs20 <WORD>	Set the WLAN type Set the WLAN type to standard usage Set the WLAN type to guest access Set the WLAN type to Hotspot using the hotspot service specified Set the WLAN type to Hotspot 2.0 using the HS2.0 operator specified
---------------------------	---	--

Configuring Controller Settings

Configure WLAN Settings Commands

Defaults	None.
Example	<pre>ruckus(config-wlan)# type standard-usage The command was executed successfully. To save the changes, type 'end' or 'exit'. ruckus(config-wlan)#[/pre></pre>

open none

To set the authentication method to 'open' and encryption method to 'none', use the following command:

```
open none
```

Syntax Description	
open	Set the authentication method to 'open'
none	Set the encryption method to 'none'

Defaults	None.
Example	

Example	<pre>ruckus(config)# wlan randy-wlansvc-01-open The WLAN service 'randy-wlansvc-01-open' has been created. To save the WLAN service, type end or exit. ruckus(config-wlan-randy-wlansvc-01-open)# open none The command was executed successfully. ruckus(config-wlan-randy-wlansvc-01-open)#[/pre></pre>
----------------	--

open wpa passphrase algorithm AES

To set the authentication method to 'open', encryption method to 'WPA', and algorithm to 'AES', use the following command:

```
open wpa passphrase <PASSPHRASE> algorithm AES
```

Syntax Description	
open	Set the authentication method to open
wpa	Set the encryption method to WPA
passphrase <PASSPHRASE>	Set the WPA passphrase to <PASSPHRASE>
algorithm AES	Set the encryption algorithm to AES

Defaults	None.
Example	

Example

```
ruckus(config)# wlan randy-wlansvc-01-open
The WLAN service 'randy-wlansvc-01-open' has been created. To save
the WLAN service, type end or exit.
ruckus(config-wlan-randy-wlansvc-01-open)# open wpa passphrase
12345678 algorithm AES
The command was executed successfully.
ruckus(config-wlan-randy-wlansvc-01-open)#

```

open wpa passphrase algorithm TKIP

To set the authentication method to 'open', encryption method to 'WPA', and algorithm to 'TKIP', use the following command:

```
open wpa passphrase <PASSPHRASE> algorithm TKIP
```

Syntax Description

open	Set the authentication method to open
wpa	Set the encryption method to WPA
passphrase <PASSPHRASE>	Set the WPA passphrase to <PASSPHRASE>
algorithm TKIP	Set the encryption algorithm to TKIP

Defaults

None.

Example

```
ruckus(config)# wlan randy-wlansvc-01-open
The WLAN service 'randy-wlansvc-01-open' has been created. To save
the WLAN service, type end or exit.
ruckus(config-wlan-randy-wlansvc-01-open)# open wpa passphrase
12345678 algorithm TKIP
The command was executed successfully.
ruckus(config-wlan-randy-wlansvc-01-open)#

```

open wpa passphrase algorithm auto

To set the authentication method to 'open', encryption method to 'WPA', and algorithm to 'Auto', use the following command:

```
open wpa passphrase <PASSPHRASE> algorithm auto
```

Syntax Description

open	Set the authentication method to open
wpa	Set the encryption method to WPA

Configuring Controller Settings

Configure WLAN Settings Commands

passphrase <PASSPHRASE>	Set the WPA passphrase to <PASSPHRASE>
algorithm auto	Set the encryption algorithm to Auto

Defaults

None.

Example

```
ruckus(config)# wlan randy-wlansvc-01-open  
The WLAN service 'randy-wlansvc-01-open' has been created. To save  
the WLAN service, type end or exit.  
ruckus(config-wlan-randy-wlansvc-01-open)# open wpa passphrase  
12345678 algorithm auto  
The command was executed successfully.  
ruckus(config-wlan-randy-wlansvc-01-open)#[/pre>
```

open wpa2 passphrase algorithm AES

To set the authentication method to 'open', encryption method to 'WPA2', and algorithm to 'AES', use the following command:

```
open wpa2 passphrase <PASSPHRASE> algorithm AES
```

Syntax Description

open	Set the authentication method to open
wpa2	Set the encryption method to WPA2
passphrase <PASSPHRASE>	Set the WPA2 passphrase to <PASSPHRASE>
algorithm AES	Set the encryption algorithm to AES

Defaults

None.

Example

```
ruckus(config)# wlan randy-wlansvc-01-open  
The WLAN service 'randy-wlansvc-01-open' has been created. To save  
the WLAN service, type end or exit.  
ruckus(config-wlan-randy-wlansvc-01-open)# open wpa2 passphrase  
12345678 algorithm AES  
The command was executed successfully.  
ruckus(config-wlan-randy-wlansvc-01-open)#[/pre>
```

open wpa2 passphrase algorithm TKIP

To set the authentication method to 'open', encryption method to 'WPA2', and algorithm to 'TKIP', use the following command:

```
open wpa2 passphrase <PASSPHRASE> algorithm TKIP
```

Syntax Description

open	Set the authentication method to open
wpa2	Set the encryption method to WPA2
passphrase <PASSPHRASE>	Set the WPA2 passphrase to <PASSPHRASE>
algorithm TKIP	Set the encryption algorithm to TKIP

Defaults

None.

Example

```
ruckus(config)# wlan randy-wlansvc-01-open
The WLAN service 'randy-wlansvc-01-open' has been created. To save
the WLAN service, type end or exit.
ruckus(config-wlan-randy-wlansvc-01-open)# open wpa2 passphrase
12345678 algorithm TKIP
The command was executed successfully.
ruckus(config-wlan-randy-wlansvc-01-open) #
```

open wpa2 passphrase algorithm auto

To set the authentication method to 'open', encryption method to 'WPA2', and algorithm to 'Auto', use the following command:

```
open wpa2 passphrase <PASSPHRASE> algorithm auto
```

Syntax Description

open	Set the authentication method to open
wpa2	Set the encryption method to WPA2
passphrase <PASSPHRASE>	Set the WPA passphrase to <PASSPHRASE>
algorithm auto	Set the encryption algorithm to Auto

Defaults

None.

Example

```
ruckus(config)# wlan randy-wlansvc-01-open
The WLAN service 'randy-wlansvc-01-open' has been created. To save
the WLAN service, type end or exit.
ruckus(config-wlan-randy-wlansvc-01-open)# open wpa2 passphrase
12345678 algorithm auto
The command was executed successfully.
ruckus(config-wlan-randy-wlansvc-01-open) #
```

Configuring Controller Settings

Configure WLAN Settings Commands

open wpa-mixed passphrase algorithm auto

To set the authentication method to 'open', encryption method to 'WPA mixed', and algorithm to 'Auto', use the following command:

```
open wpa-mixed passphrase <PASSPHRASE> algorithm [AES | TKIP | auto]
```

Syntax Description

open	Set the authentication method to open
wpa-mixed	Set the encryption method to WPA-mixed
passphrase <PASSPHRASE>	Set the WPA passphrase to <PASSPHRASE>
algorithm AES	Set the encryption algorithm to AES
algorithm TKIP	Set the encryption algorithm to TKIP
algorithm auto	Set the encryption algorithm to Auto

Defaults

None.

Example

```
ruckus(config-wlan)# open wpa-mixed passphrase pass1234 algorithm auto
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-wlan)#

```

open wep-64 key {KEY} key-id {KEY-ID}

To set the authentication method to 'open', encryption method to 'WEP-64', key index, and WEP key, use the following command:

```
open wep-64 key {key} key-id {key ID}
```

Syntax Description

open	Set the authentication method to open
wep-64	Set the encryption method to WEP 64-bit
key {key}	Set the WEP key to {key}
key-id {key ID}	Set the WEP key ID to {key ID}

Defaults

None.

Example

```
ruckus(config)# wlan randy-wlansvc-01-open
```

The WLAN service 'randy-wlansvc-01-open' has been created. To save the WLAN service, type end or exit.

```
ruckus(config-wlan-randy-wlansvc-01-open) # open wep-64 key  
1234567890 key-id 1
```

The command was executed successfully.

```
ruckus(config-wlan-randy-wlansvc-01-open) #
```

open wep-128 key key-id

To set the authentication method to 'open', encryption method to 'WEP-128', key index, and WEP key, use the following command:

```
open wep-128 key {key} key-id {key ID}
```

Syntax Description

open	Set the authentication method to open
wep-128	Set the encryption method to WEP 128-bit
key {key}	Set the WEP key to {key}
key-id {key ID}	Set the WEP key ID to {key ID}

Defaults

None.

Example

```
ruckus(config) # wlan randy-wlansvc-01-open
```

The WLAN service 'randy-wlansvc-01-open' has been created. To save the WLAN service, type end or exit.

```
ruckus(config-wlan-randy-wlansvc-01-open) # open wep-128 key  
12345678901234567890123456 key-id 1
```

The command was executed successfully.

```
ruckus(config-wlan-randy-wlansvc-01-open) #
```

mac none auth-server

To set the authentication method to 'MAC Address' and encryption method to 'none', use the following command:

```
mac none auth-server <WORD>
```

Syntax Description

mac	Set the authentication method to 'MAC Address'
none	Set the encryption method to 'none'
auth-server <WORD>	Set the authorization server address to <WORD>

Defaults

None.

Example

```
ruckus(config-wlan-randall-wlansvc-01) # mac none auth-server  
Ruckus-Auth-01
```

Configuring Controller Settings

Configure WLAN Settings Commands

The command was executed successfully.

```
ruckus(config-wlan-randall-wlansvc-01) #
```

mac wpa passphrase alogrithm AES auth-server

To set the authentication method to 'MAC Address', encryption method to 'WPA', and algorithm to 'AES', use the following command:

```
mac wpa passphrase <PASSPHRASE> algorithm AES auth-server <WORD>
```

Syntax Description

mac	Set the authentication method to 'MAC Address'
wpa	Set the encryption method to 'WPA'
passphrase <PASSPHRASE>	Set the WPA passphrase to <PASSPHRASE>
algorithm AES	Set the encryption algorithm to 'AES'
auth-server <WORD>	Set the authorization server address to <WORD>

Defaults

None.

Example

```
ruckus(config-wlan-randall-wlansvc-01) # mac wpa passphrase  
12345678 algorithm AES auth-server Ruckus-Auth-01  
The command was executed successfully.  
ruckus(config-wlan-randall-wlansvc-01) #
```

mac wpa passphrase alogrithm TKIP auth-server

To set the authentication method to 'MAC Address', encryption method to 'WPA', and algorithm to 'TKIP', use the following command:

```
mac wpa passphrase <PASSPHRASE> alogrithm TKIP auth-server  
<WORD>
```

Syntax Description

mac wpa	Set the authentication method to 'MAC Address' and encryption method to 'WPA'
passphrase <PASSPHRASE>	Set the WPA passphrase to <PASSPHRASE>
algorithm TKIP	Set the encryption algorithm to 'TKIP'
auth-server <WORD>	Set the authorization server address to <WORD>

Defaults

None.

Example

```
rukus(config-wlan-randall-wlansvc-01) # mac wpa passphrase  
12345678 algorithm TKIP auth-server Ruckus-Auth-01  
The command was executed successfully.  
rukus(config-wlan-randall-wlansvc-01) #
```

mac wpa2 passphrase algorith AES auth-server

To set the authentication method to 'MAC Address', encryption method to 'WPA2', and algorithm to 'AES', use the following command:

```
mac wpa2 passphrase <PASSPHRASE> algorithm AES auth-server  
<WORD>
```

Syntax Description

mac wpa2	Set the authentication method to 'MAC Address' and encryption method to 'WPA2'
passphrase <PASSPHRASE>	Set the WPA2 passphrase to <PASSPHRASE>
algorithm AES	Set the encryption algorithm to 'AES'
auth-server <WORD>	Set the authorization server address to <WORD>

Defaults

None.

Example

```
rukus(config-wlan-randall-wlansvc-01) # mac wpa2 passphrase  
12345678 algorithm AES auth-server Ruckus-Auth-01  
The command was executed successfully.  
rukus(config-wlan-randall-wlansvc-01) #
```

mac wpa2 passphrase algorith TKIP auth-server

To set the authentication method to 'MAC Address', encryption method to 'WPA2', and algorithm to 'TKIP', use the following command:

```
mac wpa2 passphrase <PASSPHRASE> algorith TKIP auth-server  
<WORD>
```

Syntax Description

mac wpa2	Set the authentication method to 'MAC Address' and encryption method to 'WPA2'
passphrase <PASSPHRASE>	Set the WPA2 passphrase to <PASSPHRASE>
algorithm TKIP	Set the encryption algorithm to 'TKIP'
auth-server <WORD>	Set the authorization server address to <WORD>

Configuring Controller Settings

Configure WLAN Settings Commands

Defaults None.

Example

```
ruckus (config-wlan-randall-wlansvc-01) # mac wpa2 passphrase  
12345678 algorithm TKIP auth-server Ruckus-Auth-01
```

The command was executed successfully.

```
ruckus (config-wlan-randall-wlansvc-01) #
```

mac wpa-mixed passphrase algorithm AES auth-server

To set the authentication method to 'MAC Address', encryption method to WPA-Mixed, and algorithm to AES, use the following command:

```
mac wpa-mixed passphrase <PASSPHRASE> algorithm AES auth-server  
<WORD>
```

Syntax Description

mac wpa-mixed	Set the authentication method to 'MAC Address' and encryption method to 'WPA-Mixed'
passphrase <PASSPHRASE>	Set the WPA2 passphrase to <PASSPHRASE>
algorithm AES	Set the encryption algorithm to 'AES'
auth-server <WORD>	Set the authorization server to this auth server

Defaults

None.

Example

```
ruckus (config-wlan) # mac wpa-mixed passphrase pass1234 algorithm  
AES auth-server radius
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus (config-wlan) #
```

mac wpa-mixed passphrase algorithm TKIP auth-server

To set the authentication method to 'MAC Address', encryption method to 'WPA-Mixed', algorithm to TKIP, use the following command:

```
mac wpa-mixed passphrase <PASSPHRASE> algorithm TKIP auth-server  
<WORD>
```

Syntax Description

mac wpa-mixed	Set the authentication method to 'MAC Address' and encryption method to 'WPA-Mixed'
passphrase <PASSPHRASE>	Set the WPA2 passphrase to <PASSPHRASE>
algorithm TKIP	Set the encryption algorithm to 'TKIP'
auth-server <WORD>	Set the authorization server to this auth server

Defaults

None.

Example

```
ruckus(config-wlan)# mac wpa-mixed passphrase pass1234 algorithm TKIP auth-server radius
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-wlan)#+
```

mac wep-64 key key-id auth-server

To set the authentication method to 'MAC Address', encryption method to 'WEP-64', key index, and WEP key, use the following command:

```
mac wep-64 key {KEY} key-id {KEY-ID} auth-server <WORD>
```

Syntax Description

mac	Set the authentication method to MAC address
wep-64	Set the encryption method to WEP 64-bit
key {KEY}	Set the WEP key to {KEY}
key-id {KEY-ID}	Set the WEP key ID to {KEY-ID}
auth-server <WORD>	Set the authorization server address to <WORD>

Defaults

None.

Example

```
ruckus(config-wlan-randy-wlansvc-01-wpa2)# mac wep-64 key 15791BD8F2 key-id 2 auth-server Ruckus-Auth-01
```

The command was executed successfully.

```
ruckus(config-wlan-randy-wlansvc-01-wpa2)#+
```

Configuring Controller Settings

Configure WLAN Settings Commands

mac wep-128 key key-id auth-server

To set the authentication method to 'MAC Address', encryption method to 'WEP-128', key index, and WEP key, use the following command:

```
mac wep-128 key {KEY} key-id {KEY-ID} auth-server <WORD>
```

Syntax Description

mac	Set the authentication method to MAC address
wep-128	Set the encryption method to WEP 128-bit
key {KEY}	Set the WEP key to {key}
key-id {KEY-ID}	Set the WEP key ID to {key ID}
auth-server <WORD>	Set the authorization server address to <WORD>

Defaults

None.

Example

```
ruckus(config-wlan-randy-wlansvc-01-wpa2) # mac wep-128 key  
15715791BD8F212345691BD8F2 key-id 2 auth-server Ruckus-Auth-01  
The command was executed successfully.  
ruckus(config-wlan-randy-wlansvc-01-wpa2) #
```

shared wep-64

To set the authentication method to 'Shared', encryption method to 'WEP-64', key index, and WEP key, use the following command:

```
shared wep-64 key {KEY} key-id {KEY-ID}
```

Syntax Description

shared	Set the authentication method to 'Shared'
wep-64	Set the encryption method to WEP 64-bit
key {KEY}	Set the WEP key to {key}
key-id {KEY-ID}	Set the WEP key ID to {KEY-ID}

Defaults

None.

Example

```
ruckus(config-wlan-randy-wlansvc-01-wpa2) # shared authentication  
encryption wep-64 key 15791BD8F2 key-id 2  
The command was executed successfully.  
ruckus(config-wlan-randy-wlansvc-01-wpa2) #
```

shared wep-128 key key-id

To set the authentication method to 'Shared', encryption method to 'WEP-128', key index, and WEP key, use the following command:

```
shared wep-128 key {KEY} key-id {KEY-ID}
```

Syntax Description

shared	Set the authentication method to 'Shared'
wep-128	Set the encryption method to WEP 128-bit
key {KEY}	Set the WEP key to {key}
key-id {KEY-ID}	Set the WEP key ID to {KEY-ID}

Defaults

None.

Example

```
ruckus (config-wlan-randy-wlansvc-01-wpa2) # shared wep-128 key 15791B15791BD8F2123456D8F2 key-id 2  
The command was executed successfully.  
ruckus (config-wlan-randy-wlansvc-01-wpa2) #
```

dot1x eap-type EAP-SIM auth-server

To set the authentication method to 'EAP-SIM', use the following command:

```
dot1x eap-type EAP-SIM auth-server[local | name <WORD>]
```

Syntax Description

dot1x	Set the authentication method to '802.11x'
eap-type	Set the EAP type
EAP-SIM	Set the authentication method to EAP-SIM
auth-server	Set authentication server
local	Set the authentication server to 'local database'
name	Set the auth server
<WORD>	Name of the auth server

Defaults

None.

Example

```
ruckus (config-wlan) # dot1x eap-type EAP-SIM auth-server local  
The command was executed successfully. To save the changes, type  
'end' or 'exit'.
```

dot1x eap-type PEAP auth-server

To set the authentication method to 'PEAP', use the following command:

Configuring Controller Settings

Configure WLAN Settings Commands

```
dot1x eap-type PEAP auth-server [local | name <WORD>]
```

Syntax Description

dot1x	Set the authentication method to '802.11x'
eap-type	Set the EAP type
PEAP	Set the authentication method to PEAP
auth-server	Set authentication server
local	Set the authentication server to 'local database'
name	Set the auth server
<WORD>	Name of the auth server

Defaults

None.

Example

```
ruckus(config-wlan)# dot1x eap-type PEAP auth-server local
The command was executed successfully. To save the changes, type
'end' or 'exit'.
```

dot1x wpa algorithm AES auth-server

To set the authentication method to '802.1x EAP', encryption method to 'WPA', and algorithm to 'AES', use the following command:

```
dot1x wpa algorithm AES auth-server [local | name <WORD>]
```

Syntax Description

dot1x	Set the authentication method to '802.11x'
wpa	Set the encryption method to WPA
algorithm AES	Set the algorithm to AES
auth-server	Set authentication server
local	Set the authentication server to 'local database'
name	Set the auth server
<WORD>	Name of the auth server

Defaults

None.

Example

```
ruckus(config-wlan-wlansvc-012)# dot1x wpa algorithm AES auth-
server Ruckus-Auth-01
The command was executed successfully.
ruckus(config-wlan-wlansvc-012)#

```

dot1x wpa algorithm TKIP auth-server

To set the authentication method to '802.1x EAP', encryption method to 'WPA', and algorithm to 'TKIP', use the following command:

```
dot1x wpa algorithm TKIP auth-server <WORD>
```

Syntax Description

dot1x	Set the authentication method to '802.11x'
wpa	Set the encryption method to WPA
algorithm TKIP	Set the algorithm to TKIP
auth-server	Set authentication server
local	Set the authentication server to 'local database'
name	Set the auth server
<WORD>	Name of the auth server

Defaults

None.

Example

```
ruckus(config-wlan-wlansvc-012)# dot1x wpa algorithm TKIP auth-server Ruckus-Auth-01
```

The command was executed successfully.

dot1x wpa algorithm auto auth-server

To set the authentication method to '802.1x EAP', encryption method to 'WPA', and algorithm to 'Auto', use the following command:

```
dot1x wpa algorithm auto auth-server [local | name <WORD>]
```

Syntax Description

dot1x	Set the authentication method to '802.11x'
wpa	Set the encryption method to WPA
algorithm auto	Set the algorithm to Auto
auth-server	Set authentication server
local	Set the authentication server to 'local database'
name	Set the auth server
<WORD>	Name of the auth server

Defaults

None.

Example

```
ruckus(config-wlan-wlansvc-012)# dot1x wpa algorithm auto auth-server Ruckus-Auth-01
```

Configuring Controller Settings

Configure WLAN Settings Commands

The command was executed successfully.

```
ruckus(config-wlan-wlansvc-012) #
```

dot1x wpa2 algorithm AES auth-server

To set the authentication method to '802.1x EAP', encryption method to 'WPA2', and algorithm to 'AES', use the following command:

```
dot1x wpa2 algorithm AES auth-server [local | name <WORD>]
```

Syntax Description

dot1x	Set the authentication method to '802.11x'
wpa2	Set the encryption method to WPA2
algorithm AES	Set the algorithm to AES
auth-server	Set authentication server
local	Set the authentication server to 'local database'
name	Set the auth server
<WORD>	Name of the auth server

Defaults

None.

Example

```
ruckus(config-wlan-randy-wlansvc-01-open) # dot1x wpa2 algorithm AES auth-server Ruckus-RADIUS
```

The command was executed successfully.

```
ruckus(config-wlan-wlansvc-01-open) #
```

dot1x wpa2 algorithm TKIP auth-server

To set the authentication method to '802.1x EAP', encryption method to 'WPA2', and algorithm to 'TKIP', use the following command:

```
dot1x wpa2 algorithm TKIP auth-server [local | name <WORD>]
```

Syntax Description

dot1x	Set the authentication method to '802.11x'
wpa2	Set the encryption method to WPA2
algorithm TKIP	Set the algorithm to TKIP
auth-server	Set authentication server
local	Set the authentication server to 'local database'
name	Set the auth server
<WORD>	Name of the auth server

Defaults	None.
-----------------	-------

Example	<pre>ruckus (config-wlan-wlansvc-012) # dot1x authentication encryption wpa2 algorithm TKIP auth-server Ruckus-Auth-01</pre> <p>The command was executed successfully.</p> <pre>ruckus (config-wlan-wlansvc-012) #</pre>
----------------	---

dot1x wpa2 algorithm auto auth-server

To set the authentication method to '802.1x EAP', encryption method to 'WPA2', and algorithm to 'Auto', use the following command:

```
dot1x wpa2 algorithm auto auth-server [local | name <WORD>]
```

Syntax Description

dot1x	Set the authentication method to '802.11x'
wpa2	Set the encryption method to WPA2
algorithm auto	Set the algorithm to auto
auth-server	Set authentication server
local	Set the authentication server to 'local database'
name	Set the auth server
<WORD>	Name of the auth server

Defaults	None.
-----------------	-------

Example	<pre>ruckus (config-wlan-wlansvc-012) # dot1x wpa2 algorithm auto auth-server Ruckus-Auth-01</pre> <p>The command was executed successfully.</p> <pre>ruckus (config-wlan-wlansvc-012) #</pre>
----------------	---

dot1x wpa-mixed algorithm AES auth-server

To set the authentication method to 802.1x EAP, encryption method to WPA-Mixed, and encryption method to AES, use the following command:

```
dot1x wpa-mixed algorithm AES auth-server [local | name <WORD>]
```

Syntax Description

dot1x	Set the authentication method to '802.11x'
wpa-mixed	Set the encryption method to WPA-Mixed
algorithm AES	Set the algorithm to AES

Configuring Controller Settings

Configure WLAN Settings Commands

auth-server	Set authentication server
local	Set the authentication server to 'local database'
name	Set the auth server
<WORD>	Name of the auth server

Defaults None.

Example

```
ruckus(config-wlan-wlansvc-012)# dot1x wpa-mixed algorithm AES auth-server local
```

The command was executed successfully.

```
ruckus(config-wlan-wlansvc-012)#+
```

dot1x wpa-mixed algorithm TKIP auth-server

To set the authentication method to 802.1x EAP, encryption method to WPA-Mixed, and encryption method to TKIP, use the following command:

```
dot1x wpa-mixed algorithm TKIP auth-server [local | name <WORD>]
```

Syntax Description

dot1x	Set the authentication method to '802.11x'
wpa-mixed	Set the encryption method to WPA-Mixed
algorithm TKIP	Set the algorithm to TKIP
local	Set the authentication server to 'local database'
name	Set the auth server
<WORD>	Name of the auth server

Defaults None.

Example

```
ruckus(config-wlan-wlansvc-012)# dot1x wpa-mixed algorithm AES auth-server local
```

The command was executed successfully.

```
ruckus(config-wlan-wlansvc-012)#+
```

dot1x wpa-mixed algorithm auto auth-server

To set the authentication method to 802.1x EAP, encryption method to WPA-Mixed, and encryption method to Auto, use the following command:

```
dot1x wpa-mixed algorithm auto auth-server [local | name <WORD>]
```

Syntax Description

dot1x	Set the authentication method to '802.11x'
wpa-mixed	Set the encryption method to WPA-Mixed
algorithm auto	Set the algorithm to Auto
local	Set the authentication server to 'local database'
name	Set the auth server
<WORD>	Name of the auth server

Defaults

None.

Example

```
ruckus(config-wlan-wlansvc-012)# dot1x wpa-mixed algorithm AES auth-server local
The command was executed successfully.
ruckus(config-wlan-wlansvc-012)#

```

dot1x authentication encryption wep-64 auth-server

To set the authentication method to '802.1x EAP', encryption method to 'WEP-64', key index, and WEP key, use the following command:

```
dot1x authentication encryption wep-64 auth-server {auth server}
```

Syntax Description

dot1x authentication	Set the authentication method to '802.11x'
encryption wep-64	Set the encryption method to WEP 64-bit
auth-server {auth server}	Set the auth server to {auth server}

Defaults

None.

Example

```
ruckus(config-wlan-wlansvc-012)# dot1x authentication encryption wep-64 auth-server Ruckus-Auth-01
The command was executed successfully.
ruckus(config-wlan-wlansvc-012)#

```

dot1x wep-128 auth-server

To set the authentication method to '802.1x EAP', encryption method to 'WEP-128', key index, and WEP key, use the following command:

```
dot1x wep-128 auth-server [local|name <WORD>]
```

Configuring Controller Settings

Configure WLAN Settings Commands

Syntax Description

dot1x	Set the authentication method to '802.11x'
wep-128	Set the encryption method to WEP 128-bit
auth-server [local name<WORD>]	Set the auth server to local or to the named server

Defaults

None.

Example

```
ruckus(config-wlan-wlansvc-012)# dot1x authentication encryption  
wep-128 auth-server Ruckus-Auth-01  
The command was executed successfully.  
ruckus(config-wlan-wlansvc-012)#{
```

dot1x none

To set the encryption as none and authentication server to 'Local Database' or the named server, use the following command:

```
dot1x none auth-server [local|name<WORD>]
```

Syntax Description

dot1x none	Set the authentication method to '802.1x' and encryption to none
auth-server [local name<WORD>]	Set the auth server to local or to the named server

Defaults

None.

Example

```
ruckus(config-wlan-wlansvc-012)# dot1x none auth-server Ruckus-  
Auth-01  
The command was executed successfully.  
ruckus(config-wlan-wlansvc-012)#{
```

dot1x-mac none

To set the encryption as none and authentication method to 802.1x-MAC, use the following command:

```
dot1x-mac none auth-server name <WORD>
```

Syntax Description

dot1x-mac none	Set the authentication method to '802.1x-MAC' and encryption to none
auth-server name<WORD>	Set the auth server to the named server

Defaults	None.
Example	<pre>ruckus(config-wlan-wlansvc-012) # dot1x-mac none auth-server Ruckus-Auth-01</pre> <p>The command was executed successfully.</p> <pre>ruckus(config-wlan-wlansvc-012) #</pre>

bgscan

To enable background scanning on the WLAN, use the following command:

```
bgscan
```

Example	<pre>ruckus(config-wlan) # bgscan</pre> <p>The command was executed successfully. To save the changes, type 'end' or 'exit'.</p> <pre>ruckus(config-wlan) #</pre>
----------------	--

no bgscan

To disable background scanning on the WLAN, use the following command:

```
no bgscan
```

Example	<pre>ruckus(config-wlan) # no bgscan</pre> <p>The command was executed successfully. To save the changes, type 'end' or 'exit'.</p> <pre>ruckus(config-wlan) #</pre>
----------------	---

client-isolation

To enable client isolation, use the following command:

```
client-isolation [local|full]
```

Syntax Description	<table><tr><td>client-isolation</td><td>Enable client isolation for this WLAN</td></tr><tr><td>local</td><td>Wireless clients associated with the same AP will be unable to communicate with one another locally.</td></tr><tr><td>full</td><td>Wireless clients will be unable to communicate with each other or access any of the restricted subnets.</td></tr></table>	client-isolation	Enable client isolation for this WLAN	local	Wireless clients associated with the same AP will be unable to communicate with one another locally.	full	Wireless clients will be unable to communicate with each other or access any of the restricted subnets.
client-isolation	Enable client isolation for this WLAN						
local	Wireless clients associated with the same AP will be unable to communicate with one another locally.						
full	Wireless clients will be unable to communicate with each other or access any of the restricted subnets.						

Example	<pre>ruckus(config-wlan) # client-isolation local</pre> <p>The command was executed successfully. To save the changes, type 'end' or 'exit'.</p>
----------------	---

Configuring Controller Settings

Configure WLAN Settings Commands

```
ruckus(config-wlan) #
```

no client-isolation

To enable client isolation, use the following command:

```
no client-isolation
```

Syntax Description

no client-isolation	Disable client isolation for this WLAN
---------------------	--

Example

```
ruckus(config-wlan) # no client-isolation
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-wlan) #
```

load-balancing

To enable load balancing for this WLAN, use the following command:

```
load-balancing
```

Example

```
ruckus(config-wlan) # load-balancing
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-wlan) #
```

no load-balancing

To disable load balancing for this WLAN, use the following command:

```
no load-balancing
```

Example

```
ruckus(config-wlan) # no load-balancing
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-wlan) #
```

send-eap-failure

To enable send EAP failure messages, use the following command:

```
send-eap-failure
```

Example

```
ruckus(config-wlan) # send-eap-failure
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan) #

no send-eap-failure

To disable send EAP failure messages, use the following command:

```
no send-eap-failure
```

Example

```
ruckus(config-wlan) # no send-eap-failure
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan) #

pap-authenticator

To enable RADIUS message authenticator in PAP requests, use the following command:

```
pap-authenticator
```

Example

```
ruckus(config-wlan) # pap-authenticator
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan) #

no pap-authenticator

To disable RADIUS message authenticator in PAP requests, use the following command:

```
no pap-authenticator
```

Example

```
ruckus(config-wlan) # no pap-authenticator
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.
ruckus(config-wlan) #

nasid-type

To set the NAS ID type, use the following command:

```
nasid-type [wlan-bssid|mac-addr|user-define <WORD>]
```

Configuring Controller Settings

Configure WLAN Settings Commands

Syntax Description

nasid-type	Set the NAS ID type
wlan-bssid	Set NAS ID type WLAN-BSSID (default)
mac-addr	Set NAS ID type to Controller MAC Address
user-define <WORD>	Set NAD ID type to a user-defined string

Default

wlan-bssid

Example

```
ruckus(config-wlan)# nasid-type wlan-bssid  
The command was executed successfully. To save the changes, type  
'end' or 'exit'.  
ruckus(config-wlan)#[/pre>
```

priority low

To set the WLAN priority to low, use the following command:

```
priority low
```

priority high

To set the WLAN priority to high, use the following command:

```
priority high
```

web-auth

To enable Web authentication, use the following command:

```
web-auth [local | name <WORD>]
```

Syntax Description

web-auth	Enable Web authentication
local	Use local database as auth server
name	Specify an external auth server
<WORD>	The AAA server to use for Web authentication

Defaults

None.

Example

```
ruckus# config  
ruckus(config)# wlan wlan-123  
ruckus(config-wlan-wlan-123)# web-auth Ruckus-RADIUS  
The command was executed successfully.  
ruckus(config-wlan-wlan-123)#[/pre>
```

no web-auth

To disable Web authentication, use the following command:

```
no web-auth
```

Syntax Description	no web-auth	Disable Web authentication
---------------------------	-------------	----------------------------

Defaults	None.
-----------------	-------

Example	<pre>ruckus# config ruckus(config)# wlan wlan-123 ruckus(config-wlan-wlan-123)# no web-auth</pre> <p>The command was executed successfully.</p>
----------------	---

grace-period

To set the grace period (idle timeout), use the following command:

```
grace-period <NUMBER>
```

Syntax Description	grace-period	Enables and Sets a maximum time (in minutes) for which users must re-authenticate after disconnecting.
---------------------------	--------------	--

Defaults	Disabled.
-----------------	-----------

Example	<pre>ruckus(config-wlan)# grace-period 20</pre> <p>The command was executed successfully. To save the changes, type 'end' or 'exit'.</p>
----------------	--

no grace-period

To disable the grace period (idle timeout), use the following command:

```
no grace-period <NUMBER>
```

Syntax Description	no grace-period	Disables grace period timeout.
---------------------------	-----------------	--------------------------------

Defaults	Disabled.
-----------------	-----------

Configuring Controller Settings

Configure WLAN Settings Commands

Example

```
ruckus(config-wlan)# no grace-period
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

acct-server

To set the accounting server, use the following command:

```
acct-server <WORD>
```

Syntax Description

acct-server	Configure the AAA server
-------------	--------------------------

<WORD>	Set the AAA server to this address
--------	------------------------------------

Defaults

None.

Example

```
ruckus# config
```

```
ruckus(config)# wlan wlan-123
```

```
ruckus(config-wlan-wlan-123)# acct-server Ruckus-Acct-01
```

The command was executed successfully.

acct-server interim-update

To configure the interim update frequency (in minutes) of the AAA server, use the following command:

```
acct-server <WORD> interim-update <NUMBER>
```

Syntax Description

acct-server	Configure the interim update frequency of the AAA server
-------------	--

interim-update{minutes}	Set the update frequency to this value (in minutes)
-------------------------	---

Defaults

5 (minutes)

Example

```
ruckus# config
```

```
ruckus(config)# wlan wlan-123
```

```
ruckus(config-wlan-wlan-123)# acct-server Ruckus-Acct-01
```

```
interim-update 5
```

The command was executed successfully.

no acct-server

To disable the AAA server, use the following command:

```
no acct-server
```

Syntax Description

no acct-server	Disable AAA server authentication
----------------	-----------------------------------

Defaults

None.

Example

```
ruckus# config
ruckus(config)# wlan wlan-123
ruckus(config-wlan-wlan-123)# no acct-server
The command was executed successfully.
```

inactivity-timeout

To enable and set the inactivity timeout, use the following command:

```
inactivity-timeout <NUMBER>
```

Syntax Description

inactivity-timeout	Enable and set the inactivity timeout
<NUMBER>	Set the inactivity timeout in minutes

Defaults

5

Example

```
ruckus(config-wlan)# inactivity-timeout 15
The command was executed successfully. To save the changes, type
'end' or 'exit'.
ruckus(config-wlan)#

```

vlan

To enable the VLAN and set the VLAN ID, use the following command:

```
vlan <NUMBER>
```

Syntax Description

vlan	Enable VLAN
<NUMBER>	Set the VLAN ID to this value

Defaults

None.

Configuring Controller Settings

Configure WLAN Settings Commands

Example

```
ruckus# config
ruckus(config)# wlan wlan-123
ruckus(config-wlan-wlan-123)# vlan 12
The command was executed successfully.
```

dynamic-vlan

To enable dynamic VLAN, use the following command:

```
dynamic-vlan
```

Syntax Description

dynamic-vlan	Enable dynamic VLAN
--------------	---------------------

Notes

Dynamic VLAN can be enabled or disabled in the following two conditions: 1) The authentication method is '802.1X/EAP' or 'MAC Address', Encryption method is WPA, WPA2, WPA mixed, or none. 2) Authentication method is 'Open', Encryption method is WPA, WPA2 (Algorithm may not be Auto), enable Zero-IT Activation, enable Dynamic PSK.

Example

```
ruckus(config-wlan)# dynamic-vlan
The command was executed successfully. To save the changes, type
'end' or 'exit'
```

no dynamic-vlan

To disable dynamic VLAN, use the following command:

```
no dynamic-vlan
```

Syntax Description

no dynamic-vlan	Disable dynamic VLAN
-----------------	----------------------

Defaults

Disabled.

Example

```
ruckus(config-wlan)# no dynamic-vlan
The command was executed successfully. To save the changes, type
'end' or 'exit'.
```

mcast-filter

To enable multicast filter for the WLAN, use the following command:

```
mcast-filter
```

no mcast-filter

To disable multicast filter for the WLAN, use the following command:

```
no mcast-filter
```

hide-ssid

To hide an SSID from wireless users, use the following command. Wireless users who know the SSID will still be able to connect to the WLAN service.

```
hide-ssid
```

Syntax Description	hide-ssid	Hide SSID from wireless users
Defaults	None.	
Example	<pre>ruckus# config ruckus(config)# wlan wlan-123 ruckus(config-wlan-wlan-123)# hide-ssid</pre>	The command was executed successfully.

no hide-ssid

To unhide or broadcast an SSID to wireless users, use the following command:

```
no hide-ssid
```

Syntax Description	no hide-ssid	Broadcast SSID to wireless users
Defaults	None.	
Example	<pre>ruckus# config ruckus(config)# wlan wlan-123 ruckus(config-wlan-wlan-123)# no hide-ssid</pre>	The command was executed successfully

ofdm-only

To enable support of OFDM rates only, use the following command:

```
ofdm-only
```

no ofdm-only

To disable OFDM only rates, use the following command:

Configuring Controller Settings

Configure WLAN Settings Commands

```
no ofdm-only
```

admission-control

To enable Call Admission Control, use the following command:

```
admission-control
```

no admission-control

To disable Call Admissino Control, use the following command:

```
no admission-control
```

bss-minrate

To set the minimum BSS transmission rate of the WLAN (in Mbps), use the following command:

```
bss-minrate <NUMBER>
```

Syntax Description

bss-minrate	Set the minimum BSS transmission rate in Mbps.
<NUMBER>	Minimum BSS transmission rate

Defaults

None.

Example

```
ruckus(config-wlan)# bss-minrate 2
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-wlan)#

```

no bss-minrate

To disable the minimum BSS transmission rate for the WLAN, use the following command:

```
no bss-minrate
```

tunnel-mode

To enable tunnel mode, use the following command:

```
tunnel-mode
```

Syntax Description

tunnel-mode	Enable tunnel mode
-------------	--------------------

Defaults

None.

Example

```
ruckus# config
ruckus(config)# wlan wlan-123
ruckus(config-wlan-wlan-123)# tunnel-mode
The command was executed successfully.
```

no tunnel-mode

To disable the tunnel mode, use the following command:

```
no tunnel-mode
```

Syntax Description

no tunnel-mode	Disable the tunnel mode
----------------	-------------------------

Defaults

None.

Example

```
ruckus# config
ruckus(config)# wlan wlan-123
ruckus(config-wlan-wlan-123)# no tunnel-mode
The command was executed successfully.
```

dhcp-relay

To set the DHCP relay server to the specified address (tunneled WLANs only), use the following command:

```
dhcp-relay <WORD>
```

no dhcp-relay

To disable DHCP relay, use the following command:

```
no dhcp-relay
```

option82

To enable DHCP option82, use the following command:

```
option82
```

no option82

To disable DHCP option 82, use the following command:

```
no option82
```

Configuring Controller Settings

Configure WLAN Settings Commands

sta-info-extraction

To enable station information extraction (client fingerprinting), use the following command:

```
sta-info-extraction
```

no sta-info-extraction

To disable station information extraction (client fingerprinting), use the following command:

```
no sta-info-extraction
```

max-clients

To set the maximum number of clients for a specific WLAN, use the following command:

```
max-clients <NUMBER>
```

Syntax Description

max-clients	Configure the maximum number of clients that the WLAN can support
<NUMBER>	Set the maximum clients to this value

Defaults

None.

Example

To set the maximum number of clients on WLAN-123 to 50, enter this command:

```
ruckus# config
ruckus(config)# wlan wlan-123
ruckus(config-wlan-wlan-123)# max-clients 50
The command was executed successfully.
```

802dot11d

To enable 802.11d for the WLAN, use the following command:

```
802dot11d
```

no 802dot11d

To disable 802.11d for the WLAN, use the following command:

```
no 802dot11d
```

auto-proxy

To enable auto-proxy and set the location of the wpad.dat file, use the following command:

auto-proxy [<wpad-saved-on-zd | wpad-saved-on-external-server>]
url <WORD>

Syntax Description

auto-proxy	Enable auto-proxy and specify the location of the wpad.dat file
wpad-saved-on-ZD	WPAD.DAT file is saved on ZoneDirector
wpad-saved-on-external-server	WPAD.DAT file is saved on an external server
url	Specify the WPAD URL configured on DHCP/DNS server
<WORD>	Auto-proxy path and file name

Defaults

None.

Example

ruckus(config-wlan)# **auto-proxy wpad-saved-on-zd url 192.168.0.2/wpad.dat**

The file has been loaded into ZoneDirector successfully, Please use 'import' to apply it
ruckus(config-wlan) #

no auto-proxy

To disable auto-proxy, use the following command:

no auto-proxy

import

To import the wpad.dat file into ZoneDirector, use the following command:

import

pmk-cache

To set the PMK cache time to the specified number in minutes (1~720 minutes), use the following command:

pmk-cache timeout <NUMBER>

Defaults

720 minutes

no pmk-cache

To disable PMK cache, use the following command:

no pmk-cache

Configuring Controller Settings

Configure WLAN Settings Commands

pmk-cache-for-reconnect

To apply PMK cache when client reconnects (default), use the following command:

```
pmk-cache-for-reconnect
```

no pmk-cache-for-reconnect

To disable application of PMK caching when client reconnects, use the following command:

```
no pmk-cache-for-reconnect
```

When “no pmk-cache-for-reconnect” is set, the controller attempts to look up PMK cache for roaming clients only, so every client reconnection requires a full reauthentication. A graceful roaming (disconnect before connecting to the roam-to AP) is not regarded as roaming from the controller’s perspective.

Defaults

Enabled

roaming-acct-interim-update

To enable accounting interim-updates when a client roams, use the following command:

```
roaming-acct-interim-update
```

When “roaming-acct-interim-update” is set, all traffic and session-id data from the original session is carried over to the new session.

Defaults

Disabled.

no roaming-acct-interim-update

To disable accounting interim updates when a client roams (default: disabled), use the following command:

```
no roaming-acct-interim-update
```

zero-it-activation

To enable Zero-IT activation, use the following command:

```
zero-it-activation
zero-it
```

Syntax Description

zero-it-activation	Enable Zero-IT activation
zero-it	Enable Zero-IT activation

Defaults	Disabled.				
Example	<pre>ruckus(config-wlan)# zero-it-activation</pre> <p>The command was executed successfully. To save the changes, type 'end' or 'exit'.</p>				
no zero-it-activation	<p>To disable Zero-IT activation, use the following command:</p> <pre>no zero-it-activation no zero-it</pre>				
Syntax Description	<hr/> <table><tr><td>no zero-it-activation</td><td>Disable Zero-IT activation</td></tr><tr><td>no zero-it</td><td>Disable Zero-IT activation</td></tr></table> <hr/>	no zero-it-activation	Disable Zero-IT activation	no zero-it	Disable Zero-IT activation
no zero-it-activation	Disable Zero-IT activation				
no zero-it	Disable Zero-IT activation				
Defaults	Disabled.				
Example	<pre>ruckus(config-wlan)# no zero-it</pre> <p>The command was executed successfully. To save the changes, type 'end' or 'exit'.</p>				
dynamic-psk enable	<p>To enable Dynamic Pre-Shared Keys, use the following command:</p> <pre>dynamic-psk enable</pre>				
Syntax Description	<hr/> <table><tr><td>dynamic-psk enable</td><td>Enable Dynamic PSK</td></tr></table> <hr/>	dynamic-psk enable	Enable Dynamic PSK		
dynamic-psk enable	Enable Dynamic PSK				
Defaults	None.				
Example	<pre>ruckus(config-wlan)# dynamic-psk enable</pre> <p>The DPSK can't be enabled or disabled when the wlan type is not Standard Usage and Encryption method is not WPA or WPA2 and Authentication method is not open and Zero-IT is not enabled.</p> <pre>ruckus(config-wlan)# zero-it</pre> <p>The command was executed successfully. To save the changes, type 'end' or 'exit'.</p> <pre>ruckus(config-wlan)# dynamic-psk enable</pre> <p>The command was executed successfully. To save the changes, type 'end' or 'exit'.</p>				

Configuring Controller Settings

Configure WLAN Settings Commands

```
ruckus (config-wlan) #
```

dynamic-psk passphrase-len

To set the Dynamic Pre-Shared Key passphrase length, use the following command:

```
dynamic-psk passphrase-len <NUMBER>
```

no dynamic-psk

To disable Dynamic Pre-Shared Keys on the WLAN, use the following command:

```
no dynamic-psk
```

limit-dpsk

To enable Dynamic PSK limits and set the max number of devices per user, use the following command:

```
limit-dpsk <NUMBER>
```

no limit-dpsk

To disable Dynamic PSK limits, use the following command:

```
no limit-dpsk
```

no l2acl

To disable Layer 2 Access Control Lists, use the following command:

```
no l2acl
```

no l3acl

To disable Layer 3/4 ACLs, use the following command:

```
no l3acl
```

no l3acl-ipv6

To disable Layer 3/4 IPv6 ACLs, use the following command:

```
no l3acl-ipv6
```

no dvcpcy

To disable device policy for this WLAN, use the following command:

```
no dvcpcy
```

rate-limit

To set the rate limiting for the WLAN, use the following command:

```
rate-limit uplink <NUMBER> downlink <NUMBER>
```

Syntax Description

rate-limit	Set the rate limit
uplink	Set the uplink rate limit
downlink	Set the downlink rate limit
<NUMBER>	Set the rate limiting to the value specified. Valid values include 0.10 and between 0.25~20.00 in 0.25 increments.

Defaults

None.

Example

```
ruckus(config-wlan)# rate-limit uplink 20 downlink 20  
The command was executed successfully. To save the changes, type  
'end' or 'exit'.  
ruckus(config-wlan)#+
```

no rate-limit

To disable the rate limit, use the following command:

```
no rate-limit
```

Syntax Description

no rate-limit	Disable rate limiting for the WLAN
---------------	------------------------------------

Defaults

Disabled.

Example

```
ruckus(config-wlan)# no rate-limit  
The command was executed successfully. To save the changes, type  
'end' or 'exit'.  
ruckus(config-wlan)#+
```

mac-auth-8021x-format

To set the MAC auth MAC address format to 802.1X format (00-10-A4-23-19-C0), use the following command:

```
mac-auth-8021x-format
```

Example

```
ruckus(config-wlan)# mac-auth-8021x-format  
The command was executed successfully. To save the changes, type  
'end' or 'exit'.  
ruckus(config-wlan)#+
```

Configuring Controller Settings

Configure WLAN Settings Commands

no mac-auth-8021x-format

To set the MAC auth MAC address format to default format (0010a42319c0), use the following command:

```
no mac-auth-8021x-format
```

acl

To apply an Access Control List to this WLAN, use the following command:

```
acl [<12acl>|<13acl>|<13acl-ipv6>] <WORD>
```

Syntax Description

acl	Apply a previously saved ACL to this WLAN
l2acl	Apply a Layer 2 ACL
l3acl	Apply a Layer 3/Layer 4/IP ACL
l3acl-ipv6	Apply an IPv6 L3/L4/IP ACL
<WORD>	The name of the ACL

Defaults

None.

Example

```
ruckus(config-wlan)# acl 12acl acl1
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-wlan) #
```

acl dvcpcy

To apply a Device Policy to the WLAN, use the following command:

```
acl dvcpcy <WORD>
```

acl prece

To apply a Precedence Policy to the WLAN, use the following command:

```
acl prece <WORD>
```

qos classification

To enable Quality of Service classification, use the following command:

```
qos classification
```

no qos classification

To disable Quality of Service classification, use the following command:

```
no qos classification
```

qos heuristics-udp

To enable QoS heuristics for UDP traffic, use the following command:

```
qos heuristics-udp
```

no qos heuristics-udp

To disable QoS heuristics for UDP traffic, use the following command:

```
no qos heuristics-udp
```

qos directed-multicast

To enable QoS directed multicast, use the following command:

```
qos directed-multicast
```

no qos directed-multicast

To disable QoS directed multicast, use the following command:

```
no qos directed-multicast
```

qos igmp-snooping

To disable QoS directed multicast, use the following command:

```
qos igmp-snooping
```

no qos igmp-snooping

To disable QoS IGMP snooping, use the following command:

```
no qos igmp-snooping
```

qos mld-snooping

To enable QoS MLD snooping, use the following command:

```
no qos mld-snooping
```

no qos mld-snooping

To disable QoS MLD snooping, use the following command:

```
no qos mld-snooping
```

qos tos-classification

To enable QoS TOS classification, use the following command:

```
qos tos-classification
```

Configuring Controller Settings

Configure WLAN Settings Commands

no qos tos-classification

To disable QoS TOS classification, use the following command:

```
no qos tos-classification
```

qos priority high

To set QoS priority to 'high', use the following command:

```
qos priority high
```

qos priority low

To set QoS priority to 'low', use the following command:

```
qos priority low
```

qos directed-threshold

To set the QoS directed threshold, use the following command:

```
qos directed-threshold <NUMBER>
```

disable-dgaf

To disable Downstream Group-Address Frame Forwarding, use the following command (Hotspot 2.0 WLAN only):

```
disable-dgaf
```

no disable-dgaf

To enable Downstream Group-Address Frame Forwarding, use the following command (Hotspot 2.0 WLAN only):

```
no disable-dgaf
```

proxy-arp

To enable Proxy ARP service for the WLAN, use the following command:

```
proxy-arp
```

no proxy-arp

To disable Proxy ARP service for the WLAN, use the following command:

```
no proxy-arp
```

ignor-unauth-stats

To enable ignoring unauthorized client statistics, use the following command:

```
ignor-unauth-stats
```

no ignor-unauth-stats

To disable ignoring unauthorized client statistics, use the following command:

```
no ignor-unauth-stats
```

show

To display the WLAN settings, use the following command:

```
show
```

Syntax Description

show	Display WLAN settings
------	-----------------------

Defaults

None.

Example

```
ruckus(config)# wlan ruckus1
The WLAN service 'ruckus1' has been loaded. To save the WLAN service,
type 'end' or 'exit'.
ruckus(config-wlan)# show
WLAN Service:
ID:
2:
NAME = ruckus1
Tx. Rate of Management Frame(2.4GHz) = 2.0Mbps
Beacon Interval = 100ms
SSID = ruckus1
Description =
Type = Standard Usage
Authentication = open
Encryption = none
Web Authentication = Disabled
Authentication Server = Disabled
Accounting Server = Disabled
Called-Station-Id type = wlan-bssid
Tunnel Mode = Disabled
DHCP relay = Disabled
Background Scanning = Enabled
Max. Clients = 100
Client Isolation = None
Zero-IT Activation = Disabled
Priority = High
Load Balancing = Disabled
Rate Limiting Uplink = Disabled
```

Configuring Controller Settings

Configure WLAN Group Settings Commands

```
Rate Limiting Downlink = Disabled
Auto-Proxy configuration:
    Status = Disabled
Inactivity Timeout:
    Status = Enabled
    Timeout = 5 Minutes
VLAN-ID = 1
Dynamic VLAN = Disabled
Closed System = Disabled
OFDM-Only State = Disabled
Multicast Filter State = Disabled
802.11d State = Disabled
DHCP Option82 State = Disabled
Ignore unauthorized client statistic = Disabled
STA Info Extraction State = Enabled
BSS Minrate = Disabled
Call Admission Control State = Disabled
PMK Cache Timeout= 720 minutes
PMK Cache for Reconnect= Enabled
NAS-ID Type= wlan-bssid
Roaming Acct-Interim-Update= Disabled
PAP Message Authenticator = Enabled
Send EAP-Failure = Disabled
L2/MAC = No ACLS
L3/L4/IP Address = No ACLS
L3/L4/IPv6 Address = No ACLS
Precedence = precedence1
Proxy ARP = Enabled
Device Policy = No ACLS

ruckus(config-wlan) #
```

Configure WLAN Group Settings Commands

Use the `wlan-group` commands to configure the settings of a particular WLAN group.

wlan-group

To create a new WLAN group or update an existing WLAN group, use the following command:

```
wlan-group <WORD>
```

Syntax Description

wlan-group	Configure the WLAN group
<WORD>	Name of the WLAN group

Defaults

Default.

Example

```
ruckus# config
ruckus(config)# wlan-group wlangrp-01
The WLAN group has been created. To save the WLAN group, type end
or exit.
```

no wlan-group

To delete a WLAN group from the list, use the following command:

```
no wlan-group <WORD>
```

Syntax Description

no wlan-group	Delete the WLAN group
<WORD>	Name of the WLAN group

Defaults

None.

Example

```
ruckus(config)# no wlan-group wlan-grp-01
The WLAN group 'wlan-grp-01' has been removed.
ruckus(config) #
```

abort

To exit the wlan-group context without saving changes, use the **abort** command. Enter this command from within the context of the WLAN group that you are configuring.

```
abort
```

Syntax Description

abort	Exit the WLAN group without saving changes
-------	--

Defaults

None.

Example

```
ruckus# config
ruckus(config)# wlan-group wlangrp-01
ruckus(config-wlangrp-01)# abort
```

Configuring Controller Settings

Configure WLAN Group Settings Commands

No changes have been saved.

end

To save changes to the WLAN group settings and exit the wlan-group context, use the following command. Enter this command from within the context of the WLAN group that you are configuring.

end

Syntax Description

end	Save changes, and then exit the WLAN group
-----	--

Defaults

None.

Example

```
ruckus# config
ruckus(config)# wlan-group wlangrp-01
ruckus(config-wlangrp-wlangrp-01)# end
The WLAN group 'hello-wlangrp' has been updated.
Your changes have been saved.
```

exit

To save changes to the WLAN group settings and exit the wlan-group context, use the exit command. Enter this command from within the context of the WLAN group that you are configuring.

exit

Syntax Description

exit	Save changes, and then exit the WLAN group
------	--

Defaults

None.

Example

```
ruckus# config
ruckus(config)# wlan-group wlangrp-01
ruckus(config-wlangrp-wlangrp-01)# exit
The WLAN group 'wlangrp-01' has been updated.
Your changes have been saved.
```

quit

To exit the wlan-group context without saving changes, use the following command. Enter this command from within the context of the WLAN group that you are configuring.

quit

Syntax Description

quit	Exit the WLAN group without saving changes
------	--

Defaults

None.

Example

```
ruckus# config
ruckus(config)# wlan-group wlangrp-01
ruckus(config-wlangrp-wlangrp-01)# quit
No changes have been saved.
```

name

To set the WLAN group name, use the following command. Enter this command from within the context of the WLAN group that you are configuring.

```
name {WLAN group name}
```

Syntax Description

name	Configure the WLAN group name
{WLAN group name}	Set the WLAN group name to this value

Defaults

None.

Example

```
ruckus# config
ruckus(config)# wlan-group wlangrp-01
ruckus(config-wlangrp-wlangrp-01)# name hello-wlangrp
The command was executed successfully.
```

description

To set the WLAN group description, use the following command. Enter this command from within the context of the WLAN group that you are configuring.

```
description {WLAN group description}
```

Syntax Description

description	Configure the WLAN group description
{WLAN group description}	Set the WLAN group description to this value

Defaults

None.

Configuring Controller Settings

Configure WLAN Group Settings Commands

Example

```
ruckus# config
ruckus(config)# wlan-group wlangrp-01
ruckus(config-wlangrp-wlangrp-01)# description my-description-123
The command was executed successfully.
```

wlan

To add a WLAN service to the WLAN group, use the following command. Enter this command from within the context of the WLAN group that you are configuring.

```
wlan <WORD>
```

Syntax Description

wlan	Add a WLAN to the WLAN group
<WORD>	Name of the WLAN to be added

Defaults

None.

Example

```
rruckus(config-wlangrp)# wlan ruckus1
The command was executed successfully. To save the changes, type
'end' or 'exit'.
ruckus(config-wlangrp)# show
WLAN Group:
  ID:
  :
  Name= wlangroup1
  Description=
  WLAN Service:
    WLAN1:
      NAME= ruckus1
      VLAN=
```



```
ruckus(config-wlangrp) #
```

no wlan

To remove a WLAN service from the WLAN group, use the following command. Enter this command from within the context of the WLAN group that you are configuring.

```
no wlan <WORD>
```

Syntax Description

no wlan	Delete an existing WLAN service from the WLAN group
---------	---

	<code><WORD></code>	Name of the WLAN to be removed
Defaults		None.
Example		<pre>ruckus(config-wlangrp) # no wlan ruckus1 The command was executed successfully. To save the changes, type 'end' or 'exit'. ruckus(config-wlangrp) #</pre>
wlan wlan override none		
To add a WLAN service to the WLAN group and set the VLAN tag to 'No Change', use the following command. Enter this command from within the context of the WLAN group that you are configuring.		
<pre>wlan <WORD> wlan override none</pre>		
Syntax Description		
	<code>wlan <WORD></code>	Add the WLAN to the WLAN group
	<code>vlan override none</code>	Set the VLAN tag to No Change
Defaults		None.
Example		<pre>ruckus(config-wlangrp) # wlan ruckus1 wlan override none The command was executed successfully. To save the changes, type 'end' or 'exit'. ruckus(config-wlangrp) #</pre>
wlan wlan override tag		
To add a WLAN service to the WLAN group and set the VLAN tag to the specified VLAN, use the following command:		
<pre>wlan <NAME> wlan override tag <NUMBER></pre>		
Syntax Description		
	<code>wlan <NAME></code>	Add the <NAME> to the WLAN group
	<code>vlan override tag <NUMBER></code>	Set the VLAN tag of <NAME> to the specified <NUMBER>
Defaults		None.

Configuring Controller Settings

Configure Role Commands

Example

```
ruckus(config-wlangrp) # wlan ruckus1 vlan override tag 12  
The command was executed successfully. To save the changes, type  
'end' or 'exit'.  
ruckus(config-wlangrp) #
```

show

To display WLAN group settings, use the following command:

```
show
```

Defaults

```
ruckus(config-wlangrp) # show  
WLAN Group:  
ID:  
1:  
Name= Default  
Description= Default WLANS for Access Points  
WLAN Service:  
WLAN1:  
NAME= Ruckus1  
VLAN=
```



```
ruckus(config-wlangrp) #
```

Configure Role Commands

Use the `role` commands to configure user roles on the controller. To run these commands, you must first enter the `config-role` context.

role

To create a new role or modify an existing role, use the following command:

```
role <WORD>
```

Syntax Description

role	Create or modify a user role
<WORD>	Name of role

Defaults

None.

Example

```
ruckus(config) # role role1  
The role entry 'role1' has been created
```

```
ruckus(config-role) #
```

no role

To delete a role entry from the list, use the following command:

```
no role <WORD>
```

Syntax Description

no role	Delete a user role
<WORD>	Name of role

Defaults

None.

Example

```
ruckus(config)# no role role1
The Role 'role1' has been deleted.
ruckus(config) #
```

abort

To exit the config-role context without saving changes, use the **abort** command. Enter this command from within the context of the role that you are configuring.

```
abort
```

Syntax Description

abort	Exit the role without saving changes
-------	--------------------------------------

Defaults

None.

Example

```
ruckus(config-role)# abort
No changes have been saved.
ruckus(config) #
```

end

To save changes, and then exit the config-role context, use the following command:

```
end
```

Syntax Description

end	Save changes, and then exit the context
-----	---

Defaults

None.

Configuring Controller Settings

Configure Role Commands

Example

```
ruckus(config-role)# end  
The Role entry has saved successfully.  
Your changes have been saved.  
ruckus(config)#
```

exit

To save changes, and then exit the config-role context, use the following command:

```
exit
```

Syntax Description

exit	Save changes, and then exit the context
------	---

Defaults

None.

Example

```
ruckus(config-role)# exit  
The Role entry has saved successfully.  
Your changes have been saved.  
ruckus(config)#
```

quit

To exit the config-role context without saving changes, use the **quit** command. Enter this command from within the context of the role that you are configuring.

```
quit
```

Syntax Description

quit	Exit the role without saving changes
------	--------------------------------------

Defaults

None.

Example

```
ruckus(config-role)# quit  
No changes have been saved.  
ruckus(config)#
```

name

To set the name of a user role, use the following command:

```
name <WORD>
```

Syntax Description

name	Set the name of a user role
<WORD>	Set to this role

Defaults

None.

Example

ruckus(config-role)# **name guest33**

The command was executed successfully. To save the changes, type 'end' or 'exit'.

description

To set the description for a user role, use the following command:

description <WORD>

Syntax Description

description	Set the description of a user role
<WORD>	Set to this description

Defaults

None.

Example

ruckus(config-role)# **description testforCLI**

The command was executed successfully. To save the changes, type 'end' or 'exit'.

group-attributes

To set the group attributes of a user role, use the following command:

group-attributes <WORD>

Syntax Description

group-attributes	Set the attributes of a user role
<WORD>	Set to this attribute

Defaults

None.

Example

ruckus(config-role)# **group-attributes ruckus1**

The command was executed successfully. To save the changes, type 'end' or 'exit'.

Configuring Controller Settings

Configure Role Commands

wlan-allowed

To set the WLANs to which a user role will have access, use the following command:

```
wlan-allowed [all | specify-wlan]
```

Syntax Description

wlan-allowed	Set the WLANs to which a role will have access
all	Grant access to all WLANs
specify-wlan	Grant access to a specific WLAN

Defaults

None.

Example

```
ruckus(config-role)# wlan-allowed all
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-role)# wlan-allowed specify-wlan
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

no specify-wlan-access

To remove a particular WLAN from the list of WLANs that a user role can access, use the following command:

```
no specify-wlan-access <WORD/SSID>
```

Syntax Description

no specify-wlan-access	Remove access to a WLAN by a user role
<WORD/SSID>	Remove access to this WLAN

Defaults

None.

Example

```
ruckus(config-role)# no specify-wlan-access joejoe98
```

The wlan 'joejoe98' has been removed from the Role.

specify-wlan-access

To add a particular WLAN to the list of WLANs that a user role can access, use the following command:

```
specify-wlan-access <wlan_ssid>
```

Syntax Description

specify-wlan-access	Add access to a WLAN by a user role
<wlan_ssid>	Add access to this WLAN

Defaults	None.
-----------------	-------

Example	<pre>ruckus(config-role)# specify-wlan-access joejoe98</pre> <p>The wlan 'joejoe98' has been added to the Role.</p>
----------------	--

no guest-pass-generation

To remove guest pass generation privileges from a user role, use the following command:

```
no guest-pass-generation
```

Syntax Description	no guest-pass-generation	Remove guest pass generation privileges from a user role
---------------------------	--------------------------	--

Defaults	None.
-----------------	-------

Example	<pre>ruckus(config-role)# no guest-pass-generation</pre> <p>The command was executed successfully. To save the changes, type 'end' or 'exit'.</p>
----------------	--

guest-pass-generation

To add guest pass generation privileges to a user role, use the following command:

```
guest-pass-generation
```

Syntax Description	guest-pass-generation	Add guest pass generation privileges to a user role
---------------------------	-----------------------	---

Defaults	None.
-----------------	-------

Example	<pre>ruckus(config-role)# guest-pass-generation</pre> <p>The command was executed successfully. To save the changes, type 'end' or 'exit'.</p>
----------------	---

no admin

To remove ZoneDirector administration privileges from a user role, use the following command:

```
no admin
```

Configuring Controller Settings

Configure Role Commands

Syntax Description	no admin	Remove ZoneDirector administration privileges from a user role
---------------------------	----------	--

Defaults	None.
-----------------	-------

Example	ruckus(config-role)# no admin The command was executed successfully. To save the changes, type 'end' or 'exit'.
----------------	---

admin

To add ZoneDirector administration privileges to a user role, use the following command:

```
admin [super | operator | monitoring]
```

Syntax Description	admin	Add ZoneDirector administration privileges to a user role
	super	Sets to Super (Perform all configuration and management tasks)
	operator	Sets to Operator (Change settings affecting single AP's only)
	monitoring	Sets to Monitoring (Monitoring and viewing operation status only)

Defaults	None.
-----------------	-------

Example	ruckus(config-role)# admin super The command was executed successfully. To save the changes, type 'end' or 'exit'.
----------------	--

show

To display the settings of a role, use the following command:

```
show
```

Syntax Description	show	Display the settings of a role
---------------------------	------	--------------------------------

Defaults	None.
-----------------	-------

Example

```
ruckus(config-role)# show
Role:
  ID:
  :
  Name= role1
  Description=
  Group Attributes=
  Guest Pass Generation= Disallowed
  ZoneDirector Administration:
    Status= Disallowed
  Allow All WLANs:
    Mode= Allow Specify WLAN access

ruckus(config-role)#

```

Configure User Commands

Use the user commands to configure a user's name, password, and role. To run these commands, you must first enter the config-user context.

user

To create a user or modify an existing user and enter the config-user context, use the following command:

```
user <WORD>
```

Syntax Description

user	Create or modify a user entry
<WORD>	Name of the user

Defaults

None.

Example

```
rruckus(config)# user johndoe
The User entry 'johndoe' has been created.
ruckus(config-user)#

```

no user

To delete a user record, use the following command:

```
no user <WORD>
```

Configuring Controller Settings

Configure User Commands

Syntax Description

user	Create or modify a user entry
<WORD>	Name of the user

Defaults

None.

Example

```
ruckus(config)# no user johndoe  
The User 'johndoe' has been deleted.  
ruckus(config)#[/pre>
```

abort

To exit the config-user context without saving changes, use the **abort** command. Enter this command from within the context of the user that you are configuring.

```
abort
```

Syntax Description

abort	Exit the user settings without saving changes
-------	---

Defaults

None.

Example

```
ruckus(config-user)# abort  
No changes have been saved.  
ruckus(config)#[/pre>
```

end

To save changes, and then exit the config-user context, use the following command:

```
end
```

Syntax Description

end	Save changes, and then exit the context
-----	---

Defaults

None.

Example

```
ruckus(config-user)# end  
The User entry has saved successfully.  
Your changes have been saved.  
ruckus(config)#[/pre>
```

exit

To save changes, and then exit the config-user context, use the following command:

```
exit
```

Syntax Description

exit	Save changes, and then exit the context
------	---

Defaults

None.

Example

```
ruckus(config-user)# exit
The User entry has saved successfully.
Your changes have been saved.
ruckus(config)#
```

quit

To exit the config-user context without saving changes, use the quit command. Enter this command from within the context of the user that you are configuring.

```
quit
```

Syntax Description

quit	Exit the user settings without saving changes
------	---

Defaults

None.

Example

```
ruckus(config-role)# quit
No changes have been saved.
ruckus(config)#
```

user-name

To set the name of a user, use the following command:

```
user-name <user_name>
```

Syntax Description

user-name	Set the name of a user
<user_name>	Set to this user name

Defaults

None.

Configuring Controller Settings

Configure User Commands

Example

```
ruckus(config-user) # user-name joe1
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

full-name

To set the full name of a user, use the following command:

```
full-name <WORD>
```

Syntax Description

full-name	Set the full name of a user
<WORD>	Set to this full name

Defaults

None.

Example

```
ruckus(config-user) # full-name joejoe
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

password

To set the password of a user, use the following command:

```
password <WORD>
```

Syntax Description

password	Set the password of a user
<WORD>	Set to this password

Defaults

None.

Example

```
ruckus(config-user) # password 1234
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

role

To assign a role to a user, use the following command:

```
role <WORD>
```

Syntax Description

role	Assign a role to a user
<WORD>	Assign this role

Defaults None.

Example

```
ruckus(config-user)# role guest
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

show

To display the settings of a user, use the following command:

```
show
```

Syntax Description

show	Show user settings
------	--------------------

Defaults None.

Example

```
ruckus(config-user)# show
```

```
User:
```

```
ID:
```

```
:
```

```
User Name= joe1
```

```
Full Name= joejoe
```

```
Password= 1234
```

```
Role= guest
```

Configuring Controller Settings

Configure Guest Access Commands

Configure Guest Access Commands

Use the guest-access commands to configure the guest access settings. To run these commands, you must first enter the config-guest-access context.

guest-access

To configure Guest Access settings and enter the config-guest-access context, use the following command:

```
guest-access
```

Example

```
ruckus(config)# guest-access  
ruckus(config-guest-access) #
```

abort

To exit the config-guest-access context without saving changes, use the abort command.

```
abort
```

Syntax Description

abort	Exit the guest access settings without saving changes
-------	---

Defaults

None.

Example

```
ruckus(config-guest-access)# abort  
No changes have been saved.  
ruckus(config) #
```

end

To save changes, and then exit the config-guest-access context, use the following command:

```
end
```

Syntax Description

end	Save changes, and then exit the context
-----	---

Defaults

None.

Example

```
ruckus(config-guest-access)# end
```

```
Your changes have been saved.  
ruckus(config)#
```

exit

To save changes, and then exit the config-guest-access context, use the following command:

```
exit
```

Syntax Description

exit	Save changes, and then exit the context
------	---

Defaults

None.

Example

```
ruckus(config-guest-access) # exit  
Your changes have been saved.  
ruckus(config) #
```

quit

To exit the config-guest-access context without saving changes, use the quit command.

```
quit
```

Syntax Description

quit	Exit the guest access settings without saving changes
------	---

Defaults

None.

Example

```
ruckus(config-guest-access) # quit  
No changes have been saved.  
ruckus(config) #
```

no authentication

To disable guest access authentication, use the following command:

```
no authentication
```

Syntax Description

exit	Disable guest access authentication
------	-------------------------------------

Defaults

None.

Configuring Controller Settings

Configure Guest Access Commands

Example

```
ruckus(config-guest-access)# no authentication  
The command was executed successfully.
```

authentication guest-pass

To allow multiple users to share a single guest pass, use the following command:

```
authentication guest-pass [shared | no-shared]
```

Syntax Description

authentication guest-pass	Configure guest pass authentication
---------------------------	-------------------------------------

shared	Allow multiple users to share a single guest pass
--------	---

no-shared	Allow only a single user to use a guest pass
-----------	--

Defaults

None.

Example

```
ruckus(config-guest-access)# authentication guest-pass shared  
The command was executed successfully.
```

no term-of-use

To hide the Terms of Use text on the guest pass access page, use the following command:

```
no term-of-use
```

Syntax Description

no term-of-use	Hide Terms of Use
----------------	-------------------

Defaults

None.

Example

```
ruckus(config-guest-access)# no term-of-use  
The command was executed successfully.
```

term-of-use

To display and specify the Terms of Use text on the guest pass access page, use the following command:

```
term-of-use <term_of_use_text>
```

Syntax Description

term-of-use	Display Terms of Use
-------------	----------------------

<term_of_use_text>	Use this text
--------------------	---------------

Defaults None.

Example
ruckus(config-guest-access) # **term-of-use test.guest**
The command was executed successfully.

redirect

To set the URL to which to redirect a guest user after passing authentication, use the following command:

```
redirect [original | url <start_page_url>]
```

Syntax Description

redirect	Set the URL to which the guest user will be redirected
original	Redirect user to the original page that he intended to visit
url <start_page_url>	Redirect user to a different URL. Specify the URL in <start_page_url>.

Defaults original

Example
ruckus(config-guest-access) # **redirect url
http://www.ruckuswireless.com**
The command was executed successfully.

auth-server

To set the authentication server for guest user authentication, use the following command:

```
auth-server [local | name <auth_server_name>]
```

Syntax Description

auth-server	Set the authentication server for guest users
local	Use the controller as the authentication server
name <auth_server_name>	Use an external authentication server. Specify the authentication server name in <auth_server_name>.

Defaults local

Example
ruckus(config-guest-access) # **auth-server local**
The command was executed successfully.

Configuring Controller Settings

Configure Guest Access Commands

guestpass-effective

To set the duration during which the guest pass will be effective, use the following command:

```
guestpass-effective [now | first-use-expired <NUMBER>]
```

Syntax Description

guestpass-effective	Set the guest pass effectivity period
now	Set the guest pass effective as soon as it is generated
first-use-expired <NUMBER>	Set the guest pass to be effective upon first use and to expire after a specified number of days.

Defaults

now

Example

```
ruckus(config-guest-access) # guestpass-effective first-use-expired 4
```

The command was executed successfully.

welcome-text

To configure the text to display on the guest access user login page, use the following command:

```
welcome-text <WORD>
```

Syntax Description

welcome-text	Configure the welcome message
<WORD>	Use this as the welcome message

Defaults

Welcome to the Guest Access login page.

Example

```
ruckus(config-guest-access) # welcome-text "Welcome to the Guest Access Login Page"
```

The command was executed successfully.

```
ruckus(config-guest-access) #
```

show

To display the guest pass settings, use the following command:

```
show
```

Syntax Description

show	Display the guest pass settings
------	---------------------------------

Defaults	None.
Example	<pre>ruckus(config-guest-access)# show Guest Access: Authentication: Mode= Use guest pass authentication Multiple users to share a single guest pass= Disallowed Terms of Use: Status= Disabled Redirection: Mode= To the URL that the user intends to visit Authentication Server= Local Database Validity Period: Mode= Effective from the creation time Title= Welcome to the Guest Access Login Page Restricted Subnet Access: Name= Guest Description= Default Action if no rule is matched= Deny all by default Rules: 1: Description= Type= Deny Destination Address= local Destination Port= Any Protocol= Any 2: Description= Type= Deny Destination Address= 10.0.0.0/8 Destination Port= Any Protocol= Any 3: Description= Type= Deny Destination Address= 172.16.0.0/12 Destination Port= Any Protocol= Any 4: Description= Type= Deny Destination Address= 192.168.0.0/16</pre>

Configuring Controller Settings

Configure Guest Access Commands

```
Destination Port= Any
Protocol= Any

Restricted IPv6 Access:
  Name= Guest
  Description=
  Default Action if no rule is matched= Deny all by default
  Rules:
    1:
      Description=
      Type= Deny
      Destination Address= local
      Destination Port= Any
      Protocol= Any
      ICMPv6 Type= Any

ruckus(config-guest-access) #
```

Guest Access Restriction Commands

Use the `guest-restrict-access` commands to configure network segments to which guest access will be blocked. To run these commands, you must first enter the `config-guest-restrict-access` context.

no restrict-access-order

To delete a restrict access order, use the following command:

```
no restrict-access-order <NUMBER>
```

Syntax Description

```
no restrict-access-order Delete a restrict access order
```

```
<NUMBER> Delete this order ID
```

Defaults

None.

Example

```
ruckus(config-guest-access) # no restrict-access-order 4
```

The Restricted Subnet Access entry has been removed from the Guest Access.

restrict-access-order

To create a new restrict access order or modify an existing restrict access order, use the following command:

```
restrict-access-order <NUMBER>
```

This command enters the config-guest-restrict-access context. The following commands are available from within this context:

Syntax Description

help	Shows available commands
history	Shows a list of previously run commands.
abort	Exits the config-guest-restrict-access context without saving changes.
end	Saves changes, and then exits the config-guest-restrict-access context.
exit	Saves changes, and then exits the config-guest-restrict-access context.
quit	Exits the config-guest-restrict-access context without saving changes.
order <NUMBER>	Sets the guest access rule order.
description <WORD>	Sets the guest access rule description.
type [allow deny]	Sets the guest access rule type to allow or deny.
destination [address <ADDR> port <NUMBER/WORD>]	Sets the destination address/port of a guest access rule.
protocol <NUMBER/WORD>	Sets the protocol of a guest access rule.
show	Displays restricted subnet access settings.

abort

To exit the config-guest-restrict-access context without saving changes, use the `abort` command.

```
abort
```

Syntax Description

abort	Exit the guest access restriction settings without saving changes
-------	---

Defaults

None.

Configuring Controller Settings

Configure Guest Access Commands

Example

```
ruckus(config-guest-restrict-access)# abort  
No changes have been saved.  
ruckus(config-guest-access)#[/pre>
```

end

To save changes, and then exit the config-guest-restrict-access context, use the following command:

```
end
```

Syntax Description

end	Save changes, and then exit the context
-----	---

Defaults

None.

Example

```
ruckus(config-guest-restrict-access)# end  
The Restricted Subnet Access entry has been added to the Guest  
Access.  
Your changes have been saved.  
ruckus(config-guest-access)#[/pre>
```

exit

To save changes, and then exit the config-guest-restrict-access context, use the following command:

```
exit
```

Syntax Description

exit	Save changes, and then exit the context
------	---

Defaults

None.

Example

```
ruckus(config-guest-restrict-access)# exit  
The Restricted Subnet Access entry has been added to the Guest  
Access.  
Your changes have been saved.  
ruckus(config-guest-access)#[/pre>
```

quit

To exit the config-guest-restrict-access context without saving changes, use the **quit** command.

```
quit
```

Syntax Description	quit	Exit the guest access restriction settings without saving changes
---------------------------	------	---

Defaults	None.
-----------------	-------

Example	rukus(config-guest-restrict-access)# quit No changes have been saved. rukus(config-guest-access) #
----------------	---

show

To display guest access restriction settings, use the following command:

show

Syntax Description	show	Display guest access restriction settings
---------------------------	------	---

Defaults	None.
-----------------	-------

order

To configure the guest access rule order, use the following command:

order <NUMBER>

Syntax Description	order	Set the order of a guest access rule
	<NUMBER>	Assign the rule this order

Defaults	None.
-----------------	-------

Example	rukus(config-guest-restrict-access)# order 3 The command was executed successfully.
----------------	---

description

To set the description of a guest access rule, use the following command:

description <WORD>

Syntax Description	description	Set the description of a guest access rule
	<WORD>	Set this as description

Configuring Controller Settings

Configure Guest Access Commands

Defaults None.

Example
ruckus (config-guest-restrict-access) # **description guestd3**
The command was executed successfully.

type allow

To set the guest access rule type to 'allow', use the following command:

```
type allow
```

Syntax Description

type	Set the guest access rule type
allow	Set the rule type to 'allow'

Defaults None.

Example
ruckus (config-guest-restrict-access) # **type allow**
The command was executed successfully.

type deny

To set the guest access rule type to 'deny', use the following command:

```
type deny
```

Syntax Description

type	Set the guest access rule type
deny	Set the rule type to 'deny'

Defaults None.

Example
ruckus (config-guest-restrict-access) # **type deny**
The command was executed successfully.

destination address

To set the destination address of the rule, use the following command:

```
destination address <IP-ADDR/WORD>
```

Syntax Description

destination address	Set the destination address of the rule
IP-ADDR/WORD	Set the destination to this IP address

Defaults None.

Example ruckus (config-guest-restrict-access) # **destination address 192.168.0.20/24**

The command was executed successfully.

destination port

To set the destination port of the rule, use the following command:

```
destination port <NUMBER/WORD>
```

Syntax Description

destination port	Set the destination port of the rule
<NUMBER/WORD>	Set the destination to this port number

Defaults None.

Example ruckus (config-guest-restrict-access) # **destination port 562**

The command was executed successfully.

protocol

To set the protocol for the rule, use the following command:

```
protocol <NUMBER/WORD>
```

Syntax Description

protocol	Set the protocol for the rule
<NUMBER/WORD>	Set to this protocol

Defaults None.

Example ruckus (config-guest-restrict-access) # **protocol 69**

The command was executed successfully.

IPv6 Guest Restrict Access Commands

Use the IPv6 guest restrict access commands to configure IPv6 network segments to which guest access will be blocked. To run these commands, you must first enter the config-ipv6-guest-restrict-access context.

Configuring Controller Settings

Configure Guest Access Commands

no restrict-access-order-ipv6

To delete a restrict access order, use the following command:

```
no restrict-access-order-ipv6 <NUMBER>
```

Syntax Description

no restrict-access-order-ipv6	Delete a restrict access order
<NUMBER>	Delete this order ID

Defaults

None.

Example

```
ruckus(config-guest-access) # no restrict-access-order-ipv6 2
The IPv6 Restricted Subnet Access entry has been removed from the
Guest Access.
ruckus(config-guest-access) #
```

restrict-access-order-ipv6

To create a new restrict access order or modify an existing restrict access order, use the following command:

```
restrict-access-order-ipv6 <NUMBER>
```

This command enters the config-ipv6-guest-restrict-access context. The following commands are available from within this context:

Syntax Description

help	Shows available commands
history	Shows a list of previously run commands.
abort	Exits the config-guest-restrict-access context without saving changes.
end	Saves changes, and then exits the config-guest-restrict-access context.
exit	Saves changes, and then exits the config-guest-restrict-access context.
quit	Exits the config-guest-restrict-access context without saving changes.
order <NUMBER>	Sets the guest access rule order.
description <WORD>	Sets the guest access rule description.
type [allow deny]	Sets the guest access rule type to allow or deny.

destination [address <IPv6-ADDR> port <NUMBER/WORD>]	Sets the destination address/port of a guest access rule.
protocol <NUMBER/WORD>	Sets the protocol of a guest access rule.
icmpv6-type	Sets the ICMPv6 type of a Guest Access rule.
show	Displays restricted subnet access settings.

Example

```
ruckus (config-guest-access) # restrict-access-order-ipv6 2
ruckus (config-ipv6-guest-restrict-access) # type allow
The command was executed successfully.
ruckus (config-ipv6-guest-restrict-access) # show
    Description=
    Type= Allow
    Destination Address= Any
    Destination Port= Any
    Protocol= Any
    ICMPv6 Type= Any
ruckus (config-ipv6-guest-restrict-access) # end
The IPv6 Restricted Subnet Access entry has been added to the Guest Access.
Your changes have been saved.
ruckus (config-guest-access) #
```

abort

To exit the config-ipv6-guest-restrict-access context without saving changes, use the **abort** command.

abort

Syntax Description

abort	Exit the guest access restriction settings without saving changes
-------	---

Defaults

None.

Example

```
ruckus (config-ipv6-guest-restrict-access) # abort
No changes have been saved.
ruckus (config-guest-access) #
```

Configuring Controller Settings

Configure Guest Access Commands

end

To save changes, and then exit the config-ipv6-guest-restrict-access context, use the following command:

```
end
```

Syntax Description

end	Save changes, and then exit the context
-----	---

Defaults

None.

Example

```
ruckus(config-ipv6-guest-restrict-access)# end
The Restricted Subnet Access entry has been added to the Guest
Access.
Your changes have been saved.
ruckus(config-guest-access) #
```

exit

To save changes, and then exit the config-ipv6-guest-restrict-access context, use the following command:

```
exit
```

Syntax Description

exit	Save changes, and then exit the context
------	---

Defaults

None.

Example

```
ruckus(config-ipv6-guest-restrict-access)# exit
The Restricted Subnet Access entry has been added to the Guest
Access.
Your changes have been saved.
ruckus(config-guest-access) #
```

quit

To exit the config-ipv6-guest-restrict-access context without saving changes, use the quit command.

```
quit
```

Syntax Description

quit	Exit the guest access restriction settings without saving changes
------	---

Defaults None.

Example

```
ruckus(config-ipv6-guest-restrict-access)# quit
No changes have been saved.
ruckus(config-guest-access) #
```

show

To display guest access restriction settings, use the following command:

```
show
```

Syntax Description

show	Display guest access restriction settings
------	---

Example

```
ruckus(config-ipv6-guest-restrict-access)# show
Description=
Type= Allow
Destination Address= Any
Destination Port= Any
Protocol= Any
ICMPv6 Type= Any
ruckus(config-ipv6-guest-restrict-access) #
```

order

To configure the guest access rule order, use the following command:

```
order <NUMBER>
```

Syntax Description

order	Set the order of a guest access rule
<NUMBER>	Assign the rule this order

Defaults None.

Example

```
ruckus(config-ipv6-guest-restrict-access)# order 3
The command was executed successfully.
```

description

To set the description of a guest access rule, use the following command:

```
description <WORD>
```

Configuring Controller Settings

Configure Guest Access Commands

Syntax Description

description	Set the description of a guest access rule
<WORD>	Set this as description

Defaults

None.

Example

```
ruckus (config-ipv6-guest-restrict-access) # description guestd3  
The command was executed successfully.
```

type allow

To set the guest access rule type to 'allow', use the following command:

```
type allow
```

Syntax Description

type	Set the guest access rule type
allow	Set the rule type to 'allow'

Defaults

None.

Example

```
ruckus (config-ipv6-guest-restrict-access) # type allow  
The command was executed successfully.
```

type deny

To set the guest access rule type to 'deny', use the following command:

```
type deny
```

Syntax Description

type	Set the guest access rule type
deny	Set the rule type to 'deny'

Defaults

None.

Example

```
ruckus (config-ipv6-guest-restrict-access) # type deny  
The command was executed successfully.
```

destination address

To set the destination address of the rule, use the following command:

```
destination address <IP-ADDR/WORD>
```

Syntax Description

destination address	Set the destination address of the rule
IP-ADDR/WORD	Set the destination to this IP address

Defaults

None.

Example

```
ruckus(config-ipv6-guest-restrict-access)# destination address fe80::/64
```

The command was executed successfully.

```
ruckus(config-ipv6-guest-restrict-access)#+
```

destination port

To set the destination port of the rule, use the following command:

```
destination port <NUMBER/WORD>
```

Syntax Description

destination port	Set the destination port of the rule
<NUMBER/WORD>	Set the destination to this port number

Defaults

None.

Example

```
ruckus(config-ipv6-guest-restrict-access)# destination port 562
```

The command was executed successfully.

protocol

To set the protocol for the rule, use the following command:

```
protocol <NUMBER/WORD>
```

Syntax Description

protocol	Set the protocol for the rule
<NUMBER/WORD>	Set to this protocol

Defaults

None.

Example

```
ruckus(config-ipv6-guest-restrict-access)# protocol 69
```

The command was executed successfully.

icmpv6-type

To set the ICMPv6 type of a Guest Access rule, use the following command:

Configuring Controller Settings

Configure Hotspot Commands

```
icmpv6-type [any | number <NUMBER>]
```

Defaults

Any.

Example

```
ruckus(config-ipv6-guest-restrict-access)# icmpv6-type any  
The command was executed successfully.  
ruckus(config-ipv6-guest-restrict-access)#+
```

Configure Hotspot Commands

Use the `hotspot` commands to configure the controller's hotspot settings. To run these commands, you must first enter the `config-hotspot` context.

hotspot

To create a new hotspot or edit an existing entry and enter the `config-hotspot` context, use the following command:

```
hotspot <WORD>
```

Syntax Description

hotspot	Create or edit a hotspot service
<WORD>	Name of hotspot service

Defaults

None.

Example

```
ruckus(config)# hotspot hotspot1  
The Hotspot entry 'hotspot1' has been loaded. To save the Hotspot  
entry, type end or exit.  
ruckus(config-hotspot)#+
```

no hotspot

To delete a hotspot record from the list, use the following command:

```
no hotspot <WORD>
```

Syntax Description

hotspot	Create or edit a hotspot service
<WORD>	Name of hotspot service

Defaults

None.

Example

```
ruckus(config)# hotspot hotspot1  
The Hotspot entry 'hotspot1' has been loaded. To save the Hotspot  
entry, type end or exit.  
ruckus(config-hotspot)#
```

abort

To exit the config-hotspot context without saving changes, use the **abort** command.

```
abort
```

Syntax Description

abort	Exit the hotspot settings without saving changes
-------	--

Defaults

None.

Example

```
ruckus(config-hotspot)# abort  
No changes have been saved.  
ruckus(config)#
```

end

To save changes, and then exit the config-hotspot context, use the following command:

```
end
```

Syntax Description

end	Save changes, and then exit the context
-----	---

Defaults

None.

Example

```
ruckus(config-hotspot)# end  
The login page url can't be empty.  
ruckus(config-hotspot)# end  
The Hotspot entry has saved successfully.  
Your changes have been saved.  
ruckus(config)#
```

exit

To save changes, and then exit the config-hotspot context, use the following command:

Configuring Controller Settings

Configure Hotspot Commands

exit

Syntax Description

exit	Save changes, and then exit the context
------	---

Defaults

None.

Example

```
ruckus(config-hotspot)# exit  
The login page url can't be empty  
ruckus(config-hotspot)# exit  
The Hotspot entry has saved successfully.  
Your changes have been saved.
```

quit

To exit the config-hotspot context without saving changes, use the **quit** command.

quit

Syntax Description

quit	Exit the hotspot settings without saving changes
------	--

Defaults

None.

Example

```
ruckus(config-hotspot)# quit  
No changes have been saved.  
ruckus(config)#
```

show

To display the current hotspot settings, use the following command:

show

Syntax Description

show	Display the current hotspot settings
------	--------------------------------------

Defaults

None.

Example

```
ruckus(config-hotspot)# show  
Hotspot:  
ID:  
1:
```

```
Name= h1
Login Page Url= http://172.18.110.122
Start Page= redirect to the URL that the user intends to visit.
Session Timeout= Disabled
Idle Timeout= Enabled
Timeout= 60 Minutes
Authentication Server= Local Database
Accounting Server= Disabled
Location ID=
Location Name=
Walled Garden 1=
Walled Garden 2=
Walled Garden 3=
Walled Garden 4=
Walled Garden 5=
Rules:
Order= 1
Description= h1_order1
Type= Deny
Destination Address= 192.168.20.20/24
Destination Port= 920
Protocol= 58
```

name

To set the hotspot name, use the following command

```
name <WORD>
```

Syntax Description

name	Set the hotspot name
<WORD>	Set to this name

Defaults

None.

Example

```
ruckus(config-hotspot)# name ruckus1
The command was executed successfully. To save the changes, type
'end' or 'exit'.
```

smartclient

Use the following command to enable WISPr smart client support

Configuring Controller Settings

Configure Hotspot Commands

```
smartclient [secure https] [secure http] [wispr-only secure https] [wispr-only secure-http] [info]
```

Syntax Description

smartclient	Enable WISPr smartclient support
secure https	Enables WISPr smart client support with HTTPS security.
secure http	Enables WISPr smart client support with no security.
wispr-only secure https	Enables only WISPr smart client support with HTTPS security.
wispr-only secure http	Enables only WISPr smart client support with no security.
info	Sets the instruction to guide user to login by Smart Client application.

Defaults

None.

Example

```
ruckus(config-hotspot)# smartclient secure https
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-hotspot)#
```

no smartclient

To disable WISPr Smart Client support, use the following command:

```
no smartclient
```

login-page

To set the URL of the hotspot login, use the following command:

```
login-page [original | <WORD>]
```

Syntax Description

login-page	Set the URL of the hotspot login
<WORD>	Set to this URL
original	Redirect to the URL that the user intends to visit

Defaults

None.

Example

```
ruckus(config-hotspot)# login-page http://ruckuswireless.com
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

start-page

To set the URL or page to which the user will be redirected after logging into the hotspot, use the following command:

```
start-page [original | url <WORD>]
```

Syntax Description

start-page	Set the URL or page to which the user will be redirected after logging into the hotspot
original	Redirect user to the original page he or she intended to visit
url <WORD>	Redirect user to another page. Set the URL of the page in <WORD>.

Defaults

original

Example

```
ruckus(config-hotspot)# start-page url  
http://www.ruckuswireless.com
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

no session-timeout

To disable the session timeout for hotspot usage, use the following command:

```
no session-timeout
```

Syntax Description

no session-timeout	Disable the session timeout for hotspot usage
--------------------	---

Defaults

None.

Example

```
ruckus(config-hotspot)# no session-timeout
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

session-timeout

To enable and set the session timeout for hotspot usage, use the following command:

```
session-timeout <minutes>
```

Configuring Controller Settings

Configure Hotspot Commands

Syntax Description

session-timeout	Disable the session timeout for hotspot usage
<minutes>	Set the session timeout to this value (in minutes)

Defaults

1440 minutes

Example

```
ruckus(config-hotspot)# session-timeout 20  
The command was executed successfully. To save the changes, type  
'end' or 'exit'.
```

no grace-period

To disable the grace period (idle timeout) for hotspot users, use the following command:

```
no grace-period
```

Syntax Description

no grace-period	Disable the idle timeout for hotspot users
-----------------	--

Defaults

None.

Example

```
ruckus(config-hotspot)# no grace-period  
The command was executed successfully. To save the changes, type  
'end' or 'exit'.
```

grace-period

To enable and set the grace period (idle timeout) for hotspot users, use the following command:

```
grace-period <minutes>
```

Syntax Description

grace-period	Set the idle timeout for hotspot users
<minutes>	Set the idle timeout to this value (in minutes)

Defaults

60 minutes

Example

```
ruckus(config-hotspot)# grace-period 20  
The command was executed successfully. To save the changes, type  
'end' or 'exit'.
```

auth-server local

To use ZoneDirector as the authentication server for hotspot users, use the following command:

```
auth-server local
```

Syntax Description

auth-server	Set an authentication server for hotspot users
local	Use ZoneDirector as the authentication server

Defaults

local

Example

```
ruckus(config-hotspot)# auth-server local
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

auth-server name

To use an external server for authenticating hotspot users, use the following command:

```
auth-server name <WORD>
```

Syntax Description

auth-server name	Set an external authentication server for hotspot users
<WORD>	Use this server as the authentication server

Defaults

None.

Example

```
ruckus(config-hotspot)# auth-server name radius1
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-hotspot) #
```

auth-server name mac-bypass

To enable MAC authentication bypass (no redirection) and use password as authentication password, use the following command:

```
auth-server name <WORD> mac-bypass password <WORD>
```

Syntax Description

auth-server name	Set an external authentication server for hotspot users
------------------	---

Configuring Controller Settings

Configure Hotspot Commands

<WORD>	Authentication server name
mac-bypass	Enable MAC auth bypass
mac	Enables MAC authentication bypass (no redirection) and use device MAC address as authentication password.
password <WORD>	Enables MAC authentication bypass (no redirection) and use password as authentication password.
mac-in-dot1x	Use device MAC address as authentication password and enable to send username and password in 802.1X format of 00-10-A4-23-19-C0 (by default 0010a42319c0).
password-in-dot1x <WORD>	Use password as authentication password and enable to send username and password in 802.1X format of 00-10-A4-23-19-C0 (by default 0010a42319c0).

Defaults

None.

Example

```
ruckus(config-hotspot)# auth-server name radius1 mac-bypass mac  
The command was executed successfully. To save the changes, type  
'end' or 'exit'.  
ruckus(config-hotspot) #
```

acct-server

To enable the accounting server for hotspot usage, use the following command:

```
acct-server <WORD>
```

Syntax Description

acct-server	Enable the accounting server for hotspot usage
<WORD>	Name of the AAA server

Defaults

None.

Example

```
ruckus(config-hotspot)# acct-server "RADIUS Accounting"  
The command was executed successfully. To save the changes, type  
'end' or 'exit'.  
ruckus(config-hotspot) #
```

no acct-server

To disable the accounting server for hotspot usage, use the following command:

```
no acct-server
```

Syntax Description

no acct-server	Disable the accounting server for hotspot usage
----------------	---

Defaults

None.

Example

```
ruckus(config-hotspot)# no acct-server
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

acct-server interim-update

To enable and set the accounting server for hotspot usage, use the following command:

```
acct-server <WORD> interim-update <NUMBER>
```

Syntax Description

no acct-server	Enable and set the accounting server for hotspot usage
<WORD>	Set to this accounting server
interim-update	Set the interim update interval
<NUMBER>	Set to this interval (in minutes)

Defaults

5 minutes

Example

```
ruckus(config-hotspot)# acct-server asd interim-update 10
```

The AAA server 'asd' could not be found. Please check the spelling, and then try again.

```
ruckus(config-hotspot)# acct-server acct1 interim-update 20
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

client-isolation

To enable wireless client isolation and set the level of isolation, use the following command:

```
client-isolation [local | full]
```

Configuring Controller Settings

Configure Hotspot Commands

Syntax Description

client-isolation	Enable client isolation
local	Set client isolation to local. Wireless clients associated with the same AP will be unable to communicate with one another locally.
full	Set client isolation to full. Wireless clients will be unable to communicate with each other or access any of the restricted subnets.

Defaults

None

Example

```
ruckus(config-hotspot)# client-isolation local
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-hotspot) #
```

no client-isolation

To disable wireless client isolation, use the following command:

```
no client-isolation
```

Example

```
ruckus(config-hotspot)# no client-isolation
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-hotspot) #
```

location-id

To set the location ID of the hotspot, use the following command:

```
location-id <location-id>
```

Syntax Description

location-id	Set the location ID of the hotspot
<location-id>	Set to this location ID

Defaults

None.

Example

```
ruckus(config-hotspot)# location-id us
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

location-name

To set the location name of the hotspot, use the following command:

```
location-name <location-name>
```

Syntax Description

location-name	Set the location name of the hotspot
<location-name>	Set to this location name

Defaults

None.

Example

```
ruckus(config-hotspot)# location-name shenzhen
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

walled-garden

To set a hotspot "walled garden" URL, use the following command:

```
walled-garden <INDEX> <WORD>
```

Syntax Description

walled-garden	Create a walled garden rule
<INDEX>	Enter walled garden URL index. (1~35)
<WORD>	Destination URL

Defaults

None.

Example

```
ruckus(config-hotspot)# walled-garden 1 www.ruckuswireless.com
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-hotspot) #
```

no walled-garden

To delete a walled garden URL, use the following command

```
no walled-garden <INDEX>
```

Syntax Description

walled-garden	Delete a walled garden rule
<INDEX>	Enter walled garden URL index. (1~35)

Configuring Controller Settings

Configure Hotspot Commands

Defaults	None.
Example	<pre>ruckus(config-hotspot)# no walled-garden 1 The command was executed successfully. To save the changes, type 'end' or 'exit'. ruckus(config-hotspot) #</pre>

Configuring Hotspot Restricted Access Rules

The following commands are used to create and modify Hotspot restricted access rules. Use the restrict-access-order command from the config-hotspot context to enter the config-hotspot-restrict-access context.

restrict-access-order

To create a new restrict access order or modify an existing restrict access order, use the following command:

```
restrict-access-order <NUMBER>
```

Syntax Description	
restrict-access-order	Add a restrict access order
<NUMBER>	Add this order ID
order <NUMBER>	Sets the hotspot rule order.
description <WORD>	Sets the hotspot rule description.
type allow	Sets the hotspot rule type to 'allow'.
type deny	Sets the hotspot rule type to 'deny'.
destination address <IP-ADDR/WORD>	Sets the destination address of a hotspot rule.
destination port <NUMBER/WORD>	Sets the destination port of a hotspot rule.
protocol <NUMBER/WORD>	Sets the protocol of a hotspot rule.
show	Displays the policy rule.

Defaults	None.
Example	<pre>ruckus(config-hotspot)# restrict-access-order 1 ruckus(config-hotspot-restrict-access)# ruckus(config-hotspot-restrict-access)# show Description= Type= Deny</pre>

```
Destination Address= Any
Destination Port= Any
Protocol= Any
ruckus(config-hotspot-restrict-access) #
```

no restrict-access-order

To delete a restrict access order, use the following command:

```
no restrict-access-order <NUMBER>
```

Syntax Description

no restrict-access-order	Delete a restrict access order
--------------------------	--------------------------------

<NUMBER>	Delete this order ID
----------	----------------------

Defaults

None.

Example

```
ruckus(config-hotspot) # no restrict-access-order 1
```

The rule '1' has been removed from the Hotspot.

restrict-access-order-ipv6

To create a new IPv6 restrict access order or modify an existing restrict access order, use the following command:

```
restrict-access-order-ipv6 <NUMBER>
```

Syntax Description

restrict-access-order-ipv6	Add a restrict access order
----------------------------	-----------------------------

<NUMBER>	Add this order ID
----------	-------------------

order <NUMBER>	Sets the hotspot rule order.
----------------	------------------------------

description <WORD>	Sets the hotspot rule description.
--------------------	------------------------------------

type allow	Sets the hotspot rule type to 'allow'.
------------	--

type deny	Sets the hotspot rule type to 'deny'.
-----------	---------------------------------------

destination address <IP-ADDR/WORD>	Sets the destination address of a hotspot rule.
------------------------------------	---

destination port <NUMBER/WORD>	Sets the destination port of a hotspot rule.
--------------------------------	--

protocol <NUMBER/WORD>	Sets the protocol of a hotspot rule.
------------------------	--------------------------------------

icmpv6 type [any number <NUMBER>]	Sets the icmpv6 type of a hotspot rule.
-----------------------------------	---

Configuring Controller Settings

Configure Hotspot Commands

	show	Displays the policy rule.
Defaults	None.	
Example		<pre>ruckus(config-hotspot)# restrict-access-order-ipv6 1 ruckus(config-hotspot-restrict-access)# ruckus(config-hotspot-restrict-access-ipv6)# show Description= Type= Deny Destination Address= Any Destination Port= Any Protocol= Any ICMPv6 Type= Any ruckus(config-hotspot-restrict-access-ipv6)# </pre>
Syntax Description		<pre>no restrict-access-order Delete a restrict access order <order_id> Delete this order ID</pre>
Defaults	None.	
Example		<pre>ruckus(config-hotspot)# no restrict-access-order-ipv6 1 The rule '1' has been removed from the Hotspot.</pre>
	icmpv6-type	
		To set the ICMPv6 type, use the following command:
		<pre>icmpv6-type [any number <NUMBER>]</pre>
Defaults	Any.	
Example		<pre>ruckus(config-hotspot-restrict-access-ipv6)# icmpv6-type any The command was executed successfully. To save the changes, type 'end' or 'exit'. ruckus(config-hotspot-restrict-access-ipv6)# </pre>

Hotspot Access Restriction Commands

Use the `hotspot-restrict-access` commands to configure network segments to which hotspot access will be blocked. To run these commands, you must first enter the `config-hotspot-restrict-access` context.

The same commands are available for IPv6 networks from the `config-hotspot-restrict-access-ipv6` context.

end

To save changes, and then exit the `config-hotspot-restrict-access` context, use the following command:

```
end
```

Syntax Description

end	Save changes, and then exit the context
-----	---

Defaults

None.

Example

```
ruckus (config-hotspot-restrict-access) # end  
ruckus (config-hotspot) #
```

exit

To save changes, and then exit the `config-hotspot-restrict-access` context, use the following command:

```
exit
```

Syntax Description

exit	Save changes, and then exit the context
------	---

Defaults

None.

Example

```
ruckus (config-hotspot-restrict-access) # exit  
ruckus (config-hotspot) #
```

show

To display hotspot access restriction settings, use the following command:

```
show
```

Configuring Controller Settings

Configure Hotspot Commands

Syntax Description	show	Display the hotspot access restriction settings
---------------------------	------	---

Defaults	None.
-----------------	-------

order

To configure the hotspot access rule order, use the following command:

```
order <NUMBER>
```

Syntax Description	order	Set the order of a hotspot access rule
	<NUMBER>	Assign the rule this order

Defaults	None.
-----------------	-------

Example	ruckus(config-hotspot-restrict-access)# order 1 The command was executed successfully. To save the changes, type 'end' or 'exit'.
----------------	---

description

To set the description of a hotspot access rule, use the following command:

```
description <WORD>
```

Syntax Description	description	Set the description of a hotspot access rule
	<WORD>	Set this as description

Defaults	None.
-----------------	-------

Example	ruckus(config-hotspot-restrict-access)# description h1_order1 The command was executed successfully. To save the changes, type 'end' or 'exit'.
----------------	---

type allow

To set the hotspot access rule type to 'allow', use the following command:

```
type allow
```

Syntax Description	type	Set the hotspot access rule type
---------------------------	------	----------------------------------

allow	Set the rule type to 'allow'
-------	------------------------------

Defaults	None.
-----------------	-------

Example	<pre>ruckus(config-hotspot-restrict-access)# type allow</pre> <p>The command was executed successfully. To save the changes, type 'end' or 'exit'.</p>
----------------	---

type deny

To set the hotspot access rule type to 'deny', use the following command:

```
type deny
```

Syntax Description	<table><tr><td>type</td><td>Set the hotspot access rule type</td></tr><tr><td>deny</td><td>Set the rule type to 'deny'</td></tr></table>	type	Set the hotspot access rule type	deny	Set the rule type to 'deny'
type	Set the hotspot access rule type				
deny	Set the rule type to 'deny'				

Defaults	None.
-----------------	-------

Example	<pre>ruckus(config-hotspot-restrict-access)# type deny</pre> <p>The command was executed successfully. To save the changes, type 'end' or 'exit'.</p>
----------------	--

destination address

To set the destination address of the rule, use the following command:

```
destination address <IP-ADDR/WORD>
```

Syntax Description	<table><tr><td>destination address</td><td>Set the destination address of the rule</td></tr><tr><td>IP-ADDR/WORD</td><td>Set the destination to this IP address</td></tr></table>	destination address	Set the destination address of the rule	IP-ADDR/WORD	Set the destination to this IP address
destination address	Set the destination address of the rule				
IP-ADDR/WORD	Set the destination to this IP address				

Defaults	None.
-----------------	-------

Example	<pre>ruckus(config-hotspot-restrict-access)# destination address 192.168.20.20/24</pre> <p>The command was executed successfully. To save the changes, type 'end' or 'exit'.</p>
----------------	---

destination port

To set the destination port of the rule, use the following command:

Configuring Controller Settings

Configure Hotspot Commands

destination port <NUMBER/WORD>

Syntax Description	destination port <NUMBER/WORD>	Set the destination port of the rule Set the destination to this port number
--------------------	--------------------------------	---

Defaults	None.
----------	-------

Example	ruckus(config-hotspot-restrict-access)# destination port 920 The command was executed successfully. To save the changes, type 'end' or 'exit'.
---------	--

protocol

To set the protocol for the rule, use the following command:

protocol <NUMBER/WORD>

Syntax Description	protocol <NUMBER/WORD>	Set the protocol for the rule Set to this protocol
--------------------	------------------------	---

Defaults	None.
----------	-------

Example	ruckus(config-hotspot-restrict-access)# protocol 58 The command was executed successfully. To save the changes, type 'end' or 'exit'.
---------	---

intrusion-prevention

To enable temporary blocking of Hotspot clients with repeated authentication attempts, use the following command:

intrusion-prevention

Defaults	Disabled.
----------	-----------

Example	ruckus(config-hotspot)# intrusion-prevention The command was executed successfully. To save the changes, type 'end' or 'exit'. ruckus(config-hotspot) #
---------	--

no intrusion-prevention

To disable temporary blocking of Hotspot clients with repeated authentication failure, use the following command:

```
no intrusion-prevention
```

Example

```
ruckus(config-hotspot)# no intrusion-prevention
The command was executed successfully. To save the changes, type
'end' or 'exit'.
ruckus(config-hotspot) #
```

Configure Hotspot 2.0 Commands

Use the `hs20op` and `hs20sp` commands to configure the controller's Hotspot 2.0 operator and service provider settings. To run these commands, you must first enter the `config-hs20op` or `config-hs20sp` context.

To deploy a Hotspot 2.0 service, you must configure the following:

- A Hotspot 2.0 Operator entry
- A Hotspot 2.0 Service Provider entry
- A WLAN with Hotspot 2.0 service enabled

hs20op

Use the following command to configure a Hotspot 2.0 Operator entry:

```
hs20op <WORD>
```

Syntax Description

hs20op	Create or configure a Hotspot 2.0 Operator entry
<WORD>	The name of the Hotspot 2.0 Operator entry.

Example

```
ruckus(config)# hs20op operator1
The Hotspot (2.0) operator entry 'operator1' has been created.
ruckus(config-hs20op)# end
The Hotspot (2.0) operator entry has saved successfully.
Your changes have been saved.
ruckus(config) #
```

no hs20op

Use the following command to delete a Hotspot 2.0 Operator entry:

```
no hs20op <WORD>
```

Example

```
ruckus(config)# no hs20op operator1
```

Configuring Controller Settings

Configure Hotspot 2.0 Commands

```
The Hotspot (2.0) oerprator 'operator1' has been deleted.  
ruckus(config)#
```

Configure Hotspot 2.0 Operator Settings

The following commands can be used to configure Hotspot 2.0 Operator entry settings. To execute these commands, you must first create or edit a Hotspot 2.0 Operator entry using the hs20op command and entering the config-hs20op context.

Syntax Description

help	Shows available commands.
history	Shows a list of previously run commands.
abort	Exits the config-hs20op context without saving changes.
end	Saves changes, and then exits the config-hs20op context.
exit	Saves changes, and then exits the config-hs20op context.
quit	Exits the config-hs20op context without saving changes.
no internet-option	Disables with connectivity to internet.
no hessid	Sets the HESSID to empty.
no service-provider <WORD>	Deletes a service provider from the Hotspot (2.0) operator.
no venue-group-type	Sets both venue group and venue type to unspecified.
no friendly-name <LANGUAGE>	Disable the friendly name for the specified language.
no asra	Disables additional step required for access.
no asra terms	Disables ASRA Type: Acceptance of terms and conditions.
no asra enrollment	Disables ASRA Type: On-line enrollment supported.
no asra http-https	Disables ASRA Type: http/https redirection.
no asra dns	Disables ASRA Type: DNS redirection.
no asra http-https-url	Sets the redirect URL of http/https redirection to empty.
no wan-metrics sym	Disables Symmetric Link.
no wan-metrics at-cap	Disables WAN at Capability.
no custm-conn-cap <NUMBER>	Deletes a Connection Capability entry.
no adv-gas dos-detect	Disables the GAS DOS detection.
no hs-caps operating-class-indication	Disables the operating class indication.
name <WORD>	Sets the hotspot(2.0) operator entry name.

description <WORD>	Sets the hotspot(2.0) operator entry description.
internet-option	Enables with connectivity to internet.
hessid <MAC>	Sets the HESSID.
hessid-use-bssid	Sets the HESSID to use BSSID.
service-provider <WORD>	Adds a service provider to the Hotspot (2.0) operator.
venue-group-type unspecified	Sets the venue group to unspecified
venue-group-type assembly	Sets the venue group to assembly
venue-group-type assembly unspecified	Sets the venue type to unspecified
venue-group-type assembly arena	Sets the venue type to arena
venue-group-type assembly stadium	Sets the venue type to stadium
venue-group-type assembly passenger-terminal	Sets the venue type to passenger terminal
venue-group-type assembly amphitheater	Sets the venue type to amphitheater
venue-group-type assembly amusement-park	Sets the venue type to amusement park
venue-group-type assembly place-worship	Sets the venue type to place of worship
venue-group-type assembly convention-center	Sets the venue type to convention center
venue-group-type assembly library	Sets the venue type to library
venue-group-type assembly museum	Sets the venue type to museum
venue-group-type assembly restaurant	Sets the venue type to restaurant
venue-group-type assembly theater	Sets the venue type to theater
venue-group-type assembly bar	Sets the venue type to bar

Configuring Controller Settings

Configure Hotspot 2.0 Commands

venue-group-type assembly coffee-shop	Sets the venue type to coffee shop
venue-group-type assembly zoo-or-aquarium	Sets the venue type to zoo or aquarium
venue-group-type assembly emergency-coordination-center	Sets the venue type to emergency coordination center
venue-group-type business	Sets the venue group to business
venue-group-type business unspecified	Sets the venue type to unspecified
venue-group-type business doctor-or-dentist-office	Sets the venue type to doctor or dentist office
venue-group-type business bank	Sets the venue type to bank
venue-group-type business fire-station	Sets the venue type to fire station
venue-group-type business police-station	Sets the venue type to police station
venue-group-type business post-office	Sets the venue type to post office
venue-group-type business professional-office	Sets the venue type to professional office
venue-group-type business research-and-development-facility	Sets the venue type to research and development facility
venue-group-type business attorney-office	Sets the venue type to attorney office
venue-group-type educational	Sets the venue group to educational
venue-group-type educational unspecified	Sets the venue type to unspecified
venue-group-type educational school-primary	Sets the venue type to school primary

venue-group-type educational school- secondary	Sets the venue type to school secondary
venue-group-type educational university- or-college	Sets the venue type to university or college
venue-group-type factory-industrial	Sets the venue group to factory industrial
venue-group-type factory-industrial unspecified	Sets the venue type to unspecified
venue-group-type factory-industrial factory	Sets the venue type to factory
venue-group-type institutional institutional	Sets the venue group to institutional
venue-group-type institutional unspecified	Sets the venue type to unspecified
venue-group-type institutional hospital	Sets the venue type to hospital
venue-group-type institutional long-term- care-facility	Sets the venue type to long term care facility
venue-group-type institutional alcohol- and-drug-reHabilitation- center	Sets the venue type to alcohol and drug reHabilitation center
venue-group-type institutional group- home	Sets the venue type to group home
venue-group-type institutional prison-or-jail	Sets the venue type to prison or jail
venue-group-type mercantile	Sets the venue group to mercantile
venue-group-type mercantile unspecified	Sets the venue type to unspecified
venue-group-type mercantile retail-store	Sets the venue type to retail store
venue-group-type mercantile grocery- market	Sets the venue type to grocery market

Configuring Controller Settings

Configure Hotspot 2.0 Commands

venue-group-type mercantile automotive-service-station	Sets the venue type to automotive service station
venue-group-type mercantile shopping-mall	Sets the venue type to shopping mall
venue-group-type mercantile gas-station	Sets the venue type to gas station
venue-group-type residential	Sets the venue group to residential
venue-group-type residential unspecified	Sets the venue type to unspecified
venue-group-type residential private-residence	Sets the venue type to private residence
venue-group-type residential hotel-or-motel	Sets the venue type to hotel or motel
venue-group-type residential dormitory	Sets the venue type to dormitory
venue-group-type residential boarding-house	Sets the venue type to boarding house
venue-group-type storage	Sets the venue group to storage
venue-group-type storage unspecified	Sets the venue type to unspecified
venue-group-type utility-miscellaneous	Sets the venue group to utility miscellaneous
venue-group-type utility-miscellaneous unspecified	Sets the venue type to unspecified
venue-group-type vehicular	Sets the venue group to vehicular
venue-group-type vehicular unspecified	Sets the venue type to unspecified
venue-group-type vehicular automobile-or-truck	Sets the venue type to automobile or truck

venue-group-type vehicular airplane	Sets the venue type to airplane
venue-group-type vehicular bus	Sets the venue type to bus
venue-group-type vehicular ferry	Sets the venue type to ferry
venue-group-type vehicular ship-or-boat	Sets the venue type to ship or boat
venue-group-type vehicular train	Sets the venue type to train
venue-group-type vehicular motor-bike	Sets the venue type to motor bike
venue-group-type outdoor	Sets the venue group to outdoor
venue-group-type outdoor unspecified	Sets the venue type to unspecified
venue-group-type outdoor muni-mesh-network	Sets the venue type to muni mesh network
venue-group-type outdoor city-park	Sets the venue type to city park
venue-group-type outdoor rest-area	Sets the venue type to rest area
venue-group-type outdoor traffic-control	Sets the venue type to traffic control
venue-group-type outdoor bus-stop	Sets the venue type to bus stop
venue-group-type outdoor kiosk	Sets the venue type to kiosk
friendly-name <LANGUAGE> <WORD>	Sets the friendly name for the specified language.
asra	Enables additional step required for access.
asra terms	Enables ASRA Type: Acceptance of terms and conditions.
asra enrollment	Enables ASRA Type: On-line enrollment supported.
asra http-https	Enables ASRA Type: http/https redirection.
asra http-https url <WORD>	Sets the redirect URL of http/https redirection.
asra dns	Enables ASRA Type: DNS redirection.

Configuring Controller Settings

Configure Hotspot 2.0 Commands

accs-net-type private	Sets the access network type to Private network.
accs-net-type private-with-guest	Sets the access network type to Private network with guest access.
accs-net-type chargeable-public	Sets the access network type to Chargeable public network.
accs-net-type free-public	Sets the access network type to Free public network.
accs-net-type personal-device	Sets the access network type to Personal device network.
accs-net-type test-or-experimental	Sets the access network type to Test or experimental.
accs-net-type wildcard	Sets the access network type to Wildcard.
ip-addr-type ipv4 not-avail	Sets the IPv4 Address Type to not available.
ip-addr-type ipv4 public	Sets the IPv4 Address Type to public address.
ip-addr-type ipv4 port-restricted	Sets the IPv4 Address Type to port-restricted address.
ip-addr-type ipv4 single-nated	Sets the IPv4 Address Type to single NATed private address.
ip-addr-type ipv4 double-nated	Sets the IPv4 Address Type to double NATed private address.
ip-addr-type ipv4 port-single	Sets the IPv4 Address Type to port-restricted address and single NATed private address.
ip-addr-type ipv4 port-double	Sets the IPv4 Address Type to port-restricted address and double NATed private address.
ip-addr-type ipv4 unknown	Sets the IPv4 Address Type to unknown.
ip-addr-type ipv6 not-avail	Sets the IPv6 Address Type to not available.
ip-addr-type ipv6 avail	Sets the IPv6 Address Type to available.
ip-addr-type ipv6 unknown	Sets the IPv6 Address Type to unknown.
wan-metrics sym	Enables Symmetric Link.
wan-metrics at-cap	Enables WAN at Capability.
wan-metrics link-stat up	Sets Link Status to Link UP.
wan-metrics link-stat down	Sets Link Status to Link Down.
wan-metrics link-stat test	Sets Link Status to Link in Test State.

wan-metrics downlink-load <NUMBER>	Sets WAN downlink load.
wan-metrics downlink-speed <NUMBER>	Sets WAN downlink speed.
wan-metrics uplink-load <NUMBER>	Sets WAN uplink load.
wan-metrics uplink-speed <NUMBER>	Sets WAN uplink speed.
wan-metrics lmd <NUMBER>	Sets Load Measurement Duration.
conn-cap icmp closed	Sets the ICMP Connection Capability Status to closed
conn-cap icmp open	Sets the ICMP Connection Capability Status to open
conn-cap icmp unknown	Sets the ICMP Connection Capability Status to unknown
conn-cap ftp closed	Sets the FTP Connection Capability Status to closed
conn-cap ftp open	Sets the FTP Connection Capability Status to open
conn-cap ftp unknown	Sets the FTP Connection Capability Status to unknown
conn-cap ssh closed	Sets the SSH Connection Capability Status to closoed
conn-cap ssh open	Sets the SSH Connection Capability Status to open
conn-cap ssh unknown	Sets the SSH Connection Capability Status to unknown
conn-cap http closed	Sets the HTTP Connection Capability Status to closoed
conn-cap http open	Sets the HTTP Connection Capability Status to open
conn-cap http unknown	Sets the HTTP Connection Capability Status to unknown
conn-cap tls-vpn closed	Sets the TLS VPN Connection Capability Status to closoed
conn-cap tls-vpn open	Sets the TLS VPN Connection Capability Status to open
conn-cap tls-vpn unknown	Sets the TLS VPN Connection Capability Status to unknown
conn-cap pptp-vpn closed	Sets the PPTP VPN Connection Capability Status to closoed
conn-cap pptp-vpn open	Sets the PPTP VPN Connection Capability Status to open
conn-cap pptp-vpn unknown	Sets the PPTP VPN Connection Capability Status to unknown
conn-cap voip-tcp closed	Sets the VoIP(TCP) Connection Capability Status to closed
conn-cap voip-tcp open	Sets the VoIP(TCP) Connection Capability Status to open
conn-cap voip-tcp unknown	Sets the VoIP(TCP) Connection Capability Status to unknown
conn-cap ikev2 closed	Sets the IKEv2 Connection Capability Status to closoed

Configuring Controller Settings

Configure Hotspot 2.0 Commands

conn-cap ikev2 open	Sets the IKEv2 Connection Capability Status to open
conn-cap ikev2 unknown	Sets the IKEv2 Connection Capability Status to unknown
conn-cap voip-udp closed	Sets the VoIP(UDP) Connection Capability Status to closed
conn-cap voip-udp open	Sets the VoIP(UDP) Connection Capability Status to open
conn-cap voip-udp unknown	Sets the VoIP(UDP) Connection Capability Status to unknown
conn-cap ipsec-vpn closed	Sets the IPSec VPN Connection Capability Status to closed
conn-cap ipsec-vpn open	Sets the IPSec VPN Connection Capability Status to open
conn-cap ipsec-vpn unknown	Sets the IPSec VPN Connection Capability Status to unknown
conn-cap esp closed	Sets the ESP Connection Capability Status to closed
conn-cap esp open	Sets the ESP Connection Capability Status to open
conn-cap esp unknown	Sets the ESP Connection Capability Status to unknown
custm-conn-cap <NUMBER> ip-proto <NUMBER> port <NUMBER> status closed	Sets Status to closed.
custm-conn-cap <NUMBER> ip-proto <NUMBER> port <NUMBER> status closed description <WORD>	Sets the description of Connection Capability entry.
custm-conn-cap <NUMBER> ip-proto <NUMBER> port <NUMBER> status open	Sets Status to open.
custm-conn-cap <NUMBER> ip-proto <NUMBER> port <NUMBER> status open description <WORD>	Sets the description of Connection Capability entry.

custm-conn-cap <NUMBER> ip-proto <NUMBER> port <NUMBER> status unknown	Sets Status to unknown.
custm-conn-cap <NUMBER> ip-proto <NUMBER> port <NUMBER> status unknown description <WORD>	Sets the description of Connection Capability entry.
adv-gas cb-delay <NUMBER>	Sets the GAS Comeback Delay.
adv-gas rsp-limit <NUMBER>	Sets the GAS query response length limit.
adv-gas rsp-buf-time <NUMBER>	Sets the GAS query response buffering time.
adv-gas dos-detect	Enables the GAS DOS detection.
adv-gas dos-maxreq <NUMBER>	Set the GAS DOS detection maximum request number.
hs-caps operating-class- indication 2.4	Sets the operating class indication to 2.4 GHz.
hs-caps operating-class- indication 5	Sets the operating class indication to 5 GHz.
hs-caps operating-class- indication dual-band	Sets the operating class indication to 2.4/5 GHz.
show	Displays hotspot 2.0 operator settings.

hs20sp

Use the following command to configure a Hotspot 2.0 Service Provider entry:

hs20sp <WORD>

Example

ruckus(config)# **hs20sp serviceprovider1**

The Hotspot (2.0) service provider entry 'serviceprovider1' has been created.

ruckus(config-hs20sp)# **end**

The Hotspot (2.0) service provider entry has saved successfully.

Your changes have been saved.

Configuring Controller Settings

Configure Hotspot 2.0 Commands

```
ruckus(config)#
```

no hs20sp

Use the following command to delete a Hotspot 2.0 Service Provider entry:

```
no hs20sp <WORD>
```

Example

```
ruckus(config)# no hs20sp provider1
```

The Hotspot (2.0) service provider 'provider1' has been deleted.
ruckus(config)#

Configure Hotspot 2.0 Service Provider Settings

The following commands can be used to configure Hotspot 2.0 Service Provider entry settings. To execute these commands, you must first create or edit a Hotspot 2.0 Service Provider entry using the `hs20sp` command and entering the `config-hs20sp` context.

Syntax Description

help	Shows available commands.
history	Shows a list of previously run commands.
abort	Exits the config-hs20sp context without saving changes.
end	Saves changes, and then exits the config-hs20sp context.
exit	Saves changes, and then exits the config-hs20sp context.
quit	Exits the config-hs20sp context without saving changes.
no nai-realm <NUMBER>	Deletes a NAI Realm entry.
no domain-name <NUMBER>	Deletes a domain name entry.
no roam-consortium <NUMBER>	Deletes a roaming consortium entry.
no anqp-3gpp-info <NUMBER>	Deletes a 3GPP cellular network information entry.
name <WORD>	Sets the hotspot(2.0) service provider entry name.
description <WORD>	Sets the hotspot(2.0) service provider entry description.
nai-realm <NUMBER>	Creates a new NAI Realm entry or modifies an existing entry.

domain-name <NUMBER>	Creates a new domain name entry or modifies an existing entry.
domain-name <NUMBER> name <WORD>	Sets the domain name of a domain name entry.
roam-consortium <NUMBER>	Creates a new roaming consortium entry or modifies an existing entry.
roam-consortium <NUMBER> org-id <HEX>	Sets the organization ID of a roaming consortium entry.
roam-consortium <NUMBER> org-id <HEX> name <WORD>	Sets the name of a roaming consortium entry.
anqp-3gpp-info <NUMBER>	Creates a 3GPP cellular network information entry or modifies an existing entry list.
anqp-3gpp-info <NUMBER> mcc <NUMBER>	Sets the MCC of 3GPP cellular network information entry.
anqp-3gpp-info <NUMBER> mcc <NUMBER> mnc <NUMBER>	Sets the MNC of 3GPP cellular network information entry.
anqp-3gpp-info <NUMBER> mcc <NUMBER> mnc <NUMBER> name <WORD>	Sets the name of 3GPP cellular network information entry.
show	Displays hotspot 2.0 service provider settings.

nai-realm

To create, a new NAI Realm entry or modifies an existing entry, use the following command:

`nai-realm <NUMBER>`

This command enters the config-hs20sp-nai-realm context. The following commands can be executed from within this context.

Syntax Description

name	Sets the name of the NAI Realm entry.
encoding	Sets the encoding of the NAI Realm entry.
eap-method <NUMBER>	Sets the EAP method #X of the NAI Realm entry. (X:1~4)
no	Contains commands that can be executed from within the context.
show	Displays NAI Realm settings.

Example

```
ruckus(config-hs20sp) # nai-realm 1
ruckus(config-hs20sp-nai-realm) # name realm1
The command was executed successfully. To save the changes, type
'end' or 'exit'.
ruckus(config-hs20sp-nai-realm) # show
    Name= realm1
    Encoding= RFC-4282
    EAP Method #1= N/A
    EAP Method #2= N/A
    EAP Method #3= N/A
    EAP Method #4= N/A
ruckus(config-hs20sp-nai-realm) # end
To save the changes, type 'end' or 'exit'.
ruckus(config-hs20sp) # end
The Hotspot (2.0) service provider entry has saved successfully.
Your changes have been saved.
ruckus(config) #
```

name

Use the following command to set the name of the NAI Realm entry:

```
name <WORD>
```

encoding

Use the following command to set the encoding of the NAI Realm entry:

```
encoding [rfc-4282 | utf-8]
```

eap-method

Use the following command to set the EAP method of the NAI Realm entry:

```
eap-method <NUMBER>
```

eap-method eap-mthd

Use the following command to set the EAP method of the NAI Realm entry:

```
eap-method <NUMBER> eap-mthd [N/A | <NAME>]
```

Syntax Description

N/A	Sets the EAP method of the NAI Realm entry to N/A.
-----	--

MD5-Challenge	Sets the EAP method of the NAI Realm entry to MD5-Challenge.
EAP-TLS	Sets the EAP method of the NAI Realm entry to EAP-TLS.
EAP-CISCO	Sets the EAP method of the NAI Realm entry to EAP-Cisco.
EAP-SIM	Sets the EAP method of the NAI Realm entry to EAP-SIM.
EAP-TTLS	Sets the EAP method of the NAI Realm entry to EAP-SIM.
PEAP	Sets the EAP method of the NAI Realm entry to PEAP.
MSCHAP-V2	Sets the EAP method of the NAI Realm entry to EAP-MSCHAP-V2.
EAP-AKA	Sets the EAP method of the NAI Realm entry to EAP-AKA.
EAP-AKA-Prime	Sets the EAP method of the NAI Realm entry to EAP-AKA'.
Reserved	Sets the EAP method of the NAI Realm entry to Reserved.

Syntax Description

```
ruckus(config-hs20sp-nai-realm)# eap-method 1 eap-mthd EAP-TLS
The command was executed successfully. To save the changes, type
'end' or 'exit'.
ruckus(config-hs20sp-nai-realm)#

```

eap-method auth-info

To set the Auth Info of the EAP method, use the following command:

```
eap-method <NUMBER> auth-info <NUMBER>
```

Syntax Description

auth-id	Sets the auth info ID of the auth info.
auth-id expanded-EAP-method	Sets the Auth Info of the EAP method to expanded-EAP-method.
auth-id expanded-EAP-method vndr-id <NUMBER>	Sets the vendor ID of the auth info.
auth-id expanded-EAP-method vndr-id <NUMBER> vndr-type <NUMBER>	Sets the vendor type of the auth info.

Configuring Controller Settings

Configure Hotspot 2.0 Commands

auth-id nonEAP-inner-auth	Sets the Auth Info of the EAP method to Non-EAP Inner Authentication Type.
auth-id nonEAP-inner-auth auth-type	Sets the auth info type of the auth info.
auth-id nonEAP-inner-auth auth-type Reserved	Sets the Non-EAP Inner Authentication Type to Reserved.
auth-id nonEAP-inner-auth auth-type PAP	Sets the Non-EAP Inner Authentication Type to PAP.
auth-id nonEAP-inner-auth auth-type CHAP	Sets the Non-EAP Inner Authentication Type to CHAP.
auth-id nonEAP-inner-auth auth-type MSCHAP	Sets the Non-EAP Inner Authentication Type to MSCHAP.
auth-id nonEAP-inner-auth auth-type MSCHAPV2	Sets the Non-EAP Inner Authentication Type to MSCHAPV2.
auth-id inner-auth-EAP-mthd	Sets the Auth Info of the EAP method to Inner Authentication EAP Method Type.
auth-id inner-auth-EAP-mthd auth-type	Sets the auth info type of the auth info.
auth-id inner-auth-EAP-mthd auth-type EAP-TLS	Sets the Inner Authentication EAP Method Type to EAP-TLS.
auth-id inner-auth-EAP-mthd auth-type EAP-SIM	Sets the Inner Authentication EAP Method Type to EAP-SIM.
auth-id inner-auth-EAP-mthd auth-type EAP-TTLS	Sets the Inner Authentication EAP Method Type to EAP-TTLS.
auth-id inner-auth-EAP-mthd auth-type EAP-AKA	Sets the Inner Authentication EAP Method Type to EAP-AKA.
auth-id inner-auth-EAP-mthd auth-type EAP-AKA-Prime	Sets the Inner Authentication EAP Method Type to EAP-AKA'.
auth-id exp-inner-EAP-mthd	Sets the Auth Info of the EAP method to expanded-inner-EAP-method.
auth-id exp-inner-EAP-mthd vndr-id <NUMBER>	Sets the vendor ID of the auth info.
auth-id exp-inner-EAP-mthd vndr-id <NUMBER> vndr-type <NUMBER>	Sets the vendor type of the auth info.
auth-id credential-type	Sets the Auth Info of the EAP method to Credential Type.
auth-id credential-type auth-type	Sets the auth info type of the auth info.

auth-id credential-type auth-type SIM	Sets the Credential Type to SIM.
auth-id credential-type auth-type USIM	Sets the Credential Type to USIM.
auth-id credential-type auth-type NFC-secure-elem	Sets the Credential Type to NFC Secure Element.
auth-id credential-type auth-type hardware-token	Sets the Credential Type to Hardware Token.
auth-id credential-type auth-type softoken	Sets the Credential Type to Softoken.
auth-id credential-type auth-type certificate	Sets the Credential Type to Certificate.
auth-id credential-type auth-type username-password	Sets the Credential Type to username/password.
auth-id credential-type auth-type none	Sets the Credential Type to none.
auth-id credential-type auth-type reserved	Sets the Credential Type to Reserved.
auth-id tunnel-EAP-mthd-crdn-type	Sets the Auth Info of the EAP method to Tunneled EAP Method Credential Type.
auth-id tunnel-EAP-mthd-crdn-type auth-type	Sets the auth info type of the auth info.
auth-id tunnel-EAP-mthd-crdn-type auth-type SIM	Sets the Tunneled EAP Method Credential Type to SIM.
auth-id tunnel-EAP-mthd-crdn-type auth-type USIM	Sets the Tunneled EAP Method Credential Type to USIM.
auth-id tunnel-EAP-mthd-crdn-type auth-type NFC-secure-elem	Sets the Tunneled EAP Method Credential Type to NFC Secure Element.
auth-id tunnel-EAP-mthd-crdn-type auth-type hardware-token	Sets the Tunneled EAP Method Credential Type to Hardware Token.
auth-id tunnel-EAP-mthd-crdn-type auth-type softoken	Sets the Tunneled EAP Method Credential Type to Softoken.
auth-id tunnel-EAP-mthd-crdn-type auth-type certificate	Sets the Tunneled EAP Method Credential Type to Certificate.
auth-id tunnel-EAP-mthd-crdn-type auth-type username-password	Sets the Tunneled EAP Method Credential Type to username/password.
auth-id tunnel-EAP-mthd-crdn-type auth-type reserved	Sets the Tunneled EAP Method Credential Type to Reserved.

Configuring Controller Settings

Configure Hotspot 2.0 Commands

auth-id tunnel-EAP-mthd-crdn-type auth-type anonymous	Sets the Tunneled EAP Method Credential Type to Anonymous.
no eap-method <NUMBER>	Sets the EAP method #X of the NAI Realm entry. (X:1~4)
no eap-method <NUMBER> auth-info <NUMBER>	Disable the Auth Info of the EAP method
show	Displays NAI Realm settings.

Configure Mesh Commands

Use the mesh commands to configure the controller's mesh networking settings. To run these commands, you must first enter the config-mesh context.

mesh

Use the mesh command to enter the config-mesh context and configure the mesh-related settings.

```
mesh
```

Syntax Description	mesh	Configure mesh settings
Defaults	none	
Example	ruckus(config)# mesh	

abort

To exit the config-mesh context without saving changes, use the abort command.

```
abort
```

Syntax Description	abort	Exit the mesh settings without saving changes
Defaults	None.	
Example	ruckus(config-mesh)# abort	

end

To save changes, and then exit the config-mesh context, use the following command:

```
end
```

Syntax Description	end	Save changes, and then exit the context
--------------------	-----	---

Configuring Controller Settings

Configure Mesh Commands

Defaults None.

Example

```
ruckus(config-mesh) # end  
Are you sure you want to enable mesh[Y/n]  
Your changes have been saved.  
ruckus(config) #
```

exit

To save changes, and then exit the config-mesh context, use the following command:

```
exit
```

Syntax Description

exit	Save changes, and then exit the context
------	---

Defaults None.

Example

```
ruckus(config-mesh) # exit  
Are you sure you want to enable mesh[Y/n]  
Your changes have been saved.  
ruckus(config) #
```

quit

To exit the config-mesh context without saving changes, use the quit command.

```
quit
```

Syntax Description

quit	Exit the mesh settings without saving changes
------	---

Defaults None.

Example

```
ruckus(config-mesh) # quit  
No changes have been saved.  
ruckus(config) #
```

show

To display the current mesh settings, use the following command:

show

Syntax Description	show	Display the current mesh settings
---------------------------	------	-----------------------------------

Defaults	None.
-----------------	-------

Example	<pre>ruckus(config-mesh) # show Mesh Settings: Mesh Status= Enabled Mesh Name(ESSID)= Mesh-000000000311 Mesh Passphrase= GdxW5CUGNn_SEHOPyCSxv_chHSca MH-OpnRGfX sRvwXBjL- wUsD64eK8CMEZfm Mesh Hop Detection: Status= Disabled Mesh Downlinks Detection: Status= Disabled Tx. Rate of Management Frame=2Mbps Beacon Interval= 200ms ruckus(config-mesh) #</pre>
----------------	--

ssid

To set the SSID of the mesh network, use the following command:

`ssid <WORD/SSID>`

Syntax Description	ssid	Set the SSID of the mesh network
	<WORD/SSID>	Set to this SSID

Defaults	None.
-----------------	-------

Example	<pre>ruckus(config-mesh) # ssid rks_mesh</pre> <p>The command was executed successfully. To save the changes, type 'end' or 'exit'.</p>
----------------	--

passphrase

To set the passphrase that allows access to the mesh network, use the following command:

`passphrase <WORD>`

Configuring Controller Settings

Configure Mesh Commands

Syntax Description	passphrase	Set the passphrase that allows access to the mesh network
	<WORD>	Set to this passphrase

Defaults	None.
----------	-------

Example	ruckus(config-mesh) # passphrase test123456 The command was executed successfully. To save the changes, type 'end' or 'exit'.
---------	---

hops-warn-threshold

To enable and configure the mesh hop threshold, use the following command:

```
hops-warn-threshold <NUMBER>
```

Syntax Description	hops-warn-threshold	Set the mesh hop threshold (max hops)
	<NUMBER>	Set to this threshold value

Defaults	5
----------	---

Example	ruckus(config-mesh) # hops-warn-threshold 6 The command was executed successfully. To save the changes, type 'end' or 'exit'.
---------	---

no detect-hops

To disable the mesh hop threshold, use the following command:

```
no detect-hops
```

Syntax Description	no detect-hops	Disable the mesh hop threshold
--------------------	----------------	--------------------------------

Defaults	None.
----------	-------

Example	ruckus(config-mesh) # no detect-hops The command was executed successfully. To save the changes, type 'end' or 'exit'.
---------	--

fan-out-threshold

To enable and configure the mesh downlink threshold, use the following command:

```
fan-out-threshold <NUMBER>
```

Syntax Description	fan-out-threshold <NUMBER>	Set the mesh downlink threshold (max downlinks) Set to this threshold value
--------------------	----------------------------	--

Defaults	5
----------	---

Example	ruckus(config-mesh) # fan-out-threshold 8 The command was executed successfully. To save the changes, type 'end' or 'exit'.
---------	---

no detect-fanout

To disable the mesh downlink threshold, use the following command:

```
no detect-fanout
```

Syntax Description	no detect-fanout	Disable the mesh downlink threshold
--------------------	------------------	-------------------------------------

Defaults	None.
----------	-------

Example	ruckus(config-mesh) # no detect-fanout The command was executed successfully. To save the changes, type 'end' or 'exit'.
---------	--

beacon-interval

To set the beacon interval for mesh links, use the following command:

```
beacon-interval <NUMBER>
```

Syntax Description	beacon-interval <NUMBER>	Set the beacon interval for mesh links Enter the beacon interval (100~1000 TUs)
--------------------	--------------------------	--

Defaults	200
----------	-----

Example	ruckus(config-mesh) # beacon-interval 200
---------	--

Configuring Controller Settings

Configure Alarm Commands

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-mesh) #
```

mgmt-tx-rate

To set the transmit rate for management frames, use the following command:

```
mgmt-tx-rate <RATE>
```

Syntax Description

mgmt-tx-rate	Set the max transmit rate for management frames
<RATE>	Set the transmit rate (in Mbps).

Defaults

2

Example

```
ruckus(config-mesh) # mgmt-tx-rate 2
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-mesh) #
```

Configure Alarm Commands

Use the `alarm` commands to configure the controller's alarm notification settings. To run these commands, you must first enter the `config-alarm` context.

alarm

To enter the `config-alarm` context, use the following command.

```
alarm
```

Example

```
ruckus(config) # alarm
```

```
ruckus(config-alarm) #
```

no alarm

To disable alarm settings, use the following command:

```
no alarm
```

Example

```
ruckus(config) # no alarm
```

The Alarm settings have been updated.

```
ruckus(config)#
```

abort

To exit the config-alarm context without saving changes, use the **abort** command.

```
abort
```

Syntax Description

abort	Exit the alarm settings without saving changes
-------	--

Defaults

None.

Example

```
ruckus(config-alarm)# abort  
No changes have been saved.  
ruckus(config)#
```

end

To save changes, and then exit the config-alarm context, use the following command:

```
end
```

Syntax Description

end	Save changes, and then exit the context
-----	---

Defaults

None.

Example

```
ruckus(config-alarm)# end  
The Alarm settings have been updated.  
Your changes have been saved.  
ruckus(config)#
```

exit

To save changes, and then exit the config-alarm context, use the following command:

```
exit
```

Syntax Description

exit	Save changes, and then exit the context
------	---

Configuring Controller Settings

Configure Alarm Commands

Defaults None.

Example

```
ruckus(config-alarm)# exit  
The Alarm settings have been updated.  
Your changes have been saved.
```

quit

To exit the config-alarm context without saving changes, use the **quit** command.

```
quit
```

Syntax Description

quit	Exit the alarm settings without saving changes
------	--

Defaults None.

Example

```
ruckus(config-alarm)# quit  
No changes have been saved.  
ruckus(config)#
```

show

To display the current alarm settings, use the following command:

```
show
```

Syntax Description

show	Display the current alarm settings
------	------------------------------------

Defaults None.

Example

```
rruckus(config)# alarm  
ruckus(config-alarm)# show  
Alarm:  
    Status= Enabled  
    Email Address= johndoe@gmail.com  
    E-mail From = zonedirector@ruckuswireless.com  
    SMTP Server Name= smtp.gmail.com  
    SMTP Server Port= 587  
    SMTP Authentication Username= johndoe@gmail.com  
    SMTP Authentication Password= *****  
    wait time=
```

```
SMTP Encryption Options:  
  TLS= Enabled  
  STARTTLS= Enabled
```

```
ruckus(config-alarm) #
```

e-mail

To set the email address to which alarm notifications will be sent, use the following command:

```
e-mail <WORD>
```

Syntax Description

e-mail	Set the email address to which alarm notifications will be sent
<WORD>	Send alarm notifications to this email address

Defaults

None.

Example

```
ruckus(config-alarm) # e-mail joe@163.com
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

from

To set the sender from address for email alarms, use the following command:

```
from <WORD>
```

Syntax Description

from	Set the email address from which alarm notifications will be sent
<WORD>	Send alarm notifications from this email address

Defaults

None.

Example

```
ruckus(config-alarm) # from zonedirector@zonedirector.com
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

```
ruckus(config-alarm) #
```

Configuring Controller Settings

Configure Alarm Commands

smtp-server-name

To set the SMTP server that ZoneDirector uses to send alarm notifications, use the following command:

```
smtp-server-name <WORD>
```

Syntax Description

smtp-server-name	Set the SMTP server that ZoneDirector uses to send alarm notifications
<WORD>	Set to this SMTP server name

Defaults

None.

Example

```
ruckus(config-alarm)# smtp-server-name smtp.163.com
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

smtp-server-port

To set the SMTP server port that ZoneDirector uses to send alarm notifications, use the following command:

```
smtp-server-port <NUMBER>
```

Syntax Description

smtp-server-port	Set the SMTP server port that ZoneDirector uses to send alarm notifications
<NUMBER>	Set to this SMTP server port

Defaults

587

Example

```
ruckus(config-alarm)# smtp-server-port 25
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

smtp-auth-name

To set the user name that ZoneDirector uses to authenticate with the SMTP server, use the following command:

```
smtp_auth_name <WORD>
```

Syntax Description

smtp_auth_name	Set the user name that ZoneDirector uses to authenticate with the SMTP server
----------------	---

<WORD>	Set to this user name
--------	-----------------------

Defaults	None.
-----------------	-------

Example	<pre>ruckus(config-alarm)# smtp-auth-name joe</pre> <p>The command was executed successfully. To save the changes, type 'end' or 'exit'.</p>
----------------	---

smtp-auth-password

To set the password that ZoneDirector uses to authenticate with the SMTP server, use the following command:

```
smtp-auth-password <WORD>
```

Syntax Description	smtp-auth-password Set the password that ZoneDirector uses to authenticate with the SMTP server
	<WORD> Set to this password

Defaults	None.
-----------------	-------

Example	<pre>ruckus(config-alarm)# smtp-auth-password 123456</pre> <p>The command was executed successfully. To save the changes, type 'end' or 'exit'.</p>
----------------	--

smtp-wait-time

To set the SMTP server wait time (in seconds), use following command:

```
smtp-wait-time <NUMBER>
```

Example	<pre>ruckus(config-alarm)# smtp-wait-time 10</pre> <p>The command was executed successfully. To save the changes, type 'end' or 'exit'.</p> <pre>ruckus(config-alarm) #</pre>
----------------	--

tls-smtp-encryption

To enable TLS for SMTP encryption of alarm notifications, use the following command:

```
tls-smtp-encryption [tls|starttls]
```

Syntax Description	tls-smtp-encryption Enable SMTP encryption of alarm notifications
---------------------------	--

Configuring Controller Settings

Configure Alarm-Event Settings

tls	Enable TLS encryption for alarm notifications
starttls	Enable STARTTLS encryption for alarm notifications

Defaults

None.

Example

```
ruckus(config-alarm)# tls-smtp-encryption tls
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

no tls-smtp-encryption

To disable TLS for SMTP encryption of alarm notifications, use the following command:

```
no tls-smtp-encryption [tls | starttls]
```

Syntax Description

no tls-smtp-encryption	Disable SMTP encryption of alarm notifications
tls	Disable TLS encryption
starttls	Disable STARTTLS encryption

Defaults

None.

Example

```
ruckus(config-alarm)# no tls-smtp-encryption tls
```

The command was executed successfully. To save the changes, type 'end' or 'exit'.

Configure Alarm-Event Settings

Use the alarm-event command to configure which events will trigger ZoneDirector email alerts. Entering this command enters the config-alarm-event context.

alarm-event

To enable email alarm notifications for specific event types, use the following command:

```
alarm-event
```

Syntax Description

event all	Enable email alarms for all event types
no event all	Disable email alarms for all event types

event rogue-ap-detected	Enable email notification when Rogue AP detected
event rogue-device-detected	Enable email notification when Ad hoc network detected
event ap-lost-contacted	AP lost contact
event ssid-spoofing-ap-detected	SSID spoofing AP detected
event mac-spoofing-ap-detected	MAC spoofing AP detected
event rogue-dhcp-server-detected	Rogue DHCP server detected
event temporary-license-expired	Temporary license has expired
event temporary-license-will-expire	Temporary license will expire
event lan-rogue-ap-detected	LAN Rogue AP detected
event aaa-server-unreachable	AAA server unreachable
event ap-has-hardware-problem	AP hardware problem detected
event uplink-ap-lost	Mesh AP uplink connection lost
event incomplete-primary/secondary-ip-settings	AP fails to maintain primary/secondary ZD IP address settings
event smart-redundancy-state-changed	Smart Redundancy device status change detected
event smart-redundancy-active-connected	Smart Redundancy device active device connected
event smart-redundancy-standby-connected	Smart Redundancy standby device connected
event smart-redundancy-active-disconnected	Smart Redundancy active device disconnected
event smart-redundancy-standby-disconnected	Smart Redundancy standby device disconnected
test-alarm ap-lose-connection	Test AP connection lost alarm event
show	Show alarm settings

Defaults	All enabled
----------	-------------

Example	<pre>ruckus(config-alarm) # no event all ruckus(config-alarm) # event uplink-ap-lost ruckus(config-alarm) # show Alarm: Status= Enabled Email Address= johndoe@gmail.com</pre>
---------	--

Configuring Controller Settings

Configure Alarm-Event Settings

```
E-mail From = zonedirector@ruckuswireless.com
SMTP Server Name= smtp.gmail.com
SMTP Server Port= 25
SMTP Authentication Username= johndoe@gmail.com
SMTP Authentication Password= test123
wait time=
SMTP Encryption Options:
TLS= Enabled
STARTTLS= Enabled
Alarm Events Notify By Email:
MSG_rogue_AP_detected= disabled
MSG_ad_hoc_network_detected= disabled
MSG_AP_lost= disabled
MSG_SSID_spoofing_AP_detected= disabled
MSG_MAC_spoofing_AP_detected=disabled
MSG_admin_rogue_dhcp_server= disabled
MSG_admin_templic_oneday=disabled
MSG_lanrogue_AP_detected=disabled
MSG_RADIUS_service_outage= disabled
MSG_AP_hardware_problem= disabled
MSG_ZD_Sensor_problem= disabled
MSG_AP_no_mesh_uplink= enabled
MSG_AP_keep_no_AC_cfg= disabled
MSG_cltr_change_to_active= disabled
MSG_cltr_active_connected= disabled
MSG_cltr_standby_connected=disabled
MSG_cltr_active_disconnected=disabled
MSG_cltr_standby_disconnected= disabled

ruckus(config-alarm) #
```

no event

To disable email alarm notifications for specific event types, use the following command:

```
no event <event_name>
```

Syntax Description

no event	Disable email alarms for this event type
all	Disable email alarms for all event types
rogue-ap-detected	Rogue AP detected

rogue-device-detectedq	Ad hoc network detected
ap-lost-contacted	AP lost contact
ssid-spoofing-ap-detected	SSID spoofing AP detected
mac-spoofing-ap-detected	MAC spoofing AP detected
rogue-dhcp-server-detected	Rogue DHCP server detected
temporary-license-expired	Temporary license has expired
temporary-license-will-expire	Temporary license will expire
lan-rogue-ap-detected	LAN Rogue AP detected
aaa-server-unreachable	AAA server unreachable
ap-has-hardware-problem	AP hardware problem detected
uplink-ap-lost	Mesh AP uplink connection lost
incomplete-primary/secondary-ip-settings	AP fails to maintain primary/secondary ZD IP address settings
smart-redundancy-state-changed	Smart Redundancy device status change detected
smart-redundancy-active-connected	Smart Redundancy device active device connected
smart-redundancy-standby-connected	Smart Redundancy standby device connected
smart-redundancy-active-disconnected	Smart Redundancy active device disconnected
smart-redundancy-standby-disconnected	Smart Redundancy standby device disconnected

Configure Services Commands

Use the services commands to configure miscellaneous service settings, such as automatic power and channel selection settings, ChannelFly, background scanning, rogue AP and rogue DHCP server detection, etc. To run these commands, you must first enter the config-services context.

abort

To exit the config-services context without saving changes, use the `abort` command.

`abort`

Syntax Description

abort	Exit the service settings without saving changes
-------	--

Configuring Controller Settings

Configure Services Commands

Defaults None.

Example

```
ruckus(config-services)# abort  
No changes have been saved.  
ruckus(config)#
```

end

To save changes, and then exit the config-services context, use the following command:

```
end
```

Syntax Description

end	Save changes, and then exit the context
-----	---

Defaults None.

Example

```
ruckus(config-services)# end  
Your changes have been saved.  
ruckus(config)#
```

exit

To save changes, and then exit the config-services context, use the following command:

```
exit
```

Syntax Description

exit	Save changes, and then exit the context
------	---

Defaults None.

Example

```
ruckus(config-services)# exit  
Your changes have been saved.  
ruckus(config)#
```

quit

To exit the config-services context without saving changes, use the **quit** command.

```
quit
```

Syntax Description	quit	Exit the service settings without saving changes
Defaults	None.	
Example	ruckus(config-services) # quit No changes have been saved. ruckus(config) #	

auto-adjust-ap-power

To enable the auto adjustment of theAP radio power, which helps optimize radio coverage when radio interference is present, use the following command:

```
auto-adjust-ap-power
```

Syntax Description	auto-adjust-ap-power	Enable the auto adjustment of theAP radio power
Defaults	None.	
Example	ruckus(config-services) # auto-adjust-ap-power The command was executed successfully.	

no auto-adjust-ap-power

To disable the auto adjustment of theAP radio power, which helps optimize radio coverage when radio interference is present, use the following command:

```
no auto-adjust-ap-power
```

Syntax Description	no auto-adjust-ap-power	Disable the auto adjustment of theAP radio power
Defaults	None.	
Example	ruckus(config-services) # no auto-adjust-ap-power The command was executed successfully.	

auto-adjust-ap-channel

To enable the auto adjustment of theAP radio channel when radio interference is present, use the following command:

```
auto-adjust-ap-channel
```

Configuring Controller Settings

Configure Services Commands

Syntax Description	auto-adjust-ap-channel	Enable the auto adjustment of theAP radio channel
---------------------------	------------------------	---

Defaults	None.
-----------------	-------

Example	ruckus(config-services) # auto-adjust-ap-channel The command was executed successfully.
----------------	---

no auto-adjust-ap-channel

To disable the auto adjustment of theAP radio channel when radio interference is present, use the following command:

```
no auto-adjust-ap-channel
```

Syntax Description	no auto-adjust-ap-channel	Disable the auto adjustment of theAP radio channel
---------------------------	---------------------------	--

Defaults	None.
-----------------	-------

Example	ruckus(config-services) # no auto-adjust-ap-channel The command was executed successfully.
----------------	--

channelfly

To enable ChannelFly channel management, use the following command:

```
channelfly [radio-2.4-mtbc | radio-5-mtbc] <NUMBER>
```

Syntax Description	channelfly	Enable ChannelFly automatic adjustment of theAP radio channel
	radio-2.4	Enable ChannelFly on the 2.4 GHz radio
	radio-5	Enable ChannelFly on the 5 GHz radio
	mtbc	Set the mean time between channel changes
	<NUMBER>	Number in minutes (1~1440) to set as mean time between channel change

Defaults	Enabled for both 2.4 and 5 GHz radios MTBC: 100
-----------------	--

Example

```
ruckus(config-services)# channelfly radio-2.4 100  
The command was executed successfully.  
ruckus(config-services)#[/pre>
```

Example

```
ruckus(config-services)# channelfly radio-2.4-mtbc 100  
The command was executed successfully.  
ruckus(config-services)#[/pre>
```

no channelfly

To disable ChannelFly channel management, use the following command:

```
no channelfly [radio-2.4 | radio-5]
```

Syntax Description

no channelfly	Disable ChannelFly automatic adjustment of the AP radio channel
radio-2.4	Disable ChannelFly on the 2.4 GHz radio
radio-5	Disable ChannelFly on the 5 GHz radio

Defaults

None.

Example

```
ruckus(config-services)# no channelfly radio-2.4  
The command was executed successfully.  
ruckus(config-services)# no channelfly radio-5  
The command was executed successfully.  
ruckus(config-services)#[/pre>
```

background-scan

To enable background scanning and configure the scan interval, use the following command:

```
background-scan [radio-2.4-interval | radio-5-interval]  
<NUMBER>
```

Syntax Description

background-scan	Enable background scanning and configure the scan interval
radio-2.4-interval	Configure background scanning interval for the 2.4 GHz radio
radio-5-interval	Configure background scanning interval for the 5 GHz radio

Configuring Controller Settings

Configure Services Commands

	<NUMBER>	Perform background scan at this interval (in seconds)
Defaults	20 seconds	
Example	ruckus(config-services) # background-scan radio-2.4-interval 6 The command was executed successfully.	
	no background-scan	
	To disable background scanning on the 2.4GHz radio, use the following command:	
	no background-scan [radio-2.4 radio-5]	
Syntax Description		
	no background-scan	Disable background scanning
	radio-2.4	Disable background scanning on the 2.4GHz radio
	radio-5	Disable background scanning on the 5GHz radio
Defaults	None	
Example	ruckus(config-services) # no background-scan radio-2.4 The command was executed successfully. ruckus(config-services) # no background-scan radio-5 The command was executed successfully.	
	aeroscout-detection	
	To enable detection of AeroScout RFID Tags by APs that are managed by ZoneDirector, use the following command:	
	aeroscout-detection	
Syntax Description		
	aeroscout-detection	Enable detection of AeroScout RFID Tags by APs
Defaults	None	
Example	ruckus(config-services) # aeroscout-detection The command was executed successfully.	

no aeroscout-detection

To disable detection of AeroScout RFID Tags by APs that are managed by ZoneDirector, use the following command:

```
no aeroscout-detection
```

Syntax Description	no aeroscout-detection	Disable detection of AeroScout RFID Tags by APs
Defaults	None	
Example	ruckus(config-services)# no aeroscout-detection The command was executed successfully.	

tun-encrypt

To enable tunnel encryption for tunneled traffic, use the following command:

```
tun-encrypt
```

Defaults	Disabled
Example	ruckus(config-services)# tun-encrypt The command was executed successfully.

no tun-encrypt

To disable tunnel encryption for tunneled traffic, use the following command:

```
no tun-encrypt
```

Defaults	Disabled
Example	ruckus(config-services)# no tun-encrypt The command was executed successfully.

tun-block-mcast all

To enable multicast blocking for tunneled traffic, use the following command:

```
tun-block-mcast all
```

Defaults	Disabled
-----------------	----------

Configuring Controller Settings

Configure Services Commands

Example

```
ruckus(config-services) # tun-block-mcast all  
The command was executed successfully.  
ruckus(config-services) #
```

tun-block-mcast non-well-known

To enable multicast blocking for non-well-known tunneled traffic, use the following command:

```
tun-block-mcast non-well-known
```

Defaults

Disabled

Example

```
ruckus(config-services) # tun-block-mcast non-well-known  
The command was executed successfully.  
ruckus(config-services) #
```

no tun-block-mcast

To disable blocking multicast traffic from network to tunnel, use the following command:

```
no tun-block-mcast
```

tun-block-bcast

To enable broadcast blocking for tunneled traffic, use the following command:

```
tun-block-bcast
```

Defaults

Disabled

Example

```
ruckus(config-services) # tun-block-bcast  
The command was executed successfully.  
ruckus(config-services) #
```

no tun-block-bcast

To disable blocking broadcast traffic from network to tunnel except ARP and DHCP, use the following command:

```
no tun-block-bcast
```

tun-proxy-arp

To enable proxy ARP service for tunneled traffic, use the following command:

```
tun-proxy-arp <NUMBER>
```

Defaults Disabled

Example

```
ruckus(config-services)# tun-proxy-arp 1000
The command was executed successfully.
ruckus(config-services)#{}
```

no tun-proxy-arp

To disable Proxy ARP for the tunneled WLAN, use the following command:

```
no tun-proxy-arp
```

tun-ip-ageing

To set ageing time for IP/IPv6 table, use the following command:

```
tun-ip-ageing <NUMBER>
```

pif

To enable Packet Inspection Filter and set rate limiting threshold, use the following command:

```
pif [uplink-proc | rate-limit <NUMBER>]
```

Syntax Description

pif	Enable Packet Inspection Filter
uplink-proc	Enable uplink process of Packet Inspection Filter
rate-limit	Enable and set Broadcast Neighbor Discovery Packets (ARP and ICMPv6 Neighbor Solicit) rate limit threshold.
<NUMBER>	Rate limiting threshold for PIF feature.

Example

```
ruckus(config-services)# pif uplink-proc
The command was executed successfully.
ruckus(config-services)# pif rate-limit 1000
The command was executed successfully.
ruckus(config-services)# show
Services:
    Automatically adjust ap radio power= Disabled
    Automatically adjust ap channel= Enabled
    Channelfly works on 2.4GHz radio:
        Status= Disabled
    Channelfly works on 5GHz radio:
        Status= Disabled
```

Configuring Controller Settings

Configure Services Commands

```
Run a background scan on 2.4GHz radio:  
  Status= Enabled  
  Time= 20 seconds  
Run a background scan on 5GHz radio:  
  Status= Enabled  
  Time= 20 seconds  
AeroScout RFID tag detection= Disabled  
Tunnel encryption for tunneled traffic= Enabled  
Block multicast traffic from network to tunnel= Disabled  
Block broadcast traffic from network to tunnel except ARP and  
DHCP= Disabled  
Tunnel Proxy ARP of tunnel WLAN:  
  status= Disabled  
Packet Inspection Filter(PIF) uplink process= Enabled  
Packet Inspection Filter(PIF) rate limit:  
  status= Enabled  
  rate limit= 1000  
ruckus(config-services) #
```

no pif

To disable uplink process of packet inspection filter or disables Broadcast Neighbor Discovery Packets (ARP and ICMPv6 Neighbor Solicit), use the following command:

```
no pif [uplink-proc | rate-limit <NUMBER>]
```

show

To display the current service settings, use the following command:

```
show
```

Syntax Description

show	Display the current service settings
------	--------------------------------------

Defaults

None.

Example

```
ruckus(config-services) # show  
Services:  
  Automatically adjust ap radio power= Disabled  
  Automatically adjust ap channel= Enabled  
  Channelfly works on 2.4GHz radio:  
    Status= Disabled  
  Channelfly works on 5GHz radio:  
    Status= Disabled
```

```
Run a background scan on 2.4GHz radio:  
  Status= Enabled  
  Time= 2000 seconds  
Run a background scan on 5GHz radio:  
  Status= Enabled  
  Time= 2000 seconds  
AeroScout RFID tag detection= Disabled  
Tunnel encryption for tunneled traffic= Disabled  
Block multicast traffic from network to tunnel= Block non well-known  
Block broadcast traffic from network to tunnel except ARP and  
DHCP= Disabled  
Tunnel Proxy ARP of tunnel WLAN:  
  status= Disabled  
  ageing time= 0  
Packet Inspection Filter(PIF) uplink process= Disabled  
Packet Inspection Filter(PIF) rate limit:  
  status= Disabled  
ruckus(config-services) #
```

Configure WIPS Commands

Use the `wips` commands to configure Wireless Intrusion Prevention settings. To run these commands, you must first enter the `config-wips` context.

wips

Use the `wips` command to enter the `config-wips` context and configure WIPS settings.

```
wips
```

Syntax Description

<code>help</code>	Shows available commands.
<code>history</code>	Shows a list of previously run commands.
<code>end</code>	Saves changes, and the exits the <code>config-wips</code> context.
<code>exit</code>	Saves changes, and the exits the <code>config-wips</code> context.
<code>no</code>	Disable WIPS services.
<code>protect-excessive-wireless-request</code>	Enables protecting the wireless network against excessive wireless requests.

Configuring Controller Settings

Configure WIPS Commands

temp-block-auth-failed-client	Temporarily block wireless clients with repeated authentication failures.
rogue-report	Enables report rogue devices in ZD event log.
malicious-report	Enables protecting the network from malicious rogue access points.
rogue-dhcp-detection	Enables rogue DHCP server detection.
show	Displays the WIPS settings.

Example

```
ruckus(config)# wips
ruckus(config-wips)# show
  Protect my wireless network against excessive wireless requests=
  Disabled
  Temporarily block wireless clients with repeated authentication
  failures:
    Status= Enabled
    Time= 30 seconds
    Report rogue devices in ZD event log= Enabled
    Protect the network from malicious rogue access points= Disabled
    Rogue DHCP server detection= Enabled
ruckus(config-wips)# temp-block-auth-failed-client time 45
The command was executed successfully.
ruckus(config-wips)# show
  Protect my wireless network against excessive wireless requests=
  Disabled
  Temporarily block wireless clients with repeated authentication
  failures:
    Status= Enabled
    Time= 45 seconds
    Report rogue devices in ZD event log= Enabled
    Protect the network from malicious rogue access points= Disabled
    Rogue DHCP server detection= Enabled
ruckus(config-wips)# end
Your changes have been saved.
ruckus(config)#

```

Using Debug Commands

In This Chapter

Debug Commands Overview	361
General Debug Commands	361
Show Commands	365
Accessing a Remote AP CLI	370
Working with Debug Logs and Log Settings	371
Remote Troubleshooting	384
AP Core Dump Collection	385
Script Execution	386

Debug Commands Overview

This section describes the commands that you can use to debug ZoneDirector and connected APs, and to configure debug log settings. From the privileged commands context, type **debug** to enter the debug context. To show a list of commands available from within the debug context, type **help** or **?**.

General Debug Commands

The following section describes general debug commands can be executed from within the debug context.

help

Shows available commands.

list-all

List all available commands.

history

Shows a list of previously run commands.

quit

Exits the debug context.

fw_upgrade

To upgrade the controller's firmware, use the following command:

```
fw_upgrade <protocol>://<server ip|server name>/<path/image  
name> [-f]  
fw_upgrade OPTIONS
```

Syntax Description

fw_upgrade	Upgrade the controller's firmware
<protocol>	Protocol for image transfer (FTP, TFTP, HTTP, KERMIT)
<OPTIONS>	 -p: protocol -s: server IP address or name -n: image name with path on the server -f: non-verbose mode -h: fw_upgrade help message

Defaults None.

Example

```
ruckus# debug
ruckus(debug) # fw_upgrade ftp://<user>:<password>@<server ip>/
<image file>
```

delete-station

To deauthorize the station with the specified MAC address, use the following command.

```
delete-station <MAC>
```

Syntax Description

delete-station	Delete the station with the specified MAC address
<MAC>	The MAC address of the station that will be deleted

Defaults None.

Example

```
ruckus# debug
ruckus(debug) # delete-station 00:10:77:01:00:01
The command was executed successfully.
```

restart-ap

To restart the device with the specified MAC address, use the `restart_ap` command.

```
restart-ap <MAC>
```

Syntax Description

restart-ap	Restart the device with the specified MAC address
<MAC>	The MAC address of the device to be restarted

Defaults None.

Example

```
ruckus# debug
ruckus(debug) # restart-ap 00:13:92:EA:43:01
The command was executed successfully.
```

load-custom-ap

To load an AP customization file, use the following command:

```
load-custom-ap <WORD>
```

wlaninfo

Configures and enables debugging of WLAN service settings.

```
wlaninfo <OPTIONS>
```

Syntax Description

wlaninfo	Enable logging of WLAN info
<OPTIONS>	Configure WLAN debug information options

Defaults

None.

Example

```
ruckus(debug) # wlaninfo -W
WLAN svc "ruckus1" (id=1):
    WLAN ID = 0, ref_cnt = 5
    SSID = "ruckus1" enabled
    Apply to 11a and 11g/b radios
    Closed system = No, Privacy = Enabled, ACL enabled Guest-WLAN = No
    WISPr-WLAN = No
    Access Policy = 0/0, Web Auth = No, grace period = 0 (0 means
    disable), max clients = 100
    WMM = enabled priority = 0 uplink = DISABLE downlink = DISABLE
    Cipher = Clear Text Local bridging = Enabled, vlan = 1, dvlan =
    Disabled, bgscan = Enabled
    wep key index = 0, wep key len = 0
    PAP message authenticator = Enabled, EAP-Failure = Disabled
    Num of VAP deployed: 4
        VAP: c4:10:8a:1f:d1:fc, number of stations = 1
        VAP: c4:10:8a:1f:d1:f8, number of stations = 0
        VAP: 04:4f:aa:0c:b1:0c, number of stations = 0
        VAP: 04:4f:aa:0c:b1:08, number of stations = 0
    ACL 1 (System): default=Allowed system-wide=yes
    Auth Policy:
        Auth Algorithms:RSN/PSK  RSN/Dynamic PSK
        Auth Server Type: None
        WPA Version: WPA2
        WPA Auth and Key Management: WPA PSK
        GTK life time = 28800 seconds, GTK Life size = 2000 Kpkts
```

```
GMK life time = 86400 seconds, Strict Rekey = No
WPA Group Cipher Suites:0x00000010
    CCMP
    WPA Pairwise Cipher Suites:0x00000010
        CCMP
    NASID Type: = wlan-bssid
    PMK Cache Time: = 43200
    PMK Cache for Reconnect: = enabled
    Roaming Acct-Inerim-Update: = disabled
    Called-Station-Id-type: 0
    Classification: enabled
    UDP Heuristic Classification: enabled
    Directed Multicast: enabled
    IGMP Snooping: enabled
    MLD Snooping: enabled
    ToS Classification: enabled
    Dot1p Classification: disabled
    Multicast Filter: disabled
    Directed Threshold: 5
    Priority: Voice:0 Video:2 Data:4 Background:6

*** Total WLAN Entries: 1 ***
wlaninfo -W
ruckus(debug) #
```

save_debug_info

Saves debug information.

```
save_debug_info <IP-ADDR> <FILE-NAME>
```

Syntax Description

save_debug_info	Save debug log file
<IP-ADDR>	The destination IP address
<FILE-NAME>	The destination file name

Defaults

None.

Example

```
ruckus(debug) # save_debug_info 192.168.11.26 log.log
Creating debug info file ...
Done
Sending debug info file to "log.log@192.168.11.26" ...
...
```

Using Debug Commands

Show Commands

```
ruckus (debug) #
```

save-config

Upload the configuration file to the designated TFTP site.

```
save-config <IP-ADDR> <FILE-NAME>
```

Syntax Description

save-config	Upload the configuration file
<IP-ADDR>	The destination IP address
<FILE-NAME>	The destination file name

Defaults

None.

Example

```
ruckus (debug) # save-config 192.168.11.26 config.log
Creating backup config file
Done
Uploading backup config file
...
ruckus (debug) #
```

Show Commands

This section describes the show commands available within the debug context.

show ap

Displays a list of all approved devices.

```
show ap
```

Syntax Description

show ap	Display a list of all approved APs
---------	------------------------------------

Defaults

None.

Example

```
ruckus (debug) # show ap
AP:
ID:
1:
MAC Address= 04:4f:aa:0d:b1:00
```

```
Model= zf7962
Approved= Yes
Device Name= 7962-MAP
...
...
ruckus(debug) #
```

show station

Displays a list of all connected stations (or clients).

```
show station
```

Syntax Description

show station	Show all connected stations
--------------	-----------------------------

Defaults

None.

Example

```
ruckus(debug) # show station
Clients List:
Client:
  MAC Address= 6c:62:6d:1b:e3:00
  User Name=
  IP Address= 192.168.11.11
  IPv6 Address=
  Access Point= 04:4f:aa:0c:b1:00
  WLAN= Ruckus1
  Channel= 1
  Signal (dB)= 53

Client:
  MAC Address= 00:22:fb:ad:1b:2e
  User Name=
  IP Address= 192.168.11.7
  IPv6 Address=
  Access Point= 04:4f:aa:0c:b1:00
  WLAN= Ruckus1
  Channel= 165
  Signal (dB)= 42

ruckus(debug) #
```

show logs

Displays a list of debug log components.

```
show logs
```

Using Debug Commands

Show Commands

Syntax Description

show logs	Display debug log components
-----------	------------------------------

Defaults

None.

Example

```
ruckus (debug) # show logs
Debug Logs:
    All= Enabled
    Sys-mgmt= Enabled
    Mesh= Enabled
    Web-auth= Enabled
    Rf-mgmt= Enabled
    Radius= Enabled
    Hotspot-srv= Enabled
    Aps= Enabled
    Net-mgmt= Enabled
    802.1x= Enabled
    Web-svr= Enabled
    802.11= Enabled
    Dvlan= Enabled
    Smart-redundancy= Enabled
    Debug logs of specified MAC address:
        Status= Disabled
ruckus (debug) #
```

show remote-troubleshooting

Shows remote-troubleshooting status.

```
show remote-troubleshooting
```

Syntax Description

show remote-troubleshooting	Display remote troubleshooting status
-----------------------------	---------------------------------------

Defaults

None.

Example

```
ruckus(debug)# show remote-troubleshooting
Ruckus CA troubleshooting is stopped!
The server addr is: None
```

ruckus(debug)#

ps

Displays information about all processes that are running (ps -aux).

ps

Syntax Description	ps	Display a list of all running processes
--------------------	----	---

Defaults	None.
----------	-------

Example	ruckus (debug) # ps
	<pre>PID PPID USER VSZ STAT COMMAND 1 0 ruckus 1200 S init 2 1 ruckus 0 SWN [ksoftirqd/0] 3 1 ruckus 0 SW [watchdog/0] 4 1 ruckus 0 SW< [events/0] 5 1 ruckus 0 SW< [khelper] 6 1 ruckus 0 SW< [kthread] 7 6 ruckus 0 SW< [kblockd/0] 8 6 ruckus 0 SW< [khubd] 9 6 ruckus 0 SW [pdflush] 10 6 ruckus 0 SW [pdflush] 12 6 ruckus 0 SW< [aio/0] 11 1 ruckus 0 SW [kswapd0] 13 1 ruckus 0 SW [mtdblockd] 14 6 ruckus 0 SW< [scsi_eh_0] 15 6 ruckus 0 SW< [usb-storage] 17 6 ruckus 0 SW< [V54_bodygard/0] 18 1 ruckus 0 SW [pktgen/0] 29 6 ruckus 0 SW< [reiserfs/0] 104 1 ruckus 956 S /usr/sbin/in.tftpd -l -s /etc/ airespider-images 110 1 ruckus 660 S /bin/wd_feeder 242 1 ruckus 2572 S /bin/emf_repo_flashsync monitor 15 243 1 ruckus 944 S ttymologd 246 1 ruckus 0 SW< [uif-246] 260 1 ruckus 14492 S stamgr -d3 -t0 266 260 ruckus 14492 S stamgr -d3 -t0 267 266 ruckus 14492 S < stamgr -d3 -t0 268 266 ruckus 14492 S stamgr -d3 -t0</pre>

Using Debug Commands

Show Commands

269	1	ruckus	2268	S	apmgr
277	269	ruckus	2268	S	apmgr
278	277	ruckus	2268	S <	apmgr
299	1	ruckus	19564	S	emfd
316	299	ruckus	19564	S	emfd
317	316	ruckus	19564	S	emfd
318	316	ruckus	19564	S	emfd
322	1	ruckus	1108	S	/usr/sbin/dropbear -e /bin/login.sh
	-r	/etc/air			
328	1	ruckus	1188	S	/bin/sh /bin/login.sh
329	1	ruckus	1188	S	/bin/sh /bin/tacmon.sh
331	1	ruckus	676	S	/bin/rhttpd
332	1	ruckus	1140	S <	/bin/zapd
333	1	ruckus	1100	S <	/bin/clusterD
334	328	ruckus	856	S	/bin/login
335	329	ruckus	680	S	/bin/tacmon -i 30 -r 15
347	1	ruckus	808	S	/bin/tsyslogd -r -h -n --rotate=7
368	277	ruckus	2268	S <	apmgr
369	277	ruckus	2268	S <	apmgr
572	1	ruckus	1184	S	/sbin/udhcpc -i br0 --pidfile=/var/run/udhcpc.p
580	316	ruckus	19564	S	emfd
612	316	ruckus	19564	S	emfd
616	316	ruckus	19564	S	emfd
622	316	ruckus	19564	S	emfd
624	299	ruckus	6132	S <	webs &
625	316	ruckus	19564	S	emfd
637	624	ruckus	6132	S	webs &
638	637	ruckus	6132	S <	webs &
639	637	ruckus	6132	S <	webs &
640	637	ruckus	6132	S <	webs &
641	637	ruckus	6132	S <	webs &
642	637	ruckus	6132	S	webs &
655	637	ruckus	6132	S <	webs &
656	637	ruckus	6132	S <	webs &
20503	316	ruckus	19564	S	emfd
30679	1	ruckus	2672	S	/usr/sbin/vsftpd /etc/vsftpd2.conf
10220	322	ruckus	1184	S	/usr/sbin/dropbear -e /bin/login.sh
	-r	/etc/air			
10221	10220	ruckus	1188	S	/bin/sh /bin/login.sh
10222	10221	ruckus	856	S	/bin/login
10223	10222	ruckus	7972	S	ruckus_cli2
10426	10223	ruckus	1188	S	sh -c /bin/ps -aux

```
10427 10426 ruckus      1188 R      /bin/ps -aux
ruckus (debug) #
```

Accessing a Remote AP CLI

The following command is used to access the command line interface of a connected AP and execute AP CLI commands from ZoneDirector. Configuration changes made through the AP CLI may be overwritten by ZoneDirector settings if the AP is restarted or reconnects to ZoneDirector.

remote_ap_cli

Use the `remote_ap_cli` command to access an AP remotely and execute AP CLI commands.

```
remote_ap_cli [-q] {-a ap_mac | -A } "cmd arg1 arg2 ..."
```

Syntax Description

<code>remote_ap_cli</code>	Execute CLI commands in a remote AP
<code>-q</code>	Do not display results
<code>-a</code>	Specify AP by MAC address
<code>ap_mac</code>	The AP's MAC address
<code>-A</code>	All connected APs
<code>cmd</code>	AP CLI command
<code>arg</code>	AP CLI command argument

Defaults

None.

Example

```
rruckus (debug) # remote_ap_cli -A get director
---- Command 'rkscli -c "get director "' executed at
04:4f:aa:0c:b1:00
----- ZoneDirector Info -----
Primary Controller : n/a
Secondary Controller : n/a
DHCP Opt43 Code : 3
```

The information of the most recent Zone Director:

```
[1] 192.168.11.100
```

```
AP is under management of ZoneDirector: 192.168.11.100 / :: /
00:13:11:01:01:01,
Currently AP is in state: RUN
```

Using Debug Commands

Working with Debug Logs and Log Settings

```
OK
---- Command 'rkscli -c "get director "' executed at
c4:10:8a:1f:d1:f0
----- ZoneDirector Info -----
Primary Controller : n/a
Secondary Controller : n/a
DHCP Opt43 Code : 3

The information of the most recent Zone Director:
[1] 192.168.11.100

AP is under management of ZoneDirector: 192.168.11.100 / :: /
00:13:11:01:01:01,
Currently AP is in state: RUN
OK
---- Command Execution Summary:
    success: 2
    failure: 0
    total: 2
rksap_cli -A get director
ruckus(debug) #
```

Working with Debug Logs and Log Settings

This section describes the commands that you can use to configure and review ZoneDirector debug logs.

logs all

Enables debug logs of all debug components.

Syntax Description

logs all	Enable logging of all debug components
----------	--

Defaults

None.

Example

```
ruckus(debug) # logs all
The command was executed successfully.
ruckus(debug) # show logs
Debug Logs:
    All= Enabled
    Sys-mgmt= Enabled
```

```
Mesh= Enabled
Web-auth= Enabled
Rf-mgmt= Enabled
Radius= Enabled
Hotspot-srv= Enabled
Aps= Enabled
Net-mgmt= Enabled
802.1x= Enabled
Web-svr= Enabled
802.11= Enabled
Dvlan= Enabled
Smart-redundancy= Enabled
Debug logs of specified MAC address:
    Status= Disabled
ruckus (debug) #
```

logs comp sys-mgmt

Enables debug logs of system management components.

Syntax Description

logs	Enable debug logs
comp sys-mgmt	Component system management

Defaults

None.

Example

```
ruckus (debug) # logs comp sys-mgmt
The command was executed successfully.
ruckus (debug) # show logs
Debug Logs:
    All= Disabled
    Sys-mgmt= Enabled
    Mesh= Disabled
    Web-auth= Disabled
    Rf-mgmt= Disabled
    Radius= Disabled
    Hotspot-srv= Disabled
    Aps= Disabled
    Net-mgmt= Disabled
    802.1x= Disabled
    Web-svr= Disabled
```

Using Debug Commands

Working with Debug Logs and Log Settings

```
802.11= Disabled
Dylan= Disabled
Smart-redundancy= Disabled
Debug logs of specified MAC address:
  Status= Disabled
ruckus(debug) #
```

logs comp mesh

Enables debug logs of mesh components.

Syntax Description

logs	Enable debug logs
comp mesh	Component mesh

Defaults

None.

Example

```
ruckus(debug) # logs comp mesh
The command was executed successfully.
ruckus(debug) #
```

logs comp web-auth

Enables debug logs of web authentication components.

Syntax Description

logs	Enable debug logs
comp web-auth	Component web auth

Defaults

None.

Example

```
ruckus(debug) # logs comp web-auth
The command was executed successfully.
ruckus(debug) #
```

logs comp rf-mgmt

Enables debug logs of RF management components.

Syntax Description

logs	Enable debug logs
comp rf-mgmt	Component RF management

Defaults

None.

Example

```
ruckus (debug) # logs comp rf-mgmt  
The command was executed successfully.  
ruckus (debug) #
```

logs comp radius

Enables debug logs of radius components.

Syntax Description

logs	Enable debug logs
comp radius	Component RADIUS

Defaults

None.

Example

```
ruckus (debug) # logs comp radius  
The command was executed successfully.  
ruckus (debug) #
```

logs comp hotspot-srv

Enables debug logs of hotspot services components.

Syntax Description

logs	Enable debug logs
comp hotspot-srv	Component Hotspot services

Defaults

None.

Example

```
ruckus (debug) # logs comp hotspot-srv  
The command was executed successfully.  
ruckus (debug) #
```

Using Debug Commands

Working with Debug Logs and Log Settings

logs comp aps

Enables debug logs of AP components.

Syntax Description

logs	Enable debug logs
comp aps	Component APs

Defaults

None.

Example

```
ruckus (debug) # logs comp aps  
The command was executed successfully.  
ruckus (debug) #
```

logs comp net-mgmt

Enables debug logs of network management components.

Syntax Description

logs	Enable debug logs
comp net-mgmt	Component network management

Defaults

None.

Example

```
ruckus (debug) # logs comp net-mgmt  
The command was executed successfully.  
ruckus (debug) #
```

logs comp 802.1x

Enables debug logs of 802.1x components.

Syntax Description

logs	Enable debug logs
comp 802.1x	Component 802.1x

Defaults

None.

Example

```
ruckus (debug) # logs comp 802.1x
```

The command was executed successfully.
ruckus (debug) #

logs comp web-svr

Enables debug logs of web server components.

Syntax Description

logs	Enable debug logs
comp web-svr	Component Web server

Defaults

None.

Example

ruckus (debug) # **logs comp web-svr**
The command was executed successfully.
ruckus (debug) #

logs comp 802.11

Enables debug logs of 802.11 components.

Syntax Description

logs	Enable debug logs
comp 802.11	Component 802.11

Defaults

None.

Example

ruckus (debug) # **logs comp 802.11**
The command was executed successfully.
ruckus (debug) #

logs comp dvlan

Enables debug logs of dynamic VLAN components.

Syntax Description

logs	Enable debug logs
comp dvlan	Component dynamic VLAN

Using Debug Commands

Working with Debug Logs and Log Settings

Defaults None.

Example

```
ruckus (debug) # logs comp dvlan
The command was executed successfully.
ruckus (debug) #
```

logs comp smart-redundancy

Enables debug logs of smart redundancy components.

Syntax Description

logs	Enable debug logs
comp smart-redundancy	Component Smart Redundancy

Defaults None.

Example

```
ruckus (debug) # logs comp smart-redundancy
The command was executed successfully.
ruckus (debug) #
```

logs mac

Enables and sets filter running logs based on specified mac address.

```
logs mac <MAC>
```

Syntax Description

logs	Enable debug logs
mac	Filter logs by specific MAC address
<MAC>	The MAC address of the device to be filtered

Defaults None.

Example

```
ruckus (debug) # logs mac 04:4f:aa:0c:b1:00
The command was executed successfully.
ruckus (debug) #
```

logs play

Starts displaying logs on console.

Syntax Description

logs	Enable debug logs
play	Start log play

Defaults

None.

Example

```
rukus(debug) # logs play
rukus(debug) # [Feb 15 05:53:30] [EMFD] [debug] jobService-
Func():Executing job[user auth attempt_hash_autoexpire] at
1329285210...
[Feb 15 05:53:30] [EMFD] [debug] jobServiceFunc():Executing job at
1329285210...Done
[Feb 15 05:53:30] [EMFD] [debug] jobServiceFunc():Executing
job[station auth attempt_hash_autoexpire] at 1329285210...
[Feb 15 05:53:30] [EMFD] [debug] jobServiceFunc():Executing job at
1329285210...Done
[Feb 15 05:53:33] [STAMgr] [debug] acsrvvc_thread():ACSRVC rcv AP
04:4f:aa:0c:b1:00, IP= 192.168.11.6, IPv6=fc00::1
...
...
rukus(debug) # no logs play
rukus(debug) #
```

no logs all

Disables debug logs of all debug components.

Syntax Description

no logs	Disable debug logs
all	Disable all log components

Defaults

None.

Example

```
rukus(debug) # no logs all
The command was executed successfully.
rukus(debug) #
```

Using Debug Commands

Working with Debug Logs and Log Settings

no logs comp sys-mgmt

Disables debug logs of system management components.

Syntax Description

no logs	Disable debug logs
comp sys-mgmt	Component system management

Defaults

None.

Example

```
ruckus (debug) # no logs comp sys-mgmt  
The command was executed successfully.  
ruckus (debug) #
```

no logs comp mesh

Disables debug logs of mesh components.

Syntax Description

no logs	Disable debug logs
comp mesh	Component Mesh

Defaults

None.

Example

```
ruckus (debug) # no logs comp mesh  
The command was executed successfully.  
ruckus (debug) #
```

no logs comp web-auth

Disables debug logs of web authentication components.

Syntax Description

no logs	Disable debug logs
comp web-auth	Component Web authentication

Defaults

None.

Example

```
ruckus (debug) # no logs comp web-auth
```

The command was executed successfully.
ruckus (debug) #

no logs comp rf-mgmt

Disables debug logs of RF management components.

Syntax Description

no logs	Disable debug logs
comp rf-mgmt	Component RF management

Defaults

None.

Example

ruckus (debug) # **no logs comp rf-mgmt**
The command was executed successfully.
ruckus (debug) #

no logs comp radius

Disables debug logs of radius components.

Syntax Description

no logs	Disable debug logs
comp radius	Component RADIUS

Defaults

None.

Example

ruckus (debug) # **no logs comp radius**
The command was executed successfully.
ruckus (debug) #

no logs comp hotspot-srv

Disables debug logs of hotspot services components.

Syntax Description

no logs	Disable debug logs
comp hotspot-srv	Component Hotspot services

Defaults

None.

Using Debug Commands

Working with Debug Logs and Log Settings

Example

```
ruckus (debug) # no logs comp hotspot-srv  
The command was executed successfully.  
ruckus (debug) #
```

no logs comp aps

Disables debug logs of access points components.

Syntax Description

no logs	Disable debug logs
comp aps	Component APs

Defaults

None.

Example

```
ruckus (debug) # no logs comp aps  
The command was executed successfully.  
ruckus (debug) #
```

no logs comp net-mgmt

Disables debug logs of network management components.

Syntax Description

no logs	Disable debug logs
comp net-mgmt	Component network management

Defaults

None.

Example

```
ruckus (debug) # no logs comp net-mgmt  
The command was executed successfully.  
ruckus (debug) #
```

no logs comp 802.1x

Disables debug logs of 802.1x components.

Syntax Description

no logs	Disable debug logs
comp 802.1x	Component 802.1x

Defaults

None.

Example

```
ruckus (debug) # no logs comp 802.1x  
The command was executed successfully.  
ruckus (debug) #
```

no logs comp web-svr

Disables debug logs of web server components.

Syntax Description

no logs	Disable debug logs
comp web-svr	Component Web server

Defaults

None.

Example

```
ruckus (debug) # no logs comp web-svr  
The command was executed successfully.  
ruckus (debug) #
```

no logs comp 802.11

Disables debug logs of 802.11 components.

Syntax Description

no logs	Disable debug logs
comp 802.11	Component 802.11

Defaults

None.

Example

```
ruckus (debug) # no logs comp 802.11  
The command was executed successfully.  
ruckus (debug) #
```

no logs comp dvlan

Disables debug logs of dynamic vlan components.

Syntax Description

no logs	Disable debug logs
comp dvlan	Component DVLAN

Defaults

None.

Using Debug Commands

Working with Debug Logs and Log Settings

Example

```
ruckus (debug) # no logs comp dvlan  
The command was executed successfully.  
ruckus (debug) #
```

no logs comp smart-redundancy

Disables debug logs of smart redundancy components.

Syntax Description

no logs	Disable debug logs
comp smart-redundancy	Component Smart Redundancy

Defaults

None.

Example

```
ruckus (debug) # no logs comp smart-redundancy  
The command was executed successfully.  
ruckus (debug) #
```

no logs mac

Disables MAC address filtering on running logs.

Syntax Description

no logs	Disable debug logs
mac	Filter by MAC address

Defaults

None.

Example

```
ruckus (debug) # no logs mac  
The command was executed successfully.  
ruckus (debug) #
```

no logs play

Stops displaying logs on console.

Syntax Description

no logs	Disable debug logs
play	Stop log play

Defaults

None.

Example

```
rruckus (debug) # logs play
ruckus (debug) # [Feb 15 05:53:30] [EMFD] [debug] jobService-
Func():Executing job[user auth attempt_hash_autoexpire] at
1329285210...
[Feb 15 05:53:30] [EMFD] [debug] jobServiceFunc():Executing job at
1329285210...Done
[Feb 15 05:53:30] [EMFD] [debug] jobServiceFunc():Executing
job[station auth attempt_hash_autoexpire] at 1329285210...
[Feb 15 05:53:30] [EMFD] [debug] jobServiceFunc():Executing job at
1329285210...Done
[Feb 15 05:53:33] [STAMgr] [debug] acsrvc_thread():ACSRVC rcv AP
04:4f:aa:0c:b1:00, IP= 192.168.11.6, IPv6=fc00::1
...
...
ruckus (debug) # no logs play
ruckus (debug) #
```

Remote Troubleshooting

This section describes remote troubleshooting commands.

remote-troubleshooting server

To set the remote troubleshooting server IP address, use the following command:

```
remote-troubleshooting server <IP-ADDR>
```

remote-troubleshooting start

Enables remote troubleshooting.

Syntax Description

remote-troubleshooting	Remote troubleshooting
start	Start remote troubleshooting

Defaults

None.

Example

```
ruckus (debug) # remote-troubleshooting start
ruckus (debug) #
```

remote-troubleshooting stop

Disables remote troubleshooting.

Syntax Description

remote-	Remote troubleshooting
troubleshooting	
stop	Stop remote troubleshooting

Defaults

None.

Example

```
ruckus (debug) # remote-troubleshooting stop
```

```
ruckus (debug) #
```

AP Core Dump Collection

This section lists the AP core dump commands.

collect_ap_coredump

Enable AP core dump collection.

```
collect_ap_coredump [all|<MAC>]
```

Syntax Description

collect_ap_coredump	Collect AP core dump
pm	
all	Collect core dump from all connected APs
<MAC>	Specific AP MAC address

Defaults

None.

Example

```
ruckus (debug) # collect_ap_coredump all
---- Command 'apmgrinfo --coredump y' executed at 04:4f:aa:0c:b1:00
start reporting coredump to ZD!
---- Command 'apmgrinfo --coredump y' executed at 00:24:82:3f:14:60
start reporting coredump to ZD!
---- Command Execution Summary:
      success: 2
      failure: 0
```

```
total: 2
rm: cannot remove '/etc/airespider-images/firmwares/ap-dump/*': No
such file or directory
sh: codump_server: not found
start collecting AP's coredump !
ok
ruckus(debug) #
```

no collect_ap_coredump

Disable AP core dump collection.

Syntax Description

```
no          Stop collecting AP core dump
collect_ap_coredump
mp
```

Defaults

None.

Example

```
ruckus(debug) # no collect_ap_coredump all
---- Command 'apmgrinfo --coredump n' executed at 04:4f:aa:0c:b1:00
stop reporting coredump to ZD!
---- Command 'apmgrinfo --coredump n' executed at 00:24:82:3f:14:60
stop reporting coredump to ZD!
---- Command Execution Summary:
      success: 2
      failure: 0
      total: 2
rm: cannot remove '/etc/airespider-images/firmwares/ap-dump/*': No
such file or directory
stop collecting AP's coredump !
ok
ruckus(debug) #
```

Script Execution

This section lists the commands that can be executed from the script context. The script context must be entered from the debug context.

script

Enters the script context from the debug context. You must first enter the script context before executing a script.

```
script
```

Syntax Description

script	Enter the script context
--------	--------------------------

Defaults

None.

Example

```
ruckus(debug) # script
ruckus(script) #
```

quit

Exit the script context.

```
quit
```

Syntax Description

quit	Exit the script context
------	-------------------------

Defaults

None.

Example

```
ruckus(script) # quit
ruckus(debug) #
```

list

List all available scripts.

```
list
```

Syntax Description

list	List all available scripts
------	----------------------------

Defaults

None.

Example

```
ruckus(script) # list -a
```

Index

1

Scripts

.version.sh

```
ruckus(script) #
```

del

Deletes a script.

info

Display script help file

```
    info
```

Syntax Description

info	Display script information
------	----------------------------

Defaults

None.

Example

```
ruckus(script) # info
info <file>
ruckus(script) #
```

exec

Execute script.

```
exec <file> {parameter}
```

Syntax Description

exec	Excecute the script
------	---------------------

Defaults

None.

Example

```
ruckus(script) # exec
exec <file> {parameter}
ruckus(script) #
```

Index

Numerics

11n-only, 127
802dot11d, 251

A

aaa, 74
aaa all, 11
aaa name, 12
abort, 71, 124, 139, 142, 156, 163, 179, 203,
211, 262, 268, 275, 279, 292, 298, 327, 340,
348
accs-net-type chargeable-public, 323
accs-net-type free-public, 323
accs-net-type personal-device, 323
accs-net-type private, 323
accs-net-type private-with-guest, 323
accs-net-type test-or-experimental, 323
accs-net-type wildcard, 323
acct-server, 245, 305
acct-server interim-update, 245, 306
acl, 158, 257
acl dvcpcy, 257
acl end, 163
acl l3acl, 257
acl l3acl-ipv6, 257
acl prece, 257
acl quit, 164
acl-l2acl, 257
active-wired-client, 64
act-threshold, 181
add-mac, 159
ad-global-catalog, 79
adj-threshold, 180
admin, 88, 273
admin-dn, 79
admin-password, 80
admission-control, 97, 127, 249
adv-gas cb-delay, 326

adv-gas dos-detect, 326
adv-gas dos-maxreq, 326
adv-gas rsp-buf-time, 326
adv-gas rsp-limit, 326
aeroscout-detection, 353
alarm, 62, 339
alarm-event, 345
anqp-3gpp-info, 328
ap all, 15
ap devname, 17
AP group model-specific port settings, 139
ap mac, 19, 23
ap-auto-approve, 117
ap-group, 125
ap-group all, 21
ap-group name, 23
ap-load-balancing, 120
ap-management-vlan, 116
ap-max-clients, 120
ap-policy, 24, 115
asra, 322
asra dns, 322
asra enrollment, 322
asra http-https, 322
asra http-https url, 322
asra terms, 322
authentication guest-pass, 281
auth-method, 76
auth-server, 90, 282
auth-server local, 304
auth-server name, 304
auth-server name mac-bypass, 304
auth-server with-fallback, 91
auto-adjust-ap-channel, 350
auto-adjust-ap-power, 350
auto-channel-selection, 127
auto-proxy, 251
auto-recovery, 121

B

background-scan, 352
backup, 82
backup-ip-addr, 83
backup-radius-secret, 84
beacon-interval, 219, 338
bgscan, 240
bonjour, 206
bss-minrate, 249
bypasscna, 201

C

called-station-id-type, 218
cband-channels, 102, 136
cband-channels-override, 137
channel, 97, 127
channelfly, 351
channelization, 97, 127
channel-range, 97
client fingerprinting, 251
client-isolation, 240, 306
collect_ap_coredump, 385
config, 9
config wlan dot1x authentication encryption wpa2 algorithm TKIP auth-server, 235–236
conn-cap esp, 325
conn-cap ftp, 324
conn-cap http, 324
conn-cap icmp, 324
conn-cap ikev2, 324
conn-cap ipsec-vpn, 325
conn-cap pptp-vpn, 324
conn-cap ssh, 324
conn-cap tls-vpn, 324
conn-cap voip-tcp, 324
conn-cap voip-udp, 325
contact, 195
country code, 184
creating a WLAN, 265
current-active-clients, 55
custrm-conn-cap, 325

D

debug, 9

del, 388
delete station, 362
del-mac, 161
description, 88, 93, 126, 159, 165, 168, 174, 218, 264, 270, 288, 294, 313, 318, 327
destination address, 169, 289, 295, 314
destination port, 170, 290, 296, 314
device fingerprinting, 251
devname, 92
dhcp, 86
dhcp all, 13
dhcp name, 14
dhcp-relay, 250
disable, 9
disable-dgaf, 259
disabling NTP client, 189
disabling SNMP agent, 209–210
disabling SNMP traps, 210–211
displaying interface settings, 187
domain-name, 78, 328
dot11-country-code, 184
dot1x, 148
dot1x acctsvr, 113, 140, 149
dot1x authentication encryption wep-64 auth-server, 238
dot1x authentication encryption wpa algorithm AES auth-server, 233
dot1x authentication encryption wpa algorithm TKIP auth-server, 234
dot1x authentication encryption wpa2 algorithm AES auth-server, 235
dot1x authsvr, 113, 140, 149
dot1x eap-type EAP-SIM auth-server, 232
dot1x eap-type PEAP auth-server, 232
dot1x mac-auth-bypass, 114, 140, 149
dot1x none, 239
dot1x supplicant mac, 115, 140, 150
dot1x supplicant password, 114, 150
dot1x supplicant user-name, 140
dot1x supplicant username, 114, 150
dot1x supplicant user-name password, 140
dot1x wep-128 auth-server, 238
dot1x wpa algorithm auto auth-server, 234
dot1x wpa2 algorithm auto auth-server, 236
dot1x wpa-mixed algorithm AES auth-server, 236

dot1x wpa-mixed algorithm TKIP auth-server, 237
dot1x-mac none, 239
dvcpcy, 175
dynamic-certs, 60
dynamic-psk enable, 254
dynamic-psk passphrase-len, 255
dynamic-psk-expiration, 217
dynamic-psks, 59
dynamic-vlan, 247

E

eap-method, 329
eap-method auth-info, 330
eap-method eap-mthd, 329
e-mail, 342
encoding, 329
end, 71, 139, 143, 156, 163, 167, 179, 203, 212, 263, 268, 279, 293, 298, 327, 340, 349
ethinfo, 29
events-activities, 61
exec, 388
exit, 9, 71, 124, 139, 143, 157, 164, 168, 180, 202, 212, 263, 269, 280, 293, 298, 327, 340, 349
extant-gain, 97
external-antenna, 101, 135, 137
external-antenna-override, 137

F

facility, 199
fan-out-threshold, 338
first, 88
flexmaster, 193
from, 342
ftp, 189
ftp-anon, 189
full-name, 277
fw_upgrade, 361

G

gateway, 185, 192–193
gps, 93
grace-period, 244, 303
group, 94

group-attributes, 270
guest-access, 279
guestpass-effective, 283
guest-passes, 60
guest-pass-generation, 272
guest-vlan, 112

H

headroom, 182
help, 9, 71, 139, 327, 361
hessid, 318
hessid-use-bssid, 318
heuristics classification video packet-octet-count, 205
heuristics classification voice packet-octet-count, 205
heuristics no-classification video packet-octet-count, 205
heuristics no-classification voice packet-octet-count, 205
heuristics video inter-packet-gap, 204
heuristics video packet-length, 204
heuristics voice inter-packet-gap, 204
heuristics voice packet-length, 204
hide ssid, 248
history, 9, 71, 139, 327, 361
hops-warn-threshold, 337
hostname, 184
hotspot, 297
hotspot all, 44
hotspot name, 46
hotspot_redirect_https, 154
hs20op, 316
hs20sp, 326
hs-caps operating-class-indication 2.4, 326
hs-caps operating-class-indication 5, 326
hs-caps operating-class-indication dual-band, 326

I

icmpv6-type, 296, 311
ignor-unauth-stats, 259
import, 252
import-aplist, 124
inactivity-timeout, 246

info, 388
interface, 185
internal-heater, 101, 136
internal-heater-override, 137
internet-option, 318
intrusion-prevention, 315
ip, 95
ip addr, 186, 192
IP address, 186
IP address mode, 187
ip enable, 185
ip mode, 186–187
ip mode DHCP, 95
ip mode keep, 95
ip mode static, 95
ip name-server, 186
ip route gateway, 185
ip-addr, 76
ip-addr port, 77
ip-addr-type ipv4 double-nated, 323
ip-addr-type ipv4 not-avail, 323
ip-addr-type ipv4 port-double, 323
ip-addr-type ipv4 port-restricted, 323
ip-addr-type ipv4 port-single, 323
ip-addr-type ipv4 public, 323
ip-addr-type ipv4 single-nated, 323
ip-addr-type ipv4 unknown, 323
ip-addr-type ipv6 avail, 323
ip-addr-type ipv6 not-avail, 323
ip-addr-type ipv6 unknown, 323
ipmode, 103, 126
ipv6, 96
ipv6 addr, 188, 193
ipv6 enable, 188
ipv6 mode, 188
ipv6 mode auto, 96
ipv6 mode keep, 96
ipv6 mode manual, 96
ipv6 name-server, 188
ipv6 route gateway, 188

K

key-attribute, 80
kt-hotspot, 190

L

l2acl, 257
l2acl all, 40
l2acl name, 41
l3acl, 162, 257
l3acl all, 42
l3acl name, 43
l3acl-ipv6, 162, 257
l3acl-ipv6 all, 42
l3acl-ipv6 name, 43
lan, 109, 139, 145
lan guest-vlan, 139
lan dot1x, 113
lan dot1x auth-mac-based, 139
lan dot1x auth-port-based, 139
lan dot1x disabled, 139
lan dot1x supplicant, 139
lan dvlan, 112, 151
lan dvlan disabled, 112, 140
lan dvlan enabled, 140
lan guest-vlan, 151
lan member, 111, 139, 147
lan opt82, 112, 147
lan opt82 disabled, 139
lan opt82 enabled, 139
lan qos, 151
lan qos igmp-snooping, 140, 152
lan qos mld-snooping, 140, 152
lan untag, 110, 139, 146
lan uplink, 110, 139, 145
license, 63
limit, 255
limit-dpsk, 255
limited-zd-discovery, 118
limited-zd-discovery keep-ap-setting, 119
limited-zd-discovery prefer-primary-zd, 119
list, 387
list-all, 361
load-balancing, 179, 241
load-custom-ap, 363
location, 94, 195
location-id, 307
location-name, 308
login-page, 301
logs all, 371

logs comp 802.11, 376
logs comp 802.1x, 375
logs comp aps, 375
logs comp dylan, 376
logs comp hotspot-srv, 374
logs comp mesh, 373
logs comp net-mgmt, 375
logs comp radius, 374
logs comp rf-mgmt, 373
logs comp smart-redundancy, 377
logs comp sys-mgmt, 372
logs comp web-auth, 373
logs comp web-srv, 376
logs mac, 377
logs play, 378
lwapp-message-mtu, 121

M

mac authentication encryption none auth-server, 226
mac authentication encryption wep-128 key key-id auth-server, 231
mac authentication encryption wep-64 key key-id auth-server, 230
mac authentication encryption wpa passphrase algorithm AES auth-server, 227
mac authentication encryption wpa passphrase algorithm TKIP auth-server, 227
mac authentication encryption wpa2 passphrase algorithm AES auth-server, 228
mac authentication encryption wpa2 passphrase algorithm TKIP auth-server, 228
mac wpa-mixed passphrase algorithm AES auth-server, 229
mac wpa-mixed passphrase algorithm TKIP auth-server, 229
mac-auth-8021x-format, 256
malicious-report, 359
max clients, 251
max-clients, 136, 251
mcast-filter, 247
member, 141
member add, 141
member add mac, 141
member mac, 141
member mac move-to, 141

member mac move-to name, 142
member mac move-to system-default, 141
mesh, 334
mesh info, 58
mesh mode, 99
mesh mode auto, 99
mesh mode disable, 99
mesh mode mesh-ap, 99
mesh mode root-ap, 99
mesh topology, 58
mesh uplink-selection, 99
mesh uplink-selection add-mac, 99
mesh uplink-selection auto, 99
mesh uplink-selection del-mac, 99
mesh uplink-selection manual, 99
mgmt-acl, 202
mgmt-acl all, 32
mgmt-acl name, 33
mgmt-acl-ipv6, 202
mgmt-acl-ipv6 all, 33
mgmt-acl-ipv6 name, 33
mgmt-if, 191
mgmt-if-ipv6, 192
mgmt-tx-rate, 219, 339
mode allow, 160, 166
mode deny, 160, 166
model, 135
model c-band channels, 136
model external-antenna, 135, 137
model internal-heater, 136
model max-clients, 136
model poe-out, 136
model port-setting, 135, 139, 142
model radio-band, 136
model spectra-analysis, 135
model status-leds, 135
model usb-software, 136
model-specific port settings, 139
monitor, 9
monitor ap mac, 65
monitor current-active-clients, 67
monitor sysinfo, 68
move-ap, 122–123
move-ap-group, 123

N

nai-realm, 327–328
name, 74, 88–89, 159, 165, 174, 203, 213, 220, 264, 269, 300, 317, 327, 329
name password, 89
nasid-type, 242
new-trigger, 181
no 802dot11d, 251
no aaa, 74
no acct-server, 246, 306
no acl, 158
no ad-global-catalog, 79
no admin, 272
no admission-control, 249
no adv-gas dos-detect, 317
no aeroscout-detection, 354
no alarm, 339
no anqp-3gpp-info, 327
no ap, 92
no ap-auto-approve, 118
no ap-group, 125
no ap-load-balancing, 121
no ap-management-vlan, 117
no asra, 317
no asra dns, 317
no asra enrollment, 317
no asra http-https, 317
no asra http-https-url, 317
no asra terms, 317
no authentication, 280
no auth-server, 90
no auto-adjust-ap-channel, 351
no auto-adjust-ap-power, 350
no auto-proxy, 252
no auto-recovery, 121
no background-scan, 353
no backup, 84
no bgscan, 240
no blocked-client, 155
no bonjour, 206
no bss-minrate, 249
no bypasscna, 201
no cband-channels-override, 102
no channelfly, 352
no client-isolation, 241, 307
no collect_ap_coredump, 386
no custm-conn-cap, 317
no description, 93, 126
no detect-fanout, 338
no detect-hops, 337
no devname, 93
no dhcp, 87
no dhcp-relay, 250
no disable-dgaf, 259
no domain-name, 327
no dot1x, 151–152
no dot1x acctsvr, 140, 152
no dot1x authsvr, 140, 152
no dot1x mac-auth-bypass, 140, 152
no dvcpcy, 179, 255
no dynamic-psk, 255
no dynamic-vlan, 247
no event, 347
no external-antenna-override, 101
no flexmaster, 194
no friendly-name, 317
no ftp, 190
no ftp-anon, 189
no gateway, 192–193
no gps, 94
no grace-period, 244, 303
no guest-pass-generation, 272
no hessid, 317
no hide ssid, 248
no hotspot, 297
no hotspot_redirect_https, 154
no hs20op, 316
no hs20sp, 327
no hs-caps operating-class-indication, 317
no ignor-unauth-stats, 260
no internal-heater-override, 102
no internet-option, 317
no intrusion-prevention, 316
no ip, 188
no ipmode-override, 103, 127
no ipv6, 96, 188
no kt-hotspot, 190
no l2acl, 255
no l3acl, 162, 255
no l3acl-ipv6, 255
no lan, 110, 140, 144
no lan qos, 152

no lan qos igmp-snooping, 140, 152
no lan qos mld-snooping, 140, 152
no limit-dpsk, 255
no limited-zd-discovery, 119
no load-balancing, 183, 241
no location, 94
no logs all, 378
no logs comp 802.11, 382
no logs comp 802.1x, 381
no logs comp aps, 381
no logs comp dylan, 382
no logs comp hotspot-srv, 380
no logs comp mesh, 379
no logs comp net-mgmt, 381
no logs comp radius, 380
no logs comp rf-mgmt, 380
no logs comp smart-redundancy, 383
no logs comp sys-mgmt, 379
no logs comp web-auth, 379
no logs comp web-svr, 382
no logs mac, 383
no logs play, 383
no mac-auth-8021x-format, 257
no mcast-filter, 248
no mgmt-acl, 201
no mgmt-acl-ipv6, 202
no mgmt-if, 192–193
no model, 136
no model cband-channels-override, 137
no model external-antenna-override, 137
no model internal-heater-override, 137
no model override, 136
no model poe-out-override, 137
no model port-setting, 137
no model radio-band-override, 137
no model status-leds-override, 137
no model usb-software-override, 137
no model-setting, 135
no move-ap, 123
no move-ap-group, 123
no nai-realm, 327
no northbound, 194
no ntp, 189
no ofdm-only, 248
no option82, 250
no pap-authenticator, 242
no pif, 357
no pmk-cache, 252
no pmk-cache-for-reconnect, 253
no poe-out-override, 101
no port-setting, 139
no prece, 175
no proxy-arp, 259
no qos, 203
no qos classification, 257
no qos directed-multicast, 258
no qos heuristics-udp, 258
no qos igmp-query v2, 135
no qos igmp-query v3, 135
no qos igmp-snooping, 258
no qos mld-query v1, 134
no qos mld-query v2, 135
no qos mld-snooping, 258
no qos tos-classification, 259
no radio, 98
no radio 2.4 11n-only-override, 132
no radio 2.4 admission-control, 133
no radio 2.4 admission-control-override, 133
no radio 2.4 channelization-override, 132
no radio 2.4 channel-override, 132
no radio 2.4 channel-range-override, 132
no radio 2.4 tx-power-override, 132
no radio 2.4 wlan-group-override, 133
no radio 5 11n-only-override, 133
no radio 5 admission-control, 133
no radio 5 admission-control-override, 134
no radio 5 channelization-override, 133
no radio 5 indoor channel-override, 133
no radio 5 indoor channel-range-override, 133
no radio 5 outdoor channel-override, 133
no radio 5 outdoor channel-range-override, 133
no radio 5 tx-power-override, 133
no radio 5 wlan-group-override, 133
no radio-band-override, 104
no rate-limit, 256
no restrict-access-order, 285, 310
no restrict-access-order-ipv6, 291, 311
no roam-consortium, 327
no roaming-acct-interim-update, 253

no role, 268
no rule-order, 166
no second, 88
no send eap-failure, 242
no service-provider, 317
no session-timeout, 302
no smartclient, 301
no smart-redundancy, 191
no snmp-agent, 209–210
no snmp-trap, 210
no snmp-trap-ap, 198
no snmpv2-trap, 210
no snmpv3, 210
no snmpv3-trap, 211
no specify-wlan-access, 271
no sta-info-extraction, 251
no static-route, 208
no static-route-ipv6, 209
no status-leds-override, 100
no stp, 183
no syslog, 198
no syslog-ap, 201
no telnetd, 207
no term-of-use, 281
no tls-smtp-encryption, 345
no tun-block-bcast, 355
no tun-block-mcast, 355
no tun-encrypt, 354
no tunnel mode, 250
no tun-proxy-arp, 356
no upnp, 215
no usb-software, 103
no usb-software override, 101
no user, 274
no venue-group-type, 317
no venue-name, 104
no vlan-qos, 122
no walled-garden, 308
no wan-metrics at-cap, 317
no wan-metrics sym, 317
no web authentication, 244
no wlan-group, 262
no zero-it-activation, 254
northbound, 194

O

ofdm-only, 248
open authentication encryption wep-128
 key key-id, 226
open authentication encryption wep-64
 key key-id, 225
open authentication encryption wpa passphrase algorithm AES, 221
open authentication encryption wpa passphrase algorithm auto, 222
open authentication encryption wpa passphrase algorithm TKIP, 222
open authentication encryption wpa2
 passphrase algorithm AES, 223
open authentication encryption wpa2
 passphrase algorithm TKIP, 223
open none, 221
open wpa-mixed passphrase algorithm
 auto, 225
option82, 250
order, 168, 288, 294, 313

P

pap-authenticator, 242
passphrase, 336
password, 277
peer-addr, 191
pif, 356
ping, 9
pmk-cache, 252
pmk-cache-for-reconnect, 253
poe-out, 100, 136
poe-out-override, 137
port settings, 139
port-setting, 106, 135, 137, 139
prece, 173
priority, 199
protect-excessive-wireless-request, 358
protocol, 170, 290, 296, 315
proxy-arp, 259
ps, 368

Q

qos, 134, 204
qos classification, 257

qos directed-multicast, 258
qos directed-threshold, 259
qos heuristics-udp, 258
qos igmp-query, 134
qos igmp-query v2, 134
qos igmp-query v3, 134
qos igmp-snooping, 258
qos mld-query, 134
qos mld-query v1, 134
qos mld-query v2, 134
qos mld-snooping, 258
qos priority high, 259
qos priority low, 259
qos query-interval, 134
qos tos-classification, 258
quit, 9, 71, 124, 139, 143, 153, 157, 164, 180, 203, 212, 264, 269, 280, 293, 299, 327, 341, 349, 361, 387

R

radio, 97, 127
radio 2.4, 97
radio 2.4 11n-only Auto, 130
radio 2.4 11n-only N-only, 130
radio 2.4 admission-control, 130
radio 2.4 auto-channel-selection four-channel, 129
radio 2.4 auto-channel-selection three-channel, 129
radio 2.4 channel auto, 129
radio 2.4 channel number, 129
radio 2.4 channelization auto, 129
radio 2.4 channelization number, 129
radio 2.4 channel-range, 130
radio 2.4 tx-power 1/2, 130
radio 2.4 tx-power 1/4, 130
radio 2.4 tx-power 1/8, 130
radio 2.4 tx-power Auto, 129
radio 2.4 tx-power Full, 129
radio 2.4 tx-power Min, 130
radio 2.4 tx-power Num, 130
radio 2.4 wlan-group, 130
radio 5, 97
radio 5 11n-only Auto, 132
radio 5 11n-only N-only, 132
radio 5 admission-control, 132
radio 5 channel auto, 131
radio 5 channel number, 131
radio 5 channelization auto, 131
radio 5 channelization number, 131
radio 5 indoor channel auto, 130
radio 5 indoor channel number, 130
radio 5 indoor channel-range, 131
radio 5 outdoor channel auto, 131
radio 5 outdoor channel number, 131
radio 5 outdoor channel-range, 131
radio 5 tx-power 1/2, 131
radio 5 tx-power 1/4, 131
radio 5 tx-power 1/8, 132
radio 5 tx-power Auto, 131
radio 5 tx-power Full, 131
radio 5 tx-power Min, 132
radio 5 tx-power Num, 132
radio 5 wlan-group, 132
radio-band, 103, 136
radio-band-override, 137
radius-secret, 81
rate-limit, 256
read-only community, 195
read-write community, 196
reboot, 9
reconnect-primary-interval, 86
redirect, 282
re-generate-private-key, 153
remote_ap_cli, 370
remote-troubleshooting server, 384
remote-troubleshooting start, 384
remote-troubleshooting stop, 385
request-timeout, 85
restart-ap, 362
restore, 153
restrict-access-order, 286, 309
restrict-access-order-ipv6, 291, 310
restrict-type, 203
restrict-type range ip-range, 214
restrict-type single ip-addr, 213
restrict-type subnet ip-subnet, 214
retry-count, 85
roam-consortium, 328
roaming-acct-interim-update, 253
ro-community, 195
rogue-devices, 61

rogue-dhcp-detection, 359
rogue-report, 359
role, 267, 277
role all, 53
role name, 53
ro-user, 196
rule, 174, 177
rule-order, 167
rw-community, 195–196
rw-user, 196

S

save_debug_info, 364
save-config, 365
script, 387
search-filter, 81
second, 88
secret, 191
send eap-failure, 241
service-provider, 318
session-timeout, 9, 64, 302
set-factory, 9
shared wep-128, 232
shared wep-64, 231
show, 88, 104, 108, 116, 124–125, 139, 144, 157, 164, 171, 182, 187, 191, 196, 203, 206, 209, 214, 260, 267, 273, 278, 283, 288, 294, 299, 312, 326, 328, 335, 341, 357
show aaa, 71
show active-wired-client all, 64
show active-wired-client mac, 65
show admin, 72
show ap, 72, 365
show ap-group, 73
show ap-policy, 73
show current-active-clients mac, 56
show dhcp, 13, 72
show dvcpcy, 72
show hotspot, 73
show hs20op all, 47
show hs20op name, 49
show hs20sp all, 51
show hs20sp name, 52
show l2acl, 72
show l3acl, 72
show l3acl-ipv6, 72

show load-balancing, 73
show logs, 366
show mgmt-acl, 72
show mgmt-acl-ipv6, 72
show performance, 26
show performance ap-radio2-4, 26
show performance ap-radio5, 27
show performance station, 27
show prece, 72
show remote-troubleshooting, 367
show role, 73
show static-route, 72
show static-route-ipv6, 72
show station, 366
show usb-software, 73
show user, 73
show user all, 54
show user name, 54
show wlan, 73
show wlan-group, 73
smartclient, 300
smartclient info, 301
smartclient secure http, 301
smartclient secure https, 301
smartclient wispr-only secure http, 301
smartclient wispr-only secure https, 301
smart-redundancy, 190
smtp-auth-name, 343
smtp-auth-password, 344
smtp-server-name, 343
smtp-server-port, 343
smtp-wait-time, 344
SNMP RO, 195
SNMP RW, 196
snmp-trap, 211
snmp-trap-format, 197
snmpv2, 195
snmpv2-trap, 197
snmpv3, 196
snmpv3-trap, 197
specify-wlan-access, 271
spectra-analysis, 135
ssid, 219, 336
sta-info-extraction, 251
start-page, 302
static-route, 207

static-route all, 34
static-route name, 34
static-route-ipv6, 208
static-route-ipv6 all, 34
static-route-ipv6 name, 34
status-leds, 100, 135
status-leds-override, 137
stp, 183
strong-bypass, 181
support-entitle, 209
sysinfo, 24
syslog, 199
syslog notifications, 198
sysstats, 28
system, 184

T

tacplus-secret, 81
tacplus-service, 78
techsupport, 30
telnetd, 206
temp-block-auth-failed-client, 359
term-of-use, 281
timeout, 123
tls-smtp-encryption, 344
tos classification background, 205
tos classification data, 205
tos classification video, 205
tos classification voice, 205
trap server, 211
tun-block-bcast, 355
tun-block-mcast all, 354
tun-block-mcast non-well-known, 355
tun-encrypt, 354
tun-ip-ageing, 356
tunnel mode, 249
tunnel-mtu, 206
tun-proxy-arp, 355
tx-power, 97, 127
type, 220
type ad, 75
type allow, 169, 289, 295, 313
type deny, 169, 289, 295, 314

U

upnp, 215
usb-software, 64, 102, 136
usb-software-override, 137
user, 274
user-name, 276

V

venue-group-type assembly, 318
venue-group-type unspecified, 318
venue-name, 104
vlan, 188, 192–193, 246
vlan-qos, 122

W

walled-garden, 308
wan-metrics at-cap, 323
wan-metrics downlink-load, 324
wan-metrics downlink-speed, 324
wan-metrics link-stat down, 323
wan-metrics link-stat test, 323
wan-metrics link-stat up, 323
wan-metrics lmd, 324
wan-metrics sym, 323
wan-metrics uplink-load, 324
wan-metrics uplink-speed, 324
weak-bypass, 180
web authentication, 243
web-auth, 243
welcome-text, 283
wips, 358
wlan, 217, 265
wlan all, 35
WLAN description, 218
wlan name, 36
WLAN SSID, 219
wlan wlan override none, 266
wlan wlan override tag, 266
wlan-allowed, 271
wlan-group, 97, 127, 261
wlan-group all, 39
wlan-group name, 40
wlaninfo, 363
wlan-service, 97

Z

zero-it, 216
zero-it-activation, 253
zero-it-auth-server, 216
ZoneDirector
 gateway, 185
 IP address, 186
 IP address mode, 187
 name server, 186