



TVWS

# CPE-O-R-WS

## User and Installation Manual

FCC ID: XYMCPETVWS-1

**DOC: RUNCOM CPE-O-R-WS USER MANUAL RN-PMG-300516 V-1.3**

## About this Guide

This User Manual describes the procedures for commissioning, mounting, installing and managing the CPE-O-R-WS.

## Notice

This document contains proprietary and confidential material of Runcom Ltd. Any unauthorized reproduction, use or disclosure of this material, or any part thereof, is strictly prohibited. This document is solely for the use of Runcom Ltd. employees and authorized Runcom Ltd. customers.

The material furnished in this document is believed to be accurate and reliable. However, no responsibility is assumed by Runcom Ltd. for the use of this material. Runcom Ltd. reserves the right to make changes to the material at any time and without notice.

All other trademarks are the property of their respective owners. Other company and brand products and service names are trademarks or registered trademarks of their respective holders.

## Safety Precautions

To avoid injury and to prevent equipment damage, observe the safety precautions below.

- Only qualified personnel should be allowed to install, replace, and service the equipment. The device cannot be sold retail, to the general public or by mail order. It must be sold to dealers. Installation must be controlled. Installation must be performed by licensed professionals. Installation requires special training. The Runcom radios and antennas should be installed **ONLY** by experienced installation professionals who are familiar with local building and safety codes and, wherever applicable, are licensed by the appropriate government regulatory authorities. Failure to do so may void product warranty and may expose the end user or the service provider to legal and financial liabilities.
- Always observe standard safety precautions during installation, operation and maintenance of this product.
- This equipment must be installed according to country national electrical codes.
- Any changes and modifications to the device and the accessories must be approved by Runcom.
- All equipment and accessories must be installed in a restricted access area.
- Observe all the labels on the equipment, providing operation details and warnings.
- Read and follow the installation instructions provided in this manual.
- The CPE should be positioned more than 2 meters from humans.
- In case of using cables that are not provided with the equipment package, ensure these cables comply with the regulatory inspection authorities and are the responsibility of the customer.
- Do not move or ship equipment unless it is properly packed in its original wrapping and shipping containers.

### Electrical Shock Prevention

- When connecting equipment to the AC and DC voltage supplies, ensure proper polarity.
- Disconnect the power source before installing or maintaining the power wiring.
- Do not operate the equipment if there is any failure or damage to electrical components.
- Do not touch exposed connections, components or wiring when power is on.
- Install the equipment and the grounded DC supply circuits in adjacent cabinets.
- Protect the DC power source with an adjacent circuit breaker.
- The equipment must be properly grounded before attempting to operate or perform any repairs.

## RF Exposure

To comply with FCC Section 1.310 for human exposure to radio frequency electromagnetic fields, implement the following instruction:

A distance of at least 200cm between the equipment and all persons should be maintained during the operation of the equipment.

## Radio Interference

This equipment generates and radiates radio frequency energy and if not installed and used in accordance with the instruction manual, may cause interference to radio communications.

To avoid interferences:

- Avoid conjunction with any other antenna or transmitter.
- In case of Radio Interference: Relocate the antenna and Increase separation between the equipment and the receiver (e.g. connect to a separate circuit or outlet).
- When using an external antenna, the external antenna must not be co-located or operating in conjunction with any other antenna or transmitter

*NOTE: This equipment has been tested and found to comply with the rules for TV band device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:*

*-Reorient or relocate the receiving antenna.*

*-Increase the separation between the equipment and receiver.*

*-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.*

*-Consult the dealer or an experienced radio/TV technician for help.*

**NOTE: THE GRANTEE IS NOT RESPONSIBLE FOR ANY CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.**

**Warning: THE CPE-O-R-WS EQUIPMENT SHALL BE INSTALLED AT A HEIGHT NO GREATER THAN 30 METERS ABOVE THE GROUND.**

**Note: THE CPE-O-R-WS EQUIPMENT SHALL BE OPERATED ONLY IN CONJUNCTION WITH THE AFAS SOFTWARE THAT CONNECTS THE CPE TO THE TVWS DATA BASE**



# Table of Contents

---

<b>1</b>	<b>Introducing CPE-O-R-WS</b>	<b>4</b>
<b>2</b>	<b>CPE-O-R-WS Overview</b>	<b>5</b>
2.1	Interfaces Specifications	5
2.1.1	User Interface Specification	5
2.1.2	TVWS Interface Specification	6
2.1.3	Operational Description	6
<b>3</b>	<b>Getting Started</b>	<b>7</b>
3.1	Packing list	7
3.2	Unpacking the Equipment	7
3.3	Operating and Configuration of the CPE-O-R-WS	8
3.3.1	Device Logic connection	8
3.3.2	CPE Configuration	8
3.4	CPE-O-RS-WS Registration (in the Data Base) and Configuration (prior to installation)	9
3.4.1	CPE Network	9
3.4.2	Registration of the CPE-O-RS-WS in the Data Base (Spectrum Bridge)	9
3.4.3	CPE-O-RS-WS relocation	10
3.4.4	Adding of CPE-O-RS-WS to the AFAS	10
3.5	Preparations before physical installation	12
3.5.1	Skills Required	12
3.5.2	Information Needed before	12
3.5.3	Required Tools and Equipment	12
3.5.4	Performing a Site Survey	13
3.6	Installing the Equipment	13
3.6.1	Device Logic connection	13
3.6.2	Installing Outdoor Unit (ODU)	13
3.6.3	CPE Connection to the PoE adapter	14
3.6.4	Sequence for Interconnect Cable	14
<b>4</b>	<b>Managing CPE Devices</b>	<b>16</b>
4.1	General	16
4.2	Accessing CPE via Web Brower	16
4.2.1	Access CPE from LAN Segment	16
4.2.2	Access CPE Device from WAN Segment	17
4.3	CPE LAN Side Network configuration	18
4.3.1	Router / Bridge selection	18
4.3.2	DHCP	19
4.3.3	LAN IP settings	19

4.4	CPE WAN Side Network configuration.....	20
4.4.1	WAN interface enabling .....	20
4.4.2	WAN IP Address Settings .....	20
4.4.3	DNS IP Address Settings .....	21
4.5	LAN access control .....	21
4.6	Radio Control.....	23
4.6.1	Radio Transmission Enable .....	23
4.6.2	Radio Signal Transmission .....	23
4.7	Operation Channels Frequency Control .....	24
4.7.1	Adding Allowed Channels.....	24
4.8	Controlling CPE access .....	25
4.9	Viewing CPE status Information .....	26
4.9.1	Running Information .....	26
4.9.2	WiMAX Information .....	26
4.9.3	LAN Information .....	27
4.9.4	Traffic Statistic Information .....	27
4.10	Viewing Wireless status and Information.....	28
4.10.1	Networking Status .....	28
4.10.2	WiMAX Data Statistics .....	29
4.10.3	Hardware Information .....	29
<b>5</b>	<b>MAX Rx Signal Adjusting.....</b>	<b>30</b>
5.1	RF Signal Adjusting .....	30
5.2	Link Status .....	30
5.2.1	Networking Status .....	30
5.2.2	WiMAX data statistics and Hardware information .....	31
5.3	Welcome WEB Page .....	31
5.4	LED Display.....	32

## Figures and Tables

Figure 1:	WiMAX CPE Application in 802.16e Network .....	4
Figure 2:	CPE Equipment Photo .....	5
Figure 3:	Package Equipment Photo .....	7
Figure 4:	PoE Connectivity.....	8
Figure 5:	AFAS Site administration page .....	10
Figure 6:	AFAS Select CPE page.....	10
Figure 7:	AFAS CPE configuration page.....	11
Figure 8:	AFAS CPE available channels request .....	11
Figure 9:	Pole Mount Diagram .....	14
Figure 10:	CPE - Ethernet Header Connection .....	14
Figure 11:	RJ45 Pin Diagram.....	15
Figure 12:	Logon Web Pages.....	17
Figure 13:	LAN Network Configuration.....	18
Figure 14:	WAN Network Configuration.....	20

Figure 15: Access Control Configuration .....	21
Figure 16: WiMAX Radio Control.....	23
Figure 17: Operation Channels Frequency Control .....	24
Figure 18: Device Access options.....	25
Figure 19: CPE Status Information .....	26
Figure 20: Traffic Data Counters.....	27
Figure 21: WiMAX Interface Status and Information.....	28
Figure 22: Signal Indicators .....	30

Table 1: LAN Interface Specification .....	5
Table 2: TVWS Interface Specification.....	6
Table 3: Packaging List.....	7
Table 4: Required Tools and Extra Equipment .....	12
Table 5: PoE Specification .....	14
Table 6: Ethernet RJ45 Cable Specification .....	15
Figure 7: Led Diaplay .....	32

# 1 Introducing CPE-O-R-WS

Runcom's CPE-O-R-WS terminal is a WiMAX CPE product 802.16e WAVE II compliant terminal that was adapted to the TVWS market according to the FCC regulations for use as a fixed device.

Both indoor and outdoor models are available for different application environment needs and the end customer can choose a variety of product models with different user interfaces. The CPE can also support multiple frequency bands to meet different operator or country deployment needs. The sophisticated QoS feature also helps service providers to better control data traffic in their wireless networks. All CPE products are equipped with advanced capability to differentiate end user traffic, mark traffic with different priorities, and policing traffic at the edge of their networks. These capabilities are vital for service providers to avoid service disruption caused by malicious users.

The CPE products provide multiple management interfaces to allow local or over the air provision and management of the device. The supported user management interface and management protocol include WEB, FTP, TFTP and future TR-069. Runcom also offers a standard alone device management solution for device auto provision, firmware management and remote monitoring and maintenance. A north bound API is available for quick integration with operator OSS/BSS platform.




Figure 1: WiMAX CPE Application in 802.16e Network

This manual provides user reference information necessary for configuration and provisioning of CPE-O-R-WS products. It can also be used by technical support engineers for troubleshooting and problem resolution.

## 2 CPE-O-R-WS Overview



Figure 2: CPE Equipment Photo

### 2.1 Interfaces Specifications

#### 2.1.1 User Interface Specification

Table 1: LAN Interface Specifications

Model	Description & User Interface
<b>CPE-O-R-WS</b>	<ul style="list-style-type: none"> <li>- External antenna</li> <li>- 1 RJ45 10/100M LAN Port</li> <li>- PWR, RUN, LAN, and WiMAX (1-4) LEDs</li> <li>- 24V DC PoE supply, ODU Power &lt; 11 Watts</li> <li>- Dimensions: 220 mm (L) × 220 mm (W) × 70 mm (D)</li> <li>- Weight: Less than 3Kg</li> </ul>

## 2.1.2 TVWS Interface Specification

Table 2: TVWS Interface Specifications

Frequency Bands	470-698MHz
Radio Access	802.16e Wave 2
Operation Mode	TDD
Channel Bandwidth	6 MHz
Output Power	24 dBm at antenna port
Modulation	QPSK, 16QAM, 64QAM for DL and QPSK, 16QAM for UL
FFT	512 FFT points
FEC	Convolution Code and Turbo Code
Authentication	TTLS and TLS

## 2.1.3 Operational Description

The CPE-O-RS-WS is operated as part of a TVWS Network. The CPE is used to provide connectivity (Internet Access) to users using Broadband Wireless Access based on WiMAX technology.

The TVWS Network uses the TV White Space spectrum (470-698 MHz) in channels that are not used by licensed or protected users such as broadcasters and wireless microphones.

The CPEs are wirelessly connected to Base Stations (RNU4000-BTS) that are usually installed in high places such as tower, water tanks, rooftops, etc. and from the Base Stations the communication is relayed to the Internet cloud via a gateway/router (Micronoc, CompactNOC, ASN Gateway, etc.). The CPE is connected through the Base Stations to the Automatic Frequency Allocation Software (AFAS) in order to receive the available TVWS channels from the TVWS Data Base. The CPE will only transmit after it is synchronized to the Base Station on a channel allocated by the TVWS Data Base via the AFAS SW

The CPE uses OFDMA technology in TDD (Time Division Duplexing) mode with adaptive modulation in order to provide a reliable connectivity, the CPE modulation will change automatically according to the link budget between the CPE and the Base Station. The available modulation levels are described in Table 2 above.

The CPE will adapt automatically its output power level according to the link budget between the CPE and the Base Station in order to reduce self-interference. In addition the CPE is GPS synchronized with the Base Station and other CPE's in the area connected to the same TVWS Network in such a way that all CPE's will transmit and receive at the same time, the GPS synchronization mitigates the self-interference between the CPE's in the same network

The CPE can be connected at the customer's premises via POE to any IP device that needs Internet connectivity such as Wi-Fi routers, laptop/desktop computers, IP switches, etc.

# 3 Getting Started

## 3.1 Packing list

Upon receiving the product, unpack the product package carefully. Each product is shipped with the following items:

*Table 3: Packing List*

	<b>Outdoor CPE Products</b>	<b>Quantity</b>	<b>Note</b>
1	ODU unit	1	All
2	PoE adapter	1	All
3	24V DC Power Adapter	1	All
4	Mounting brackets	1	All
5	PC Ethernet Cable	1	All

If you find any of the items is missing, please contact our local distributor immediately.

## 3.2 Unpacking the Equipment

Table 4 lists all the standard parts that are supplied in your CPE-O-R-WS Unit Installation Package. Please take the time to unpack the package and check its contents against this list.



*Figure 3: Package Equipment Photo*

## 3.3 Operating and Configuration of the CPE-O-R-WS

### 3.3.1 Device Logic connection

Connect the CPE to the PoE adapter port ODU using a standard CAT 5 Ethernet cable. The CPE is powered from a 24V DC power supply from a power adapter. The power adapter operates from 90-250V AC range. Once the device is powered, the user should wait for about 2 minutes before the device becomes operational. For CPE with the RUN LED indicator, a slowly flashing light indicates the system has completed the startup procedure.

To connect PC, LAN switch or other type of IP device to the CPE product, connect a standard CAT5 Ethernet cable and connect to the NET port of the PoE. Once it is connected the CPE LAN LED indicator should come on.




Figure 4: PoE Connectivity

### 3.3.2 CPE Configuration

Connect Laptop to the Net port of the PoE and open Google Chrome Browser. Connect to IP 192.168.0.1 and follow the instruction in paragraph 4 to configure the CPE, to the required channel frequency obtained by AFAS from the TVWS Data Base.

**Warning! – use discrete channels settings only!**

## 3.4 CPE-O-RS-WS Registration (in the Data Base) and Configuration (prior to installation)

---

### 3.4.1 CPE Network

The CPE-O-RS-WS shall be used **only** in a TVWS network with Runcom AFAS Software and RNU-4000TVWS Base Stations (FCC Identifier: XYMBSTVWS-1) and cannot operate with any other base station.

### 3.4.2 Registration of the CPE-O-RS-WS in the Data Base (Spectrum Bridge)

Prior the installation of the CPE-O-RS-WS, the professional installer shall register the CPE-O-RS-WS in the Spectrum Bridge TVWS Data Base. The Registration includes the CPE-O-RS-WS MAC ID, the location Latitude and Longitude, antenna height, and Base Station ID to where the CPE-O-RS-WS will be connected. All this will be done using the AFAS (Automatic Frequency Allocation Software).

Runcom Automated Frequency Allocation Software (AFAS) is a SW element that mediates between the TV white space (TVWS) database and Runcom Base Stations (BTS) and user terminals (CPE), in order to comply with FCC rules.

The AFAS main tasks are to register the TVWS fixed devices (Base Station and CPE's) to the TVWS Data Base, to receive the available channels from the Data Base to each one of the fixed devices registered and to disable the operation of the fixed devices in a TVWS channel that is no longer available or due to a communication failure between the AFAS and the Data Base.

The AFAS Software is connected to the CPE through the Wireless Connection between the Base Station and the CPE.

The CPE registration is done according to the procedure described in paragraph 3.4.4 below

After the registration, if the CPE is allowed by the Data Base to operate in this location, the AFAS will receive from the TVWS Data Base the list of free channels that can be used in this location, and the operator shall configure the CPE-O-RS-WS with those channels.

Note- The location and height of the CPE will be obtained by an accurate device (>95%) such as GPS, or Google Earth application.

**Installation Process:** Following the Registration process, the professional installer should proceed to the physical installation of the CPE at the designated site at the location (Latitude, Longitude and height) registered in the Data Base. The physical installation should be according to paragraph 3.5 and 3.6 of this Manual

**Turn on Process:** After the physical installation the CPE-O-RS-WS is turned on and a link is established in one of the configured TVWS channels (the channel that the Base Station operates in), the management of the CPE-O-RS-WS will be done over the air by the AFAS software over an IP network.

AFAS connects every T hours ( $T \leq 24$  hours) with Spectrum Bridge (SB) TVWS database and retrieves for each of its related TVWS fixed devices (Base Stations and CPE-O-RS-WS) in its network an updated set of available TVWS channels.

One of the channels of this set will be selected automatically by AFAS for use in the Base Station (RNU4000-TVWS) and its related CPEs.

There is no possibility for the Base Station and its related CPEs to operate on any other channel which is not listed in the last updated set of available TVWS channels.

In case that the CPE available channels will not coincide with the Base Station available channels the AFAS, or in case the AFAS is disconnected from the Data Base the CPE will turn off its transmitter by the AFAS and the CPE

will not be able to transmit again until it will be synchronized with the Base Station in a new channel allocated by the TVWS Data Base via AFAS

### 3.4.3 CPE-O-RS-WS relocation

In case the CPE is relocated to a different location than the location registered in the Data Base, the installer shall do a new registration according to paragraph 3.4.4 below prior to turning on the relocated CPE. The relocation must be to a new location that is covered by a registered TVWS Base Station.

### 3.4.4 Adding of CPE-O-RS-WS to the AFAS

To add a CPE in the AFAS open the “Site administration” page in the AFAS and Choose CPE as shown in Figure 3 below.




Figure 5: AFAS Site administration page

The AFAS SW will open the “Select CPE” page, on this page click the “Add cpe” option as shown in figure 4 below.




Figure 6: AFAS Select CPE page

On the “Add cpe” page fill the CPE ID, CPE IP, CPE Latitude and Longitude, the Connecting Base ID, The CPE antenna Height, MAC ID and save it as shown in Figure 5 below:

**NOTE:** Each CPE MAC ID will have one set of location data (Latitude, Longitude and Antenna Height) associated to it at the AFAS

The screenshot shows the 'Add cpe' configuration page in the RUNCOM TVWS AFAS web interface. The page is titled 'Add cpe' and is part of the 'Management > Cpes > Add cpe' navigation path. The form includes the following fields:

- General Info Group Number:** A text input field.
- CPE ID:** A text input field with a note: 'CPE name without spaces. Example: north\_base1'.
- CPE IP:** A text input field with a note: 'CPE IP as configured in the ASN/DHCP'.
- CPE Latitude:** A text input field with a note: 'Latitude coordinate'.
- CPE Longitude:** A text input field with a note: 'Latitude coordinate'.
- Conn Base ID:** A dropdown menu.
- CPE Antenna Height:** A text input field with a note: 'Above ground level - Meters, whole number'.
- Preferred Channels:** A text input field with a note: 'Example: 18,19,30,40,51'.
- Available Channels:** A text input field.
- Refresh In:** A text input field.

Figure 7: AFAS CPE configuration page

After completion of entering the information in the “Add cpe page” click the "Channel request to select Devices" and press "Go" and the AFAS will ask for channels from the Data Base as shown in Figure 6 below.

The screenshot shows the 'Select cpe to change' page in the RUNCOM TVWS AFAS web interface. The page displays a table of available channels for a selected CPE. The table has the following columns:

CPE ID	CPE IP	Conn Base ID	Available Channels	Last Channel Request	Channel Valid Time	CPE Latitude	CPE Longitude	CPE Antenna Height	RF Status
CPE-2	10.0.2.2	Base	14,21,22,23,24,25,26,31,32,33,34,35,40,41,50	22:46:18 06/05/16	22:46:18 06/07/16	37.528000	-86.705000	6	N/A

Below the table, it indicates '1 cpe' is selected. The page also includes an 'Action:' dropdown menu and a 'Go' button.

Figure 8: AFAS CPE available channels request

After receiving the available channels from the Data Base, AFAS will load the allowed channels to the CPE and the CPE will establish the link with the Base Station in one of the allowed channels.

## 3.5 Preparations before physical installation

### 3.5.1 Skills Required

The CPE-O-RS-WS shall be installed by a professional installer that was qualified to install TVWS equipment.

It is forbidden to install the CPE-O-RS-WS by non-professional installer.

### 3.5.2 Information Needed before

The professional installer shall gathered the following information prior to the installation

- Locations of the Base Station and the azimuth from the CPE to the Base Station, which you should be able to connect to.
- Log in account and password

### 3.5.3 Required Tools and Equipment

This section lists all the extra tools and equipment mentioned in this guide that you will need to perform the installation. None of the items listed in Table 2-1 are supplied with the kit, so make sure you gather everything you need before you start. Use the table below to check exactly what you will need (this will depend on where you are going to install the outdoor transceiver).

*Table 4: Required Tools and Extra Equipment*

<b>Tools Required</b>	<b>Extra Equipment Required</b>
Compass	Grounding clamp
Area map with an accurate direction legend showing magnetic north	Grounding wire
Flat-head screwdriver	Roll of UTP CAT 5 cable
Hammer or mallet	Cable clip
Power drill	Anchor sleeves
1/8 inch drill bit	RJ-45 connectors (plastic bodied)
3/16 inch, 4mm hex (Allen) wrench	1 inch copper tape
Bubble level or plumb line	
Adjustable wrench	
Crimping tool (must be specifically matched for the RJ-45 connector used)	
Wire stripper	
Small wire cutters	
Punch down tool	

### 3.5.4 Performing a Site Survey

This section explains how to select the best location for mounting the outdoor CPE. The steps you will perform are:

- Determine the direction of available Base station from the house or building.

#### What You Need

- Compass.
- Area map with an accurate direction legend showing magnetic north.
- TVWS Base station location.

#### TVWS Base station and CPE Location

While installing the unit, you need to determine the direction of the Base Station from the house or building.

- a) Use the compass to determine the Base Station direction.
- b) Find on the customer premises the best place to install the CPE. It is recommended on the TV mast if exist.

**Warning:** The CPE-O-R-WS equipment shall be installed at a height no greater than 30 meters above the ground.

- c) Turn the CPE antenna to the Base Station direction and adjust tilt it up and down and to the right and to the left side to obtain maximum signal. Perform this antenna align process if a second antennas is used
- d) Use a Laptop with WEB connected to the PoE to read the RSSI and CINR that the CPE receive.
- e) If the signal is not good try to move and find a better location where the RSSI and CINR will be better.
- f) Record the Latitude and Longitude of the CPE installation location using a digital compass and update it in the AFAS if it is different from the registration per paragraph 3.4.2 above.

## 3.6 Installing the Equipment

---

### 3.6.1 Device Logic connection

For outdoor CPE product, it is suggested that the CPE device be installed in a shaded area to avoid direct sun light exposure which may cause over heat in certain extreme weather condition.

The CPE should be properly grounded for proper protection against lightning or power surge.

The CPE-O-R-WS is powered by 24V DC over a CAT5 Ethernet cable by a PoE device. The power is from a power adapter that operates in 90-250V AC range. The PoE and the power adapter are indoor units and need to be located in the house or office. Fix the PoE device near an electrical outlet. User Ethernet are provided via the PoE adapter too.

### 3.6.2 Installing Outdoor Unit (ODU)

The CPE-O-R-WS can be mounted on a pole or on the wall. Fix the CPE and the antenna and connect the antenna to the CPE using a coax cable. Connect the coax cable to Antenna 1 on the CPE.




Figure 9: Pole Mount Diagram

**Warning! – The CPE should be properly grounded for proper protection against lightning or power surge!**

### 3.6.3 CPE Connection to the PoE adapter

The outdoor CPE is connected to the PoE over a CAT5 Ethernet cable. User Ethernet are provided via the PoE adapter too. Prepare the Cable and connect it to the CPE and the second edge to the PoE.



Figure 10: CPE - Ethernet Header

Table 5: PoE Specifications

INTERFACE	FUNCTION	DESCRIPTION
24V DC	Power Input Jack on PoE adapter	Use 24 V /1A DC Power adapter supplied with the CPE. Misuse of power may cause damage to the device.
ODU	RJ45 Connector to Outdoor Unit	The connector carries both 24V power wires (2), Ethernet wires (4) and phone lines (2). User must use outdoor water proof CAT5 cable for installation!
LAN	RJ45 Interface to Local Area Network	Local Area Network interface (RJ45), to connect to computer, or a hub or switch. 1 or 4 ports can be available depending on the PoE adapter model

### 3.6.4 Sequence for Interconnect Cable

Separate the twisted pair wires and align by color code in the order listed in the following:




Figure 11: RJ45 Pin Diagram

Table 6: Ethernet RJ45 Cable Specification

Pin	Color Code
1	White / Orange
2	Orange
3	White / Green
4	Blue
5	White / Blue
6	Green
7	White / Brown
8	Brown

# 4 Managing CPE Devices

---

## 4.1 General

---

- ⇒ Configuration of any field should be followed by “**apply**”
- ⇒ When changes in a page are finished, the “**save settings**” button should be pushed before leaving the page.
- ⇒ After all changes in the CPE configuration is done and saved, “**reboot system**” is required to guarantee proper operation of the device.

## 4.2 Accessing CPE via Web Brower

---

Managing CPE requires access by Web browser from a local port or remote host via WiMAX network, for example, Internet Explorer in Windows operation systems.

Two options are available to access the CPE by using the LAN interface or via the wireless network if its network IP is known.

- The default IP address for the LAN interface is 192.168.0.1, unless the configuration has been modified.
- The IP address for the WAN interface is usually acquired from service provider’s network after CPE connects to the network.

Two levels of managing CPE are available, Administrator and User.

- Administrator’s privilege is designed for service providers to provision a CPE device before selling or leasing out to end users. By supplying administrator’s user name and password, a technician has access to all configurations of a CPE device. Default user name for administrator’s privileges is “**admin**”. Default password is “**admin**”.
- Users’ privilege is provisioned for end users to make limited changes of configurations for a CPE device. Most of other configurations are not visible when accessed with normal user’s privileges. Default user name and password for user is “**user**”.

### 4.2.1 Access CPE from LAN Segment

Connect the LAN port of Control Station (a PC) directly to the LAN port of the CPE, or in-indirectly via an Ethernet hub or switch. By default, the CPE will act as a DHCP server for hosts in the LAN segment unless this feature is disabled. The Control Station can dynamically acquire an IP address from CPE’s built-in DHCP server.

After IP layer connectivity is established between the Control Station and the CPE, the user may launch a Web browser and specify `http://192.168.0.1` in the address bar. A window will pop up requesting user name and password.

Input user name and password, and then click on the “OK” button. After a successful log on, the welcome page of web management interface will appear.



Figure 12: Logon Web Pages

#### 4.2.2 Access CPE Device from WAN Segment

Service providers may access the CPE Web management interface remotely, by specifying the CPE wireless IP address obtained after connecting to the service provider network.

As the wireless IP address is dynamically assigned by the service provider, the support technician may seek end user's help to find out the IP address of wireless interface for the CPE located in customer premise. The end user can retrieve the wireless IP by following the instructions given in WiMAX CPE User Manual.

## 4.3 CPE LAN Side Network configuration

The CPE can act as “Router” or as “Bridge”. In router mode the CPE has DHCP function to allocate IP address to the user devices, while in bridge mode the IP allocation is done in the network resources (such as MicroNOC).

⇒ Clarification: bridge mode is layer 3 bridge and not layer 2 bridge

To configure the LAN interface select in the menu “Network Configuration”, and “LAN Networking”

The screenshot displays the 'LAN Networking' configuration page in the AirStream 4000 Web Management System. The left sidebar shows the 'Configuration Tree' with 'LAN Networking' selected under 'Network Configuration'. The main content area is titled 'LAN Networking' and includes the following sections:

- Operation Mode Configuration:** Radio buttons for 'Router' (selected) and 'Bridge'. 'Apply' and 'Cancel' buttons are present.
- LAN PHY Setting:** A dropdown menu set to 'Auto'. 'Apply' and 'Cancel' buttons are present.
- DHCP Server Configuration:** A checkbox for 'Enable DHCP Server' which is checked. 'Apply' and 'Cancel' buttons are present.
- LAN and DHCP Server IP Setting:** Radio buttons for 'Auto' (selected) and 'Manual'. Below are input fields for:
  - LAN IP Address: 192, 168, 0, 1
  - Subnet Mask: 255, 255, 255, 0
  - DHCP Begin IP: 192, 168, 0, 2
  - DHCP End IP: 192, 168, 0, 33
  - Lease Time: 1 Minute(1-4320)
 'Apply' and 'Cancel' buttons are present.
- DHCP Static Lease:** A table with columns 'Index', 'IP Address', and 'MAC Address'. The table is currently empty with 'N/A' in the center. Below the table are input fields for 'IP Address' and 'MAC Address', and 'Add', 'Delete', and 'Delete All' buttons.

At the bottom of the page, there are 'Save Setting' and 'Reboot System' buttons.

Figure 13: LAN Network Configuration

### 4.3.1 Router / Bridge selection

The selection between router and bridge operation mode is done on the “Operation Mode Configuration” and should be followed by “apply” immediately.

### 4.3.2 DHCP

If route mode selected, the CPE can be used as DHCP server by enabling it at “DHCP server configuration”

### 4.3.3 LAN IP settings

If router mode selected, the LAN IP address should be defined with the subnet mask.

If DHCP enabled, the start IP and end IP address should be defined. The DHCP IPs must be under the subnet range.

Other IPs which are not in the DHCP range, can be used by manually configuration of the devices behind CPE or by DHCP static lease (configuring static IP for specific device recognized by MAC address).

Lease time define the time which the IP is reserved for a specific MAC identifier after connection loss. In case of CPE power loss or reboot all reserved IPs are removed from the list.

## 4.4 CPE WAN Side Network configuration

To configure the WAN (WiMAX) interface select in the menu “Network Configuration”, and “WAN Networking”

The screenshot displays the 'WAN Networking' configuration page in the AirStream 4000 Web Management System. The page is titled 'WAN Networking' and contains the following sections:

- WAN IP Address Setting:**
  - IP Address Configuration Type:  Dynamic  Static
  - IP Address: 0 . 0 . 0 . 0
  - Subnet Mask: 0 . 0 . 0 . 0
  - Default Gateway: 0 . 0 . 0 . 0
  - Running Status:  Up  Down
  - Administrative Status:  Enable This Interface
- DNS Configuration:**
  - Running Primary DNS: 0 . 0 . 0 . 0
  - Running Secondary DNS: 0 . 0 . 0 . 0
  - DNS Configuration Type:  Auto  Manual
  - Primary DNS: . . . .
  - Secondary DNS: . . . .
- IP Route Configuration:**
  - Static Route Table:
 

Destination	NetMask	Gateway	Flags	Interface	Pre F
Destination:	NetMask:	Gateway:			Preference: 60 (0-199)
- Ethernet MTU Size Configuration:**
  - MTU Size: 1500 Bytes(1300~1500)

Buttons for 'Apply' and 'Cancel' are present for each section. At the bottom of the page, there are 'Save Setting' and 'Reboot System' buttons.

Figure 14: WAN Network Configuration

### 4.4.1 WAN interface enabling

There is an option to disable or enable the WAN (WiMAX) interface by ticking the field “enable this interface”

### 4.4.2 WAN IP Address Settings

Two options available: Static IP address and Network DHCP IP address

- Static IP Address – insert the IP address according to the network manager information. Default gateway IP address is a must.

- Dynamic IP Address – by selecting this option the CPEA acquire IP address from the WiMAX network DHCP server or from the xNOC static settings. If this option selected, the fields shows the acquired IP address, Mask and default gateway.

### 4.4.3 DNS IP Address Settings

It is recommended to use Auto in this field. The xNOC is redirecting the request to the appropriate server as defined in the xNOC.

## 4.5 LAN access control

The CPE supports additional layer of access control, which help to prevent unappropriated use of the CPE.

- ⇒ If the CPE is operating as bridge mode, it is recommended to use access control of each CPE at the xNOC and not at the CPE itself.




Figure 15: Access Control Configuration

- ⇒ If router mode selected and the operator would like to control access use local control tick the field “user access control”.
- If “enable” selected the operator should define the allowed number of users behind CPE, and the “inactive timeout”
  - MAC filtering is also available

## 4.6 Radio Control

### 4.6.1 Radio Transmission Enable

The WAN interface is a wireless WiMAX radio interface. The CPE radio link must be enabled, by ticking the WiMAX connection, to connect to the wireless network and connect the user behind CPE.




Figure 16: WiMAX Radio Control

### 4.6.2 Radio Signal Transmission

For TVWS CPEs the radio signal is transmitting only from Antenna interface 1. Therefore the WIMAX TX Mode must be “TX0” and not other options.

## 4.7 Operation Channels Frequency Control

**Operator Profile**

In this page, you can configure WIMAX operator profile including Home NSP, Operator Restriction, Channel Plan, NAP and NSP settings.

**Scan Channel Settings:**

Index	Channels ID	Start Frequency(KHz)	End Frequency(KHz)	Step(KHz)	Bandwidth(KHz)	Frame Duration(us)	Status
N / A							

Channel ID:

Start Frequency:  (KHz : 693000~780000)

End Frequency:  (KHz : 693000~780000)

Step:  (KHz : 250 ~ 10000)

Bandwidth:  (KHz)

Frame Duration:  (us)

**Discrete Channel Settings:**

Index	Channels ID	Frequency(KHz)	Bandwidth(KHz)	Frame Duration(us)	Status
0	0	737000	5000	5000	Active

Channel ID:

Frequency:  (KHz : 693000~780000)

Bandwidth:  (KHz)

Frame Duration:  (us)

**Home NSP Setting:**

Operator Name:

Figure 17: Operation Channels Frequency Control

### 4.7.1 Adding Allowed Channels

The list of allowed channel for the CPE installation location, which was downloaded from an authorized web site, should be uploaded to the CPE manually or automatically by the AFAS.

At least one channel, which has the frequency of the local BTS site must be loaded manually.

⇒ **Warning! – use discrete channels settings only!**

- Channel ID – Integer 0 to 99. The number is the local CPE ID number for the channels. The CPE scan the air to locate authorized BTS from channel 0 to the highest channel and return to zero.
- Frequency – The central frequency of the channel.
- Bandwidth – 5000 Khz is the only option for USA.
- Frame Duration – 5000us is the only option for WiMAX network.

After inserting the information push the “add” button.

## 4.8 Controlling CPE access

There are options to block, restrict or allowed access to the CPE device from LAN side and / or WAN side.




Figure 18: Device Access options

## 4.9 Viewing CPE status Information

The CPE status shows the static configuration and information of the CPE device and live wireless connection status information.




Figure 19: CPE Status Information

### 4.9.1 Running Information

The Running information shows the CPE user side configuration information and the system up time from power on. The date and time of the day are valid only if updated from remote server.

### 4.9.2 WiMAX Information

The WiMAX information shows the following:

- Status – the air connection status. Searching – looking for valid WiMAX frame from base station, DL Synchronization – BTS found and the CPE is performing network entry protocols, Operation – the CPE is in service.
- IP Address – if DHCP presented: CPE wait to get IP from the network resources. If data is presented – it is the IP address, mask, gateway that the xNOC supported. If STATIC and data – it is the static configuration at the CPE

### 4.9.3 LAN Information

Valid in router mode and shows the LAN configuration

### 4.9.4 Traffic Statistic Information

This page shows the traffic which transferred over the WiMAX air interface.

The screenshot displays the 'Statistics Info' page in the AirStream 4000 Web Management System. The page title is 'Statistics Info' and it includes a brief description: 'In this page, you can see device TCP and UDP statistics information.' Below this, a table titled 'TCP/UDP Statistics:' provides the following data:

TCP Packet Sent	TCP Packet Received	UDP Packet Sent	UDP Packet Received	TCP Byte Sent	TCP Byte Received	UDP Byte Sent	UDP Byte Received
261	280	14	264	283814	30775	4592	28570

At the bottom of the page, there are two buttons: 'Save Setting' and 'Reboot System'.

Figure 20: Traffic Data Counters

## 4.10 Viewing Wireless status and Information

The WiMAX status and information page includes important information which assist operator and installer to identify proper installation and operation of CPE device

The screenshot shows the 'AirStream 4000' web management interface. On the left is a 'Configuration Tree' with categories like System Information, WiMAX Configuration, Network Configuration, and Device Management. The main content area is titled 'WIMAX Configuration > Interface Info' and 'WIMAX Interface Info'. It contains the following information:

**Networking Status:**

- Connection Status: DL SYNCHRONIZATION
- Network Service Provider:
  - BS ID: 00:00:00:00:00:00
  - Security: Disable
  - Frequency: 736990 (KHz)
  - Signal Radio: Enable
  - RSSI: 0 (dBm)
  - TX Power: 0.00 (dBm)
  - Preamble CINR: 0.00 (dB)
  - CINR(REUSE1): 0.00 (dB)
  - CINR(REUSE3): 0.00 (dB)
  - Downlink MCS: QPSK CC 1/2
  - Uplink MCS:
  - MTU Size: 1500 Byte
  - Convergency Sublayer: N/A

**WIMAX Data Statistic:**

- Transmit Packets: 663
- Receive Packets: 0
- Transmit Bytes: 68642
- Receive Bytes: 0

**WIMAX Hardware Info:**

- MAC Address: 6C:AD:EF:FF:F0:4A
- RF Configuration: 2x2(MIMO) 700(MHz)
- RF Chip Type: PM8870
- RF Driver: Build 63 Patch 12
- WIMAX Adapter Type: SQN 1130-EXC

At the bottom of the page are two buttons: 'Save Setting' and 'Reboot System'.

Figure 21: WiMAX Interface Status and Information

### 4.10.1 Networking Status

- Connection Status: shows the air interface state status
- BS ID – if not 00:00:00... shows the ID of the base station which the CPE is connected to
- Frequency – shows the channel which is selected to connect to the BTS
- RSSI – the radio signal strength that the CPE receive the BTS
- Tx Power – the TX power which the BTS request from the CPE to transmit
- CINR – the calculated signal to noise ratio.

### **4.10.2 WiMAX Data Statistics**

This information presents the traffic which is passing via the air interface

### **4.10.3 Hardware Information**

Shows the air interface MAC addresses which the BTS and xNOC see during system entrée, authentication and authorization processes.

# 5 MAX Rx Signal Adjusting

## 5.1 RF Signal Adjusting

When the TVWS CPE ODU has installed, the direction of antenna's azimuth and pitch angle needs to adjust for the best signal strength, if the antenna is just pointing the base station the signal will be the best strength.

Thus, we can adjust the holder to change the direction and angle of the antenna while observing the RF LED of the ODU which indicates the signal



Figure 22: Signal Indicators

## 5.2 Link Status

When clicking on the “Interface Info” link, the following WiMAX interface information is displayed.

### 5.2.1 Networking Status

Additional interface information such as RSSI, uplink or downlink throughput will be added in the coming software release.

**Networking Status:**

Connection Status: DL SYNCHRONIZATION  
Network Service Provider:  
BS ID: 00:00:00:00:00:00  
Security: Disable  
Frequency: 609990 (KHz)  
Signal Radio: Enable  
RSSI: 0 (dBm)  
TX Power: 0.00 (dBm)  
Preamble CINR: 0.00 (dB)  
CINR(REUSE1): 0.00 (dB)  
CINR(REUSE3): 0.00 (dB)  
Downlink MCS: QPSK CC 1/2  
Uplink MCS: QPSK CC 1/2  
MTU Size: 1500 Byte  
Convergency Sublayer: N/A  
Connected Time: 0 min

## 5.2.2 WiMAX data statistics and Hardware information

The WiMAX data statistics shows the wireless data traffic amount and the hardware info displays the underlying WiMAX chipset and driver information.

**WiMAX Data Statistic:**

Transmit Packets: 1734  
Receive Packets: 0  
Transmit Bytes: 153953  
Receive Bytes: 0

**WiMAX Hardware Info:**

MAC Address: 6C:AD:EF:FF:F3:A3  
RF Configuration: 2x2(MIMO) 470~698(MHz)  
RF Chip Type: PM8870  
RF Driver: Build 63 Patch 12  
WiMAX Adapter Type: SQN 1130-EXC  
WiMAX Firmware: 4.6.2.4 [r4.6.2.4/29146]

The configuration of WiMAX other parameters reference by following instructions given in WiMAX CPE User Manual.

---

## 5.3 Welcome WEB Page

The following figure shows the Welcome page of web management interface of AirStream 4000 CPE which provides 1 LAN ports, 1 Phone line port.

And the CPE connected to the WiMAX base station successfully.



**AirStream 4000**

RUNCOM

System Information > System Status

**System Status**

**Running Info:**

Device Name:

Operation Mode: Router

System Up Time: 0 day(s) 0 hour(s) 5 minute(s)

System Time: 2014-10-21 11:23:13

**Version Info:**

Manufacture: RUNCOM

Current Software Version: AirStream 4000 V1.3.0B1675 (build on Aug 8 2014)

Main Image Version: V1.3.0B1675

Shadow Image Version: V1.3.0B1675

BIOS Version: 3.0.0.0

Hardware Version: V2.0

**WiMAX Info:**

Status: DL SYNCHRONIZATION

MAC Address: 6c:ad:ef:ff:f3:a3

IP Address: (DHCP)

Subnet Mask:

Default Gateway:

DNS Server:

Radio Calibration: Yes

## 5.4 LED Display

Table 7: Led Display

LED Indicator	Function	Description
PWR	Power Indicator	Green Color – Device is powered on
RUN	System Run Indicator	Fast Blinking – Device is rebooting Slow Blinking – Device is in normal operation
LAN	LAN port status	Solid Green – LAN port is up Blinking Green – LAN data activity in progress
RF (4 LEDs)	RF Signal Strength	4 level signal strengths indication by 4 green LEDs