


NECKER V1

1080P高畫質運動型錄影機



使用手冊

Table of Contents

1.	Introduction.....	2
●	System Requirements.....	3
2.	Preparation.....	4
●	Component & Accessories.....	4
●	Part Names.....	5
●	Indicator LED.....	6
3.	Charging.....	7
4.	Recording.....	9
●	Car Mode.....	9
●	Sport Mode.....	12
5.	Download.....	15
●	Download from NECKER V1.....	15
●	Download from Card Reader.....	16
6.	Playback.....	17
●	Playback from PC / Mac.....	17
7.	Wireless.....	18
●	Enable Wireless Function.....	18
●	Enable APP Function.....	20
8.	Expert Mode.....	21
●	Load from NECKER V1.....	21
●	Load from microSD Card Reader.....	22
●	Adjust NECKER V1 Settings.....	23
●	Adjust the Date and Time Settings.....	24
9.	FAQ.....	25
10.	Appendix.....	28
●	Specification.....	29
●	Default Setting.....	

1. Introduction

Welcome to the world of digital imaging. The following information will help you to use your NECKER V1 to its full capabilities.

Before you install and operate the product, please take a few minutes to read through this manual. It provides proper instructions for you to install and operate the product.



The NECKER V1 may be affected by static electricity interference. Please plug-in / out and wait a few minutes to start this function.

- **System Requirements**

PC System Requirements

- Intel® Core2Duo 1.8G or AMD equivalent CPU
- Hi-speed USB2.0 port
- 1 GB RAM internal memory minimum
- 500MB free hard disk space
- 800 x 600 pixel color monitor
- nVIDIA GeForce MX440 or above, AMD (ATi) Radeon 9200 or above
- DirectX 9.0 or higher
- Windows® XP (SP2 or higher) / Windows Vista™ / Windows 7™, Windows 8™


Note: If your system is Windows XP Service Pack I, please go to www.microsoft.com. It's free to update your system to Windows XP Service Pack II.

Mac System Requirements

- Power PC G5 or Intel Core Duo processor recommended
- Free USB2.0 port
- 1 GB RAM internal memory minimum
- 500MB free hard disk space
- 800 x 600 color monitor
- Mac OS 10.5 or above

2. Preparation

● Component & Accessories



NECKER V1 Sport DV




QOG




User Manual



USB Cable




AC Adaptor



Camera Holder



Hand Strap



Waterproof

Car Charger

MicroSD

(optional)



Hi-Speed


charger cable

(For charging

use only.)



Base Mount





Tripod Mount



Bike Mount



Universal
Mount




- Indicator LED

		Front LED	Rear LED
Power	<i>Off</i>	Off	-
	<i>On</i>	Blue, On	-
Record	<i>Off</i>	Off	-
	<i>On</i>	Blue, Slow Blink	-
Wireless	<i>Off</i>	-	Off
	<i>Booting</i>	-	Red, Slow Blink
	<i>On</i>	-	Red, On
Battery	<i>Low</i>	Blue, Quick Blink	-
	<i>Charge</i>	-	Green, On
	<i>Full</i>	-	Off
SD Card	<i>No Card</i>	-	Red, Quick Blink
	<i>Card Full</i>	-	Red, Quick Blink


3. Charging


EN

1. Remove the rear protective cap of the NECKER V1 and connect the supplied mini USB cable into the NECKER V1.



2. Plug the USB cable into the supplied AC wall adaptor, car adaptor, or a PC / Mac USB port.





3. The NECKER V1 will illuminate the Green LED in the Rear LED to tell you it's charging.
4. When the Green LED turns off, the battery is full and charging is complete.


Note: The Front LED will blink blue and auto power off after 10 seconds when the battery power is low and reference the charging procedure to recharge it.

4. Recording


EN

● Car Mode

1. Remove the rear protective cap of The NECKER V1 and insert a microSD card (optional) in the microSD Card Slot.




2. Slide the Mode Switch to the Left side.




Note: 1. In Car Mode, the NECKER V1 circulate record video and overwrite the oldest recorded file first.

2. The record file automatic divides each 1, 3 or 5 minutes depend on user setting.


3. Hold down the Power Button for 1 seconds and release, the NECKER V1 will illuminate the Blue Front LED and vibrates 3 times. The Rear LED will blink Red and boot the wireless module.




4. When the wireless module has booted, the Rear LED turn off.




5. The NECKER V1 vibrates 1 time and auto record. The Front LED blink slowly in Blue.




6. To stop recording, hold down the Power Button for 1 second and release, the Front LED stop blink, vibrates 1 time and save the file.



7. Hold down the Power Button for 5 seconds and release. The Front LED turn off and vibrates 3 times then power off.




Note: 1. The Rear LED will blink quickly the RED and the NECKER V1 will vibrate until power off when the micro SD card has full or there is no micro SD card insert into the micro SD card slot.




2. The wireless module will boot at the same time when power on. The rear LED slow blink in red. Reference the “8 Wireless” for more information.
3. NECKER V1 need about 20 seconds to boot the wireless module. The record function will be disabled before wireless module has booted.
4. It will auto power on when plug-in the mini USB cable.

- **Sporty Mode**

1. Remove the rear protective cap of the NECKER V1 and insert a microSD card (optional) in the microSD Card Slot.




2. Slide the Mode Switch to the Right side.




Note: 1. In Sporty Mode, the NECKER V1 doesn't circulate record and overwrite the oldest recorded file. It will auto power off when memory card is full.

2. The record file automatic divides each 1, 3 or 5 minutes depend on user setting.


3. Hold down the Power Button for 1 seconds and release, the NECKER V1 will illuminate the Blue Front LED and vibrates 3 times. The Rear LED will blink Red and boot the wireless module.




4. When the wireless module has booted, the Rear LED turn off.




5. Hold down the Power Button for 1 second and release to start video recording. The NECKER V1 vibrates 1 time and the Front LED blink slowly in Blue.




6. To stop recording, hold down the Power Button for 1 second and release, the Front LED stop blink, vibrates 1 time and save the file.



7. Hold down the Power Button for 5 seconds and release. The Front LED turn off and vibrates 3 times then power off.




Note: 1. The Rear LED will blink quickly the RED and the NECKER V1 will vibrate until power off when the micro SD card has full or here is no micro SD card insert into the micro SD card slot.




2. The wireless module will boot at the same time when power on. The rear LED slow blink in red. Reference the “8 Wireless” for more information.
3. NECKER V1 need about 20 seconds to boot the wireless module. The record function will be disable before wireless module has booted.
4. It will not auto power on when plug-in the mini USB cable.

- **Download from NECKER V1**

1. Remove rear protective cap and power off.



2. Connect the supplied mini USB cable into the micro USB port of the NECKER V1.
3. Plug the USB cable into a PC / Mac USB 2.0 port.



4. On a PC / Mac your NECKER V1 will mount to your computer as a mass storage device


in MSDC mode.

5. You may download your video files from the X:\DCIM\100MEDIA folder.

Note: Always eject device from PC / Mac.

- **Download from microSD Card Reader**

1. Remove rear protective cap.



2. Take the microSD card out and insert it to a compatible card reader. You may download your video files from the X:\DCIM\100MEDIA folder.

- **Playback from PC / Mac**

The video file format is MOV which can be played by QuickTime™ with PC / Mac.

- **Windows 7:** The videos can be viewed by the built-in Windows Media Player or QuickTime.
- **Windows XP:** The videos can be viewed by the Windows Media Player Ver. 11 or QuickTime.
- **Mac:** Use the built-in QuickTime.


Note: For PC version which can be downloaded from:

<http://www.apple.com/quicktime/download/>


7. Wireless

● Enable Wireless Function


1. Remove the rear protective cap of The NECKER V1 and insert a microSD card (optional) in the microSD Card Slot.




2. Hold down the Power button for 1 seconds and release, the NECKER V1 will illuminate the BLUE Front LED and vibrates 3 times. The Rear LED will blink Red and boot the wireless module.




3. When the wireless module has booted, the Rear LED turn off.





4. Press and hold the Wireless Button 1 second then release to enable the wireless function. The camera vibrates 2 times.



5. Wait about 2 or more seconds until the wireless function enable. The Red of Rear LED will light



6. Use the mobile device to connect the NECKER V1 and modify settings via the App.
7. To turn off the Wireless function, press and hold the Wireless Button to disable the wireless function. The Red of Rear LED turn off and the NECKER V1 vibrates 2 times.



● Enable APP Function


IOS System

Please kindly download 『Action Cam HD』 from APP STORE as below:



Android system

Please kindly download 『Action Cam HD』 from Play Store as below:



After installed above APP, please connect with wireless of V1 to use.


***Please kindly input “1234567890” upon password request.**

8. Expert Mode


Allow user to adjust the NECKER V1 full function settings by text editor.

● Load from NECKER V1

1. Remove rear protective cap and power off.




2. Connect the supplied mini USB cable into the micro USB port of the NECKER V1.
3. Plug the USB cable into a PC / Mac USB 2.0 port.



4. On a PC / Mac your NECKER V1 will mount to your computer as a mass storage device in MSDC mode.
5. Find “config.txt” from “x:\” folder of micro SD card.


EN



Note: Always eject device from PC / Mac.

- **Load from micro SD Card Reader**


1. Remove rear protective cap and take the micro SDHC out of the NECKER V1.



2. Take the microSD card out and insert it to a compatible card reader. Find "config.txt" from "x:\\" folder of micro SD card


- **Adjust NECKER V1 Settings**

1. Open the "config.txt" from text editor as below.
(ex. Notepad for Windows.)



2. Reference the Index Area for detail descriptions then change settings from the Settings Area.
3. Modify the UPDATE: "N" to "Y" before save and close it.

Note: It will not active any changed settings if the "N" has not be changed to "Y".



4. Disconnect the USB cable / insert the memory card to camera then restart and done these settings.

Note: The "config.txt" is created by the NECKER V1 automatic when insert a new memory card or even deleted it. All settings are current used by NECKER V1.

● **Adjust Date and Time**

1. Open the "config.txt" from text editor as below.
(ex. Notepad for Windows.)
2. Find the "DT" code from the Setting Area and follow the current format to adjust the date and time. Revise "UPDATE: "N" to "Y" before save and close it.
3. Remove the USB cable / insert the memory card to NECKER V1 then power on and complete the setting.

9. FAQ

This chapter will list some of the problems you might face when using this device and their solutions. Even if the following guide can not solve your problem, please do not dismantle this device on your own. Please send the device back to the store where you purchased it for maintenance.

Q1.Why power indicator is not working?

A: Please make sure you are using the car charger from our company. If it is not, it may have connecting problem.

Q2.Why image is not clear?

A: Please make sure your lens is clean and use lens-cleaning cloth to remove the dirty. Or it may come from unclean front windshield.

Q3.Why image has violent jump in while driving?

A: Please make sure the mount is well holding.

Q4.Why it is not smooth while playing in computer?

A: Please copy video file to your computer then play. Please use class dual core CPU or higher class and also at least 512MB memory capacity.

Please also use common media player, such as Windows Media Player to play. And then check

setup latest version of video codec.

Q5.Does it is not smooth enough and have jump seconds?

A: NECKER V1 products use standard Micro SD card socket. Please avoid to use Micro SD card which under class 6.

Q6.Do I need to reset the date or time after every turning on?

A: You don't need to reset the date or time again.

All of information will be remained on this product.

Q7.How long does NECKER V1 use? Shall we use power bank?

A:NECKER V1 could work for 1.5 hours continuously, however; it depends on methods.

Moreover; NECKER V1 can work with power bank. Please be kind noted that power bank could not have water proof function, therefore; don't use power bank when raining.

Q8.Why does base mount not tight with 3M lable?

A:Before using NECKER V1, please be sure prominence

nearby base mount must be pressed down and hear buckling and then it is ready for use.

Q9. Shall we use NECKER V1 when snorkeling ?

A:Water proof for V1 is IPX8, therefore; you could use V1 under 3M water. However; it will be

a problem if out water 3M, please be kind understanding.

Q10.How do I use two cable inside NECKER V1 box? A:Hi-speed charge cable if only for charging use not for download video or images. Water proof charge cable could be used for motorcyle when raining.

10. Appendix

● Specification

Sensor	14M (4608x3288) CMOS 1/2.3"
DSP	Ambarella A5S
Lens	6G+IR, F1.6, f3.6 mm, Optical 160.0°
Video Resolution	Full HD : 1080P : 1920x1080 @ 30 fps HD:720P : 1920 x 720 @ 30 fps 1920 x 720 @ 60 fps
Video File Format	MOV
White Balance	Auto
Exposure	Auto
Video Encoder	H.264
Audio Encoder	AAC and AC3 mono, sample rate 48K
Audio Input	Built-in MIC
Battery	Internal Li-Ion Rechargeable Battery 3.7V / 800mA
Storage	MicroSD up to 32GB
Connector	USB 2.0, mini USB B Type (5 pin)
Dimensions	107.8 (L) x 34.0 (W) x 34.0 (H) mm

Specifications are subject to change without prior notice.

- “Config.txt” default

Type: Necker V1

Version: Vxx.xxx

UPDATE: N

FORMAT

RES: 0

AE: 0

EV: 5

AWB: 0

SHRP: 3

CTST: 67

DEF: 0

SPLIT: 180

STAMP: 3

FLK: 0

APO: 180

MICG: 25

DT: 2013/12/16 15:49:16

RES (Resolution) : 0 ~ 2

(0)1080p30 (1)720p60 (2)720p30

AE (AE meter) : 0 ~ 2

(0)Center (1)Average (2)Spot

EV (EV bias) : 0 ~ 12

(0)-2EV (3)-1EV (6)0EV (9)+1EV (12)+2EV

AWB (AWB mode) : 0 ~ 7

(0)Auto (1)Incandescent (2)4000K_Fluorescent (3)5000K_DaylightD50

(4)6500K_DaylightD65 (5)7500K_Cloudy (6)9000K_Shade (7)10000K_XenonHID

SHRP (Sharpness) : 1 ~ 5

(1)Soft (3)Standard (5)Hard

CTST (Contrast) : 32 ~ 88

(32)Soft (64)Standard (88)Hard

DEF (Digital Effect) : 0 ~ 5

(0)Off (1)Art (2)Sepia (3)Negative (4)Black White (5)Vivid

SPLIT (Split File Size) : 60/180/300

(60)1 Min (180)3 Mins (300)5 Mins

STAMP (Date/Time Stamp) : 0 ~ 3

(0)Off(Video stamp will disable in wifi mode) (1)Date (2)Time (3)Date&Time

FLK (Flicker) : 0 ~ 2

(0)Auto (1)60Hz (2)50Hz

APO (Auto Power Off) : 0 ~ 300

(0)Off (180)3Min. (300)5Min.

MICG (Microphone AGC Max) : 0 ~ 59 db

DT (Date Time) : YYYY/MM/DD hh:mm:ss

YYYY: 2011 ~ 2037

MM: 01 ~ 12

DD: 01 ~ 31

This symbol on the product or in the instructions means that your electrical and electronic equipment should be disposed at the end of its life separately from your household waste. There are separate collection systems for recycling in the EU. For more information, please contact the local authority or your retailer where you purchased the product.



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

FCC RF Radiation Exposure Statement:

1. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

2. This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.