

SAMSUNG

RFV01U-D1A Installation Manual

Describes product installation and requirement procedure.

Document Version 2.0
July 2017

Radio Access Network

Document Number: 2600-00KYMEGAA

© 2017 SAMSUNG Electronics Co., Ltd.

All Rights Reserved. The contents of this document/presentation contain proprietary information that must be kept confidential. No part of this document shall be photocopied, reproduced, stored in a retrieval system, or transmitted, in any form or by any means whether, electronic, mechanical, or otherwise without the prior written permission of SAMSUNG Electronics Co., Ltd.

No warranty of accuracy is given concerning the contents of the information contained in this publication. To the extent permitted by law no liability (including liability to any person by reason of negligence) will be accepted by SAMSUNG Electronics Co., Ltd., its subsidiaries or employees for any direct or indirect loss or damage caused by omissions from or inaccuracies in this document. SAMSUNG Electronics Co., Ltd. reserves the right to change details in this publication without notice.

SNMTC-v3-0312

This manual should be read and used as a guideline for properly installing and/or operating the product. Owing to product variations across the range, any illustrations and photographs used in this manual may not be a wholly accurate depiction of the actual products you are using.

This manual may be changed for system improvement, standardization and other technical reasons without prior notice.

Samsung Networks documentation is available at <http://www.samsungdocs.com>

Contents

Preface		ix
	Conventions in this Document	ix
	New and Changed Information	x
	Revision History.....	x
	Organization of This Document	x
	Related Documentation	x
	Personal and Product Safety	xi
	Equipment Markings	xv
Chapter 1	Before Installation	1
	System Configuration and Interface	1
	<i>RRH View</i>	1
	<i>RRH External Interface</i>	2
	Specifications	4
	Cautions for Installation.....	5
	<i>Before Installing</i>	5
	<i>While Installing</i>	5
	<i>After Installing</i>	6
	Installation Tools	7
Chapter 2	Installing System	10
	Installation Procedure	10
	System Arrangement	11
	Unpacking and Transporting.....	16
	<i>Bringing in Items</i>	16
	<i>Unpacking Items</i>	16
	RRH Handling	17
	Fixing RRH	18
	<i>Fixing Finger Guard</i>	18
	<i>Fixing Unit Bracket</i>	21
	<i>Fixing Pole Type</i>	24
	<i>Fixing Wall Type</i>	36
Chapter 3	Connecting Cables	50
	Cabling Procedure	50
	Guidelines for Cable Connections	51
	<i>Cable Path Inspection</i>	51
	<i>Cable Cutting</i>	52
	<i>Cable Installation</i>	52
	<i>Cable Binding</i>	53
	<i>Connector Attachment</i>	53
	<i>Identification Tag Attachment</i>	54
	Cabling Diagram	55
	Grounding	58
	<i>Connecting Ground Cable</i>	58
	Power Cabling	61
	<i>Connecting Power Cable</i>	62
	Interface Cable Connection.....	65

	<i>Remove/Insert Optical Module</i>	65
	<i>Connecting CPRI Cable</i>	66
	<i>Connecting UDA Cable</i>	71
	<i>Connecting RET Cable</i>	75
	<i>Connecting RF Cable</i>	77
Chapter 4	Inspect the Installation	88
Appendix A	Acronyms	92
Appendix B	Sector Antenna Installation	93
	Cautions when Installing a Sector Antenna	93
	Sector Antenna Installation.....	94
Appendix C	Clean the Optical Connectors	95
	Introduction	95
	<i>Measure the Optical Output and Connecting the Optical Connector</i>	95
Appendix D	Standard Torque	97

List of Figures

Figure 1.	RRH View (without Finger Guard)	1
Figure 2.	RRH View (with Finger Guard).....	2
Figure 3.	RRH External Interface	3
Figure 4.	Procedure to Install the RRH	10
Figure 5.	RRH Arrangement_1 Sector Pole Type Installation (Standard Installation)	11
Figure 6.	RRH Arrangement_1 Sector Pole Type Installation (Side Installation).....	11
Figure 7.	RRH Arrangement_2 Sector Pole Type Installation (Side Installation).....	12
Figure 8.	RRH Arrangement_1 Sector Wall Type Installation (Standard Installation).....	13
Figure 9.	RRH Arrangement_1 Sector Wall Type Installation (Side Installation)	13
Figure 10.	RRH Arrangement_3 Sector Wall Type Installation (Standard Installation).....	14
Figure 11.	RRH Arrangement_3 Sector Wall Type Installation (Side Installation)	15
Figure 12.	RRH Handling	17
Figure 13.	Finger Guard Fixing (1).....	19
Figure 14.	Finger Guard Fixing (2).....	19
Figure 15.	Finger Guard Fixing (3).....	19
Figure 16.	Finger Guard Fixing (4).....	20
Figure 17.	Finger Guard Fixing (5).....	20
Figure 18.	Finger Guard Fixing (6).....	20
Figure 19.	Fixing Unit Bracket_Standard Installation (1)	22
Figure 20.	Fixing Unit Bracket_Standard Installation (2)	22
Figure 21.	Fixing Unit Bracket_Standard Installation (3)	23
Figure 22.	Fixing Unit Bracket_Side Installation.....	24
Figure 23.	Assembling Mounting Bracket (1).....	25
Figure 24.	Assembling Mounting Bracket (2).....	26
Figure 25.	Lifting RRH & Mounting Bracket Assembly	27
Figure 26.	Lifting RRH & Mounting Bracket Assembly	28
Figure 27.	Fixing Mounting Bracket Assembly_1 Sector Pole Type (1)	29
Figure 28.	Fixing Mounting Bracket Assembly_1 Sector Pole Type (2)	29
Figure 29.	Fixing Mounting Bracket Assembly_1 Sector Pole Type (3).....	30
Figure 30.	Levelling Mounting Bracket Assembly_1 Sector Pole Type	30
Figure 31.	Fixing Mounting Bracket Assembly_2 Sector Pole Type (Side Installation 1)	31
Figure 32.	Fixing Mounting Bracket Assembly_2 Sector Pole Type (Side Installation 2)	31
Figure 33.	Fixing Mounting Bracket Assembly_2 Sector Pole Type (Side Installation 3)	32
Figure 34.	Fixing RRH_1 Sector Pole Type (Standard Installation).....	33
Figure 35.	Fixing RRH_1 Sector Pole Type (Side Installation).....	34
Figure 36.	Fixing RRH_2 Sector Pole Type (Side Installation 1).....	36
Figure 37.	Fixing RRH_2 Sector Pole Type (Side Installation 2).....	36
Figure 38.	RRH marking dimensions_1 Sector Wall Type (Standard Installation).....	37
Figure 39.	RRH marking dimensions_1 Sector Wall Type (Side Installation)	38
Figure 40.	RRH marking dimensions_3 Sector Wall Type (Standard Installation).....	38
Figure 41.	RRH marking dimensions_3 Sector Wall Type (Side Installation)	39
Figure 42.	Marking_Wall Type	40
Figure 43.	Drilling & Anchoring.....	41
Figure 44.	Fixing Mounting Bracket_1 Sector Wall Type	42
Figure 45.	Fixing Mounting Bracket_3 Sector Wall Type	43
Figure 46.	Fixing RRH_1 Sector Wall Type (Standard Installation).....	44
Figure 47.	Fixing RRH_1 Sector Wall Type (Side Installation)	45

Figure 48.	Fixing RRH_3 Sector Wall Type (Standard Installation 1).....	47
Figure 49.	Fixing RRH_3 Sector Wall Type (Standard Installation 2).....	47
Figure 50.	Fixing RRH_3 Sector Wall Type (Side Installation 1).....	49
Figure 51.	Fixing RRH_3 Sector Wall Type (Side Installation 2).....	49
Figure 52.	Procedure to Connect System Cable.....	50
Figure 53.	Cable Connection Procedure.....	51
Figure 54.	Cable Diagram_2.1 GHz RF Connection: 2T2R	55
Figure 55.	Cable Diagram_2.1 GHz RF Connection: 2T4R, 4T4R	55
Figure 56.	Cable Diagram_1.9 GHz RF Connection: 2T2R	56
Figure 57.	Cable Diagram_1.9 GHz RF Connection: 2T4R, 4T4R	56
Figure 58.	Connecting Ground Cable (1).....	59
Figure 59.	Connecting Ground Cable (2).....	60
Figure 60.	Power Equipment Elements.....	61
Figure 61.	Connecting Power Cable (1).....	63
Figure 62.	Connecting Power Cable (2).....	63
Figure 63.	Optical Module Removal (1)	65
Figure 64.	Optical Module Removal (2)	65
Figure 65.	Optical Module Removal (3)	65
Figure 66.	Optical Module Inset.....	66
Figure 67.	Connecting CPRI Cable (1).....	67
Figure 68.	Connecting CPRI Cable (2).....	68
Figure 69.	Connecting CPRI Cable (3).....	68
Figure 70.	Connecting CPRI Cable (4).....	69
Figure 71.	Connecting CPRI Cable (5).....	69
Figure 72.	Connecting CPRI Cable (6).....	70
Figure 73.	Connecting UDA Cable (1).....	72
Figure 74.	Connecting UDA Cable (2).....	72
Figure 75.	Connecting UDA Cable (3).....	72
Figure 76.	Connecting UDA Cable (4).....	73
Figure 77.	Connecting UDA Cable (5).....	73
Figure 78.	Connecting UDA Cable (6).....	74
Figure 79.	Connecting RET Cable (1).....	76
Figure 80.	Connecting RET Cable (2).....	76
Figure 81.	Connecting RET Cable (3).....	77
Figure 82.	Connecting RET Cable (4).....	77
Figure 83.	Connecting RF Cable_2.1 GHz 2T2R Connection (1)	79
Figure 84.	Connecting RF Cable_2.1 GHz 2T2R Connection (2)	79
Figure 85.	Connecting RF Cable_2.1 GHz 2T2R Connection (3)	80
Figure 86.	Connecting RF Cable_2.1 GHz 2T4R, 4T4R Connection (1)	81
Figure 87.	Connecting RF Cable_2.1 GHz 2T4R, 4T4R Connection (2)	81
Figure 88.	Connecting RF Cable_2.1 GHz 2T4R, 4T4R Connection (3)	82
Figure 89.	Connecting RF Cable_1.9 GHz 2T2R Connection (1)	83
Figure 90.	Connecting RF Cable_1.9 GHz 2T2R Connection (2)	83
Figure 91.	Connecting RF Cable_1.9 GHz 2T2R Connection (3)	84
Figure 92.	Connecting RF Cable_1.9 GHz 2T4R, 4T4R Connection (1)	85
Figure 93.	Connecting RF Cable_1.9 GHz 2T4R, 4T4R Connection (2)	85
Figure 94.	Connecting RF Cable_1.9 GHz 2T4R, 4T4R Connection (3)	86
Figure 95.	Installation Inspection Procedure	88
Figure 96.	Sector Antenna.....	94

List of Tables

Table 1.	Specifications	4
Table 2.	Basic Installation Tools	7
Table 3.	Parts and Tools for fixing Finger Guard	18
Table 4.	Parts and Tools for fixing Unit Bracket_Standard installation	21
Table 5.	Parts and Tools for fixing Unit Bracket_Standard Installation	23
Table 6.	Parts and Tools for assembling Mounting Bracket	24
Table 7.	Parts and Tools for fixing Mounting Bracket Assembly_1 Sector Pole Type.....	28
Table 8.	Parts and Tools for fixing Mounting Bracket Assembly_2 Sector Pole Type (Side Installation).....	31
Table 9.	Fixing RRH_1 Sector Pole Type (Standard & Side Installation).....	32
Table 10.	Parts and Tools for fixing RRH_2 Sector Pole Type (Side Installation)	34
Table 11.	Tools for Marking	37
Table 12.	Parts and Tools for Drilling & Anchoring.....	40
Table 13.	Anchor Bolt Drill Bits and Hole Depth	41
Table 14.	Parts and Tools for fixing Mounting Bracket_1 Sector Wall Type.....	42
Table 15.	Parts and Tools for fixing Mounting Bracket_3 Sector Wall Type.....	42
Table 16.	Parts and Tools for fixing RRH_1 Sector Wall Type (Standard & Side Installation).....	44
Table 17.	Parts and Tools for fixing RRH_3 Sector Wall Type (Standard Installation)	45
Table 18.	Parts and Tools for fixing RRH_3 Sector Wall Type (Side Installation)	48
Table 19.	Recommended Minimum Allowed Cable bend Radius	52
Table 20.	RRH Connection Cable	56
Table 21.	Parts and Tools for connecting Ground Cable	58
Table 22.	Parts and Tools for connecting Power Cable	62
Table 23.	Power Cable/Connector Pin Map.....	62
Table 24.	Parts and Tools for connecting CPRI Cable	66
Table 25.	Parts and Tools for connecting UDA Cable	71
Table 26.	UDA Cable Pin Map	71
Table 27.	Parts for connecting RET Cable	75
Table 28.	RET Cable Pin Map	75
Table 29.	RF Cable Minimum Radius of Curvature	77
Table 30.	Parts and Tools for connecting RF cable	78
Table 31.	RF Cable Identification Tag.....	87
Table 32.	Construction Situation Check list	89
Table 33.	Standard Torque Value for Fastening Bolts	97
Table 34.	Brass Bolts Torque Value	97
Table 35.	Connector Connection Torque Value.....	97

Preface







This manual describes how to install the 1.9/2.1 GHz RRH including how to connect cables. This manual includes the following 1.9/2.1 GHz RRH:

- RFV01U-D1A

Conventions in this Document

Samsung Networks product documentation uses the following conventions.

Symbols

Symbol	Description
	Indicates a task.
	Indicates a shortcut or an alternative method.
	Provides additional information.
	Provides information or instructions that you should follow to avoid service failure or damage to equipment.
	Provides information or instructions that you should follow to avoid personal injury or fatality.
	Provides antistatic precautions that you should observe.

Menu Commands

menu | command

This indicates that you must select a command on a menu, where **menu** is the name of the menu, and **command** is the name of the command on that menu.

File Names and Paths

These are indicated by a bold typeface. For example:

Copy **filename.txt** into the **/home/folder1/folder2/bin/** folder.

User Input and Console Screen Output Text

Input and output text is presented in the Courier font. For example,

```
context <designated epc-context-name>
```

CLI commands are presented in bold small caps. For example,

Type the **RTRV-NE-STS** command in the input field.

New and Changed Information

This section describes information that has been added/changed since the previous publication of this manual.

- Changed weight. (Table 1 Specifications)
- Changed UDA cable pin map. (Table 26 UDA Cable Pin Map)

Revision History

The following table lists all versions of this document.

Document Number	Product/Software Version	Document Version	Publication Date	Remarks
2600-00KYMEGAA	RFV01U-D1A	1.0	July 2017	-
2600-00KYMEGAA	RFV01U-D1A	2.0	July 2017	-

Organization of This Document

Section	Title	Description
Chapter 1	Before Installation	This chapter introduces RRH and describes items should be understood before installation.
Chapter 2	Installing System	This chapter describes the procedures to install the RRH.
Chapter 3	Connecting Cables	This chapter describes the procedures to connect the cables to the RRH installed.
Chapter 4	Inspect the Installation	This chapter describes the procedures of inspecting installation status after RRH installation and cabling is completed.
Appendix A	Acronyms	This annex describes the acronyms used in this manual.
Appendix B	Sector Antenna Installation	This annex describes the sector antenna installation.
Appendix C	Clean the Optical Connectors	This annex describes the procedure of cleaning the optical connector and cleaning tool.
Appendix D	Standard Torque	This annex describes the standard torque when fastening the bolt.

Related Documentation

- LTE eNB System Description

Personal and Product Safety

This product safety information includes European directives, which you must follow. If these do not apply in your country, please follow similar directives that do apply in your country.

Proposition 65 Warning (US Only)

State of California Proposition 65 Warning (US only)

WARNING: This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

Electrical

The product is designed to operate from a -48 V DC supply and is therefore classified as Safe Extra Low Voltage (SELV) equipment.

All structural parts are grounded and all input and outputs have built-in isolation from the network. All input and output ports that connect to external power sources are designed to meet relevant national safety requirements.

The product contains hazardous energy levels as defined by EN 60950. Care must be taken when maintaining this equipment as injury to personnel or damage to the equipment could result from mistakes. Maintenance should only be carried out by trained and competent engineers who are familiar with the relevant procedures and instructions.

Lasers

The product is fitted with optic modules rated as Class 1 radiation-emitting devices under EN 60825-1. During installation, operation, and maintenance, never look into the end of an optical fiber directly or by reflection either with the naked eye or through an optical instrument. Do not operate equipment with exposed fiber connectors-cover these with fiber cables or blanking caps. Do not remove equipment covers during operation unless requested to do so in the documentation. Carry out normal safety precautions when trimming fibers during installation.

Manual Handling

Care should be taken when handling equipment. Give due consideration to the weight of the equipment, the physical capability of the individual(s) handling the equipment, and movements such as twisting, bending and stooping, which could lead to skeletal and muscular injuries.

Installation

Installation must be carried out by trained and competent engineers only. All relevant safety measures should be taken to ensure equipment is not connected to

live power and transmission sources during installation. Equipment must be correctly installed in order to meet the relevant safety standards and approval conditions.

Each power feed to the unit requires a separate fused feed from the provided power supply. The cable between the power distribution point and the installed equipment must have a minimum cross-sectional area of 2.5 mm².

Rack-mountable equipment must be placed in a standard 19-inch rack and secured with the appropriate fixings as detailed in the installation manual.

Maintenance

Maintenance must only be carried out by a suitably trained and competent technician. All safety instructions must be carefully observed at all times. Equipment covers should not be removed while live power and transmission is connected unless in a controlled environment by trained technicians.

Fire

The product is powered from a -48 V DC supply. To protect against fire, the equipment is fused.

Environment

The product must be operated in an environment with the specified relative humidity and ambient temperature ranges.

Keep all liquids away from the equipment as accidental spillage can cause severe damage.

Cooling

The product cools down by its own set of cooling fans housed in a fan module. Each fan module detects a fan that is not operating normally. LEDs on the front panel of the fan module provide an alarm indication in the event of fan failure.

In the event of fan failure, take urgent remedial action to restore full cooling capacity.

Take appropriate measures to ensure that fan modules do not start spinning during repair and maintenance procedures.

Anti-Static Precautions

The circuit boards and other modules in the product are sensitive to and easily damaged by static electricity. If any card or sub-assembly is removed from the unit, the following anti-static precautions must be observed at all times:

- Service personnel must wear anti-static wrist straps.
- Circuit boards and sub-assemblies must be placed on ground conductive mats

or in conductive bags.

- All tools must be discharged to ground before use.
- The anti-static wrist strap and cord must be checked at regular intervals for their suitability for use.

Grounding

To comply with EN 60950, the equipment must be connected to a safety grounding point via a permanent link. Grounding points are located on the product for this purpose. Always connect the ground cable before fitting other cables. The product must remain grounded continuously unless all connections to the power supply and data network are all removed.

If equipment is grounded through a cabinet or rack, make sure it is done so properly according to the installation instructions.

Power Supply Connection

The equipment is designed to be powered from a -48 V DC supply. Power connections and installation of associated wiring must be carried out by a suitably qualified technician.

Only devices that comply with all relevant national safety requirements should be connected to the unit's power supply inlets. Other usage will invalidate any approval given to this equipment.

Connection of this equipment to devices that are not marked with all relevant national safety requirements may produce hazardous conditions on the network.

When the power supply is obtained by a rectifier/safety isolation transformer, the supply must meet the requirements of EN 60950 providing double/reinforced insulation between hazardous voltages and SELV/TNV circuits. Any battery must be separated from hazardous voltages by reinforced insulation.

Indirect Connection

Before indirectly connecting any equipment to another device through a shared power supply, ALWAYS seek advice from a competent engineer.

Devices that are not marked according to the relevant national safety standards may produce hazardous conditions on the network.

Product Disposal

To reduce the environmental impact of products, Samsung has joined WEEE compliance activities.

The WEEE symbol on the product indicates that the product is covered by the European Directive 2002/96/CE for the disposal of Waste Electrical and Electronic Equipment (WEEE). This means that the product should be disposed of separately from the municipal waste stream via designated collection facilities appointed by

the government or the local authorities. This will help prevent potential negative consequences for the environment and human health. Please check the terms and conditions of the purchase contract for information about correct disposal.

Battery Disposal

The product contains a battery on the processor card. The battery should not be disposed of with other household waste. Where marked, the chemical symbols Hg, Cd or Pb indicate that the battery contains mercury, cadmium or lead above the reference levels in EC Directive 2006/66. The battery incorporated in this product is not user replaceable. For information on its replacement, please contact your service provider. Do not attempt to remove the battery or dispose it in a fire. Do not disassemble, crush, or puncture the battery.

End of life recycling materials information is available from Samsung.

California USA Only

This Perchlorate warning applies only to primary CR (Manganese Dioxide) Lithium coin cells in the product sold or distributed ONLY in California USA

‘Perchlorate Material-special handling may apply, See www.dtsc.ca.gov/hazardouswaste/perchlorate.’

Antenna Gain

The antenna gain with a maximum of 19.7 dBi should be used to satisfy maximum ERP. But the antenna gain can be grown up to 22.7 dBi, when the operator is extending the coverage to the unserved area.

Equipment Markings



This marking on the product, accessories or literature indicates that the product and its electronic accessories (e.g. charger, headset, USB cable) should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.



Correct disposal of batteries in this product (Applicable in countries with separate collection systems.)

The marking on the battery, manual or packaging indicates that the battery in this product should not be disposed of with other household waste. Where marked, the chemical symbols Hg, Cd or Pb indicate that the battery contains mercury, cadmium or lead above the reference levels in EC Directive 2006/66.

The battery incorporated in this product is not user replaceable. For information on its replacement, please contact your service provider. Do not attempt to remove the battery or dispose it in a fire. Do not disassemble, crush, or puncture the battery. If you intend to discard the product, the waste collection site will take the appropriate measures for the recycling and treatment of the product, including the battery.



Protective earth

RRH should be grounded.

Chapter 1 Before Installation

System Configuration and Interface

RRH View

The view of RRH is as follows.

Figure 1. RRH View (without Finger Guard)






Figure 2. RRH View (with Finger Guard)



RRH External Interface

The external interface structure of RRH is as follows.

Figure 3. RRH External Interface



Specifications

The table below lists the main specifications of the RRH.

Table 1. Specifications

Item	RRH
Technology	3GPP Rel. 13
Duplex type	FDD
Operating Frequency	<ul style="list-style-type: none"> • Band66 (2,100 MHz) <ul style="list-style-type: none"> ○ DL: 2,110 to 2,180 MHz ○ UL: 1,710 to 1,780 MHz • Band2 (1,900 MHz) <ul style="list-style-type: none"> ○ DL: 1,930 to 1,990 MHz ○ UL: 1,850 to 1,910 MHz
Channel Bandwidth	5 MHz, 10 MHz, 15 MHz, 20 MHz 2Tx2Rx/2Tx4Rx/4Tx4Rx per RRH
Input Voltage	-48 V DC (-38~57 V DC)
Input Current (Max)	28 A
Dimension (in./mm)	<ul style="list-style-type: none"> • without Finger Guard: 14.96/380 (W) × 10.04/255 (D) × 14.96/380 (H) • with Finger Guard: 15.88/403.5 (W) × 11.93/303 (D) × 15.49/393.5 (H)
Weight (kg)	<ul style="list-style-type: none"> • Approx. 38.3 • With Finger Guard: 40.4
Operating Temperature (Ambient)	-40~55°C (without solar load)
Operating Humidity	5~100 % RH, condensing, not to exceed 30 g/m ³ absolute humidity
Altitude (m)	-60~1,800 (Telcordia GR-63-CORE)
Earthquake	Telcordia Earthquake Risk Zone4 (Telcordia GR-63-CORE)
Vibration	<ul style="list-style-type: none"> • Office Vibration (Section 4.4.4) • Transportation Vibration (Section 4.4.5)
Noise	Fanless (natural convection cooling)
EMC	FCC Title 47 CFR Part 15
Safety	UL 60950-1 2nd Ed.
RF	FCC Title 47 CFR Part 27

Cautions for Installation

Observe the following safety instructions when installing the system:
Installation shall be in accordance with the applicable local electric codes.

Before Installing

- Post warning signs in areas where high-voltage cables are installed.
- Post 'off limit' signs in areas where accidents are most expected.
- With guardrails or fences, block open areas such as connecting parts, roof, and scaffold.



Install the system in the Restrict Access Area.

While Installing

- The system power must be cut off before installing.
- Be careful not to damage or scratch the boards mounted on the system and the cables among the boards when the system is transported or installed.



Make sure the power switch of power supply is off when installing the system. Installing the system with power switch on may cause system damage or fatal human injury when cables are not correctly connected.



Make sure that worker wears protection gloves and goggles to prevent damage from debris while drilling holes in a wall or ceiling.



Do not wear accessories such as watches and rings in order to prevent electrical shock.



Never allow foreign substances to be inserted into unused ports by covering them with a cap.



To prevent foreign substances, outdoor air and moisture from entering the cable inlet (including cable gland and conduit), finish it as follows:

- Unused inlet

Use the hole finishing materials including cap and rubber packing.

- Cable-installed inlet

After cable installation, block any space in the inlet with tape, compressed sponge, rubber packing, and silicon.



Keep a safe distance between the base station antenna and people.

SRU	Safe Distance
RFV01U-D1A	1510 cm

After Installing

Remove any debris produced during the work and clean up the installation site.



In the system, the laser beam light runs through the optical cable. Handle the optical cables with care as the laser beam can seriously damage the worker's eyes.



Make sure that worker does not damage installed cables while cleaning the system.


























While cleaning the power supply device, take caution that the device does not come in contact with foreign objects that may cause power failure.








Installation Tools

The basic tools for installation are listed in the table below. The additional tools required for each site need to be identified and prepared during a site survey before starting installation.

Table 2. Basic Installation Tools

No.	Name	Specification	Purpose of use
1	 Torque Driver	Apply a torque range : 2~10 lbf·in	For fastening finger guard (M3)
		Apply a torque range : 20~90 lbf·in	For fastening RRH ground pressure terminal (M5, M6)
2	 Screw Driver Bit	'+', No. 2	For fastening finger guard (M3, M5)
		'+', No. 3	For fastening RRH ground pressure terminal (M6)
3	 Screw Driver	'+', No. 2	For loosening M3, M5 screw
		'+', No. 3	For loosening M6 screw
4	 Torque Wrench	Apply a torque range : 10~50 lbf·in	For tightening M6 Hex.Bolt and RF connector of system (4.3-10 Type)
		Apply a torque range : 100~400 lbf·in	For tightening M10 Hex.Bolt and RF connector of antenna (DIN Type)
5	 Torque Wrench Spanner Head	Apply Hex. Bolt Head: 10 mm (for 10~50 lbf·in)	For tightening M6 Hex.Bolt
		Apply Hex. Bolt Head: 17 mm (for 100~400 lbf·in)	For tightening M10 Hex.Bolt
		Apply Hex. Bolt Head: 22 mm (for 10~50 lbf·in)	For tightening RF connector of system (4.3-10 Type)
		Apply Hex. Bolt Head: 32 mm (for 100~400 lbf·in)	For tightening RF connector of antenna (DIN Type)
6	 Spanner	10 mm	For loosening M6 Hex.Bolt
		17 mm	For loosening M10 Hex.Bolt
		22 mm	For loosening RF connector of system (4.3-10 Type)
		32 mm	For loosening RF connector of antenna (DIN Type)
7	 Ratchet Wrench	10 × 13/17 × 19 (4 in 1)	For fastening Hex. Bolt
8	 Tape Measure	16 ft./150 ft.	Tape measure for length measurement
9	 Power Extension Cable	100 ft.	Basic tool

No.	Name	Specification	Purpose of use
10	Level 	Normal	For horizontality and verticality
11	Hammer Drill 	Normal	Wall Type Drilling
12	Concrete Drill Bit 	0.55 in. (14 mm)	For M10 Strong Anchor
13	Anchor Punch 	M10	For M10 Strong Anchor
14	Hammer 	Normal	Anchor fixing
15	Vacuum Cleaner 	Normal	For removing dust during the drilling work
16	Heating Gun 	122~572°F (50~300°C)	Shrinking Feeder cable tube
17	Cable Cutter 	0.24~1.26 in. (6~32 mm)	Cable cutting
18	Crimping Tool 	AWG14~AWG4 (1.5~16 mm ²)	Pressure terminal for crimping
19	Wire Stripper 	Apply cable thickness: 1.5~6.2 in. (4~16 mm)	Cable sheath for removal
20	Nipper 	Basic Tool	For cutting cable
21	LAN Tool 	Basic Tool	RJ45 Crimper
22	Industrial Scissor 	Basic Tool	Cutting
23	Knife 	Basic Tool	Cutting

No.	Name	Specification	Purpose of use
24	Optical Connector Cleaner 	For LC Connector	For Optical Connector Cleaning
25	Optical Transceiver Removal Tool 	Normal	Separate the Optical Module
26	Multi tester 	Digital Pocket Tester	The voltage and current measurements Whether measured cable disconnection
27	Fiber Optical Test Set 	Wave length: 1310 nm, 1550 nm (single mode) 850 nm, 1310 nm (multi mode)	Optical level check
28	Angle Meter 	Normal	Antenna angle measurement
29	Multi master (VSWR & RF Power) 	Normal	Feeder VSWR measurement
30	Compass 	Normal	Check azimuth during installation




The required installation tools may vary depending on the conditions at the site. In addition to the basic tools, a protractor, ladder, safety equipment, cleaning tools, and so on should also be prepared in consideration of the site conditions.

Chapter 2 Installing System

Installation Procedure

The procedure to install the RRH is as follows.

Figure 4. Procedure to Install the RRH



Make sure that the power switch of the power supply is OFF when installing the system. Installing the system with the power switch ON may cause system damage or fatal human injury when connecting or disconnecting the cables.



To prevent the risk of electrical shock do not wear accessories such as watches and rings.

System Arrangement

A minimum distance must be secured around the RRH, in each direction for installation and maintenance.

Figure 5. RRH Arrangement_1 Sector Pole Type Installation (Standard Installation)




Figure 6. RRH Arrangement_1 Sector Pole Type Installation (Side Installation)





Figure 7. RRH Arrangement_2 Sector Pole Type Installation (Side Installation)




When fixing a pole mounting bracket, the length of a carriage bolt is 220 mm for the pole diameter 50~100 A.

Pole Size (Diameter)	Length of Carriage Bolt
50 A (60.5 mm)	220 mm
65 A (76.3 mm)	
80 A (89.2 mm)	
90 A (101.6 mm)	
100 A (114.3 mm)	



[1 Sector]



[2 Sector]



When 2 sector pole type (side installation) is installed, it is recommended to install it to the pole of the 80 to 100 A specification.

Figure 8. RRH Arrangement_1 Sector Wall Type Installation (Standard Installation)




Figure 9. RRH Arrangement_1 Sector Wall Type Installation (Side Installation)




Figure 10. RRH Arrangement_3 Sector Wall Type Installation (Standard Installation)





Figure 11. RRH Arrangement_3 Sector Wall Type Installation (Side Installation)



Unpacking and Transporting

This paragraph describes the work to unpack cabinets and other components and transport them to the place to be installed.

Bringing in Items

Bring in items, taking care of the followings:

- When carrying a system, fasten the system firmly to the transport vehicle or carrier to prevent damage to the system for a vibration or shock.
- When carrying system, use a lift to prevent accidents. However, if the system must be carried by people, enough people are required to carry the system.
- Before moving the system, check the storage place for the system and remove obstacles in advance.
- While moving system, the system should not be shocked physically and damaged caused by dust, moisture, and static electricity.

Unpacking Items


The procedure to unpack items is as follows:

- The packing items must be packed until they reach the installation place.
- The items are classified in accordance with each job specification and stored on a place that does not interfere with working.
- Unpacked systems must be installed immediately. If not installed immediately, the systems must be stored in the installation place temporarily.
- Unpack only external packing, leaving the internal packing in unpacked status.
- Unpack the inner packaging after each system is placed on its installation location.
- Scrap by-products (packaging waste) in accordance with the rule. Do not recycle the by-products.


RRH Handling

When transporting an RRH, hold a handle at the top of the RRH. (No tool is needed for using the handle.)

Figure 12. RRH Handling



When lifting or putting down the RRH, two or more operators must hold handle and support bracket respectively. The corner of the RRH may be scratched if one operator holds and handles the handle.



Fixing RRH

Fixing Finger Guard

▶ To fix Finger Guard


- 1 Make sure you have the following items:

Table 3. Parts and Tools for fixing Finger Guard

Category	Description	
Parts	Finger Guard_Front	1 EA/RRH
	Finger Guard_Rear	1 EA/RRH
	Finger Guard_Bottom	1 EA/RRH
	Fastener	M3 × 10L Screw
M5 × 10L SEMS		12 EA/RRH
Recommended Torque Value	M3 Screw	5.6 lbf·in (6.4 kgf·cm)
	M5 SEMS	25 lbf·in (29 kgf·cm)
Working Tools	Torque Driver (2~10 lbf·in, 20~90 lbf·in), Screw Driver Bit ('+', No. 2), Screw Driver ('+', No. 2)	




Check the type and fixing location of Finger guard before fixing it.



[Finger Guard_Front]




[Finger Guard_Rear]



[Finger Guard_Bottom]


- 2 Place a finger guard_front to the RRH front.

Figure 13. Finger Guard Fixing (1)




3 Fix the finger guard_front using fasteners.

Figure 14. Finger Guard Fixing (2)




4 Place a finger guard_rear to the RRH rear.

Figure 15. Finger Guard Fixing (3)




5 Fix the finger guard_rear using fasteners.

Figure 16. Finger Guard Fixing (4)




6 Place a finger_guard_bottom to the RRH bottom.

Figure 17. Finger Guard Fixing (5)



7 Fix the finger_guard_bottom using fasteners.


Figure 18. Finger Guard Fixing (6)



Fixing Unit Bracket



There are two ways to fix a unit bracket to the RRH. One is fixing a unit mounting bracket to the rear side of RRH (Standard installation). The other is fixing a unit bracket to the side of RRH (Side installation). These are the same for the wall type and pole type installation procedures.



▶ To fix Unit Bracket_Standard Installation


- 1 Make sure that you have the following items:

Table 4. Parts and Tools for fixing Unit Bracket_Standard installation

Category	Description	
Parts	Unit bracket	1 EA/RRH
	Fasteners	M6 × 35L Hex. Bolt (washer assembly) 6 EA/RRH
Recommended Torque Value	M3 Screw	5.6 lbf·in (6.4 kgf·cm)
	M6 Hex. Bolt	43 lbf·in (50 kgf·cm)
Working Tools	Torque Wrench (10~50 lbf·in), Torque Wrench Spanner head (apply Hex. Head: 10 mm), Spanner (10 mm), Torque Driver (2~10 lbf·in), Screw Driver Bit ('+', No. 2), Screw Driver ('+', No. 2)	


- 2 Loosen a fastener of finger guard_rear and separate the dummy cover from it.

Figure 19. Fixing Unit Bracket_Standard Installation (1)




- 3 Place a dummy cover to the RRH left and fix it using fasteners.

Figure 20. Fixing Unit Bracket_Standard Installation (2)



- Place a unit bracket to the RRH rear and fix it using fasteners.

Figure 21. Fixing Unit Bracket_Standard Installation (3)



▶ To fix Unit Bracket_Side Installation


- Make sure that you have the following items:

Table 5. Parts and Tools for fixing Unit Bracket_Standard Installation

Category	Description		
Parts	Unit bracket		1 EA/RRH
	Fasteners	M6 × 35L Hex. Bolt (washer assembly)	6 EA/RRH
Recommended Torque Value	M6 × 20L Hex. Bolt		43 lbf-in (50 kgf-cm)
Working Tools	Torque Wrench (10~50 lbf-in), Torque Wrench Spanner head (apply Hex. Head: 10 mm), Spanner (10 mm)		

- Place a unit bracket to the RRH left and fix it using fasteners.

Figure 22. Fixing Unit Bracket_Side Installation



Fixing Pole Type


Assembling Mounting Bracket


▶ To assemble Mounting Bracket


- 1 Make sure you have the following items:

Table 6. Parts and Tools for assembling Mounting Bracket

Category	Description		
Parts	Mounting Bracket_Front		1 EA
	Mounting Bracket_Rear		1 EA
	Fasteners	M10 × 220L Carriage Bolt	4 EA
		M10 Plain Washer	4 EA
M10 Spring Washer		4 EA	
M10 Hex. Nut		4 EA	
Working Tools	Spanner (17 mm)		


 When fixing the mounting bracket, the specification of pole is from 50 A (2.38 in./60.5 mm) to 100 A (4.5 in./114.3 mm) and the specification of carriage bolt is M10 × 220L.

 When fixing pole, fix it using the outside hole of mounting bracket_front.




2 Insert carriage bolts to the outside hole of mounting bracket_front.

Figure 23. Assembling Mounting Bracket (1)



3 Pass the carriage bolt through the side closed hole of the mounting bracket_rear, fix the fastening material, and fasten the other carriage bolt to the mounting bracket_front only.

Figure 24. Assembling Mounting Bracket (2)




Lifting RRH & Mounting Bracket Assembly

▶ To lift RRH/Mounting Bracket Assembly


- 1 Tie the rope in two carrying points of RRH and Mounting bracket assembly.

Figure 25. Lifting RRH & Mounting Bracket Assembly



- 2 While Operator A hauls the rope to carry up the RRH/mounting bracket assembly, Operator B pulls the rope outward so that RRH/mounting bracket assembly would not hit the tower platform.

Figure 26. Lifting RRH & Mounting Bracket Assembly



Fixing Mounting Bracket Assembly

For 1 Sector

The way to fix 1 Sector mounting bracket assembly is as follows:

▶ To fix Mounting Bracket Assembly_1 Sector Pole Type


- 1 Make sure you have the following items:

Table 7. Parts and Tools for fixing Mounting Bracket Assembly_1 Sector Pole Type

Category	Description	
Parts	1 Sector Mounting Bracket Assembly	1 Set
Recommended Torque Value	M10 Hex. Nut	217 lbf-in (250 kgf·cm)
Working Tools	Torque Wrench (100~400 lbf-in), Torque Wrench Spanner head (apply Hex. Head: 17 mm), Spanner (17 mm), Level	


- 2 Place a mounting bracket assembly to the pole.

Figure 27. Fixing Mounting Bracket Assembly_1 Sector Pole Type (1)




- 3** Locate the upper carriage bolt in the upper side hole of the mounting bracket_rear and fix the fastening materials temporarily on upper side.

Figure 28. Fixing Mounting Bracket Assembly_1 Sector Pole Type (2)




- 4** Locate the lower carriage bolt in the lower side hole of the mounting bracket_rear and fix the all fastening materials.

Figure 29. Fixing Mounting Bracket Assembly_1 Sector Pole Type (3)



- 5 Check the level of mounting bracket assembly on a pole and adjust the level.

Figure 30. Levelling Mounting Bracket Assembly_1 Sector Pole Type



When fixing the pole mounting bracket assembly on a pole, be sure to check the level of bracket. After finishing the installation, you can adjust the level minutely.



When occurring poor levelling, adjust the position of fasteners used to fix the Mounting bracket assembly or its levelling status.

For 2 Sector

The way to fix 2 Sector mounting bracket assembly is as follows:

▶ To fix Mounting Bracket Assembly_2 Sector Pole Type (Side Installation)

- 1 Make sure you have the following items:


Table 8. Parts and Tools for fixing Mounting Bracket Assembly_2 Sector Pole Type (Side Installation)

Category	Description	
Parts	1 Sector Mounting Bracket Assembly	
	1 Set	
	Extension Mounting Bracket	
Fastener	M10 × 25L Hex. Bolt (washer assembly)	2 EA
	2 EA	
Recommended Torque Value	M10 Hex. Bolt/Nut	217 lbf-in (250 kgf·cm)
Working Tools	Torque Wrench (100~400 lbf-in), Torque Wrench Spanner head (apply Hex. Head: 17 mm), Spanner (17 mm), Level	

- 2 Fix 1 sector mounting bracket assembly to the pole. (Refer to 'For 1 Sector')

Figure 31. Fixing Mounting Bracket Assembly_2 Sector Pole Type (Side Installation 1)


- 3 Fit the Extension mounting bracket's groove into the mounting bracket_front's right hook, fix it using fasteners.

Figure 32. Fixing Mounting Bracket Assembly_2 Sector Pole Type (Side Installation 2)

- 4 Fit the Extension mounting bracket's groove into the mounting bracket_front's

left hook, fix it using fasteners.

Figure 33. Fixing Mounting Bracket Assembly_2 Sector Pole Type (Side Installation 3)



Fixing RRH

For 1 Sector

The way to fix 1 sector RRH is as follows:

▶ To fix RRH_1 Sector Pole Type (Standard & Side Installation)

- 1 Make sure you have the following items:

Table 9. Fixing RRH_1 Sector Pole Type (Standard & Side Installation)

Category	Description	
Parts	M10 × 35L Hex. Bolt (washer assembly, attached to the unit bracket)	1 EA
Recommended Torque Value	M10 Hex. Bolt	217 lbf·in (250 kgf·cm)
Working Tools	Torque Wrench (100~400 lbf·in), Torque Wrench Spanner head (apply Hex. Head: 17 mm), Spanner (17 mm)	

- 2 Hang the unit bracket hook of RRH side on the mounting bracket_front hook's groove and fix it using fasteners.

Figure 34. Fixing RRH_1 Sector Pole Type (Standard Installation)





Figure 35. Fixing RRH_1 Sector Pole Type (Side Installation)

**For 2 Sector**

The way to fix 2 sector RRH is as follows:

▶ To fix RRH_2 Sector Pole Type (Side Installation)

- 1 Make sure you have the following items:

Table 10. Parts and Tools for fixing RRH_2 Sector Pole Type (Side Installation)


Category	Description	
Parts	M10 × 35L Hex. Bolt (washer assembly, attached to the unit bracket)	1 EA/RRH
Recommended Torque Value	M10 Hex. Bolt	217 lbf-in (250 kgf·cm)
Working Tools	Torque Wrench (100~400 lbf-in), Torque Wrench Spanner head (apply Hex. Head: 17 mm), Spanner (17 mm)	



Check the location to install the RRH.




Fix the RRH according to the order of [RRH-0 → RRH-1].




- 2 Hang the unit bracket hook of RRH-0 side on the mounting bracket_front hook's groove and fix it using fasteners.

Figure 36. Fixing RRH_2 Sector Pole Type (Side Installation 1)



3 Fix RRH-1 in the same way as the RRH-0.

Figure 37. Fixing RRH_2 Sector Pole Type (Side Installation 2)



Fixing Wall Type

Marking and Drilling for Wall Mounting

▶ To mark on a wall

1 Make sure you have the following items:

Table 11. Tools for Marking

Category	Description
Working Tools	Tape Measure, Permanent Marker, Level



To mount the system on a wall, perform the leveling test by referring to System Leveling to check the positions are marked to be horizontal or vertical before drilling. If the result shows they are not horizontal or vertical, modify the marking positions.



When the position where the system will be placed is determined, place the system on that position and then mark the positions where anchor bolts will be fixed. This will reduce marking error range.

- 2 Check the distance between the location for fixing the RRH and anchor bolt hole.

Figure 38. RRH marking dimensions_1 Sector Wall Type (Standard Installation)




Figure 39. RRH marking dimensions_1 Sector Wall Type (Side Installation)




Figure 40. RRH marking dimensions_3 Sector Wall Type (Standard Installation)






Figure 41. RRH marking dimensions_3 Sector Wall Type (Side Installation)



- 3 Place a mounting bracket on the fixing location, Check the level status using a level and adjust the level of bracket assembly.
- 4 If the level status is normal, mark the anchor bolt holes on a wall.

Figure 42. *Marking_Wall Type*



▶ To drill anchor holes and fix anchors


- 1 Make sure you have the following items:

Table 12. *Parts and Tools for Drilling & Anchoring*

Category	Description		
Parts	1, 3 Sector Installation	M10 Strong Anchor	4 EA/RRH
Working Tools	Hammer Drill, Concrete Drill Bit [0.55 in. (14 mm)], Vacuum Cleaner, Hammer, Anchor Punch (For M10 Strong Anchor)		


Table 13. Anchor Bolt Drill Bits and Hole Depth

Category	Anchor Bolt	Drill Bits	Hole Depth
RRH (Wall Type)	M10	0.55 in. (14 mm)	1.73 in. (44 mm)




- 2 Drill anchor holes at marked points with removing dust from the holes using a cleaner. Fix strong anchor to the drilled hole.

Figure 43. Drilling & Anchoring



When fixing the mounting bracket_front or 2 sector mounting bracket assembly_front on a wall, 'A' side should stick on the wall.



For 1 Sector

The way to fix 1 sector mounting bracket is as follows:

▶ To fix Mounting Bracket_1 Sector Wall Type


- 1 Make sure you have the following items:

Table 14. Parts and Tools for fixing Mounting Bracket_1 Sector Wall Type

Category	Description		
Parts	Mounting Bracket_Front		1 EA
	Fastener	M10 Plain Washer	4 EA
		M10 Spring Washer	4 EA
		M10 × 70L Hex. Bolt	4 EA
Recommended Torque Value	M10 Hex. Bolt	217 lbf·in (250 kgf·cm)	
Working Tools	Torque Wrench (100~400 lbf·in), Torque Wrench Spanner head (apply Hex. Head: 17 mm), Spanner (17 mm)		

- 2 Place the mounting bracket_front along with the fixed strong anchors and fix it using fasteners.

Figure 44. Fixing Mounting Bracket_1 Sector Wall Type

**For 3 Sector**

The way to fix 3 sector mounting bracket is as follows:

▶ To fix Mounting Bracket_3 Sector Wall Type

- 1 Make sure you have the following items:


Table 15. Parts and Tools for fixing Mounting Bracket_3 Sector Wall Type

Category	Description	
Parts	Mounting Bracket_Front	1 EA/RRH

Category	Description		
	Fastener	M10 Plain Washer M10 Spring Washer M10 × 70L Hex. Bolt	4 EA/RRH 4 EA/RRH 4 EA/RRH
Recommended Torque Value	M10 Hex. Bolt		217 lbf-in (250 kgf-cm)
Working Tools	Torque Wrench (100~400 lbf-in), Torque Wrench Spanner head (apply Hex. Head: 17 mm), Spanner (17 mm)		

- Place the mounting bracket_front along with the fixed strong anchors and fix it using fasteners.

Figure 45. Fixing Mounting Bracket_3 Sector Wall Type



Fixing RRH

For 1 Sector

The way to fix 1 sector RRH is as follows:

▶ To fix RRH_1 Sector Wall Type (Standard & Side Installation)

- Make sure you have the following items:

Table 16. Parts and Tools for fixing RRH_1 Sector Wall Type (Standard & Side Installation)

Category	Description	
Parts	M10 × 35L Hex. Bolt (washer assembly, attached to the unit bracket)	1 EA
Recommended Torque Value	M10 Hex. Bolt	217 lbf·in (250 kgf·cm)
Working Tools	Torque Wrench (100~400 lbf·in), Torque Wrench Spanner head (apply Hex. Head: 17 mm), Spanner (17 mm)	

- 2 Hang the unit bracket hook of RRH side on the mounting bracket_front hook's groove and fix it using fasteners.



Figure 46. Fixing RRH_1 Sector Wall Type (Standard Installation)

Figure 47. Fixing RRH_1 Sector Wall Type (Side Installation)



For 3 Sector

The way to fix 3 sector RRH is as follows:

▶ To fix RRH_3 Sector Wall Type (Standard Installation)

- 1 Make sure you have the following items:

Table 17. Parts and Tools for fixing RRH_3 Sector Wall Type (Standard Installation)

Category	Description	
Parts	M10 × 35L Hex. Bolt(washer assembly, attached to the unit bracket)	1 EA/RRH
Recommended Torque Value	M10 Hex. Bolt	217 lbf·in (250 kgf·cm)
Working Tools	Torque Wrench (100~400 lbf·in), Torque Wrench Spanner head (apply Hex. Head: 17 mm), Spanner (17 mm)	



Check the location to install the RRH.