

features of your new MP3 Player

Good looking. Smart. Reliable. And lots of fun. Your new MP3 player is all this and more. Its compact silhouette takes up the tiniest space in your pocket, and its state-of-the-art technology delivers rich sound, and vibrant pictures. You'll love your new MP3 player, whether you're exercising, downloading your favorite tunes, watching videos, or even listening to FM Radio. Use it once, and you'll wonder how you ever lived without it.

PUTTING THE "MULTI" IN MULTIMEDIA

We call it an MP3 player, but it's much more than that. It allows you to view pictures, text, and videos, listen to FM radio.

And Bluetooth wireless technology turns your MP3 player into your own personal network.

TOUCH NAVIGATION!

You can tap on the touch screen to navigate through the menus.

COLOR LCD SCREEN DESIGN

It delivers vivid color and images with an wide LCD screen.

WHERE FORM MEETS FUNCTION

Sure, it's sleek and good-looking. But it's easy to hold and use, too.

EASY SEARCH!

You can search for files with the easy-to-use File Brower, and also navigate through menus while listening to music.

LONGER PLAY TIME AND SHORTER DOWNLOADING!

A fully charged battery can play up to 15 hours of music and 5 hours of video.

Download times are shorter. Because of its USB 2.0 capability, the player is much faster than models with USB 1.1.

ACOUSTIC WONDER











Your new MP3 player has built-in DNSe (Digital Natural Sound engine), Samsung's™ unique sound technology created to deliver richer, deeper sound for an unbelievable listening experience.

DATACAST

Using <Media Studio>, you can transfer multimedia sources including news, blogs and UCC registered on RSS to the player for your entertainment.

safety information

What the icons and signs in this user manual mean :

 WARNING	Means that death or serious personal injury is a risk.
 CAUTION	Means that there is a potential risk for personal injury or material damage.
 CAUTION	To reduce the risk of fire, explosion, electric shock, or personal injury when using your MP3 Player, follow these basic safety precautions:
 NOTE	Means hints or referential pages that may be helpful to operate the player.
	Do NOT attempt.
	Do NOT disassemble.
	Do NOT touch.
	Follow directions explicitly.
	Unplug the power plug from the wall socket.
	Call the service center for help.

These warning signs are here to prevent injury to you and others.
Please follow them explicitly.
After reading this section, keep it in a safe place for future reference.

safety information

This manual describes how to properly use your new mp3 player. Read it carefully to avoid damaging the player and injuring yourself. Pay particular attention to the following serious warnings:

PROTECT YOURSELF



- Do not disassemble, repair, or modify this product on your own.



- Do not get the product wet or drop it in water. If the product gets wet, do not switch it on because you could get an electric shock. Instead, contact a Samsung Customer Service Center near you.



- Do not use the earphone while you are driving a bicycle, automobile or motorcycle. Otherwise it can cause a serious accident and, furthermore, it is prohibited by the law in some areas. Using the earphone while walking or jogging on a road, in particular, on a crosswalk can lead to a serious accident.
- For your safety, make sure the earphone cable does not get in the way of your arm or other surrounding objects while you are taking exercise or a walk.



- Do not place the product in damp, dusty, or sooty areas because these environments could lead to fire or electric shock.

PROTECT YOURSELF



- Using the earphone or headphone for an extended time can cause serious damage to your hearing.
If you are exposed to sound louder than 85db for an extended time, you may adversely affect your hearing. The louder the sound is, the more seriously damaged your hearing may be (an ordinary conversation is between 50 to 60db and road noise is approximately 80db). You are strongly advised to set the volume level to medium (the medium level is usually less than 2/3 of the maximum).
- If you feel a ringing in the ear(s), lower the volume or stop using the earphone or headphone.

PROTECT YOUR MP3 PLAYER



- Do not leave the player in temperatures above 95°F (35°C), such as a sauna or a parked car.
- Do not cause excessive impact on the player by dropping it.
- Do not place heavy objects on top of the player.
- Prevent any foreign particles or dust from entering into the product.
- Do not place the product near magnetic objects.



- Be sure to backup important data. Samsung is not responsible for data loss.
- Use only accessories provided by or approved by Samsung.



- Do not spray water on the product. Never clean the product with chemical substances such as benzene or thinner, as it may cause fire, electric shock or deteriorate the surface.



- Failure to follow these instructions may lead to physical injuries or damage to the player.



- When printing this user manual, we recommend that you print in color and check "Fit to Page" in the print option for better viewing.

SAFETY INFORMATION

FCC

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Any changes or modifications in construction of this device which are not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

SAFETY INFORMATION (Continued)

FCC

Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the device.

Compliance

This product conforms to the following.

Council Directive: Directive 89/336/EEC, 92/31/EEC (EMC)

Declaration of Conformity

Name: Samsung Electronics Co., Ltd

Address: 416, Maetan-3Dong, Yeongtong-Gu, Suwon City, Kyungki-Do, Korea
442-742 declares under its sole responsibility that the product

Trade Name: Samsung Electronics Co., Ltd

Model Number: YP-P2 has been tested according to the FCC/CISPR22/95 requirements for Class B devices and found compliant with the following standards:

EMI/EMC: FCC Part 15 Subpart B

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesirable operation.

Party Responsible for Product Compliance

Samsung Electronics America

QA Lab.

3351 Michelson Dr. Suite #290

Irvine, CA92612

contents

THE BASICS

9

- 9 What's included
- 9 Using the cable winder
- 10 Your MP3 Player
- 13 Screen displays
- 14 Using the touch button
- 14 Using the clip
- 15 Charging the battery
- 16 Caring for the battery
- 16 Turning the Power on & off
- 17 Playing music
- 18 Controlling the volume
- 18 Disabling the buttons
- 19 Changing the settings and preferences
 - 19 Music preferences
 - 21 FM Radio preferences
 - 24 Time preferences
 - 25 Language preferences
 - 27 System preferences
- 30 Resetting the system

SAMSUNG MEDIA STUDIO

31

- 31 PC requirements
- 32 Installing Samsung Media Studio
- 33 Organizing folders and files using Samsung Media Studio
 - 35 To add folders
 - 35 To add files
- 36 Transferring files to the Player with Samsung Media Studio

contents

LISTENING TO MUSIC

38

- 38 **Listening by category**
- 39 **Pausing**
- 39 **Searching within a track**
- 39 **Playing from the beginning of the current track**
- 39 **Playing the previous or next track**
- 40 **To search a music file**
- 40 **To switch back to the current play screen**
- 41 **Creating an album (playlist) using Samsung Media Studio**
- 42 **Adding music files to an album (playlist) you've created**
- 43 **Transferring an album (playlist) to your player using Media Studio**
- 44 **Playing a playlist**
- 45 **User button custom function**
- 45 **To set user button mode**

contents

MORE THAN MUSIC

48

- 48 Listening to FM Radio**
- 49 To search for FM stations
- 50 To store stations in the preset memory
- 50 To listen to preset stations
- 51 To delete a preset
- 52 Voice Recording**
- 53 To stop recording
- 54 Recorded file names
- 54 To listen to a previously recorded file

UPGRADING FIRMWARE

55

- 55 Upgrading firmware**

TROUBLESHOOTING

57

- 57 Troubleshooting**

APPENDIX

60

- 60 Menu Tree**
- 61 Product Specifications**
- 62 License**
- 63 Warranty**

the basics

WHAT'S INCLUDED

Your new mp3 player comes with these accessories. If you're missing any of these items, contact Samsung Customer Service at 1-800-SAMSUNG (1-800-726-7864).




Player




Earphones

AH30-00087D



USB Cable

AH39-00899A



Installation CD


AH80-00138A




NOTE

▪ Please note that you cannot be serviced by Samsung Customer service for separately purchased or gift accessories.

YOUR MP3 PLAYER




YOUR MP3 PLAYER (Continued)



SCREEN DISPLAYS

Video



1	Bluetooth/Lock/Alarm Indicator	7	Play/Pause, Search Indicator
2	Battery Status	8	Video Mode Indicator
3	Current Time	9	Play Status Bar
4	Current /Total Play Time	10	Back Icon
5	File Name	11	Menu Icon
6	Play/Pause, Search Icon		




NOTE

- The screen pictures are for illustration purposes only. The actual screen may differ.
- Information and icon on the current video playback will disappear in a certain time. Tap on the screen if you want to display the video playback information and icon again.

SCREEN DISPLAYS (Continued)


Music



1	Bluetooth/Lock/Alarm Indicator
2	Current Time
3	Battery Status
4	Current track playing / Total number of tracks Indicator
5	Music Play Screen
6	Play Status Bar
7	Current /Total Play Time
8	Play/Pause, Search Icon
9	DNSe Icon
10	Play/Pause, Search Indicator
11	Music Mode Indicator
12	Parent Folder Indicator
13	Music Title
14	DNSe Indicator
15	Play Mode Indicator
16	Back Icon
17	Menu Icon

SCREEN DISPLAYS (Continued)

Picture




1	Bluetooth/Lock/Alarm Indicator
2	Current Time
3	Battery Status
4	Current file / Total number of files Indicator
5	Next Image Icon
6	Zoom Icon
7	Music Play Status
8	Picture Mode Indicator
9	File Name
10	Previous Image Icon
11	Back Icon
12	Menu Icon



- Information and icon on the current picture viewing will disappear in a certain time. Tap on the screen if you want to display the picture information and icon again,
- The Previous/Next Image [◀, ▶] icon appears if you tap on the screen once. Tapping it again will display both picture information and icon.


SCREEN DISPLAYS (Continued)

FM Radio



USING THE TOUCH SCREEN

Tap on touch screen with your fingertip.



- NOTE**
- To avoid damage to the touch screen, do not use any object other than your fingers to operate the touch screen.
 - Do not tap on the touch screen if your fingers are not clean.
 - Do not tap on the touch screen with gloves on. Otherwise, the touch screen does not operate in any way.
 - The touch screen may not function if you use a fingernail or other instruments such as a ballpoint pen.

USING THE TOUCH SCREEN (Continued)


You can tap on the screen in four directions – up, down, left and right, according to the function.

ex. Play status bar for music

How To 1


Press and briefly hold the Play status bar on the screen and move to a desired point before releasing it.

- The player resumes playing at the point of release.



How To 2

Tap on a desired point in the play status bar.





USING THE TOUCH SCREEN (Continued)

ex. Zoomed image

How To 3

Press and briefly hold the screen and move in a desired direction before releasing it.

- In zoom mode, move your finger in a desired direction and release it as if you snap it. The picture moves and appears in that direction.





USING THE TOUCH SCREEN (Continued)

ex. Play the previous/next video file

How To 3

Tap on the screen left or right as if you keep flipping it.
(It is similar to flipping pages of a book.)


- Left : Moves to the next according to the horizontal stroke setting.
- Right : Moves to the previous according to the horizontal stroke setting.



CHARGING THE BATTERY

Charge it before using the player for the first time and when you haven't used it for a long time.

The battery for your mp3 player will fully charge in about 4 hours, although total charging time varies depending on your PC environment.



1. Connect the other (larger) end of the USB cable to the USB Connection Port on the bottom of the player.
2. Connect the USB cable to the USB port (↔) on your PC.
 - The Power LED is lit in red while the battery is being charged. When done, it turns green.

CARING FOR THE BATTERY

Your battery will last longer if you follow these simple guidelines for caring for and storing it.

- Recharge and store the battery within the temperature range of 40°F~95°F (5°C~35°C).
- Do not overcharge (longer than 12 hours). Excessive charging or discharging may shorten the battery's life.
- Battery life naturally shortens slowly over time.




NOTE

- If you are charging the player while it is connected to a laptop computer, make sure the laptop's battery is also fully charged or that the laptop is plugged into its power source.
- The battery is not charged in the PC Standby mode or when the hardware is safely removed.


TURNING THE POWER ON & OFF

Turning the Power on

Press and briefly hold the  button.

- Power is turned on.

Turning the Power off


Press and briefly hold the  button.

- Power is turned off.




NOTE


- Your mp3 player will be automatically turned off when none of the buttons and icons have been pressed for a specific length of time in the pause mode. The factory setting for **<Auto Power Off>** is 1 minute, but you can change this length of time. See [page 35](#) for more information.



PLAYING A VIDEO FILE

Load video files onto your new mp3 player using Samsung Media Studio. Learn more about Media Studio on [page 39](#).

1. Tap the  icon on the main menu screen.
 - The video list appears.
2. Tap on the video file twice you want to play.
 - The selected video file horizontally starts to play.







-  **NOTE** Tap the [↩] icon to move to the previous screen. Press and briefly hold the [↩] icon to move to the main menu screen.

CONTROLLING THE VOLUME

You can adjust the volume while a file is stopped or in its playback.

How To 1

Press the ,  button.

- The volume control bar appears. The range of volume is set between 0 to 30.
- Press the  button to increase the volume or the  button to decrease it.





How To 2

Tap on the middle right of the screen upward or downward as if you keep snapping it.

- The volume control bar appears.
- Tapping on upward will increase the volume while tapping on downward will decrease it.

DISABLING THE BUTTONS


The hold function disables all the other buttons and icons on the mp3 player, so that if you accidentally bump one-while working out, for example-your music won't be interrupted.


1. Push the  switch in the direction of the arrow.
2. Push the  switch in the opposite direction of the arrow to release the hold function.



BROWSING FOR FILES USING “File Browser”

Search easily for files using the “File Browser” function.

1. Tap on the  icon on the main menu screen.
 - The <File Browser> folder list containing “Datacasts, Music, Pictures, Playlists, Texts and Video” appears.
2. Tap on a desired folder to bring up the file list.
 - Tap on the [↔] icon to move to the previous screen.
3. Tap on a desired file twice.
 - The file will start playing.



CHANGING THE SETTINGS AND PREFERENCES


Your mp3 player comes with settings and preferences that were set up at the factory, but you can change these pre-set values to truly customize your player.




- Tap the [↔] icon to move to the previous screen.
- Press and briefly hold the [↔] icon to move to the main menu screen.

Menu Style Settings

You can change the menu design and font and delete background image of the main menu.

1. Tap the  icon on the main menu screen.
 - The <Settings> menu appears.
2. Tap <Menu Style> twice.
 - The <Menu Style> menu appears.
3. Tap on a desired menu.
4. Set the options you prefer and tap <OK>.



Menu Style Setting Options

- **Menu Design** : You can change the style of the main menu screen. Select from <Cosmos>, <Matrix> and <My Skin>.
- **Font** : You can change the font type of the menu language. Select one from 3 font types.
- **Reset My Skin** : Initializes the background image of the touch screen to its default image..




- If the <Settings> screen is open and you don't push any buttons for about 1 minute, the unsaved settings will be lost, and the player will return to the previous function.

CHANGING THE SETTINGS AND PREFERENCES (Continued)

Using the Cosmos Menu


How To 1

Position your finger on a blank space and tap on the screen upward or downward as if you flipping it. Tap on a desired icon of the main menu.



How To 2


Position your finger on a blank space and circle around slowly. Tap on a desired icon of the main menu.



CHANGING THE SETTINGS AND PREFERENCES (Continued)


Using the Matrix Menu

Tap on a desired icon of the main menu.



Using the My Skin Menu


Tap on the touch screen and scroll left or right by moving your fingertip to locate the desired main menu. Tap on a desired icon of the main menu.



CHANGING THE SETTINGS AND PREFERENCES (Continued)



Sound Settings

You can set the master EQ, beep sound, volume limit.

1. Tap the  icon on the main menu screen.
 - The <Settings> menu appears.
2. Tap <Sound> twice.
 - The <Sound> menu appears.
3. Tap on a desired menu.
4. Set the options you prefer and tap <OK>.




Sound Setting Options

- **Master EQ** : You can optimize sound settings to your earphone.
Tap the [] icon to select the frequency you want to adjust. Tap the [] icon to adjust the selected frequency's level and tap <OK>.
 - **Beep Sound** : Sets the beep sound for touch screen operations to on or off.
Select from <Off> and <On>.
 - **Volume Limit** : You can avoid hearing damage by setting the limit of the volume when using the earphone. <On> will limit the maximum volume level up to 15. The maximum volume level when volume limit is set to <Off> is 30.
-

CHANGING THE SETTINGS AND PREFERENCES (Continued)


Display Settings

Change the display off time and brightness of your screen.

1. Tap the  icon on the main menu screen.
 - The <Settings> menu appears.
2. Tap <Display> twice.
 - The <Display> menu appears.
3. Tap on a desired menu.
4. Set the options you prefer and tap <OK>.




Display Setting Options

- **Display Off** : If no button and icon are tapped within the time set shown below, the touch screen will be automatically turned off. Select from <15sec>, <30sec>, <1min>, <3min>, <5min> and <Always On>. Press any button to turn it back on. However, when the HOLD condition, slide the  switch in the opposite direction of the arrow to release the lock.
 - **Brightness** : You can adjust the brightness of the screen. Select a level from "0-10", where 10 is the brightest.
-

CHANGING THE SETTINGS AND PREFERENCES (Continued)

Language Settings

The menus on your new mp3 player can appear in any one of multiple languages. You can change your preference language easily.

1. Tap the  **icon** on the main menu screen.
 - The <Settings> menu appears.
2. Tap **<Language>** twice.
 - The <Language> menu appears.
3. Tap on a desired menu.
4. Set the options you prefer and tap **<OK>**.



CHANGING THE SETTINGS AND PREFERENCES (Continued)

Language Setting Options

- **Menu** : Set the menu language. Tap the [▲ , ▼] icon to move to the next page. Select from <English>, <汉语 (简体)>, <漢語 (繁體)>, <Français>, <Deutsch>, <Italiano>, <日本語>, <Español>, <Русский>, <Magyar>, <Nederlands>, <Polski>, <Português>, <Svenska>, <ไทย>, <Čeština>, <Ελληνικά>, <Türkçe>, <Norsk>, <Dansk>, <suomi>, <Español (Sudamérica)>, <Português (Brasil)>, <Indonesia>, <Tiếng Việt>, <Bulgarian>, <Romani>, <Українська>, <Slovenščina> or <Slovenský>.
 - **Contents** : Set the language in which the track information will appear. Tap the [▲ , ▼] icon to move to the next page. Select from <Afrikaans>, <Basque>, <Catalan>, <Chinese (S)>, <Chinese(T)>, <Czech>, <Danish>, <Dutch>, <English>, <Estonian>, <Finnish>, <French>, <German>, <Greek>, <Hrvatski>, <Hungarian>, <Icelandic>, <Italian>, <Japanese>, <Korean>, <Norwegian>, <Polish>, <Portuguese>, <Romany>, <Russian>, <Slovak>, <Slovene>, <Spanish>, <Swedish>, <Turkish>, <Vietnamese>, <Thai>, <Indonesian>, <Ukrainian>, <Bulgarian> or <Romanian>.
-



- The supported languages can be changed or added.


NOTE ▪ **What is Contents?**


This is what is attached to an MP3 to carry information relevant to the file, such as the title, artist, album, year, genre and a comment field.

CHANGING THE SETTINGS AND PREFERENCES (Continued)

Time Settings

Setting the time allows you to use the date/time set, date type and even time zone.

1. Tap the  icon on the main menu screen.
 - The <Settings> menu appears.
2. Tap <Time> twice.
 - The <Time> menu appears.
3. Tap on a desired menu.
4. Set the options you prefer and tap <OK>.




Time Setting Options


- **Date/Time Set** : Set the current date and time. Tap the [^, v] icon to set each item of <Year>, <Month>, <Day>, <Hour>, <Min> and <AM/PM>.
 - **Date Type** : You can set the time display type for the world clock. Select from <YY-MM-DD>, <MM-DD-YY> and <DD-MM-YY>.
 - **Time Zone** : You can change the current time by selecting an international city specific time zone. You must set the time zone before you can display the world time information ► page 87
-

CHANGING THE SETTINGS AND PREFERENCES (Continued)

System Settings

Choose the sleep timer, start mode, auto power off, default set that's right for you.

1. Tap the  icon on the main menu screen.
 - The <Settings> menu appears.
2. Tap **<System>** twice.
 - The <System> menu appears.
3. Tap on a desired menu.
4. Set the options you prefer and tap **<OK>**.



CHANGING THE SETTINGS AND PREFERENCES (Continued)

System Setting Options

- **Sleep** : Turns off power automatically after the preset time. Select either **<Off>**, **<15min>**, **<30min>**, **<60min>**, **<90min>**, or **<120min>**.
- **Start Mode** : You can set the start screen displayed when you turn on the player. Select from **<Home>** and **<Last State>**. Select **<Home>** to start the system with the main menu screen while **<Last State>** will use the last used screen.
- **Auto Power Off** : Automatically turns power off when there is no button operation after the preset time in the pause mode. Select either **<15sec>**, **<30sec>**, **<1min>**, **<3min>**, **<5min>** or **<Always On>**.
- **<Library Update>** : Be sure to update your library once you transferred the file to the removable disk.
Otherwise, transferred files can be found only in **<File Browser>** and those files will not be listed in **<Music>** and **<Pictures>** of the main menu. Tap **<Yes>** to update the library.
- **Default Set** : Returns all settings to the default value. Select either **<YES>** or **<NO>**. **<YES>** initializes all settings to default. **<NO>** cancels default settings.
- **Format** : Formats the internal memory. Select either **<YES>** or **<NO>**. Selecting **<YES>** will format the internal memory and delete all files on the player. Selecting **<NO>** does not format the internal memory. Check before formatting it.
- **About** : Checks the firmware version and memory capacity.
 - **Firmware** - Displays the current firmware version.
 - **Memory** - Indicates the remaining memory capacity. "Used" indicates the usage, "Remaining" indicates the remaining capacity and "Total" indicates the total memory capacity.




NOTE Regarding the Built-In Memory

1GB=1,000,000,000 bytes : actual formatted capacity may be less as the internal firmware uses a portion of the memory.

RESETTING THE SYSTEM

If your mp3 player won't turn on, won't play music, or isn't recognized by your computer when you connect it, you may have to reset the system.



Press the Reset hole at the rear of the player with a pointed object such as a safety clip.

- The system will be initialized.
- Your settings and files will not be affected.

Samsung Media Studio

Samsung Media Studio is the easy-to-use software application that helps you organize your files on your PC. With your files already sorted and organized in Media Studio, you can quickly transfer them to your mp3 without searching your entire hard drive for the right file.

PC REQUIREMENTS


Your PC system must meet the following minimum specifications in order to install and run Media Studio:


- Pentium 300MHz or higher
- USB Port 2.0
- **Windows XP Service Pack 2 or higher**
- DirectX 9.0 or higher
- 100MB of free hard disc space
- CD Rom Drive (2X or higher)
- **Windows Media Player 10.0 or higher**
- Resolution 1024 X 768 or higher
- Internet Explorer 6.0 or higher

INSTALLING SAMSUNG MEDIA STUDIO




- Ensure that you run the <Media Studio> installer in your PC's administrator account. Otherwise, <Media Studio> will not be installed. To find the administrator account, please refer to your PC's user manual.


1. Insert the Installation CD provided with the player into the CD-ROM drive.
2. Click <Install Now>.
3. Click <Next>.
 - <Media Studio> installation starts and then creates an  icon on your desktop when installation is complete.



TRANSFERRING FILES TO THE PLAYER WITH SAMSUNG MEDIA STUDIO

<Media Studio> enables you to select and organize files and folders before transferring them to your player. This will make scanning files on your mp3 player easier and faster. <Media Studio> file transfer is the easiest way to get files from your PC to your mp3 player.



1. Connect the other (larger) end of the USB cable to the USB Connection Port on the bottom of the player.
2. Connect the USB cable to the USB port (↔) on your PC.
 - <USB Connected> appears on the touch screen of the player.
 - <Media Studio> will automatically start when the player is connected to your PC.
 - If the program does not start automatically, double click the <Media Studio> icon  on the desktop.








NOTE

- Music recognition technology and related data are provided by Gracenote and Gracenote CDDB® Music Recognition ServiceSM.
- CDDB is a registered trademark of Gracenote. The Gracenote logo and logotype, the Gracenote CDDB logo and logotype, and the “Powered by Gracenote CDDB” logo are trademarks of Gracenote. Music Recognition Service and MRS are service marks of Gracenote.

TRANSFERRING FILES TO THE PLAYER WITH SAMSUNG MEDIA STUDIO (Continued)

3. Click the icon for the type of file you want to transfer.

- Click  to display music list.
- Click  to display video list.
- Click  to display picture list
- Click  to display etc list. The ETC list includes file types (ex: TXT, etc) other than music, picture, and video files.




4. Click **<Add File>** on the bottom of **<Media Studio>**.

- The **<Open>** window will appear.

5. Select the files to add and click **<Open>**.


- The files are added to the list on the left side the **<Media Studio>** Screen.



6. Select the file to transfer from the list on the left side.

7. Click the  icon.

- The file you selected is transferred to the player.



TRANSFERRING FILES TO THE PLAYER WITH SAMSUNG MEDIA STUDIO (Continued)



CAUTION

- Do not disconnect the USB plug during file transfer. Disconnecting during transfer may damage the player or your PC.
- Connect the player to your computer directly rather than through a USB hub to avoid an unstable connection.





NOTE


- When transferring a video file to the player using <Media Studio>, it is automatically converted into SVI format before transfer. The file size is automatically adjusted too. However a WMV file supported by the player is not converted into a SVI file.
- When transferring a picture file to the player using <Media Studio>, it is automatically converted into JPG format before transfer. The file size is automatically adjusted, too.
- A photo file that is transferred to the player without using <Media Studio> can look different from the source on the screen of the player.
- All functions are disabled during connection.
- If you connect the USB plug to the PC in the Low Battery condition, the player will be charged for several minutes before connecting to the PC.
- Samsung Media Studio has a thorough Help function. If you can't find the answer to your question about Media Studio, click <MENU> → <Help> → <Help> on the top of the <Media Studio> program.

watching a video

- ★ **Before you start** - Transfer video files to the player using <Media Studio>. See page 39. Connect the earphones, then turn on the player, and check the battery.


- NOTE  Tap the [↔] icon to move to the previous screen. Press and briefly hold the [↔] icon to move to the main menu screen.

1. Tap the  icon on the main menu screen.
 - The video list appears.
2. Tap on the video file twice you want to play.
 - The selected video file horizontally starts to play.



PAUSING


1. Tap the [||] icon during playback.
 - The Video playback will be paused.
2. Tap the [▶] icon to resume playing.
 - The video will play from the point where it stopped.

- NOTE  Information and icon on the current video playback will disappear in a certain time. Tap on the screen if you want to display the video playback information and icon again.
 - When transferring a video file to the player using <Media Studio>, it is automatically converted into SVI(video) format before transfer. The file size is automatically adjusted, too. However a WMV file supported by the player is not converted into a SVI file.

TO MOVE TO A SPECIFIC FRAME

How To 1

1. In a horizontal view, press and briefly hold the [⏮, ⏭] icon during playback.
 - This enables you to move up or back in the current video file.
2. Release the icon when you have moved to the position you want.
 - The video starts playing from the position.



How To 2

- Tap on the point you want at the video play status bar.
- The video starts playing from the point you have selected.



- NOTE ▪ If it is set to <Horizontal Stroke> other than <1 File>, tapping on the center of the touch screen to the left / right direction will move to the next / previous by the set stroke interval . See [page 46](#).

TO PLAY THE PREVIOUS VIDEO FILE


How To 1

Tap the [⏮] icon within 5 seconds after the current video started playing.
Tap the [⏮] icon twice after 5 seconds after the current video started playing

- This will return to the previous video.

How To 2

Tap on the center area of the touch screen to the right as if you keep flipping it.



How To 2

TO PLAY THE NEXT VIDEO FILE


How To 1

Tap the [⏭] icon.

- This will move to the next video.

How To 2

Tap on the center area of the touch screen to the left as if you keep flipping it.



How To 2

USING THE VIDEO MENU

To set a bookmark

Once you bookmark a specific scene that you want to see again, you can enjoy it at any time you want.

1. Tap the [≡] icon at the scene you want during video playback.

- The <Video> menu appears.

2. Tap <Bookmark>.

- The <Bookmark> menu appears.


3. Tap <Add>.

- The currently played/stopped point is set to a bookmark.



NOTE ▪ The Overwrite window appears if there is a bookmark previously set. If you select <Yes>, the previously set bookmark is deleted and a new bookmark is added.

- The bookmark can be set one for each video file, and you can set a maximum of 100 bookmarks.



To move / remove the bookmark

1. Tap the [≡] icon on the video playback screen.


- The <Video> menu appears.

2. Tap <Bookmark>.

- The <Bookmark> menu appears.

3. Tap <Go to> or <Delete>.

- When you selected <Go to> then it will move to the selected bookmark and <Delete> will remove the selected bookmark from the video file.




NOTE ▪ Tap the [≡] icon to exit the menu.

USING THE VIDEO MENU (Continued)

To Set the Digital Natural Sound engine (DNSe)

Select the right sound for each video genre.


1. Tap the [☰] icon.
 - The <Video> menu appears.
2. Tap <DNSe>.
 - The <DNSe> menu appears.
3. Tap on a desired DNSe.
 - Select from <Normal>, <Drama> and <Action>.



To set the horizontal stroke

You can fast forward through a file at various intervals when you touch the screen to the left or right. Skip a whole track or skip several seconds at a time.

1. Tap the [☰] icon on the video playback screen.
 - The <Video> menu appears.
2. Tap <Horizontal Stroke>.
 - The <Horizontal Stroke> menu appears.
3. Tap on a desired horizontal stroke.
 - Select from <1 File>, <Seek>, <10sec Skip>, <30sec Skip> and <1min Skip>.
 - Left : Moves to the next by the set horizontal stroke interval.
 - Right : Moves to the previous by the set horizontal stroke interval.
 - For <Seek> option, tapping on the touch screen to the left / right cycles through <x2> → <x4> → <x8> playback speed.



NOTE

▪ If the file was developed with a variable bit rate, the actual length of the horizontal stroke may not be exactly what you select.

USING THE VIDEO MENU (Continued)

To select the screen size

You can select the display size of the movie playback.

1. Tap the [⋮] icon on the video playback screen.


- The <Video> menu appears.

2. Tap <Screen Size>.


- The <Screen Size> menu appears.

3. Tap on a desired Screen Size.


- Select from <Actual Size>, <Standard>, <Full> and <Zoom>.



Images in 4:3 ratio



<Actual Size>



<Full>




<Zoom>


Images in 16:9 or wider ratio



<Actual Size>



<Full>



<Zoom>


USING THE VIDEO MENU (Continued)

- ★ **Before you start** - Check if the stereo headset has been registered. <Connect to Headset> appears when there is a registered headset. For more information, refer to "Using the Stereo Headset." See page 78

To connect a stereo headset


You can directly connect to a registered Bluetooth headset during video playback.

1. Tap the [☰] icon on the video playback screen.
 - The <Video> menu appears.
2. Tap <Connect to Headset>.
 - If <Bluetooth Mode> is set to <Off>, it will be switched to <On>.
 - When the connection is successfully done, you will see the [🔊]
 - You can enjoy your video file via the stereo headset.



To disconnect the stereo headset

1. Tap the [☰] icon on the video playback screen.
 - The <Video> menu appears.
2. Tap <Disconnect Headset>.
 - The headset is disconnected.




listening to music



- **Before you start** - Connect the earphones, then turn on the player, and check the battery.
 - Tap the [↔] icon to move to the previous screen.
- NOTE** Press and briefly hold the [↔] icon to move to the main menu screen.

LISTENING BY CATEGORY



1. Tap the  icon on the main menu screen.
 - The <Music> list will appear.
2. Tap on a desired list.
 - The Music file appear.
3. Tap on a music file twice on the screen.
 - The music will start playing.

PAUSING

1. Tap the [||] icon or press the  button while the music is playing.
 - The music playback will be paused.
2. Tap the [||] icon or press the  button again.
 - The music will play from the point where it stopped.

PLAYING FROM THE BEGINNING OF THE CURRENT TRACK

1. Tap the [⏮] icon after 3 seconds of play.
 - The current track starts playing from the beginning.

PLAYING THE PREVIOUS TRACK

How To 1


- Tap the [⏮] icon within 3 seconds of play.
Tap the [⏮] icon twice after 3 seconds of play.

How To 2

- Tap on the center area of the touch screen to the right as if you keep flipping it.
 - The previous track will start playing.



How To 2

-  ▪ When playing VBR files, the previous track may not play even if you tap the [⏮] icon within 3 seconds of the play.

PLAYING THE NEXT TRACK


How To 1

Tap the [▶▶] icon.

How To 2

Tap on the center area of the touch screen to the left as if you keep flipping it.

- The next track will start playing.



How To 2


SEARCHING WITHIN A TRACK


How To 1

1. Press and briefly hold the [⏮] or [⏭] icon while the selected track is playing.
 - It searches to the beginning or the end of the track.
2. Release the icon at the point you wish to start.
 - It starts playing from the point you release the icon.

How To 2

Tap on a desired point in the play status bar.




-  **NOTE** ▪ If it is set to <Horizontal Stroke> other than <1 File>, tapping on the center of the touch screen to the left / right direction will move to the next / previous by the stroke interval setting.

CREATING AN ALBUM (PLAYLIST) USING SAMSUNG MEDIA STUDIO

With <Media Studio>, you can create your own collection, or album, of audio files.

- ★ **Before you start** - Connect the player to your PC.
Media Studio must be installed on your PC.

Creating an Album (Playlist)




1. Click **<My Album>** on the top of **<Media Studio>**.
 - The <My Album> window appears.
2. Click **<New Album>** on the bottom.
 - The <Creation> window appears.
3. Type in the album title and click **[OK]**.
 - A new album (playlist) will be named and stored in the <My Album> section of <Media Studio>.

CREATING AN ALBUM (PLAYLIST) USING SAMSUNG MEDIA STUDIO (Continued)

Adding music files to an Album (Playlist) you've created




1. Click **<My PC>** on the top of **<Media Studio>**.
 - The **<My PC>** window appears.
2. Click **<My Album>** in the right corner of the window.
 - The **<My Album>** window appears.
3. Double click on an album in the right window.
4. Select files that you want to transfer in the **<My PC>** window.
5. Click .
 - The selected files will be added to the album (playlist).

CREATING AN ALBUM (PLAYLIST) USING SAMSUNG MEDIA STUDIO (Continued)

Transferring an Album (Playlist) to your player using Media Studio



1. Click **<My Album>** on the top of **<Media Studio>**.
 - The **<My Album>** window appears.
2. Select an album in the **<My Album>** list.
3. Click .
 - The selected album will be transferred to the player folder by folder in **<File Browser>** → **<Playlists>**.






NOTE


- A maximum of 999 playlists transferred to the player can be played.

CREATING A PLAYLIST ON YOUR MP3 PLAYER


If you've already downloaded files to your mp3 player, you can create a "Favorites" playlist without Media Studio or your PC.

1. Tap the  icon on the main menu screen.
2. Tap **<Music>** twice.
 - The music file list appears.
3. Select a file to add to the playlist and tap  icon.
 - The Playlist menu appears.
4. Tap **<Add to Playlist>**.
 - **<Playlist 1>** to **<Playlist 5>** appear.
5. Tap on the playlist number to which the selected file is added.
 - You can check the playlist in **<Music>** → **<Playlists>** → **<Playlist 1>** to **<Playlist 5>** in the main menu.



-  **NOTE** ▪ You can add up to 200 music files to each of **<Playlist 1>** to **<Playlist 5>**.


PLAYING A PLAYLIST


1. Tap the  icon on the main menu screen.
 - The music list appears.
2. Tap **<Playlists>** twice.
 - The Playlist(s) will appear.
3. Tap on a desired playlist twice.
 - The music files saved in the selected playlist will appear.
 - If there is no playlist found, you will see a **<No file>** message on the screen.
2. Tap on a file to play file twice.
 - The music file will start playing.
 - See page 34 and 35 for how to transfer the playlist using **<Media Studio>**.



DELETING A PLAYLIST

Follow the same 1-3 steps above.

1. Select a file to delete to the playlist and tap the  icon.
 - The Playlist menu appears.
2. Tap **<Delete from Playlist>**.
 - The playlist including the selected file appears.
3. Tap on the playlist that you want to delete the selected file from.
 - The selected file is removed from the playlist.



- A playlist cannot be deleted while in use.

NOTE

USING THE MUSIC MENU

The Music menu allows you manage all facets of listening - from repeating tracks and albums to choosing the background on the screen as you listen.

To set the sound effect

You can enjoy clearer sound.

1. Tap the [☰] icon on the music play screen.
 - The <Music> menu appears.
2. Tap <Sound Effect>.
 - The <Sound Effect> menu appears.
3. Tap on a desired sound effect.
 - Select from <Street Mode> and <Clarity>.



Sound Effect Options

- **Street Mode** : Allows you to hear the music outdoors as clearly as indoors by filtering out some of the street noise. Select either <Off> or <On>
- **Clarity** : You can enjoy clearer sound with improved quality. Select from <0-2>.



NOTE


- Tap the [☰] icon to exit the menu.


USING THE MUSIC MENU (Continued)

To set the Digital Natural Sound engine (DNSe)

Select the right sound for each music genre.

1. Tap the [☰] icon on the music play screen.
 - The <Music> menu appears.
2. Tap <DNSe>.
 - The <DNSe> menu appears.
3. Tap on one of the DNSe options.
 - Select from <Normal>, <Studio>, <Rock>, <Classical>, <Jazz>, <Ballad>, <Club>, <Rhythm & Blues>, <Dance>, <Concert Hall> and <User>.
 - You can set <EQ> and <3D&Bass> when you have selected <User>. See page 69



-  NOTE
- You can also set DNSe by touching the [DNSe] icon on the music play screen.

▪ What is DNSe?




Digital Natural Sound Engine (DNSe) is a sound effect function for MP3 players developed by Samsung. It provides various sound settings to enhance the type of music you're listening to.


USING THE MUSIC MENU (Continued)

To set the Digital Natural Sound engine (DNSe) (Continued)

<3D&Bass>






Sets 3D sound effect and bass enhancement.


- 1 Tap the [] icon of <User>.
 - The <User> menu appears.
2. Tap <3D&Bass>.
 - The <3D&Bass> setting screen appears.
3. Tap either <3D> or <Bass> and tap the [ , ] icon to set the point you want. Tap <OK>.
 - You can select from <0-4> for the <3D> and <Bass>.
 - The setting is completed.



<EQ>

You can adjust individual frequencies to adjust the sound to your preference.

- 1 Tap the [] icon of <User>.
 - The <User> menu appears.
2. Tap <EQ>.
 - The <EQ> setting screen appears.
3. Tap the [ , ] icon to select the frequency you want to adjust, and tap the [ , ] icon to adjust the selected frequency's level. Tap <OK>.
 - You can select from <-10 - +10> for <EQ>.
 - The setting is completed.




USING THE MUSIC MENU (Continued)

To set the play mode

Select playback mode such as repeat settings.

1. Tap the [☰] icon on the music play screen.
 - The <Music> menu appears.
2. Tap <Play Mode>.
 - The <Play Mode> menu appears.
3. Tap on a desired play mode.
 - Select from <Normal>, <Repeat>, <Repeat One> and <Shuffle>.






Play Mode Options


- **Normal** : To play all the tracks in order one time.
 - **Repeat**: To repeat all files.
 - **Repeat One**: To repeat one file.
 - **Shuffle**: To play files at random.
-

USING THE MUSIC MENU (Continued)

To select the music play screen

Choose a background image from those provided, or choose an image of your own to be displayed as you listen to music.

1. Tap the [] icon on the music play screen.
 - The <Music> menu appears.
2. Tap <Music Play Screen>.
 - The <Music Play Screen> menu appears.
3. Tap the [ , ] icon to select a desired music play screen, and tap <OK>.
 - Select from <Type 1>, <Type 2>, <Type 3>, <Type 4>, <Album Info.> and <Album Art>.



Music Play Screen Options


- **Type 1 ~ Type 4** : You can select a desired music play screen.
 - **Album Info.** : Information on the artist name, album and genre displays if Contents information is stored on the music file.
 - **Album Art** : The album cover image displays if an album cover image is included in the Contents information of the music file.
The album cover image stored in the player displays if there is no album cover image in the Contents information of the music file.
Album Cover supports only less than 200 pixel (horizontal) x 200 pixel(vertical) in size.
-

USING THE MUSIC MENU (Continued)

To add to alarm sound

You can add your favorite music file to the alarm sound list, so it can be heard the next time the alarm goes off. See [page 83](#) to set the alarm.

1. Select a music file to add to the alarm sound and tap the [⌂] icon.
 - The <Music> menu appears.
2. Tap <Add to Alarm>.
 - The Save window appears.
3. Tap <OK>.
 - The selected music will be added to the alarm sound list.
 - You can add only one music file at a time to the alarm sound list.




To set the horizontal stroke

You can set the stroke interval of scrolling a music file playback by tapping on the touch screen to the left or right.

1. Tap the [⌂] icon on the music play screen.
 - The <Music> menu appears.
2. Tap <Horizontal Stroke1>.
 - The <Horizontal Stroke> menu appears.
3. Tap on a desired horizontal stroke.
 - Select from <1 File>, <5sec Skip>, <10sec Skip>, <30sec Skip> and <1min Skip>.



NOTE ▪ If the file was developed with a variable bit rate, the actual length of the horizontal stroke may not be exactly what you select.




USING THE MUSIC MENU (Continued)

- ★ **Before you start** - Check if the stereo headset has been registered. <Connect to Headset> appears when there is a registered headset. For more information, refer to "Using the Stereo Headset." See page 78

To connect a stereo headset

You can connect directly to the registered Bluetooth headset during music playback.

1. Tap the [⌂] icon on the music play screen.
 - The <Music> menu appears.
2. Tap <Connect to Headset>.
 - If <Bluetooth Mode> is set to <Off>, it will be switched to <On>.
 - When the connection is successfully done, you will see the [🔊].
 - You can listen to the music through the stereo headset.





To disconnect the stereo headset

1. Tap the [⌂] icon on the music play screen.
 - The <Music> menu appears.
2. Tap <Disconnect from Headset>.
 - The headset is disconnected.

viewing pictures

- ★ **Before you start** - Connect the earphones, then turn on the player, and check the battery.
- ✍ **NOTE** Tap the [↔] icon to move to the previous screen.
Press and briefly hold the [↔] icon to move to the main menu screen.

1. Tap the  icon on the main menu screen.
 - The picture preview window appears.
2. Tap on a desired picture file twice.
 - The selected picture is displayed.
 - Tap the [↔] icon to move to the preview window.



To move to the previous/next photo

Tap on the screen once in the slideshow screen.

- The previous/next video file will be displayed.


- ✍ **NOTE** Information and icon on the current picture viewing will disappear in a certain time. Tap on the screen if you want to display the picture information and icon again,
 - The Previous/Next Image [↩, ↪] icon appears if you tap on the screen once. Tapping it again will display both picture information and icon.
 - A JPG file including incorrect thumbnail data will be displayed in [👤].
 - Some picture files can be displayed slowly.
 - When transferring a picture file to the player using <Media Studio>, it is automatically converted into JPG format before transfer. The file size is automatically adjusted.
 - You can also use the <File Browser> to search for a picture file. See page 18.
 - You can keep listening to music even if you select <Pictures> to view a picture.

USING THE PICTURE MENU


To watch a slideshow

How To 1

Tap the [] icon on the preview screen.


- The [] icon on the screen appears on the screen, and the slideshow will start.

How To 2

1. Tap the [] icon on the picture view screen.


- The <Pictures> menu appears.

2. Tap <Start Slideshow>.

- The [] icon on the screen appears on the screen, and the slideshow will start.



To set the slideshow speed

1. Tap the [] icon on the picture view screen.


- The <Pictures> menu appears.

2. Tap <Slideshow Speed>.

- The <Slideshow Speed> menu appears.

3. Tap on a desired speed.

- Select from <Fast>, <Normal>, and <Slow>.



- Tap the [] icon to exit the menu.

NOTE

66 _ viewing pictures

USING THE PICTURE MENU (Continued)

To stop the slideshow


Tap on the screen in the slideshow mode

- This will stop the slideshow.

To select a picture as a background image

You can set a desired picture to the background image for the screen.


1. Select a picture file to set as a background image and tap the [☰] icon.
 - The <Pictures> menu appears.
2. Tap **<Select as My Skin>**.
 - The Save window appears.
3. Tap **<OK>**.
 - The selected picture file is set to a background image.




- NOTE ▪ If you turn off and restart the player, the selected picture file is still displayed as background image.

USING THE PICTURE MENU (Continued)



To select the picture view mode

1. Tap the [] icon on the picture view screen.
 - The <Picture> menu appears.
2. Tap <View Mode>.
 - The <View Mode> menu appears.
3. Tap on a desired mode.
 - Select from <Auto> and <Horizontal>.
 - If you select <Horizontal>, the picture file is displayed horizontally.



To enlarge a picture


You can zoom in a picture.

1. Tap the [] icon on the picture view screen.
 - The picture is enlarged.
 - Each time you press the [] icon, the size of the picture is enlarged in the sequence of <x2> → <x3> → <x4>.
2. To move to a desired position, tap on the screen to the desired direction as if you keep snapping it. See page 17
 - You can move the picture in a desired direction.




listening to FM radio


- **Before you start** - Connect the earphones, then turn on the player, and check the battery.
 - Tap the [↶] icon to move to the previous screen.
- NOTE Press and briefly hold the [↶] icon to move to the main menu screen.

Tap the  icon on the main menu screen.

- FM radio reception will start.




TO USE MUTE FUNCTION

Press the  button while listening to FM Radio.

- Sound is muted.
- Press the  button once again to resume listening.

- NOTE
- Always connect your earphones to the player when searching or setting frequencies. The earphones serve as antennas to receive FM Radio reception.
 - In poor reception areas, the player may not find an available FM frequency.



TO SEARCH FOR FM STATIONS

1. Press and briefly hold the [<, >] icon and then release in the manual mode.
 - <Searching> appears on the screen.
 - The search will stop at the frequency nearest from the point the button is released.



OR,



1. Tap the [<, >] icon to progress through the frequencies one by one in the manual mode.
 - Moves to frequencies whenever the button is pressed.



USING THE FM RADIO MENU

To switch to Preset Mode


Select this mode if you want to search through your saved FM presets one preset at a time.

1. Tap the [] icon in the manual mode.
 - The <FM Radio> menu appears
 2. Tap <Go to Preset Mode>.
 - FM radio reception will start.
 - You will see <PRESET> on the screen.
 - If no frequencies were preset, <Preset list does not exist> will appear and the player will not switch to <Preset Mode>.
-  **NOTE**
- If you set <Settings> → <System> → <Default Set>, the saved preset lists are deleted.
 - Preset frequencies are stored in the numeric sequence.



To switch to Manual Mode

Select this mode if you want to manually search through the FM band one frequency at a time.

1. Tap the [] icon in the preset mode.
 - The <FM Radio> menu appears
2. Tap <Go to Manual Mode>.
 - You will see <MANUAL> on the screen.




USING THE FM RADIO MENU (Continued)

To store stations in the preset memory

You can store up to 30 stations in your MP3 player's memory and return to them with the press of just one number. Have the MP3 player choose only the stations you want using the manual process, or find and store the local stations automatically.

Manual - choose only the stations you want to store


1. Tap the [<, >] icon to select a frequency to preset in the manual mode and tap [] icon.

2. Tap <Add to Preset>.

- The selected frequency is stored as one of empty preset numbers.



- If the same frequency is already set, the <This preset already exists> message appears and the setting is disabled.



To listen to preset stations

Tap on a desired preset number in the preset mode.

- The preset number is selected and you can listen to the radio frequency that is previously stored for the number.
- Tap the [<, >] icon to move to the previous or the next number list.



- Tap the [] icon to exit the menu.

NOTE
72_ listening to FM radio

USING THE FM RADIO MENU (Continued)

To store stations in the preset memory (Continued)

Automatic – automatically store all the stations the player receives

1. Tap the [] icon on the FM Radio screen.
 - The <FM Radio> menu appears.
2. Tap <Auto Preset>.
 - The <Auto Preset> window appears.
3. Tap <OK>.
 - The <Auto Preset> will appear and up to 30 frequencies are automatically set.



To cancel during setting

If you want to cancel the auto preset, touch the screen in the process.

- The auto preset setting is canceled, and only frequencies set up to that point are stored.



- NOTE** ▪ You may want to re-set the stored stations if you're going to listen to your MP3 player in a different city. To delete the preset stations and store new ones, simply repeat the process.


USING THE FM RADIO MENU (Continued)

To delete a preset

Follow the steps below to delete frequencies while listening to FM Radio.

1. Tap the [⌘] icon in the preset mode.
 - The <FM Radio> menu appears
2. Tap <Delete from Preset>.
 - The preset frequency list appears.
3. Tap on the frequency twice that you want to remove from the preset list.
 - The confirmation window will appear.
4. Tap <Yes>.
 - The selected preset number is deleted.
 - If you don't want to delete the preset number, select <No>.





-  **NOTE** ▪ When a preset frequency is deleted, the numbers of the following presets are moved up by one.

USING THE FM RADIO MENU (Continued)

To set the FM sensitivity

To receive more or fewer FM radio frequencies, adjust the <FM Sensitivity>.

1. Tap the [] icon on the FM Radio screen.
 - The <FM Radio> menu appears
2. Tap <FM Sensitivity>.
 - The <FM Sensitivity> menu appears.
3. Tap on a desired reception sensitivity.
 - Select from <High>, <Middle> and <Low>.
 - If you select <High>, the more frequencies can be received.



To set the FM region

You can change an FM area setting in preparation for overseas travel.

1. Tap the [] icon on the FM Radio screen.
 - The <FM Radio> menu appears
2. Tap <FM Region>.
 - The <FM Region> appears.
3. Tap on a desired FM Region.
 - Select from <Korea/US>, <Japan> and <Other Countries>.



NOTE

- Frequency range by region
 - Korea/US: Search for FM frequencies in 100 kHz increments between 87.5 MHz~108.0 MHz.
 - Japan: Search for FM frequencies in 100 kHz increments between 76.0 MHz~108.0 MHz.
 - Other Countries: Search for FM frequencies in 50 kHz increments between 87.50 MHz~108.00 MHz.
- Your previously stored radio frequencies will be deleted when you change the <FM Region> on your player.



using the datacast

Using <Media Studio>, you can transfer blog information and files registered on RSS to the player for your entertainment.

★ ▪ **Before you start** - <Media Studio> must be installed on your PC. See page 25.

REGISTERING A CHANNEL


You can create a new channel by registering RSS-supported web sites or web pages.


1. Click the **<Register a Channel>** on the bottom of the **<My Cast>** of <Media Studio>.

2. Enter an address in the **<URL>** and Click **<▶ Next>**.

- when you copy an web address and click **<Register a Channel>**, the copied address is displayed automatically in the **<URL>**.
- The setting confirmation window appears if the Web address supports RSS.

3. Click **<OK>**.

- The channel you want is registered.
- The  icon appears in My Cast for the registered channel.



CREATING A NEW CHANNEL GROUP

You can create a new group to manage channels by the category.


1. Click **<New Group>** on the bottom of **<My Cast>** of <Media Studio>.

2. Type in a group name and description and click **<OK>**.



TRANSFERRING THE DATACAST FROM THE “MEDIA STUDIO”

- ★ ▪ **Before you start** - Connect the player to your PC.
<Media Studio> must be installed on your PC. See page 25.

1. <Media Studio> will automatically start when the player is connected to your PC.
 - If the program does not start automatically, double click the <Media Studio>  icon on the desktop.

2. Click **<My Datacast>** on the top of <Media Studio>.
 - My Datacast group channel list appears.

3. Click a desired group channel.

4. Click a desired channel.

5. Select the post you want to transfer.

6. Click the  icon.

- The Post of the selected channel will be transferred to the player in <File Browser> → <Datacasts>.

- Click  on the top of <Media Studio> to move to the previous screen.

▪ **What is Datacast?**

You can automatically receive updated information without having to visit your frequently visited news, blog and UCC sites every time.



NOTE

▪ **What is RSS?**

RSS stands for Rich Site Summary or Really Simple Syndication. It is a xml-based data transmission system used to deliver information on frequently updated web sites such as news and blogs to users in a more convenient and easier way.




VIEWING DATACASTS

You can view the posts of the channels added to <My Cast>.

 ▪ **Before you start** - Transfer the post of a desired channel to the player using <Media Studio>. See page 77

 ▪ Tap the [↔] icon to move to the previous screen.
NOTE Press and briefly hold the [↔] icon to move to the main menu screen.

1. Tap the  icon on the main menu screen.


▪ The Datacast list appears.


2. Tap on a desired channel title twice.


▪ The title is the same as that of the channel added to <My Cast> in <Media Studio>.


3. Tap on a desired post title twice.

▪ The file list appears.

 icon: main text for the transferred post

 icon: picture file



 icon: music file

 icon: video file

4. Tap on a desired file twice.

▪ File playback begins.

 ▪ In <My Cast> using <Media Studio>, you can download a multimedia attachment to the post such as music, picture and video to the player and play it.
NOTE





enjoying the prime pack


READING TEXT

Whether it's a novel, the manuscript of a new story, or your research paper, your mp3 player allows you to read it... all while listening to music!

- ★ **Before you start** - Turn on the player and check the battery.
Transfer text files to the player using <Media Studio>. See [page 39](#).
Set a preferred for text in <Settings> → <Language> → <Contents>. See [page 31](#)
- NOTE Tap the [↔] icon to move to the previous screen.
Press and briefly hold the [↔] icon to move to the main menu screen.



1. Tap the  icon on the main menu screen.
2. Tap <Texts>.
 - The text file list appears.
3. Tap on a desired text file twice.
 - You will see the text on the screen.

- NOTE  You can also use the "File Browser" to search for a text file.
- NOTE You your mp3 player supports the TXT file format in Text mode.
- NOTE You can keep listening to music even if you select text file.

READING TEXT (Continued)

To move to previous/next page


How to 1

Tap the [◀,▶] icon on the bottom of the touch screen, or drag the page scroll bar to the left or right.

How to 2

Tap on the touch screen left or right as if you keep snapping it.

- Tapping to the left will display the next page, while to the right will display the previous page.



USING THE TEXT MENU

To set a bookmark

Set a bookmark to return to that point in the text at any time.

1. Tap on the [🔖] icon on a desired page of the text view screen.

- The <Bookmark> menu appears.

2. Tap <Add Bookmark>.


- The current text screen is set to a bookmark with the [🔖] symbol displayed on the top left corner.



- The Overwrite window appears if there is a bookmark previously set. If you select <Yes>, the previously set bookmark is deleted and a new bookmark is added.

- One bookmark can be set for each text file, and you can set a maximum of 100 bookmarks.


80 _ enjoying the prime pack



USING THE TEXT MENU (Continued)

To move / remove the bookmark


1. Tap the [🗑️] icon on the text view screen.
 - The <Bookmark> menu appears.
2. Tap <Go to Bookmark> or <Delete Bookmark>.
 - When you selected <Go to Bookmark> then it will move to the selected bookmark and <Delete Bookmark> will remove the selected bookmark from the text file.



To set the text viewer color

Choose what color you'd like the text to appear.

1. Tap the [📄] icon on the text view screen.
 - The <Text> menu appears.
2. Tap <Text Viewer Color>.
 - The <Text Viewer Color> menu window appears.
3. Tap the [👁️, 🗑️] icon to select a color for the text viewer.
 - Select from <Type 1> to <Type 9>.
4. Tap <OK>.
 - The selected text viewer color is displayed.







- Tap the [📄] icon to exit the menu.

USING THE TEXT MENU (Continued)

To change the font size


You can change the font size of the text.




1. Tap the [] icon on the text view screen.
 - The <Text> menu appears.
2. Tap .
 - The menu appears.
3. Tap the [ , ] icon to select a desired font size.
 - Select from <Small>, <Medium> and <Large>.
4. Tap <OK>.
 - The font size is changed.





SETTING THE ALARM

This player has an alarm which can be set to go off at a scheduled time.


 **Before you start** - First, you should set the clock for the current time. ► page 33


1. Tap the  icon on the main menu screen.
2. Tap **<Alarm>** twice.
3. Tap **<New Alarm>**.
 - The alarm setting screen appears.
4. Tap on the first item repeatedly to select the alarm frequency.
 - Select from **<Once>**, **<Everyday>**, **<Mon~Fri>**, **<Mon~Sat>**, **<Sat~Sun>** and **<Off>**.
5. Tap on the second item.
 - The alarm time setting screen appears.
6. Tap the [ , ] icon to set **<Hour>**, **<Min>** and **<AM/PM>**.
7. Tap **<OK>** on the alarm time setting screen.



SETTING THE ALARM (Continued)

8. Tap on the third item repeatedly to select the alarm sound.
 - You can select from **<Alarm Sound 1>** to **<Alarm Sound 3>** or music files added as alarm sound. See [page 63](#)
9. Tap on the fourth item repeatedly to set the alarm interval.
 - Once you set the interval, the alarm repeats in the set time interval. Select from **<Interval: 3min>**, **<Interval: 5min>** and **<Interval: 10min>**.
10. Tap **<OK>**.
 - The save confirmation window will appear.
11. Tap **<Yes>**.
 - The alarm setting is added to the alarm list.




-  **NOTE** ▪ You can store up to **7** alarms.
▪ One music file can be added to the alarm sound.



SETTING THE ALARM (CONTINUED)

To edit the alarm setting

1. Tap on the alarm setting you want to change twice on the alarm screen.
 - The alarm setting screen appears.
2. Follow the same steps as the new alarm setting above to edit the setting. See [page 83](#)



To delete an alarm setting

1. Tap on an alarm setting to delete in the alarm list.
2. Tap the [] icon.
 - Tap the [] icon to delete all of the alarm setting.
 - The Delete window appears.
3. Tap <Yes>.
 - The selected alarm will be deleted.



NOTE

- The player will sound the alarm when it reaches the scheduled time. Alarm stops briefly and starts to sound again after the alarm interval you previously set, if there is no button or Touch screen operation. Alarm sounds work repeatedly as above for one hour if there is no operation.





CAUTION


- If the USB cable is connected to the player, the alarm function does not work.

VIEWING THE CALENDAR

You can check the calendar.




 ▪ **Before you start** - First, you should set the clock for the current time. ▶ page 33


1. Tap the  icon on the main menu screen.
2. Tap **<Calendar>** twice.
 - The <calendar> screen appears.
3. Tap the [**<**, **>**] icon to select a desired month.
 - You can view the calendar of the month of your choice.



To set the type of the calendar

You can view the calendar by changing the order of days of the week.


1. Tap the [] icon on the calendar view screen.
 - The <Calendar> menu appears.
2. Tap **<View Type>**.
 - The <View Type> screen appears.
3. Tap the [, ] icon to select the view mode you want and Tap **<OK>**.
 - Select either **<Type 1>** or **<Type 2>**.
 - **<Type 1>** displays Sunday through Saturday while **<Type 2>** displays Monday through Sunday.




VIEWING THE WORLD CLOCK

You can check the location and date/time of major world cities based on their respective time zone.

- ★ **Before you start** - First, you should set the clock for the current time. ► page 33
Set the time zone you want in the **<Setting>** → **<Time>** → **<Time Zone>**.

1. Tap the  icon on the main menu screen.
2. Tap **<World Clock>** twice.
 - The **<World Clock>** screen appears.
3. Tap the [**<**, **>**] icon to select a time zone.
 - You can view the date/time of the city you select.



You can check local time of the following time zone.
('/' indicates the standard time zone in the region)

Cape Verde / London, Lisbon / **Rome**, Paris, Berlin, Stockholm, Madrid, Frankfurt /
Athens, Helsinki, Cairo, Ankara / **Moscow**, Riyadh / **Abu Dhabi**, Muskat /
Tashkent, Ashgabat / **Alma Ata**, Kathmandu / **Bangkok**, Jakarta, Rangoon /
Hong Kong, Beijing, Taipei, Manila, Singapore / **Seoul**, Tokyo, Pyongyang /
Guam, **Sydney**, Brisbane / **Okhotsk** / **Wellington**, Oakland, Fiji / Samoa, **Midway** /
Honolulu, Hawaii, Tahiti / Alaska / **LA**, San Francisco, Vancouver, Seattle /
Denver, Phoenix, Salt Lake City / Chicago, **Dallas**, Houston, Mexico City /
New York, Miami, Washington DC, Montreal, Atlanta / **Cracas**, LA Paz, Santiago /
Buenos Aires, Brasilia, Sao Paulo / **The middle Atlantic**

using bluetooth



- Tap the [↔] icon to move to the previous screen.
- Press and briefly hold the [↔] icon to move to the main menu screen.

WHAT IS BLUETOOTH?

Bluetooth is an industry specification that describes how Bluetooth-compliant stereo headsets, mobile phones, and external devices can easily interconnect with each other using a short wireless connection.

- **The Bluetooth device can cause a noise or malfunction, depending on the use conditions.**
 - Physical signal interference, for instance, if you hold the player in the hand and wear a stereo headset in the ears.
 - When a part of the body is in contact with the receiving/transmitting system of the player or the stereo headset.
 - Electrical variation from electrical jamming by the wall, corner or office partitioning.
 - Electrical interference from the same frequency-band devices including medical equipment, microwave oven and wireless LAN.
- **When pairing the Bluetooth device with the player, make it within a short distance as possible.**
- **The farther the distance between player and stereo headset is, the worse the quality is. If the distance exceeds the limit, the communications are disconnected.**
- **You are not recommended to use text and picture view modes while listening to the music with the headset. Otherwise, it can cause deterioration of both player performance and Bluetooth communications.**
- **Depending on the model of the stereo headset, files in less than 32 KHz can not be played.**
- **In poor reception-sensitivity areas such as inside the elevator or under the ground, the Bluetooth connection may not work properly.**
- **The maximum distance that enables wireless connection between the player and the bluetooth is 10m. The connection will be automatically cut off if the distance is out of this range. The sound quality will be deteriorated in places of obstacles such as walls or doors even within this range.**

BLUETOOTH SPECIFICATION

The performance of a Bluetooth device can vary, depending on the specification. This player is applied to the standard Bluetooth specifications.

- **Specifications for certain purposes:** In general, the transmission output is high, causing less reduction of the signal strength but requiring more power from the battery.
- **Standard Specifications:** The transmission output is comparatively low, which causes more reduction of the signal strength but minimizing the power consumption to increase the battery life.



NOTE

- When not in use, set the **<Bluetooth Mode>** to **<Off>**. If you stay in **<On>** for **<Bluetooth Mode>**, the battery usable time is reduced.





USING A STEREO HEADSET



You can use a Bluetooth stereo headset to let you enjoy music with high quality stereo sound.

- ★ **Before you start** - Ensure that the Bluetooth device to connect is ready for pairing. (refer to the device's user manual)
Set <Search Options> under <Bluetooth Setting> to <Search Enabled>.

Registering the Stereo Headset

(simply register it only once)

1. Tap the  icon on the main menu screen.
 - The Bluetooth Settings window appears.
2. Tap <Yes>.
 - The <Bluetooth Mode> is set to <On>.
 - The  icon appears brightly.
3. Set the stereo headset ready for pairing.
 - To set the headset ready for the pairing mode, refer to the device's user manual.
4. Tap <Stereo Headset>
5. Tap the [] icon.
 - This player automatically starts search for any Bluetooth device even if you do not press the [] icon, if there is no device detected previously.
 - A device to be registered will be listed.





USING A STEREO HEADSET (Continued)

Registering the Stereo Headset (continued)

6. Tap on the name of device you want to register.
 - The Enter Password window appears if the password for the headset is other than 0000. For the password, refer to the product's manual.
 - The registration of the headset is completed.

Registering the Stereo Headset (continued)





- You can use the Bluetooth function only when playing music and video files. It is not supported while you are listening to FM Radio.
- Description of the Bluetooth icon
 -  : Bluetooth mode on
 -  : Connected to a stereo headset
- If you want to turn off the Bluetooth function, set the Bluetooth Mode to in the **<Bluetooth>** → **<Bluetooth Mode>** → **<Off>**.
- Bluetooth-compliant Headsets

Company	Model	Company	Model
i.TECH	Blueband	SAMSUNG	SBH100
Plantronics	PULSAR 590A	Jabra	BT620s
MOTOROLA	HT820		

- Use only the Bluetooth-certified stereo headset. The mono hands-free headset is not supported.

USING A STEREO HEADSET (Continued)

Connecting the registered stereo headset


1. Tap the  icon on the main menu screen.
2. Tap **<Stereo Headset>**
3. Tap on the stereo headset to connect.
 - When the connection is successfully done, you will see the .
 - You can connect up to 2 headsets.
4. Play a file of your choice.
 - You can listen to the music using a stereo headset.




- If you can't find the desired headset to connect, register it first. ► page 90
- NOTE ▪ If you turn off the player or the headset, and then turn it on, the bluetooth communication may be disconnected. If you want to listen to the music again using the stereo headset, repeat the instructions above.


SETTING A BLUETOOTH

★ ▪ **Before you start** - Set <Bluetooth Mode> to <On>.

1. Tap the  icon on the main menu screen.
2. Tap <Bluetooth Settings>.
 - The <Bluetooth Settings> menu appears.
3. Set the options you prefer and tap <OK>.






Bluetooth Settings Options

- **Discover Option** : You can set to enable or disable a Bluetooth stereo headset to detect this player when it searches for a Bluetooth device. Select from <Discoverable> and <Non-Discoverable>.
 - **Search Timeout** :: You can select the search time period for a new device. Select one from <10sec>, <20sec>, <30sec>, <45sec> and <60sec>.
 - **Delete Device** : You can delete a registered device in the player. Press the [] icon to delete all of the registered devices.
 - **My Device Info.** : You can check the name and address of your player.
-



SETTING A BLUETOOTH (Continued)

To delete a bluetooth device

1. Tap **<Delete Device>** twice.
 - You will see the list of the registered devices.
2. Select a device to remove and tap the [] **icon**.
 - Tap the [] **icon** to delete all of the registered devices.
3. Tap **<Yes>**.
 - The selected device will be removed.





To rename a bluetooth device


1. Tap **<My Device Info>** twice.
 - The My Device Info screen appears.
2. Tap the [] **icon**.
 - The Edit Device Name window appears.
3. Rename the device by tapping on the number or character **icon**.
 - [**1Aa**] : The input mode switches from number to uppercase english and to lowercase English.
 - [] : You can delete the characters from the end one at a time.
 - [**-**] : You can add space between characters.
 - [**OK**] : Confirm your change.





USING BLUETOOTH MENU


To disconnect the Bluetooth Device

1. Tap the  icon on the main menu screen.
2. Tap the  icon.
 - The Bluetooth menu appears.
3. Tap **<Disconnect>**
 - The Disconnection Confirmation window appears.
4. Tap **<Yes>**.
 - The currently connected device will be disconnected.



To check the Bluetooth Device connected

1. Tap the  icon on the main menu screen.
2. Tap the  icon.
 - The Bluetooth menu appears.
3. Tap **<Connected Device>**
 - You can see a list of connected devices.



▪ Tap the  icon to exit the menu.


upgrading firmware

Future upgrades may be available for this player to enhance performance and compatibility.


1. Connect to <http://www.samsung.com>, select **[SUPPORT]** → **[DOWNLOAD CENTER]** and then select your player.
2. When the player page appears, select **[Firmware]** below the model name to download the latest firmware.
3. Uncompress the downloaded file onto your Desktop.
 - The uncompressed files will be displayed.
4. Connect the player to your PC.
5. Right click on the Start button on the bottom left of your PC's screen, then choose Explore to Open Windows Explorer on your PC.
 - **[P2]** is displayed in Windows Explorer.




6. Locate and click on the Desktop icon in Windows Explorer (left column). The contents of the Desktop will appear in the right column.



7. Locate and select the Firmware update files (right column) and drag-and-drop it into the folder of [P2] → [Data] → [System].





8. After disconnecting USB plug, the player will be turned off automatically.
9. Press and briefly hold the  button.
- The firmware will be upgraded.
 - When upgrading is complete, the player will be turned off automatically.



- NOTE**
- Check the battery charge status of the player. If the battery is not sufficiently charged, the firmware will not be upgraded.
 - You need to have at least **20 MB** of free space on the player for the upgrade.

troubleshooting

If you have a problem with your new mp3 player, check for a solution in this list. If the problem persists, contact Samsung Customer Service at 1-800-SAMSUNG (1-800-726-7864).

PROBLEM	SOLUTION
Power will not turn on.	<ul style="list-style-type: none">• Power will not turn on if the battery is completely drained. Recharge the battery and turn the power on again.• Press the Reset hole.
Buttons do not work.	<ul style="list-style-type: none">• Check if the  switch is in the direction of the arrow position.• Ensure that you press the right button and icon before trying.• Press the Reset hole.
The screen will not turn on.	<ul style="list-style-type: none">• The screen may not be visible under direct sunlight.• When <Display Off> is selected from <Settings> → <Display>, the LCD can be turned off. Turn on the screen by tapping on the screen or pressing any button. However, when the HOLD condition, slide the  switch in the opposite direction of the arrow to release the lock.
Bluetooth connections could not be made.	<ul style="list-style-type: none">• Check if the stereo headset is Bluetooth-certified. The mono hands-free headset is not supported.• The Bluetooth connection can be set off if you turn off and restart the player or stereo headset. In this case, try to connect again.


PROBLEM	SOLUTION
Power is turning off.	<ul style="list-style-type: none"> • Check the battery status. • The power is automatically turned off when the battery is completely drained. Recharge the battery. • If <Auto Power Off> is selected from <Settings> → <System>, the Power in the pause mode will be turned off. Turn on the Player.
Battery life differs from the manual.	<ul style="list-style-type: none"> • The battery life can vary depending on the sound mode and display setting. • Battery life may be shortened when the player is left for extended periods in low or high temperatures.
Media Studio Program Malfunction	<ul style="list-style-type: none"> • Check if your PC meets the basic system requirements.
Connection to your PC is disabled.	<ul style="list-style-type: none"> • Check the USB plug if it's correctly connected and try again. • Press <Start> on the toolbar of your PC to run Windows Update. Select Key Updates and Service Packs, then update all. Reboot your PC and reconnect.
The file transfer rate is too slow.	<ul style="list-style-type: none"> • If you are running multiple programs including <Media Studio> on your PC, the file transfer rate will be slow. Exit unnecessary programs and try transferring again.

PROBLEM	SOLUTION
Player isn't playing.	<ul style="list-style-type: none"> • Check if the available file has been saved in the memory. • Check if the music file is damaged. • Check if there is enough battery power.
File upload doesn't work.	<ul style="list-style-type: none"> • Check if the USB plug is securely connected. Reconnect if necessary. • Check if the memory is full. • Press the Reset hole.
Files or data are missing.	<ul style="list-style-type: none"> • Check if the USB plug has been disconnected during file or data transmission. If this is the case, it may cause serious damage not only to files/data but also to the product. You have to be extra cautious as Samsung is not responsible for data loss.
Abnormal play time display during play.	<ul style="list-style-type: none"> • Check if the file is in Variable Bit Rate (VBR) format.
Abnormal display of file name.	<ul style="list-style-type: none"> • Go to <Settings> → <Language> → <Contents> in the Main Menu screen and set an appropriate language.
The product is hot.	<ul style="list-style-type: none"> • Heat may be generated during recharging. This has no effect on the product life or functions.
A message appears while watching a video.	<ul style="list-style-type: none"> • Try to download the video clip through Media Studio again.

appendix

MENU TREE

Here's a quick look at how the menus and functions are organized on your new mp3 player.



PRODUCT SPECIFICATIONS

Model Name	YP-P2
Power	3.7V (Li-Polymer Rechargeable)
Built-in Battery Power	830 mAh
File Compatibility	<p>AUDIO : MPEG1/2/2.5 Layer3(8kbps~320kbps, 8kHz~48kHz) WMA(5kbps~320kbps,8kHz~48kHz), Ogg(Q-1~Q10)</p> <p>VIDEO : SVI (MPEG4 Video 480x272, 30fps, MP3 Audio 44.1kHz 16bit Stereo 128kbps) WMV9 (WMV9 Simple Profile Video 320x240 or 480x272 30fps, Max 860kbps, WMA9 Audio)</p> <p>IMAGE : JPG (Baseline only)</p>
Supported Number of Files	Music File : Max. 4,000, File : Max. 10,000(Including music file/folder)
Earphone Output	20mW (16Ω)
Output Frequency Range	20Hz~20KHz
Signal to Noise Ratio	89 dB with 20 KHz LPF(based on 1kHz 0 dB)
Play Time	35 hours of music play (MP3 128kbps, Volume 20, Normal sound mode)
Temperature Range for Operation	-5~35°C (23~95°F)
Case	PMMA, Stainless
Weight	85 g
Dimensions (WxHxD)	52 X 100 X 9.9 mm

FM RADIO	Frequency Range:	87.5~108.0MHz	FM T.H.D	0.8%
	FM Signal to Noise Ratio	59 dB	FM Useable Sensitivity	5dB μ

Bluetooth	Frequency Range:	Transmit/Receive : 2402~2480 MHz	Module	BTTZ0502SA
	Spec Version Supported	1.2	Transmission Output	2.4 mW

The contents of this Manual are subject to change without prior notice for further improvement.

Wireless System

Emission Type	F1D
Power	DC 3.7V
RF Power	0.02mW
Transmit Frequency	2402MHz ~ 2480MHz
Receive Frequency	2402MHz ~ 2480MHz
No. of channels	79 ch
Temperature	-10 °C~ +50°C
Modulation System	GFSK
Communication Mode	Semi-duplex Operation
Humidity	95%

LICENSE

The product unit accompanying this user manual is licensed under certain intellectual property rights of certain third parties. In particular, this product is licensed under the following US patents : 5,991,715, 5,740,317, 4,972,484, 5,214,678, 5,323,396, 5,539,829, 5,606,618, 5,530,655, 5,777,992, 6,289,308, 5,610,985, 5,481,643, 5,544,247, 5,960,037, 6,023,490, 5,878,080, and under US Published Patent Application No. 2001-44713-A1.

This license is limited to private non-commercial use by end-user consumers for licensed contents. No rights are granted for commercial use. The license does not cover any product unit other than this product unit and the license does not extend to any unlicensed product unit or process conforming to ISO/IEC 11172-3 or ISO/IEC 13818-3 used or sold in combination with this product unit. The license only covers the use of this product unit to encode and/or decode audio files conforming to the ISO/IEC 11172-3 or ISO/IEC 13818-3. No rights are granted under this license for product features or functions that do not conform to the ISO/IEC 11172-3 or ISO/IEC 13818-3.

WARRANTY

Samsung warrants this product as free of defects in material, design and workmanship for a period of twelve (12) months from the original date of purchase.

If during the period of warranty this product proves defective under normal use and service, you should return the product to the retailer from whom it was originally purchased.

The liability of Samsung and its appointed maintenance company is limited to the cost of repair and/or replacement of the unit under warranty.

Return of the product for defective reasons should be to the original purchaser; however, Samsung Authorized Dealers and Authorized Service Centers will comply with the warranty on the terms issued to purchasers in the country concerned. For further information relating to the Authorized Service Centers contact; 1-800-SAMSUNG (1-800-726-7864).

www.samsung.com

WARRANTY CONDITIONS:

1. The warranty is only valid when the warranty card is properly completed, and upon presentation of the proof of purchase consisting of original invoice or sales slip confirmation, indicating the date of purchase, dealer's name, model, serial No. and product number.

Samsung reserves the right to refuse warranty service if this information has been removed or changed after the original purchase of the product from the dealer.

WARRANTY (Continued)

2. Samsung's obligations are to the repair of the defective part, and at its discretion, replacement of the product (service exchange unit).
3. Warranty repairs must be carried out by an Authorized Samsung Dealer/ Service Center. No reimbursement will be made for repairs carried out by non Samsung Centers, and warranty coverage will not be valid for any repairs or damage caused by such repairs.
4. Repair or replacement under the terms of this warranty does not give right to extension to or a new starting of the period of warranty. Repair or direct replacement under the terms of this warranty may be fulfilled with functionally equivalent service exchange units.
5. The warranty is not applicable in cases other than defects in material, design and workmanship.
 - The warranty does not cover the following:
 - Periodic checks, maintenance, repair and replacement of parts due to normal wear and tear.
 - Abuse or misuse, including but not solely limited to the failure to use this product for its normal purposed or in accordance with Samsung's instructions usage and maintenance.
 - Use of the product in conjunction with accessories not approved by Samsung for use with this product.

WARRANTY (Continued)

- Failure of the product arising from incorrect installation or use not consistent with technical or safety standards in current force, or failure to comply with product manual instructions.
 - Accidents, Acts of God or any cause beyond the control of Samsung caused by lightning, water, fire, public disturbances and improper ventilation.
 - Unauthorized modifications carried out for the product to comply with local or national technical standards in countries for which the Samsung product was not originally designed.
 - Repairs performed by non-authorized service centers such as opening of the product by a non-authorized person.
 - The model, serial No. and product number on the product has been altered, deleted, removed or made illegible.
- 6.** This warranty does not affect the consumer's statutory rights nor the consumers rights against the dealer from their purchase/sales agreement.

WARRANTY (Continued)

THERE ARE NO EXPRESS WARRANTIES OTHER THAN THOSE LISTED AND DESCRIBED ABOVE, AND NO WARRANTIES WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, SHALL APPLY AFTER THE EXPRESS WARRANTY PERIODS STATED ABOVE, AND NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR CORPORATION WITH RESPECT TO THIS PRODUCT SHALL BE BINDING ON SAMSUNG, SAMSUNG SHALL NOT BE LIABLE FOR LOSS OF REVENUE OR PROFITS, FAILURE TO REALIZE SAVINGS OR OTHER BENEFITS, OR ANY OTHER SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES CAUSED BY THE USE, MISUSE OR INABILITY TO USE THIS PRODUCT, REGARDLESS OF THE LEGAL THEORY ON WHICH THE CLAIM IS BASED, AND EVEN IF SAMSUNG HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

NOR SHALL RECOVERY OF ANY KIND AGAINST SAMSUNG BE GREATER IN AMOUNT THAN THE PURCHASE PRICE OF THE PRODUCT SOLD BY SAMSUNG AND CAUSING THE ALLEGED DAMAGE.

WITHOUT LIMITING THE FOREGOING,

WARRANTY (Continued)

PURCHASER ASSUMES ALL RISK AND LIABILITY FOR LOSS, DAMAGE OR INJURY TO PURCHASER AND PURCHASER'S PROPERTY AND TO OTHERS AND THEIR PROPERTY ARISING OUT OF THE USE, MISUSE OR INABILITY TO USE THIS PRODUCT SOLD BY SAMSUNG NOT CAUSED DIRECTLY BY THE NEGLIGENCE OF SAMSUNG.

THIS LIMITED WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL PURCHASER OF THIS PRODUCT, IS NONTRANSFERABLE AND STATES YOUR EXCLUSIVE REMEDY.

Some states do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

This product is for personal use only, and is only for use in compliance with the limitations of copyright and other laws.

To obtain warranty service, please contact SAMSUNG at: Samsung Electronics America, Inc. 400 Valley Road, Suite 201 Mount Arlington, NJ 07856

1-800-SAMSUNG (1-800-726-7864)

www.Samsung.com 081299

If you have any questions or comments relating to Samsung products,
please contact the SAMSUNG customer care center.

Samsung Electronics America, Inc.
1-800-SAMSUNG (7267864)
www.samsung.com

REV.0.0