

SAMSUNG

MICROWAVE OVEN

Owner's Instructions and Cooking Guide

PG3210




Quick Look-up Guide	2
Oven	3
Accessories	3
Control Panel	4
Using this Instruction Booklet	4
Safety Precautions	5
Installing Your Microwave oven	7
Setting the Time	7
What to Do if You are in Doubt or Have a Problem	8
Cooking / Reheating	8
Power Levels	9
Stopping the Cooking	9
Adjusting the Cooking Time	9
Using the Auto Reheat Feature	10
Using the Auto Cook Feature	11
Using the Power Defrost Feature	12
Power Defrost Feature	12
Choosing the Heating Element Position of Lower Heater	13
Accessory positions	13
Choosing the Accessories	13
Using the Top Grill	14
Power Grilling	14
Combining Microwaves and the Top Grill	15
Combining Microwaves and the Power Grill	16
Using the Power Grill Auto Cook Features	17
Using the Power Grill Auto Reheat Features	18
Using the Deodorization Feature	19
Switching the Beeper Off	20
Safety-Locking Your Microwave Oven	20
Using the Easy Clean button	20
Cookware Guide	21
Cooking Guide	22
Cleaning Your Microwave Oven	31
Storing and Repairing Your Microwave Oven	31
Technical Specifications	32

Quick Look-up Guide

GB

If you want to cook some food




1. Place the food in the oven.
Select the power level by pressing the  button once or more times.




2. Select the cooking time by pressing the **10min**, **1min** or **10s** button as required.



3. Press the  button.
Result : Cooking starts.
The oven beeps four times when cooking is over.

If you want to defrost some food



1. Place the frozen food in the oven.
Press the **Power** () button once or more times according to the type of food to be defrosted.



2. Select the weight by pressing the **kg** and **g** buttons as required.



3. Press the  button.

If you want to add an extra minute





- Leave the food in the oven.
Press **+30s** once or more times for each extra 30 seconds that you wish to add.


If you want to power grill some food



1. Place the food on the rack in the oven.
Press the **Power Grill** button.




2. Select the **Power Grill** () mode by turning the **Grill Mode Knob**.




3. Select the grilling time by pressing the **10min**, **1min** and **10s** button.



4. Press the  button.


Oven



Accessories


Depending on the model that you have purchased, you are supplied with several accessories that can be used in a variety of ways.

GB




1. **Coupler**, already placed over the motor shaft in the base of the oven.

Purpose The coupler rotates the turntable.




2. **Roller ring**, to be placed in the centre of the oven.

Purpose The roller ring supports the turntable.




3. **Turntable**, to be placed on the roller ring with the centre fitting to the coupler.

Purpose The turntable serves as the main cooking surface; it can be easily removed for cleaning.




4. **Metal rack**

Purpose The metal rack can be used in grill and combination and power grill cooking.



5. **Metal tray**

Purpose The Metal tray is used to brown food better in the grill Combination Cooking Mode and keep pastry and pizza dough crisp




6. **Heat-resistant gloves**

Purpose Use the safety gloves when taking out metal rack or turntable or dishes from the oven after cooking.



DO NOT operate the microwave oven without the roller ring and turntable.



- | | |
|---------------------------------------|----------------------------------|
| 1. GRILL SETTING | 11. STOP/CANCEL BUTTON |
| 2. POWER GRILL MODE | 12. POWER GRILL + MWO COMBI MODE |
| 3. GRILL MODE KNOB | 13. GRILL MODE |
| 4. CLOCK SETTING BUTTON | 14. TOP GRILL COMBI MODE |
| 5. POWER GRILL AUTO COOK SELECTION | 15. EASY CLEAN BUTTON |
| 6. POWER GRILL AUTO REHEAT SELECTION | 16. AUTO REHEAT |
| 7. POWER DEFROST FEATURE SELECTION | 17. AUTO COOK |
| 8. WEIGHT SELECTION | 18. SERVING SIZE |
| 9. MICROWAVE POWER LEVEL MODE SETTING | 19. MORE/LESS BUTTON |
| 10. TIME SETTING | 20. DEODORIZATION BUTTON |
| | 21. START BUTTON |

You have just purchased a SAMSUNG microwave oven. Your Owner's Instructions contain much valuable information on cooking with your microwave oven:

- Safety precautions
- Suitable accessories and cookware
- Useful cooking tips

Inside the cover you will find a quick look-up guide explaining four basic cooking operations:

- Cooking food
- Defrosting food
- Power grilling food
- Adding extra cooking time

At the front of the booklet you will find illustrations of the oven, and more importantly the control panel, so that you can find the buttons more easily.

The step-by-step procedures use three different symbols.

- | | | |
|---|---|---|
|  |  |  |
| Important | Note | Caution |

PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY

Failure to observe the following safety precautions may result in harmful exposure to microwave energy.

- (a) Under no circumstances should any attempt be made to operate the oven with the door open or to tamper with the safety interlocks (door latches) or to insert anything into the safety interlock holes.
- (b) Do not place any object between the oven door and front face or allow food or cleaner residues to accumulate on sealing surfaces. Ensure that the door and door sealing surfaces are kept clean by wiping after use first with a damp cloth and then with a soft dry cloth.
- (c) Do not operate the oven if it is damaged until it has been repaired by a qualified microwave service technician trained by the manufacturer. It is particularly important that the oven door closes properly and that there is no damage to the:
 - (1) Door, door seals and sealing surfaces
 - (2) Door hinges (broken or loose)
 - (3) Power cable
- (d) The oven should not be adjusted or repaired by anyone other than a properly qualified microwave service technician trained by the manufacturer.

Important Safety Instructions.

Read Carefully and keep for future reference.

Before cooking food or liquids in your microwave oven, please check that the following safety precautions are taken.

1. **DO NOT** use any metallic cookware in the microwave oven:
 - Metallic containers
 - Dinnerware with gold or silver trimmings
 - Skewers, forks, etc.

Reason: Electric arcing or sparking may occur and may damage the oven.
2. **DO NOT** heat:
 - Airtight or vacuum-sealed bottles, jars, containers
Ex) Baby food jars
 - Airtight food.
Ex) Eggs, nuts in shells, tomatoes

Reason: The increase in pressure may cause them to explode.
Tip: Remove lids and pierce skins, bags, etc.
3. **DO NOT** operate the microwave oven when it is empty.

Reason: The oven walls may be damaged.
Tip: Leave a glass of water inside the oven at all times.
The water will absorb the microwaves if you accidentally set the oven going when it is empty.
4. **DO NOT** cover the rear ventilation slots with cloths or paper.

Reason: The cloths or paper may catch fire as hot air is evacuated from the oven.
5. **ALWAYS** use oven gloves when removing a dish from the oven.

Reason: Some dishes absorb microwaves and heat is always transferred from the food to the dish. The dishes are therefore hot.
6. **DO NOT** touch interior oven walls.

Reason: These walls may be hot enough to burn even after cooking has finished, even though they do not appear to be so. Do not allow inflammable materials to come into contact with any interior area of the oven. Let the oven cool down first.

Safety Precautions (continued)

GB

7. To reduce the risk of fire in the oven cavity:
 - Do not store flammable materials in the oven
 - Remove wire twist ties from paper or plastic bags
 - Do not use your microwave oven to dry newspapers.
 - If smoke is observed, keep the oven door closed and switch off or disconnect the oven from the power supply
8. Take particular care when heating liquids and baby foods.
 - ALWAYS allow a standing time of at least 20 seconds after the oven has been switched off so that the temperature can equalize. Stir during heating, if necessary, and ALWAYS stir after heating.
 - Take care when handling the container after heating. You may burn yourself if the container is too hot.
 - A risk of delayed eruptive boiling exists.
 - To prevent delayed boiling and possible scalding, you should put a plastic spoon or glass stick into the beverages and stir before, during and after heating.
Reason: During the heating of liquids the boiling point can be delayed; this means that eruptive boiling can start after the container is removed from the oven. You may scald yourself.
 - In the event of scalding, follow these FIRST AID instructions:
 - * Immerse the scalded area in cold water for at least 10 minutes.
 - * Cover with a clean, dry dressing.
 - * Do not apply any creams, oils or lotions.
 - **NEVER** fill the container to the top and choose a container that is wider at the top than at the bottom to prevent the liquid from boiling over. Bottles with narrow necks may also explode if overheated.
 - **ALWAYS** check the temperature of baby food or milk before giving it to the baby.
 - **NEVER** heat a baby's bottle with the teat on, as the bottle may explode if overheated.
9. Be careful not to damage the power cable.
 - Do not immerse the power cable or plug in water and keep the power cable away from heated surfaces.
 - Do not operate this appliance if it has a damaged power cable or plug.
10. Stand at arm's length from the oven when opening the door.
Reason: The hot air or steam released may cause scalding.
11. Keep the inside of the oven clean.
Reason: Food particles or spattered oils stuck to oven walls or floor can cause paint damage and reduce the efficiency of the oven.
12. You may notice a "Clicking" sound during operation (especially when the oven is in defrosting).
Reason: This sound is normal when the electrical power output is changing.

13. When the microwave oven is operating without any load, the power will be cut off automatically for safety. You can operate normally after letting it stand for over 30 minutes.

IMPORTANT SAFETY INSTRUCTIONS


During cooking, you should look into the oven from time to time when food is being heated or cooked in disposable containers of plastic, paper or other combustible materials.

IMPORTANT


Young children should **NEVER** be allowed to use or play with the microwave oven. Nor should they be left unattended near the microwave oven when it is in use. Items of interest to children should not be stored or hidden just above the oven.

Installing Your Microwave oven

Place the oven on a flat, level surface that strong enough to safely bear the weight of the oven.



1. When you install your oven, make sure there is adequate ventilation for your oven by leaving at least 10 cm (4 inches) of space behind, and on the sides of the oven and 20 cm (8 inches) of space above the oven and 85 cm (33 inches) of the floor.
2. Remove all packing materials inside the oven. Install the roller ring and turntable. Check that the turntable rotates freely.
3. This microwave oven has to be positioned so that plug is accessible.



- * **Never** block the air vents as the oven may overheat and automatically switch itself off. It will remain inoperable until it has cooled sufficiently.
- * For your personal safety, plug the cable into a 3-pin, 230 Volt, 50Hz, AC earthed socket. If the power cable of this appliance is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- * **Do not** install the microwave oven in hot or damp surroundings like next to a traditional oven or radiator. The power supply specifications of the oven must be respected and any extension cable used must be of the same standard as the power cable supplied with the oven. Wipe the interior and the door seal with a damp cloth before using your microwave oven for the first time.


Setting the Time


Your microwave oven has an inbuilt clock. The time can be displayed in either the 24-hour or 12-hour notation. You must set the clock:

- **When you first install your microwave oven**
- **After a power failure**

✉ Do not forget to reset the clock when you switch to and from summer and winter time.




1. To display the time in the... Then press the  button...
24-hour notation Once
12-hour notation Twice



2. Set the hour with the **h** button and the minutes with the **min** button.





3. When the right time is displayed, press the  button again to start the clock.
Result: The time is displayed whenever you are not using the microwave oven.

What to Do if You are in Doubt or Have a Problem

If you have any of the problems listed below try the solutions given.

- ◆ This is normal.
 - Condensation inside the oven
 - Air flow around the door and outer casing
 - Light reflection around the door and outer casing
 - Steam escaping from around the door or vents

- ◆ The oven does not start when you press the  button.
 - Is the door completely closed?

- ◆ The food is not cooked at all
 - Have you set the timer correctly and/or pressed the  button?
 - Is the door closed?
 - Have you overloaded the electric circuit and caused a fuse to blow or a breaker to be triggered?

- ◆ The food is either overcooked or undercooked
 - Was the appropriate cooking length set for the type of food?
 - Was an appropriate power level chosen?

- ◆ Sparking and cracking occur inside the oven (arcing)
 - Have you used a dish with metal trimmings?
 - Have you left a fork or other metal utensil inside the oven?
 - Is aluminium foil too close to the inside walls?

- ◆ The oven causes interference with radios or televisions
 - Slight interference may be observed on televisions or radios when the oven is operating. This is normal. To solve this problem, install the oven away from televisions, radios and aerials.
 - If interference is detected by the oven's microprocessor, the display may be reset. To solve this problem, disconnect the power plug and reconnect it. Reset the time.

- ☒ If the above guidelines do not enable you to solve the problem, contact your local dealer or SAMSUNG after-sales service.


Cooking / Reheating

The following procedure explains how to cook or reheat food. **ALWAYS** check your cooking settings before leaving the oven unattended.

First, place the food in the center of the turntable. Then, close the door.



1. Press the  button.

Result : The 900W (maximum cooking power) indications are displayed:
Select the appropriate power level by pressing the  button again until the corresponding wattage is displayed. Refer to the power level table on the next page.



2. Set the cooking time by pressing the **10min. 1min** and **10s** button.



3. Press the  button.

Result : The oven light comes on and the turntable starts rotating.
(1) Cooking starts and when it has finished the oven beeps four times.
(2) The end reminder signal will beep 3 times (once every minute).
(3) The current time is displayed again.



Never switch the microwave oven on when it is empty.



The oven must be plugged into an appropriate wall socket. The turntable must be in position in the oven. If a power level other than the maximum is used, the water takes longer to boil.



If you wish to heat a dish for a short period of time at maximum power (900W), simply press the **+30s** button once for each 30 seconds of cooking time. The oven starts immediately.

Power Levels


You can choose among the power levels below.

Power Level	Output		
	MWO	TOP GRILL (Upper Heater)	POWER GRILL (Upper + Lower Heater)
HIGH	900 W		
MEDIUM HIGH	600 W		
MEDIUM	450 W		
MEDIUM LOW	300 W		
DEFROST(**)	180 W		
LOW/KEEP WARM	100 W		
GRILL	-	900 W	1850 W
COMBI I	300 W	900 W	1850 W
COMBI II	450 W	900 W	1850 W
COMBI III	600 W	900 W	1850 W


- ✉ If you select higher power level, the cooking time must be decreased.
If you select lower power level, the cooking time must be increased.

Stopping the Cooking

You can stop cooking at any time to check the food.



- To stop temporarily;
Open the door.
Result : Cooking stops. To resume cooking, close the door and press \diamond again.



- To stop Completely;
Press the ∇ button.
Result : The cooking stops.
If you wish to cancel the cooking settings, press the **Cancel**(∇) button again.



You can cancel any setting before starting cooking by simply pressing **Cancel**(∇).

Adjusting the Cooking Time

You can increase the cooking time by pressing the **+30s** button once for each 30 seconds to be added.



Press the **+30s** button once for each 30 seconds to be added.



You can not adjust the time during cooking when Auto modes are selected.


Using the Auto Reheat Feature

GB

With the Auto Reheat feature, the cooking time is set automatically. You can adjust the pressing the weight range of serving by appropriate Auto Reheat button the required number of times.

First, place the food in the center of the turntable. Then, close the door.





1. Press the **Auto**() button which you want the required number of times.




2. Select the serving size by pressing  button



3. Increase or decrease the cooking time, if necessary, by pressing the **MORE/LESS**() button.






4. Press  button
Result : When it has finished:
 (1) The oven beeps four times.
 (2) The end reminder signal will beep 3 times. (once every minute)
 (3) The current time is displayed again.

 Use only recipients that are microwave-safe.

The following table presents 3 Auto Reheat Programmes and the quantities, standing times and appropriate recommendations.


These programmes are running with microwave only.

Code	Food	Serving Size	Standing Time	Recommendations
1	 Ready Meal (chilled)	300-350 g 400-450 g	3 min	Put on a ceramic plate and cover with microwave cling film. This programme is suitable for meals consisting of 3 components (e.g. meat with sauce, vegetables and a side dish like potatoes, rice or pasta).
2	 Soup/Stew (chilled)	300-350 ml 400-450 ml 500-550 ml	3 min	Pour the soup or sauce into a deep ceramic soup plate or bowl. Cover during heating and standing time. Stir before and after standing time.
3	 Drinks (coffee, milk, tea, water with room temperature)	150 ml (1 cup) 300 ml (2 cups) 450 ml (3 cups) 600 ml (4 cups)	1-2 min	Pour the liquid into ceramic cups and reheat uncovered. Place one cup in the center, 2 cups opposite to each other and 3 or 4 cups in a circle. Leave them to stand in the microwave oven. Stir drinks before and after standing time. Be careful while taking the cups out (see safety instructions for liquids).

Using the Auto Cook Feature

With the Auto Cook feature, the cooking time is set automatically. You can adjust the pressing the serving size (or weight range of serving) by appropriate Auto Cook button the required number of times.

First, place the food in the center of the turntable. Then, close the door.



1. Press the **Auto** (👉) button which you want the required number of times.



2. Select the serving size by pressing button



3. Increase or decrease the cooking time, if necessary, by pressing the **MORE/LESS** (⬅️) button.



4. Press button

Result : When it has finished:

- (1) The oven beeps four times.
- (2) The end reminder signal will beep 3 times. (once every minute)
- (3) The current time is displayed again.

☒ Use only recipients that are microwave-safe.

The following table presents 3 Auto Cook Programmes and the quantities, standing times and appropriate recommendations.

These programmes are running with microwave only.


Code	Food	Serving Size	Standing Time	Recommendations
1	Vegetables	200-250 g 300-350 g 400-450 g 500-550 g	3 mins	Weigh the vegetables after washing, cleaning and cutting into similar size. Put them into a glass bowl with lid. Add 30 ml (2tablespoons) water when cooking for 200-250 g, add 45ml (3 tablespoons) for 300-450 g and add 60 ml (4 tablespoons) for 500-550 g. Stir after cooking. When cooking higher quantities stir once during cooking.
2	Frozen Vegetables	200-250 g 300-350 g 400-450 g 500-550 g	4 mins	Weigh the frozen vegetables (-18°C) and put them in a suitable sized glass pyrex bowl with lid. When cooking 200-350 g add 15 ml (1 tablespoon) water for 400-550 g add 30 ml (2 tablespoons). Stir after cooking and before serving. This programme is suitable for peas, sweet corn, broccoli, cauliflower and mixed vegetables such as peas, carrots and cauliflower.
3	Potatoes	300-350 g 400-450 g 500-550 g 600-650 g	3 min	Weigh the potatoes after peeling, washing and cutting into a similar size. Put them into a glass bowl with lid. Add 45 ml (3 tablespoons) water when cooking 300-450 g, add 60 ml (4 tablespoons) for cooking 500-650g.

Using the Power Defrost Feature

With the Power Defrost feature you can easily defrost meat, poultry, fish or Bread/cake. The defrost time and power level are set automatically. You simply select the programme and the weight.


Use only dishes that are microwave-safe.

First, place the food in the centre of the turntable. Then, close the door..



1. Press the **Power** (Power) button.

Press the **Power** (Power) button one or more times according to the number of type of food to be defrosted. Refer to the table for further details.



2. Select the food weight by pressing the **kg** and **g** button.



3. Press **◆** button.

Result :





- ◆ Defrosting begins.
- ◆ The oven beeps halfway through defrosting to remind you to turn the food over.
- ◆ Press **◆** again to finish defrosting. When it has finished.
 - (1) The oven beeps four times.
 - (2) The end reminder signal will beep 3 times (once every minute).
 - (3) The current time is displayed again.

You can also defrost food manually. To do so, select the microwave cooking/reheating function with a power level of 180W. Refer to the section entitled "Cooking/Reheating" on page 8 for further details.

Power Defrost Feature

The following table presents the various Power Defrost programmes, quantities, standing times and appropriate recommendations.


Remove all kinds of package material before defrosting. Place meat, poultry and fish on a ceramic plate.

Code	Food	Serving Size	Standing Time	Recommendations
1	Meat 	200-2000g	20-90min	Shield the edges with aluminium foil. Turn the meat over, when the oven beeps. This programme is suitable for beef, lamb, pork, steaks, chops, minced meat.
2	Poultry 	200-2000g	20-90min	Shield the leg and wing tips with aluminium foil. Turn the poultry over, when the oven beeps. This programme is suitable for whole chicken as well as for chicken portions.
3	Fish 	200-2000g	20-80min	Shield the tail of a whole fish with aluminium foil. Turn the fish over, when the oven beeps. This programme is suitable for whole fishes as well as for fish fillets.
4	Bread/cake 	125- 1000g	10-60min	Put bread on a piece of kitchen paper and turn over, as soon as the oven beeps. Place cake on a ceramic plate and if possible, turn over, as soon as the oven beeps. (Oven keeps operating and is stopped, when you open the door. This programme is suitable for all kinds of bread, sliced or whole, as well as for bread rolls and baguettes. Arrange bread rolls in a circle. This programme is suitable for all kinds of yeast cake, biscuit, cheese cake and puff pastry. It is not, suitable for short/crust pastry, fruit and cream cakes as well as for cake with chocolate topping.

Choosing the Heating Element Position of Lower Heater

The heating element is used when Power grilling. It can be placed in one of two positions:

- **Horizontal position for Power grilling, or combined microwave + power grill cooking**
- **Vertical position for microwave cooking, grilling or combined microwave + grill cooking. With upper heater only.**



If you place food in the heater and select Power Grill or Super Combi, the lower heater will be set in the horizontal position automatically.



If you want to reheat the heater, cool down it first after it is heated. (Minimum 10 minutes)


Accessory positions

When using the rack and the metal tray at the same time, do not position them in one direction.


i.g.) If the metal tray is placed in the lower part, the rack should not be placed in the same area.



(X)




(X)



(X)

Choosing the Accessories

Use microwave-safe recipients; do not use plastic containers, dishes, paper cups, towels, etc.



If you wish to select the combined cooking mode (grill and microwave), use only dishes that are microwave-safe and oven-proof. Metallic cookware or utensils may damage your oven.




For further details on suitable cookware and utensils, refer to the Cookware Guide on page 21.

Using the Top Grill

GB


The top grill enables you to heat and brown food quickly, without using microwaves. To this aim, a grill rack (metal rack) is supplied with your microwave oven.



1. Open the door and place the food on the metal rack.




2. Press the **Power Grill** button.



3. Select the **Grill** (☐☐) mode by turning the **Grill Mode Knob**.



Result : The display show :



4. Select the cooking time by pressing the **10min**, **1min** and **10s** buttons.

(The maximum grilling time is 60 minutes.)

Result : The following indication displayed.



5. Press the **+30s** button.

Result : The oven light comes on and the turntable starts rotating.

- (1) Cooking starts and when it has finished the oven beeps four times.
- (2) The end reminder signal will beep 3 times (once every minute).
- (3) The current time is displayed again.



Always use oven gloves when touching the dishes in the oven, as they will be very hot.



Do not worry if The heater turns off and on during grilling. This system is designed to prevent overheating oven.



When 5 seconds remains, you can't **+30s** button to add time.

Power Grilling


The power grill enables you to heat and brown food very quickly, without using microwaves. To this aim, a grill rack (metal rack) is supplied with your microwave oven.




If you select Power Grill, two lower heaters will be set in the horizontal position automatically.




The lower heater will move vertically 5 seconds before the cooking process ends.



1. Open the door and place the food on the metal rack.



2. Press the **Power Grill** button.



3. Select the **Power Grill** (☐☐☐) Mode by turning the **Grill Mode Knob**.



Result : The display show :



4. Select the cooking time by pressing the **10min**, **1min** and **10s** buttons.

(The maximum grilling time is 60 minutes.)

Result : The following indication is displayed:



5. Press the **+30s** button.

Result : The oven light comes on and the turntable starts rotating.

- (1) Cooking starts and when it has finished the oven beeps four times.
- (2) The end reminder signal will beep 3 times (once every minute).
- (3) The current time is displayed again.



Always use oven gloves when touching the dishes in the oven, as they will be very hot.





When 5 seconds remains, you can't **+30s** button to add time.


Combining Microwaves and the Top Grill

This cooking mode combines the radiant heat that is coming from the grill with the speed of microwave cooking. It operates only while the door is closed. The turnble will keep rotating.

Three combination modes with Top grill are available with this model: 600 W + Top grill, 450 W + Top grill and 300 W + Top grill.

 **ALWAYS** use microwave-safe and oven-proof cookware. Glass or ceramic dishes are ideal as they allow the microwaves to penetrate the food evenly.


 **ALWAYS** use oven gloves when touching the recipients in the oven, as they will be very hot.



1. Place the food on the rack and the rack in the high stage or low stage. Close the door.



2. Press the **Power Grill** button.



3. Select the **Mwo + Grill Combi** (⏏, ⏏, ⏏) Mode by turning the **Grill Mode Knob**.

Result : The display show :



Grille + MWO (300W)




Grille + MWO (450W)




Grille + MWO (600W)

Result : You cannot set the temperature of the grill.



4. Set the cooking time by pressing the **10min**, **1min** and **10s** buttons. The maximum cooking time is 60 minutes.



5. Press the  button.

Result : Combination cooking starts. When it has finished.

- (1) The oven beeps four times.
- (2) The end reminder signal will beep 3 times (once every minute).
- (3) The current time is displayed again.



When 5 seconds remains, you can't **+30s** button to add time.




Always use oven gloves when touching the dishes in the oven, as they will be very hot.


Combining Microwaves and the Power Grill


GB

This cooking mode combines the radiant heat that is coming from the grill with the speed of microwave cooking. It operates only while the door is closed and the turntable is rotating. Due to upper and lower heaters are operating the food will browned on top side and bottom side. You do not need to . You do not need to turnover the food. Insert food in the high stage. Three combination modes with Power Grill are available with this model:

600 W + Power Grill, 450 W + Power Grill and 300 W + Power Grill.

 **ALWAYS** use microwave-safe and oven-proof cookware. Glass or ceramic dishes are ideal as they allow the microwaves to penetrate the food evenly.


 **ALWAYS** use oven gloves when touching the recipients in the oven, as they will be very hot.



1. Place the food on the rack and the rack in the high stage. Close the door.



2. Press the **Power Grill** button.



3. Select the **Mwo + Power Grill Combi** (👇👈, 🔄👈, 🔄👉) Mode by turning the **Grill Mode Knob**.

Result : The display show :



Power Grill + MWO (300W)




Power Grill+ MWO (450W)




Power Grill + MWO (600W)

Result : You cannot set the temperature of the grill.



4. Set the cooking time by pressing the **10min**, **1min** and **10s** buttons. The maximum cooking time is 60 minutes.



5. Press the  button.

Result :

- Combination cooking starts. When it has finished.
- (1) The oven beeps four times.
 - (2) The end reminder signal will beep 3 times (once every minute).
 - (3) The current time is displayed again.




When 5 seconds remains, you can't **+30s** button to add time.




Always use oven gloves when touching the dishes in the oven, as they will be very hot.

Using the Power Grill Auto Cook Features

With the power grill auto cook feature, the cooking time is set automatically. You can adjust the serving size pressing the appropriate power grill auto cook button the required number of times.

 **ALWAYS** use microwave-safe and oven-proof cookware. Glass or ceramic dishes are ideal as they allow the microwaves to penetrate the food evenly.


 **ALWAYS** use oven gloves when touching the recipients in the oven, as they will be very hot.

First, place the food on the rack and insert rack in the high stage. Then, close the door.




1. Press the **Power Grill Auto Cook** button one or more times according to number of type of food. Refer to the table for further details. The number will be shown in display.





2. Select the food serving size by pressing  button.



3. Increase or decrease the cooking time, if necessary, by pressing the **MORE/LESS**() button.







4. Press  button.
Result : When it has finished.
(1) The oven beeps four times.
(2) he end reminder signal will beep 3 times (once every minute).
(3) The current time is displayed again.



5. The lower heaters will be set in the horizontal position automatically.



 Use only recipients that are microwave-safe.

The following table presents the various Power Grill Auto Programmes for Roast Meat, Roast Poultry and Roast Fish and the quantities, standing times and appropriate recommendations. The steaks programme is running with Power Grill only. The following programmes are running with a combination of microwaves and power grill.

Icon	Code	Food	Serving Size	Standin g Time	Recommendations
	1	Steaks	350-400 g (2 pcs) 450-500 g (2-3 pcs)	-	Brush the beef steaks or lamb steaks with oil and spices. Put them in side by side in the centre of the square rack. Insert rack in high stage, metal tray on low stage.
	2	Kebab Spits/ Shashilik Spits	400 g (2-4 spits) 600 g (4-6 spits)	1-2 min.	Prepare fresh meat cubes of pork, beef or lamb with pieces of vegetables on skewer and spice it. (Do not marinate meat in vinegar.) Put the ready prepared kebab spits side by side on the rack. Insert rack in high stage, metal tray on low stage.
	1	Chicken Pieces	200-300 g (1 pc) 400-500 g (2 pcs) 600-700 g (3 pcs)	2 min	Brush the chicken pieces with oil and spice them with pepper, salt and paprika. Put them in a circle on the rack with the skin-side up. Insert rack in high stage, metal tray on low stage.
	2	Chicken Breast	300 g (1-2 pcs) 400 g (2 pcs) 500 g (2-3 pcs)	-	Marinate chicken breast. Put breasts in a circle on the rack. Insert rack in high stage, metal tray on low stage. This programme can be used for chicken breast fillets as well as turkey breast fillets.

Using the Power Grill Auto Cook Features (continued)

GB

Icon	Code	Food	Serving Size	Standing Time	Recommendations
	1	Roast Fish	300 g (1pc) 600 g (2pcs)	3-4 min.	Brush skin of whole fish with oil and salt. Add herbs and spices inside fish. Put one fish widthways in the center on rack, put two fishes widthways side by side, head to tail on the rack. Insert rack in high stage, metal tray on low stage. This programme is suitable for whole fish like trout, carp, dorade or zander.
	2	Fish Fillets	200-300 g (1 pc) 400-500 g (2 pcs)	3-4 min.	Put fish fillets side by side in the center of rack. Insert rack in high stage, metal tray on low stage. This programme is suitable for fish fillets like salmon, pollack or rose-fish fillets.

Using the Power Grill Auto Reheat Features

With the power grill auto reheat features, the cooking time is set automatically. You can adjust the serving size/portion pressing the appropriate power grill auto reheat button the required number of times.



ALWAYS use microwave-safe and oven-proof cookware. Glass or ceramic dishes are ideal as they allow the microwaves to penetrate the food evenly.



ALWAYS use oven gloves when touching the recipients in the oven, as they will be very hot.

First, place the food on the rack and put the rack in the high stage. Then, close the door.




1. Press the **Power Grill Auto Reheat** button and select serving size by pushing several time. Refer to the table on the next page for further details.



2. Increase or decrease the cooking time, if necessary, by pressing the **MORE/LESS**(⇄) button.



3. Press ⇄ button.
Result : When it has finished.
(1) The oven beeps four times.
(2) he end reminder signal will beep 3 times (once every minute).
(3) The current time is displayed again.



4. The lower heater will be set in the horizontal position automatically.





Use only recipients that are microwave-safe.

Using the Power Grill Auto Reheat Features (continued)

The following table presents the Power Grill Auto Programmes for Toast Hawaii and Frozen Pizza and the quantities, standing times and appropriate recommendations.

These programmes are running with a combination of microwaves and power grill.


Icon	Food	Serving Size	Standing Time	Recommendations
	Toast Hawaii	250-300 g (2 pcs) 500-550 g (4 pcs)	1-2 min.	Take 2 or 4 slices of toast and put e.g. slice of ham, pineapple and cheese on top of each toast slice. Put the prepared cheese toasts side by side on the square rack and insert rack in high stage.
	Frozen Pizza	300 g 400 g 500 g	-	Put the frozen pizza on the square rack and insert it in high stage.

Using the Deodorization Feature

Use this feature after cooking odorous food or when there is a lot of smoke in the oven interior.

First clean the oven interior.




Press the **Deodorization** () button after you have finished cleaning, you will hear four beeps.



- ✘ The deodorization time has been specified as 5 minutes. It increases by 30 seconds whenever the **+30s** button is pressed.
- ✘ The maximum deodorization time is 15 minutes.

Switching the Beeper Off


GB



You can switch the beeper off whenever you want.



1. Press the  and  buttons at the same time.
Result : The oven will not beep each time you press a button.

OFF




2. To switch the beeper back on, press the  and  buttons again at the same time.
Result : The oven operates with the beeper on again.



On

Safety-Locking Your Microwave Oven


Your microwave oven is fitted with a special Child Safety programme, which enables the oven to be “locked” so that children or anyone unfamiliar with it cannot operate it accidentally.



The oven can be locked at any time.



1. Press the  and  buttons at the same time.
Result : The oven is locked (no functions can be selected).

L



2. To unlock the oven, press the  and  buttons again at the same time.
Result : The oven can be used normally.

Using the Easy Clean button


The function rotates the Lower Heaters for Convenient inside cleaning.




Operates only when door is opened.



Press the **Easy Clean** button.
lower Heaters rotate into a horizontal position.
After cleaning.



Press **Easy Clean** button or **stop/cancel**  button.

Cookware Guide

To cook food in the microwave oven, the microwaves must be able to penetrate the food, without being reflected or absorbed by the dish used.

Care must therefore be taken when choosing the cookware. If the cookware is marked microwave-safe, you do not need to worry.

The following table lists various types of cookware and indicates whether and how they should be used in a microwave oven.

Cookware	Microwave-Safe	Comments
Aluminium foil	✓ X	Can be used in small quantities to protect areas against overcooking. Arcing can occur if the foil is too close to the oven wall or if too much foil is used.
Browning plate	✓	Do not preheat for more than eight minutes.
China and earthenware	✓	Porcelain, pottery, glazed earthenware and bone china are usually suitable, unless decorated with a metal trim.
Disposable polyester cardboard dishes	✓	Some frozen foods are packaged in these dishes.
Fast-food packaging		
• Polystyrene cups containers	✓	Can be used to warm food. Overheating may cause the polystyrene to melt. May catch fire.
• Paper bags or newspaper	X	May cause arcing.
• Recycled paper or metal trims	X	
Glassware		
• Oven-to-table ware	✓	Can be used, unless decorated with a metal trim.
• Fine glassware	✓	Can be used to warm foods or liquids. Delicate glass may break or crack if heated suddenly.
• Glass jars	✓	Must remove the lid. Suitable for warming only.
Metal		
• Dishes	X	May cause arcing or fire.
• Freezer bag twist ties	X	

Paper

- Plates, cups, napkins and Kitchen paper ✓ For short cooking times and warming. Also to absorb excess moisture.
- Recycled paper X May cause arcing.

Plastic

- Containers ✓ Particularly if heat-resistant thermoplastic. Some other plastics may warp or discolour at high temperatures. Do not use Melamine plastic.
- Cling film ✓ Can be used to retain moisture. Should not touch the food. Take care when removing the film as hot steam will escape.
- Freezer bags ✓ X Only if boilable or oven-proof. Should not be airtight. Prick with a fork, if necessary.

Wax or grease-proof paper ✓

Can be used to retain moisture and prevent spattering.

✓ :Recommended

✓X :Use Caution

X :Unsafe

Cooking Guide

GB

MICROWAVES

Microwave energy actually penetrates food, attracted and absorbed by its water, fat and sugar content.

The microwaves cause the molecules in the food to move rapidly. The rapid movement of these molecules creates friction and the resulting heat cooks the food.

COOKING

Cookware for microwave cooking:

Cookware must allow microwave energy to pass through it for maximum efficiency. Microwaves are reflected by metal, such as stainless steel, aluminium and copper, but they can penetrate through ceramic, glass, porcelain and plastic as well as paper and wood. So food must never be cooked in metal containers.

Food suitable for microwave cooking:

Many kinds of food are suitable for microwave cooking, including fresh or frozen vegetables, fruit, pasta, rice, grains, beans, fish, and meat. Sauces, custard, soups, steamed puddings, preserves, and chutneys can also be cooked in a microwave oven. Generally speaking, microwave cooking is ideal for any food that would normally be prepared on a hob. Melting butter or chocolate, for example (see the chapter with tips, techniques and hints).

Covering during cooking

To cover the food during cooking is very important, as the evaporated water rises as steam and contributes to cooking process. Food can be covered in different ways: e.g. with a ceramic plate, plastic cover or microwave suitable cling film.

Standing times

After cooking is over, standing time for the food is important to allow the temperature to even out within the food.

Cooking Guide for frozen vegetables

Use a suitable glass pyrex bowl with lid. Cook covered for the minimum time - see table. Continue cooking to get the result you prefer. Stir twice during cooking and once after cooking. Add salt, herbs or butter after cooking. Cover during standing time.

Food	Portion	Power	Time (min.)	Standing Time(min.)	Instructions
Spinach	150g	600W	5-6	2-3	Add 15 ml (1 tablespoon) cold water.
Broccoli	300g	600W	8-9	2-3	Add 30 ml (2 tbsp.) cold water.
Peas	300g	600W	7-8	2-3	Add 15 ml (1 tbsp.) cold water.
Green Beans	300g	600W	7½-8½	2-3	2-3 Add 30 ml (2 tbsp.) cold water.

Food	Portion	Power	Time (min.)	Standing Time(min.)	Instructions
Mixed Vegetables (carrots/peas/corn)	300g	600W	7-8	2-3	Add 15 ml (1 tbsp.) cold water.
Mixed Vegetables (Chinese style)	300g	600W	7½-8½	2-3	Add 15 ml (1 tbsp.) cold water.

Cooking Guide for rice and pasta

Rice: Use a large glass pyrex bowl with lid - rice doubles in volume during cooking. Cook covered. After the cooking time is over, stir before standing time and salt or add herbs and butter. Remark: the rice may not have absorbed all water after the cooking time is finished.

Pasta: Use a large glass pyrex bowl. Add boiling water, a pinch of salt and stir well. Cook uncovered. Stir occasionally during and after cooking. Cover during standing time and drain thoroughly afterwards.

Food	Portion	Power	Time (min.)	Standing Time(min.)	Instructions
White Rice (parboiled)	250g 375g	900W	15-16 17½-18½	5	Add 500 ml cold water. Add 750 ml cold water.
Brown Rice (parboiled)	250g 375g	900W	20-21 22-23	5	Add 500 ml cold water. Add 750 ml cold water.
Mixed Rice (rice + wild rice)	250g	900W	16-17	5	Add 500 ml cold water.
Mixed Corn (rice + grain)	250g	900W	17-18	5	Add 400 ml cold water.
Pasta	250g	900W	10-11	5	Add 1000 ml hot water.

Cooking Guide (continued)

Cooking Guide for fresh vegetables

Use a suitable glass pyrex bowl with lid. Add 30-45 ml cold water (2-3 tbsp.) for every 250 g unless another water quantity is recommended - see table. Cook covered for the minimum time - see table. Continue cooking to get the result you prefer. Stir once during and once after cooking. Add salt, herbs or butter after cooking. Cover during a standing time of 3 minutes.

Hint: Cut the fresh vegetables into even sized pieces. The smaller they are cut, the quicker they will cook.

All fresh vegetables should be cooked using full microwave power (900 W).

Food	Portion	Time (min.)	Standing Time (min.)	Instructions
Broccoli	250g 500g	4½-5 7-8	3	Prepare even sized florets. Arrange the stems to the centre.
Brussels Sprouts	250g	6-6½	3	Add 60-75 ml (5-6 tbsp.) water.
Carrots	250g	4½-5	3	Cut carrots into even sized slices.
Cauliflower	250g 500g	5-5½ 7½-8½	3	Prepare even sized florets. Cut big florets into halves. Arrange stems to the centre.
Courgettes	250g	4-4½	3	Cut courgettes into slices. Add 30 ml (2 tbsp.) water or a knob of butter. Cook until just tender.
Egg Plants	250g	3½-4	3	Cut egg plants into small slices and sprinkle with 1 tablespoon lemon juice.
Leeks	250g	4-4½	3	Cut leeks into thick slices.
Mushrooms	125g 250g	1½-2 2½-3	3	Prepare small whole or sliced mushrooms. Do not add any water. Sprinkle with lemon juice. Spice with salt and pepper. Drain before serving.

Food	Portion	Time (min.)	Standing Time (min.)	Instructions
Onions	250g	5-5½	3	Cut onions into slices or halves. Add only 15 ml (1 tbsp.) water.
Pepper	250g	4½-5	3	Cut pepper into small slices.
Potatoes	250g 500g	4-5 7-8	3	Weigh the peeled potatoes and cut them into similar sized halves or quarters.
Turnip Cabbage	250g	5½-6	3	Cut turnip cabbage into small cubes.

GB

Cooking Guide (continued)

GB

REHEATING

Your microwave oven will reheat food in a fraction of the time that conventional ovens hobs normally take.

Use the power levels and reheating times in the following chart as a guide. The times in the chart consider liquids with a room temperature of about +18 to +20°C or a chilled food with a temperature of about +5 to +7°C.

Arranging and covering

Avoid reheating large items such as joint of meat - they tend to overcook and dry out before the centre is piping hot. Reheating small pieces will be more successful.

Power levels and stirring

Some foods can be reheated using 900 W power while others should be reheated using 600 W, 450 W or even 300 W.

Check the tables for guidance. In general, it is better to reheat food using a lower power level, if the food is delicate, in large quantities, or if it is likely to heat up very quickly (mince pies, for example).

Stir well or turn food over during reheating for best results. When possible, stir again before serving.

Take particular care when heating liquids and baby foods. To prevent eruptive boiling of liquids and possible scalding, stir before, during and after heating. Keep them in the microwave oven during standing time. We recommend putting a plastic spoon or glass stick into the liquids. Avoid overheating (and therefore spoiling) the food.

It is preferable to underestimate cooking time and add extra heating time, if necessary.

Heating and standing times

When reheating food for the first time, it is helpful to make a note of the time taken - for future reference.

Always make sure that the reheated food is piping hot throughout.

Allow food to stand for a short time after reheating - to let the temperature even out.

The recommended standing time after reheating is 2-4 minutes, unless another time is recommended in the chart.

Take particular care when heating liquids and baby food. See also the chapter with the safety precautions.

REHEATING LIQUIDS

Always allow a standing time of at least 20 seconds after the oven has been switched off to allow the temperature to even out. Stir during heating, if necessary, and ALWAYS stir after heating. To prevent eruptive boiling and possible scalding, you should put a plastic spoon or glass stick into the beverages and stir before, during and after heating.

REHEATING BABY FOOD

BABY FOOD:

Empty into a deep ceramic plate. Cover with plastic lid. Stir well after reheating! Let stand for 2-3 minutes before serving. Stir again and check the temperature.

- Recommended serving temperature: between 30-40°C.

BABY MILK:

Pour milk into a sterilised glass bottle. Reheat uncovered. Never heat a baby's bottle with teat on, as the bottle may explode if overheated. Shake well before standing time and again before serving! Always carefully check the temperature of baby milk or food before giving it to the baby. Recommended serving temperature: ca. 37°C.

REMARK:

Baby food particularly needs to be checked carefully before serving to prevent burns. Use the power levels and times in the next table as a guide lines for reheating.

-
-

Cooking Guide (continued)

Reheating Baby Food and Milk

Use the power levels and times in this table as guide lines for reheating.

Food	Portion	Power	Time	Standing Time (min.)	Instructions
Baby food (vegetables + meat)	190g	600W	30sec.	2-3	Empty into ceramic deep plate. Cook covered. Stir after cooking time. Stand for 2-3 minutes. Before serving, stir well and check the temperature carefully.
Baby porridge (grain +milk + fruit)	190g	600W	20sec.	2-3	Empty into ceramic deep plate. Cook covered. Stir after cooking time. Stand for 2-3 minutes. Before serving, stir well and check the temperature carefully.
Baby milk	100ml 200ml	300W	30-40sec. 1 min. to 1min.10sec.	2-3	Stir or shake well and pour into a sterilised glass bottle. Place into the centre of turn-table. Cook uncovered. Shake well and stand for at least 3 minutes. Before serving, shake well and check the temperature carefully.

Reheating Liquids and Food

Use the power levels and times in this table as a guide lines for reheating.

Food	Portion	Power	Time (min.)	Standing Time (min.)	Instructions
Drinks (coffee, tea. and water)	150ml (1 cup) 300ml (2 cups) 450ml (3 cups) 600ml (4 cups)	900W	1-1½ 2-2½ 3-3½ 3½-4	1-2	Pour into cups and reheat uncovered: 1 cup in the centre, 2 cups opposite of each other, 3 cups in a circle. Keep in microwave oven during standing time and stir well.
Soup (chilled)	350g 450g	900W	3-3½ 3½-4	2-3	Pour into a deep ceramic plate or deep ceramic bowl. Cover with plastic lid. Stir well after reheating. Stir again before serving.
Stew (chilled)	350g	600W	4½ -5½	2-3	Put stew in a deep ceramic plate. Cover with plastic lid. Stir occasionally during reheating and again before standing and serving.
Pasta with sauce (chilled)	350g	600W	3½ -4½	3	Put pasta (e.g. spaghetti or egg noodles) on a flat ceramic plate. Cover with microwave cling film. Stir before serving.
Filled pasta with sauce (chilled)	350g	600W	4-5	3	Put filled pasta (e.g. ravioli, tortellini) in a deep ceramic plate. Cover with plastic lid. Stir occasionally during reheating and again before standing and serving.
Plated Meal (chilled)	350g 450g	600W	4½-5½ 5½ -6½	3	Plate a meal of 2-3 chilled components on a ceramic dish. Cover with microwave cling-film.

Cooking Guide (continued)

GB

DEFROSTING

Microwaves are an excellent way of defrosting frozen food. Microwaves gently defrost frozen food in a short period of time. This can be of great advantage, if unexpected guests suddenly show up.

Frozen poultry must be thoroughly thawed before cooking. Remove any metal ties and take it out of any wrapping to allow thawed liquid to drain away.

Put the frozen food on a dish without cover. Turn over half way, drain off any liquid and remove any giblets as soon as possible.

Check the food occasionally to make sure that it does not feel warm.

If smaller and thinner parts of the frozen food start to warm up, they can be shield by wrapping very small strips of aluminium foil around them during defrosting.

Should poultry start to warm up on the outer surface, stop thawing and allow it to stand for 20 minutes before continuing.

Leave the fish, meat and poultry to stand in order to complete defrosting. The standing time for complete defrosting will vary depending on the quantity defrosted. Please refer to the table below.

Hint: Flat food defrosts better than thick and smaller quantities need less time than bigger ones. Remember this hint while freezing and defrosting food.

For defrosting of frozen food with a temperature of about -18 to -20 °C, use the following table as a guide.

All frozen food should be defrosted using defrosting power level (180 W).

Food	Portion	Time (min.)	Standing Time (min.)	Instructions
Meat	Minced beef	250g 500g	6-7 10-12	15-30 Place the meat on a flat ceramic plate. Shield thinner edges with aluminium foil. Turn over after half of defrosting time!
	Pork steaks	250g	7-8	
Poultry	Chicken pieces	500g (2 pcs)	14-15	
	Whole chicken	1200g	30-34	
Fish	Fish fillets	200g	5-7	10-25 Put frozen fish in the middle of a flat ceramic plate. Arrange the thinner parts under the thicker parts. Shield narrow ends with aluminium foil. Turn over after half of defrosting time!
	Whole fish	400g	11-13	
Fruits	Berries	300g	6-7	5 - 10 Spread fruit on a flat, round glass dish (with a large diameter).
Bread	Bread rolls	2 pcs	1-1½	5 - 20 Arrange rolls in a circle or bread horizontally on kitchen paper in the middle of turntable. Turn over after half of defrosting time!
	(each about 50 g)	4 pcs	2½-3	
	Toast/ Sandwich	250g	4-4½	
	German bread (wheat+ rye flour)	500g	7-9	

POWER GRILL

The upper grill-heating element is located underneath the ceiling and two lower movable heating-elements are located at the sides, while fixed at the back of cavity. They operate while the door is closed. When using power grill modes the two side heating-elements will move in horizontal position automatically. When using power grill function all three elements will heat up and the food will be browned from top-side and bottom-side. The advantage of power grill function is that you do not have to turnover food (see power grill Guide).

Preheating the grill elements for 3 minutes will make the food brown more quickly.

Cookware for grilling:

Should be flameproof and may include metal. Do not use any type of plastic cookware, as it can melt.

Food suitable for grilling:

Chicken pieces, chops, sausages, steaks, hamburgers, bacon and gammon rashers, thin fish portions, sandwiches and all kinds of toast with toppings.

Important remark:

Whenever the power grill function is used, make sure that the side-grill-heating elements are able to move in horizontal position.

Please remember that food must be placed on the rack or tray, insert it on the high stage, between the upper heating-element and the two movable heating-elements below

MICROWAVE + POWER GRILL

This cooking mode combines the radiant heat that is coming from the grill with the speed of microwave cooking. It operates only while the door is closed. Due to the food is placed on high stage on rack, the food browns on top side and bottom side. You do not need to turnover the food. Three combination modes with Power Grill are available with this model:

600 W + Power Grill, 450 W + Power Grill and 300 W + Power Grill.

Important remark:

Whenever the combination mode (microwave + power grill) is used, make sure that the movable heating-elements can move in horizontal position automatically. The food should be placed on the rack, unless another instruction is recommended. Please refer to the instructions in the following chart.

TOP GRILL

The upper heater can be used without lower heaters if you want to brown top side of food (see Grill Guide for Top Grill).

The food should be placed on the rack and can be inserted on the high stage or low stage, unless another instruction is recommended.

MICROWAVE + TOP GRILL

This cooking mode combines the radiant heat that is coming from the Top grill with the speed of microwave cooking. It operates only while the door is closed. Three combination modes with Top Grill are available with this model:

- 600 W + Top Grill, 450 W + Top Grill and 300 W + Top Grill.

Important remark:

Whenever the combination mode (microwave + Top grill) is used, make sure that the side heaters are placed at the side of cavity in vertical position. The food should be placed on the rack, inserted on high or low stage, unless another instruction is recommended.

Cookware for cooking with microwave + grill

Please use cookware that microwaves can pass through. Cookware should be flameproof. Do not use metal cookware with combination mode. Do not use any type of plastic cookware, as it can melt.

Food suitable for microwave + grill cooking:

Food suitable for combination mode cooking include all kinds of cooked food which need heating and browning (e.g. baked pasta), as well as foods which require a short cooking time to brown the top of the food. Also, the power grill modes can be used for food portions that benefit from a browned and crispy top side and bottom side (e.g. chicken pieces). Please refer to the grill charts for further details.

Cooking Guide (continued)

GB

Power Grill Guide for toasts, pastries and vegetables

Use the Power levels and times in this table as guide lines for grilling.

Use oven gloves while taking food out. Do not touch the hot heaters directly after grilling keep care while they are moving.

Food	Portion	Preheating Time(min.) Power Grill	Power	Time (min.)	Instructions
Toast Slices	4-6 pcs	-	Power Grill only	5-7	Put toast slices side by side in the middle on rack. Insert rack in high stage.
Tomato-Cheese-Toast	2pcs (250 g)	-	300 W + Power Grill	3-4	Take a slice of toast bread and put a slice of ham, tomato, cheese on top of each toast slice. Put toasts on rack and insert in high stage.
Toast Hawaii (ham, pineapple, cheese slices)	4pcs (500 g)	-	300 W + Power Grill	5½-6½	Put the toasts with topping (ham, pineapple, cheese slice) side by side in the middle on the rack. Insert rack in high stage. After cooking stand 2 min.
Puff Pastry (fruit filling)	300 g (4pcs)	-	Power Grill only	5-7	Fill fresh puff pastry with e.g. apricots. Put 4 filled pastries side by side on baking paper on the tray and insert in high stage. Brush pastries with stirred egg.
Puff Pastry (fish filling)	500 g (8pcs)	-	Power Grill only	6-8	Fill fresh puff pastry with minced fish and spices. Put pastries on baking paper in the middle on tray and insert in high stage. Brush pastries with stirred egg.
Pancake Rolls 'russian style'	400 g (6pcs)	-	Power Grill only	5-6	Put the pancake rolls filled with minced meat (ready cooked) side by side on tray. Insert tray in high stage.

Food	Portion	Preheating Time(min.) Power Grill	Power	Time (min.)	Instructions
Omelette	250 g	-	300 W + Power Grill	6-7	Stir 2 eggs, 2 tbsp. milk and add spices. Fill into a greased, flat glass pyrex dish and put some cheese on top. Put dish on rack. Insert rack in high stage
Vegetable Spits	200 g (2 spits)	3	Power Grill only	8-10	Cut vegetables e.g. courgettes, pepper, mushrooms into pieces and put on a skewer. Put oil and spice on vegetables and set spits side by side on rack. Insert rack in high stage.
Baked Aubergines	300 g	3	Power Grill only	8-10	Put 6-8 slices of aubergines on the preheated tray. Put topping of minced tomatoes, sour cream, spices and grated cheese on top. Insert rack in high stage.
Baked Potatoes	500 g	3	600W + Power Grill	6-8	Put the potatoes (4-5 pcs) in the middle on rack. Insert rack in high stage.
Frozen Pizza	300-400g	-	450W + Power Grill	6-8	Put the pizza on rack and insert rack in high stage.

Cooking Guide (continued)

Power Grill Guide for meat, poultry and fish

Use the Power levels and times in this table as guide lines for grilling.
Use oven gloves while taking out food. Do not touch the hot heaters directly after grilling, keep care while they are moving.

Fresh Food	Portion	Preheating Time(min.) Power Grill	Power	Time (min.)	Instructions
Beef Steaks (medium)	300-400g (4 pcs)	3	Power Grill only	11-12	Brush beef steaks or lamb steaks with oil and spices. Put them side by side on the rack. Insert rack in high stage tray in low stage.
Kebab Spits/ Shashlik Spits	600 g (4-6 pcs)	3	300 W + Power Grill	8-10	Put fresh meat cubes of pork, beef, or lamb with pieces of vegetables and spices on skewer. Do not marinate meat in vinegar. Put the ready prepared kebab spits side by side on rack. Insert rack in high stage, tray in low stage.
Chicken Kebab 'chinese style'	400 g (4-5 pcs)	3	Power Grill only	9-11	Put fresh meat cubes of chicken on skewer. Coat them with mixture of soy sauce, starch, oil and garlic. Put the ready prepared kebab spits side by side on preheated tray. Insert tray in high stage.
Minced Meat Rolls on Spits	300 g (2 pcs)	3	Power Grill only	6-8	Prepare minced meat, add herbs and spices. Put it on two wooden spits and set on preheated tray. Insert tray in high stage. Stand for 1-2 minutes after grilling.
Chicken Pieces	400-500g	-	300 W + Power Grill	11-13	Brush chicken pieces with oil and spices. Put them opposite to each other in the middle on rack. Insert rack in high stage, tray in low stage. Stand for 2-3 minutes.

Fresh Food	Portion	Preheating Time(min.) Power Grill	Power	Time (min.)	Instructions
Chicken Breast Fillets	400 g (2 pcs)	-	300 W + Power Grill	9-11	Marinate fillets of chicken breast or turkey breast and put side by side in the middle on rack. Insert rack in high stage, tray in low stage.
Roast Fish	300 g (1 fish) 600 g (2 fishes)	-	300 W + Power Grill	7-8 11-13	Brush skin of e.g. trout or dorade with oil and salt. Add herbs and spices inside of fish. Put fishes side by side, head to tail on rack. Insert rack in high stage, tray in low stage. Stand for 2-3 minutes after grilling.
Salmon Fillets	400-500g (2 pcs)	-	300 W + Power Grill	11-12	Put fish fillet in the centre on rack. Put rack in high stage, tray in low stage. Stand for 2-3 min. after grilling.

GB

Cooking Guide (continued)

GB

Grill Guide for Top Grill

Preheat the Top grill with the only-grill-function for 3 minutes.

Use the power levels and times in this table as guide lines for grilling.

Food	Portion	Power	1. Side Time (min.)	2. Side Time (min.)	Instructions
Grilled Tomatoes	200 g (2pcs)	300 W + Grill	3-4	---	Cut tomatoes into halves. Put some cheese on top. Arrange in a circle in a flat glass pyrex dish. Place it on rack an insert on high stage. Stand for 2-3 minutes.
Baked Apples	3 apple (ca.400g) 6 apples (ca.800g)	300 W + Grill	7-8 13-15	----	Core the apples and fill them with raisins and jam. Put some almond slices on top. Put apples on a flat glass pyrex dish. Place the dish directly on the turntable. Stand for 2-3 min after cooking.
Fresh Gratin (Chilled)	450-500 g	600 W + Grill	10-12	---	Put the fresh pasta gratin into a small glass pyrex dish. Put the dish on the turntable. After cooking stand for 2-3 min.

SPECIAL HINTS

MELTING BUTTER

Put 50 g butter into a small deep glass dish. Cover with plastic lid. Heat for 30-40 seconds using 900 W, until butter is melted.

MELTING CHOCOLATE

Put 100 g chocolate into a small deep glass dish. Heat for 3-5 minutes, using 450 W until chocolate is melted. Stir once or twice during melting. Use oven gloves while taking out!

MELTING CRYSTALLIZED HONEY

Put 20 g crystallized honey into a small deep glass dish. Heat for 20-30 seconds using 300 W, until honey is melted.

MELTING GELATINE

Lay dry gelatine sheets (10 g) for 5 minutes into cold water. Put drained gelatine into a small glass pyrex bowl. Heat for 1 minute using 300 W. Stir after melting.

COOKING GLAZE/ICING (FOR CAKE AND GATEAUX)

- Mix instant glaze (approximately 14 g) with 40 g sugar and 250 ml cold water. Cook uncovered in a glass pyrex bowl for 3 ½ to 4 ½ minutes using 900 W, until glaze/icing is transparent. Stir twice during cooking.

COOKING JAM

Put 600 g fruits (for example mixed berries) in a suitable sized glass pyrex bowl with lid. Add 300 g preserving sugar and stir well. Cook covered for 10-12 minutes using 900 W. Stir several times during cooking. Empty directly into small jam glasses with twist-off lids. Stand on lid for 5 minutes.

COOKING PUDDING

- Mix pudding powder with sugar and milk (500 ml) by following the manufacturers instructions and stir well. Use a suitable sized glass pyrex bowl with lid. Cook covered for 6 ½ to 7 ½ minutes using 900 W. Stir several times well during cooking.

BROWNING ALMOND SLICES

Spread 30 g sliced almonds evenly on a medium sized ceramic plate. Stir several times during browning for 3 ½ to 4 ½ minutes using 600 W. Let it stand for 2-3 minutes in the oven. Use oven gloves while taking out!

Cleaning Your Microwave Oven

The following parts of your microwave oven should be cleaned regularly to prevent grease and food particles from building up:

- *Inside and outside surfaces*
- *Door and door seals*
- *Turntable and Roller rings*

☞ **ALWAYS** ensure that the door seals are clean and the door closes properly.

1. Clean the outside surfaces with a soft cloth and warm, soapy water. Rinse and dry.
2. Remove any splashes or stains on the inside surfaces or on the roller ring with a soapy cloth. Rinse and dry.
3. To loosen hardened food particles and remove smells, place a cup of diluted lemon juice on the turntable and heat for ten minutes at maximum power.
4. Wash the dishwasher-safe plate whenever necessary.

☒ **DO NOT** spill water in the vents. **NEVER** use any abrasive products or chemical solvents. Take particular care when cleaning the door seals to ensure that no particles:

- Accumulate
- Prevent the door from closing correctly

☒ Clean the microwave oven cavity right after each use with a mild detergent solution, but let the microwave oven cool down before cleaning in order to avoid injury.

Storing and Repairing Your Microwave Oven

A few simple precautions should be taken when storing or having your microwave oven serviced.

The oven must not be used if the door or door seals are damaged:

- *Broken hinge*
- *Deteriorated seals*
- *Distorted or bent oven casing*

Only a qualified microwave service technician should perform repair.

☞ **NEVER** remove the outer casing from the oven. If the oven is faulty and needs servicing or you are in doubt about its condition:

- Unplug it from the wall socket
- Contact the nearest after-sales service centre

☒ If you wish to store your oven away temporarily, choose a dry, dust-free place.
Reason: Dust and damp may adversely affect the working parts in the oven.

☒ This microwave oven is not intended for commercial use.

Technical Specifications

Note

GB

SAMSUNG strives to improve its products at all times. Both the design specifications and these user instructions are thus subject to change without notice.

Model	PG3210
Power source	230V ~ 50 Hz
Power consumption	
Maximum power	3250 W
Microwave	1400 W
Top Grill	900 W
Power Grill	1850 W
Output power	100 W / 900 W (IEC-705)
Operating frequency	2450 MHz
Magnetron	OM75P(31)
Cooling method	Cooling fan motor
Dimensions (W x H x D)	
Outside	529 x 350 x 481 mm
Oven cavity	344 x 240 x 345 mm
Volume	30 liter
Weight	
Net	21 kg approx

—
•
—
•
—
•
—

—
•
—
•
—
•
—

—
•
—
•
—
•
—

