


Modicon Quantum Ethernet Web Embedded Server Module User Guide

840 USE 115 00 Version 1.0



Data, Illustrations, Alterations

Data and illustrations are not binding. We reserve the right to alter products in line with our policy of continuous product development. If you have any suggestions for improvements or amendments or have found errors in this publication, please notify us using the form on one of the last pages of this publication.

Training

Schneider Automation Inc. offers suitable further training on the system.

Hotline

See addresses for Technical Support Centers at the end of this publication.

Trademarks

All terms used in this publication to denote Schneider Automation Inc. products are trademarks of Schneider Automation Inc.

All other terms used in this publication to denote products may be registered trademarks and/or trademarks of the corresponding corporations. Microsoft and MS-DOS are registered trademarks of Microsoft Corporation. Windows is a brand name of Microsoft Corporation in the USA and other countries. IBM is a registered trademark of International Business Machines Corporation. Intel is a registered trademark of Intel Corporation.

Copyright

All rights are reserved. No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, including copying, processing or by online file transfer, without permission in writing from Schneider Automation Inc. You are not authorized to translate this document into any other language.

© 1997 Schneider Automation Inc. All rights reserved.

Modicon Quantum Ethernet
Web Embedded Server Module
User Guide

840 USE 115 00 Version 1.0

October, 1998



GROUPE SCHNEIDER

■ Modicon ■ Square D ■ Telemecanique

Document Set

Quantum Automation Series Hardware Reference Guide
840 USE 100 00, Version 6.0

Modicon Quantum Ethernet TCP/IP Module User Guide
840 USE 107 00, Version 3.0

Preface

The data and illustrations found in this book are not binding. We reserve the right to modify our products in line with our policy of continuous product development. The information in this document is subject to change without notice and should not be construed as a commitment by Schneider Automation, Inc.

Schneider Automation assumes no responsibility for any errors that may appear in this document. If you have any suggestions for improvements or amendments or have found errors in this publication, please notify us.

No part of this document may be reproduced in any form or by any means, electronic or mechanical, including photocopying, without express permission of the Publisher, Schneider Automation, Inc.



CAUTION

All pertinent state, regional, and local safety regulations must be observed when installing and using this product. For reasons of safety and to assure compliance with documented system data, repairs to components should be performed only by the manufacturer.

Failure to observe this precaution can result in injury or equipment damage.

MODSOFT® is a registered trademark of Schneider Automation, Inc. The following are trademarks of Schneider Automation, Inc:


Modbus Modbus Plus Modicon 984 Quantum

Microsoft®, MS-DOS® and Windows® are registered trademarks of Microsoft Corp.

IBM® and IBM AT® are registered trademarks of International Business Machines Corp.

©Copyright 1998, Schneider automation, Inc. Printed in U.S.A.

Contents




About This Book	1
Document Scope	1
Validity Note	2
Related Documentation	2
Chapter 1 Introduction	3
1.1 Ethernet Web Embedded Server Modules	3
1.1.1 The Benefits of Quantum Design	3
1.1.2 Models for Fiber Optic and Twisted Pair Cable Systems	4
1.2 Front Panel Components	5
1.2.1 LED Display	7
1.2.2 Address Labels	8
1.2.3 Twisted Pair Connector	10
1.2.4 Fiber Optic Connectors	10
1.3 Utility Diskette	11
1.3.1 Network Options Ethernet Tester	11
1.3.2 ERRLOG	11
1.4 Ethernet and Your Application	12
1.4.1 Meeting the Demands of Your Application	12
1.4.2 Compatibility	13
1.4.3 Guidelines for Designing Your Network	13
Chapter 2 Installing and Configuring the Module	15
2.1 Before You Begin	15
2.1.1 Verifying the Default Configuration	15
2.1.2 Verifying that the Network Has Been Constructed Properly	16
2.2 Installing the Module	17
2.2.1 Are You Really Ready to Install? Check!	17
2.2.2 Mounting the Module on the Backplane	17
2.2.3 Connecting the Cable	18
2.3 Changing the Default Configuration	20
2.4 Configuring the Module with Modsoft	20

2.4.1	Selecting the Ethernet Framing Type	21
2.4.2	Assigning a Slot Number	21
2.4.3	Assigning the IP Network Address	22
2.4.4	Assigning the Default Gateway Address and Subnet Mask	22
2.4.5	Resetting the Module	22
2.4.6	Configuring More Than One Ethernet Module	23
2.5	Configuring the Module with Concept	24
Chapter 3	The MSTR Instruction	25
3.1	Introduction	25
3.2	MSTR Description	25
3.2.1	Characteristics	26
3.2.2	Representation	27
3.2.3	MSTR Function Error Codes	28
3.2.4	Read and Write MSTR Operations	31
3.2.5	Get Local Statistics MSTR Operation	32
3.2.6	Clear Local Statistics MSTR Operation	33
3.2.7	Get Remote Statistics MSTR Operation	33
3.2.8	Clear Remote Statistics MSTR Operation	34
3.2.9	Peer Cop Health MSTR Operation	35
3.2.10	Reset Option Module MSTR Operation	37
3.2.11	Read CTE (Config Extension Table) MSTR Operation	37
3.2.12	Write CTE (Config Extension Table) MSTR Operation	39
3.2.13	TCP/IP Ethernet Statistics	40
Chapter 4	Retrieving Data via the World Wide Web	41
4.1	Introduction	41
4.2	Accessing the Web Utility Home Page	42
4.3	Web Utility for Quantum Page	43
Chapter 5	Using the Network Options Ethernet Tester	45
5.1	Introduction	45
5.2	Installing the Network Options Ethernet Tester	46
5.3	Establishing a Connection with an Ethernet Module	46
5.4	Getting and Clearing Statistics	48
5.5	Reading and Writing Registers	51
Chapter 6	Maintenance	53
6.1	Responding to Errors	53
6.1.1	Detecting Errors	53
6.1.2	Active LED	54
6.1.3	Ready LED	54
6.1.4	Link LED	55
6.1.5	Kernel LED	55
6.1.6	Fault LED	55
6.1.7	Collision LED	56

6.1.8	Application LED	57
6.1.9	Reading and Clearing the Error Log	57
6.2	Hot Swapping An Ethernet Module	60
6.3	Downloading a New Software Image	61
Appendix A Specifications		63
Appendix B Ethernet Developers Guide		65
B.1	Introduction	65
B.2	References	65
B.3	Overview	66
B.4	Development Environment	66
B.5	Class Descriptions	67
B.6	The CSample_doc Class	68
B.7	The CSample_View Class	69
B.8	Timers	71
B.9	Transaction Processing	71
B.10	Transmit State Machine	72
B.11	Receive State Machine	74
B.12	Displaying on the Screen	76
Appendix C Quantum Ethernet TCP/IP Modbus Application Protocol ..		77
C.1	Introduction	77
C.2	Modbus Application Protocol PDU Analysis	80
C.3	TCP/IP Specific Issues	82
C.4	Reference Documents	83
Appendix D Suppliers		85
Glossary		87
Index		93

About This Book



Document Scope

This manual will acquaint you with the Quantum Ethernet web embedded server modules and their parts, tell you how to install them, describe changes you may make in configuration, review the operation of the modules and provide maintenance procedures. It also describes how to obtain statistics about the embedded server module and its controller from the embedded World Wide Web site. For details regarding the information available on the web site, please refer to the *Web Utility Users Manual*, 890 USE 152 00.

This manual is written for an Ethernet user and assumes familiarity with Ethernet networks. If you are not familiar with Ethernet, please consult your system administrator before connecting this module to your network.

This manual also assumes that the user is acquainted with Quantum Automation Series control systems. For information about Quantum products, please refer to the *Quantum Automation Series Hardware Reference Guide*, 840 USE 100 00.

The web embedded server module is one of the Quantum series of Ethernet Modules (NOE). Throughout this manual, any reference to the NOE module is synonymous with the Ethernet web embedded server module.

Validity Note

For the Ethernet web embedded server module to work properly, you must have the proper version of other system components. Use the version specified in the table below *or a later version*.

	Quantum Embedded Server Firmware	Modsoft	Concept	ModLink
Version	1.1	2.6	2.1	2.0

Related Documentation

The following manuals may also be helpful. Be sure to order the version specified *or a later version*.

- Modicon TSX Quantum Automation Series Hardware Reference Guide
840 USE 100 00 Ver. 6
- Modicon Ladder Logic Block Library User Guide
840 USE 101 00 Ver. 2
- Modicon ModLink User Guide
890 USE 129 00
- Modsoft Programmer User Manual
890 USE 115 00
- Modbus Protocol Reference Guide
PI-MBUS-300
- Web Utility User Manual
890 USE 152 00

Introduction

1

1.1 Ethernet Web Embedded Server Modules

The Quantum Ethernet Web embedded server modules make it possible for a Quantum industrial control system to communicate with devices on an Ethernet network. For example, the modules can be used to link a Quantum Automation Series controller to a PC.

Each module contains a World Wide Web server, which allows users to obtain statistics about the NOE module and its controller from an embedded web site.

The Ethernet network is well supported worldwide, with a wide variety of third party products and services. TCP/IP is the de facto standard protocol.

1.1.1 The Benefits of Quantum Design

Like all Quantum modules, the web embedded server modules are easy to install. They may be inserted into existing Quantum systems and connected to existing Ethernet networks. They do not require proprietary cabling.

The modules may be plugged into any slot in a local Quantum backplane and may be replaced while the system is running (hot swapped). They come fully configured and are recognized by the controller as soon as they connect with the backplane.



Note: The web embedded server module must be routed through an Ethernet hub to function properly. Do not connect it directly to another device.

1.1.2 Models for Fiber Optic and Twisted Pair Cable Systems

Modicon has designed two Ethernet web embedded server modules: one for fiber optic networks and the other for networks using twisted pair cabling. Both are covered in this manual.

Type of Cable Network	Part Number
Twisted Pair	140 NOE 211 10
Fiber Optic	140 NOE 251 10

1.2 Front Panel Components

On the front panel of each Ethernet embedded web server module, you will find an LED display, a global address label and a cable connector.




Figure 1 140 NOE 211 10 Ethernet Web Embedded Server Module for Twisted Pair Networks




Figure 2 140 NOE 251 10 Ethernet Web Embedded Serve Module for Fiber Optic Networks

1.2.1 LED Display




Figure 3 LED Display

LED	Color	Indication When On
Active	Green	Module is communicating with backplane.
Ready	Green	Module has passed internal diagnostic tests.
Run	Green	Flashes during normal operation.
Link	Green	Ethernet link to hub is ok.
Kernel	Amber	If steady, module is operating in kernel mode. If flashing, module is waiting for download.
Fault	Red	An error has been detected, a download has failed or a reset is in process.
Coll	Red	If steady, cable is not connected. If flashing, Ethernet collisions are occurring.
Appl	Amber	Entry exists in crash log.

1.2.2 Address Labels

Each Quantum Ethernet web embedded server module has two address labels. One identifies the Ethernet or MAC address. The other label allows you to record the module's Internet Protocol (IP) network address.

Ethernet Address Label

The Ethernet address or MAC address is assigned at the factory and is recorded on a label on the front panel, above the cable connector. This is a unique 48-bit global assigned address. It is set in PROM. The Ethernet address is recorded on the label in hexadecimal, in the form 00.00.54.xx.xx.xx.



Figure 4 Global Address Label

Internet Protocol (IP) Network Address Label

The IP address comes from one of three places in the following order:

- The configured address
- An address from a BOOTP server
- Derived IP network address

You can use the derived address, which is calculated from the Ethernet address set by the factory. You can also configure a unique address via Modsoft or Concept. Throughout this book, these alternatives will be referred to as *the derived IP network address* and *a user-configured address*.

The IP network address has the form xxx.xxx.xxx.xxx, where each group xxx is a decimal number from 0 to 255. A space is provided for recording this address on the label inside the front door panel of the module.

If you will be operating on an open network, you should opt for a user-configured address. Obtain a valid address from your network administrator.

If you will be operating on a local network, you may use the derived IP network address. However, you should check with your network administrator first to ensure that this address is not already in use.

To calculate the derived IP network address, convert the rightmost eight digits of the Ethernet address from hex to decimal. They will take the form 84.xxx.xxx.xxx, where each group xxx is a decimal number from 0 to 255.

Example Calculating the Derived IP Network Address

Locate the global address label on the front panel of the module.

IEEE GLOBAL ADDRESS
0000540B72A8

Note the rightmost eight digits.

5 4 0 B 7 2 A 8

Convert them from hexadecimal to decimal. Each pair of hexadecimal numbers will result in a decimal number between 0 and 255. This is the derived IP address.

┌ ─┬─┐ ┌ ─┬─┐ ┌ ─┬─┐ ┌ ─┬─┐
↓ ↓ ↓ ↓
8 4 . 1 1 . 1 1 4 . 1 6 8



Note: When you have determined which IP network address you will be using, register it with your system administrator to avoid duplication.

1.2.3 Twisted Pair Connector




Figure 5 NOE 211 Connector

For the NOE 211, Schneider Automation recommends that you use Category 5 UTP cabling, which is rated to 100 Mbps, with an RJ-45 connector. You may also use Category 3 UTP cabling, which is rated to 16 Mbps.

The eight pins are arranged vertically and numbered in order from the bottom to the top. The RJ-45 pinout used by this module is:

- Receive Data (+) 3
- Receive Data (-) 6
- Transmit Data (+) 1
- Transmit Data (-) 2

1.2.4 Fiber Optic Connectors




Figure 6 NOE 251 Connectors

For the NOE 251, you need 62.5/125 micron fiber optic cable with ST-style connectors. Schneider Automation offers a 3 m cable with connectors (990 XCA 656 09).

This module comes with two fiber cable clasps, tubular plastic tools for installing the cable.

1.3 Utility Diskette

Included with this manual is a diskette containing two utilities for the Ethernet module: the Network Options Ethernet Tester utility and the ERRLOG utility.

1.3.1 Network Options Ethernet Tester

This utility will allow you to:

- establish a connection
- get and clear statistics
- read and write registers

The Network Options Ethernet Tester communicates with the module over the Ethernet, from an IBM-compatible PC operating with Windows 3.1 or greater and with WinSock.

Instructions for using the Network Options Ethernet Tester are given in Chapter 6 on page 73.

The source code for the Network Options Ethernet Tester is included on the diskette.

1.3.2 ERRLOG

This utility allows you to read and clear the crash log from an IBM-compatible PC communicating with the local Quantum controller via Modbus Plus.

The PC must be equipped with an SA85 Modbus Plus card and software driver. ERRLOG may be run in a native DOS environment or in a DOS box under Windows 3.1 or Windows 95.


Instructions for using ERRLOG to read and clear the crash log are given in section 7.1.9 on page 85.

1.4 Ethernet and Your Application

Careful planning of your network can help you achieve optimum performance. You should consider whether Ethernet meets the demands of your application, which devices are compatible with your network and how to minimize congestion on the network.

1.4.1 Meeting the Demands of Your Application

The Quantum Ethernet web embedded server modules provide connectivity to many different systems via an Ethernet network. However, Ethernet installations have characteristics which may not be suitable for all control applications.



Note: This data was measured between Quantum controllers on an otherwise empty LAN and as such reflects best case operation.

Figure 7 Network Throughput: Ethernet vs. Modbus Plus

Ethernet network traffic, message length and routing are all variable and can be unpredictable. This can give rise to congestion and message collisions. When collisions occur, Ethernet uses a variable delay before retransmitting messages. Therefore, absolute determinism -- or totally predictable performance -- cannot be guaranteed on busy Ethernet networks.

1.4.2 Compatibility

Ethernet technology allows devices from different vendors to coexist on the same network. These devices include hubs, bridges, routers and gateways. However, for these devices to be compatible they must support the same set of protocols. Quantum Ethernet modules support Modbus protocol over TCP/IP over Ethernet protocol. Systems that wish to communicate with Quantum Ethernet web embedded server modules need to support this protocol stack.

Ethernet Developers Kit

The Modbus protocol was chosen for its particular suitability for the real time control environment. It is a well-known and widely-adopted protocol and is fully described in the Ethernet Developers Kit. This kit (140 EDK 211 00) helps users develop Ethernet-based communications to their own host (PC-based) sockets applications. It contains a Quantum Ethernet module plus documentation and software tools which fully explain the protocols. The Ethernet Developers Kit is available from your distributor or local Square D office.

Ethernet and Quantum Hot Standby Systems

Ethernet web embedded server modules may be installed in a hot standby system, but they are not supported at switchover. When control shifts from the primary controller to the standby, the Ethernet network is not notified. The network continues to address the Ethernet web embedded server module in the original primary rack, not the module in the new primary rack.

EMBP Gateway

A Quantum Ethernet web embedded server module can exist on the same Ethernet network as the EMBP Gateway, but it cannot communicate with the EMBP Gateway because of differences in formatting and network addressing. However, the MBT Ethernet Bridge can be used with the web embedded server module (refer to *Modbus Plus to Ethernet Bridge Users Guide*, 890 USE 151 00).

1.4.3 Guidelines for Designing Your Network

A typical Ethernet installation carries many different types of traffic. Large data file transfers or World Wide Web graphics files can keep the network busy and cause network congestion and collisions. These collisions cause nodes to wait a variable amount of time before resending their messages. Because the size and frequency of non-control traffic is unpredictable, network performance may not be suitable for control applications. These problems can be greatly reduced by segregating the office and MIS traffic from control data.

Segregating Traffic

The best method to protect Quantum Automation traffic from information systems traffic is to provide a completely separate physical network for automation control. Another method is to use readily available Ethernet devices such as bridges and routers to logically segment the network, isolating office traffic from control data.

Minimizing Delays

Components such as repeaters, bridges, routers and hubs take a finite time to process each message. If messages pass through many of these devices, processing delays will accumulate. Delay times are available from device manufacturers. Check with your network administrator to quantify the effect on control messages and to determine whether it will be significant for your application.

Using Switches

Ethernet switches can be used to ensure higher network performance. These newer devices allow each connection to have access to the full 10 Mbps bandwidth instead of having to share the bandwidth with all other nodes. They reduce the timing problems associated with Ethernet collisions and the resulting “back off” transmission delays. Check with your network administrator to see if your application would benefit from switching Ethernet devices.

Installing and Configuring the Module

2

2.1 Before You Begin . . .

Quantum Ethernet web embedded server modules come fully configured. They are designed to go straight from the box to the backplane. But before you install your module, you must verify that:

- the default configuration is appropriate for your network
- your Ethernet network is properly constructed



CAUTION

DUPLICATE ADDRESS HAZARD

The default configuration includes the IP network address. Do not connect this module to your network until you have ensured that its IP address will be unique on the network.

Failure to observe this precaution can result in injury or equipment damage.

2.1.1 Verifying the Default Configuration

You should change the default configuration before installing the module:

- if the module will be communicating on an open network
- if the module's derived IP network address is already in use on your network
- if the network uses IEEE 802.3 framing
- if you need to specify the default Ethernet gateway and subnet mask

Consult your network administrator to see if any of these conditions apply. If they do, follow the directions on page 20 for changing the default configuration.



Note: If you will be changing the default configuration, you should stop the controller, then install the module, then change the configuration *before* starting the controller again.

The Ethernet web embedded server module only reads its configuration data at power-up and when it is reset. Whenever the configuration data is changed, the module must be reset, either by hot swapping or through a reset command in the MSTR block (see page 37). Once the module is installed, stopping and restarting the controller will not reset it.

2.1.2 Verifying that the Network Has Been Constructed Properly

You should not connect an Ethernet web embedded server module directly to another device with a length of cable. For the network to operate properly, you must route the cable for each device through an Ethernet hub. Hubs are widely available and can be purchased from many suppliers.




Figure 8 Improper Network Topologies




Figure 9 Proper Network Topology

2.2 Installing the Module

The Ethernet web embedded server module comes fully ready to be installed. Installation consists of mounting the module on the backplane and connecting the cable.

2.2.1 Are You Really Ready to Install? Check!

Have you reviewed the configuration and network guidelines on page 15? You must meet those guidelines before installing the module. *If you are planning to change the default configuration, stop the controller before installing the Ethernet web embedded server module.*

Modicon also recommends that you test to be sure your Ethernet cabling is working properly before connecting it to the Ethernet module. Some suppliers of testing equipment are listed in Appendix D.

2.2.2 Mounting the Module on the Backplane

Mount the module at an angle onto the two hooks located near the top of the backplane. Swing the module down to make an electrical connection with the backplane I/O bus connector.




Figure 10 Mounting an Ethernet Module on the Backplane

Tighten the screw at the bottom of the module to fasten it to the backplane. The maximum tightening torque for this screw is 2-4 in-lbs (.23 - .45 Nm).

2.2.3 Connecting the Cable

Twisted Pair

If you are using twisted pair cable, Modicon recommends Category 5, which is rated to 100 Mbps. Use RJ-45 connectors. Slip the connector into the port. It should snap into place.

Fiber Optic

Use 62.5/125 fiber optic cable with ST-style connectors. Modicon sells a 3 m cable with connectors (990 XCA 656 09).

Remove the protective plastic coverings from the cable ports and the tips of the cable. Snap one of the fiber cable clasps onto the cable, carefully pressing the cable through the slot so that the wider end of the clasp is closest to the boot.




Figure 11 Attaching the Fiber Cable Clasp to the Cable

The key to installing the cable is to align the barrel, the locking ring and the connector.




Figure 12 Aligning the Key and Locking Ring

Turn the locking ring to align an arrow with the key. Then align the key with the keyway. As a result, the locking tab, groove and lock should also be aligned.

Slide the clasp up to the locking ring. Gripping the cable with the clasp, plug the cable into the lower (receive) cable connector. If it does not connect easily, realign the key with the arrow and try again.




Figure 13 Attaching the Cable

Turn the cable to the right, so that the tab locks securely. You may leave the fiber cable clasp on the cable for future use, but slide it off the boot of the cable to allow the module door to close.

Repeat this process with the remaining strand of cable and the upper (transmit) cable connector.

When connecting the cable to the hub, make sure that the strands are crossed. The transmit port of one device should be linked to the receive port of the other.

2.3 Changing the Default Configuration

If any of the following conditions apply, you should stop the controller, then install the module, then change the default configuration *before* starting the controller again:

- The module will be communicating on an open Ethernet network.
- The module's IP address is already in use.
- The network uses IEEE 802.3 framing.
- You must specify a default Ethernet gateway and subnet mask.

If you change the configuration after installing the module, you must reset the module for your changes to take effect.

You may configure the module using Modsoft or Concept.

2.4 Configuring the Module with Modsoft

From the Modsoft Configuration Overview screen, select the **Cfg Ext** pulldown menu.

Be sure that you have specified sufficient memory resources for the Ethernet configuration extension in the **Cfg. Extension Size** field. The first Ethernet module configured requires 20 words. Each additional module requires an additional 16 words.

From the options, select **TCP/IP Setup**. You will reach the Ethernet configuration extension screen.

modsoft									
Hex	Dec	Bin	Goto	F5	F6	F7	Lev 8	F8	Quit
F1	F2	F3	F4	F5	F6	F7	Lev 8	F8	F9
Quantum TCP/IP CONFIG EXT.									
Ethernet Framing Type: Ethernet II									
Quantum Backplane Slot: 0									
Internet Address:									
(B4) : 0	DEC			B4. B3. B2. B1		Note: 000.000.000.000			
(B3) : 0	DEC			represents the TCP/IP					
(B2) : 0	DEC			Board Default					
(B1) : 0	DEC			Internet Address					
Default Gateway Address:									
(G4) : 0	DEC			G4. G3. G2. G1		Note: 000.000.000.000			
(G3) : 0	DEC			represents the TCP/IP					
(G2) : 0	DEC			Board Default					
(G1) : 0	DEC			Gateway Address					
SubNetwork MASK: FFFFFFF0 HEX									
PgDn/Up to next/prev Screen									

Figure 14 Configuration Extension Screen

2.4.1 Selecting the Ethernet Framing Type

You may choose between Ethernet II and IEEE 802.3, depending on your system. The default choice is Ethernet II.

If you are using the configuration extension to change the framing to IEEE 802.3, do not forget to designate the backplane slot number on the next line. Without the slot number, the system will not record the change in framing.

2.4.2 Assigning a Slot Number

To activate the configuration extension screen, you must enter the backplane slot number on the second line. This is the slot where you have mounted or intend to mount the Ethernet web embedded serve module. The slots are numbered from left to right, from one to x.



Note: If you do not enter the slot number, the system will ignore any other data you enter on this screen.

2.4.3 Assigning the IP Network Address

The Internet Protocol (IP) network address is a 32-bit address in the form xxx.xxx.xxx.xxx, where each group xxx is a decimal number ranging from 0 to 255.

If the module will be communicating on an open network or if the module's derived IP address is already being used, consult your network administrator to obtain a unique address. Type the new address in fields B4 through B1.

A space is provided for recording the IP network address on the label inside the front door panel.

If you input the address before installing the module or if you hot swap the module, it will automatically recognize the address you have already specified and will identify itself accordingly.



CAUTION

DUPLICATE ADDRESS HAZARD

Be sure to register the module's IP network address with your system administrator to avoid duplication.

Failure to observe this precaution can result in injury or equipment damage.



Note: If you are using the configuration extension to change the IP network address, you also must input the backplane slot number. Without the slot number, the system will not recognize your changes.

2.4.4 Assigning the Default Gateway Address and Subnet Mask

Consult your network administrator to determine whether you need to specify a default gateway address and subnet mask. If this data is required, the network administrator should supply it. Input the gateway address in fields G4 through G1. Input the subnet mask at the bottom of the screen.



Note: If you are using the configuration extension to assign a gateway address and subnet mask, remember to input a slot number as well. The slot number is required to activate the configuration extension.

2.4.5 Resetting the Module

If you change the default configuration after installing the module, you must reset the module for your changes to take effect. The module may be reset through a command in the MSTR block in Modsoft (page 37), by cycling power or by lifting the module off the backplane and then setting it back in its slot.

2.4.6 Configuring More Than One Ethernet Module

You may configure from two to six Ethernet modules in a single controller, depending on the model. A 140 CPU 113 or 213 will accept a total of two network option modules, including NOE, NOM, NOP, CRP 811 and other modules. A 140 CPU 424, 434 or 534 will accept six.

The first Ethernet web embedded server module configured requires 20 words of memory. Each additional module requires an additional 16 words of memory.

The modules may be placed in any slot in the backplane. They do not have to be placed next to each other.

To configure the modules, simply page down to an unused configuration extension screen. Enter the backplane slot number to activate the screen.

2.5 Configuring the Module with Concept

Once the Ethernet web embedded server module has been installed in the backplane and you have consulted your network administrator about whether to change the IP address or framing or to specify a gateway or subnet mask:

1. Open the Concept project without connecting to the controller. The controller and I/O should be configured.
2. Set the number of Ethernet modules in the configuration extension.
3. Enter each Ethernet module in the I/O map.
4. Fill in the parameter dialog box for each Ethernet module.




Figure 15 Parameter Dialog for an Ethernet Web Embedded Server Module

5. Save the project.
6. Connect to the controller.
7. Open the online control panel. Clear the existing configuration of the controller.
8. Download the project, including the configuration, to the controller. Do not start the controller. Leave the dialog open.
9. Reset the Ethernet web embedded server module in the backplane (hot swap). Wait until the Link indicator lights.
10. Start the controller. This will close the dialog box.

The MSTR Instruction

3

3.1 Introduction

All NOE 2X1 10 Quantum Ethernet web embedded server modules provide the user with the capability of transferring data to and from nodes on a Modbus Plus or TCP/IP network through the use of a special MSTR (master instruction). All PLCs that support networking communication capabilities over Modbus Plus and Ethernet can use the MSTR ladder logic instruction to read or write controller information.

3.2 MSTR Description

The MSTR instruction allows you to initiate one of 12 possible network communications operations over the network. Each operation is designated by a code. The following table lists the 12 operations and indicates those that are supported on an Ethernet TCP/IP network.

MSTR Operation	Code	TCP/IP Ethernet Support
Write data	1	supported
Read Data	2	supported
Get local statistics	3	supported
Clear local statistics	4	supported

MSTR Operation	Code	TCP/IP Ethernet Support
Write global database	5	not supported
Read global database	6	not supported
Get remote statistics	7	supported
Clear remote statistics	8	supported
Peer Cop health	9	supported
Reset Option Module	10	supported
Read CTE(config extension)	11	supported
Write CTE (config extension)	12	supported

Up to four MSTR instructions can be simultaneously active in a ladder logic program. More than four MSTRs may be programmed to be enabled by the logic flow as one active MSTR block releases the resources it has been using and becomes deactivated, the next MSTR operation encountered in logic can be activated.

3.2.1 Characteristics

Size

Three nodes high

**PLC
Compatibility**

- Standard in PLCs that have built-in Modbus Plus capabilities (Modbus Plus functionality only)
- Standard in all Quantum PLCs with Modbus Plus functionality and/or TCP/IP Ethernet option modules
- Available as a loadable in chassis mount PLCs (Modbus Plus functionality only)

Opcode

BF hex

3.2.2 Representation




Figure 16 MSTR Block Structure

Inputs

The MSTR instruction has two control inputs:

- the input to the top node enables the instruction when it is ON
- the input to the middle node terminates the active operation when it is ON

Outputs

The MSTR instruction can produce three possible outputs:

- the output from the top node echoes the state of the top input - it goes ON while the instruction is active
- the output from the middle node echoes the state of the middle input - it goes ON if the MSTR operation is terminated prior to completion or if an error occurs in completing the operation
- the output from the bottom node goes ON when an MSTR operation has been completed successfully
- all outputs are zero indicates four MSTR instructions are already in progress

Top Node Content

The 4x register entered in the top node is the first of several (network dependent) holding registers that comprise the network *control block*. The control block structure differs according to the network in use. For the TCP/IP Ethernet network the control block structure is as follows:

Register	Content
Displayed	Identifies one of ten MSTR operations legal for TCP/IP (1 ... 4 and 7 ... 12).
First implied	Displays error status.
Second implied	Displays length (number of registers transferred).
Third implied	Displays MSTR operation-dependent information.
Fourth implied	High byte: Destination index. Low byte: Quantum backplane slot address of the web embedded server module.
Fifth implied	Byte 4 of the 32-bit destination IP Address.
Sixth implied	Byte 3 of the 32-bit destination IP Address.
Seventh implied	Byte 2 of the 32-bit destination IP Address.
Eight implied	Byte 1 of the 32-bit destination IP Address.

Middle Node Content

The 4x register entered in the middle node is the first in a group of contiguous holding registers that comprise the *data area*. For operations that provide the communication processor with data such as a Write operation, the *data area* is the source of the data. For operations that acquire data from the communication processor, such as a Read operation, the *data area* is the destination for the data.

In the case of the Ethernet Read and Write CTE operations (see sections 3.2.11 and 3.2.12), the middle node stores the contents of the Ethernet configuration extension table in a series of registers.

Bottom Node Content

The integer value entered in the bottom node specifies the *length* - the maximum number of registers in the *data area*. The *length* must be in the range 1 ... 100.

3.2.3 MSTR Function Error Codes

If an error occurs during an MSTR operation, a hexadecimal error code will be displayed in the first implied register in the *control block* (the top node). Function error codes are network-specific.

TCP/IP Ethernet Error Codes

An error in an MSTR routine over TCP/IP Ethernet may produce one of the following errors in the MSTR *control block*:

Hex Error Code	Meaning
1001	User has aborted the MSTR element.
2001	An unsupported operation type has been specified in the <i>control block</i> .
2002	One or more <i>control block</i> parameters has been changed while the MSTR element is active (applies only to operations that take multiple scans to complete). <i>Control block</i> parameters may be changed only when the MSTR element is not active.
2003	Invalid value in the length field of the <i>control block</i> .
2004	Invalid value in the offset field of the <i>control block</i> .
2005	Invalid values in the length and offset fields of the <i>control block</i> .
2006	Invalid slave device data area.
3000	Generic Modbus fail code.
30ss*	Modbus slave exception response.
4001	Inconsistent Modbus slave response.
F001	Option Module not responding

* The ss subfield in error code 30ss is shown in the following table.

ss Hex value	Meaning
01	Slave device does not support the requested operation.
02	Nonexistent slave device registers requested.
03	Invalid data value requested.
04	
05	Slave has accepted long-duration program command.
06	Function can't be performed now; a long-duration command is in effect.
07	Slave rejected long-duration program command.

An error on the TCP/IP Ethernet network itself may produce one of the following errors in the MSTR *control block*:

Hex Error Code	Meaning
5004	Interrupted system call.
5005	I/O error.
5006	No such address.
5009	The socket descriptor is invalid.
500C	Not enough memory.
500D	Permission denied.
5011	Entry exists.

Hex Error Code	Meaning
5016	An argument is valid
5017	An internal table has run out of space.
5020	The connection is broken.
5023	This operation would block and the socket is nonblocking.
5024	The socket is nonblocking and the connection cannot be completed.
5025	The socket is nonblocking and a previous connection attempt has not yet completed.
5026	socket operation on a nonsocket.
5027	The destination address is invalid.
5028	Message too long.
5029	Protocol wrong type for socket.
502A	Protocol not available.
502B	Protocol not supported.
502C	Socket type not supported.
502D	Operation not supported on socket.
502E	Protocol family not supported.
502F	Address family not supported.
5030	Address is already in use.
5031	Address is not available.
5032	Network is down.
5033	Network is unreachable.
5034	Network dropped connection on reset.
5035	The connection has been aborted by the peer.
5036	The connection has been reset by the peer.
5037	An internal buffer is required, but cannot be allocated.
5038	The socket is already connected.
5039	The socket is not connected.
503A	Can't send after socket shutdown.
503B	Too many references; can't splice.
503C	connection timed out.
503D	The attempt to connect was refused.
5040	Host is down.
5041	The destination host could not be reached from this node.
5042	Directory not empty.
5046	NI_INIT returned

Hex Error Code	Meaning
5047	The MTU is invalid
5048	The hardware length is invalid.
5049	The route specified cannot be found.
504A	Collision in select call: these conditions have already been selected by another task.
504B	The task id is invalid.

CTE Error Codes

The following error codes are returned if there is a problem with the Ethernet configuration extension table (CTE) in your program configuration.

Hex Error Code	Meaning
7001	There is no Ethernet configuration extension.
7002	The CTE is not available for access.
7003	The offset is invalid.
7004	The offset + length is invalid.
7005	Bad data field in the CTE.

3.2.4 Read and Write MSTR Operations

An MSTR Write operation (type 1 in the displayed register of the top node) transfers data from a master source device to a specified slave destination device on the network. An MSTR Read operation (type 2 in the displayed register of the top node) transfers data from a specified slave source device to a master destination device on the network. Read and Write use one data master transaction path and may be completed over multiple scans.



Note: TCP/IP Ethernet routing must be accomplished via standard third-party Ethernet IP router products.

Control Block Utilization

The registers in the MSTR *control block* (the top node) contain the Read or Write information as described in the following table:

Register	Function	Content	
Displayed	Operation Type	1 = Write, 2 = Read.	
First Implied	Error status	Displays a hex value indicating an MSTR error.	
		Exception response, where response size is incorrect.	Exception code + 3000
		Exception response where response size is incorrect.	4001
		Read Write	

Register	Function	Content
Second implied	Length	Write = number of registers to be sent to slave. Read = number of registers to be read from slave.
Third implied	Slave device data area	Specifies starting 4x register in the slave to be read from or written to (1 = 4001, 49 =40049).
Fourth implied	Low byte	Quantum backplane slot address of the NOE module.
Fifth ... eighth implied	Destination	Each register contains one byte of the 32-bit IP address.

3.2.5 Get Local Statistics MSTR Operation

The Get Local Statistics operation (type 3 in the display register of the top node) obtains information related to the local node where the MSTR has been programmed. (See page page 40 for a listing of the TCP/IP Ethernet network statistics).

Control Block Utilization

The registers in the MSTR *control block* (the top node) contain the Get Local Statistics information as described in the following table:

Register	Function	Content
Displayed	Operation Type	3
First implied	Error status	Displays a hex value indicating an MSTR error, when relevant.
Second implied	Length	Starting from <i>offset</i> , the number of words of statistics from the local processor's statistics table; the <i>length</i> must be $> 0 \leq \text{data area}$.
Third implied	Offset	An offset value relative to the first available word in the local processor's statistics table. If the offset is specified as 1, the function obtains statistics starting with the second word in the table.
Fourth implied	Low byte	Quantum backplane slot address of the NOE module.
Fifth .. Eighth implied	Not applicable	

3.2.6 Clear Local Statistics MSTR Operation

The Clear Local Statistics operation (type 4 in the displayed register of the top node) clears statistics relative to the local node where the MSTR has been programmed.

Control Block Utilization

The registers in the MSTR *control block* (the top node) contain the Clear Local Statistics information as described in the following table:

Register	Function	Content
Displayed	Operation Type	4
First implied	Error status	Displays a hex value indicating an MSTR error, when relevant.
Second implied	Not applicable	
Third implied	Not applicable	
Fourth implied	Low byte	Quantum backplane slot address of the NOE module.
Fifth ... Eighth implied	Not applicable	

3.2.7 Get Remote Statistics MSTR Operation

The Get Remote Statistics operation (type 7 in the displayed register of the top node) obtains information relative to remote nodes on the network. This operation may require multiple scans to complete and does not require a master data transaction path. (See page page 40 for a listing of the TCP/IP Ethernet network statistics).

The remote comm processor always returns its complete statistics table when a request is made, even if the request is for less than the full table. The MSTR instruction then copies only the amount of words you have requested to the designated 4x registers.



Note: TCP/IP Ethernet routing must be accomplished via standard third-party Ethernet IP router products.

Control Block Utilization

The registers in the MSTR *control block* (the top node) contain the Get Remote Statistics information as described in the following table:

Register	Function	Content
Displayed	Operation Type	7
First implied	Error status	Displays a hex value indicating an MSTR error, when relevant.
Second implied	Length	Starting from an <i>offset</i> , the number of words of statistics from the local processor's statistics table. The length must be $> 0 \leq \text{data area}$.
Third implied	Offset	Specifies an offset value relative to the first available word in the local processor's statistics table. If the offset is specified as 1, the function obtains statistics starting with the second word in the table.
Fourth implied	High byte	Destination index.
Fifth ... Eighth implied	Destination	Each register contains one byte of the 32-bit IP address.

3.2.8 Clear Remote Statistics MSTR Operation

The Clear Remote Statistics operation (type 8 in the displayed register of the top node) clears statistics relative to a remote network node from the *data area* in the local node. This operation may require multiple scans to complete and uses a single data master transaction path.

Control Block Utilization

The registers in the MSTR *control block* (the top node) contain the Clear Remote Statistics information as described in the following table:

Register	Function	Content
Displayed	Operation Type	8
First implied	Error status	Displays a hex value indicating an MSTR error, when relevant.
Second implied	Not applicable	
Third implied	Not applicable	
Fourth implied	High byte	Destination index.
Fifth ... Eighth implied	Destination	Each register contains one byte of the 32-bit IP address.

3.2.9 Peer Cop Health MSTR Operation

The peer cop health operation (type 9 in the displayed register of the top node) reads selected data from the peer cop communications health table and loads that data to specified 4x registers in state RAM. The peer cop communications health table is 12 words long, and the words are indexed via this MSTR operation as words 0 ... 11.

Control Block Utilization

The registers in the MSTR *control block* (the top node) contain the information for a Peer Cop Health operation as described in the following table:

Register	Function	Content
Displayed	Operation Type	9
First implied	Error status	Displays a hex value indicating an MSTR error, when relevant.
Second implied	Data Size	Number of words requested from peer cop table (range 1 ... 12).
Third implied	Index	First word from the table to be read (range 0 ... 11, where 0 = the first word in the peer cop table and 11 = the last word in the table).
Fourth implied	Low byte	Quantum backplane slot address of the NOE module.
Fifth ... Eighth implied	Destination	Each register contains one byte of the 32-bit IP address.

Peer Cop Communications Health Status Information

The peer cop communications health table (shown below) comprises 12 contiguous registers that can be indexed in an MSTR operation as words 0 ... 11. Each bit in each of the table words is used to represent an aspect of communications health relative to a specific node on the TCP/IP network:

- The bits in words 0 ... 3 represent the health of the global input communication expected from nodes 1 ... 64. Since global input is not supported these bits are set to zero.
- The bits in words 4 ... 7 represent the health of the output from a specific node.
- The bits in words 8 ... 11 represent the health of the input to a specific node.

Type of Status	Word Index	Bit-To-Network Node Relationship
Global Input	0	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
	1	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
	2	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
	3	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
Specific Output	4	16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1
	5	32 31 30 29 28 27 26 25 24 23 22 21 20 19 18 17
	6	48 47 46 45 44 43 42 41 40 39 38 37 36 35 34 33
	7	64 63 62 61 60 59 58 57 56 55 54 53 52 51 50 49
Specific Input	8	16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1
	9	32 31 30 29 28 27 26 25 24 23 22 21 20 19 18 17
	10	48 47 46 45 44 43 42 41 40 39 38 37 36 35 34 33
	11	64 63 62 61 60 59 58 57 56 55 54 53 52 51 50 49

The state of a peer cop health bit reflects the current communication status of its associated node:

- A health bit is set when data is successfully exchanged with its corresponding node.
- A health bit is cleared when no communication has occurred with the corresponding node within the configured peer cop health time-out period.
- All health bits are cleared at PLC start time. The health bit for a given node is always zero when its associated peer cop entry is null.
- All global health bits are always reported as zero.

3.2.10 Reset Option Module MSTR Operation

The Reset Option Module operation (type 10 in the displayed register of the top node) causes a Quantum web embedded server module to enter a reset cycle to reset its operational environment.

Control Block Utilization

The registers in the MSTR *control block* (the top node) contain the Reset Option Module information as described in the following table:

Register	Function	Content
Displayed	Operation Type	10
First implied	Error status	Displays a hex value indicating an MSTR error, when relevant.
Second implied	Not applicable	
Third implied	Not applicable	
Fourth implied	Low byte	Quantum backplane slot address of the web embedded server module.
Fifth ... Eighth implied	Not applicable	

3.2.11 Read CTE (Config Extension Table) MSTR Operation

The Read CTE operation (type 11 in the displayed register of the top node) reads a given number of bytes from the Ethernet configuration extension table to the indicated buffer in PLC memory. The bytes to be read begin at a byte offset from the beginning of the CTE. The content of the Ethernet CTE table is displayed in the middle node of the MSTR block.

Control Block Utilization

The registers in the MSTR *control block* (the top node) contain the Read CTE information as described in the following table:

Register	Function	Content
Displayed	Operation Type	11
First implied	Error status	Displays a hex value indicating an MSTR error, when relevant.
Second implied	Not applicable	
Third implied	Not applicable	
Fourth implied	Low byte	Quantum backplane slot address of the web embedded server module.
Fifth ... Eight implied	Not applicable	

CTE Display Implementation

The values in the Ethernet configuration extension table (CTE) are displayed in a series of registers in the middle node of the MSTR instruction when a Read CTE operation is implemented. The middle node contains the first of 11 contiguous 4x registers. The registers display the following CTE data:

Parameter	Register	Content
Frame type	Displayed	1 = 802.3
		2 = Ethernet
IP Address	First implied	First byte of the IP address
	Second implied	Second byte of the IP address
	Third implied	Third byte of the IP address
	Fourth implied	Fourth byte of the IP address
Subnetwork mask	Fifth implied	Hi word
	Sixth implied	Low word
Gateway	Seventh implied	First byte of the gateway
	Eighth implied	Second byte of the gateway
	Ninth implied	Third byte of the gateway
	Tenth implied	Fourth byte of the gateway

3.2.12 Write CTE (Config Extension Table) MSTR Operation

The Write CTE operation (type 12 in the displayed register of the top node) reads an indicated number of bytes from PLC memory, starting at a specified byte address, to an indicated Ethernet configuration extension table at a specified offset. The content of the Ethernet CTE table is displayed in the middle node of the MSTR block.

Control Block Utilization

The registers in the MSTR *control block* (the top node) contain the Write CTE information as described in the following table:

Register	Function	Content
Displayed	Operation Type	12
First implied	Error status	Displays a hex value indicating an MSTR error, when relevant.
Second implied	Not applicable	
Third implied	Not applicable	
Fourth implied	Low byte	Quantum backplane slot address of the NOE module.
Fifth ... Eight implied	Not applicable	

CTE Display Implementation

The values in the Ethernet configuration extension table (CTE) are displayed in a series of registers in the middle node of the MSTR instruction when a Write CTE operation is implemented. The middle node contains the first of 11 contiguous 4x registers. The registers display the following CTE data:

Parameter	Register	Content
Frame type	Displayed	1 = 802.3
		2 = Ethernet
IP Address	First implied	First byte of the IP address
	Second implied	Second byte of the IP address
	Third implied	Third byte of the IP address
	Fourth implied	Fourth byte of the IP address
Subnetwork mask	Fifth implied	Hi word
	Sixth implied	Low word
Gateway	Seventh implied	First byte of the gateway
	Eighth implied	Second byte of the gateway
	Ninth implied	Third byte of the gateway
	Tenth implied	Fourth byte of the gateway

3.2.13 TCP/IP Ethernet Statistics

A TCP/IP Ethernet board responds to “Get Local Statistics” and “Set Local Statistics” commands with the following information:

Word	Meaning
00 ... 02	MAC address
03	Board Status
04 and 05	Number of receiver interrupts
06 and 07	Number of transmitter interrupts
08 and 09	Transmit _ timeout error count
10 and 11	Collision_detect error count
12 and 13	Missed packets
14 and 15	Memory error
16 and 17	Number of times driver has restarted lance
18 and 19	Receive framing error
20 and 21	Receiver overflow error
22 and 23	Receive CRC error
24 and 25	Receive buffer error
26 and 27	Transmit silo underflow
28 and 29	Late collision
30 and 31	Lost carrier
32 and 33	Number of retries
34 and 35	IP address

Retrieving Data via the World Wide Web

4

4.1 Introduction

Each Ethernet web embedded server module contains a World Wide Web server. Pages on the embedded web site display:

- the Ethernet statistics for the node
- the controller's configuration
- the controller's register values
- the controller's configuration
- the status, configuration and register values of remote I/O
- the status, configuration and register values of distributed I/O

The web pages can only be viewed across the World Wide Web using either Netscape Navigator version 4.06 (or higher), or Internet Explorer version 4.0 w/ SP1 (or higher), both of which support JDK 1.1.6 (or higher).

4.2 Accessing the Web Utility Home Page

Before you can access the module's home page, you must learn its full IP address or URL from your system administrator. Type the address or URL in the Address or Location box in the browser window which will then bring Schneider's web utility home page onto the screen. (See Figure 17.)



Figure 17 Web Utility Home Page

Select "Diagnostics and Online Data Editor" from the web utility home page to bring the Quantum Web utility page onto the screen. (See Figure 18.)



Figure 18 Quantum Web Utility Page

4.3 Web Utility for Quantum Page

The Quantum web utility page contains hyperlinks to seven pages of data:

- Configured Local Rack
- Controller Status
- Ethernet Statistics
- RIO Status
- Configured RIO
- Configured DIO
- Data Editor

These pages are discussed in detail in the *Web Utility Users Manual for Quantum & Premium PLCs*, 890 USE 152 00.

Using the Network Options Ethernet Tester

5

5.1 Introduction

An Ethernet module may act as a client or as a server.

If it will be acting as a client -- that is, initiating transactions on the network for its Quantum controller -- then you must program an MSTR block in ladder logic.

For details about the MSTR block, please refer to Chapter 3 on page 25.

The Ethernet module may also act as a server, responding to requests and commands from devices on the network for its Quantum controller.

The Network Options Ethernet Tester utility allows you to get and clear statistics and to read and write registers over the network, using a Windows-based PC.

You may also create your own program using the Ethernet module as a server. For guidance in creating your own program, refer to Appendix B on page 65.



Note: In its capacity as server, the Ethernet module can only accept 20 connections at any one time. If a new connection is attempted and the server has already reached its limit, it will terminate the least used connection in order to make room for the new one.

5.2 Installing the Network Options Ethernet Tester

Insert the utility diskette in your disk drive. Run A:\Setup.exe.

5.3 Establishing a Connection with an Ethernet Module

To establish a connection with an Ethernet module using the Network Options Ethernet Tester, you must know the module's IP network address or host name.




Figure 19 Initial Menu



From the initial menu, select **File** and choose **New** from the options in the pulldown menu *or* click on the new connection button in the toolbar.

Type the module's IP network address or host name in the box provided. Click the **OK** button. This dedicates a connection from your PC to the designated Ethernet module and brings you to the main menu.




Figure 20 Main Menu



To activate the connection, select **Management** and choose **Connect** from the pulldown menu *or* click on the connect button in the toolbar.



When you are ready to disconnect, select **Management** and choose **Disconnect** from the pulldown menu *or* click on the disconnect button in the toolbar.

You may establish several connections with the same module or with other modules by selecting **New** from the **File** pulldown menu *or* by clicking on the create new connection button in the toolbar. Each connection has its own window within the main window. The **Window** pulldown menu gives you options for arranging connection windows and allows you to select one. The options available on the pulldown menus and toolbar in the main window apply to the selected connection.

After disconnecting from one module, you may reassign its dedicated connection by selecting **Management** and choosing **Set IP Address** from the pulldown menu. Type the new IP network address or host name in the box provided.

5.4 Getting and Clearing Statistics



To get statistics from the Ethernet module, select **Messages** and choose **Get Statistics** from the pulldown menu *or* click on the get statistics button in the toolbar.




Figure 21 Get Statistics Box

The polling interval is the number of seconds between transactions. Type a polling interval in the box provided and click **OK**. Complete statistics for the module will be printed in the window for this connection.



Similarly, to clear statistics, select **Messages** and choose **Clear Statistics** from the pulldown menu *or* click on the clear statistics button in the toolbar.

Type a polling interval in the box provided and click **OK**. The first line in the statistics, total transaction count, indicates how many transactions have been completed.

To change the polling interval without interrupting communication with the Ethernet module, select **Messages** and choose **Poll Interval**. Type the new polling interval in the box.

The Network Options Ethernet Tester will provide the following statistics:

- Total Transaction Count. How many transactions have been completed.
- IP Address.

- MAC Address.




Figure 22 Sample Statistics

- Status. The hex value displayed may be 0001, 8001 or C001:
 - 0001 indicates that the module is running, the Link indicator is not lit and no entry exists in the crash log
 - 8001 indicates that module is running and the Link indicator is lit. No entry exists in the crash log.
 - C001 indicates that the module is running, the Link indicator is lit and an entry exists in the crash log.

- Receive Interrupts and Transmit Interrupts. The number of times the PCNET controller chip has generated interrupts.
- Transmit timeout errors. The number of times the transmitter has been on the channel longer than the interval required to send the maximum length frame of 1519 bytes. This is also known as a babble error.
- Collision errors. The number of collisions detected by the Ethernet chip.
- Missed packet errors. The number of times a received frame was dropped because a receive descriptor was not available.
- Memory errors. The number of times an Ethernet controller chip experienced an error accessing shared RAM. A memory error will cause a restart.
- PcNet restart count. The number of times the Ethernet controller chip was restarted due to fatal runtime errors, including memory errors, transmit buffer errors and transmit underflow.
- Framing error. The number of times an incoming frame contained a non-integer multiple of eight bits.
- Overflow errors. The number of times the receiver has lost part or all of an incoming frame, due to an inability to store the frame in memory before the internal FIFO overflowed.
- CRC errors. The number of times a CRC (FCS) error was detected on an incoming frame.
- Receive buffer errors. The number of times a receive buffer was not available while data chaining a received frame.
- Transmit buffer errors. The number of times the end packet flag on the current buffer was not set and the Ethernet controller did not own the next buffer. A transmit buffer error causes a restart.
- Silo Underflow. The number of times a packet was truncated due to data late from memory. A Silo Underflow will cause a restart.
- Late Collision. The number of times a collision was detected after the slot time of the channel had elapsed.
- Lost Carrier. The number of times a carrier was lost during a transmission.
- Transmit retries. The number of times the transmitter has failed after 16 attempts to transmit a message, due to repeated collisions.

These statistics also may be obtained from the MSTR block. Refer to the *Ladder Logic Block Library User Guide* for details.

5.5 Reading and Writing Registers



To read registers, select **Messages** and chose **Read Registers** from the pulldown menu *or* click on the read register button in the toolbar.

The screenshot shows a dialog box titled "Read Registers". It has a standard window title bar with a close button. The dialog contains three input fields, each with a label above it: "Polling Interval" (value: 1), "Starting 4X Register" (value: 800), and "Number of registers to read" (value: 50). To the right of these fields are two buttons: "OK" and "Cancel".

Figure 23 Read Register Box

Type in a polling interval, the first 4x register you want to read and the number of registers to read. The polling interval is the number of seconds between transactions. When typing the 4x register number, omit the leading 40 or 400, as in Figure 23 above.

Click **OK**. The register values will be displayed in the window for this connection. Five values will be listed in each row, with the number of the first register at the beginning of the row.



To write registers, select **Messages** and choose **Write Registers** from the pulldown menu *or* click on the write register button in the toolbar.

Type in a polling interval, the first register you want to write, the number of registers to write and data to be written to those registers. The polling interval is the number of seconds between transactions. When typing the 4x register number, omit the leading 40 or 400, as in Figure 24 below.

If you select the **Increment Write Data** box, the value of the data you have entered will be increased by one with each transaction. The write data will be displayed in the window for this connection.

To change the polling interval without interrupting communication with the Ethernet module, select **Messages** and choose **Poll Interval**. Type the new polling interval in the box.

The image shows a dialog box titled "Write Register". It has a standard window title bar with a close button. The dialog contains the following elements:

- Polling Interval:** A text input field containing the number "1".
- First 4X register to write:** A text input field containing the number "800".
- Number of registers to write:** A text input field containing the number "50".
- Write Data:** A text input field containing the number "1".
- Increment Write Data:** A checkbox that is checked (indicated by an 'x' in the box).
- Buttons:** "OK" and "Cancel" buttons are located on the right side of the dialog.

Figure 24 Write Register Box

If you try to read or write registers and an error occurs, the NOE Tester will display a Read Request Error or Write Request Error. The error codes correspond with MSTR block error codes. For more information, refer to the *Ladder Logic Block Library User Guide*.

6.1 Responding to Errors

6.1.1 Detecting Errors

When faults occur, the LED display can help you determine what went wrong. During normal operation, the LEDs should display the following pattern:




Figure 25 LED Display During Normal Operation

The **Run** indicator will flash. The **Coll** LED also may flash, indicating that collisions are occurring on the Ethernet network. Such collisions are normal.

If a fault has occurred, the normal LEDs may be extinguished or other indicators may light. This section will discuss errors reported by the **Active, Ready, Coll, Link, Kernel, Appl** and **Fault** indicators.

For each type of error, try the suggested remedies in the order given. If no remedy suggested here overcomes the error, consult your Schneider Automation customer representative.

Certain error codes are recorded in the MSTR block. For instructions on how to read and interpret those codes through Modsoft, please refer to *MSTR Function Error Codes* on page 28.

6.1.2 Active LED

If the **Active** LED fails to light, the module is not communicating with the backplane.

Troubleshooting

1. Make sure the Ethernet web embedded server module and the controller are installed properly. Verify that the controller is functioning.

If the controller is not functioning, replace it. If neither the new controller nor the Ethernet module will function, replace the backplane.
2. Make sure that no more than two network option modules -- including NOE, NOM, NOP and CRP 811 modules -- have been installed in the backplane with a 140 CPU 113 or 213; no more than six network option modules with a 140 CPU 424, 434 or 534.
3. Check the version of the controller executive. You must have version 1.1 or greater to support the Ethernet web embedded server module. Earlier versions do not recognize the module.
4. Replace and return the faulty Ethernet web embedded server module.

6.1.3 Ready LED

If the **Ready** LED fails to light, the module has failed internal diagnostic tests.

Troubleshooting

1. Make sure that power has been applied to the backplane.
2. Replace and return the faulty Ethernet web embedded server module.

6.1.4 Link LED

If the **Link** LED fails to light, the module is not communicating with the Ethernet hub.

Troubleshooting

1. Make sure that the cable has been installed correctly and the module is functioning properly.
2. Verify that the hub is working properly.

6.1.5 Kernel LED

If the **Ready** LED is on and the **Kernel** LED is flashing, the module has detected an invalid software image. If the **Ready** LED is on and the **Kernel** LED is shining steadily, an attempt to download a software image has failed and the module is in kernel mode.

In either case, download a new software image, using the procedure on page 61.

6.1.6 Fault LED




Figure 26 LED Display When the Error Log is Full

The **Fault** LED will flash briefly following an error as the module attempts to recover. The **Fault** indicator will remain on only when the error log is full (the error log has space for 1023 entries). In that case, the module will be unable to recover. Use the ERRLOG utility to clear the error log, as described on page 57.

6.1.7 Collision LED

If the twisted pair cable has not been connected properly, the **Coll** LED will shine steadily and the **Link** LED will be extinguished. (This condition does not occur with fiber optic modules.)




Figure 27 LED Display for Improperly Connected Twisted Pair Cable

Troubleshooting

1. Make sure the cable has been installed properly and is working properly.
2. Verify that the Ethernet hub is functioning properly.




Figure 28 LED Display When Ethernet Collisions Are Occurring

If the **Coll** LED is flashing, the module is reporting collisions on the Ethernet network. While such collisions are normal, the frequency of the flashes is an indication of the volume of traffic on the network. The flashes may be so frequent that the LED appears to be shining steadily. Heavy traffic will slow communications. If response time is important to your application, you should consider segmenting your network to reduce the frequency of collisions.

6.1.8 Application LED

If the module crashes, it will note the reason in a log. If the module is able to recover, the **Appl** LED will light, indicating that an entry has been made in the error log. To learn how to read and clear the error log, refer to the section below.

6.1.9 Reading and Clearing the Error Log

If the **Appl** indicator is lit, entries have been made in the error log. The log may hold up to 1023 entries. If the error log is full, the **Fault** indicator will remain on and the module will be unable to recover until the log is cleared.

You may read the error log while the controller is running or stopped, using the ER-RLOG utility. However, if you plan to clear the error log, you must stop the controller first. During the program, ERRLOG will ask you whether you want to stop the controller. If you respond yes, it will stop and restart the controller for you.



CAUTION

PROCESS INTERRUPTION

Do not stop the controller unless it is safe to stop the operations it is controlling. When a controller is stopped, all operations under its control will also stop.

Failure to observe this precaution can result in injury or equipment damage.

To read the error log, at the DOS prompt in the appropriate directory, type:

```
ERRLOG <routing path> <slot> [/d] [/sxx] [/ny]
```

where <routing path> is the Modbus Plus address of the Quantum PLC

<slot> is the slot number of the Ethernet web embedded server module.

[/d] is optional, to enable debug messages. Default is no debug.

[/sxx] is optional and specifies the software interrupt to use, xx in hexadecimal. The default is 5c.

[/ny] is optional and specifies the Modbus Plus adapter number to use, y.

The default is 0.

Example ERRLOG 49 1

This is the minimum command. It will display the error log of the Ethernet web embedded server module in slot 1 of the controller at Modbus Plus address 49.

.

Example ERRLOG 49.50 4 /d /s5d /n1 > TRACE.OUT

This will display the error log of the Ethernet web embedded server module in slot 4 of the controller at Modbus Plus address 49.50. It will display debug information, use software interrupt 5d and use Modbus Plus adapter number 1. The output will be redirected to a file named TRACE.OUT.

If you have entered a viable command, ERRLOG will respond:

```
Path DM. x. x. x. x. x was opened
```

where *x* is the Modbus Plus address of the Quantum controller.

Next, it will list the number and date of the Quantum Ethernet web embedded server firmware version.

Then, for each entry in the error log, ERRLOG will display the following information:

Error log entry number.

File name:Line:error code:

The ten registers of the microprocessor in hexadecimal (EAX, EDX, ECX, EBX, EBP, ESI, EDI, ESP, EFLAGS, EIP).

For hardware exceptions, the file name and line number will be replaced by the hardware exception vector number in decimal.

If you have requested debug messages, ERRLOG will also display the Modbus messages and responses between the controller and the PC.

Example Sample Error Log

```
Path DM. 24. 0. 0. 0. 0 was opened.
Quantum Ethernet firmware Ver. 1.00 07/15/96 09:31:35
Error Log Entry Number: 1
File name: user_lgc.cpp, Line: 200, error code: 0x0101
EAX=00000001 EDX=00000001 ECX=00300101 EBX=00000000
EBP=00012efc ESI=00000000 EDI=00000000 ESP=00012edc
EFLAGS=00000046 EIP=03f0e0f4
```

Record the information in the entry and report it to your Schneider Automation customer representative.

After displaying all entries, ERRLOG will prompt:

```
Clear the Error Log? (N)
```

If you do not want to clear the log, enter the default N. If you want to clear the log, type Y. If you enter Y, ERRLOG will ask:

```
Do you wish to stop the PLC? (N)
```

Again, enter Y or N. Remember that the controller must be stopped before you can clear the log.

If you enter Y, ERRLOG will stop the controller and clear the log. Then it will prompt:

```
Do you wish to re-start it? (N)
```

To restart the controller, type Y.

6.2 Hot Swapping An Ethernet Module

You may replace your Ethernet web embedded server module while the controller is running. However, you should first make sure that the IP network address of the replacement module will be unique on your network.

The new Ethernet module will inherit any configuration changes you had made. If the original Ethernet module was given a user-configured address, the new module will assume that address. If you will be using the default address, check with your system administrator to ensure that address is not already in use on your network.

To hot swap the module, simply disconnect the cable and remove the old module from the backplane. Then insert the new module in the slot and reconnect the cable.

If you are replacing the module because it failed, be aware that you may have lost several transactions. These transactions are not captured in memory and cannot be recovered by the new module.

6.3 Downloading a New Software Image

From time to time, Schneider Automation may release improved versions of the Quantum Ethernet embedded server firmware. These new software images may be downloaded through Modsoft using the following procedure.

1. Stop the controller.
2. From the main Modsoft menu, select **Transfer**. From the Transfer pulldown menu, select **Download Exec**.




Figure 29 Main Menu Transfer Options

3. From the Device to Download menu, select **Local Head**.




Figure 30 Download Device Options

Now you must specify which PLC is controlling the Ethernet web embedded server module and the backplane slot (head) number for that module.

4. Modsoft will prompt you for the filename of the executive. It is referring to the new software image. Load the diskette with the file in the floppy drive and type the drive designation and filename in the space provided, separated by a colon, ie. `a:\filename.ext`.
5. Restart the controller.

Specifications



Communication Ports	
Ethernet ports transmit and receive Modbus commands encapsulated in TCP/IP protocol: TCP/UDP system port number 502 used with ASA protocol_id of 0	
NOE 211 10	1 10BASE-T Ethernet network (RJ-45) port
NOE 251 10	1 10BASE-FL Ethernet network (ST-style) port
Power Dissipation	5 W
Bus Current Required	1 A
Operating Conditions	
Temperature	0 to 60°C
Humidity	0 to 95% Rh noncondensing @ 60°C
Altitude	15,000 ft (4500 m)
Vibration	10-57 Hz @ 0.0075 mm d.a. 57-150 Hz @ 1 g
Storage Conditions	
Temperature	-40 to +85°C
Humidity	0 to 95% Rh noncondensing @ 60°C
Free Fall	1 m unpackaged
Shock	3 shocks / axis, 15 g, 11 ms

Ethernet Developers Guide



B

B.1 Introduction

This appendix describes the design of the sample TCP/IP application named Network Options Ethernet Tester (NOET). The NOET application is a multiple document interface windows application that verifies the installation of the Quantum Ethernet TCP/IP module and also serves as a sample application for developers.

TCP/UDP system port number 502 is used with ASA protocol_id of 0.

B.2 References

Inside Visual C++, Second Edition, David J. Kruglinski

Window Sockets, An Open Interface for Network Programming under Microsoft® Windows Version 1.1

B.3 Overview

The sample application performs the following steps:

- Calls the window socket function **socket** to create a socket.
- Calls the window socket function **setsockopt** to set the socket attributes.
- Calls the window socket function **connect** to establish a connection.
- Encodes the request. The request consists of a header followed by a Modbus message. The header contains an invoke identifier, a protocol type, the command length, and a destination identifier.

Invoke Identifier	Protocol Type	Command Length	Destination ID	Modbus Message
-------------------	---------------	----------------	----------------	----------------

- Calls the window socket function **send** to transmit the request to the remote node.
- Calls the window socket function **recv** to receive the response from the remote node.
- Calls the window socket function **closesocket** to close the connection and release the socket.

The winsock.lib import library provided by the installation is used to link the window socket calls.

B.4 Development Environment

The sample application was developed with Microsoft Visual C++, version 1.52. The sample application uses Microsoft Foundation Class. The initial application was generated by the Visual C++ application wizard.

B.5 Class Descriptions

The following list describes the different classes:

1. **CSample_app.** The Csample_app is the application class. This application was generated by the application wizard, and the source is in the file sam_app.cpp. The class declaration is in sam_app.h.
2. **CMainFrame.** The CMainFrame is derived from the MFC class CMDIFrameWnd and is the application's main window frame. The source for CMainFrame is in mainfrm.cpp, and the declaration is in mainfrm.h. The code for CMainFrame was initially generated by the application wizard, and was modified to process window timer messages.
3. **CSample_doc.** The CSample_doc is the document class. The declaration is in sam_doc.h and the implementation is in sam_doc.cpp.
4. **CSample_View.** The CSample_View is the view of the document. It is derived from the CScrollView class. The declaration is in the sam_vw.h class, and it is implemented in the sam_vw.cpp, disp.cpp, tcp_hlp.cpp, and the tx_rx.cpp files.
5. **CIP_dlg.** The CIP_dlg class is the dialog class for getting the IP address. It is derived from the CDialog class. The declaration is in the cip_dlg.h file and the implementation is in the cip_dlg.cpp file. Both of these files were generated by The Visual C++ class wizard.
6. **ClrStatsDlg.** The ClrStatsDlg class is the dialog class for clearing statistics. It is derived from the CDialog class. The declaration is in the cstatdlg.h file and the implementation is in the cstatdlg.cpp. Both of these files were generated by The Visual C++ class wizard.
7. **GetStatsDlg.** The GetStatsDlg class is the dialog class for get statistics. It is derived from the CDialog class. The declaration is in the gstatdlg.h file and the implementation is in the gstatdlg.cpp file. Both of these files were generated by The Visual C++ class wizard.
8. **CPollDlg.** The CPollDlg class is the dialog class for determining the poll period. It is derived from the CDialog class. The declaration is in the polldlg.h file, and the implementation is in the polldlg.cpp file. Both of these files were generated by The Visual C++ class wizard.

9. **CReadDlg.** The CReadDlg class is the dialog class for determining the registers to read. It is derived from the CDialog class. The declaration is in the readdlg.h file, and the implementation is in the readdlg.cpp file. Both of these files were generated by The Visual C++ class wizard.
10. **CWriteDlg.** The CWriteDlg class is the dialog class for determining the registers to write and the write data. It is derived from the CDialog class. The declaration is in the writedlg.h and the implementation is in the writedlg.cpp file. Both of these files were generated by The Visual C++ class wizard.
11. **CAboutDlg.** The CAboutDlg class is the dialog class for **about**. Both the declaration and its implementation are in the sam_app.cpp file.

B.6 The CSample_doc Class

The CSample_doc (the document class) contains the user data used by the CSample_View class. The user data consists of the remote node's IP address, the transaction type and its associated values. The different transaction types are read register, write register, clear statistics, and get statistics. In addition to the transaction type and the associated values, the document class also contains the poll interval.

A user modifies the user data via a menu or tool bar. The CSample_doc processes the menu or tool bar window command message by invoking the corresponding dialog. The state of the various menu items and tool bar buttons depends on the connection state between the application and the remote node. The CSample_View class maintains the connection state, and hence sets the state of the menu items and tool bar buttons.

B.7 The CSample_View Class

The CSample_View class manages the TCP/IP connection, sends requests to remote nodes, and displays either connection state, or the results of a transaction. In addition it sets the states of the tool bar buttons and menu items.

B.7.1 Accessing TCP/IP

The CSample_View interfaces with window sockets via its application programming interface, and via messages sent by the window sockets DLL to the CSample_View window. The reference for the window socket API is given above. The first call made to the window sockets DLL must be WSASStartup. This call is made by InitInstance member function of the CSample_app class. The last call to the window socket DLL must be WSACleanup. This call is made by the ExitInstance member function of the Csample_app class.

The CSample_View allocates and sets the socket attributes. The attributes it sets are given in the following table.

- Set Linger to cause a hard close
- Receive out of band data in the normal data stream
- Disable Nagel algorithm for send coalescing

When Nagel algorithm is disabled, if the stack receives an application message, it will immediately pass the message to the application and will send a TCP/IP acknowledgment message. Although this can generate more traffic, the application receives the message sooner than if Nagel algorithm is enabled. The member function tcpip_setsocket_options sets the socket attributes.

The window socket interface provides the WSAAsyncSelect function which notifies the window of network events. The member function tcpip_setsocket_options calls WSAAsyncSelect function. The different events are given by the following table.

Event	Description
FD_READ	A socket can read data
FD_WRITE	A socket can write data
FD_OOB	A socket can read out of band data
FD_CONNECT	A connect response has been received
FD_CLOSE	The connection has been closed

One of the parameters to the `WSAAsyncSelect` is a user defined message the window socket DLL sends to the window. The sample application user message is `WM_TCPIP_EVENT` and is defined in the file `wn_msh.h`. MFC architectural framework calls the `CSample_View tcpip_event` member function to process this message. Like all functions which process messages, `tcpip_event` parameters are a word and a long word. The word parameter is the socket, and the long word parameter contains the network event, and an error code. `Tcpip_event` examines the network event and calls the member function indicated in the following table.

Network Event	Member Function
<code>FD_READ</code>	<code>OnTcpIpRead()</code>
<code>FD_WRITE</code>	<code>OnTcpIpWrite()</code>
<code>FD_OOB</code>	<code>OnTcpIpOob()</code>
<code>FD_CONNECT</code>	<code>/OnTcpIpConnect</code>
<code>FD_CLOSE</code>	<code>OnTcpIpClose()</code>

B.7.2 Application Message Format

TCP/IP transmits a message as a stream. There is no indication of the start of a message nor the end of the message. The NOE option module adds a header to determine the message boundaries. The message is a Modbus message. The header contains the following fields.

- **Invoke Identifier.** This two byte field associates a request with the response. The client application picks the invoke identifier, and server returns the same invoke identifier in the response.
- **Protocol Type.** This two byte field identifies the protocol type. Currently, the only protocol supported is Modbus.
- **Command Length.** This two byte field is the size of the rest of the message.
- **Destination Identifier.** This one byte field is reserved for future use.

The Modbus message follows the header. The message does not contain the address field, instead, the first byte is the Modbus function code.

The data structure for the header is declared in `modbus.h` and the `CSample_View encode_header` function encodes the header. The member functions `encode_clear_stats`, `encode_read_stats`, `encode_read_rq`, and `encode_write_rq` encode the corresponding Modbus messages.

B.8 Timers

CSample_View requires to periodically receive a timer message. This message triggers the CSample_View to transmit a message. Since window timers are a limited resource, the window associated with CMainFrame class receives the timer messages. CMainFrame member AddTimerList function will place a window on its timer list. When CMainFrame processes the WM_TIMER message, it sends each window on its time list the user defined WM_POLL_INTERVAL message.

MFC calls CSample_View member OnInitialUpdate function when it is first being created. OnInitialUpdate calls CMainFrame's AddTimerList in order to receive the WM_POLL_INTERVAL message. MFC architectural framework calls CSample_View OnPollInterval member function to process this message.

B.9 Transaction Processing

CSample_View transaction processing consists of establishing a connection, transmitting the request, receiving the response, and displaying the response. CSample_View uses both a transmit and a receive state machine to advance a transaction.

B.10 Transmit State Machine

The transmit state machine establishes a connection, and periodically transmits a request. The different states for the transmit state machine are as follows.

- **IDLE.** In the IDLE state, there is no connection.
- **RESOLVING_NAME.** In the RESOLVING_NAME state, CSample_View is waiting for the window socket DLL to convert a node's name into an IP address.
- **CONNECTING.** In the CONNECTING state, CSample_View is waiting for the window socket DLL to generate the FD_CONNECT event. This event indicates if the attempt to establish a connection succeeded or failed.
- **CONNECTED.** The CONNECTED state indicates that a connection has been successfully established.
- **WAIT_TO_TX.** In the WAIT_TO_TX state, CSample_View is waiting to transmit the message. It transmits the message, when the time from the last transmit exceeds the specified poll interval.
- **BLOCKED.** When CSample_View attempts to send a message, the window socket DLL may not be able to transmit the complete message. This is a flow control condition, and CSample_View enters the BLOCKED state. The window socket DLL generates the FD_WRITE event when it can send more data.
- **TX_DONE.** CSample_View enters the TX_DONE when it has completed transmitting the request.

If the CSample_View is in the IDLE state, and user selects either the connect menu item, or the connect tool bar button, CSample_View OnManagConnect function attempts to establish connect with its tcpip_initate_connection function. This function examines the remote destination and determines if it's a name or an IP address. If it's a name, OnMangConnect changes the transmit state to RESOLVING_NAME, and it invokes the window sockets DLL WSAAsyncGetHostByName function to resolve the name. Window sockets DLL will generate the user defined WM_TCPIP_NAME_RESOLVED message which indicates if the name has been resolved. The OnTcpIpNameResolved member function process the WM_TCPIP_NAME_RESOLVED message. If the name is not resolved, OnTcpIpNameResolved changes the transmit state back to IDLE.

If the remote node is an IP address, or if it's a name that has been resolved, then `CSample_View tcpip_connect_rq` function is called to initiate a connect request to the remote node. The listen port for the connect request is five hundred and two, and is defined by the constant `MBAP_LISTEN_PORT` in `modbus.h`. If `tcpip_connect_rq` succeeded in initiating a connect request, then `tcpip_connect_rq` changes the transmit state to `CONNECTING`, otherwise it changes the transmit state to `IDLE`.

The window sockets DLL generates a `FD_CONNECT` event which indicates if the connect request succeeded or failed. `CSample_View OnTcpIpConnect` function processes the `FD_CONNECT` event. If the connect request succeeded, `OnTcpIpConnect` changes the transmit state to `CONNECTED`, otherwise it changes the state to `IDLE`.

Recall that MFC architectural framework calls `CSample_View OnPollInterval` member function to process `WM_POLL_INTERVAL` message sent as result of `CMainFrame` class processing a `WM_TIMER` message. `OnPollInterval` examines the transmit state. If the transmit state is `CONNECTED`, and the user has selected a transaction type, then `OnPollInterval` calls `CSample_View TransmitUserRequest` function.

`TransmitUserRequest` encodes a request based on the transaction type, saves the current time, and calls `CSample_View TransmitMessage` function. `OnPollInterval` uses the saved time to determine when to transmit the next request. `TransmitMessage` attempts to send a message to the remote side. To send the message, `TransmitMessage` enters a loop. In the body of the loop transmit message calls the window socket DLL send function. The following lists the outcomes of the send function and the actions taken.

- The message was sent successfully. `TransmitMessage` changes the transmit state to `TX_DONE` and exits the loop.
- Only part of the message was sent. `TransmitMessage` reenters the loop.
- Send function returns an error indicating there is no buffer space within the transport system. `TransmitMessage` changes the transmit state to `BLOCKED` and exists the loop.
- Send function returns some other error. `TransmitMessage` closes the connection, changes the transmit state to `IDLE`, and exits the loop.

When buffer space within the transport system becomes available to transmit messages, the window socket DLL generates a `FD_WRITE` event. `CSample_View OnTcpWrite` function processes the `FD_WRITE` function by calling `TransmitMessage`.

The receive state machine (which is described below) processes the response to a request. When the receive state machine has completed receiving the response, it changes the transmit state machine from the TX_DONE state to the WAIT_TO_TX state.

Recall that the TransmitUserRequest saves the time. CSample_View OnPollInterval uses this saved time to determine if a new request needs to be transmitted. OnPollInterval is called by MFC architectural framework to process the WM_POLL_INTERVAL sent when CMainFram class processes the window timer message, WM_TIMER. OnPollInterval examines the transmit state. If the transmit state is WAIT_TO_TX, and the elapsed time from the previous transmit request exceeds the poll interval, then OnPollInterval calls TransmitUserRequest to start another transaction.

B.11 Receive State Machine

The receive state machine receives a response to a transaction by first reading the header, determining the size of the rest of the message, and then reading the body of the message. The different states of the receive state machine are as follows.

- RX_HEADER. In the RX_HEADER state, the receive machine is receiving the message header.
- RX_BODY. In the RX_BODY state, the receive machine is receiving the response message associated to the requested transaction.
- DUMP_BODY. In the DUMP_BODY state, the receive message is receiving a message, but there is no associated transaction with respect to this message.

The window socket DLL generates the FD_READ event whenever there is data to be read. If only part of the data is read, it generates another event. CSample_View OnTcpIpRead function processes the FD_READ event, and drives the receive state machine.

When a FD_READ event is generated it is possible that the complete message is not present. The remote node may have attempted to send a 100 byte response, but the transport system may have only had buffer space to transmit three bytes. The receiver will get a FD_READ for the three bytes. OnTcpIpRead calls CSample_View rx_msg to read the receive data into the buffer. There are three parameters to rx_msg. The first parameter is a pointer to a receive buffer. The second input parameter is the receive size. The third parameter is both an input and output parameter. On both input and output the third parameter is the number of bytes read. These parameters allow the processing of a partially received message.

The receive state machine maintains a variable which is the number of bytes received. Initially the receive state machine is in the RX_HEADER state, and the number of bytes received is zero.

When OnTcplpRead is called and the receive state is RX_HEADER OnTcplpRead calls rx_msg with receive size equal to the header size. On return OnTcplpRead examines the number of bytes received. If the number of bytes received is not equal to the header size, then receive machine remains in the RX_HEADER state, and OnTcplpRead returns.

If upon return, the number bytes received is the same size as the header size, then the header has been received. OnTcplpRead sets the number of bytes received to zero, and the receive size is obtained from the header. These two values will be used the next time rx_msg is called. OnTcplpRead also obtains the transaction identifier and the protocol type from the header. If the transaction identifier matches the transmit request identifier and the protocol type is MODBUS, then OnTcplpRead changes the receive state to RX_BODY. However if either transaction identifier does not match or the protocol is not MODBUS, then OnTcplpRead changes the receive state to DUMP_BODY.

When OnTcplpRead is called and the receive state is RX_BODY, OnTcplpRead calls rx_msg with receive size equal to the value obtained from the header. On return OnTcplpRead examines the number of bytes received. If the number of bytes received is not equal to the receive size, then the receive machine remains in the RX_HEADER state, and OnTcplpRead returns.

If upon return the number of bytes received is the same as the receive size, then OnTcplpRead has read the response to a transaction. OnTcplpRead saves the results and invalidates the client area which causes the results to be display. OnTcplpRead also changes the transmit state to WAIT_TO_TX, and resets the state receive state machine by setting the state to RX_HEADER and the number of bytes received to zero. It then returns.

When OnTcplpRead is called and the receive state is DUMP_BODY, OnTcplpRead calls rx_msg with receive size equal to the value obtained from the header. On return OnTcplpRead examines the number of bytes received. If the number of bytes received is not equal to the receive size, then the receive machine remains in the RX_HEADER state, and OnTcplpRead returns.

If upon return the number of bytes received is the same as the receive size, the OnTcplpRead has completed reading the message. Since this message does not correspond to an transaction, the only processing OnTcplpRead performs is resetting the receive state machine.

The member function `rx_msg` calls the window socket `recv` function to read data. The `recv` function either returns a non negative number that is the number of bytes read or it returns an error. If the number bytes read is zero, then the connection no longer exists, and `rx_msg` closes the socket, and sets the transmit state to IDLE. If the `recv` function returns the error indicating that no receive data is available, then `rx_msg` just returns. For any other `recv` function error, `rx_msg` closes the socket, and sets the transmit state to IDLE.

B.12 Displaying on the Screen

`CSample_View` `m_display` member indicates the display type. The different types of the displays and the `CSample_View` member functions for showing the display are as follows.

1. `Displaying the connection state.` The different connection states displayed are IDLE, RESOLVING NAME, and CONNECTING. `ConnPaint` member function displays the connection state.
2. `GetStatsPaint` member function displays the results of a get statistics request.
3. `ClearStatsPaint` member function displays the results of a clear statistics request.
4. `ReadRegPaint` member function displays the results of a read register request.
5. `WriteRegPaint` member function displays the results of a write register request.

MFC architectural framework calls `CSample_View` `OnDraw` member function to process the window `WM_PAINT` message. `OnDraw` examines `m_display` member variable and calls the corresponding member function described in the previous paragraph. Whenever `CSample_View` needs to display a result, it calls `Cview` `Invalidate` function which causes a `WM_PAINT` message.

`CSample_View` is derived from MFC `CScrollView` class. This class handles the scroll logic. To perform the scroll logic, `CScrollView` requires the size of the document. It is informed of the document size via its `SetScrollSizes` member function.

`CSample_View` `UpdateScrollSizes` member function based on the display type calculates the document size, and then calls `SetScrollSizes`. `CSample_View` calls `UpdateScrollSizes` when the display type changes or when the user changes the window size.

Quantum Ethernet TCP/IP Modbus Application Protocol



C.1 Introduction

The Modbus Application Protocol (MBAP) is a layer-7 protocol providing peer-to-peer communication between programmable logic controllers (PLCs) and other host-based nodes on a LAN. Collectively these nodes implement all or part of a control application used for industrial automation applications in the automotive, tire and rubber, food and beverage, and utilities industries, to name a few.

Modbus protocol transactions are typical request-response message pairs. Modbus requests contain function codes representing several classes of service including data access, online programming, and program download and upload classes. Modbus responses can be ACKs with and without data, or NACKs with error information.

The Modbus Application Protocol can be transmitted over any communication system that supports messaging services. However, the current Quantum implementation transports Modbus Application Protocol PDUs over TCP/IP. Both Ethernet II and IEEE 802.3 framing are accommodated, although Ethernet II framing is the default.

For more information, consult the Modbus Protocol Reference Guide (PI-MBUS-300).

C.1.1 Modbus Application Protocol PDU

The Modbus Application Protocol PDU, `mbap_pdu`, is received at TCP port number 502. The current maximum size of the `mbap_pdu` for this class of services is 256 bytes. The structure and content of the `mbap_pdu` is defined to be:

```
mbap_pdu ::= { inv_id[2], proto_id[2], len[2], dst_idx[1], data=mb_pdu }
```

The header is seven bytes long and includes the following fields:

<code>inv_id</code>	[2 bytes] invocation id used for transaction pairing
<code>proto_id</code>	[2 bytes] used for intra-system multiplexing, default is 0 for Modbus services
<code>len</code>	[2 bytes] the len field is a byte count of the remaining fields and includes the <code>dst_id</code> and data fields

The remainder of the pdu includes two fields:

<code>dst_idx</code>	[1 byte] destination index is used for intra-system routing of packets (currently not implemented)
<code>data</code>	[n bytes] this is the service portion of the Modbus pdu, <code>mb_pdu</code> and is defined below

The service portion of the Modbus Application Protocol, called `mb_pdu`, contains two fields:

```
mb_pdu ::= { func_code[1], data[n] }
```

<code>func_code</code>	[1 byte] Modbus function code
<code>data</code>	[n bytes] this field is function code dependent and usually contains information such as variable references, variable counts and data offsets

The size and content of the data field are dependent on the value of the function code.

Example Modbus Application Protocol PDU

Here are the values for a sample mbap_pdu for reading a register:

```
00 01 00 00 00 06 01 03 00 00 00 01
```

This example has the following structure and content:

```
inv_id  00 01
        proto_id  00 00
        len       00 00
        dst_idx   01
        func_code 03
        data      00 00 00 01
```

C.1.2 Modbus Application Protocol Service Classes

There are several classes of service that are part of the Modbus Application Protocol. They include:

Data access	Read/write both discrete and analog data values from PLC register files.
Online programming	Services make relatively minor alterations to ladder logic programs with a highly controlled introduction of these changes into the executing program.
Image download/upload	Image download services support the downloading of a ladder logic control program to the PLC. Image upload services support the uploading of a ladder logic control program from a PLC to PC host for archival/backup purposes.
Configuration	Configuration services allow the user to define parameter values which affect the PLC's register files, I/O map, communication port configuration and scan attributes, to name a few.
Device execution state control	The class of service allows the user to start/stop the PLC scan execution. These services require the user to be in an application login context which is obtained through other Modbus services.

C.2 Modbus Application Protocol PDU Analysis

The Modbus Application Protocol PDU is transmitted over a TCP/IP Ethernet stack. Both Ethernet II and IEEE 802.3 framing will be accommodated. Ethernet II framing is the default.

... from the wire in for IEEE 802.3 framing ...
... is IEEE 802.3 framing if length <=1500 ...

802.3_pdu ::= {dst_addr[6], src_addr[6], length[2], data=802.2_pdu}

*an IEEE 802.3 PDU has a maxFrameSize of 1518 octets
*an IEEE 802.3 PDU has a minFrameSize of 64 octets

802.2_pdu ::= {dsap[1], ssap[1], frm_cntrl[1], snap_hdr[5], data=ip_pdu}

*the snap_hdr is associated with a "well-known" 802.2 sap snap_hdr
::={org_code[3], ethertype[2]}

*the snap_hdr (sub network access protocol) allows the older style Ethernet protocols to run on the newer IEEE 802.2 interface. The ethertype parameter indicates the service, ex. ip or arp. IP has a value 0x800.

... from the wire in for Ethernet II framing ...
... is Ethernet II framing if length >1500 ...

802.3_pdu ::= {dst_addr[6], src_addr[6], length[2], data=ip_pdu}

... the common part of the packet begins here ...

ip_pdu ::= {ip_hdr[20], data=tcp_pdu}

tcp_pdu ::= {tcp_hdr[24], data=appl_pdu=mbap_pdu}

The mbap_pdu is the Modbus Application Protocol whose messages are received at a well-known port. The current maximum size of the mbap_pdu for this class of services is 256 bytes.

The structure and content of the mbap_pdu is defined to be:

mbap_pdu ::= {inv_id[2], proto_id[2], len[2], dst_idx[1], data=mb_pdu}

The header is 7 bytes long, and includes the following fields:

inv_id[2 bytes] invocation id used for transaction pairing

proto_id[2 bytes] used for intra-system multiplexing, default is 0 for Modbus services

len[2 bytes] the len field is a byte count of the remaining fields and includes the dst_id and data fields.

The remainder of the pdu includes two fields:

dst_idx[1 byte] destination index is used for intra-system routing of packets. (currently not implemented)

data[n bytes] this is the service portion of the Modbus pdu, mb_pdu, and is defined below

The service portion of the Modbus Application Protocol, called mb_pdu, contains 2 fields:

mb_pdu ::= { func_code[1], data[n] }

func_code[1 byte] MB function code

data[n bytes] this field is function code dependent and usually contains information such as variable references, variable counts, and data offsets.

The size and content of the data field are dependent on the value of the function code.

C.3 TCP/IP Specific Issues

C.3.1 Broadcast/Multicast

Although broadcast and/or multicast are supported by both IP network address and IEEE 802.3 MAC address, the Modbus Application Protocol does not support either broadcast or multicast at the application layer.

Schneider Automation's Quantum PLCs use broadcast addressing because they use ARP as the means of locating the destination node. The client interface to the Modbus Application Protocol service on the PLC, the MSTR block, requires the user to provide the destination IP address. Also the embedded stack does use a pre-configured default gateway IP address in the case where ARP does not succeed.

C.3.2 TCP Port Number

Schneider Automation has obtained a well-known system port from an Internet Authority. Schneider Automation's well-known system port number is 502. The Internet Authority assigned the system port number 502 to asa-appl-proto with Dennis Dubé as the company point of contact.

This port number allows Schneider Automation to transport various application protocols over with TCP or UDP. The particular protocol is indicated by the value of the proto_id parameter in the mbap_pdu. Currently the only assignment is 0 meaning Modbus Application Protocol.

C.4 Reference Documents

- [1] ANSI/IEEE Std 802.3-1985, ISO DIS 8802/3, ISBN - 0-471-82749-5, May 1988
- [2] ANSI/IEEE Std 802.2-1985, ISO DIS 8802/2, ISBN 0-471-82748-7, Feb 1988
- [3] RFC793, TCP (Transmission Control Protocol) DARPA Internet Program Protocol Specification, Sep 1981
- [4] RFC 791, IP (Internet Protocol) DARPA Internet Protocol Specification, Sep 1981
- [5] RFC826, An Ethernet Address Resolution Protocol (ARP), David Plummer, NIC Sep 1982
- [6] RFC1042, A Standard for the Transmission of IP Datagrams over IEEE 802.2 Networks, Postel & Reynolds, ISI, Feb 1988
- [7] RFC 792, ICMP (Internet Control Message Protocol) DARPA Internet C Control Message Protocol Specification, Jon Postel, Sep 1981
- [8] RFC951, BOOTSTRAP PROTOCOL (BOOTP), Bill Croft and John Gilmore , September 1985
- [9] RFC783, The Trivial File Transfer Protocol (TFTP) rev 2, K.R. Sollins MIT, June 1981

Suppliers



D


A variety of Ethernet installation tools, cable diagnostic tools, cables, connectors and other related equipment is readily available from mail order suppliers or at your local computer supply store.

Cable testing equipment is available from:

- Datacom Technologies 1-800-468-5557
- Microtest, Inc. 1-800-526-9675
- Scope Communications, Inc. 1-508-393-1236
- Wavetek, Inc. 1-800-854-2708

Schneider Automation has not qualified and does not endorse any of these products.

Glossary



A

address

On a network, the identification of a station. In a frame, a grouping of bits that identifies the frame's source or destination.

API

Application Program Interface. The specification of functions and data used by one program module to access another; the programming interface that corresponds to the boundary between protocol layers.

ARP

Address Resolution Protocol. A network layer protocol used to determine the physical address which corresponds to the IP address for a host on the network. ARP is a sub-protocol which operates under TCP/IP.

B

bps

Bits per second.

bridge

A device that connects two or more physical networks which use the same protocol. Bridges read frames and decide whether to transmit or block them based on their destination address.

C

client

A computer process requesting service from other computer processes.

D

default gateway The IP address of the network or host to which all packets addressed to an unknown network or host are sent. The default gateway is typically a router or other device.

DNS Domain Name System. A protocol within TCP/IP used to find IP addresses based on host names.

F

field A logical grouping of contiguous bits that convey one kind of information, such as the start or end of a message, an address, data or an error check.

frame A group of bits which form a discrete block of information. Frames contain network control information or data. The size and composition of a frame is determined by the network technology being used.

framing types Two common framing types are Ethernet II and IEEE 802.3.

FTP File Transfer Protocol. A networking protocol used to exchange files between stations on a network or over the Internet.

G

gateway A device which connects networks with dissimilar network architectures and which operates at the Application Layer. This term may refer to a router.

H

host A node on a network.

hostname A domain name given to a specific computer on a network and used to address that computer.

HTTP HyperText Transport Protocol. A protocol used to deliver hypertext documents.

hub	A device which connects a series of flexible and centralized modules to create a network.
I	
ICMP	Internet Control Message Protocol. A protocol within TCP/IP used to report errors in datagram transmission.
Internet	The global interconnection of TCP/IP based computer communication networks.
IP	Internet Protocol. A common network layer protocol. IP is most often used with TCP.
IP Address	Internet Protocol Address. A 32-bit address assigned to hosts using TCP/IP.
IO Map	An area in the controller configuration memory used to map input and output points. Previously called traffic cop.
L	
layer	In the OSI model, a portion of the structure of a device which provides defined services for the transfer of information.
M	
MAC Address	Media Access Control address. The hardware address of a device. A MAC address is assigned to an Ethernet TCP/IP module in the factory.
N	
network	Interconnected devices sharing a common data path and protocol for communication.
node	An addressable device on a communications network.

O

OSI model Open System Interconnection model. A reference standard describing the required performance of devices for data communication. Produced by the International Standards Organization.

P

packet The unit of data sent across a network.

PING Packet Internet Groper. A program used to test whether a destination on a network can be reached.

port An access point for data entry or exit within a host using TCP services.

protocol Describes message formats and a set of rules used by two or more devices to communicate using those formats.

PLC Programmable Logic Controller

R

repeater A device that connects two sections of a network and conveys signals between them without making routing decisions or filtering packets.

router A device that connects two or more sections of a network and allows information to flow between them. A router examines every packet it receives and decides whether to block the packet from the rest of the network or transmit it. The router will attempt to send the packet through the network by the most efficient path.

S

server Provides services to clients. This term may also refer to the computer on which the service is based.

socket	The association of a port with an IP address, serving as an identification of sender or recipient.
stack	The software code which implements the protocol being used. In the case of the NOE modules it is TCP/IP.
STP	Shielded Twisted Pair. A type of cabling consisting of several strands of wire surrounded by foil shielding, twisted together.
subnet	A physical or logical network within an IP network, which shares a network address with other portions of the network.
subnet mask	Used to indicate which bits in an IP address identify a subnet.
switch	A network device which connects two or more separate network segments and allows traffic to be passed between them. A switch determines whether a frame should be blocked or transmitted based on its destination address.

T

TCP	Transmission Control Protocol.
TCP/IP	A protocol suite consisting of the Transmission Control Protocol and the Internet Protocol; the suite of communications protocols on which the Internet is based.

U

UDP	User Datagram Protocol. A protocol which transmits data over IP.
URL	Uniform Resource Locator. The network address of a file.
UTP	Unshielded Twisted Pair. A type of cabling consisting of insulated cable strands which are twisted together in pairs.


W

Winsock	The Microsoft implementation of the Windows Sockets networking API based on the Berkeley UNIX Sockets interface for supporting TCP/IP.
----------------	--

WWW

World Wide Web. A hypertext-based, distributed information system in which clients and servers are freely available.

Index



A

- address labels 8
- assigning
 - default Gateway address 22
 - IP network address 22
 - subnet mask 22

B

- backplane
 - mounting module to 17
- bandwidth of
 - Ethernet switches 14
- broadcast addressing 82

C

- cable
 - fiber optic 18
 - twisted pair
 - pinout 10
- compatibility
 - protocol stack 13
- Concept
 - configuring the module 24
- configuration
 - custom
 - set up before installation 16, 20
 - default
 - changing 20
 - complete 3

- configuration extension
 - requires backplane slot number 21
 - requires framing type 21
 - screen view 21
- configuring the module
 - with Concept 24
 - with Modsoft 20
- connectors
 - fiber optic 10
 - twisted pair 10
- crash log
 - how to read and clear 57

D

- default configuration
 - changing 20
 - verifying 15
- downloading a new exec 61

E

- EMBP Gateway
 - compatibility 13
- ERRLOG
 - description 11
 - how to use 57
 - requirements 11
- errors
 - responding to 53
- Ethernet
 - vs Modbus Plus

- predictability 12
- Ethernet address
 - label 8
 - set by factory 8
- Ethernet Developers Kit 13
- EtherNet framing type
 - selecting 21
- Ethernet Home Page 42
- Ethernet hub
 - NOE connection to 16
 - troubleshooting 56
- Ethernet networks 3
 - local
 - may use default IP network address 8, 16
 - open
 - custom IP network address required 8, 16
- Ethernet switches 14
- Ethernet TCP/IP modules
 - address labels 8
 - fiber optic connector 10
 - fully configured 3, 16
 - hot swap 3
 - installing 17
 - LED display 7
 - twisted pair connector 10
 - twisted pair model
 - view 5

F

- fiber cable clasps 10
 - how to snap onto cable 18
 - using to attach cable 19
- fiber optic cable
 - how to connect 19
- fiber optic connector 10
- framing type
 - Ethernet II
 - default 16
 - IEEE 802.3
 - requires configuration change 16
 - required in configuration extension 21
 - setting 21

H

- hot standby systems
 - NOE module compatibility 13
- hot swap 3, 60
- hub
 - NOE module connection to 16

I

- installation 3, 17
- Internet Explorer 41
- IP network address
 - custom 8
 - obtaining 22
 - setting in configuration extension 22
 - default 8
 - label 8

L

- labels
 - Ethernet address 8
 - IP network address 8
- LED display 7

M

- mask
 - subnet 22
- Modbus Application Protocol (MBAP) 77
- Modsoft
 - configuring the module with 20
- module
 - resetting 22

MSTR 25

- clear local statistics operation 33
- clear remote statistics operation 34
- CTE display implementation 38
- CTE error codes 31
- description of 25
- get local statistics operation 32
- get remote statistics operation 33
- inputs 27
- node content 27
- Opcode 26
- outputs 27
- Peer Cop health operation 35
- PLC compatibility 26
- read/write operations 31
- reset option module operation 37
- size 26
- TCP/IP EtherNet error codes 28

N

- Netscape Navigator 41
- network
 - performance
 - guidelines for improving 13
 - network delays
 - minimizing 14
- Network Options Ethernet Tester
 - description 11
 - how to use 48
 - requirements 11
- network topology 16
- NOE module specifications 63

O

- Opcode
 - MSTR instruction 26
- Output
 - MSTR instruction 27

P

- performance
 - reducing traffic
 - guidelines 13

- Port Numer, TCP 82
- protocol stack 13

Q

- Quantum control systems 3
- Quantum Hot Standby system
 - compatibility 13

R

- read MSTR operation 31
- remote I/O status web page 41
- resetting the module 22

S

- segregating traffic 14
- server, limited connections to 45
- slot number assignment 21
- specifications, NOE module 63
- subnet mask 22
- switches, Ethernet 14

T

- TCP port number 82
- traffic, segregating 14
- twisted pair connector 10

U

- URL address 42
- utility diskette
 - ERRLOG 11
 - Network Options Ethernet Tester 11

W

- World Wide Web server 41