

Operation Manual

UAIS Transponder System

3.19 DSC Tuning Menu

UAIS can receive and process DSC information sent by Base stations. Periodically lists of geographical regions and their associated parameters are transmitted on the DSC channel. DSC is normally set to Channel 70.

Methods of tuning DSC:

- DSC command from coastal station.

- Manually from the VDU.




The screenshot shows a terminal window titled "Tuning DSC". The content is as follows:

```
Tuning DSC
DSC: Enabled
DSC tr. channel: 70
Bandwidth: 25KHz
Power: High
```

At the bottom right, there are three buttons: "Change", a button with a downward arrow, and "Return".

3.20 Long Range Request Menu

This feature is only available with a specialised interface to a suitable source.



The screenshot shows a terminal window with the following text:

```
Do you want to enable automatically
responses on next Long range requests?
```

At the bottom, there are two buttons: "Yes" and "No".

3.21 Other Stations Menu

This is the main working menu that displays information on all the received targets. These targets can be viewed in three ways; as a list of vessel names along with Bearing and Distance, more detailed information about individual vessels or as a 'radar-style' overview.


MMSI:227273000 CallSign:FNN0		
Lat:N50 48.6666 Lon:W001 5.7234		
Type:Ship class A Old: 10s		
Brg	Dist(nm)	Name
235	001.78	
234	001.80	NORMANDIE
298	001.93	YOGI
163	002.64	
224	003.13	
194	009.75	
273	010.32	KPITI COLOR
285	013.22	TRIANON
---	undef	MCMURDO
---	undef	


Individual targets can be viewed in more detail in 2 ways. Highlight a target; at the top of the screen more detailed information can be seen about the selected target. For full details, highlight the target and press **Detail**

Target information		
MMSI: 227273000		
Name: NORMANDIE		
Call sign: FNN0		
Old: 3s		
Lat: N50 48.6660		
Lon: W001 5.7237		
Pos:Sec=24 GPS		
SOG: 0.0		
COG: 62.7		
HDG: undef		
ROT: undef		



Further information on the selected target is produced by selecting **More**


Extra target information		
Status: Under way (engine)		
Dist.GNSS-Bow: 25m		
Dist.GNSS-Stern: 137m		
Dist.GNSS-Port side: 13m		
Dist.GNSS-Starboard: 13m		
Max static draught: 5.5		
Type of cargo: 60		
Dest: OUISTREHAMPORTSMOUTH		
ETA(time): 14:43		
ETA(date): 24-09		
RAIM: Not present		
Display present: Yes		

Press  on the Other Stations menu to view the navigational situation in a “radar-style” format.



This screen shows all received AIS stations and their velocity vector. The top left number is the number of stations within the range of the display. The range, shown at top right, corresponds with the outer ring of the displayed graphic.

Press  or  to change range between 1nm to 100nm in 7 steps.







Press  to view or hide text captions (call signs) of the displayed targets.

3.22 Sending messages

From the Other Stations menu, short text messages can be sent to specific vessels or groups of vessels. The text is generated using the on-screen keyboard and may be sent to any or all of the indicated targets (which may be shore based stations).

From the target list, highlight the intended destination of the message and press



MMSI:999999997 CallSign:GB022				
Lat:N50 49.7174 Lon:W001 3.3936				
Type:Ship class A Old: 0s				
Brg	Dist(nm)	Name		
086	000.00			
089	000.01	MCM 7		
298	001.94			
177	005.84			
194	009.75			
274	010.37			
				

The top line of the screen shows the destination call sign and MMSI number. The second line displays the message text and the bottom line shows the AIS channel on which the message is to be sent, A or B. Either may be used.



A screenshot of a screen with a light blue background. It displays three lines of text: 'To: GB022(999999997)' on the top line, 'Txt:' on the second line, and 'Channel to transmit: A' on the third line. On the right side, there are three buttons: 'Change' (top), 'Send' (middle), and 'Cancel' (bottom). A small arrow button is located to the left of the 'Cancel' button.

To change the destination of the message, select the **To:** line and select **Change**



A screenshot of a screen with a light blue background. At the top, it says 'Enter dest. MMSI or 0 to broadcast'. Below this is a text box containing '235899938'. Below the text box is a numeric keypad with buttons for digits 0 through 9. At the bottom, there are buttons for left arrow, right arrow, 'BS', 'Del', 'Ok', and 'Cancel'.

From this screen the MMSi of the recipient vessel may be changed, or a group MMSI may be used, or the message may be broadcast to all ships. **OK** returns to the previous screen.

Highlight the Txt: line and select **Change**. A keyboard entry screen appears. Enter the test to be transmitted, switching between screens to access different sections of the keyboard.

Enter the message

TEST TRANSMISSION█

A	B	C	D	E	F	G	H
I	J	K	L	M	N	O	
Pr set	←	→	BS	Del	Ok	Can cel	Nx set

When the message has been entered correctly, select **OK**. Select **Send** to transmit the message.

To: GB022(9999999997) ↑

Ext: ~~TEST TRANSMISSION~~ B

Channel to transmit:

Change

Se
nd

↓

Can
cel

To test the system, select a coast station and compose a message, for example: -
"This is an AIS test call, please acknowledge".

If no acknowledgement is received the message will be re-transmitted up to four times. If no acknowledgement is received after the four transmissions, try another station in the list.

3.23 Receiving a message


When a message is received and identified as being for the particular vessel (ie it has the correct MMSI number), a screen appears to alert the operator and to display the text.




Further details of the message can be viewed by entering the Radio Exchange screen.

3.24 Radio Exchange menu

Full details of received messages can be viewed.





The received messages are then displayed with time and date of transmission, message text and details of the sender.



3.25 Alarms & Faults

When an alarm condition occurs a pop-up window will appear, eg



Press  to acknowledge the alarm message.

To clear an alarm and deactivate the BIIT relay, first select **Alarms & faults** from the **Main menu** then select **Alarm status** to view all the alarm conditions.



3.9 **Dist.GNSS-Bow**
 Dist.GNSS-Stern
 Dist.GNSS-Port-side
 Dist.GNSS-Starboard

(Default = 0)
These values are set up during commissioning. Refer to section 4.15 for further information.

3.10 **Type of Cargo**

(Default = 0)
Enter to type of vessel and cargo.

Enter the code of the cargo

60

0

1

2

3

4

5

6

7

8

9

←

→

BS

Del

Ok

Cancel

Please see the tables below for details (tables are derived from the ITU-1371-1 standard).

Identifiers Used by Ships to Report Their Type	
First Digit	Second Digit
0 - Not used	0 - All ships of this type
1 - Reserved for future use	1 - Carrying DG, HS, or MP IMO hazard or pollutant category A
2 - WIG (Wing In Ground)	2 - Carrying DG, HS, or MP IMO hazard or pollutant category B
3 – Other ships See table overleaf	3 - Carrying DG, HS, or MP IMO hazard or pollutant category C
4 - HSC (High Speed Craft)	4 - Carrying DG, HS, or MP IMO hazard or pollutant category D
5 – Special craft See table overleaf	5 - Reserved for future use
6 - Passenger Ships	6 - Reserved for future use
7 - Cargo Ships	7 - Reserved for future use
8 - Tankers	8 - Reserved for future use
9 - Other types of Ship	9 - No additional information

DG = Dangerous Goods HS = Hazardous Substances MP = Marine Pollutants

Identifiers Used by Other Ships to Report Their Type		
Identifier Number		Vessel Type
First Digit	Second Digit	
3	0	Fishing
3	1	Towing
3	2	Towing and length of the tow exceeds 200mtrs (656ft) or breadth exceeds 25mtrs (82ft)
3	3	Engaged in dredging or underwater operations
3	4	Engaged in diving operations
3	5	Engaged in military operations
3	6	Sailing
3	7	Pleasure craft
3	8	Reserved for future use
3	9	Reserved for future use

Identifiers Used by Special Craft to Report Their Type		
Identifier Number		Vessel Type
First Digit	Second Digit	
5	0	Pilot vessel
5	1	Search and rescue vessel
5	2	Tugs
5	3	Port tenders
5	4	Vessels with anti-pollution facilities or equipment
5	5	Law enforcement vessels
5	6	Spare – for assignments to local vessels
5	7	Spare – for assignments to local vessels
5	8	Medical transports (as defined in the 1949 Geneva Conventions and Additional Protocols)
5	9	Ships according to Resolution No. 18 (Mob-83)

3.11 Max. Static Draught

(Default = 0.0)

Enter the maximum static draught of vessel (in metres) during the current voyage.

Max.static draught							
<input type="text" value="2.5"/>							
0	1	2	3	4	5	6	7
8	9	-	.				
		←	→	BS	Del	Ok	Can cel

3.12 Persons on Board

(Default = 0)

Enter the total number of persons on-board during this voyage. This information is normally provided at the Master's discretion or on request from a competent authority.

Number of persons on the board							
<input type="text" value="65"/>							
0	1	2	3	4	5	6	7
8	9						
		←	→	BS	Del	Ok	Can cel

3.13 Destination

Enter the port of destination (Entered at Master's discretion).

Destination of the voyage							
<input type="text" value="PORTSMOUTH"/>							
A	B	C	D	E	F	G	H
I	J	K	L	M	N	O	
Pr set	←	→	BS	Del	Ok	Can cel	Nx set

3.14 ETA (time)

(Default = 24:60 Undefined)

Enter the local Estimated Time of Arrival at port of destination. (Entered at Master's discretion).

ETA(time) (HH:MM, 24:60-undef)

23:45

0	1	2	3	4	5	6	7
8	9	:					
		←	→	BS	Del	Ok	Can cel

3.15 ETA (date)

(Default = 00-00 Undefined)

Enter the Estimated Date of Arrival at port of destination. (00-00 = undefined)
(Entered at Master's discretion).

ETA(date) (DD-MM, 00-00-undef)

03-03

0	1	2	3	4	5	6	7
8	9	-					
		←	→	BS	Del	Ok	Can cel

3.16 Status

(Default = Undefined)

Enter the navigational status of the vessel: -

Choice current nav.status

Undefined

Under way (engine)

At anchor

Not under command

Restr. maneuverability

Constr. by her draught

Moored

Aground

Engaged in Fishing

Under way (sailing)

↑

OK

↓

Cancel

3.17 Display Present

(Default = Yes)

When **Display present** is set to **Yes**, this option indicates to other UAIS stations that the VDU is capable of showing received text messages. If the UAIS Transponder is not connected to any application display (MKD, ECDIS, ARPA or ECS) this parameter must be set to "No".

Static and voyage data

Call sign: ABCD1

Name: SILVER POINT

Dist. GNSS-Bow: 20m

Dist. GNSS-Stern: 8m

Dist. GNSS-Port side: 6m

Dist. GNSS-Starboard: 6m

Type of cargo: 60

Max static draught: 2.5

Persons on board: 35

Dest: PORTSMOUTH

ETA(time): 23:45

ETA(date): 03-03

Status: Under way (engine)

Display present: Yes


↑

Change

Return

3.18 VHF Regions Menu

UAIS works on two radio channels at any time and may select those channels depending on the geographical area. A list of up to 10 regions with their associated channels can be stored in the permanent memory; if not in any of these regions, UAIS uses the default channels of 2087 and 2088.



To view the region list stored in memory, select **VHF regions** option from the **Main set-up** menu. The top item as highlighted above) indicates the frequencies used outside the specified regions (ie at sea). Successive items, where present, show manually entered frequencies and their parameters (eg transmitter power). The station uses these entered frequencies within that specific region. "R" indicates the frequency is used for receiving, similarly "T" is for transmitting.

Information on a particular region is shown at the top of the screen: geographical co-ordinates, bandwidth and power of transmitter and time of entering or leaving the region.

There are several ways a station can acquire region information: -

- From a base station on the AIS channels.
- From external devices through the input interfaces.
- From a coastal station on CH70 DSC.
- From an operator using the VDU.

Normally it is not necessary to enter the regions manually, as the station should pick them up automatically, however it can still be done as shown in the following section by selecting **Tune** in the previous screen

Tuning of AIS transceiver

Mode of tuning

This area

Channel A

2087

Bandwidth A

25.0

Channel B

2088

Bandwidth B

25.0

Mode

TxAB/RxAB

Transmitter power

High

↓

Change

Cancel

Accept

Changing the geographical location defines the region, and the associated parameters may then be set.

Tuning of AIS transceiver

Mode of tuning

In area

Channel A

2080

Bandwidth A

25.0

Channel B

2081

Bandwidth B

25.0

Mode

TxAB/RxAB

Transmitter power

High

Transitional (nm)

5

North border

N50 0.0

South border

N40 0.0

East border

E010 0.0

West border

W010 0.0

↑

Change

Cancel

↓

Accept

A confirmation screen appears, then the new region and information is displayed on the main screen.

NE: N50 0.0 E010 0.0 Band A=25.0
SW: N40 0.0 W010 0.0 Band B=25.0
Left at 24:60 TrPwr=High
Source=M Updated at 10:23
N: Dist ChannelA ChannelB
High sea T/R:2087 T/R:2088+

↑

1: 49.7 T/R:2080 T/R:2081

Tune

Return

Applicability of this manual

This manual is valid for all hardware and software issues of the equipment described, and is kept current by updates.

When updates are posted, any incompatibility with earlier issues of hardware and/or software will be highlighted here.

Issue 5 of the Operation manual refers to V24 software, which is expanded over earlier issues.

Disclaimer

Information contained in this manual is supplied in good faith, but is liable to change without notice. McMurdo Limited disclaims any liability for consequences arising from omissions or inaccuracies in the manuals and documentation provided with this product.

IMPORTANT: Please take time to read this manual carefully and to understand its contents fully, so that you can operate your Transceiver correctly.

Table of Contents

1	INTRODUCTION	1
1.1	About this Manual	1
1.2	Safety Summary.....	1
1.3	Rules of Operation Licensing.....	2
1.4	Disclaimer	2
2	PRODUCT DEFINITION	3
2.1	System Overview	3
2.2	Compliance	4
2.3	UAIS Key Functions.....	4
3	OPERATION	5
3.1	Activation.....	5
3.2	Menu Navigation	5
3.3	Initial Start-up	7
3.4	Set to Work	9
3.5	Show Sensors Menu.....	9
3.6	Static & Voyage Data Menu.....	10
3.7	Call Sign.....	11
3.8	Name.....	11
3.9	Dist.GNSS-Bow	12
3.10	Type of Cargo	12
3.11	Max. Static Draught.....	14
3.12	Persons on Board	14
3.13	Destination	14
3.14	ETA (time)	15
3.15	ETA (date).....	15
3.16	Status.....	16
3.17	Display Present.....	16
3.18	VHF Regions Menu.....	17
3.19	DSC Tuning Menu	19
3.20	Long Range Request Menu.....	19
3.21	Other Stations Menu	20
3.22	Sending messages.....	21
3.23	Receiving a message.....	24
3.24	Radio Exchange menu.....	24
3.25	Alarms & Faults.....	25
3.26	Show Status Menu.....	26
3.27	Processor Memory	27
3.28	Report Rate.....	27
3.29	Receiver / Transmitter.....	27
3.30	Test Radio-Link.....	27
3.31	Log File	27
3.32	Log File (Unfiltered)	28
3.33	Log File (Alarms).....	28
3.34	Log File (Security).....	29
3.35	Enter Setup Menu	29
3.36	Display Brightness Menu	29

4	COMMISSIONING	31
4.1	Initial Start-up	31
	Main Set-up Menu	34
4.3	General Set-up Menu	35
4.4	MMSI	35
4.5	Purpose	35
4.6	IMO Number	36
4.7	RAIM Present	36
4.8	Setup System Password	36
4.9	Addressed Message Filter	37
4.10	Media Analyser Mode	37
4.11	Max. Repeating Message 6, 12	37
4.12	Transmission w/o Sync	37
4.13	Enable Deleting Regions	38
4.14	Extra Setup Menu	38
4.15	Intern. GNSS Position	38
4.16	Dist.Int.GNSS-Bow	39
4.17	Out Position to MAIN & AUX	39
4.18	Alarm Signals Menu	40
4.19	RS-422 Set-up Menu	41
4.20	Test Interfaces	43
4.21	DGNSS Set-up Menu	44
4.22	Engineering Mode	44
4.23	Other Options	44
4.24	Log File	45
4.25	Saving Changes	45
5	MAINTENANCE AND SERVICING	47
5.1	Preventative Maintenance	47
5.2	VDU Touch-Screen	47
5.3	Electrical Connections	47
5.4	Repair and Service	47
5.5	Spare Parts	47
5.6	World-wide Sales and Service	47
6	TROUBLESHOOTING	49
7	SPECIFICATION	53
8	GLOSSARY	55
9	DECLARATION OF CONFORMITY	57

1 Introduction

1.1 About this Manual

This Operation Manual has been designed to help understand how to operate an UAIS Transponder system as quickly as possible.

Please read this Manual thoroughly before attempting to use the UAIS Transponder system.


The UAIS Transponder provides Communication, Navigation and Surveillance (CNS) capabilities to either mobile or fixed stations. The primary purpose of this UAIS is as a Class A mobile Ship-borne Transponder system.. A separate Installation Manual is supplied, covering detailed information on installing and interfacing an UAIS, assuming that the appropriate external equipment has already been installed.


This Manual is a step by step guide to the procedures needed to successfully operate an UAIS and will explain how to: -


- View received targets
- Check the status of the system and connected sensors
- Enter the static & voyage related data
- View VHF regions
- Respond to Long Range requests
- Filter incoming messages
- Check the status of alarms & faults
- Commission an installation


1.2 Safety Summary


 **WARNING: ENSURE THAT THE UAIS HAS BEEN CORRECTLY INSTALLED IN ACCORDANCE WITH IMO GUIDELINES AND INSTALLATION MANUAL BEFORE SWITCHING ON**


 **WARNING:** Transponder chassis can become hot during extended periods of operation, avoid touching this when the Transponder is operating.


 **WARNING:** Do not touch the VHF antenna or connecting cable when the Transponder is in operation.


 **WARNING:** Unauthorised opening of the Transponder system will invalidate the warranty.


 **WARNING:** Avoid using chemical solvents to clean the VDU as they can damage the casing material.

 **WARNING:** The use and operation of a UAIS transponder is legislated and forms a part of the ship's mandatory navigation equipment. It is therefore necessary that the installation is certified (commissioned) and that certain information has to be available before full operation of the transponder can take place. The ship's IMO and MMSI number has to be programmed into the transponder, as these form part of the mandatory information that is transmitted.

 **WARNING:** This product is sold or provided as merely an aid to navigation. It is the responsibility of the user to exercise discretion and proper navigational and seamanship skills.

 **WARNING:** NOT ALL SHIPS CARRY AIS. The Officer of the Watch (OOW) should always be aware that other ships and, in particular, leisure craft, fishing boats and warships, and in some cases coastal shore stations (including Vessel Traffic Systems (VTS) centres), might not be fitted with UAIS. The OOW should always be aware that UAIS that is fitted on other ships as a mandatory carriage requirement, might, under certain circumstances, be switched off based on the Master's professional judgement.

 **WARNING:** The use of a Megger (High Voltage Insulation Tester) may damage the equipment and therefore should not be used.

 **WARNING:** Do not operate the equipment when persons are closer than 3 metres from the antenna. If any person (e.g. the operator) must be closer, then a grounded RF shield should be interposed between that person and the antenna.

1.3 Rules of Operation Licensing

IMPORTANT: Operation of the UAIS Transponder is a part of the international radio regulations and therefore the ship must possess a current VHF radio telephone licence listing the UAIS system, and the equipment must be registered (Call Sign and MMSI number). Please contact the relevant authority in your country for further information.

1.4 Disclaimer

Information contained in this manual is correct at time of going to print, but is liable to change without notice. McMurdo Limited disclaims any liability for consequences arising from omissions or inaccuracies in the manuals and documentation provided with this product.

2 Product Definition

2.1 System Overview

Universal Automatic Identification System (UAIS) is a maritime VHF based transponder system that provides high-speed automated communication from ship-to-ship and ship-to-shore, of vessel, voyage and safety related data. This UAIS transponder and touch screen VDU display system is the latest in state-of-the-art technology and is designed to meet the latest IMO SOLAS requirements. The UAIS transponder transmits the ship's navigational data to other vessels, as well as shore based VTS systems. Utilising marine VHF channels, UAIS is primarily designed as a ship-borne mobile station and consists of an integral GNSS engine used for timing, one VHF transmitter, three VHF receivers and a computer unit. Interfacing to external GNSS used for navigation, a VHF antenna, a gyrocompass, and an optional ECDIS or ARPA display system is made easy by the built-in screw terminal board and the intuitive operating menu system on the touch-screen display unit. The VDU is designed to fulfil the minimum SOLAS requirements for system set-up and display of the received target information. However the large LCD touch screen display also gives the user easy access to the menu system that displays the received targets on a graphical, radar-like display.

The UAIS Transponder transmits the following information, which is separated into three basic information groups:

Static - Vessel name, type, length and breadth, MMSI and IMO numbers and GNSS antenna location.

Dynamic – Position, accuracy and integrity, time, course and speed over ground and navigational status.

Voyage – Cargo, draft, port of destination and estimated time of arrival.

- In addition to this information, UAIS can transmit and receive short text messages regarding navigation safety that include, warnings of floating objects, collisions, meteorological situation, etc.
- Differential correction information for GNSS can also be conveyed through the UAIS, increasing the accuracy of positional information between 2 and 10 metres. This significantly increases vessel safety, thus improving the marine environment as well as the safety of life at sea.

2.2 Compliance

This UAIS is designed to comply with international standards and is approved in accordance with the high standards of the European Marine Equipment Directive:

- MSC.74(69)
- ITU-R M.1371, ITU-R M.1084-4, ITU-R M.823-3, ITU-R M.493-9
- IEC 60945, IEC 61993-1,2, IEC 61162-1,2,3, IEC 61108
- ETS 300 113

2.3 UAIS Key Functions

- Automatic identification of other UAIS equipped vessels.
- Self-organising control of access to the radio channels.
- Reception of data via the radio channels from other vessels and coast centres.
- Transmission of own vessel data via the radio channels for use by other vessels and coast centres.
NOTE: Two channels, A and B, are used for transmission.
- Storage of static data intended for automatic transmission via the radio channels.
- Output of data received via the radio channels from other UAIS objects for presentation on the minimum display.
- Determination of the position and motion of own vessel if the external GNSS receiver fails by utilising the internal timing GNSS receiver.
- Application of GNSS differential corrections using information supplied from a supplementary receiver.
- The application of GNSS differential corrections using information received from a controlling station via the VDL (VHF Data Link) channel.
- The output of Built-In-Integrity Test (BIIT) information regarding the UAIS status on the main (e.g. ECDIS) display interface, auxiliary (e.g. Pilot) display interface and also the minimum display.
- Delivery to the display of bearings and distances to the vessels, calculated from their co-ordinates, obtained via the VDL channel.

3 Operation

Please read all the warning notices at the front of this manual before turning on the Transponder.

3.1 Activation

It is recommended that UAIS should not be switched off and should remain in operation continuously. However, based on the Master's professional judgement, either transmission may be inhibited or the UAIS may be switched off entirely if continuous operation might compromise the ship's safety or security. Reactivation must take place as soon as the source of danger has disappeared. This might be necessary in waters where pirates or armed robbers are known to operate. It might also be necessary to switch off UAIS during some cargo handling operations. Actions of this nature should always be recorded in the ship's logbook.

3.2 Menu Navigation

The "keyboard" is the touch-sensitive screen of the VDU. The keys displayed change according to the other information on the screen. Touch a key square to use that key function.

All on-screen menus follow the same basic principles to navigate around them.



Using the up and down arrows allows the operator to move quickly and easily through the current menu system.

Once the required item is highlighted PRESS either: -



to enter a sub-menu.



or



to change the data in the selected field.



or



to confirm the change.



or



to stop the action and return to the previous command.



or



to go to the previous menu.

Some menu options are automatically selected depending upon the input data available.

The data entry keyboard is divided into three screens as shown overleaf.

Enter the password

■

A	B	C	D	E	F	G	H
I	J	K	L	M	N	O	P
Pr set	+	→	BS	Del	Ok	Can cel	Nx set

Enter the password


A■


Q	R	S	T	U	V	W	X
Y	Z	1	2	3	4	5	.
Pr set	+	→	BS	Del	Ok	Can cel	Nx set

Enter MMSI


111111111■

0	1	2	3	4	5	6	7
8	9						
	+	→	BS	Del	Ok	Can cel	

Press  to move to the previous character set

Press  to move to the next character set

Press  to Back Space

Press  to Delete a character

Press  or  to move the cursor

3.3 Initial Start-up

Ensure that power is available to the Transponder unit and that the main power on/off switch, located to the left side of the cable entry of the Transponder, is switched to the “on” position (green LED illuminated). At this point the Transponder is active and will wait for 1 minute before entering the network and starting transmission as it is listening to other stations to determine its own transmission time slot sequence schedule.

Press  to switch on VDU. To switch off, press and hold for 2 seconds.

NOTE: When re-starting the VDU, the screen displayed will be that when the VDU was switched off.

For a complete overview of the operating menu structure, please refer to Appendix 1 “UAIS Operating Menu Hierarchy” at the back of this Manual.

At power-up the system conducts a series of self-tests and the results are displayed on-screen as follows:-



No link with the main unit!




```
Check ROM:OK
Check RAM:OK
Check Flash:OK
Starting...
```


No link with the main unit!



After successful completion of the self-test and communication between the VDU and the transponder has been established the following screen will appear.



The welcome screen giving the GNSS type (GPS or GLONASS), software version, and software build date then appears, which confirms that the VDU is ready for operation.


Press  to enter the Main Menu.

3.4 Set to Work

NOTE: If the display is not easy to read, refer to section 3.35 which details how to adjust the display.


The next screen to appear is the **Main menu** that contains all the basic functions required to successfully operate a class A UAIS ship-borne station.

The **Other stations** option in this menu is where all received target information can be monitored. (See section 3.21 on page 20)



When in operation mode the **Main menu** appears with the following options: -

3.5 Show Sensors Menu



Sensor information	
Date/UTC:	17-06-2003 / 12:22:23
Lat:	N50 49.7135
Lon:	W001 3.4056
Pos:	Sec=23 GPS Diff
SOG:	0.1
COG:	248.3
HDG:	undef
ROT:	undef
RAIM:	Not present

This screen will display navigation data used by UAIS. Normally the navigation data is received via the input ports Sens1, Sens2 and Sens3 as well as the RTCM port for differential corrections. If the data is not being received via these interfaces, UAIS can use it's own internal GNSS, providing this facility has been enabled (see section 4.14 on page 38). Co-ordinates for non-mobile stations may be pre-set during commissioning.

3.6 Static & Voyage Data Menu

Static and voyage data	
Call sign:	
Name:	
Dist.GNSS-Bow:	0m
Dist.GNSS-Stern:	0m
Dist.GNSS-Port side:	0m
Dist.GNSS-Starboard:	0m
Type of cargo:	0
Max static draught:	0.0
Persons on board:	0
Dest:	
ETA(time):	24:60
ETA(date):	00-00
Status:	Under way (engine)
Display present:	No

In this menu, the static and voyage related data may be reviewed or changed. This is not password protected, allowing ship's information to be entered or changed at any time.

3.7 Call Sign

Enter the Ship's radio call sign.

Enter the own ship's callsign

ABCD1

A	B	C	D	E	F	G	H
I	J	K	L	M	N	O	
Pr set	←	→	BS	Del	Ok	Can cel	Nx set

3.8 Name

Enter the Ship's registered name (maximum 20 characters).

Enter the own ship's name

SILVER POINT

A	B	C	D	E	F	G	H
I	J	K	L	M	N	O	
Pr set	←	→	BS	Del	Ok	Can cel	Nx set

To confirm the change in ship's name the system password must be entered. (See section 4.8 Setup System Password on page 36)

Enter the password

■

A	B	C	D	E	F	G	H
I	J	K	L	M	N	O	P
Pr set	←	→	BS	Del	Ok	Can cel	Nx set