



User's Manual

Vol. 1

V4.0

3011401

October 2000



To contact SERCEL

Nantes, France

Commercial Customer Support;
Manufacturing & Repair;
B.P. 433, 16 rue du Bel Air
44614 Ceuilly Cedex
Tel: +33 2 40 30 11 81, Fax: +33 2 40 30 19 48
Hot-Line: Land: +33 2 40 30 58 88
Nantes: +33 2 40 30 59 59
E-mail: sales@sercel.fr
customer.support@sercel.fr
www.sercel.com

St Quentin, France

Vibrator Customer Support;
Vibrator Manufacturing & Repair;
Streamer Manufacturing & Repair;
Tel: +33 5 61 89 90 00, Fax: +33 5 61 89 90 45
Hot-Line: +33 5 61 89 90 01

Alhston, U. K.

Streamers Manufacturing & Repair;
Customer Support;
Tel: +44 1 773 605 076, Fax: +44 1 773 241 778

Houston, USA

Commercial Customer Support;
Manufacturing & Repair;
Streamers Manufacturing & Repair;
Tel: +1 281 492 64 88, Fax: +1 281 492 69 18
Hot-Line: +1 281 492 64 88
E-mail: sales.hou@sercel.com
training.hou@sercel.com
customer.support@sercel.com

Pozna City, USA

Vibrator Customer Support;
Vibrator Manufacturing & Repair;
Tel: +1 580 763 09 66, Fax: +1 580 763 09 22

Moscow, Russia

Commercial Customer Support;
Tel: +7 095 254 66 58, Fax: +7 095 254 66 80

Beijing, P. R. of China

Commercial Customer Support;
Tel: +86 106 43 76 661, Fax: +86 106 43 76 107

Tanggu, P. R. of China

Manufacturing & Repair;
Tel: +86 222 58 23 228, Fax: +86 222 58 23 242

Xian, P. R. of China

Manufacturing & Repair;
Tel: +86 297 85 25 05, Fax: +86 297 85 55 04

Singapore

Streamers Manufacturing & Repair;
Customer Support;
Tel: +65 545 0411, Fax: +65 545 5418

Delhi, India

Customer Support;
Tel: +91 11 33 773 382, Fax: +91 11 33 773 132
E-mail: sercel@delhi.sercel.in

In no event shall SERCEL be liable for incidental or consequential damages or related expenses resulting from the use of this product, or arising out of or related to this manual or the information contained in it, even if SERCEL has been advised, or knew or should have known of the possibility of such damages.

The information included in this documentation is believed to be accurate and reliable. However, SERCEL reserves the right to make changes in its products or specifications at any time, without notice, in order to improve design or performance and to supply the best possible product. This documentation does not form in any way a contractual agreement of sales promises on the part of SERCEL.

Software mentioned in this documentation is sold under a previous license agreement and as such the documentation may cover technical areas for which the user may not have a final license.

No part of this documentation, or any of the information included herein may be modified or copied in any form or by any means without the prior written consent of SERCEL.

Acknowledgments: All brand or product names are trademarks or registered trademarks of their respective companies or organizations.

Table of Contents

1 Introduction

Overview	1-2
Terminology	1-4
Working with windows	1-8
File menu	1-12
To save the setup parameters to a file,	1-12
To restore the setup parameters from a file	1-13
Utilities	1-15
Snapshots	1-15
Copy And Paste	1-15
Drag And Drop	1-16
"HCI Print" utility	1-16
How to select text	1-17
Miscellaneous	1-17

2 408UL Install

The 408UL Install window	2-2
HCI type	2-3
Nb of screens	2-3
Screen Saver	2-3

Vibrator type	2-4
Pictor type	2-4
Blister type	2-5
Printer Type	2-5
Mobile Receiver Unit (MRU)	2-5
Licences	2-6
3 Configuration	
The main window	3-2
File menu	3-2
Status pane	3-3
Customer Support icon	3-3
The View menu	3-4
UC Modules Configuration	3-4
Software Configuration	3-4
Copyrights	3-5
Identity Card	3-5
Clear Status	3-6
The Setup menu	3-7
Crew setup window	3-7
User Info	3-9
UC Module Configuration	3-9
On Line/Off Line	3-11
Wireline telemetry	3-11
Radio or dual telemetry	3-13
4 Line	
The main window	4-2
Topographic view	4-5
Sensors view	4-7

Seismometer	4-8
Instruments view	4-10
Batteries view	4-11
Working with graphic views	4-12
Numeric view	4-17
Histogram view	4-19
The Survey setup window	4-20
Survey	4-21
Point Code	4-23
Sensor	4-24
The Layout setup window	4-26
Marker	4-27
Aux	4-31
Detour	4-33
Mute	4-34
REM	4-34
SU6-R	4-34
The Spreads setup window	4-35
Absolute spreads	4-36
Generic spreads	4-37
The Preferences setup window	4-40
Graphic	4-40
Cloning	4-41
Histograms	4-42
Working with FDU3C units	4-43
General	4-43
FDU3C in the Survey Setup	4-45
FDU3C in the Layout Setup	4-46
FDU3C in the Spread Setup	4-47
FDU3C in the Test Setup	4-47
Radio or Dual telemetry	4-48

Parameters	4-49
Working with REMs	4-53
Radio section management	4-55
Parameters	4-55
Working with SU6-Rs	4-56
Quick Deploy	4-60
Test functions	4-61
Instrument tests	4-63
Field tests	4-65
Seismometer	4-67
Check Line	4-68
Line Troubleshooting	4-70
Network Management	4-72

5 Operation

The Main Window	5-2
File	5-3
View	5-3
Options	5-4
Lock Props	5-5
Print	5-5
Check	5-5
The Process Type Setup window	5-6
Impulsive type	5-10
Impulsive Stack	5-11
Correlation Before Stack	5-13
Correlation After Stack	5-16
Vibro Stack	5-17
To Generate a Process Type	5-18
The Signal Type Setup window	5-19

To generate a Signal Type Setup	5-21
More About Synthetic Signal Files.....	5-21
The Operation Source Setup window.....	5-25
To generate a Source Operation Setup	5-28
The Operation Signal Setup window	5-29
The Observer's Comment Type Setup window.....	5-30
The Shooter Setup window	5-31
Dynamite/Airgun (RF Blaster only).....	5-32
Fire Blaster Timing pane (RF Blaster only).....	5-32
Cap Limits.....	5-34
Uphole Geophone Continuity.....	5-34
Uphole Channel Description pane (RF Blaster only).....	5-34
Shooter Setup pane (RF Blaster only)	5-35
To generate a Shooter Setup.....	5-35
The Observer Report Setup window	5-37
The Slip Time Setup menu	5-38
To start, stop and execute a shot	5-39
General	5-39
GO.....	5-41
STOP.....	5-41
ABORT.....	5-42
Automation.....	5-43
The Look Properties menu	5-46
Shot data retrieval.....	5-47
Slip-sweep	5-49
The Navigation option	5-51
The Results pane	5-52
More About Correlation	5-55
Description	5-55
Data Distribution.....	5-59

6 Noise Editing

The main window	6-2
Auto/Manual	6-2
Hold/Var	6-2
Fail Thresh	6-3
Load Thresh	6-3
Save Thresh	6-3
The Noise Editing Setup window	6-4
More About Noise Elimination	6-8
"Spike Editing" method	6-8
Diversity Stack	6-10
The Results pane	6-15

7 Recorder

The main window	7-2
File	7-2
The Tape Setup window	7-3
The Tape Transport Configuration setup window	7-5
Auto/Manual	7-6
AUTO Mode	7-6
MANUAL MODE	7-8
Function Buttons	7-9
Results	7-14

8 Plotter

The main window	8-2
File	8-3
The Option menu	8-4
AUTO option	8-4
MANUAL option	8-5

The AGC SETUP pane	8-6
AGC Off	8-7
AGC On	8-8
Sample normalization for a camera	8-9
The CAMERA pane	8-11
The PLOT SELECTION pane	8-13
The AGC On Properties setup window	8-14
The Plot Group Type setup window	8-16
To generate a Plot Group Type setup	8-18
9 Positioning	
The main window	9-2
How to use the Zoom function	9-2
How to load a graphic file to the hard disk	9-4
The Datum Type setup window	9-5
The Projection Type setup window	9-7
The View setup window	9-9
The Image setup window	9-10
The Marker setup window	9-14
The Base setup window	9-16
Allowed area for tracked vehicles	9-16
To place a base station icon into your survey map view	9-17
To move the base station icon within the survey map view	9-17
To delete the base station icons	9-17
The Quality Warning setup window	9-18
The Vehicle Log setup window	9-20
The Message setup window	9-25
The Vehicle Identity setup window	9-27
Graphic display of the spread	9-30
How to use the Positioning main window	9-30

How to interpret the graphic view	9-31
Source Attributes	9-35
More about the estimated COG position	9-36
Vehicle tracking	9-38
Alarm	9-40
Warnings	9-41
Requesting a vehicle to move	9-42
Playing back a vehicle's trackline	9-43
Sending a message to a vehicle	9-43
Basic Geodesy Glossary	9-44

10 Log

The main window	10-2
Overview	10-2
Data Transfer	10-4
Text editor	10-5
Drag and Drop	10-5
The Database List setup window	10-7
To generate a Data Base View list	10-8
The Page Setting Type setup window	10-9
To generate a Pagination Type	10-10
Glossary of parameters	10-12
The Shooting setup window	10-17
The Text List setup window	10-20
The Void File setup window	10-24
Log View	10-25
Exporting an Observer Report	10-26
Exporting DPG Status Data	10-28
Exporting receiver position history data	10-30
Data Base View	10-31

Exporting operating parameters or results	10-33
Exporting a description of the system configuration	10-34
Media View	10-35
Importing 408UL script files	10-35
Importing SPS files.....	10-36
Floppy disk utility.....	10-37
408UL Setup script format.....	10-38
11 VE432	
The main window	11-2
File	11-2
View	11-3
Check	11-5
Reconfiguration	11-5
The Vibrator Crew Setup window	11-7
To generate a Crew Setup.....	11-9
The Basic Type Setup window.....	11-10
Linear	11-12
LOG	11-14
Tm	11-15
Pulse	11-16
Pseudorandom.....	11-17
Custom	11-19
Compound.....	11-21
Delay.....	11-22
Deboost option	11-22
How to generate a Basic Type	11-23
The Acquisition Type Setup window	11-24
The Radio Management Setup window	11-28
The QC Limits Setup window	11-31

The QC Choice setup window.....	11-32
The T0 Setup window.....	11-33
The function buttons.....	11-35
Auto/Manual.....	11-35
Look.....	11-36
Vib Fleet.....	11-39
Local Acq.....	11-40
Set DSD.....	11-42
Get DSD.....	11-44
Get QC.....	11-48
Radio Delay.....	11-54
Set Servo.....	11-58
Statistics.....	11-61
Normal acquisition.....	11-65
Graphic view.....	11-67
Numeric view.....	11-69
DPG/DSD status codes.....	11-72

12 SPS

The main window.....	12-2
Overview.....	12-2
Device option button.....	12-3
Database.....	12-3
The Text setup window.....	12-5
The Header setup window.....	12-6
The Record setup window.....	12-8
The Void file setup window.....	12-10
SPS View.....	12-11
Media View.....	12-12
408UL Scripts View.....	12-13

Working with SPS files	12-16
Creating SPS files from Observer Reports	12-16
Creating or modifying SPS files	12-17
Creating 408UL setup scripts from SPS files	12-19
Merging 408UL SPS files in SPS coordinates files	12-21

13 VQC

Overview	13-2
The main window	13-5
The File menu	13-6
Load/Save	13-6
Copy	13-7
The Import menu	13-8
The View menu	13-9
Data Files	13-9
Clear Graphics	13-10
The Signal Type Setup windows	13-11
Signal From 408UL Logic processor	13-13
Signal From File	13-14
The Correlation Type Setup window	13-16
The Sequence Type Setup window	13-18
TRIGGER BY ACQ option	13-19
Amplitude/Time	13-21
Frequency/Time	13-23
Spectrum	13-24
Phase & Distortion	13-25
Harmonic Distortion	13-27
FT Analysis	13-28
Working with VQC	13-29
Real-time analysis	13-29

Post-processing	13-29
Working with graphs	13-31
2D graph	13-33
3D graph	13-34
The Graph Properties menu	13-35
Unit Conversion	13-37
Signal unit	13-37
International System units	13-37
14 VE416	
The main window	14-2
File	14-2
View	14-3
Check	14-3
The Basic Type setup window	14-4
Sinewave-type signals	14-7
Pulse type	14-11
Pseudorandom	14-12
How to generate a basic type	14-13
The Sweep Type setup window	14-15
How to generate a sweep type	14-16
The Acquisition Type setup window	14-17
How to generate an Acquisition Type Setup	14-20
The Return Signals setup window	14-21
The QC Limits setup window	14-23
The Radio setup window	14-25
The DSD Limits setup window	14-28
The Invalid Sweep setup window	14-29
The function buttons	14-30
Auto/Manual	14-30

Look	14-30
Radio delay.....	14-33
Set Servo.....	14-36
Get DSD	14-39
Set DSD	14-43
Local Acquisition	14-45
Get QC	14-49
Normal Acquisition	14-52
Normal Acquisition results	14-54
Example with four acquisitions and three DSDs	14-54
With the Real-Time button activated	14-57
With the Statistics button activated	14-58
More about the radio delay	14-60
The radio delay	14-60
Radio delay measurement	14-61
DPG/DSD status codes	14-63
15 RF spectrum	
The main window	15-2
File	15-2
Window.....	15-2
The Setup menu	15-3
RF Spectrum Monitoring view	15-5
The RF Spectrum Monitoring function	15-7
Theory of operation	15-7

INDEX



408UL User's Manual

Volume 1

Introduction

See also the [*Index*](#).

This chapter includes the following sections:

- *Overview (page 1-2)*
- *Terminology (page 1-4)*
- *Working with windows (page 1-8)*
- *File menu (page 1-12)*
- *Utilities (page 1-15)*

Overview

This manual provides operating instructions for the 408UL system's Graphic User Interface (referred to as HCI).

Before using this manual, you need to install the system by following the instructions given in the 408UL Installation Manual.

The User's Manual is automatically loaded from the 408UL CDROM to your workstation's disk as you load the 408UL software package. Then it is just one click away at all times, using the HELP button available in every main window, or it can be viewed using the menu that pops up when you press the mouse centre button. With a PC computer equipped with a PDF file reader (Adobe Acrobat Reader) you can view this manual direct from the 408UL CDROM's DOC directory.

This manual assumes you are familiar with window-driven systems and you know how to work with windows, including how to use a mouse and standard menus and commands, and to open, move, resize, shrink, restore and close a window. For help with any of these techniques, see the documentation that came with your workstation.

408UL documentation consists of the following manuals:

- **Installation Manual** (0311400): contains an introduction to the 408UL system, installation information, a few instructions for the operator to get started, and reference information that will help you select a 408UL configuration tailored to your needs.
- **User's Manual Volume 1** (0311401): this manual.
- **User's Manual Volume 2** (0311402): contains information on interfaces (description of Input/Output formats, including SEGID format).
- **User's Manual Volume 3** (0311403): contains reference information on the definition of parameters involved in the HCI or in the instrumentation.

- **Technical Manual (0311404):** contains maintenance information and associated procedures and diagrams, including LT408 and TMS408 documentation.

1

Terminology

You'll need to be familiar with a number of terms that are described below.

- **Click**
To press and release a mouse button quickly (left-hand button, unless otherwise specified).
- **Command button**
A button that carries out a command (Add, Change, Delete, Swap, Reverse) with the parameters specified in the text boxes.
- **Dialog box**
A secondary window that provides or requests information within an environment's main window.
- **Double-click**
To press and release the left-hand mouse button twice in rapid succession without moving the mouse.
- **Drag**
To move an item on the screen by holding down the mouse button while moving the mouse. See *Drag And Drop* (page 1-16).
- **Icon**
A small graphical image used to represent a window. Windows can be turned into icons or minimized to save room or unclutter the workspace.

Working with REMs

After all REMs to be used are entered into the list box, click **Apply**, then choose the desired action from the option buttons at the foot of the REM Layout Setup window.

Alternately, you can use the menu that pops up when you press the right-hand button of the mouse in the graphic view, prompting one or more contextual shortcuts that let you perform actions on the selected REM. You cannot perform any action on a REM group until **all** the REMs in the group are ready (e. g. connected, supplied with power, etc.).

• Wake Up

When you click GO with this option selected, wakeup messages are continuously sent to all SU6-Rs controlled by the REM or REM group for 10 minutes. You can terminate the wakeup by clicking on ABORT.

A wakeup is normally performed at the beginning of each day.

To see the remaining time until SU6-Rs are woken up, choose the numeric view mode.

• Sleep

When you click GO with this option selected, a message is sent to all SU6-Rs telling them to go to sleep mode. The sleep mode allows the SU6-Rs to consume much less power when not actively being used. SU6-Rs are normally put to sleep at the end of each day in order to conserve battery power.



WARNING

Once the SU6-Rs are put to sleep, they must be woken up (this takes 10 minutes) before being used.



- **Receive Freq**

When you click GO with this option selected, the system subsequently uses the following selections when retrieving data: "Nb of Retries", "Retrieve SuspendDelay" time, ...

- **Xmit Freq (REM)**

When you click GO with this option selected, the system immediately sets the transmit frequency in the RF unit as specified in the "Transmit" frequency text field.

- **Xmit Freq (REM & SU6-R)**

When you click GO with this option selected, the system uses the previous transmit frequency to send the new REM transmit/SU6-R receive frequency to the SU6-Rs. Then it sets the new REM transmit frequency in the RF unit.




WARNING

This procedure should be done with caution because if an SU6-R misses the command, it will still be receiving on the old transmit frequency.

Radio section management

You open this window by selecting **Layout** from the **Setup** menu and clicking on the SU6-R tab. It is used to describe Radio-type receiver sections by assigning the desired receiver positions to the channels of the SU6-Rs to be deployed.



4

Parameters

- Index
(Allowable range: 1 to 1200). Sequential number in the list of SU6-R units.
- SU6-R S. N.
(Allowable range: 0 to 9999999). SU6-R serial number.

- **REM S. N.**
(Allowable range: 0 to 9999999). Serial number of the REM controlling the specified SU6-R. See also *Radio or Dual telemetry* (page 4-48).
- **Line Nb**
(Allowable range: 0 to 99999). Used to specify the acquisition Line on which to deploy the specified SU6-R.
- **Station Nb 1 to 6**
(Allowable range: 0 to 99999). Six text boxes used to specify the Receiver position assigned to each channel in the specified SU6-R.

Working with SU6-Rs

The list box to the left of the ADD button shows the list of described SU6-Rs.

To describe a new SU6-R, enter the desired Number and description into the appropriate text boxes, then click **ADD**.

To make changes to any existing SU6-R, double-click the desired row in the list box. The corresponding description appears in the text boxes.

Make the desired changes and click **CHANGE**.



NOTES:

- If the selected SU6-R is deployed, then only the Frequency can be changed right away. To change the other fields, you must click **UNDEPLOY** first.
- If you wish to assign a deployed SU6-R to another REM, simply change the serial number of the REM (REM SN) for that SU6-R in the list box.

To jump to a particular SU6-R in the list, enter its identification number into the SU6-R S. N. text box and click **FIND**.

To re-arrange the described Lines by REM numbers or Line number, choose the desired option (By REM/By Line) and click **Sort**.

To remove SU6-Rs from the list, specify the desired SU6-R numbers in the Index text box and click **DELETE**.

To save the list of SU6-Rs, click **APPLY**.



TIP: To select several rows in the list box, click and:

- **Shift**-click for adjacent rows,
- **Control**-click for separate rows.

TIP: You can press the <c> key repeatedly to arrange the SU6-Rs by deploy status code in the list box:

- 1st time selects the 1st SU6-R not deployed
- 2nd time selects the 1st SU6-R deployed as RF radio link (R)
- 3rd time selects the 1st SU6-R deployed as MASTER (M)
- 4th time selects the 1st SU6-R deployed as SLAVE (S)
- 5th time selects the 1st SU6-R deployed as MUTE (T)

4

You can view the status of each SU6-R identified in this window in the numeric view or, using the mouse **right button** and selecting **Properties**, in the graphic view.

Use the option button at the foot of the SU6-R Layout Setup window to deploy/undeploy, check the SU6-Rs as required and control their power level. First you must select the desired SU6-Rs (by clicking in the list box).

Alternately, you can use the menu that pops up when you press the right-hand button of the mouse in the graphic view, prompting one or more contextual shortcuts that let you perform actions on the selected SU6-R (e. g. Deploy, etc.).

- **Deploy**

With this option selected, clicking GO assigns the channels of the selected SU6-Rs to physical Lines and Receivers. (This function is equivalent to the Foma Line function in wireline-type units, performed prior to Look or Check Line or test functions).

In a REM group, you can deploy all SU6-Rs concurrently.

- **Undeploy**

With this option selected, clicking GO cancels the assignment of the selected SU6-R channels.

- **Loop**

With this option selected, clicking GO causes the system to cycle on the command to get the status from the selected SU6-Rs. If you fail to get the status from any SU6-R because of radio-communication problems, you can use this function and adjust the orientation of the SU6-R's antenna until you get the status. To quit the loop, click ABORT.

- **Check (deployed SU6-Rs)**

With this option selected, clicking GO will collect the status from the selected deployed SU6-Rs, including continuity and battery voltage.

- **Reset (deployed SU6-Rs)**



With this option selected, clicking GO generates a hardware reset command to the SU6-Rs and re-deploys the specified SU6-Rs.

- **Low Power (deployed SU6-Rs)**

With this option selected, clicking GO tells the selected SU6-Rs to use the Low Power mode (25 W) to transmit back information to the REM.

- High Power (deployed SU6-Rs)

With this option selected, clicking GO tells the selected SU6-Rs to use the High Power mode (40 W) to transmit back information to the REM.



4