

# SC800 / SC820 User's Manual

WinCE. NET Rugged Portable Data Terminal

---



Mar/10/2008 Ver: 0.2

---

# Table of Contents

---

---

Chapter 1. Introduction .....	1-1
1.1 About this Manual.....	1-1
1.2 User and Product Safety.....	1-2
1.3 Battery Safety.....	1-3
1.4 CE Statement.....	1-4
1.5 FCC Statement .....	1-8
1.6 Recycling & disposal instructions. ....	1-9
1.7 Regulatory information.....	1-9
1.8 Product Labeling.....	1-10
1.9 System Specifications .....	1-14
1.10 Environment Standard.....	1-16
1.11 Warranty and after service.....	1-16
Chapter 2. Getting Started.....	2-1
2.1 Check the package .....	2-1
2.2 General View of the PDT.....	2-3
2.2.1 SC800 general view .....	2-3
2.2.2 SC820 general view .....	2-5
2.3 Charging the Battery Pack .....	2-7
2.3.1 Installing the battery pack.....	2-7
2.3.2 Charging the battery pack with Power Adapter .....	2-9
2.4. Handling the PDT .....	2-10
2.4.1 Starting the PDT.....	2-10
2.4.2 Power on / off.....	2-10
2.4.3 Calibration of the touch Screen.....	2-11
2.4.4 To mute the Sound for SC800.....	2-11
2.4.5 Adjusting the Sound for SC820 .....	2-11
2.4.6 Using the Stylus .....	2-12
2.4.7 Using the SC800 Keypad.....	2-12
2.4.8 Using the SC820 Keypad.....	2-14
2.4.9 Using the Ear/Microphone.....	2-17
2.5 Navigating the Display .....	2-18
2.5.1 Setting Time and Date.....	2-18
2.5.2 Entering the Data .....	2-18
2.5.3 The Command Bar .....	2-19

---

2.5.4 The Task Bar .....	2-19
2.5.5 The Soft Keypad .....	2-20
2.5.6 Setting Up Wireless LAN .....	2-20
2.5.7 Reading barcodes, 1D laser version.....	2-25
2.5.8 Help.....	2-26
2.6 Power management.....	2-27
2.6.1 Suspend Mode.....	2-27
2.6.2 Resuming .....	2-28
2.7 Resetting the PDT .....	2-28
2.7.1 Software (Warm) Reset.....	2-28
2.7.2 Cold Reset.....	2-28
Chapter 3.Setting.....	3-1
3.1 Introduction.....	3-1
3.2 Control Panel .....	3-1
3.2.1 BarCode Setting.....	3-2
3.2.2 Symbologies List .....	3-8
3.2.3 Bluetooth Device Properties .....	3-24
3.2.4 Certificates .....	3-28
3.2.5 Control Center.....	3-30
3.2.6 Date/Time.....	3-34
3.2.7 Dialing Properties .....	3-34
3.2.8 Display Properties.....	3-36
3.2.9 Input Panel .....	3-37
3.2.10 Internet Options .....	3-38
3.2.11 Keyboard.....	3-40
3.2.12 Network and Dial-up Connections.....	3-41
3.2.13 Owner.....	3-45
3.2.14 Password .....	3-46
3.2.15 PC Connection .....	3-47
3.2.16 Power .....	3-48
3.2.17 Regional Settings .....	3-50
3.2.18 Remove Programs.....	3-51
3.2.19 Storage Manager .....	3-52
3.2.20 Stylus.....	3-53
3.2.21 System.....	3-54
3.2.22 Volume & Sounds Properties .....	3-56
3.3 Taskbar and Start Menu .....	3-57

---

Chapter 4.Communication .....	4-1
4.1 Installing & Setting Up Microsoft ActiveSync.....	4-1
4.1.1 Installing Microsoft ActiveSync on the Host PC.....	4-1
4.1.2 Connecting PDT to Host PC .....	4-1
4.2 Using ActiveSync.....	4-1
4.2.1 Setting up a Partnership .....	4-1
4.2.2 ActiveSync File Synchronization.....	4-3
4.3 Networking .....	4-3
Chapter 5.Software Applications .....	5-1
5.1 Introduction.....	5-1
5.2 Software Applications .....	5-1
5.2.1 Inbox .....	5-1
5.2.2 Internet Explorer .....	5-10
5.2.3 Media Player .....	5-13
5.2.4 Messenger .....	5-13
5.2.5 Microsoft WordPad .....	5-13
5.2.6 Remote Connection.....	5-19
5.2.7 Windows Explorer .....	5-20
5.3 DiskOnChip .....	5-22
5.3.1 Saving to Flash.....	5-22
5.3.2 DiskOnChip Location .....	5-22
5.3.3 DiskOnChip Size .....	5-23



# Chapter 1. Introduction

---

Congratulations on purchasing the SC800/SC820 Portable Data Terminal (PDT), a Microsoft Windows®CE .Net rugged PDT. Its special combination of features makes it perfect for using in a wide range of applications. These features as:

- Intel® XScale™ PXA270 520MHz 32 bits RISC Processor
- Windows® CE .NET 5.0 Operating System
- 128 MB SDRAM & 128 MB Flash ROM
- Open Architecture: User Accessible SD Slot
- 240 x 320, 3.5” Color TFT Display with Touch Panel
- One Numeric-Alpha Keyboards with LED backlight
- 802.11b/g Radio Support (Bluetooth Optional)
- Integrated 1D Barcode Scanner
- Changeable Keypad

## 1.1 About this Manual

The following chapters contained in this manual are:

Chapter 1:	Introduction	General information about the PDT.
Chapter 2:	Getting started	Describe the basic use of the PDT.
Chapter 3:	Setting	Provide basic instructions for customizing the PDT.
Chapter 4:	Communication	Describe how to use all kinds of communication of the PDT.
Chapter 5:	Software Application	Describe the installed applications on the PDT.

## 1.2 User and Product Safety

- Do not stare into the laser or LED beam directly or shine it into eyes.
- Never use strong pressure onto the screen or subject it to severe impact, as the LCD panel could become cracked and possibility cause personal injury. If the LCD panel is broken, never touch the liquid inside because the liquid irritates the skin.
- Although the PDT has passed the test of IP65 standard for water and dust resistance, avoid prolonged exposure to rain or other concentrated moisture. Such condition exceeds the IP65 standard, and could result in water or other contaminants entering into the PDT.
- Use only the original approved AC Adapter with the PDT. Use of an unapproved AC Adapter could result in electrical problems, or even cause a fire or electrical shock to the user.
- Do not disassemble the PDT. Servicing should be done by supplier only. If the PDT or accessories gets damaged due to wrong handling or unauthorized repair, warranty is void. In case the warranty seals are broken, warranty is void too.
- Make regularly back-ups of all important data.
- Under no circumstance will supplier be liable for any direct, indirect, consequential or incidental damages baring out of the use or inability to use the hardware and software and/or any data loss, even if supplier has been informed about the possibility of such damages.
- **LASER RADIATION DO NOT STARE INTO BEAM CLASS 2 LASER PRODUCT**

## 1.3 Battery Safety

**CAUTION: Risk of Explosion if Battery is replaced by an Incorrect Type. Dispose of Used Batteries According to the Instructions.**

Lithium-ion battery packs might get hot, explode, ignite and/or cause serious injury if exploded by abusive using. Please follow the safety warnings listed as below:

- Do not throw the battery pack in fire. Do not expose the battery to high temperatures.
- Do not connect the positive battery pack with negative battery pack to each other with any metal object (like wire).
- Do not carry or store battery pack together with metal objects.
- Do not pierce the battery pack with nails or drills, strike the battery pack with a hammer, step on the battery pack or otherwise expose it to strong impacts, shocks or excessive force.
- Do not solder onto the battery pack.
- Do not expose battery pack to liquid or allow the battery contacts to get wet.
- Do not disassemble or modify the battery pack. The battery pack contains safety and protection measures, which, if damaged, may cause the battery pack to generate heat, explode or ignite.
- Do not discharge the battery pack using any device except for the specified device. When it is used in devices other than the specified devices, the battery pack can be damaged or its life expectancy reduced. If the device causes any abnormal current to flow, it may cause the battery pack to become hot, explode or ignite and cause serious injury.
- In the event the battery pack leaks and the fluid gets into one's eye, do not rub the eye. Rinse well with water and immediately seek medical care. If left untreated, the battery fluid could cause damage to the eye.

## 1.4 CE Statement

### Europe – EU Declaration of Conformity

This device complies with the essential requirements of the R&TTE Directive 1999/5/EC. The following test methods have been applied in order to prove presumption of conformity with the essential requirements of the R&TTE Directive 1999/5/EC:

- **EN 60950-1: 2006**  
Safety of Information Technology Equipment
  
- **EN50360 : (2001-07)**  
- Product standard to demonstrate the compliance of mobile phones with the basic restrictions related to human exposure to electromagnetic fields (300 MHz-3GHz)
  
- **EN50361 : (2001-07)**  
- Basic standard for the measurement of specific absorption rate related to human exposure to electromagnetic fields from mobile phones (300 MHz-3 GHz)
  
- 
  
- **EN50371 : (2002-03)**  
- Generic standard to demonstrate the compliance of low power electronic and electrical apparatus with the basic restrictions related to human exposure to electromagnetic fields (10 MHz-300 GHz) -- General public
  
  
- **EN 300 328 V1.7.1: (2006-10)**  
- Electromagnetic compatibility and Radio spectrum Matters (ERM); Wideband Transmission systems; Data transmission equipment operating in the 2,4 GHz ISM band and using spread spectrum modulation techniques; Harmonized EN covering essential requirements under article 3.2 of the R&TTE Directive
  
  
- **EN 301 511 V9.0.2: (2003-03)**  
- Global System for Mobile communications (GSM); Harmonized standard for mobile stations in the GSM 900 and DCS 1800 bands covering essential requirements under article 3.2 of the R&TTE directive (1999/5/EC)
  
  
- **EN 301 489-1 V1.6.1: (2005-09)**



- Electromagnetic compatibility and Radio Spectrum Matters (ERM);  
ElectroMagnetic Compatibility (EMC) standard for radio equipment and services;  
Part 1: Common technical requirements
  
- **EN 301 489-17 V1.2.1 (2002-08)**
- Electromagnetic compatibility and Radio spectrum Matters (ERM);  
ElectroMagnetic Compatibility (EMC) standard for radio equipment and services;  
Part 17: Specific conditions for 2,4 GHz wideband transmission systems and 5  
GHz high performance RLAN equipment
  
- **EN 301 489-7 V1.2.1: (2002-08)**
- ElectroMagnetic compatibility and Radio spectrum Matters (ERM);  
ElectroMagnetic Compatibility (EMC) standard for radio equipment ad services;  
Part 7: Specific conditions for mobile and portable radio and ancillary equipment  
of digital cellular radio telecommunications systems (GSM and DCS)

This device is a 2.4 GHz wideband transmission system (transceiver), intended for use in all EU member states and EFTA countries, except in France and Italy where restrictive use applies.






In Italy the end-user should apply for a license at the national spectrum authorities in order to obtain authorization to use the device for setting up outdoor radio links and/or for supplying public access to telecommunications and/or network services.

This device may not be used for setting up outdoor radio links in France and in some areas the RF output power may be limited to 10 mW EIRP in the frequency range of 2454 – 2483.5 MHz. For detailed information the end-user should contact the national spectrum authority in France.

**CE 0560** 

<p>☐ Česky [Czech]</p>	<p><i>[Jméno výrobce]</i> tímto prohlašuje, že tento <i>[typ zařízení]</i> je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.</p>
<p>☐ Dansk [Danish]</p>	<p>Undertegnede <i>[fabrikantens navn]</i> erklærer herved, at følgende udstyr <i>[udstyrets typebetegnelse]</i> overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.</p>

[de]Deutsch [German]	Hiermit erklärt [ <i>Name des Herstellers</i> ], dass sich das Gerät [ <i>Gerätetyp</i> ] in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.
[et]Eesti [Estonian]	Käesolevaga kinnitab [ <i>tootja nimi = name of manufacturer</i> ] seadme [ <i>seadme tüüp = type of equipment</i> ] vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.
[en]English	Hereby, [ <i>name of manufacturer</i> ], declares that this [ <i>type of equipment</i> ] is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.
[es]Español [Spanish]	Por medio de la presente [ <i>nombre del fabricante</i> ] declara que el [ <i>clase de equipo</i> ] cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.
[el]Ελληνική [Greek]	ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ [ <i>name of manufacturer</i> ] ΔΗΛΩΝΕΙ ΟΤΙ [ <i>type of equipment</i> ] ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.
[fr]Français [French]	Par la présente [ <i>nom du fabricant</i> ] déclare que l'appareil [ <i>type d'appareil</i> ] est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.
[it]Italiano [Italian]	Con la presente [ <i>nome del costruttore</i> ] dichiara che questo [ <i>tipo di apparecchio</i> ] è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.
Latviski [Latvian]	Ar šo [ <i>name of manufacturer / izgatavotāja nosaukums</i> ] deklarē, ka [ <i>type of equipment / iekārtas tips</i> ] atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.
Lietuvių [Lithuanian]	Šiuo [ <i>manufacturer name</i> ] deklaruoja, kad šis [ <i>equipment type</i> ] atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.
[nl] Nederlands [Dutch]	Hierbij verklaart [ <i>naam van de fabrikant</i> ] dat het toestel [ <i>type van toestel</i> ] in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.
[mt]Malti [Maltese]	Hawnhekk, [ <i>isem tal-manifattur</i> ], jiddikjara li dan [ <i>il-mudel tal-prodott</i> ] jikkonforma mal-ħtiġijiet essenzjali u ma provvedimenti oħrajn rilevanti li hemm fid-Dirrettiva 1999/5/EC.
[hu]Magyar [Hungarian]	Alulírott, [ <i>gyártó neve</i> ] nyilatkozom, hogy a [ <i>... típus</i> ] megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb

	elðírásainak.
<p>  Polski            [Polish]         </p>	Niniejszym <i>[nazwa producenta]</i> oświadczam, że <i>[nazwa wyrobu]</i> jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.
<p>  Português            [Portuguese]         </p>	<i>[Nome do fabricante]</i> declara que este <i>[tipo de equipamento]</i> está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.
<p>  Slovensko            [Slovenian]         </p>	<i>[Ime proizvajalca]</i> izjavlja, da je ta <i>[tip opreme]</i> v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.
<p>           Slovensky            [Slovak]         </p>	<i>[Meno výrobcu]</i> týmto vyhlasuje, že <i>[typ zariadenia]</i> spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.
<p>  Suomi            [Finnish]         </p>	<i>[Valmistaja = manufacturer]</i> vakuuttaa täten että <i>[type of equipment = laitteen tyyppimerkintä]</i> tyypinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.
<p>  Svenska            [Swedish]         </p>	Härmed intygar <i>[företag]</i> att denna <i>[utrustningstyp]</i> står i överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

## 1.5 FCC Statement

### Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. **Complies with 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice No. 50, dated June 24, 2007.**

### IMPORTANT NOTE:

#### Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. To maintain compliance with FCC RF exposure compliance requirements, please follow operation instruction as documented in this manual.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The availability of some specific channels and/or operational frequency bands are

country dependent and are firmware programmed at the factory to match the intended destination. The firmware setting is not accessible by the end user.

**Caution:** SCC declares that SC800 ( FCC ID: TQ2-SC800PDT-BW ) / SC820 ( FCC ID: TQ2-SC800PDT-BW ) is limited in CH1~CH11 for 2.4GHz by specified firmware controlled in U.S.A.  
The FCC ID of SC800/SC820 is TQ2-SC800PDT-BW

## LED AND LASER SAFETY INFORMATION

- Class II LED/Laser Product
- Do not stare at the LED/Laser or shine into eyes
- Do not allow young children to use the product without adult supervision
- Do not replace/repair the LED/Laser, these are not user replaceable
- Do not shine the LED/Laser on a shiny reflective surface
- **LASER RADIATION DO NOT STARE INTO BEAM CLASS 2 LASER PRODUCT**

## 1.6 Recycling & disposal instructions.



Do not throw this product in the home waste bin. For proper end-of-life treatment consult the Environmental care section of <ftp://ftp.sccltd.com.tw/>

## 1.7 Regulatory information.



For CE, FCC, RoHS and other Document of Conformities, consult the Regulatory section of <ftp://ftp.sccltd.com.tw/>

## 1.8 Product Labeling

The PDT has several labels as showed in Figure 1-1 to 1-4.

### A. SC800




Figure 1-1 Product Labeling (Front side view)

Label nr.	Description
1	LCD panel protection film
2	SC800 logo
3	Warranty seal PDT

Table 1-1 Front labeling




Figure 1-2 Product Labeling (Back side view)

Label nr.	Description
4	Laser radiation warning label
5	Serial / Configuration number
6	PenPower label (only use on Simplified Chinese version)
7	CCC label (only use with China)
8	System and regulatory label
9	NCC label (only use on Traditional Chinese version)
10	RoHS Use Life Label for China
11	Windows CE .NET label

Table 1-2 Rear labeling

## B. SC820




Figure 1-3 Product Labeling (Front side view)

Label nr.	Description
1	LCD panel protection film
2	SC820 logo
3	Warranty seal PDT

Table 1-3 Front labeling






Figure 1-4 Product Labeling (Back side view)

Label nr.	Description
4	LED/Laser radiation warning label
5	Serial / Configuration number
6	PenPower label (only use on Simplified Chinese version)
7	CCC label (only use with China)
8	System and regulatory label
9	NCC label (only use on Traditional Chinese version)
10	RoHS Use Life Label for China
11	Windows CE .NET label

Table 1-4 Rear labeling

## 1.9 System Specifications

The SC800 / SC820 detailed specifications as follows. Unless otherwise noted, all the specifications are subject to change without prior notification.

Table 1-5 System Specification

<b>SC800 / SC820</b>	
Processor	- Intel PXA270 520MHz 32 bits RISC CPU
Memory	- 128MB Flash ROM - 128MB SDRAM
Display	- 240 x 320 3.5" TFT 256K Color LCD with LED backlight
Audio	- One mono speaker for system voice (on lower case) - One 2.5 mm Ø stereo earphone jack with mono mike input - One internal MIC - One Receiver
Expansion Slot	- One SD/MMC slot (only support SD memory) - One SIM slot for WAN module
LED	- One Dual-Color LED for Charger Indicator - One Dual-Color LED for Scanner Indicator
Radio Support	- <b>Wireless LAN:</b> 802.11b/g - <b>Bluetooth:</b> Class II - <b>IrDA:</b> 1.2
Scan Engine	- Symbol, Opticon Laser (1D) Engine. (optional)
Communication Ports	- <b>USB:</b> Support USB v1.1 both host and client. (PDT and Cradle) - <b>Serial:</b> RS232 via optional cable or Cradle.
Power System	- Standard Li-Ion Battery Pack, 3.7V, 2200mAh - Advanced Smart Battery with Gas-Gauge - Built-in Battery Charger - 4.2V/70mAh rechargeable backup battery - One Battery Cover Sensor Switch - Power Adapter: 100~240V AC, 50/60Hz Input ; 5VDC/2.6A Output

<b>SC800 / SC820</b>		
Keypad / Buttons	SC800	<ul style="list-style-type: none"> <li>- One Power Button</li> <li>- One Reset Button</li> <li>- Three Barcode Scanner Buttons</li> <li>- Two Navigation Buttons</li> <li>- Four Application Buttons</li> <li>- One 18-key Numeric Keypad</li> <li>- One Reserved Button</li> </ul>
	SC820	<ul style="list-style-type: none"> <li>- One Power Button</li> <li>- One Reset Button</li> <li>- Three Barcode Scanner Buttons</li> <li>- Two Navigation Buttons</li> <li>- Four Application Buttons</li> <li>- One 33-key Alpha-Numeric Keypad</li> <li>- One Reserved Button</li> </ul>
Dimensions and Weight	<ul style="list-style-type: none"> <li>- Dimensions: L: 155mm, W: 82mm, H: 31~33mm</li> <li>- Weight: 400g with Standard Battery Pack</li> </ul>	
Color	<ul style="list-style-type: none"> <li>- Black</li> </ul>	
Peripherals and Accessories	<ul style="list-style-type: none"> <li>- Optional: RS232 Serial Cable for Terminal / USB Host Cable for Terminal / High-Capacity Li-Ion Battery Pack (3.7V, 4000 mAh) / Single Dock / 4 Slot Battery Charger / Car Adapter / RS232 Cable / Pistol Grip</li> </ul>	
Software	<ul style="list-style-type: none"> <li>- Microsoft Windows CE.NET 5.0 Professional</li> </ul>	

## 1.10 Environment Standard

Table 1-6 Environment Standards

<b>Operating Temperature</b>	14°F ~ 122°F( -10°C ~ 50°C)
<b>Storage Temperature</b>	-4°F ~ 158°F (-20°C ~ 60°C)
<b>Humidity</b>	5% ~ 95% (non-condensing)
<b>Drop</b>	5ft (1.5m) Drop onto Concrete
<b>Water &amp; Dust proof</b>	IP65 Certificated
<b>Vibration</b>	MIL STD 810F

## 1.11 Warranty and after service

Should this PDT be malfunctioned, please contact your original retailer providing information about the product name, the serial number, and the details about the problem.

# Chapter 2. Getting Started

---

## 2.1 Check the package

Open the package and check all the parts are inside without shortage and damage:

### A. SC800



Figure 2-1 Inside the package

1. SC800 Terminal
2. Standard Battery Pack (3.7V, 2200 mAh)
3. USB Client Cable for Terminal
4. AC Power Cord
5. Standard AC Adapter 5VDC/2.6A
6. Earphone/ Microphone Set
7. Quick Guide (not shown in the picture)

## B. SC820



Figure 2-2 Inside the package

1. SC820 Terminal
2. Standard Battery Pack (3.7V, 2200 mAh)
3. USB Client Cable for Terminal
4. AC Power Cord
5. Standard AC Adapter 5VDC/2.6A
6. Earphone/ Microphone Set
7. Quick Guide (not shown in the picture)

## 2.2 General View of the PDT

### 2.2.1 SC800 general view



Figure 2-3 SC800 front side view



Figure 2-4 SC800 back side view

Table 2-1 Description of SC800 General View

1	Scanner LED Indicator	“Red” color	Reading barcode
		“Green” color	Successful reading
2	Charge LED Indicator	“Red” color	Charging battery
		“Green” color	Battery charged full
3	LCM / Touch Panel	Do specific action through touch panel by stylus	
4	Left Scan key Right Scan key Scan key	Start scanning the barcode by pressing any one of these three scan keys	
5	Power key	Puts the terminal into and wakes the terminal from suspend mode.	
6	F1 ~ F4 key	The four application keys, hot keys of application program defined by end user.	
7	Navigation key	Navigation keys for left, right, up and down directions	
8	Alpha-Numeric keys	Numeric keys, Change to Alpha keys after pressing Alpha key.	
9	Alpha key	Toggle Alpha-mode for Alpha-Numeric keys	
10	Fn key	This key is used in combination with other keys to type special characters and perform system functions.	
11	Enter key	This key confirms data entry	
12	Earphone Jack Connector	A connector to plug a earphone	
13	USB / Serial / Synchronization port	A connector to support USB Host/Client and serial functions	
14	Scan window	A window for scanning of barcode reader	
15	Stylus	Use the stylus for selecting items and entering information.	
16	Battery Cover	Protect Battery pack, keep the switch of battery cover to leave system from suspend mode	
17	Battery cover Latch	To keep Battery Cover locked	
18	Hand Strap	This strap can be sealed tighter or looser	
19	Speaker	1W speaker for audio sound	
20	DC Power Jack	A connector to support AC power.	
21	IrDA	A connector to support IrDA functions	



## 2.2.2 SC820 general view



Figure 2-5 SC820 front side view



Figure 2-6 SC820 back side view

Table 2-2 Description of SC820 General View

1	Scanner LED Indicator	“Red” color	Reading barcode
		“Green” color	Successful reading
2	Charge LED Indicator	“Red” color	Charging battery
		“Green” color	Battery charged full
3	LCM / Touch Panel	Do specific action through touch panel by stylus	
4	Left Scan key Right Scan key Scan key	Start scanning the barcode by pressing any one of these three scan keys	
5	Power key	Puts the terminal into and wakes the terminal from suspend mode.	
6	F1 ~ F4 key	The four application keys, hot keys of application program defined by end user.	
7	Navigation key	Navigation keys for left, right, up and down directions	
8	Alpha keys	Alpha key.	
9	Numeric keys	Numeric keys.	
10	Fn key	This key is used in combination with other keys to type special characters and perform system functions.	
11	Enter key	This key confirms data entry	
12	Earphone Jack Connector	A connector to plug a earphone	
13	USB / Serial / Synchronization port	A connector to support USB Host/Client and serial functions	
14	Scan window	A window for scanning of barcode reader	
15	Stylus	Use the stylus for selecting items and entering information.	
16	Battery Cover	Protect Battery pack, keep the switch of battery cover to leave system from suspend mode	
17	Battery cover Latch	To keep Battery Cover locked	
18	Hand Strap	This strap can be sealed tighter or looser	
19	Speaker	1W speaker for audio sound	
20	DC Power Jack	A connector to support AC power.	
21	IrDA	A connector to support IrDA functions	

## 2.3 Charging the Battery Pack

Before using the PDT, perform the basic procedure of charging the battery pack through the following steps.

### 2.3.1 Installing the battery pack


1. On the PDT attached with a hand-strap, detach and loose the hand-strap.

Figure 2-7 Release the Hand strap from PDT



2. Turn the locking screws (right and left) downwards and lift the battery cover away from the PDT.

Figure 2-8 Detach the battery cover from PDT




3. Insert the battery pack into the battery compartment with the label facing out, and ensuring the battery snaps into place.

Figure 2-9 **Insert the battery pack**



4. Replace the battery cover by inserting the top first, and then press the bottom in firmly. Turn the locking screws (right and left) upwards to secure the cover to the PDT.

Figure 2-10 **Replace the battery cover**



5. Charge time. For the first time to charge the battery pack needs approximately 6 hours. Subsequent charging time needs approximately 4 hours.

- ◆ When charging the battery pack, the charge LED indicator on the PDT turns on **Red**. After the battery pack is fully charged, the charge LED indicator turns to **Green**.

### 2.3.2 Charging the battery pack with Power Adapter

1. Connect the Power cord to the Power adapter.
2. Plug in the connector of the power adapter.
3. Connect the power cord to a power source.

Figure 2-11 Charging with power adapter




- ◆ When charging the battery pack, the charge LED indicator on the PDT turns on **Red**.
- ◆ After the battery pack is fully charged, the charge LED indicator turns to **Green**.

## 2.4. Handling the PDT

### 2.4.1 Starting the PDT

Press the Power key to turn on/off the PDT. If the PDT does not power on, perform a cold boot. See 2-7 Resetting the PDT.

**CAUTION:** When a battery is fully inserted in PDT for the first time, upon the PDT's first power up, the device boots and powers on automatically.



When the PDT is powered on for the first time, it initializes its system. A splash screen (figure 2-13) appears for a short period of time followed by the Wince.NET 5.0 window.

This section offers the basic procedures of PDT using.

Figure 2-13 Starting the PDT

### 2.4.2 Power on / off

#### ➤ To turn on the PDT

Press the Power key briefly (🔌). If the PDT does not power on, perform the cold reset. See chapter 2.7.1.

As the PDT initializes its file system, its splash screen displays for about 30 seconds followed by calibration screen. Every time you perform a cold reset, these screens will also appear.

To turn off the PDT, just press the Power key again. This action does not actually turn off the PDT, it only turns the PDT into suspend mode. All running applications remain as you left them, until you press the Power key again to resume operation of the PDT

### 2.4.3 Calibration of the touch Screen

On the initial boot-up of the PDT, the stylus calibration screen (Labeled Align Screen) opens. Use the stylus to press and hold briefly on the center of each target as it moves around the screen.

If necessary, adjust the backlight on the PDT to make the screen readable. (See below 2.4.4. Adjust the brightness).

When you feel the touch screen function is poor or the operation does not match the exact location it should be, please recalibrate the screen by using the stylus to tap the **Start > Settings > Control Panel > Stylus**, to open the “**Calibration**” to recalibrate again.




Figure 2-14 Calibration

### 2.4.4 To mute the Sound for SC800

To mute the sound, press the **Fn** key first, and then press the **Caps** key to turn off and on of the sound.

### 2.4.5 Adjusting the Sound for SC820

The factory default for the sound is in Middle level. You can adjust the sound to meet your environment and comfort as:

- 1) Become low voice: Press the **Fn** key and then press the **Esc** key to become low voice.
- 2) Become high voice: Press the **Fn** key and then press the **Tab** key to become high voice.



## 2.4.6 Using the Stylus

The stylus is located next to hand-strap on the left rear of the PDT. The stylus function is same as the mouse on a PC. Use the stylus to:

- 1) Navigate the display, select menu item and open optional applications.
- 2) Tap the characters on soft keyboard panel.
- 3) Hold the stylus on the screen and drag across the screen to select the list of multiple items.

**CAUTION:** Never use a pen, pencil, or other sharp object on the display to avoid any unexpected damage of the touch screen.

## 2.4.7 Using the SC800 Keypad







Figure 2-15 SC800 Keypad

Table 2-3 Keypad List

Key	Main Function	Fn + Main Function	Alpha + Main Function
	BarCode Start		
	Power On/Off		
	Internet Explorer		



























Key	Main Function	Fn + Main Function	Alpha + Main Function
	Microsoft WordPad		
	Inbox		
	File Explorer		
	Up	Left	
	Down	Right	
	TAB (Tabulation)	ESC	
	Caps	Audio Mute	
	Function change		
	Change to letters		
	Backspace		
	1	@ (at)	: \
	2	' (Quotation Marks)	A B C
	3	+ (Plus Sign)	D E F
	4	Paste	G H I
	5	Del (Delete)	J K L
	6	- (Minus Sign)	M N O
	7	Copy	P Q R S
	8	& (AND)	T U V
	9	X (Multiplication)	W X Y Z
	0	Space	[ ]
	* (Asterisk)	Start Menu	. (Point) ' ;
	#	/ (Division)	= %
	Enter		

Table 2-4 Special Assembler Key













Assembler Key	Functionality	Definition
	Warm Reset	Press “Reset” button in the back.
	Cold Reset	Press “Power” and “Reset” button simultaneously.



















## 2.4.8 Using the SC820 Keypad



Figure 2-16 SC820 Keypad

Table 2-5 Keypad List

Key	Main Function	Fn + Main Function
	Main Barcode Scan Key	
	Power On/Off	
	Internet Explorer	F5
	Microsoft WordPad	F6
	Inbox	F7
	File Explorer	F8
	Up	Left
	Down	Right
	Esc	+<img alt="Speaker icon" data-bbox="514 706 548 721"/>
	Tab	-<img alt="Speaker icon" data-bbox="514 751 548 766"/>
	Backspace	Del
	Caps	Start Menu

Key	Main Function	Fn + Main Function
	<b>Enter</b>	
	<b>Function change</b>	
	<b>Space</b>	
	<b>A</b>	~
	<b>B</b>	\$
	<b>C</b>	+
	<b>D</b>	1
	<b>E</b>	2
	<b>F</b>	3
	<b>G</b>	!
	<b>H</b>	%
	<b>I</b>	– (Minus Sign)
	<b>J</b>	4
	<b>K</b>	5
	<b>L</b>	6
	<b>M</b>	<b>Copy</b>
	<b>N</b>	@
	<b>O</b>	\













Key	Main Function	Fn + Main Function
	P	*
	Q	7
	R	8
	S	9
	T	Paste
	U	#
	V	&
	W	/
	X	. (Point)
	Y	0
	Z	=

Table 2-6 Special Assembler Key

Assembler Key	Functionality	Definition
	Warm Reset	Press “Reset” button in the back.
	Cold Reset	Press “Power” and “Reset” button simultaneously.

## 2.4.9 Using the Ear/Microphone

Connect Ear/Microphone to PDT earphone jack connector. The PDT is not built in microphone; if you like to record the voice, you have to use Ear/Microphone.



Figure 2-17 Ear/Microphone

## 2.5 Navigating the Display

### 2.5.1 Setting Time and Date

In the **Date/Time** options, you can change the year, month, date, time, time zone, or select automatic adjust for Daylight Saving Time. To set or change the date and time:

1. Select **Start > Settings > Control Panel > Date/Time**
2. To change the year, select the year or open a numeric dial. Select the up arrow to increase the value; select the down arrow to decrease the value. Or you can type a new value in the field.
3. Select the month to open a pull-down list of months or press the arrow buttons to either side of the month to increase or decrease the month.




Figure 2-18 **Date/Time** properties

4. To change the time, select the hour, minute, seconds, or AM/PM and select the up arrow to increase the value; select /tape the down arrow to decrease the value. Or you can type a new value in the field.
5. Select your correct time zone from the pull-down list.
6. To automatically adjust the clock for Daylight Saving Time, enable the checkbox at the bottom of the screen.
7. Select **Apply** to make save your changes [and make additional modifications] or select **OK** to exit the **Date/Time** settings.

### 2.5.2 Entering the Data

To select and open programs, select **Start > Programs** from the task bar to open a list of available programs. Or if the program has a icon on the desktop, double-tap to open it.

There are several ways to enter data on the PDT once in an application:

- Use the keypad to enter alpha-numeric characters, Refer to “2.4.7 Using the

### SC800 keypad”.

- Use the stylus on the touch screen.
- Select text in the same way you select the text on a PC. Use the stylus to highlight the desired text by dragging the stylus across the desired text, double-tapping to select one word and triple-tapping to select an entire line/paragraph. Refer to “**2.5 Navigating the Display**” starting.
- Use the soft input panel (digital keyboard) with the stylus.
- Use the bar code scanning to enter data. Press the trigger or “Barcode Scan” key to initiate a scan. The scanned data will enter the current application’s open file. Refer to “**2.5.7 Reading barcodes, 1D laser version**” starting for more information on using a scanner.

For more information on factory installed applications, Refer to Chapter 4 “**Software Programs**”.

## 2.5.3 The Command Bar

Use the **Command** bar at top of the screen to perform tasks in programs, such a opening a file, or editing a file.

## 2.5.4 The Task Bar

The **Task** bar at the bottom of the screen displays the icon, an icon for the active program, the current time, and system icons for utilities loaded in memory. The **Task** bar includes menu names, buttons, and the keyboard icon, which opens and closes the soft input panel (SIP). The **Task** bar allows you to select and close programs. Refer to Figure 2-19 to view the **Task** bar.




Figure 2-19 Task Bar & Command Bar

## 2.5.5 The Soft Keypad

In applications that accept keypad input, the soft input panel (**SIP**) can be used to enter data using the stylus. The **SIP** is digital, QWERTY-style keyboard.

To open the **SIP**, tap the **keyboard** icon to open the menu and select **Hide Input Panel** to close the keyboard.

Use the stylus to select letters, numbers, or symbols from the **Soft Input Panel** for the current application.

## 2.5.6 Setting Up Wireless LAN

The Summit Client Utility (SCU) is an application designed for end users and administrators of mobile devices that use a Summit radio module. Using SCU, an end user can:

- Disable the radio (turn it off) and enable the radio (turn it on)
- View the contents of configuration profiles, or profiles, each of which houses the RF, security, and other settings for the radio
- Select the profile to be used to connect to a WLAN
- View global settings, which apply to every profile
- View status information on the radio, the access point (AP) or WLAN router to which it is connected, and the RF connection or link between the two
- To troubleshoot a connection or performance issue, view in-depth diagnostic information on the connection and the radio, and perform various troubleshooting and diagnostic tests

After completing an administrator login to the utility, a user can perform these additional tasks:

- Create, rename, edit, and delete profiles
- Alter global settings, which apply to every profile

SCU provides a graphical user interface (GUI) for access to all of its functions. Access to these functions also is available through an application programming interface (API), which an application programmer can use to enable another utility to manage the radio.

To initialize SCU:


- From the Start menu, select Programs
- Select the directory called Summit
- Inside the Summit directory are two items: a directory for the storage of security certificates and an SCU icon. To run SCU, double-click the SCU icon

SCU has five tabs: Main, Profile, Status, and Diags, and Global.

Each tab is described in more detail in this section.



## Main Tab




- **Enable/Disable Radio:** When the radio is enabled, selecting this button disables it; when the radio is disabled, selecting this button enables it.
- **Active Profile:** You can view the name of the active profile and, using the selection list, select a different profile.  
If you select “ThirdPartyConfig” then, after the device goes through a power cycle, WZC is used for configuration of the radio.
- **Status:** Indicates the radio’s status.
- **Radio Type:** Indicates the type of radio in the device.  
“BG” means a Summit radio that supports 802.11b and 802.11g.
- **Regulatory Domain:** Indicates the regulatory domain or domains for which the radio is configured.  
“Worldwide” means that the radio can be used in any domain.  
The domain cannot be configured by an administrator or user.
- **Driver:** Indicates the version of the device driver that is running on the device.
- **SCU:** Indicates the version of SCU that is running on the device.
- **About SCU:** When tapped, supplies information on SCU that on a Windows application normally would appear under Help\About.

## Profile Tab

Profile settings are radio and security settings that are stored in the registry as part of a configuration profile. When a profile is selected as the active profile on the Main tab, the settings for that profile become active. An administrator can define up to 20 profiles, edit

them, and delete them on the Profile tab in SCU. **Profile changes made on the tab are saved to the profile only when the Commit button is pressed.**

Unless it is modified, the Default profile does not specify an SSID, EAP type, or method of encryption. If the Default profile is the active profile, then the radio will associate only to an access point that broadcasts its SSID and requires no EAP type and no encryption.



- **Edit Profile:** This is used to select the profile to be viewed or, if you are an administrator, edited.
- **Actions:** Four actions are available, with the first three available only to an administrator:
  - New:** Create a new profile with default settings and give it a unique name (and then change settings using other selections on the tab).
  - Rename:** Give the profile a new name, one that is not assigned to another profile
  - Delete:** Delete the profile, provided that it is not the active profile.
  - Scan:** Open a window that lists access points that are broadcasting their SSIDs. Each time you tap the Refresh button, you view an updated list of APs, with each row showing an AP's SSID, its received signal strength indication (RSSI), and whether or not data encryption is in use (true or false). You can sort the list by clicking on the column headers. If you are authorized as an administrator, select an SSID in the list, and tap Commit, you return to the Profile tab to create a profile for that SSID.
- **Radio:** Radio attributes in the list box can be selected individually. When an attribute is selected, the current setting or an appropriate selection box with the current setting highlighted appears on the right.

- **Security:** Values for the two primary security attributes, EAP type and encryption type, are displayed in separate dropdown lists, with the current values highlighted. When you as an administrator select an EAP type, the Credentials button appears; when you tap it, a dialog box appears that enables you to define authentication credentials for that EAP type. When you as an administrator select an encryption type that requires the definition of WEP keys or a pre-shared key, the PSKs/WEP Keys button appears; when you tap it, a dialog box appears that enables you to define WEP keys or a PSK.
- **Commit:** To ensure that changes to profile settings made on the tab are saved in the profile, you must tap the Commit button.

To cause a Summit radio to connect to a typical business WLAN, you must select a profile that specifies the SSID, EAP type, and encryption type supported by the WLAN:


- **SSID:** This is the name or identification of the WLAN.
- **EAP type:** This is the protocol used to authenticate the device and its user if the WLAN uses the Enterprise version of Wi-Fi Protected Access (WPA) and WPA2. SCU supports five EAP types: PEAP with EAP-MSCHAP (PEAP-MSCHAP), PEAP with EAP-GTC (PEAP-GTC), EAP-TLS, LEAP, and EAP-FAST
- **Encryption:** This specifies the type of key used to encrypt and decrypt transmitted data and how that key is specified or derived. Encryption options include:
  - WPA2 or WPA with dynamic keys (derived from the EAP authentication process)
  - WPA2 or WPA with pre-shared keys
  - Static WEP keys

Consult the user's guide for details on all profile settings, including security settings.


## Status Tab

The Status tab provides status information on the radio.

- Active profile
- Radio's status: Down (not recognized), Disabled, Not Associated, Associated, or [EAP type] Authenticated
- Client info: Name, IP address, and MAC address
- AP info: Name, IP address, MAC address, beacon period, and DTIM interval
- Connection info: Channel, data rate, transmit power, signal strength, and signal quality



## Diags Tab



- **(Re)connect:** Disable and enable the radio, apply or reapply the current profile, and attempt to associate and authenticate to the wireless LAN, logging all activity in the output area at the bottom.
- **Release/Renew:** Obtain a new IP address through DHCP release/renew, and log all activity in the output area at the bottom.
- **Start Ping:** Start a continuous ping to the address in the edit box next to it. Once the button is clicked, its name and function will change to Stop Ping. Moving to an SCU window other than Status or Diags also will stop the ping, as will Pings will continue

until you tap the Stop Ping button, move to an SCU window other than Diags or Status, exit SCU, or remove the radio.


- **Diagnostics:** Attempt to (re)connect to an AP, and provide a more thorough dump of data than is obtained with (Re)connect. The dump will include radio state, profile settings, global settings, and a BSSID list of APs in the area.
- **Save To...:** Save the diagnostics output to a file.

## Global Tab

Global settings include:

- Radio and security settings that apply to all profiles
- Settings that apply to SCU itself

An administrator can define and change most global settings on the Global Settings Tab in SCU.



The default setting for each global setting ensures reliable operation in most environments. Consult the user's guide for details on all global settings.

### 2.5.7 Reading barcodes, 1D laser version.

To use the scanning function, complete the following steps:

1. If you have not already done so, remove the protective plastic film before using devices equipped with a 1D laser bar code reader.
2. Select **Start > Setting > Control Panel > Barcode Setting**; complete all

configurations following all description of **3.2.1 BarCode Setting**.


3. Run the **WordPad** software program.
4. Press one of the three barcode reader trigger buttons.
5. Aim the scanning beam at the center of barcode.



6. Good scanning position.

The reading range is from 40 to 300mm distance.

- 1) Decrease the scanning distance to the bar code when scanning small barcodes.
- 2) Increase the scanning distance from the bar code when scanning large barcodes
- 3) The scanning area is visible by a red laser beam.



7. Bad scanning position.

- 1) Make sure that the laser beam sweeps across whole bar code.
- 2) Scanning operations may fail if the laser beam is positioned as below.



8. upon reading a barcode, the red LED indicator turns on until the trigger is release or after five seconds. The green LED and the beep tone indicates a good read.

**Note:** This product scans using laser light. Never look directly into the laser light or shine the laser light into the eyes.



## 2.5.8 Help

To tap “?” can get help information for each program.

## 2.6 Power management

### 2.6.1 Suspend Mode

The PDT will go into a suspend mode when it is idle for a period of time. The idle duration can be customized using the **Power** control panel (refer to Figure “**Schemes Tab**”)

Suspend mode works and looks just like you have turned the unit off. Press the  key to suspend the PDT, Press the  key again for the PDT to resume its Previous state.

Use the **Battery power** control panel to set the duration to switch state to Suspend mode when system using battery power. This will save battery power when PDT is not in use.





Figure 2-24 Schemes Tab

### Suspending:

The following conditions will suspend:

- Press <Power> key while the unit is on.
- The duration timer of item “**Switch state to Suspend**” expires, which indicates that there has been no use for a specified of time.
- The battery pack is completely discharged.
- Tap **Start > Suspend**



## 2.6.2 Resuming

Use one of following methods to resume (wake up the PDT):

- Press <Power> key to suspend or resume (wake up).
- Put the PDT into a dock.

When a battery pack completely discharges while the unit is in suspend mode, the PDT remains suspended until discharged battery condition is corrected.

## 2.7 Resetting the PDT

### 2.7.1 Software (Warm) Reset

A warm reset is a transition from the on, idle, or suspend power state that close all applications, clears the working RAM, but preserves the file system.

**Reason to Warm Reset:** If an application “hangs”, initiate a warm reset to terminate the application only.

**Process to Warm Reset:** To a warm reset, press “F1” and “F4” button simultaneously.

#### After Warm Reset:

- The desktop appears with the application shortcuts on the screen.
- The custom settings in the registry are persistent.

### 2.7.2 Cold Reset

- 1) You can use Cold Reset to initiate device if WINCE.NET OS lock up or Warm Reset still can't work
- 2) To perform Cold Reset, press “Power”, “F1” and “F4” button simultaneously.
- 3) Device will initiate boot up after Cold Reset.

**CAUTION:** Only use the Warm Reset. Try warm reset before you initiate Cold Reset. All applications will be Closed and working RAM and all files will be cleared if you initiate the Cold Reset. It's better usually to back up your files to Flash ROM, Flash Card or PC.



# Chapter 3.Setting

---

## 3.1 Introduction

To view available options for PDT's setting, tap **Start > Settings**. Then, there are three items inside **Settings**: “**Control Panel**”, “**Network and Dial-up**” and “**Taskbar and Start**”.

## 3.2 Control Panel

To view the **Control Panel** and settings you can modify by tapping **Start > Settings > Control Panel**.




Figure 3-1 Control Panel

### 3.2.1 BarCode Setting

**CAUTION :** Please do not enter into any Barcode Application Program before settings completing this Barcode.



There are three Tabs for scanner configuration setting: “**Basic**” Tab, “**Code Configure**” Tab and “**Code ID**” Tab. In addition, there is “**BarCode Setup**” for the “Code Configure” Tab.

#### 3.2.1.1 “Basic” Tab




Figure 3-2 Basic Tab

Table 3-1 Basic Explaining

Field Name	Function Explaining	
Beep After Scan OK	Select the numbers of beep tone after scan OK.	
	None	After scanning the barcode, do not give out beep sound.
	<u>One Time</u>	After scanning the barcode, give out beep one time.

Field Name	Function Explaining	
	Two Times	After scanning the barcode, give out beep two times.
<b>Scan Timeout (sec)</b>	Select the scanning timeout duration (in seconds) from this pull-down list. <2 ~ 20 sec, <u>Default: 5</u> >	
<b>Termination Code</b>	None	After showing barcode, do not action.
	<u>CRLF</u>	After showing the barcode, jump to next row.
	Space	After showing the barcode, jump one unit.
	Tab	After showing the barcode, jump a section.
<b>Continuous Scan</b>	<u>Disable</u>	Disable this functionality.
	1 ~5 sec	Alternate second number of Continuous Scan.
<b>Keybd Message</b>	Select a method based upon the barcode scanning application you will use.	
	Type Writing	A unit continues a unit, fast showing barcode number.
	<u>Copy &amp; Paste</u>	Once show barcode number.
	Disable	Not show the barcode number.
<b>Prefix</b>	Type the desired label prefix in this text box	
<b>Suffix</b>	Type the desired label suffix in this text box	
<b>Default</b>	Press “Default” button to reset all configuration setting of “Basic” Tab into default values.	
<b>F/W ver.</b>	Decoder firmware version.	
<b>Set All To Default</b>	Press “Set All To Default” button to reset all configuration setting of “Basic” Tab, “Code Configure” Tab, “Code ID” Tab and all barcode of “BarCode Setup” into default values.	

### 3.2.1.2 “Code Configure” Tab:

Select the barcode symbologies you plan to scan from the list. Tap to enable/disable the desired symbologies.




Figure 3-3 Code Configure Tab

Table 3-2 Code Configure Explaining

Barcode Symbology		Explaining
<b>Type A. Numeric-only Barcodes</b>		
<input checked="" type="checkbox"/>	UPC-E	Compressed version of UPC code for use on small products.
<input checked="" type="checkbox"/>	UPC-A	Universal product code seen on almost all retail products in the USA and Canada.
<input checked="" type="checkbox"/>	EAN-13 / ISBN	<b>EAN-13:</b> European Article Numbering international retail product code. <b>ISBN:</b> Special use of the EAN-13 symbol to used internationally to mark books.
<input checked="" type="checkbox"/>	EAN-8 / JAN-8	Compressed version of EAN code for use on small products.
<input type="checkbox"/>	UPC-EAN Add-ON 2/5	UPC-A, UPC-E, EAN-13, and EAN-8 may all include an additional barcode to the right of the main barcode. This second barcode, which is usually not as tall as the primary barcode, is used to encode additional information for newspapers,

		books, and other periodicals.
<input type="checkbox"/>	Industrial 2 of 5 / IATA	Older code not in common use.
<input checked="" type="checkbox"/>	Interleaved 2 of 5	Compact numeric code, widely used in industry, air cargo, other applications.
<input type="checkbox"/>	Plessey / MSI	<b>Plessey:</b> Older code commonly used for retail shelf marking. <b>MSI:</b> Variation of the Plessey code commonly used in USA.
<input type="checkbox"/>	Code 11	Used primarily for labeling telecommunications equipment.
<input checked="" type="checkbox"/>	Codabar / NW 7	Older code often used in library systems, sometimes in blood bank.
<input type="checkbox"/>	Matrix 2 of 5	Used in miscellaneous industrial applications, and mechanical numbering systems.
<b>Type B. Alphanumeric Barcodes</b>		
<input checked="" type="checkbox"/>	Code 39 / Code32	General-purpose code in very wide use world-wide.
<input checked="" type="checkbox"/>	Code 93	Compact code similar to Code 39.
<input checked="" type="checkbox"/>	Code128 / UCC EAN128	Very capable code, excellent density, high reliability; in very wide use world-wide. Widely used data formatting model for Code 128
<b>Type C. Others Barcodes</b>		
<input type="checkbox"/>	China Post	Used by China Postal Service for automated mail sorting.
<input type="checkbox"/>	Code 4	---
<input type="checkbox"/>	GTIN	Global Trade Identification Number
<input type="checkbox"/>	Korea Code 3 of 5	---
<input type="checkbox"/>	RSS	Reduced Space Symbology

### 3.2.1.3 “Code ID” Tab:




Figure 3-4 Code ID Tab

Table 3-3 Code ID Explaining

Code ID is added into prefix of the barcode and let user identify which kind of barcode being scanned.	
<input type="checkbox"/> Enable Code ID	Enable this functionality.
Set 1 ~ Set 5	Select one default value by Set 1 ~ Set 5. (See the “ <a href="#">Table 3-4 Code ID Set1-Set5 Table</a> ”)
User Define	Establish number by oneself.
Barcode List	Set 1 ~ Set 5: defaults setting. User Define: select barcode to define.
Default	Press “Default” button to reset all configuration setting of “Code ID” Tab into default values.

Table 3-4 Code ID Set1-Set5 Table

	Set 1	Set 2	Set 3	Set 4	Set 5
<b>UPC-E</b>	S	E	C	E	E
<b>UPC-A</b>	M	A	A	A	E
<b>EAN-13 / ISBN</b>	M	A	A	F	E
<b>EAN-8 / JAN-8</b>	P	B	B	F	E
<b>Industrial 2 of 5 / IATA</b>	C	H	H	H	S
<b>Interleaved 2 of 5</b>	D	I	Z	I	S

	Set 1	Set 2	Set 3	Set 4	Set 5
<b>Plessey / MSI</b>	V	V	D	P	M
<b>Code 11</b>	J	J	J	J	J
<b>Codabar / NW 7</b>	F	N	X	N	F
<b>Matrix 2 of 5</b>	E	G	G	G	S
<b>Code 39 / Code 32</b>	A	C	Y	M	A
<b>Code 93</b>	I	L	L	L	G
<b>Code 128</b>	H	K	K	K	C
<b>Code 4</b>	U	U	U	U	U
<b>Korea Code 3 of 5</b>	R	R	R	R	R
<b>RSS</b>	R	R	R	R	R
<b>UCC128 / EAN128</b>	W	W	W	W	W

### 3.2.1.4 BarCode Setup

- A. First select barcode type then select barcode to setting.
- B. Press “**Default**” button to reset all configuration setting of this barcode into default values.
- C. Press “**Apply**” button to be decided setting of this barcode.

*Please see 3.2.2 Symbolologies List for more detail information of each Barcode.*




Figure 3-5 BarCode Setup

### 3.2.2 Symbologies List

#### A Type -- Numeric-only Barcodes

##### 3.2.2.1 UPC-E




Figure 3-6 UPC-E

Table 3-5 UPC-E Explaining

Item		Explaining
Format	Ignore 1st digit	Do not transmit 1st digit by barcode.
	<b>Transmit 1st digit</b>	Transmit 1st digit by barcode.
<input checked="" type="checkbox"/>	Send Check Digit	Whether send check digit by barcode.



### 3.2.2.2 UPC-A

UPC-A movements together with EAN-13, so only Enable EAN-13 then UPC-A will be Enable, too.




Figure 3-7 UPC-A

Table 3-6 UPC-A Explaining

Item		Explaining
Format	Ignore 1st & 2nd digits	Do not transmit 1st digit by barcode.
	Transmit 1st digit	Transmit 1st digit by barcode.
	Transmit 2nd digit	Transmit 2nd digit by barcode.
	<b>Transmit 1st &amp; 2nd digits</b>	Transmit 1st & 2nd digits by barcode.
<input checked="" type="checkbox"/> Send Check Digit		Whether send check digit by barcode.

### 3.2.2.3 EAN-13 / ISBN




Figure 3-8 EAN-13 / ISBN

Table 3-7 EAN-13 / ISBN Explaining

Item		Explaining
Format	Ignore 1st & 2nd digits	Do not transmit 1st digit by barcode.
	Transmit 1st digit	Transmit 1st digit by barcode.
	Transmit 2nd digit	Transmit 2nd digit by barcode.
	<b>Transmit 1st &amp; 2nd digits</b>	Transmit 1st & 2nd digits by barcode.
<input checked="" type="checkbox"/> Send Check Digit		Whether send check digit by barcode.
<input type="checkbox"/> Enable ISBN Code		Whether use this ISBN Code.

### 3.2.2.4 EAN-8/JAN-8




Figure 3-9 EAN-8/JAN-8

Table 3-8 EAN-8/JAN-8 Explaining

Item		Explaining
Format	Ignore 1st digit	Do not transmit 1st digit by barcode.
	<b>Transmit 1st digit</b>	Transmit 1st digit by barcode.
<input checked="" type="checkbox"/>	Send Check Digit	Whether send check digit by barcode.
<input type="checkbox"/>	Convert to EAN-13	When this option is selected the scanner will convert EAN-8 to EAN-13 by transmitting five zeroes ...
	Add five 0	Ahead of code
		<b>After 3 digits</b>
		Add five zeroes at prefix of the barcode.
		Add five zeroes after 3rd digits.

### 3.2.2.5 UPC-EAN Add on 2/5

- A. UPC-E, UPC-A, EAN-13 / ISBN and EAN-8 / JAN-8 may all include an additional barcode to the right of the main barcode.
- B. This barcode will show primary & additional code together.
- C. So the UPC-EAN Add-ON 2/5 code is unable to use alone, must operate in UPC-E or UPC-A or EAN-13 / ISBN or EAN-8 / JAN-8.




Figure 3-10 UPC-EAN Add on 2/5

Table 3-9 UPC-EAN Add-On 2/5 Explaining

Item	Explaining
<input type="checkbox"/> Only read the code with Addon 2/5	Only reads the codes that have addenda.

### 3.2.2.6 Industrial 2 of 5 / IATA




Figure 3-11 Industrial 2 of 5 / IATA

Table 3-10 Industrial 2 of 5 / IATA Explaining

Item		Explaining
<input checked="" type="checkbox"/>	Send Check Digit	Whether send check digit by barcode.
<input type="checkbox"/>	Enable IATA Code	Whether use this IATA Code.
Checksum	<input type="checkbox"/> Verify	Whether verify checksum by barcode.
Length	<input checked="" type="radio"/> Min-Max (Default: 2 / 48)	Min Length can be set from 2 to 48
		Max Length can be set from 2 to 48
	<input type="radio"/> Fixed	Length 1 can be set from 2 to 48
		Length 2 can be set from 2 to 48
		Length 3 can be set from 2 to 48

### 3.2.2.7 Interleaved 2 of 5




Figure 3-12 Interleaved 2 of 5

Table 3-11 Interleaved 2 of 5 Explaining

Item		Explaining
<input checked="" type="checkbox"/>	Send Check Digit	Whether send check digit by barcode.
Checksum	<input type="checkbox"/> Verify	Whether verify checksum by barcode.
Length	<input checked="" type="radio"/> Min / Max (Default: 4 / 48)	Min Length can be set from 4 to 48
		Max Length can be set from 4 to 48
	<input type="radio"/> Fixed	Length 1 can be set from 4 to 48
		Length 2 can be set from 4 to 48
		Length 3 can be set from 4 to 48

### 3.2.2.8 Plessey / MSI




Figure 3-13 Plessey / MSI

Table 3-12 Plessey / MSI Explaining

Item		Explaining
Format	<b>Mode 10</b>	Checksum mode for this barcode.
	Mode 10-10	
	Mode 11-10	
<input checked="" type="checkbox"/> Send Check Digit	<b>1 Digit</b>	Whether send check digit by barcode.
	<b>1 Digit</b>	Check 1 digit & send by checksum.
	2 Digits	Check 2 digits & send by checksum.

### 3.2.2.9 Code11




Figure 3-14 Code 11

Table 3-13 Code 11 Explaining

Item	Explaining
<input type="checkbox"/> Send Check Digit	Whether send check digit by barcode.
1 Digit	Check 1 digit & send by checksum.
<b>2 Digits</b>	Check 2 digits & send by checksum.



### 3.2.2.10 Codabar / NW7




Figure 3-15 Codabar / NW7

Table 3-14 Codabar / NW7 Explaining

Item		Explaining
<input type="checkbox"/> Start / Stop Digit	ABCD	Whether transmit Start & Stop Digit.  Start / Stop transmit type
	<b>abcd</b>	
	TN*E	
	tn*e	
Checksum	<input type="checkbox"/> Verify	Whether verify checksum by barcode.

### 3.2.2.11 Matrix 2 of 5




Figure 3-16 Matrix 2 of 5

Table 3-15 Matrix 2 of 5 Explaining

Item		Explaining
<input checked="" type="checkbox"/>	Send Check Digit	Whether send check digit by barcode.
Checksum	<input type="checkbox"/> Verify	Whether verify checksum by barcode.
Length	<input checked="" type="radio"/> Min-Max (Default: 4 / 48)	Min Length can be set from 4 to 48
		Max Length can be set from 4 to 48
	<input type="radio"/> Fixed	Length 1 can be set from 4 to 48
		Length 2 can be set from 4 to 48
		Length 3 can be set from 4 to 48

## B Type -- Alphanumeric Barcodes

### 3.2.2.12 Code39 / Code32




Figure 3-17 Code39 / Code32

Table 3-16 Code39 / Code32 Explaining

Item		Explaining
Format	<b>Code39 Standard</b>	Enable Code 39 Standard characters
	Code39 Full ASCII	Enable Code 39 Full ASCII character
	Code32	Enable Code 32
<input type="checkbox"/> Start / Stop Digit		Whether transmit Start & Stop Digit.
Checksum	<input type="checkbox"/> Verify	Whether verify checksum by barcode.
	<input checked="" type="checkbox"/> Transmit	Whether transmit checksum by barcode.

### 3.2.2.13 Code93

The barcode do not have setting.




Figure 3-18 Code93

### 3.2.2.14 Code128 / UCC EAN128




Figure 3-19 Code 128 / UCC EAN128

Table 3-17 Code128 / UCC EAN128 Explaining

Item	Explaining
<input type="checkbox"/> Enable UCC128/EAN128	Enable UCC128/EAN128.

## C Type -- Others Barcodes

### 3.2.2.15 China Post




Figure 3-20 China Post

Table 3-18 China Post Explaining

Item		Explaining
Checksum	<input type="checkbox"/> Verify	Whether verify checksum by barcode.
	<input checked="" type="checkbox"/> Send Check Digit	Whether send check digit by barcode.
Length	<input checked="" type="radio"/> Min-Max (Default: 4 / 48)	Min Length can be set from 4 to 48
		Max Length can be set from 4 to 48
	<input type="radio"/> Fixed	Length 1 can be set from 4 to 48
		Length 2 can be set from 4 to 48
		Length 3 can be set from 4 to 48

### 3.2.2.16 Code4

The barcode do not have setting.




Figure 3-21 Code4

### 3.2.2.17 GTIN

The barcode do not have setting.




Figure 3-22 GTIN

### 3.2.2.18 Korea Code 3 of 5

The barcode do not have setting.




Figure 3-23 Korea Code 3 of 5

### 3.2.2.19 RSS






Figure 3-24 RSS

Table 3-19 RSS Explaining

Item		Explaining
<input type="checkbox"/>	Convert to UCC128	The scanner will convert RSS to UCC128.
Checksum	<input type="checkbox"/> Verify	Whether verify checksum by barcode.

### 3.2.3 Bluetooth Device Properties

Table 3-20 Bluetooth Device Properties

ICON	ITEM & FUNCTION
	<ul style="list-style-type: none"> <li>● <b>“BT Service” Tab ( Figure 3-25) :</b></li> <li>✓ Tap the <b>“Enable Bluetooth Device”</b> to enable Bluetooth device.</li> <li>✓ Wait for 20 seconds in order to initialize the Bluetooth hardware correctly.</li> <li>✓ Click <b>“Scan Device Service”</b> to pop <b>“Bluetooth Manager”</b> window. Then tap the <b>Scan Device</b> button to initiate a scan for Bluetooth hardware. The Bluetooth manager lists the Bluetooth devices that it finds, see <b>Figure 3-26</b>. If Bluetooth hardware is not found the <i>Bluetooth Hardware Error</i> window appears, see <b>Figure 3-27</b>. <b>Table 3-21</b> described the Bluetooth Icons.</li> <li>✓ Double tap the device to connect to on the device list. The Bluetooth Manager Authentication window appears. Tap <b>No</b> to connect to the device without authentication, or tap <b>Yes</b> to authenticate the device before connecting. (<b>Figure 3-28</b>)</li> <li>✓ If the <b>Yes</b> button was selected in the Bluetooth Manager Authentication window, the enter PIN windows appears. Enter a PIN (between 1 and 16 characters) in the <i>Enter PIN:</i> text box, and tap <b>OK</b>. The mobile computer sends the PIN request to the device for bonding. (<b>Figure 3-29</b>)</li> <li>✓ When prompted, the same PIN must be entered on the other device. When the PIN is entered correctly on the other device, the bonded icon  appears on the device list. (<b>Figure 3-30</b>)</li> <li>● <b>“Serial Port” Tab ( Figure 3-30-1) :</b></li> <li>✓ Tap the <b>“Enable Bluetooth Device”</b> to enable Bluetooth device.</li> <li>✓ Wait for 20 seconds in order to initialize the Bluetooth hardware correctly.</li> <li>✓ If want to use Virtual com, only SPP base profiles are supported.(i.e. Printer, Modem, and LAP).Switch to <b>“Serial Port”</b> tab, and will see the devices you had trusted or active. Select the device that you want to map a virtual com and which virtual com you want to use.</li> <li>✓ Now COM1 has mapped for BT device.</li> </ul>






Figure 3-25 Bluetooth Device Properties




Figure 3-25-1 Bluetooth Device Properties



Figure 3-26 Bluetooth Manager Windows




Figure 3-26-1 Bluetooth Manager Windows



Figure 3-27 Bluetooth Error Windows



Figure 3-28 Bluetooth Manager Windows



Figure 3-29 Bluetooth Enter PIN Windows




Figure 3-30 Bluetooth Manager Windows




Figure 3-30-1 Bluetooth Manager Windows




Figure 3-30-2 Bluetooth Manager Windows




Figure 3-30-3 Bluetooth Manager Windows





Figure 3-30-4 Bluetooth Manager Windows

**Note:** If the device to which the mobile computer is bonding does not appear in the list, ensure it is turned on, in discoverable mode, and within range (30 feet / 10 meters) of the mobile computer.

Table 3-21 Bluetooth Icon

Icon		Description
	Unknown device icon	Device is not defined
	Locked icon	Device is locked and cannot be bonded to.
	Not locked icon	Device is not locked and can be bonded to.
	Bluetooth device icon	Bluetooth device
	Bonded device icon	Bonded Bluetooth device
	Mobile device icon	Device is a mobile device
	Phone icon	Device is a phone.
	Printer icon	Device is a printer
	Network icon	Device is a network.

Icon		Description
	Linked icon	Device is linked.

### 3.2.4 Certificates

Certificates are used by some applications for establishing trust and for secure communications.

Certificates are signed and issued by certificate authorities and are valid for a prescribed period of time. Windows CE manages multiple certificate stores.

Table 3-22 Certificates


ICON	ITEM & FUNCTION
 Certificates	<ul style="list-style-type: none"> <li>● <b>“Store” Tab ( Figure 3-31 ) :</b></li> </ul>
	<ul style="list-style-type: none"> <li>✓ In the Stores tab, select the certificate store you wish to view or modify from the drop-down list (<b>Figure 3-32</b>).</li> <li>✓ The <b>“Trusted Authorities”</b> store lists the top-level certificates for authorities you trust. (<b>Figure 3-33 , Figure 3-34</b>)</li> <li>✓ The <b>“My Certificates”</b> store contains your personal certificates, which you use to identify yourself.</li> <li>✓ Intermediate certificate authorities that help establish a chain of trust are stored in the <b>“Other Authorities”</b> store.</li> </ul>
	<ul style="list-style-type: none"> <li>● <b>“Store” Tab :</b></li> </ul>
	<ul style="list-style-type: none"> <li>✓ To add a certificate or associated private key to the selected store, select <b>“Import”</b> (<b>Figure 3-35</b>).</li> <li>✓ To view more details of the selected certificate, such as the expanded name or expiration date, choose <b>“View”</b>.</li> <li>✓ To delete the selected certificate from the store, choose <b>“Remove”</b>.</li> </ul>



Figure 3-31 Certificates




Figure 3-32 Certificates




Figure 3-33 Certificates




Figure 3-34 Certificates



Figure 3-35 Certificates

### 3.2.5 Control Center

The Control Center includes four AP, listed the following .....





Figure 3-36 Control Center

#### 3.2.5.1 Information

Table 3-23 Information

ICON	ITEM & FUNCTION
	<ul style="list-style-type: none"><li data-bbox="454 1400 1343 1444">● <b>“Information” Tab :</b></li><li data-bbox="454 1444 1343 1534">✓ Provide Software version, MAC address, Bluetooth ID, Serial No. and Configuration No.</li></ul>

### 3.2.5.2 Brightness

Table 3-24 Brightness




ICON	ITEM & FUNCTION	
	<b>LCD Brightness</b>	
	Set the LCD brightness by adjusting the slider from low to high	
	Amounts 5 steps: Every step have corresponding picture of self.	
		
	<input checked="" type="checkbox"/> Battery Power, turn off backlight after	The table must disable when its item is not marked.
	The table has 15 seconds, 30 seconds, 1 minute, <u>2 minutes</u> and 5 minutes.	
<input checked="" type="checkbox"/> AC Power, turn off backlight after	The table must disable when its item is not marked.	
	The table has 15 seconds, 30 seconds, 1 minute, <u>2 minutes</u> and 5 minutes.	
<input type="checkbox"/> Enable Keypad Brightness	Open keypad brightness or not.	



Figure 3-37 Brightness

### 3.2.5.4 Fn-key Settings

Table 3-26 Fn-Key

ICON	ITEM & FUNCTION		
	<ul style="list-style-type: none"> <li><b>Fn-Key Setting (Figure 3-42)</b></li> </ul>		
	<b>Fn Key</b>	<b>The Application Program of default setting</b>	
	F1	Internet Explorer	
	F2	Microsoft WordPad	
	F3	Inbox	
	F4	My Computer	
	F5	Barcode Settings	<b>Only for SC820</b>
	F6	Media Player	
	F7	<None>	
	F8	Information	
<ul style="list-style-type: none"> <li>✓ To assign your favorite application program to Hot Keys.</li> <li>✓ Choose one of Hot Keys from pull-down list. <b>(Figure 3-43)</b></li> <li>✓ To tap “Browse...” inside “Assign program” applet.</li> <li>✓ Select one application program you want from program list, then, choose “OK”. <b>(Figure 3-43)</b></li> <li>✓ To tap “Default” to return back to default setting. <b>(Figure 3-42)</b></li> </ul>			




Figure 3-42 Fn-Key Settings



Figure 3-43 Fn-Key Settings



### 3.2.5.3 Backup Restore

Table 3-25 Backup Restore


ICON	ITEM & FUNCTION
	<ol style="list-style-type: none"> <li>1. You can backup/restore system to/from flash disk or inserted memory card. (A. Disk on Chip, B. CF Card, C. SD Card) ( Figure 3-38)</li> <li>2. When you launch this AP, it must check backup file in DOC first. And if you select other storage, it will check again.</li> <li>3. Then if it has the file, appeared its date behind “Last backup date:”; if not, disable “Restore Now” Button.</li> <li>4. When you press the Backup/Restore Button will be a warning dialog pop up. ( Figure 3-39)</li> <li>5. When system backup/restoring finished will be a message dialog will pop up. (A. Backup: Figure 3-40, B. Restore: Figure 3-41)</li> </ol>



Figure 3-38 Backup Restore





Figure 3-39 Backup & Restore Start




Figure 3-40 Backup OK





Figure 3-41 Restore OK


### 3.2.6 Date/Time

Table 3-27 Date/Time

ICON	ITEM & FUNCTION
 Date/Time	<ul style="list-style-type: none"> <li>● <b>“Date/Time” Tab :</b> ( Figure 2-14)</li> <li>✓ Please see the detail information of <b>2.5.1 Setting Time and Date on P.2-21</b></li> </ul>

### 3.2.7 Dialing Properties

Table 3-28 Dialing properties

ICON	ITEM & FUNCTION
 Dialing	<ul style="list-style-type: none"> <li>● <b>“Dialing Properties” Tab :</b> ( Figure 3-44)</li> <li>✓ In the <b>When dialing from</b> list, select the <b>“Location”</b> where you want to change settings.(Figure 3-45)</li> <li>✓ To create a new location, select <b>“New”</b>. Enter the name of the location, and then select <b>“OK”</b>.(Figure 3-46)</li> <li>✓ Enter or edit the area code and local country code as needed.</li> <li>✓ In <b>Dial using</b>, select <b>“Tone dialing”</b> or <b>“Pulse dialing”</b>. Most phone lines are tone.</li> <li>✓ To automatically disable call waiting, select <b>“<input type="checkbox"/> Disable call waiting by dialing”</b>, select the appropriate number sequence in the list, or enter a new sequence.</li> <li>● <b>Editing dialing patterns (Figure 3-47)</b></li> <li>✓ Using the codes listed in the topic; revise the dialing patterns as needed.</li> </ul> <p><b>Notes:</b></p> <ul style="list-style-type: none"> <li>■ If you need to use character other than the ones listed here, use manual dialing.</li> <li>■ Hyphens and spaces in dialing strings are ignored.</li> <li>■ Some modems may not respond to the following characters, even though your device lets you add them to the dial string.</li> </ul>




Figure 3-44 Dialing Properties




Figure 3-45 Dialing Properties




Figure 3-46 Dialing Properties





Figure 3-47 Dialing Properties

### 3.2.8 Display Properties

Table 3-29 Display properties

ICON	ITEM & FUNCTION
 Display	<ul style="list-style-type: none"> <li>● <b>“Background” Tab</b> :( <b>Figure 3-48</b>)</li> <li>✓ From the <b>“Image”</b> list, select an image you want as the background of the desktop.(<b>Figure 3-49</b>)</li> <li>✓ To locate an image in another folder, select <b>“Browse”</b>.(<b>Figure 3-50</b>)</li> <li>✓ To have the image cover the entire background, select “ <input type="checkbox"/> <b>Tile image on background</b>”</li> </ul> <hr/> <ul style="list-style-type: none"> <li>● <b>“Appearance” Tab</b>(<b>Figure 3-51</b>)</li> <li>✓ Change the color scheme :( <b>Figure 3-52</b>)             <ul style="list-style-type: none"> <li>➢ From the” <b>Scheme</b>” list, select a scheme.</li> <li>➢ View your choice in the preview box. If you like the scheme, select <b>“Apply”</b>.</li> </ul> </li> <li>✓ Create a custom color scheme:             <ul style="list-style-type: none"> <li>➢ From the <b>“Item”</b> list, select a display item.</li> <li>➢ From the <b>“Basic colors”</b> list, select a color, and select <b>“OK”</b>.</li> <li>➢ View your color selection(s) in the Preview box.</li> <li>➢ To save the scheme, select <b>“Save”</b>.</li> <li>➢ In the <b>“Save this color scheme as”</b> box, enter a name for the scheme, and select <b>“OK”</b>.</li> <li>➢ Select <b>“Apply”</b>.</li> </ul> </li> </ul>




Figure 3-48 Display properties



Figure 3-49 Display properties




Figure 3-50 Display properties




Figure 3-51 Display properties





Figure 3-52 Display properties

### 3.2.9 Input Panel

Table 3-30 Display properties

ICON	ITEM & FUNCTION
 Input Panel	<ul style="list-style-type: none"> <li>• “Input panel” Tab :( Figure 3-53)</li> <li>✓ Select the input method you want to change.</li> <li>✓ To change the <b>Soft Keyboard Options</b> , tap “Option” (Figure 3-54) .</li> </ul>

	<ul style="list-style-type: none"> <li>• <b>“Options” Tab :</b></li> <li>✓ Change the soft keyboard options as desired, selecting from: <ul style="list-style-type: none"> <li>➢ Large or small keys</li> <li>➢ Using gestures for space, black-space shift, and enter.</li> </ul> </li> <li>✓ To exit the <b>soft keyboard Options</b>, press <b>“OK”</b> on the control bar, or press the <b>&lt;Enter&gt;</b> key on the keypad.</li> <li>✓ To exit the <b>Input Panel</b>, press <b>“OK”</b> on the control bar, or press the <b>&lt;Enter&gt;</b> key on the keypad.</li> </ul>
--	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------




Figure 3-53 Input Panel Properties





Figure 3-54 Input Panel Properties

### 3.2.10 Internet Options

Table 3-31 Internet Options

ICON	ITEM & FUNCTION
	<ul style="list-style-type: none"> <li>• <b>“General” Tab :</b> ( Figure 3-55)</li> </ul>
	<ul style="list-style-type: none"> <li>✓ Type in the URL of desired start page and the desired search engine. You also change the <b>Cache Size</b>, <b>clear the Cache</b> and <b>Clear the History</b>..</li> </ul>
	<ul style="list-style-type: none"> <li>• <b>“Connection” Tab :</b> ( Figure 3-56)</li> </ul>
	<ul style="list-style-type: none"> <li>✓ Modify the network access setting as desired.</li> </ul>

<ul style="list-style-type: none"> <li>● <b>“Security” Tab (Figure 3-57)</b></li> </ul>
<ul style="list-style-type: none"> <li>✓ Modify the security settings as desired. You can enable any of the following by tapping the checkbox: <ul style="list-style-type: none"> <li>➤ Allow cookies</li> <li>➤ Allow TLS 1.0 security</li> <li>➤ Allow SSL 2.0 security</li> <li>➤ Allow SSL 3.0 security</li> <li>➤ Warn when switching across secure and insecure areas.</li> </ul> </li> </ul>
<ul style="list-style-type: none"> <li>● <b>“Advanced” Tab (Figure 3-58)</b></li> </ul>
<ul style="list-style-type: none"> <li>✓ Modify the security settings as desired. You can enable any of the following by tapping the checkbox: <ul style="list-style-type: none"> <li>➤ Display Image in pages</li> <li>➤ Play sounds in pages</li> <li>➤ Enable scripting</li> <li>➤ Display a notification about every script error</li> <li>➤ Underline links- <ul style="list-style-type: none"> <li>○ Never</li> <li>○ Always</li> <li>○ Hover</li> </ul> </li> </ul> </li> </ul>



Figure 3-55 Internet Settings




Figure 3-56 Internet Settings




Figure 3-57 Internet Settings





Figure 3-58 Internet Settings

### 3.2.11 Keyboard

Table 3-32 Keyboard

ICON	ITEM & FUNCTION
 Keyboard	<ul style="list-style-type: none"> <li data-bbox="427 1182 885 1220">• “Repeat” Tab :( Figure 3-59)</li> <li data-bbox="427 1232 1244 1317">✓ To change the amount of time between depressions before repetition starts, adjust the <b>Repeat delay</b> slider</li> <li data-bbox="427 1328 1209 1366">✓ To change the repeat rate, adjust the <b>Repeat rate</b> slider.</li> <li data-bbox="427 1377 774 1415">✓ Test your new setting.</li> <li data-bbox="427 1426 1013 1464">✓ Tap “<b>OK</b>” to exit the “<b>Keyboard</b>” Tab.</li> </ul>







Figure 3-59 Keyboard Properties

### 3.2.12 Network and Dial-up Connections

Table 3-33 Network and Dial-up Connections

ICON	ITEM & FUNCTION
 Network and Dial-up Co...	<ul style="list-style-type: none"> <li>● <b>“Connection” Tab :</b></li> <li>✓ To create a <b>“Dial-up Connection”</b>:             <ul style="list-style-type: none"> <li>➢ Double-tap the <b>“Make New connection”</b>.</li> <li>➢ In the <b>“Make New Connection”</b> dialog box, enter a name for the connection.</li> <li>➢ Select <b>“Dial-Up Connection”</b>.</li> <li>➢ Select the <b>“Next”</b> button.</li> <li>➢ Select the modem you want use.</li> <li>➢ Select <b>“Configure”</b></li> <li>➢ Under <b>“Connection Reference”</b>, use the default settings provided. If you can’t connect using these settings, see your ISP or network administrator for specific information. If you want to always enter a phone number before connecting, Select <b>“Manual Dial”</b>. Select <b>“OK”</b>.</li> </ul> </li> </ul>

- Select “**TCP/IP Settings**”. In the “**General**” tab, ensure “**Use Server-assigned IP address**” is selected. In the “**Name Servers**” tab, ensure “**Use Server-assigned addresses**” is selected, and select “**OK**”. If you are unable to connect with these default settings, see your ISP or network administrator for specific TCP/IP information.
- Select the “**Next**” button and type the telephone number.
- Select the “**Finish**” button.

The connection you just created appears as an icon in the “**Network and Dial-up Connections**” folder.

- ✓ Set up a **point-to-Point Protocol (PPP)** account with an ISP and obtain the following information:
  - Access telephone number
  - User name
  - Password

Once you have established an account, create a new connection on your device. When creating this connection, you should be able to use all of the default TCP/IP settings provided in the Make New Connection Wizard. If you can’t connect using the default settings, contact your ISP or access your ISP’s Web site for specific TCP/IP information as well as primary and secondary DNS address.

- ✓ **Modify connection setting**
  - Select **Start > Settings > Network and Dialup Connections**
  - Select the icon for connection settings you want to modify.
  - Select **File > Properties**, or double- tap the appropriate icon.
  - Select desired options. There may be additional settings that depend on the connection. To modify, select the icon and select the icon and select **Advanced Settings...** from the menu.



Figure 3-60 Network and Dial-up Connections




Figure 3-61 Network and Dial-up Connections



Figure 3-62 Network and Dial-up Connections



Figure 3-63 Network and Dial-up Connections






Figure 3-64 Network and Dial-up Connections




Figure 3-65 Network and Dial-up Connections




Figure 3-66 Network and Dial-up Connections




Figure 3-67 Network and Dial-up Connections




Figure 3-68 Network and Dial-up Connections




Figure 3-69 Network and Dial-up Connections



Figure 3-70 Network and Dial-up Connections





Figure 3-71 Network and Dial-up Connections

### 3.2.13 Owner

Table 3-35 Owner

ICON	ITEM & FUNCTION
	<ul style="list-style-type: none"> <li>• “Identification” Tab : (Figure 3-72)</li> </ul>

	<ul style="list-style-type: none"> <li>✓ Fill in or edit the data as desired.</li> <li>✓ To have this information displayed when you start your device, select <b>“Display Owner Identification”</b> at Power On.</li> <li>✓ To set up identification for remote networks, see Setting up identification for remote networks.</li> </ul>
	<ul style="list-style-type: none"> <li>● <b>“Network ID” Tab: (Figure 3-73)</b></li> </ul>
	<ul style="list-style-type: none"> <li>✓ Enter the user name, password, and domain name you use to log on to remote network.</li> </ul>



Figure 3-72 Owner Properties




Figure 3-73 Owner Properties

### 3.2.14 Password

Table 3-36 Password



ICON	ITEM & FUNCTION
 Password	<ul style="list-style-type: none"> <li>● <b>“Password Setting” Tab : (Figure 3-74)</b></li> <li>✓ Enter the password</li> <li>✓ In the <b>“Confirm password”</b> box, enter the password again.</li> <li>✓ To require the password on startup, select <b>“Enable password protection at power- on”</b>. and/or select <b>“Enable password protection for screen saver”</b></li> <li>✓ To exit the <b>Password</b> control panel, press <b>“OK”</b> from the control bar, or press the <b>&lt;Enter&gt;</b> key on the keypad.</li> </ul>



Figure 3-74 Password Properties

### 3.2.15 PC Connection

Table 3-37 PC Connection

ICON	ITEM & FUNCTION
 <p>PC Connection</p>	<ul style="list-style-type: none"> <li>● <b>“PC Connection” Tab : (Figure 3-75)</b></li> <li>✓ Select the first checkbox to enable direct connections to the desktop computer. <b>(Figure 3-75)</b></li> <li>✓ Tap the <b>“Change Connection...”</b> button to modify the connection method from <b>USB</b> or <b>Serial</b>. <b>(Figure 3-76)</b></li> <li>✓ To exit the <b>“Change Connection”</b> dialog, press <b>“OK”</b> from the control bar, or press the <b>&lt;Enter&gt;</b> key on the keypad.</li> <li>✓ To exit the <b>“PC Connection”</b> properties control panel, press <b>“OK”</b> from the control bar, or press the <b>&lt;Enter&gt;</b> key on the keypad.</li> </ul>




Figure 3-75 PC Connection








Figure 3-76 PC Connection

### 3.2.16 Power

Table 3-38 Power

ICON	ITEM & FUNCTION
 Power	<ul style="list-style-type: none"> <li>● <b>“Battery” Tab : (Figure 3-77)</b></li> <li>✓ Provide change level indicators for <b>Main battery</b> and <b>Backup battery</b>.</li> <li>✓ Provide remaining power capacity of main battery.</li> <li>✓ If a “Main Batteries very Low” warning message shows, the remaining battery life is around 30 minutes to SC800 shuts down. ( <b>Figure 3-81</b>)</li> <li>✓ The PDT will shutdown during the main batteries capacity is around <b>0%</b></li> <li>✓ To exit Battery control panel, press “<b>OK</b>” from the command bar, or press &lt;<b>Enter</b>&gt; key on keypad.</li> <li>● <b>“ Schemes” Tab: (Figure 3-78)</b></li> </ul>



	<ul style="list-style-type: none"> <li>✓ The <b>Scheme</b> Tab allows you to determine the time to switch state to Suspend mode when using either <b>Battery Power</b> or <b>AC Power</b>.</li> <li>✓ Select <b>Battery Power</b> or <b>AC Power</b> as the power scheme from the pull-down list.( <b>Figure 3-78</b>)</li> <li>✓ Select the time to suspend mode from the pull-down list. ( <b>Figure 3-79</b>)</li> </ul>
	<ul style="list-style-type: none"> <li>● <b>“Device Status” Tab: ( Figure 3-80)</b></li> </ul>
<p><b>Note:</b></p> 	<p>This ICON inside the Task Bar shows that AC adapter provides power to the PDT</p>
	<p>The ICON inside the Task Bar shows that Main Batteries provides the power to the PDT.</p>
	<p>The ICON inside the Task Bar shows that AC adapter provides the power to the PDT and is charging the main batteries..</p>




Figure 3-77 Power




Figure 3-78 Power




Figure 3-79 Power




Figure 3-80 Power





Figure 3-81 Power

### 3.2.17 Regional Settings

Table 3-39 Regional Settings

ICON	ITEM & FUNCTION
 Regional Settings	<ul style="list-style-type: none"> <li>● “Region” Tab : (Figure 3-82)</li> <li>✓ Select the desired location/language.</li> <li>✓ Review the <b>Appearance samples</b> in the bottom half of the screen.</li> <li>✓ Select the Tab at the top for any settings you wish to change, Options to modify include <b>Number, Currency, Time, and Date.</b></li> </ul>





Figure 3-82 Regional Settings


### 3.2.18 Remove Programs

Table 3-40 Remove Programs

ICON	ITEM & FUNCTION
 Remove Programs	<ul style="list-style-type: none"> <li>● <b>“Remove Programs” Tab :</b></li> <li>✓ Only user installed programs can be removed.</li> <li>➤ Select the program you wish to remove from the list and press <b>“remove”</b> button.</li> </ul>

### 3.2.19 Storage Manager

Table 3-41 Storage Manager

ICON	ITEM & FUNCTION
 <p>Storage Manager</p>	<ul style="list-style-type: none"> <li>• “Storage Manager” Tab : (Figure 3-83)</li> <li>✓ To change Storage properties control panel default settings:               <ul style="list-style-type: none"> <li>Insert. Compact Flash(CF) or Secure digital (SD) storage card into the unit.</li> <li>➢ Select <b>Start &gt; Settings &gt; Control Panel &gt; Storage Properties</b></li> <li>➢ From the “<b>Storage Info</b>” pull-down list, select the desired storage device.</li> <li>➢ You can also <b>format, dismount</b>, and create partitions on storage devices using this control panel.</li> <li>➢ To save and exit the <b>Storage Properties</b> control panel, press “<b>OK</b>” from the control bar, or press the &lt;<b>Enter</b>&gt; key on the keypad.</li> </ul> </li> </ul> <p><b>Caution:</b> Dismounting or formatting the DiskOnChip will erase all files and program stored in Flash Memory</p>





Figure 3-83 Storage Manager

### 3.2.20 Stylus

Table 3-42 Stylus

ICON	ITEM & FUNCTION
 Stylus	<ul style="list-style-type: none"> <li>● <b>“Double-Tap” Tab : (Figure 3-84,Figure 3-85)</b></li> <li>✓ Double-tap the checkerboard grid at a comfortable speed.</li> <li>✓ Double-tap clapboard to test your settings</li> <li>✓ The function is OK if the figures are changed from Figure 3-84 to Figure 3-85.</li> <li>✓ To tap <b>“OK”</b> to exit the Stylus Properties.</li> </ul>
	<ul style="list-style-type: none"> <li>● <b>“Calibration”:</b> (Figure 3-86, Figure 3-87)</li> <li>✓ In the Welcome Wizard, you tapped a target with the stylus to set the amount of pressure needed for the screen to respond to your stylus taps.</li> <li>✓ Please also see <b>2.4.3 Calibration of the touch Screen</b></li> </ul>




Figure 3-84 Stylus Properties




Figure 3-85 Stylus Properties



Figure 3-86 Stylus Properties





Figure 3-87 Stylus Properties

### 3.2.21 System

Table 3-43 System

ICON	ITEM & FUNCTION
 System	<ul style="list-style-type: none"> <li>● <b>“General” Tab : (Figure 3-88)</b></li> </ul>
	<ul style="list-style-type: none"> <li>✓ To show:               <ul style="list-style-type: none"> <li>➢ Firmware information</li> <li>➢ Information about Processor type, Memory size, Expansion card</li> </ul> </li> </ul>
	<ul style="list-style-type: none"> <li>● <b>“Memory” : (Figure 3-89)</b></li> </ul>
	<ul style="list-style-type: none"> <li>✓ Move the slider to adjust memory allocation. Default storage memory is normally is normally set to about 8MB with the reminder assigned to Program memory.</li> <li>✓ Press the “OK” key on the Keypad.</li> </ul> <p><b>Note: the difference is occupied by OS between the RAM size in Information properties and total memory size of storage memory and program memory</b></p>
	<ul style="list-style-type: none"> <li>● <b>“Device Name” Tab : (Figure 3-90)</b></li> </ul>
	<ul style="list-style-type: none"> <li>✓ Your device uses this information to identify itself to other computers.</li> <li>✓ The input panel will open to facilitate data entry.</li> </ul>

	<ul style="list-style-type: none"> <li>✓ To close the <b>Device Name</b>, press the “<b>OK</b>” button, or press the <b>&lt;Enter&gt;</b> key on keypad.</li> </ul>
	<ul style="list-style-type: none"> <li>• “<b>Copyrights</b>” Tab: (Figure3-91)</li> </ul>
	<ul style="list-style-type: none"> <li>✓ Refer to this tab for specific copyright data. As a user, you are responsible to read this statement.</li> </ul>



Figure 3-88 System Properties




Figure 3-89 System Properties




Figure 3-90 System Properties





Figure 3-91 System Properties

### 3.2.22 Volume & Sounds Properties

Table 3-44 Volume & Sound

ICON	ITEM & FUNCTION
 <p>Volume &amp; Sounds</p>	<ul style="list-style-type: none"> <li>● “Volume” Tab : (Figure 3-92)</li> </ul> <p>✓ The factory default for Volume is the forth level. You can adjust the volume to your environment and comfort.</p> <ul style="list-style-type: none"> <li>➤ Set the volume by adjusting the slider from <b>Soft</b> to <b>Loud</b>, or press <b>Right</b> or <b>Left</b> edge of <b>Navigation</b> keys</li> </ul>
	<ul style="list-style-type: none"> <li>● “Sounds ” Tab: (Figure3-93)</li> </ul> <p>✓ Enable the desired sounds for key clicks, screen taps, notifications, and applications.</p>




Figure 3-92 Volume & Sound




Figure 3-93 Volume & Sound



### 3.3 Taskbar and Start Menu

Table 3-45 Taskbar and Start menu

ICON	ITEM & FUNCTION
Taskbar and Start Menu	<ul style="list-style-type: none"> <li>● <b>“General” Tab :</b></li> </ul>
	<ul style="list-style-type: none"> <li>✓ In this tab, You can change the position of the Taskbar and Start menu               <ul style="list-style-type: none"> <li>➤ Is <b>always on top</b> or not</li> <li>➤ <b>Auto hide</b> or not</li> <li>➤ <b>Show Clock</b> or not</li> </ul> </li> </ul>
	<ul style="list-style-type: none"> <li>● <b>“Advanced ” Tab:</b></li> </ul>
	<ul style="list-style-type: none"> <li>✓ Tap the <b>“Clear”</b> button to remove the contents of the Documents Menu.</li> <li>✓ Enable <b>“<input type="checkbox"/> Expand Control Panel”</b> to list all icons of Control Panel from top to bottom.</li> </ul>

# Chapter 4. Communication

---

## 4.1 Installing & Setting Up Microsoft ActiveSync

### 4.1.1 Installing Microsoft ActiveSync on the Host PC

Microsoft ActiveSync is a file transfer tool to synchronize the files on a PC with the files on your PDT.

To install Microsoft ActiveSync, complete the following steps on the PC:

1. Go to the Microsoft Windows CE.NET website and download the latest current version of ActiveSync:  
<http://www.microsoft.com/mobile/pockeypc/downloads/> .
2. Install the latest version of Microsoft ActiveSync on the host PC.
3. Open ActiveSync.
4. Select **File > Communication Settings** from ActiveSync's menu bar.
5. Go to "Using ActiveSync" on page 4-1 to continue using ActiveSync.

### 4.1.2 Connecting PDT to Host PC

1. You can use either the USB/Serial (RS232) port of Single Dock or a USB/Serial (RS232) cable to connect the PDT to the Host PC.
  - To use the dock, you must first insert the PDT into the slot, making sure that the unit is firmly seated the dock.
  - To use the cable, connect the USB/Serial cable to the PDT.
2. Connect the USB/Serial dock or cable to the Host PC's serial port or USB port.
3. Connect the dock or PDT to the power adapter and power source.

## 4.2 Using ActiveSync

Use ActiveSync to transfer and synchronize files between the PDT and the Host PC.

### 4.2.1 Setting up a Partnership

During the Microsoft ActiveSync installation, you were prompted to create a partnership with your mobile device. When you set up a partnership, you select synchronization and file conversation settings, which are contained in a file on your desktop computer. This file enables your desktop computer to recognize your device.

Only devices that have a partnership with a desktop computer can synchronize information between the two computers.

For more information on partnerships, please refer to your Microsoft ActiveSync documentation or help file.

### **Transferring Files:**

To transfer files, complete the following steps on the host PC:

- ✓ Select **Start > Programs > Communication > (Serial, or USB) ActiveSync.**
- ✓ Double-click on the selected **ActiveSync** icon
- ✓ After you have established a connection with PDT, tap the “**Explore**” button at the top of the **ActiveSync** window (or select **Explore** from the File menu).
- ✓ Navigate to the target directory on your PDT and copy the desired file by using the **Copy/paste** method or dragging and dropping the desired file(s) into the folder.



Figure 4-1 **Communication**

## 4.2.2 ActiveSync File Synchronization

ActiveSync files synchronization requires an ActiveSync partnership between the PDT and the Host PC. Refer to “Setting up a Partnership”, above:

- ✓ Select the files in the synchronization configuration for the PDT partnership.
- ✓ Select **Tools > Options** from the ActiveSync command bar to configure the synchronization options.
- ✓ Place the file to be synchronized in the **Synchronization** folder created you’re **My Documents** directory. Defaults to the desktop. During the ActiveSync connection, all files in the **Synchronization** folder will be synchronized to the **\My Documents** directory on the PDT.




Figure 4-2 **Connected**

## 4.3 Networking

Please see the **3.2.14 Owner, Table 3-33 Owner** on page 3-45 for **setting up the network ID**. And see the **2.5.6 Setting Up Wireless LAN RF** to setup the 802.11b Wireless LAN for RF connecting.

# Chapter 5. Software Applications

---

## 5.1 Introduction

The PDT includes Calculator, Inbox,.....

You can switch to any software program by tapping the Start Menu.

## 5.2 Software Applications

### 5.2.1 Inbox

Use **Inbox** to send and receive e-mail messages in the following ways:

- ✓ Synchronize e-mail messages with Microsoft Exchange or Outlook on the Host Computer.
- ✓ Send and receive e-mail messages by connecting directly to an e-mail server through an Internet server provider (ISP) or a network.

To setup “**Inbox**”:

- ✓ Select **Start> Programs> Inbox** to open it.
- ✓ Select **Service> Options** from the command bar. Drag the dialog to show the right edge to configure e-mail.
- ✓ Select “**Add...**” (Note 1)
- ✓ In the “**Service Type**” list, select **POP3 Mail** or **IMAP4 Mail**. (**POP3** is the most common mail protocol for ISPs). Enter a unique name for e-mail service in the “**Service name**” field. This name cannot be changed later.
- ✓ Select “**OK**”.
- ✓ The Mail Service Setup wizard appears after you add a service. If you are adjusting the setting of an existing service, select **Service> Options**, select the service you are using, and then **Properties**. In the **Service Definition** dialog box, complete the following entries as needed:
  - **Connection**: Select the name of the connection you created to connect to the mail server. If you are receiving e-mail through a network(Ethernet) connection, select **Network Connection**. If you want Inbox to use your current connection, select (**none**). If you have not created a connection, select **Create new connection**. Double-tap the “**Make new Connection**”

icon, and follow the instructions in wizard. When finished, select Inbox in the Taskbar and continue setting up Inbox.

- **POP3 Host**(POP3 only): Enter the name of the mail server you use to receive and send messages.
  - **Server**(IMPA4 only): Enter the name of he mail server you use to receive and send messages.
  - **User ID**: Enter the user name or mailbox ID assigned to you.
  - **Password**: Enter the password you use to access this mail account. If you do not want to be prompted to enter the password each time you connect, select “**Save password**”.
  - **Domain**(**Windows NT**): Enter your Windows NT domain name. This name is required only when connecting to networks, such as a corporate network, that use Windows NT domain security. This is not required for most ISP accounts. If you have trouble connecting, try clearing this box.
  - **SMTP Host**: If your mail service uses a separate server for SMTP, enter the name in the box. If you’re setting up a POP3 Mail service with an ISP, the ISP must use an SMTP mail gateway.
  - **Return Address**: By default, the return address is set to *username@POP3host* or *username@Servername*. Depending on the service you are using. If this is not your e-mail address, enter the correct address in the box.
- ✓ **Set general preferences:**
- If you are adjusting the setting of an existing service, select **Service> Options**, select the service you are using, select **Properties**, and then select **Next**. In the **General Preferences** dialog box, choose any of the following setting settings, all of which are optional:
- **Disconnect service after actions are performed**: Select to automatically disconnect from the server upon completion of all pending actions. This option minimizes connect time and cost.
  - **Check for new messages every**: select the time interval(in minutes) at which you want the device to check for new mail. If this option is turned off, you must check for new mail manually by selecting **Services> Send/Receive Mail**.
  - **Display a message box when new mail arrives** (POP3 only): Select to be informed that new mail has arrived.
  - **Display a message box when new mail arrives** (IMAP4 only): Select to be informed that new mail has arrived.
  - **Send using MIME format** (POP3 only): Select to send messages with

extended characters.

- **Only display messages from last 3 days:** Select how many day's messages you want downloaded.

✓ **Set inbox preferences**

If you are adjusting the settings of an existing service, select **Services> Options**, select the service you are using, select **Properties**, and then select **New** twice. In the **Inbox Preferences** dialog box, choose any of the following options:

- **Get message headers only:** Select to save storage space and time by downloading only headers. You can download a full copy of the message later by selecting the message and then **Services> Get Full Copy**.
- **Include <number> lines:** Select to set the message length (approximate number of lines) that you want to download.
- **Get Full Copy of messages:** Select to receive a full copy of all messages. In addition to the message body, any options you select in **When getting full copy** will be downloaded. Selecting this option increases the amount of time needed to download messages.
- **Only synchronize folder hierarchy under Inbox (IMAP4 only):** Select to speed download time by preventing the complete downloaded of the folder list every time you connect.
- **Get meeting requests (POP3 only):** Select to download and store copies of meeting requests when getting full copies of messages. This setting applies whether you have chosen to download full copies of messages by default, or you selectively download full copies of messages by opening the message and selecting **Services> Get Full Copy** Limitations apply.
- **Get file attachments (POP3 only):** Select to download and save message attachments when getting full copies of messages. This option may use significant RAM and slow download time. This setting applies whether you have chosen to download full copies of messages by default, or if you selectively download full copies of messages and selecting **Services> Get Full Copy**.
- **Get file attachments and meeting requests (IMAP4 only):** Select to download and store meeting requests and message attachments when getting full copies of messages. This setting applies you have chosen to download full copies of messages by default, or if you selectively download full copies of messages by opening the message and selecting **Services> Get Full Copy** Limitations apply.
- **Only if small than (IMAP4 only):** Select to restrict the size of the attachments you download. Set to 10K if you want to receive meeting requests only.

- ✓ **Include the original message in a reply:**
    - Select **Services> Options> Compose** tab.
    - Under **Reply**, select **Include Body**. This setting will place a copy of the original message beneath your response text.
    - To indent the original message, select **Indent**.
    - To add leading characters (such as>) to the original message lines, select **Add leading character**, and enter the character you want.
  
  - ✓ **Save copies of sent messages:**

By default, sent messages are not saved on your device.

    - Select **Services> Options> Compose** tab.
    - Select **Keep copy of sent mail in Sent folder**.
  - ✓ **Set the action to follow deleting, moving, or responding to a message:**
    - Select **Services> Options > Read** tab.
    - Select desired options.
  - ✓ **Delete a message:**

Select the message and select **File> Delete**. Messages are moved to Deleted (local) folder and deleted according to the option you have selected in **Services> Options> Delete** tab:

    - **On connect/disconnect:** Deletes messages when you connect or disconnect from your mail service or exit Inbox.
    - **Immediately:** Deletes messages as soon as you select **File> Delete**.
    - **Manual:** Deletes messages when you select **File> Empty Deleted (local)**
- Note:** If you are working offline, messages that have been deleted from the device the next time you connect.
- ✓ **Empty the Deleted (local) folder:**
    - Select **File> Empty Deleted (local)**. This permanently deletes messages in the Deleted (local) folder.
    - To check or adjust the current settings for deleting messages, select **Services> Options> Delete** tab.
  
  - ✓ **Move or copy a message:**

**Caution:** When you move a message that you have received through POP3 or synchronization to a folder you created on your device, the copy of the message on the server is deleted. This prevents duplicate copies of messages. Although the complete message is moved, message attachments will be deleted if you have not selected the option to download attachments. Once the message is moved, you will be able to access the message only from your device.



- Select the message
  - Select **File> Move To** or **File> Copy To**.
  - Select the destination folder. If you are working offline, the message will be moved or copied from the server the next time you connect.
- ✓ **Folder-**
- ◆ **Create a folder:**
    - Select **File> Folder> New Folder**
    - Type a name for the folder.
  - ◆ **Delete a folder:**
    - Select the folder you want to delete
    - Select **File> Delete**
  - ◆ **Designate a folder as offline:**

Only IMAP4 folders can be designated as offline. All IMAP4 default folders, such as Inbox, are automatically designated as offline. Messages in offline folders can be viewed when you are disconnected from your mail server. If a folder is not designated as offline, you will be able to read and respond to messages in that folder only when connected to the server.

    - To designate a folder as offline, select the folder and then select **Service > Offline Folder**.
  - ◆ **Rename a folder:**
    - Select the folder you want to rename.
    - Select **File> Folder> Rename Folder**.
    - Type the new name for the folder.

**Notes:**

- Default folders, such as Inbox, can't be renamed.
  - Folders you create for IMAP4 mail servers can't be renamed.
- ◆ **Synchronize folders while connected:**

When you synchronize folders, the contents of your device folders and mail server folders are compared and updated. New mail messages are downloaded, and messages in your device Outbox folder are sent. The synchronization behavior depends on how you connect to your mail server.

    - When you connect to a POP3 server, the Inbox and Outbox folders on your device are synchronized with the corresponding folders on the mail server. To synchronize after the initial connection, select **Services> Send/Receive Mail**.
    - When you connect to an IMAP4 server, Inbox, Outbox, and all folders

marked as offline are synchronized. To synchronize all folders after the initial connection, select **Services> Synchronize Folders**. To synchronize just the selected folder and the Outbox folder, select **Services> Send/Receive Mail**.

✓ **Compose and send a message:**

- In list view, select **Compose> New Message**
- Enter the address of one or more recipients, separating them with a semicolon. If the recipient is listed in the Address Book, enter a few letters of the recipient's name and select **Compose> Check Name**. If there is only one match, the e-mail address is inserted. If there is more than one match, select the correct address from the **Choose E-mail Recipients** dialog box. If there is no match then add a new e-mail address through **Choose E-mail Recipients**.
- To attach a file, select **File> attachments> Add Attachment**.
- Select **File> Send**. If you are working offline, the message is moved to the Outbox folder and will be sent the next time you connect.

**Tip:** to see more header information, select the triangle in the lower-right corner of the header area. Select the triangle again to collapse the header area.

✓ **Save a message:**

- Select **File> Save** to save the message you are composing or editing. The message is not sent and is saved in the inbox folder of the active service.

✓ **Reply to or forward a message:**

- Open the message, and then select **Compose> Reply to Sender, Reply to All, or Forward**.
- Enter your response.
- Select **File> Send**.

**Tips:**

- Selections in the Options dialog box determine whether the original text is included.
- To see more header information, select the inverted triangle in the lower-right corner of the header area. Select the triangle again to collapse the header area.

✓ **Check Inbox status:**

- In list view, select **Compose> Status**. You can view details such as the number of messages to be sent, deleted, and copied, and the number of attachments to be downloaded.

✓ **Download message from the server:**

When you download messages, you need to create two connections: a remote

connection and a mail server connection. The remote connection connects you and your ISP or network. The mail server connection downloads messages from your mail server to Inbox on your device. When you select **Services> Connect** in Inbox, Inbox starts a remote connection using the connection you specified when setting up the current mail service. If you are already connected through a remote connection other than the one you specified in the service, you will be asked if you want to use the current connection. If you choose not to, you will need to disconnect from the current connection before you can check for new messages.

- Select the **Services** menu and make sure that the service you want to use is selected (the selected service has a bullet next to it.)
- Select **Services> Connect**. The messages on your device and mail server are synchronized: new messages are downloaded to the device Inbox folder, messages in the device Outbox folder are sent, and messages that have been deleted on the server are removed from the device Inbox. Double-tap a message list to open it.
- If you read a message and decide that you need the full copy, select **File> Get Full Copy** while in the message window or **Services> Get Full Copy** while in list view. This will also download message attachments and meeting requests if you have those options selected in the **Inbox Preferences** dialog box. You can also choose to download full copies of messages by default.
- When finished, select **Services> Connect** to disconnect. You also need to disconnect your dial-up connection by double-tapping the icon in the status bar and selecting **Disconnect**.

**Notes:**

- Receiving entire messages consumes storage memory.
- The size column in the Inbox list view displays the local size and server size of a message. Even when a message has been downloaded fully, these numbers may differ because the size of a message can vary between the server and the device.
- When using IMAP4 to get Outlook + data, you will see the contents of your Journal folder. File editing transactions and documents (such as Task items, e-mail message, and Word documents) attached using drag and drop will appear as shortcuts on the device. A copy of the document will not be moved to your device, and the shortcut on the device cannot be used to access the documents associated with a journal entry to the device, attach the document to the entry rather than dragging and dropping it. Also, be sure to set your IMAP4 service to

receive full copies of messages, attachments, and meeting requests. For more information on using Journal, see the Help for the desktop version of Outlook.

✓ **Working with Message Attachments:**

- If you receive messages through a remote mail server, in Inbox on the device, select the **Get file attachments and meeting requests (IMAP4)** or **Get meeting requests (POP3)** setting in the **Inbox Preferences** dialog box. For more information, see **Set Inbox preferences**.

**Notes:**

- Embedded images and OLE objects cannot be received as attachments
  - Embedded messages can be viewed as an attachment when using IMAP4 to receive e-mail. However, this feature does not work if TNEF is enabled so that you can receive meeting requests.
- ✓ **Check attachments status:**
- An attachment sent with an e-mail message, whether it has been downloaded or not, will appear as an icon at the bottom of the message in its own window pane. If you don't see this pane, select **File> Attachments> Show Attachments**. If TNEF is turned on so you can receive meeting requests, you will not see attachments until they are fully downloaded.
  - To mark an attachment for downloading in a POP3 or IMAP4 service, double-click it. The attachment will be downloaded the next time you connect. You can also set Inbox to download attachments automatically when you get a full copy of a message. For more information, see **Receive attachments**.
- ✓ **Open an attachment:**
- With the message open, double-tap the attachment's icon at the bottom of the message. If you don't see this pane, select **File> Attachments> Show Attachments**.
- ✓ **Store an attachment:**
- Select **Service> Options> Storage** tab.
  - Select to store attachments on internal RAM or a storage card.
  - If you use more than one storage card, select it from the list.
- Note:** Once you make the above selection, all attachments will be moved to the selected card.
- ✓ **Delete an attachment:**
- To delete an attachment from a message you are sending, select the attachment, and then select **Edit> Clear** or press the **DEL** key on the keypad.

- To delete an attachment you have received, delete the message.
- ✓ **Attach a file to a message:**
  - With the message open, select **File> Attachments> Add Attachment**.
  - Select the file you want to attach.

**Note:**

OLE objects cannot be attached to Inbox messages.

Note 1: To add a mail service, select “**Add**”, To remove a mail service, select the service from the **Installed service** box and select “**Remove**”. To view a mail service’s properties, select the service from the **Installed service** box and then select **Properties**.




Figure 5-1 **Inbox**

## 5.2.2 Internet Explorer

With Internet Explorer, you can view Web or intranet Web pages on your device. You will need to use a modem or WLAN to connect to an Internet server provider (ISP) or network.

### 5.2.2.1 Connect to the Internet

Before you can view Web pages, you must set up a remote connection to your ISP or network.

### 5.2.2.2 Start Internet Explorer

- ✓ Open Internet Explorer by selecting **Start > Programs > Internet Explorer**.
- ✓ To get default home page, navigate to the desired default web page.
- ✓ Select **View > Internet Options** from the command bar.
- ✓ Enter the desired URL in the **Start page** field.
- ✓ Press the **OK** button.



Figure 5-2 Internet Explorer

### 5.2.2.3 Navigation Control

Internet Explorer uses sliding menus for application and navigation control. Tap and drag the sliding menus to the left or right to see the hidden menu items and toolbars. To achieve more screen real estate in Internet Explorer, you can hide the **Status** bar and **View** menu. From the top menu bar, go to **View > Hide Toolbars**.

Once it is hidden, you must cold reset to access these features again. Refer to 2.7.2 “**Cold Reset**” for more information.

### 5.2.2.4 Set up a proxy server

Proxy servers are often used when connecting to the Internet through a local network, such as a corporate network, for added security.

- ✓ Select **View > Internet Options > Connection** Tab.
- ✓ Select **Access the Internet using a proxy server**.
- ✓ Enter the proxy server address and port. For more information, see your administrator.
- ✓ To bypass the proxy server for local address, such as corporate intranet pages, select **Bypass proxy for local address**.

#### 5.2.2.5 Enable Cookies

A cookie file contains information about your identity and preferences so that a Web site can tailor information to your needs. The Web site sends the file and it is stored on your mobile device.

- ✓ Select **View > Internet Options > Security** Tab.
- ✓ Select **Allow cookies**.

#### 5.2.2.6 Search for an Internet Site

- ✓ Select **View > Go > Search** to search the web.

#### 5.2.2.7 Go to an Internet address

- ✓ Select **Address Bar**, if necessary to display the Address bar
- ✓ Enter the address
- ✓ Press “**ENTER**” key.

#### 5.2.2.8 View previously visited sites

- ✓ Tap the **Arrow** button at the right side of Address Bar
- ✓ Select the **Web Address** you want to view.

#### 5.2.2.9 Add and view Favorites

- ✓ Go to the page you want add
- ✓ Select **Favorites > Add To Favorites**.
- ✓ If necessary, locate the folder you want.
- ✓ Confirm or change the name.
- ✓ To view your favorite Web sites, select **Favorites** and the Web site you want to view.

#### **Note:**

To organize your Favorites list, select **Favorites > Organize Favorites**.

#### 5.2.2.10 Browse Web pages

- ✓ To move to a page you have previously view, select **View > Back**
- ✓ To move to the next page (provided you have viewed it previously), Select **View > Forward**.
- ✓ To return to your Home page, select **View > Go > Home**.

#### 5.2.2.11 Refresh current page

- ✓ Select **View > Refresh**.

#### **5.2.2.12 Stop loading a page**

- ✓ Select **View > Stop**.

#### **5.2.2.13 View current page**

- ✓ Select **View > Internet Options**
- ✓ To view the protocol, page type, size, and address, selects the **General** tab.
- ✓ To view security information about the page, select the **Security** tab.

#### **5.2.2.14 View HTML source code**

- ✓ While viewing the page, select **File > Save As** and save the file as .txt file.
- ✓ Open the file in a word processing program, such as **WordPad**.

#### **5.2.2.15 Change home and search page settings**

- ✓ Open the page you want to use as your home or search page.
- ✓ Select **View > Go > Home** or **Search**.

#### **5.2.2.16 Save a copy of current page**

You can save Web pages and view them later when you're disconnected from the Internet or Intranet without using cached memory.

- ✓ Select **File > Save As**
- ✓ Specify a folder location and give the file name.

#### **5.2.2.17 Copy a Web page to a document**

- ✓ Select all or part of the Web page you want to copy.
- ✓ Select **Edit > Copy**.
- ✓ Go to the document where you want to place the information and select the location.
- ✓ Select **Edit > Paste**.

#### **5.2.2.18 Select security Options**

- ✓ Select **View > Internet Options > Security** tab
- ✓ Select the security protocols you want.

#### **5.2.2.19 Change the font size**

- ✓ Select **View > Text Size** and select the desired size.



### 5.2.3 Media Player

The PDT comes with Media Player for Windows CE.NET installed.

- ✓ Open Media Player by selecting **Start > Programs > Media Player** from the desktop.
- ✓ Select File > Open to open a new media file.
- ✓ Please refer to [www.microsoft.com](http://www.microsoft.com) for additional information and help with your Microsoft Windows Media Player.



Figure 5-3 Media Player

### 5.2.4 Messenger

The Windows CE Messenger client application in Windows CE.NET allows you to communicate real-time using text-based messaging, VOIP, and more.

- ✓ See who's online. See when your colleagues are online. You can also post your presence information to a list of watchers that you define.
- ✓ Talk instead of type Stop typing Talk with a colleague anywhere in the world using the microphone and speakers on your device. Windows Messenger supports high-quality voice calling r Windows CE device.
- ✓ Communicate using Session Initiation Protocol (SIP) or Hotmail contacts Windows Messenger supports. Communication with your colleagues in the enterprise with a SIP based communications service. You can also talk to your Hotmail contacts using the .NET Messenger.

### 5.2.5 Microsoft WordPad

You can create and edit documents and templates in WordPad, using buttons and menu commands that are similar to those used in the desktop version of Microsoft Word. You can work with files Normal or Outline view.

WordPad documents are usually saved as **.pwd** files, but you can also save documents in other file formats, such as **.rtf** or **.doc**.

### 5.2.5.1 Selecting and Editing Text

#### ✓ **Select text**

To select	Do this
Any amount of text	Drag the stylus over the text.
A word	Double-tap the word.
A single paragraph	Triple-tap within the paragraph.
An entire document	Select Edit > Select All
An picture	Tap the picture

#### ✓ **Find text**

- To search for text in one part of a document, select that part. Otherwise, the whole document is searched.
- Select Edit > Find
- Enter the text you want to find. For a paragraph, enter **^p**. For a tab stop, enter **^t**.
- Select the search options you want.
- To continue searching, select **Edit > Find > Next**.

#### ✓ **Replace text**

- To replace text in one part of document, select that part. Otherwise, the whole document is searched.
- Select **Edit > Replace**.
- Enter the text you want to find and the text you want to replace it with. For a paragraph, enter **^p**. For a tab stop, enter **^t**.
- Select the replacement options you want.
- Select **Find Next**.
- On the **Find/Replace** toolbar, select the appropriate button.

#### ✓ **Move, copy, or delete text**

- Select the text you want to move, copy, or delete.
- To move or delete text, select the **Cut** button. To copy the text, select the **Copy** button.
- To paste the information, move the insertion point to the desired location, and select the **Paste** button.

#### **Notes:**

- To undo an action, select **Edit > Undo**.
- To restore the action, select **Edit > Redo**.

### 5.2.5.2 Formatting Text

#### ✓ **Create bulleted and numbered lists**

- Select the **Bullets** or **Numbering** button.
- Type the first item.
- Press **ENTER**, type the next item, and repeat as needed.
- Select the button again to end list formatting.

**Note:** To change the number style for the selected list, select **Format > Paragraph**. In the **Format** list, select the style you want.

#### ✓ **Set the default font**

- Select **Format > Font**.
- Select the font you want.
- Select **Set As Default**
- To confirm that your changes will be applied to subsequent documents you create, select **Yes**.

**Note:** To apply the default font and stylus to selected text, select **Apply Default**.

#### ✓ **Select a different font**

- Select the text you want to change. To select all text, select **Edit > Select All**.
- From the **Font** list, select the font you want.
- From the **Font Size** list, select a size.

**Note:** To see more formatting options, select **Format > Font**.

#### ✓ **Change font formatting**

- Select desired text.
- Select the **Bold**, **Italic**, or **Underline** button.
- To change the color, select **Format > Font** and select the color you want from the **Color** list.

#### ✓ **Adjust the paragraph alignment**

- Select the paragraph you want to align.
- Select the **Align Left**, **Center**, or **Align Right** button.

**Note:** To see more formatting options, select **Format > Paragraph**.

#### ✓ **Indent a paragraph**

- Select the paragraph you want to indent.
- Select **Format > paragraph**.

- Adjust the indentation settings as needed.
- ✓ **Set tabs**
- Select **Format > Tabs**.
- Change the tab settings as needed.

### 5.2.5.3 Adjusting the Display

- ✓ **Wrap text in the window**
  - Select **View > Wrap to Window**.
  
  - ✓ **Display the document using the full screen**
  - Select **View > Full Screen**.
  - To exit Full Screen view, select **Restore**.
  - To move the **Restore** button, drag the bar on the left side.
  
  - ✓ **Display or hide scroll bars**
  - Select **View > Horizontal Scroll Bar** or **Vertical Scroll Bar**.
  
  - ✓ **Zoom in or out**
  - Select **View > Zoom**, and select the desired percentage.
- Note:** For **Custom**, enter the exact percentage and select **OK**.

### 5.2.5.4 Working in Outline View

- ✓ **Switch between Normal and Outline views**
- Select **View > Normal** or **Outline**.
  
- ✓ **Assign and change outline levels**
- Select **View > Outline**.
- Select the appropriate buttons on the toolbar.

### 5.2.5.5 Inserting Symbols

- ✓ Place the insertion point where you want to insert the symbol.
- ✓ Select **Tools > Insert Symbols**.
- ✓ Select the symbol you want, and then select **Insert**.

#### **Tips:**

If you select a different font ( or subset of a font), a different set of Symbols will be displayed.

### 5.2.5.6 Printing a Document

- ✓ Select **File > Print**.
- ✓ Select the printing options you want.

#### **Tips:**

- **Port** list the available printer ports
- If **Network** is selected from the **Port** list, enter the path to the network printer to the **Net Path** box.

### 5.2.5.7 Setting a password for a Document

- ✓ Select **File > password**.
- ✓ Type and verify the password.
- ✓ You must save the document (**File > Save**) to return the password.

### 5.2.5.8 Converting Documents

#### ✓ **About document conversion**

If an e-mail program is installed on your device and you receive an attached Word document or template created in Word version 6.0 or later, WordPad will convert the file on your device. To view the document, simply open the attachment in your e-mail program or open the file in the WordPad.

During conversion, some formatting attributes may be changed or lost. To avoid losing these attributes permanently, close the file after viewing it rather saving the file on your device. If you save the file, save with a different file name.

For more information about conversion performed on your device, see the following topics.

#### ✓ **Changes caused by Word document conversion**

##### ➤ **Formatting**

- **Borders and Shading**

Borders and shading are not displayed in WordPad, but are restored when converted back to a Word document. Shading is not restored when used in a table, but simple borders are restored.

- **Character formatting**

Bold, italic, strikethrough, superscript, subscript, and hidden text are retained and displayed. Other effects are changed or removed.

- **Colors**

Colors are retained and mapped to colors available on your device.

- **Fonts and font sizes**  
Fonts not supported by your mobile device are mapped to the closest font available in WordPad.
- **Page Formatting**  
Headers, footers, footnotes, columns, pages setup information, and style sheets are removed during conversion to WordPad. WordPad supports built-in headings.
- **Paragraph formatting**  
Tabs, alignment, bullets, indentation, simple numbered lists, and paragraph spacing are retained and displayed in WordPad.
  
- **Pictures**  
Pictures are removed during conversion.
  
- **Table of Contents**  
Table of Contents text and some formatting are preserved. However, any text set at right-aligned tab stops may wrap to the next line.
  
- **Index**  
Index text and some formatting are preserved.
  
- **Tables**  
Tables appear as tab-delimited text. Cells containing wrapped text, tabs, or paragraph markers may be difficult to read. Simple tables are displayed accurately and restored when you convert the WordPad file back to a WordPad document.
  
- **OLE Objects**  
OLE Objects are removed during conversion.
  
- **Revisions marks, annotations, and comments**  
Revision marks are visible but cannot be changed. Annotations and documents are removed during conversion.

## 5.2.6 Remote Connection

Using Remote Desktop Connection, you can log on to Windows Terminal Server and use all programs installed on this server. For example, instead of running Microsoft Pocket Word, you can run the desktop version of Microsoft Word.

### 5.2.6.1 Connecting to Terminal Server

- ✓ Select **Start > Programs > Remote Connection**, or run 'CETSC' from the command prompt.
- ✓ In the Server box, type or select a Terminal Server name or TCP/IP address, or select a server in the drop-down list.
- ✓ Select **Connect**.
- ✓ In the **Remote Connection** window, type your user name, password, and domain(if required), and then select **OK**.




Figure 5-4 Remote Connected

### 5.2.6.2 Disconnecting Without Ending a Session

- ✓ In the **Remote Connection** window, select **Start > Shutdown**.
- ✓ Select **Disconnect > OK**.

**Note:** If you previously disconnected from a Terminal Server without ending the session, the Terminal Server will continue to execute any running processes and Remote Connection can later reconnect to this same session(if your administrator has configured Remote Connection to reconnect to disconnected sessions).

### 5.2.6.3 Disconnecting and Ending a Session

- ✓ In the **Remote Connection** window, select **Start > Shutdown**.
- ✓ Select **Log Off > OK**.

## 5.2.7 Windows Explorer

Windows Explorer works almost the same on your PDT as it does on your PC. See the topics below for information about the difference in Windows Explorer on your device.




Figure 5-5 Windows Explorer

### 5.2.7.1 Navigating in File View

#### ✓ Go forwards and Back

- To go to the previous folder, select **Go > Back**.
- To go to the next folder (which you have just viewed), select **Go > Forward**.

#### ✓ Use the Go menu

- To quickly access the My Documents folder, select **Go > My Documents**
- To see all of the folders you have accessed, select **Go > History**. Double-tap a folder to return to it.

### 5.2.7.2 Viewing Files as Icons Lists

- ✓ To view icons, select **View > Large Icons** or **Small Icons**.
- ✓ To view a list, select **View > Details**.

### 5.2.7.3 Working with Files and Folders

#### ✓ Create a new folder

- If necessary, open the folder where you want the new folder to reside.
- Select **File > New Folder**.

#### ✓ Add a folder to your Favorites list

- Open the folder
- Select **Favorites > Add to Favorites**.
- In the **Name** box, type the shortcut name.

#### Tips:

- To open a favorite file or folder, select **Favorites** and then select the folder.
- To organize your favorites, select **Favorites > Organize Favorites**.
- ✓ **Transfer a file using infrared**
  - To send a file, select it, line up the infrared ports, and select **File > Send To**



**> Infrared Recipient.**

- To receive a file, line up the infrared ports, and select **File > Receive**.

**5.2.7.4. Creating Desktop Shortcuts**

- ✓ Display the file or Web page for which you want to create a Shortcut.
- ✓ Select **File > Send to**.
- ✓ Select **Desktop as Shortcut**.

**5.2.7.5 Switch to Internet**

- ✓ Type a URL in the Address bar.

## 5.3 DiskOnChip

The DiskOnChip let the application or a data file can be stored into the Flash Memory.

**Note: The DiskOnChip storage memory persists all reset (warm/cold reboot) conditions and software/firmware updates.**

**We strongly recommends installing all applications, applets, programs, and important data files to the DiskOnChip Flash location.**

### **Caution:**

**If an application or a data file is only installed or saved in RAM, a hard reset will result in the loss of that application or data file.**

### 5.3.1 Saving to Flash

To save an application or data to the Flash Memory, from your current application, select **File > Save As >** navigate to the **DiskOnChip** location and save it.

### 5.3.2 DiskOnChip Location

To access the contents of DiskOnChip storage:

- ✓ Double-tap the **My Computer** icon on the desktop.
- ✓ Double-tap the **DiskOnChip** icon to view **DiskOnChip**.



Figure 5-6 **DiskOnChip**

### 5.3.3 DiskOnChip Size

The size of the DiskOnChip will vary, depending on the size of system firmware.

- ✓ Inside the **DiskOnChip** directory, tap **File > Properties**.
- ✓ The **DiskOnChip Properties** dialog:

The number following **Free** is the amount of memory currently available on your device.




Figure 5-7 DiskOnChip Size