

Interface Manual Flow Totalizer

SignalFire Model: SFTotalizer-1BIS



The SignalFire Flow Totalizer is an Intrinsically Safe (pending) device with the following features:

- Frequency range 1Hz – 4kHz (low gain), 1Hz – 2kHz (high gain)
- Input Sensitivity of 20mV or 5mV peak-to-peak (jumper selectable)
- Provides grand total, yesterday's total, and today's total to individual Modbus registers
- Real time clock for daily contract hour setting
- Configurable K factor
- Flow rate reporting
- Display showing flow rates and flow totals
- Low power operation from an Intrinsically Safe (pending) high capacity lithium primary battery pack
- Sends data to a SignalFire Buffered Modbus Gateway
- On-board logging of 30 days of flow totals

Specifications

Overall Size	9.8" tall × 4.4" wide × 3.6" deep
Power Source	Internal IS lithium battery pack <i>SignalFire Part Number: 810-0030-01 (1BIS)</i>
Temperature Rating	-40°C to +60°C / -40°F to +140°F
Radio Frequency	902-928MHz Ism Band, FHSS radio
FCC ID	W8V-FT
IC ID	8373A-FT
Compliance	Certified for use in Class I, Division 1 groups C and D. EXia. FCC/IC Certified. (Pending)
Turbine Input	Sensitivity: 5mV peak-to-peak (high gain), 20mV peak-to-peak (low gain) Input Frequency: 1Hz to 2kHz (high gain), 1Hz-4kHz (low gain) 1" NPT swivel union connector. Includes standard 2-pin pickup connector

Battery Life

The table below gives battery life estimates assuming a new battery and good radio link.

Check in Interval	LCD Off	LCD Always on
5 Seconds	1.25 Years	1.0 Years
15 Seconds	3.0 Years	2.25 Years
1 Minute	5.5 Years	4.0 Years
2 Minutes	6.75 Years	4.5 Years
5 Minutes	7.5 Years	5.0 Years
10 Minutes	8.5 Years	5.25 Years
30 Minutes	9.0 Years	5.5 Years
60 Minutes	9.5 Years	5.75 Years



WARNING: Use of this equipment in a manner not specified by the manufacturer may impair the protection provided by the equipment.

3

AVERTISSEMENT: L'utilisation et l'implémentation de cet équipement d'une manière non spécifiée par le fabricant peut affecter son intégrité ainsi que sa protection




WARNING: The use of any parts not supplied by the manufacturer violates the safety rating of the equipment.

AVERTISSEMENT: L'utilisation de composants ne provenant pas du fabricant compromet la sécurité et la certification du produit.

*The associated apparatus provides Intrinsically Safe (pending) outputs.
L'appareil associé fournit des sorties à sécurité intrinsèque (en attente).*

Refer to control drawing 960-0087-01 for requirements when used in a Class I Division 1 area.



Radio LEDs

- The Radio TX LED (green) flashes each time a radio packet is sent. This LED will blink rapidly while searching for the radio network.
- The Radio RX LED (red) blinks on each received radio packet.

Status LEDs

- The STATUS LED (green) Currently not implemented – for future use.
- The ERROR LED (red) will blink to indicate an error condition.

Checkin Button

- If this button is pressed the Flow Totalizer will perform a check-in and send the current readings to the gateway.

Setup

The nodes need to be set up for correct operation before being fielded. The configurable items include:

- Network selection
- Check-in period selection
- Modbus Slave ID setting

All settings are made using the SignalFire Toolkit PC application and a serial programming cable.




WARNING: Perform the steps in this section (Setup) in a safe location only.

AVERTISSEMENT: Les étapes de démarrage (setup) doivent être fait dans une zone sécuritaire.

Using the SignalFire Toolkit

The SignalFire Toolkit application can be downloaded at www.signal-fire.com/customer. After installation, launch the software and the main toolkit window will open:



Select the COM port associated with the Flow Totalizer Node and click "Auto-Detect Device on COM Port." This will open the device configuration window, where all device settings can be configured.



- | | |
|--------------------------|------------------------------|
| 1 Serial Port Settings | 2 Flow Totalizer Information |
| 3 Network Settings | 4 Status of Last Operation |
| 5 Reported Sensor Values | 6 Units Settings |
| 7 Battery Life Estimate | 8 Parameters Settings |
| 9 Clock Settings | 10 Encryption Settings |

Network Setting

The network address can be used to create separate networks using multiple gateways (that are in close proximity with one another). The network is set using the SignalFire Toolkit. The Network Group setting is used when more than 8 networks are needed. Both the network and network group must match those of other nodes for nodes to communicate.

Radio Network	1	Set
Radio Network Group	0	Set

Encryption

It is possible to encrypt over-the-air transmissions to prevent tampering. Encryption keys replace the Corporate ID system, so it is important that all devices connected to a Gateway have the same encryption key as well as network and network group number.

To set up a Flow Totalizer to use encryption, click the checkbox labeled **Enable Encryption** inside the **Set Corporate ID** box:

The encryption key box. For more details, click the Help button.

The box will then change into a **Set Encryption Key** box, and it will prompt instead for the encryption key you would like to use. Note that keys may not contain spaces or angle brackets. Enter it and then press **Set**. If you are setting up a new network, you will need to set the encryption key on all of your devices. If you are adding a Flow Totalizer to a legacy network, you can simply set the Corporate ID without clicking the Enable Encryption box, and it will remain compatible with the older system.

Setting the encryption key.

It is also possible to hide your encryption key so it cannot be read. This is the most secure option, but if you forget your key, there is no way to recover it – you have to reset the key on every device on its network. To enable this option, select **Set Encryption Key Unrecoverable** under the **Settings** menu.

Setting the encryption key unrecoverable.

System Check-In Period

This setting controls how often the node will read the Modbus device and forward the register data to the gateway.

Checkin Interval

Modbus Slave ID

The Modbus Slave ID must be set with the SignalFire Toolkit. Each remote device connected to a SignalFire Gateway must have a unique Modbus Slave ID.

Turbine Meter Connection

The Flow Totalizer is supplied with a 1" NPT Union to allow it to be directly mounted to a standard turbine flowmeter. The nut on the union can be loosened to allow the totalizer to be rotated to the desired orientation. Also supplied is a 2-pin connector for connection to the turbine flow meter magnetic pickup. Teflon tape should be used on the NPT connections.

Pickup Sensitivity Selection

For most turbine flow meters, the gain selection jumper should remain in its default "LOW GAIN" position. This provides a sensitivity of 20mV p-p. If a high sensitivity is needed the jumper can be moved to the "HIGH GAIN" position which increases the sensitivity to 5mV p-p.

Flow Settings / Configuration

Clock Setting

The battery backed up real-time clock must be set. To set the clock to match the PC's clock, simply click "Set to PC". Alternatively, the time/date can be manually entered.

Volume Units

The Volume units set the units that the accumulated volumes and flow rate will be presented in. Volume units available are:

- Gallons
- Barrels
- Liters
- Cubic Meters

Timebase Units

The Timebase units configure the units used for the flow rates. For example, if the volume units are set to 'gallons', and the timebase units are set to 'minute', the flow rates will be reported as gallons/minute. Timebase units available are:

- Seconds
- Minutes
- Hours
- Days

K-Factor Units / K-Factor

The K-factor units set the units that the flow meter uses for its k-factor. For example, if the turbine flow meter has a stated k-factor of 50,000 pulses/gallon, select 'gallons' for the K-Factor units, and enter 50000 for the k-factor.

Contact Hour

The contract hour setting controls when the volume accumulated for today, rolls over to yesterday's volume. The contract hour is set in hh:mm in the 24-hour format. For example, 2:30pm would be entered as 14:30.

30 Day Logging

The Flow Totalizer also keeps an on-board log of the last 30 days of flow totals. This log can be accessed using the SignalFire ToolKit. From the Tools Menu, select 'Daily Log'. On the daily log window click 'Refresh' to read the log file. The log can be saved as a .csv file.

Flow Rate Reporting

The Flow totalizer reports two flow rates, average flow rate, and instantaneous flow rate. The average flow rate is the flow rate over the configured check-in period. For example, if the check-in period is configured as 2-minutes, each check-in will contain the average flow rate over the 2-minutes.

The Instantaneous flow rate is calculated every 2-seconds. At check-in the most recent instantaneous calculated flow rate will be reported.

Local Display

The Flow Totalizer has a local LCD display (with back-light) that allows for easy viewing of the flow totals and flow rates. The display is powered on only when the button under the display is pressed. Pressing the button when the display is on, cycles through the various information screens. The display and backlight will automatically turn itself off after 30 seconds.

10

LCD Always on

The default operation of the LCD is for it to time out and turn off after 30 seconds. It will come back on when the front button is pressed. If it is desired that the LCD remain on always, this can be selected from the 'Settings' menu. Leaving the LCD always on will impact the system battery life, see the table on page 2 for details. Note that the LCD backlight will still turn off after 30 seconds.

Remote Modbus Register Mapping

11

The Flow Totalizer sends data to a SignalFire Telemetry Modbus Gateway. The data that is sent to the gateway is available at the gateway in registers where it can then be read by a Modbus RTU. Consequently, the node needs to have a unique (to the network it is in) Modbus slave ID which the gateway will use to store its unique data.

Modbus Registers

Every check-in period, the sensors are read and data is sent to the gateway. The gateway will save the data under the set Modbus ID in 16-bit registers. The register map for this system is below.

Register Map

Register Number	Register Address	Description	Data Type
41101	1100	Volume Units (2 = gallons; 3 = barrels)	Int
41102	1101	K-Factor Units (2 = gallons; 3 = barrels)	Int
41103	1102	Time Base Units(3=day, 2=hour, 1=min, 0=second)	Int
41104	1103	Flow Total (High Word)	Float
41105	1104	Flow Total (Low Word)	Float
41106	1105	Yesterday's Flow Total (High Word)	Float
41107	1106	Yesterday's Day Flow Total (Low Word)	Float
41108	1107	Current Day Flow Total (High Word)	Float
41109	1108	Current Day Flow Total (Low Word)	Float
41110	1109	Avg Flow Rate (High Word)	Float
41111	1110	Avg Flow Rate (Low Word)	Float
41112	1111	Instantaneous Flow Rate (High Word)	Float
41113	1112	Instantaneous Flow Rate (Low Word)	Float
41114	1113	Gear Meter K Factor (High Word)	Float
41115	1114	Gear Meter K Factor (Low Word)	Float
49988	9987 or 65524	Major revision number for the mainboard	Int
49989	9988 or 65525	Minor revision number for the mainboard	Int
49990	9989 or 65526	Major revision number for the radio	Int
49991	9990 or 65527	Minor revision number for the radio	Int
49995	9991 or 65528	Received signal strength of last packet from the slave	Signed Int
49996	9992 or 65529	Battery voltage, in millivolts	Int
49997	9993 or 65530	Minutes until this slave will time out, unless new data is received	Int
49998	9994 or 65531	Number of registers cached for this slave device	Int
49999	9995 or 65532	Remote device type. 60 for Flow Totalizer	Int

Internal Lithium Battery Replacement

Battery Packs can be changed with the node in place.

- 1 Open the cover.
- 2 Slide the power switch to the off position
- 3 Unplug the battery from the PCB, by depressing the locking clip on the connector.
- 4 Remove the battery from the clip and replace with new battery.
- 5 Connect the battery to the main PCB battery connector.
- 6 Slide the power switch to the on position.
- 7 Close and snap shut the enclosure cover.



WARNING: Use of any battery other than the SignalFire part number 810-0030-01 (1BIS) will impair the protection provided by the equipment.

AVERTISSEMENT: La sécurité intrinsèque et la protection du produit seront compromis par l'utilisation de batteries autres que celle fournie par SignalFire ayant comme numéro de pièce 810-0030-01(1BIS).

Coin Cell Battery Replacement

The coin cell is used to backup the real time clock in the event that the main battery pack is unplugged. The battery is a CR2032 coin cell battery



WARNING: Use of any battery other than a Panasonic CR2032 coin cell battery will impair the protection provided by the equipment.

AVERTISSEMENT: La sécurité intrinsèque et la protection du produit seront compromis par l'utilisation de batteries autres que celle fournie par SignalFire ayant comme numéro de pièce Panasonic CR2032.

The outside of the enclosure may be cleaned with water, mild soap, and a damp cloth as needed. High pressure washing is not recommended.



WARNING: Electrostatic Discharge Hazard! Care must be taken to avoid the potential of creating a charge on the enclosure or antenna. Do not wipe with a dry cloth. Do not brush against the enclosure with clothing or gloves.

AVERTISSEMENT: Danger de décharges électrostatiques! Utilisez les précautions nécessaires pour éviter l'accumulation d'électricité statique sur l'antenne. Ne pas nettoyer l'antenne avec un linge sec. Ne pas frotter le boîtier avec des vêtements ou des gants.



WARNING: Only connect to the debug port in a safe area! Ensure that the maximum voltage applied to the configuration port is less than 5 VDC!

AVERTISSEMENT: Branchez le port de débogage que dans une zone secure.

Assurez-vous que la tension électrique sur le port de configuration soit moins de 5 volt DC.

Debug and configuration information is available if a connection is made via the debug port on the main board. A USB converter cable (available from SignalFire) must be used for this interface.

Debug and configuration is done using the SignalFire Toolkit PC application.

Technical Support and Contact Information

SignalFire Telemetry
43 Broad St C-300
Hudson, MA 01752
(978) 212-2868
support@signal-fire.com

Revision History

Revision	Date	Changes/Updates
1.0	6/26/17	Initial release
2.0	7/11/17	Added units info, updated ToolKit screenshot
2.1	7/17/17	Minor edits
2.2	8/8/17	Added battery life table, added detail on LCD always on setting
2.3	8/15/17	Updated warnings
2.4	8/28/17	Added FCC/IC details

Changes or modifications not expressly approved by SignalFire Telemetry, Inc could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device has been designed to operate with the antenna listed below, and having a maximum gain of 5.8 dBi. Antennas not included in this list or having a gain greater than 5.8 dBi are strictly prohibited for use with this device. The required antenna impedance is 50 ohms.

San Jose Technology Inc. Model EEH-915

To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that permitted for successful communication.

To comply with FCC's and IC's RF radiation exposure requirements, the antenna(s) used for this transmitter must be installed such that a minimum separation distance of 20cm is maintained between the radiator (antenna) & user's/nearby person's body at all times and must not be co-located or operating in conjunction with any other antenna or transmitter.

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:(1) This device may not cause interference; and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.