



SIMPLESHARE USER'S GUIDE



Copyright

©2005 by SimpleTech™, Inc. All rights reserved.

This guide is copyrighted by SimpleTech™ with all rights reserved. Information contained in this document, including but not limited to any instructions, descriptions and product specifications, is company private to SimpleTech and shall not be modified, used, copied, reproduced or disclosed in whole or in part, in any form or by any means, electronic or mechanical, for any purpose, without the written consent of SimpleTech.

Export Administration Regulation

This document may contain technical data controlled by the U.S. Export Administration Regulations, and may be subject to the approval of the U.S. Department of Commerce prior to export. Any export, directly or indirectly, in contravention of the U.S. Export Administration Regulation is prohibited.

Trademark Information

SimpleTech, DirectPath and SimpleTech are trademarks of SimpleTech, Inc. No right, license, or interest to such trademarks is granted hereunder, and you agree that no such right, license, or interest shall be asserted by you with respect to such trademark.

Other product and corporate names mentioned in this document are used for identification purposes only and may be trademarks or registered trademarks of their respective companies.

Disclaimer of Liability

Information contained in this document, including but not limited to any instructions, descriptions and product specifications, is subject to change without prior notice.

SIMPLETECH, INC. PROVIDES NO WARRANTY WITH REGARD TO THIS GUIDE OR ANY OTHER INFORMATION CONTAINED HEREIN AND HEREBY EXPRESSLY DISCLAIM ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE WITH REGARD TO ANY OF THE FOREGOING. SIMPLETECH ASSUMES NO LIABILITY FOR ANY DAMAGES INCURRED DIRECTLY OF INDIRECTLY FROM ANY TECHNICAL OR TYPOGRAPHICAL ERRORS OR OMISSIONS CONTAINED HEREIN. IN NO EVENT SHALL SIMPLETECH BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, SPECIAL, OR EXEMPLARY DAMAGES, WHETHER BASED ON TORT, CONTRACT OR OTHERWISE, ARISING OUT OF OR IN CONNECTION WITH THIS GUIDE OR ANY OTHER INFORMATION CONTAINED HEREIN OR THE USE THEREOF.

Contents herein are current as of the date of publication. No patent liability is assumed with respect to the use of the information contained herein.

This disclaimer of liability applies to all products, publications and services during and after the warranty period. Some states do not allow the excluding of incidental or consequential damages so the above limitation or exclusion may not apply to you.

GETTING STARTED

Congratulations on purchasing your new high performance SimpleShare Office Storage Server.

SimpleShare makes it possible for you to easily add high performance storage to your home or small business network. SimpleShare is ideal for sharing data files, digital photos, and music with other users on your local network. In addition, with SimpleShare, everyone on the network has instant access to extra storage.

UNPACK AND INSPECT YOUR SHIPMENT

Upon receipt of the equipment:

- Unpack and inspect the contents for signs of damage. If the equipment has been damaged in transit, immediately report the extent of damage to the transportation company and to SimpleTech. Order replacement equipment, if necessary.
- Check the packing list to ensure complete and accurate shipment of each listed item. If the shipment is short or irregular, contact SimpleTech, as described in “[Product Support](#)” on page 104. If you must store the equipment for a prolonged period, store it in its original packaging.

WHAT'S INCLUDED WITH SIMPLESHARE

The following items are included in the SimpleShare package. If any items are missing or damaged, please contact your SimpleShare reseller or retailer for replacements.

- SimpleShare Office Storage Server
- 12 Volt DC Power Adapter
- Vertical Stands (2)
- CAT5e Ethernet Cable
- NASFinder Quick Setup CD
- SimpleShare Quick Installation Guide (printed)
- SimpleShare User's Guide (on NASFinder Quick Setup CD)
- NASFinder User's Guide (on NASFinder Quick Setup CD)
- Warranty Card

FEATURES AND BENEFITS

- Easy setup—no device drivers or configuration required (no network experience required)
- Web-based interface for setting up advanced features from networked computers
- Automatically adjusts to 10Mbps or 100Mbps Ethernet speeds
- Supports file sharing between Windows, Mac and Unix/Linux computers
- Built-in print server allows addition of a network printer
- Windows Domain and Workgroup configuration options
- Supports access to shared folders by group or individual users
- Expandable storage
- Acts as a stand alone DHCP server for your network
- RTC to keep the time during power off. Auto-sync with the Internet time server during bootup
- SMART for monitoring disk drive health

REGISTERING SIMPLESHARE

To register your SimpleShare, just complete and mail the registration card or go online and register your SimpleShare at <http://www.simpletech.com/webspeed/registration>.

SIMPLESHARE INSTALLATION CD

The SimpleShare Installation CD contains the NASFinder configuration utility and user documentation for your SimpleShare Office Storage Server. The CD is configured to automatically run NasFinder when it is inserted into your CD-ROM drive. However, you can directly access the directories and files on the installation CD.

- **SimpleShare Administrator** - Provides a platform-independent, HTML-based tool for configuring and managing your SimpleShare Office Storage Server accelerator.
- **Documentation** - Contains the Readme and PDF files. See “[SimpleShare Documentation](#)” for details.

SIMPLESHARE DOCUMENTATION

- **SimpleShare Quick Installation Guide** - The guide provides general instructions on installing and setting up your SimpleShare Office Storage Server.
- **SimpleShare User’s Guide** - Describes your SimpleShare Office Storage Server, along with instructions on how to use SimpleShare Administrator to configure and manage the server. This guide also contains product support and warranty information, and product specifications.
- **SimpleShare Online Help** - Provides detailed online instructions on configuring and managing SimpleShare.
- **NASFinder Online Help** - Provides instructions and tips on using NASFinder to locate a SimpleShare server on your network and performing basic setup tasks.

ABOUT THIS GUIDE

This user guide provides instructions for setting up and operating the SimpleTech DirectPath SimpleShare Office Storage ServerH Streaming Media Kit in the HP ProLiant DL380 G3 server. This guide also provides information on evaluating SimpleShare Office Storage Server performance.

Using This Guide

The following conventions are used in this manual:

- `Carrier` type indicates screen text.
- Buttons and keys you press are indicated by small icons—such as  or .
- Items you select are in **bold**.

Safety Icons

This guide contains the safety instructions that must be observed in order to avoid personal injury or damage to your equipment. The safety instructions have been classified according to the seriousness of the risk. All safety instructions must be read carefully and fully understood before installing the SimpleShare Office Storage Server or performing maintenance on your computer equipment. The following icons highlight these instructions as follows:



WARNING: This icon indicates the existence of a hazard that could result in serious bodily injury or death if the safety instruction is not observed.



CAUTION: This icon indicates the existence of a hazard that could result in equipment or property damage or equipment failure if the safety instruction is not observed.



NOTE: This icon identifies information that relates to the safe operation of the equipment of related items.



ESD: This icon indicates that a device or assembly is susceptible to damage from electrostatic discharge.



TIP: This icon identifies helpful hints and tips.

EMISSION AND IMMUNITY CHARACTERISTICS

FCC Declaration of Conformity

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the users manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

EU Declaration of Conformity

The SimpleShare Office Storage Server carries the CE-Mark in accordance with the related European Directives and standards.



This is a Class A product. In a domestic environment, this product may cause radio interference in which case the user may be required to take adequate measures.

TABLE OF CONTENTS

Getting Started iv

What's Included With SimpleShare v

Features and Benefits vi

Registering SimpleShare vi

Installing SimpleShare 1

System Requirements and Recommendations 1

Requirements 1

Recommendations 1

Installing SimpleShare Server 2

Setting Up SimpleShare for the First Time 3

Expanding SimpleShare's Capabilities 10

Connecting a USB Printer 10

Connecting a USB Drive 11

Accessing Shares 12

Accessing SimpleShare From Windows 13

Accessing SimpleShare From Mac OS X 16

Managing SimpleShare 18

- Running SimpleShare Administrator 19
- Setting the SimpleShare Network Name 20
- Setting the Administration Username and Password 21
- Setting the Date and Time Manually 22
- Acquiring the Date and Time From Your Browser 24
- Synchronizing the Date and Time with an NTP Server 25
- Upgrading SimpleShare Firmware 27
- Setting Up Email Alert Notification 28
- Setting Up Popup Alert Notification 29
- Adding SimpleShare to an Existing Workgroup 30
- Adding SimpleShare to an Existing Domain 31
- Restoring Factory Setting 32
- Restarting SimpleShare 33
- Setting File System Support on SimpleShare 34
- Creating a Share 35
- Deleting a Share 37
- Renaming a Share 38
- Enabling Security on an Existing Share 39
- Disabling Security on an Existing Share 40
- Renaming a Disk Drive 42

Erasing a Disk Pool	43
Erasing a Disk Drive	44
Enabling Disk Power Management	46
Viewing Disk Drive Health Information	47
Running Disk Drive Self-Tests	49
Removing External Drives	51
Viewing Foreign Disk Information	53
Claiming Foreign Disk for SimpleShare	54
Claiming a Foreign Disk as FAT32	56
Claiming a Blank Disk for SimpleShare	58
Claiming a Blank Disk as FAT32	60
Checking Foreign Disk File System Integrity	62
Creating a Basic Pool	64
Creating a Mirror Pool	67
Creating a Striped Pool	71
Deleting (Wiping) a Pool	75
Renaming a Pool	77
Resizing a Pool	78
Adding a Mirror to an Existing Pool	80
Removing a Mirror or Spare	83
Creating an Encrypted Pool	85

- Changing the Encryption Password 88
- Disabling Pool Encryption 90
- Mounting Encrypted Pools 92
- DHCP Client Network Setup 94
- DHCP Server Network Setup 95
- Static IP Network Setup 97
- Enabling the Print Server 98
- Disabling the Print Server 100
- Installing Printer Drivers on Windows Computers 101

Specifications 103

Product Support 104

- SimpleTech Technical Support 104
- Worldwide Headquarters 104

Certification and Warranty 105

- FCC Compliance 105
- Limited Warranty 106
- Modifications 106
- GPL Statement 106

INSTALLING SIMPLESHARE

Installing SimpleShare is easy. This guide assumes the user has a basic understanding of Personal Computers and networks.

SYSTEM REQUIREMENTS AND RECOMMENDATIONS

REQUIREMENTS

- Windows XP (Home and Professional), Windows 2000 (Professional and Server, Windows 2000 (Professional and Server), Windows Me and 98SE
- Intel Pentium III processor (or later)
- 256 MB RAM
- Web browser (Internet Explorer 5.0 or above, Safari, Linux Nautilus and Netscape 6.2.x or above)
- Available network connection (10Base-T or 100Base-T)

RECOMMENDATIONS

- DHCP server
- Network router or switch



A DHCP server is not required. However, SimpleTech strongly recommends using a DHCP server to assign IP addresses to the devices on your network. Otherwise, depending on how your network is configured, you may have to manually setup the computers on your network to talk to SimpleShare. For detailed information on using a DHCP server, see [DHCP Server Network Setup](#).

INSTALLING SIMPLESHARE SERVER

- 1 Connect the provided Ethernet cable to the Network connector on SimpleShare's rear panel. Connect the other end of the cable to your switch, router or directly to your computer.
- 2 Connect the low voltage connector on the AC power adapter to SimpleShare's DC-IN jack. Connect the power plug on the other end of the adapter to a live 120/240V electrical outlet, surge protector or UPS (uninterruptable power supply).




Only use the AC power adapter that came with SimpleShare. Using any power adapter, other than the one provided by SimpleTech, may damage SimpleShare and voids your warranty. SimpleTech assumes no liability for damage resulting from improper use.

- 3 Momentarily press the **Power** push button to power on SimpleShare.




The only way to shut off power completely to SimpleShare is to disconnect the power plugs from the power source. Make sure the power cords for SimpleShare are within easy reach so that you can unplug SimpleShare when you need to do so.



SETTING UP SIMPLESHARE FOR THE FIRST TIME

Once the SimpleShare server is connected and powered on, you can begin using it to share files and data with other network users immediately. However, if SimpleShare is installed on a complex network configuration that routes traffic to various network segments (subnets) using gateways and routers, locating SimpleShare using its network name might be difficult without assistance. In such cases, you can use NASFinder to locate your SimpleShare and perform basic configuration tasks like renaming your SimpleShare, changing its administration username and password and mapping the shared folders on SimpleShare to your computer.

- 1 Insert the NASFinder Quick Setup CD in the CD-ROM drive on your computer. Depending on how your computer is configured, NASFinder may launch automatically. If NASFinder does not start automatically, start it manually by clicking on the **Start** menu, and then selecting the **Run...** option. In the Run dialog box, enter `x: nasfinder.exe` (where x is the drive letter of the CD-ROM drive), and then click **OK**.



- On the Welcome to NASFinder page, click **Next** to start the SimpleShare Discovery and search your network for connected SimpleShare servers.



SimpleShare Discovery displays the network name, IP address and connection status of detected SimpleShare servers.



“Available” This icon indicates NASFinder has detected and is able to communicate with SimpleShare from your computer.



“Unavailable” This icon indicates NASFinder has detected, but cannot communicate with SimpleShare from your computer. Typically, this occurs when SimpleShare and the computer accessing SimpleShare are configured on different network segments or subnets.

If SimpleShare is unable to talk to your computer, review the NASFinder online help topic on SimpleShare Discovery before continuing this procedure.

- 3 If there are multiple SimpleShare servers installed on your network, choose the one you want to configure and then click **Next** to continue.



- 4 In the login prompt, enter SimpleShare's administration username and password. If you are configuring SimpleShare for the first time, enter the factory default username **admin** and password **simple**. If you want the system to remember your password, select **Remember my password**, then click **OK** to continue.

You are now ready to complete SimpleShare basic setup. In the future, you will be able to access SimpleShare by typing `http://simpleshare_name` in the address box of your Web browser (where `simpleshare_name` is the network name of your SimpleShare server).



The Server Name Setup page allows you to change SimpleShare's network name.

- 5 In **Machine Name**, enter a new name for SimpleShare or choose to keep the current name.



Choose a name that is easy to remember. For example, you can use the owner's last name, a description of the data SimpleShare will store, or where SimpleShare will be located. If there's only one SimpleShare on your network, you can use its default name, "SimpleShare."

The SimpleShare name can be up to 15 characters in length, containing any combination of alphanumeric (A-Z and 1-9) characters. You may also use the dash (-) character. Spaces and special characters are not allowed. If you share SimpleShare with MS-DOS computers, do not use more than eight characters in the SimpleShare name.

- 6 Click **Next** to continue.



The screenshot shows the 'Server Name Setup' window in the NASFnder application. The window title is 'NASFnder' and it has 'Help' and 'Exit' buttons in the top right corner. The SimpleTech logo is in the top left, and the SimpleShare logo is in the top right. The main heading is 'Server Name Setup'. Below this, there is a paragraph of instructions: 'The Server Name Setup page allows you to change the name that identifies SimpleShare on the network. Choose a name that is easy to remember. For example, you can use your last name, a description of the data SimpleShare will store, or where SimpleShare will be located. If there's only one SimpleShare on your network, you can use its default name, "SimpleShare."'. Below the text is another paragraph: 'When you are satisfied with the SimpleShare name you have chosen, click Next to apply the setting and continue to the next page.' There is a text input field labeled 'Machine Name' containing the text 'SimpleShare'. Below the input field are two buttons: 'Previous' and 'Next'. At the bottom right of the window, there is a copyright notice: '© Copyright 2004 SimpleTech, Inc. All rights reserved.'

The Administration Security Setup page allows you to change the administration username and password required to access SimpleShare configuration data.

- 7 Enter a new username and password for accessing SimpleShare. If you are logging onto SimpleShare for the first time, enter the default username “admin” and password “simple.” In **Confirm Password**, re-enter the new password to verify that it was entered correctly.
- 8 Click **Next** to continue.



Share Management makes it easy to access your shared folders in Windows. Share Management assigns a drive letter to SimpleShare folders, allowing them to be accessed from My Computer.

- 9 Choose a drive letter from the **Map to Local Drive** list next to the share you want to map. For each share you don't want mapped to your computer, choose **None**.



The Map to Local Drive list only displays letters available on your computer.

- 10 Click **Next** after making your selection(s).

- 11 On the Setup Complete page, click **Done** to exit NASFinder. If you need to perform more advanced configuration tasks, such as creating additional shares, click **Advanced Setup** to run SimpleShare Administrator.



EXPANDING SIMPLESHARE'S CAPABILITIES

CONNECTING A USB PRINTER

- 1 Connect one end of a USB cable to the USB port on the printer. Connect the other end of the cable to one of the USB ports on SimpleShare.
- 2 Connect AC power and power on the printer according to the instructions provided by the manufacturer.
- 3 In the **Administration** menu, click **Basic**.
- 4 Click **Reboot** to restart SimpleShare and apply your changes.
- 5 In the confirmation dialog, click **OK**.
- 6 Run SimpleShare Administrator to setup print server services on SimpleShare. See "Enabling the Print Server" on page 98.

If you are setting up SimpleShare for the first time, complete the basic setup before running SimpleShare Administrator.

CONNECTING A USB DRIVE

- 1 Connect one end of a USB cable to the USB port on the disk drive. Connect the other end of the cable to one of the USB ports on SimpleShare.
- 2 Connect AC power and power on the disk drive according to the instructions provided by the manufacturer.
- 3 Run SimpleShare Administrator to setup the new disk on SimpleShare. If you are setting up SimpleShare for the first time, complete the basic setup before running SimpleShare Administrator.

ACCESSING SHARES

You can access the shares (shared folders) on SimpleShare from the Web browser on a Windows, Macintosh, Linux or Unix computer. This section contains detailed instructions for accessing SimpleShare data Windows and Macintosh computers. If you are operating in a Linux or Unix environment, refer to documentation for your specific operating system for instruction on accessing and mounting network shares.



SimpleTech highly recommends that you back up files the files on SimpleShare. SimpleTech is not responsible for any data loss, nor will SimpleTech perform any recovery on loss data files.

ACCESSING SIMPLESHARE FROM WINDOWS

- 1 In the Address box of your Web browser, type \\simpleshare_name (where simpleshare_name is the network name of your SimpleShare server), and then press the **Enter** key.



To access the shared folders, you must type backslash character when entering SimpleShare's name.

- 2 In the login prompt, enter your user password for accessing the shared folders on SimpleShare. If you want the system to remember your password in the future, select **Remember my password**.
- 3 Click **OK** to continue. You will be logged onto SimpleShare as a guest user.




If your computer is unable to locate SimpleShare (login dialog does not appear), check the connections, make sure SimpleShare is in Ready mode and properly connected to the network. Then, try to connect to SimpleShare again.



Internet Explorer appears displaying the SimpleShare's root directory and the shared folders available on SimpleShare. You are now ready to save files to or retrieve files from SimpleShare.


To make it easier to access SimpleShare shared folders in the future, you can assign a drive letter to a share, allowing you to access the folder using My Computer. To map a shared folder, continue to [Step 4 on page 15](#).



- 4 In the **Tools** menu, click **Map Network Drive**.
- 5 Open the **Drive** list and select a drive letter to assign to the shared folder you want to map to your computer (or accept the next available drive letter displayed in the list).
- 6 In **Folder**, type `\\simpleshare_name\share_name` (where SimpleShare_name is the network name of your SimpleShare server and share_name is the name of the shared folder you want to map to your computer). You can also use the **Browse** button to find the share.
- 7 If you want your computer to reconnect to the shared folder every time you log on, select **Reconnect at logon**.
- 8 After making your selections, click **Finish** to map the share to the drive letter.




Mapped shares are available only when SimpleShare is available. You can assign a share to a different drive letter by disconnecting from the drive and then reassigning it to a new drive letter.



ACCESSING SIMPLESHARE FROM MAC OS X

1 Open the **Go** menu in Finder and click **Connect to Server**.



2 In the Connect to Server window, select your SimpleShare from the servers listed in the left pane.

If Workgroup names are listed, check the Workgroup in which your SimpleShare is a member. If you can't locate your SimpleShare, enter its URL in the **Address** box (where the URL consists of the protocol "smb://" and the network name or IP address of your SimpleShare).

3 After selecting your SimpleShare, click **Connect**.



- 4 In the SMB Mount dialog box, select the share you want to access from the drop-down list, then click **OK**.



- 5 In the SMB/CIFS Filesystem Authentication dialog, enter your SimpleShare administration username and password. If you are logging onto SimpleShare for the first time, enter the default username “admin” and password “simple.”
- 6 If you want the system to remember your authentication information, select **Add to Keychain**.
- 7 After making your selections, click **OK**.

A desktop icon for the mapped share appears on your desktop.



MANAGING SIMPLESHARE


This section provides detailed instructions on managing your SimpleShare Office Storage Server. The procedures provided in this section are divided into the following:

- Administration
- Share Management
- Basic Disk Management
- Foreign and Blank Disk Management
- Disk Pool Management
- Network Management
- Printer Management

ADMINISTRATION

RUNNING SIMPLESHARE ADMINISTRATOR

- 1 In the Address box of your Web browser, type `http://simpleshare_name` (where `simpleshare_name` is the network name of your SimpleShare server), and then press the **Enter** key.
- 2 In the login dialog box, enter the administration username and password for accessing SimpleShare. If you want the system to remember your password in the future, select **Password my password**. Click **OK** to log onto the SimpleShare Administrator.



SETTING THE SIMPLESHARE NETWORK NAME

The name you choose for SimpleShare is very important. This name not only gives SimpleShare a unique identity on the network, but is required in order to access SimpleShare data. When choosing a name, pick one that is easy to remember. For example, you can use your last name, a description of the data SimpleShare will store, or where SimpleShare will be located. If there's only one SimpleShare on your network, you can use its default name, "SimpleShare."

- 1 In the **Administration** menu, click **Basic**.
- 2 In **Machine Name**, enter the network name you want assigned to the SimpleShare, then Click **Apply**.



The SimpleShare name can be up to 15 characters in length, containing any combination of alphanumeric (A-Z and 1-9) characters, including the dash (-) character. Spaces and special characters are not allowed.

If you share SimpleShare with MS-DOS computers, do not use more than eight characters in the SimpleShare name. The TCP/IP networking protocol supports network names up to 63 characters long. However, these longer names should only contain the numbers 0-9, the letters A-Z and a-z, and hyphens. You can use other characters, but doing so might prevent other users from finding your SimpleShare on the network. If your network is using the Microsoft DNS server, you can use any characters except periods.



SimpleShare Administration - Basic

Machine Name:

Admin/Driver Username:

Admin/Driver Password:

Config Password:

SimpleShare Date: Thu Nov 25 22:23:39 2004 [Set Date Manually](#)

SimpleShare Version: Mon Dec 13 10:39:11 2004 [Set SimpleShare Version to Match](#)

Time Zone Region:

Time Zone Country:

Time Zone City:

Network Time Servers:

-
-
-

© Copyright 2004 SimpleTech, Inc. All rights reserved.

SETTING THE ADMINISTRATION USERNAME AND PASSWORD

The Administration Security Setup page allows you to specify a username and password pair to guard against unauthorized access to SimpleShare's Web-based configuration utility. To enable security, you may choose to specify a username, a password or both. To disable security, leave the Username and Password text boxes empty.


- 1 In the **Administration** menu, click **Basic**.
- 2 Enter a new administration username and/or password for SimpleShare. In **Confirm Password**, re-enter the new password to verify that it was entered correctly.



The username and password are case-sensitive. Administration Security treats the username "ADMIN" differently from "admin."

Usernames and passwords should be at least eight characters long and may contain any combination of alphanumeric characters (A-Z and 1-9) and special characters such as &, \$, and >. Spaces are not allowed.

- 3 Click **Apply**.



The screenshot shows the 'Administration - Basic' configuration page. At the top, there are navigation icons for Administration, Share Management, Disk Management, Networking, Profiles, and Help. The main content area includes the following fields and information:

- Machine Name:** SimpleShare
- Administration Username:** admin
- Administration Password:** *****
- Confirm Password:** *****
- SimpleShare Time:** Thu Feb 25 20:23:39 2004 [Set Time Manually](#)
- Browser Time:** Mon Dec 13 10:39:11 2004 [Set SimpleShare Time to Match](#)
- Time Zone Region:** America
- Time Zone Country:** United States
- Time Zone City:** New York
- Network Time Servers:** 192.5.41.40, 192.5.41.41, 133.100.9.2

At the bottom of the form, there are four buttons: **Apply**, **Cancel**, **Restore Defaults**, and **Reboot**.

SETTING THE DATE AND TIME MANUALLY

- 1 In the **Administration** menu, click **Basic**.
- 2 Click the **Set Time Manually** hyperlink.



The screenshot shows the 'Administration - Basic' page in the SimpleShare web interface. The page has a navigation bar at the top with icons for Administration, Share Management, Disk Management, Networking, Profiles, and Help. The main content area contains the following fields and options:


- Machine Name:** SimpleShare
- Administration Username:** admin
- Administration Password:** *****
- Confirm Password:** *****
- SimpleShare Time:** Thu Nov 25 20:23:39 2004 [Set Time Manually](#)
- Browser Time:** Mon Dec 13 10:39:11 2004 [Set SimpleShare Time to Match](#)
- Time Zone Region:** America
- Time Zone Country:** United States
- Time Zone City:** New York
- Network Time Servers:**
 - 192.5.41.40
 - 192.5.41.41
 - 133.100.9.2

At the bottom of the form are buttons for **Apply**, **Cancel**, **Restore Defaults**, and **Reboot**. The footer of the page contains the text: © Copyright 2004 SimpleTech, Inc. All rights reserved.

- 3 On the Setting The Time page, enter the current date and time.
- 4 Open the clock mode list and select the appropriate clock mode (AM, PM or 24-Hour), and then click **Apply**.
- 5 On the **Apply** screen, click **Continue**.
- 6 On the Administration - Basic page, select the region, country and city in which SimpleShare is located.
- 7 Click **Apply**.



You may need to adjust the time setting in the future to accommodate daylight savings time.



The screenshot shows the 'Setting The Time' page in the SimpleShare administration interface. The page has a blue header with the SimpleTech logo on the left and SimpleShare on the right. Below the header is a navigation bar with icons for Administration, Share Management, Disk Management, Networking, Features, and Help. The main content area is titled 'Setting The Time' and contains a form for setting the date and time. The form includes a 'New Date' label and a table of input fields for Year, Month, Day, Hour, Minute, and Second. The current values are 2006, January, 13, 10, 40, and 32. There is also a dropdown menu for 'Clock Mode' with options for AM, PM, and 24 Hour. Below the form are 'Apply' and 'Cancel' buttons. At the bottom of the page, there is a copyright notice: '© Copyright 2004 SimpleTech, Inc. All rights reserved.'

ACQUIRING THE DATE AND TIME FROM YOUR BROWSER

- 1 In the **Administration** menu, click **Basic**.
- 2 Click **Set SimpleTech NAS Time To Match**.
- 3 On the **Apply** screen, click **Continue**.
- 4 On the Administration - Basic page, select the region, country and city in which SimpleShare is located.
- 5 Click **Apply**.



You may need to adjust the time setting in the future to accommodate daylight savings time.



Administration - Basic

Machine Name:

Administration Username:

Administration Password:

Confirm Password:

SimpleShare Time: Thu Nov 25 20:23:39 2004 [Set Time Manually](#)

Browser Time: Mon Dec 13 10:39:11 2004 [Set SimpleShare Time to Match](#)

Time Zone Region:

Time Zone Country:

Time Zone City:

Network Time Servers:

© Copyright 2004 SimpleTech, Inc. All rights reserved.

SYNCHRONIZING THE DATE AND TIME WITH AN NTP SERVER

If Internet access is available through your network, you can configure SimpleShare to periodically synchronize its calendar and clock with a public Network Time Protocol (NTP) server on the Internet. Specifying an NTP server and clicking the **Apply** button will not cause the date and time on SimpleShare to change immediately.

By default, the SimpleShare is configured to access the following NTP public time servers:

Location	IP Address	Service Area	Access Policy:
United States Naval Observatory Washington, DC	192.5.41.40	NSFNET	Open Access
	192.5.41.41	Italy/Europe	Open Access
Fukuoka University Fukuoka, Japan	133.100.9.2	Japan/Asia Pacific	Open Access

- 1 In the **Administration** menu, click **Basic**.
- 2 In the uppermost **NTP Servers** text box, enter the IP address of the primary NTP public time server you want to access. In the two remaining text boxes, enter the IP addresses of your first and second alternate NTP servers.




You can specify the IP addresses of up to three NTP servers. SimpleShare connects to the first available server in the list.

- 3 Select the region, country and city in which SimpleShare is located.
- 4 Click **Apply**.



You may need to adjust the time setting in the future to accommodate daylight savings time.



The screenshot shows the 'Administration - Basic' configuration page in the SimpleShare web interface. The page has a navigation bar at the top with icons for Administration, Share Management, Disk Management, Networking, Profiles, and Help. The main content area contains the following fields and options:

- Machine Name:** SimpleShare
- Administration Username:** admin
- Administration Password:** *****
- Console Password:** *****
- SimpleShare Time:** Thu Nov 25 00:23:39 2004 [Set Time Manually](#)
- Browser Time:** Mon Dec 13 10:39:11 2004 [Set SimpleShare Time to Match](#)
- Time Zone Region:** America
- Time Zone Country:** United States
- Time Zone City:** New York
- Network Time Servers:**
 - 192.5.41.40
 - 192.5.41.41
 - 133.100.9.2

At the bottom of the form are four buttons: **Apply**, **Cancel**, **Restore Defaults**, and **Reboot**. The footer of the page includes a copyright notice: © Copyright 2004 SimpleTech, Inc. All rights reserved.

UPGRADING SIMPLESHARE FIRMWARE

- 1 Save the update file to a location accessible to your computer.




Download the new firmware version from the SimpleShare website at www.simpletech.com/support or contact SimpleTech. For contact information, see “SimpleTech Technical Support” on page 104.

- 2 In the **Administration** menu, click **Firmware**.
- 3 In **New Firmware**, enter the path to the update file or click **Browse** to locate the file.
- 4 Click **Upgrade**.
- 5 In the confirmation dialog, click **OK**.



The upgrade process take several minutes to complete. Do not turn SimpleShare off while the upgrade is in progress. Interrupting the upgrade process will corrupt the firmware on the SimpleShare, and make it impossible to boot later.

- 6 After the upgrade process completes, press and hold the **Reset** button (located on the rear panel) for 5 seconds to initialize SimpleShare with the new firmware.



SETTING UP EMAIL ALERT NOTIFICATION

Email Notification allows SimpleShare to inform network users of system error conditions through e-mail messages.



Before setting up E-mail Alert Notification on SimpleShare, make sure your network's SMTP server is set up and can be accessed SimpleShare.

- 1 In the **Administration** menu, click **Alerts/Logging**.
- 2 Select **Email Notification Enabled**.
- 3 In **Error Handling SMTP Server**, enter the IP address or hostname of the SMTP server on your network.



If you don't know the IP address or hostname of your SMTP server, check the configuration of the e-mail program on your computer. Use the same SMTP server IP address or hostname that it uses.

- 4 To specify a different SMTP port, select **SMTP Port Override**, and then enter the new port number in **Error Handling SMTP Number**.
- 5 In **Error Handling E-Mail Recipients**, enter the email address of users to receive email alert notifications. You can specify up to five recipients.

- 6 To verify that email alert notification is working properly, click **Send Test E-Mail**, then confirm that the email recipients received the test alert notice.
- 7 Click **Apply**.



The screenshot shows the 'Error Alerts/Logging' configuration page in the SimpleShare Administration interface. The page has a blue header with the SimpleTech logo on the left and the SimpleShare logo on the right. Below the header is a navigation bar with icons for Administration, Share Management, Disk Management, Networking, Profiles, and Help. The main content area is titled 'Error Alerts/Logging' and contains several sections:

- E-mail Notification Enabled:** A checkbox that is checked. Below it are fields for 'Error Handling SMTP Server', 'SMTP Port Override' (with a dropdown arrow), and 'Error Handling SMTP Port Number' (with a dropdown arrow). There are also five empty text input fields for 'Error Handling E-Mail Recipients' and a 'Send Test E-Mail' button.
- Pop-Up Notification Enabled:** A checkbox that is unchecked. Below it are five empty text input fields for 'Error Handling Pop-Up Mechanism' and a 'Send Test Pop-Up' button.
- View Logging options:** A checkbox that is unchecked.

At the bottom of the page are 'Apply' and 'Cancel' buttons. A copyright notice is visible at the very bottom: '© Copyright 2004 SimpleTech, Inc. All rights reserved.'


SETTING UP POPUP ALERT NOTIFICATION

Email Notification allows SimpleShare to inform network users of system error conditions through onscreen messages.



Before setting up Popup Alert Notification on SimpleShare, make sure the message popup service has been enabled on each computer selected to receive the messages.

- 1 In the **Administration** menu, click **Alerts/Logging**.
- 2 Select **Pop-Up Notification Enabled**.
- 3 In **Error Handling Pop Up Machines**, enter the network name of each computer to receive alert notification popup messages. You can specify up to five computers.
- 4 To confirm that popup alert notification is working properly, click **Send Test Popup**, then verify that the selected computers received the test alert popup message.
- 5 Click **Apply**.




The screenshot shows the 'Error Alerts/Logging' configuration page in the SimpleShare Administration console. The page has a navigation bar at the top with icons for Administration, Share Management, Disk Management, Networking, Profiles, and Help. The main content area is titled 'Error Alerts/Logging' and contains two sections:

- E-mail Notifications Enabled:** A checkbox is checked. Below it are fields for 'Error Handling SMTP Server', 'SMTP Port Override', 'Error Handling SMTP Port Number', and 'Error Handling E-Mail Recipients'. A 'Send Test E-Mail' button is located below these fields.
- Pop-Up Notification Enabled:** A checkbox is checked. Below it are fields for 'Error Handling Pop Up Machines'. A 'Send Test Pop-Up' button is located below these fields.

At the bottom of the page, there is a 'View Logging options' checkbox and 'Apply' and 'Cancel' buttons. The footer of the page contains a copyright notice: '© Copyright 2004 SimpleTech, Inc. All rights reserved.'

ADDING SIMPLESHARE TO AN EXISTING WORKGROUP

- 1 In the **Administration** menu, click **Windows Setup**.
- 2 Select **Workgroup Member Mode**, then in **Workgroup Name**, type the name of the workgroup to which you are making SimpleShare a member.
- 3 Select the share access method to be enabled on SimpleShare.
 - To provide share access to all users in a Workgroup, select **Password Based Share Access**.
 - To limit share access to selected users in a Workgroup, select **User Based Share Access**, then from the **Pool Name** list choose the disk pool to which access is being granted.
- 4 After making your selections, click **Apply**.
- 5 In the confirmation dialog, click **OK**.




ADDING SIMPLESHARE TO AN EXISTING DOMAIN

- 1 In the **Administration** menu, click **Windows Setup**.
- 2 Select **Domain Member Mode**, then in **Domain Name** type the name of the domain to which you are making SimpleShare a member.
- 3 Click **Apply**.
- 4 In **Domain Authentication** dialog, enter the username and password you use to log onto Windows as the administrator or a member of the administrator's group, then click **OK**.




You must be logged on Windows as an administrator or a member of the Administrator's group in order to join a domain and complete this procedure. If your computer is connected to a network, network policy settings may also prevent you from completing this procedure.

- 5 In the **Administration** menu, click **Basic**.
- 6 Click **Reboot** to restart SimpleShare and apply your changes.



RESTORING FACTORY SETTING

- 1 In the **Administration** menu, click **Basic**.
- 2 Click **Restore Defaults**.
- 3 In the confirmation dialog, click **OK** to continue.
- 4 On the **Apply** screen, click **Continue**.



Administration - Basic

Machine Name:

Admin User:

Admin Password:

Confirm Password:

SimpleShare Date: Thu Nov 20 22:23:39 2004 Get Time Manually

Recover Date: Mon Dec 13 10:39:11 2004 Get SimpleShare Time to Match

Time Zone Region:

Time Zone Country:

Time Zone City:

Network Time Servers:


-
-
-

Buttons:

© Copyright 2004 SimpleTech, Inc. All rights reserved.

RESTARTING SIMPLESHARE

- 1 In the **Administration** menu, click **Basic**.
- 2 Click **Reboot**.



Administration - Basic

Machine Name: SimpleShare

Admin User Name: admin

Admin Password: *****

Admin Password Confirmation: *****

SimpleShare Name: Thu Nov 25 20:22:39 2004 [Set Time Manually](#)

Renewal Date: Mon Dec 13 10:26:11 2004 [Get SimpleShare Name to Match](#)

Time Zone Region: America

Time Zone Country: United States

Time Zone City: New York

Network File Servers:

- 192.5.41.40
- 192.5.41.41
- 192.100.9.2


Apply Cancel Restore Defaults **Reboot**

Copyright 2004 SimpleTech, Inc. All rights reserved.

SHARE MANAGEMENT

SETTING FILE SYSTEM SUPPORT ON SIMPLESHARE

- 1 In the **Share Management** menu, click **Basic**.
- 2 Locate the shared folder you want to setup, and then select file system(s) supported on the share.
 - To enable CIFS support on SimpleShare for Windows and Mac computers, select **Enabled** from the **Windows Access (CIFS)** list.
 - To enable NFS support on SimpleShare for Unix/Linux computers, select **Enabled** from the **Unix/Linux Access (NFS)** list.
- 3 Click **Apply**.




CREATING A SHARE

Share Authentication only provides password protection on shares when accessed from Windows computers. To enable share authentication, SimpleShare must be configured as a member of a Windows workgroup.

- 1 In the **Share Management** menu, click **Create Share**.
- 2 In **New Share Name**, enter a descriptive name for the share you want to create.
- 3 Choose the disk pool in which the new share will reside from the **Create in Pool** list.
- 4 Select file system(s) supported on the share.
 - To enable CIFS support on the share for Windows and Mac computers, select **CIFS Access**.
 - To enable NFS support on the share for Unix/Linux computers, select **NFS Access**.



If the desired file system not available (checkbox is gray), support for the protocol is not enabled on your SimpleShare server. To enable file system protocol on SimpleShare, see “Setting File System Support on SimpleShare” on page 34.



The screenshot shows the 'Create New Share' web interface. At the top, there is a navigation bar with icons for Administration, Share Management, Disk Management, Networking, Printers, and Help. The main content area has the SimpleTech logo and the title 'Create New Share' with a subtitle 'This page allows you to create new shares.' Below this, there are several form fields and checkboxes:

- New Share Name:** A text input field.
- Create in Pool:** A dropdown menu with 'SimplePool' selected.
- CIFS Access:** A checkbox labeled 'CIFS Enabled' which is checked.
- NFS Access:** A checkbox labeled 'NFS Enabled' which is checked.
- Share Authentication:** A checkbox labeled 'Enable Share Authentication' which is unchecked.

At the bottom of the form, there are two buttons: 'Create Share' and 'Cancel'. The footer of the page contains the copyright notice: '© Copyright 2004 SimpleTech, Inc. All rights reserved.'

- 5 To enable authentication (password security) on the new share, select **Enable Share Authentication**.
- 6 In **Share Password**, enter a password for accessing the share.



Passwords can be up to eight characters long and may contain any combination of alphanumeric characters (A-Z and 1-9) and special characters such as &, \$, and >. Spaces are not allowed.

- 7 In **Confirm Password**, re-enter the password to confirm it was entered correctly.
- 8 Click **Create Share**.




The screenshot shows the 'Create New Share' page in the SimpleShare web interface. The page has a blue header with navigation icons for Administration, Share Management, Task Management, Networking, Profiles, and Help. The main content area is white with a blue header containing the SimpleTech logo and the title 'Create New Share'. Below the title is a sub-header: 'This page allows you to create new shares.' The form includes the following fields and options:

- New Share Name:** A text input field containing 'New Share'.
- Create in Pool:** A dropdown menu set to 'SimplePool'.
- CIFS Access:** A checkbox labeled 'CIFS Enabled' which is checked.
- NFS Access:** A checkbox labeled 'NFS Enabled' which is checked.
- Share Authentication:** A checkbox labeled 'Enable Share Authentication' which is checked.
- Share Password:** A text input field with eight asterisks (*****).
- Confirm Password:** A text input field with eight asterisks (*****).

At the bottom of the form are two buttons: 'Create Share' and 'Cancel'. The footer of the page contains a copyright notice: '© Copyright 2004 SimpleTech, Inc. All rights reserved.'


DELETING A SHARE

- 1 In the **Share Management** menu, click **Basic**.
- 2 In **Disk Pool Mappings**, click **Delete** next to the share you want to delete.
- 3 In the warning dialog, click **OK**.
- 4 In the verification dialog, click **OK**.



RENAMING A SHARE

- 1 In the **Share Management** menu, click **Basic**.
- 2 Click **Rename Share**.
- 3 Select the share you want to rename from the **Old Share Name** list.
- 4 Enter the new share name in **New Share Name**.
- 5 Click **Rename Share**.



The screenshot displays the SimpleShare web interface. At the top, there is a navigation bar with icons for Administration, Share Management, Disk Management, Networking, Profiles, and Help. Below this is a header with the SimpleTech logo on the left and the SimpleShare logo on the right. The main content area is titled "Rename Share" and includes the subtitle "This page allows you to rename shares". There are two input fields: "Old Share Name" with a dropdown menu currently showing "NetFolder" and a small downward arrow, and "New Share Name" with an empty text box. Below the input fields are two buttons: "Rename Share" and "Cancel". At the bottom of the page, there is a copyright notice: "© Copyright 2004 SimpleTech, Inc. All rights reserved."

ENABLING SECURITY ON AN EXISTING SHARE

Share Authentication only provides password protection for shares when accessed from Windows machines. To enable share authentication, SimpleShare must be configured as a member of a Windows workgroup.

- 1 In the **Share Management** menu, click **Share Access**.
- 2 From the **Share Name** list, choose the share you want to modify.
- 3 Select **Enable Share Authentication**.
- 4 In **New Password**, enter the password required to access the selected share.



Passwords can be up to eight characters long and may contain any combination of alphanumeric characters (A-Z and 1-9) and special characters such as &, \$, and >. Spaces are not allowed.


- 5 In **Confirm Password**, re-enter the password to confirm it was entered correctly.
- 6 Click **Apply**.
- 7 In the confirmation dialog, click **OK**.



The screenshot shows the 'Share Access' configuration page in SimpleShare. The page has a navigation bar with icons for Administration, Share Management, Disk Management, Networking, Profiles, and Help. The main content area is titled 'Share Access' and includes a sub-header 'This page allows you to view and modify share access.' Below this, there are several fields: 'Share Name' (set to 'testorder'), 'Resides in Path' (set to 'SimplePool'), 'Share Authentication' (with a checked 'Enable Share Authentication' checkbox), 'New Password' (masked with asterisks), and 'Confirm Password' (also masked with asterisks). At the bottom of the form are 'Apply' and 'Cancel' buttons. A copyright notice for SimpleTech, Inc. is visible at the bottom right of the page.

DISABLING SECURITY ON AN EXISTING SHARE

- 1 In the **Share Management** menu, click **Share Access**.
- 2 From the **Share Name** list, choose the share you want to modify.
- 3 Deselect **Enable Share Authentication**.
- 4 Click **Apply**.
- 5 In the confirmation dialog, click **OK**.



BASIC DISK MANAGEMENT

SimpleShare's is equipped with either an 160 MB or 250 MB internal IDE hard disk drive, depending on the model you purchased. However, SimpleShare's storage capacity can be easily increased by attaching an external disk drive. The disk space on SimpleShare is divided into storage areas or "Disk Pools." You can create multiple storage areas on a single drive or combine multiple drives to create a single pool. Disk Management menu options allow you to manage SimpleShare disk drives and disk pools. To create shares and store files on a SimpleShare drive one or more disk pools must exist on the drive. SimpleShare's internal disk drive is configured at the factory with a single disk pool named "SimplePool", which is allocated the full capacity of the drive. SimpleShare's advanced disk management features provide:

- Foreign disk support
- Mirror pools
- Striped pools
- Spanning

SimpleShare's multi-disk functions can be configured using any combination of internal and external USB drives. For example, you can mirror the data on the internal disk onto an external USB drive or mirror the data on an external drive to a second external drive. Except foreign disk support, the drives connected to SimpleShare must be "claimed." Claiming a disk reformats the drive for exclusive use by SimpleShare. Once a drive is claimed, it can only be read by SimpleShare. The claiming process destroys all the data on the drive.


RENAMING A DISK DRIVE

- 1 In the **Disk Management** menu click **Basic**.
- 2 Select **Show Disk Details**.



The Show Disk Details checkbox is located at the bottom of the Disk Management page. It may be necessary to use the scroll bar to see the checkbox.

- 3 Click **Rename Disk**.
- 4 Select the disk you want to rename from the **Old Disk Name** list.
- 5 In **New Disk Name**, enter the new name of the disk.
- 6 Click **Rename Disk**.
- 7 In the confirmation dialog, click **OK**.



ERASING A DISK POOL

- 1 Erase all shares from the disk pool you want to delete. For instructions, see “Deleting a Share” on page 37.



Deleting shares and disk pools erases all data within them so make complete backups prior to deleting shares or disk pools.



Before you can delete a disk pool, you must first delete all shares allocated within the pool.

- 2 In the **Disk Management** menu, click **Basic**.
- 3 Click **Erase Disk**.
- 4 In **Disks Available** on the **Wipe Pool** page, select the disk drive you want to wipe (erase).
- 5 In Confirmation String, enter **Yes, destroy everything on this disk**.
- 6 Click **Quick Erase** or **Full Erase**, depending on the type of erase process you want to perform.



Quick Erase performs a brief erasure of the primary file system structures but does not erase all locations on the disk that contained user data. Full Erase performs multiple erasure passes on the entire disk.

- 7 In the confirmation dialog, click **OK**.

An erased or wiped disk appears in SimpleShare Administrator as a Blank Disk.

ERASING A DISK DRIVE

Erasing disks destroys the existing data on the disks. Do not use this function unless you wish to destroy the data on a disk. Exercise extreme caution when using this function, as the data on disks that are erased using this function may not be recoverable.



Quick erase only takes a few minutes to complete. However, portions of the data may be recoverable using data recovery tools. If you are concerned about erased data becoming available to others, perform a full erase. Keep in mind that a full erase takes several days to complete. If the data on SimpleShare is encrypted, it may not be necessary to perform a full erase. Since the data is encrypted, any data recovered will be encrypted. To decrypt the data requires knowledge of the encryption password.

- 1 In the **Disk Management** menu, click **Basic**.
- 2 Select **Show Disk Details**.



The **Show Disk Details** checkbox is located at the bottom of the **Disk Management** page. It may be necessary to use the scroll bar to see the checkbox.

- 3 Click **Erase Disk**.

Disk Management - Basic

Disk Graphic

External Disk 1	Internal Drive
164.7 GB	256.1 GB
Unknown	Good
Safely Remove Disk	

Disk Pool Mappings:

Pool	Type	Status	Logical Size	Space Used	Physical Size	External Disk 1	Internal Drive
External Disk 1	Raw	Good	249.5 GB	0.034 GB	249.5 GB	249.5 GB	0 GB
Unallocated					165.2 GB	164.7 GB	0.512 GB
Total			249.5 GB	0.034 GB	414.8 GB	164.7 GB	250.1 GB

Create New Disk Pools:

Rename Disk Pools:

Show Disk Details

Available Disks:

Make and Model	Physical Size	Health
External Disk 1 HD572291 6VLA720	164.7 GB	unknown Full Health Details
Internal Drive HD572292SVLA780	250.1 GB	good Full Health Details
Total	414.8 GB	

Rename Disks:

Erase Disks:


© Copyright 2004 SimpleTech, Inc. All rights reserved.

- 4 In **Disks Available**, select each disk you want to erase.
- 5 In **Safety Confirmation**, type **Yes, destroy everything on this disk**.
- 6 Click **Quick Erase** or **Full Erase**, depending on the type of erase process you want to perform.



Quick Erase performs a simple erase of the primary file system structures but does not erase all locations on the disk that contained user data. Full Erase performs multiple erasure passes on the entire disk.

- 7 In the confirmation dialog, click **OK**.



ENABLING DISK POWER MANAGEMENT

Disk power management allows the internal SimpleShare disk drive to be automatically powered off during periods when it is not being accessed.

- 1 On the Disk Management menu, click **Disk Power Management**.
- 2 Choose **Specify Timeout** to enable automatic power management.
- 3 Enter the time-out period in the **Minutes** and **Seconds** text boxes. The time-out period can range from 0 (zero) minutes and 0 seconds, up to 21 minutes and 15 seconds. Seconds can only be set in increments of 5. Seconds values not in increments of 5 (five) are rounded to the closest multiple of 5.
- 4 Click **Apply**.
- 5 In the confirmation dialog, click **OK**.



VIEWING DISK DRIVE HEALTH INFORMATION

SimpleShare's internal disk drive supports SMART (Self-Monitoring Analysis and Reporting Technology) for monitoring drive health. SMART monitors the operation of the disk drive for signs of impending failure. Health information is reported to SimpleShare and can be viewed on the Health Report page.

- 1 In the **Disk Management** menu, click **Basic**.
- 2 Select **Show Disk Details**.



The **Show Disk Details** checkbox is located at the bottom of the **Disk Management** page. It may be necessary to use the scroll bar to see the checkbox.

- 3 In **Available Disks**, click the **Full Health Details** hyperlink to the right of SimpleShare's internal disk drive.

Disk Management - Basic

Disk Graphic

External Disk 1	164.7 GB	Unknown
Internal Drive	250.1 GB	Good

Disk Pool Mappings:

Pool	Type	Status	Logical Size	Space Used	Physical Size	External Disk 1	Internal Drive
External Disk 1	Raw	Good	249.5 GB	0.034 GB	249.5 GB	249.5 GB	
Unallocated					165.2 GB	164.7 GB	0.512 GB
Total			249.5 GB	0.034 GB	414.8 GB	164.7 GB	250.1 GB

Available Disks:

Make and Model	Physical Size	Health
External Disk 1: HD572291 6VLA720	164.7 GB	unknown
Internal Drive: HD572292SVLA780	250.1 GB	good
Total	414.8 GB	

© Copyright 2004 SimpleTech, Inc. All rights reserved.

4 Click **Continue** to the Disk Management - Basic page.

The screenshot shows the 'Disk Internal Drive Health Report' page in the SimpleShare web interface. The page has a blue header with the SimpleTech logo and navigation icons for Administration, Share Management, Disk Management, Networking, Profiles, and Help. The main content area displays the following information:

Health details:
 Device: HD572529LATE0 Supports ATA Version 6
 Drive supports S.M.A.R.T. and is enabled
 Check S.M.A.R.T. Passed

General Smart Values:
 Off-line data collection status: (0x00) Off-line data collection activity was never started

Self-test execution status: () The previous self-test routine completed without error or no self-test has ever been run

Total time to complete off-line data collection: (5552) Seconds

Off-line data collection Capabilities: (0x10)SMART EXECUTE OFF-LINE IMMEDIATE
 Automatic timer ON/OFF support
 Suspend Off-line Collection upon new command
 Off-line surface scan supported
 Self-test supported

Smart Capabilities: (0x0003) Saves SMART data before entering power-saving mode
 Supports SMART auto save timer

Error logging capability: (0x01) Error logging supported

Short self-test routine recommended polling time: (1) Minutes

Extended self-test routine recommended polling time: (93) Minutes

Vendor Specific SMART Attributes with Thresholds:
 Revision Number: 16

Attribute	Flag	Value	Worst	Threshold	Raw Value
1) Raw Read Error Rate	0x0020	100	100	060	0
2) Throughput Performance	0x0005	100	100	050	0
3) Spin Up Time	0x0007	091	091	024	2234205
4) Start Stop Count	0x0013	100	100	060	40
5) Reallocated Sector Ct	0x0013	100	100	005	0
7) Seek Error Rate	0x000B	100	100	060	0
8) Seek Time Performance	0x0005	100	100	020	0
9) Power On Hours	0x0012	100	100	000	874
10) Spin Retry Count	0x0013	100	100	060	0
12) Power Cycle Count	0x0012	100	100	050	39
13) Power-Off Retract Count	0x0031	100	100	050	66
191) Load Cycle Count	0x0012	100	100	050	66
194) Temperature	0x0022	122	122	000	1376317
190) Reallocated Event Count	0x0022	100	100	000	0
197) Current Pending Sector	0x0021	100	100	000	0
199) Offline Uncorrectable	0x0008	100	100	000	0
198) CRC Error Count	0x000A	200	200	000	0

SMART Error Log:
 SMART Error Logging Version: 1
 No Errors Logged

Self Test Options:
 Run Short Test
 Run Long Test
 Notify Test Results

At the bottom of the page, there are two buttons: 'Run Self Test' and 'Continue'. The 'Continue' button is highlighted, indicating the next step in the process.

RUNNING DISK DRIVE SELF-TESTS

SimpleShare's internal disk drive supports self-tests as part of its health monitoring system. These self-tests check the operation of the disk drive inspect internal components and calibration of the disk drive attempting to detect failures or potential failures. These self-tests do not modify or destroy user data.

- 1 In the **Disk Management** menu, click **Basic**.
- 2 Select **Show Disk Details**.



The Show Disk Details checkbox is located at the bottom of the Disk Management page. It may be necessary to use the scroll bar to see the checkbox.

- 3 In **Available Disks**, click the **Full Health Details** hyperlink to the right of SimpleShare's internal disk drive.

Disk Management - Basic

Disk Graphic

External Disk 1	Internal Drive
164.7 GB	250.1 GB
Unknown	Good
Safety Remove Disk	

Disk Pool Mappings:

Pool	Type	Status	Logical Size	Space	Physical Size	External Disk 1	Internal Drive
External Disk 1	Raw	Good	249.5 GB	0.034 GB	249.5 GB	249.5 GB	
Unallocated					165.2 GB	164.7 GB	0.512 GB
Total			249.5 GB	0.034 GB	414.8 GB	164.7 GB	250.1 GB

Create New Disk Pools:

Rename Disk Pools:

Show Disk Details

Available Disks:

Make and Model	Physical Size	Health
External Disk 1 HD572291 6VLA7Z0	164.7 GB	unknown
Internal Drive HD5722S25VLA780	250.1 GB	good
Total	414.8 GB	

Rename Disks:

Erase Disks:

[Full Health Details](#) [Full Health Details](#) [Safety Remove Disk](#)

© Copyright 2004 SimpleTech, Inc. All rights reserved.

- 4 Choose **Run Short Test** **Run Short Test** or **Run Long Test** , depending on the type of self-test you want to perform.



Run Short Test performs a quick check to verify that the drive is fully operational. Run Long Test performs a comprehensive test of the disk drive.

- 5 If you want SimpleShare Administrator to display an onscreen message when the self-test completes, select **Notify Test Results**.

- 6 Click **Run Self Test** to begin the testing disk drive.



If **Notify Test Results** is selected, when the self-test completes a yellow banner containing the test results appears across the top of the SimpleShare Administrator page you are on. Clicking the hyperlink in the clears the notification and displays the health report.

- 7 In the confirmation dialog, click **OK** .
- 8 Click **Continue** to return to the Disk Management - Basic page.

The screenshot shows the 'Disk Internal Drive Health Report' window in SimpleShare Administrator. The report details SMART data for a device (H0572252SLATE0). It includes sections for 'General Smart Values', 'Self-test execution status', 'Total time to complete off-line data collection', 'Offline data collection Capabilities', 'Smart Capabilities', 'Error logging capability', 'Short self-test routine recommended polling time', 'Extended self-test routine recommended polling time', and 'Vendor Specific SMART Attributes with Thresholds'. At the bottom, there are radio buttons for 'Self Test Options': 'Run Short Test' (selected), 'Run Long Test', and 'Notify Test Results'. 'Run Self Test' and 'Continue' buttons are also visible.

REMOVING EXTERNAL DRIVES

Disconnecting an external USB drive without performing a safe removal causes an alert notification to appear across the top of the SimpleShare Administrator window indicating that the disk was removed unexpectedly.

- 1 In the **Disk Management** menu, click **Basic**.
- 2 Click **Safely Remove Disk** below the external drive you want to remove.
- 3 In the dialog that appears indicating that the disk can now be safely removed, click **OK**.

The screenshot shows the 'Disk Management - Basic' interface. At the top, there are navigation icons for Administration, Share Management, Disk Management, Networking, Printers, and Help. Below the navigation bar, the SimpleTech and SimpleShare logos are displayed. The main content area features a 'Disk Graphic' with two bars: a red bar for 'External Disk 1' (164.7 GB, Unknown) and a blue bar for 'Internal Drive' (250.1 GB, Good). A red button labeled 'Safely Remove Disk' is positioned below the External Disk 1 bar. Below the graphic is a 'Disk Pool Mappings' table:

Pool	Type	Status	Logical Size	Space	Physical Size	External	Internal Drive
External disk 1	Raw	Good	249.5 GB	0.034 GB	249.5 GB	249.5 GB	
Unallocated					165.2 GB	164.7 GB	0.512 GB
Total			249.5 GB	0.034 GB	414.8 GB	164.7 GB	250.1 GB

Below the table, there are buttons for 'Create New Disk Pools' and 'Rename Disk Pools'. A 'Show Disk Details' checkbox is checked. At the bottom, the 'Available Disks' section shows:

Make and Model	Physical Size	Health
External Disk 1 HD572291 6VLA720	164.7 GB	unknown
Internal Drive HD572292SVLA780	250.1 GB	good
Total	414.8 GB	

Buttons for 'Rename Disks' and 'Erase Disks' are also present. A 'Safely Remove Disk' button is highlighted in red next to the 'Internal Drive' row. The footer contains the copyright notice: '© Copyright 2004 SimpleTech, Inc. All rights reserved.'

FOREIGN AND BLANK DISK MANAGEMENT

When a USB drive formatted with the FAT or NTFS file system is connected to SimpleShare recognizes the drive as a “Foreign Disk,” and immediately makes it available to users on the network. The share name for foreign disks is set by SimpleShare, based on the file system used on the disk. The files on foreign disks are not modified by SimpleShare in any way. If the disk is later disconnected from the SimpleShare and attached to a Windows or Mac OS computer, it will still be readable by that computer. The shares created by SimpleShare for foreign disks are referred to as “Foreign Shares.” An unformatted drive connected to SimpleShare are recognized as “Blank Disk.” Before a Blank disk can be made available to network users, it has to be formatted or claimed by SimpleShare.

SimpleShare’s foreign disk support function makes it easy to attach a USB disk formatted with FAT or NTFS and share its files with other users on the network, with the following restrictions:

- Disks formatted with NTFS are read-only
- Foreign disks cannot be used for mirroring
- Foreign disks cannot be used for striping
- Only share level access is provided for foreign shares (user base security, domain member and domain controller security is not provided)

VIEWING FOREIGN DISK INFORMATION

- 1 In the **Disk Management** menu, click **Foreign Disk**.
- 2 To view detailed disk information, select **Show Foreign Disk Details**.

The screenshot displays the 'Foreign Disk Management - Basic' interface. At the top, there is a navigation bar with icons for Administration, Share Management, Disk Management, Networking, Profiles, and Help. Below the navigation bar, the SimpleTech and SimpleShare logos are visible. The main content area features a 'Disk Partition Graphic' showing a single blue bar representing 'Foreign Disk 1' with a size of 164.7 GB. A red warning box below the bar says 'Safety Remove Disk'. Below the graphic, the 'Disk Partition Mappings' section shows a table for 'Disk: Foreign Disk 1'. The table has columns for Partition, File System, Total Space, and Space Used. The data shows one partition named 'EXTENDED' with a FAT file system, 164.7 GB of total space, and 0.0 GB of space used. There is also an 'Unallocated' section with 0.002 GB of space. A 'Check and Repair' button is located to the right of the table. At the bottom left, there is a checkbox labeled 'Show Foreign Disk Details' which is currently unchecked. A copyright notice at the bottom reads '© Copyright 2004 SimpleTech, Inc. All rights reserved.'

Partition	File System	Total Space	Space Used
EXTENDED	FAT	164.7 GB	0.0 GB
Unallocated		0.002 GB	
Total		164.7 GB	0.0 GB

CLAIMING FOREIGN DISK FOR SIMPLESHARE

Claiming a disk places the disk under the exclusive control of SimpleShare and allows you to manage the disk using SimpleShare Administrator. Once SimpleShare claims a disk it is no longer readable by Windows or Mac OS computers and any data that existed on the drive is destroyed.



Claiming a disk destroys the data on the disk. If you have important data on the drive, create a backup.

- 1 In the **Disk Management** menu, click **Basic**.
- 2 Select **Show Disk Details**.



The **Show Disk Details** checkbox is located at the bottom of the **Disk Management** page. It may be necessary to use the scroll bar to see the checkbox.

- 3 Click the **Claim** button located to the right of the Foreign disk you want to claim.

Disk Management - Basic

Disk Graph

249.5 GB

Internal Drive
249.5 GB
Good

Disk Pool Mappings:

Pool	Type	Status	Logical Size	Space Used	Physical Size	Internal Drive
SimplePool	Raw	Good	249.5 GB	0.034 GB	249.5 GB	249.5 GB
Unallocated				0.512 GB	0.512 GB	
Total			249.5 GB	0.034 GB	250.1 GB	250.1 GB

Create New Disk Pools: There are currently no available disks with usable space.
Rename Disk Pools:

Show Disk Details

Available Disks:

Make and Model	Physical Size	Health
Internal Drive HDS722525VLAT80	250.1 GB	good
Total	250.1 GB	

Foreign Disks:

Make and Model	Physical Size	Health
Foreign Disk 1 HDS72251 6VLAT20	164.7 GB	unknown
Total	164.7 GB	

Rename Disks:
Erase Disks:

- 4 In **New Disk Name**, enter a descriptive name for the disk being claimed.
- 5 Make sure **Claim as FAT32 Disk** is not selected.



“Claim as FAT32 Disk” is intended for disks that may be attached to Windows or Mac OS computers in addition to SimpleShare. To enable all SimpleShare capabilities, make sure Claim as FAT32 Disk checkbox is not selected. **“Foreign and Blank Disk Management” on page 52** provides detailed information on the limitations of using FAT32 disks.

- 6 In **Safety Confirmation**, type **Yes, destroy everything on this disk.**
- 7 Click **Claim**.
- 8 In the confirmation dialog, click **OK**.



The screenshot shows the 'Claim Foreign Disk 1' dialog box in the SimpleShare interface. The interface includes a navigation bar with icons for Administration, Share Management, Disk Management, Networking, Printers, and Help. The dialog box contains the following fields and options:

- Disk Info:** Foreign Disk 1, HD572251 0VAAT20, 164.7 GB
- New Disk Name:** External Disk 1
- Partition Type:** Claim as FAT32 disk
- WARNING:** Disk 'Foreign Disk 1' might have useful data. If you continue, you will lose any data on this disk. If you are certain you want to do this, type 'Yes, destroy everything on this disk.' below and click 'Claim', otherwise hit 'Cancel'.
- Safety Confirmation:** Yes, destroy everything on this disk.

Buttons for 'Claim' and 'Cancel' are located at the bottom of the dialog box. The SimpleShare logo and name are visible in the top right corner of the dialog box.



CLAIMING A FOREIGN DISK AS FAT32

SimpleShare allows you to claim a blank disk and format it with the FAT32 file system. Though SimpleShare recognizes the drive as a foreign disk, this feature is useful if you plan to use the drive on Windows or Mac computers as well as SimpleShare. “Foreign and Blank Disk Management” on page 52 provides detailed information on the limitations of using FAT32 disks.

- 1 In the **Disk Management** menu, click **Basic**.
- 2 Select **Show Disk Details**.



The Show Disk Details checkbox is located at the bottom of the Disk Management page. It may be necessary to use the scroll bar to see the checkbox.

Click the **Claim** button located to the right of the Foreign disk

you want to claim.

The screenshot shows the 'Disk Management - Basic' page in SimpleShare. At the top, there are navigation icons for Administration, Share Management, Disk Management, Networking, Printers, and Help. Below the navigation bar is the SimpleTech logo and the SimpleShare logo. The main content area displays a 'Disk Graphic' showing a single bar for 'Internal Drive' with a size of 249.5 GB and a status of 'Good'. Below this is a table for 'Disk Pool Mappings' with columns for Pool, Type, Status, Logical Size, Space Used, Physical Size, and Internal Drive. The table shows 'SimplePool' as 'Raw' with a status of 'Good' and 'Unallocated' space. Below the table, there are sections for 'Create New Disk Pools' (with a message that no disks are available) and 'Rename Disk Pools'. The 'Show Disk Details' section is expanded, showing 'Available Disks' (Internal Drive) and 'Foreign Disks' (Foreign Disk 1). The 'Foreign Disk 1' entry has a 'Claim' button next to it. At the bottom, there are 'Rename Disks' and 'Erase Disks' buttons.

Pool	Type	Status	Logical Size	Space Used	Physical Size	Internal Drive
SimplePool	Raw	Good	249.5 GB	0.034 GB	249.5 GB	249.5 GB
Unallocated				0.512 GB		0.512 GB
Total			249.5 GB	0.034 GB	250.1 GB	250.1 GB

Make and Model	Physical Size	Health
Internal Drive HD5722525VLAT80	250.1 GB	good
Total	250.1 GB	

Make and Model	Physical Size	Health
Foreign Disk 1 HD572251 6VLAT20	164.7 GB	unknown
Total	164.7 GB	

- 3 In **New Disk Name**, enter a descriptive name for the disk being claimed.
- 4 Select **Claim as FAT32 Disk**.
- 5 Select file system(s) to be supported on the disk.
 - To enable CIFS support on the share for Windows and Mac computers, select **CIFS Access**.
 - To enable NFS support on the share for Unix/Linux computers, select **NFS Access**.
- 6 To enable authentication (password security) on the new share, select **Enable Share Authentication**. In **Share Password**, enter a password for accessing the share. In **Confirm Password**, re-enter the password to confirm it was entered correctly.



Passwords can be up to eight characters long and may contain any combination of alphanumeric characters (A-Z and 1-9) and special characters such as \$, &, and >. Spaces are not allowed.

- 7 In **Safety Confirmation**, type **Yes, destroy everything on this disk**.
- 8 Click **Claim**.
- 9 In the confirmation dialog, click **OK**.



CLAIMING A BLANK DISK FOR SIMPLESHARE

Claiming a disk places the disk under the exclusive control of SimpleShare and allows you to manage the disk using SimpleShare Administrator. Once SimpleShare claims a disk it is no longer readable by Windows or Mac OS computers and any data that existed on the drive is destroyed.

- 1 In the **Disk Management** menu, click **Basic**.
- 2 Select **Show Disk Details**.



The Show Disk Details checkbox is located at the bottom of the Disk Management page. It may be necessary to use the scroll bar to see the checkbox.

- 3 Click the **Claim** button located to the right of the Blank disk you want to claim.

Disk Management - Basic

Disk Graphic

249.5 GB

Internal Drive 250.1GB Good

Disk Pool Mapping:

Pool	Type	Status	Logical Size	Space Used	Physical Size	Internal Drive
External Disk	Raw	Good	249.5 GB	0.034 GB	249.5 GB	249.5 GB Delete Unassign Pools
Unallocated			0.512 GB		0.512 GB	
Total			249.5 GB	0.034 GB	250.1 GB	250.1 GB

Create New Disk Pools: There are currently no available disks with usable space.
 Rename Disk Pools:

Show Disk Details

Available Disks:

Make and Model	Physical Size	Health
Internal Drive HD5722529VLA7B0	250.1 GB	good Full Health Details
Total	250.1 GB	

Blank Disks:

Make and Model	Physical Size	Health
Blank Disk 1 HD572251 6VLA720	164.7 GB	unknown Full Health Details <input type="button" value="Claim"/>
Total	164.7 GB	

Rename Disks:
 Erase Disks:


© Copyright 2008 SimpleTech, Inc. All rights reserved.

- 4 In **New Disk Name**, enter a descriptive name for the disk being claimed.
- 5 Make sure **Claim as FAT32 Disk** is not selected.



“Claim as FAT32 Disk” is intended for disks that may be attached to Windows or Mac OS computers in addition to SimpleShare. To enable all SimpleShare capabilities, make sure Claim as FAT32 Disk checkbox is not selected. [“Foreign and Blank Disk Management” on page 52](#) provides detailed information on the limitations of using FAT32 disks.

- 6 Click **Claim**.
- 7 In the confirmation dialog, click **OK**.



CLAIMING A BLANK DISK AS FAT32

SimpleShare allows you to claim a blank disk and format it with the FAT32 file system. Though SimpleShare recognizes the drive as a foreign disk, this feature is useful if you plan to use the drive on Windows or Mac computers as well as SimpleShare. “Foreign and Blank Disk Management” on page 52 provides detailed information on the limitations of using FAT32 disks.

- 1 In the **Disk Management** menu, click **Basic**.
- 2 Select **Show Disk Details**.



The **Show Disk Details** checkbox is located at the bottom of the **Disk Management** page. It may be necessary to use the scroll bar to see the checkbox.

- 3 Click the **Claim** button located to the right of the Blank disk you want to claim.

The screenshot shows the 'Disk Management - Basic' interface. At the top, there are navigation icons for Administration, Share Management, Disk Management, Networking, Printers, and Help. Below the navigation bar, the SimpleTech logo and SimpleShare text are visible. The main content area features a 'Disk Graph' showing a single bar for 'Internal Drive 250.1 GB' with a 'Good' status. Below the graph is a 'Disk Pool Mappings' table:

Pool	Type	Status	Logical Size	Space Used	Physical Size	Internal Drive		
External Disk	Raw	Good	249.5 GB	0.034 GB	249.5 GB	249.5 GB	Delete	Unassign Pool
Unallocated			0.512 GB		0.512 GB	0.512 GB		
Total			249.5 GB	0.034 GB	250.1 GB	250.1 GB		

Below the table, there are sections for 'Create New Disk Pools' (with a 'Rename Pool' button) and 'Rename Disk Pools' (with a 'Rename Pool' button). A 'Show Disk Details' checkbox is checked. The 'Available Disks' section shows 'Internal Drive HD572259VLAT80' with a '250.1 GB' size and 'good' health. The 'Blank Disks' section shows 'Blank Disk 1 HD572251 6VLAT20' with a '164.7 GB' size and 'unknown' health, and a 'Claim' button next to it. At the bottom, there are buttons for 'Rename Disks' and 'Erase Disks'. A copyright notice for SimpleTech, Inc. is at the very bottom.

- 4 In **New Disk Name**, enter a descriptive name for the disk being claimed.
- 5 Select **Claim as FAT32 Disk**.
- 6 Select file system(s) to be supported on the disk.
 - To enable CIFS support on the share for Windows and Mac computers, select **CIFS Access**.
 - To enable NFS support on the share for Unix/Linux computers, select **NFS Access**.
- 7 To enable authentication (password security) on the new share, select **Enable Share Authentication**. In **Share Password**, enter a password for accessing the share. In **Confirm Password**, re-enter the password to confirm it was entered correctly.



Passwords can be up to eight characters long and may contain any combination of alphanumeric characters (A-Z and 1-9) and special characters such as &, \$, and >. Spaces are not allowed.

- 8 Click **Claim**.
- 9 In the confirmation dialog, click **OK**.



CHECKING FOREIGN DISK FILE SYSTEM INTEGRITY



The Check and Repair option is only available for foreign disks formatted with the FAT file system.


- 1 On the **Disk Management** menu, click **Foreign Disks**.
- 2 In **Disk Partition Mappings**, click the **Check and Repair** button of the disk you want to repair. SimpleShare displays the results of the file system integrity check

The screenshot shows the 'Foreign Disk Management - Basic' interface. At the top, there are navigation icons for Administration, Share Management, Disk Management, Networking, Printers, and Help. The main content area features a 'Disk Partition Graph' with a blue bar representing 164.7 GB. Below the graph, it identifies 'Foreign Disk 1' with a size of 164.7 GB and a 'Safely Remove Disk' button. The 'Disk Partition Mappings' section includes a table:

Disk: Foreign Disk 1				
Partition	File System	Total Space	Space Used	
EXTERNAL	FAT	164.7 GB	0.0 GB	Check and Repair
Unallocated		0.002 GB		
Total		164.7 GB	0.0 GB	

Below the table, there is a checkbox for 'Show Foreign Disk Details'. The 'Foreign Disks' section lists 'Foreign Disk 1' with ID 'HD0722C51-04A1A2D', a size of 164.7 GB, and an unknown health status, with a 'Safely Remove Disk' button. At the bottom, there is an 'Erase Disk' button.

- After reviewing the results of the integrity check, click **Continue** to return to the Foreign Disk Management - Basic page.



DISK POOL MANAGEMENT


CREATING A BASIC POOL

One method of using additional drives added to SimpleShare is to simply use the additional disk to create new shares. This is the easiest method and only requires claiming the new disk, creating one or more pools on the disk and finally creating share(s) within the new pools. This procedure is for creating a basic unencrypted pool. If you want to create an encrypted pool, see “Creating an Encrypted Pool” on page 85.

- 1 In the **Disk Management** menu, click **Create New Pool**.
- 2 In **New Pool Name**, enter a descriptive name for the pool.
- 3 To allocate all available disk space on SimpleShare to the new pool, in **Pool Mapping Preference** select **Auto Configuration**, then continue to [Step 5 on page 65](#).



Selecting **Auto Configuration** automatically selects the **Maximum Size** checkbox.



The screenshot shows the 'Create New Disk Pool' window in the SimpleShare application. The interface includes a navigation bar at the top with icons for Administration, Share Management, Disk Management, Networking, Printers, and Help. The main content area is titled 'Create New Disk Pool' and contains the following fields and options:

- New Pool Name:** A text input field containing 'SimplePool'.
- Pool Encryption:** A checkbox labeled 'Encrypt Pool' which is currently unchecked.
- Mirroring:** A text label stating 'There aren't enough disks available for mirroring.'
- Striping:** A text label stating 'There aren't enough disks available for striping.'
- Pool Mapping Preference:** Two checkboxes: 'Auto Configuration' (checked) and 'Manual Configuration' (unchecked).
- Maximize Size:** A checkbox which is checked.
- Disk Assignment:** A table with columns 'Disk', 'Available', and 'Use'. The 'Internal Drive' row shows '249.5 GB' in the 'Available' column and a checked box in the 'Use' column.
- Space Allocation:** A slider control for the 'Internal Drive' (ID: 149,547,34,9872) showing a value of 249.5 GB.
- Buttons:** 'Create Pool' and 'Cancel' buttons at the bottom.

At the bottom right of the window, there is a copyright notice: '© Copyright 2004 SimpleTech, Inc. All rights reserved.'

4 To set the capacity of the new pool manually, complete the following steps:

- In **Pool Mapping Preference** select **Manual Configuration**.
- In **Disk Assignment** select the **Use** checkbox for each disk being used to create the pool.




Disk Assignment allows you to specify which disk drives are to be used by the pool being created. To create a pool that only occupies a portion of a single disk, make sure to only select the Use checkbox for the drive you want to use.

- In **Space Allocation**, enter the size (in gigabytes) of the basic pool. The pool size can be set using the text box or the slider control.



If multiple disks are connected to SimpleShare, by default the Space Allocation selects all available drives. This results in all available space on each drive being allocated to the new pool being created. To remove disks from the pool being created the Manual checkbox must be selected and the Use checkbox for the drives that are not to be included in the pool must be deselected.

5 Click **Create Pool**.



The screenshot shows the 'Create New Disk Pool' configuration window in SimpleShare. The window has a navigation bar at the top with icons for Administration, Share Management, Disk Management, Networking, Printers, and Help. The main content area is titled 'Create New Disk Pool' and contains the following fields and controls:

- New Pool Name:** A text box containing 'SimplePool'.
- Pool Encryption:** A checkbox labeled 'Encrypt Pool' which is currently unchecked.
- Mirroring:** A checkbox labeled 'Mirroring' which is unchecked. Below it, a message states: 'There aren't enough disks available for mirroring.'
- Striping:** A checkbox labeled 'Striping' which is unchecked. Below it, a message states: 'There aren't enough disks available for striping.'
- Pool Mapping Preference:** Two checkboxes: 'Auto Configuration' (unchecked) and 'Maximize Size' (unchecked).
- Disk Assignment:** A section with a 'Manual Configuration' checkbox checked. Below it is a table:

Disk	Available	Use
Internal Drive	249.5 GB	<input checked="" type="checkbox"/>
- Space Allocation:** A section with a 'Basic' label. Below it is a slider control for 'Internal Drive' set to '150 GB'.

At the bottom of the window are 'Create Pool' and 'Cancel' buttons. A copyright notice at the bottom right reads: '© Copyright 2004 SimpleTech, Inc. All rights reserved.'


6 In the confirmation dialog, click the **OK**.



To avoid losing data, do not reset or power off the SimpleShare server, or click any browser menus or buttons while the disk pool is being created.

7 On the **Create Disk Pool Result** page, click

Continue to Disk Management to view information on the new disk pool or click **Create Share** to create a share in the new pool.



CREATING A MIRROR POOL

Mirror pools are pools that use equal amounts of space on two or more disks. Mirror pools allow you to create multiple copies of important data. Each disk drive used in a mirror pool contains a copy of the same data files. The primary disk or “Base” contains the original file. Whenever a file in the Base is saved, the file is updated in the mirror.

- 1 In the **Disk Management** menu, click **Create New Pool**.
- 2 In **New Pool Name**, enter a descriptive name for mirror pool.
- 3 Selected **Mirroring**.



Auto Configuration automatically designates the drive with the least amount of available space as the Base and the drive with the greater amount of available space as the Mirror.

To configure the Mirror pool automatically, continue to [Step 4](#). To configure the pool manually, go to [Step 5 on page 69](#).

- 4 To have SimpleShare determine which drive will store the Base and which drive will store the Mirror, in **Pool Mapping Preference** select **Auto Configuration**, then do one of the following to set the capacity of the pool:
- To set the size of the Mirror equal to the amount of available space on the Base, select **Maximize Size**, then, continue to [Step 8 on page 69](#).
 - To specify the capacity of the Base and Mirror, deselect **Maximize Size** and enter the desired capacity (in gigabytes) in **Allocate**, continue to [Step 8 on page 69](#).



- 5 To configure the pool manually, select **Manual Configuration**.
- 6 In **Disk Assignment**, select the drive to store the Base pool and the drive to store the Mirror pool.
- 7 In **Space Allocation**, enter the size (in gigabytes) of the Base pool. The pool size can be set by entering the capacity in the text box or using the slider control.



When entering the size of the Base and Mirror manually, you must enter the same value for each disk.

- 8 Click **Create Pool**.

The screenshot shows the 'Create New Disk Pool' configuration window in SimpleShare. The window has a navigation bar at the top with icons for Administration, Share Management, Disk Management, Networking, Printers, and Help. The main content area is titled 'Create New Disk Pool' and contains the following sections:

- New Pool Name:** MirrorPool
- Pool Encryption:** Encrypt Pool
- Mirroring:** Number of Mirrors: 1
- Striping:** There aren't enough disks available to do 2-way mirroring plus striping.
- Pool Mapping Preference:** Auto Configuration, Maximize Size (or) Allocate [] GB
- Manual Configuration:** Manual Configuration
- Disk Assignment:** A table with columns for Disk, Available, Base, and Mirror 1.

Disk	Available	Base	Mirror 1
External Disk 1	164.2 GB	<input checked="" type="checkbox"/>	<input type="checkbox"/>
Internal Drive	249.5 GB	<input type="checkbox"/>	<input checked="" type="checkbox"/>
- Space Allocation:**
 - Base:** External Disk 1: 164.184549376 GB (with a slider control)
 - Mirror 1:** Internal Drive: 164.184549376 GB (with a slider control)

At the bottom of the window are 'Create Pool' and 'Cancel' buttons. A copyright notice at the bottom right reads: © Copyright 2004 SimpleTech, Inc. All rights reserved.

9 In the confirmation dialog, click the **OK**.



To avoid losing data, do not reset or power off the SimpleShare server, or click any browser menus or buttons while the disk pool is being created.

10 On the **Create Disk Pool Result** page, click **Continue to Disk Management** to view information on the disk pool you just created or click **Create Share** to create a share in the pool.



CREATING A STRIPED POOL

The main reason for creating a striped pool is to increase performance. Two or more disks are required to create a striped pool. Striped pools alternate (or interleave) the data accessed in the pool. They do not provide for multiple copies of data stored in a pool and do not provide for protection from loss of data should a drive fail. In fact should a single drive that is part of a striped pool fail all data in the pool is lost even though the remaining disk(s) are functional.

- 1 On the **Disk Management** menu, click **Create New Pool**.
- 2 In **New Pool Name**, enter a descriptive name for the pool.
- 3 Select **Striping**.
- 4 If three disks are connected to SimpleShare, in **Number of Stripes** enter the number of disks to be included in the striped pool.



At least two disks are required to create a striped pool. If three disks are connected to SimpleShare, the Number of Stripes field allows you to specify how many disks to include in the striped pool.



The screenshot shows the 'Create New Disk Pool' configuration window in SimpleShare. The window has a navigation bar at the top with icons for Administration, Share Management, Disk Management, Networking, Printers, and Help. The main content area is titled 'Create New Disk Pool' and contains the following fields and options:

- New Pool Name:** A text box containing 'StripePool'.
- Pool Encryption:** A checkbox labeled 'Encrypt Pool' which is unchecked.
- Mirroring:** A text box containing 'There aren't enough disks available to do 2-way striping plus mirroring'.
- Striping:** A checkbox labeled 'Number of Stripes: 1' which is checked.
- Pool Mapping Preference:** A checkbox labeled 'Auto Configuration' which is unchecked.
- Manual Configuration:** A checkbox labeled 'Maximize Size (or) Allocate' with a value of 'GB'.
- Disk Assignment:** A table with columns for 'Disk', 'Available', 'Stripe 0', and 'Stripe 1'.

Disk	Available	Stripe 0	Stripe 1
External Disk 1	164.2 GB	<input type="checkbox"/>	<input type="checkbox"/>
Internal Disk	249.5 GB	<input type="checkbox"/>	<input type="checkbox"/>
- Space Allocation:** Two sections for 'Stripe0' and 'Stripe1'. Each section has a 'Number of Stripes' field set to '1' and a 'Disk' dropdown menu. The 'Internal Disk' dropdown is selected for both stripes.
- Buttons:** 'Create Pool' and 'Cancel' buttons at the bottom.

At the bottom right of the window, there is a copyright notice: '© Copyright 2004 SimpleTech, Inc. All rights reserved.'



To configure the Mirror pool automatically, continue to **Step 4**. To configure the pool manually, go to **Step 7** on page 73.

- 5 To configure the pool parameters automatically, in **Pool Mapping Preference** select **Auto Configuration**, then do one of the following to set the capacity of the each stripe in the pool:
 - To create the largest pool possible, based on the amount of available disk space on each disk, select **Maximize Size**, then continue to **Step 7** on page 73.
 - To specify the size of stripe to be placed on each disk, deselect **Maximize Size** and enter the desired capacity (in gigabytes) in **Allocate**, then continue to **Step 7** on page 73.



Create New Disk Pool

New Pool Name:

Pool Encryption: Encrypt Pool

Mirroring: There aren't enough disks available to do 2-way striping plus mirroring.

Striping: Number of Stripes: 1

Pool Mapping Preference: Auto Configuration

Maximize Size (or) Allocate GB

Manual Configuration

Disk	Available	Stripe 0	Stripe 1
External Disk 1	164 .2 GB	<input type="checkbox"/>	<input type="checkbox"/>
Internal Disk	249 .5 GB	<input type="checkbox"/>	<input checked="" type="checkbox"/>

Space Allocation:

Stripe 0

External Disk 1: GB

Internal Disk: GB


Stripe 1

External Disk: GB

Internal Disk: GB

© Copyright 2004 SimpleTech, Inc. All rights reserved.

- 6 To configure the pool parameters manually, in **Pool Mapping Preference** select **Manual Configuration**, then do one of the following to set the capacity of the each stripe in the pool:
 - In **Disk Assignment**, select the disk to contain Stripe 0, Stripe 1 and Stripe 3 (if three drives are connected to SimpleShare).
 - In **Space Allocation**, enter the size (in gigabytes) of the stripe to be created on each disk. The stripe size can be set by entering the capacity in the text box or using the slider control.
- 7 Click **Create Pool**.



8 In the confirmation dialog, click **OK**.



To avoid losing data, do not reset or power off the SimpleShare server, or click any browser menus or buttons while the disk pool is being created.



If SimpleShare displays a pop-up indicating that all columns should add up to the same disk space, space allocation for each disk is not set properly. Make sure only a single checkbox in each Stripe n column is selected and that the total space allocated for all disks in a stripe is the same for each stripe.

9 On the **Create Disk Pool Result** page, click **Continue to Disk Management** to view information on the new disk pool or click **Create Share** to create a share in the pool.



DELETING (WIPING) A POOL



Before you can delete a disk pool you must remove all shares residing within the pool (Deleting a Share). Erasing a disk pool destroys all data saved to the pool. We recommend that you back up your data before proceeding.

- 1 In the **Disk Management** menu, click **Basic**.
- 2 In **Disk Pool Mappings**, click the **Delete** button to the right of the pool you want to delete.

Disk Management - Basic

Disk Graph:

Disk	Free Space	Used Space
External Disk 1	100.0 GB	64.7 GB
Internal Disk	100.0 GB	150.1 GB

Disk Pool Mappings:

Pool	Type	Status	Logical Size	Space Used	Physical Size	External Disk 1	Internal Disk	Actions
StripePool	Striped	Good	200.0 GB	0.034 GB	200.0 GB	100.0 GB	100.0 GB	Delete
Unallocated					214.8 GB	64.7 GB	150.1 GB	Unmount Pool
Total			200.0 GB	0.034 GB	414.8 GB	164.7 GB	250.1 GB	

Create New Disk Pools:

Rename Disk Pools:



Show Disk Details

© Copyright 2004 SimpleTech, Inc. All rights reserved.

- 3 In the confirmation dialog, click **OK**.
- 4 Click **Quick Erase** or **Full Erase**, depending on the type of erase process you want to perform.



Quick Erase erases data from the disk pool. However, data can be recovered using special data recovery utilities. Full Erase overwrites the entire disk pool with random data, making data recovery impossible.




RENAMING A POOL

- 1 In the **Disk Management** menu click **Basic**.
- 1 Click **Rename Pool**.



The Rename Pool button is located at the bottom of the Disk Management page. It may be necessary to use the scroll bar to see the button.

- 2 Select the pool to be renamed from the **Old Pool Name** list.
- 3 Enter the new descriptive name in **New Pool Name**.
- 4 Click **Rename Pool**.
- 5 In the confirmation dialog, click **OK**.



RESIZING A POOL




SimpleTech recommends that you backup all your data before resizing pools. Loss of power or other failures during the resize operation could result in data loss. You must also delete all shares on disk pools to be resized.

- 1 In the **Disk Management** menu, click **Resize Pool**.
- 2 From the **Pool Name** list, choose the disk pool you want to resize.
- 3 In **Space Allocation**, enter the desired size (in gigabytes) of the pool being resized. The pool size can be set by entering the capacity in the text box or using the slider control.



Pools cannot be reduced in capacity to a size less than the storage space consumed by the shares currently in the pool.

- 4 Click **Resize Pool**.



5 In the confirmation dialog, click the **OK**.



To avoid losing data, do not reset or power off the SimpleShare server, or click any browser menus or buttons while the disk pool is being created.

6 On the **Resize Pool Result** page, click **Continue**.




ADDING A MIRROR TO AN EXISTING POOL

- 1 In the **Disk Management** menu, click **Add Mirrors/Spares**.
- 2 From the **Pool Name** list, choose the pool you want to mirror.
- 3 In **Number of Additional Mirrors**, enter the number of mirrors to be created.



Pools can only be mirror to a separate physical disk. Therefore, the number of mirrors you can create of a pool depends on the number of disks connected to SimpleShare.

- 4 In **Disk Assignment**, select the checkbox for the drive(s) on which the mirror will be stored. The number of disks you select must equal the number of pools specified in **Number of Additional Mirrors** (see [Step 3](#), above).
- 5 Click **Add Mirrors/Spares**.



The screenshot shows the 'Add Mirrors / Spares' configuration window in the SimpleShare interface. The window has a navigation bar at the top with icons for Administration, Share Management, Disk Management, Networking, Pools, and Help. The main content area includes the following fields and controls:

- Pool Name:** A dropdown menu currently set to 'SimplePool'.
- Mirroring:** A section containing two spinners: 'Number of Additional Mirrors:' (set to 1) and 'Number of Additional Spares:' (set to 0).
- Disk Assignment:** A text label stating 'You can add 1 mirrors/spares each of size 150 GB'.
- Space Allocation:** A section with two buttons: 'Add Mirrors/Spares' and 'Cancel'.

At the bottom of the window, there is a copyright notice: '© Copyright 2004 SimpleTech, Inc. All rights reserved.'

6 In the confirmation dialog, click **OK**.



To avoid losing data, do not reset or power off the SimpleShare server, or click any browser menus or buttons while the disk pool is being created.

7 On the Add Mirrors/Spares Result page, click **Continue**.



- 8 In the **Administration** menu, click **Basic**.
- 9 Click **Reboot** to restart SimpleShare and apply your changes.
- 1 In the **Disk Management** menu, click **Basic** to check the rebuild status of the new mirror pool.



To add a mirror to an existing pool, SimpleShare must rebuild the disk array, which takes an extensive amount of time. For example, adding a 150 GB mirror may take approximately 4 hour to create.

The screenshot shows the 'Disk Management - Basic' interface. At the top, there are navigation icons for Administration, Share Management, Disk Management, Networking, Printers, and Help. Below the navigation bar is the SimpleTech logo and the SimpleShare logo. The main content area features a 'Disk Graphic' showing two stacked bar charts. The left chart represents 'External Disk 1' (164.7 GB, Unknown status) with a blue base of 150.0 GB and a red top of 14.7 GB. The right chart represents 'Internal Disk' (250.1 GB, Good status) with a blue base of 150.0 GB and a red top of 100.1 GB. Below the graphic is a table titled 'Disk Pool Mappings:' with columns for Pool, Type, Status, Logical Size, Space Used, Physical Size, External Disk 1, and Internal Disk. The table shows a 'SimplePool Mirrored' entry with a status of 'Rebuilding (0% Complete, 4 Hours, 27 Minutes, 50 Seconds Left)' and a 'Delete' button. Below the table are buttons for 'Create New Pool', 'Rename Pool', and 'Show Disk Details'. At the bottom right, there is a copyright notice: '© Copyright 2004 SimpleTech, Inc. All rights reserved.'

Pool	Type	Status	Logical Size	Space Used	Physical Size	External Disk 1	Internal Disk
SimplePool	Mirrored	Rebuilding (0% Complete, 4 Hours, 27 Minutes, 50 Seconds Left)	150.0 GB	0.034 GB	300.0 GB	150.0 GB	150.0 GB
	Unallocated				114.8 GB	14.7 GB	100.1 GB
Total			150.0 GB	0.034 GB	414.8 GB	164.7 GB	250.1 GB

REMOVING A MIRROR OR SPARE

- 1 In the **Disk Management** menu, click **Remove Mirrors/Spares**.
- 2 From the **Pool Name** list, choose the pool you want to modify.
- 3 In **Available Mirrors/Spares**, select the mirror(s) or spare(s) to be removed from the mirror pool.




Make sure the checkboxes for disks that are to remain part of the mirror pool are not selected. For example, to remove all mirrors and keep the Base pool, select all existing mirrors except the Base.



Available Mirrors/Spares list the mirrors/spares associated with the mirror pool. The Base represents the original pool from which the mirror was created. Mirror1, Mirror2 and so forth represent the copies (or mirrors) created from the original (Base) pool.

- 4 Click **Remove Mirrors**.



- 5 On the Remove Mirrors/Spares Result page, click **Continue** .



CREATING AN ENCRYPTED POOL

Encrypted pools provide security for the data stored in the pool. Encrypted pools must be remounted whenever SimpleShare is rebooted, powered off or reset to factory defaults. Instructions for mounting an encrypted pool are provided in “Mounting Encrypted Pools” on page 92.

- 1 In the **Disk Management** menu, click **Create New Pool**.
- 2 In **New Pool Name**, enter a descriptive name for the encrypted pool.
- 3 Select **Encrypt Pool**.
- 4 In **Encryption Password**, enter the password to be used to encrypt data in the pool. In **Confirm Password**, re-enter the password to verify it was entered correctly.



Passwords should be at least eight characters long and may contain any combination of alphanumeric characters (A-Z and 1-9) and special characters such as &, \$, and >. Spaces are not allowed.

- 5 To allocate all available disk space on SimpleShare to the new pool, in **Pool Mapping Preference**, select **Auto Configuration**, then continue to [Step 7 on page 86](#).



Selecting Auto Configuration automatically selects the Maximum Size checkbox.

6 To set the capacity of the new pool manually, complete the following steps:

- In **Pool Mapping Preference**, select **Manual Configuration**.
- In **Disk Assignment**, select the **Use** checkbox for each disk being used to create the pool.



Disk Assignment allows you to specify which disk drives are to be used by the pool being created. To create a pool that only occupies a portion of a single disk, make sure to only select the Use checkbox for the drive you want to use.

- In **Space Allocation**, enter the size (in gigabytes) of the pool. The pool size can be set using the text box or the slider control.



If multiple disks are connected to SimpleShare, by default the Space Allocation selects all available drives. This results in all available space on each drive being allocated to the new pool being created. To remove disks from the pool being created the Manual checkbox must be selected and the Use checkbox for the drives that are not to be included in the pool must be deselected.

7 Click **Create Pool**.



The screenshot shows the 'Create New Disk Pool' configuration window in SimpleShare. The window has a navigation bar at the top with icons for Administration, Share Management, Disk Management, Networking, Printers, and Help. The main content area is titled 'Create New Disk Pool' and contains the following fields and options:

- New Pool Name:** EncryptedPool
- Pool Encryption:** Encrypt Pool
- Encryption Password:** [masked]
- Confirm Password:** [masked]
- Mirroring:** There aren't enough disks available for mirroring.
- Striping:** There aren't enough disks available for striping.
- Pool Mapping Preference:** Auto Configuration Maximize Size Manual Configuration
- Disk Assignment:** A table with columns 'Disk', 'Available', and 'Use'. The 'Internal Disk' row shows '249.5 GB' and the 'Use' checkbox is checked.
- Space Allocation:** A slider control for 'Internal Disk' set to '150 GB'.

At the bottom of the window are 'Create Pool' and 'Cancel' buttons. A copyright notice at the bottom right reads: '© Copyright 2004 SimpleTech, Inc. All rights reserved.'

8 In the confirmation dialog, click **OK**.



To avoid losing data, do not reset or power off the SimpleShare server, or click any browser menus or buttons while the disk pool is being created.

9 On the **Create Disk Pool Result** page, click **Continue to Disk Management** to view information on the new disk pool or click **Create Share** to create a share in the pool.



CHANGING THE ENCRYPTION PASSWORD

- 1 In the **Disk Management** menu, click **Basic**.
- 2 In **Disk Pool Mappings**, click the **Change Encryption** button next to the pool whose encryption password you want to change.

Disk Management - Basic

Disk Graph:

Internal Disk 250.1GB Good

Disk Pool Mappings:

Pool	Type	Status	Logical Size	Space Used	Physical Size	Internal Disk	
EncryptedPool	Raw	Good	150.0 GB	0.034 GB	150.0 GB	150.0 GB	Change Encryption
Unallocated					100.1 GB	100.1 GB	Delete
Total			150.0 GB	0.034 GB	250.1 GB	250.1 GB	

Create New Disk Pools:

Rename Disk Pools:

Show Disk Details

© Copyright 2004 SimpleTech, Inc. All rights reserved.

- 3 From the **Encrypted Pool Name** list, choose the pool whose encryption password you want to change.
- 4 In **Encrypt Pool**, select **Enable Pool Encryption**.
- 5 In **New Password**, enter the new encryption password. In **Confirm Password**, re-enter the password to verify it was entered correctly.



Passwords should be at least eight characters long and may contain any combination of alphanumeric characters (A-Z and 1-9) and special characters such as &, \$, and >. Spaces are not allowed.

- 6 Click **Change Encryption**.



If you did not select the Enable Pool Encryption the status for the pool, as reported in the Disk Management - Basic page will become “Decrypting” until the data stored in the pool has been converted into un-encrypted data fully. If you left the Enable Pool Encryption checkbox selected and changed the password the status for the pool, as reflect in the Disk Management - Basic page will become “Re-encrypting” until the data is completely re-encrypted using the newly supplied encryption key.




DISABLING POOL ENCRYPTION

- 1 In the **Disk Management** menu, click **Basic**.
- 2 In **Disk Pool Mappings**, click the **Change Encryption** button next to the pool whose encryption password you want to change.

Disk Management - Basic

Disk Graph:

Internal Disk 256.1GB Good

Disk Pool Mappings:

Pool	Type	Status	Logical Size	Space Used	Physical Size	Internal Disk	
EncryptedPool	Raw	Good	150.0 GB	0.034 GB	150.0 GB	150.0 GB	Change Encryption
Unallocated					100.1 GB	100.1 GB	Delete
Total			150.0 GB	0.034 GB	250.1 GB	250.1 GB	

Create New Disk Pools:

Rename Disk Pools:

Show Disk Details

© Copyright 2004 SimpleTech, Inc. All rights reserved.

- 3 From the **Encrypted Pool Name** list, choose the pool you want to modify.
- 4 In **Encrypt Pool**, make sure **Enable Pool Encryption** is selected.
- 5 In **New Password**, delete the encryption password, making sure the text box is empty. In **Confirm Password**, delete the encryption password, making sure the text box is empty.
- 6 Click **Change Encryption** .



MOUNTING ENCRYPTED POOLS

The password(s) for any encrypted pools must be re-entered after resetting, rebooting or power cycling SimpleShare. If the passwords are not re-entered after one of these events the pools and any shares within the pools will not be visible over the network.

- 1 In the **Disk Management** menu, click **Basic**.



The **Status** column under the Disk Pool Mappings controls shows “Unavailable” for any encrypted pool that has not been unlocked by entering the encryption password as described below.

- 2 In **Disk Pool Mappings**, click the **Enter Encryption Password** button next to the encrypted pool you want to mount.

Disk Management - Basic

Disk Graph

External Disk 1: 164.7 GB Unbalanced
Internal Disk: 249.5 GB Good

EncryptedPool Unavailable
Unallocated

Pool	Type	Status	Logical Size	Space Used	Physical Size	External Disk	Internal Disk
EncryptedPool	Raw	Unavailable	249.5 GB	0.0 GB	249.5 GB	249.5 GB	0.512 GB
Unallocated					165.2 GB	164.7 GB	
Total			249.5 GB	0.0 GB	414.8 GB	164.7 GB	250.1 GB

Create New Disk Pools:

Rename Disk Pools:

Show Disk Details

© Copyright 2004 SimpleTech, Inc. All rights reserved.

- 3 In **Encrypted Pool Names**, enter the password for the encrypted pool.
- 4 Click **Mount Pools**.



If an incorrect password was supplied SimpleShare will provide a notification that it was unable to mount the pools and list which pools had an incorrect password supplied. If multiple encrypted pools were listed in the Encrypted Pool Names controls only those that had passwords will be listed in the error notification. Encrypted pools that valid passwords were supplied for will be unlocked. SimpleShare will return to the Encrypted Pool Authentication page with the Encrypted Pool Names controls updated to reflect those pools that remain locked, i.e., had incorrect passwords supplied.

- 5 In the confirmation dialog, click **OK**.



NETWORK MANAGEMENT

DHCP CLIENT NETWORK SETUP

DHCP client is the default IP addressing protocol set on SimpleShare. In this mode, SimpleShare receives its IP address and subnet mask, along with other networking configuration information, from the DHCP server on the network. Since most home gateways and routers use the DHCP protocol to assign IP addresses to the computers and other devices on the network, this is the easiest way to manage IP addressing.

- 1 Click the **Networking** menu.
- 2 From the **LAN Protocol** list, choose **DHCP Client**.
- 3 To enable SimpleShare auto configuration, select **Enabled** from the **LAN IP Autoconfiguration** list.



LAN IP Autoconfiguration makes it possible for SimpleShare to configure itself on your IP network automatically, when a DHCP server is not available. Autoconfiguration provides “zero configuration” for SimpleShare by automatically discovering devices on the network and assigning an IP address to SimpleShare without user intervention.

- 4 Click **Apply**.



SimpleTech SimpleShare

LAN

This page allows you to see and set various networking parameters.

LAN Link: Connected

LAN MAC Address: 00:01:5C:3D:92:0E
 LAN Protocol: DHCP Client
 LAN IP Autoconfiguration: Enabled
 LAN IP Address:
 LAN Subnet Mask:
 LAN Default Gateway:
 LAN Domain Name:
 LAN DNS Servers:
 LAN WINS Servers:

DHCP lease info for Client: DHCP Server lease Obtained, Lease Expires

Apply Cancel

© Copyright 2004 SimpleTech, Inc. All rights reserved.

DHCP SERVER NETWORK SETUP

The DHCP Server IP addressing option allows you to configure SimpleShare as the DHCP server on the network. In this mode, computers and other network devices are automatically provided IP addresses and other network configuration information by SimpleShare. Configuring SimpleShare as the network DHCP server may make it necessary to set some network and DHCP parameters, manually.



Only choose the DHCP Server option if you are an experienced network administrator. Do not configure SimpleShare as a DHCP server if there is another DHCP server on the network.



Dynamic Host Configuration Protocol (DHCP) is a TCP/IP service protocol that offers dynamic leased configuration of host IP addresses and distributes other configuration parameters to eligible network clients. DHCP provides safe, reliable, and simple TCP/IP network configuration, prevents address conflicts, and helps conserve the use of client IP addresses on the network. DHCP uses a client/server model where the DHCP server maintains centralized management of IP addresses that are used on the network. DHCP-enabled clients can then request and obtain lease of an IP address from a DHCP server as part of their network boot process.

Unless specifically specified, SimpleShare Administrator sets the following default network parameter values:

Network Parameter	IP Address
LAN Subnet Mask:	255.255.255.0
LAN Default Gateway	0.0.0.0
LAN DHCP Starting IP Address	xxx.xxx.xxx.100
LAN DHCP Ending IP Address	xxx.xxx.xxx.150
LAN Lease Time	86400 seconds (24 hours)

NOTE: xxx.xxx.xxx specifies the network segment (subnet) on which SimpleShare server resides.

- 1 Click the **Networking** menu.
- 2 Select **DHCP Server** from the **LAN Protocol** list.
- 3 In **LAN IP Address**, enter a static IP address for SimpleShare. Make sure the IP address you specify is on the same LAN segment as the computer running SimpleShare Administrator.
- 4 Set the following IP addresses, as necessary, to configure SimpleShare on your local network:
 - LAN Domain Name
 - LAN DNS Servers (preferred server and up to two alternates)
 - LAN WINS Servers (preferred server and up to two alternates)
- 5 Click **Apply**.
- 6 On **Apply** screen, click **Continue**.



LAN
This page allows you to see and set various networking parameters

LAN Link: Connected

LAN MAC Address: 00:01:5C:30:92:0E
LAN Protocol: DHCP Server

LAN IP Autoconfiguration: Enabled

LAN IP Address: 100.231.55.1

LAN Subnet Mask: 255.255.255.0

LAN Default Gateway: 100.231.55.1

LAN Domain Name: mydomain.com

LAN DNS Servers:

LAN WINS Servers: 172.16.0.101

LAN DHCP Starting IP Address: 100.231.55.100
LAN DHCP Ending IP Address: 100.231.55.150
LAN Lease Time (seconds): 86400

Active DHCP Leases:

Hostname	MAC Address	IP Address	Expires In
----------	-------------	------------	------------

Apply Cancel

© Copyright 2004 SimpleTech, Inc. All rights reserved.

STATIC IP NETWORK SETUP

The Static LAN protocol option allows you to assign a fixed IP address to SimpleShare. Choosing this option provides considerable flexibility, however, keep in mind that every computer on the network connecting to SimpleShare must also have been configured with a static (fixed) IP address. To set the IP address for SimpleShare statically, complete the following steps:

- 1 Click the **Networking** menu.
- 2 From the **LAN Protocol** list, choose **Static**.
- 3 From the **LAN IP Autoconfiguration** list, choose **Disabled**.
- 4 Set the following IP network addresses, as necessary, to configure SimpleShare on your local network:
 - LAN IP Address
 - LAN Subnet Mask
 - LAN Default Gateway
 - LAN Domain Name
 - LAN DNS Servers (primary server and two alternates)
 - LAN WINS Servers (primary server and two alternates)
- 5 Click **Apply**.
- 6 On the **Apply** screen, click **Continue**.



PRINTER MANAGEMENT


To set up network a USB, you must enable first enable print server services on SimpleShare, and then install the printer driver on each networked computer accessing the printer through SimpleShare.

ENABLING THE PRINT SERVER

- 1 Make sure your USB printer is connected to SimpleShare and powered On. For instructions on installing a printer, see “Connecting a USB Printer” on page 10.
- 2 Click the **Printers** menu.
The Printers page displays the name, manufacturer, model and serial number (if available) of the printer connected to SimpleShare.
- 3 From the **Printer Pool Name** list, choose the disk pool that will store your printer files.
- 4 Click .




- 5 In the confirmation dialog, click **OK**.
- 6 In the **Administration** menu, click **Basic**.
- 7 Click **Reboot** to restart SimpleShare and apply your changes.



DISABLING THE PRINT SERVER

- 1 Click the **Printers** menu.
- 2 Select **No Printer Pool** from the **Printer Pool Name** list.
- 3 Click **Apply**.



- 4 In the warning dialog, click **OK**.




- 5 In the confirmation dialog, click **OK**.




INSTALLING PRINTER DRIVERS ON WINDOWS COMPUTERS

- 1 In the Address line of your browser, enter \\<SimpleShare name> to open the SimpleShare root directory (where <SimpleShare name> is the network name of your SimpleShare server).
- 2 Right-click on the printer icon, and then click **Connect** to start the Add Printer Wizard.



- If you are running Windows XP, the **Connect to Printer** dialog appears. Click **OK** to start the Add Printer Wizard.



- Select the manufacturer and model of your printer from those listed or if you have the printer installation disk, click **Have Disk** and follow the onscreen instructions.
- Click **OK**.



SPECIFICATIONS

Network Standards	IEEE 802.3 100 BASE-TX; IEEE 802.3u 10 BASE-T (RJ-45 network interface)
File System Support	NFS, SMB/CIFS
USB Standards	USB 2.0/1.1 (two USB A host connectors for external USB disk drives and printers)
Internal Storage	1 IDE disk drive, conforming to ATA-6 up to 133MB/s; 160 and 250 Gigabyte disk sizes available (depending on model)
Operating Temperature	41° to 95° F (5° to 35° C)
Humidity (relative)	20 to 80%, non-condensing
Power	External Power Adapter: 100/240V, 50/60Hz AC input; 12V DC, 3A output
Power Consumption	36W (maximum)
Dimensions	Length: 8.06 in (204.72 mm)Width: 1.62 in (41.15 mm)Height: 5.13 in (130.3 mm)
Weight	2.75 lbs (1.03 kg)

PRODUCT SUPPORT

SIMPLETECH TECHNICAL SUPPORT

The SimpleTech Technical Support center provides customer support Monday through Friday from 6:30 am until 5:30 pm Pacific Standard Time, for the duration of the warranty period on this product. Customers can contact SimpleTech Technical Support through our Web site, by email or by phone.

Technical Support Phone Line: 1-800-945-3444 or 949-476-1180

Technical Support Email Address: support@simpletech.com

Online Chat with Technical Support: www.simpletech.com/support

When contacting SimpleTech for technical assistance, please be prepared to provide the name, model, serial number and software version of your SimpleShare.

WORLDWIDE HEADQUARTERS

SimpleTech, Inc.
3001 Daimler Street
Santa Ana, California 92705 USA
Tel. (949) 476-1180
Fax: (949) 476-1209
Web: www.simpletech.com

CERTIFICATION AND WARRANTY

FCC COMPLIANCE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the affected device and the computer equipment.
- Connect the computer and its peripherals into a different branch circuit from that to which the affected device is connected.
- If necessary, consult the dealer or an experienced radio/television technician for additional suggestions.

LIMITED WARRANTY

SimpleTech Inc. SimpleShare home office servers (Product) are warranted against defects in material and workmanship, and will operated in substantial conformance with their respective specifications under normal use and service for a period of TBD (TBD) years from the date of shipment. SimpleShare software (firmware and utilities) is warranted against media defects for a period of ninety (90) days from the date of shipment. Subject to the conditions and limitations set forth below, SimpleTech will, at its own option, either repair or replace any defective SimpleShare product that proves to be defective by reasons of improper workmanship or materials, if Buyer notifies SimpleTech of such failure within the stated warranty period. Products repaired or replaced during the applicable warranty period shall be covered by the foregoing warranties for the remainder of the original warranty period or ninety days (90) from the date of reshipment, whichever is longer. Parts used to repair Product or replacement Product may be provided by SimpleTech on an exchange basis, and will be either new or refurbished to be functionally equivalent to new.

SIMPLETECH DISCLAIMS ALL OTHER WARRANTIES, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WITH RESPECT TO ITS PRODUCTS AND ANY ACCOMPANYING WRITTEN MATERIALS. FURTHER, SIMPLETECH DOES NOT WARRANT THAT SOFTWARE WILL BE FREE FROM DEFECTS OR THAT ITS USE WILL BE UNINTERRUPTED OR REGARDING THE USE, OR THE RESULTS OF THE USE OF THE SOFTWARE IN TERMS OF CORRECTNESS, ACCURACY, RELIABILITY OR OTHERWISE.

MODIFICATIONS

Any changes or modifications made to this device that are not expressly approved by SimpleTech, void the user's warranty. All wiring external to the product should follow the provisions of the current edition of the National Electrical Code.

GPL STATEMENT

Portions of this product, in part, use GPL/LGPL software. Please see the GNU license document on the NASFinder Quick Setup CD for information concerning the terms of the license. To obtain a copy of our open source software, please send a message to SimpleTech Technical Support at support@simpletech.com.