

MANUAL
Simrad
AP26 and AP27
Autopilots



[20221586]



[AB]

SIMRAD
A KONGSBERG Company

MAXIMIZING YOUR PERFORMANCE AT SEA

This page is intentionally left blank

Instruction Manual

This manual is intended as a reference guide for operating and correctly installing the AP26 and AP27 autopilots.

Great care has been paid to simplify operation and set-up of the autopilots, however, an autopilot is a complex electronic system. It is affected by sea conditions, speed of the vessel, hull shape and size.

Please take time to read this manual to get a thorough understanding of the operation and system components and their relationship to a complete autopilot system.

Other documentation material that is included in this manual is a warranty card. This must be filled out by the authorized dealer that performed the installation and mailed in to activate the warranty.

Document revisions

Rev	Date	Written by	Checked by	Approved by
A	18.03.04	NG	ThH	ThH
B	27.04.04	<i>NG</i>		<i>Th. H.</i>

Document history

Rev. A First edition.

Rev. B FU50 substituted by FU25. Part no. for AC40 Power PCB ass'y, page 124 corrected. Added notes in chapter 3.19. Minor corrections in text and display pictures.

Contents

1	System description	9
1.1	General	9
1.2	How to use this manual	9
1.3	System components	10
1.4	AP26 Control Unit	11
1.5	AP27 Control Unit	11
1.6	Autopilot Computer	11
1.7	RF300 Rudder Feedback unit	12
1.8	Heading Sensors	12
	RC36 Rate compass	12
	RFC35 Electronic Fluxgate Compass (optional)	12
	NMEA compass (optional)	13
	Simrad RGC10 and RGC50 gyrocompasses	13
1.9	Optional equipment	14
	R3000X Remote Control	14
	JS10 Joystick	14
	FU25 Follow-Up Steering Lever	14
	Multiple stations	14
2	Operation	15
2.1	Overview	15
2.2	ON/OFF - Standby mode	17
	Flashing course knob icon	18
	Alarms	18
2.3	AP26 and AP27 with MSD50 Stern Drive unit	18
	Zero point setting	18
2.4	Follow-Up steering (FU)	19
2.5	Non-Follow-Up steering (NFU)	20
2.6	R3000X Remote Control (NFU)	21

2.7	JS10 Joystick (NFU)	21
2.8	Automatic Steering	22
	Heading catch.....	22
2.9	Automatic control of steering parameters.....	23
	Power boat.....	23
	Sailboat.....	24
2.10	Manual Parameter Selection	24
2.11	U-Turn.....	25
2.12	Dodge in AUTO.....	26
2.13	Tacking in Auto mode	27
2.14	Navigating with the AP26 and AP27.....	27
	Setting the waypoint arrival circle	30
2.15	Dodge in NAV	31
2.16	Selecting a different Navigation source.....	31
2.17	Wind vane steering.....	32
2.18	Tacking and gybing in Wind mode.....	33
	Gybing.....	34
	Tack and gybe prevent.....	34
2.19	Wind steering and navigation	35
	Operating in WIND _{NAV} mode.....	37
	RACING	37
2.20	Multiple station system	38
2.21	Lock function	38
2.22	User Set-up Menu	39
	Alternating Course Knob Icon	39
	STANDBY Mode	39
	AUTO Mode	44
	NAV Mode.....	45
	WIND Mode	45
2.23	INFO menu	46
	Course knob icon	48

INFO menu flowchart	49
Alternative mode screens in STBY, AUTO and NAV	50
INFO menu and Main screen, active unit	50
INFO menu and Main Screen, inactive unit	50
3 Installation	51
3.1 General	51
3.2 Installation checklist	51
3.3 Unpacking and handling	52
3.4 Determine system configuration	52
3.5 Autopilot System Layout	53
3.6 RF300 Rudder feedback installation.....	53
3.7 Autopilot computer installation	55
3.8 Cable connections	55
3.9 Grounding and RFI	56
3.10 Drive unit installation.....	58
Connecting a reversible pump	60
Connecting a hydraulic linear drive.....	61
Connecting a solenoid valve	61
3.11 Control unit installation	62
Panel mounting of AP26.....	62
Alternative panel mounting of AP26	62
Optional bracket mounting	63
3.12 ROBNET2 network cables	63
AP27 connection.....	65
3.13 RC36 Rate Compass installation	65
3.14 RFC35 Fluxgate Compass installation	67
3.15 R3000X Remote Control installation	68
3.16 JS10 Joystick.....	68
3.17 S35 NFU Lever installation	68
3.18 Interfacing	69
3.19 SimNet.....	69

SimNet network cables	70
SimNet power and termination	70
3.20 Single NMEA input/output	75
3.21 Double NMEA input/output	75
3.22 NMEA output on Port 2	76
3.23 NMEA Compass input	76
3.24 Radar Clock/Data	77
3.25 IS15 Instrument installation	77
3.26 External Alarm	79
3.27 LF3000 Linear Feedback	79
4 Configuration and setup	83
4.1 First time turn on	83
4.2 Description of Installation Settings	84
4.3 Installation Menu	85
Language selection	87
4.4 Dockside settings	87
Boat type	88
Drive unit voltage	88
Rudder Feedback Calibration	89
Rudder Test	90
Drive engage	91
Rudder Deadband	92
Wind setup	92
Minimum wind angle (NORMAL)	93
Minimum wind angle (RACING)	93
Tack angle (RACING)	93
Tack time (RACING)	94
Wind shift alarm limit (RACING)	94
4.5 Interface Settings	95
4.6 Display units	95
4.7 Sea Trial	96

Set Rudder zero	97
Minimum rudder	97
Compass calibration	98
Compass Offset	100
Wind Offset	101
Wind damping	101
Depth Offset	102
Automatic tuning	102
Transition Speed	103
Init NAV	104
4.8 Parameters	104
Manual parameter adjust	105
Recall Autotuned?	107
4.9 Service Menu	107
System Data Menu	108
SimNet and NMEA Data Screen	108
NMEA Port test (AC hardware)	110
SimNet setup	110
Master Reset	112
Final sea trial	112
Providing user training	113
5 Maintenance	115
5.1 Control unit	115
5.2 Autopilot Computer	115
5.3 Rudder Feedback	115
5.4 Compass	115
5.5 Drive unit	115
5.6 Exchange of software programme	116
Autopilot Computer	116
Autopilot Control Unit	117

6	Trouble shooting	118
6.1	Alarms	118
7	Spare Parts List.....	123
8	Technical Specifications	126
8.1	AP26 and AP27 Autopilot System	126
8.2	AP26 Control Unit	127
8.3	AP27 Control Unit	129
8.4	Autopilot Computers.....	130
8.5	RC36 Rate compass	132
8.6	RFC35 Fluxgate compass	133
8.7	RF300 Rudder Feedback.....	133
8.8	R3000X Remote Control	135
8.9	JS10 Joystick.....	135
8.10	FU25 Steering Lever.....	136
8.11	IS15 Rudder	137
8.12	SimNet.....	138
8.13	IP protection.....	139
8.14	NMEA and SimNet messages.....	140
9	Glossary	144
10	Index.....	147

SALES AND SERVICE WORLDWIDE

TERMS OF WARRANTY

WARRANTY CARD

1 SYSTEM DESCRIPTION

1.1 General

Congratulations on the purchase of your new Simrad autopilot system and thank you for selecting what we feel is the most advanced autopilot system available on the market today.

Today, Simrad manufactures a complete range of autopilots for all types of vessels, from recreational boats to merchant marine vessels. Our factory for these products, Simrad Egersund AS, is located in Egersund on the southwest coast of Norway. The company's involvement in autopilots began in 1953 with equipment for the North Sea fishing fleet under the brand name Robertson. Professional mariners around the world acknowledge that the Robertson and Simrad brand names are synonymous with the absolute best in autopilot technology.

The Simrad AP26 and AP27 autopilots represents yet another step forward in autopilot technology with the intent of providing leisure boats between 30 and 80 foot with a host of new features. The system can be expanded and enhanced with a selection of options and accessories.

The brain in the autopilot system is the single "intelligent" autopilot computer that communicates on the Robnet2 network. The Robnet2 has been developed to establish a reliable digital communication and power distribution network between the units in the autopilot system.

In the AP26 and AP27 autopilots Simrad introduces the new SimNet data and control network. SimNet provides high speed data transfer and control between Simrad products that are integrated as a total steering and navigation system onboard.

1.2 How to use this manual

This manual is intended as a reference guide for operating, installing and maintaining the Simrad AP26 and AP27 autopilots. Great care has been paid to simplify operation and set-up.

Please take time to read this manual to get a thorough understanding of the operation and system components and their relationship to a complete autopilot system.

Other documentation material that is provided with your system includes a warranty card. This must be filled out by the authorized dealer that performed the installation and mailed in to activate the warranty.

1.3 System components

A basic autopilot system consists of the following units (refer to Figure 1-1):

- AP26 Control Unit or AP27 Control Unit with accessories
- Autopilot Computer
- Rate compass
- Rudder Feedback Unit with transmission link
- Drive unit

The basic system can be expanded with multiple fixed and hand held full function control units, hand held remote and steering lever.




Figure 1-1 AP26 Basic system




Figure 1-2 AP27 Basic System

1.4 AP26 Control Unit

A compact autopilot control for panel, bulkhead or bracket mounting. It has a multifunction LCD display for readout of autopilot data, mode keys and a rotary course knob. It has two Robnet2 connectors for system interconnection and expansion and two SimNet connectors for control and data sharing with other Simrad products. A NMEA2000 Adapter Cable is available for interface through a SimNet port (page 125).

1.5 AP27 Control Unit

A portable control unit with 7 m (20 ft.) of cable. It has the same autopilot functions as AP26 and can be used as a hand held autopilot or be mounted in a fixed, bracket mount.

1.6 Autopilot Computer

The autopilot computer is the heart in the autopilot system. It contains the steering computer, interface to other system components, NMEA 0183 interface and drive electronics for the drive unit motor and clutch. Three models, AC10, AC20 and AC40 are available.

Autopilot computer comparison chart:

	AC10	AC20 (AC40)
Supply voltage	10-28 V	10-40 V
Motor current (continuous/peak)	6/10 A	10/20A (20/40A)
Clutch/bypass current	1,5 A*	1,5 A*
Number of control units	2	7
NMEA 0183 ports (input/output)	1	2
Solenoid output	x	x
Input for NFU control	x	x
External alarm		x
Radar clock/data interface		x
Input for NMEA compass		x

* 3A on later models.

1.7 RF300 Rudder Feedback unit

Rudder feedback unit with transmission link and 10 m (30 feet) of cable. Transforms the angular travel of the rudder to a digital signal read by the autopilot steering computer.

1.8 Heading Sensors

The AP26 and AP27 autopilots can be used with the following combinations of heading sensors:

RC36 Rate compass

Fluxgate compass with integrated rate sensor. Provides a dramatic improvement to the dynamic performance of both the autopilot and a stabilized radar display.

RC36 comes as standard with the autopilot.

RFC35 Electronic Fluxgate Compass (optional)

A compact heading sensor from Simrad with 15 m (45 feet) of cable. The direction of the earth's magnetic field is sensed by a

floating ring core in a fluxgate coil and transformed to a digital signal read by the autopilot steering computer.

RFC35 can operate as a low cost back-up compass for the AP26 and AP27 autopilots.

NMEA compass (optional)

A well performing compass that outputs NMEA 0183 HDT or HDG messages at 10 Hz can be connected directly to the AC20 or AC40 autopilot computer.

It is absolutely necessary for the autopilot that the heading rate is minimum 10 Hz.

Simrad RGC10 and RGC50 gyrocompasses

The optional GI51 unit is needed to interface these two gyrocompass models. Ask your Simrad dealer for information.

1.9 Optional equipment

A series of optional equipment are available for the basic AP26 and AP27 systems.

R3000X Remote Control

A small handheld remote control with two push buttons for power steering or course selection (port and starboard), and one push button with built-in lighted indicator for limited mode change.

JS10 Joystick

The JS10 Joystick is a Non-Follow-Up steering lever designed for indoor and outdoor console mount. It has a spring-loaded return-to-mid-position feature and is equipped with 10 m (33') of cable and installation hardware.

FU25 Follow-Up Steering Lever

The FU25 Follow-up steering lever features a dial with 5° rudder angle markings. The rudder will move and stop at the angle selected on the dial. The FU25 has a mid-position indent, buttons for (limited) mode selection, and mode indicators. It is designed for indoor and outdoor bulkhead or flush panel-mounting. Refer to the FU25 manual for more information.

Multiple stations

Multiple control units can be added to the system. See page 11

2 OPERATION

WARNING ! An autopilot is a very useful navigational aid, but **DOES NOT** under any circumstance replace a human navigator.

Do not use automatic steering when:

- In heavy traffic areas or in narrow waters
- In poor visibility or extreme sea conditions
- When in areas where use of autopilot is prohibited by law

When using an autopilot:

- Do not leave the helm unattended
- Do not place any magnetic material or equipment near heading sensor used in the autopilot system
- Verify at regular intervals course and position of vessel
- Always switch to Standby mode and reduce speed in due time to avoid hazardous situations

2.1 Overview




Figure 2-1 AP26 Front Panel




Figure 2-2 AP27 Front Panel

The control units shown above can operate as a stand alone unit in an autopilot system or combined in a multistation system. In a multistation system the command can easily be transferred from one unit to another. Units not in control will display "Inactive" and/or ☒.

The autopilot system is capable of the following primary steering modes: STBY (power steering), AUTO, NAV and WIND, each mode having a dedicated push button.

Each of the mode push buttons is clearly identified with the primary function in large text, and a secondary function listed in smaller text. Each button provides you with a multiple function mode display.


A group of user adjustable settings are provided in the User Setup Menu (page 39).

Alarms are presented in plain text to alert you of system and external data failure conditions. Alarms include both audible and visual presentations. The alarm listing is on page 118.

2.2 ON/OFF - Standby mode

Note ! *At first time turn on see paragraph 4.1.*

A single press on the STBY button switches the system ON and the following status displays are shown:




SW and HW revisions shown are examples only.

After approximately 5 seconds, the system is operative and the unit that was turned on will show the Standby mode display. Other units in a multistation system will display "Inactive". Control is transferred to any single unit by pressing its' **STBY** button.



The main Standby mode display shows the current heading.

Alternatively, the Standby mode display can show the following information by a long press on the **TURN/DODGE/INFO** button:



- Standby mode
- Current heading 345°M
- Compass source: Rate compass
- Rudder angle =00°.

Refer to INFO menu, page 46.

A long press (2-3 sec.) on the **STBY** button switches the system OFF and during this time, the alarm will sound.

Note ! *In an emergency, it is possible, on a multistation system, to turn OFF the system at any control unit by pressing the **STBY** button for 2-3 seconds.*

STBY mode is the mode that is used when steering the boat at the helm.

Flashing course knob icon



When the course knob and the **PORT/STBD** buttons are used for settings etc., an icon will flash on the screen to tell that no course changes can be made unless you press the **AUTO** button.

Alarms

In the event there is an audible alarm with explaining text on the control unit, refer to section 6 Trouble shooting.

2.3 AP26 and AP27 with MSD50 Stern Drive unit

Note ! *The information in section 2.3 only applies if your autopilot is driving a Simrad MSD50 Stern Drive.*

The MSD50 Stern drive unit has a relative feedback signal which needs a zero point setting after the autopilot has been turned on. Refer to the MSD50 manual for further information.


Zero point setting

Note ! *If you do not need a rudder angle display when leaving the dock, just steer the boat manually on a straight course and press the **AUTO** button. The zero point is then set automatically.*


If you prefer to use the rudder angle display when leaving the dock, proceed as follows:



After turn on the rudder angle display will alternate between 10 degrees port and starboard to indicate that the "rudder" zero point need be set.



Use the wheel to bring the "rudder" to midship position. Turn the wheel from lock to lock (H.O. to H.O.) and count the exact number of turns. Then start from one lock position and turn the half number of turns.




Press **AUTO** and then **STBY**. The zero point is now set and the display will show:




Follow the operating instructions on the following pages. There is no further need for zero point settings until next time you turn the autopilot on.

2.4 Follow-Up steering (FU)


In the Follow-Up steering mode the course knob may be used to set rudder commands. The commanded rudder angle is shown on the display and the rudder will move to the commanded angle and stop.



Press both buttons simultaneously to activate Follow-Up



Use course knob to command rudder angle



Commanded rudder angle 10° to port. Rudder angle: 4° to port and moving.




Return to manual control in Standby by pressing the **STBY** button

WARNING ! While in Follow-up mode you cannot take manual control of the wheel.

2.5 Non-Follow-Up steering (NFU)

In Standby mode, the NFU display is presented when the **PORT** or **STBD** button is pressed. The rudder will move as long as the button is pressed and the rudder angle is shown on the display.




Activates
PORT rudder
command

Activates
STBD
rudder
command

Note ! *When a NFU steering lever or remote control is operated, other control units become “Inactive”.*

2.6 R3000X Remote Control (NFU)



Push button for Port and Stbd commands

STBY/automatic.

Automatic modes are active when the lamp is lit.

In STANDBY mode, the rudder will move as long as the Port or Stbd button is pressed.

In AUTO mode and Wind modes the set course or set wind angle will change 1° each time the button is pressed.

Note!

If you keep the button pressed, it will automatically change the setting in increments of 3° per second.

Mode changes are as per table below.

Initial mode	1 st press	2 nd press
STBY	AUTO	STBY
AUTO	STBY	AUTO
NAV	STBY	AUTO ¹⁾³⁾
STBY	WIND	STBY ²⁾
AUTO	STBY	WIND ²⁾
WIND	STBY	WIND ²⁾
WINDN	STBY	WIND ³⁾

Notes !

1. When NAV mode is selected in User Setup
2. When WIND mode is selected in User Setup
3. NAV and WIND_N modes can only be entered from the Control unit because you have to accept the prompt displays.

2.7 JS10 Joystick (NFU)

The principle is similar to that of R3000X Remote Control (see above). The rudder will move as long as the lever is offset to Port or Starboard. JS10 has no mode change feature.

Note !

When a NFU steering lever or a remote control is operated, the control units and FU25 become "Inactive".


2.8 Automatic Steering

When AUTO mode is selected, the autopilot automatically picks the current boat heading as the set course and maintains the simultaneous rudder angle. This gives a bumpless transfer at the mode change.



The main Auto mode display shows the mode index and the set course.

Alternatively, the Standby mode display can show the following information by a long press on the **TURN/DODGE/INFO** button:



Automatic steering mode
 Set course: 340 degrees
 Steering parameter: LO-A
 Compass reading: 340°M
 Rudder angle: 00°

Refer to INFO menu, page 46.


The autopilot will keep the boat on the set course until a new mode is selected or a new course is set with the course knob or the **PORT** or **STBD** buttons. One revolution of the course knob equals a 45° course change.



Decrease



Increase



Course change

CCW: Decrease CW: Increase

Course adjust 1°
 (or 10°)/ push

Note !

On power boats it is possible in the User Setup menu to set the buttons to change the course by 10° per press (see page 45).

Once the course is changed to a new set course, the boat will automatically turn to the new heading and continue to steer straight.

Heading catch

When in Auto mode this feature allows you to automatically cancel the turn you are in by an instant press on the AUTO

button. The autopilot will immediately counteract the turn and the boat will continue straight ahead on the heading read from the compass the very moment you pressed the **AUTO** button.




Automatic steering mode

New “caught” heading: 305°

Compass reading: 303° M (magnetic)
or T (true)

Rudder angle: 00°.

Steering parameter: LO-A



Regain manual steering by pressing the **STBY** button

2.9 Automatic control of steering parameters

The autopilot provides two different sets of steering parameters for controlling the response of the boat at different speeds or wind directions while in AUTO, NAV or WIND modes.

Power boat

The autopilot selects the LO (response) steering parameters when engaging an automatic mode from STBY provided there is no speed input. This is a safety feature. When entering an automatic mode at low speed, the steering parameters may be changed to HI automatically by input data from a speed log or a GPS navigator, or manually.

The speed at which the autopilot automatically changes from LO to HI parameters (or opposite) is determined by the "Transition Speed" set in the Installation Setup Menu (Sea trial). See diagram below.


Legend

HI-A High response parameters set automatically

LO-A Low response parameters set automatically


HI-M High response parameters set manually

LO-M Low response parameter set manually



Sailboat

When sailing in WIND mode, the parameters are automatically changed by the direction of the wind as per below or by the boat speed.




The transition between HI and LO parameters and vice versa will have a different characteristics with regards to the wind angle compared with the transition controlled by the speed of the boat.

If you loose too much speed e.g. when tacking, the parameters will change to HI to gain sufficient rudder response. This should be observed when setting the transition speed on sailboats.

2.10 Manual Parameter Selection

Manual selection of steering parameters is necessary if there is no speed input to the autopilot or if you want to override the automatic control.

To toggle between LO and HI parameters, press the "AUTO" button two times quickly.



Notes !

1. *If you are in NAV or WIND modes you need not enter AUTO mode to manually change the parameter set. Just make a quick double press on the AUTO button.*
2. *The manually selected setting (HI or LO) will override the automatic selection and remain in effect until you re-enter any automatic mode from STBY.*

2.11 U-Turn

This feature is very useful in a man overboard situation and whenever you want to steer back on a reciprocal heading.


U-Turn changes the current set course to be 180 degrees in the opposite direction. The user must decide whether the U-Turn should be made to Port or Starboard when bringing the boat on the new course. U-Turn is activated by a quick press on the **TURN/DODGE/INFO** button. The autopilot will continue on the set course until you press either the **PORT** or **STBD** button to select the direction to make the U-Turn. If you do not press **PORT** or **STBD** within 1 minute, the autopilot will return to the AUTO mode and stay on course.



2.12 Dodge in AUTO

Dodging is useful in situations where you need to quickly take control of the helm to steer around an obstruction, and then resume the previous set heading. Dodging is activated by a quick double press on the **TURN/DODGE/INFO** button.

When in DODGE mode the displayed set course is the last one set prior to activating the dodge function. When DODGE is displayed, the autopilot is no longer in control of the steering, and you must either manually steer the boat in STBY mode or take control using Non Follow Up or Follow Up steering. On manual steering (STBY mode) the clutch or bypass valve in the drive unit will be disengaged. The autopilot will remain in the DODGE mode until you exit DODGE by a second press on the **TURN/DODGE/INFO** button or select a mode.




Quick double press to activate Dodge mode




Perform dodging in one of the following ways:

1. Manually steer the boat by the wheel:




2. Non Follow Up steering by pressing:



or using NFU steering lever

3. Follow Up steering by pressing both:




and using the course knob

To return from Dodge mode, press one of the following:



Selects AUTO mode and returns to the last set course

or



Selects AUTO mode with the current heading as the set course

Note !

Using NFU or FU modes while dodging will make "NFU" or "FU" flash instead of "DODGE".

2.13 Tacking in Auto mode

The tack function is only available in sailboats when the system is set up for SAIL boat type in the installation setup.

Tacking in AUTO mode is different from tacking in WIND mode. In AUTO mode the tack angle is fixed and can be set in the Installation/Dockside menu.

Tacking should only be performed into the wind and must be tried out in calm sea conditions with light wind to find out how it works on your boat. Due to a wide range of boat characteristics (from cruising to racing boats) the performance of the tack function may vary from boat to boat. Except for the fixed course change and the difference in displays, the procedure is similar to that of the U-Turn described on page 25.



2.14 Navigating with the AP26 and AP27

The autopilot has the capability to use steering information from an external navigator (GPS, Chart Plotter) to direct the boat to a specific waypoint location, or through a route of waypoints. In the NAV mode, the autopilot uses the compass as heading source for course keeping. The information received from the navigator alters the set course to keep the boat on the track line and direct the autopilot to the destination waypoint.

Note ! *Navigational steering should only be used in open waters. By selecting the NAV mode, the autopilot is set for automatic steering on the current set course and then waits for the user to accept the course change to the track line or destination waypoint.*

To obtain satisfactory navigation steering, the following points must be fulfilled prior to entering the NAV mode:

- The autopilot autosteering must be tested and determined satisfactory.
- The navigation receiver (GPS, Chart Plotter) must be in full operating mode with adequate signal characteristics for valid position and navigation data.
- At least one waypoint must be entered and selected as the current “Go to” waypoint.
- The navigation receiver (source) for the autopilot will be the one that is automatically selected in the interface set-up or manually selected in the User setup menu item called “Source select” (page 42).

The autopilot is designed to steer in “mixed mode” operation. This combines the straight steering capability of cross track error (XTE) steering in conjunction with the turning capability of bearing mode steering (Course To Steer, CTS) and automatic waypoint shift.

Note !

If the autopilot is connected to a navigation receiver that does not transmit a message with bearing to next waypoint, it will pick a XTE message and steer on Cross Track Error only. In that case you have to revert to AUTO mode at each waypoint and manually change set course to equal bearing to next waypoint and then select NAV mode again.

Press the NAV button to activate the NAV prompt display.

A rectangular screen displaying navigation data in a monospaced font. The text is: WP :Egersund, BW: 270°M, CHG: ←086, and Ok?:Press NAV. The last line is highlighted with a black background.


```
WP :Egersund
BW: 270°M
CHG: ←086
Ok?:Press NAV
```

The prompt display shows the name or number of the next waypoint (WP), the bearing of the track line (BW) from the previous waypoint to the destination waypoint, the required course change (CHG) and the direction in which the boat will turn.

Note !

If only one waypoint has been entered the bearing will be from the present position to the destination waypoint.

Press the NAV button again to accept the waypoint as the location to steer towards. The autopilot turns the boat onto the track line.





- NAV mode
- Course to steer (CTS): 260 is set internally by the autopilot to steer the boat onto the track line.
- Cross track error (XTE): 0.010 nm to stbd.

Note !

For Cross Track Error, the number of decimals shown depends on the output from the GPS/chart plotter. Three decimals give a more accurate track keeping.

Alternatively, the NAV mode display can show the following information by a long press on the **TURN/DODGE/INFO** button:



- Next waypoint: Egersund
- Bearing from current position to the next waypoint (BPW): 270°M
- Distance to waypoint: 10 nm
- Steering parameter: LO-M
- Rudder angle: 00°

When operating the autopilot in NAV mode to steer through a route of waypoints, the autopilot will steer to the first waypoint in the route after you accept the first waypoint as the location to steer towards. When you arrive at the waypoint, the autopilot will output an audible warning, display an alert screen with the new course information, and automatically change course onto the new leg.


Note !

If the required course change is more than 10°, you will need to verify that the upcoming course change is acceptable. This is a safety feature.



Alert screen. Press NAV button to verify course change larger than 10°.

If no verification is received, the autopilot will continue on the current set course in AUTO mode.




Regain manual steering by pressing the **STBY** button


Setting the waypoint arrival circle

For route navigation it is recommended to use automatic waypoint shift/change at a set waypoint arrival circle.

The arrival circle should be adjusted according to boat speed. The higher speed, the wider circle. The intention is to make the autopilot start the heading change in due time to make a smooth turn onto the next leg.



The figure below may be used to select the appropriate waypoint arrival circle.



Example: With the speed of 20 knots you should use a waypoint arrival circle with radius 0.09 nm.


Note !

The distance between any waypoints in a route must not be smaller than the radius of the waypoint arrival circle when using automatic waypoint shift.

2.15 Dodge in NAV

When dodging in NAV mode, the course displayed as Course To Steer (CTS) is the boat's recommended heading. However, the previous set course is stored by the autopilot. When DODGE is flashing on the display, the autopilot is no longer in control of the steering and you must either steer the boat manually or take control using either Non-Follow-up steering or Follow-up steering. On manual steering, the clutch (or bypass valve) in the drive unit will be disengaged when dodging. The autopilot will remain in the DODGE mode until you exit DODGE by a second press on the **TURN/DODGE/INFO** button or until you select another mode.




Perform dodging the same way as in AUTO mode above.



Quick double press to activate Dodge mode



To return from Dodge mode, press one of the following:

1.  Selects AUTO mode with the current heading as the set course.
2.  Returns to NAV mode at present position with new bearing to waypoint prompt. Keeps all offset estimates (Wind/current etc.) in the algorithms (recommended).
3.  Selects NAV mode at present position with new bearing to waypoint prompt.

2.16 Selecting a different Navigation source

If you have more than one navigation source connected to the autopilot, you will be able to choose any for navigation. Refer to the 'Source Select' item in the User Set-up menu for details on selecting a different navigator (page 42).

2.17 Wind vane steering

Prior to entering WIND mode the autopilot system should be operating in AUTO, with valid input from the selected wind transducer. The WIND mode is only available if the system has been set up for SAIL-boat in the Installation Menu, and the NAV/WIND source is set to WIND under the USER SETUP menu. (Refer to page 40).


Enter the WIND mode by pressing the **NAV/WIND/SETUP** button.

The set course to steer (CTS) and set wind angle are entered from the compass heading and the wind transducer at the moment the WIND-mode is selected. From that point the autopilot will change the course to maintain the wind angle as the wind direction may change.

Note ! *If the cumulative shift of the wind direction exceeds a set limit from the time a new wind angle is set, a WIND SHIFT alarm will sound.*

The display will show the set wind angle. Adjustments to this set angle can be made by using the course knob or **PORT** or **STBD** button.

The display also presents heading and rudder angle.



Wind (vane) mode

Set wind angle:

045 degrees from stbd.

Measured wind angle: 042°A

A = Apparent

T = True

Rudder angle: 01° to port.

Parameter: LO-M (Low response, manually set)




Steer port




Steer stbd.

Adjust set wind angle 1°/push



Major wind angle adjust
CCW: Steer port CW: Steer stbd



Regain manual steering by pressing the **STBY** button


2.18 Tacking and gybing in Wind mode

In WIND mode there is a tacking and gybing aid function.



Tacking in WIND mode as compared to AUTO mode can be performed when sailing with apparent or true wind as the reference, and with a true wind angle of less than 90 degrees.

The tacking operation will immediately mirror the set wind angle to the opposite side. A tacking-message will flash on the display for 5 seconds. Any new command given when the message is flashing, will interrupt the tack operation. The rate of turn during the tack will be given by the 'Tack time' parameter set in the Installation/Dockside menu (page 94).

A quick press on the **TURN/DODGE/INFO** button will activate the tack function and the boat will start turning to the same wind angle on the other side.




Quick press



Gybing

Gybing is possible when the true wind angle is larger than 120°



When a gybe is initiated, the wind angle will first be set to 170°T on the same side as the current wind angle. The main sail should now be hauled. With the main sail safely hauled, the wind side may be changed. This is done by pressing either **PORT** or **STBD** buttons depending on the way the boat should continue to turn. The new set wind angle will then become the same as the wind angle set before the gybe operation started.

The rate of turn when changing wind side in a gybe will be the highest possible, determined by the performance of the drive unit.

Tack and gybe prevent

When beating and running, sailing is at the most critical.

If the sails are unbalanced when beating, yaw forces from the sails can drive the boat into the wind. If the boat is driven beyond the minimum wind angle, the thrust from the sails will suddenly disappear and the boat speed reduced. Then the boat will be even more difficult to steer because the rudder will become less effective.

The tack prevent function in WIND-mode has been implemented to avoid such situations. It will react immediately when the apparent wind angle becomes 5° less than the set minimum wind angle. Additional amount of rudder will be commanded to immediately increase the wind angle.

When running, it is difficult to steer the boat with waves coming sideways or from behind. The waves may yaw the boat so that the wind side is shifted and an unwanted gybe may happen. This can be hazardous for both the crew and the mast.

The gybe prevent function will be activated when the measured apparent wind angle becomes greater than 175° or when the wind angle gets opposite to the set wind angle. Additional rudder will be commanded to keep the wind on the same side as the set wind angle.

Caution ! *The tack and gybe prevent functions are not a guarantee against getting into a hazardous situation. If the effect of the rudder and/or drive unit is not adequate, it may happen. Pay particular attention in such situations.*

2.19 Wind steering and navigation

The autopilot can also steer the boat given both wind data and track data from a GPS/Chartplotter. In this mode called WIND_{NAV} mode the automatic steering is based on a set of criteria (see bullets below). Wind steering and navigation is activated by pressing the **NAV/WIND/SETUP** button when in Wind mode. There are two sub-modes under this key: **NORMAL** (default) and **RACING** (see below). The initial course change (CHG) needed to navigate towards the active waypoint, is calculated by the autopilot. The autopilot will maintain windside in these calculations and the change of course is accepted by pressing the **PORT** or **STBD** button [1].





Figure 2-3

Operating in WIND_{NAV} mode

Refer to Figure 2-3 with references [] the associated displays and the criteria (bullets) below.

- The set wind angle should be larger than the ‘Minimum wind angle’ set in the Installation/Dockside menu and smaller than 170° Apparent.
- Information about when it is time to head directly towards the waypoint, Distance To Turn (DTT) and Estimated Time to Turn (ETT) are displayed. These calculations are based on the assumption that the set wind angle will be the same or larger after a tack or gybe towards the waypoint [2][3].
- A turn prompt will appear when it is time to head towards the waypoint and the autopilot will calculate and display the change of heading by comparing between the current heading and the heading towards the waypoint (CHG) [5].
- When heading towards the waypoint, the autopilot utilizes either the XTE from the GPS/Chartplotter to maintain track or a layline calculated by the autopilot. The calculated layline applies when the Cross Track Error (XTE) from the external navigator is larger than 0.15 nm [8].


RACING

If ‘Wind setup’ is set to ‘*RACING*’ in the Installation/Dockside menu, a more advanced steering is possible:

- Optimising VMG to wind may be enabled when beating and it is not possible to head directly towards the waypoint [2][4].
- Layline steering may be disabled when heading directly towards the waypoint. Instead you can optimise the Waypoint Closure Velocity (WCV) by trimming the sails and the set wind angle. A turn prompt will then be displayed if the difference between Course Over Ground (COG) and Bearing Position Waypoint (BPW) exceeds 30° when heading towards a waypoint [8].

See chapter 2.22 User Set-up Menu on how to access these parameters.

2.20 Multiple station system





In normal operation control is accessible from every control unit connected to the autopilot system. One control unit is "active" and provides the user with access to all functions. All remaining control units are "inactive" and have no effect on mode changes or course selection. A single press on any of the mode buttons on an "inactive" control unit will allow transfer of command and make it "active".


2.21 Lock function

The "LOCK" function is a safety feature in the autopilot system. It will disable all control units, including the FU25 Follow-up lever, except for a single user selected control unit location.


When the "lock" function is in use, no transfer of command can take place; only the active control unit stays in command.

To enable the "lock" function, make a quick double press on the STBY button.




The display on the active control unit will first show a  icon and then the icon will alternate with the mode index.

The "locked" control units in the system will show:




The "Lock function is disengaged by one of the following actions:


- The active control unit unlocks the other ones and makes them "inactive" by another double press on the STBY button. It also displays the  icon before it returns to the normal active state.
- The system is switched OFF by any control unit (press STBY for 2-3 seconds).

2.22 User Set-up Menu


In the AP26 and AP27, all modes except NFU and FU have a complementary User Set-up menu. You can easily access the set-up menu by a quick double press on the **NAV/WIND/SETUP** button.



Quick double press
to access



Scroll through the menu



Use the course knob to
change a value or a setting

Alternating Course Knob Icon



When the course knob is used in the User Set-up menu, an icon will alternate with the mode index to tell that no course changes can be made unless you press the mode button.

The user set-up menu times out 30 seconds after the last operation in the menu.

STANDBY Mode

Backlight



The backlight of the display and buttons may be adjusted to 10 levels (10 = brightest). The setting is stored when the system is turned off. Adjustment is local to the control unit you adjust or synchronized with other units in the Simrad Group (page 110).

Contrast



The contrast of the display may be adjusted to 10 levels (10 = highest contrast). The setting is stored when the system is turned off.

Adjustment is local to the control unit you adjust. At high temperatures, not all levels are available due to automatic temperature compensation.

Nav/Wind



This parameter will only be available if 'Boat type' is set to 'Sail' in the Installation/Dockside menu (see Dockside settings, page 88). The 'Nav/Wind' parameter will configure the active mode on the **NAV/WIND** button.

The following alternatives are available:

- NAV
- WIND Auto

Wind steering will be disabled when the 'Nav/Wind' parameter is set to 'NAV'. Then the normal NAV mode for power boats is activated when pressing the **NAV/WIND** button.



If 'Nav/Wind' is set to 'WIND Auto', wind steering will be enabled. Pressing the NAV/WIND button will then initiate the WIND-mode. The autopilot will automatically select between apparent and true wind steering.

True wind steering is used when running. When the boat is running, it will also be surfing on the waves. This may lead to significant changes in boat speed, hence changes in apparent wind angle. Steering to apparent wind is therefore used only when beating or reaching.

Range: NAV, WIND Auto

Default: WIND Auto

Nav/Wind, RACING parameters

If 'Wind setup' is set to 'RACING' in the Installation/Dockside menu (see page 92), more settings are available under the 'Nav/Wind' parameter:


- NAV
- WIND Apparent
- WIND True
- WIND Auto

Default: WIND Auto

'*WIND Apparent*' is selected when you only want to steer to apparent wind. Apparent wind steering is preferred when you want to achieve maximum boat speed. The autopilot will try to maintain a constant apparent wind angle to get maximum thrust from a given trim of the sails.

'*WIND True*' is selected when you only want to steer to true wind. When sailing in closed waters, the apparent wind angle may change temporarily due to wind gusts. It may then be preferred to sail to the true wind.

VMG Optimizing



The VMG (to wind) parameter can only be enabled or disabled when 'Wind setup' is set to 'RACING'. It is disabled in the 'NORMAL' sub-mode.


When enabled, the VMG optimizing will be active for 5 – 10 minutes after a new wind angle has been set. It will only be activated when beating.

'VMG' will be displayed in the lower left corner when the VMG optimizing feature is active.

Range: Enabled/Disabled

Default: Disabled

Layline Steering



'Layline steering' can only be enabled or disabled when 'Wind setup' is set to 'RACING'. It is enabled in the 'NORMAL' sub-mode.

Layline steering is useful when navigating. It will use the Cross Track Error (XTE) from the navigator to keep the boat on the track line. If the XTE from the navigator exceeds 0.15 nm, the autopilot will calculate its own layline towards the waypoint and follow that. Layline steering is not active when turning, tacking or gybing.

'XTE' will be displayed in the lower left corner when layline steering is active.

Range: Enabled/Disabled

Default: Enabled

Instrument Select




Select the contents of the instrument page(s) to be available under the **DODGE/TURN/INFO** button (page 46). Step through the list of instrument pages by using the **PORT** or **STBD** button. Select the wanted information by rotating the course knob to fill the squares.

Source Select



Provides you with automatic or manual selection of interfaced data sources for heading (Compass), Navigation, Position, Wind Angle, Calculated Wind, Water speed, Water temperature, Distance log (not displayed on AP26 and AP27) and Depth.

Wind-C (calculated) is a common term for true wind and wind direction.



Auto source update

Is used for automatically update of sources if the interfaced units have been removed/added or switched on/off.

Select Auto source update by rotating the course knob. Make sure all interfaced units are powered on

The autopilot will search for new connected sources, and replace sources no longer available. "SEARCHING" is flashing as long as the autopilot is searching. When the automatic update is finished, the display will read "DONE".



Press the STBD button to leave the User setup.

Manual select

Step through the list of sources using the **PORT** or **STBD** button. Select wanted source by rotating the course knob.

-- indicates that no source is supplying the data available.

Notes !

1. *Simrad products will be identified by the product name provided the data is available on SimNet. If data is provided via an NMEA0183 port on the autopilot computer, the display will read NMEA-1 or NMEA-2. NMEA2000 products will have a special ID.*
2. *See note on page 74 and note 3 below.*
3. *In the event the SimNet is not powered on, sources supplying data to SimNet are not on or malfunctioning, or there is no SimNet installed, it is possible to use any control unit in the system to select NMEA sources. The source select displays are then available on all control units.*

```
Source select
Comp RATE-0
```

Compass

Select the compass to be used if more than one compass is connected.

```
Source select
Nav CE33-1
```

Navigation

Select the source for navigational data.

```
Source select
Pos CE33-1
```

Position

Select the source for position data.

```
Source select
Wind-A IS12TW
```

Wind Angle

Select the source for Wind Angle.

```
AP:Intrnl src
Wind-C AC20
```

Wind Calculated

Select the source for Calculated Wind data for the Simrad group. AP uses internal sources irrespective of the selected source.

```
Source select
Wa-Spd NMEA-1
```

Water Speed

Select the source for water speed (normally the same as the source providing Log data).

```
Source select
W-Temp NMEA-1
```

Water temperature

Select the source for water temperature (normally the same as the source providing depth data).



DisLog


Select the Log source.





Depth

Select the source for depth data.

Course Adjust



When using the  (**PORT**) or  (**STBD**) buttons in AUTO mode, you are changing the set course in 1° increments. If you prefer the increments to be 10° each press (does not apply for sailboats), proceed as follows:

Select *Course adjust* and turn the course knob to change the setting. The default value is 1°, which is the preferred setting. Select 10° if you want to make major course changes in 10° increments with the buttons and fine-tune the set course with the course knob.

Press the STBY button to leave the User setup.

AUTO Mode

Settings that are added for the AUTO and WIND modes are shown below. Other relevant settings are described under STANDBY mode in this chapter.



Seastate filter

OFF: Seastate filter is disabled.

AUTO: Automatically reduces rudder activity and autopilot sensitivity in rough weather by an adaptive process (default).

MANUAL: Manual yaw band adjust (1-10, 10 ≈ ±6°).

The manual setting determines the number of degrees the vessel may deviate from the set course before any command is given to the rudder. The AUTO setting is recommended. The MANUAL settings may be used to find the optimum combination of course keeping and low rudder activity in rough but steady sea conditions.

Response

The Autotune function in the AP26 and AP27 is so refined that 80-85 % of the boats will need no further adjustments of the steering parameters. On some boats, however, or at particular sea conditions a fine tuning of the steering parameters may improve the performance of the autopilot.



The Response control allows you to make this fine tuning. It can be set to seven levels. Level 3 (default) has the values of *Rudder* and *Counter Rudder* parameters set by the Autotune function. If no Autotune is made (not recommended) the level 3 values are the factory default values.

A low response level reduces the rudder activity and provides a more “loose” steering.

A high response level increases the rudder activity and provides a more “tight” steering.

A too high response level will make the boat start S-ing.

Range: 1 – 7

Default: 3

NAV Mode

The User setup for NAV mode is identical to the User setup for AUTO mode.

WIND Mode



The User setup for WIND mode includes the same items as the User setup for AUTO mode. In addition you have:

Wind response

If the difference between the set wind angle and the actual wind angle is too big, the ‘Wind response’ can be increased to reduce the deviation.

Note !

First make sure that the course keeping is acceptable, i.e. the difference between the Course To Steer (CTS) and the actual heading is at a minimum.

If the actual wind angle is S-ing around the set wind angle or the rudder activity is too high, the ‘Wind response’ should be reduced.

Range: 1 – 7

Default: 3

See also other relevant settings for WIND mode operation under STANDBY mode in this chapter.

2.23 INFO menu

A number of instrument pages are available under each mode screen if the required NMEA 0183 sentences are provided (see paragraph 8.1) or the information is available on SimNet (page 110). The INFO menu is accessed by a long press on the **TURN/DODGE/INFO** button.

The mode screens for Standby, Auto and Nav mode have an alternative screen.

A large digital display showing the heading 'S 345'.

An alternative display for Standby mode showing 'S 345°M' at the top, 'RATE-0' below it, and 'P 00 S' at the bottom.

Standby mode

The main screen shows current heading with large figures. A long press on the **TURN/DODGE/INFO** button gives you an alternative screen where the heading is shown together with heading source and rudder angle. You have to select this screen from the pages in the INFO menu.

A large digital display showing the heading 'A 345'.

An alternative display for Auto mode showing 'A 345' at the top, 'LO-M' and '345°M' below it, and 'P 00 S' at the bottom.


Auto mode

As for Standby mode you can change the Auto mode main screen to show the set course, steering parameter, heading and rudder angle by a long press on the **TURN/DODGE/INFO** button. As for the STBY mode you have to select this screen from the INFO menu.




Nav mode

For Nav mode the alternative mode screen gives you the name of the waypoint, bearing and distance to waypoint and rudder angle. This screen is also among the INFO pages.




Step or scroll through the available instrument screens by pressing the **PORT** or **STBD** button or using the course knob.




Compass

Heading source
Heading
Rudder angle



Depth/Speed

Depth
Speed



Apparent wind

Apparent wind angle
Apparent wind speed



True wind

True wind angle
True wind speed




True wind

True wind angle
VMG to wind









Wind direction

Wind direction
Wind speed



Wind shift

Wind direction
Wind shift

	<p>Track data Cross Track Error Distance to Waypoint</p>
	<p>Position Latitude Longitude</p>
	<p>Nav data Waypoint ID Bearing Position – Waypoint</p>
	<p>Nav data Course Over Ground Speed over ground</p>
	<p>Nav data Course Over Ground Bearing Position – Waypoint</p>
	<p>Sea Temperature</p>

If you prefer not to have all the instrument pages available in the INFO menu, you may remove pages under the User setup menu. See page 42.


Return to last instrument screen by a long press on the **TURN/DODGE/INFO** button.

Course knob icon




Initially when the INFO menu is accessed an icon will replace the mode index to tell that no course changes or other course related settings can be made unless you press a mode key. The icon will time out after 3-5 seconds and be replaced by the mode index.


INFO menu flowchart



Alternative mode screens in STBY, AUTO and NAV




INFO menu and Main screen, active unit



Note ! Whenever the INFO menu is active and the mode index is present on an active unit, operating the PORT and STBD button or the course knob will immediately make the main screen reappear.

INFO menu and Main Screen, inactive unit



You can view the INFO pages without activating the unit.

3 INSTALLATION

3.1 General

This section provides detailed information required to successfully installing the AP26 and AP27 Autopilot system.

The autopilot systems include several modules that need to be mounted in different locations on the boat, and also need to interface with at least three different systems on the boat:

- The boat's steering system
- The boats electrical system (input power)
- Other equipment on board

In addition, the advanced capabilities of the autopilot require the installer to perform a series of settings and tests to verify proper operation of the system, refer to the check list below.

3.2 Installation checklist

1. Determine the system configuration you are installing (Figure 3-1)
2. Perform the hardware installation (Page 53)
3. Connect SimNet devices to SimNet (page 69)
4. Connect NMEA2000 devices (page 72)
5. Connect NMEA 0183 devices (inputs and outputs, page 75)
6. Perform Set-up (Section 4, page 83)
7. Perform dockside autopilot tests (refer to Operating Instructions, page 15)
 - a) Test all stations (if applicable) - lock/unlock - active/inactive
 - b) Test Non-Follow Up mode
 - c) Test Follow-Up mode
 - d) Test AUTO mode
 - e) Test NAV mode and input interfaces
 - f) Test WIND and WIND_N modes (if sailboat) and input interfaces
 - g) Test interface outputs to external equipment (if connected)
8. Perform sea trial settings (Page 96)
 - a) Rudder zero
 - b) Compass calibration

- c) Compass Offset adjustment
 - d) Automatic tuning
 - e) Viewing parameters
9. Test Autopilot Operation at Sea (refer to Sea Trial instructions, pages 96, 112)
 10. Provide the user with training (Page 113)

3.3 Unpacking and handling

Care should be taken when unpacking and handling the equipment. A visual inspection should be made to see that the equipment has not been damaged during shipment and that all components and parts are present according to the packing list.

A standard autopilot system will include:

- Control unit with standard installation accessories.
- Autopilot computer (AC10, AC20 or AC40) and one 15 m (49') Robnet2 cable.
- RC25 Rate Compass with 15 m (49') cable attached.
- RF300 Feedback unit with 10 m (33') cable attached and transmission rod.
- Appropriate drive unit for the installation (unless the autopilot is going to operate an existing drive unit or solenoids).
- Optional equipment that may have been ordered for the installation.

3.4 Determine system configuration

It is important to become familiar with the configuration of the system prior to beginning the installation. The autopilot system layout with options is shown in Figure 3-1.

Pay particular attention to the autopilot computer/drive unit combinations on page 58 and the chart on page 12.

As many of the units are communicating on a common network (Robnet2), with identical connectors, the installation is simplified. Try to mount the units within the standard cable length supplied with each unit, if possible. Robnet2 Extension Cable (1, 5 and 10m) are available from your distributor.

3.5 Autopilot System Layout




Figure 3-1 Autopilot system layout with options

3.6 RF300 Rudder feedback installation

The RF300 Rudder feedback unit mounts close to the rudder, and is mechanically linked to the rudder tiller arm or rudder quadrant.

Refer to Figure 3-2 for the recommended mounting arrangement. Note that the RF300 transmitter arm has two slots for the transmission link. The slots enable maximum flexibility to provide the 1:1 mechanical linkage relationship.

Note !

Do not try to remove the transmitter arm from the feedback unit. The unit is factory adjusted and need no further adjustment at installation than described below.

As a starting point, it is desirable to set the transmitter rod to the inner limit of the outer slot if possible. (Refer to Figure 3-2). Drill and tap the rudder tiller arm so that the Y1 dimension is equal to the Y2 dimension (Use 4.2 mm drill and 5 mm tap).

Attach the ball joint to the tiller arm, and connect the transmitter rod to the ball joint at the rudder tiller arm.

Turn the helm wheel to set the rudder tiller arm to approximate centre position.

Rotate the RF300 transmitter lever until it is set to centre position. (Use the alignment mark to line up the transmitter lever to be opposite the cable entry into the feedback.)

Note ! *Carefully observe the alignment marks. A rudder feedback alarm may be the result if the alignment instructions as per Figure 3-2 are neglected.*

Attach the transmitter rod to the RF300. Set the RF300 mounting location to be in accordance with Figure 3-2. The centre of the RF300 should be in line with the centre of the rudder post. Mount the RF300 to a suitable platform using the screws provided. If necessary, add blocking material under the RF300 to adjust the height of the transmission arm to be level with the rudder tiller arm.




Figure 3-2 RF300 mounting (019356)

Note ! *Due to space limitations, it may be necessary to cut the length of the transmitter rod to move the RF300 closer to the rudder post.*

Tighten the mounting screws for both the RF300 feedback unit and the transmitter rod ball joint.

Observe the RF300 while someone turns the helm wheel through the complete travel from full port to full stbd. rudder to verify that the mechanical linkage to the RF300 is not obstructed.




Figure 3-3 RF300 connection

3.7 Autopilot computer installation

The autopilot computer is designed to operate in a location that provides ambient temperatures below +55°C (+130°F).

Note !

The autopilot computer units (AC10, AC20 and AC40) are not weatherproof and should be mounted vertically as shown in a dry place between the control unit and the drive unit.




Figure 3-4 Autopilot computer mounting

3.8 Cable connections

Use only shielded cables. This includes Mains input, drive units and if necessary for the extension of the RF300 Rudder Feedback cable. The clutch/bypass cable and the solenoid cable should be 1,5 mm² (AWG14). Signal cables should be 0.5 mm² (AWG20) twisted pairs.

The mains supply cable and the drive unit motor cable should have sufficient wire gauge. This will minimize voltage drop and allow the drive unit to operate at full power.

Refer to the table below for recommended cable sizes.

Cable length	Drive Unit Voltage			
	12 V		24 V	
1. Breaker panel to autopilot computer. 2. Autopilot computer to Drive Unit motor (Length refers to each of the two cables)	AWG	mm ²	AWG	mm ²
Up to 3 m (10 ft.)	12	2,5	12	2,5
Up to 6 m (20 ft.)	10	4	10	2,5
Up to 10 m (32 ft.)	8	6	10	4
Up to 16 m (52 ft.)	6	10	8	6

3.9 Grounding and RFI

The autopilot system has excellent RFI protection and all units use the autopilot computer as a common ground/shield connection. The autopilot computer should therefore have a proper ground connection to the hull/bonding system.

RobNet2 cables and other signal cables (compass, feedback, NMEA) should not be run in parallel with other cables carrying RF or high current, such as VHF and SSB transmitters, battery chargers/ generators, winches and thrusters.


Remove the bottom cover to get access to the plug-in terminals. Strip about 1 cm (0.4") of the cable's insulation and pull the screen backwards to cover the insulation. Position the straps as shown and tighten well to make sure the screen has good contact.

Provide sufficient wire length so that the plug-in terminals can be easily connected/disconnected.

Pull out each terminal before connecting the wires. Remove all strands before putting on the terminal cover.

Note!

The Mains input is not polarity protected on AC40.



Power Board										Monitor diodes										
+ - Supply Voltage See manual		Sol-Motor	Sol-Motor	Sol.gnd	Drive Engage		Yel G n Red Blu REMOTE			Ext. alarm		Radar		NMEA Input2		NMEA Output2				
					+	-	Lamp	Sbd	Port	Gnd	+	-	Data_h	Data_c	Clk_h	Clk_c	RX2+	RX2-	TX2+	TX2-
TB1	TB2	TB3	TB4	TB5	TB6		TB7			TB8		TB9		TB10						

Power Board terminals

TB9 and TB10 are not on the AC10 Power Board

Main Board																
Monitor diodes																
		NMEA TX		NMEA RX		Motor Inhibit										
Rudder Feedb.		Heading Sensor		NMEA Output1		NMEA Input 1		NMEA Input 1		ROBNET2		ROBNET2		ROBNET2		
RF+	RF-	HS+	HS-	TX1+	TX1-	Vbat+	RX1+	Sys. sel.	RX1-	Gnd	Bus-	Bus+	Vsys+	Vsys-	On-Off	Not used
TB11	TB12	TB13		TB14		TB15										

Main Board terminals

3.10 Drive unit installation

The relations between drive units, drive unit voltage, autopilot computer, drive performance and interface to the steering gear are shown in the tables below.

Refer to the connecting diagram for the different drive units on page 60 onwards.

Installation instruction for the drive units are found in the manual for the individual units.

The maximum drive current capability of the AC10, AC20 and AC40 autopilot computers are different. Use the table below as reference and observe the notes on next page.

HYDRAULIC PUMPS

MODEL	MOTOR VOLTS	AUTOPILOT COMPUTER	RAM CAPACITY		FLOW RATE AT 10 bar cm ³ /min (cu. in./min)	MAX PRESSURE bar	PWR. CONSUMPTION
			MIN cm ³ (cu. in.)	MAX cm ³ (cu. in.)			
RPU80	12V	AC10	80 (4,9)	250 (15,2)	800 (49)	50	2,5-6 A
RPU160	12V	AC20	160 (9,8)	550 (33,5)	1600 (98)	60	3-10 A
RPU300	12V	AC40	290 (17,7)	960 (58,5)	3000 (183)	60	5-25 A
RPU300	24V	AC20	290 (17,7)	960 (58,5)	3000 (183)	60	2,5-12 A

Steering gear interface: Hydraulic plumbing

Notes !

- 1. The autopilot system detects whether a reversible motor or a solenoid is connected and outputs the correct drive signal automatically.*
- 2. The drive output of AC10 is sufficient for any type of 12 and 24V solenoids normally found on a recreational boat.*

LINEAR DRIVE UNITS

MODEL	MOTOR VOLTS	AUTO-PILOT COMPUTER	MAX STROKE mm (in.)	PEAK THRUST kg (lb.)	MAX RUDDER TORQUE Nm (lb.in.)	HARD-OVER TIME sec. (30% load)	PWR. CON-SUMP.	TILLER ARM mm (in.)
MLD200	12V	AC10	300 (11,8)	200 (440)	490 (4350)	15	1,5-6 A	263 (10,4)
HLD350	12V	AC10	200 (7,9)	350 (770)	610 (5400)	12	2,5-8 A	175 (6,9)
HLD2000L	12V	AC20	340 (13,4)	500 (1100)	1460 (12850)	19	3-10 A	298 (11,7)
HLD2000D	24V	AC20	200 (7,9)	1050 (2310)	1800 (15900)	11	3-10 A	175 (6,9)
HLD2000LD	24V	AC20	340 (13,4)	1050 (2310)	3180 (28000)	19	3-10 A	298 (11,7)
MSD50*	12V	AC10	190 (7,5)	60 (132)	–	15	0,8-2 A	–

Steering gear interface: Connects to quadrant or tiller.

* For stern drive power assisted steering only.

1. The motor voltage is stepped down by the autopilot computer when operating from 24V or 32V mains.
2. The specified autopilot computer is necessary to achieve max drive unit capacity.
3. Recommended operational thrust or torque is 70% of listed peak value.
4. Typical average power consumption is 40% of listed maximum value.

PREVIOUS MODELS OF DRIVE UNITS

Model	Autopilot computer	Drive unit voltage	Input voltage (Mains)	Drive output	Interface to steering gear
RPU100 (1,0l) RPU150 (1,5l) RPU200 (2,0l) (Reversible hydraulic pump)	AC20 AC20 AC20	12V 12V 24V	12,24,32V	Proportional rate	Hydraulic plumbing
RPU1 (1,4/2,0l) RPU3 (3,8/5,0l)	AC10 AC10	12V, 24V 24V, 24V		Solenoid valves, on/off	Hydraulic plumbing
MRD100 (Reversible mechanical drive)	AC40 AC20	12V 24V	12,24,32V 24,32V	12V to clutch 24V to clutch Proportional rate to motor	Chain/sprockets
MRD150 (USA only)	AC20	12V 32V	12, 24V 32V	12V to clutch 32V to clutch Proportional rate to motor	Chain/sprocket

Note ! *When selecting **DRIVE UNIT** voltage in the Installation setup, the clutch/bypass voltage is always set equal to the motor voltage. If a retrofit installation where e.g. a HLD2000 has a 12V motor and a 24V bypass valve, the bypass valve solenoid has to be changed back to standard 12V version.*

Connecting a reversible pump




Figure 3-5 Connecting a reversible pump

Connecting a hydraulic linear drive




Figure 3-6 Connecting a hydraulic linear drive

Connecting a solenoid valve





Figure 3-7 Connecting a solenoid valve

3.11 Control unit installation

Avoid mounting the control unit(s) where it is easily exposed to sunlight, as this will shorten the lifetime of the display. If this is not possible, make sure the units are always covered with the white protection cover when not used.

Caution ! *Do not install the control unit where moisture at the rear can be present. It could cause damage by entering the breathing hole or by coming into contact with the electrical connectors.*

Panel mounting of AP26




This side towards control unit

The mounting surface must be flat and even to within 0.5 mm.

- Drill the 4 mounting holes and make a panel cut-out according to supplied template.
- Place one of the three supplied gaskets between the panel and the unit with the interlocking feature correctly orientated (see figure).
- Use the supplied screws to fasten the control unit to the panel. **Do not over-tighten the mounting screws!**
- Apply the front panel corners.
- Connect the Robnet2 cable(s) to the control unit connector(s)

Alternative panel mounting of AP26



This side towards control unit

This way of mounting is simpler, but will lift the unit from the panel surface. When installed adjacent to Simrad equipment there will be a difference in height between the autopilot and the other equipment.

- Use the template and drill hole(s) only for the connectors.
- Place all three gaskets between panel and unit with the interlocking feature correctly orientated (see figure).
- Follow above panel mounting instructions but use the supplied 32 mm screws to fasten the control unit to the panel

Do not over-tighten the mounting screws!

Optional bracket mounting

- Locate the cradle on the mounting site and mark the 4 holes for the fixing screws on the mounting surface.
- Drill the 4 mounting holes and screw the cradle to the mounting surface.
- Use the supplied screws to fasten the control unit to the left and right brackets.
- Apply the front panel corners.
- Use the two locking knobs to assemble the cradle with the left and right brackets and adjust the control head to best viewing angle.
- Connect the Robnet2 cable(s) to the control unit connector(s) **(See note on page 64)**.




Figure 3-8 AP26 Bracket mounting

3.12 ROBNET2 network cables

As Robnet2 units have two Robnet2 connectors (blue) they can be used as "jack points" for further expansion of the system. There are no dedicated "in" or "out" connectors. You may connect the cables to any available Robnet2 connector (blue) on the specific unit. The Robnet2 connectors have a locking mechanism for extra safety.

Caution ! *Do not mix the blue Robnet2 cables with the yellow SimNet cables.*

The 15 m cable to the autopilot computer has a connector only at the control unit end. Robnet2 cables with 5 pin male connector at

both ends are available in 1, 5 and 10 m length. For cable extension a Robnet2 T-Joiner is required.

When installing a system, try to minimize the total cable length by connecting all Robnet2 units to the nearest available Robnet2 connector.

Total length of Robnet2 cable installed in a system should not exceed 50 m (165').

Examples of interconnecting Robnet2 units:




Figure 3-9 Interconnecting Robnet2 units

A Robnet2 T-Joiner P/N 24005662 is available to make the Robnet2 interconnection more simple by reducing the number of cables or extend cables when necessary.

See table for pin configuration and colour code of the network cable.

Cable pairs	Color code	Signal
1. pair	Pink	V SYSTEM+
	Grey	V SYSTEM-
2. pair	Brown	Bus-
	White	Bus+
	Yellow	On - Off




Figure 3-10 Robnet2 Connector

Note !

The connectors are weather proof according to IP65, when properly installed. All unused Robnet2 connectors must be fitted with the plastic cap to protect them against dirt and moisture.




Figure 3-11 Control unit connection

J1 and J2 (left) are Robnet2 connectors. J3 and J4 are SimNet connectors.

AP27 connection

If a Simrad AP27 is part of the system, use the Robnet2 connector in a free receptacle (see Figure 3-9). Alternatively cut the connector from the cable and connect the wires in parallel with the cable shown on Figure 3-11 using the same colour code.

Note ! *The AP27 cable contains an air-breathing tube. Check that the tube is open after you have cut the cable.*

3.13 RC36 Rate Compass installation




Figure 3-12 RC36 mounting

The heading sensor is the most important part of the autopilot system and great care should be taken when deciding the

mounting location. As the heading is displayed on the Control Unit, the heading sensor can be mounted at a remote location.

The RC36 rate compass also contains a magnetic heading sensor, so particular attention must be paid to the location. It can be mounted on deck or bulkhead, athwartship or alongship and has a 15 m (99') cable with a Robnet2 connector. The heading offset feature in the autopilot will compensate for the mechanical offsets that may be a result of the selected location and orientation of the RC36.

If the RC36 is deck or bulkhead mounted athwartship with the cable gland pointing aft, little if any offset correction is required. With the cable gland pointing forward a 180° correction is required.

When mounting RC36 on a bulkhead alongship, a +90° or -90° correction is needed dependent on whether it is port or starboard bulkhead.

Note ! *Offset correction is performed after the calibration (see paragraph Note !).*

Find a location that provides a solid mounting place free from vibration, and as close to the vessel's centre of roll and pitch as possible, i.e. close to the water line. It should be as far as possible from disturbing magnetic influences such as the engines (min. 2 meters), engine ignition cables, other large metal objects and particularly the drive unit. On steel hull boats it should be mounted 0,75-1 m above the wheel house on a non magnetic stand.

Use the supplied mounting kit and drill the holes through the centre of the slots in the sensor or the mounting brackets.

Note ! *The compass face plate on the RC36 is the TOP. Never mount it upside down! Level the sensor as close to horizontal as possible.*




Figure 3-13 RC36 connection to autopilot control unit

Plug the RC36 into a Robnet2 connector (see Figure 3-9) or cut the connector from the cable and connect the wires in parallel with the cable shown in Figure 3-11.

3.14 RFC35 Fluxgate Compass installation

(Optional back-up)

The RFC35 Fluxgate Compass is a magnetic sensor, which means you have to take the same precautions at installation as for the standard RC36 (see previous page).

- Connect the RFC35 to the autopilot computer as per Figure 3-14.




Figure 3-14 RFC35 connection

3.15 R3000X Remote Control installation

R3000X should be mounted in the supplied bracket that can be fixed by four mounting screws. The unit is weather proof and can be mounted outdoor.




Figure 3-15 R3000X connection

3.16 JS10 Joystick

Refer to separate installation procedure for JS10 Joystick.

3.17 S35 NFU Lever installation

The unit is mounted to a bulkhead or panel by two screws from the front. The cable is connected to the autopilot computer according to Figure 3-16. Interchange the Port and Stbd wires to the screw terminals if necessary to make the direction of the lever movement coincide with the direction of the rudder movement.




Figure 3-16 S35 connection

The unit is opened by removing the three screws on the back cover. Inside are two sets of micro-switches, a printed circuit board with a plug-in terminal and a jumper strap.

3.18 Interfacing

With the autopilot system there are several possibilities to connect to other equipment for data collection and exchange:

1. Use SimNet
2. Use SimNet via AT10 Universal SimNet/NMEA Converter
3. Connect to a NMEA2000 network or unit
4. The AC10 has a single NMEA0183 input/output port.
5. The AC20 and AC40 have two NMEA0183 input/output ports and Clock Data interface to Simrad and Furuno radars.

The NMEA0183 output may also drive Simrad IS15 instruments directly.

The different connecting diagrams on the following pages illustrate the interface possibilities of the autopilots.

3.19 SimNet

The SimNet cable system with very small plugs in both ends makes it easy to run the cables, only 10 mm (3/8") holes are required through panels and bulkheads. The SimNet accessory program contains the necessary items to make a successful installation.

SimNet network cables

A SimNet unit has one or two yellow SimNet connectors. There are no dedicated “in” or “out” connectors. Find the shortest and easiest way to route the SimNet cables from product to product and select the standard length cables from the SimNet accessory program. SimNet cables are available in 0.3 m (1 ft.), 2 m (6.6 ft.), 5 m (16.6 ft.) and 10 m (33 ft.) length all with plugs at both ends. Connect products with two SimNet connectors in a daisy chain and use drop cable and T-joiner for products with only one SimNet connector.

The SimNet power cable has a red connector with built in terminator.

If you plan to extend your SimNet system in the future it may be an idea to prepare for it by adding a few T-joiners in central locations. The T-joiners provides easy access to the network and can be replaced with a new product, or the new product can be connected via a drop cable.

SimNet power and termination

The following rules should be observed when installing SimNet.

1. It must have a separate 12VDC power from the battery bus or the circuit breaker board to avoid interference
2. It must not be connected to the supply voltage terminals of the Autopilot Computer (introduces interference).
3. It will power and be powered from an IS12 instrument system.
4. It must be properly terminated.

The SimNet network has to be terminated according to the number and type of products connected.

In a small system consisting of maximum 5 SimNet products and a total length of 5 m SimNet cable you need the SimNet power cable with built in termination (red disc on cable plug).

For additional information about SimNet ask for the separate SimNet Manual.




Figure 3-17 SimNet network, small system




Figure 3-18 SimNet network, small system with Wind transducer

Notes !

1. The wind transducer (*) has a built in terminator
2. If there is no wind transducer connected, a SimNet terminator must be connected instead.




Figure 3-19 SimNet/NMEA2000 network, medium system

Notes !

1. Maximum total length of SimNet cable is 40 m (130 ft.) excluding the 30 m (99 ft.) of masthead cable.
2. The wind transducer (*) has a built in terminator
3. If there is no wind transducer connected, a SimNet terminator must be connected instead.
4. A SimNet/NMEA2000 adapter cable (page 125) is required to connect a NMEA2000 device to SimNet, see Figure 3-19. The cable is available at your SimNet dealer.




Figure 3-20 Robnet2 and SimNet network

Simrad AP26 and AP27 Autopilots




Figure 3-21 Robnet2, SimNet and Roblink network

Notes !

1. Maximum total length of SimNet cable is 40 m (130 ft.) excluding the 30 m (99 ft.) of masthead cable.
2. It is not necessary to connect all autopilot control units to SimNet for data sharing. However, if you want to have full redundancy and SimNet control, e.g. select sources, you have to connect the actual unit to SimNet.
3. AT15 is a NMEA0183/SimNet converter for the IS15 Instrument system.
4. AT44 is a SimNet interface that is supplied with CX44 and CX54.

3.20 Single NMEA input/output




Figure 3-22 Single NMEA connection

Caution ! *If an IS15 Instrument is powered from TB14 Vbat+ and Gnd, please observe that Vbat output voltage will follow mains supply voltage (IS15 Compass = 12V only!).*

3.21 Double NMEA input/output




Figure 3-23 Double NMEA connection

3.22 NMEA output on Port 2

Output signal	Output terminal	Output sentence
Continuous output of compass heading at 10 Hz (10x/sec.) Rudder angle output at 5 Hz NMEA format	Autopilot Computer Power PCB. NMEA2, TX2+, TX2-	HDT (True) or HDG (Magn.) depending on heading source. RSA Rudder angle

3.23 NMEA Compass input




Figure 3-24 NMEA compass connection

Note ! *The compass connected to the NMEA In port (RX2) will not be calibrated.*

3.24 Radar Clock/Data




Figure 3-25 Radar Clock/Data connection

3.25 IS15 Instrument installation

For installation and operation of the IS15 instruments refer to separate manuals. There are two options for interfacing the IS15 SimNet (see page 69) and NMEA0183. The SimNet interface is recommended and you need an AT15 Active Tee as an interface item (page 74).

NMEA In

This connection will provide speed, depth and temperature input to the autopilot. If an IS15 Wind Transducer is connected to the system, wind information will also be transferred to the autopilot.

The connection is made by a Roblink cable from the instrument NMEA socket (4) to the Autopilot Computer Main Board, Terminal RX1+ and RX1-. See Figure 3-26.

NMEA Out

This will provide the instrument system with heading data.

The connection is made by a Roblink cable from Autopilot Computer Main Board, terminal TX1+ and TX1- to the instrument NMEA socket (4). See Figure 3-26.

You will need a minimum of two instrument heads to make the system both 'listen' and 'talk' (I/O).

If IS15 Expander is used in the instrument system, the NMEA connections are made to this unit. See Figure 3-27.




Figure 3-26 IS15 Instruments / Autopilot computer connection




Figure 3-27 IS15 Expander / Autopilot computer connection

3.26 External Alarm

The external alarm circuit has an open collector output for an external alarm relay or buzzer. The operating voltage for the circuit is the main supply voltage. Max. load on external alarm output is 0.9 Amp.




Figure 3-28 External alarm connection

3.27 LF3000 Linear Feedback

Caution ! *The rod of the LF3000 is not locked in place in the cylinder. Pay attention as it may slip out of its housing and end up on the seabed.*

The LF3000 is a waterproof feedback unit. It has a 300 mm (11,8") stroke and comes with a special mounting bracket which secures the LF3000 to the cylinder of the existing outboard drive unit.

The 8,5 m (28') cable is terminated in the LFI3000 Mk2 Linear Feedback Interface according to Figure 3-30.

The mounting hardware provided is made to interface with Teleflex HC5340 cylinders and Hynautic K7 and K10 Cylinders. The hardware may not be appropriate for other systems.

Center the drives. Loosely secure the LF3000 to the supplied mounting bracket, across the center of the drive unit cylinder. Either cylinder may be used if there is a dual set up. You may mount the feedback in either direction, i.e. the shaft of LF3000 may point to port or starboard.

Loosen the end bolt (a) used to secure the cylinder to the drive unit mount. Insert the rod retaining assembly (b) and retighten

the bolt. Secure the feedback rod to the retainer plate using the two washers and the cap nut provided. Adjust the location of the LF3000 Linear Feedback to allow full travel of the hydraulic cylinder without causing the retainer plate to hit the end of the cylinder. Check that the outboard motor can be tilted freely. Tighten all nuts and the mounting bracket.

Turn the helm slowly by hand to the stop on either side, check that the rod does not bind in any direction. Make a “drip nose” (c) on the cable to the unit and clamp the cable to allow full engine movement to port and starboard.




Figure 3-29 LF3000 mounting

Electrical connection




Figure 3-30 LF3000/LFI3000 Mk2 connections

This page is intentionally left blank.

4 CONFIGURATION AND SETUP

4.1 First time turn on

Before attempting to turn on the autopilot and perform an Installation Setup, the hardware installation and electrical connections must be completed in accordance with the installation instructions.

The design of the autopilot includes advanced features that have simplified the installation and setup of an autopilot.

This is the start-up screen that is presented the first time you turn on your autopilot by pressing the **STBY/PWR** button.

Notes !

1. You can postpone the automatic interface by going directly to the Installation/Dockside setup. Any time the **STBY** button is pressed the interface prompt will reappear until the automatic interface has been performed.
2. Be aware that you will have no compass reading before the automatic interface is completed.

Continue by pressing the **STBD** (START) button to start the automatic interface.

The autopilot will search for connected sources, and as the sources are detected a black square appears on the screen.

“SEARCHING” is flashing as long as the autopilot is searching for data. When the automatic interface setup is finished, “Done press →” is displayed. Press the **STBD** button to accept. The display will read “SETUP REQUIRED”.

Continue with the installation setup according to the next chapters.

If you already have completed the installation settings, the autopilot will enter **STBY** mode.

4.2 Description of Installation Settings

Note !

The installation settings must be performed as part of the installation of the autopilot system. Failure to do so correctly may prohibit the autopilot from functioning properly!

The Installation menu can only be accessed in STBY mode.

The Installation Settings are grouped into the following functional categories:

- Language: Selection of language used for display information
- Dockside: Items to be set prior to seatrials
- Interface: Setting the format of the clock/data output for radars connected to the Autopilot Computer.
- Display units: Setting the units to be displayed for wind speed, water temperature and depth.
- Seatrial: Presents settings and automatic calibrations to be performed during sea trial.
- Parameters: Permits viewing and changing of basic steering parameters (See also response control page 45).
- Service: System data, NMEA data, NMEA test, SimNet setup, Master reset of memories.

Each group is designed to focus on specific functions and enable quick access when changes need to be made.

Some important points regarding the installation settings:

- When the autopilot is delivered new from the factory AND ANY TIME AFTER A MASTER RESET OF MEMORIES HAS BEEN PERFORMED, the installation settings are all reset to factory preset (default) values. The automatic interface prompt will appear (see page 83) and a complete setup has to be made.
- The values that are selected from within the Installation Settings Menu, are stored in the memory of the autopilot system. No specific action is required to "SAVE" the selected values. Once the value is changed, it is stored until the next time the menu item is selected and changed.

- The Installation Settings are global except for display units and language, enabling settings to be distributed to all control units in the system.
- The Seatrial settings are dependent on successful completion of the Dockside settings.

4.3 Installation Menu



The Installation Menu is presented on the autopilot display by pressing and holding the **NAV/WIND/SETUP** button for 5 seconds.

Note !

The INSTALLATION MENU is different from the USER SETUP MENU. Refer to the flow diagram on the next page for a pictorial view of the Installation Menu.

Navigate through the Installation Menu as follows:

- Answer YES to a question by rotating the course knob clockwise.
- Answer NO to a question or proceed to the next menu item by pressing the **STBD** button.
- Return to the previous menu item by pressing the **PORT** button.
- Change the selected item by rotating the course knob in either direction.
- Exit the Installation Menu by pressing **STBY**, **AUTO**, or **NAV/WIND** buttons.

When using the Installation Menu, refer to the diagram "Installation Menu Flow Chart" on next page.

Note !

You may proceed through all items in the installation menu by continuing pressing the STBD button.




Figure 4-1 Installation Menu Flow Chart

Language selection

To access the language selection in the Installation Menu, confirm “Yes” by turning the course knob clockwise

The autopilot can present the display text in eight different languages:

English, Deutsch, Francais, Espanol, Italiano, Nederlands, Svenska and Norsk.



Turn the course knob to select the language you wish to use.

Continue to next item in the menu by pressing the **STBD** button, or leave the menu by pressing the **STBY** button.

4.4 Dockside settings

The following menu items are accessible and can be set up in the Dockside Menu:

- Boat type
- Drive Unit voltage
- Rudder Feedback calibration
- Rudder test
- Drive engage
- Rudder deadband

When Sail is selected as Boat type the following menu items are also accessible in the Dockside Menu:


- Wind setup
- Min. wind angle

If Wind setup is set to RACING the following items are added to the menu.

- Separate (port, stbd) wind angle limits
- Tack angle
- Tack time
- Wind shift limit

Select STANDBY mode and enter the Installation Menu as previously described. Select *Dockside* by pressing **STBD** button and confirm by rotating the course knob clockwise.

Boat type



Actual boat type is selected by turning the rotary course knob. The options are: Planing, Displacement and Sail.

Type of boat selected will affect the steering parameters, and the functions available in the autopilot system. Select appropriate *Boat type* and press **STBD** button.

Drive unit voltage

Set the drive unit voltage to correct level. The selections are 12V, 24V, or 32V and should be set to the voltage specified for your drive unit.


Refer to the drive unit table on page 58 for information.

The drive engage/bypass clutch output follows the same voltage as set for the drive unit. It is not possible to select a higher voltage than the input voltage.

Note !

Selection of improper voltage level for your drive unit may damage both the drive unit and the autopilot computer even if the protection circuits in the autopilot computer are activated.

During the Rudder Test, the autopilot system will automatically detect whether the drive unit is a reversible motor or a solenoid is operated.



To change the voltage selection, rotate the course knob.

Note !

The drive unit voltage setting does not apply when operating solenoids on a continuous running pump/steering gear. Hence, the output voltage to the solenoids will be the same as the input voltage.

Proceed to next menu item by pressing **STBD** button.

Rudder Feedback Calibration

Make sure the RF300 is installed and aligned as pr. instruction in section 3.6 (or eventually section 3.27 for LF3000). This function enables you to compensate for any non-linearity in the transmission between the rudder and the rudder feedback.



Confirm Rudder feedback calibration to STBD by turning the course knob clockwise.

Manually turn the helm/wheel to starboard until the rudder stops at starboard lock (H.O.).



The value on the display is the angle read by the rudder feedback unit before any adjustment is made.

If the actual rudder angle is different from that of the display, correct the reading by turning the course knob clockwise to increase the value or counter clockwise to decrease the value. See note.

Advance to the next step by pressing the **STBD** button.

Manually turn the helm to port until the rudder stops at maximum port rudder.

Adjust the displayed angle the same way as for starboard rudder.

Note !

Many boats have $\pm 45^\circ$ (90° H.O. - H.O.) rudder angle as standard. So if you are not making any adjustment to the display readout (i.e. not turning the course knob), the autopilot will set a (default) value of 45° to each side. However, you should always simulate an adjustment by tuning the course knob forwards and back again. This is necessary to prevent the rudder from hitting the end stops.

Rudder zero may still be inaccurate and should be adjusted later during sea trial.

Proceed to next menu item by pressing **STBD** button.

Rudder Test

Note ! *If the boat uses power assisted steering, it is important that the engine or electric motor used to enable the power assist steering be turned on prior to this test.*


Bring the rudder manually to midship position before starting the test.

Caution ! *Stand CLEAR of the wheel and do not attempt to take manual control of the wheel during this test!*




Rudder test
Motor 010%
Clutch/Bypass
NOT Installed

Activate the automatic rudder test by turning the course knob clockwise.



Testing
rudder
101

The autopilot will after a few seconds issue a series of PORT and STBD rudder commands and automatically verify correct rudder direction. It detects minimum power to drive the rudder, and reduces the rudder speed if it exceeds the maximum acceptable speed (8°/sec.) for autopilot operation.



Motor OK

The **Rudder test** is verified by the display showing 'Motor OK', 'Solenoids OK', or 'Failed'. If 'Failed' is given, check for correct electrical connection.



Rudder test
Motor 100%
Clutch/Bypass
NOT Installed

The *Motor Drive out* (displayed in percentage) is the amount of maximum available power needed to achieve correct rudder speed on automatic steering (Maximum speed is used in NFU mode).

The screen also tells whether a clutch is installed or not.


If the Automatic rudder test fails, refer to "Alarms" beginning on page 118.

Test of LF3000/LFI3000 Mk2 feedback

1. *Align engines to centre position; “zero rudder”.*
2. *Rev engines to 3-4000 rev/min and observe the rudder angle indicator on the autopilot, a 2° change in the reading should be accepted.*
3. *If the rudder angle exceeds 2°, connect the screen on the TBI cable to the centre block terminal and repeat item 2 (See Figure 3-30). If this gives a better result keep the screen connected.*

Proceed to next menu item by pressing **STBD** button.

Drive engage



This determines the use of the autopilot computer drive engage port. The port voltage is the same as the selected drive unit voltage. Drive engage has the following settings:


Bypass/clutch:

The port will activate (go high), in all autopilot steering modes, and typically engages a bypass valve on a hydraulic linear drive or a clutch on a mechanical drive when entering any of the active autopilot modes. This is the default setting and it allows you to steer the boat with the helm or wheel when in STBY or DODGE modes.

Auto:

This setting is implemented for future use. Always use the “Bypass/clutch” (default) setting.

Rudder Deadband



The rudder deadband function is adaptive and is continuously operative. It prevents the rudder from hunting and the adaptive function optimizes the deadband to the speed of the boat and the pressure on the rudder.

If the auto-setting does not perform properly due to high inertia from the wheel or a loose steering gear, it can be adjusted manually.

Adjust the *Rudder deadband* by rotating the course knob. Find the lowest possible value that will prevent the rudder from hunting. A wide deadband will cause inaccurate steering. It is recommended to check rudder stability and accuracy in FU-mode when the boat is moving to get pressure on the rudder.

Range: AUTO, 0.1° to 4.0° in 0.1° increments.

Default: AUTO.

Proceed to the next menu item by pressing the **STBD** button.

Wind setup

Wind setup is only available if 'Boat type' is set to 'Sail' in the Installation/Dockside menu.



Wind setup has two levels: NORMAL and RACING. The RACING level will give access to more wind setup items to achieve optimal performance when sailing.

Additional setup items also become available in the User setup and the Quick setup menus.

Range: NORMAL and RACING

Default: NORMAL

Minimum wind angle (NORMAL)



The 'Minimum wind angle' is the minimum apparent wind angle that will keep the sails well shaped and give an acceptable thrust. This parameter will vary from boat to boat.

The 'Minimum wind angle' applies in the tack-prevent function. It also applies when the autopilot is navigating in Wind mode.

Range: 15 – 90°

Default: 30°

Minimum wind angle (RACING)



If 'Wind setup' is set to RACING, you can set different minimum wind angles for port and starboard.

The difference between port and starboard wind angles will be taken into account when calculating the Estimated Time to Turn (ETT) and Distance To Turn (DTT).

The minimum wind angle also applies when the autopilot is optimising the VMG (available parameter in the Quick setup menu when 'Wind setup' is set to RACING).

Range: 15 – 90°

Default: 30°

Tack angle (RACING)




The autopilot can tack also in AUTO-mode. The set tack angle replaces a similar change of the set course using the course knob.

Range: 50 – 150°

Default: 100°

Tack time (RACING)



When performing a tack in WIND-mode, the rate of turn can be limited. This will give single handed sailors time to handle the boat and the sails during a tack.

The tack time is the time needed for the sailor to initiate the tack, start using the winches and hauling the foresail from one side to the other.

A turn performed without shifting the wind side, will also be made at a reduced turn rate. Shifting wind side when gybing, however, is an instant action from the autopilot.

Range: 2 – 50 seconds

Default: 12s

Wind shift alarm limit (RACING)



The monitored wind shift in WIND mode is the wind shift angle measured from the last time the wind angle was set on the autopilot. If this wind shift exceeds the 'Wind shift alarm limit', a wind shift alarm will be activated.

The wind shift monitoring can be turned off by setting the 'Wind shift limit' to 'OFF'.

Note !

A wind shift reading is also presented in the 'Wind shift'-display. This is the change of wind direction measured from the last time the autopilot mode was changed, e.g. STANDBY to AUTO, AUTO to WIND. This wind shift reading is for information only, and not to activate the wind shift alarm.

Range: OFF, 2 – 90°

Default: 30°

4.5 Interface Settings

Sets the format of the clock/data output for radars connected to the Autopilot Computer.



Step to the Interface part of the Installation Menu.

Turn the course knob clockwise to access the Interface Setup items.




Use the course knob to select the connected type of radar.

Note ! *This setting is not available in the AC10 Autopilot Computer.*

4.6 Display units



Select *Display units* by pressing **STBD** button and confirm by rotating the course knob clockwise. This screen gives access to the display unit set-up of the *Wind Speed*, *Sea temperature* and *Depth*. The setup is local to each control unit.



Use the **STBD** button to select an item and the course knob to select the unit.

Available units are:



Wind Speed: Knots (kt) or meter/second (m/s)

Sea temperature: Fahrenheit (°F) or Celsius (°C)



Depth: Meter (m) or feet (ft)

Exit the Display units menu by pressing **STBD** button to proceed to the Sea trial menu, or press **STBY** to return to normal autopilot operation.


4.7 Sea Trial

Caution ! *The Sea Trial must always be performed in open waters at a safe distance from other traffic.*

The Sea-trial menu can only be accessed if the Dockside Settings are completed and confirmed.

The seatrial settings are:

- Rudder zero adjust (To tell the autopilot the precise midships position of the rudder)
- Minimum rudder
- Compass calibration (To automatically compensate for onboard magnetic interference)
- Compass Offset (To compensate for a fixed offset (A-error) in the final compass heading readout)
- Wind Offset (To compensate for a fixed mechanical offset of the Wind vane)
- Wind Damping (To avoid flickering on the wind display)
- Depth offset (To compensate for the distance between the depth transducer and the surface if required)
- Automatic tuning (A method of determining the steering parameters)
- Transition speed (the speed at which you want a power boat to change steering parameters)
- Init NAV (to set the response you prefer when steering onto a track in NAV mode)
- Drive output adjust (See Dockside Rudder Test page 90.)




Select *Seatrial* by pressing the **STBD** button and confirm by rotating the course knob clock-wise.

Set Rudder zero

This adjustment should be made in calm sea and side forces from wind or current should be avoided.

- Bring the boat up to cruising speed, and head directly into the wind.
- If the boat has twin engines, synchronize the engine RPM's.
- Set the trim tabs and stabilizers to have no effect on the boats heading.
- Steer the boat manually on a steady course.
- Confirm the rudder ZERO position by rotating the course knob clockwise.



Press **STBD** to proceed to next menu item.

Minimum rudder

Some vessels may have a tendency of not responding to small rudder commands around the “course keeping” position because of a small rudder, a rudder deadband or whirls/disturbance of the water-stream passing the rudder.

By turning the Minimum Rudder function ‘On’, it may improve the course keeping performance on some boats, but will increase the rudder activity.



Turn the minimum rudder on by turning the rotary course knob.


Range: OFF-ON.

Default: OFF

Note !

Only set Minimum Rudder to ON if it proves to give a better course keeping performance in calm sea.

Compass calibration



This function will activate the compass calibration procedure for Simrad compasses connected to Robnet2 and the Autopilot Computer terminals (HS).

Notes !


1. *The RC36 Rate Compass that comes with the autopilot as standard will store the calibration and off-set data in its own memory.*
2. *Compass calibration for a second compass connected to the HS terminal will be stored in the Autopilot Computer memory.*
3. *Calibration is made on the compass that is active for the autopilot. The active compass is the one that is displayed on the compass calibration screen.*

RATE-0 = Rate compass, FLUX-0 = Fluxgate compass on HS terminals.

4. If an optional NMEA compass from Simrad or another manufacturer is installed, also refer to the optional compass' manual regarding calibration. This compass will not be calibrated by the autopilot.

Before you start the compass calibration, make sure you have enough open water around you to make a full turn with the boat.

The calibration should be done in calm sea conditions and with minimal wind to obtain good results. Use about 60-90 seconds to make a full circle.



Increase speed: >>>>>

Decrease speed: <<<<<<

Appropriate speed: > <


1. Select the 'Calibration' item on the display
2. Begin turning the boat (port or starboard).
3. Confirm start of calibration by turning the course knob clockwise. The display will flash "Calibrating". Establish your turning rate using the arrows in the display.

4. When the calibration is completed, (after having made approximately 1 1/4 turns), it will be confirmed by the display reading “Confirmed”.

Compass deviation

The heading from a magnetic heading sensor will normally have a deviation when compared with the actual direction of the earth’s magnetic field. This is caused by interference from the boat’s local magnetic field. The deviation will be at a minimum if the compass is placed as far as possible from any magnetic object on board. On the other hand, you may have to compromise with other requirements for the installation of the compass (page 65).

During the calibration, the compass will measure the magnitude and direction of the local magnetic field from where the compass is mounted. The magnitude is given in % of the magnitude of the earth’s magnetic field. If the local magnetic field is stronger than the earth’s magnetic field (the local field is reading more than 100%), the compass calibration will fail. If the local field is reading more than 30%, you should look for any interfering magnetic objects and remove them, or you should move the compass to a different location. The local field angle will aid you to the local interfering magnetic object. See drawing.



Note !

In certain areas and at high latitudes the local magnetic interference becomes more significant and heading errors exceeding $\pm 3^\circ$ may have to be accepted.

Compass Offset

After calibration, also check the compass readout against a known reference, a compensated compass or a bearing. If the reading has a fixed offset, proceed to next menu item by pressing **STBD** button or return to STANDBY mode by pressing the **STBY** button.

Note ! *Offset correction is always performed after the calibration. If you use COG as a reference for the offset remember it has to be a magnetic reading.*

The compass OFFSET feature allows you to correct for a fixed heading offset. This offset may be present as a result of the compass being installed with a lubber line offset or if a fixed offset remains after the calibration procedure has been completed. The value of compass offset is specific to the heading sensor that is selected at the time the offset is entered. This means that you can have individual offsets for each compass installed.



Select the amount of correction by turning the course knob to offset the heading to agree with the known, accurate heading. The *Offset* value can be either positive or negative.

Note ! *If an OFFSET still exists after having compensated for it, one of the following problems may still exist:*

- The heading reference to which you are comparing the compass is not correct.
- The automatic calibration is not correct. Refer to above “Compass deviation”.

Proceed to the next menu item by pressing the **STBD** button, or return to Standby mode by pressing the **STBY** button.

Wind Offset

Note !

This offset only applies if you have a wind transducer directly connected to SimNet (IS12TW) or a wind transducer that outputs data on NMEA2000 format.

The Wind Offset feature allows you to correct for a fixed wind angle offset. Steer the boat directly into the wind with a damping of 15s. Keep the bow a steady heading for 15-20 sec. and read the wind angle. If necessary turn the course knob to input an off set that makes the display read Wind 000°.



The *Offset* value can be either positive or negative.

Wind damping



Damping of the apparent wind angle is made by the Advanced Wind Filter (AWF) in the Autopilot Computer.

The inputs to the AWF are heading, boat speed, apparent wind angle and wind speed. Verify that these inputs are available in User Setup/Source Select.

Heading sensors, speed sensors and wind sensors have variable performance. The measured wind angle can be very erratic when the boat is rolling heavily. In such conditions the AWF gives a better result when the calculations are based more on heading and boat speed inputs to achieve the correct apparent wind angle. Increasing the 'Wind damping', will make the AWF depend more on heading and boat speed to calculate the correct apparent wind angle. Decreasing the 'Wind damping', will make the AWF depend more on the "raw" apparent wind angle data.

The boat speed input to the AWF is primarily Speed Over Ground (SOG). If this is not available, the AWF will use speed through water. If none of these are available, the AWF will use a boat speed that is 1.5 times the the Transition Speed set in the Installation/Seatrial menu.


Range: 1 – 100 seconds

Default: 15 seconds

Depth Offset

Note !

This adjustment only applies to “smart” depth transducers that outputs depth on NMEA2000 format. NMEA0183 sentence ‘DPT’ contains offset and the depth reading is from the surface. NMEA0183 sentence ‘DBT’ contains no depth offset and the reading will be from the position of the transducer.



When the depth offset is set to zero, the indicated depth is from the transducer to the bottom.

To read the depth from the water surface to the bottom you have to set the depth offset according to the vertical distance between the surface and the transducer, i.e. positive (+) value. If you want to indicate the depth from the keel to the bottom you have to set the depth offset according to the vertical distance between the transducer and the keel, i.e. negative (–) value.

Automatic tuning

Automatic tuning is a feature that automatically sets the two main steering parameters (Rudder and Counter Rudder) by taking the boat through a number of S-turns. The scaling factors of the parameters are also set automatically as a function of the boat type selection performed in the Dockside menu.

Automatic tuning is an optional procedure that is not required for the autopilot to function. The autopilot is preset with steering parameters that should steer most boats in the 30 - 80 foot range. It is, however, recommended to perform an automatic turning as part of the sea trial.

Recommended speed during *Automatic tuning* varies with the type of boat, but should not exceed 10 knots.

Note !

Automatic tuning should not be performed at planing speed!

For displacement boats use a speed that is approximately half the normal cruising speed (i.e. if cruising speed is 10 knots, perform the *Automatic tuning* at about 5 knots).

The parameter values calculated during *Automatic tuning* becomes the HI parameters. The LO parameters are automatically set to 66% of the HI.

It also is recommended to perform the *Automatic tuning* steering East or West, as this will yield the best balanced parameters.

Note ! *After the Automatic tuning has been completed the rudder must be controlled manually, as the autopilot has returned to STBY mode.*

Caution ! *The Automatic tuning function will take control of the boat and perform a number of S-turns. It must always be performed in open waters at a safe distance from other traffic. The Automatic tuning function may take from 1 to 2 minutes to complete. To stop the Automatic tuning, press the STBY button.*



Activate the Automatic tuning, by rotating the course knob clockwise. The display will flash “Automatic tuning”.

After an *Automatic tuning*, there should be no need for further adjustments. “Fine tuning” of these parameters are made by the response control (see page 45). However, viewing or changing the parameters can be made from within the Parameters menu item. See also “Recall Autotune” on page 107.

Proceed to the next menu item by pressing the **STBD** button, or return to Standby mode by pressing the **STBY** button.

Transition Speed

The transition speed is the speed where the autopilot will automatically change the steering parameter set from HI to LO parameters, or vice versa (page 23).

The default setting of transition speed is 5 kts.

It is recommended that you set the transition speed to a speed that represents the speed where the hull begins to plane, or the speed where you change from slow to cruising speed.

The speed used for the automatic transition is obtained with the following priority:

1. Speed through water from the speed log source.
2. Speed Over Ground (SOG) from the GPS/Chartplotter.

If no speed data is available, manual speed selection is required. See also chapters 2.9 and 2.10.



Rotate the course dial clockwise until the transition speed is set to the desired value in knots.


Range: OFF – 30 knots

Default: 5 knots

Proceed to next menu item by pressing **STBD** button.

Init NAV

Sets a firm or soft approach to the track line when entering the NAV mode at the first leg. The approach angle is dependant (adaptive) on the distance (XTE) from the track line and the boat speed.



Select firm or soft approach to the track line by rotating the course knob.

Range: Firm - Soft

Default: Firm

Proceed to the “**Parameters**” item by pressing the **STBD** button or return to STANDBY mode by pressing the **STBY** button.

4.8 Parameters



To access the Parameters, rotate the course knob clockwise.





A boats steering parameters found by the Automatic tuning can be looked at and if needed changed under this menu item. The steering parameters can also be set manually instead of performing an Automatic tuning. The parameters are divided into two sets:


- HI value parameters for automatic steering at low speed with a power boat and when running with a sailboat.
- LO value parameters for automatic steering at high speed and when sailing into the wind or reaching with a sailboat.

Step through the menu items by pressing the **STBD** or **PORT** buttons. Adjust the value by rotating the course knob.

Manual parameter adjust

Displayed parameter	Boat type		Own boat	
	Displacem. & Sail	Planing	Automatic tuning	Manual
LOW				
Rudder LO	0.35	0.20		
Cont.Rudder LO	1.00	1.00		
Autotrim LO	40 sec.	40 sec.		
Rudder Lim LO	20°	20°		
HIGH				
Rudder HI	0.50	0.30		
Cont.Rudder HI	1.40	1.40		
Autotrim HI	40 sec.	40 sec.		
Rudder Lim HI	20°	20°		

Use course knob to adjust parameters





Use PORT and STBD buttons to step through parameters

Note ! *The values in the table are factory set (default) and listed for information only. After having performed the Automatic tuning, the values may differ from those listed in the table. See also “Automatic Tuning” previously in this chapter.*

The two most important parameters that determine the performance of the automatic steering are Rudder and Counter Rudder.


Rudder sets the rudder gain which is the ratio between the commanded angle and the heading error.




- Too little Rudder and the autopilot fails to keep a steady course.
- Too much Rudder gives unstable steering and reduces speed.
- Low speed requires more Rudder than high speed.

Counter Rudder is the parameter that counteracts the effect of the boats turn rate and inertia. For a short time period it is superimposed on the proportional rudder response as provided by the heading error. It may sometimes appear as if it tends to make the rudder move to the wrong side (counter rudder).

The best way of checking the value of the Counter Rudder setting is when making turns. The figures illustrate the effects off various Counter Rudder settings.





Autotrim standard value is 40 sec. which should work well on most boats.

Rudder Limit should be kept at 20 degrees unless there is a need for more rudder when performing dockside manoeuvres.

Recall Autotuned?



To recall the parameter values that were achieved during the *Automatic tuning* procedure, rotate the course knob clockwise. When parameter values are recalled, *Confirmed* is displayed.

Exit the Parameter menu by pressing **STBD** button to proceed to the Service menu, or press **STBY** to return to normal autopilot operation.

4.9 Service Menu


Select STANDBY mode and then enter the Installation Menu by pressing and holding the **NAV/WIND/SETUP** button for 5 seconds. Select "Service by pressing the **STBD** button and confirm by rotating the course knob clockwise.



System data and *SimNet/NMEA data* are test functions to analyze data processed by the autopilot.

To exit the menu, press any mode key (STBY, AUTO or NAV).

System Data Menu



```
Service
SYSTEM DATA
```

Select *System data* by rotating the course knob clockwise.

Step through the menu by pressing the **STBD** button. The menu provides you with additional system data that can be useful when testing or trouble shooting the system.




```
Steer compass
356°M
Rudder
S 00.07
```

Steer compass

Steering Compass readout, M=Magnetic, T=True

Rudder

Rudder angle. Normally between zero and 45 degrees.



```
Input voltage
25 V
```

Input voltage

Mains voltage on input terminals.



```
Drive out
078%
Clutch/Bypass
installed
```


Drive out

Power needed to drive the unit in percent of full (100%) to get satisfactory rudder speed.

Clutch/bypass

Verifies if a clutch or bypass valve has been activated when performing the rudder test.

SimNet and NMEA Data Screen



```
Service
SimNet/NMEA
DATA
```

Select the screen by pressing the **STBD** button and confirm by rotating the course knob clockwise.

Step through the menu by pressing the **STBD** button. The menu provides you with status information about the different SimNet and/or NMEA messages used by the system.

OK XTE L 0.991nm OK BWB 270°	OK BPW 270°
OK Latitude N 00°14.499' Longitude E 000°01.761'	OK COG 356° SOG 8.0kt
OK Wind L 016°A 13.10kt	OK Speed 08.10kt OK Depth 100.3m

Decoding

The incoming signals are decoded according to a built in priority table in the autopilot. Cross Track Error and bearing information are taken from the NMEA messages with highest priority.

For all data items, one of the following codes will be displayed:

- No data or no NMEA sentence containing the data needed is available at the input port.
- OK Valid data found
- INV Message with invalid information.
- FRM Message has format failure such as
 - a) Incorrect check sum
 - b) Wrong contents in datafield(s)

If data are missing or invalid, perform the following:

- Check the NMEA signal monitor (see below)
- Open the source select page in the User Setup menu and check that data are available
- Check the navigator setup and make sure it is transmitting appropriate data.
- Perform a NMEA Port Test (hardware) as per below.

Note !

The "WIND" reading is the apparent wind from the port (L) or starboard (R). The "SPEED" reading is the speed through water.

NMEA signal monitor


Near the NMEA terminals in the Autopilot Computer you will find a green monitor LED marked “RX”. A flickering LED indicates that a NMEA signal is received. It does not, however, qualify the contents of the message.

Note !

Do not mix up the “RX” LED with the LED marked “TX”. The “TX” LED will always be lit or flickering when the autopilot is on.


NMEA Port test (AC hardware)

Disconnect the cables on the Main PCB in the Autopilot Computer and connect TX1+ to RX1+ and TX1- to RX1-. Similarly, on the Power PCB connect the NMEA ports the same way; TX2+ to RX2+ and TX2- to RX2-.



```
Service
NMEA 0183
Port test
```

Under *Service* in the Installation Menu, select *NMEA port test* by pressing the **STBD** button and confirm this by rotating the course knob clockwise.




```
Loopback1 OK
Loopback2 NO
Checksum1 OK
Checksum2 OK
```

Verify that the hardware is OK. If not, replace the corresponding PCB(s).

Proceed to the SimNet Setup menu by pressing the **STBD** button, or press **STBY** to return to normal autopilot operation.

SimNet setup



```
Service
SimNet setup
Sn 00000
```

Under *Service* in the Installation Menu, select *Simnet setup* by pressing the **STBD** button and confirm this by rotating the course knob clockwise.

Sn 00000 is the unique SimNet ID number for the specific autopilot control unit.



```
Group select
SIMRAD
Backlight
STAND ALONE
```

Group selection

SIMRAD: Autopilot is part of the Simrad Group. Source selection will be common for the

products in the group (synchronized).

STAND ALONE: Source selection for the autopilot will not be transferred to other products in the Simrad Group (no synchronization).

```
Group select
SIMRAD
Backlight
ILLUM BANK1
```

Backlight Illumination

Set backlight to synchronize with one of the illumination banks (1-3) available on the SimNet, or to STAND ALONE for individual control of the autopilot illumination.

Instance number

An item to identify units by a number when the autopilot is connected to a NMEA2000 Network. On SimNet units the Instance number is added to the product name e.g. AP26-1, AP26-2 for easy identification on various display screens.

```
Instance
number 00
SimNet gateway
Yes
```

SimNet gateway

Indicates which control unit that transmits and receives information on SimNet. The display verifies by reading 'Yes', all other units read 'No'.

```
SimNet setup
Global SimNet
reset
```


Global SimNet reset

Resets the entire SimNet setup in the Simrad Group and initiates a new automatic interface setup. See chapter 4.1.

Master Reset

Note !


A Master Reset is part of the final test at the factory, which will reset the memories to factory settings. Unless you need to clear all stored values during the installation setup procedure, you should not perform a Master Reset.



Service
Master reset
of memories



Service
Turn CCW
to reset



Service
Master reset
Confirmed

Under *Service* in the Installation Menu, select *Master reset of memories* by pressing the **STBD** button and confirm this by rotating the course knob clockwise.

The Master Reset needs a double confirmation to prevent an accidental reset. To perform a Master Reset, rotate the course knob clockwise and observe the display; then rotate the course knob counter clockwise. The display will then read: “Master Reset confirmed”.

Unless you have made a Master Reset, exit the Installation Menu by pressing **STBY** to return to normal autopilot operation.

In the event a Master Reset has been made, refer to chapter 4.2.

Final sea trial

After having completed all settings in the Installation Menu, take the boat out and perform a final sea trial in open waters at a safe distance from other traffic.

- Steer the boat on all cardinal headings in AUTO mode.
- Start with low and medium speeds to get familiar with the response from the autopilot.
- Try the effect of LO and HI parameter settings.
- If the hardware for automatic HI/LO selection is connected and configured, verify that the HI/LO transition is occurring, and the HI/LO parameters are changing after the transition speed is crossed (by more than 1 Knot higher or lower speed).

- Try the Dodge and U-turn function.
- If a Non-Follow Up lever (or handheld remote) is connected, test change of modes and verify port and starboard steering commands of the lever.
- Set waypoints into each navigator connected to the system, and verify that the autopilot steers in NAV mode for each NAV source.
- If the boat is a sailboat use the WIND mode and try the autopilot at different settings of the apparent wind angle. Also try the WINDN(av) mode, optimized VMG and WCV when sailing (tacking) to a waypoint.
- Provide the owner with user training.

Providing user training

The user should be instructed in the "basic" operational functions, such as:

- Turning the system on and off
- Changing modes. Explain briefly what takes place in the different modes.
- Regaining manual control from any mode. Point out in what modes the helm is engaged by the autopilot (bypass/clutch).
- Taking command at an "inactive" station, if applicable.
- Using the lock mode, how to lock/unlock and how to shut the system down from a locked control unit, if applicable.
- Use of the Non-Follow-up and Follow-up steering modes and learning the difference between the two.
- Use of a Non-Follow-up and Follow-up controller, if connected.
- Changing course by rotary knob and buttons.
- Moving through the User Set-up Menu learning how to (and why to) change the settings.
- How to select alternative sources for heading (compass), navigation (GPS), chartplotter), speed, depth etc. if available.
- Locating compasses and knowing to keep magnetic items away.

- Locating the Mains circuit breaker and the separate SimNet circuit breaker if provided.

5 MAINTENANCE

5.1 Control unit

The AP26 and AP27 Control Units will under normal use require little maintenance.

If the unit requires any form of cleaning, use fresh water and a mild soap solution (not a detergent). It is important to avoid using chemical cleaners and hydrocarbons such as diesel, petrol etc.

Make sure that all open Robnet2 connectors are fitted with a protection cap.

It is advisable at the start of each season to check all connections to the control unit head and cover with Vaseline or WD40. If the Control unit is not removed from the boat, it should be covered with the white protection cover.

5.2 Autopilot Computer

No special maintenance is required. It is advisable, however, at the start of each season to make a visual inspection of the internal and check all connections.

5.3 Rudder Feedback

Make a visual inspection at 2-3 month intervals and at the start of each season. Apply some grease at the ball joints when required (RF300)

5.4 Compass

If the compass is exposed to the weather, make a visual inspection at 2-3 months intervals, and at the start of each season.

5.5 Drive unit

Refer to the drive unit manual for maintenance instructions.

5.6 Exchange of software programme

Autopilot Computer





Figure 5-1 AC10/AC20/AC40 Main PC-Board

- Remove the EPROM from the socket by means of the special extraction tool (p/n 44139806).
- Insert the tool by pressing the two grip pins down into the two slots in the corners of the socket.
- Squeeze the tool and pull out the EPROM.
- The identification tag indicates:
 - Name of unit
 - Part number
 - Software version




Caution!

When inserting a new EPROM, make sure the cut-off corner matches with the one in the socket. Press it gently into the socket.

EPROM for AC10, AC20 and AC40
Autopilot Computers: P/N 22088462

After change of EPROM, perform a master
reset as described on page 112.




Autopilot Control Unit

You will need a special kit for a PC to perform the programming of the Control Unit. Order the following from Simrad:


Programming kit P/N 22088595.

Instructions are included.



Software
download
connector

Figure 5-2 Part of AP26 PCB



Software
download
connector

Figure 5-3 Part of AP27 PCB

Remove the cables and unscrew the screws that secure the back cover. Apply a firm pull with your fingers to pull the back cover loose from the connector pins. Then you have access to the software download connector.

6 TROUBLE SHOOTING

An autopilot is a complex system. Its performance depends on a proper installation and a successful sea trial.

In the event of an autopilot failure, the autopilot's numerous test features will assist you in isolating a probable fault.

Audible and visual alarm is provided for every fault being detected.

The audible alarm is reset by pressing any button (e.g. by changing mode from AUTO to STANDBY). All visual alarms will remain and alternate with the operating display until the fault has been rectified. Refer to the table below for hints and try to solve the problem yourself. You may also consult your nearest Simrad dealer for assistance, if required.

Perform any repair action in the listed sequence.

Notes!

1. *'Compass difference', 'Vessel off course', and 'Rudder limit' warnings are automatically reset when the error is rectified.*
2. *--- in a display indicates that data is missing.*

6.1 Alarms

Display readout	Probable fault	Recommended action
System failure Alarms:		
The boat is off course	Boats heading is outside fixed off course limit of 20 deg. (Automatic reset when inside limit.) Extreme weather conditions, too slow speed.	<ol style="list-style-type: none"> 1. Check steering parameters (Rudder, Autotrim, Seastate-filter). 2. Increase Rudder value 3. Increase boat speed, if possible, or steer by hand.
NAV. data failure	Missing or invalid NAV data.	<ol style="list-style-type: none"> 1. Check the Nav. Receiver/GPS setup. 2. See <i>Service menu</i> Chapter 4.9.

Display readout	Probable fault	Recommended action
Shallow water (Only if AP25 is part of the system)	The depth is inside the set limit or outside the range. Depth data is missing.	<ol style="list-style-type: none"> 1. Carefully observe the actual depth. 2. Adjust the alarm limit if not hazardous. 3. Steer to safe depth, the alarm will reset automatically. 4. Turn off the shallow alarm if depth data is missing.
Compass data missing	No data from selected compass.	<ol style="list-style-type: none"> 1. If more than one compass is connected to the system, refer to the <i>User Setup2/Source select</i> menu to select a different compass. 2. Make a source update if no compass is available. 3. Check connections. 4. Replace compass PCB (<i>Note: Do not cut cables. There are screw terminals inside</i>).
Rudder feedback failure (autopilot operates on simulated feedback)	Rudder feedback signal missing or erratic	<ol style="list-style-type: none"> 1. Check all connections. 2. Check the alignment as per the installation instructions 3. Replace rudder feedback unit.
Rudder response failure	No response to rudder command	<ol style="list-style-type: none"> 1. Check all connections 2. Check Rudder FB transmission link. 3. Check drive unit motor/brushes. 4. Replace the Autopilot Computer Power PCB.
Rudder too slow	Excessive load on steering gear. Air in hydraulic system. Insufficient drive unit capacity.	<ol style="list-style-type: none"> 1. Look for mechanical obstructions at the rudder/tiller/quadrant. Check the back drive force. 2. Bleed the hydraulic system. 3. Replace with bigger pump unit.

Display readout	Probable fault	Recommended action
Rudder test failed	<p>Following conditions may exist:</p> <ul style="list-style-type: none"> a) Rudder feedback failure b) Autopilot Computer current overload c) Bypass/clutch overload 	Refer to recommended actions for the specific probable faults.
	<p>Rudder moves in only one direction</p> <ul style="list-style-type: none"> a) Poor connection to one of the solenoids (continuously running pump) b) Faulty Power PCB in autopilot computer 	<ul style="list-style-type: none"> a) Check the connections b) Replace the Autopilot Computer Power PCB
	<p>Rudder test not completed within 2 min.</p> <ul style="list-style-type: none"> a) Poor connections to the drive unit b) Faulty Main PCB in the Autopilot Computer c) Faulty Power PCB in the Autopilot Computer 	<ul style="list-style-type: none"> a) Check connections b) Replace the Main PCB c) Check the Power PCB for traces of burned transistors. – Change Power PCB.
	<p>Rudder moves at full speed to one side.</p> <ul style="list-style-type: none"> a) Faulty Power PCB in Autopilot Computer 	Replace Autopilot Computer Power PCB

Display readout	Probable fault	Recommended action
Failure active Control Unit	Active control unit goes silent.	<ol style="list-style-type: none"> 1. Press the STBY button on an "Inactive" unit to reset. 2. Check/repair Robnet2 cable. 3. Replace the control unit PCB.
ACXX current overload	The drive unit shut down due to an excessive load or a short circuit.	<ol style="list-style-type: none"> 1. Check the drive unit and drive unit installation/Manual steering/Rudder. 2. Disconnect the drive unit. If the fault is still present, replace the Autopilot Computer Power PCB.
Low 15 volt	Internal 15 Volt supply in Autopilot Computer below limit.	<ol style="list-style-type: none"> 1. Replace Autopilot Computer Main PCB 2. Replace Autopilot Computer Power PCB if Mains voltage is 12V.
Bypass/clutch overload	Clutch/bypass current exceeds 2,5 Amps (overload or short circuit).	<ol style="list-style-type: none"> 1. Check actual current 2. Check voltage marking on coil 3. Check coil resistance (through connecting wires)
Bypass/clutch disengaged	Poor connection or open circuit in bypass/clutch coil	<ol style="list-style-type: none"> 1. Check connections 2. Replace bypass/clutch if open. 3. Perform new "Rudder test".
ACXX high temp.	Excessive temperature in Autopilot Computer (>75°C), possible long term overload.	<ol style="list-style-type: none"> 1. Switch off autopilot 2. Check for backload in Drive unit/steering system. 3. Check that the autopilot computer specifications matches Drive unit.
Memory failure ACXX	Wrong checksum on memory parameters or variables. Autopilot Computer will use default values.	Perform a "Master reset" and make a new "Dockside set-up". Switch off and on again. If the alarm is repeated, replace Autopilot Computer Main PCB.

Display readout	Probable fault	Recommended action
Com. failure with ACXX	Faulty Autopilot Computer or poor Robnet2 cable connections from the same.	<ol style="list-style-type: none"> 1. Check Robnet2 connectors and cable. 2. Replace Autopilot Computer Main PCB.
Low supply voltage	Mains voltage less than 9 Volts	<ol style="list-style-type: none"> 1. Verify in the System Data Menu 2. Switch autopilot off, charge batteries 3. Check/repair battery charger
High supply voltage	AC20/AC40 Mains exceeds 44 V AC10 Mains exceeds 29 V	<ol style="list-style-type: none"> 1. Verify in the System Data Menu 2. Switch the autopilot off 3. Check / repair battery charger

7 SPARE PARTS LIST

AP26 Control Unit

- 22087910 AP26 Control Unit
- 22088439 AP26 mounting kit consisting of:
 - 22084529 Cabinet corners
 - 22085807 Gasket
 - 44165181 Screw 3.5x19
 - 44165645 Screw 3.5x32
- 22085872 Optional mounting bracket consisting of:
 - 44148906 Screw M4x12
 - 22084776 Right bracket
 - 22084784 Left bracket
 - 22084859 Locking knob
 - 22085880 Cradle
 - 44163145 Locking washer for left and right bracket
 - 44163160 Locking washer for cradle
- 22087925 AP26 Front Ass'y
- 22087944 AP26 Back Ass'y
- 22087761 AP26 Board Ass'y
- 22084750 Protection Cover
- 22088181 AP26&AP27 software

AP27 Control Unit

- 22088090 AP27 Control Unit
- 22086276 AP27 Standard Mounting kit
- 22087795 AP27 Board Ass'y
- 22088181 AP26&AP27 software
- 22086193 Back cover

Autopilot Computers

- 22088108 AC10 Autopilot Computer
- 22088116 AC20 Autopilot Computer
- 22088124 AC40 Autopilot Computer
- 22081707 AC20 Installation accessories
- 22081855 AC10 Installation accessories
- 22081962 AC40 Installation accessories

22081251	AC20 Power PCB Ass'y
22081715	AC10 Power PCB Ass'y
22088694	AC40 Power PCB Ass'y
22088447	AC Main PCB Ass'y (All models)
22088462	PROM for all autopilot computers
22081434	AC10/AC20 Base plate
22082036	AC40 Base plate
22081350	Main cover
22081368	Terminal cover

RFC35 Electronic Fluxgate Compass

22081459	RFC35 Fluxgate Compass
22081442	Installation accessories consisting of:
20104972	Mounting plate (2)
44140762	Screw 3.5x25 (2)
44140770	Screw 30x9 (4)
22081376	Plug (2)
22081178	RFC35 PCB Ass'y

RC36 Rate compass

22086920	RC36 Rate Compass
22081442	Installation Accessories Consisting of:
20104972	Mounting plate (2)
44140762	Screw 3.5x25 (2)
44140770	Screw 30x9 (4)
22081376	Plug (2)
22086938	RC36 PCB Ass'y
24005647	Robnet2 Cable, 15 m with Plug

RF300 Rudder Feedback Unit

20193462	RF300 Rudder Feedback
20193470	RF300 transmission lever
20193454	RF300 transmission link
44133122	Transmission rod M5x325mm
20193624	RF300 Ball joint Ass'y (2)

Robnet2 cables

24005613	Robnet2 cable, 1 m (3') with two plugs
----------	--

- 24005621 Robnet2 cable, 5 m (16') with two plugs
- 24005639 Robnet2 cable, 10 m (33') with two plugs
- 24005647 Robnet2 cable 15 m (49') with one plug
- 24005662 Robnet2 joiner

SimNet cables and accessories

- 24005829 SimNet cable 0.3 m (1')
- 24005837 SimNet cable 2 m (6.6')
- 24005845 SimNet cable 5 m (16.6')
- 24005852 SimNet cable 10 m (33')
- 24005860 SimNet T-joiner
- 24005878 SimNet cable gland
- 24005886 SimNet protection plug
- 24005894 SimNet termination plug
- 24005902 SimNet power w/termination 2 m (6.6')
- 24005910 SimNet power w/o termination 2 m (6.6')
- 24005936 AT10 Universal NMEA0183 converter
- 24005944 AT15 Active Tee w/connector, IS15
- 24005928 SimNet cable protection cap
- SimNet/NMEA2000 Adapter Cable

Tools

- 44139806 Extraction tool for EPROM

8 TECHNICAL SPECIFICATIONS

8.1 AP26 and AP27 Autopilot System

- Boat size and type:..... Up to 80 feet, Power, Displacement, Sail
- Steering system types: Hydraulic, Mechanical
- Inter-unit connection: RobNet2 network or two-wire supply/data
- System ON/OFF: From control units
- Supply voltage: See autopilot computers
- Power consumption: Dependent on system configuration
- Environmental Protection:
- Control Unit: IP56 from front, IP43 from back.
 - RC36, RFC35, CDI35: IP56
 - RF300: IP56
 - AC10, AC20, AC40: IP44
- EMC protection: EN60945 : 1993, A1 : 1993
- Automatic Steering control:
- Rudder Drive: Proportional rate or solenoid on/off
 - Parameter selection: Automatic with manual override
 - Sea state control: Adaptive sea state filter or manual
- Language selection: English, Norwegian, French, Spanish, German, Italian, Dutch, Swedish.
- Electronic Interface:
- Navigation interface: Standard (NMEA 0183)
 - NMEA inp./outp. ports: Max. 6 (see autopilot computer specifications)
 - NMEA input sentences: APA, APB, BOD, BWC, BWR, BWW, DBT, DPT, GGA, GLL, MTW, MWV, RMA, RMB, RMC, VHW, VLW, VTG, XTE.
 - NMEA output sentences: .. BWC, BWW, GLL, HDG, HDM, HDT, HSC, RMB, RMC, RSA, VTG, XTE.
- See chapter 8.14 for NMEA0183 details.
- Optional output: Simrad and Furuno radar display (clock/data)
- NMEA2000 interface: Via SimNet port and SimNet/NMEA2000 adapter cable

Heading sensors:

- Standard: RC25 Rate Compass
- Options: RFC35 Electronic Fluxgate compass
- NMEA Compass (Not AC10)
- Simrad RGC50/RGC10 gyrocompasses *
- * By GI51

Course Selection: Rotary course dial and push button

Alarms: Audible and visual, optional external

Alarm modes: Off course, system failures, overload

Steering modes: Standby, Non-follow up, Follow-up, Auto, Nav, Wind

Special Turn modes: Dodging, Tacking, Gybing, U-Turn

Instrument screen interface:

Instrument screen	NMEA0183 messages and SimNet
MAIN (HDG+RUDDER)	ROBNET2 PROPRIETARY, NMEA HDT and HTG, SimNet
SPEED/DEPTH	VHW + DBT/DPT, SimNet
APPARENT WIND	MWV, SimNet
TRUE WIND/WIND DIRECT.	MWV + VTG/RMC, SimNet
POSITION	GGA/RMC/RMA, SimNet
NAV/TRACK DATA	APB + VTG/RMC + GGA/RMC + RMB/BWC, SimNet
LOG/SEA TEMPERATURE	VLW + MTW, SimNet

Note ! *Alternative messages are separated by slashes.*

8.2 AP26 Control Unit

Dimensions: See Figure 8-1

Weight: 0,5 kg (1.1 lbs)

Power consumption 3 W

Display:

Type: Backlit LCD matrix display

Resolution: 80 x 32 pixels

Colour: Black

Illumination: Adjustable in 10 steps

Environmental Protection: IP56 from front, IP43 from back.

Safe distance to compass: 0.3 m (1.0 ft.)

Temperature:

Operating: 0 to +55 °C (+32 to +130 °F)

Storage: -30 to +80 °C (-22 to +176 °F)




Figure 8-1 AP26 Control Unit – dimensions
(Mounting bracket is optional equipment)

8.3 AP27 Control Unit

- Dimensions: See Figure 8-2
- Weight: 0,57 kg (1,25 lbs)
- Power consumption 3 W
- Display:
 - Type: Backlit LCD matrix display
 - Resolution: 80 x 32 pixels
- Colour: Black
- Illumination: Adjustable in 10 steps
- Environmental Protection: IP56.
- Safe distance to compass: 0.3 m (1')
- Temperature:
 - Operating: 0 to +55 °C (+32 to +130 °F)
 - Storage: -30 to +80 °C (-22 to +176 °F)
- Mounting: Handheld or mounted in a fixed, bracket mount.
- Cable 7m (23') special RobNet2 cable with air tube.




Figure 8-2 AP27 Control Unit - dimensions

8.4 Autopilot Computers

Dimensions: See Figure 8-3 and Figure 8-4

Weight:

AC10/AC20 1,3 kg (2,9 lbs.)

AC40 2,8 kg (6,2 lbs)

Supply voltage:

AC10 10-28V DC

AC20/AC40 10-40V DC

Reverse voltage protection Yes (not AC40)

Power consumption: 5 Watt (electronics)

Motor / solenoid drive:

AC10: 6 A continuous, 12 A for 5 sec.

AC20: 10 A continuous, 20 A for 5 sec.

AC40: 20 A continuous, 40 A for 5 sec.

Heading Sensor input: Composite pulse width modulated

Rudder feedback input: Frequency signal, 3400 Hz., 20 Hz/deg.

Rudder feedback units: RF300, LF3000

NMEA input/output ports: AC10:1 (one)

AC20, AC40: 2 (two)

External Alarm: Open collector

Temperature range:

Operation: 0 to +55 °C (+32 to +130 °F)

Storage: -30 to +80 °C (-22 to +176 °F)

Mounting: Bulkhead mount

Material: Anodized aluminium and black ABS cover




Figure 8-3 AC10/AC20 Autopilot computer - Dimensions




Figure 8-4 AC40 Autopilot computer - Dimensions

8.5 RC36 Rate compass

Dimensions: See Figure 8-5

Weight: 0,9 kg (2,0 lbs)

Supply and interface: RobNet2

Power consumption: 0,9 watts

Automatic Performance:

Calibration: Automatically activated by control head

Gain compensation: Automatically adjusted continuously

Rate sensor stabilized heading output

Accuracy: $<1.25^\circ$ (rms)

Repeatability: $<0.2^\circ$ (rms)

Roll/Pitch: ± 35 degrees

Cable supplied: 15 m TP shielded Robnet2 cable

Temperature range:

Operation: 0 to $+55^\circ\text{C}$ ($+32$ to $+130^\circ\text{F}$)

Storage: -30 to $+80^\circ\text{C}$ (-22 to $+176^\circ\text{F}$)

Environmental Protection: IP56

Mounting: Deck or bulkhead

Material: White ABS




Figure 8-5 RC36 Rate Compass - Dimensions

8.6 RFC35 Fluxgate compass

Dimensions:	Same as RC36. See Figure 8-5
Weight:	0,9 kg (2,0 lbs)
Supply and output:	Polarity independent 2-wire supply with superimposed pulse width modulation
Automatic Performance:		
Calibration:	Automatically activated by control head
Gain compensation:	Automatically adjusted continuously
Repeatability:	± 0.5 degrees
Roll/Pitch:	± 35 degrees
Accuracy:	± 3 degrees after calibration
Cable supplied:	15 m TP shielded cable
Temperature range:		
Operation:	0 to +55 °C (+32 to + 130 °F)
Storage:	-30 to +80 °C (-22 to +176 °F)
Environmental Protection:	IP56
Mounting:	Deck or bulkhead
Material:	Black ABS

8.7 RF300 Rudder Feedback

Dimensions:	See Figure 8-6 and Figure 8-7.
Weight:	0,5 kg (1,1 lbs)
Material:	Arnite T06 200 PBT
Environmental Protection:	IP56
Temperature range:		
Operation:	-25 to +55 °C (-13 to +130 °F)
Storage:	-30 to +80 °C (-22 to + 176 °F)
Mounting:	Horizontal, vertical, or upside down
Cable supplied:	10 m (33 ft.) twisted pair shielded cable
Rudder angle:	± 90 degrees
Output signal:	Polarity independent two wire frequency signal
Frequency resolution:	Centre: 3400 Hz, 20 Hz/degree of change
Linearity:	± 3 degrees up to 45 degrees of rudder

Transmission link: Stainless 350mm (13.8") with 2 ball joints.
 Ball joint stud for rudder arm requires 4.2mm diameter hole and 5mm tap.




Figure 8-6 RF300 Rudder Feedback - Dimensions





Figure 8-7 Transmission link - Dimensions


8.8 R3000X Remote Control



Dimensions: See Figure 8-8
 Weight:..... 0,4 kg (0,9 lbs)
 Material:..... Epoxy coated aluminium
 Protection IP56
 Safe distance to compass: 0.15 m (0.5 ft.)
 Temperature range:
 Operation: ...-25 to +55 °C (-13 to +130 °F)
 Storage:-30 to +80 °C (-22 to + 176 °F)
 Cable length: ... 7 m, shielded
 Mounting bracket:..... Supplied

Figure 8-8 R3000X - Dimensions

8.9 JS10 Joystick



Dimensions: See Figure 8-9
 Weight:0.5 kg (1.1 lbs.)
 Environmental Protection:
 Joystick..... IP66
 Terminals..... IP20
 Safe distance to compass:..... 0.15 m (0.5 ft.)
 Shock resistance (according to MIL 202 B method 202 A):
 1/2 sinusoid 11 ms:
 No damage or disassembling at 100 g
 Vibration resistance (according to IEC 68-2-6):
 16 g with frequency range from 40 to 500 Hz and maximum shifting 0,75 mm (peak -to- peak)
 Temperature range:
 Operation:-25 to +70°C (-13 to +158°F)
 Storage:-40 to +70°C (-40 to +158°F)
 Mounting:..... Panel-mount
 Cable: 10 meters (33 ft.)

Figure 8-9 JS10 Joystick Dimensions

8.10 FU25 Steering Lever

Dimensions: See Figure 8-10

Handle can be mounted pointing upwards or downwards.

Weight: 1.2 kg (2.6 lbs.) including cable

Material:..... Polyacetal (POM)

Environmental Protection:..... IP56

Power consumption: 3W

Safe distance to compass:..... 0.15 m (0.5 ft.)

Temperature:

Operating: -25 to +55°C (-13 to +130°F)

Storage: -30 to +80°C (-22 to +176°F)

Cable:..... 10 m (33 ft.) cable with three twisted pairs of wire run through a cable gland.

(cable gland can alternatively be mounted on back cover; see Figure 8-10)

Max. rudder command angle:.... Equal to physical stop minus 2°

Autopilot interface:..... Via proprietary RobNet2™ bus

Accuracy:..... ±1° within ±40° of mid-position at 25°C




Figure 8-10 FU25 Steering Lever Dimensions

8.11 IS15 Rudder

Dimensions:	See Figure 8-11
Weight:	225 grams
Environmental Protection:	IP56 from front, IP44 from rear
Power requirement:	12/24 VDC, 70 mA (100 mA max with max lighting)
Safe distance to compass:	0.15 m (0.5 ft.)
Temperature: Operating:	-0 to +55°C (+32 to +130°F)
Storage:	-30 to +80°C (-22 to +176°F)
Scale:	Full deflection adjustable for any h.o. angle between $\pm 20^\circ$ and $\pm 45^\circ$. Divisions: Marking per each 1/8 of full deflection. Accuracy: $\pm 2^\circ$ of full scale deflection.
Heading Display (Digital):	0 to 359°
Heading Resolution:	1°
Heading reference:	True or Magnetic North
Heading Lock:	Course and direction to steer on digital display
Course to Steer:	Settable on digital display
Display Backlighting:	Green color with seven levels plus Off
Display Backlighting Control: ...	Two independent lighting banks or individual settings (bank 0)
Inputs: Rudder Angle:	2-wire p.w.m. NMEA 0183, RSA Roblink (IS15 system)
Compass heading:	NMEA 0183, HDG, HDM, HDT
Outputs: Rudder Angle:	NMEA 0183, RSA, 5 Hz*
Compass heading:	NMEA 0183, HDG
Other:	NMEA 0183 sentences according to IS15 NMEA in/out table.




Figure 8-11 IS15 Rudder - Dimensions

8.12 SimNet

Maximum number of products connected in a network:.....	50
Maximum cable length:.....	120 m (400')
Bit rate of the bus:	250 kbit/second
Maximum DC current through a single SimNet plug	5A
SimNet power supply:	12VDC
Maximum drop cable length:.....	6 m (20')
Maximum total length of all drop cables (accumulated):.....	60 m (200')
Environmental protection: Cable and plug/connector system.....	IP66
Temperature:.....	70°C (158°F)

8.13 IP protection

Each part of a Simrad autopilot system has a two digits IP protection code.

The IP rating is a method to classify the degree of protection against solid objects, water ingress and impact afforded by electrical equipment and enclosures. The system is recognised in most European countries and is set out in a number of British and European standards.

The first code number describes the protection against solid objects, and the second number describes the protection against liquids.

FIRST NUMBER Protection against solid objects	SECOND NUMBER Protection against liquids
IP TESTS	IP TESTS
0 No protection	0 No protection
1 Protection against solid objects up to 50 mm, eg. accidental touch by hands.	1 Protected against vertically falling drops of water (eg. condensation).
2 Protection against solid objects up to 12 mm, eg. fingers.	2 Protected against direct sprays of water up to 15° from the vertical.
3 Protection against solid objects over 2.5 mm (tools + wires)	3 Protected against sprays to 60° from the vertical.
4 Protection against solid objects over 1 mm (tools + wires + small wires)	4 Protected against water sprayed from any direction.
5 Protection against dust - limited ingress (no harmful deposit)	5 Protected against low pressure jets of water from all directions - limited ingress permitted.
6 Totally protected against dust	6 Protected against strong jets of water, eg. for use on shipdecks - limited ingress permitted.
	7 Protected against the effects of immersion between 15 cm and 1 m.
	8 Protected against long periods of immersion under pressure.

8.14 NMEA and SimNet messages

NMEA0183 messages and data overview for AC10, AC20, AC40															
Message ident.	HDG	HDM	HDT	RSA	MWV ²⁾	VPW ²⁾	DBT	DPT	MTW	VHW ²⁾	VLW	VBW	GGA	GLL	RMA
Data source: (n/p/h=nav/pos/heading source, c=calculated):	h	h	h	c									P	P	P
Accept. cond. (N=nav. flag, P= pos. flag): Status flag													P	P	P
Compass_Data Compass heading, M ¹⁾ Compass heading, T	2	1													
Rudder_Data Rudder angle			3												
Wind_Data Apparent wind angle ¹⁾ Apparent wind speed ¹⁾ True wind angle True wind speed Velocity made good to windward ¹⁾³⁾				1	1										
Depth_Data Depth ref transducer Transducer-Keel Offset							1	2							
Speed_Temp_Data Speed through water ¹⁾ Log distance and trip Water temperature									1		2				
Gps_Data Present position Lat, Lon ¹⁾ COG, T COG, M ¹⁾ Magnetic variation SOG ¹⁾													4	1	2
Nav_Data To-wp position ¹⁾ To-wp ident. Bearing wp-wp, T Bearing wp-wp, M ¹⁾ Bearing pos-wp, T Bearing pos-wp, M ¹⁾ Distance pos-wp ¹⁾ XTE ¹⁾ Waypoint closure velocity ¹⁾				1											5
Steering_contr1 Heading steering cmd, T / M															1
AC NMEA-1 Rx:					x	x	x	x	x	x	x	x	x	x	x
AC NMEA-2 Rx:	x	x	x		x	x	x	x	x	x	x	x	x	x	x
AC NMEA-1 TX: Transmission interval in sec.->	1	1	1	1											2
AC NMEA-2 TX:	.1*	1	.1*	.2											

1. Information required to operate in WIND_N mode
2. Recommended sentences for operating in WIND_N mode
3. If the VPW sentence is not available, the autopilot will calculate the VMG internally.

RMC ²⁾	VTG ²⁾	APB ²⁾	BOD	BWW	BWC	BWR	RMB ²⁾	XTE	HSC	Indata use				OutACXX	Remarks:
P	P	N	N	N	N	N	N	N	C	AP16	AP25	AP26	AP27		
P	P*	N	N	N	N*	N*	N	N		d	d	d	d	x	* Pos flag or NMEA version 3.01 N/P=nav/pos data warning, *DGPS if flag=2
P		N					N	N		d	d	d	d	x	
										d	d	d	d		
										d	d	d	d		
										d	d	d	d		
										d	d	d	d		
										d	d	d	d		
										d	d	d	d		
3	2 3				2 1 3					d	d	d	d	x	
	1				3 2 4					d	d	d	d	x	
6 4		3 2								d	d	d	d	x	
2 3										d	d	d	d	x	
		6 5 1			2 1 3					d	d	d	d	x	
		3 2 1			3 2 4					d	d	d	d	x	
		3 2 1								d	d	d	d	x	
		4			2 1 3					d	d	d	d	x	
		4			2 1 3*					d	d	d	d	x	* Only if Magnetic variation is present
					2 1 3					d	d	d	d	x	
		3						1 2		d	d	d	d	x	
								1		d	d	d	d	x	
														x	
x x	x x	x x	x x	x x	x x	x x	x x	x x							
x x	x x	x x	x x	x x	x x	x x	x x	x x							
2 2			10 10				2 5		10						* HDG out if magn. sensor, HDT out if true sensor
									10						

Simrad AP26 and AP27 Autopilots

SimNet/NMEA2000 messages and data overview		127250	127245	130306	128267	130310	128259	128275	65408*	129025	129029	129026	130577	128259	127250
Message ident.															
Data source: N=nav, P=pos, H=heading, D=depth, Wa=Wind apparent, Wt=Wind True, WaS=Water Speed/ WaT=Water temp, DI=Distance log, C=Calculated):		H	C	Wa / Wt	D	WaT	WaS	DI	DI	P	P	P	P	P	P
Compass Data	Compass heading ¹⁾	1													
Rudder Data	Rudder angle														
Wind Data	Apparent wind angle ¹⁾ Apparent wind speed ¹⁾ True wind angle True wind speed			1 1 1 1											
Depth Data	Depth ref transducer Transducer-Keel Offset				1 1										
Speed Data	Speed through water ¹⁾						1								
Distance Log Data	Log distance and trip							1	1						
Temperature Data	Water temperature					1									
Position Data	Present position Lat, Lon ¹⁾ COG ¹⁾ Magnetic variation SOG ¹⁾									2	1		2	1	1
Navigation Data	To-wp position ¹⁾ To-wp ident. Bearing wp-wp ¹⁾ Bearing pos-wp ¹⁾ Distance pos-wp ¹⁾ XTE ¹⁾ Waypoint closure velocity ¹⁾												3	2	1
Steering Data	Heading steering cmd, T / M														
APXX Gateway		x*	x	x*	x*	x*	x*	x*	x*	x*	x*				

Additional PGNs supported

Simrad Proprietary

- 61184 Parameter Command
- 65408 Parameter Reply
- 130840 DataUserGroup Configuration
- 65323 DataUserGroup Request

NMEA2000

- 59392 ISO acknowledge
- 60928 ISO Adress claim

1) Information required to operate in WIND_N mode.

				Indata use			Remarks:		
129283	129284	65357*	65408*	127237	AP16	AP25	AP26	Out Gateway	
Z	Z	Z	C						* SimNet proprietary
					d	d	d	x	
					d	d	d	x	
					d	d	d	x	
					d	d	d	x	
					d	d	d	x	In INFO views Depth+Offset is displayed if offset is present
					d	d	d	x	
					d	d	d	x	
					d	d	d	x	
1		1			d	d	d	x	
1					d	d	d	x	
1					d	d	d	x	
1					d	d	d	x	
1					d	d	d	x	
								x	
x*	x*	x*		x					*Only transmitted if NMEA183/RC36/RFC35 is source

9 GLOSSARY

Apparent wind – The speed and direction from which the wind appears to blow with reference to the bow when the boat is moving (also called relative wind).

Arrival alarm – An alarm signal issued by a GPS/chartplotter that indicates arrival at or at a predetermined distance from a waypoint. (see arrival circle).

Arrival circle – An artificial boundary placed around the destination waypoint of the present navigation leg, the entering of which will signal an arrival alarm.

Bearing – The horizontal direction of one terrestrial point from another, expressed as the angular distance from a reference direction, usually measured from 000° at the reference direction clockwise through 359°.

BPW – Bearing to a specified waypoint from present position.

BWW – Bearing waypoint to waypoint - Bearing angle of the line between the “TO” and the “FROM” waypoint, calculated at the “FROM” waypoint for any two arbitrary waypoints.

COG - Course Over Ground - The actual direction of progress of a vessel, between two points, with respect to the surface of the earth, The vessel’s heading may differ from the course over ground due to the effects of wind, tide, currents.

GPS - Global Positioning System - This system is based on satellites in fixed orbits, circling the earth at an altitude of approximately 20,200 km. The system will provide the user with 24 hour a day all weather position coverage, with an accuracy of 5 to 30 meters.

Magnetic bearing – Bearing relative to magnetic north; compass bearing corrected for deviation.

Magnetic deviation – A local magnetic field onboard a vessel. Can interfere with the earth’s magnetic field and create compass readings that may deviate from the actual magnetic heading. The deviation will vary with the actual heading.

Magnetic heading – heading relative to magnetic north.

Magnetic variation - A magnetic compass points to the magnetic north pole. The difference between this direction and true north is the magnetic variation. The amount and direction of this variation is dependent upon where on the earth you are located.

NMEA0183 - A format (language) designed to permit communication between various types of marine electronic equipment. In essence this is a two-wire shielded, serial data link, permitting one device to talk while other devices listen. Numerous different sentences are available, permitting communication between various different devices.

NMEA2000 – A modern serial-data communications network to interconnect marine electronic equipment onboard vessels. Equipment designed to this standard will have the ability to share data, including commands and status, with other compatible equipment over a single signalling channel.

Product ID – A number, suffix, acronym or term that can identify a product.

Product name – The name of a Simrad product known from sales and other literature.

Route - A stored sequence of waypoints. These waypoints will be listed in the order in which you desire to follow them.

SimNet Source – Any product or device directly connected to SimNet or NMEA2000, or interfaced to SimNet via NMEA0183 or Robnet2.

Simrad Group – A number of Simrad products that are selecting and sharing the same data sources via the SimNet network.

Simrad Class 1 products – Simrad products that are SimNet controllers, i.e. they have an appropriate display and routines that can set up and control the SimNet.

Simrad Class 2 products – Simrad products that do not contain a SimNet controller. When connected to SimNet they will automatically pick the first available source on SimNet and lock on to that. When a Class 1 product is added to the Simrad Group, Class 2 products will automatically subordinate themselves to the Class 1 source selection.

SOG - Speed over ground is the actual speed of the vessel relative to the ocean floor.

True bearing – Bearing relative to true north; compass bearing corrected for compass error.

True heading – Heading relative to true north (the meridian).

Waypoint - A discrete point, stored in a navigator, located on the surface of the earth. Normally this point will be identified by Lat/Lon coordinates although in some systems it may be shown by T.D.'s.

XTE - Cross Track Error - Used to identify a vessels position relative to a straight line drawn between two waypoints. The amount the vessel is off to the left or to the right of this line is known as the track. It is normally displayed in thousands of a nautical mile, equal to 6 ft or 1.85 m.

10 INDEX

A

alarm
 external, 79
 listing, 118
apparent wind, 32, 41, 144
arrival circle, 30
auto setup, 83
automatic tuning, 102
autopilot computer
 installation, 55
 maintenance, 115
 specifications, 130
autotrim, 107

B

backlight, 39
boat type, 88

C

cable
 Robnet, 63
 specifications, 55
compass
 calibration, 98
 deviation, 99
 installation, 66
 maintenance, 115
 offset, 100
 selection, 43
contrast, 39
control unit
 front panel, 16
 installation, 62
 maintenance, 115
 specifications, 127, 129
counter rudder, 45, 102
 setting, 106
course adjust, 44
Course knob icon, 39
course to steer, 28
cross track error, 28

D

depth offset, 102
depth source, 43
display units, 95
dockside settings, 87
Dodging, 26
drive engage, 91
Drive out, 90
drive unit
 hydraulic pumps, 58
 installation, 58
 linear drive, 58
 maintenance, 115
 reversible pump, 60
 solenoid valve, 61
 stern drive, 18
 voltage, 88

F

fluxgate compass
 specifications, 133
follow-up steering, 19

G

grounding, 56

H

heading catch, 23

I

illumination. *See* backlight
Init NAV, 104
instance number, 111
instrument
 installation, 77
 menu, 46
 screen, 46
 selection, 48
instrument select, 42
interface setting, 95

- interfacing, 69
- IP protection code, 139
- L**
- language, 87
- layline, 37, 41
- linear feedback
 - installation, 79
- lock function, 38
- log source, 43
- loopback, 110
- M**
- master reset, 112
- minimum rudder, 97
- minimum wind angle, 93
- modes of operation
 - standby, 17
- mounting
 - bracket, 63
 - panel, 62
- multiple station, 38
- N**
- Nav source, 43
- navigating, 27
- NFU Steering lever, 14
- NMEA compass, 76
- NMEA data, 108
- NMEA input/output, 75
- NMEA messages, 140
- NMEA port test, 110
- non-follow-up steering, 20
- P**
- parameter
 - view, 104
- parameters, 104
- position source, 43
- product ID, 110
- R**
- racing, 40, 92
- radar connection, 77
- radar output, 95
- recall autotuned, 107
- remote control
 - installation, 68
 - specifications, 135
- response, 45
- Rhumb line, 104
- rudder, 45, 102
 - setting, 106
- Rudder deadband, 92
- rudder feedback
 - installation, 53
 - maintenance, 115
 - specifications, 133
- rudder feedback calibration, 89
- rudder limit, 107
- rudder test, 90
- rudder zero, 97
- S**
- sea trial, 96
- seastate filter, 44
- service, 107
- SimNet, 9, 11, 69
- SimNet backlight, 111
- SimNet gateway, 111
- SimNet messages, 142
- SimNet reset, 111
- SimNet setup, 110
- Simrad group, 110
- software program exchange, 117
- software setup, 83
- source auto update, 42
- source manually update, 42
- source select, 42
- specifications, 126
- steering lever
 - installation, 68
- steering parameters selection
 - automatic, 23
 - manual, 25

system
 basic, 10
 components, 10
 specifications, 126
system data, 108

T

tack angle, 93
tack time, 33, 94
tacking
 in auto mode, 27
 in wind mode, 33
transition speed, 23, 103
True bearing, 146
True heading, 146
true wind, 32, 41

U

user setup menu, 39
user training, 113

U-Turn, 25

V

VMG, 37, 41

W

water speed source, 43
water temperature source, 43
wind
 offset, 101
wind angle source, 43
wind auto, 40
wind calculated source, 43
wind damping, 101
wind response, 45
wind setup, 40, 92
wind shift, 32, 94
wind shift alarm, 94
wind vane steering, 32

This page is intentionally left blank.