


# TSN47W+TSNA02

## User Manual

### 1. Key features


- JPEG, PDF-A4 or PDF-Letter scan-format selection.
- Color or Mono scan-color selection.
- Up to 3000AM (600/Hi) 1050/1200 DPI scan-quality selection.
- Directly save JPG (JPEG)/PDF files to MicroSD card.
- Support the MicroSD & Micro-SDHC memory card up to 32GB.
- Color display to playback the scanned images.
- Backup Wi-Fi for file transfer.
- Support Scan Direct function.
- Scan Device Wi-Fi - Connect with mobile device or PC through Wi-Fi and scan the image and directly output to the mobile device or PC.

### 2. Functional Parts



- Power On/Off:** Press and hold this key for 3 seconds to turn power on or off.  
In Power on mode:  
1) When using the scanner without the docking station, press this button to start scanning; press this button again to stop.  
2) When betting the scanner on the docking station with PC connection, press this button to switch between Standby mode and USB mode.  
In Standby mode, press this button to confirm changes.  
In Playback mode, press this button to change the zoom times between 4x, 6x and normal.  
Press this button to enter Playback mode.  
Press this button to return to the previous screen.  
Press this button to return to the previous screen.  
Press this button to return to the previous screen.
- Display Scanning Status, Scanned Image and Scanner Settings:**  
When zooming in under Playback mode, press this button to shift the functions of and between UP/DOWN and LEFT/RIGHT.  
In Playback mode, Long press this button to turn Wi-Fi on or off.  
Press this button to select JPG (JPEG), PDF-A (PDF-A4) or PDF-L (PDF-Letter) file format. The icon of the selected mode will be displayed on the LCD screen.  
Press this button to move up the selection bar.  
In Playback mode, Press this button to preview the former image. When zooming in under Playback mode, press it to move to the upper/right portion of the image.
- Wash Controller:** Press this button to select 1000dpi, MI (600dpi) or HI (1050dpi) without docking & 1200dpi (with docking) scan quality in DPI. The icon of the selected quality will be displayed on the LCD screen.  
In Setup mode, Press this button to move down the selection bar.  
In Playback mode, Press this button to preview the latter image. When zooming in under Playback mode, press it to move to the lower/left portion of the image.
- Connect button:** Press this button to connect to the computer, nor in Wi-Fi mode.
- Reset:** Press this button to reset the scanner (hardware reset).
- MicroSD card slot:** Connect to a computer with the USB cable provided to view and transfer files.  
To charge up the scanner with an optional AC/DC power adapter or by connecting to a computer.
- USB Interface:** Connect to a computer with the USB cable provided to view and transfer files.  
To charge up the scanner with an optional AC/DC power adapter or by connecting to a computer.

### 3. Explanation of the Status Icons



Item	Function	Description
1	Scan Format	JPG/PDF-A/PDF-L
2	Scan Resolution	MI: 600 DPI HI: 1050 DPI (without docking) / 1200 DPI (with docking)
3	Battery Power Indicator	Fully charged Low battery. Recharge needed
4	Scan Color	Color/MONO
5	File Counter	Shows the number of scanned files in the MicroSD card

### 4. Using the Scanner

#### 4.1 Charging up the Battery

Charge the built-in battery before starting to use your scanner. When the scanner is at power off condition, the charging time from empty to full is about 2.3 hours. The battery can be charged up in either of the following ways:  
1. By connecting to an AC/DC power adapter with the included USB cable via the USB interface on the scanner or the docking station. (AC/DC power adapter is not included).  
2. By connecting to a computer with the included USB cable via the USB interface on the scanner or the docking station.

Note: When charging is completed during scanner power off, the fully charged battery indicator will be displayed on the LCD screen for a short time and will turn off automatically.

#### 4.2 Inserting a MicroSD Memory Card (not included)

You must insert a MicroSD Card (not supplied) to record and store your pictures. To insert the MicroSD memory card:



- Turn Off the scanner.  
Insert the MicroSD card into the MicroSD card slot, and gently press in until the card is locked.
- Do not force the MicroSD card into the slot as this may damage both the scanner and the MicroSD memory card. If the card cannot be inserted successfully, align the MicroSD card position (as marked) and try again.  
The MicroSD memory card must be formatted before scanning. Refer to section 4.8 for details.

### 4.3 Turning on/off the Scanner

Turn on/off the scanner by pressing and holding for 3 seconds.

- If the Auto off is set at 15 Min (refer to section 4.8), the scanner will turn off automatically if no scanning action is detected within 3 minutes.
- If the scanner is turned on by first, it will enter a Date & Time/Language setup mode. Only after you have completed the settings for Date & Time/language can the scanner enter into standby mode.

#### To Set Date & Time/language:

- Press to jump to next setting option: YEAR > MONTH > DATE > HOUR > MINUTE. When setting up the value for MINUTE, press to return to the previous setting option until going back to YEAR.
- Press to set the figure corresponding to each setting.
- Press to confirm and move to next setting.
- After completing the setting for MINUTE, will enter language setup screen.
- Press to select your desired language.
- Press to confirm and enter standby status.

### 4.4 Docking / Undocking Your Scanner

- Docking:**  
Slide the Connect button from "LOCK" to "RELEASE", put the scanner on the docking station by leaving the right side to first. The scanner will be locked on the docking station with the Connect button switched to the "LOCK" position.
- Undocking your scanner:**  
When the Connect button is oriented on the "RELEASE" side, do not press the eject button inside the docking station as this may generate a big clicking sound, and you may get your finger hurt.



### 4.5 How to Scan


#### Scanning without the docking station:

- Turn on your scanner by pressing and holding for 3 seconds.  
Hold the document firmly with one hand on a flat surface.  
Place the scanner on the edge of the paper to ensure the whole document can be scanned. Make sure to keep the scanning area within the scanning width indicators marked on the side of the scanner.
- Hold the scanner flat against the material and then press once to start the scanning process.  
Slide the scanner across the document slowly, top to bottom. Keeping your hand stable to get the best picture quality.  
During scanning, the scanning status icon will be displayed on the LCD screen to indicate scanning is under progress.
- Once the scanner has reached the end of the document, press again to stop scanning.

Note: If the scanning is done too quickly or when there is any abnormal operation, "Scan Error" icon will pop up on the LCD screen. The error image will still be saved after the scanning stops.  
If the instant preview is set to "on", no matter the scan result is normal or abnormal, the scanned image will be shortly displayed on the LCD screen before the scanner returns to standby mode.  
When the memory card is full, the scanner is unable to scan more images. If you press the scan button under such situation, "Full" will flash rapidly on the File Counter of the LCD screen for 2 seconds.

#### Scanning with the docking station:


- Before scanning, make sure the scanner docking station has been connected to an external power supply and is not in Wi-Fi mode.
- Adjust the Wash Controller to an appropriate gear in accordance with the size of the document.
- Smooth the edge of the document before scanning.  
Align the edge of the document at the slot of the scanner. (Align to the right side of the slot.)
- Settle into the paper into the slot and gently push it, scanning will start automatically.  
During scanning, the scanning status icon will be displayed on the LCD screen to indicate scanning is under progress.



- If the scanner is connected to the computer via the USB interface, press once to enter the USB mode, then you can view the scanned files on your computer screen.
- If no paper is detected from the front feed slot within 4 or 5 seconds, just remove the document, put it in place and scan again.  
When docked, the scanner is unable to scan black or transparent documents.  
When scanning relatively thick documents such as credit card or ID card, the narrow side, rather than the wide side, is suggested to be inserted into the slot to guarantee normal scanning.
- The scanner will enter the battery charging mode if no scanning action is detected within 1 minute subsequent to each scanning.  
If "Scan Error" icon pops up on the LCD screen, you need to replace the original memory card with another higher class MicroSD card. (Class 6 or above recommended). The error image will still be saved after the scanning stops.
- If the instant preview is set to "on", no matter the scan result is normal or abnormal, the scanned image will be shortly displayed on the LCD screen before the scanner returns to standby mode.
- When the memory card is full, the scanner is unable to scan more images. If you find the document into the slot under such situation, "Full" will flash rapidly on the File Counter of the LCD screen for 2 seconds.

### 4.6 How to Playback Image

- Press to enter Playback mode. The last scanned image will be displayed.
- Press to zoom in to the image.
- Press to zoom out to the image.
- Press to select your desired image; Press to zoom in to the image.
- Press to select your desired language.
- Press to confirm and enter standby status.



- Press to return to the previous Playback screen, press it again to return to standby mode.
- Press to return to the previous Playback screen, press it again to return to standby mode.

Note: When scanning one relatively long document or scanning several documents in a row, the scanned image cannot be magnified if the file size exceeds 9 MB.

### 4.7 Deleting Single File

- Press to enter Playback mode.
- Press to select the file you want to delete.
- Press to enter Delete File menu.
- Press to select Yes or No Select "Yes" to delete the current file in the MicroSD card. Select "No" to return to previous Playback screen.
- Press to confirm your selection and return to the previous Playback screen.

### 4.8 Setup Menu

- Press to enter Setup menu
- Press to shortly to exit Setup menu.

#### Follow the below three steps to enter setup screen for each Menu Item:

- Press to shortly to enter setup mode.
- Press or to select the Menu item you want to set.
- Press to enter the setup screen.

Menu Items	Description	Options
JPG/PDF	Scan Format	• JPG • PDF - A (A4) • PDF - L (Letter)
Quality	Scan Quality (DPI)	• LO-300 DPI • MI-600 DPI • HI-1050 DPI (without docking) • HI-1200 DPI (with docking)
Color	Scan Color	• Color • Mono
Language	Menu language	• English • Spanish • French • German • Italian • Dutch • Russian • Japanese

### 4.9 Calibrating the Scanner

- Note: If the scanned images are too dark or too bright, you may need to calibrate your scanner by adjusting the white light balance. Follow the below steps to perform calibration:  
1. Take the scanner out from the docking station.  
2. Wipe off any dirt on the surface of the scanning lens with the clean dry cloth provided.  
3. Place the scanner on the white portion of the included calibration paper. Press to turn on the scanner.  
4. Press and hold then press . Release both buttons afterwards to enter the auto-calibration mode. The message "1. Calibration starts. Do not move the device!" will pop up on LCD screen.  
5. Do not move the scanner until another message "2. Scan the calibration sheet" pops up on the LCD screen, start scanning the white portion of the calibration paper by sliding the scanner across the paper (slide the scanner backwards if necessary).  
6. When the message "3. Calibration completed" pops up on the LCD, calibration is completed. Press any button to power off the scanner.

### 5 Connecting to the Computer

You may also connect your scanner to your computer and view pictures on the computer monitor. Before connecting your scanner to your computer, you should make sure that your scanner is not in Wi-Fi mode.

#### When the scanner is undocked

- Press to turn on your scanner, connect your scanner to your computer to enter into USB mode.
- Your computer will recognize the scanner as a "Removable Disk". The USB icon will be displayed on the LCD screen. Click "Open folder to view files" to view, import, copy, move or delete the scanned files.



#### When the scanner is docked

- Press to turn on your scanner.
- Connect your scanner to your computer. Press once to enter into USB mode.
- Your computer will recognize the scanner as a "Removable Disk". The USB icon will be displayed on the LCD screen. Click "Open folder to view files" to view, import, copy, move or delete scanned files. Press to switch to standby mode.



### 6 Connecting to the Scanner via Wi-Fi

- Turn on the scanner, then press and hold . The "Starting" indicator will display on the status LCD.
- Wait 30-40 seconds for Wi-Fi to initialize.
- The "Ready" indicator will display on the status LCD once Wi-Fi mode is enabled and ready for connection.

#### Note:

- The use of Wi-Fi function will consume more battery power. To preserve battery power, it is suggested to turn the Wi-Fi off while you are not using it.
- In Wi-Fi mode, unless you use the SCAN Direct function in the free Application, you cannot use the scanner to scan files. Refer to section 6.3 to utilize the SCAN Direct function to directly scan files to your device.
- You cannot perform calibration in Wi-Fi mode.

### 6.2 Connecting to the Scanner via Wi-Fi

- Turn on the Wi-Fi mode on your scanner.
- Go to network setting on your computer/Android device to enable the Wi-Fi setting.
- With the "Ready" indicator displayed on the scanner's status LCD, search for the "WIFISCAN" network.
- Enter password "123456789" to connect to the scanner.
- The "Connected" indicator will display on the scanner's status LCD once Wi-Fi is connected with the device.
- Open Internet browser and input "192.168.1.2" or "wifiscan" in the address bar to enter navigation page.
- Enter password "123456789" to connect to the scanner.
- The "Connected" indicator will be presented on the browser in thumbnails, you can view and delete files stored in the scanner or change Scanner Wi-Fi settings.

#### View files from Internet Browser via Wi-Fi

- Click the "View" button to preview a single file.

#### Delete files from Internet Browser via Wi-Fi

- Delete your selected files.

a. Click the "Delete" icon to enter the Delete mode, the "Selected File(s)" dialogue box will pop up.

- Delete the files you want to delete by ticking them off.



c. Click the "OK" icon on the "Selected File(s)" dialogue box to delete your selected files.

- Delete all files:  
a. In the "Selected File(s)" dialogue box that pops up, click the "Select all" icon, it will change to "Clear all". All the files in current page will be ticked off.
- Click the "OK" icon to delete all files in current page.

d. Click the "Clear all" icon, all the ticks in current page will disappear. Click the "OK" icon again to confirm.

### 6.3 Connecting to the Scanner via Wi-Fi

In navigation page, click "Scanner Wi-Fi settings" to modify the default settings. When conducting the scanner Wi-Fi settings on the phone, only when you click the "MENU" icon will the "SCANNER Wi-Fi SETTINGS" option pop up.

- Filling in your new SSID, Password, IP Address and Domain Name in the blanks
- Click "Submit" icon to submit your setting.
- After completing Scanner Wi-Fi settings, you should reconnect Wi-Fi.
- With the "Ready" indicator displayed on the scanner's status LCD, search for the "WIFISCAN" network.
- Enter password "123456789" to connect to the scanner.
- Open your creative Scan App. You may conduct relevant operations in accordance with the specific Application interface.

### 6.4 Wi-Fi Reset

You may reset the Wi-Fi settings to default condition via the setup menu of the scanner. Please insert a micro-SD card before conducting the Wi-Fi reset.

- Turn on the scanner and enter the Reset Wi-Fi menu. Refer to section 4.7 to enter the Reset Wi-Fi menu.
- After entering the Reset Wi-Fi menu, a message "Reset the Wi-Fi settings?" will be displayed on the LCD screen. Select "Yes" to confirm and the message "Reset in progress!" will be displayed on the status LCD.
- The message "Reset completed" will be displayed on the status LCD when Wi-Fi reset is completed. Press any button to return to setup menu.

### 6.5 Wi-Fi Settings

When scanning one relatively long document or scanning several documents in a row, the scanned image cannot be magnified if the file size exceeds 9 MB.

### 6.6 Connecting to the Scanner via Wi-Fi

- Turn on the scanner, then press and hold . The "Starting" indicator will display on the status LCD.
- Wait 30-40 seconds for Wi-Fi to initialize.
- The "Ready" indicator will display on the status LCD once Wi-Fi mode is enabled and ready for connection.

#### Note:

- The use of Wi-Fi function will consume more battery power. To preserve battery power, it is suggested to turn the Wi-Fi off while you are not using it.
- In Wi-Fi mode, unless you use the SCAN Direct function in the free Application, you cannot use the scanner to scan files. Refer to section 6.3 to utilize the SCAN Direct function to directly scan files to your device.
- You cannot perform calibration in Wi-Fi mode.

### 6.7 Connecting to the Scanner via Wi-Fi

- Turn on the Wi-Fi mode on your scanner.
- Go to network setting on your computer/Android device to enable the Wi-Fi setting.
- With the "Ready" indicator displayed on the scanner's status LCD, search for the "WIFISCAN" network.
- Enter password "123456789" to connect to the scanner.
- The "Connected" indicator will display on the scanner's status LCD once Wi-Fi is connected with the device.
- Open Internet browser and input "192.168.1.2" or "wifiscan" in the address bar to enter navigation page.
- Enter password "123456789" to connect to the scanner.
- The "Connected" indicator will be presented on the browser in thumbnails, you can view and delete files stored in the scanner or change Scanner Wi-Fi settings.

#### View files from Internet Browser via Wi-Fi

- Click the "View" button to preview a single file.

#### Delete files from Internet Browser via Wi-Fi

- Delete your selected files.

a. Click the "Delete" icon to enter the Delete mode, the "Selected File(s)" dialogue box will pop up.

- Delete the files you want to delete by ticking them off.

Auto power off	3 Minutes
USB port	USB 2.0 High speed
External memory	MicroSD Card
Storage battery	Built-in 2000mAh Lithium-Polymer
Wi-Fi	802.11b/g/n

### 8. Computer System Minimum Requirements

Operating System	Windows 7&8 / Vista / XP and Mac OS 10.5 or above
CPU	Pentium III or above
RAM	At least 256MB
Interface	USB port

### 9. Troubleshooting

Problem	Cause	Solution
---------	-------	----------

Cannot turn on the scanner  
Low battery power  
Recharge the battery

Picture cannot be saved while you are scanning them  
1. The MicroSD card has not been installed.  
2. Memory is full.  
3. The MicroSD card has not been formatted properly.  
1. Insert a MicroSD card  
2. Transfer the pictures from the scanner to the computer to create storage space in the memory card.  
3. Please refer to section 4.8

"Scan Error" icon pops up on the LCD screen while scanning without the docking station.  
Scanning speed is too fast  
Scan the document again

"Scan Error" icon pops up on the LCD screen while scanning with the docking station.  
The speed of the MicroSD card is relatively low.  
Replace the original memory card with another higher class MicroSD card. (Class 6 or above is recommended)

Computer does not recognize your scanner when connected you  
Connection failure  
1. Make sure all cable connections are secured.  
2. Restart the computer if necessary

Zebra stripes occur on the top or bottom of scanned document.  
The scanning document goes away during scanning  
Put the document in place and scan again

Blurry images  
1. The lens of scanner is dirty.  
2. Calibration data is off-set  
1. Clean the lens with soft and dry cloth.  
2. Recalibrate the scanner. Refer to section 4.9

Black Images/Black or white vertical lines  
1. scanner sensor's protective glass is dirty  
2. Calibration data is off-set  
1. Clean the sensor's protective glass with clean and soft dry cloth.  
2. Recalibrate the scanner. Refer to section 4.9

Wi-Fi abnormal connection  
1. Abnormal connection  
2. The battery power is low.  
1. Reconnect the Wi-Fi. Refer to section 6.  
2. Change the built-in battery with the included USB cable or an AC/DC power adapter via the USB interface (Not included).

### FCC Statement

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference.  
(2) This device must accept any interference received, including interference that may cause undesired operation.

Shielded cables with a ferrite core must be used with this unit to ensure compliance with the Class B FCC limits.



AM-47W+402-GB-STD-3