



USER GUIDE



ADSL2 BARRICADE™

4-Ports Annex A ADSL/ADSL2+ Modem Router

SMC7904BRA3

Fast Ethernet Router with built-in ADSL2/2+ Modem

From SMC's line of award-winning connectivity solutions

February 2009

R.01 f/w 1.0

Copyright

Information furnished is believed to be accurate and reliable. However, no responsibility is assumed by our company for its use, nor for any infringements of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under any patent or patent rights of our company. We reserve the right to change specifications at any time without notice.

Copyright © 2009 by

SMC Networks, Inc.

20 Mason

Irvine, CA 92618

All rights reserved.

Trademarks:

SMC is a registered trademark; and Barricade is a trademark of SMC Networks, Inc. Other product and company names are trademarks or registered trademarks of their respective holders.

Warranty and Product Registration

To register SMC product and to review the detailed warranty statement, please refer to the Support Section of the SMC website at <http://www.smc.com>

SMC Networks, Inc.

20 Mason

Irvine, CA 92618

COMPLIANCES

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

FCC - Part 68

This equipment complies with Part 68 of the FCC rules. This equipment comes with a label attached to it that contains, among other information, the FCC registration number and ringer equivalence number (REN) for this equipment. If requested, this information must be provided to the telephone company.

This equipment uses the following jacks: RJ-11.

The REN is used to determine the quantity of devices that may be connected to the telephone line. Excessive RENs on the telephone line may result in the devices not ringing in response to an incoming call. In most, but not all areas, the sum of the RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to the line, as determined by the total RENs, contact the telephone company to determine the maximum REN for the calling area.

COMPLIANCES

If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. If advance notice is not practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.

The telephone company may make changes in its facilities, equipment, operations, or procedures that will provide advance notice in order for you to make the necessary modifications in order to maintain uninterrupted service.

If trouble is experienced with this equipment, please contact our company at the numbers shown on back of this manual for repair and warranty information. If the trouble is causing harm to the telephone network, the telephone company may request you to remove the equipment from the network until the problem is resolved.

No repairs may be done by the customer.

This equipment cannot be used on telephone company-provided coin service. Connection to Party Line Service is subject to state tariffs.

When programing and/or making test calls to emergency numbers:

- Remain on the line and briefly explain to the dispatcher the reason for the call.
- Perform such activities in off-peak hours such as early morning or late evenings.

The Telephone Consumer Protection Act of 1991 makes it unlawful for any person to use a computer or other electronic device to send any message via a telephone facsimile machine unless such message clearly contains, in a margin at the top or bottom of each transmitted page or on the first page of the transmission the date and time it is sent and an identification of the business, other entity, or individual sending the message and the telephone number of the sending machine or such business, other entity, or individual.

In order to program this information into your facsimile, refer to your communications software user manual.

EC Conformance Declaration

SMC contact for these products in Europe is:

SMC Networks Europe,
Edificio Conata II,
Calle Frutuós Gelabert 6-8, 2o, 4a,
08970 - Sant Joan Despí,
Barcelona, Spain.

COMPLIANCES

Marking by the above symbol indicates compliance with the Essential Requirements of the R&TTE Directive of the European Union (1999/5/EC). This equipment meets the following conformance standards:

- EN 55022
- EN 55024•EN 61000-3-2
- EN 61000-3-3
- EN 60950-1

CSA Statement

This unit is to be used with an external power adaptor of a Class 2 or level 3 type and Approved type suitable for use in the North America of equipment installation, having an output voltage rating of 12 V dc, and output current rating of 1.0A or equivalent. The external AC adapter must be complied with the requirements of LPS (Limited Power Sources).

COMPLIANCES

Safety Compliance

Wichtige Sicherheitshinweise (Germany)

1. Bitte lesen Sie diese Hinweise sorgfältig durch.
2. Heben Sie diese Anleitung für den späteren Gebrauch auf.
3. Vor jedem Reinigen ist das Gerät vom Stromnetz zu trennen. Verwenden Sie keine Flüssigoder Aerosolreiniger. Am besten eignet sich ein angefeuchtetes Tuch zur Reinigung.
4. Die Netzanschlusßsteckdose soll nahe dem Gerät angebracht und leicht zugänglich sein.
5. Das Gerät ist vor Feuchtigkeit zu schützen.
6. Bei der Aufstellung des Gerätes ist auf sicheren Stand zu achten. Ein Kippen oder Fallen könnte Beschädigungen hervorrufen.
7. Die Belüftungsöffnungen dienen der Luftzirkulation, die das Gerät vor Überhitzung schützt. Sorgen Sie dafür, daß diese Öffnungen nicht abgedeckt werden.
8. Beachten Sie beim Anschluß an das Stromnetz die Anschlußwerte.
9. Verlegen Sie die Netzanschlußleitung so, daß niemand darüber fallen kann. Es sollte auch nichts auf der Leitung abgestellt werden.
10. Alle Hinweise und Warnungen, die sich am Gerät befinden, sind zu beachten.
11. Wird das Gerät über einen längeren Zeitraum nicht benutzt, sollten Sie es vom Stromnetz trennen. Somit wird im Falle einer Überspannung eine Beschädigung vermieden.
12. Durch die Lüftungsöffnungen dürfen niemals Gegenstände oder Flüssigkeiten in das Gerät gelangen. Dies könnte einen Brand bzw. elektrischen Schlag auslösen.
13. Öffnen sie niemals das Gerät. Das Gerät darf aus Gründen der elektrischen Sicherheit nur von autorisiertem Servicepersonal geöffnet werden.
14. Wenn folgende Situationen auftreten ist das Gerät vom Stromnetz zu trennen und von einer qualifizierten Servicestelle zu überprüfen:
 - a. Netzkabel oder Netzstecker sind beschädigt.
 - b. Flüssigkeit ist in das Gerät eingedrungen.
 - c. Das Gerät war Feuchtigkeit ausgesetzt.
 - d. Wenn das Gerät nicht der Bedienungsanleitung entsprechend funktioniert oder Sie mit Hilfe dieser Anleitung keine Verbesserung erzielen.
 - e. Das Gerät ist gefallen und/oder das Gehäuse ist beschädigt.
 - f. Wenn das Gerät deutliche Anzeichen eines Defektes aufweist.
15. Zum Netzanschluß dieses Gerätes ist eine geprüfte Leitung zu verwenden. Für einen Nennstrom bis 6 A und einem Gerätegewicht größer 3 kg ist eine Leitung nicht leichter als H05VV-F, 3G, 0.75 mm² einzusetzen.

Der arbeitsplatzbezogene Schalldruckpegel nach DIN 45 635 Teil 1000 beträgt 70 dB(A) oder weniger.

Contents

1	Introduction	1
1.1	Package List	1
1.2	Safety Precautions	1
1.3	Description of LEDs and Interfaces	2
1.4	System Requirements	3
1.5	Features	3
2	Hardware Installation	5
3	Introducing the Web Configurator	7
3.1	How to Access the Router	7
3.2	Status	8
3.2.1	System	8
3.2.2	LAN	8
3.2.3	WAN	9
3.2.4	Port Mapping	10
3.2.5	Statistic	10
3.2.6	ARP Table	12
3.3	Wizard	13
3.4	LAN	20
3.4.1	LAN Settings	20
3.4.2	DHCP Settings	21
3.5	WAN	25
3.5.1	WAN Interface	25
3.5.2	ADSL Settings	28
3.6	Advance	29
3.6.1	DNS	29
3.6.2	Firewall	30
3.6.3	Virtual Server	32
3.6.4	Routing	33
3.6.5	IP QoS	35
3.6.6	Anti-DOS	35
3.6.7	Port Mapping	36
3.6.8	Other	37
3.7	Admin	40
3.7.1	Remote Access	40

3.7.2	Commit/Reboot	41
3.7.3	Password	42
3.7.4	Backup/Restore	42
3.7.5	Upgrade Firmware	43
3.7.6	Time Zone	44
3.7.7	System Log	45
3.7.8	SNMP	46
3.7.9	ACL	47
3.8	Diagnostic	48
3.8.1	Ping	48
3.8.2	ATM Loopback	49
3.8.3	ADSL	50
3.8.4	Diagnostic	50
Appendix A	Questions & Answers	51
Appendix B	Technical Specifications	53
Appendix C	GPL Announcement	55

1 Introduction

The ADSL access device supports multiple line modes. It provides four 10/100Base-T Ethernet interface at the user end. Utilizing the high-speed ADSL connection, the device provide users with broadband connectivity to the Internet or the Intranet for high-end users as net bars, office users, etc. can provide a downlink speed up to 24 Mbps and uplink speed up to 1 Mbps.

1.1 Package List

- One ADSL device (ADSL four port router)
- One external splitter
- One power adapter
- Two pieces of telephone lines (RJ11)
- One piece of Ethernet cable (RJ45)
- One copy of QIG (Quick Installation Guide)
- One User Manual CD

1.2 Safety Precautions

Follow these announcements below to protect the device from risks and damage caused by fire or electric power.

- Use volume labels to mark the type of power.
- Use the power adapter packed within the device package.
- Pay attention to the power load of the outlet or prolonged lines. An overburden power outlet or damaged lines and plugs may cause electric shock or fire accident. Check the power cords regularly. If you find any damage, replace it at once.
- Proper space left for heat radiation is necessary to avoid any damage caused by overheating to the device. The long and thin holes on the Access Point are designed for heat radiation to make sure the device works normally. Do not cover these heat radiant holes.
- Do not put this device close to a place where a heat source exits or high temperature occurs. Avoid the device from direct sunshine.
- Do not put this device close to a place where is over damp or watery. Do not spill any fluid on this device.
- Do not connect this device to any PC or electronic product, unless our customer engineer or your broadband provider instructs you to do this, because any wrong connection may cause any power or fire risk.
- Do not place this device on an unstable surface or support.

1.3 Description of LEDs and Interfaces

Front panel




Fig 1.3-1 Front panel

LED	Color	Status	Description
Power	Green/Red	OFF	No power
		GREEN	Device init OK
		RED	Device init
		RED BLINK	Firmware upgrade
Data	Green	OFF	No WAN link
		BLINK	WAN data transiting
		ON	WAN link established and active
Link	Green	OFF	Initial self-test failed
		BLINK	Device is detecting itself
		ON	Initial self-test of the unit is OK and ready
LAN4/3/2/1	Green	OFF	No LAN link
		BLINK	LAN data transiting
		ON	LAN link established and active

Rear panel





Fig 1.3-2 Rear panel

Item	Usage
Line	Line RJ-11 port
Reset	Resets to factory defaults. To restore factory defaults, keep the device powered on and push a paper clip in to the hole. Press down the button over 5 seconds and then release.
LAN1/2/3/4	Ethernet RJ-45 port

Item	Usage
	Power On/Off.
Power	Power connector. DC 12 Voltage/1000mA, female pole is positive.

1.4 System Requirements

Make sure first that you have prepared these following items to guarantee the ROUTER can work normally.

- Services subscriptions
- An 10BaseT/100BaseT Ethernet card installed on your PC
- HUB or Switch. (Attached to several PCs through one of Ethernet interfaces on the device)
- Operation system: Windows 98SE, Windows 2000, Windows ME, or Windows XP
- Internet Explorer V5.0 or higher, or Netscape V4.0 or higher, or FireFox 1.5 or higher.

1.5 Features

- Supports various line modes
- Supports external PPPoE dial-up access
- Supports internal PPPoE/PPPoA dial-up access
- Supports leased line mode
- Supports ZIPB (Zero Installation PPP Bridge Mode)
- Supports 1483B/1483R/MER access
- Supports multiple PVCs (eight at most) and these PVCs can be isolated from each other
- Support a single PVC with multiple sessions
- Support multiple PVCs with multiple sessions
- Supports the binding of the ports and the PVCs
- Supports the 802.1Q and 802.1P protocol
- Supports DHCP server
- Supports NAT/NAPT
- Supports static route
- Supports firmware upgrade: WEB/TFTP^{note 1}/FTP
- Supports reset to factory default: reset, Web
- Supports DNS relay
- Supports Virtual server
- Supports DMZ functions
- Supports two-level passwords and usernames

- Supports WEB interface
- Supports telnet CLI
- Supports System status display
- Supports PPP session PAP/CHAP
- Supports IP filter function
- Supports IP QoS function
- Supports remote access control
- Supports line connection status test
- Supports remote management (Telnet; HTTP)
- Supports configuration file backup and restoration function
- Ethernet supported such as Crossover Detection & Auto-Correction and polarity correction
- Supports UPnP

**note 1:**

When upgrading firmware by TFTP, you can not access the Web GUI temporarily until the upgrading procedure has been finished and the device is rebooted.

2 Hardware Installation

1. Refer to the figure below: Connect the DSL port of the device and the ROUTER port of the splitter with a telephone cable; connect the phone to the Phone port of the splitter through a cable; connect the incoming line to the Line port of the splitter.

The splitter has three ports:

LINE: Connects to a wall phone jack (RJ-11 jack)

ROUTER: Connects to the DSL jack of the device

PHONE: Connects to a telephone set

2. Connect the LAN port of the device to the network card of the PC via an Ethernet line (MDI/MDIX).

Note: Use twisted-pair cables to connect with the HUB/Switch.

3. Plug the power adapter to the wall outlet and then connect the other end of it to the PWR port of the device.

Connection 1: Fig. 2-1 displays the application diagram for the connection of the Router, PC, splitter and telephone set.




Fig 2-1 Connection Diagram (Without connecting telephone sets before the splitter)

Connection 2: As illustrated in the following figure, the splitter is installed close to the device.




Fig 2-2 Connection Diagram (Connecting a telephone set before the splitter)

It is **recommended** to follow the Connection 1 in an actual connection!

Note: When Connection 2 is used, the filter must be installed close to the telephone lines. (See Fig. 2-2. Do not use the splitter instead of the filter).

Installing a telephone directly before the splitter may lead to a failure of connection between the device and the device of LAN side, or cannot access into the Internet, or slow the connection speed if you really need to add a telephone set before the splitter, you have to add a MicroFilter before connecting to a telephone set. Do not connect several telephones before the splitter. Moreover, do not connect several telephones with MicroFilters.

3 Introducing the Web Configurator

3.1 How to Access the Router

The following is a detail “How-To” user guide for the first time users.

1. Open IE browser and enter <http://192.168.2.1> in address bar.
 2. You are required to enter user name and password. See the Fig 3.1-1.
- The super user name and password is admin/smcadmin
 - The common user name and password is user/user





Fig 3.1-1

3. If you enter as super user, the below screen is displayed when you enter successfully.



System	
Alias Name	SMC7904BRA3
Software Version	1.3.9
DSP Version	2.8.1.6
DSL	
DSL mode	T1.413 G.Dmt ADSL2 ADSL2+
DSL Status	ACTIVATING
Upstream Speed	0 kbps 0
Downstream Speed	0 kbps 0
Upstream SNR	0.0dB
Downstream SNR	0.0dB
Reconnection Counts	0
Uptime	22 min
Showtime	

Fig 3.1-2

After you enter router as super user, you can check, configure, and modify all the options. You can use the system diagnostic function also.


If you enter as common user, you can check the status of Router, but cannot change the most of options.

3.2 Status

Click **Status** in the menu to open the sub-menu which contains 6 items: **System**, **LAN**, **WAN**, **Port Mapping**, **Statistic** and **ARP Table**.

3.2.1 System

Click **System** in the sub-menu to open the screen of Fig 3.2.1. In this page, you can view the current status and some basic settings of this router, for example, Software Version, DSL mode, Upstream Speed, Downstream Speed, Uptime and so on.



The screenshot shows the SMC Networks Advanced Status page. The left sidebar has a 'System Status' link. The main content area is titled 'System Status' and includes a description: 'This page shows the current status and some basic settings of the device.' Below this is a table of system parameters.

System	
Alias Name	SMC7904BRA3
Software Version	1.3.9
DSP Version	2.8.1.6
DSL	
DSL mode	T1.413 G.Dmt ADSL2 ADSL2+
DSL Status	ACTIVATING
Upstream Speed	0 kbps 0
Downstream Speed	0 kbps 0
Upstream SNR	0.0dB
Downstream SNR	0.0dB
Reconnection Counts	0
Uptime	22 min
Showtime	

Fig 3.2.1

3.2.2 LAN

Click **LAN** in the sub-menu to open the screen of Fig 3.2.2. In this page, you can view the LAN IP, DHCP Server status, MAC Address and DHCP Client Table. If you want to configure the LAN network, refer to section 3.4.1 “LAN Settings”.




Fig 3.2.2

3.2.3 WAN

Click **WAN** in the sub-menu to open the screen of Fig 3.2.3. In this page, you can view basic status of WAN, Default Gateway, and DNS Server. If you want to configure the WAN network, refer to section 3.5.1 “WAN Interface”.




Fig 3.2.3

3.2.4 Port Mapping

Click **Port Mapping** in the sub-menu to open the screen of Fig 3.2.4. In this page, you can view the mapping relation and the status of port mapping.




Fig 3.2.4

3.2.5 Statistic

Click **Statistic** in the sub-menu to open the menu in the left bar, which contains two items: **Traffic Statistic** and **DSL Statistic**.

3.2.5.1. Traffic Statistic

Click **Traffic Statistic** in the left bar to open the screen of Fig 3. 2.5.1. In this page, you can view the statistics of each network port.




Fig 3.2.5.1

3.2.5.2. DSL Statistic

Click **DSL Statistic** in the left bar to open the screen of Fig 3.2.5.2. In this page, you can view the ADSL line statistics, downstream rate, and upstream rate.

The screenshot displays the SMC Networks Advanced configuration interface. The top navigation bar includes tabs for Status, Wizard, LAN, WAN, Advance, Admin, and Diagnostic. The Status tab is active, and the sub-menu shows System, LAN, WAN, Port Mapping, Statistics, and ARP Table. The left sidebar contains links for Traffic Statistics and DSL Statistics. The main content area is titled 'Statistics -- ADSL' and shows 'Adsl line statistics.' Below this, there are two tables. The first table lists ADSL parameters: Mode, Latency, Trellis Coding (Enable), Status (ACTIVATING), and Power Level (L0). The second table is a performance metrics table with columns for Downstream and Upstream, listing various parameters and their values.

	Downstream	Upstream
SNR Margin (dB)	0.0	0.0
Attenuation (dB)	0.0	0.0
Output Power (dBm)	0.0	25.5
Attainable Rate (Kbps)	0	0
Rate (Kbps)	0	0
K (number of bytes in DMT frame)		
R (number of check bytes in RS code word)		
S (RS code word size in DMT frame)		
D (interleaver depth)		
Delay (msec)		
FEC	0	0
CRC	0	0
Total ES	0	0
Total SES	0	0
Total UAS	0	0

Fig 3.2.5.2

3.2.6 ARP Table

Click **ARP Table** in the sub-menu to open the screen of Fig 3.2.6. In this page, you can view the table that shows a list of learned MAC addresses.




Fig 3.2.6

3.3 Wizard

Click **Wizard** in the menu to open the sub-menu which contains one item: **Wizard**.

Wizard enables speedy and accurate configuration of your Internet connection and other important parameters. The following sections describe these various configuration parameters. Whether you configure these parameters or use the default ones, click 'Next' to enable your Internet connection.

When subscribing to a broadband service, you should be aware of the method by which you are connected to the Internet. Your physical WAN device can be either Ethernet, DSL, or both. Technical information regarding the properties of your Internet connection should be provided by your Internet Service Provider (ISP). For example, your ISP should inform you whether you are connected to the Internet using a static or dynamic IP address, or what protocols, such as PPPOA or PPPoE, you use to communicate over the Internet.

Click **Wizard** in the sub-menu to open the screen of Fig 3.3.1-1. In this page, you can configure the VPI/VCI number.

SMC Networks Advanced

Wizard Status Wizard LAN WAN Advance Admin Diagnostic

| Wizard |

Wizard

Wizard

This Wizard will guide you through the steps necessary to configure your DSL Router.
Note: After you finish a new PVC configuration, one of the old configurations will be replaced.

ATM PVC Configuration

The Virtual Path Identifier (VPI) and Virtual Channel Identifier (VCI) are needed for setting up the ATM PVC.
 Do not change VPI and VCI numbers unless your ISP instructs you otherwise.

VPI: (0-255)
 VCI: (32-65535)

[Next >](#)

Fig 3.3.1-1

Be sure to use the correct Virtual Path Identifier (VPI) and Virtual Channel Identifier (VCI) numbers assigned to you. The valid range for VPI is 0 to 255 and for VCI is 32 to 65535 (0 to 31 is reserved for local management of ATM traffic).

Then press **Next**, the Fig 3.3.1-2 screen appears. In this page, you can select the WAN Connect Type and the encapsulation method.

SMC Networks Advanced

Wizard Status Wizard LAN WAN Advance Admin Diagnostic

| Wizard |

Wizard

Connection Type

Select the type of network protocol and encapsulation mode over the ATM PVC that your ISP has instructed you to use.

WAN Connection Type:

- ☐ PPP over ATM(PPPoA)
- ☐ PPP over Ethernet(PPPoE)
- ☐ 1483 MER
- ☐ 1483 Routed
- ☒ 1483 Bridged

Encapsulation Mode:

[< Back](#) [Next >](#)

Fig 3.3.1-2

The following table describes the fields in this screen.

Label	Description
-------	-------------

Label	Description
WAN Connection Type	If you select the WAN Connection Type, you can select PPPoA , PPPoE , 1483 MER , 1483 Routed or 1483 Bridged .
Encapsulation Mode	Select the method of encapsulation used by your ISP from the drop-down list box. Choices are LLC/SNAP or VC-Mux .
< Back	Click < Back to return to the previous screen
Next >	Click Next > to go to the next screen

If you select PPPoA or PPPoE in WAN Connection Type, click **Next**, the screen of Fig 3.3.1-3 appears as shown next.

The screenshot shows the SMC Networks Advanced Wizard interface. The top navigation bar includes tabs for Wizard, Status, Wizard, LAN, WAN, Advance, Admin, and Diagnostic. The current screen is titled 'WAN IP Settings' and instructs the user to enter information provided by their ISP. Two radio buttons are present: 'Obtain an IP address automatically' (selected) and 'Use the following IP address:'. Below this, the 'WAN IP Address' is displayed as '0.0.0.0' in a text box. A checkbox for 'Enable NAT' is checked. At the bottom right, there are buttons for '< Back' and 'Next >'.

Fig 3.3.1-3

The following table describes the fields of this screen.

Label	Description
Obtain an IP address automatically	The dynamic IP is not fixed; your ISP assigns you the different one each time.
Use the following IP address	A static IP is a fixed IP that your ISP gives you.
WAN IP Address	Input the IP address of the WAN interface provided by your ISP
Enable NAT	Select it to enable the NAT functions of the MODEM. If you are not to enable NAT and intend the user of the MODEM to access the Internet normally, you must add a route on the uplink equipment; otherwise the access to the Internet fails. Normally, it is required to enable NAT.
< Back	Click < Back to return to the previous screen
Next >	Click Next > to go to the next screen

Then click **Next**, the screen of Fig3.3.1-4 appears as shown next.

The screenshot shows the SMC Networks Advanced Wizard interface. The top navigation bar includes tabs for Wizard, Status, Wizard, LAN, WAN, Advance, Admin, and Diagnostic. The 'Wizard' tab is active, and the sub-tab is 'PPP Username and Password'. The main content area explains that PPP usually requires a username and password and provides input fields for 'PPP Username' and 'PPP Password'. Below these are radio buttons for 'PPP Connection Type': 'Continuous' (selected), 'Connect on Demand', and 'Manual'. Each option has an 'Idle Time' field with the value '20'. At the bottom right are '< Back' and 'Next >' buttons.

Fig 3.3.1-4

The following table describes the fields of this screen.

Label	Description
PPP Username	The username and password apply to PPPoE and PPPoA encapsulation only. Make sure that you have entered the correct username and password.
PPP Password	
PPP Connection Type	Choices are Continuous , Connect on Demand and Manual .
< Back	Click < Back to return to the previous screen
Next >	Click Next > to go to the next screen

Then click **Next**, the screen of Fig3.3.1-5 appears as shown next.

SMC Networks Advanced

Wizard | Status | **Wizard** | LAN | WAN | Advance | Admin | Diagnostic

| Wizard |

Wizard

LAN Interface Setup

This page is used to configure the LAN interface of your ADSL router.

LAN IP: 192.168.2.1

Subnet Mask: 255.255.255.0

☒ Enable Secondary IP

Secondary LAN IP: 192.168.100.1

Secondary Subnet Mask: 255.255.255.0

DHCP Server

Set and configure the Dynamic Host Protocol mode for your device.

☒ Enable DHCP Server

Start IP: 192.168.2.2

End IP: 192.168.2.254

Max Lease Time: 1 Day 0 Hour 0 Min (If all is -1, Max Lease Time is not limited)

< Back Next >

Fig 3.3.1-5

The following table describes the fields of this screen.

Label	Description
LAN IP	Enter the IP address of your ROUTER in dotted decimal notation, for example, 192.168.2.1 (factory default)
LAN Netmask	Enter the subnet mask of LAN IP.
Enable Secondary IP	Select this check box to enable the secondary LAN IP
Secondary LAN IP	Enter the secondary IP address of your ROUTER in dotted decimal notation, for example, 192.168.100.1 (factory default)
Secondary LAN Netmask	Enter the subnet mask of the secondary LAN IP
Enable DHCP Server	Select this check box to enable the DHCP Server
Start IP	This field specifies the first of the contiguous addresses in the IP address pool.
End IP	This field specifies the last of the contiguous addresses in the IP address pool.
< Back	Click < Back to return to the previous screen
Next >	Click Next > to go to the next screen

If you finish the settings of this page, click **Next**, the screen appears as shown next.

SMC Networks Advanced

Wizard Status **Wizard** LAN WAN Advance Admin Diagnostic

| Wizard |

Wizard

WAN Setup - Summary

Make sure that the settings below match the settings provided by your ISP.

WAN Setup:

VPI/VC	0 / 35
Connect Type	PPPoE LLC/SNAP, connect forever
NAPT	Enabled
WAN IP	auto assigned
Reserved Gateway	auto assigned
DNS Server	auto assigned

LAN Configuration:

LAN IP	192.168.2.1 / 255.255.255.0
Secondary IP	192.168.100.1 / 255.255.255.0
DHCP Server	Enabled
DHCP IP Range	192.168.2.2 ~ 192.168.2.254
DHCP Lease Time	1day 0hour 0min

Click "Finish" to save these settings. The system will reboot. Click "Back" to make any modifications.

< Back Finish

Fig 3.3.1-7

If you select 1483 MER in Fig 3.3.1-2, the screen appears as shown next.

SMC Networks Advanced

Wizard Status **Wizard** LAN WAN Advance Admin Diagnostic

| Wizard |

Wizard

WAN IP Settings

Enter information provided to you by your ISP to configure the WAN IP settings.

☒ Obtain an IP address automatically
☐ Use the following IP address:
 WAN IP Address: 0, 0, 0, 0
 WAN Subnet Mask: 255, 255, 255, 0
 Default Gateway: 0, 0, 0, 0

☒ Obtain DNS server addresses automatically:
☐ Use the following DNS server addresses:
 Primary DNS server: 0, 0, 0, 0
 Secondary DNS server: 0, 0, 0, 0

☒ Enable NAT

< Back Next >

Fig 3.3.1-8

The following table describes the fields of this screen.

Label	Description
Obtain an IP address automatically	The MODEM obtains a WAN IP address automatically and at this time it enables DHCP Client functions. The WAN IP address is obtained from the uplink equipment like BAS and the uplink equipment is required to enable the DHCP Server functions.

Label	Description
Use the following IP address	If you want to input the WAN ip address by yourself. Check this entry and then input related data in the field.
WAN IP Address	Input the IP address of the WAN interface provided by your ISP
WAN Subnet Mask	Input the subnet mask concerned to the IP address of the WAN interface provided by your ISP.
Default Gateway	You can input the IP address of the default gateway by yourself, click this entry and then input related data in the fields.
Obtain DNS server addresses automatically	To obtain the IP address of the DNS server assigned by the uplink equipment such as BAS.
Use the following DNS server addresses	If you want to input the IP address of the DNS server by yourself, click this entry and then input related data in the fields.
Primary DNS server	Input the IP address of the primary DNS server here.
Secondary DNS server	Input the IP address of the secondary DNS server provided by your ISP here.
Enable NAT	Select it to enable the NAT functions of the MODEM. If you are not to enable NAT and intend the user of the MODEM to access the Internet normally, you must add a route on the uplink equipment; otherwise the access to the Internet fails. Normally, it is required to enable NAT.
< Back	Click < Back to return to the previous screen
Next >	Click Next > to go to the next screen

If you finish the settings of this page, click Next, the screen of Fig 3.3.1-6 appears. For the settings of this screen, see above paragraphs.

If you select 1483 Routed in Fig 3.3.1-2, the screen of Fig 3.3.1-9 appears as shown next.

Fig 3.3.1-9

The following table describes the fields of this screen.

Label	Description
None	-
Obtain an IP address automatically	The dynamic IP is not fixed; your ISP assigns you the different one each time.

Label	Description
Use the following IP address	A static IP is a fixed IP that your ISP gives you.
WAN IP Address	Input the IP address of the WAN interface provided by your ISP
WAN Subnet Mask	Input the subnet mask concerned to the IP address of the WAN interface provided by your ISP.
Obtain DNS server addresses automatically	To obtain the IP address of the DNS server assigned by the uplink equipment such as BAS.
Use the following DNS server addresses	If you want to input the IP address of the DNS server by yourself, click this entry and then input related data in the fields.
Primary DNS server	Input the IP address of the primary DNS server here.
Secondary DNS server	Input the IP address of the secondary DNS server provided by your ISP here.
Enable NAT	Select it to enable the NAT functions of the MODEM. If you are not to enable NAT and intend the user of the MODEM to access the Internet normally, you must add a route on the uplink equipment; otherwise the access to the Internet fails. Normally, it is required to enable NAT.
< Back	Click < Back to return to the previous screen
Next >	Click Next > to go to the next screen

3.4 LAN

Click **LAN** in the menu to open the sub-menu which contains 2 items: **LAN Settings** and **DHCP Settings**.

You can use the LAN configuration to define an IP address for the DSL Router and configure the DHCP server.

3.4.1 LAN Settings

On this screen you can change the IP address of the device. The preset IP address is 192.168.2.1. This is the Private IP address of the DSL Router. This is the address under which the device can be reached in the local network. It can be freely assigned from the block of available addresses.

Click **LAN Settings** in the sub-menu to open the screen of Fig 3.4.1. In this page you can configure the LAN network.

SMC Networks Advanced

LAN Status Wizard **LAN** WAN Advance Admin Diagnostic

| LAN Settings | DHCP Settings |

LAN Interface

LAN Interface Setup

This page is used to configure the LAN interface of your ADSL router. Here you may change the settings for the IP address, subnet mask, etc..

Note: Please Commit/Reboot if you have changed the configuration and need the configuration take effect forever.

Interface Name: br0

IP Address: 192.168.2.1

Subnet Mask: 255.255.255.0

☒ Secondary IP

IP Address: 192.168.100.1

Subnet Mask: 255.255.255.0

IGMP Snooping: ☒ Disabled ☐ Enabled

Apply Changes

Fig 3.4.1

The following table describes the fields of this screen.

Label	Description
IP Address	Input the IP of Local area network interface here.
Subnet Mask	We recommend that you use an address from a block that is reserved for private use. This address block is 192.168.2.1- 192.168.255.254
Secondary IP	Select this checkbox to enable the secondary LAN IP. The two LAN IP addresses must be in the different network.
Apply Changes	Click this button to save the settings of this page.

3.4.2 DHCP Settings

DHCP (Dynamic Host Configuration Protocol) allows the individual client (computers) to obtain the TCP/IP configuration at start-up from the centralize DHCP server. You can configure this router as a DHCP server or disable it. DHCP server can assign IP address, an IP default gateway and DNS server to DHCP clients. This router can also act as a surrogate DHCP server (DHCP Proxy) where it relays IP address assignment from an actual real DHCP server to clients.

If the DHCP was disabled, the screen of Fig 3.4.2-1 appears. You can enable/disable DHCP Server or DHCP Proxy.

SMC Networks Advanced

LAN Status Wizard **LAN** WAN Advance Admin Diagnostic

| LAN Settings | DHCP Settings |

DHCP Settings

DHCP Server Setup

Enable the DHCP Server if you are using this device as a DHCP server. This page lists the IP address pools available to hosts on your LAN. The device distributes numbers in the pool to hosts on your network as they request Internet access.
This page is also used to configure the DHCP server IP addresses for DHCP Relay.

Note: Please Commit/Reboot if you have changed the configuration and need the configuration take effect forever.

LAN IP Address: 192.168.2.1 Subnet Mask: 255.255.255.0

☒ Disable ☐ DHCP Proxy ☐ DHCP Server

Apply Changes

Fig 3.4.2-1

If you set to DHCP Proxy, the screen of Fig 3.4.2-2 appears.

SMC Networks Advanced

LAN Status Wizard **LAN** WAN Advance Admin Diagnostic

| LAN Settings | DHCP Settings |

DHCP Settings

DHCP Server Setup

Enable the DHCP Server if you are using this device as a DHCP server. This page lists the IP address pools available to hosts on your LAN. The device distributes numbers in the pool to hosts on your network as they request Internet access.
This page is also used to configure the DHCP server IP addresses for DHCP Relay.

Note: Please Commit/Reboot if you have changed the configuration and need the configuration take effect forever.

LAN IP Address: 192.168.2.1 Subnet Mask: 255.255.255.0

☐ Disable ☒ DHCP Proxy ☐ DHCP Server

DHCP Proxy:

DHCP Server Address: 172.19.31.4

Apply Changes

Fig 3.4.2-2

The following table describes the fields of this screen.

Label	Description
DHCP Proxy	If set to DHCP Proxy, your ROUTER acts a surrogate DHCP Server and relays the DHCP requests and responses between the remote server and the client.
DHCP Server Address	Enter the IP address of the actual, remote DHCP server in this field.
Apply Changes	Click this button to save the changes of this page.

If you set to DHCP Server, the screen of Fig3.4.2-3 appears as shown next.

SMC Networks Advanced

LAN Status Wizard **LAN** WAN Advance Admin Diagnostic

| LAN Settings | DHCP Settings |

DHCP Settings

DHCP Server Setup

Enable the DHCP Server if you are using this device as a DHCP server. This page lists the IP address pools available to hosts on your LAN. The device distributes numbers in the pool to hosts on your network as they request Internet access. This page is also used to configure the DHCP server IP addresses for DHCP Relay.

Note: Please Commit/Reboot if you have changed the configuration and need the configuration take effect forever.

LAN IP Address: 192.168.2.1 Subnet Mask: 255.255.255.0

☐ Disable ☐ DHCP Proxy ☒ DHCP Server

DHCP Server:

IP Pool Range: 192.168.2.2 - 192.168.2.254

Max Lease Time: 1 days 0 hours 0 minutes (-1 indicates an infinite lease)

Domain Name: domain.name

Gateway Address: 192.168.2.1

Fig 3.4.2-3

The following table describes the fields in this screen.

Label	Description
DHCP Server	If set to DHCP Server, your ROUTER can assign IP addresses, an IP default gateway and DNS Servers to Windows95, Windows NT and other systems that support the DHCP client.
IP Pool Range	This field specifies the first and the last of contiguous IP address of the IP address pool.
Show Client	Click this button, the screen of Fig 3.5.2-4 appears, which shows the assigned IP address of the clients.
Max Lease Time	The Lease time determines the period for which the PCs retain the IP addresses assigned to them without changing them.
Domain Name	Input the domain name here if you know. If you leave this blank, the domain name obtained by DHCP from the ISP is used. While you must enter host name (System Name) on each individual computer, the domain name can be assigned from this router via DHCP server.
Gateway Address	Enter the IP default gateway of the IP address pool.
MAC-base Assignment	Click this button, the screen of Fig3.5.2-5 appears. This function allows you assign IP addresses on the LAN to specific individual computers based on their MAC address.
Apply Changes	Click this button to save the changes of this page.

Click **Show Client**, the following window appears. In this window, you can view the IP address assigned to each DHCP client.



Fig 3.4.2-4

The following table describes the fields in this screen.

Label	Description
IP Address	This field displays the IP address relative to the MAC address.
MAC Address	This field displays the MAC (Media Access Control) address of the computer. Every Ethernet device has a unique MAC address. The MAC address is assigned at the factory and consists of six pairs of hexadecimal character, for example, 00-A0-C5-00-02-12.
Time Expired(s)	Here shows the lease time. The Lease time determines the period for which the PCs retain the IP addresses assigned to them without changing them.
Refresh	Click this button to refresh the Active DHCP Client Table.
Close	Click this button to close this window.

Click **MAC-Base Assignment** button, the below window appears. In this page, you can assign IP addresses on the LAN to specific individual computers based on their MAC address.




Fig 3.4.2-5

The following table describes the fields of this screen.

Label	Description
Host MAC Address	Enter the MAC address of a computer on your LAN
Assigned IP Address	Display the IP of the IP address pool.

Label	Description
Assign IP	Click this button after entered Host MAC Address and Assigned IP Address , a row is added in MAC-Base Assignment Table .
Modify Assigned IP	Select a row in MAC-Base Assignment Table , the MAC address and IP address display Host MAC Address and Assigned IP Address . After modified the MAC Address and IP Address, click this button to save the changes.
Delete Assigned IP	Select a row in MAC-Base Assignment Table and click this button, this row is deleted.
Close	Click this button to close this window.
MAC-Base Assignment Table	Show the assigned IP address based on the MAC address.

3.5 WAN

Click **WAN Interface** in the menu to open the sub-menu which contains 2 items: **WAN Interface** and **ADSL Settings**.

3.5.1 WAN Interface

Click **WAN Interface** in the sub-menu to open the screen of Fig 3.5.1-1. In this page, you can configure WAN Interface of your router.

SMC Networks Advanced

WAN Status Wizard LAN **WAN** Advance Admin Diagnostic

| WAN Interface | ADSL Settings |

WAN Interface

Channel Configuration

This page is used to configure the parameters for the channel operation modes of your ADSL Modem/Router.

Note: Please Commit/Reboot if you have changed the configuration and need the configuration take effect forever.

Current ATM VC Table:

Select	Inf	Mode	VPI	VCI	Encap	NAPT	IP Addr	Remote IP	User Name	Route	Status	Action
<input type="radio"/>	Internet_R_0_35	PPPoE	0	35	LLC	On			admin	On	Enable	

VPI: VCI:

Encapsulation: ☒ LLC ☐ VC-Mux

Channel Mode:

Application Mode:

Admin Status: ☒ Enable ☐ Disable

Enable NAPT: ☐

PPP Settings

Login Name: Password:

Connection Type: Idle Time(min):

WAN IP Settings Type

☒ Fixed IP ☐ Use DHCP:


Local IP Address: Remote IP Address:


Subnet Mask: Unnumbered: ☐


Default Route: ☐ Disable ☒ Enable

Fig 3.5.1-1

Label	Description
Current ATM VC Table	This table shows the PVCs already existed. It shows the Interface name, Channel Mode, VPI/VCI, Encapsulation mode, local IP Address, Remote IP address, etc. The maximum item of this table is eight.
VPI	(Virtual Path Identifier) The virtual path between two points in an ATM network, and its valid value is from 0 to 255
VCI	The virtual channel between two points in an ATM network, ranging from 32 to 65535 (1 to 31 are reserved for known protocols)
Encapsulation	Choices are LLC and VC-Mux.
Channel Mode	There are five choices: 1483 Bridged, 1483 MER, PPPoE, PPPoA and 1483 Routed.
Admin Status	If select Disable, this PVC is unavailable.
Enable NAPT	Select it to enable the NAPT functions of the MODEM. If you are not to enable NAPT and intend the user of the MODEM to access the Internet normally, you must add a route on the uplink equipment; otherwise the access to the Internet fails. Normally, it is required to enable NAPT.
PPP Settings	-
Login Name	The correct user name that your ISP has provided to you.
Password	The correct password that your ISP has provided to you
Connection Type	The choices are Continuous , Connect on Demand and Manual .
Idle Time (min)	If select Connect on Demand , you need to input the idle timeout time. Within the preset minutes, if the Modem does not detect the flow of the user continuously, the Modem automatically disconnects the PPPOE connection.

Label	Description
WAN IP Settings	
Type	The choices are Fixed IP and Use DHCP . If set Fixed IP , you should enter the Local IP Address , Remote IP Address and Subnet Mask . If set Use DHCP , your Modem is a DHCP client, the WAN IP is assigned by the remote DHCP server.
Local IP Address	This is the IP of WAN interface which is provided by your ISP.
Remote IP Address	This is the gateway IP which is provided by your ISP.
Subnet Mask	This is the Subnet Mask of the Local IP Address .
Unnumbered	Select this checkbox to enable IP Unnumbered function.
Default Route	
Add	After configuring the parameters of this page, click this button then a new PVC is added into Current ATM VC Table .
Modify	Select a PVC in the Current ATM VC Table , and then modify the parameters of this PVC. When you finish, click this button to apply the change of this PVC.
Delete	Select a PVC in the Current ATM VC Table , and then click this button to delete this PVC.
Undo	Click this button to begin configuring this screen afresh.
ATM Setting	Click this button, the Fig 3.5.1-3 appears. In this page, you can configure the QoS mode of ATM PVCs. For details, see the following pages.
	Click this button, the following screens appears. In the page, you can modify the parameters of PVCs.

If the PVC uses PPPoE mode, click , the Fig 3.5.1-2 appears. In this page, you can configure the parameters of this PPPoE PVC.



The screenshot shows the SMC Networks Advanced configuration interface. The top navigation bar includes tabs for WAN, Status, Wizard, LAN, WAN (selected), Advance, Admin, and Diagnostic. Below the navigation bar, the breadcrumb trail reads '| WAN Interface | ADSL Settings |'. The main content area is titled 'WAN Interface' and 'PPP Interface - Modify'. The configuration fields are as follows:

- PPP Interface: ppp0
- Protocol: PPPoE
- ATM VCC: 0/35
- Status: ☐ Disable ☒ Enable
- Login Name: admin
- Password: [masked]
- Authentication Method: Auto
- Connection Type: Continuous
- Idle Time(min): 0
- Default Route: ☐ Disable ☒ Enable
- MTU: 1492
- IP Address: ☒ Dynamic IP ☐ Static IP 0.0.0.0
- Bridge: ☒ Disable Bridge ☐ Bridged Ethernet(Transparent Bridging) ☐ Bridged PPPoE(implies Bridged Ethernet)
- AC-Name: [empty]
- 802.1q: ☒ Disable ☐ Enable
- VLAN ID(0-4095): 0

At the bottom, there are three buttons: 'Apply Changes', 'Return', and 'Undo'.

Fig 3.5.1-2

ATM Setting: Click **ATM Setting** button in Fig3.5.1-1, the screen of Fig 3.5.1-3 appears. In this page, you can configure the parameters of the ATM for your ADSL router, including QoS type, PCR, CDVT, SCR and MBS.

Index	VPI	VCI	QoS	PCR	CDVT	SCR	MBS
0	0	35	UBR	6000	0	---	---

Fig 3.5.1-3

3.5.2 ADSL Settings

Click **ADSL Interface** in the sub-menu to open the screen of Fig 3.5.2. In this page, you can select the DSL modulation. Mostly, the user just need to remain this factory default setting. Our modem support these modulations: G.Dmt, G.lite, T1.413, ADSL2, ADSL2+, AnnexL and AnnexM. The router negotiates the modulation mode with the DSLAM.

Fig 3.5.2

3.6 Advance

Click **Advance** in the menu to open the sub-menu which contains 8 items: **DNS**, **Firewall**, **Virtual Server**, **Routing**, **IP QOS**, **Anti-dos**, **Port Mapping** and **Others**.

3.6.1 DNS

Short for Domain Name System (or Service or Server), an Internet service that translates domain names into IP addresses. Because domain names are alphabetic, they are easier to remember. The Internet however, is really based on IP addresses. Every time you use a domain name, therefore, a DNS service must translate the name into the corresponding IP address. For example, the domain name www.example.com might translate to 198.105.232.4.

The DNS system is, in fact, its own network. If one DNS server does not know how to translate a particular domain name, it asks another one, and so on, until the correct IP address is returned.

Click **DNS** in the sub-menu to open the screen of Fig 3.6.1.




Fig 3.6.1

Label	Description
Obtain DNS Automatically	When this checkbox is selected, this router accepts the first received DNS assignment from one of the PPPoA, PPPoE or MER enabled PVC(s) during the connection establishment.
Set DNS Manually	When this checkbox is selected, please enter the primary and optional secondary DNS server IP addresses.
Apply Changes	Click this button to save the settings of this page.
Reset Selected	Click this button to begin configuring this screen afresh.

3.6.2 Firewall

Click **Firewall** in the sub-menu to open the menu in the left bar, which contains three items: **IP/Port Filter**, **MAC Filter** and **URL Blocking**.

3.6.2.1. IP/Port Filter

Click **IP/Port Filter** in the left bar to open the screen of Fig 3.6.2.1. Entries in this table are used to restrict certain types of data packets through the Gateway. Use of such filters can be helpful in securing or restricting your local network.



Fig 3.6.2.1

Click **Apply Changes** to save the settings of this page.

Click **Add Rule** to add a new rule of the IP/Port Filter.

3.6.2.2. MAC Filter

Click **MAC Filter** in the left bar to open the screen of Fig 3.6.2.2. Entries in this table are used to restrict certain types of data packets from your local network to Internet through the Gateway. Use of such filters can be helpful in securing or restricting your local network.

Click the button **Apply Changes** to save the settings of this page.

Click the button **Add Rule** to add a new rule of the MAC Filter.




Fig 3.6.2.2

3.6.2.3. URL Blocking

Click **URL Blocking** in the left bar to open the screen of Fig 3.6.2.3. This page is used to configure the Blocked FQDN (Such as tw.yahoo.com) and filtered keyword. Here you can add/delete FQDN and filtered keyword.



Fig 3.6.2.3

3.6.3 Virtual Server

Click **Virtual Server** in the sub-menu to open the menu in the left bar, which contains two items: **Services** and **DMZ Settings**.

3.6.3.1. Services

Click **Services** in the left bar to open the screen of Fig 3.6.3.1. This page is used to enable the servers in the local network.




Fig 3.6.3.1

Click **Add** to add a virtual server.

3.6.3.2. DMZ Settings

Click **DMZ Settings** in the left bar to open the screen of Fig 3.6.3.2. A Demilitarized Zone is used to provide Internet services without sacrificing unauthorized access to its local private network. Typically, the DMZ host contains devices accessible to Internet traffic, such as Web (HTTP) servers, FTP servers, SMTP (e-mail) servers and DNS servers.




Fig 3.6.3.2

Select the checkbox **Enable DMZ** to enable this function. Then input a IP Address of the DMZ host.
Click the button **Apply Changes** to save the settings of this page.

3.6.4 Routing

Click **Routing** in the sub-menu to open the menu in the left bar, which contains two items: **RIP** and **Static Route**.

3.6.4.1. RIP

Click **RIP** in the left bar to open the screen of Fig 3.6.4.1. Enable the RIP if you are using this device as a RIP-enabled router to communicate with others using the Routing Information Protocol. This page is used to select the interfaces on your devices that use RIP, and the version of the protocol used.

SMC Networks Advanced

Advance Status Wizard LAN WAN **Advance** Admin Diagnostic

| DNS | Firewall | Virtual Server | Routing | IP QOS | Anti-DOS | Port Mapping | Other |

RIP
Static Route

RIP Configuration

Enable the RIP if you are using this device as a RIP-enabled router to communicate with others using the Routing Information Protocol. This page is used to select the interfaces on your devices that use RIP, and the version of the protocol used.

RIP: ☒ Disable ☐ Enable

Apply Changes

Interface:

Receive Mode:

Send Mode:

Add Delete Selected Entry

RIP Configuration Table:

Select	Interface	Receive Mode	Send Mode
--------	-----------	--------------	-----------

Fig 3.6.4.1

3.6.4.2. Static Route

Click **Static Route** in the left bar to open the screen of Fig 3.6.4.2-1. This page is used to configure the routing information. Here you can add/delete IP routes.

SMC Networks Advanced

Advance Status Wizard LAN WAN **Advance** Admin Diagnostic

| DNS | Firewall | Virtual Server | Routing | IP QOS | Anti-DOS | Port Mapping | Other |

RIP
Static Route

Routing Configuration

This page is used to configure the routing information. Here you can add/delete IP routes.

Enable: ☒

Destination:

Subnet Mask:

Next Hop:

Metric:

Interface:


Add Route Update Delete Selected Show Routes

Static Route Table:

Select	State	Destination	Subnet Mask	Next Hop	Metric	Interface
--------	-------	-------------	-------------	----------	--------	-----------

Fig 3.6.4.2-1

Click **Show Routes**, the below window appears. The table shows a list of destination routes commonly accessed by your network.




Destination	Subnet Mask	Next Hop	Metric	Interface
192.168.100.0	255.255.255.0	*	0	br0
192.168.2.0	255.255.255.0	*	0	br0
127.0.0.0	255.255.255.0	*	0	lo

Fig 3.6.4.2-2

3.6.5 IP QoS

Click **IP QoS** in the sub-menu to open the screen of Fig 3.6.5. Entries in this table are used to assign the precedence for each incoming packet based on physical LAN port, TCP/UDP port number, and source/destination IP address/subnet masks.



SMC Networks Advanced

Advance Status Wizard LAN WAN **Advance** Admin Diagnostic

| DNS | Firewall | Virtual Server | Routing | **IP QoS** | Anti-DOS | Port Mapping | Other |

IP QoS

IP QoS

Entries in this table are used to assign the precedence for each incoming packet based on physical LAN port, TCP/UDP port number, and source/destination IP address/subnet masks.

Note: Please Commit/Reboot to make these changes take effect immediately.

IP QoS: ☒ Disabled ☐ Enabled

Fig 3.6.5

3.6.6 Anti-DOS

Click **Anti-DOS** in the sub-menu to open the screen of Fig 3.6.6.

DoS Attack (denial-of-service attack) is a type of attack on a network that is designed to bring the network to its knees by flooding it with useless traffic. In this page, you can configure to prevent DOS attacks.

SMC Networks Advanced

Advance | Status | Wizard | LAN | WAN | **Advance** | Admin | Diagnostic

| DNS | Firewall | Virtual Server | Routing | IP QOS | **Anti-DOS** | Port Mapping | Other |

Anti-DOS

Anti-dos Settings

"denial-of-service attack"(DoS Attack),a type of attack on a network that is designed to bring the network to its knees by flooding it with useless traffic.This page is used to prevent DOS attacks that you configure. Select the DOS attack types you wish to prevent.

Note: Please Commit/Reboot to make these changes take effect immediately.

☐ **Enable Anti-DOS**

<input type="checkbox"/> Whole System Flood: SYN	<input type="text" value="100"/> packets/sec
<input type="checkbox"/> Whole System Flood: FIN	<input type="text" value="100"/> packets/sec
<input type="checkbox"/> Whole System Flood: UDP	<input type="text" value="100"/> packets/sec
<input type="checkbox"/> Whole System Flood: ICMP	<input type="text" value="100"/> packets/sec
<input type="checkbox"/> Per-Source IP Flood: SYN	<input type="text" value="100"/> packets/sec
<input type="checkbox"/> Per-Source IP Flood: FIN	<input type="text" value="100"/> packets/sec
<input type="checkbox"/> Per-Source IP Flood: UDP	<input type="text" value="100"/> packets/sec
<input type="checkbox"/> Per-Source IP Flood: ICMP	<input type="text" value="100"/> packets/sec
<input type="checkbox"/> TCP/UDP PortScan	<input type="text" value="High"/> Sensitivity
<input type="checkbox"/> ICMP Smurf	
<input type="checkbox"/> IP Land	
<input type="checkbox"/> IP Spoof	
<input type="checkbox"/> IP TearDrop	
<input type="checkbox"/> PingOfDeath	
<input type="checkbox"/> TCP Scan	
<input type="checkbox"/> TCP SynWithData	
<input type="checkbox"/> UDP Bomb	
<input type="checkbox"/> UDP EchoChargen	

☐ **Enable Source IP Blocking** **Block Time(Sec)**

Fig 3.6.6

Click the button **Apply Changes** to save the settings of this page.

3.6.7 Port Mapping

Click **Port Mapping** in the sub-menu to open the screen of Fig 3.6.7. In this page, you can bind the WAN interface and the LAN interface to the same group.

To manipulate a mapping group:

1. Select a group from the table.
2. Select interfaces from the WAN and LAN interface list and add them to the grouped interface list using the arrow buttons to manipulate the required mapping of the ports.
3. Click "Apply Changes" button to save the changes.




Fig 3.6.7

3.6.8 Other

Click **Others** in the sub-menu to open the menu in the left bar, which contains four items: **IGMP Proxy**, **UPNP**, **Bridge** and **IP PassThrough**.

3.6.8.1. IGMP Proxy

Click **IGMP Proxy** in the left bar to open the screen of Fig 3.6.8.1. IGMP proxy enables the system to issue IGMP host messages on behalf of hosts that the system discovered through standard IGMP interfaces. The system acts as a proxy for its hosts after you enable it.

Click **Apply Changes** to save the settings of this page.



Fig 3.6.8.1

3.6.8.2. UPNP

Click **UPNP** in the left bar to open the screen of Fig 3.6.8.2. This page is used to configure UPnP. The system acts as a daemon after you enable it.

Click **Apply Changes** to save the settings of this page.




Fig 3.6.8.2

3.6.8.3. Bridge

Click **Bridge** in the left bar to open the screen of Fig 3.6.8.3-1. This page is used to configure the bridge parameters. Here you can change the settings or view some information on the bridge and its attached ports.




Fig 3.6.8.3-1

Click **Show MACs** button in Fig 3.6.8.3-1, the below window appears. This table shows a list of learned MAC addresses for this bridge.




Fig 3.6.8.3-2

3.6.8.4. IP PassThrough

Click **IP PassThrough** in the left bar to open the screen of Fig 3.6.8.4. The IP PassThrough has the other name ZIPB or IP Extension. In this page, you can enable and configure IP PassThrough function.




Fig 3.6.8.4

3.7 Admin

Click **Admin** in the menu to open the sub-menu which contains 11 items: **Remote Access**, **Commit/Reboot**, **Password**, **Backup/Restore**, **Upgrade Firmware**, **Time Zone**, **System Log**, **SNMP**, **TR069**, **ACL** and **Logout**.

3.7.1 Remote Access

Click **Remote Access** in the sub-menu to open the screen of Fig 3.7.1. In this page, you can enable or disable the services which are used by the remote host. For example, if TELNET service is enabled and port is 23, the remote host can access this router by telnet through port 23.

SMC Networks Advanced

Admin Status Wizard LAN WAN Advance **Admin** Diagnostic

| Remote Access | Commit/Reboot | Password | Backup/Restore | Upgrade Firmware | Time Zone | System Log | SNMP | ACL |

Remote Access

Remote Access

This page is used to enable/disable management services for the WAN.

Interface: Internet_R_0_35

Service Name	Open	Port
TELNET	<input type="checkbox"/>	23
FTP	<input type="checkbox"/>	21
TFTP	<input type="checkbox"/>	
HTTP	<input type="checkbox"/>	80
SNMP	<input type="checkbox"/>	
ICMP	<input type="checkbox"/>	

Fig 3.7.1

3.7.2 Commit/Reboot

Click **Commit/Reboot** in the sub-menu to open the screen of Fig 3.7.2. In this page, you can set the router reboot to default settings or set the router save the current settings then reboot.

SMC Networks Advanced

Admin Status Wizard LAN WAN Advance **Admin** Diagnostic

| Remote Access | **Commit/Reboot** | Password | Backup/Restore | Upgrade Firmware | Time Zone | System Log | SNMP | ACL |

Commit/Reboot

Commit/Reboot

Please press "Reboot" to reboot your system.

If you want reset the current settings to factory default, please choose "reset to default settings", then press "Reboot" to reboot the system.
If you want commit current settings, please choose "commit current settings", then press "Reboot" to reboot the system.

☐ reset to default settings
☒ commit current settings

Fig 3.7.2

Label	Description
reset to default settings	Select this checkbox to reset router to default settings.
commit current settings	Select this checkbox to save the current settings and reboot router.
Reboot	Click this button to reboot the router according to the above option.

3.7.3 Password

Click **Login Password** in the sub-menu to open the screen of Fig 3.7.3. In this page, you can change the password of the user, include admin and user. The super user name and password are admin/admin as default, and the common user name and password are user/user.

The screenshot shows the SMC Networks Advanced web interface. The 'Admin' tab is selected in the top navigation bar. Below the navigation bar, there is a sub-menu with 'Password' highlighted. The main content area is titled 'User/Password Management'. It contains a text box stating: 'This page is used to set the password for accessing the web interface of the router. The new password will become available after system reboot.' Below this, there is a form with the following fields: 'User Name' (a dropdown menu showing 'admin'), 'Old Password' (a text input field), 'New Password' (a text input field), and 'Confirmed Password' (a text input field). At the bottom of the form are two buttons: 'Apply Changes' and 'Reset'.

Fig 3.7.3

Label	Description
User Name	Select the user name in the drop-down list box. The choices are admin and user .
Old Password	After selected the user name, input the old password of the user here.
New Password	Input the new password what you want to set of the user.
Confirmed Password	Input the new password again.
Apply Changes	Click this button to save the settings of this page.
Reset	Click this button to begin configuring the password afresh.

3.7.4 Backup/Restore

Click **Backup/Restore** in the sub-menu to open the screen of Fig 3.7.4. In this page, you can backup the current settings to a file and restore the settings from the file which was saved previously.

IMPORTANT! Do not turn off your router or press the Reset button while these procedures are in progress.




Fig 3.7.4

Label	Description
Save Settings to File	Click the Save button, then select the path and save the configuration file of your router.
Load Settings from File	Click the Browse button to select the configuration file.
Upload	Selected the configuration file of router, click Upload button to begin restore the router configuration.

3.7.5 Upgrade Firmware

Click **Upgrade Firmware** in the sub-menu to open the screen of Fig 3.7.5. In this page, you can upgrade the firmware of this router.

IMPORTANT! Do not turn off your router or press the Reset button while this procedure is in progress.



Fig 3.7.5

Label	Description
Select File	Click the Browse button to select the Firmware file.
Upload	Selected the Firmware file, click Upload button to begin upgrading the Firmware.
Reset	Click this button to begin selecting the Firmware file afresh.

3.7.6 Time Zone

Click **Time Zone** in the sub-menu to open the screen of Fig 3.7.6. In this page, you can set the system time manually or get the system time from the time server.

SMC Networks Advanced

Admin | Status | Wizard | LAN | WAN | Advance | **Admin** | Diagnostic

| Remote Access | Commit/Reboot | Password | Backup/Restore | Upgrade Firmware | Time Zone | System Log | SNMP | ACL |

Time Zone

System Time Zone Modification

Set the system time.

Configure Method:
If you configure the time manually, press button "Time Synchronize", it will update the date and time automatically, besides, you can preconcert the date and time, press button "Time Synchronize" again, the automatic update will stop.

Note:
1. Manual settings are lost when the modem is turned off.
2. Note: Please **Commit/Reboot** to make these changes take effect immediately.

Synchronized Instant Time: **2009-1-21 11:27:26**

System Time: **1970-1-1 1:8:25** Refresh

Time Mode: ☒ Time Server ☐ Manual

☐ Enable SNTP Client Update

SNTP Server: ☒ 203.117.180.36 - Asia ▼
☐ (manual setting)

Time Zone: (GMT+08:00) Beijing, Chongqing, Hong Kong, Urumqi ▼

Apply Changes

Fig 3.7.6

Label	Description
Refresh	Click this button to refresh the system shown in the page.
Time Mode	If select Time Server, the router obtains the system time from the time server. If select Manual, you should configure the system time manually.
Enable SNTP Client Update	If select this checkbox, you can choose the correct SNTP Server which you want.
SNTP Server	Choose the SNTP Server here.
Time Zone	Select the Time Zone of in which area you are.
Apply Changes	Click this button to save the settings of this page.

3.7.7 System Log

Click **System Log** in the sub-menu to open the screen of Fig 3.7.7. In this page, you can enable or disabled the System log function, view the system log.




Fig 3.7.7

Label	Description
System Log	You can enable or disable the System Log function.
Apply Changes	Click this button to save the settings of this page.
Refresh	Click this button to refresh the system log shown in the text field.

3.7.8 SNMP

Click **SNMP** in the sub-menu to open the screen of Fig 3.7.8. In this page, you can set the SNMP parameters.

SMC Networks Advanced

Admin Status Wizard LAN WAN Advance Admin Diagnostic

| Remote Access | Commit/Reboot | Password | Backup/Restore | Upgrade Firmware | Time Zone | System Log | **SNMP** | ACL |

SNMP

SNMP Configuration

This page is used to configure the SNMP protocol.

Trap IP Address: 192.168.2.254

Community name (read-only): public

Community name (write-only): public

Apply Changes Reset

Fig 3.7.8

Label	Description
Trap IP Address	Enter the IP address of the trap host. The trap information is sent to this host.
Community name (read-only)	The network administrators must use this password to read the information of this router.
Community name (write-only)	The network administrators must use this password to configure the information of this router.
Apply Changes	Click this button to save the settings of this page.
Reset	Click this button to begin configuring this screen afresh.

3.7.9 ACL

Click **ACL** in the sub-menu to open the screen of Fig 3.7.10. In this page, you can configure the IP Address for Access Control List. If ACL enabled, only the effective IP in ACL can access ADSL Router.



Fig 3.7.10

Step 1: If you want to enable ACL, select "Enable" and click "Apply Changes".

Step 2: Configure Access Control List.

Step 3: Click "Apply Changes" to effect the configuration.

Note: If you check "Enable" in ACL Capability, please make sure that your host IP is in ACL List before it takes effect

3.8 Diagnostic

Click **Diagnostic** in the menu to open the sub-menu which contains 4 items: **Ping**, **ATM Loopback**, **ADSL** and **Diagnostic**.

3.8.1 Ping

Click **Ping** in the sub-menu to open the screen of Fig 3.8.1.




Fig 3.8.1

Label	Description
Host Address	Enter the IP Address here.
Send	Click this button to begin to Ping the Host Address .

3.8.2 ATM Loopback

Click **ATM Loopback** in the sub-menu to open the screen of Fig 3.8.2. In this page, you can use VCC loopback function to check the connectivity of the VCC.




Fig 3.8.2

Apply Changes: Click this button to begin testing.

3.8.3 ADSL

Click **ADSL** in the sub-menu to open the screen of Fig 3.8.3. This page is used for ADSL Tone Diagnostics.

The screenshot shows the SMC Networks Advanced Diagnostic interface. The top navigation bar includes 'Diagnostic', 'Status', 'Wizard', 'LAN', 'WAN', 'Advance', 'Admin', and 'Diagnostic'. Below this, a sub-menu bar shows 'Ping | ATM Loopback | ADSL | Diagnostic |'. The left sidebar has 'ADSL' selected. The main content area is titled 'Diagnostics -- ADSL' and contains the text 'Adsl Tone Diagnostics.' followed by a 'Go!' button. Below the button is a table with two columns: 'Downstream' and 'Upstream'.

	Downstream	Upstream
Hlin Scale		
Loop Attenuation(dB)		
Signal Attenuation(dB)		
SNR Margin(dB)		
Attainable Rate(Kbps)		
Output Power(dBm)		

Fig 3.8.3

Go!: Click this button to begin ADSL Tone Diagnostics.

3.8.4 Diagnostic

Click **Diagnostic** in the sub-menu to open the screen of Fig 3.8.4. This page is used for testing your DSL connection.

The screenshot shows the SMC Networks Advanced Diagnostic interface. The top navigation bar includes 'Diagnostic', 'Status', 'Wizard', 'LAN', 'WAN', 'Advance', 'Admin', and 'Diagnostic'. Below this, a sub-menu bar shows 'Ping | ATM Loopback | ADSL | Diagnostic |'. The left sidebar has 'Diagnostic' selected. The main content area is titled 'Diagnostic Test' and contains the text: 'The DSL router can test your DSL connection. The individual tests are listed below. If a test displays a fail status, click the "Run Diagnostic Test" button again to make sure the fail status is consistent.' Below this text is a dropdown menu labeled 'Select the Internet Connection:' with 'Internet_R_0_36' selected. To the right of the dropdown is a 'Run Diagnostic Test' button.

Fig 3.8.4

Run Diagnostic Test: Click this button to begin testing.

Appendix A

Questions & Answers

This section describes common problems you may encounter and possible solutions to them. The Barricade can be easily monitored through panel indicators to identify problems.

1. Question: Why all LED indicators are off?

Answer:

- Check the connection between the power adaptor and the power socket
- Check the power switch is on or not

2. Question: Why LAN LED is not lighting?

Answer:

- Check the connection between the ADSL modem and your computer or Hub/Switch
- Check your PC or Hub/Switch running status and make sure them are working normally.

3. Question: Why ADSL LED is not lighting?

Answer: Check the connection between the ADSL “line” port and the wall jack.

4. Question: Why cannot visit Internet with ADSL LED is on?

Answer: Make sure following information has been input correctly:

VPI/VCI

User/password.

5. Question: Why cannot open the Modem configuring web page?

Answer:

Follow below steps to check the communication between the computer and Modem:

Click start -> run (input ping demands)-> Ping 192.168.2.1 (MODEM IP address).

If cannot reach the modem, please check following configuration:

- The type of the network cable
- The connection between the modem and computer
- You computer's TCP/IP configuration

6. Question: How to load the default setting after incorrect configuration?

Answer:

Press "reset" button 5s-10s to load the default configuration. The modem's default IP address: 192.168.2.1/255.255.255.0,

Username/password: admin/smcadmin

Appendix B

Technical Specifications

External Connectors

- 1 push power switch
- 1 DC power jack
- 1 factory reset button
- 4 LAN 10/100M Auto MDI/MDIX RJ45 ports
- 1 WAN RJ11 DSL port

Protocol Feature

Bridging/Routing

- RFC 1483 Bridge
- IEEE 802.1D transparent bridging
- Bridge Filtering
- RFC 1483 Router
- RIP 1 & 2 supported
- DHCP (RFC1541) Server, Relay
- Network Address Translation (NAT)/ Network Address Port Translation (NAPT)
- DNS relay
- IGMP v1 and v2

Encapsulation

- RFC 1483 router/bridge
- PPPoA
- PPPoE
- MER

ADSL Feature

- Support ANSI T1.413 Issue2
- Support ITU G.992.1(G.dmt) Annex A
- Support ITU G.992.2 (G.lite) Annex A
- Support ITU G.992.3 ADSL2(G.dmt.bis) Annexes A, L, M
- Support ITU G.992.4 ADSL2(G.lite.bis)
- Support ITU G.992.5 ADSL2plus

Ethernet Feature

- Fully compliant with IEEE802.3/802.3u auto-negotiation function
- Support 10base-T, 100base-TX
- Support half duplex, full duplex
- Support back pressure flow control for half duplex, IEEE802.3x flow control for full duplex
- Support MDI/MDIX auto cross

Management Support

- Support WEB/TFTP mode which use as native and long-distance edition upgrade
- Support test estate of circuitry connect (Diagnostics)
- Support WEB interface setting
- Support Telnet CLI command line
- Support user setting the reset function : hardware reset or WEB interface mode
- Support configuration files backup and resume function
- Support LAN port IP address amend function
- Support System LOG function
- Support SNMP V1/V2C native and long-distance control (MIB II RFC1213/ADSL line MIB RFC 2662 ATM MIB RFC 2515)
- Support SNTP enactment

Security Support

- Support firewall function
- Support the passwords of two grades of users and can be revised
- Support and sign electronically the function (prevent the different kind of editions from upgrading each other)
- Support DOS (Denial of service) which detect & protect a number of attacks (such as SYN/FIN/RST Flood, Smurf, WinNuke, Echo Scan, Xmas Tree Scan)
- Packet filter based on IP and port
- Access control based on MAC
- PAP, CHAP authentication

Environment

- Operating temperature: 0°C to 40°C (32°F to 104°F)
- Storage temperature: -20°C to 70°C (-13°F to 131°F)
- Operating humidity: 10%~85% Non-Condensing
- Storage humidity: 5%~95% Non-Condensing
- External adapter spec: Input: AC220V, 50Hz. Output: 12V DC, 1000 mA(min)
- Dissipation: 7W (max)

Appendix C

GPL Announcement

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.,

51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Lesser General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the

program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

GNU GENERAL PUBLIC LICENSE TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.

b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.

c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that

you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING,

REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING

OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

<one line to give the program's name and a brief idea of what it does.> Copyright (C) <year> <name of author>

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA.

Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) year name of author

Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type `show w'.

This is free software, and you are welcome to redistribute it under certain conditions; type ``show c'` for details.

The hypothetical commands ``show w'` and ``show c'` should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than ``show w'` and ``show c'`; they could even be mouse-clicks or menu items--whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the program
'Gnomovision' (which makes passes at compilers) written by James Hacker.

<signature of Ty Coon>, 1 April 1989 Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Lesser General Public License instead of this License.

TECHNICAL SUPPORT

From U.S.A. and Canada (24 hours a day, 7 days a week)

Phn: (800) SMC-4-YOU / (949) 679-8000

Fax: (949) 679-1481

English: Technical Support information available at www.smc.com

English(For Asia Pacific): Technical Support information available at www.smc-asia.com

Deutsch: Technischer Support und weitere Information unter www.smc.com

Español: En www.smc.com Ud. podrá encontrar la información relativa a servicios de soporte técnico

Français: Informations Support Technique sur www.smc.com

Português: Informações sobre Suporte Técnico em www.smc.com

Italiano: Le informazioni di supporto tecnico sono disponibili su www.smc.com

Svenska: Information om Teknisk Support finns tillgängligt på www.smc.com

Nederlands: Technische ondersteuningsinformatie beschikbaar op www.smc.com

Polski: Informacje o wsparciu technicznym są dostępne na www.smc.com

Čeština: Technická podpora je dostupná na www.smc.com

Magyar: Műszaki támogat információ elérhető -on www.smc.com

简体中文: 技术支持讯息可通过www.smc-prc.com查询

繁體中文: 產品技術支援與服務請上 www.smcnetworks.com.tw

ไทย: สามารถหาข้อมูลทางด้านเทคนิคได้ที่ www.smc-asia.com

한국어: 기술지원관련 정보는 www.smc-asia.com을 참고하시기 바랍니다

INTERNET

E-mail address: www.smc.com→ Support→ By email

Driver updates: www.smc.com→ Support→ Downloads

World Wide Web: <http://www.smc.com/>



SMC7904BRA3