



SKYWAY-MOBILE SERIES

Base Transceiver Station

User's Guide

July 2008

Rev 1

Note: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his/her own expense.

1. Introduction

Congratulations on your purchase of a SkyWay-Mobile BTS system. This user's guide contains basic description of the system, basic installation and configuration steps to act as a basic guideline for the end user. This guide is not to act as a step-by-step guide for self-installation by end users.

This product requires a full professional installation services by Solectek's field engineering staff or authorized reseller officially certified by Solectek. The installation services will include the following work:

- Site survey and RF planning.
- Drive test, mapping of the coverage area.
- Physical mounting of the outdoor components on tower or rooftop
- Antenna alignment
- Configuration, calibration and troubleshooting
- Commission of the service

Product Features

The SkyWay-Mobile BTS unit has the following features

- Throughput – up to 15 Mbps in a 5 MHz channel BW.
- Chanel BW – 1, 2, 3, 4, or 5 MHz, user configurable
- Support for more than 300 subscribers
- Support for 150 simultaneous phone calls
- N=1 Frequency reuse
- Voice service support – proprietary mode or VoIP

2. Installation

Installation Cabinet

The SkyWay-Mobile BTS is typically installed in a standard 19 inch cabinet. The outer dimensions are:

- Height x Width x Depth – 1550 mm x 600 mm x 722 mm

The following is a diagram of the cabinet, as an example.




Fig 2-1: SkyWay-Mobile BTS cabinet

2.2 Position and Installation of Cabinet

Layout of Cabinet

It is recommended to position the BTS cabinet as shown in Figure 2-2 in accordance with the following guidelines.

- The spacing between the rear side of the cabinet and the wall should be at least 600mm.
- In the front side of the cabinet, at least 600mm spacing should be reserved as a work area.




Fig 2-2: Layout of the network facility and location of BTS cabinet

Place the cabinets based on the engineering design requirements and accurately mark out the positions of the supports on the floor. Install the accessories for cabinet installation, as shown in Figure 2-3. Drill vertical holes with the appropriate punch drill and drill bit, and then install M12 expansion bolts.




Figure 2-3: Installation of cabinet accessories

Do not over tighten the expansion bolts so that the installation accessories can be easily moved if necessary. Install the cabinet in the preset position, and then rotate the

accessories to move the U-shape opening on the corresponding round steel bar of the cabinet support, as show in Figure 2-5.




Figure 2-4 Bottom of the cabinet

Position the cabinet, make it sit flat by using a level and then tighten the expansion bolts. Check the insulation impedance with a meg-ohmmeter between the cabinet and the floor and make sure that the value is greater than 5MΩ.

2.3 BTS Installation

The overall structure of the BTS is shown in Figure 2-5.

Open the cabinet door, adjust the partition positions, push the BTS into the sub-rack. Record the model and Factory No. of the BTS and cable loss data for future references. Keep this set of information at an easily accessible location.

Make sure that any empty slot in the BTS enclosure is filled in with a cover panel.




Figure 2-6: Rack-mount BTS Enclosure

2.4 Connection of Ethernet Cable

The following diagram (Fig 2-7) shows the connections between the BTS and a network switch. The data interface on the BTS is Ethernet with standard RJ-45 connector, as shown below in Figure 2-7.





Figure 2-7 RJ-45 Ethernet Connector

Fabricate the Ethernet cable using the RJ-45 connectors shown in Fig 2-7. Connect one end to the Ethernet port located on the bottom left side of the BTS front panel as shown in Fig 2-8 and the other to a network switch or other transmission equipment.



Ethernet cable port
 Fig 2-8: Front panel of the BTS with the Ethernet port

2.5 Connect Power Cable

The BTS uses a DC+24V power supply. A +24V power source may be locally available as part of telco closet facility. Solectek supplies either of the following power supply options in case that the user needs to use a separate stand-alone power supply.

- 220/120 V AC to +24V DC power supply unit.
- -48V DC to 24V DC power supply unit (in case -48V DC is available on site).

A stand-alone power supply must be securely installed in the cabinet. An example of a typical power supply is shown in Figure 2-9.



Fig 2-9: An example of a stand alone power supply to be installed in the cabinet

In case of an AC installation, first use a standard electrical cord to bring 120/220V AC to the power supply's AC input, connect the equipment's DC output to the cabinet's circuit breaker and then the grounding to the cabinet's pooling current bar.

WARNING: AC/DC equipment installation and use must strictly comply with the AC/DC equipment instruction requirements, and reliable grounding must be finished through grounding cable




Figure 2-10: BTS rear panel with BTS power cable connections shown.

Use flame retardant cables as base station power cables, press them out through $\Phi 6$ copper lug, and screw down on the base station power wire posts, as shown in Figure 2-10.

Connect one end of the DC+24V power cable to the air switch at the cabinet's bottom, the red is connected to the positive pole, and the blue is connected to the negative pole.

Connect the other end to DC power cabinet's output terminal correspondingly, the red is connected to the positive pole (the working ground), and the blue is connected to the negative pole. One end of the greenish yellow is connected to the pooling current bar of the base station cabinet, and the other end is connected to the protection grounding bus bar in the equipment room, as shown in Figure 2-11.




Figure 2-11: Power distribution board

Connect one end of the power cable to the power distribution board underneath the rear of the cabinet, and the other end to base station power wire posts. Complete the connection for the air switch and the power distribution board as shown in Figure 2-12.




Figure 2-13 Connection map of the power

Connect the power cables to the connection at the side of electric power distribution cabinet and label the connection as well. Connect the grounding bus bar to grounding cable via connection and tighten it with bolts. The carrier's staff are required to cooperate on the scene when connect power cable to power distribution cabinet, connecting the cables after having cut designated branch switch. After connection, close the branch switch (make sure to close the air switch firstly), then connect the black pen of the multi-meter with voltage grade to air switch working grounding and the red pen to

air switch +24V end, if measurement value shows 24 (± 3) V, connection is correct. And then close designated branch switch.

WARNING: Do not bundle power cables with other cables. They must be cabled separately.

2.6 Cabling Requirements in the Equipment Room

The following installation requirements must be followed in order to prevent accidents or damages to the equipment.

- In the equipment room, transmission cables on the cable ladder should be cabled separately from power cables and grounding wires, without any cross connection. The cabling should be done in a tidy and nice order. Excessive cables should be bundled up with cable ties and then placed on the cable ladder in the equipment room. Attached white cable ties should be used in an interval less than 400mm.
- The RF feeders between the cable ladder and the RF feeder, any elbow should be kept smooth without cross connection. The elbow angle should be $\geq 90^\circ$.
- Some cables, such as the GPS cable from the cable ladder to the cabinet, 7D-FB feeder, Ethernet cable, power cables of the BTS and the cabinet's grounding wires, should be vertically led into the cabinet's cabling holes from the cable ladder.
- Both ends of Ethernet cable should be labeled clearly. Make sure to check the Ethernet cable to ensure good contact;
- Both ends of the ground wire should be connected with specific connectors (copper lug). After checking the connectors, wrap the connection between the grounding wire and the connector with insulation tape. On the grounding wire provided upon delivery, no connection is allowed in the middle. Both ends should be tightened with bolts;
- On the power cables configured along with delivery, no connection is allowed in the middle. After connection, label the power cables clearly close to the switch. Close the branch switch on the power distribution cabinet to check the power to be connected to the BTS. If the power is correct, switch it off and connect it to the BTS.
- Power cable and signal cable in the cabinet should be distributed separately, leading power cable (connect to circuit breaker) and protection grounding cable should be laid in the cabling troughs' outboard on the left of the cabinet (see behind), GPS cable should be laid in the cabling troughs' middle, and Ethernet cable should be laid in the cabling troughs' indoor. Base station power cable should be laid in the cabling troughs on the right of the cabinet.

3. Startup Process

3.1 Base station overview

As the core element in the SkyWay-Mobile system, the BTS is the bridge between wireless transmission and wired backbone network. After the packet data signal is received at the base station from backbone network, the message is mapped with EID of the terminal and then forwarded to MDM board. After digital modulation at the DMD board, the modulated signal undergoes channel packing and processing at the CHP board and is converted into base-band signal, which is received by IF board from CHP board. Then the signal transformed to intermediate frequency and transmitted to RFC board. The signal, after transformation, is converted by RFC board to radio frequency, forwarded to TTA and transmitted after amplification.

In the same way, the uplink signal is transmitted to cable backbone network via base station in a reverse order. The routine operation of base station mainly focuses on the power and system capacity of the base station system.

3.2 EMS configuration

Before power-on the base station, some basic parameters have to be input to substations through serial port on the main board. These configuration parameters are often used as "boot parameters", with which the base station can establish communication with EMS server so that all configuration parameters can be downloaded to base station from EMS.

To maintain normal communication links, EMS server is usually connected to the main board of the base station through hub or switch (10/100 Base-T), while the debugging computer is connected to the serial port on the main board through RS-232 serial cable. The serial ports on the main board and debugging computer should be available at this time. After this, the base station is initialized and configured through some general communication software, such as HyperTerminal, the standard terminal emulation software.

3.2.1 Basic procedures

Make sure that all RF cables at the base station are correctly connected. There are 8 data RF cables and 1 calibration RF cable, as indicated on the front panel of the BTS unit.

Connect the Ethernet interface on the main board of the base station to a network switch using a standard Ethernet cable and then connect the switch to the PC with EMS server installed using another Ethernet cable.

Connect the serial port on the main board of BTS to the serial port of debugging computer through RS-232 cable (DB-9 male-female). Power-on EMS server and start debugging computer. Configure FTP server tool. It can be installed on any computer that can communicate with BTS or EMS.

Start EMS server and client in EMS server computer. Make sure that EMS server and client application are installed and configured properly

Enter EMS SERVER IP and port in IE address bar to enter EMS client GUI interface (refer to the EMS server user's guide for details). Input user name and password in EMS client login screen to start the process.

3.2.2 FTP Server Configuration

Add the base station load program to the server with the FTP server and make sure that there is a link between the FTP server, the EMS server and the BTS as shown in Fig 3-1.

Start installed FTP server software, such as serv-u, sonicftp, etc. Add user after starting and specify the path for user to read as the path where Load programs are located, for example, user name: emstest, path: d:\release0.3.2.1.




Fig 3-1: Window to enable addition of users




Fig 3-2: Window to specify the server path

3.2.3 HyperTerminal configuration

Make sure that the computer is furnished with HyperTerminal software. Tera Term Pro software is strongly recommended and it can be downloaded from a shareware website.

Click desktop shortcut to run HyperTerminal software. The following screen will show upon startup:




Fig 3-3 HyperTerminal configuration

Select "serial", "COM1" port and click [OK] button (Fig 3-4)




Fig 3-4: HyperTerminal configuration – Serial port

Clicking OK in Fig 3-4 should prompt the following screen (Fig 3-5). Go to “Setup” on the menu and select “Serial port”.




Fig 3-5 HyperTerminal configuration – Serial port setup

In the serial port setup screen (Fig 3-6), set the baud rate of the serial port to 19200. The serial port will not function at any other baud rate value.




Fig 3-6 HyperTerminal configuration (4)

The serial port is now successfully configured and can be used for configuring information (such as IP address) for connected base station so that the base station is linked to the EMS server.

3.3 Add a BTS in EMS Server

If the client program is running in EMS Server computer, click [Resource Management] to add new base station. Here only some necessary configurations are required, such as base station name, ID, IP address, subnet mask and network gateway, etc, which should be filled in according to your system network plan design.

Go to "Net Element" and select "Add Net Element" (Fig 3-7) and the "Add Net Element" screen will be shown (Fig 3-8).




Fig 3-7 Add a net element (Base Station)




Fig 3-8 "Add Net Element" screen

All entries with the asterisk "*" are required according to the parameters below (content and writing specifications).

- * BTS ID: in digits, the id assigned to the BTS

- SAG signal IP: IP address of sag signaling connected to the BTS
- SAG voice IP: IP address of sag voice connected to the BTS
- SAG ID: sag id connected to bts in digits
- Signaling sending port: signaling sending port specified
- Sag media port: media port specified
- Sag signaling code: manner of signaling coding
- Antenna type: omni-direction or directional
- Network element type: the frequency range used by network elements; at present 4 types are available: 3.3 G, 2.4G, 1.8G and 400M
- Network element name: name specified for BTS, with digits, letters and Chinese characters
- Acceptable Network element ip: ip address specified to the base station
- Network id: id assigned by carrier
- Region id: in digits
- Signaling receiving port: signaling receiving port specified
- BTS media port: media port specified
- BTS signaling coding: manner of signaling coding
- EMS: name of the front-end processor connected to the base station




Fig 3-9: "Add Net Element" screen with input values filled in.




Fig 3-10: Net Element Management Screen

3.4 Base Station Startup

3.4.1 Base station normal startup

Base station power-on

For startup, the base station power, RF cables, calibration cable and GPS etc. must be correctly connected. In particular make sure that the L3 network cable is connected. Also the serial port cable of the base station can be connected to PC to update BTS IP information or view startup message, etc. When everything is connected, switch on the power, then switch on the main switch at the back of BTS and the base station will enter startup.

Base station boot

The following is the content displayed and to be configured in HyperTerminal window during base station startup.

```
bootrom booting!!!!!!!
VxWorks System Boot
Copyright 1984-2002 Wind River Systems, Inc.
CPU: 7447A Power PC
Version: VxWorks5.5.1
BSP version: 1.0/0
Creation date: Aug 4 2006, 13:44:28
Press any key to stop auto-boot...
```

Configuration of Parameters

Press any key on the keyboard to stop automatic startup and input configuration information to configure base station:

Now there will be a boot message in HyperTerminal screen: [VxWorks Boot]:

This message provides some operations of simple commands. Input "?" or "h" and press [Enter] to display a set of commands (and examples). To use any command, just input character

command with optional parameters and press [Enter].

Boot Commands

```
[VxWorks Boot]: ?
? - print this list
@ - boot (load and go)
p - print L3 boot params
P - print L2 boot params
c - change L3 boot params
C - change L2 boot params
l - load boot file
g adrs - go to adrs
d adrs[,n] - display memory
m adrs - modify memory
f adrs, nbytes, value - fill memory
t adrs, adrs, nbytes - copy memory
e - print fatal exception
v - print boot logo with version
n netif - print network interface device address
$dev(0,procnum)host:/file h=# e=# b=# g=# u=usr [pw=password] f=#
tn=targetname s=script o=other
boot device: ata=ctrl,drive file name: /ata0/vxWorks
Boot flags:
0x02 - load local system symbols
0x04 - don't autoboot
0x08 - quick autoboot (no countdown)
0x20 - disable login security
0x40 - use bootp to get boot parameters
0x80 - use tftp to get boot image
0x100 - use proxy arp
available boot devices:Enhanced Network Devices
mv0 ata
```

Explanations of all commands:

- @ -Used when all parameters are set as required. This command will continue to execute previously cancelled boot initialization process.
- p - This command will display a brief description of L3 parameters in current boot configuration.
- P - This command will display a brief description of L2 parameters in current boot configuration.
- c - This command can be used to change current L3 boot parameters. Once this command is selected, a detailed option list will be displayed. Modify and overwrite it. When all options are modified, the system will return to [VxWorks Boot]: message. During these processes, press [Enter] to accept current parameters value or input new parameters value and press [Enter] to confirm. Besides, input "." and press [Enter] to clear current value of this entry and restore it to default. If any error occurs, process "-(hyphen)" and [Enter] to return to previous option. Or you can continue this erroneous entry and modify it when returning to [VxWorks Boot]: command line.

- C - This command can be used to change current L2 boot parameters. Once this command is selected, a detailed option list will be displayed. Modify and overwrite it. When all options are modified, the system will return to [VxWorks Boot]: message. During these processes, press [Enter] to accept current parameters value or input new parameters value and press [Enter] to confirm. Besides, input "." and press [Enter] to clear current value of this entry and restore it to default. If any error occurs, process "-(hyphen)" and [Enter] to return to previous option. Or you can continue this erroneous entry and modify it when returning to [VxWorks Boot]: command line.
- d - display memory usage; the user-defined base station memory to be displayed can be viewed here. This operation can only be conducted by Solectek certified technical support engineer.
- m - modify memory. This option allows the user to change allocation of base station memory as per the user's requests. This operation can only be conducted by Solectek certified technical support engineer.
- f - fill memory. This option allows changing BTS memory with a set mode. This operation can only be conducted by Solectek certified technical support engineer.
- t - fill memory. This option allows changing BTS memory with a set mode from other memory area. This operation can only be conducted by Solectek certified technical support engineer.

Input "c" to configure L3.

```
[VxWorks Boot]: c
'.' = clear field; '-' = go to previous field; ^D = quit
boot device : mv0 : Boot BTS from ftp server
processor number : 0
host name : hy : host username
file name : l3_image : filename of L3 startup
inet on ethernet (e) : 192.168.17.160:ffffff00 : IP and subnet mask
of L3
inet on backplane (b): 10.0.0.1 : IP of L3's BP
host inet (h) : 192.168.11.199 : IP of ftp server
gateway inet (g) : 192.168.17.1 : IP of L3's gateway
user (u) : emstest : username of ftp server
ftp password (pw) (blank = use rsh): emstest : FTP password
flags (f) : 0x0
target name (tn) :
startup script (s) :
other (o) :
[VxWorks Boot]:
```

Input "C" to configure L2.

```
[VxWorks Boot]: C
'.' = clear field; '-' = go to previous field; ^D = quit
boot device : mv0 : Boot BTS from ftp server
processor number : 0
host name : hy : host username
file name : l2_image.bin : filename of L2 startup
inet on ethernet (e) : 192.168.17.161:ffffff00 : IP and subnet
mask of L2
inet on backplane (b): 10.0.0.2 : IP of L2's BP
host inet (h) : 192.168.11.199 : IP of ftp server
```

```
gateway inet (g) : 192.168.17.1 : IP of L3's gateway
user (u) : emstest : username of ftp server
ftp password (pw) (blank = use rsh): emstest : FTP password
flags (f) : 0x0
target name (tn) :
startup script (s) :
other (o) : 0.250.0.37
[VxWorks Boot]:
```

Input "p" to view L3 configuration.

```
[VxWorks Boot]: p
boot device : mv
unit number : 0
processor number : 0
host name : hy
file name : l3_image
inet on ethernet (e) : 192.168.17.160:ffffff00
inet on backplane (b): 10.0.0.1
host inet (h) : 192.168.11.199
gateway inet (g) : 192.168.17.1
user (u) : emstest
ftp password (pw) : emstest
flags (f) : 0x0
```

Input "P" to view L2 configuration.

```
[VxWorks Boot]: P
boot device : mv
unit number : 0
processor number : 0
host name : hy
file name : l2_image.bin
inet on ethernet (e) : 192.168.17.161:ffffff00
inet on backplane (b): 10.0.0.2
host inet (h) : 192.168.11.199
gateway inet (g) : 192.168.17.1
user (u) : emstest
ftp password (pw) : emstest
flags (f) : 0x0
other (o) : 0.250.0.37
```

Boot process

```
[VxWorks Boot]: @
boot device : mv
unit number : 0
processor number : 0
host name : hy
file name : l3_image
inet on ethernet (e) : 192.168.17.160:ffffff00
inet on backplane (b): 10.0.0.1
host inet (h) : 192.168.11.199
gateway inet (g) : 192.168.17.1
user (u) : emstest
ftp password (pw) : emstest
flags (f) : 0x0
Attached TCP/IP interface to mv0.
```



```
rtc year : 2006 : Configure year
rtc month : : 11 : Configure month
rtc day : 8 : Configure date
rtc hour : 11 : Configure hour
rtc minute : : 11 : Configure minute
rtc second : : 2 : Configure second
[BOOT]:BS booting
[BOOT]: @
L3 Application booting..... Done
Now bts is successfully started.
bts(160) L3->3b55bae0 tCleanUp:0000 L3DataEB.cpp( 840) :
CleanUp sta
rt monitoring.
SatellitesVisible = 0
StatellitesTrack = 0
BootSrc = 0
RfMask = 0X00FF
SyncCardTemperature = 0
DigitalBoardTemperature = 0
TimePassedSinceBtsBoot = 0 seconds
[2006/11/08 11:11:0] [tSys] BTS software version: 0.3.2.1
: Display BTS software version
[2006/11/08 11:11:0] [tSys] BTS boot normal!
[2006/11/08 11:11:0] tSys create ok!
[2006/11/08 11:11:0] tEmsRx create ok!
[2006/11/08 11:11:0] tEmsTx create ok!
[2006/11/08 11:11:0] [tDiagL2L3EMS] create m_sfdl2l3[15] ok!
[2006/11/08 11:11:0] [tDiagL2L3EMS] create m_sfdl3ems[16] ok!
[2006/11/08 11:11:0] tDiagL2L3Ems create ok!
[2006/11/08 11:11:0] [tDiagEMSL3L2] create m_sfdems13[17] ok!
[2006/11/08 11:11:0] [tDiagEMSL3L2] create m_sfdl3l2[18] ok!
[2006/11/08 11:11:0] tDiagEmsL3L2 create ok!.
[2006/11/08 11:11:0] tAlarm create ok!
[2006/11/08 11:11:0] tCfg create ok!
[2006/11/08 11:11:0] mode = tFileM create ok!
0
[2006/11/08 11:11:0] tFtpC create ok!
[2006/11/08 11:11:0] tCpeM create ok!.
mode 0: no hold; 1: enable position hold; 2:enable altitude hold; 3:
autosite survey
[2006/11/08 11:11:0] tGps create ok!
[2006/11/08 11:11:0] tPM create ok!
[2006/11/08 11:11:0] [tSys] All OAM tasks create ok! : system se
lf-test over
[2006/11/08 11:11:0] [tSys] Send Register Notify to EMS[192.168.11.
199] @state[0] bts send register message to ems server
[2006/11/08 11:11:0] [BTS boot] ==> BTS booting from FTP server
[2006/11/08 11:11:0] [tSys] BTS send to EMS register response, stat
e[0]
[2006/11/08 11:11:0] [tSys] BTS register SUCCEED. Bts register
succeed
[2006/11/08 11:11:0] [BTS boot] ==> Download file :l2_image.bin fini
shed
[2006/11/08 11:11:0] [BTS boot] ==> Download file :app_mcp.out fini
shed
[2006/11/08 11:11:0] [BTS boot] ==> Download file :app_aux.out fini
shed
[2006/11/08 11:11:0] [BTS boot] ==> Download file :app_fep.out fini
shed
```



```
[2006/11/08 11:11:0] [BTS boot] ==> Download file :fpga_L2.out finished
[2006/11/08 11:11:0] [BTS boot] ==> Download file :fpga_L1.out finished
[2006/11/08 11:11:0] [BTS boot] ==> Download file :fpga_FEP0.out finished
[2006/11/08 11:11:0] [BTS boot] ==> Download file :fpga_FEP1.out finished
```

Download booting file is now completed.

```
[2006/11/08 11:11:0] [BTS boot] ==> FPGA download started
[2006/11/08 11:11:0] [BTS boot] ==> FPGA download succeed
[2006/11/08 11:11:0] [BTS boot] ==> Reset FPGA
```

Start the FPGA circuit module.

```
[2006/11/08 11:11:0] [BTS boot] ==> Reset AUX : Start AUX circuit module.
[2006/11/08 11:11:0] [BTS boot] ==> Reset L2 PowerPC system
[2006/11/08 11:11:0] [BTS boot] ==> L2 PreLoader is ready to accept L2 Image
[2006/11/08 11:11:0] [BTS boot] ==> L2 PPC image download finished
[2006/11/08 11:11:0] L2 PCI interface is ready for message exchange
[2006/11/08 11:11:0] [tSys] BTS L2 boot up SUCCESS
```

BTS L2 boot is now completed

```
[2006/11/08 11:11:0] [BTS boot] ==> MCP 0 reset, start code download
[2006/11/08 11:11:0] [BTS boot] ==> MCP 1 reset, start code download
[2006/11/08 11:11:0] [BTS boot] ==> MCP 2 reset, start code download
[2006/11/08 11:11:0] [BTS boot] ==> MCP 3 reset, start code download
[2006/11/08 11:11:0] [BTS boot] ==> MCP 4 reset, start code download
[2006/11/08 11:11:0] [BTS boot] ==> MCP 5 reset, start code download
[2006/11/08 11:11:0] [BTS boot] ==> MCP 6 reset, start code download
[2006/11/08 11:11:0] [BTS boot] ==> MCP 7 reset, start code download
[2006/11/08 11:11:0] [BTS boot] ==> AUX Reset, start AUX code download
[2006/11/08 11:11:0] [tSys] BTS MCP[0] boot up SUCCESS
[2006/11/08 11:11:0] [tSys] BTS MCP[1] boot up SUCCESS
[2006/11/08 11:11:0] [tSys] BTS MCP[2] boot up SUCCESS
[2006/11/08 11:11:0] [tCpeM] receive msg[0x3706] from task[57]
[2006/11/08 11:11:0] [tSys] BTS MCP[3] boot up SUCCESS
[2006/11/08 11:11:0] [tSys] BTS MCP[4] boot up SUCCESS
[2006/11/08 11:11:0] [tSys] BTS MCP[5] boot up SUCCESS
[2006/11/08 11:11:0] [tSys] BTS MCP[6] boot up SUCCESS
[2006/11/08 11:11:0] [tSys] BTS MCP[7] boot up SUCCESS
```

MSP circuit module boot is now completed

```
[2006/11/08 11:11:0] [tSys] BTS AUX boot up SUCCESS
[2006/11/08 11:11:0] [BTS boot] ==> Reset FEP 0
[2006/11/08 11:11:0] [BTS boot] ==> Reset FEP 1
[2006/11/08 11:11:0] [BTS boot] ==> FEP 0 reset, start code download
[2006/11/08 11:11:0] [BTS boot] ==> FEP 1 reset, start code download
[2006/11/08 11:11:0] [tSys] BTS FEP[0] boot up SUCCESS
[2006/11/08 11:11:0] [tSys] BTS FEP[1] boot up SUCCESS
```



```

[2006/11/08 11:11:0] [tCfg] receive msg = 0x301b
[2006/11/08 11:11:0] [tCfg] receive msg = 0x301b
[2006/11/08 11:11:0] [tCfg] receive msg = 0x301b
[2006/11/08 11:11:0] [tCfg] receive msg = 0x301b
[2006/11/08 11:11:0] [tCfg] receive msg = 0x301b
[2006/11/08 11:11:0] [tCfg] receive msg = 0x301b
[2006/11/08 11:11:0] [tCfg] receive msg = 0x301b
[2006/11/08 11:11:0] [tCfg] receive msg = 0x301b
[2006/11/08 11:11:0] [tCfg] receive msg = 0x301b
[2006/11/08 11:11:0] [tCfg] receive msg = 0x301b
[2006/11/08 11:11:0] [tCfg] receive msg = 0x301b
[2006/11/08 11:11:0] [tCfg] receive msg = 0x301b
[2006/11/08 11:11:0] [tCfg] receive msg = 0x301b
[2006/11/08 11:11:0] [tCfg] receive msg = 0x301b
[2006/11/08 11:11:0] [tCfg] receive msg = 0x301b
[2006/11/08 11:11:0] [tCfg] receive msg = 0x301b
[2006/11/08 11:11:0] [tCfg] receive msg = 0x301b
[2006/11/08 11:11:0] [tCfg] receive msg = 0x301b
[2006/11/08 11:11:0] [tCfg] receive msg = 0x301b
[2006/11/08 11:11:0] [tCfg] receive msg = 0x301b
[2006/11/08 11:11:0] [tCfg] receive msg = 0x301b
[2006/11/08 11:11:0] [tCfg] receive msg = 0x301b
[2006/11/08 11:11:0] [tCfg] Syn_Src[1] Antanna Mask in NvRam[00ff]
[2006/11/08 11:11:0] [tCfg] GPS not ready, config Antenna Mask with
0x0000
[2006/11/08 11:11:0] [tCfg] Antanna Mask: [0000]
[2006/11/08 11:11:0] [tCfg] Send L1GenData0 [0001]:
[2006/11/08 11:11:0] [tCfg] Send L1GenData1 [0000]:
[2006/11/08 11:11:0] [tCfg] Send L1GenData2 [0000]:
[2006/11/08 11:11:0] [tCfg] receive msg = 0x3012
[2006/11/08 11:11:0] [tCfg] send Data Init Finish Notify to tSys
[2006/11/08 11:11:0] [tSys] receive Data Init Finish Notify from tC
fg
[2006/11/08 11:11:0] =====
[2006/11/08 11:11:0] BTS IS WORKING STATUS
[2006/11/08 11:11:0] =====

```

BTS startup is now successful.

```

[2006/11/08 11:11:0] [tCfg] Boot from NvRam success!
[2006/11/08 11:12:0] [tGPS] send msg M_L3_L2_L1_GENERAL_SETTING_REQ
RF Mask [0x00ff] success!
[2006/11/08 11:12:0] [tGPS] GPS locked!
[2006/11/08 11:12:0] [tCpeM] receive msg [0x200b] from task [3]
[2006/11/08 11:12:0] [tCpeM] receive msg [0x3706] from task [57]
[2006/11/08 11:13:0] [tCpeM] receive msg [0x3706] from task [57]

```

When the status of the BTS that you just booted up is shown as “connected” or “In operation warning” in net element information screen in EMS, the BTS boot-up sequence has been successfully completed.

3.4.2 Base Station reboot

When base station needs to be rebooted due to incidents happening to BTS or other causes:

First, if the base station is in normal working mode, i.e. there is data output from BTS serial port (or level 3 of telnet), you can enter command “reboot” in L3 command line or “rebootL2” for only rebooting L2.

Second, there is a "Reset" switch on the front panel. Press this button for several seconds and the base station will reset and enter into the reboot sequence; A hard reboot (disconnect main switch at the back of base station rear panel) is not recommended in all circumstances except for severe equipment malfunction that causes other reset options to be unavailable.

4. Calibration

When BTS is successfully started, some of its initializing data can be configured via EMS client so that BTS is calibrated for normal work.

During base station calibration, the inter-antenna phase difference can be measured and the all output power from RFS to antenna can be matched. The calibration should be conducted at least three times to ensure its effectiveness. At least 20 minutes are required for loading new software in RFC.

Complete calibration

As there may be changes in the system due to temperature and climate changes as well as normal equipment aging in normal operation, the base station must be completely calibrated before power-on after implementation. The calibration is based on the target data set in EMS. In the SkyWay-Mobile BTS system complete calibration is adopted. In complete calibration, calculation is conducted of the power and gain in each antenna to get data for calibrating base station antenna. The calibration result covers calibration data of the eight antennas, current sending and receiving amplitude and phase diagrams of the current calibration results, comparison with history calibration data, etc.

In complete calibration a log file will be generated in the “calibration” folder in the “system” of EMS installation folder (standard file location), with standard file name in 154_20061206163046 format. Here, 154 is the base station ID and the digits are the time of calibration (year, month, day, hour, minute, second, or YYYYMMDDhhmmss).

Calibration method

In EMS client computer, open IE and start EMS client GUI in IE address bar; input user name and password in EMS client login window. Click [Resource Management| Network Element Management] and select the bts just added and successfully started. Double click to open BTS panel (Fig 4-1).




Fig 4-1 BTS Panel

Go to “Net Element” on the menu and select “Net Element” (Fig 4-2). The “Net Element Management Screen” is shown in Fig 4-3.



Fig 4-2 Net Element Option on the menu

NetElement Management Record Count:50,Current Page:1,Page Length:20

BTS Id	NetEle...	NetElement IP	Parent ...	NetEle...	Status	Softwar...	Hardwa...	Standb...	Public IP	Public ...
148	BTS_te...	192.168.13.12	default ...	1.8G	Runnin...	1.3.0.7	0.0.0.0		192.16...	8002
55	bts55	192.168.10.52	default ...	1.8G	Discon...	1.3.0.3	0.0.0.0		192.16...	8002
130	400M_...	192.168.16.100	default ...	400M	Runnin...	1.3.0.6	0.0.0.0		192.16...	8002
312	BTS_te...	192.168.1.142	default ...	1.8G	Unregi...	1.3.0.1	0.0.0.0			
317	BTS40...	192.168.1.145	default ...	400M	Unregi...	1.2.0.17	0.0.0.0			
170	BTS_te...	192.168.17.200	default ...	2.4G	Runnin...	1.3.0.6	0.0.0.0		192.16...	8002
424	2.5BTS...	192.168.1.184	default ...	2.4G	Unregi...	1.3.0.1	0.0.0.0			
320	BTS_te...	192.168.1.154	default ...	1.8G	Unregi...	1.2.0.17	0.0.0.0			
454	2.5BTS3	192.168.30.232	default ...	2.4G	Unregi...	1.3.0.1	0.0.0.0			
400	BTS_4...	192.168.30.240	default ...	400M	Unregi...	1.2.0.17	0.0.0.0			
313	BTS40...	192.168.1.143	default ...	400M	Unregi...	1.2.0.17	0.0.0.0			
120	BTS_te...	192.168.10.120	default ...	400M	Runnin...	1.3.0.6	0.0.0.0		192.16...	8002
412	2.5BTS...	192.168.1.142	default ...	2.4G	Unregi...	1.3.0.1	0.0.0.0			
322	BTS40...	192.168.1.155	default ...	400M	Unregi...	1.2.0.17	0.0.0.0			
410	2.5BTS...	192.168.1.140	default ...	2.4G	Runnin...	1.3.0.6	0.0.0.0		192.16...	8002
452	2.5BTS2	192.168.30.232	default ...	2.4G	Unregi...	1.3.0.1	0.0.0.0			
450	2.5BTS1	192.168.30.230	default ...	2.4G	Unregi...	1.3.0.6	0.0.0.0			
318	BTS_te...	192.168.1.146	default ...	1.8G	Unregi...	1.2.0.17	0.0.0.0			
188	BTS_te...	192.168.10.188	default ...	1.8G	Runnin...	1.3.0.7	0.0.0.0		192.16...	8002
176	BTS_te...	192.168.16.176	default ...	400M	Runnin...	1.3.0.7	0.0.0.0		192.16...	8002

Goto 1 Page Length: 20

Fig 4-3: Net Element Management Screen

Some basic configurations are needed at this point:

- Click [System Management-GPS Settings] and select the time zone of the base station in [GMT difference] as shown in Fig 4-4. Click [OK] and the configuration is successful.




Fig 4-4: BTS configuration for GPS time

Click [OK] in the confirmation window, as shown in Fig 4-5.




Fig 4-5: GPS Confirmation Window

Enter [System Configuration / Performance Log settings] and fill in [Server IP] with the server IP for performance log uploading and storage. Please make sure that this IP matches the IP address in front-end processor configuration. For other entries, just keep the default value.




Fig 4-6: FTP server IP configuration

Click [Ok] and the configuration is successful.

[L1 Configuration—L1 Configuration]:

- Antenna mask: Check or uncheck for each one of the 8 antenna masks.
- Sync Source: "Local" or "GPS". Please select "GPS" if GPS is connected.




Fig 4-7: Antenna Mask and GPS Configuration

Click [Ok] and the configuration is successful.

Drag the slider to select central frequency used by base station, as shown in Fig 4-8. The values shown for antenna power, receiving sensitivity, cable loss and power splitter loss are factory assigned.




Fig 4-8: RF Calibration Setting Configuration

Click [Ok] and the configuration is successful in the confirmation window (Fig 4-9).




Fig 4-9: Calibration setting confirmation window

[L2 configuration—Air link] In this screen, the "Fronting Serial ID" supports intra-frequency network. Different numbers should be used for Cell bits;




Fig 4-10: Choosing Sequence ID in the Airlink configuration

Airlink: 2.5BTS_temp2

General Info w0 configuration

General Information

Sequence ID: 2

Max Scale: 0.25

Preamble Scale: 0.1118

Total Time Slot: 8 Downlink TS Number: 4

TimeSlot0	4	RARCH		0.0406	0.1147	
TimeSlot1	8			0.0347	0.0981	
TimeSlot2	RRCH	RRCH	RRCH	0.0406	0.1147	
TimeSlot3				0.0406	0.1147	
TimeSlot4	RACH	RACH	RACH	0.0	0.0	
TimeSlot5				0.0	0.0	
TimeSlot6				0.0	0.0	
TimeSlot7				0.0	0.0	
Sub-carrier	<input checked="" type="checkbox"/> Sub-ca...	<input checked="" type="checkbox"/> Sub-ca...	<input checked="" type="checkbox"/> Sub-ca...	<input checked="" type="checkbox"/> Sub-ca...	<input checked="" type="checkbox"/> Sub-c...	TCH SCALE BCH SCALE

OK Reset Cancel Help

Fig 4-11: Choosing Time slot value in Airlink configuration window

The following default values can be used in most situations.

- Select total time slot, default: 8
- Select total downlink time slot, default: 4




Fig 4-12: Airlink configuration window

Click [Ok] and the configuration is successful.

[L2 Configuration] Radio Resource Management Policy Configuration]: Configure the modulation mode, power control and minimum bandwidth. The default, factory assigned values are recommended.




Fig 4-13: Resource Management Policy Screen

Click the base station to be calibrated and select it.



Fig 4-14: BTS Calibration Screen

Click [L1 Configuration—Calibration Request]




Fig 4-15: BTS Calibration Request

A dialogue box for calibration request pops up. Select calibration type between "Complete calibration" and "Express calibration", then click "OK" and the calibration is successful.




Fig 4-16: Calibration action request window

After calibration, click calibration result to view whether the result is saved and whether the calibration result is correct. If the result is not saved, "No calibration result" will be displayed and if the calibration is not successful, the words will be displayed in red. Meanwhile, please check calibration time to make sure that the calibration result is from current calibration.




Fig 4-17: Calibration Status

The calibration process should be executed more than twice. Make sure that the values are relatively stable(+/-3) and there is no “zero” in the result. After the second calibration is conducted, click [Calibration Data] to show the data for second calibration in the window.




Fig 4-18: Calibration Data: General Info

Calibrate Date

If the calibration date can't be updated in base station calibration, the following two solutions can be adopted: Make sure that ftp (Serve-U) is working properly: for example, the user name and password for calibration are correctly matched; the folder of calibration file is correct or not, etc. Make sure that the FTP IP information is correctly set in performance logs.




Fig 4-19: Calibration of FTP settings

5. Operating Status

Any communication equipments must work within a certain range of temperatures because over-high and over-low temperatures will affect its performance. For SkyWay-Mobile BTS system the working temperature is between 0 and 50 centigrade degree. At the digital panel of the base station there is temperature sensor for real time monitoring of digital chipset board and transmitting detected temperature to EMS network management system.

General steps for viewing base station status:

Enter the EMS screen and double click the base station to view, then select [OAM Command—BTS System Status] and the corresponding information will pop up.




Fig 5-1: Accessing the BTS System Status




Fig 5-2: BTS Status Display


- Current user number: the amount of CPE currently registered.
- Satellites visible and satellites track: usually if the number of tracing satellites is greater than 3, synchronization can be conducted.
- BTS boot source: start data source of current base station.
- SyncCard temperature: the temperature of frequency synthesizer board in the base station.
- Average Free UL Channel and DL channel: amount of currently available channels.
- Time Passed Since BTS Boot: the time length for the continuous working of current base station.
- FR mask: the one with tick mark means the RF board is enabled and the one with check mark means the RF board is disabled.

All the information above is shown graphically for easier view.

6. System Alert

Similar to any system management system, EMS maintains and stores messages of failures or alerts from the base station, which can be viewed from failure console or alert console.

Enter the EMS system and select [Fault—Console—Fault Console] to enter the screen as below. Click the network element to view and click [View] button in the left top and the detailed information of alert will be displayed.




Result of Alarm Searching

Record Count:6,Current Page:1,Page Length:20

Net Eleme...	Entity	Entity Index	Type	Severity	Time Occ...	Alarm Con...	Status
	AUX	0		Major	2007-11-...	L2 to AU...	Unconfir...
	AUX	0		Major	2007-11-...	L2 to AU...	Unconfir...
	RF	8		Critical	2007-11-...	Antenna[8...	Unconfir...
	RF	3		Critical	2007-11-...	Antenna[3...	Unconfir...
	AUX	0		Major	2007-11-...	L2 to AU...	Unconfir...
	PLL	0		Critical	2007-11-...	Synthersi...	Unconfir...

Fig 6-1: Failure Console window

The operation of alert console is similar with failure console. For a simplified information display, click a tab to sort, for example, sorting by network element.



Result of Alarm Searching

Record Count:6,Current Page:1,Page Length:20

Net Eleme...	Entity	Entity Index	Type	Severity	Time Occ...	Alarm Con...	Status
	AUX	0		Major	2007-11-...	L2 to AU...	Unconfir...
		0		Major	2007-11-...	L2 to AU...	Unconfir...
		8		Critical	2007-11-...	Antenna[8...	Unconfir...
	RF	3		Critical	2007-11-...	Antenna[3...	Unconfir...
	AUX	0		Major	2007-11-...	L2 to AU...	Unconfir...
	PLL	0		Critical	2007-11-...	Synthersi...	Unconfir...

Click here to sort

Fig 6-2: Alert console window

Enter corresponding network element management and view by selecting the right end [Failure Management—Events/Alerts] in its information panel.




Fig 6-3: Event and Alert View Console

Please refer to the EMS user's guide for detailed information and measures for failures and alerts. If it's confirmed that there is hardware failure, please consult relevant R&D or maintenance personnel to update hardware versions, etc.

Solectek Warranty Policy

Scope

Warranty Policy applies to all new products purchased from Solectek or Solectek's authorized distributor, reseller or partner. The Warranty Policy does not cover the purchase of refurbished or used equipment, or the purchase of equipment from non-authorized sources.

Standard Warranty Period

Standard Warranty period is 12 months beginning from date of shipment from Solectek or authorized distributor.

Terms

Any defect, malfunction, or failure caused by fire, lightning, or other acts of God, accident, negligence, vandalism or acts of war is excluded from this warranty. This warranty does not cover removal, or reinstallation of this product.

This warranty policy covers only the initial, end-user of the product and is not transferable. Customer is responsible for shipment of any unit to Solectek for warranty service or repairs. Solectek will repair or replace, at Solectek's option, such Solectek products or parts thereof, which, on inspection by Solectek, are found to be covered by the terms stated in this warranty.

Except as noted below, Solectek is responsible for return shipping via ground services after warranty service or repairs. Expedited return shipping is available at customer expense. Solectek reserves the right to levy a service fee on any RMA unit deemed to be fully functional by Solectek RMA services.

Repaired products will be warranted for 90 days or for the remaining balance of the original warranty period, whichever is longer.

DOA

A DOA ("dead on arrival") unit is defined to be a hardware failure diagnosed within 30 days of initial user shipment, as determined by Solectek Support. Solectek attempts, but does not guarantee, shipment of DOA replacements within 1-2 days, subject to inventory availability.

Solectek at its discretion, will replace a DOA unit with a new or refurbished unit, via UPS Ground. Expedited shipping is available only at Customer expense. Customer's faulty unit shall be returned to Solectek as described in the Logistics section below.

Extended Warranty Plan (US only)

For US customers, Solectek may make available an optional Extended Warranty Plan which extends warranty coverage beyond the Standard Warranty period. An Extended Warranty Plan must be purchased prior to initial product delivery. All terms and conditions above apply to the Extended Warranty Plan.

Rapid Replacement Service (US only)

For US customers, Solectek may make available a rapid replacement service. Such services must be purchased prior to initial product delivery. During the applicable Rapid Replacement period, units are eligible for 1-2 day replacement turn-around following diagnosis by Solectek Support.

Solectek, at its discretion, will replace a unit with a new or refurbished unit and ship via Standard Overnight Service. Customer's faulty unit shall be returned to Solectek within 30 days, as described in the Logistics section below. In the event that the faulty unit is not returned in the stated time frame, or if upon inspection by Solectek, the faulty unit is determined to be outside the scope of the Warranty Terms above, Customer shall be invoiced for the cost of the replacement unit.

Out of Warranty Repairs

Out of warranty repairs are available for a fee to all customers. Please contact Solectek for rates applicable to your specific product.

Logistics

- 1) Customer calls Solectek Technical support line at (858) 450-1220 x 6, or sends email to support@solectek.com to initiate the RMA process. Solectek staff make all fault determinations and authorizations.
- 2) Requests should include the following information:
 - i) Customer name, address and telephone number.
 - ii) Name of the Retailer for product and the purchase date.
 - iii) Model #.
 - iv) Serial #.
 - v) Length of Time unit was field deployed.
 - vi) A brief description of the issue.
 - vii) Return shipping address, if different from item #1.
- 3) Solectek provides RMA number within 5 days of request from customer.
- 4) Customer returns product to Solectek in the original box, or equivalent. A valid RMA is required prior to any return. The RMA# should be prominent on the box when shipped to:

Solectek Corporation
6370 Nancy Ridge Drive, Suite 109
San Diego, CA 92121
RMA#

- 5) Upon receipt, Solectek will process and return ship the faulty unit to the customer within 4 weeks.