User guide

Important information

Please read the Important information leaflet before you use your mobile phone.

Experience more. Discover how.

Congratulations. You now own a classy phone that comes with first-class support. Wherever you are there's always help at hand if you need an answer fast about your phone. in touch with our dedicated specialist teams in your country and for tips and tricks about how to get the most out of your


User guide in the phone

An extended User guide is available in your phone.

- Select Menu > Settings > User help > User guide.

Phone overview

- 1 Far speaker
- 3 Selection keys
- 4 Volume key
- 5 Call key
- 6 Activity menu key 7 Connector for charger,
- handsfree and USB cable
- 8 End key 9 C key (Clear)
- 10 Navigation key
- 11 Phone antenna




12 On/off, reset key

- 13 Volume key
- 14 SIM card slot



Getting started

To insert the SIM card



 Open the cover and insert the SIM card with the gold coloured contacts facing down.

To remove the SIM card



• Open the cover and press the edge of the SIM card to elease and remove it.

Turning on the phone

To turn on the phone



if requested, and select **OK**. 3 Select a language.

4 Follow the instructions that appear.

If you want to correct a mistake when you enter your PIN, press ©.

1 On the back of the phone, press and hold down ①.
2 Enter your SIM card PIN (Personal Identification Number),

• When **Menu** appears on the screen, press the centre selection key to select **Menu**.

If Menu does not appear on the screen, press End key, and then press the centre selection key to select Menu.

In addition to this User guide, Feature guides and more information are available at

There are also help functions in your phone. See the following instructions on how to access them

• Select Menu > Settings > User help > Tips and

• Scroll to a function and select Info, if available. In some cases, Info appears under Options.

• Press a volume key. Phone, memory and battery information is shown.

Xperia[™] Pureness

Supported services and features

Some of the services and features described in this User guide are not supported by all networks and/or service providers in all areas. Without limitation, this applies to the GSM International Emergency Number 112. Please contact your network operator or service provider to determine availability of any specific service or feature and whether additional access or usage fees apply.

Charging the battery

The phone battery is partly charged when you buy it.

The phone battery cannot be removed.



- charge it frequently.
- repeatedly scans for available networks. This consumes power. If you cannot move to an area with better coverage, turn off your phone temporarily.

To charge the batter



- 1 Connect the charger to the phone.
- $\boldsymbol{2}\,$ Remove the charger by tilting the plug upwards.

Maximising battery performance

Charge your phone often. The battery lasts longer if you

- If you are in an area with no coverage, your phone

Turn off 3G and Bluetooth™ wireless technology when you do not need these functions.

 Do not cover the phone antenna when you are engaged in a call. about how to maximise the battery performance.

Navigation

To navigate the phone menus



 Press the navigation key upwards, downwards, left or right to move through the menus

Press the End kev.

Press the End key.

You can use the navigation key shortcuts to go directly to functions from standby.

- · Press the navigation key upwards, downwards, left or right, to go directly to a function.
- 1 Select Menu > Settings > General > Shortcuts.
- 2 Scroll to an option and select Edit.
- 3 Scroll to a menu option and select Shortc.

Activity menu

The activity menu gives you quick access to:

- New events missed calls and new messages • Running apps – applications that are running in the
- background. • My shortcuts – add your favourite functions to access

• Press 团.

Conversations

of your contacts.

Conversations tab

Conversations tab.

3 Select a conversation.

1 Select Menu > Messaging.

4 Write a message and select Send

Pictures and videos

Viewing pictures and videos

2 Scroll to a picture and select View.

left or right.

a conversation.

memory and on the SIM card. Pictures, videos and music are saved in the Media memory. If the Media memory is full, pictures videos and music are saved in the phone memory.

You can choose whether to view your messages in

• Select Menu > Messaging > Inbox > the

2 Select Conversations, or select Inbox > the

Conversations or the Inbox. A messaging conversation

shows all messaging communication between you and one

Select Menu > Messaging > Conversations and select

You can view pictures and videos that you have received or

downloaded to your phone. Saved pictures and videos can be found in the **File manager**.

1 Select Menu > Organiser > File manager > Pictures.

3 To scroll through the pictures, press the navigation key

Messages and contacts are saved in the phone memory, but you can choose to save them on the SIM card.

Entering text

You can use multitap text input or Quick text input Je to enter text. The Quick text input method uses a dictionary application in your phone.

- When you enter text, press and hold down (# an 3).
- When you enter text, press (# a/A 5).
- 1 When you enter text, press (#ax ?) repeatedly until [2] appears at the top of the scree
- 2 To enter a number, press (D =) (9). To enter a number from text input mode, you can

press and hold down (D -) - (9).

- When you enter text, press (+ *...) briefly.
 Scroll to a symbol and select Insert. To select from the most commonly used punctuation

marks, you can also press 1.

1 Select, for example, Menu > Messaging > Write new >

- 3 Press each key only once, even if the letter you want is not the first letter on the key. For example, to write the word "Jane", press (5), (2), (6), (3). Write the
- whole word before looking at the suggestions.

 4 To view word suggestions, press (+X or press the navigation key downwards.
- 5 Press 🗓 to accept a suggestion and add a space.
- 1 Select, for example, Menu > Messaging > Write new >
- 2 If is displayed, press and hold down to change and phone number
- to multitap text input.

 3 Press 2 9 repeatedly until the desired letter
- 4 Press O to add a space.

To add words to the phone d

- 1 When you enter text using Quick text input, select Options > Spell word. 2 Write the word using multitap input and select Save.

Calling

You need to turn on your phone and be within range of a

Connect a portable handsfree. Music stops when you

receive a call and resumes when the call has ended.

Making and answering calls

- 1 Enter a phone number (with international country code and area code, if applicable).
- 2 Press the Call key. You can call numbers from Contacts and your call list.
- Press the End key.
- 1 Press and hold down (+* until a "+" sign appears.
- 2 Enter the country code, area code (without the first zero)
- Press the Call key.
- Press the End key.
- To change the ear speaker volume during a call · Press the volume keys up or down.
- 1 Press and hold down C again to resume.

Do not hold the phone to your ear when using the loudspeaker. This could damage your hearing.

Your phone supports international emergency numbers, for example, 112 or 911. You can normally use these numbers to make emergency calls in any country, with or without the SIM card inserted, if you are within range of a network.

In some countries, other emergency numbers may also
 be promoted. Your network operator may therefore

have saved additional local emergency numbers on the SIM card.

and missed or rejected 📤 calls.

Enter 112 (the international emergency number) and

Scroll to New contact and select Options > Special numbers > Emerg. numbers.

You can view information about answered 😭 , dialled 😭

2 Scroll to a name or a number and press the Call key

Contacts You can save names, phone numbers and personal information in **Contacts**. Information can be saved in the phone memory or on the SIM card.

You can synchronise your contacts using the Sony Ericsson PC Suite.

Calling contacts

- corresponding letters are shown in a list. 2 Scroll to a contact or a phone number and press the Call

2 Select an option

Speed dialling lets you select nine contacts that you can dial

- 1 Select Menu > Contacts.
 2 Scroll to New contact and select Options > Speed

- 2 Scroll to New contact and select Add.
- 5 Enter the number and select **OK**.

quickly from standby. The contacts can be saved in

- positions 1-9.
- 4 Select a contact.

- 3 Enter the name and select OK.
- Select a number option. 7 Scroll between the tabs and add information to the fields.
- 1 Press (D_) (9) to enter a sequence of (at least two) digits. All entries which match the sequence of digits or
- 1 Select Menu > Settings > Calls > Smart search.
- Speed dial
- numbers to contacts

- 1 Select Menu > Contacts.
- 4 Scroll to New number: and select Add.

8 Select Save

- number and press the Call key.

- 3 Scroll to a position number and select Add.

• Enter the position number and press the Call key.

1 Select Menu > Messaging > Messages > Inbox.

Messaging

2 Scroll to the message and select View

When you are viewing the message, scroll to the phone

Sending messages You can send messages from your phone. The maximum size of a standard text message is 160 characters (including spaces) if no other items are added to the message. If you enter more than 160 characters, a second message is created. Your messages are sent as one concatenated

4 Select a recipient and select Send.

 Enter text. To add items to the message, press the navigation key downwards, scroll by pressing the navigation key left or right, and select an item. 3 Select Continue > Contacts look-up.

If you send a message to a group, you may be charged

for each member. Contact your service provider for

Select Menu > Messaging > Write new > Message.

- them quickly.

Media memory You can save content in the Media memory, in the phone

Select Play.

You can listen to music, audio books and podcasts. Use

Media Go™ to transfer content to and from your phone. For

more information, see Transferring content to and from a

1 Select Menu > Organiser > File manager > Videos.

computer on page 24.

2 Scroll to a video and select View.



- If headphones are not included with the phone, youmay purchase them separately. Music player
 - 1 Select Menu > Music player

3 Browse by category using the navigation key.4 Press the centre selection key to play music.

• Press the centre selection key.

2 Select Options > My music

• Press and hold down the navigation key right or left. • Press the navigation key right or left.

• Press the volume keys up or down. TrackID™ technology

TrackID™ technology is a music recognition service. You can search for title, artist and album name for a track you hear playing through a loudspeaker or on the radio in your phone. If you cannot use TrackID™ technology, see I cannot use Internet-based services on page 35.

• When you hear a track playing through a loudspeaker,

select $Menu > Entertainment > TrackID^{TM} > Start$.

• When the radio in your phone is playing, select **Options** > TrackID TM . For best results, use TrackID™ in a quiet area.

To listen to the radio, you need to use wired

function as an antenna. If wired headphones are not included with the phone, you need to purchase them separately

headphones that act as an antenna for the radio. The Bluetooth headset supplied with the phone cannot

Do not use your phone as a radio in places where this

To turn on the radio

is prohibited.

Radio

1 Connect a handsfree to the phone. 2 Select Menu > Radio Saving channels You can save up to 20 preset channels.

• Select Options > Channels > Auto save.

• Press the navigation key upwards or downwards.

You can also select a saved channel by pressing $\Box \Box - \Box$.

press the Call key. 1 Select Menu > Contacts.

1 Press the Call key and scroll to a tab

Transferring and handling

You can transfer and handle content such as pictures and

You are not allowed to exchange some copyrightprotected material. 🔐 identifies a protected item.

Handling content in the phone

You can use File manager in your phone to handle content saved in the phone memory in the Media memory. Tabs and icons in File manager show where the content is saved. If

1 Select Menu > Organiser > File manager.

2 Select Options > Memory status. 3 Select Media memory or Phone.

Select Menu > Organiser > File manager.
 Scroll to a folder and select Open.

3 Select Options > Mark > Mark several.
4 For each item you want to mark, scroll to the item and

select Mark.

To move items between the phone memory and the Media

Select Menu > Organiser > File manager.
 Find an item and select Options > Manage file >

3 Select Media memory or Phone.

4 Scroll to a folder and select Open.5 Select Paste.

Sending content to another phone

You can send content using different transfer methods, for

example, Messages or Bluetooth wireless technology.

 Scroll to an item and select Options > Send.
 Select a transfer method. $\P \ \ \text{Make sure the receiving device supports the transfer}$

method you select. Using a USB cable

You can connect your phone to a computer using a USB cable. If you are using a computer running Microsoft® Windows®, where you have not already installed the necessary USB software, you are asked to install PC

You may have to purchase a USB cable separately.Only use a USB cable supported by your phone. Check that Autoplay functionality is enabled on your PC.

To disconnect the USB cable safely

Do not disconnect the USB cable when transferring content as this may corrupt the content.

1 Computer: Right-click the Safely Remove Hardware icon in Microsoft® Windows® Explorer. 2 Select the drives you want to disconnect. Select Stop.

3 Wait until you are notified that it is safe to remove the drive. Disconnect the USB cable.

PC Companion

PC Companion lets you

Explore content in your phone.

 Use your phone as a modem Install PC software used to synchronise, transfer and back up phone content.

For more information, including Feature guides, go to

To download Mac® compatible software, go to

To install PC Companion

¶ If the necessary USB software has not been installed on your PC, you need to install PC Companion. Autoplay functionality needs to be enabled on your PC.

1 Connect your phone to a computer running Microsoft®

Windows® using a USB cable supported by your phone.

2 Computer: Follow the on-screen instructions.

Required operating systems

You need one of these operating systems to use Sony Ericsson PC software:

Microsoft® Windows Vista™

Microsoft® Windows® XP, Service Pack 2 or higher

Transferring content to and from a computer

You can use Media Go™ to transfer media content betweer your phone and a computer. Media Go™ is available for

download through PC Companion or from

1 Connect your phone to a computer using a USB cable.
2 Computer: Wait until the phone memory and Media

3 Drag and drop selected files between the phone and the

memory appear as external disks in Microsoft®

1 Connect the phone to a computer with a USB cable

4 Wait until the phone appears in Media Go™

devices, free of charge. You can, for example:

Connect to handsfree devices.Connect to several devices at the same time.

2 Computer: Select Start/Programs/Sony/Media Go™.

5 Move files between your phone and the computer in

Using Bluetooth™ wireless technology

Use Bluetooth™ technology to wirelessly connect to other

3 Select Transfer to or from Device using Media Go™ and

 Connect to computers and access the Internet.
 Exchange MP3 files, virtual business cards, photos, and To download Mac® compatible software, go to · Play multiplayer games.

Dragging and dropping content

Microsoft® Windows® Explorer.

Windows® Explorer.

supported by your phone.

computer.

click OK

Media Go™.

objects in between, is recommended for Bluetooth You can drag and drop content between your phone memory, the Media memory and a computer using Before using Bluetooth wireless technology

You must turn on the Bluetooth function to communicate with other devices. You may also have to pair your phone with other Bluetooth devices.

¶ A range of less than 10 metres (33 feet), with no solid

Select Menu > Settings > Connectivity > Bluetooth >

Make sure that the device you want to pair your phone with has the Bluetooth function activated and Bluetooth visibility turned on.

1 Select Menu > Settings > Connectivity > Bluetooth >

Add new device.

Enter a passcode, if required.

1 Select Menu > Settings > Connectivity > Bluetooth 2 Select a device from the list.

3 Select Options > Allow conn.

4 Select Always ask or Always allow.

This is only possible with devices that require access to a secure service.

Backing up and restoring

content in the phone on page 22.

You can back up and restore contacts, the calendar, tasks, notes and bookmarks using the Sony Ericsson PC Suite. Before backing up and restoring, you need to install the Sony Ericsson PC Suite, which is available through PC Companion or from www.sonyericsson.com/support. You can back up and restore contacts in your phone using the Media memory. You can move content between the Media memory and the phone memory. See *Handling*

Back up your phone content regularly to make sure you do not lose it.

1 Computer: Start the Sony Ericsson PC Suite from Start/ Programs/Sony Ericsson/Sony Ericsson PC Suite

2 Follow the instructions in the Sony Ericsson PC Suite on how to connect.

3 Go to the backup and restore section in the Sony Ericsson PC Suite and make a backup of your phone content.

Updating your phone

You can update your phone with the most recent software for optimal performance and to get the latest enhancements. This is done with the Update Service application. You have two options to update your phone with the Update Service application:

Using a computer

Wireless update

Remember to back up your phone content before updating with a computer. See Backing up and restoring on page 27.

Updating your phone using a computer

You can update your phone with the latest software by connecting it to a computer on which the Update Service application is installed. You need a USB cable and an nternet-connected PC. To learn how, go to

Internet

If you cannot use the Internet, see I cannot use Internetbased services on page 35.

• Select Menu > Entertainment > Internet.

To go back to the previous page, select .

When you are browsing the web, select and then select .
 Select Exit browser.

To access the web browser toolbar When you are viewing a web page, select . The following

options appear:

Icon Function

Pan and zoom the web page

Search the web or enter a web address

Manage your favourite web pages

Manage the files you have downloaded from the

Web browser shortcuts You can use the keypad to go directly to a web browser

	Key	Shortcut
	1	Bookmarks
	2 - 9	Enter text to enter an address, search the Internet or search in Bookmarks
	0-	Zoom
		O

More features

Fliaht mode

In Flight mode the network and radio transceivers are turned off to prevent disturbance to sensitive equipment. When the flight mode menu is activated you are asked to select a mode the next time you turn on your phone:

Normal mode - full functionali

Flight mode – limited functionality

Select Menu > Settings > General > Flight mode > Continue > Show at startup.

1 When the flight mode menu is activated, turn off your

2 Turn on your phone and select Flight mode. appears.

You can set a sound or the radio as an alarm signal. The alarm sounds even if the phone is turned off. When the alarm

sounds, you can silence it or turn it off.

1 Select Menu > Alarms.

Scroll to an alarm and select Edit.
 Scroll to Time: and select Edit.

4 Enter a time and select $\mathbf{OK} > \mathbf{Save}$

• When the alarm sounds, press any key. • To repeat the alarm, select **Snooze**.

To turn off the alarr

Calendar You can synchronise your calendar with a computer calendar, with a calendar on the web or with a

• When the alarm sounds, press any key, then select Turn

Microsoft® Windows Server® (Outlook®) application.

Appointments

You can add new appointments or reuse existing appointments.

Select Menu > Organiser > Calendar

4 Enter the information and confirm each entry

2 Select a date

Scroll to New entry and select Add.

5 Select Save

1 Select Menu > Organiser > Calendar. 2 Select a date

3 Select Options > Advanced > Reminders.4 Select an option. A reminders option set in Calendar affects a reminders

option set in Tasks. Ringtones

Ringtone.

1 Select Menu > Settings > Sounds & alerts >

2 Find and select a ringtone.

 Press and hold down (# = 1/2).
 appears. The alarm signal is not affected.

PIN codes

This lock only protects your subscription. Your phone will work with a new SIM card. If the lock is on, you have to enter

a PIN (Personal Identity Number). If you enter your PIN incorrectly three times in a row, the SIM card is blocked and you need to enter your PUK (Personal Unblocking Key). Your PIN and PUK are supplied by your network operator.

1 When PIN blocked appears, enter your PUK and select

2 Enter a new four-to-eight-digit PIN and select OK.3 Re-enter the new PIN and select OK.

1 Select Menu > Settings > General > PIN codes > SIM

protection > Change PIN. 2 Enter your PIN and select OK.
3 Enter a new four-to-eight-digit PIN and select OK.

4 Re-enter the new PIN and select OK. ¶ If Codes do not match appears, you entered the new PIN incorrectly. If Incorrect PIN appears, you entered

the old PIN incorrectly. **Troubleshooting**

Some problems can be fixed using Update Service. Using Update Service on a regular basis will optimise the phone's performance. See *Updating your phone using a* computer on page 28.

Some problems will require you to call your network

For more support go to www.sonyericsson.com/support.

Common questions

Where can I find the regulatory information such as my IMEI number if I cannot turn on my phone?



I have problems with memory capacity or the phone is working slowly

Restart your phone every day to free memory or do a

If you select **Reset settings**, the changes that you have made to settings will be deleted.

If you select **Reset all**, your settings and content, such as contacts, messages, pictures, sounds and downloaded games, will be deleted. You may also lose content that was in the phone at purchase.

Select Menu > Settings > General > Master reset.
 Select an option.

3 Follow the instructions that appear What do I do if the phone freezes or hangs? Press and hold down the volume down key and the power



No battery icon appears when I start charging the

It may take a few minutes before the battery icon appears

Some menu options appear in grey

I cannot use Internet-based services

You can download settings using the Settings downl. or

1 Select Menu > Settings > User help > Settings

2 Follow the instructions that appear

To send messages, you need to set a service centre number. The number is supplied by your service provider and is usually saved on the SIM card. If the number of your

To send most picture messages, you must set an MMS (Multimedia Messaging Service) profile and the address of your message server. If no MMS profile or message server

your network operator, using the Settings download, or go

Select Menu > Settings > Connectivity > Message settings > Text message and scroll to Service centre.

3 Scroll to New serv. centre and select Add.

Select Menu > Settings > Connectivity > Message settings > Multimedia msg.

1 Select Menu > Settings > Connectivity > Message

4 Enter the address and select OK > Save. I cannot synchronise or transfer content between my phone and the computer, when using a USB

Error messages

There is no SIM card in your phone or you may have inserted

See *To insert the SIM card* on page 5.
The SIM card connectors need cleaning. If the card is damaged, contact your network operator.

Your phone is set to work only with certain SIM cards

PIN blocked/PIN2 blocked You have entered your PIN or PIN2 code incorrectly three

Your phone is in flight mode. See Flight mode on page 29.

The SIM card is not working properly. Insert your SIM

card in another phone. If this works, it is probably your phone that is causing the problem. Please contact the

nearest Sony Ericsson service location.

You are within range of a network, but you are not allowed to use it. However, in an emergency, some network

This User guide is published by Sony Ericsson Mobile Communications AB or its local affiliated company, without any warranty. Improvements and changes to this User guide necessitated by typographical errors, inaccuracies of current information, or improvements to programs and or equipment, may be made by Sony Ericsson Mobile Communications AB at any time and without notice. Such changes will, however, be incorporated into new editions of this User guide.

©Sony Ericsson Mobile Communications AB, 2009

Media Go is a trademark or registered trademark of Sony Media Software

Adobe Photoshop Album Starter Edition is a trademark or registered trademark of Adobe Systems Incorporated in the United States and/or

other countries.

Microsoft, Windows, Outlook, Windows Vista, Windows Server and ActiveSync are registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

This product is protected by certain intellectual property rights of Microsoft. Use or distribution of such technology outside of this product is prohibited without a license from Microsoft.

Other product and company names mentioned herein may be the trademarks of their respective owners.

Any rights not expressly granted herein are reserved.

All illustrations are for illustration only and may not accurately depict the

5 Select Save.

2 Select an existing profile or create a new one

settings > Multimedia msg.
2 Scroll to a profile and select Options > Edit. 3 Scroll to Message server and select Edit.

The software or the USB drivers have not been properly installed. Go to www.sonyericsson.com/support to read Feature guides which contain detailed installation

Insert correct SIM card

Incorrect PIN/Incorrect PIN2

times in a row

No network

received signal is too weak. Contact your network operator and make sure that the network has coverage where you are.

Legal information Sonv Ericsson X5

Bluetooth is a trademark or a registered trademark of Bluetooth SIG Inc. and any use of such mark by Sony Ericsson is under license. The Liquid Identity logo, Xperia, pureness and TrackID are trademarks or registered trademarks of Sony Ericsson Mobile Communications AB. Sony and "make.believe" are trademarks or registered trademarks of Sony Corporation.

croSD is a trademark or a registered trademark of SanDisk sson is a trademark or registered trademark of Telefonaktiebolaget

A service is not activated. Contact your network operator

This feature might not be available in all markets. Contact your network operator or service provider for

I cannot send messages from my phone

service centre is not saved on your SIM card, you must enter the number yourself.

Sony Ericsson

Sony Ericsson Mobile Communications AB SE-221 88 Lund, Sweden

The number is shown if it is saved on the SIM card.

4 Enter the number, including the international "+" sign and

2 If there is no number shown, select Edit.

Check if you are using the correct operator SIM card.

You have entered your PIN or PIN2 incorrectly Enter the correct PIN or PIN2 and select **OK**.

To unblock, see SIM protection on page 32.

Your phone is not receiving any network signal, or the

operators allow you to call the international emergency number 112. See *Emergency calls* on page 15.

©Sony Ericsson Mobile Communications AB, 2009
Publication number: 1231-0121.1
Your mobile phone has the capability to download, store and forward additional content, e.g. ringtones. The use of such content may be restricted or prohibited by rights of third parties, including but not limited to restriction under applicable copyright laws. You, and not Sony Ericsson, are entirely responsible for additional content that you download to or forward from your mobile phone. Prior to your use of any additional content, please verify that your intended use is properly licensed or is otherwise authorized. Sony Ericsson does not guarantee the accuracy, integrity or quality of any additional content or any other third party content. Under no circumstances will Sony Ericsson be liable in any way for your improper use of additional content or other third party content.

Mac is a trademark of Apple Computer, Inc., registered in the U.S. and

Your subscription does not include data capability. Settings are missing or incorrect.

exists, you can receive all the settings automatically from

Preflighted by **Elanders** Passed Falls

FCC Statement

Declaration of Conformity

ww.sonyericsson.com



Sony Ericsson Mobile Communications AB



Important Information

United States & Canada
THIS PHONE MODEL HAS BEEN CERTIFIED IN COMPLIANCE
WITH THE GOVERNMENT'S REQUIREMENTS FOR EXPOSURE

TO RADIO WAVES. The Series mobile phones have been designed to comply with applicable safety requirements for exposure to radio waves. You wireless phone is a radio transmitter and receiver. It is designed to not exceed the limits* of exposure to radio frequency (RF) energy set by governmental authorities. These limits establish permitted set by governmental authorities. These limits establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by international scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a safety margin designed to assure the safety of all individuals, regardless of age and

The radio wave exposure guidelines employ a unit of measurement known as the Specific Absorption Rate (SAR). Tests for SAR are conducted using standardized methods with the phone transmitting at its highest certified power level in all used frequency bands. While there may be differences between the SAR

frequency bands. While there may be differences between the SAR levels of various phone models, they are all designed to meet the relevant guidelines for exposure to radio waves. For more information on SAR, please refer to the safe and efficient use chapter in the User Guide.

The highest SAR value as reported to the authorities for this phone model when tested for use by the ear is 1.37 W/kg², and when worn on the body is 0.76 W/kg² for speech and 0.97 W/kg² for data calls. Body worn measurements are made while the phone is in use and worn on the body with a Sony Ericsson accessory supplied with or designated for use with this phone. It is therefore recommended that only Ericsson and Sony Ericsson original accessories be used in conjunction with Sony Ericsson phones.

**Before a phone model is available for sale to the public in the US, it must be tested and certified by the Federal Communications Commission (FCC) that it does not exceed the limit established by

Sony Ericsson X5

UMTS HSPA band 1 GSM GPRS/EDGE 850/900/1800/1900

the government-adopted requirement for safe exposure*. The tests are performed in positions and locations (i.e., by the ear and worn on the body) as required by the FCC for each model. The FCC has granted an Equipment Authorization for this phone model with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. While there may be differences between the SAR levels of various phones, all mobile phones granted an FCC equipment authorization meet the government requirement for safe exposure. SAR information on this phone model is on file at the FCC and can be found under the Display Grant section of http://www.fcc.gov/oet/fccid after searching on FCC ID PY7A3880049, Additional information on SAR can be found on the Cellular Telecommunications & Internet Association (CTIA) website at http://www.phonefacts.net.
* In the United States and Canada, the SAR limit for mobile

phones used by the public is 1.6 watts/kilogram (W/kg) averaged over one gram of tissue. The standard incorporates a margin of safety to give additional protection for the public and to account *This paragraph is only applicable to authorities and customers

in the United States.

3

5

Renseignements importants

États-Unis et Canada CE MODÈLE DE TÉLÉPHONE A ÉTÉ CERTIFIÉ CONFORME AUX EXIGENCES GOUVERNEMENTALES RELATIVES À L'EXPOSITION AUX ONDES RADIOÉLECTRIQUES.

Les téléphones mobiles ont été conçus pour répondre aux normes de sécurité en vigueur en matière d'exposition aux ondes radioélectriques. Votre téléphone sans fil est un émetteur et un récepteur radio. Il est conçu de manière à ne pas dépasser les limites" d'exposition aux signaux radiofréquences (RF) établies par les autorités gouvernementales. Ces limites fixent les niveaux maximaux d'énergie radiofréquence auxquels peut être soumis le grand public. Ces lignes directrices sont basées sur des normes qui ont été élaborées par des organisations scientifiques internationales par le biais d'évaluations périodiques et approfondies des études scientifiques. Ces normes prévoient une marge de sécurité visant à assurer la protection de toutes les personnes, quels que soient leur âge et leur état de santé.

marge de sécurité visant à assurer la protection de toutes les personnes, quels que soient leur âge et leur état de santé. Les lignes directrices relatives à l'exposition aux ondes radioélectriques utilisent une unité de mesure appelée "Débit d'absorption spécifique" (SAR). Les tests de SAR sont effectués selon des méthodes standardisées dans lesquelles le téléphone émet dans toutes les bandes de fréquences utilisées, à la plus forte puissance pour laquelle il a été homologué. Bien que le débit d'absorption spécifique puisse être différent d'un modèle de téléphone à un autre, tous les appareils sont conçus pour respecter les lignes directrices relatives aux ondes radioélectriques. Pour en savoir plus sur le débit d'absorption radioélectriques. Pour en savoir plus sur le débit d'absorption spécifique, reportez-vous au chapitre sur l'utilisation efficace et

sans danger de ce présent guide. Le débit d'absorption spécifique le plus élevé relevé par les autorités pour ce modèle de téléphone est de 1,37 W/kg* lorsqu'il autorités pour condende de l'éprinte set de 1,37 w/kg "lour les est testé en utilisation près de l'oreille, et de 0,76 W/kg* (pour les appels vocaux) et de 0,97 W/kg* (pour les appels de données) lorsqu'il est porté sur le corps. Lors des mesures de port sur le e était n

Ericsson fourni avec ce téléphone ou conçu pour être utilisé avec l'appareil. Il est par conséquent recommandé de n'utiliser que les accessoires authentiques Ericsson et Sony Ericsson avec les téléphones Sony Ericsson.

**Avant qu'un modèle de téléphone ne soit offert au public aux

États-Unis, la FCC (Federal Communications Commission) doit le tester et certifier qu'il respecte les limites fixées dans les exigences gouvernementales d'exposition sans danger*. Pour chaque modèle, les tests sont effectués en position et aux endroits d'usage (c'est-à- dire près de l'oreille et porté sur le corps), tel que l'exige la FCC. La FCC a accordé une autorisation d'équipement (Equipment Authorization) pour ce modèle de téléphone, après que tous les débits d'absorption spécifique indiqués aient été évalués et considérés conformes aux lignes directrices de la FCC en matière d'exposition aux radiofréquences. Même s'il peut y avoir des différences entre les niveaux de SAR des différents téléphones, tous les téléphones mobiles auxquels la FCC a accordé une autorisation d'équipement répondent aux normes gouvernementales en matière d'exposition sans danger. La FCC conserve dans ses dossiers l'information relative aux débits d'absorption spécifique relevés pour ce modèle de téléphone. Vous pouvez la consulter au http://www.fcc.gov/oet/fccid, sous la rubrique "Display Grant ", après avoir effectué une recherche sur FCC ID PY7A3880049 . Vous trouverez des renseignements supplémentaires concernant le débit d'absorption spécifique (SAB) sur le site Weh de la Cellular Telecommunications & Internet (SAR) sur le site Web de la Cellular Telecommunications & Internet

Association (CTIA) au http://www.phonefacts.net. *Aux États-Unis et au Canada, la limite de débit d'absorption spécifique (SAR) des téléphones mobiles utilisés par le public est de 1,6 watt/kg (W/kg) en moyenne sur un gramme de tissus. Cette norme comporte une marge importante de sécurité afin d'assurer une protection supplémentaire et de tenir compte de toute variation dans les mesures.

**Ce paragraphe ne concerne que les autorités et les clients des

États-Unis

Información importante

Estados Unidos y Canadá
ESTE MODELO DE TELÉFONO HA SIDO CERTIFICADO Y
CUMPLE CON LOS REQUISITOS GUBERNAMENTALES DE
EXPOSICIÓN A LAS ONDAS DE RADIO.

El teléfono móvil ha sido diseñado para cumplir con los requisitos de seguridad aplicables de exposición a las ondas de radio. El teléfono inalámbrico es un transmisor y receptor de radio. Está diseñado para no superar los límites' de exposición a la energía de radiofrecuencia (RF) establecidos por las autoridades gubernamentales. Estos límites establecen los niveles permitidos de energía de RF para la población en general. Las especificaciones se basan en los estándares desarrollados por organizaciones científicas internacionales mediante una evaluación periódica y minuciosa de estudios científicos. Estos estándares incluyen un margen de seguridad destinado a garantizar la seguridad de todas las personas,

independientemente de su edad y condición de salud.

Las especificaciones de exposición a las ondas de radio emplean una unidad de medición conocida como Tasa específica de absorción (SAR). Las pruebas de SAR se realizan usando métodos estandarizados mientras el teléfono transmite al nivel de potencia más alto certificado en todas las bandas de frecuencia utilizadas. Si bien puede haber diferencias entre los niveles de SAR de diversos modelos de teléfono, todos los teléfonos han sido diseñados para cumplir con las especificaciones pertinentes de exposición a las ondas de radio. Para obtener más información acerca de SAR, consulte el capítulo sobre uso seguro y eficaz en la Guía del usuario

El mayor valor SAR según lo informado a las autoridades para este teléfono cuando se evaluó para su uso cerca del oído fue de 1,37 W/kg*, y cuando se utilizó cerca del cuerpo fue de 0,76 W/kg* para llamadas de voz y 0,97 W/kg* para llamadas de datos. Las mediciones para el uso cerca del cuerpo se realizan mientras el teléfono está en uso y ubicado cerca del cuerpo con un accesorio Sony Ericsson proporcionado con el teléfono o diseñado para su

uso con este teléfono. Por lo tanto, se recomienda utilizar sólo accesorios originales Ericsson y Sony Ericsson en conjunto con los teléfonos Sony Ericsson.

**Antes de que un modelo de teléfono esté disponible para la

venta al público en los EE.UU., se debe probar y certificar ante la Comisión Federal de Comunicaciones (FCC) que no supera el límite establecido por los requisitos gubernamentales de exposición segura*. Las pruebas se realizan en las posiciones y lugares (es decir, en el oído y cerca del cuerpo) exigidos por la FCC para cada modelo. La FCC ha otorgado una Autorización de equipo para este modelo de teléfono con todos los niveles SAR informados y que han sido evaluados en cumplimiento con las especificaciones de exposición de RF de la FCC. Si bien puede haber diferencias en los niveles SAR entre distintos modelos de teléfonos móviles, todos los teléfonos móviles que han recibido una autorización de equipo de la FCC cumplen con los requisitos gubernamentales de exposición segura. La información de SAR acerca de este modelo de teléfono está archivada en la FCC y se puede encontrar en la sección Display Grant de http://www.fcc.gov/oet/fccid luego de buscar en FCC ID PY7A3880049. Si desea información adicional acerca de SAR, puede encontrarla en el sitio Web de la Asociación de Telecomunicaciones Celulares e Internet (CTIA, Cellular Telecommunications & Internet Association) en la dirección http://www.phonefacts.net.

* En los Estados Unidos y Canadá, el limite SAR para teléfonos móviles utilizados por el público es de 1,6 watts/kilogramo (W/kg) promediado sobre un gramo de tejido. El estándar incorpora un margen de seguridad para entregar protección adicional al público y para representar las variaciones en las mediciones.

*Este párrafo sólo es aplicable a las autoridades y clientes en los Estados Unidos.

Important Information

Latin & South America

xposure and Specific Absorption Rate (SAR) information

The Series mobile phones have been designed to comply with applicable safety requirements for exposure to radio waves. These requirements are based on scientific guidelines that include safety margins designed to assure the safety of all persons, regardless of age and health.

The radio wave exposure guidelines employ a unit of

measurement known as the Specific Absorption Rate, or SAR. Tests for SAR are conducted using standardised methods with the phone transmitting at its highest certified power level in all used frequency bands.

requency bands. While there may be differences between the SAR levels of various phone models, they are all designed to meet the relevant guidelines for exposure to radio waves. For more information on SAR, please refer to the safety chapter in the User Guide.

SAR data information for residents in countries that have adopted the SAR limit recommended by the International Commission on Non-Ionizing Radiation Protection (ICNIRP), which is 2 W/kg averaged over ten (10) gram of tissue (for example European Union, Japan, Brazil and New Zealand): The highest SAR value for this model phone when tested by

Sony Ericsson for use at the ear is 1.60 W/kg (10g).

Información importante

Latinoamérica y América del Sur Información acerca de la exposición a ondas de r Tasa específica de absorción (SAR)

El teléfono móvil ha sido diseñado para cumplir con los requisitos de seguridad aplicables de exposición a las ondas de radio. Dichos requisitos se basan en directrices científicas que establecen márgenes de seguridad con el fin de evitar perjuicos a todas las personas, independientemente de su edad o estado de

Las directrices de exposición a ondas de radio utilizan una unidad de medida denominada coeficiente de absorción específica o SAR. Las pruebas de SAR se líevan a cabo utilizando métodos normalizados, con el teléfono transmitiendo en el nivel más elevado de potencia autoridado en todas las bandas de frecuen utilizadas.

Aunque puede existir diferencias entre los niveles de SAR de diferentes modelos de teléfono, todos han sido diseñados para cumplir las directrices pertinentes sobre exposición a ondas de

Para obtener más información sobre el SAR, consulte el capítulo sobre seguridad en la guía del usuario.

Información sobre datos de SAR para residentes de países en los que se haya adoptado el limite de SAR recomendado por la International Commission on Non-Ionizing Radiation Protection (ICNIRP, Comisión internacional de protección contra la radiación no ionizantes (ICNIRP, International Commission on Non-Ionizing Radiation Protection), es 2 W/kg promedio por cada diez (10) gramos de tejido (por ejemplo, la Unión Europea, Japón, Brasil y Nueva Zelanda): El valor de SAR más elevado para este modelo de teléfono

cuando Sony Ericsson realizó la prueba para su uso en la oreja era de 1,60 W/kg (10g).

9

8

Informação importante

América do Sul e Latina Informações sobre SAR (Taxa de Absorção Específica) e exposição à radiofrequência

O celular foi projetado para cumprir os requisitos de segurança aplicáveis para exposição à radiofreqüência. Esses requisitos têm como base diretrizes científicas que incluem as margens de

como base diretrizes científicas que incluem as margens de segurança para garantir a segurança de todas as pessoas, independentemente da idade e da saúde.

As diretrizes de exposição à radiofreqüência usam uma unidade de medida conhecida como SAR ou Taxa de Absorção Específica. Os testes de SAR são conduzidos por métodos padronizados com a transmissão telefônica em seu nível certificado de energia mais alto em todas as faixas de freqüência usadas.

Embora possa haver diferenças entre os níveis de SAR de vários modelos de telefone, todos foram projetados para atender as diretrizes relevantes de exposição à radiofreqüência.

Para obter mais informações sobre SAR, consulte o capítulo de segurança do Guia do Usuário.

Para obter mais informações sobre SAR, consulte o capítulo de segurança do Guia do Usuário. Informações sobre os dados de SAR para moradores de países que adotaram o limite SAR recomendado pelo ICNIRP (International Commission on Non-Ionizing Radiation Protection) que é o limite médio de 2 W/kg em dez (10) gramas de tecido (por exemplo, União Européia, Japão, Brasil e Nova Zelândia). Quando testado pela Sony Ericsson, o valor de SAR mais alto para este modelo de telefone para uso junto ao ouvido foi de 1,60 W/kg (10g).

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2)

This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Any change or modification not expressly approved by Sony Ericsson may void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- · Consult the dealer or an experienced radio/TV technician for

10 11

Industry Canada Statement

This device complies with RSS-210 of Industry Canada.

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Declaration of Conformity for X5

We, **Sony Ericsson Mobile Communications AB** of Nya Vattentornet SE-221 88 Lund, Sweden

SE-221 88 Lund, Sweden declare under our sole responsibility that our product Sony Ericsson type AAD-3880049-BV and in combination with our accessories, to which this declaration relates is in conformity with the appropriate standards EN 301 511:V9.0.2, EN 301 908-1:V3.2.1, EN 301 908-2:V3.2.1, EN 300 328:V1.7.1, EN 301 489-7:V1.3.1, EN 301 489-17:V2.2.1, EN 301 489-24:V1.4.1,EN 301 489-3:V1.4.1 following the provisions of, Radio Equipment and Telecommunication Terminal Equipment directive 1999/5/EC. directive 1999/5/EC

Lund, September 2009

Zitto Sahaful

C € 0682

Rikko Sakaguchi, Corporate Vice President and Head of Creation & Development We fulfil the requirements of the R&TTE Directive (1999/5/EC). Ce produit est conforme aux directives de R&TTE (1999/5/EC).

Cumplimos con los requisitos de la Directiva R&TTE – Normas sobre equipos de terminales de radio y telecomunicaciones (1999/ 5/EC).

Atendemos aos requisitos da Diretriz R&TTE (1999/5/EC).

Sony Ericsson

Important information

Sony Ericsson Consumer Web site

At www.sonyericsson.com/support there is a support section where help and tips are only a few clicks away. Here you will find the latest computer software updates and tips on how to use your product more efficiently.

Service and support

You have access to a portfolio of exclusive service advantages such as:

- · Global and local Web sites providing support.
- · A global network of Contact Centers.
- An extensive network of Sony Fricsson service partners.
- A warranty period. Learn more about the warranty conditions in the Limited warranty section.

At www.sonyericsson.com/support, you can find the latest support tools and information. For operator-specific services and features, please contact your network operator.

You can also contact our Contact Centers. If your country/ region is not represented in the list below, please contact your local dealer. (Calls are charged according to national rates, including local taxes, unless the phone number is a toll-free number.)

If your product needs service, please contact the dealer from whom it was purchased, or one of our service partners. For warranty claims, save proof of purchase.

Guidelines for Safe and Efficient Use

Please follow these guidelines. Failure to do so might entail a potential health risk or product malfunction. If in doubt as to its proper function, have the product checked by a certified service partner before charging or using it.



Recommendations for care and safe use of our products

. Handle with care and keep in a clean and dust-free place.

-

- Warning! May explode if disposed of in fire.
- · Do not expose to liquid or moisture or excess humidity.
- For optimum performance, the product should not be operated in temperatures below -10°C(+14°F) or above +45°C(+113°F). Do not expose the battery to temperatures above +60°C(+140°F).



- Do not expose to flames or lit tobacco products.
- . Do not drop, throw or try to bend the product.
- . Do not paint or attempt to disassemble or modify the product. Only Sony Fricsson authorised personnel should perform service
- . Consult with authorised medical staff and the instructions of the medical device manufacturer before using the product near pacemakers or other medical devices or equipment.
- . Discontinue use of electronic devices, or disable the radio transmitting functionality of the device, where required or requested to do so.
- Do not use where a potentially explosive atmosphere exists.
- . Do not place the product, or install wireless equipment, in the area above an air bag in a car.
- Caution: Cracked or broken displays may create sharp edges or splinters that could be harmful upon contact.
- Do not use the Bluetooth Headset in positions where it is uncomfortable or will be subject to pressure.

Children

Warning! Keep out of the reach of children. Do not allow children to play with mobile phones or accessories. They could hurt themselves or others. Products may contain small parts that could become detached and create a choking hazard.

Power supply (Charger)

Connect the charger to power sources as marked on the product. Do not use outdoors or in damp areas. Do not alter or subject the cord to damage or stress. Unplug the unit before







cleaning it. Never alter the plug. If it does not fit into the outlet, have a proper outlet installed by an electrician. When a power supply is connected there is a small drain of power. To avoid this small energy waste, disconnect the power supply when the product is fully charged. Use of charging devices that are not Sony Ericsson branded may pose increased safety risks.

Battery

New or idle batteries can have short-term reduced capacity. Fully charge the battery before initial use. Use for the intended purpose only. Charge the battery in temperatures between +5°C(+41°F) and +45°C(+113°F). Do not put the battery into your mouth. Do not let the battery contacts touch another metal object. Turn off the product before removing the battery. Performance depends on temperatures, signal strength, usage patterns, features selected and voice or data transmissions. Only Sony Ericsson service partners should remove or replace built-in batteries. Use of batteries that are not Sony Ericsson branded may pose increased safety risks. Replace the battery only with another Sony Ericsson battery that has been qualified with the product per the standard IEEE-1725. Use of an unqualified battery may present a risk of fire, explosion, leakage or other hazard

Personal medical devices

Mobile phones may affect implanted medical equipment. Reduce risk of interference by keeping a minimum distance of 15 cm(6 inches) between the phone and the device. Use the phone at your right ear. Do not carry the phone in your breast pocket. Turn off the phone if you suspect interference. For all medical devices, consult a physician and the manufacturer.

Driving

Some vehicle manufacturers forbid the use of phones in their vehicles unless a handsfree kit with an external antenna supports the installation. Check with the vehicle manufacturer's representative to be sure that the mobile phone or Bluetooth

,

handsfree will not affect the electronic systems in the vehicle. Full attention should be given to driving at all times and local laws and regulations restricting the use of wireless devices while driving must be observed.

GPS/Location based functions

Some products provide GPS/Location based functions. Location determining functionality is provided "As is" and "With all faults". Sony Ericsson does not make any representation or warranty as to the accuracy of such location information.

Use of location-based information by the device may not be uninterrupted or error free and may additionally be dependent on network service availability. Please note that functionality may be reduced or prevented in certain environments such as building interiors or areas adiacent to buildings.

Caution: Do not use GPS functionality in a manner which causes distraction from driving.

Emergency calls

Calls cannot be guaranteed under all conditions. Never rely solely upon mobile phones for essential communication. Calls may not be possible in all areas, on all networks, or when certain network services and/or phone features are used.

Antenna

Use of antenna devices not marketed by Sony Ericsson could damage the phone, reduce performance, and produce SAR levels above the established limits. Do not cover the antenna with your hand as this affects call quality, power levels and can shorten talk and standby times.

Radio Frequency (RF) exposure and Specific Absorption Rate (SAR)

When the phone or Bluetooth handsfree is turned on, it emits low levels of radio frequency energy. International safety guidelines have been developed through periodic and thorough evaluation of scientific studies. These guidelines establish

permitted levels of radio wave exposure. The guidelines include a safety margin designed to assure the safety of all persons and to account for any variations in measurements.

Specific Absorption Rate (SAR) is used to measure radio frequency energy absorbed by the body when using a mobile phone. The SAR value is determined at the highest certified power level in laboratory conditions, but because the phone is designed to use the minimum power necessary to access the chosen network, the actual SAR level can be well below this value. There is no proof of difference in safety based on difference in SAR value.

Products with radio transmitters sold in the US must be certified by the Federal Communications Commission (FCC). When required, tests are performed when the phone is placed at the ear and when worn on the body. For body-worn operation, the phone has been tested when positioned a minimum of 15 mm from the body without any metal parts in the vicinity of the phone or when properly used with an appropriate Sony Ericsson accessory and worn on the body.

For more information about SAR and radio frequency exposure, go to: www.sonyericsson.com/health.

Flight mode

Bluetooth and WLAN functionality, if available in the device, can be enabled in Flight mode but may be prohibited onboard aircraft or in other areas where radio transmissions are prohibited. In such environments, please seek proper authorisation before enabling Bluetooth or WLAN functionality even in Flight mode.

Malware

Malware (short for malicious software) is software that can harm the mobile phone or other computers. Malware or harmful applications can include viruses, worms, spyware, and other unwanted programs. While the device does employ security measures to resist such efforts, Sony Ericsson does not warrant or represent that the device will be impervious to the introduction of malware. You can however reduce the risk of malware attacks

by using care when downloading content or accepting applications, refraining from opening or responding to messages from unknown sources, using trustworthy services to access the Internet, and only downloading content to the mobile phone from known, reliable sources.

Accessories

Use only Sony Ericsson branded original accessories and certified service partners. Sony Ericsson does not test third-party accessories. Accessories may influence RF exposure, radio performance, loudness, electric safety and other areas. Third-party accessories and parts may pose a risk to your health or safety or decrease performance.

Accessible Solutions/Special Needs

In the US, compatible Sony Ericsson phones may offer compatibility with TTY terminals (with use of necessary accessory). For more information call the Sony Ericsson Special Needs Center on 877 878 1996 (TTY) or 877 207 2056 (voice), or go to www.sonyericsson-snc.com.

Disposal of old electrical and electronic equipment

Electronic equipment and batteries should not be included as household waste but should be left at an appropriate collection point for recycling. This helps prevent potential negative consequences for the environment and human health. Check local regulations by contacting your local city office, your household waste disposal service, the shop where you purchased the product or calling a Sony Ericsson Contact Center. Do not attempt to remove internal batteries shall be removed only by a waste treatment facility or trained service professional.

Disposing of the battery

Check local regulations or call a Sony Ericsson Contact Center for information. Never use municipal waste.



Memory card

If the product comes complete with a removable memory card, it is generally compatible with the handset purchased but may not be compatible with other devices or the capabilities of their memory cards. Check other devices for compatibility before purchase or use. If the product is equipped with a memory card reader, check memory card compatibility before purchase or use.

Memory cards are generally formatted prior to shipping. To reformat the memory card, use a compatible device. Do not use the standard operating system format when formating the memory card on a PC. For details, refer to the operating instructions of the device or contact customer support.

Warning!

If the device requires an adapter for insertion into the handset or another device, do not insert the card directly without the required adapter.

Precautions on memory card use

- Do not expose the memory card to moisture.
- Do not touch terminal connections with your hand or any metal object.
- . Do not strike, bend, or drop the memory card.
- Do not attempt to disassemble or modify the memory card.
- Do not use or store the memory card in humid or corrosive locations or in excessive heat such as a closed car in summer, in direct sunlight or near a heater, etc.
- Do not press or bend the end of the memory card adapter with excessive force.
- Do not let dirt, dust, or foreign objects get into the insert port of any memory card adapter.
- Check you have inserted the memory card correctly.

- Insert the memory card as far as it will go into any memory card adapter needed. The memory card may not operate properly unless fully inserted.
- We recommend that you make a backup copy of important data. We are not responsible for any loss or damage to content you store on the memory card.
- Recorded data may be damaged or lost when you remove the memory card or memory card adapter, turn off the power while formatting, reading or writing data, or use the memory card in locations subject to static electricity or high electrical field emissions

Protection of personal information

Erase personal data before disposing of the product. To delete data, perform a master reset. Deleting data from the phone memory does not ensure that it cannot be recovered. Sony Ericsson does not warrant against recovery of information and does not assume responsibility for disclosure of any information even after a master reset.

Loudness warning!

Avoid volume levels that may be harmful to your hearing.

End User Licence Agreement

Software delivered with this device and its media is owned by Sony Ericsson Mobile Communications AB, and/or its affiliated companies and its suppliers and licensors.

Sony Ericsson grants you a non-exclusive limited licence to use the Software solely in conjunction with the Device on which it is installed or delivered. Ownership of the Software is not sold, transferred or otherwise conveyed.

Do not use any means to discover the source code or any component of the Software, reproduce and distribute the Software, or modify the Software. You are entitled to transfer rights and obligations to the Software to a third party, solely together with the Device with which you received the Software,

provided the third party agrees in writing to be bound by the terms of this Licence.

This licence exists throughout the useful life of this Device. It can be terminated by transferring your rights to the Device to a third party in writing.

Failure to comply with any of these terms and conditions will terminate the licence immediately.

Sony Ericsson and its third party suppliers and licensors retain all rights, title and interest in and to the Software. To the extent that the Software contains material or code of a third party, such third parties shall be beneficiaries of these terms.

This licence is governed by the laws of Sweden. When applicable, the foregoing applies to statutory consumer rights.

In the event Software accompanying or provided in conjunction with your device is provided with additional terms and conditions, such provisions shall also govern your possession and usage of the Software.

Export regulations

Export regulations: This product, including any software or technical data contained in or accompanying the product, may be subject to import and export regulations of the European Union, the United States and other countries. The user and any possessor of the product agrees to comply strictly with all such regulations and acknowledges that it is their responsibility to obtain any required licenses to export, re-export, or import this product. Without limiting the foregoing, and as an example, the user and any possessor of the product; (1) must not knowingly export or re-export Products to destinations identified pursuant to Articles in Chapter II of European Council Regulation (EC) 1334/2000; (2), must comply with U.S. government Export Administration Regulations ("EAR", 15 C.F.R. §§ 730-774, http:// www.bis.doc.gov/) administered by Department of Commerce. Bureau of Industry and Security; and (3) must comply with economic sanctions regulations (30 C.F.R. §§ 500 et. seg.... http://www.treas.gov/offices/enforcement/ofac/) administered by

the U.S. Department of Treasury, Office of Foreign Assets Control. The user and any possessor of the product may not transport or deliver the product, its accessories or separate software to any country, region, entity or person prohibited by these regulations.

Limited Warranty

Sony Ericsson Mobile Communications AB, SE-221 88 Lund, Sweden, (Sony Ericsson) or its local affiliated company, provides this Limited Warranty for your mobile phone, original accessory delivered with your mobile phone, and/or your mobile computing product (hereinafter referred to as "Product").

Should your Product need warranty service, please return it to the dealer from whom it was purchased, or contact your local Sony Ericsson Contact Center (national rates may apply) or visit www.sonyericsson.com to get further information.

Our warranty

Subject to the conditions of this Limited Warranty, Sony Ericsson warrants this Product to be free from defects in design, material and workmanship at the time of its original purchase by a consumer. This Limited Warranty will last for a period of two (2) years as from the original date of purchase of the Product for your mobile phone, and for a period of one (1) year following the original purchase date of the Product for all original accessories (such as the battery, charger or handsfree kit) which may be delivered with your mobile phone.

What we will do

If, during the warranty period, this Product fails to operate under normal use and service, due to defects in design, materials or workmanship, Sony Ericsson authorised distributors or service partners, in the country/region* where you purchased the Product, will, at their option, either repair or replace the Product in accordance with the terms and conditions stipulated herein. Sony Ericsson and its service partners reserve the right to charge a handling fee if a returned Product is found not to be under warranty according to the conditions below.

Please note that some of your personal settings, downloads and other information may be lost when your Sony Ericsson Product is repaired or replaced. At present, Sony Ericsson may be prevented by applicable law, other regulation or technical restrictions from making a backup copy of certain downloads. Sony Ericsson does not take any responsibility for any lost information of any kind and will not reimburse you for any such loss. You should always make backup copies of all the information stored on your Sony Ericsson Product such as downloads, calendar and contacts before handing in your Sony Ericsson Product for repair or replacement.

Conditions

- 1. This Limited Warranty is valid only if the original proof of purchase for this Product issued by a Sony Ericsson authorised dealer specifying the date of purchase and serial number**, is presented with the Product to be repaired or replaced. Sony Ericsson reserves the right to refuse warranty service if this information has been removed or changed after the original purchase of the Product from the dealer.
- 2. If Sony Ericsson repairs or replaces the Product, the repair for the defect concerned, or the replaced Product shall be warranted for the remaining time of the original warranty period or for ninety (90) days from the date of repair, whichever is longer. Repair or replacement may involve the use of functionally equivalent reconditioned units. Replaced parts or components will become the property of Sony Ericsson.
- 3. This warranty does not cover any failure of the Product due to normal wear and tear, or due to misuse, including but not limited to use in other than the normal and customary manner, in accordance with the Sony Ericsson instructions for use and maintenance of the Product. Nor does this warranty cover any failure of the Product due to accident, software or hardware

modification or adjustment, acts of God or damage resulting from liquid.

A rechargeable battery can be charged and discharged more than a hundred times. However, it will eventually wear out – this is not a defect and corresponds to normal wear and tear. When the talk-time or standby time is noticeably shorter, it is time to replace the battery. Sony Ericsson recommends that you use only batteries and chargers approved by Sony Ericsson.

Minor variations in display brightness and colour may occur between phones. There may be tiny bright or dark dots on the display. These are called defective pixels and occur when individual dots have malfunctioned and can not be adjusted. Two defective pixels are deemed acceptable.

Minor variations in camera image appearance may occur between phones. This is nothing uncommon and is not regarded as a defective camera module.

- 4. Since the cellular system on which the Product is to operate is provided by a carrier independent from Sony Ericsson, Sony Ericsson will not be responsible for the operation, availability, coverage, services or range of that system.
- 5. This warranty does not cover Product failures caused by installations, modifications, or repair or opening of the Product performed by a non-Sony Ericsson authorised person.
- 6. The warranty does not cover Product failures which have been caused by use of accessories or other peripheral devices which are not Sony Ericsson branded original accessories intended for use with the Product.

Sony Ericsson disclaims any and all warranties, whether express or implied, for failures caused to the Product or peripheral devices as a result of viruses, trojan horses, spyware, or other malicious software. Sony Ericsson strongly recommends that you install appropriate virus protection software on your Product and any peripheral devices connected to it, as available, and update it regularly, to better protect your device. It is understood, however, that such software will never fully protect your Product or its peripheral

- devices and Sony Ericsson disclaims all warranties, whether express or implied, in case of failure by such antivirus software to fulfil its intended purpose.
- Tampering with any of the seals on the Product will void the warranty.
- 8. THERE ARE NO EXPRESS WARRANTIES, WHETHER WRITTEN OR ORAL, OTHER THAN THIS PRINTED LIMITED WARRANTY. ALL IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY, IN NO EVENT SHALL SONY ERICSSON OR ITS LICENSORS BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY NATURE WHATSOEVER, INCLUDING BUT NOT LIMITED TO LOST PROFITS OR COMMERCIAL LOSS TO THE FULL EXTENT THOSE DAMAGES

Some countries/states do not allow the exclusion or limitation of incidental or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you.

The warranty provided does not affect the consumer's statutory rights under applicable legislation in force, nor the consumer's rights against the dealer arising from their sales / purchase contract.

*Geographical scope of the warranty

CAN BE DISCLAIMED BY LAW

If you have purchased your Product in a country member of the European Economic Area (EEA) or in Switzerland or the Republic of Turkey, and such Product was intended for sale in the EEA or in Switzerland or in Turkey, you can have your Product serviced in any EEA country or in Switzerland or in Turkey, under the warranty conditions prevailing in the country in which you require servicing, provided that an identical Product is sold in such country by an authorised Sony Ericsson distributor. To find out if your Product is sold in the country you are in, please call the local Sony Ericsson Contact Center. Please observe that certain

services may not be available outside the country of original purchase, for example, due to the fact that your Product may have an interior or exterior which is different from equivalent models sold in other countries. Please note in addition that it may sometimes not be possible to repair SIM-locked Products.

** In some countries/regions additional information (such as a valid warranty card) may be requested.

Trademarks and acknowledgements

The Liquid Identity logo and Xperia are trademarks or registered trademarks of Sony Ericsson Mobile Communications AB.

Sony is a trademark or a registered trademark of Sony Corporation.

Ericsson is a trademark or registered trademark of Telefonaktiebolaget LM Ericsson.

Bluetooth is a trademark or a registered trademark of Bluetooth SIG Inc. and any use of such mark by Sony Ericsson is under license

Other product and company names mentioned herein may be the trademarks of their respective owners.

Any rights not expressly granted herein are reserved.

Support

Anguilla	1-800-080-9518 (Toll Free)	questions.CO@support.sonyericsson.com
Antigua and Barbuda	1-800-081-9518 (Toll Free)	questions.CO@support.sonyericsson.com
Argentina	0800-333-7427 (número gratuito)	questions.CO@support.sonyericsson.com
Australia	1300 650-050 (Toll Free)	questions.AU@support.sonyericsson.com
The Bahamas	1-800-205-6062 (Toll Free)	questions.CO@support.sonyericsson.com
Barbados	1-800-082-9518 (Toll Free)	questions.CO@support.sonyericsson.com
Belgique/ België	02-0745 1611	questions.BE@support.sonyericsson.com
Belize	AN 815, PIN 5597 (Toll Free)	questions.CO@support.sonyericsson.com
Bermuda	1-800-083-9518 (Toll Free)	questions.CO@support.sonyericsson.com
Bolivia	800-100-542 (número gratuito)	questions.CO@support.sonyericsson.com
Brasil	4001-0444 (ligação gratuita)	questions.BR@support.sonyericsson.com
Canada	1 866 766 9374 (Toll Free / sans frais)	questions.CA@support.sonyericsson.com
Cayman Islands	1-800-084-9518 (Toll Free)	questions.CO@support.sonyericsson.com
Central and Southern Africa	+27 11 506 0123	questions.CF@support.sonyericsson.com
Česká republika	844 550 055	questions.CZ@support.sonyericsson.com
Chile	800-646-425 (número gratuito)	questions.CO@support.sonyericsson.com
Colombia	01800-0966-080 (número gratuito)	questions.CO@support.sonyericsson.com
Costa Rica	0 800 011 0400 (número gratuito)	questions.CO@support.sonyericsson.com
Danmark	3331 2828	questions.DK@support.sonyericsson.com

Deutschland	0180 534 2020 (ortsübliche Gebühren)	questions.DE@support.sonyericsson.com
Dominica	1-800-085-9518 (Toll Free)	questions.CO@support.sonyericsson.com
Ecuador	1-800-0102-50 (número gratuito)	questions.CO@support.sonyericsson.com
Eesti	06 032 032	questions.EE@support.sonyericsson.com
مصر/Egypt	16727	questions.EG@support.sonyericsson.com
Ελλάδα	801 11 810 810 +30 210 899 19 19 (από κινητό τηλέφωνο)	questions.GR@support.sonyericsson.com
El Salvador		questions.CO@support.sonyericsson.com
España	902 180 576 (tarifa local)	questions.ES@support.sonyericsson.com
France	09 69 32 21 21 09 69 32 21 22 (Xperia™ uniquement)	questions.FR@support.sonyericsson.com
Guatemala	1-800-300-0057 (número gratuito)	questions.CO@support.sonyericsson.com
Haïti/Ayiti	AN 193, PIN 5598 (numéro gratuit / nimewo gratis)	questions.CO@support.sonyericsson.com
Honduras	AN 8000122, PIN 5599 (número gratuito)	questions.CO@support.sonyericsson.com
Hong Kong/香港	+852 8203 8863	questions.HK@support.sonyericsson.com
Hrvatska	062 000 000	questions.HR@support.sonyericsson.com
India/भारत	1800 11 1800 (Toll Free) +91 (011) 39011111	
Indonesia	021 2701388	questions.ID@support.sonyericsson.com
Ireland	1850 545 888 (Local rate)	questions.IE@support.sonyericsson.com
Italia	06 48895206 (tariffa locale)	questions.IT@support.sonyericsson.com
Jamaica	1-800-442-3471 (Toll Free)	questions.CO@support.sonyericsson.com

Κύπρος/ Kıbrıs	0800 90 909	questions.CY@support.sonyericsson.com
Latvija Lietuva Magyarország		questions.LV@support.sonyericsson.com questions.LT@support.sonyericsson.com questions.HU@support.sonyericsson.com
Malaysia	1800-88-9900 (Toll Free / bebas tol)	questions.MY@support.sonyericsson.com
/Maroc المغرب	+212 2 2958 344	questions.MA@support.sonyericsson.com
México	0 1800 000 4722 (número gratuito)	questions.MX@support.sonyericsson.com
Nederland Nederlandse Antillen	0900 8998318 001-866-509-8660 (gratis nummer)	questions.NL@support.sonyericsson.com questions.CO@support.sonyericsson.com
New Zealand	0800-100-150 (Toll Free)	questions.NZ@support.sonyericsson.com
Nicaragua	AN 1800-0166, PIN 5600 (número gratuito)	questions.CO@support.sonyericsson.com
Norge	815 00 840 (lokaltakst)	questions.NO@support.sonyericsson.com
Österreich Pakistan/ پاکستان	0810 200 245 021 - 111 22 55 73	questions.AT@support.sonyericsson.com questions.PK@support.sonyericsson.com
Panamá	00800-787-0009 (número gratuito)	questions.CO@support.sonyericsson.com
Paraguay	009 800 54 20032 (número gratuito)	questions.CO@support.sonyericsson.com
Perú	0800-532-38 (número gratuito)	questions.CO@support.sonyericsson.com
Philippines/ Pilipinas	+63 2 7891860	questions.PH@support.sonyericsson.com
Polska Portugal	+48 22 22 77 444 808 204 466 (chamada local)	questions.PL@support.sonyericsson.com questions.PT@support.sonyericsson.com
República Dominicana	1-800-751-3370 (número gratuito)	questions.CO@support.sonyericsson.com
România Saint Kitts and Nevis	+40 21 401 0401 1-800-087-9518 (Toll Free)	questions.RO@support.sonyericsson.com questions.CO@support.sonyericsson.com

	1-800-088-9518	questions.CO@support.sonyericsson.com
and the	(Toll Free)	
Grenadines		
Schweiz/	0848 824 040	questions.CH@support.sonyericsson.com
Suisse/		
Svizzera		
Singapore	+65 6744 0733	questions.SG@support.sonyericsson.com
Slovenia	01 600 5000	questions.SI@support.sonyericsson.com
Slovensko	02 5443 6443	questions.SK@support.sonyericsson.com
South Africa	0861 632222	questions.ZA@support.sonyericsson.com
South Korea/	(+82) 1588 4170	questions.KO@support.sonyericsson.com
대한민국		
Suomi	09 299 2000	questions.FI@support.sonyericsson.com
Sverige	013 24 45 00	questions.SE@support.sonyericsson.com
	(lokal taxa)	
Trinidad and	1-800-080-9521	questions.CO@support.sonyericsson.com
Tobago	(Toll Free)	
Türkiye	+90 212 473 77 77	
United	08705 237 237	questions.GB@support.sonyericsson.com
Kingdom	(Local rate)	
United States		questions.US@support.sonyericsson.com
Uruguay	000-401-787-013	questions.CO@support.sonyericsson.com
	(número gratuito)	
Venezuela	0-800-1-00-2250	questions.CO@support.sonyericsson.com
	(número gratuito)	
Việt Nam	1900 1525 (miễn	questions.VN@support.sonyericsson.com
	phí)	
Беларусь	8 82 00 361 0001	questions.BY@support.sonyericsson.com
България	0800 1 8778	questions.BG@support.sonyericsson.com
Россия	+7 (495) 7870986	questions.RU@support.sonyericsson.com
Україна	(+380) 44 590	questions.UA@support.sonyericsson.com
	1515	
الأردن	+971 4 3919 880	questions.JO@support.sonyericsson.com
الإمارات	+971 4 3919 880	questions.AE@support.sonyericsson.com
العربية	(UAE)	
المتحدة		
الكويت	+971 4 3919 880	questions.KW@support.sonyericsson.com
المملكة	800-8200-727	questions.SA@support.sonyericsson.com
العربية		
السعودية		
中国	+86 400 810 0000	questions.CN@support.sonyericsson.com
台灣	+886 2 25625511	questions.TW@support.sonyericsson.com
ไทย	02 2483 030	questions.TH@support.sonyericsson.com

www.sonyericsson.com



Sony Ericsson Mobile Communications AB SE-221 88 Lund, Sweden

1222-9269.2