

- When you set screen lock to "Swipe", slide the status bar downward to check the Notification panel without unlocking the screen.

■ Notification LED

Notification LED informs charging prompt, battery level while charging, missed calls, new mails, etc. by turning on or flashing.

Status	Description
Red	The battery is charging when the remaining battery level is 14% or lower.
Orange	The battery is charging when the remaining battery level is 15% - 89%.
Green	The battery is charging when the remaining battery level is 90% or higher.
Flashing red	The remaining battery level is 14% or lower.
Flashing white	Indicates missed call, new Gmail message, new SMS message. ^{*1}

^{*1} Notification LED flashes while backlight is turned off or lock screen is displayed.

◆Information

- When the remaining battery is not sufficient for turning the product ON, pressing Ⓞ makes LED flash red three times.
- When you start charging with the product powered off, the notification LED turns in red. When the status of battery appears on the display, however, the notification LED lights in color that indicates the battery level.

21

Continuous stand-by time	In Japan	Approx. 640 hours (4G (LTE)) Approx. 670 hours (3G)
	Overseas (GSM)	Approx. 710 hours
Charging time	Using Common AC Adapter (sold separately): Approx. 150 min. (alone) Approx. 160 min. (with Desktop Holder)	
Continuous Full Seg watching time	Approx. 4 hours 50 min.	
Continuous 1Seg viewing time	Approx. 6 hours 40 min.	
Continuous tethering time	Approx. 580 min. (4G (LTE) on WAN) Approx. 790 min. (3G on WAN)	
Wi-Fi® tethering maximum connection number	10	

◆Information

- The continuous call time, continuous stand-by time, continuous Full Seg watching time, continuous 1Seg viewing time and continuous tethering time may drop to less than half depending on the battery charging status, usage environment such as temperature, reception condition at the location where the product is used, and the function settings.

28

■ Checking own phone number

1 **From the Home screen, [☰]▶[Settings]**

2 **[About phone]▶[Status]**

The phone number of the product is shown under "My phone number".

◆Information

- Alternatively, from the Home screen, [☰] ▶[Contacts]▶[Myself] to check your phone number.

■ Setting the Silent Mode

Set the ringtone volume to 0. Setting to Silent mode does not mute sounds for shutter, playback of video or music, alarm, etc. And adjusting the volume of ringtone & notifications or pressing upper part of volume key cancels Silent mode.

1 Ⓞ **(over 1 sec)**

2 [☒]/[☑]

Tap ☒* to set mute (ringtone volume 0) and tap ☑* to set vibrator.

◆Information

- Alternatively, slide the status bar downward ▶ [Quick settings] ▶ [Sound] to switch the Silent mode settings.

■ Setting Airplane mode

When airplane mode is set, all wireless functions (phone, packet communication, Wi-Fi® function, Bluetooth® function, NFC Reader/Writer, P2P function) are turned off.

1 Ⓞ **(over 1 sec)▶[Airplane mode]**

◆Information

- Slide the status bar downward ▶ Tap [Quick settings] ▶ "Airplane" to switch the airplane mode on or off.

Entering characters

Use software keyboard to enter characters.

To display the software keyboard, tap a character input box on the character entry screen for adding contacts, creating a message, etc.

■ Switching keyboards

With "Xperia™ Japanese keyboard" for Japanese input, you can switch input types between "Keypad" and "QWERTY".

1 **Tap a character input box**

2 [⋮] **on quick toolbar**

When quick toolbar is not displayed, tap 👉👈* (when the character mode is "Alphabet"/"Numeric", tap 👉👈*/👉👈*) to switch to "Hiragana/Kanji" then 👉👈 appears).

3 **[Switch to QWERTY]/[Switch to keypad]**

◆Information

- Tap 👉👈* at the bottom left of the screen to hide the software keyboard.
- Word suggestions or direct conversion candidates for the entered characters appear. Tap a word to enter.
- Tap 👉👈* to delete the character before the cursor.
- Tap 👉👈* to enter symbols, facemarks etc. from the displayed list.
- For details on "Xperia™ Japanese keyboard" for Japanese input, character input box→[⋮]→[使い方ガイド (Operation guide)], see POBox Plus operation guide.

Troubleshooting

Before you assume that the product is malfunctioning, check the following:

Symptom	What you should check
Power is not turned on even though Ⓞ is pressed	Is the internal battery charged? Is Ⓞ pressed for over 1 second?
The power goes off	Is the internal battery charged?
The power turns off while activation screen is displayed	Is the internal battery charged?
The screen freezes and the power cannot be turned off	Open the microSD memory card/ Micro IC Card slot cover while hooking the groove with your fingernail, press the OFF button (RED) with a fine-tipped object for approximately three seconds▶ release your finger after it vibrates three times. Alternatively, press and hold Ⓞ and upper part of volume key at the same time for approximately three seconds, and release your finger after it vibrates three times.

Symptom	What you should check
📶 (Out of service area) appears	Is the product out of the service area or in an area where the signal is weak? Is the built-in antenna covered with hand?
Cannot charge the battery (Notification LED does not light, the battery icon does not change into charging one)	Is the specified charging equipment (sold separately) attached properly?
Cannot operate key/touch panel	Is the power turned on? Is "Screen lock" set? Turn off the power and then turn it on again.
Cannot operate touch panel as intended	Are you operating with gloved hands? Are you operating with a fingernail or foreign object on the operating screen?
Charging is not complete	Is the temperature of the product raised or very low?
A message such as "charge the battery" appears	The battery is almost dead.

24

25

Symptom	What you should check
Battery usage time is short	Is the battery fully charged? Charge until the notification LED turns green. Is the internal battery end-of-life? Is the product used for a long period at places where 📶 (out of range) appears?
The screen backlight turns off in a short while	Is set "Sleep" period too short?
The display is dark.	Is "Brightness" set to dark? Is the proximity sensor blocked or covered by sticker?
Screen response is slow when you tap on the screen/press the keys	When a large amount of data is saved in the product or transferring large-size data between the product and microSD memory card, the screen response may be delayed.
Cannot recognize a microSD memory card	Is the microSD memory card inserted properly? Is the microSD memory card unmounted?

Updating Software

You can update the product to the most recent software for optimal performance and to get the latest enhancements.

- You are charged for data communication when connecting to the Internet from the product by using packet communication.

- You are recommended to back up your data before updating software.
- For details, visit **http://www.sonymobile.co.jp/support/** or refer to the "Instruction Manual" (Japanese) application or "取扱説明書 (Full instruction manual)" (Japanese) available.

■ Downloading and updating software

Update files can be downloaded from the Internet web site into the product directly.

- Note that when Wi-Fi® communication becomes unstable, packet communication takes the place automatically, which may apply communication fees.

1 **From the Home screen, [☰]▶[ツール (Tool)]▶[Update Center]**

2 **Tap "System" tab▶[☑]**

Main specifications

Display	Approx. 5 inches TRILUMINOS® Display for mobile Approx. 16.77 million colors
Weight	Approx. 167 g (with internal battery)
Dimension (W x H x T)	Approx. 72 mm x 137 mm x 10.8 mm
Continuous call time	In Japan Approx. 1340 min. Overseas (GSM) Approx. 800 min.

27

26

23

22