# **Welcome**

Thank you for purchasing your Sony VAIO® computer! Your new computer is a superb blend of high technology and easy-to-use functionality. The information provided here is designed to help you to become familiar with the hardware and software applications included with your system.

- View the <u>Electronic Flyer</u>, which provides updates and supplemental information about your computer.
- View the <u>VAIO</u> <u>Computer Specifications</u>, which lists your computer's hardware specifications and preinstalled software information.

# **Getting Started**


Congratulations on your purchase of the Sony VAIO® computer! Your new, high-performance, multimedia computer combines state-of-the-art computer functionality with the latest audio, video and information technology features.

- Unpacking your Computer
- Planning An Ergonomic Work Space


# **Unpacking your Computer**

Your computer may not be supplied with all of the accessories shown, depending on the system configuration you purchased. For details on the accessories supplied with your computer, see the online <u>Specifications</u> sheet.

# Computer and supplied accessories



#### Giga Pocket Personal Video Recorder accessories



#### **Manuals**

- VAIO® Computer Quick Start—Provides basic information on setting up and registering your computer. The Quick
  Start also provides resources for technical support, safety guidelines and owner's information.
- Microsoft® Windows® XP guide—Explains how to use the basic features of the latest Windows operating system.

#### **Online Documentation**

**VAIO**® **Computer User Guide** — Contains features and specifications of your computer. It also includes information on the applications included with your system, how to contact software vendors, and solve common problems.

To access the online User Guide:

- 1. Click **Start** in the Windows taskbar, then click **Help and Support**.
- 2. From the VAIO Help and Support Center menu, click VAIO User Guide.
- Giga Pocket Personal Video Recorder Included within the online VAIO User Guide, this section contains information on setting up and using the Giga Pocket Personal Video Recorder equipment and software applications 3

The **Internet Electronic Program Guide** (**iEPG**) service information describes new Sony technology that is used with the Internet, to locate, record and set up timed recordings of your favorite TV programs.

Specifications — This online specification sheet describes the hardware and software configuration of your VAIO computer.

To access this online information:

- 1. Click **Start** in the Windows taskbar, then click **Help And Support**.
- 2. From the VAIO Help And Support Center menu, click VAIO User Guide.
- 3. Locate the link in the text, "View the VAIO® Computer Specifications..."

#### **Hard Disk Drive Recovery**

Your computer is equipped with a utility program that enables you to recover your computer's operating system and preinstalled software.

For more information about hard disk drive recovery:

Your VAIO® computer is not supplied with System or Application Recovery CDs. Use the VAIO Recovery utility to recover your computer's operating system and preinstalled software.

- 1. Click **Start** in the Windows® taskbar, then click **Help and Support**.
- 2. From the VAIO Help And Support Center, click VAIO Recovery Options.

#### Other

Software Library containing the Microsoft software license agreement and Sony end-user license agreement.

# **Planning An Ergonomic Work Space**

Before you set up your new computer, find the best location for your new computer and plan your work space. There are several ergonomic factors to consider when you arrange your work space:

- Stable work surface Use a stable work surface large enough to support the computer and other peripheral equipment.
- Ventilation Leave at least eight inches of space on the left and back sides of your computer to enable proper ventilation.
- Placement of the keyboard, mouse, and other input devices Place your keyboard, mouse, and other input devices so that your arms and hands are in a relaxed, comfortable position. The keyboard should be directly in front of you. Adjust the level of the keyboard so that your lower arms are parallel to the floor. Keep your wrists in a relaxed position when you are using the keyboard—not angled up or down. Use the palmrest only briefly, for resting. While typing, never use the palmrest or rest your hands on the table. Position the mouse at the same level as the keyboard. Hold the mouse with a relaxed hand, and use your whole arm to move it. Take breaks during sessions with your computer. Excessive use of the mouse or a joystick may strain muscles or tendons.
- **Furniture and posture** Sit in a chair with good back support and armrests. Adjust the level of the chair so your feet are flat on the floor. A footrest may make you more comfortable. Sit with relaxed, upright posture—avoid slouching forward or leaning far backward.
- **Viewing angle of the display** Position the display 18 to 26 inches directly in front of you, with the top of the screen at or a little below eye level. Use the display's tilting feature to find the best position. You can reduce eye strain and muscle fatigue by placing the display in the proper position.
- **Lighting** Choose a location where windows and lights do not create glare and reflection on the display. Use indirect lighting to avoid bright spots on the display. You can also purchase accessories for your display that help reduce glare. Proper lighting adds to your comfort and work effectiveness.

# **Locating Controls And Ports**


This section is intended to familiarize you with the controls, ports and jacks on your computer. Your computer may not be equipped with all of these hardware features and the location of the controls, ports, and jacks may vary from the illustrations shown in this section. To view the specific connection capabilities for your system, see the online specifications sheet.

- About the Front Panel
- About the Back Panel
- About the Remote Control
- About the Keyboard

# **About the Front Panel**

The front panel of your VAIO Computer enables access to the optical and floppy disk drives. On certain models, the front panel also provides access to Giga Pocket Personal Video Recorder jacks and ports, a Memory Stick media slot and the Universal Serial Bus (USB), and i.LINK® ports that enable you to connect compatible peripheral devices.

#### Front panel



#### 1 Optical drive 1

See the online specifications sheet for optical drive information.

## 2 Optical drive 2

See the online specifications sheet for optical drive information.

#### 3 Floppy disk drive

Reads and writes data from and to a 3.5-inch floppy disk.

#### 4 Floppy disk drive access indicator

Light is green while reading and writing data from and to a floppy disk.

#### 5 Power indicator

Light is blue while the power is on.

#### 6 Power switch

Turns the computer on and off.

# 7 Stand by indicator

Light is red when the computer is placed in Stand by mode.

#### 8 Optical drive access indicator

Light is amber while reading and writing data from and to the optical drives.

#### 9 Hard disk drive access indicator

Light is amber while reading and writing data from and to the hard disk.

# 10 S-video In jack

Connection for an S-video cable (optional).

#### Composite video In jack

Connection for a video cable (optional).

#### Composite audio L In jack

Connection for an audio cable (optional).

# Composite audio R In jack

Connection for an audio cable (optional).

# 11 Optical drive 1 eject button

Ejects a disc from Optical drive 1.

# 12 Optical drive 2 eject button

Ejects a disc from Optical drive 2.

#### 13 Memory Stick media slot and access indicator

Reads and writes data from and to a Memory Stick® media. The access indicator light is amber when reading or writing data.

#### 14 Floppy disk eject button

Ejects a floppy disk from the floppy disk drive.

#### 15 Universal Serial Bus (USB 2.0) ports (4)

Connections for compatible high/full/low-speed USB devices.

# 16 i.LINK (4-pin) S400 port (IEEE 1394)

Connection for a compatible digital device.


i.LINK is a trademark of Sony used only to designate that a product contains an IEEE 1394 connection. The i.LINK connection may vary, depending on the software applications, operating system, and compatible i.LINK devices. All products with an i.LINK connection may not communicate with each other.

Please refer to the documentation that came with your compatible i.LINK device for information on operating conditions and proper connection. Before connecting compatible i.LINK devices to your system, such as an optical or hard disk drive, confirm their operating system compatibility and required operating conditions.

# **About the Back Panel**

The back panel of your computer contains the ports for supplied and optional accessories. The icons on the back panel locate and identify the ports on your computer.

# Back panel



# AC Input port

Connection for the supplied power cord.

# 2 Mouse port

Connection for a PS/2® mouse.

# 3 Keyboard port

Connection for a PS/2 keyboard.

## 4 Printer port

Connection for a parallel device, such as a printer or scanner.

# 5 Monitor port<sup>1</sup>

Connection for a standard display.

# 6 i.LINK 6-pin S400 port (IEEE 1394)

Connection and power for a compatible digital device, such as a Sony Digital Handycam® camcorder.

# 7 Universal Serial Bus (USB 2.0) ports (4)

Connections for compatible high/full/low-speed USB devices.

#### 8 Microphone jack

Connection for a microphone (optional).

#### **Headphones jack**

Connection for the supplied speakers or optional headphones.

#### Line In jack

Connection for an audio device.

#### 9 Monitor port<sup>2</sup>

Connection for a standard display.

# 10 Composite audio R Out jack

Connection for an audio or stereo dubbing cable (optional).

# Composite audio L In jack

Connection for an audio or stereo dubbing cable (optional).

#### **Composite video In jack**

Connection for a digital video or stereo A/V dubbing cable (optional).

#### S-video In jack

Connection for an S-video cable (optional).

#### 11 Telephone jack

Connection for a telephone cable (optional) to the computer.

#### 12 Speaker DC Out jack

Connection for the speaker power cable.

# 13 S/P DIF optical out port

Connection for a digital audio or optical device.

#### 14 Ethernet port

Connection for a 10BASE-T/100BASE-TX/1000BASE-TX Ethernet.

(The port marked with  $\frac{1}{2}$  (Network) is for LAN connections only.)

# 15 TV Out (S-Video/video) jack<sup>2</sup>

Connection for an S-video cable (optional).

# 16 Monitor (DVI) port

Connection for a DVI monitor.

# 17 VHF/UHF port

Connection for a coaxial cable (supplied).

#### 18 Modem line jack


Connection for the modem (supplied) cable to the wall jack.

- 1 This monitor port may have a cover, indicating that it is not available for use. On some models, the monitor port location may be in a different location.
- <sup>2</sup>On some locations, the monitor port location may be in a different location.
- <sup>3</sup> This feature is available on selected models. See the specifications sheet for information on your computer's hardware configuration

# **About the Remote Control**

Giga Pocket Personal Video Recorder features are controlled with the remote control. The remote control can start and stop video recording and playback, select channels, and set viewing preferences. This section describes the basic functions of your remote control.

#### Remote control



#### 1 MUTE button

Press to turn off the sound. Press again to restore the sound.

#### 2 Channel number buttons (1-9)

Press to select specific channels.

(Press the ENT button to activate channel selection.)

# **JUMP** button

Press to go to the previous channel. Press again to return to the current channel.

#### **ENT** button

Press to activate channel selection. See Channel number buttons.

#### 3 SIZE button

Press to view the current software in full-screen size. Press again to return the view to its original size.

#### 4 AUDIO button

Press to view available sound mode options on the monitor/display.

#### 5 DVD angle button

Press to change the camera angle during DVD playback. See the DVD player software for details. This function is not available for other software.

#### **DVD Subtitle button**

Press to turn on/off subtitles or to change the subtitle language during DVD playback. See the DVD player software for details. This function is not available for other software.

#### **DISPLAY** button

During DVD playback in full screen mode, press to show the settings window.

When using Giga Pocket software, press to display the TV/Recording deck and playback deck screens. Press again to hide these views.

#### **TV/VIDEO** button

Press to change the on-screen image from the TV/Recording deck to external video equipment, such as your VCR.

(Note: You cannot change the input source while recording.)

### 6 REW and FF buttons

Press to rewind or fast-forward.

#### **PREV and NEXT buttons**

Press to move back to the previous screen or forward to the next screen.

#### 7 TITLE button

The function of this button may vary between DVDs. See the DVD player software instructions for details.

#### 8 CANCEL button

When using Giga Pocket software, press to close an error message dialog box. The window returns to its original size when displayed in full-screen mode.

(Note: This function is not available for other software.)

#### 9 STANDBY button

Press to place the system into Stand by mode.

(Note: You cannot place the computer into Stand by mode when certain Giga Pocket functions are running.)

#### 10 MODE switch

Set the switch from  ${\bf 1}$  to  ${\bf 3}$ , to change the remote control's control between computers. The target computer's remote control software determines the assigned number.

(Note: The default setting is 1, if you are using a single computer.)

#### 11 MENU button

Press to view a shortcut menu of available software applications. Press again to hide this menu.

(Note: For Giga Pocket software, the Select Video Capsules window displays. Press the button again to hide this window.)

#### **START button**

Press to start the selected software.

#### **CLOSE button**

Press to close the current software.

# **FUNCTION** button

When Giga Pocket software is selected with the **Menu** button, press to switch from the TV/recording deck to the playback deck.

When using SonicStage software, plress to change from the music drive (hard disk drive) to the CD.

#### 12 CHANNEL button

Press to change channels automatically (no number input required).

(Note: This function is available for Giga Pocket software only.)

# 13 VOLUME button

Press to raise or lower the volume.

#### 14 REC button


Press to begin recording.


# **REC MODE button** Press to select the recording mode. **REC STOP button** Press to stop recording. (Note: The REC, REC MODE, and REC STOP functions are available for Giga Pocket software only.) **PLAY STOP button** 15 Press to stop playback. **PLAY button** Press to begin playback. **PAUSE button** Press to pause playback. **MENU** button 16 Press to display the root menu during DVD playback. Press again to minimize the window. See the DVD player software for details. When using Giga Pocket software, press to display Video Capsule listings. When using SonicStage software, press to display Playlists. When using VAIO Media software, press to display the main menu. 17 **Direction and ENTER buttons** Press a direction arrow to navigate. Press ENTER to select. 18 **RETURN button** Press to return to the previous screen. (Note: This function is not available for Giga Pocket software.) For more details about the function buttons on your remote control, see the Giga Pocket Help.

#### Inserting batteries into the remote control

Insert two AA batteries (supplied) into the remote control as shown.

To set up the remote control






Under normal use, the AA batteries may last up to six months. If your remote control does not operate properly, the batteries may need to be replaced.

If your remote control is not being used for extended periods of time, remove the batteries to avoid possible damage from battery leakage.

# **About the Keyboard**

Your VAIO® keyboard uses a standard key arrangement with additional keys that perform specific functions.

#### VAIO Keyboard



#### **KEY DESCRIPTION**

**Function** The 12 function keys along the top of the keyboard are used to perform certain tasks. The task associated with each function key may vary from one application to the next.

**Volume Control** 

Press a button to increase (+) or decrease (-) the volume of the speakers.

Mute sound.

Press the button to turn off the volume of the speaker. Press the Mute button again to restore

Standby Press the button to place the computer in Standby mode. Press the Power button or any key briefly, to resume normal operation.

Numeric keypad Use the numeric keypad area to type numbers or to perform basic math calculations. Press the Num Lock key to activate the numeric keypad. (The Num Lock indicator lights.) Press the Num Lock key again to deactivate the numeric keypad.

**Directional Arrows** The Up, Down, Left, and Right arrow keys move the pointer on the screen.

# **Applications**

The Applications key displays a shortcut menu in certain software applications. Pressing this key is equivalent to clicking the right mouse button.

#### Windows

The key with the Microsoft® Windows® logo, displays the Start menu. Pressing this key is equivalent to clicking Start on the taskbar.

#### **INDICATORS FUNCTION**

arrow and correction keys on the numeric keypad area are active.

**Caps Lock** The Caps Lock indicator lights up to advise you that the keyboard is set to type letters in uppercase. When the indicator is off, the letters appear in lower case as you type.

**Scroll Lock** The Scroll Lock indicator lights up to advise you that your screen's scrolling pattern has changed. When the indicator is off, the screen scrolls normally. This function is not available with all software applications.

# **Setting Up Your Computer**


Your computer may not be equipped with all of the hardware features described in the section. The location of the controls, ports, and jacks may vary from the illustrations shown. See the online specifications sheet for your system's specific hardware configuration.

- Connecting a Display (Monitor)
- Connecting the Speakers
- Connecting the Keyboard and Mouse
- Connecting the Telephone and Modem cables
- Connecting the Power Cords
- Turning On Your Computer
- Registering your Computer


# **Connecting a Display (Monitor)**

- 1. Plug the display's cable into the monitor port.
- 2. If necessary, plug the display's cable into the rear of the display.

# To connect a display



# To connect a DVI display




 $mm{\angle}$  Install your equipment so that you can easily reach the power outlet in the event of an emergency.

# **Connecting the Speakers**

- 1. Plug the cable attached to the back of the left speaker into the L Out jack on the back of the right speaker.
- 2. Plug the cable attached to the back of the right speaker into the Headphones jack, located on the back panel of your computer.
- 3. Plug the jack end (yellow) of the speaker power cable into the DC In jack (yellow) on the back of the right speaker.
- 4. Plug the jack end (black) of the speaker power cable into the DC Out jack located on the back panel of your computer.


# To connect the speakers



# **Connecting the Keyboard and Mouse**

- 1. Plug the keyboard cable into the keyboard port on the back of the computer.
- 2. Plug the mouse cable into the mouse port on the back of the computer.

# To connect the keyboard and mouse



#### To use an optical mouse


An optical mouse requires an ideal surface texture in order to provide precision pointing and tracking.

- Use surfaces such as plain paper, card stock, or fabric that have minimal repetitive patterning.
- Avoid surfaces such as mirrors, smooth glass, or magazines that have half- tone printing.

# **Connecting the Telephone and Modem cables**

- Unplug your telephone from the wall jack.
- 2. Plug the modem cable (supplied) into the Modem line jack, located on the back panel of your computer
- Plug the other end of the cable into the wall jack.

# To connect the telephone and modem cables




Your computer has a protective sticker covering the Ethernet port located on the rear panel. Connect 10BASE-T, 100BASE-TX or 1000BASE-TX cables to the Ethernet port. Using other cables or a telephone cable may result in an electric current overload that can cause a malfunction, excessive heat, or fire in the Ethernet port. For help on connecting to a network, see your network administrator.

# **Connecting the Power Cords**

- 1. Plug the power cord into the back of the computer.
- 2. Plug both the display and power cords into a grounded AC wall outlet or a power strip.

# To connect the power cords




# **Turning On Your Computer**

When you start your system for the first time, your computer may detect new equipment and display a dialog box that prompts you to restart your computer. Respond to this prompt immediately.

- 1. Press the power switch on the computer to turn on the power.
- 2. Press the power switch on the display to turn on the power.
- B. Press the power switch on the right speaker to turn on the power.

#### To turn on your computer



# **Registering your Computer**

Take advantage of Sony's commitment to quality customer support and receive these benefits by registering your computer:

- **Sony Customer Support** Communicate with a Support Representative to troubleshoot problems you may be having with your computer.
- **Limited warranty** Protect your investment. See the Limited Warranty Card for more details.

You are prompted to register your computer the first time you turn on the unit. Follow the on-screen instructions to complete the registration process. If you are not able to register your computer during the first session, you are provided with additional registration opportunities later.

# Giga Pocket Personal Video Recorder

Giga Pocket Personal Video Recorder is a suite of interactive Sony audio and video components that are designed to create, capture, and play back video files derived from television and your personal videos.¹

☐ Giga Pocket Personal Video Recorder hardware and software applications are not available on all VAIO® computers. See your computer's online specification sheet for details on your system configuration.

- About Giga Pocket Personal Video Recorder
- Setting Up Giga Pocket Personal Video Recorder
- Setting Up Giga Pocket Software
- Giga Pocket
- Timer Recording Wizard
- Timer Recording Manager
- Giga Pocket Explorer
- CLIÉ Converter
- Glossary
- Internet Electronic Program Guide Service

<sup>1</sup> Unauthorized duplication of audio or video files is a violation of applicable laws.

# **About Giga Pocket Personal Video Recorder**

Giga Pocket Personal Video Recorder is a unique set of tools that enhance your VAIO® computer's capabilities. Giga Pocket gives you a wide range of video viewing, recording, and playback capabilities, such as:

- Watching and recording television programs from your computer.
- Viewing and recording TV programming simultaneously.
- Setting and managing daily/weekly timer recording schedules.
- Managing Video Capsules (recorded video contents) on your computer.
- Recording personal video content from a videotape.
- Playing your Video Capsules on other computers.
- Operating Giga Pocket functions with a remote control device.
- Sharing Giga Pocket features and functions with other computers on a network.
- Transforming Video Capsules into gMovie format for viewing on your CLIÉ handheld.
- For an explanation of Giga Pocket terms, see the Glossary.

# **Giga Pocket Personal Video Recorder includes:**

- **Giga Pocket**—This application enables you to watch TV programs on your computer's display and record them onto the hard disk drive as Video Capsules for later playback.
- **Timer Recording Manager**—The Timer Recording Manager keeps track of all TV program recordings you have scheduled. This program also enables you to modify timer recordings.
- **Timer Recording Wizard**—The Wizard interface guides you through setting up a timer recording schedule. You can program one-time recordings and set up daily or weekly recurring recording schedules.
- **Giga Pocket Explorer**—The Giga Pocket Explorer program functions as your video file management system, and stores recorded Video Capsules as well as modified Playlists. Giga Pocket Explorer contains export/import functions for file format conversions.
- **Giga Pocket Server**—The Giga Pocket Server enables multiple computers on a network to use certain Giga Pocket software functions.
- CLIÉ Converter—The CLIÉ Converter is a plug-in application that enables the conversion of Video Capsules into gMovie format. You can change the format your Giga Pocket contents and transfer them onto a Memory Stick® media for viewing with your Sony CLIÉ Handheld.

#### **Accessing the Giga Pocket Help**

For more information about Giga Pocket Personal Video Recorder, follow these steps:

- 1. Click Start in the Windows® taskbar and select All Programs.
- 2. Select Giga Pocket, Help, and click Giga Pocket Help.

Giga Pocket Personal Video Recorder maintains information about the software and Video Capsules on your computer's drive D, in a folder named D:\Giga Pocket V5. This folder and its contents are not designed for your direct maintenance. Please do not move, modify or delete the Giga Pocket Folder or any of its contents. Any alteration to this folder or its contents may cause your Giga Pocket software and Video Capsules to stop working properly.

# **Setting Up Giga Pocket Personal Video Recorder**

This section illustrates how to set up the cables and connections for your Giga Pocket Personal Video Recorder system.

The hardware configuration of your computer may vary from the illustrations shown. To view the specific hardware configuration for your computer, see the online specifications sheet.

#### To set up TV connections

The best method of connecting your computer system, TV monitor or display, and cable service access, depends on the type of cable connection available in your home.


Your VAIO® Computer is supplied with certain audio and video cables. Depending on your in-home cable access, you may require extra cables, adapters or connection equipment not supplied with your computer.

# Connecting to standard cable access (CATV)

#### Option 1

- 1. Connect one end of the TV coaxial cable (supplied) to your cable service access.
- Connect the other end of the TV coaxial cable to the VHF/UHF port on the back panel of your computer.


#### To connect in CATV mode (Option 1)



#### Option 2

- 1. Connect one end of a TV coaxial cable (optional) to your cable service access. Connect the other end to the single-connection end of a splitter adapter.
- 2. Connect the TV coaxial cable (supplied) to the double-connection end of the splitter adapter. Connect the other end to the VHF/UHF port on the back panel of your computer.
- 3. Connect a third TV coaxial cable (optional) to the double-connection end of the splitter adapter. Connect the other end to the VHF/UHF port on the rear of your TV monitor or display.

#### To connect in CATV mode (Option 2)



You can connect your Giga Pocket system to an indoor/outdoor antenna system, using Option 1 or 2 from the previous section, Connecting to standard cable access (CATV). Depending on the type of antenna system in your home, your connection may require a VHF/UHF RF combiner/transformer (optional) to connect your computer and the indoor/outdoor antenna system.

🖾 If you are connecting to an indoor/outdoor antenna, you may need to reorient the antenna for best reception.


#### Option 1

- 1. Connect one end of a TV coaxial cable (optional) to your antenna outlet. Connect the other end to a VHF/UHF RF combiner/transformer (optional).
- Connect the TV coaxial cable (supplied) from the combiner/transformer to the VHF/UHF port on the back panel of your computer.

#### Option 2

- Connect both ends of the antenna's twin lead cable to the screw-type grips on the combiner/transformer.
- Connect the TV coaxial cable (supplied) from the combiner/transformer to the VHF/UHF port on the back panel of your computer.

#### To connect in standard antenna mode (air)



🎾 Your VAIO® Computer is supplied with certain audio and video cables. Depending on your in-home cable access, you may require extra cables, adapters or connection equipment not supplied with your computer.

#### Connecting with a cable or satellite set-top box (STB)


You can connect your Giga Pocket system to cable service access that uses a set-top box (cable or satellite).

#### Option 1

- Connect one end of a TV coaxial cable (optional) to your cable service access. Connect the other end to the In jack on the back panel of your set-top box (STB).
- Connect a second TV coaxial cable (optional) to the Out jack on your STB. Connect the other end to the single-connection end of a splitter adapter (optional).
- Connect a third TV coaxial cable (supplied) to the double-connection end of the splitter adapter. Connect the Page 33 other end to the VHF/UHF port on the back panel of your computer.

4. Connect a fourth TV coaxial cable (optional) to the double-connection end of the splitter adapter. Connect the other end to the VHF/UHF port on the rear of your TV monitor or display.


#### To connect in STB mode (Option 1)



#### Option 2

- 1. Connect one end of the TV coaxial cable (supplied) to your cable service access. Connect the other end to the In jack on the back panel of your set-top box (STB).
- 2. Connect a second TV coaxial cable (optional) to the Out jack on your STB unit. Connect the other end to the VHF/UHF port on the rear of your TV monitor or display.
- 3. Connect one end of the stereo A/V dubbing cables with triple RCA jacks (optional) to the Video Out and Audio-OUT (L/R) jacks on the back panel of your STB unit, matching the plug and jack colors.
- 4. Connect the other RCA jacks of the stereo dubbing cable into the Audio-R (IN), Audio-L (IN), and Composite video (IN) jacks on the back panel of your computer, matching the plug and jack colors.

#### To connect in STB mode (Option 2)



#### To set up additional equipment

This section illustrates how to set up additional equipment with the Giga Pocket Personal Video Recorder System.

#### Connecting a VCR or camcorder with an audio cable

Your VAIO® computer has both audio and video connection capability. You can locate the connections behind the bottom panel on the front of the system unit. You can connect a VCR or camcorder, using the audio jacks and video ports.

- 1. Connect a dual audio cable (optional) to the L and R audio jacks, located on the either the front or rear panels of your computer.
- Connect the other ends of the dual audio cable to your VCR or camcorder.

# Connecting equipment with an S-video or video cable

Your VCR or camcorder may have either standard video or S-video connection capability.


#### Option 1

- Connect an S-video cable (optional) directly into the S-video jack on either the front or back panel of your computer.
- Connect the other end of the S-video cable into the appropriate port on your compatible VCR or camcorder.
- 3. Connect an audio cable with double RCA plugs at each end (optional) into the composite audio L and R jacks.

# Option 2


- 1. Connect a stereo A/V dubbing cable with triple RCA plugs at each end (optional) directly into the composite video port, composite audio L and R jacks, located on either the front or back panel of your computer.
- Connect the other ends of the stereo A/V dubbing cable into the appropriate jacks on your compatible VCR or camcorder.

#### To connect a VCR or camcorder (Option 1)



# Connecting the infrared receiver

Connect the infrared receiver cable to a USB port located on either the front or back panel of your computer. Place the infrared receiver unit in a position that enables it to communicate with your remote control.



# **Setting Up Giga Pocket Software**

Giga Pocket Personal Video Recorder software features and functions are detailed in this section, enabling you to begin viewing or recording TV programs.

#### To set up TV viewing

When you start Giga Pocket Personal Video Recorder for the first time, you are automatically prompted to set the video input source for watching TV or cable TV (CATV) programs on your computer.

#### Starting Giga Pocket for TV Setup (For first time setup)


1. Verify that the computer time and date settings as displayed in the taskbar are correct.

To adjust these settings:

- 1. Right-click with your mouse. A shortcut menu appears.
- 2. Select **Adjust Date/Time**, and a dialog box appears.
- 3. Correct the date and time, if necessary.
- Click Start in the Windows taskbar, point to All Programs, point to Giga Pocket, point to All Software, and then click TV Setup.

The TV Setup Wizard appears.

## TV Setup Wizard




- 3. Depending on your cable service access, select **Standard CATV**, **Standard antenna**, or **set-top box (STB)**.
  - Standard CATV (C1-C125) without STB For this connection, you must use a coaxial cable directly (without an STB) to your computer. The default setting for this connection option is STD. Depending on your local connection requirements, HRC and IRC are also available.
  - 2. Standard antenna (2-69) Select this option if you connect an aerial antenna's coaxial cable directly to your computer for watching TV programs.
  - 3. STB (Set top box) Select this option if the broadcast signal is received from a set top box (STB) such as a digital cable box or a satellite cable box. Make sure that the Input channel on your STB (Ch. 3, Ch. 4, etc.) matches the Input channel listed in the Giga Pocket TV Setup dialog box.

If you are not sure of the type of cable connection to use (Standard, HRC, or IRC), contact your cable provider for information.

- 4. Click **Next**. The wizard displays a dialog box that enables you to customize the channel listings.
- 5. Click Auto Scan.

You can view the channel reception in the pop-up TV Setup - Monitor window.

## TV Setup Wizard - Customize the channel listing



If your computer is connected to the Internet, you can click **Go to Web Site...** and download channel listings from the iEPG listing site.

- 6. Connect to the Internet.
- 7. Click **Go to Web Site...** and download channel listings by clicking **Download all Channel Settings**.
- 8. Click **Next**. For the first time setup, you are prompted to set your Giga Pocket Server password.

## TV Setup Wizard - Giga Pocket Server password



Type in a password and click Finish.

#### Setting up your display (monitor)

When using Giga Pocket Personal Video Recorder, set your display settings as follows:

- **Colors**—Use the default factory settings (32-bit).
- **Screen area**—Set your video resolution to 1024 x 768 pixels.

If you change the default settings, you may experience poor image quality on your display.

Microsoft® Windows® XP operating system supports a single Giga Pocket user at any given time. Even if a different user logs on using the fast switch feature, Giga Pocket is not available to any other user account. For more information, see the Giga Pocket Help.

# **Giga Pocket**

Giga Pocket enables you to watch a TV program on your computer display while recording it onto your hard disk drive. Using the Giga Pocket Slip Play feature, you can view a program from the beginning even while it is being recorded.

## **Starting Giga Pocket**

1. Click **Start** in the Windows® taskbar, point to **All Programs**, point to **Giga Pocket**, then click **Giga Pocket**. The Giga Pocket window appears.

## Giga Pocket window




The current television broadcast is displayed, based on the selected channel.

## Using the TV/Recording deck and Playback deck


Giga Pocket features two decks on the main interface window: the TV/Recording deck and the Playback deck.

## TV/Recording deck (detail)



Use the TV/Recording deck to view programs and record Video Capsules. You can use the Playback deck of your Giga Pocket to play back a prerecorded Video Capsule.

## Playback deck (detail)



### **Recording a Video Capsule**

Giga Pocket stores recorded images as Video Capsules. The Video Capsules provide file recording information, which can be viewed through Giga Pocket Explorer. Manage your Video Capsules with Giga Pocket Explorer.

You cannot record a program into a previously recorded Video Capsule. All new content is recorded into a new Video Capsule.

- 1. Select your program by switching to the appropriate channel. Use the channel buttons located at the bottom of the Giga Pocket window, or use the right and left direction arrows on your keyboard.
- 2. Click **Record** , located at the bottom of the window, to begin recording your Video Capsule.
- 3. When your program has completed or you wish to end the Video Capsule, click **Stop** .....
- To pause your recording session, click Pause ................ Click on it again to resume recording.

## Using the Slip Play feature

While a program is being recorded on the TV/Recording deck, you can watch that same program from the beginning, using the Playback deck. You can begin using Slip Play to view your recording, beginning approximately ten seconds after your recording session begins.

- From the menu bar, click Functions.
- Select Start Slip Play.

### **Additional information about Giga Pocket**

- Giga Pocket can be used for external video recording. Depending on conditions, not all video images can be recorded or displayed.
- Video input from game consoles may not be recorded or displayed in Giga Pocket.
  - When you input an image from a video player device, such as a VCR that is connected to your computer, the following images may not record or display:
    - The still images of a paused playback screen.
    - A screen without images, such as a blue screen.
    - The menu screens of the attached video player device.
- The Giga Pocket software's displayed image or images from a prerecorded Video Capsule may be interrupted or distorted under the following circumstances:
  - If you change the channel on an attached video player device.
  - If you switch input during the analog input from an attached video player device.
  - If you attempt to play back a damaged video tape.
  - If you press Pause during the recording process.
- When you play a Video Capsule for a few seconds from the end of the film roll using the scroll bar, you may not be able to see a displayed image.
- The computer's response may decrease when you attempt to play a Video Capsule while recording a TV program using Giga Pocket.

Giga Pocket may interrupt or stop playback to allocate system resources for the timer recording event, if there are other applications running simultaneously. If this occurs, wait until Giga Pocket finishes recording before playing the Video Capsule.

- The timer recording may fail due to an "Event buffer of audio overflow" error in the following circumstances:
  - The input cable (coaxial or video cable) is disconnected after recording starts.

- You record a TV channel that has no broadcast content.
- You record video content from an old video tape with poor signal quality.
- The on-screen display may shift and split under some circumstances. If this occurs, switch the TV/Recording deck and the playback deck, or switch the channel. The recording proceeds even if the on-screen display shifts.
- Giga Pocket does not operate properly if used concurrently with other video applications, such as DVgate or MovieShaker software.


#### **Using the TV Program Web site**

Click Start in the Windows taskbar, point to All Programs, point to Giga Pocket, and then select Zap2it.

You can also go directly to the Web site at <a href="http://www.sony.com/vaiotv">http://www.sony.com/vaiotv</a>.

Timer Recording requires an Internet connection. See the section, <u>To set up your Internet Electronic Program</u> <u>Guide service</u>, for information on setting up for first-time use.

#### Internet Electronic Program Guide Web site



The appearance of the online channel guide Web site, its contents, and the accuracy of the TV listings are controlled by the TV listing provider and may change without notice. Pay-per-view channels can be accessed when making payments directly to the appropriate TV program provider.

You can schedule up to 100 timer recordings using Giga Pocket Personal Video Recorder.

From the online channel guide, click on the **REC** icon **PREC** to select the program you wish to record. The Timer Recording Wizard begins and the **New Timer Recording - Set Channel and Start Date and Time** window appears.

 $mm{\angle}$  Timer recordings create virtual containers for the recorded content that are called Video Capsules.

#### Accessing the Giga Pocket Help

For more information about Giga Pocket Personal Video Recorder, follow these steps:

- 1. Click **Start** in the Windows® taskbar and select **All Programs**.
- 2. Select Giga Pocket, Help, and click Giga Pocket Help.

# **Timer Recording Wizard**

With the Timer Recording Wizard, you can set, adjust, and cancel the timer recording settings.

## **Using the Timer Recording Wizard**


- Click Start in the Windows taskbar, select All Programs, then select Giga Pocket.
- 2. Select **Timer Recording Wizard**. The Timer Recording Wizard dialog box appears.

#### Timer Recording Wizard



 Select the desired option from the Select Timer Recording Settings menu and click Next. Follow the on-screen instructions. Click Help for assistance.

### New Timer Recording - Set Channel and Start Date and Time



4. Verify that the information is correct and click **Next**. The programming station and time information is

automatically programmed into the appropriate Timer Recording Wizard fields.

5. You can set the stop time for your timer recording and select the recording mode. The stop time is automatically programmed into the Timer Recording Wizard. Verify the stop time, choose a recording mode, and then click **Next** 

### Recording Mode Description

Standard Play (SP) Standard recording mode (MPEG-1, MPEG-2, and AVI).

High Quality (HQ) Image quality is improved, but recording requires more space on the hard disk drive as compared to using SP or LP recording modes (MPEG-1, MPEG-2, and AVI).


Long Play (LP) Image quality is reduced, but recording requires less space on the hard disk drive as compared to using HQ recording mode (MPEG-1).

## New Timer Recording - Set Stop Time and Recording Mode




6. From the New Timer Recording - Set Details dialog box, you can customize the timer recording schedule. Select how often you want to record the program.

### New Timer Recording - Set Details



- 7. Select a date for the recorded program to be automatically deleted from your hard disk drive, using the Expiration date of Video Capsule drop-down list.
  - To maintain adequate space on your hard disk drive, Giga Pocket Personal Video Recorder enables you to set an expiration date for your Video Capsules to be automatically deleted.
- Click **Decide** to review your setting preferences. The New Timer Recording Confirm dialog box appears. Click **Next**.

#### New Timer Recording - Confirm



9. The New Timer Recording - Completed dialog box appears. Click **Finish**.



#### Additional information about the Timer Recording Wizard

Timer recording requires approximately 30 seconds (pre-recording) preparation time prior to beginning each recording session. Please keep this in mind when setting up multiple, back-to-back recording sessions. Giga Pocket software stops the current timer recording, pauses to prepare, and then begins the next timer recording according to the set start time. The length of your first Video Capsule is approximately 30 seconds shorter than the actual time set.

You may experience some timing problems with multiple recording sessions when the second timer recording is preset as a daily or weekly recorded event. The first timer recording may end as early as 60 seconds sooner than the set stop time.

- Scheduled daily or weekly timer recording sessions do not occur if your hard disk drive does not have sufficient space. Giga Pocket software does not allow a new Video Capsule to be created if there is less than 100 MB of free space on the hard disk drive. These scheduled events resume at their scheduled time, as hard disk drive space becomes available.
- Approximately three minutes before Giga Pocket begins a timer recording and during a timer recording, you must avoid:
  - Starting up or using other software applications.
  - Setting up, changing, or deleting timer recordings.
  - All activities that may access the hard disk drive, such as copying files.

#### **Accessing the Giga Pocket Help**

For more information about Giga Pocket Personal Video Recorder, follow these steps:

- 1. Click **Start** in the Windows® taskbar and select **All Programs**.
- Select Giga Pocket, Help, and click Giga Pocket Help.

## **Timer Recording Manager**

The Timer Recording Manager keeps track of all scheduled TV recordings. Your computer settings, by default, are set to start Timer Recording Manager automatically when the computer is turned on.

Timer recordings are being performed when the Timer Recording Manager icon U(Timer Recording Manager) is visible in the Windows taskbar. The timer recording does not start unless the Timer Recording Manager application is available. For the Timer Recorder Manager application to be available, your computer should be in Stand by or Hibernate mode, if the system is not in active use. You can schedule up to 100 programs at a time, for timer recording with the Timer Recording Manager.

Microsoft® Windows® XP operating system supports a single Giga Pocket user at any given time. If a different user logs on using the fast switch feature, the Timer Recording feature is not available to another user account. The Timer Recording Manager icon appears in the taskbar of the first user to log on.

## **Using the Timer Recording Manager**

- Click Start in the Windows® taskbar, select All Programs, select Giga Pocket, and then click All Software.
- 2. Click **Timer Recording Manager**. The Timer Recording Manager dialog box appears:
  - Windows Stand by button—Places the Windows operating system into Stand by mode when the preset timer recording is set to begin, or if a Video Capsule is set to expire. Windows automatically starts and performs the appropriate action.
  - Interrupt Current Recording button—Stops the current timer recording. Use this option when you wish to end the current recording session.
  - Timer Recording List—Displays a list of timer recordings that have been performed, as well as pending timer recordings. If a daily/weekly timer recording is set, only the current recording session is shown.
    - The total number of timer recordings displayed does not exceed 100.

### Timer Recording Manager dialog box



Double-click on a recorded timer recording to play it back on Giga Pocket.

- 3. Click **Hide** to restore Timer Recording Manager to the taskbar.
- If you turn off your computer, the timer recording function is disabled.

### Viewing your selected program recording schedule

You can easily view the programs you have selected to record, using Giga Pocket Personal Video Recorder. The Timer Recording Manager feature enables you to change or cancel your timer recording at any time.

To view your scheduled timer recordings, follow these steps:

1. Double-click on the **Timer Recording Manager** icon located in the Windows® taskbar.

Review your scheduled timer recordings and make any desired changes or cancellations.

- 2. Click **Hide** to return the icon to the taskbar.
- \land You do not have to be connected to the Internet to use the Timer Recording Manager feature.

#### Additional information about the Timer Recording Manager

- When creating a timer recording, it is important to remember the following information:
- The timer recording function is disabled if you turn your computer off.
- Your computer should be in Stand by or Hibernate mode, if the system is not in active use.
- Disable screensavers and any other applications that may access your computer's hard disk drive during the timer recording.
- If you are using a set-top box (STB), make sure it is turned on and set to the channel you want to record.
- When you set up a timer recording using Giga Pocket software, always use the Timer Recording Manager. If the Timer Recording Manager is not set up, the recording does not start, even if you set the timer recording settings with the Timer Recording Wizard.

Your computer's default setting enables Timer Recording Manager to start automatically when the computer is started.

- The timer recording starts a few seconds earlier than the specified recording start time.
- Under certain circumstances, a daily or weekly timer recording may not be executed the second and subsequent times.
- A timer recording may fail if the computer's clock setting is changed right before the preset recording time. Before changing the computer's clock setting, verify that there are no timer recordings set to begin.
  - Close the Time Recording Manager before changing the computer's clock setting. Restart Timer Recording Manager after you have changed the time setting.
- If a different user logs on, using the fast switch or switch user features, the Timer Recording feature is not available to another user account. The Timer Recording Manager icon appears in the taskbar of the first user to log on.

#### **Accessing the Giga Pocket Help**

For more information about Giga Pocket Personal Video Recorder, follow these steps:

- 1. Click **Start** in the Windows® taskbar and select **All Programs**.
- 2. Select **Giga Pocket**, **Help**, and click **Giga Pocket Help**.

## **Giga Pocket Explorer**

The Giga Pocket Explorer application serves as a file manager for your Video Capsules. Video Capsules and saved Playlists are managed in Cabinets.

Giga Pocket Explorer enables you to play back Video Capsules using Giga Pocket. You can import MPEG files, that were created with compatible Sony applications, and export Video Capsules as AVI or MPEG files.


#### **Using Giga Pocket Explorer**

Click Start in the Windows taskbar, point to All Programs, point to Giga Pocket, point to Giga Pocket Explorer.

The Giga Pocket Explorer main window appears.

Click on the desired Cabinet to see a list of saved Video Capsules and Playlists.

#### Giga Pocket Explorer main window



#### **Using the Giga Pocket Explorer Toolbar functions**

From the Giga Pocket Explorer toolbar, you can:

- Launch Giga Pocket to play a selected Video Capsule or Playlist.
- Launch Timer Recording Wizard f eto set up timer recordings.
- Launch Click to DVD software to burn Video Capsules to DVD recordable media. See Click to DVD software
  Help for more details.
- Launch DVgate Plus software to edit your Video Capsules.
- Launch Giga Pocket Help to obtain further assistance.
- Change the display views for your video contents, and edit recording information.

#### Accessing the Click to DVD Help

For additional information about using Click to DVD software features, follow these steps to access the Click to DVD Help.

- Click Start in the Windows taskbar, point to All Programs.
- 2. Point to Click to DVD and click Click to DVD Help.

## Accessing the Click to DVD Help

For additional information about using Click to DVD software features, follow these steps to access the Click to DVD Help.

- 1. Click **Start** in the Windows taskbar, point to **All Programs**.
- 2. Point to **DVgate Plus** and click **DVgate Plus Help**.

## **Recording Video Capsules onto recordable DVD media**

You can record Video Capsules to DVD-R/DVD-RW media with the Make DVD feature.

The Click to DVD software must be installed in order to burn Video Capsules to recordable DVD media.


- 1. From the Giga Pocket Explorer main window, select the Video Capsules you want to burn onto a DVD.
- 2. On the Giga Pocket Explorer Toolbar, click **Make DVD**.
- 3. The Click to DVD software launches. Follow the on-screen instructions.

#### **Exporting Video Capsules**

You can export your Video Capsules as MPEG-1, MPEG-2, or AVI file formats for viewing on external media.

- 1. In the list area, right-click the Video Capsule you want to export. A shortcut menu appears.
- 2. Select **Export**. The Export dialog box appears.

#### Export dialog box



3. Enter an output name for the file you want to export and specify the location for the exported file.

You can select the option, Delete Video Capsule after export. If you do not want to delete the Video Capsule after export, leave the option disabled.

- In the section, "Export Video Capsule As:", select to convert to an AVI, MPEG-1, or MPEG-2 format.
- 5. Click **Run** to begin exporting.

Some conversion formats may not be available, depending on the recording mode that was used to create the Video Capsule.

### Additional information about using Giga Pocket Explorer

 Video Capsules that are recorded using High Quality (HQ) or Standard Play (SP) mode can be converted and exported as MPEG-1, MPEG-2, and AVI files.

MPEG-2 files need a specific system environment for playback:

- A VAIO computer that has Giga Pocket Personal Video Recorder installed.
- A VAIO computer that has a DVD-ROM or DVD-RW drive.

If you wish to play your Video Capsule in a different system environment, you can convert and export your Video Capsule using MPEG-1 format.

- Video Capsules that are recorded using Long Play (LP) mode can be converted and exported as MPEG-1 files.
- You can convert an imported MPEG file into a Video Capsule, only if the file was created using DVgate Assemble or other VAIO AV applications.

### **Using Network Cabinets**

Giga Pocket Explorer enables you to connect to Video Capsules in network cabinets located on other computers in the network. These network cabinets can be accessed through the Giga Pocket Explorer main window when you are connected to the network.

#### **Connecting to Network Cabinets**

1. On the Giga Pocket Explorer menu, select **Network** and then **Connect/Disconnect**. The Connect/Disconnect Server dialog box appears.

#### Connect/Disconnect Server dialog box



- 2. Select the server you want to connect to from the Server list on the left side.
- 3. Click **Connect** to add the selected server to the Connected Server list, then click OK. The server is connected.
- 4. To disconnect, repeat step 1, then select the server you want to disconnect from the Connected Server list on the right.
- 5. Click **Disconnect**, then click **OK**. The server is disconnected.

### **Accessing the Giga Pocket Help**

For more information about Giga Pocket Personal Video Recorder, follow these steps:

- 1. Click Start in the Windows® taskbar and select All Programs.
- 2. Select Giga Pocket, Help, and click Giga Pocket Help.

## **CLIÉ Converter**

The CLIÉ Converter is a plug-in application that enables the conversion of Video Capsules into gMovie format. You are able to convert your Giga Pocket contents and HotSync® onto a Memory Stick® media for viewing with your Sony CLIÉ Handheld. In order to use the CLIÉ Converter plug-in application, make sure you have install all required software for the CLIÉ handheld.

The Sony CLIÉ Handheld personal entertainment organizers provide a rich and compelling handheld computing experience. Powered by the Palm operating system, the CLIÉ handheld is ready to deliver music and video with amazing clarity. For more information on this exciting device, go to the Sony Style Web site at <a href="http://sonystyle.com/vaio/clie">http://sonystyle.com/vaio/clie</a>.

# **Starting CLIÉ Converter**

- 1. Click **Start** in the Windows taskbar and point to **All Programs**.
- Point to Giga Pocket, point to Plug-ins, and then click CLIÉ Converter. The Giga Pocket -> CLIÉ Converter dialog box appears.

## Giga Pocket -> CLIÉ Converter main



## **Converting Video Capsules**

- 1. From the **Giga Pocket -> CLIÉ Converter** dialog box, click the **Setting...** button. The Settings dialog box appears. Enter your desired settings and click **OK**.
- 2. Start Giga Pocket Explorer as follows:
  - 1. Click **Start** in the Windows taskbar, and then select **All Programs**.
  - Select Giga Pocket, and then click Giga Pocket Explorer.
  - 3. Resize the Giga Pocket Explorer window so that the Giga Pocket -> CLIÉ Converter dialog box is visible.
  - 4. Click on the **Cabinet** icon to display the contents in the list area.
  - 5. Drag the Video Capsule from the Giga Pocket Explorer window and drop it in the list area of the Giga Pocket -> CLIÉ Converter main dialog box. The Video Capsule automatically converts into a video file.
    - During conversion, the Convert to CLIÉ dialog box appears, displaying the conversion status. When conversion is complete, the dialog box automatically closes.
- The conversion process may take time, depending on the settings selected.

To convert multiple Video Capsules, hold down the Ctrl key while selecting Video Capsules in Giga Pocket Explorer. Drag and drop all selected capsules to the Giga Pocket -> CLIÉ Converter main window.

### Transferring converted video files to a Memory Stick media

- 1. Insert a Memory Stick® media into the Memory Stick media slot on your computer.
- From the Giga Pocket -> CLIÉ Converter main window, click to select the videos you want to transfer to the Memory Stick media.
- 3. Click **Send To**. The Send To dialog box appears.
- 4. Select **Using Memory Stick** as the transfer destination. Click **OK**.

During transfer, the Forwarding dialog box appears, displaying the transfer status. When transfer is complete, the GP2CLIE window appears. Click  $\mathbf{OK}$ .

Your converted video files can be played back on CLIÉ Handhelds that support the use of a Memory Stick media.

### Transferring converted video files using the HotSync® operation

You can transfer your converted video files directly to your CLIÉ Handheld, when you launch a HotSync operation.

- 1. From the **Giga Pocket -> CLIÉ Converter** main window, click to select the videos you want to transfer using the HotSync operation.
- 2. Click **Send To**. The Send To dialog box appears.
- 3. Select **Using HotSync** as the transfer destination. Designate a user name, if applicable to your handheld's configuration. Click **OK**.
- 4. The "Send to HotSync" message box appears. Follow the on-screen instructions and click **OK**.
- For more information about the HotSync operation, see the information supplied with your CLIÉ Handheld.

### Accessing the CLIÉ Converter Help

For more information about using the CLIÉ Converter plug-in application, follow these steps:

- 1. Click **Start** in the Windows taskbar and point to **All Programs**.
- 2. Point to **Giga Pocket**, point to **Help**, and then click **CLIÉ Converter Help**.

### **Glossary**

The most common terms for Giga Pocket Personal Video Recorder software are defined below.

**Cabinet** A cabinet acts as a container for Video Capsules in Giga Pocket Explorer. A network cabinet is located on other computers in a network environment.

**CATV** Refers to Community Access Television, otherwise known as cable television.

**Clip** A clip is a Video Capsule when it is stored in a Playlist.

**Cut** A cut is a selected scene taken from a previously recorded Video Capsule.

**Expiration date** A Video Capsule is stored on the hard disk drive for a preset period of time. When this time has expired, the Video Capsule is automatically deleted.

**Film roll** During Video Capsule playback, a snapshot view of the scenes are captured on a film roll. You can scroll freely through the film roll to view different scenes.

**GOP** Group of Pictures (GOP) are the smallest unit of measure for the images captured on a Video Capsule. A single GOP is approximately 0.5 to 1 second in length.

**HotSync**® Registered trade name for the method of linking between a handheld device and a larger computer, such as a desktop or notebook computer.

**Management information** Management information contains the creation date of Video Capsules and their thumbnails. This information is required for preview.

**MPEG file** A file that contains compressed moving pictures using the MPEG standard, with mpg as the file name extension.

**Safety Tab** Removing the safety tab from a Video Capsule prevents accidental erasing of your video data.

**Slip play** This feature allows you to view delayed video playback. While your recording is in progress, you are able to view the recording from the beginning.

**Snapshot** A snapshot is a miniature view displayed on the film roll in Giga Pocket, Playlist Builder, and the preview monitor in Giga Pocket Explorer.

**Stand by mode** Stand by mode is a power saving mode that is set up by using the Windows® operating system. Your computer stays in this power saving mode until approximately 5 minutes before the timer recording is due to begin.

**STB** Refers to set-top box, otherwise known as a cable box.

**Thumbnail** A thumbnail is a miniature view on recorded Video Capsules or in playback by Giga Pocket. The main thumbnail is displayed in calendar view or in the Giga Pocket Explorer list area.

**Timer recording** A timer recording is a preset video recording event.

**Video Capsule** A Video Capsule is a virtual container that holds the video images recorded with Giga Pocket Recorder. A Video Capsule is created on your computer hard disk drive and managed with Giga Pocket Explorer.

## **Accessing the Giga Pocket Help**

For more information about Giga Pocket, follow these steps:

- 1. Click **Start** in the Windows taskbar and point to **All Programs**.
- 2. Point to **Giga Pocket**, point to **Help**, and then select **Giga Pocket Help**.

## **Internet Electronic Program Guide Service**

Internet Electronic Program Guide is a free, online service that enables quick and easy access to your local TV listings. You can use the Internet Electronic Program Guide service with your Giga Pocket Personal Video Recorder for a "one-click" set up of timer recordings and record your favorite TV programs<sup>1</sup>.

Giga Pocket Personal Video Recorder must be set up and configured correctly before you can use the Internet Electronic Program Guide service.

You must read and accept the User Agreement before accessing the Internet Electronic Program Guide Web site (first time only).

The Internet Electronic Program Guide service is available only to users in the United States.

<sup>1</sup> Unauthorized duplication of audio or video files is a violation of applicable laws.

## To set up your Internet Electronic Program Guide service

You must be connected to the Internet, before setting up your Internet Electronic Program Guide service.

Sony recommends using Microsoft® Internet Explorer as your Web browser to access the Internet Electronic Program Guide service.

To set up Internet Electronic Program Guide service, follow these steps:

- 1. Click **Start** in the Windows® taskbar and point to **All Programs**.
- Point to Giga Pocket, then click TV Program Web site. Microsoft® Internet Explorer launches, and you are directed to the Internet Electronic Program Guide Web site.
- 3. The **Terms of Use** window appears. Click **I accept**, to continue.

The Welcome and Registration window appears.

#### Internet Electronic Program Guide Welcome and Registration window



- 4. In the **Welcome!** section, enter your 5-digit zip code and click **Continue**. The **Choose Your Provider** window appears, listing all TV providers or TV services available in your area.
- 5. Select your TV provider and then click **Confirm Channel Lineup**. The **Confirm Lineup** window appears, listing available channels by number and name.
- 6. Click **Yes** if the channel lineup is correct. Otherwise, click **No** and repeat steps 3 and 4 until you locate the correct channel lineup.
- 7. Your TV listings appear in table format, organized by time and channel. Click **Download All Channel Settings** to set your channels. The **Channel Information Converter** window appears, if this is the first time you have used this download feature. Click **OK**.
- Close all Giga Pocket applications before downloading your TV listings.

If you are using set-top box (STB) mode, you do not need to click Download All Channel Settings.

- 8. Verify the channel settings and click **OK**.
- 9. Your personal channel settings appear whenever you access the Internet Electronic Program Guide Web site.

If your TV provider adds new channels or changes existing channels, an Update icon appears next to Download All Channel Settings. Click **Update** to add the new or updated channels to your personal channel setting.

## **VAIO Software Tutorials**

Your new VAIO® computer has audio and video software that makes it easy for you to create and edit videos, still images, and music files. This section describes your VAIO multimedia software.

Depending on the system configuration purchased, your computer may not include all of the software described in this section.

Your computer's visual presentation of the VAIO AV applications may vary from those shown in this manual.

- Multimedia Overview
- About Recordable CD and DVD Media and Playback Equipment
- Copying Data to Recordable CD and DVD media
- <u>Using Drag'n Drop CD+DVD Software</u>
- Using RecordNow Software
- Using Click to DVD Software
- About Recording and Playing Music
- Using SonicStage Software
- <u>Using SonicStage Mastering Studio Software</u>
- About Still Images (Photos)
- <u>Using PictureGear Studio Software</u>
- About Preinstalled Image-editing Software
- About Video Editing
- Using DVgate Plus Software
- Using DVgate Software
- About Networks
- Using VAIO Media Software
- Using Network Smart Capture Software

## **Multimedia Overview**

The preinstalled multimedia software give you a wide range of creative capability, such as:

- Listening to music
- Creating music CDs
- Copying music from CDs and put them on your computer
- Transferring music from your computer to different external devices
- Viewing and editing your still images
- Creating calendars, labels, and different art with your still images
- Saving your pictures into binders, albums, or onto the Web
- Saving your pictures onto CDs or DVDs
- Creating interactive DVDs
- Backing up data on CDs or DVDs
- Editing your video content
- Saving your video content onto DVDs
- Sharing your multimedia between computers and across networks

Unauthorized duplication of audio or video files is a violation of applicable laws.

## **About Recordable CD and DVD Media and Playback Equipment**

### Selecting the appropriate CD or DVD media

The following section is intended as general information for using your DVD-RW or DVD±RW drive with appropriate CD or DVD media. You can find suggestions for selecting blank recording media, understanding different disc formats, and identifying compatible playback equipment.

If your VAIO computer does not have a recordable optical drive, you cannot create CDs or DVDs.

This table can help you identify the appropriate media to use with your recordable optical drive.

#### **Drive Type Video and Data DVD**

**Music and Data CDs** 

for Genera	DVD-R I	DVD-RW	DVD+R	DVD+RW	CD-R	CD-RW
DVD-RW	Yes	Yes	No	No	Yes	Yes
DVD±RW	Yes	Yes	Yes	Yes	Yes	Yes

#### Recordable CD and DVD media types

**DVD-R for General** — DVD Recordable media for general use, also known as DVD-R(G), can be written to one time only and cannot be erased. You can use your DVD-RW or DVD±RW drives to write data to a DVD-R disc until the disc is full, but you cannot erase or overwrite any existing data. Certain software applications and disc formatting might permit the addition of information to a DVD-R disc that already contains data. DVD-R for General media is appropriate for both video and data DVD burning.

DVD-R for general media is not the same as DVD-R for Authoring media. DVD-R for Authoring discs are a special media made for commercial DVD production and equipment.

- **DVD-RW** DVD Rewritable media can be written to, erased, and written to again. Using this media with your DVD-RW or DVD±RW drives, you can record information to the same disc repeatedly, however, you must erase existing data on the disc before each recording session. Certain software applications and disc formatting might permit the addition of information to a DVD-RW disc that already contains data. DVD-RW media is appropriate for both video and data DVD burning.
- **DVD+R** DVD+R Recordable media can be written to once and cannot be erased. You can use your DVD-RW or DVD±RW drives to write data to a DVD+R disc until the disc is full, but cannot erase or overwrite any existing data. DVD+R media is appropriate for both video and data DVD burning.
- **DVD+RW** DVD+RW Rewritable media can be written to, erased, and written to again. Using this media with your DVD-RW or DVD±RW drive, you can record information to the same disc repeatedly, however, you must erase existing data on the disc before each recording session. Certain software applications and disc formatting might permit the addition of information to a DVD+RW disc that already has data on it. DVD+RW media is appropriate for both video and data DVD burning.
- **CD-R** CD Recordable media can be written to once and cannot be erased. Certain software applications and disc formatting might permit the addition of information to a CD-R disc that already has data on it. CD-R media is appropriate for both music and data CD burning.
- **CD-RW** CD Rewritable media can be written to, erased, and written to again. Certain software applications and disc formatting might permit the addition of information to a CD-RW disc that already has data on it. CD-RW media is appropriate for music and data CD burning.

#### **Incompatible DVDs and CDs**

You cannot use these CD or DVD media for recording data or music:

- CD-ROM (compact disc read-only media)
- DVD-R for Authoring

- DVD-RAM
- DVD-ROM

Media compatibility with different equipment varies between manufacturers. If you experience difficulty with recording data or playing a disc, try a different disc or a different brand of media.

#### **Additional Information**

- CD and DVD format is Universal Disk Format (UDF) with Joliet. UDF is a file system standard. Joliet is an extension to the ISO 9660 standard, which enables CDs and DVDs to use long filenames and Unicode characters in a Windows operating system environment.
- A DVD-ROM drive cannot record data to a CD or DVD. A DVD-ROM drive cannot read multi-border and multi-session discs.
- DVD+R and DVD-R drives cannot read appended data.

# **About Recordable CD and DVD Media and Playback Equipment**

## Selecting the appropriate CD or DVD media

The following section is intended as general information for using your DVD-RW or DVD±RW drive with appropriate CD or DVD media. You can find suggestions for selecting blank recording media, understanding different disc formats, and identifying compatible playback equipment.

If your VAIO computer does not have a recordable optical drive, you cannot create CDs or DVDs.

This table can help you identify the appropriate media to use with your recordable optical drive.

**Drive Type Video and Data DVD** 

**Music and Data CDs** 

for Genera	DVD-R I	DVD-RW	DVD+R	DVD+RW	CD-R	CD-RW
DVD-RW	Yes	Yes	No	No	Yes	Yes
DVD+RW	Yes	Yes	Yes	Yes	Yes	Yes

## Recordable CD and DVD media types

**DVD-R for General** — DVD Recordable media for general use, also known as DVD-R(G), can be written to one time only and cannot be erased. You can use your DVD-RW or DVD±RW drives to write data to a DVD-R disc until the disc is full, but you cannot erase or overwrite any existing data. Certain software applications and disc formatting might permit the addition of information to a DVD-R disc that already contains data. DVD-R for General media is appropriate for both video and data DVD burning.

DVD-R for general media is not the same as DVD-R for Authoring media. DVD-R for Authoring discs are a special media made for commercial DVD production and equipment.

- **DVD-RW** DVD Rewritable media can be written to, erased, and written to again. Using this media with your DVD-RW or DVD±RW drives, you can record information to the same disc repeatedly, however, you must erase existing data on the disc before each recording session. Certain software applications and disc formatting might permit the addition of information to a DVD-RW disc that already contains data. DVD-RW media is appropriate for both video and data DVD burning.
- **DVD+R** DVD+R Recordable media can be written to once and cannot be erased. You can use your DVD-RW or DVD±RW drives to write data to a DVD+R disc until the disc is full, but cannot erase or overwrite any existing data. DVD+R media is appropriate for both video and data DVD burning.
- **DVD+RW** DVD+RW Rewritable media can be written to, erased, and written to again. Using this media with your DVD-RW or DVD±RW drive, you can record information to the same disc repeatedly, however, you must erase existing data on the disc before each recording session. Certain software applications and disc formatting might permit the addition of information to a DVD+RW disc that already has data on it. DVD+RW media is appropriate for both video and data DVD burning.
- **CD-R** CD Recordable media can be written to once and cannot be erased. Certain software applications and disc formatting might permit the addition of information to a CD-R disc that already has data on it. CD-R media is appropriate for both music and data CD burning.
- **CD-RW** CD Rewritable media can be written to, erased, and written to again. Certain software applications and disc formatting might permit the addition of information to a CD-RW disc that already has data on it. CD-RW media is appropriate for music and data CD burning.

#### **Incompatible DVDs and CDs**

You cannot use these CD or DVD media for recording data or music:

- CD-ROM (compact disc read-only media)
- DVD-R for Authoring

- DVD-RAM
- DVD-ROM

Media compatibility with different equipment varies between manufacturers. If you experience difficulty with recording data or playing a disc, try a different disc or a different brand of media.

## **Additional Information**

- CD and DVD format is Universal Disk Format (UDF) with Joliet. UDF is a file system standard. Joliet is an extension to the ISO 9660 standard, which enables CDs and DVDs to use long filenames and Unicode characters in a Windows operating system environment.
- A DVD-ROM drive cannot record data to a CD or DVD. A DVD-ROM drive cannot read multi-border and multi-session discs.
- DVD+R and DVD-R drives cannot read appended data.

# **About Compatible Playback Equipment**

Compatibility between CD or DVD media and playback equipment may vary.

- Not all DVD players can play back video DVDs created on your computer.
- Some DVD players can play back DVD-R(G) media, but are incompatible with DVD-RW media.
- Some DVD players can only read certain brands of DVD-R or DVD-RW media.
- Some older computer CD-ROM drives cannot read data CD-R and CD-RW discs.
- Some older computer DVD-ROM drives cannot read certain DVD discs.

## Determining equipment, media, and format compatibility

This table provides general information to help you determine the appropriate media formats and equipment for playing different media. For specific information about product compatibility, see the documentation supplied with the specific media and equipment.

#### **Playback Equipment**

#### **Media and Format Compatibility**

#### Video DVD Music CD Data DVD Data CD

Computer DVD drive	Varies	Yes	Varies	Yes
Computer CD drive	No	Yes	No	Yes
DVD player	Varies	Varies	No	No
Audio CD player	No	Varies	No	Varies

# **Copying Data to Recordable CD and DVD media**

You can copy files to recordable media, using your computer's CD-RW, DVD-RW, or DVD $\pm$ RW drive. For detailed information on your system's hardware configuration, see the specification sheet.

## Adding data to a data DVD

When creating a data DVD, you can choose to keep the writing session open and make a disc appendable, which means you can keep adding information to the disc.

- **Appendable writing** You can add more data to a disc as long as space is available on the disc. The recording session can stay open until the disc is full. Although the space on the disc may be used efficiently, a disc written to incrementally may not be compatible with all DVD drives.
- **Non-appendable writing** All data is written to the disc at one time and the writing session is closed, even if there is more space available on the disc. You can not add more data to the disc. Non-appendable discs are more compatible with different DVD drives.



A video DVD is always non-appendable.

The table below describes the writing method for different media types for appendable and non-appendable writing.

Non-appendable

## **Writing Method**

Media Type Appendable

DVD-R	Multi-border	Disc at once
DVD-RW	Restructured overw	rite Disc at once
DVD+R	Multi-session	Disc at once
DVD+RW	Single-session	Disc at once

## Using Windows XP to create a CD or DVD

- 1. Insert a blank CD-R or CD-RW disc into your CD-RW, DVD-RW, or DVD±RW drive. (If the CD Drive window appears, click **Take no action**.)
- 2. Click **Start** in the Windows® taskbar, and then click **My Computer**. Locate the files and folders you want to copy to the CD.
- 3. Point to select a file or folder, or select several files or folders by holding down **CTRL** while pointing to each of the files you want.
- 4. Under File and Folder Tasks, click Copy this file, Copy this folder, or Copy the selected items.

If the files are located in My Pictures, under **Picture Tasks**, click **Copy to CD** or **Copy all items to CD**. Skip to step 6.

If your files are located in My Music, under **Music Tasks**, click **Copy to audio CD** or **Copy all items to audio CD**. Skip to step 6.

- 5. In the **Copy Items** dialog box, click the **read/write drive** icon<sup>1</sup>, and then click **Copy**.
  - Under Other Places, click My Computer, and then click the CD-RW or DVD-RW drive.

Windows displays the temporary area that holds the files until they are copied to the CD.

- 7. Confirm that the files and folders you want to copy are displayed under Files Ready to Be Written to the CD.
- 8. Click **Write to CD**, under **CD Writing Tasks**. The CD Writing Wizard starts.
- 9. Follow the on-screen instructions in the wizard to complete writing the files or folders to the CD.

When the writing process is finished, the wizard displays a check box that enables you to copy another CD. To create additional copies, click **Yes**, **write these files to another CD**, insert a blank CD-R or CD-RW disc, and then click **Next**.

¹The read/write drive letter designation may vary, depending your system's hardware configuration.

# **Using Drag'n Drop CD+DVD Software**

Drag'n Drop CD+DVD software easily creates data CDs and DVDs, as well as music CDs. Music, DISC Backup, and Data are the main features for Drag'n Drop software.

- 1. Click Start in the Windows® taskbar and click All Programs.
- 2. Point to **Drag'n Drop CD+DVD** and then click **Drag'n Drop CD+DVD**.

Drag'n Drop CD+DVD software starts and three Drag'n Drop CD+DVD icons (Music, Disc Backup, and Data) appear on your desktop.

3. Drag the desired music files onto the **Music** icon.

Drag the contents of a CD or DVD that you want to back up onto the **DISC Backup** icon.

Drag the desired data files onto the **Data** icon.

#### Drag'n Drop CD+DVD icons



4. Insert a blank, recordable CD or DVD<sup>1</sup>, and click the arrow icon. A progress windows displays as the data is written to the CD or DVD media.

 ${}^{\mbox{\tiny $1$}}\mbox{Use}$  the appropriate CD or DVD media for each recording session.

# To access Drag'n Drop CD+DVD software Help

- 1. Click **Start** in the Windows® taskbar and point to **All Programs**
- 2. Point to **Drag'n Drop CD+DVD**, and then click **Drag'n Drop CD+DVD Help**.

# **Using RecordNow Software**

If your VAIO® computer is equipped with a DVD-RW or DVD±RW drive, you can copy files to DVD recordable media, using the preinstalled RecordNow software.

- 1. Click **Start** in the Windows® taskbar and point to **All Programs**.
- 2. Point to **VERITAS Software**, point to RecordNow, and then click **RecordNow**.

The RecordNow main window appears.

## RecordNow main window



# To access RecordNow software Help

- 1. Click **Start** in the Windows® taskbar and point to **All Programs**.
- 2. Point to **VERITAS Software**, point to **RecordNow**, and then click **RecordNow Help**.

# **Using Click to DVD Software**

Use **Click to DVD** Automatic **Mode** software to quickly and easily make interactive DVDs. For more customized features, use **Click to DVD** software.

# To access Click to DVD software Help

- 1. Click **Start** in the Windows® taskbar and point to **All Programs**.
- 2. Point to **Click to DVD**, and then click to select **Click to DVD Help**.

## To access Click to DVD Automatic Mode software Help

- 1. Click **Start** in the Windows® taskbar and point to **All Programs**.
- 2. Point to Click to DVD, and then click to select Click to DVD Automatic Mode Help.

## Starting a video DVD project

- 1. Click **Start** in the Windows® taskbar and point to **All Programs**.
- 2. Point to Click to DVD, and then click to select Click to DVD.

The Click to DVD - New Project (Start) window appears.


 Connect an i.LINK® cable between the digital video device and the computer, and set the device to VCR/VTR mode.

For details on how to connect equipment to your computer, see the documentation supplied with the device and your online VAIO® Computer User Guide.

If the **Digital Video Device** window appears, follow these steps to start Click to DVD software:

- 1. Click to select **Create a DVD with movies and pictures**.
- 2. Click **OK.** The **Click to DVD -New Project (Start)** window appears.

## Click to DVD - New Project (Start)




- 4. Type a title for your DVD in the **DVD Title** box. This text appears in the title window of your completed DVD.
- 5. In the **Select a theme** area, select a theme from the pull-down menu.
- 6. Click a theme icon to select the background image and background music. Your selected menu theme appears in the preview window.

Clear the **Muting** check box to hear the background music. The music becomes part of your DVD regardless of this setting.

- 7. In the **Select Type** area, make sure to select the **Video** check box and clear the **Pictures** check box.
- 8. Under the **Video** check box, select one of the three quality options. High Quality video requires more storage space on your DVD.
- 9. Click Capture Video.
- 10. When the message Upon completion of video capture, it is not possible to change the picture quality. Are you sure you want to continue? appears, click OK.

# Capture Video



11. Select the **Automatic Capture** option and the **Rewind tape** check box.

With these settings, the Click to DVD software rewinds the tape and then captures all the video clips on the tape.

12. Click **Capture**. To stop capturing at any time, click **Stop Capture**.


The Click to DVD software rewinds the tape in your DV device and begins capturing all the video clips on the tape. After all the clips are captured, they appear in the clip tray at the bottom of the window.

Each captured clip becomes a chapter on your finished DVD. You can then select the chapters that appear in the chapter windows.

Capturing continues until the end of the tape or a blank segment of tape is reached.

## To edit your video content

To edit your captured clips, click **Edit Video**. The **Edit Video** window appears.



In the **Edit Video** window, your video clips appear in playback order. In this window, you can:

Delete unwanted clips by dragging them to the Recycle Bin.


- Drag clips to a new position to change the playback order.
- Divide a clip into two separate clips.
  - 1. Click to select a clip.
  - 2. Move the slider to the point where you want to divide the clip.
  - 3. Click **Divide**.
- Delete unwanted sections of clips by dividing a clip and dragging the unwanted portion to the Recycle Bin.
- Combine two clips into one by clicking the button between two clips

# To set up your DVD

Once you have edited and arranged your video clips, click **Create DVD**<sup>1</sup> from the feature buttons located at the top of the window.

The Create DVD window appears.

#### Create DVD




2. To view the title and chapter windows of your DVD, click the **Title Menu** and **Video Menu**.

Click Next and Previous to move through multiple chapter windows.

#### To create a menu

To change the windows of your DVD, click **Create Menu**.

# Create Menu



From the Create Menu window, you can modify the automatically created windows.


- Click **Title Menu** and **Video Menu** at the left of the window to move between the title window and the chapter windows.
- Click **Theme** to change the background image for the windows.
- Click Background Music to change the background music for the windows.
- Click any text in the windows, or in the boxes surrounded with dotted lines, to change the text descriptions of the windows.
- Click **Text** to change the text properties of the windows
- When viewing chapter windows, click **Chapter** to change which chapters on the DVD appear in the chapter windows and to change the thumbnail images that represent chapters in the chapter windows.

#### To preview your DVD

Before you can preview your video content, the video must be converted to DVD format. Depending on the speed of your computer and the length of the video, it may take some time before the preview feature is available.

- Click **Preview** to see the contents of your DVD.
  - A window displays the progress of your DVD project for preview. When finished, the **Preview** window appears.
- 2. In the **Preview** window, view your finished DVD.
  - The **Preview** window has controls that enable you to navigate through the video content on your DVD.

# Preview window controls



3. After previewing the DVD, click **Close**.

🖾 After viewing your DVD, you can make further changes by returning to the **Create Menu** feature.

#### To burn your DVD

- 1. When your DVD project is complete, click Create DVD! to begin burning the project to a DVD disc.
- At the message prompt, Insert a recordable DVD disc into the drive, and click OK to continue, insert a blank DVD-R, a DVD-RW, a DVD+R, or a DVD+RW disc into your DVD-RW or DVD±RW drive, and then click OK.

The Click to DVD software program begins burning your DVD.

Creating a DVD can require several hours to complete. Interrupting the DVD creation process can result in an unusable DVD disc. Sony recommends that you do not use other software applications on your computer while Click to DVD software is burning your DVD.

While the Click to DVD program is creating a DVD, you may see your computer's hard disk drive access indicator flash repeatedly. This is normal behavior.

3. When Click to DVD software finishes burning the DVD, click **No**.

The DVD-RW or DVD±RW drive tray opens.

The DVD is now ready for use in a home DVD player or on a computer with a DVD drive and DVD player software.

1 Do not click Create DVD! at this stage, as this starts the DVD burning process. You are not able to make any changes to your video content once the DVD has been created.

# To save the DVD on your computer's hard drive

Save your DVD project to your computer, so that you can edit its contents or create additional copies later.

- 1. Click **Menu.**
- 2. Select **Save Project**, type a name for your project in the **File name** field.
- 3. Click **Save**.

# **Additional Information**

For best results before capturing video clips:

- Configure your computer so capturing is not interrupted.
- Exit all other open applications, and disable screen savers.
- On VAIO® computers equipped with Giga Pocket features, cancel any scheduled timer recording sessions.

For best results while Click to DVD software is capturing clips:

- Do not connect or disconnect i.LINK® or USB cables.
- Do not turn on or turn off i.LINK or USB devices that are connected to your computer.
- Do not attempt to access the Internet or other network services.
- Do not start additional software programs.

# **About Recording and Playing Music**

The Microsoft® Windows® XP operating system and the multimedia software preinstalled on your VAIO® computer make it easy to import, export, organize, play back, and burn music CDs¹.

<sup>1</sup> Unauthorized duplication of audio files is a violation of applicable laws.

## Transferring music files to your VAIO computer

You can transfer music to your VAIO computer from many different sources.

- Audio CDs Put your CD into your optical drive and check in songs to your computer's hard drive.
- From external devices<sup>1</sup> using a USB cable Connect your external device, such as a Network Walkman® or CLIÉ Handheld, to your VAIO computer and check in the songs to your computer's hard drive.
- MagicGate Memory Stick media For computers with a built-in Memory Stick media slot, transfer songs to and from a MagicGate Memory Stick media.
- **Electronic Music Distribution**<sup>2</sup> **(EMD) services on the Internet** Download songs from the Internet to your computer's hard drive, using Electronic Music Distribution services.
- Analog records or casettes Use SonicStage Mastering Studio software to bring music from these sources into your computer.
- <sup>⊥</sup> Equipment compatibility may vary. See the documentation supplied with the device for details.
- <sup>2</sup>Use of an EMD service requires Internet access and separate subscription to the EMD service. The SonicStage software supports only EMD services compatible with OpenMG technology. Refer to the online Help within the SonicStage software for details.

# **Using SonicStage Software**


SonicStage software is a digital music management system. You can play music on your computer, create custom audio CDs<sub>1</sub>, and much more.

- Play and record music from audio CDs Play your audio CDs and record audio tracks to your computer. Combine music tracks into Playlists and check them out to portable music devices.
- Create custom audio CDs2— Create custom audio CDs from SonicStage Playlists, mixing tracks from different sources and artists.
- Make backup copies of your audio CDs Use SonicStage software's Backing Up Audio CDs utility to create backup copies of your audio CDs.
- Use Playlists to organize and manage your music Organize your music with SonicStage software's Playlist feature. Create lists of songs sorted by artist or genre.
- **Download music from Electronic Music Distribution (EMD) services on the Internet** Use Electronic Music Distribution services to download music tracks from the Internet, include them in your Playlists, and check them out to your portable digital music devices.
- Import audio files onto your computer Import MP3 and WAV audio files onto your computer to add them to Playlists and record to CD.
- **Turning your computer into a karaoke system** Use the Vocal Canceler effect to suppress the vocal track from most music during playback.
- Enjoy a Visualizer light show during music playback Enjoy the visual effects while your music plays.
- <sup>1</sup> Unauthorized duplication of audio files is a violation of applicable laws.
- <sup>2</sup>This feature is available only on computers that have a CD-RW drive.

# **Starting SonicStage software**

- 1. Click **Start** on the Windows taskbar, and point to **All Programs.**
- 2. Point to **SonicStage**, and then click **SonicStage**.

#### SonicStage - Welcome



3. The CDDB® registration window appears. Follow the on-screen instructions to register with the CDDB® service.

The **Confirm the setup of SonicStage**... dialog box appears.


4. Click **Yes** to continue.

The CDDB® (Compact Disc Database) Music Recognition Service registration wizard enables you to register with the CDDB service. You need Internet access from your computer to register and use this service. For more information regarding CDDB registration, click the **Help** button.

# To access SonicStage software Help

- 1. Click **Start** on the Windows taskbar, and point to **All Programs.**
- 2. Point to **SonicStage**, and then click **SonicStage Help**.

## SonicStage features and controls



#### 1 Recording Assistant button

Records or transfers audio files. 8 Volume Control buttons

Controls the volume for playing audio files.

# 2 Source icons

Changes the window depending on the selected feature. 9 Equalizer button

Adjusts the sound quality and registers new settings.

# 3 Playback Area (Playlist view)

Depending on the selected source, lets you do different things. Play, pause, stop, fast forward, and reverse with the Player buttons.

10 Sound Effect button

Displays the menu where you can adjust the Vocal Canceller settings.

#### 4 Import button

Displays the Import window, where you can import audio files from the hard disk drive to the Music Drive. **11 Visualizer button** 

Displays or hides the Visualizer window where you can view images synchronized to the audio file's sound.

# 5 Content Area (Playlist view)

Displays the playlists in the Categorized List you selected. Double-click a playlist to view its tracks. button

12 **Internet** 

Displays or hides the Internet window where you can download or stream audio files via EMD services.

#### 6 Categorized List (Tree view)

Displays the playlists stored in the Music Drive by artist name, genre, format, etc. Helps you locate your audio files. 13

Internet address drop-down list (Playlist view)

Displays Internet addresses associated with the currently selected song.

#### 7 **Menu button**

Displays the SonicStage software's main menu. 14 **Switch to Edit Area button** 

Switches the Content Area to the Edit Area.

## **Recording from a CD**

You can record songs from audio CDs and add them to playlists in SonicStage software.

When you record from an audio CD from your optical drive for the first time, the **CD Drive Optimization** dialog box appears. Click **Start** to verify your optical drive. After the verification is performed, recording begins.

#### To record music from a CD


1. Insert an audio CD into your computer's optical drive.

The Microsoft® Windows® system recognizes the CD, and a window may appear asking you to select an action. Click **Cancel** to close this window.

When SonicStage software is running and an audio CD is inserted, an Internet connection to the CDDB® service is automatically launched to retrieve artist and track information. An error message is displayed if there is no Internet connection. Follow these steps to disable this function:

- Click Menu.
- Select CD Settings.
- 3. Clear the **Start playing the CD automatically** check box.
- 2. Start SonicStage software.
- 3. When the Main Window appears, click . The **Recording Assistant Window** appears.
- 4. Select the **CD icon** in the Source box, and then select the **Music Drive icon** in the Target box.
- 5. Click the **Jump to Record Window** button. The **Record Window** appears.
- 6. Click Show List to view the List Area of the **Record** window. To select specific files on your CD, click to check or clear the check marks of the tracks on the CD. A check mark indicates you have selected that track for recording.

## **Record Window**



- 7. Click **CD Info** in the lower-left corner of the Record Window to launch the CDDB service, which names your CD and its song titles.
  - Not all audio CDs support the CD Info button.
- 8. Click Change CD Recording Format in the Record Window to select a different recording format and bit rate.

- 9. When recording the audio tracks on a CD, you can:
  - 1. Click the **Record All** button to record all the tracks on a CD.
  - 2. Click the **Rec Selection** button to record the specific tracks you checked in the List Area.
- 10. When the Select **Playlist** window appears, select either **Create a New Playlist** or **Add to Playlist**, and then click **Start Rec**. When the recording is finished, the playlist appears in the **Playlist** window.

## Transferring songs (Check-In/Check-Out)

Use SonicStage software to transfer audio files between the playlists stored in the Music Drive on your computer and external devices or media. Transferring files from the Music Drive to the external device or media is called "check-out," while transferring files from the external device or media to the Music Drive is called "check-in."

## To check-out songs to an external device

- 1. Connect the external device or insert the media into your computer.
- Start SonicStage software.
- 3. When the Main Window appears, click Second Your computer automatically recognizes the connected external device or media and the **Check-In/Out Window** appears.
- 4. Click Show List To view the List Area of the Check-In/Out window.

#### Check-In/Out window



- 5. Select the playlist that contains the track that you want to check out. The tracks in the playlist are shown in the **Playlist** view panel.
- 6. Click the track to select it, or select several tracks by holding down **CTRL** while pointing to each of the tracks you want.
- 7. Click **Check-Out** to begin the check-out process.

To cancel check-out click **Stop**.

#### To check-in songs

May You must check songs back into the same computer where the songs were checked out.

1. Connect the external device or insert the media into your computer.

Your computer automatically recognizes the connected external device or media and the Check-In/Out Window appears.

- 2. Click Show List V to view the List Area of the Check-In/Out window.
- 3. Select a track from the song list of the external device or media. To check in more than one track at a time, hold down the Ctrl key and click the additional songs.
- 4. Click **Check-In** , or drag the tracks onto the Playlist view panel to begin the check-in process. If you want to

check in all of the tracks in the external device or media, click the Check-In All button.



To cancel check-out, click **Stop**.

# To make a backup copy of an audio CD

On computer models equipped with a CD recording device, you can use the **Backing Up Audio CDs** utility to make a backup copy of an audio CD.

On computer models that have both a read-only optical drive and an optical writing drive, you can make a copy with one click.

On computer models with only one optical drive, you must swap the original CD for a blank CD-R disc when requested to do so in the middle of the copying process.

- 1. Click **Start** in the Windows® taskbar, and point to **All Programs**.
- 2. Point to **SonicStage** and click the **SonicStage Backup Tool**.
- Insert the music CD into the optical drive you use to read CDs. Depending upon your computer model, this could be a CD-ROM drive, CD-RW drive, a DVD-ROM drive, a DVD-RW drive, or a Combo Drive.

On computer models that have both a read-only optical drive (CD-ROM or DVD-ROM) and an optical writing drive (CD-RW or DVD-RW), put the CD into the read-only optical drive.

- 4. Select your CD drive in the **Retrieve from** drive list.
- 5. On computer models that have both a read-only optical drive (CD-ROM or DVD-ROM) and an optical writing drive (CD-RW or DVD-RW), select the optical writing drive in the **Write to** drive list.
- 6. Click Start.
- 7. If a **Reading complete** message appears, remove the original source CD from the optical writing drive and insert a blank CD-R disc.
- 8. Click **OK**.

# **Additional features**

#### SonicStage Backup Tool

You can back up and restore music, graphics, and information data managed by SonicStage software. You must be connected to the Internet to use the SonicStage Backup Tool.

#### Import audio files in various formats

You can import audio files in various formats, such as the ATRAC3 , ATRAC3plus , MP3, or WAV standards. You can also import audio files that comply with the Microsoft® Windows Media® Technologies (WMT) standard, identified by .asf or .wma extensions. Manage your audio files through the Playlist feature of SonicStage software.

#### Manage imported songs on the playlist

Additional features are available when you register your imported songs through the Playlist feature of the SonicStage software. You can manage your music by creating your own list of songs categorized by genre or artist, displaying your song list in the Playlist feature, and arranging your songs in a customized order using the Playlist folders. Edit your music by combining multiple songs into a single song, or divide one song into two, by using the Combine and Divide features.

#### Simple mode

The main SonicStage window viewed in Simple mode, is a smaller, compact version of Full mode. This may be convenient when you want to listen to music with SonicStage software, while using other applications, or whenever you feel the Full mode view is intrusive. The Simple mode feature enables you to perform playback operations only.

# **Using SonicStage Mastering Studio Software**

SonicStage Mastering Studio software enables you to record songs¹ from analog records or cassette tapes to save to your computer's hard drive. From your computer, you can burn the songs to CD-R or CD-RW discs, or create audio files in WAV format.

<sup>1</sup> Unauthorized duplication of audio files is a violation of applicable laws.

# **To start SonicStage Mastering Studio software**

- 1. Click **Start** on the Windows® taskbar, point to **All Programs**
- 2. Point to **SonicStage Mastering Studio** and click **SonicStage Mastering Studio**.

# To access the SonicStage Mastering Studio software Help

- 1. Click **Start** on the Windows taskbar, point to **All Programs**
- 2. Point to SonicStage Mastering Studio and click SonicStage Mastering Studio Help.

# To access the SonicStage Mastering Studio Tutorial

- 1. Click **Start** on the Windows taskbar, point to **All Programs**.
- 2. Point to **SonicStage Mastering Studio**, and click **Tutorial**.

# **About Still Images (Photos)**

The Microsoft® Windows® XP operating system and the multimedia software preinstalled on your VAIO® computer make it easy to import, edit, print, and customize your still images.

## Transferring still images to your VAIO computer

There are a variety of ways to bring still images into your computer using a digital camera or a traditional film camera.

- **Digital camera and Universal Serial Bus (USB) cable** Many digital cameras can connect directly to your computer using a USB cable. The Windows XP operating system enables you to import pictures from many USB digital cameras.
  - If your digital camera does not have a USB connection or is not supported by the Windows XP operating system, refer to the documentation supplied with your camera for details on how to connect your camera to your computer and transfer images.
- Memory Stick® or other data storage media Some digital cameras store pictures on Memory Stick or other media. You can copy your photos from the storage media directly to your computer's hard disk drive.
- **From a scanner** A scanner is a device that "takes a picture" of your still images and stores them as files on your computer. The Windows XP operating system is compatible with many popular scanners. For scanners not supported by the Windows® XP operating system, follow the instructions in the documentation supplied with your scanner.
- From a commercial film developer Many companies that develop traditional film can provide a CD-ROM or floppy disk containing digital copies of your photos. Consult your film developer for details.

# **Editing still images**

You can use preinstalled software to perform traditional editing tasks such as resizing, cropping, and altering colors. You can add your own creative touch by customizing and combining multiple photos into albums, calendars or labels, using PictureGear Studio software.

# **Using PictureGear Studio Software**

PictureGear Studio software has easy-to-use features that enable you to quickly load images from a digital camera or camcorder, print high-quality photos, create custom labels, and design personalized photo albums or binders to share with family and friends.

Photo albums, binders, and photo collections can only be viewed or edited using PictureGear Studio software. To share a PictureGear Studio software creation either print your creation or use the Export feature to send it to another computer. See the section, To export a photo album.

### To access the PictureGear Studio software's Help


- Click Start on the Windows® taskbar and point to All Programs.
- 2. Point to PictureGear Studio and click PictureGear Studio Help.

# **Starting PictureGear Studio software**

- 1. Click **Start** on the Windows® taskbar and point to **All Programs**.
- 2. Point to PictureGear Studio and click PictureGear Studio.

The **PictureGear Studio** main window appears.

# PictureGear Studio main window



### **Importing photos**

Capture and import the pictures from your digital camera or camcorder to your computer. You can select your favorite pictures and place them in folders for future use.

When you initially connect your digital camera, camcorder or insert a Memory Stick® media, Windows® XP operating system may attempt to recognize the device or media. An identification window may appear. To continue using PictureGear Studio software, you can close this window as follows:

### Windows XP identification window (Memory Stick® media)



- Click Cancel to close the window.
- Select Take no action, and then click OK. The window closes.

### To import photos with the Import Photo feature


- 1. Connect your digital camera or camcorder to your computer, or insert your Memory Stick® media into the appropriate slot.
- Select Import Photo using PictureGear Studio PhotoCollection, to proceed directly to the PhotoCollection Import window.
- 3. Click **Import Photo**. Your connected digital camera, camcorder, or Memory Stick® media is displayed in the Select Device window.

### Select Device window



4. Click List to view all pictures that are located on the device or media. Make your selections and click Import Selected Photos.

### Specify Folder window



5. Select a folder option. If you are importing to a new folder, type in the folder name before clicking **Start Importing**.

### Adjust window



- 6. The Adjust window displays an enlarged version of the picture on the right and thumbnail versions on the left. Use any of the following buttons to adjust your picture.
  - Save Use this to move the picture to a new folder.
  - **Delete** Use this to remove the picture from the photo collection.
  - **Rotate** Use this to change the picture's position.
  - **Trim** Use this to crop the picture or capture a specific area.
- 7. Click **Finish Importing** to save the imported pictures in a photo collection.

## Organizing your digital photo collections


You can organize and manage your imported pictures on your computer's hard drive or from your ImageStation® account.

## To organize your photos with the PhotoCollection feature

1. Click **PhotoCollection** from the PictureGear Studio software's main window.

A list of available photo sources is displayed on the left, with the selected source's contents displayed as thumbnail pictures on the right.

#### PhotoCollection window



2. From the thumbnail view, click to select pictures.

Hold down the **Ctrl** key while clicking, to select several pictures. Press the **Ctrl+A** keys to select all of the photos in a folder.

Manage your pictures with these additional tools and features:

- **Rotate** Use this to change the picture's position.
- **View** Use this to enlarge a thumbnail view.
- **Slideshow** Use this to place the selected pictures into an organized slide show, customizing the Slideshow settings with the icon toolbar at the top of the Slideshow window.
- **Print** Use this to set up your photos and select paper to make prints.


## **Creating electronic binders**

You can add comments to your favorite photos, add custom backgrounds, clip art, and stamps, or showcase your own drawing talent. Add, remove, or change your designs to create your own unique photo art.

1. Click **Binder** from the PictureGear Studio software's main window.

A list of binder styles is displayed on the left. When you add your pictures to a binder, they appear as thumbnails on the right.

### Binder window



- You can create your own custom binder styles by clicking **Create Title**.
- 2. Select a binder style, and then click **New Page**. Available photo sources are displayed as thumbnails.
- 3. Click a photo to select it. An information form appears.
- 4. Fill in your information and click **OK**. The art palette window appears.

To create an original page with art or stamps, use the decoration features on the right by clicking on the desired feature and applying it to your photo.


5. Click **Save** to add the new page to your binder.

## **Creating digital photo albums**

Organize your memorable photos in an electronic photo album. You can share your custom photo albums with friends and family


1. Click **PhotoAlbum** from the PictureGear Studio software's main window.

### PhotoAlbum window



- 2. Click **New Album**. The **Select Photo** area appears.
- To select the photos you want to include in your album from available folders, click List.

### Photo List window




4. Click **Create the Album with the selected photo(s)** after making your picture selections.

## Select Design window



5. Click to select a design layout for your album. Use the scroll bar to view all available album designs.


## Select Layout window



6. Click to select a page layout for your album. Use the scroll bar to view all available layout designs.

Scroll through your album using the book icons at the bottom of the window.

# Album preview window



7. Click **Edit Album** to make changes to your album. Customize your album by adding more pictures, pages, decorations, or comments, or by deleting pages.

Click **Edit Page** to customize a page in your album. You can customize with your own drawing, stamps or other decorations.

- 8. Click **Save**.
- 9. Enter a name for your album and click **OK**.

## **Sharing your digital albums**


To share your albums with friends and family, you can use three export formats:

- Export the album as a **Flash File**. This creates a .swf file that you can view using Microsoft® Internet Explorer.
- Export as a **Light Package**. This creates a compressed file that you can view on a computer.
- Export as a Full Package. This creates an uncompressed file to be saved to recordable media, such as a CD-R/CD-RW or Memory Stick® media.

### To export a photo album


1. With a a photo album open, click Export.

### Select Format window




Click to select an export format.

### Select Folder window



- 3. Click **Browse** and navigate to the destination folder. Enter a file name.
- 4. Click **Export**. A progress window appears briefly.

### Finish Exporting window




5. An export completion message window appears, displaying the file name and file size. Click **Return to Edit Album Screen**.

## **Designing Postcards and other customized products**

Use PrintStudio to design original postcards, calendars, art, and labels using your favorite still images.

1. Click **PrintStudio** from the PictureGear Studio software's main window.

### PrintStudio window



- 2. Select the item you want to create and click **Start Creating**.
- 3. Make selections for the pictures, design layout, and custom decoration for the item you want to create.
- 4. Set the number of copies to be printed and select a connected printer. Click **Print**.
- $m{\angle}$  Use the appropriate paper when creating postcards, labels or business cards.

# **About Preinstalled Image-editing Software**

Your VAIO® computer has other image-editing software preinstalled, depending on the system configuration purchased. For details on your preinstalled software titles, see the online or hardcopy specifications sheet.

## **Using Adobe Photoshop Elements software**

**Adobe® Photoshop® Elements** software is an image-editing software that is preinstalled on certain VAIO® computers. It has a wide assortment of tools for enhancing your images and offers extensive online help to enable you to make the most of your still images.

- 1. Click **Start** on the Windows® taskbar and point to **All Programs**
- 2. Point to **Adobe**, point to **Photoshop Elements**, and then click **Adobe Photoshop Elements**.

## To access the Adobe Photoshop Elements software's Help

- 1. Start **Adobe Photoshop Elements** software.
- 2. From the **Help** menu, click **Help Contents**.

# **Using Microsoft Paint software**

 $\label{eq:microsoft} \textbf{Paint} \ \text{software provides basic image-editing features.}$ 

## **To start Microsoft Paint software**

- 1. Click **Start** on the Windows taskbar and point to **All Programs.**
- 2. Point to **Accessories** and then click **Paint**.

# To access Microsoft Paint Help

- 1. Start the Microsoft **Paint** software.
- 2. From the menu, click **Help**.


# **About Video Editing**

The multimedia software preinstalled on your VAIO® computer makes it easy to import and edit videos from compatible digital video (DV) devices or MICROMV cameras, that have an i.LINK® connector.

You can edit your video creations, export them back to your video camera, or save them as files on your computer or storage media.

**DVgate** and **DVgate Plus** software give you advanced and powerful video import and export features, precise editing capabilities, and preserves the quality of your digital data.

### The Video Editing Process



# **Transferring video content to your VAIO computer**


Before you can start creating your video on your VAIO® computer, you need to transfer it from your DV device to your computer.

- **Digital Video device and i.LINK® cable** Many digital video devices can connect directly to your computer using an i.LINK cable. The Windows® XP operating system enables you to import video from your DV device.
- Memory Stick® or other data storage media Some DV devices store pictures on Memory Stick or other media. You can transfer your video from the storage media directly to your computer's hard disk drive.


# **Using DVgate Plus Software**

DVgate Plus software enables you to transfer video content from your DV device to your VAIO® computer. You can format your video into movies, and then save it on your computer's hard drive or record it back to your to your digital video camera.

### DVgate Plus software's flow



From your VAIO computer to file or back to the DV device



## **DVgate Plus software main features**

# **Capture and Output features**

## Capture Feature




Auto Capture mode — Captures all of the video content.

Manual Capture mode — Captures selected scenes.


Batch Capture mode — Divides the video content into scenes before capture.

Still Capture mode — Captures still images.


# Output Feature



# Capture Modes (detail)



## Output feature (detail)



For details on how to connect your digital video camera to your computer, refer to the documentation supplied with camera or the online VAIO® Computer User Guide.

## To access the DVgate Plus software Help

- 1. Click Start on the Windows® taskbar and point to All Programs
- Point to DVgate Plus and click DVgate Plus Help.

### **Starting DVgate Plus software**

- 1. Click Start on the Windows® taskbar and point to All Programs
- 2. Point to **DVgate Plus** and click **DVgate Plus**.

# To capture digital video (automatic mode)

- After starting DVgate Plus software, click Cancel to close the Mode Select Guide.
- 2. Confirm that the **Capture Mode** is active. If you are in **Output Mode**, click **Go to Capture Mode**.
- 3. Click **DV Device Selection**.
- 4. Select the **Auto Capture** tab.
- 5. Review the tape's contents using **Review Tape** and **External Device Control**.
- 6. Select a format for the files in the **Capture Settings** window.

To display the Capture Settings, click the **Settings** menu and select **Capture**.

7. Click Capture.

To change the file destination folder, click **Browse** and select the desired folder.

- 8. Type the file name, the software adds the second half of the file name as a 3-digit number.
- 9. Click OK.
- 10. Video capture begins. Progress is displayed in the **DV Auto Capturing** window.
- 11. When the capture finishes, view the results in the **Auto Capture Results** window.
- 12. Confirm the displayed contents, and click **OK**.
- 13. To save the Scene List, click **Save**.
- 14. Type in the file name and click **Save**.

# Transferring video content to your computer

- Start **DVgate Plus** software.
- 2. Click Cancel to close the Mode Select Guide.
- 3. Confirm that the **Output Mode** is active. If you see **Capture Mode**, click **Go to Output Mode**.
- 4. Click **HDD Output Device**.
- 5. From the **Clip List**, select the clips you want.
  - To select multiple clips by clicking them while holding down the Ctrl key.
  - To rearrange clip order by dragging the clip to the desired location in the Clip List.
  - To select continuous clips in the list:
    - 1. Click the desired first clip in the list.
    - 2. Hold down the **Shift** key, while clicking the desired last clip. All clips between the first and last clips are selected.
- 6. Click **File Output Settings**.
- 7. Choose your settings in the **File Output Settings** window. For more details on these settings, see the **DVgate Plus** software Help.

8. Click OK. Page 128

- 9. Click **Output**.
- 10. When the **Confirm** window appears, click **OK**.

# **Using DVgate Software**

DVgate Plus software provides complete control over all aspects of capturing, editing, and exporting digital video.

# To access the DVgate software's Help

- 1. Click **Start** on the Windows® taskbar and point to **All Programs**.
- 2. Point to **DVgate** and click **DVgate Help**.

## **Starting DVgate software**

- 1. Click **Start** on the Windows® taskbar and point to **All Programs**.
- 2. Point to **DVgate** and click **DVgate**.

## To capture digital video

1. Select **IMPORT** - **Auto** from the **MODE** list in the DVgate window, and click **SCAN**.

The DVgate software scans your tape and creates a list of video clips for capture.

You can manually select video clips to be captured, while viewing playback of your tape in the Monitor window. For details, refer to DVgate Plus software Help.

- 2. If necessary, edit the list of video clips.
  - To delete a clip: Select it and then click **DELETE**.
  - To change the clip capture order: Drag the individual clips to different locations on the list.
- 3. To capture all the video clips on the **IN/OUT** list, click **CAPTURE ALL**.

To capture an individual clip, click to select it in the IN/OUT list window and click CAPTURE.

- 4. In the **Save as a file** window, type a name for the file and choose a location to save your video clips. The default save location is on drive D.
- 5. Click **Save**.

### **Editing your digital video content**

**DVgate** software enables you to combine your captured video clips into a single movie. You can also trim the beginning and end of each clip, so you only include the scenes you want.

- 1. Click **Start** and then click **All Programs**.
- 2. Point to **DVgate** and click **DVgate Assemble.**
- 3. Click ADD.
- 4. In the ADD dialog box, select the video clip files you want to include in your combined movie, and click Open.
  - To select multiple clips: Hold down the Ctrl key while clicking on several files. Your selected clips appear in the Assemble list in the DVgate Assemble window.
- 5. In the **Assemble** list, clips are combined in the order they appear starting from the first clip.
  - To rearrange the clip order: Drag clips to different positions in the list.
  - To remove a clip from the list: Click to select a clip, and then click DELETE.
  - To copy a clip:
    - 1. Click to select a clip.
    - 2. Click **Copy** on the **Edit** menu, and then click the location on the list where you want the copy to be placed.
    - 3. Click **Insert** on the **Edit** menu.
  - To trim your video clips:
    - 1. Double-click a clip. The clip opens in the **DVgate Assemble Clip** window.
    - 2. Drag the slider in the middle of the window to the point in the clip where your chosen scene begins.
    - 3. Click **BEGIN**.
    - 4. Drag the slider to the point in the clip where your chosen scene ends.
    - 5. Click END.
    - 6. Click **OK** to save your changes and close **DVgate Assemble Clip** window.
- When you have set the order of your clips and trimmed them to include only the scenes you want, you can preview the entire finished movie by clicking **PREVIEW ALL** in the DVgate main window.
- 7. Click **OUTPUT ALL** to save your finished movie to your hard disk drive.
- Select a file destination for your movie, type a file name, and then click Save.

If you intend to export your movie to your DV device later, be sure to select **AVI file (\*.avi)** in the **Save as type** box before saving your movie.

## Transferring a finished movie to your digital video camera

After you have created a movie, you can export it back to your compatible DV device.

- 1. Confirm your DV device is set to recording mode. On certain models this is called VCR or VTR mode.
- 2. Turn on your DV device, and insert a tape.
- 3. From your VAIO® computer, click **Start** and then click **All Programs.**
- 4. Point to **DVgate** and then click **DVgate**.
- 5. Select **EXPORT Auto** from the **MODE** list in the DVgate window.
- 6. In the **DVgate AVI file list** window, click **ADD**.

If the **DVgate - AVI file list** window is not open, click **List** on the **Window** menu.

- 7. In the **ADD** dialog box, select the movie file you want to export, and click **Open**. The **ADD** dialog box closes, and your selected movie appears in the **Record** list in the **DVgate AVI file list** window.
- 8. Click **RECORD ALL**.
- 9. Click **OK**. The **Output** dialog box closes, and recording to your DV device begins.
- For more detailed information, see the DVgate Plus software Help.

#### **Additional Information**

- Connect the DV device to your VAIO® computer using an i.LINK cable. Only one DV device can be connected to your computer at a time.
- The Windows® XP operating system (default settings), may display the Digital Video Device window each time you connect a DV device. You can:
  - Select **DVgate** or **DVgate Plus** to control the DV device, and then click **OK**.
  - 2. Click **Cancel** to close the **Digital Video Device** window.
- DVgate software does not support hard disk compression. Do not use disk compression if you are planning to work with DVgate software.
- When you are using DVgate software, do not use any other software that may attempt to access the DV device, or other software that plays movies.
- Do not use DVgate software while the external device is in reserve standby mode or while it is recording.
- Writing to a file on a network is not supported.
- The use of more than one monitor is not supported. If you use more than one monitor, the zoom feature does not display.
- DVgate Plus does not support using Windows XP **Fast User Switching** and **Remote Desktop**. If another user logs on with Fast User Switching, DVgate Plus software shuts down. If this occurs, the user must log on again and restart the operation from where the shutdown occurred.
- Files cannot be saved to the root directory of an NTFS formatted hard disk drive, after logging onto Windows XP operating system as a user with limited access. Select any directory other than the root directory to save the files.
- Keep the video head of your DV device properly cleaned. Irregularities that you may see in your captured data can be due to dust or other particles on the video head.
- Video that is copy-protected cannot be captured.

# **About Networks**

VAIO Media software brings networking capability to your preinstalled multimedia software. Depending on the software preinstalled on your system, you can share still images, music, video, and live television to other VAIO® computers on your network¹.

1 For a listing on the preinstalled software on your computer, see the online or hard copy specifications sheet.

# **Network media servers**

You can set up one or more computers to act as media servers to store and deliver your multimedia files across a wired or wireless network.


► VAIO Media software is available on certain VAIO® computer models.

# **Using VAIO Media Software**

To share music, video, and photos with the VAIO Media system, set up one computer on your network as a media server, and install the VAIO Media client software on other computers. Computers on the network with the VAIO Media client software can then view the multimedia content stored on the VAIO Media server computer.

Moderate VAIO computers with Giga Pocket preinstalled are able to stream live television to other machines on your network.

### A VAIO® computer network



Your VAIO Media server computer can store and deliver:

- Music files Supports music files in MP3, WAV, OpenMG (ATRAC3), and WMA formats. Use SonicStage software, ver. 1.5 or higher, to create playlists of music to share on your network.
  - **Video files** Supports Video Capsule files created by Giga Pocket software, ver. 5.0 or later. Video Capsules in MPEG1 (LP), MPEG2 (SP), or MPEG2 (HQ) formats are supported. Only VAIO® computers preinstalled with Giga Pocket software, ver. 5.5 or later, can be used as VAIO Media servers for video content.
- Still image files Supports still image files in JPEG, GIF, BMP, PNG, and TIFF formats.
- **TV broadcast** VAIO computers equipped with Giga Pocket features are able to stream a live TV signal to other computers connected to your network.

### **System Requirements**

To begin sharing multimedia content through the network, activate the VAIO Media software on the server and register client computers to the server.

### **Server system requirements**

- The VAIO Media server requires VAIO computers running Microsoft® Windows® XP Home Edition or Windows XP Professional Edition operating systems. VAIO Media does not support other computers or environments.
- You must connect the server and client computers through a wired network with ethernet cables or a wireless local area network (WLAN).
- Only a VAIO computer with Giga Pocket software, ver. 5.5 or later, can act as a VAIO Media Video Server.

### **Client system requirements**

- All client computers must be VAIO® computers running Windows XP Home Edition or Windows XP Professional Edition operating system. VAIO Media does not support other computers or environments.
- All client computers must be connected to the same network with a server using a hub, ethernet cables, or a wireless LAN.
- All clients computers must have VAIO Media software, ver 2.0 or later, installed before attempting to register.

#### **Network requirements**

The VAIO Media network must meet one of the following network requirements:

- Use Ethernet that is built into the VAIO® computer (10BASE-T/100BASE-TX)
- Use a wireless LAN interface (IEEE 802.11a or IEEE 802.11b)

Configure each client computer to use a hub or an access point on the network.

### Setting up the client computers

From the server side, you must initialize the installer program and copy it to each client computer in the network.

## To distribute the installer program

- 1. Click **Start** on the Windows® taskbar and point to **All Programs**.
- 2. Point to VAIO Media, point to Install VAIO Media to other VAIO PCs, and then click Get Installer.
- 3. A file download message box appears. Click Save.
- 4. Select a location to save the file, VM25Inst.exe.

When saving the installer program to a specific location, browse through the network and save the file to a client computer.

You can also save the file to a blank storage media, such as a CD-R, CD-RW or Memory Stick® media, for transfer and set up of the program on each client computers.

The VM25Inst.exe file is 19 MB in size. Verify your storage media's capacity before attempting to save the program.

### To register client computers

You can only register one client computer at a time. If more than one client computer is actively seeking registration, the server computer registers only one client computer at a time. You must restart the registration process for the other client.

Begin the client computer registration process after you have loaded the **VM25Inst.exe** file on a client computer. Add the file to the client computer and run the **VM25Inst.exe** file.

- 1. Restart the client computer when you have loaded the file. VAIO Media software appears in the **Start** menu.
- 2. Click **Start** on the Windows taskbar, and point to **All Programs**
- 3. Point to VAIO Media and then click VAIO Media.
  - On the client computer, perform the following steps:
    - From the Access Control Settings tab, select the check box, Access this computer from other devices connected to the network.
    - 2. Select the option, Register devices accessing this computer [recommended].
    - 3. Click **Register**.
    - 4. Click Start Registration.
    - If you would like to use a confirmation number to register your computer, leave the check box selected.
    - Stand by mode is automatically canceled five minutes after clicking Start.
- 5. From the server computer, accept the new client.

As the server and client computers recognize each other, the server computer generates a 4-digit number for the client. Type this number on the client machine. Each client computer has a unique number that cannot be used by the other clients on the network. If the registration process is cancelled, no number is generated and the registration process must start over for that client computer.

6. Restart the client computer. A new icon, **VAIO Home Network**, appears on the desktop.

The installation is complete and users can access media files stored on the VAIO Media server.

### Preparing your multimedia content

Use preinstalled software to prepare your multimedia content for sharing across the network, using VAIO Media software.

To prepare your multimedia content:

- Music files Use SonicStage software, ver. 1.5 or later, to create playlists of music files on your VAIO Media server computer. The VAIO Media Music Server software automatically makes SonicStage software playlists available to the client computers on your network.
- **Image files** Use Photo Server Content Manager to store image files. VAIO Media Photo Server software recognizes .JPEG, .BMP, .GIF, and .TIFF file formats.
- **Video files** Use Giga Pocket software, ver. 5.0 or later, to create cabinets of Video Capsules on your VAIO Media software server computer. The VAIO Media Video Server software automatically makes Video Capsule cabinets available to the client computers on your network.

**VAIO Media Console** software starts the appropriate VAIO Media servers (VAIO Media Music Server , VAIO Media Photo Server , or VAIO Media Video Server software.).

### **Starting VAIO Media Console**

- 1. Click **Start** in the Windows taskbar, and then point to **All Programs**.
- 2. Point to VAIO Media, point to Server Administration, and click Console.

Your VAIO Media server computer is now available to serve multimedia content to the VAIO Media client computers on your network.

To make additional SonicStage playlists or Giga Pocket cabinets available to client computers on your network:

- 1. Create the playlists or cabinets, using the appropriate software.
- 2. Stop the VAIO Media software, if it is running.
- 3. Restart the VAIO Media server software.


The music playlists and video cabinet contents are updated when the server software is started.

## To view images and video, or listen to music

- 1. Click **Start** in the Windows® taskbar, and then point to **All Programs**.
  - Point to VAIO Media, and then click VAIO Media.

The VAIO Media main menu window appears.

### VAIO Media main window (client computer)



3. Click the type of content you want to view or listen to (Music, Photo, Video, or TV).

VAIO Media software searches for an available VAIO Media server computer on your network.

- If more than one VAIO Media server is found, the **Please select a server screen** appears. Select your desired VAIO Media server computer from the list.
- If only one VAIO Media server is found on your network, the Playlists window (music), the Folders window (images), or the Video Cabinets window (video) appears, depending upon the type of content you selected.

These windows display lists of playlists, image folders, or video cabinets available on the VAIO Media server.



- 4. Click the playlist, image folder, or video cabinet you want to view or listen to.
  - Playlists window When you click a playlist on the Playlist window, it displays a list of the music files
    on the playlist, and the first music file on the playlist begins playing.
  - **Folders window** When you click a folder on the Folders window, it displays thumbnail images of the image files in that folder. Click an image thumbnail to view the image file.
  - Video Cabinets window When you click a folder on the Video Cabinets window, it displays a list of Video Capsules in the cabinet. Click a Video Capsule on the list to view it.

# **Using Network Smart Capture Software**

Network Smart Capture manages the i.LINK<sup>®1</sup> connection between your VAIO<sup>®</sup> computer and a compatible i.LINK digital camera or camcorder. You can capture and enhance video or still images to share with your family and friends over the Internet or through e-mail.

See the documentation that came with your compatible i.LINK device for information on operating conditions and proper connection. Before connecting i.LINK interface compatible peripherals to your computer, such as an optical drive or hard disk drive, make sure they are compatible with your computer's Microsoft® Windows® operating system and verify the required operating conditions of the devices.

### To view the Network Smart Capture software Help

- Click Start on the Windows taskbar and then point to All Programs.
- 2. Point to **Network Smart Capture** and then click **Network Smart Capture Help**.

i.LINK is a trademark of Sony used only to designate that a product contains an IEEE1394 connection. The i.LINK connection may vary, depending on the software applications, operating system and compatible i.LINK devices. All products with an i.LINK connection may not communicate with each other.

### **Starting Network Smart Capture software**


- 1. Click **Start** on the Windows taskbar and then point to **All Programs.**
- 2. Point to **Network Smart Capture** and then click **Network Smart Capture**.

The **Network Smart Capture** main window appears.

Network Smart Capture opens with a preinstalled video clip in the Finder Window, indicating there is no data input from a digital camera or camcorder.

When you connect your digital camera or camcorder to your system with an i.LINK® cable and turn it on, an image appears in the main window. Some cameras and camcorders need to have recording media inserted before an image can be displayed in the Finder Window. See the documentation supplied with your digital camera or camcorder for more information.

### Network Smart Capture main window



### 1 Finder Window

Displays images in real-time 8 Select Effect

Saves an image to your hard disk

## 2 Help

Displays Help 9 Change Setting

Set preferences

### 3 Data list

Displays thumbnails of captured images 10 Capture

Records the image in the Finder window

4 Display Image Page 144

Opens captured images in the Finder window	11 Web Camera
Captures still images according to specified settings	
5 Save As	
Saves an image to your hard disk 12 Movie	Mode
Captures video	
6 Send the selected images	
Enables you to send images or movies by e-mail, to ImageStation® Web site, or to upload them to a ph	noto server 13 Still Mode
Captures still images	
7 Delete	

Deletes captured images

You must be connected to the Internet before attempting to upload or e-mail your still images or videos.


#### Capturing still images using Still mode

The following information tells you how to set preferences and capture a still image.

### To set Still mode preferences

- Start Network Smart Capture software and connect your compatible i.LINK® digital camera or camcorder to your computer with an i.LINK cable (optional).
- Click Still.
- 3. Click **Change Setting** to view the setting options for your still image capture.

#### Still Image Setting



The **Still Image Options** window has four tabs:


- Basic Select a folder destination for your images.
- Capturing Format Select the image size in pixels, and adjust the image quality.
- **Common** Enable or disable the sound and animation effects; enable or disable sample movie sound; and enable or disable automatic dialup connection for uploading images.
- **Cam/Mic Selection** Select your primary camera and microphone.
- Click each tab to view options and set preferences. To apply effects to an image, see <u>Applying effects to your still</u> <u>images and movies.</u>

### To capture an image in Still mode

1. Use your digital camera or camcorder to locate the image you want to capture. When you see the desired image in the Finder Window, click **Capture**. You can capture a single image or several image at once.

Your captured images are stored as thumbnails in the display list area.

### Image and thumbnail



2. Click the thumbnail images or arrows to the right of the Finder Window to view the images. As you capture each image, it appears in the Finder Window.

#### **Capturing video clips using Movie mode**

### To set Movie mode preferences

- 1. Start Network Smart Capture software and connect your compatible i.LINK® digital camera or camcorder to your computer with an i.LINK cable (optional).
- 2. Click Movie.
- Click Change Setting to view the available options for your movie capture.

#### Movie Clip Setting window



The Movie Clip Setting window has four tabs:

- Basic Select a folder destination for your movies when recording video clips.
- Capturing Format Adjust the image quality, reduce image noise, and set the maximum recording time for your movie capture.
- Common Enable or disable the sound and animation effects; enable or disable sample movie sound;
   and enable or disable automatic dialup connection for uploading images.
- **Cam/Mic Selection** Select your primary camera and microphone.
- 4. Click each tab to view options and set preferences. To apply effects to an movie, see <a href="Applying effects to your stillimages and movies.">Applying effects to your stillimages and movies.</a>
- You can remove all special effects by clicking the **No Effects** button.

#### To capture video content in Movie mode


- 1. Use your digital camcorder to locate the view(s) you want to capture. When you see it in either the Finder Window or your camcorder's viewfinder, click **Record** to begin recording your movie.
- 2. Click **Stop** when you have finished recording your video. The first frame of your movie appears in the Data list to the right of the Finder Window. Network Smart Capture automatically stops recording according to the recording time set in the Movie Clip Setting window.
- 3. You can review your movie in the Finder Window by double-clicking the movie thumbnail in the data list.

### **Capturing Web camera images**

### To set Web camera mode preferences

- 1. Start Network Smart Capture software.
- 2. Click Web camera.
- 3. Click **Change Setting** to view the available options for your image capture.

#### Web Camera Setting window



The Web Camera Setting window has six tabs:

- **Basic** Select a folder destination to store your images and choose your dial-up setting.
- Capturing Interval Set your Web camera to capture images at intervals or whenever there is movement.
- **Send** Set image upload preferences.
- Capturing Format Select the image size in pixels, and adjust the image quality.
- Common Enable or disable the sound and animation effects; enable or disable sample movie sound; and enable or disable automatic dialup connection for uploading images.
- **Cam/Mic Selection** Select your primary camera and microphone.
- Click each tab to view options and set preferences. To apply effects to an image, see <u>Applying effects to your still</u> <u>images and movies.</u>

### Applying effects to your still images and movies

You can add effects to real-time images or movies displayed in the Finder Window. You can use a different effect for each picture.

#### **Effect Selection**



- 1. Click **Select Effect** near the bottom of the window to open the drop-down list of effects. Click to select digital zoom, effect, or no effect from the list.
- 2. Use **Previous Page** or **Next Page** to view the sample effects and click the sample to select it.
- 3. Click **Properties** to adjust settings for the effect you select.
- 4. Click **OK**.

#### To remove an effect

Select **No Effect** from the drop-down list.

#### Using the ImageStation online service

ImageStation® is an online service that allows you to store your images and movies on the Internet to share with family and friends. The ImageStation service requires an Internet connection and registration for the Web-based service. You must be connected to the Internet before uploading your images or movies with Smart Capture and ImageStation programs.

### To upload images and movies to the ImageStation Web site

1. Click the ImageStation icon on the right side of the window.

The ImageStation Login window appears.

- For first-time users, the ImageStation registration wizard guides you through the initial registration process. Click **Sign Up Now**, and follow the on-screen instructions.
- If you are already a registered member, type your login name and password, and then click Login.

It is recommended that your movie file size not exceed 254 MB if compressed or 2 GB if not compressed. Large movie files take longer to upload to the ImageStation Web site.

2. Go to <a href="http://www.imagestation.com">http://www.imagestation.com</a> to view your uploaded pictures or movies. Follow the on-screen instructions to access your ImageStation account. The ImageStation Web site may ask you to complete a full login again, if your current session is not active.

# **Configuring Your VAIO Computer**

This section provides basic information about managing your computer's hard disk drive performance, using i.LINK devices, Memory Stick media, PC Cards, and changing default settings. Your computer may not be equipped with all of the hardware features described in this section, depending on the system configuration purchased. To view the specific hardware configuration for your computer, see the online specifications sheet.

- About i.LINK Compatibility
- About the Memory Stick Media Slot

### About i.LINK Compatibility

Your VAIO® computer may be equipped with a 4-pin and/or a 6-pin i.LINK® port, depending on the system configuration purchased. A 4-pin i.LINK port cannot supply power to a connected i.LINK device. A 6-pin i.LINK port can supply power (10V to 12V) to a connected i.LINK device, if the device is equipped with a 6-pin connector.

To view the hardware configuration for your computer, see the online specifications sheet.



The total power supplied by the 6-pin i.LINK port cannot exceed 6 watts.

#### For PCV-W series models only

Your PCV-W series computer has two 4-pin i.LINK ports available to connect your digital devices. The 4-pin i.LINK ports do not supply power to a connected i.LINK device.

Ø i.LINK is a trademark of Sony used only to designate that a product contains an IEEE 1394 connection. The i.LINK connection may vary, depending on the software applications, operating system and compatible i.LINK devices. All products with an i.LINK connection may not communicate with each other.

Please refer to the documentation that came with your compatible i.LINK device for information on operating conditions and proper connection. Before connecting compatible i.LINK devices to your system, such as an optical or hard disk drive, confirm their operating system compatibility and required operating conditions.

### Connecting an i.LINK (IEEE 1394) device

- 1. Use the symbol to locate the i.LINK port on your compatible i.LINK device and on your computer. Plug the i.LINK cable connector into this port.
- 2. Plug the other end of the cable into the corresponding 4- or 6-pin i.LINK port on your computer.

 $mm{\angle}$  See the instructions that came with your i.LINK device for more information on installation and use.

#### **About the Memory Stick Media Slot**

Your VAIO® computer is equipped with a Memory Stick® slot that supports certain types of Memory Stick® media.

#### **About Memory Stick media**

Memory Stick® media are a compact, portable, and versatile data storage media designed for exchanging and sharing digital data with compatible devices. The following types of Memory Stick media are available, but compatibility with your computer can vary.

- **MagicGate Memory Stick** media Provides copyright protection with authentication and encryption, using Sony MagicGate technology. Authentication ensures that protected content is only transferred between compliant devices and media. Protected content can be recorded and transferred in an encrypted format that prevents unauthorized duplication or playback. You can store different data formats on a single Memory Stick media.
- Memory Stick PRO media Provides MagicGate copyright protection and high-speed data transfer features when used with compatible Memory Stick PRO devices. VAIO® computers support Memory Stick PRO media for data storage purposes only. Currently, high-speed data transfer and the MagicGate technology features, such as authentication and encryption, are not available. You can store different data formats on a single Memory Stick media.
- Memory Stick® media Provides data storage only. The Memory Stick media does not provide MagicGate technology or high-speed data transfer. You can store different data formats on a single Memory Stick media.

Currently, Sony® SonicStage and OpenMG software are not compatible with the new Memory Stick PRO media. Sony suggests using only MagicGate Memory Stick media to store and transfer any data created with SonicStage or OpenMG software.


Visit the Sony Computing Support Web site at <a href="http://www.sony.com/pcsupport">http://www.sony.com/pcsupport</a> regularly for the latest information on Memory Stick® media.

Memory Stick media do not support video file playback directly from the media. Copy the video file to your hard disk drive and then play back the file.

### **Inserting a Memory Stick media**


1. Use your fingertip to pull open the upper front panel cover, as shown.

### Opening the front panel



2. Insert the Memory Stick® media into the Memory Stick media slot.

### Inserting the Memory Stick Media




3. If the media does not insert easily, remove it from the slot and verify that it is not upside-down or backwards. Carefully reinsert the Memory Stick media, but do not force it into the slot.

### **Removing a Memory Stick media**

A small portion of the Memory Stick media remains extended when it is inserted into the Memory Stick media slot.

- 1. Press the extended portion of the Memory Stick media to release it from the Memory Stick slot. The media extends further, enabling you to grasp it.
- 2. Remove the Memory Stick media from the slot carefully.

#### Removing the Memory Stick Media




Do not remove the Memory Stick media while the media access indicator light is on. The media or its data may become damaged.

### **Protecting data on Memory Stick media**

Memory Stick media contain a write-protect tab. The write-protect tab prevents accidental changes to information recorded on your Memory Stick media. When you slide the write-protect tab to the LOCK position, your Memory Stick media is write-protected. You cannot delete, copy, or save information on the media while the write-protect tab in the LOCK position. When you slide the tab to the un-LOCK position, you can write to or modify your Memory Stick media's contents.

#### Locking the Memory Stick Media



# **Upgrading and Maintaining vour VAIO Computer**

In the future you may want to increase the functionality of your VAIO computer. This section describes how to perform basic upgrades and maintenance on your system. For more information on upgrading your computer, see your model's *System Reference Manual*. You can download the *System Reference Manual* from the Sony Web site at <a href="http://www.sony.com/pcsupport">http://www.sony.com/pcsupport</a>.

- Overview
- About Opening the System Unit
- About Add-on Card Installation
- Installing Memory
- About the Lithium Battery
- About Hard Disk Drive Installation

### **Overview**

The upgrading procedures described in this section assume that you are familiar with the general terminology associated with personal computers and with the safety practices and regulatory compliance required for using and modifying electronic equipment.

#### Before upgrading your computer

Disconnect the computer from its power source and from telecommunications links, networks, or modems before you open the unit or follow any procedures described in this section.



👃 Failure to disconnect your computer from its power source may result in personal injury or equipment damage.

Your computer may not be equipped with all of the hardware features mentioned in this section. The interior hardware configuration of your system may vary from the illustrations, depending on the computer purchased. To view the specific hardware configuration for your system, see the online specifications sheet.

🖾 You may need to temporarily remove add-on cards or other components that may be near the slot cover you plan to remove.

Electrostatic discharge (ESD) can damage disk drives, add-on cards, and other components. Follow the procedures described here only at an ESD workstation. If such a station is not available, do not work in a carpeted area and do not handle materials that produce or hold static electricity (for example, cellophane wrappers). Ground yourself by maintaining continuous contact with an unpainted metal portion of the chassis while performing the procedure.


Always turn the power off before you open the system or connect your computer to peripheral equipment. Otherwise, damage may occur to the integrated circuits in your computer.

### **About Opening the System Unit**

## Removing the side panel

- 1. Shut down your computer and turn off all peripheral devices, such as your printer.
- 2. Unplug your computer and disconnect any peripheral devices.
- 3. Place the system unit on its side.
- 4. Locate the two tabs on the back edge of the right side panel.
- 5. Press up on these tabs and slide the side panel towards you.
- 6. Lift the side panel up and set aside.

### Removing the side panel




If you remove the side panel immediately after you shut down your computer, the components may be too hot to touch. Wait until the internal parts of the system unit cool down before you attempt to remove the side panel.

### **About Opening the System Unit**

## Removing the side panel

- 1. Shut down your computer and turn off all peripheral devices, such as your printer.
- 2. Unplug your computer and disconnect any peripheral devices.
- 3. Place the system unit on its side.
- 4. Locate the two tabs on the back edge of the right side panel.
- 5. Press up on these tabs and slide the side panel towards you.
- 6. Lift the side panel up and set aside.

### Removing the side panel




If you remove the side panel immediately after you shut down your computer, the components may be too hot to touch. Wait until the internal parts of the system unit cool down before you attempt to remove the side panel.

### Replacing the side panel

- 1. Place the system unit on its side.
- $2. \hspace{0.5cm} \mbox{Align the tabs on the side panel to the tracks on the chassis frame.}$
- 3. Gently slide the side panel onto the chassis, until the tabs lock the panel into place.

### Replacing the side panel



### **About Add-on Card Installation**

Your computer may have one or more open expansion slots, depending on the model configuration. An expansion slot enables you to install add-on cards to expand the functionality of your system. The length of the add-on card should not exceed 9.05 inches.

Add-on card configuration varies by model. Some models, such as Configure-to-Order (CTO) systems, may contain preinstalled add-on cards.


Observe the proper safety precautions when you add cards to your Sony computer. See <u>Before upgrading your computer</u>.

### Installing an add-on card

- 1. Shut down your computer and turn off all peripheral devices, such as your printer.
- 2. Unplug your computer and any peripheral devices.
- 3. Remove the side panel. See <u>Removing the side panel</u>.
- 4. Locate an available expansion slot. Remove the slot cover's screw, and then remove the slot cover.


When removing a slot cover, be careful not to damage components on the system board or add-on cards. You may need to temporarily remove add-on cards or other components that may be next to the slot cover you want to remove.

#### Removing the slot cover



5. Install the add-on card by inserting it into the expansion slot and secure it with the screw from the expansion slot cover.

#### Installing an add-on card



- 6. Attach any internal cables that the card requires. See the instructions supplied with the add-on card.
- 7. Replace the side panel. See Replacing the side panel.

- $8.\,\,\,\,\,\,\,$  Reconnect the power cord and all peripheral devices.
- 9. Turn on the computer.

### **Installing Memory**

The amount of preinstalled memory may vary, depending on the system configuration you purchased. Your computer may ship with all available memory slots filled. For memory replacement or upgrades, use the correct memory module for your computer's configuration. See the online <u>Specifications</u> sheet for details about the amount of memory installed in your computer.

You can purchase additional memory modules, accessories, and peripheral equipment from your local retailer.


Observe the proper safety precautions when you add or remove the memory in your computer. See <a href="Before upgrading your computer">Before upgrading your computer</a>.

### **Removing a memory module**

- 1. Shut down your computer and turn off all peripheral devices, such as your printer.
- 2. Unplug your computer and all peripheral devices.
- 3. Remove the side panel. See <u>Removing the side panel</u>.
- 4. Gently place the unit on its side. If necessary, remove any cables, add-on cards, or other components to access the memory module slots.
- 5. Locate the memory module(s) you wish to remove.
- 6. Push down on the latches, located on both sides of the module, to gently eject it from the slot.
- 7. Grasp one edge of the module and lift it out. Store the module in a static-free bag.

Gently handle the memory module by the sides only. Avoid touching the pins located at the bottom edge of the module.

### Removing/Installing memory



#### **Installing a memory module**

- 1. Shut down your computer and turn off all peripheral devices, such as your printer.
- 2. Unplug your computer and any peripheral devices.
- 3. Remove the side panel. See <u>Removing the side panel</u>.
- 4. Gently place the unit on its side. If necessary, remove any cables, add-on cards, or other components to access the memory module slots.
- 5. Remove the memory module from its anti-static package, handling it by the the edges.
- 6. Locate the notch on the bottom edge of the module to align it over the open memory slot.
- 7. Firmly insert the bottom edge of the memory module into the slot.
- 8. Press down evenly against the module's upper corners. The end latches snap into position, holding the module in place.

To avoid damaging a memory module slot, move the end latches slightly outward to relieve pressure. The module clicks into place.

- 9. Reinstall any components or add-on cards you may have removed.
- 10. Replace the side panel. See Replacing the side panel.

### **About the Lithium Battery**


The lithium battery starts to weaken after several years and the system settings, such as the date and time stored in CMOS RAM, may become inaccurate. Replace the lithium battery when this occurs.

There is danger of the battery exploding if it is replaced incorrectly. Replace the battery only with a CR2032-type lithium battery.

### Replacing the lithium battery

- 1. Write down any changes you may have made to the settings in the BIOS Setup utility.
- 2. Shut down your computer and turn off all peripheral devices, such as your printer.
- 3. Unplug your computer and the peripheral devices.
- 4. Remove the side panel. See Removing the side panel.
- 5. If necessary, remove any cables, add-on cards, or other components to access the lithium battery.
- 6. Gently push the battery holder's tab away from the battery and remove the battery from the holder.
- 7. Install the new battery with the plus (+) side facing the battery holder tab.

#### Installing a lithium battery



8. Replace the side panel. See Replacing the side panel.

The values stored in the CMOS memory are now reset to the factory default values. Run the Setup utility to reset the date, time, passwords, and other changes you may have made to the BIOS settings. If you do not wish to customize your BIOS settings, do not run the Setup utility.

Dispose of the lithium battery properly. In some areas, the disposal of lithium batteries in household or business trash may be prohibited. You can return your unwanted lithium batteries to your nearest Sony Service Center or Factory Service Center. To locate a Service Center near you, visit the Sony Computing Support Web site at <a href="http://www.sony.com/pcsupport">http://www.sony.com/pcsupport</a>.

### Resetting the computer's date and time

To reset your computer's date and time:

- 1. Double-click the time readout displayed in the Windows® Taskbar Notification area. The Date and Time properties window appears.
- 2. From the Date & Time tab, change the settings as desired. Click **Apply**, and then click **OK**.

### **About Hard Disk Drive Installation**

Your computer comes with an available internal bay to hold a second standard 3½-inch hard disk drive. Some models, such as Configure-to-Order (CTO) systems, may already have a second hard disk drive installed. Your system can support ATA-33, ATA-66, or ATA-100 hard disk drives. Sony recommends using an ATA-100 hard disk drive to take full advantage of your system's features.

The hard disk drive access light blinks when either internal hard disk drive is active.

#### Replacing the original hard disk drive

If you replace the original, factory-installed hard disk drive, your system cannot restore the drive partitions, operating system, or original software, using the preinstalled Hard Drive Recovery utility.

The Hard Drive Recovery utility is a quick and easy-to-use program that can restore your system if it becomes unstable or stops working properly.

To enable you to recover your system with the VAIO Recovery utility, you can purchase a Partition Recovery CD Assembly (Partition Recovery ASSY) to restore your system.

Follow these steps to order the Partition Recovery CD Assembly:

- 1. Connect to the Internet.
- 2. Go to the Sony Direct Accessories and Parts Center Web site at <a href="http://servicesales.sel.sony.com">http://servicesales.sel.sony.com</a>.
- 3. In the section, **Search by Model for Accessories**, type in your computer model and click **List Parts and accessories**.
- 4. From the list of accessories, locate the Partition Recovery ASSY and click the option, Add to Cart.
- 5. Click **Continue to Check Out**, and follow the on-screen instructions to complete your purchase.

If you are not able to access the Sony Direct Accessories and Parts Center Web site, contact a customer service representative at 1-800-488-7669.

For more information about hard disk drive recovery:

- 1. Click **Start** in the Windows® taskbar, then click **Help and Support**.
- 2. From the VAIO Help And Support Center, click VAIO Recovery Options.

### **Using the Sony Computing Support Web site**

For detailed information about installing additional hard disk drives, see the *System Reference Manual*. You can download the *System Reference Manual* from the Sony Computing Support Web site at: <a href="http://www.sony.com/pcsupport">http://www.sony.com/pcsupport</a>.

May Your computer must be connected to the Internet to access the Sony Computing Support Web site.

From the Sony support Web site:


- 1. Click on **Computers & Peripherals,** and then click to select the appropriate model series from the submenu.
- 2. Click the link for your computer model number. The model-specific support page appears.
- 3. Under Documentation, click System Reference Manual or System Reference Guide.

Observe the proper safety precautions when you upgrade your Sony computer. See <u>Before upgrading your computer</u>.

### Installing an additional hard disk drive


- 1. Shut down your computer and turn off all peripheral devices, such as your printer.
- 2. Unplug your computer and any peripheral devices.
- 3. Remove the side panel. See <u>Removing the side panel</u>.
- 4. Configure the jumpers on the new drive as a slave. See the configuration instructions supplied with your drive.
- 5. Detach the power and drive cables from the original hard disk drive that is preinstalled in your computer.
- 6. Unlock the drive holder from the chassis by pulling the drive holder tab up at a slight angle.
- 7. Slide the drive holder out.

#### Removing the drive holder



- 8. Slide the new drive into the drive holder and align the holes on each side of the drive bay.
- 9. Secure the drive to the drive holder with screws, through the holes on each side of the drive holder.

### Attaching the drive screws




Your new hard disk drive is supplied with the necessary screws. Do not overtighten these screws when securing the drive to the drive holder.

10. Align the drive holder with the tracks on the inside of the chassis. Slide the drive holder in completely.

- 11. Push down on the drive holder tab to lock the drive into position.
- 12. Connect the second drive connector to the new drive. Orient the connector to align pin 1 on the red side of the ribbon cable with pin 1 on the new drive.
- 13. Connect the second power connector to the new drive following the instructions supplied with the drive.

### Replacing the drive holder



- 14. Replace the side panel. See <u>Replacing the side panel</u>.
- 15. Reconnect the power cord to your computer.

### Identifying the additional hard disk space

When you initialize the new hard disk, it must be configured as an extended partition in Windows NT file system (NTFS) format.

- 1. Log on to Windows® as Administrator.
- 2. Click **Start** in the Windows taskbar, then right-click **My Computer**. A shortcut menu appears.
- 3. Select **Manage**. The Computer Management window appears.
- 4. Under the file directory on the right, go to Storage and then select Disk Management.
- 5. Right-click on the newly installed, unformatted hard disk (Disk label identified with red marking). From the shortcut menu, select **Initialize Disk**.
- 6. Click on the Unallocated area of the disk and then right-click to display a shortcut menu.
- 7. Select **New Partition**. The New Partition wizard appears.
- 8. Follow the wizard's on-screen instructions to complete the process.

The Windows® XP operating system recognizes the new hard disk drive and applies the NTFS format.

# **Troubleshooting**

This section describes how to troubleshoot common problems. You can also find helpful information on how to use your computer's hardware features and preinstalled software. Your computer may not be equipped with all of the features or software discussed in this section, depending on the system configuration purchased.

- About VAIO Computer Functions
- About Using the Optical Disc Drive(s)
- About the Mouse and Keyboard
- About the Modem
- About the Speakers
- About Using a Microphone
- About Using Peripheral Equipment

### **About VAIO Computer Functions**

#### My computer does not start.

- Verify that the computer is plugged into a power source and that it is turned on. Check that the power indicator is lit on the front panel of the computer.
- Confirm that a disk is not in the floppy disk drive. (unless you are using a bootable floppy disk).
- Confirm that a CD is not in an optical drive (unless you are using a bootable CD).
- Confirm that the power cord and all cables are connected firmly.
- If you plugged the computer into a power strip or Uninterruptible Power Supply (UPS), make sure the power strip or UPS is turned on and working.
  - Verify that the monitor is plugged into a power source and turned on.
  - If your system has a built-in monitor, confirm that it is plugged into an appropriate power source and that the system is turned on.
- Verify that the brightness or contrast control dials are adjusted correctly. (See the manual that came with your display for details.)
- Confirm that the computer is not in stand by mode by pressing any key on the keyboard.
- \*Certain VAIO computers are not equipped with a floppy disk drive. You can purchase this equipment separately.

## **About VAIO Computer Functions**

### My computer does not start.

- Verify that the computer is plugged into a power source and that it is turned on. Check that the power indicator is lit on the front panel of the computer.
- Confirm that a disk is not in the floppy disk drive (unless you are using a bootable floppy disk).
- Confirm that a CD is not in an optical drive (unless you are using a bootable CD).
- Confirm that the power cord and all cables are connected firmly.
- If you plugged the computer into a power strip or Uninterruptible Power Supply (UPS), make sure the power strip or UPS is turned on and working.
  - Verify that the monitor is plugged into a power source and turned on.
  - If your system has a built-in monitor, confirm that it is plugged into an appropriate power source and that the system is turned on.
- Verify that the brightness or contrast control dials are adjusted correctly. (See the manual that came with your display for details.)
- Confirm that the computer is not in stand by mode by pressing any key on the keyboard.
- \*Certain VAIO computers are not equipped with a floppy disk drive. You can purchase this equipment separately.

### Why did my computer or software stop responding?

You can try to locate and close the software application that has stopped responding.

- 1. Press the **Ctrl+Alt+Delete** keys. The Windows Task Manager window appears.
- 2. From the Applications tab, locate the application that has the status message, "Not responding."
- 3. Select the application that has a **Not Responding** status and click **End Task**. Windows attempts to close the application.

If your computer does not respond or the application does not close, try the following steps:

- 1. Save any open files, if possible.
- 2. Press the **Alt+F4** keys. The Turn Off Computer window appears.
- 3. Click **Restart**.

If your computer still does not respond and you cannot restart, shut down your computer by pressing and holding the power button for more than six seconds.

If the software application continues to stop responding or causes your computer to stop responding, contact the software publisher or designated technical support provider.

Pressing and holding the power button for more than six seconds, may result in the loss of data from files that are currently open.

## Why does the Windows operating system stop responding during shutdown?

The Windows operating system may not shut down properly for many reasons, including incompatible or conflicting drivers, damaged files, or non-responsive hardware. For troubleshooting information, you can search Windows Help.

- 1. Click **Start** in the Windows taskbar and select **Help and Support**. The **VAIO Help And Support Center** menu appears.
- 2. Select **Fixing a Problem** and then select **Startup and Shut Down problems**. A list of specific problem topics appears on the right side of the dialog box.
- 3. Select **Startup and Shutdown Troubleshooter**. Follow the on-screen instructions according to your specific situation.

## Why is my system running slowly?

- The system responsiveness varies depending with the number of applications that are open and running. Close any applications that you are not currently using.
- Increasing the system memory may also help. For information on installing memory, please see the online VAIO User Guide.

To access the online User Guide:

- 1. Click **Start** in the Windows taskbar, and then click **Help and Support**.
- 2. From the VAIO Help And Support Center menu, click VAIO User Guide.

## How do I change the video resolution of my display?

- 1. Click **Start** in the Windows taskbar, and then select **Control Panel**.
- 2. Select **Appearance and Themes**, and then select **Change the screen resolution**.
- 3. Click the **Settings** tab.
- 4. Change the Screen resolution and Color quality to the desired levels.
- 5. Click **Apply** and then click **OK**.

## **About Giga Pocket Personal Video Recorder**

This section describes how to troubleshoot common problems you may encounter when using Giga Pocket Personal Video Recorder functions. Many problems have simple solutions, so try these suggestions before you contact Sony Customer Support.

## Why can't I see an image or an image that is displayed properly when I am using a VCR?

Some images from an externally-connected video player device or a video game console, may not display or are not displayed correctly. These images include:

- Images from a playback screen that is in pause mode.
- Menu screens of the connected video player device.
- The end of the film roll being played back using the scroll bar.
- Video output from a video game console.
- Video output from a VCR, using a coaxial cable.

Giga Pocket cannot record or display all video images from this source.

# Why does my Giga Pocket viewing window or the images played back from a Video Capsule, appear distorted or corrupted?

There are some situations where screen or image distortion may occur, such as:

- When you change the channel on the video player device.
- If there is a damaged section on your video tape.

When using Giga Pocket Personal Video Recorder, set your display settings as follows:

- **Colors**—Use the default factory settings (32-bit).
- Screen area—Set your video resolution to 1024 x 768 pixels.

If you use other settings, you may experience poor image quality on your display.

## Why does my system seem to slow down when I play a Video Capsule?

Your computer may respond slower if you try to play back a Video Capsule while recording a TV program with Giga Pocket. During a timer recording, Giga Pocket may interrupt or stop your Video Capsule playback to prioritize your computer's resources for the timer recording. If this occurs, wait until the timer recording session has completed, and then play back the Video Capsule.

## Why did I get the error message, "Event buffer of audio overflow?"

The timer recording may fail in certain situations, such as:

- The coaxial cable (input) is disconnected after recording has started.
- The TV channel has lost broadcast signal during the recording session.
- Video content being recorded has poor signal quality.

## Why did my on-screen display shift or split?

Your on-screen display may shift or split in rare instances. If this should occur, switch the TV/Recording deck and the playback deck, or try switching the channel. Your timer recording continues even if the on-screen display has shifted or split.

## Why did Giga Pocket stop allowing me to create new Video Capsules?

You cannot create a new Video Capsule when the remaining free space on your hard disk drive reaches approximately 100 MB. Delete any unnecessary Video Capsules or files to increase the free space on your hard drive.

## **About Using the Optical Disc Drive(s)**

Your computer may not be equipped with all of the hardware features listed in this section. To view the specific hardware configuration for your system, see the online specifications sheet.

## Why doesn't my optical drive tray open?

### To use the Eject button

- 1. Make sure the computer is turned on.
- 2. Press the Eject button on the drive.

### To use the My Computer icon

- 1. Click **Start** in the Windows taskbar, then select **My Computer**.
- 2. Right-click the appropriate optical drive icon.
- 3. Select **Eject** from the shortcut menu.

Avoid using adhesive labels to identify your CD or DVD media. Adhesive labels may come off while the CD or DVD media is in use in your optical drive(s) and may cause damage to the unit.

### Why can't I play a DVD or CD media?

- After inserting your CD or DVD, wait a few seconds for the system to detect it before trying to access it.
- Confirm that the disc is in the tray with the label side facing up.
- Install your CD or DVD software according to the manufacturer's instructions.
- If your drive reads some DVDs or CDs, but not others, check the shiny side of the disc for dirt or scratches.
- The preinstalled CD or DVD software may not be working properly. To recover this software, see the online guide, *VAIO Recovery Options*, for more information.

To access VAIO Recovery Options, follow these steps:

- 1. Click **Start** in the Windows® taskbar and click **Help and Support**.
- 2. From the VAIO Help And Support Center menu, click VAIO Recovery Options.

#### Why isn't my DVD playing properly?

- If a region code warning appears when you are using the DVD player application, it may be that the region code of the DVD you are trying to play is incompatible with the region code setting of your optical drive. A region code is listed on the disc packaging. Region code indicators such as "1" or "ALL" are labeled on some DVDs to indicate the type of player that can play the disc. Unless a "1" or "ALL" appears on the DVD or on its packaging, you cannot play the disc on this system.
- If you hear audio but cannot see video, your computer's video resolution may be set too high. To improve video resolution, verify that your screen area is set to 1024 x 768½, using 32-bit color (preset factory default). To verify or change your video resolution:
  - 1. Click **Start** in the Windows taskbar and then select **Control Panel**.
  - 2. Select Appearance and Themes, then select Change the screen resolution.
  - 3. Click the **Settings** tab.
  - 4. Change the Screen resolution and Color quality to the desired levels.
  - 5. Click **Apply** and then click **OK**.
  - If you see video but cannot hear audio, check all of the following:
    - 1. Verify that your DVD player's mute feature is turned off.
    - 2. Check the master volume setting in the Audio Mixer.
    - 3. Check the volume settings on your computer speakers.
    - 4. Check the connections between your speakers and the computer.
    - 5. Verify that drivers are installed properly, by following these steps:
      - 1. Click **Start** in the Windows taskbar, then select **Control Panel**.
      - Click Performance and Maintenance and then click Systems. The System Properties dialog box appears.
      - 3. Select the **Hardware** tab and then select the **Device Manager** button to view installed drivers.
- A dirty or damaged disc may also cause the computer to stop responding while it tries to read the disc. If necessary, remove the disc and check that it is not dirty or damaged.
- The preinstalled CD or DVD software may not be working properly. To recover this software, see the online guide, VAIO Recovery Options, for more information.

To access VAIO Recovery Options, follow these steps:

- 1. Click **Start** in the Windows® taskbar and click **Help and Support**.
- 2. From the VAIO Help And Support Center menu, click VAIO Recovery Options.

 ${ t 1}$  The VAIO "W" series computer uses 1280 x 768 for the default video resolution setting.

## Why doesn't my mouse work properly?

- Confirm that the mouse is plugged securely into the mouse port. If you are using a USB mouse, verify that the
  mouse is plugged securely into the appropriate USB port.
- Save and close all open applications. Turn off your computer, wait approximately 10 seconds, and then restart your computer.
- If you are using an optical mouse, use an appropriate surface to ensure proper mouse tracking. A good mouse surface requires a certain amount of detail or texture to enable mouse tracking.
  - Use surfaces such as plain paper, card stock, or fabric that do not have a lot of repetitive patterning.
  - Avoid surfaces such as mirrors, smooth glass, or magazines.
  - Avoid possible damage to easily-scratched surfaces by using a mouse pad.
  - Avoid surfaces that may damage or soil your optical mouse. Dirt or damage may cause the mouse to malfunction.
  - If the cursor is not moving properly, try using the mouse on another mousing surface or using a mouse pad.
  - If you are using a trackball mouse, there may be dust or dirt inside the mouse mechanism. To clean the mouse, follow these steps:
  - Save and close all applications, and turn off your computer.
  - Turn the mouse upside down.
  - Remove the mouse ball cover on the back of the mouse by turning clockwise the ring that covers the mouse ball.
  - Turn the mouse upright, and drop the mouse ball into your hand.
  - Using a piece of tape, remove any dust or dirt on the mouse ball and inside the mouse ball socket.
  - Return the mouse ball to the socket, and replace the mouse ball cover. Secure the cover by turning the ring counter-clockwise.
  - The mouse driver(s) may not be working properly. To recover your mouse drivers, see the online guide, *VAIO Recovery Options*, for more information.

To access VAIO Recovery Options, follow these steps:

- Click Start in the Windows® taskbar and click Help and Support.
- From the VAIO Help And Support Center menu, click VAIO Recovery Options.

## Why doesn't my mouse work properly?

- Confirm that the mouse is plugged securely into the mouse port. If you are using a USB mouse, verify that the
  mouse is plugged securely into the appropriate USB port.
- Save and close all open applications. Turn off your computer, wait approximately 10 seconds, and then restart your computer.
- If you are using an optical mouse, use an appropriate surface to ensure proper mouse tracking. A good mouse surface requires a certain amount of detail or texture to enable mouse tracking.
  - Use surfaces such as plain paper, card stock, or fabric that do not have a lot of repetitive patterning.
  - Avoid surfaces such as mirrors, smooth glass, or magazines.
  - Avoid possible damage to easily-scratched surfaces by using a mouse pad.
  - Avoid surfaces that may damage or soil your optical mouse. Dirt or damage may cause the mouse to malfunction.
  - If the cursor is not moving properly, try using the mouse on another mousing surface or using a mouse pad.
  - If you are using a trackball mouse, there may be dust or dirt inside the mouse mechanism. To clean the mouse, follow these steps:
  - Save and close all applications, and turn off your computer.
  - Turn the mouse upside down.
  - Remove the mouse ball cover on the back of the mouse by turning clockwise the ring that covers the mouse ball.
  - Turn the mouse upright, and drop the mouse ball into your hand.
  - Using a piece of tape, remove any dust or dirt on the mouse ball and inside the mouse ball socket.
  - Return the mouse ball to the socket, and replace the mouse ball cover. Secure the cover by turning the ring counter-clockwise.
  - The mouse driver(s) may not be working properly. To recover your mouse drivers, see the online guide, *VAIO Recovery Options*, for more information.

To access VAIO Recovery Options, follow these steps:

- Click Start in the Windows® taskbar and click Help and Support.
- From the VAIO Help And Support Center menu, click VAIO Recovery Options.

## How do I set up my mouse for left-hand use?

- 1. Click **Start** in the Windows taskbar, then click **Control Panel**.
- 2. Click **Printers and Other Hardware**, then click **Mouse**. The Mouse Properties dialog box appears.
- 3. From the **Buttons** tab, select **Switch primary and secondary buttons** under the Button Configuration options.
- 4. Click **Apply**, then click **OK**.

## Why doesn't my keyboard work properly?

- Check that the keyboard is securely plugged into the keyboard port.
- Save and close all open applications. Turn off your computer, wait approximately 10 seconds, and then restart your computer.
- ¹The VAIO "W" series computer has a built-in keyboard.

### Why is my modem connection slow?

Many factors can influence modem connection speed, such as:

- Telephone line noise.
- Incompatibility with other telephone equipment such as fax machines or other modems.
- Internet Service Providers (ISP) connection capability may vary.

If you think your modem is not connecting properly to other PC-based modems, fax machines, or your ISP, check the following:

- Contact your telephone company and ask them to verify that your telephone line is free from line noise.
- If your problem is fax-related, check that there are no problems with the fax machine you are calling and that it is compatible with fax modems.
- For optimum performance, verify that your ISP point of presence (POP) telephone number is compliant with V.90 standards.
- If you are having a problem connecting with your ISP, check that they are not experiencing technical problems.
- Try connecting your modem through another telephone line, if available.

### Why is my modem connection slow?

Many factors can influence modem connection speed, such as:

- Telephone line noise.
- Incompatibility with other telephone equipment such as fax machines or other modems.
- Internet Service Providers (ISP) connection capability may vary.

If you think your modem is not connecting properly to other PC-based modems, fax machines, or your ISP, check the following:

- Contact your telephone company and ask them to verify that your telephone line is free from line noise.
- If your problem is fax-related, check that there are no problems with the fax machine you are calling and that it is compatible with fax modems.
- For optimum performance, verify that your ISP point of presence (POP) telephone number is compliant with V.90 standards.
- If you are having a problem connecting with your ISP, check that they are not experiencing technical problems.
- Try connecting your modem through another telephone line, if available.

#### Why doesn't my modem work properly?

Your modem may be experiencing equipment or software conflicts. If your modem is not functioning properly, check the following:

- Check that the telephone line is plugged into the modem line jack.
- Check that the telephone line is working properly. You can verify the line by plugging in an external device such as a standard telephone or fax machine and listening for a dial tone.
- Check that the access telephone number (POP) is correct.
- All software applications that are preinstalled by Sony are compatible with your computer's modem. If you have installed other software, contact the software publisher for information on how to configure the software in order to recognize the modem.
  - If it appears that your modem is not functioning properly, check the device status.
    - 1. Click **Start** in the Windows taskbar, then click **Control Panel**.
    - 2. Click **Printers and Other Hardware** and then select **Phone and Modem Options**.
    - 3. From the **Modems** tab, click to select your modem.
    - 4. Click **Properties**. The Modem Properties window appears.
    - 5. Review the information in the Device status section. If your modem is not working properly, click the **Troubleshoot** button. The VAIO Help and Support Center window appears.
    - 6. Follow the on-screen instructions to resolve the problem.
- The modem driver(s) may not be working properly. To recover your modem drivers, see the online guide, VAIO Recovery Options, for more information.

To access VAIO Recovery Options, follow these steps:

- 1. Click **Start** in the Windows® taskbar and click **Help and Support**.
- 2. From the VAIO Help And Support Center menu, click VAIO Recovery Options.

## How do I change my modem to rotary or Touch-tone dialing?

- 1. Click **Start** in the Windows taskbar, then click **Control Panel**.
- 2. Click **Printers and Other Hardware**, then click **Phone and Modem options**.
- 3. From the **Dialing Rules** tab, click **Edit**. The Edit Location dialog box appears.
- 4. Select the **Tone** or **Pulse** option. Click **OK**.

## Why is there no sound in any application?

- Check that the speakers are plugged into the Headphones jack.
- If your speakers have a mute button, verify that it is turned off.
- If your speakers are powered by batteries, verify that the batteries are inserted properly and that they are charged.
- If your speakers use an external power source, verify that the power cord is plugged into a grounded wall outlet or power strip.
- If your speakers have volume control, check the volume level.
- You cannot hear sound from your speakers if headphones are connected to your computer.
- If the software application you are using has its own volume control, check that the volume is turned up.
  - Check the volume controls in the Windows® operating system using these steps:
    - 1. Click **Start** in the Windows taskbar, then select **Control Panel**.
    - 2. Select Sounds, Speech, and Audio Devices, then click Adjust the system volume.
    - 3. From the **Volume** tab, adjust the Device volume by moving the slider bar to the desired sound level. Verify that the Mute option is not selected.
  - Check that the Mute check box is not selected in the Windows volume control.
- The sound driver(s) may not be working properly. To recover your sound drivers, see the online guide, *VAIO Recovery Options*, for more information.

To access VAIO Recovery Options, follow these steps:

- 1. Click **Start** in the Windows® taskbar and click **Help and Support**.
- 2. From the VAIO Help And Support Center menu, click VAIO Recovery Options.

### For PCV-W series models only

- Adjust the volume control dial, located on the left panel, to adjust speaker volume.
- The speakers continue to produce sound even when headphones have been connected. If you want to use your own headphones instead of the supplied speakers, adjust the volume control dial, located on the left panel, to mute the sound from the built-in stereo speakers.

## Why is there no sound in any application?

- Check that the speakers are plugged into the Headphones jack.
- If your speakers have a mute button, verify that it is turned off.
- If your speakers are powered by batteries, verify that the batteries are inserted properly and that they are charged.
- If your speakers use an external power source, verify that the power cord is plugged into a grounded wall outlet or power strip.
- If your speakers have volume control, check the volume level.
- You cannot hear sound from your speakers if headphones are connected to your computer.
- If the software application you are using has its own volume control, check that the volume is turned up.
  - Check the volume controls in the Windows® operating system using these steps:
    - 1. Click **Start** in the Windows taskbar, then select **Control Panel**.
    - 2. Select Sounds, Speech, and Audio Devices, then click Adjust the system volume.
    - 3. From the **Volume** tab, adjust the Device volume by moving the slider bar to the desired sound level. Verify that the Mute option is not selected.
  - Check that the Mute check box is not selected in the Windows volume control.
- The sound driver(s) may not be working properly. To recover your sound drivers, see the online guide, *VAIO Recovery Options*, for more information.

To access VAIO Recovery Options, follow these steps:

- 1. Click **Start** in the Windows® taskbar and click **Help and Support**.
- 2. From the VAIO Help And Support Center menu, click VAIO Recovery Options.

### For PCV-W series models only

- Adjust the volume control dial, located on the left panel, to adjust speaker volume.
- The speakers continue to produce sound even when headphones have been connected. If you want to use your own headphones instead of the supplied speakers, adjust the volume control dial, located on the left panel, to mute the sound from the built-in stereo speakers.

## **About Using a Microphone**

## Why doesn't my microphone work properly?

Check that the microphone is plugged into the Microphone jack.

## **About Using a Microphone**

## Why doesn't my microphone work properly?

Check that the microphone is plugged into the Microphone jack.

### Why is my microphone so sensitive to background noise?

If you find there is too much background noise when you record sound, you should adjust the microphone by following these steps:

- 1. Click **Start** in the Windows taskbar, then click **Control Panel**.
- 2. Click Sounds, Speech, and Audio Devices, then click Sounds and Audio Devices.
- 3. From the **Audio** tab, locate the **Sound recording** section and click **Volume**. The **Recording Control** dialog box appears.
  - If the volume control for the microphone is visible, skip to step 6.
- 4. Select the **Options** menu and click **Properties**. The **Properties** dialog box appears.
- 5. In the section, **Show the following volume controls**, select the **Recording** option. Click **OK**.
- 6. From the **Recording Control** dialog box, decrease the microphone volume level by moving the slider bar down.
- 7. Close the Recording Control dialog box and then close the Sounds and Audio Devices Properties window.

### How do I install a printer?

- Connect your USB or IEEE 1394 printer to the appropriate port on your computer's front, back or side panels. If
  your printer has a USB, IEEE 1394, or infrared connection, contact the printer manufacturer for information or
  updates that may be required for proper installation.
- Check the printer manufacturer's Web site for the latest drivers for your operating system before proceeding with installation. Some printers do not function properly without the updated drivers for specific operating systems.
- To install your printer, follow these steps:
  - 1. Click **Start** in the Windows taskbar, then click **Control Panel**.
  - 2. Click **Printers and Other Hardware**, then click **Add a Printer**.
  - 3. From the Add Printer Wizard, click Next.
  - 4. Select **Local Printer**, then click **Next**.

Place a check mark in the box for "Automatically detect and install my Plug and Play printer", if you are installing a recently manufactured printer with Plug and Play capability.

- 5. Select the appropriate port, usually LPT1, and then click **Next**.
- 6. Select the appropriate printer manufacturer and model.
- 7. Follow the on-screen instructions to print a test page and complete printer installation.

If the printer is not included in the list and the printer manufacturer included a disk with a Windows XP Printer driver, choose **Have Disk**, enter the appropriate path for the disk or CD and click **OK**.

If the printer is not included on the list and no drivers are included with the printer, choose an alternate printer driver that your printer may emulate. Refer to the manual that came with your printer for specific emulation information.

1 The location of the connection ports for peripheral equipment may vary, depending upon your computer's hardware configuration.

### How do I install a printer?

- Connect your USB or IEEE 1394 printer to the appropriate port on your computer's front, back or side panels. If your printer has a USB, IEEE 1394, or infrared connection, contact the printer manufacturer for information or updates that may be required for proper installation.
- Check the printer manufacturer's Web site for the latest drivers for your operating system before proceeding with installation. Some printers do not function properly without the updated drivers for specific operating systems.
- To install your printer, follow these steps:
  - 1. Click **Start** in the Windows taskbar, then click **Control Panel**.
  - 2. Click **Printers and Other Hardware**, then click **Add a Printer**.
  - 3. From the **Add Printer Wizard**, click **Next**.
  - 4. Select **Local Printer**, then click **Next**.

Place a check mark in the box for "Automatically detect and install my Plug and Play printer", if you are installing a recently manufactured printer with Plug and Play capability.

- 5. Select the appropriate port, usually LPT1, and then click **Next**.
- 6. Select the appropriate printer manufacturer and model.
- 7. Follow the on-screen instructions to print a test page and complete printer installation.

If the printer is not included in the list and the printer manufacturer included a disk with a Windows XP Printer driver, choose **Have Disk**, enter the appropriate path for the disk or CD and click **OK**.

If the printer is not included on the list and no drivers are included with the printer, choose an alternate printer driver that your printer may emulate. Refer to the manual that came with your printer for specific emulation information.

1 The location of the connection ports for peripheral equipment may vary, depending upon your computer's hardware configuration.

								•		
The connected	nrinter	does not	tunction	nroneriy	, when the	compute	r recumes t	trom a	nower saving	ı mode
THE COMMECTE	Pillice '	aocs not	IUIICUOII	PIOPCII	, will the	compute	i i coullico i	ii Oiii u	power saving	, illouc.

- Clear the printer memory by turning the printer off for approximately 10 seconds, and then turning it back on.
- If your printer does not resume normal operations, try restarting your computer.

## **Notes On Use**

The information in this section provides basic procedures for handling your system and common peripheral devices, and using storage media.

- About the Power Source
- About Disposing of the Lithium Battery
- About Handling the Computer System
- About Handling a Monitor (Display)
- About Recording and Data Storage Media

### **About the Power Source**

Before opening your computer, turn the system off and let it cool down for 10 minutes. This protects you against internal components that may be too hot to handle.

- Your computer operates on 100-120 V AC 50/60 Hz only.
- Plug all the power cords for your computer and its peripheral equipment into the same AC supply line. AC derived
  from different supply lines may result in voltage differences that can cause unstable operation or unwanted weak
  currents at the time of connection.
- Do not share the AC outlet with any other power-consuming equipment, such as copying machines or shredders.
- You can purchase a power strip with a surge protector. This device prevents damage to your computer caused by sudden power surges such as those that may occur during an electrical storm.
- If you live in an area that experiences frequent power fluctuations, you may want to purchase an Uninterruptible Power Supply (UPS). This device contains both a surge protector and a battery backup. The surge protector prevents damage to your computer caused by power surges. The battery backup safeguards your data during a brief period of power loss.
- The power control button on the front panel does not turn off the system AC power. To remove power from the system, you must turn off the computer and then unplug the AC power cord from the wall outlet or power strip.
- Do not place heavy objects on the power cord.
- Do not operate the system with the cover removed. Always reinstall the cover before turning on the system.
- To disconnect the cord, pull it out by the plug. Never pull the cord itself.
- Unplug your computer from the wall outlet if you do not intend to use the computer for a long time.
- Do not attempt to open the power supply. There are no user-serviceable parts in the power supply. To avoid
  personal injury or damage to your equipment, refer the repair or replacement of the power supply to qualified
  personnel only.

### **About Giga Pocket Personal Video Recorder**

The information in this section provides guidelines to follow when using Giga Pocket Personal Video Recorder.

#### Display setup

Always set up your display as follows when you use Giga Pocket:

- Color quality: Use factory default settings (32-bit).
- Screen resolution: Set to 1024 x 768 pixels. Using other display settings may cause an improper screen image or an incorrect recording by Giga Pocket software.

Some displays may require the screen resolution to be set to 1280 x 1024 pixels. For information on your display's setting requirement, see the instructions supplied with your display.

- Check your display setup in the Microsoft® Windows® operating system before starting up Giga Pocket software. For more information, refer to the operating system manual.
- Do not change the display setup while Giga Pocket is running, or your system may operate improperly.

#### Hard disk drive

- When the available free space on your hard disk approaches 100 MB, you are not able to create a new Video
  Capsule. Delete unnecessary Video Capsules or files in order to increase available space on your hard disk drive.
- If you directly delete, move, or rename a file in the D:\Giga Pocket folder, Giga Pocket Personal Video Recorder features may not work properly.

#### **Network**

- Microsoft® Windows® XP operating system supports a single Giga Pocket user at any given time. Even if a different user logs on using the fast switch feature, Giga Pocket is not available to any other user account. For more information, see the Giga Pocket Help.
- Microsoft Windows XP operating system supports a single Giga Pocket user at any given time. If a different user logs on using the fast switch feature, the Timer Recording feature is not available to another user account. The Timer Recording Manager icon appears in the task tray of the 1st user to log on.

## **About Disposing of the Lithium Battery**

Dispose of the lithium battery properly. In some areas, the disposal of lithium batteries in household or business trash may be prohibited. You can return your unwanted lithium batteries to your nearest Sony Service Center or Factory Service Center. For the Sony Service Center nearest you, visit the Sony Computing Support Web site at <a href="http://www.sony.com/pcsupport">http://www.sony.com/pcsupport</a>.

Do not handle damaged or leaking lithium batteries. The lithium battery may explode if mistreated. Do not disassemble it or dispose of it in fire.

Replace the battery with a Sony CR2032 lithium battery. Using a type of battery other than a CR2032 may present a risk of fire or explosion.

### About Handling the Computer System

Your computer uses high-frequency radio signals and may cause interference to radio or TV reception. If this occurs, relocate the computer a suitable distance away from the TV or radio equipment.

- Do not place your Sony computer in a location subject to:
- Heat sources, such as radiators or air ducts
- Direct sunlight
- Excessive dust
- Mechanical vibration or shock
- Strong magnets or speakers that are not magnetically shielded
- Ambient temperature of more than 95°F (35°C) or less than 50°F (10°C)
- High humidity, moisture, or rain
- Do not place electronic equipment near your computer. The computer's electromagnetic field may cause a malfunction.
- Provide adequate air circulation to prevent internal heat build-up. Do not place your computer on loose surfaces (such as rugs or blankets) or near materials (such as curtains or draperies) that may block its ventilation slots. Leave a space of at least 8 inches from the back panel of your computer.
- Clean the cabinet with a soft, dry cloth or a soft cloth lightly moistened with a mild detergent solution. Do not use any type of abrasive pad, scouring powder, or solvent such as alcohol or benzine, as it may damage the finish of your Sony computer.
- Should any solid object or liquid fall into the cabinet, keyboard, or mouse, shut down your computer and then unplug it. You may want to have the computer checked by qualified personnel before operating it any further.
- Use only specified peripheral equipment and interface cables; otherwise, problems may result.
- Do not use cut or damaged connection cables.
- Always switch the power off before connecting your computer to peripheral equipment; otherwise, damage may
  occur to the integrated circuits in your computer.
- Your computer, keyboard, and mouse consist of high-precision electronic parts. Do not drop them or bump them against other objects.
- Your Sony computer does not work with party lines, cannot be connected to a coin-operated telephone, and may not work with multiple telephone lines or a private branch exchange (PBX).
- If the telephone company makes a service call to your home or office and determines that your computer is responsible for the problem, the telephone company may bill you for the service call. If you do not disconnect your computer when it is adversely affecting the telephone line, the telephone company has the right to disconnect your service until you correct the problem.

#### **Moisture condensation**

If your computer is brought directly from a cold location to a warm one, moisture may condense inside your computer. In this case, allow at least an hour before turning on your computer. If any problem occurs, unplug your computer, and contact your Sony Service Center.

#### The hard disk drive

- Do not place the computer in a location that is subject to vibration or shock.
- Do not move the computer during operation.
- Do not subject the computer to sudden changes in temperature.
- Do not turn off the power while the computer is accessing the hard disk drive.

### **About Handling a Monitor (Display)**

- DVD playback and certain video-related software may not function correctly when your monitor is set to a high refresh rate. If your monitor does not play back video content properly, try setting the display to a lower refresh rate.
- Do not place the display near a strong magnetic force.
- Do not block the ventilation slots on the display.
- Using the computer in low temperature conditions may produce a residual image on the screen. This is not a malfunction. When the computer returns to normal temperature, the screen returns to normal.
- A residual image may appear on the screen if the same image is displayed for a lengthy period of time. The image
  disappears after a period of time. You can use a screen saver to prevent residual images.
- The screen becomes warm during operation. This is normal and does not indicate a malfunction.

### About handling an LCD monitor (display)

- Do not place the display near a strong magnetic force.
- Do not block the ventilation slots on the display.
- Using the computer in low temperature conditions may produce a residual image on the screen. This is not a malfunction. When the computer returns to normal temperature, the screen returns to normal.
- A residual image may appear on the screen if the same image is displayed for a lengthy period of time. The image disappears after a period of time. You can use a screen saver to prevent residual images.
- The screen becomes warm during operation. This is normal and does not indicate a malfunction.
- Do not leave the LCD in direct sunlight, as this may damage the screen. Use caution when using the computer near
  a window.
- Do not exert pressure on the LCD or scratch the surface, as this may cause the screen to malfunction.
- The LCD screen is manufactured using high-precision technology. On occasion, you may see tiny black or colored points on the LCD. This is normal and does not indicate a malfunction.
- Avoid rubbing the screen, as this can damage the LCD. Use a soft, dry cloth to clean the display.
- <sup>1</sup>The PCV-W series models have a built-in LCD monitor

### **About Recording and Data Storage Media**

#### Handling CD or DVD media

- Do not touch the surface of the disc.
- Do not drop or bend the disc.
- Do not use adhesive labels to identify the disc. The label may come off while the disc is in use in the optical drive and damage the drive.

### Cleaning CD or DVD media

- Fingerprints and dust on the surface of a disc may cause read errors. Proper care of the disc is essential to maintain its integrity. Do not use solvents such as benzine, thinner, commercially available cleaners or anti-static spray, as they may cause damage to the disc.
- For normal cleaning, hold the disc by its edge and use a soft cloth to wipe the surface from the center out.
- If the disc is badly soiled, moisten a soft cloth with water, wring it out well, and use it to wipe the surface of the disc from the center out. Wipe off any remaining moisture with a dry soft cloth.

### **Using Memory Stick media**

- MagicGate Memory Stick and Memory Stick PRO media are the only media that support MagicGate technology. Currently, Sony® SonicStage and OpenMG software are not compatible with the new Memory Stick PRO media. Sony suggests using only the MagicGate Memory Stick media to store and transfer any data created with SonicStage and OpenMG software.
- Currently, the Memory Stick slot on VAIO® computers does not support the high-speed data transfer or access control features of the new Memory Stick PRO media.
- Visit the Customer Support Web site at <a href="http://www.sony.com/pcsupport">http://www.sony.com/pcsupport</a> regularly for the latest information on the new Memory Stick PRO media.

### Handling floppy disks1

- Do not open the shutter manually and touch the surface of the floppy disk.
- Keep floppy disks away from magnets.
- Keep floppy disks away from direct sunlight and other heat sources.
- 1 The VAIO "W" series computer is not equipped with a floppy disk drive. You can purchase a floppy disk drive separately.

## **Support Options**

Sony provides several options to help solve common problems or to locate support for your VAIO $\circ$  computer. This section describes all available resources and offers suggestions on how to access this information for maximum results.

- Immediate Help and Support
- Help and Support Resources

### **Immediate Help and Support**

You can locate helpful information immediately by consulting your hard copy guides and supplements, or by accessing the online Computer User Guide and the individual software Help files.

Your computer is supplied with these support options:

- **VAIO**® **Computer Quick Start** The Quick Start contains information on how to set up your computer quickly and easily. You can find instructions on how to plan an ergonomic work space, connect power cords, cables and peripheral devices, register your computer with Sony, and establish a dial-up connection to the Internet. The Quick Start can also provide troubleshooting support, if problems occur.
- **VAIO**® **Computer User Guide** The online User Guide provides information about configuring, maintaining, and upgrading your computer. This support resource offers a variety of available topics, enabling you to quickly view specific information using context-sensitive search features. To access the online manual:
  - 1. Click **Start** in the Windows® taskbar, then click **Help and Support**.
  - 2. From the VAIO Help And Support Center menu, click VAIO User Guide.
- **Specifications** The online specifications sheet describes the hardware and software configuration of your VAIO computer. To view this online information:
  - 1. Click **Start** in the Windows taskbar and click **Help and Support**.
  - 2. From the VAIO Help And Support Center menu, click VAIO User Guide.
  - 3. Locate the link in the text, "View the VAIO® Computer Specifications..."
- **Preinstalled software Help files** Each preinstalled software application provides online Help within the software, that describes the software's features. In these Help files, you can find tutorials that teach you to use the software and locate troubleshooting support, should problems occur. To access software Help files:
  - Click Start in the Windows taskbar and point to All Programs. A submenu appears, listing all preinstalled software applications.
  - 2. Click the desired software application. The software's main window appears.
  - 3. From the menu bar, click **Help**. The Help file appears.

1 You can locate the online Help for Sony software applications by pointing to the individual application's icon and selecting Help from the submenu.

## **Help and Support Resources**

If the information provided with your VAIO® computer does not provide an immediate solution or you would like to get direct support, try these help and support resources.

### **Software Help and Support**

The contact and support information for the preinstalled software on your system is located in the online specifications sheet. Software support is free of charge for 90 days after the original date of purchase.

Your computer may not be supplied with all of the software discussed in this section, depending on the system configuration you purchased. To view the specific software preinstalled on your computer, see the online specifications sheet.

### **Sony Computing Support Web site**

Online help and support are available 24 hours a day, seven days a week, when you visit the Sony Computing Support Web site. You can access the Web site at <a href="http://www.sony.com/pcsupport">http://www.sony.com/pcsupport</a>.

The Sony Computing Support Web site provides:

- Information about your specific model computer, such as
- hardware and software specifications.
- upgrade and maintenance procedures.
- safety and legal information.
- quick solutions to common problems.
- An automated tutorial library that contains interactive, easy-to-understand lessons on using your computer's hardware and software features.
- Links that enable you to:
  - quickly find the nearest Sony service center locations.
  - arrange for repairs or check repair status.
  - review warranty information.
  - e-mail your question or comments to the Sony Customer Information Services Center.
  - check pricing and availability for products, accessories and parts, as well as purchase online.
  - access the Sony Solutions Knowledge Base, a database that contains answers to many frequently asked questions.

### **Sony Customer Information Services Center**

If other support options do not resolve your issue, you can contact a Sony Support representative directly.

Before making a call to the Sony Customer Information Services Center, have this basic information readily available.

- VAIO® computer system type
- Model number
- Serial number

Example:

.\*P/N 28470000 \* \*Serial# 3000001\*

4. Operating system Page 222

- 5. Hardware feature or software application that has a problem. (See <u>Help and Support Resources</u> for the appropriate software contact information.)
- 6. Brief description of the issue.

For VAIO® computers purchased in the U.S. and Canada, contact a Sony Support representative at 1-888-476-6972.

<sup>1</sup>The serial number is located on the back panel of your computer. The serial number is on a white barcode label.