SOT31


Basic Manual


The following items are not included in the package


- AC adapter microSD memory card Earphones
- · Purchase a specified charger (sold separately).
- Illustrations used in this manual are just images for explanations. They may be different from actual ones

Getting Ready

Names and functions of parts







Charging

When you purchase your product, the internal battery is not fully charged. Charge the battery before use.

♦Information

- When the charging starts, notification LED lights according to the battery level. To check the battery level, see the status bar in the top of the Home screen. Alternatively, from the Home screen, [∰]▶[Settings]▶[About tablet]▶[Status] and see "Battery
- When you start charging with the product powered off, the power turns on even though operation is not available. Do not charge the battery in a place where the use is prohibited such as in airplane or hospital.
- It may take longer to complete for charging while using the camera function. You cannot charge the battery by connecting the Desktop
- Be sure to attach the supplied attachment to the Desktop holder when charging. If the product is installed without the attachment attached, charging fails.
- Charging with the Desktop Holder Charging with the supplied Desktop Holder (SOT31PUA) and Common AC Adapter 05 (sold separately) is explained. Attach the supplied attachment to the Desktop holder before

You can download the English version of the Basic Manual Thank you for buying "Xperia™ Z4 Tablet" (simply called the from the au homepage (available in approximately one month after the product is released).

Before using the product, read "Basic Manual" (this manual) and "取扱説明書 (詳細版) (Full Instruction Manual)"

About Operating Instructions

(Japanese) to ensure safe use and handling.

■ Basic Manual (this manual)

Preface

"Cautions on using XperiaTM Z4 Tablet" to ensure correct use. Before you assume that the product is malfunctioning, check Handles only basic operations for main features. for possible remedies in the following au Customer Support For detailed descriptions on various functions, refer to the site of au homepage: 'Instruction Manual" (Japanese) application installed on the http://www.au.kddi.com/support/mobile/trouble/renair product or "取扱説明書 (詳細版) (Full Instruction Manual)

- http://www.au.kddi.com/support/mobile/guide/manual/ . Company names and product names referred to in this manual are trademarks or registered trademarks of respective companies. The TM, ® marks may be omitted in
- "Instruction Manual" (Japanese) application This product allows you to use the "Instruction Manual" (Japanese) application on the product to confirm detailed operational procedures. Certain functions can be directly activated from the application screens on which their operations are described. From the Home screen, [||||]▶[お客さまサポート
- (Customer support)]▶[Basic Manual] · When you activate for the first time, follow the onscreen
- instructions to download and install application.

- 1 Headset connection terminal
- 2 microSD memory card/au Nano IC Card (LTE) slot 3 Microphone
- 5 Light sensor: Auto-control for display brightness
- 6 Front camera lens
- Display (Touch panel)
- 8 Notification LED
- 9 Speaker*1
- 10 Power key/Screen lock key: (6)
- 1) Volume key/Zoom key 12 microUSB connection terminal
- 13 Built-in antenna*2 14) Wi-Fi® antenna
- (15) au Nano IC Card (LTE)
- Nameplate
- (7) Camera lens
- 18 mark

7

1

1 Do not jab with a sharp object such as a needle. Doing so may cause a fault.

1 Fitting to the shape of the installation part of the Desktop

so that there are no gaps to the Desktop holder

on the back side of the Desktop Holder

separately) into an outlet

left or right until it clicks

LED of the product turns on.

2 Insert the microUSB plug of Common AC Adapter 05

(sold separately), with the engraved side (▲) facing

3 Insert the power plug of Common AC Adapter 05 (sold

4 Install the product to the Desktop Holder and move it

When the product and the magnetic connector of the

Desktop Holder are connected correctly, the notification

down, straight into the microUSB connection terminal

holder, install the supplied attachment then press firmly

*2 The antenna is built in. Covering around the antenna by the

For Those Requiring an English Instruction Manual

http://www.au.kddi.com/support/mobile/guide/manual/

Before you start using the product, make sure to read the

Regarding notations used in this document

· In this manual, keys (key icons) are represented by

part of a screen may be omitted.

simplified illustrations such as (1), (1), (1)

Operations of tapping menu items/icons/buttons on the

screen etc. are indicated as [(name of the item etc.)].

· Screen illustrations shown in this manual may look different

from the actual screens. In some cases, minor details or a

In this manual, "microSD™ memory card", "microSDHC™ memory card" and "microSDXC™ memory card" are

· All of the indicated amounts exclude tax unless otherwise

abbreviated as "microSD memory card" or "microSD".

*3 Do not remove the nameplate with stickers of CE mark, FCC ID

hand may affect the quality of communication

0

8

1

Download URL:

Safety Precautions

Battery is built into the main unit and not removable by

CE mark and FCC ID

1 Open the slot cover, and insert a fingernail into the hook at the edge of the label tray, then pull it out



au Micro IC Card (LTE)

Your phone number etc. is recorded in the au Micro IC Card (LTE).

5 When charging is complete, lift the product to remove

6 Remove the Common AC Adapter 05 (sold separately)

Charging with Common AC Adapter 05 (sold separately) is

while pressing the Desktop Holder

■ Charging with the AC Adapter

1 Open the microUSB connection terminal cover of the product while hooking the groove with your fingernail, and insert the microUSB plug of Common AC Adapter 05 (sold

. "The Company" as appears on the product refers to the

Sold by: KDDI CORPORATION, OKINAWA CELLULAR

Manufactured by: Sony Mobile Communications Inc.

Using au 災害対策 (au Disaster Countermeasure)

You can use 災害用伝言板 (Disaster Message Board) service, 緊

急速報メール (Emergency Rapid Mail) service that distributes 緊

急地震速報 (Earthquake Éarly Warning), 災害·避難情報 (Disaster

and Evacuation Information) and 津波警報 (Tsunami Warning), and

災害用音声お届けサービス (Disaster Voice Messaging Service).

au災害対策 (au Disaster Countermeasure) menu appears.

■ Using 災害用伝言板 (Disaster Message Board)

well-being from an area of distress via LTE NET in case of large-scale

disaster such as earthquake with a seismic intensity of over 6 lower.

1 au災害対策 (au Disaster Countermeasure) menu▶[災害

(~ezweb.ne.ip) is required. Set up E-mail address beforehand.

■ Using 緊急速報メール (Emergency Rapid Mail)

Emergency Rapid Mail is a service that distributes Earthquake

meteorological bureau or Disaster and Evacuation Information

delivered from the government or local public organization to all

Attaching/removing the au Micro IC Card (LTE)

Before attaching/removing the au Micro IC Card (LTE), make

1 Open the microSD memory card/au Micro IC Card (LTE)

slot cover while hooking the groove with your fingerna

2 Hook the projection of the tray (1) with your fingernail

to slide the tray straight out, then remove the tray from

Attaching the au Micro IC Card (LTE)

用伝言板 (Disaster Message Board)]

To register information of well-being. F-mail address.

Early Warning or Tsunami Warning delivered from the

au devices in specified areas simultaneously.

The product is compatible only

IC-card or micro au IC card

au smartphone

with au Micro IC Card (LTF), You

cannot use the product with an au

switched from an au cell phone or

Do not insert an au Nano IC Card

(LTE) with a conversion adapter.

Doing so may cause a fault.

sure to turn off the product

the product

1 From the Home screen, [au災害対策 (au Disaster

TELEPHONE COMPANY

Countermeasure)]

Information

- separately), with the engraved side (\triangle) facing up, straight into the microUSB connection terminal of the product 2 Insert the power plug of Common AC Adapter 05 (sold separately) into an outlet
- Notification LED lights on the product 3 When charging is complete, remove the microUSB plug of
- Common AC Adapter 05 (sold separately) from the product and close the microUSB connection terminal cover firmly
- 4 Remove Common AC Adapter 05 (sold separately) from

Turning on (Initial settings)

Turning the power on

1 ((over 1 sec)

- The product vibrates and after a while the lock screen appears.
- When you turn on the product for the first time, follow the onscreen instructions to set the initial settings
- 2 Swipe (flick) the screen up or down

safety and take proper action according to the situation around you. When you receive a Tsunami Warning, draw away from sea coast immediately and evacuate to safe place such as upland or well-built high building.

When you receive Earthquake Early Warning, ensure your

1 au災害対策 (au Disaster Countermeasure) menu▶[緊急 速報メール (Emergency Rapid Mail)]

 Reception of Emergency Rapid Mail is notified by a special warning tone and vibration. It is not possible to change the warning tone *Farthquake Farly Warning is notified by warning tone and voice sound ("地震です" (It is an earthquake)), and vibration.

- Earthquake Early Warning may not arrive before strong tremors in areas near the epicenter.
- Tsunami Warning is a major tidal wave/seismic sea wave notification delivered from the meteorological bureau to the area including target coast.
- Disaster and Evacuation Information is a service that distributes bulletins concerning residents' safety including evacuation advisories, evacuation orders and other warnings issued by the national and local governments.
- The service is available only in Japan (it cannot be used overseas) · No information fee or communication charge is required for receiving Emergency Rapid Mail.
- · KDDI is not liable for damages suffered by customers resulting from the service's information, lack or delay in the information caused by transmission or system breakdowns or other events that are outside the responsibility of KDDI.
- · Refer to the Japan Meteorological Agency web page for details about distribution of Earthquake Early Warning. http://www.jma.go.jp/

3

au Micro IC Card (LTE)

3 Set au Micro IC Card (LTE) into the tray with IC (metal) part facing up (2), insert the tray with the card into the main unit and press it all the way Pay attention to the position of the notch and pressing tray.

4 Close the microSD memory card/au Micro IC Card (LTE)

slot cover, press it firmly to ensure that there are no gaps between the cover and the main unit

- Removing au Micro IC Card (LTE) 1 Open the cover while hooking the groove of microSD
- memory card/au Micro IC Card (LTE) slot cover with your fingernai
- 2 Hook the projection of the tray with your fingernail to slide the tray straight out, then remove the tray from the main unit
- 3 Remove au Micro IC Card (LTE) out of the tray, insert the tray into the main unit and then press it all the way Pay attention to the direction of pushing the tray.
- 4 Close the microSD memory card/au Micro IC Card (LTE) slot cover, press it firmly to ensure that there are no gaps between the cover and the main unit

■ Turning the power off

1 (b) (over 1 sec) 2 [Power off]▶[OK]

 Press (b) for over 1 second and long-touch "Power off" ▶ [OK] to restart product in safe mode.

Force-quitting

1 Open the microSD memory card/au Micro IC Card (LTE) slot cover while hooking the groove with your fingernail, press the OFF button (RED) with a fine-tipped object for approximately three seconds, and release your finger after it vibrates three times

Initial settings

When you turn on the product for the first time, follow the onscreen instructions to set language, functions, service, etc. For details, refer to "Setting Guide"

3 Close the microSD memory card/au Micro IC Card (LTE)

slot cover, press it firmly to ensure that there are no

gaps between the cover and the main unit

• You cannot receive Emergency Rapid Mail when your

Emergency Rapid Mail may not be received when your device

mail or using the browser, or if you are in a place where signal

is communicating such as while sending/receiving SMS/e-

does not reach even in the service area (e.g. in a tunnel,

• You cannot receive the Emergency Rapid Mail that the

This delivery system is different from Earthquake Early

Warning provided through TV, radio, or other communication procedures, which means that the time the Earthquake Early

Information from someplace other than your current location

■ Using 災害用音声お届けサービス (Disaster Voice

Disaster Voice Messaging Service is a service which allows

1 au災害対策 (au Disaster Countermeasure) menu▶[災害用

音声お届けサービス (Disaster Voice Messaging Service)]

you to record your voice and send someone you want to

• To use Wi-Fi®, initial settings via 4G (LTE/WiMAX 2+)/3G

Voice message can be recorded for up to 30 seconds.

Voice messages cannot be saved or played if the product

• Note the following points, otherwise handling the au Micro

• Do not lose the au Micro IC Card (LTE) after it has been

Attaching/Removing microSD memory card

1 Open the microSD memory card/au Micro IC Card (LTE)

2 Check the orientation for inserting, and insert it until it

slot cover while hooking the groove with your fingernai

Insert the microSD memory card with the contact side down.

Do not touch the IC (metal) part of the au Micro IC Card (LTE).

IC Card (LTE) may cause malfunction or damage

inform your well-being in case of a large-scale disaster.

basement) or in a place with a poor reception

device is turned off.

reception is failed.

may be received.

❖Information

4

network is required.

does not have available memory.

· Insert in the correct direction

· Do not use force to attach or remove

Attaching microSD memory card

Warning arrives may vary.

Messaging Service)

♦Information

• To change the language later, from the Home screen, [...] ▶[設定 (Settings)]▶[言語と入力 (Language & input)]▶[地域 /言語 (Language)]. To make settings, from the Home screen, [| ▶ [Settings] ▶ [Setup guide]. To make settings サポート (Customer support)]▶[au Easy Setting

Screen Lock

When the screen lock is set, the backlight turns off to avoid the keys and touch panel from false operations. When the specified time elapses, the product's screen backlight turns off automatically and screen lock is activated.

1 While the screen is displayed, (6)

Unlocking screen

The lock screen appears when turning the power on or the backlight on by pressing (6)

1 Swipe (flick) the screen up or down on the lock screen **♦Information**

19

• On the lock screen, long-touch " and drag it to " to activate the camera

■ Using 災害情報/義援金サイト (Disaster

You can check history of Disaster and Evacuation Information delivered by local government, disaster information portal, donation website, etc.

1 au災害対策 (au Disaster Countermeasure) menu▶「災害情 報/義援金サイト (Disaster information/Donation website)]▶Follow the onscreen instructions

Do you have everything?

Before your start using the product, make sure that you have all the following packaged with the product.

- XperiaTM Z4 Tablet^{*1}
- Sonv Mobile TV antenna input microUSB conversion cable 01 (conversion cable) (01SOHKA)
- *1 Including warranty
- 取扱説明書 (Instruction Manual) (Japanese
- XperiaTM Z4 Tabletのご利用にあたっての注意事項 (Cautions on using Xperia[™] Z4 Tablet) (Japanese)
- ・ 設定ガイド (Setting Guide) (Japanese)

- Insert a microSD memory card in the appropriate direction. Inserting a microSD memory card forcefully into the slot could result in failure to remove the microSD memory card or damage.
- Do not touch the terminal of the microSD memory card. ■ Removing microSD memory card

Be sure to unmount microSD memory card before removing.

1 From the Home screen, [■] > [Settings] > [Storage] [Unmount SD card]▶[OK] When it is unmounted, " SD card safe to remove" appears on the status bar to notify you that reading and

- writing from/to the microSD memory card are disabled. 2 Open the microSD memory card/au Micro IC Card (LTE) slot cover while hooking the groove with your finger
- 3 Press the microSD memory card all the way until it clicks, then pull out the microSD memory card slowly " Removed SD card" appears on status bar to inform that the microSD memory card is removed.
- 4 Close the microSD memory card/au Micro IC Card (LTE) slot cover, press it firmly to ensure that there are no gaps between the cover and the main unit

Basic Operation

Key icons

The followings are the main functions of **力**, **ඛ**, **□** keys located at the bottom of the screen

†	ŵ	7	
45	企		

Return to the previous screen. Close a dialog

Back	box, menu, or the Notifications panel.
Home	Display the Home screen. Long-touch and drag it to "Q " to activate "auスマートパス (au smart pass)"/ "Google" application or drag it to " to activate "What's New" application.
Recently	Display recently used applications on a list and activate or delete them from the list. Also, you can use and set small apps.

1

- Pressing the OFF button (RED) by a sharp object such as needle may cause malfunction.
- volume key at the same time for approximately three seconds, and release your finger after it vibrates three times.

• Alternatively, press and hold (and upper part of the

13

The display of the product is a touch panel operated by

touching it with your finger. ■ Tap/Double-tap

Tap: Gently touch a screen and then immediately release your finger. Double tap: Touch the same position twice.

Long-touch

Keep touching an item with your finger

While your finger is gently touching the screen, trace it to the desired direction to move over

Flick (swipe)

Operate the screen by quickly moving (flicking) your finger up, down, right, or left

Pinch Touch the screen with two fingers and widen (pinch-out) or

narrow (pinch-in) the fingers' distance.

Drag

Keep touching an item or icon, trace it to the desired direction

Alternatively, from the Home screen, [] ▶[Contacts] ▶

Set the volume to 0. Setting to Silent mode does not mute

sounds for shutter, alarm, etc. And pressing upper part of

· Alternatively, slide the right side of the status bar downward

When airplane mode is set, all wireless functions (packet

communication, Wi-Fi® function, Bluetooth® function, NFC

• Slide the right side of the status bar downward ▶ [Airplane

For general information, charges and operation information (toll free)

PRESSING ZERO WILL CONNECT YOU TO AN OPERATOR

2 [X]/[X]
Tap "X" to set mute (volume 0) and tap "X" to set

► [Sound] to switch the Silent mode settings.

model to switch the airplane mode on or off.

[Myself] to check your phone number

■ Setting the Silent Mode

volume key cancels Silent mode.

■ Setting Airplane mode

1 (b) (over 1 sec) ▶ [Airplane mode]

For inquiries, call: Customer Service Center

Business hours 9:00-20:00 (7 days a week)

function) are turned off.

1 (b) (over 1 sec)

vibrator

Home screen Home screen consists of multiple screens. Slide or flick left or right to move to the adjacent screen. Tap 🔝 to return to the Home screen any time

(1)

1 Long-touch an area of the Home screen where no icons

are displayed Alternatively, pinch-in on the Home screen

3 - 6		Manpaporo	to dot do a wanpapon.
D & D		Photos	Select an image from photos
Home screen position			to set as a wallpaper.
Indicates which screen of the several Home screens you are in.) Widgets) Shortcuts (Applications)) Application key		` '	Select an image to set as a wallpaper. Images displayed below "Photos"/"Live Wallpapers" are "Xperia TM 's Wallpaper".
) Wallpapers) 基本機能フォルダ (Basic functions folder)	Themes		Set the wallpapers etc. for the Home screen or the lock
dding to Home screen/Editing Home screen			screen.
ou can change wallpaper or theme of the Home screen and dd/delete/move shortcuts of applications, widgets, folders, tc. on the Home screen.	Adding a for 1 From the Hon 2 Drag the icon	ne screen, lo	ng-touch an icon r icon

22

2 Widgets

Wallpapers

Album

on the character entry screen for adding contacts, creating a

With "International keyboard", you can use QWERTY keyboard to enter characters, Numeric keypad to enter numbers and symbols, and Symbol keypad for more symbols.

QWERTY keyboard appears.

2 Tap [12!?] to display Numeric keypad For Symbol keypad, tap " +=\$ " on the Numeric keypad.

♦Information

28

- keyboard.
- to delete the character before the cursor.
- caps " on QWERTY keyboard.
- · When using QWERTY keyboard, touch and hold a character to select a character variant.

Support

Introduction of related accessories

For details, refer to the instruction manual for each device.

Add a widget.

llnaners to set as a wallnaner

Add a shortcut of an

o set as a wallpaper.

oplication, a setting screer

elect an image from albums

To set image range, adjust

cropping area by dragging

Select a content from albums

- · Sony Mobile TV antenna input microUSB conversion
- cable 01 (01SOHKA)
- Common AC Adapter 05 (0501PWA) (sold separately)
- microUSB cable 01 (0301HVA) (sold separately)

- For the latest information on accessories, visit the au homepage (http://www.au.kddi.com/) or contact the Customer Service Center
- Accessories described above can be purchased from the au Online Shop.

http://auonlineshop.kddi.com/

Before you assume that the product is malfunctioning, check the following:

Symptom	What you should check
	Is the internal battery charged?
on even though (b) is pressed	Is (b) pressed for over 1 second?
The power goes off	Is the internal battery charged?

The Application for the Internet acceptance, if "damage" "wet", "theft" and "loss" are eligible. In the case of spontaneous failure (not the cause damage, such as water wet, but does not power on, the screen does not function or other), it will be accepted by phone for

■ au after-sales service information Replacement cell phone delivery service

Spontaneous failure 1st year	Free of charge
Spontaneous failure 2nd	
-	Customer charge
	1st: 5,000 yen 2nd: 8,000 yen
	DI ITE I

Non-Keitai Guarantee Service Plus LTE members

Spontaneous failure 1st year	
Spontaneous failure 2nd	
year or later	No recompense
Partially damage, water	Two recompense
soak, irreparable damage,	
theft or loss	

Keitai Guarantee Service Plus ITE member

cital dadiantee ociviee i las ETE members			
Spontaneous failure 1st year	Free of charge		
	Free of charge (three-yea		
oor or loter	worronty)		

operations in progress, etc., and on the right, status icons appear to indicate the status of the product.

Examples of notification icon

Downloading applications

details, refer to "Setting Guide".

saved in the application.

Status bar

■ Deleting (uninstalling) applications

Knowing the status of the product

· Some applications may not be deleted.

You can download and install applications or games, etc. by using

• To use Google Play, you need to set a Google account. For

related to the application that you want to save including data

The status bar is located at the top of the product screen. On the

left of the status bar, notification icons appear to inform new mails,

Before deleting installed applications, back up contents

Σ	New Gmail message	
×	New PC mail message	
E	New E-mail (@ezweb.ne.jp) message	
SMS	New SMS	
♣ USB connecting		
₹	Wi-Fi® open network available	

Symptom What you should check Cannot operate key/ Is the power turned on? "Screen lock" set? Turn off the power and then turn it on

	agaii.
Cannot operate	Are you operating with gloved hands?
touch panel as intended	Are you operating with a fingernail or foreign object on the operating screen?

00	Is the temperature of the product raised or very low?
A message such as "charge the battery"	The battery is almost dead.

appears	
	Is the battery fully charged? Charge until the notification LED turns green.
	Is the internal battery end-of-life?

s the product used for a long period at places where (out of range) appears? Is set "Sleep" period too short?

s the light sensor blocked or cove

Customer charge

Customer charge

10.000 ven

Actual cost

No recompense

model change)

No recompense

Joner limit: 5,000 ver

backlight turns of in a short while The display is dark | Is "Brightness" set to dark?

Non-Keitai Guarantee Service Plus LTE members

Spontaneous failure 1st year Free of charge

artially damage

mage

heft, loss

vear or later

nage

Theft, loss

artially damage

Nater soak, irreparable

Spontaneous failure 2nd

Nater soak, irreparable

■ Downloading and updating software

into the product directly.

updating software.

Update files can be downloaded from the Internet web site

available on au homepage

32

Holding over and repair . Damages and malfunctions intentionally caused by the customer as well as those due to modification (e.g. disassembly, change of parts, painting, etc.) by the

casing due to stains, scratches, paint removal, etc. on the

Main specifications

Display		Approx. 10.1 inches TRILUMINOS [®] Display for mobile Approx. 16.77 million colors
		1,920 x 1,200 dots
Weight		Approx. 439 g (with internal battery)
Dimension (WxHxT)	Approx. 266 mm x 172 mm x 6.4 mm
Continuous In Japan stand-by time		Approx. 1250 hours (4G (LTE/ WiMAX 2+)) Approx. 1330 hours (3G)
	Overseas (GSM)	Approx. 1400 hours
Charging tin	ne	Using Common AC Adapter 05 (sold separately): Approx. 190 min. (alone)

■ Notification LED

Notification LED informs charging prompt, battery level while charging, new mails, etc. by turning on or flashing.

Description

Red	The battery is charging when the remaining battery level is 14% or lower.	
Orange	The battery is charging when the remaining battery level is 15% - 89%.	
Green	The battery is charging when the remaining battery level is 90% or higher.	
Flashing red	The remaining battery level is 14% or lower.	
Flashing white	Indicates new Gmail message, new SMS message.*1	

- in color that indicates the battery level.
- Checking own phone number
- 2 [About tablet]▶[Status]

26



1 From the Home screen, [計] ▶[ツール (Tool)] ▶ [Update

usable

For repair, contact Keitai Guarantee Service Center.

During the Repairs will be done based on the terms of ervices of the free-of-charge repair warranty warranty escribed on the warranty card. Outside the We shall repair the product for a charge as warranty requested by the customer if repair renders it

♦Information

period

- Before handing in the product for repair, make a backup of the contents of memory since they may disappear during repair. Note that the Company shall not be liable for any damages and loss of income should the contents of
- are sometimes used for repair
- Collected au devices by Replacement cell phone delivery service which you used before are recycled to devices for replacement after repairs. Also replaced parts by au aftersales service are collected and recycled by KDDI. They are not returned to customers.

From fixed-line phones: | From au cell phones 60077-7-111 157 without area code

AFTER CALLING 157 ON YOUR au CELLPHONE For loss or theft (toll free) Business hours: 24 hours live suppor

m fixed-line phones: | From au cell phones 0077-7-113 113 without area code In case above numbers are not available (toll free).

6120-977-033 (except Okinawa) 6 0120-977-699 (Okinawa)

Keitai Guarantee Service Center

For loss, theft, damage. Business hours 9:00-21:00 (7 days a week)

E 0120-925-919 (toll free)



Cell phone and PHS operators collect and recycle unused tele batteries and battery chargers at stores bearing the (1) logo regardles of brand and manufacturer to protect the environment and reuse

Performance parts for repair The Company retains performance parts for repair of the

Xperia[™] Z4 Tablet main unit and its peripherals for four years after discontinuation of production, "Performance parts for repair" refers to parts required for maintaining the functions of the product.

■ Warranty card

At the store of purchase, thoroughly check and read the name of the retailer, date of purchase and other necessary details filled in on the warranty card, and be sure to keep it in a safe

■ Keitai Guarantee Service Plus LTE An after-sales service membership program on a monthly

basis called "Keitai Guarantee Service Plus LTE" (monthly fee: 380 ven tax excluded) is available for using your au device for a long time without worries. This service expands coverage for many troubles including malfunction, theft and loss. For details of this service, refer to au homepage or contact Keitai Guarantee Service Center.

❖Information

- You can apply for membership only at the time of purchasing your au device. Once you cancel the membership, you cannot reapply for it
- until you purchase an au device next time. Note that when changing the model or purchasing an extra
- device, this service only covers the most recently purchased au device. When an au device is handed over to you or someone else,
- the Keitai Guarantee Service Plus LTE membership is also handed over to the successor of the device.

35

- 36

- replacement device is delivered. Available up to twice in a year from the day you use this service as a start day. If you do not use this service in the past year for the subscription to this service, it will be 1st

When you have trouble with your au device, replacement

Return your damaged device within 14 days after the

device (same model, same color) is delivered by calling to.

and if you use, it will be the 2nd. * For details, refer to au homepage

* Charge amounts are all tax excluded

Replacement cell phone delivery service

customer are not covered by this service. · You cannot receive a refund for the replacement of the outer

outer casing.

Display		Approx. 10.1 inches TRILUMINOS® Display for mobile Approx. 16.77 million colors
		1,920 x 1,200 dots
Weight		Approx. 439 g (with internal battery)
Dimension (W x H x T)		Approx. 266 mm x 172 mm x 6.4 mm
Continuous stand-by time	In Japan	Approx. 1250 hours (4G (LTE/ WiMAX 2+)) Approx. 1330 hours (3G)
	Overseas (GSM)	Approx. 1400 hours
Charging time		Using Common AC Adapter 05 (sold separately): Approx. 190 min. (alone) Approx. 260 min. (with Desktop Holder SOT31PUA)

Continuous 1Sea pprox. 8 hours 10 min. viewing time Continuous tethering pprox. 1190 min. (4G (LTE/ ViMAX 2+) on WAN) Approx. 1640 min. (3G on WAN) Wi-Fi® tethering maximum connecti number

• The continuous stand-by time, continuous Full Seg watching

tethering time may drop to less than half depending on the battery charging status, usage environment such as temperature, reception condition at the location where the product is used, and the function settings

by: KDDI CORPORATION, OKINAWA CELLULAR TELEPHONE COMPANY

June 2014, 1st Edition 1285-4436.1

Entering characters Use software keyboard to enter characters. To display the software keyboard, tap a character input box

Switching keyboards

1 Tap a character input box

- Tap " at the bottom of the screen to hide the software
- to enter facemarks etc. from the displayed list.

Desktop Holder (SOT31PUA)

- · Sony Mobile AC adapter 05 (EP880) (sold separately)

Troubleshooting

•		
The power goes off	Is the internal battery charged?	

· When you get a new au device by changing the model or purchasing an extra device, the "Keitai Guarantee Service Plus"/"Keitai Guarantee Service Plus LTE" membership for the old au device is automatically canceled. · Service contents are subject to change without notice.

au Micro IC Card (LTE) The au Micro IC Card (LTE) is lent to you by au. In case of loss or damage, the card will be replaced at your expense. When a malfunction is suspected, or in case of theft or loss, contact

■ After-sales service If you are unsure about anything regarding after-sales service, contact the following service contact.

an au shop or PiPit.

in case of loss or theft) From a land-line phone, 10077-7-113 (toll free) From an au mobile phone, 113 without area code (toll free) Business hours: 24 hours live support

Customer Service Center (for service canceling procedure

Keitai Guarantee Service Center (for loss, theft, damage) From a land-line phone/From an au cell phone. 0120-925-919 (toll free) Business hours 9:00 – 21:00 (7 days a week)

Online Repair Desk (24 hours a day over the Internet)

Reception only from PC or smartphone

https://cs.kddi.com/support/n_login.html





Basic Manual What you should check

Play Store

S, Google, Voice Search

Camera, Album

Maps

Symptom The power turns off s the internal battery charged? vhile activation creen is displayed The screen freezes Open the microSD memory card/au

Micro IC Card (LTE) slot cover while annot be turned off hooking the groove with your ingernail, press the OFF button (RED) with a fine-tipped object for approximately three seconds

■ Deleting shortcuts/widgets/folders

you want to delete

♦Information

shortcuts etc. in the folder.

■ Starting an application

2 Tap an application to use

■ Main applications

E-mail, SMS

Contacts

Browser

Settinas

Calendar

1 From the Home screen, [

Using the Applications screen

Some applications are stored in a folder.

1 From the Home screen, long-touch an icon or a folder

2 Drag the icon or the folder to "Remove from Home

To delete a folder, then tap "Delete". It also deletes

Long-touch a shortcut, widget, or folder icon to move.

You can call up functions from the Applications screen.

· You may incur communication charges depending on the

Application icons installed to the product are also displayed.

Slide or flick left or right to switch the Applications screen

elease your finger after it vibrates hree times. Alternatively, press and hold (b) and upper part of volume key at the same time for approximately hree seconds, and release your nger after it vibrates three times.

(Out of service s the product out of the service area or in an area where the signal is weak' Is the built-in antenna covered with and?

Cannot charge the Is the specified charging equipment oattery (Notification sold separately) attached properly? LED does not light the battery icon does not change nto charging one)

interview is required. To apply for the Internet, you need the e-mail address.

eitai Guarantee Service Plus LTE members				
pontaneous failure 1st year	Free of charge			
	Customer charge 1st: 5,000 yen 2nd: 8,000 yen			

Holding over and repair					
Partially damage, water soak, irreparable damage, theft or loss					
Partially damage water	No recompense				
year or later	No recompans				

38

■ Main status icons Signal level (Level 4, Out of service area)

Data communication status (4G (LTF/WiMAX 2+) available*1, 3G available) Battery level (100%, Charging) Silent mode (Vibration, Mute) Airplane mode is activated Wi-Fi® connected, Wi-Fi® communicating

*1 Two types of network, "LTE"/"WiMAX 2+" can be used. "4G"

The company determines which network is less busy

If any notification icons are displayed, slide down the left side

of the status bar to open the Notification panel. You can check

• To delete a notification, tap "Clear" or flick the notification left

Some notifications may not be deleted depending on the content

When you set screen lock to "Swipe", slide the left side of the

on the screen/press size data between the product and

Cannot recognize a Is the microSD memory card inserted

For more details, visit au Customer Support site of au homepage

You can update the product to the most recent software for

• You are charged for data communication when connecting to

• For details, visit http://www.sonymobile.co.jp/support/ or

refer to the "Instruction Manual" (Japanese) application or

"取扱説明書(詳細版) (Full instruction manual)" (Japanese)

the Internet from the product by using packet communication.

optimal performance and to get the latest enhancements.

• You are recommended to back up your data before

properly?

http://www.au.kddi.com/support/mobile/trouble/repair

status bar downward to check the Notification panel without

What you should check

When a large amount of data is saved

n the product or transferring large-

nicroSD memory card, the screen

s the microSD memory card unmounted?

esponse may be delayed.

depending on the condition of the line to connect.

details of notification icons or start corresponding

appears on the screen for either network.

■ Notification panel

unlocking the screen.

Symptom

Screen response is

microSD memory

Updating Software

slow when you tap

applications.

*1 Notification LED flashes while backlight is turned off or lock screen is displayed

♦Information

Status

• When the remaining battery is not sufficient for turning the product ON, pressing (b) makes LED flash red three times.

When you start charging with the product powered off, the notification LED turns in red. When the status of battery appears on the display, however, the notification LED lights

The phone number of the product is shown under "My phone number (MDN)".

2 Tap "System" tab▶[C]

After-sales service

When asking for repair

- memory be altered or lost. • Recycled parts that meet the Company's quality standards

Approx. 6 hours 40 min.

♦Information

Continuous Full Sec

watching time

time, continuous 1Seg viewing time and continuous