

Farawa5

Kunna wayar, kira, kewayawa, yaren waya, shigar da haruffa, maballai, menus.

Kira21

Kira, kiran bidiyo, lambobi, lissafin kira, bugun kira na sauri, ikon murya, kungiyoyi, katunan kasuwanci.

Sako38

Sakon rubutu, sakon hoto, sakon murya, email, Abokaina

Hoto51

Kamara, bidiyo, shafi, hotuna, PhotoDJ™, jigogi.

Nishadi57

Mai kunna kida, mai kunna bidiyo, rediyo, PlayNow™, mai rikodin sauti, wasanni.

Hadfi67

Saituna, Intanit, RSS, aiki tare, fasahar Bluetooth™, Kebul na USB, daukaka sabis.

karin fasali79

Agogon kararrawa, kalanda, dawainiya, bayanan martaba, lokaci da kwanan wata, kulle katin SIM da kari.

Shirya matsala.....88

Me yasa wayar bata aiki yanda nakeso tayi?

Muhimmin bayani94

Gidan yanar sadarwar mai amfani na Sony Ericsson, sabis da goyan baya, aminci da ingantaccen amfani, kare yarjejeniyar lalasisin mai amfani, garanti, bayanin tabbatarwa.

Fihirisa.....105

Sony Ericsson K530i

UMTS 2100

GSM/GPRS 900/1800/1900

Sony Ericsson Mobile Communications AB shine ya buga wannan jagoran mai amfanin ko kamfanonin sa na haɗin guiwa na cikin gida batareda wani garanti ba. Ingantawa da canje-canje game wannan da jagorar mai amfanin wanda kuskuren rubutu ya haifar dashi, kuskuren bayani na yanzu, ko inganta tsare-tsare kuma/ko kayan aiki, mai yiwuwa kamfanin sadarwar wayar hannu na Sony Ericsson Mobile Communications AB ko kamfanoninsa na haɗin guiwa na cikin gida akoda yausha ba tare da sanarwa ba. Irin waɗannan canje-canjen za'a, kowane hali shigar dasu cikin sabon bugu na jagorar mai amfani.

An kiyaye duk hakkoiki.

©Sony Ericsson Mobile Communications AB, 2007

Lambar ɗaba'a: HA/LZT 108 9411 R1A

Kula:

Wasu sabis acikin wannan jagorar mai amfanin basu da goyan bayan duk cibiyoyin sadarwa. *Haka nan ana aiwatar da wannan zuwa ga GSM Lambar Gaggawa ta Kasashen waje 112.*

Tuntubi mai sa aiki na cibiyar sadarwa ko mai bada sabis in kana shakka akan zaka iya amfani da wani sabis ko a'a.

Karanta *Jagororin saboda lafiya da amfani mai nagarta* kuma *Garantin mai iyaka* yana sa babuka kafin kayi amfani da wayarka ta hannu.

Wayarka tanada damar saukewa, ajewa da tura karin abun ciki, misali: sautin ringi. Amfani da abun cikin nan zai yiwu an takaita ko an haramta ta hakkin na uku, ya na tattare da sai dai ba a iyakance ba zuwa takaitawa karkashin dokokin hakkin mallakar masu gudana. Kai ne, ba Sony Ericsson ba, ke da cikakken alhakin na karin abun ciki wanda ka saukar zuwa ko ka tura daga wayarka ta hannu. Kafin amfaninka na kowane karin abun ciki, Ka tabbatar da amfanin da kake nufi yana da lasisi ko kuma yana da izini. Sony Ericsson bai da garantin daidai, mutunci ko ingancin wani karin abun ciki ko wani abun ciki na wani ɓangare na uku. Karkashin ko wane hali Sony Ericsson ba zai ɗauki alhakin amfanin ka wanda bai dace ba na karin abun ciki ko wani ɓangare na uku.

Bayyananniyar alamar shaida, PlayNow, MusicDJ, PhotoDJ, VideoDJ da TrackID alamune na kasuwanci ko alamun kasuwanci masu rijista na Sony Ericsson Mobile Communications AB.

Sony, Memory Stick Micro, da M2 alamun kasuwancine na Sony Corporation. Ericsson alamace ta kasuwanci ko alamace ta kasuwanci wacce akayiwa rijista na Telefonaktiebolaget LM Ericsson.

Bluetooth™ alamace ta kasuwanci ko alamace ta kasuwanci mai rijista na Bluetooth SIG Inc.

TrackID™ yana samun karfi ta Gracenote Mobile MusicID™. Gracenote da Gracenote Mobile MusicID alamune na kasuwanci na Gracenote, Inc.

Real alamace ta kasuwanci ko alamace ta kasuwanci mai rijista na RealNetworks, Inc. RealPlayer® saboda wayar hannu wanda aka kunsar karkashin lasisi daga RealNetworks, Inc. Hakkin mallak 1995-2007, RealNetworks, Inc. An kiyaye duk hakkoki.

Adobe™ Photoshop™ Album Starter Edition alamace ta kasuwanci ko alamace ta kasuwanci mai rijista na Adobe Systems Incorporated.

Microsoft, Windows da PowerPoint suma ko dai alamune na kasuwanci masu rijista ko alamune na kasuwanci na Microsoft Corporation a amurka da/ko wasu kasashe.

T9™ Text Input alamace ta kasuwanci ko alamace ta kasuwanci mai rijista na Tegic Communications. Anyi lasisin T9™ Text Input karkashin daya ko fiye na masu zuwa: U.S. Pat. Nos. 5,818,437, 5,953,541, 5,187,480, 5,945,928, da 6,011,554; Mutumin Kanada Pat. No. 1,331,057, Burtaniya Pat. No. 2238414B; Hong Kong Standard Pat. No. HK0940329; Jumhurayyar singapur Pat. No. 51383; Euro.Pat. No. 0 842 463(96927260.8) DE/DK, FI, FR, IT, NL, PT, ES, SE, GB; karin fasahohi suna rataye a duk duniya.

Java da duk tabbatattun alamun kasuwanci na Java da alamu alamune na kasuwanci ko alamune na kasuwanci masu rijista na Sun Microsystems, Inc. Amirka da wasu kasashe.

Kare yarjejeniyar lasisin mai amfani saboda Sun™ Java™ J2ME™.

- 1 Takaitawa: Software hakkin mallakan bayani ne na sirri na Sun kuma take ne zuwa duk kwafi wanda aka kiyaye shi ta Sun da/ko masu lasisinsa. Abokin ciniki ba zai gyara, watsa, tarwatsa, canja, cire, ko kuma maida injiniyan Software baya ba. Software ba zai yarjejeniya, amincewa, ko yin lasisi, a duka ko a sashi ba.
- 2 Dokokin fitarwa: Software, gamida bayanana fasaha, an tsara shi da dokokin ikon fitarwa na Amirka, gamida tsarin aikin fitarwar Amirka da dokokinta masu dangantaka, kuma za'a iya tsarawa zuwa dokokin fitarwa da shigarwa na wasu kasashe. Abokin ciniki ya amince da daukan ukubar duk dokoki da fadakarwa wanda zai dauki alhakin samun lasisin fitarwa, sake fitarwa, ko shigarda Software. Software ba zai sauke ko fitarwa ko sake fitarwa ba (i) ciniki, ko zuwa dan kasa ko mazaunin irin su, Kyuba, Iraki, Iran, Koriya ta arewa, Libiya, Sudan, Siriya (azaman wannan lissafi za a rika bita daga lokaci zuwa lokaci) ko wata kasa da Amirka ta sanyawa takunkumin kaya; ko (ii) zuwa kowane ma'aikatan Amirka da aka keɓance na musamman ko ma'aikatan kasuwancin Amirka wanda suke da oda na musamman.

- 3 Takaitattun Hakkoki: Amfani, kwafewa ko kwakkwafi na hukumar Amirka batune zuwa ga takaitawa kamar yadda aka daidaita shi azaman na huɗu a hakkokin cikin bayanana fasaha da software na kwamfuta da aka sanya acikin DFARS 252.227-7013(c) (1) (ii) da FAR 52.227-19(c) (2) azaman abin zartarwa.

Wani samfur da sunayen kamfani da aka ambata acikin nan maiyuwa su zama alamun kasuwancin masu mallakar sune.

An adana duk hakkokin da ba'a bayyana garantinsu acikin nan ba.

Dukkan zanuka saboda zane ne kawai maiyuwa kuma baza su dace dai-dai da irin wannan wayar ba.

Alamun umurni

Masu biyowa suna bayyana a jagorar mai amfani:



Kula



Sabis ko aiki suna dogara ne da cibiyar sadarwa ko biyan kuɗi. Tuntuɓi afaretanka na cibiyar sadarwa don cikakken bayani.



Duba shafi kuma...



Yi amfani da maɓallin zaɓi ko kewayawa don gungurawa da zaɓar ➡ *Kewayawa 14.*



Latsa tsakiyar maɓallin kewayawa.



Latsa bangaren saman maɓallin kewayawa.



Latsa bangaren kasan maɓallin kewayawa.



Latsa bangaren haguɗu maɓallin kewayawa.



Latsa bangaren dama na maɓallin kewayawa.

Farawa

Kunna wayar, kira, kewayawa, yaren waya, shigar da haruffa, maballai, menus.

Akwai karin bayani da saukarwa a www.sonyericsson.com/support.

Harhaɗawa

Kafin kafara amfani da wayarka, kana bukatar saka katin SIM da baturin.

Katin SIM

Lokacin da ka yi rijista azaman mai saye tare da afaretan cibiyar sadarwa, zaka sami katin (Bangaren shaidar mai saye) SIM. Katin SIM ya kunshi bangaren kwamfuta wanda ke riƙe da turbar abubuwa kamar lambar wayarka, sabis da aka haɗa acikin biyan kuɗinka, da sunaye da lambobi acikin lambobinka.

 *Ajiye bayanin lamba akan katin SIM naka kafin cire shi daga wata waya; misali, zai yiwu a ajiye lambobi acikin kwakwalwar ajiyar wayar.*

PIN

Mai yiwuwa ka bukaci PIN (Personal Identification Number) don katin SIM naka don fara wayarka da kunna sabis. Lokacin da kashigar da PIN naka, kowace lamba tana bayyana azaman *, saidai in tafara da lambobi irin lamabar gaggawa, misali 112. Wannan yana bada dama don kiran gaggawa ba tareda shigar da PIN ba. Latsa  don gyara kurukurai.


 *Idan ka shigar da PIN kuskure sau uku a jere, **An katange PIN** yana bayyana. Don cire mashi katanga, kana bukata ka shigar da PUK (Personal Unblocking Key) ➡ Kulle katin SIM 85.*

Baturi

Wasu ayyuka suna amfani da wutar baturi fiye da wasu kuma maiyuwa ya haifar da bukatar sake caji da yawa. Idan an kula lokacin magana da jiran aiki yazama mafi gajarta, maiyuwa dole ka sauya baturin. Yi amfani kawai da amintattun batura daga Sony Ericsson ➡ *Baturi 97.*


Katin SIM da baturi

Don saka katin SIM




- 1 Cire murfin baturi.
- 2 Zamar da katin SIM din zuwa cikin marikinsa tareda lambobin zinari suna fuskantar kasa.

Don saka baturin



- 1 Shigar da baturin tareda alamar gefen sama da masu hadin suna fuskantar juna.
- 2 Rufe kuma zamar da murfin baturin zuwa cinkin wurin.

Don cajiin baturi



- 1 Hada cajar zuwa wayar. Zai iya daukar kimanin awa 2.5 don cikar cajiin baturin. Latsa wani maballi don duba allon.
- 2 Cire caji ta karkatar da filogin sama.

Kunna wayarka

Tabbatar da wayar tayi caji kuma an saka katin SIM kafin kunna wayar. Bayan kunn wayarka, yi amafani da saita mayen don shiryawa don amfani da sauri asaukake.

Don kunna wayar



- 1 Latsa ka riƙe ①. Maiyuwa farawa ya dauki mintuna kaɗan.
- 2 Zaɓi yanayi:
 - **Na al'ada** – cikakkun ayyuka.
 - **Ynyin. kaura** – iyakantattun ayyuka tareda cibiyar sadarwa da masu watsawa da karɓa na Bluetooth akashe.
- 3 Shigar da PIN dɪnka na katin SIM, idan an bukata.
- 4 A farkon farawa, zaɓi yare don menus na wayarka.
- 5 ► **Ee** don saita mayen ya taimakeka.
- 6 Bi umarni don gama saiti. Saboda karin bayani, ► *Menu na yanayin kaura 8.*



Idan saitunan da aka ayyana sun kasance a wayarka, maiyuwa bazaka bukaci karin saituna ba. Idan kana amfani da **Saukar da saituna**, dole ka yarda da yin rijistar wayar a Sony Ericsson. An aika sakon rubutu Babu wasu bayanan sirri da Sony Ericsson zata aika zuwa ko ta sarrafa.

Tuntuɓi afaretan cibiyar sadarwarka ko mai baka sabis don karin bayani.

Jiran aiki

Bayan ka kunna wayar da shigar da PIN naka, sunan afaretan cibiyar sadarwar zai bayyana akan allon. Wannan ake kira yanayin jiran aiki.

Taimako a wayarka

Akwai taimako da bayani a wayarka ako wane lokaci.

Don amfani da saita maye

- Daga jiran aiki **Menu ► Saituna ► Gaba daɗaya shafin ► Saita maye** kuma zaɓi wani zaɓi:
 - **Saukar da saituna**
 - **Shirin na asali**
 - **Tukwici da zamba**

Don duba bayani gameda ayyuka

- Gungura zuwa aiki ► **Bayani**, in akwai.

Don duba gwajin wayar

- Daga jiran aiki zaɓi **Menu ▶ Nishadi ▶ Zagawar Demo.**

Sauke saituna

An saita ayyuka ta atomatik a wayarka wanda yake amfani da Intanit; Intanit, sakon hoto, email, Abokaina, aiki tare, daƙakaka sabis, shafi da jerin yawo.

Zaka iya amfani da **Saukar da saituna** Idan SIM naka yana goyan bayan sabis ɗin, an haɗa wayarka zuwa cibiyar sadarwa, ana farata a yanayi na yau da kullun kuma bata riga tanada ayyanannun saituna ba.

 *Tuntuɓi afaretan cibiyar sadarwarka ko mai baka sabis don karin bayani.*

Menu na yanayin kaura

Idan ka kashe wayra kuma **Ynyin. kaura** menu yana kunne, zaɓi daga **Na al'ada** tareda cikakken aiki ko **Ynyin. kaura** tareda iyakantaccen aiki. An kashe masu karɓa da watsawa na cibiyar sadarwa da Bluetooth don hana damun kayan aiki mai mahimmanci. Zaka iya, misali, kunna kiɗa ko rubuta sakon rubutu don aikawa a gaba amma ba yin kira acikin jirgin sama ba.

 *Bi umarnin hawa jirgi, umarnin ma'aikatan jirgi don amfanin na'urorin lantarki.*

Don duba zaɓuɓɓukan menu na yanayin kaura

- Daga jiran aiki **Menu ▶ Saituna ▶ Gaba ɗaya sahin ▶ Yanayin kaura** kuma zaɓi wani zaɓi.

Yin kira

Dole wayar taza a yanayi na al'ada (ba'a yanayin kaura ba).

Don yin kira

- 1 Shigar da lambar waya (tareda fihirisar kasar waje da lambar yanki idan an zartar).
- 2 ▶ **Kira** don yin kiran murya ko ▶ **Kari ▶ Yi kiran bidiyo** don yin kiran bidiyo.
- 3 ▶ **Kari** don zaɓuɓɓuka yayin kiran.
- 4 ▶ **Kas.kira** don kare kiran.

Menu na ayyuka

Zaka iya buɗe menu na ayyuka kusan ko ina a wayar don dubawa da tafiyar da sab.ab.auku., da kuma samun damar alamun shafi da gajerun hanyoyi.

Don buƙewa da rufe menu na ayyuka

- Latsa .

Shafukan menu na ayyuka

- **Sab.ab.auku.** – kamar kiran da aka rasa da sakonni. Lokacin da sab.ab.auku. ya wakana, shafin yana bayyana. Latsa  don fidda abin aukuwa daga shafin abin aukuwa. Madadin haka kuma za'a iya saita sab.ab.auku. don bayyana azaman rubutun faɗakarwa, daga jiran aiki zaɓi **Menu ▶ Saituna ▶ Gaba ɗaya shafin ▶ Sab.ab.auku. ▶ Pop-up.**
- **Aik.-aik. ms. gd.** – aikace-aikace masu gudana a bangon bayan. Zaɓi aikace-aikace don komawa gareshi ko latsa  don kare shi.
- **Gajer.hanya nawa** – kara, share kuma canza odar gajerun hanyoyi. Lokacin da ka zaɓi gajeriya hanya kuma aikace-aikace suka buƙe, ana rufe ko rage girman wasu shiryе-shiryе.
- **Intanit** – alamomin shafin Intanit naka. Lokacin da ka zaɓi alamar shafi kuma mai lilon ya buƙe, ana rufe ko rage girman wasu shiryе-shiryе.

PC Suite software

Habaka kwarewar wayarka ta shigar da PC Suite software a kwamfutarka. Wannan zai baka damar, misali, hada aiki tareda kalandar wayarka da kalandar kwamfuta.


Don shigar da PC Suite software

- 1 Kunna kwamfutarka kuma saka CD wanda yazo tareda wayarka cikin mai tuka CD na kwamfutarka. CD yana farawa ta atomatik kuma shigar da window yana buƙewa.
- 2 **Kwamfuta:** Zaɓi yare kuma kaɗa OK.
- 3 **Kwamfuta:** Kada *Shigar* cikin bangaren PC Suite kuma bi umarnin kan allon. Lokacin da ya gama shigarwar, gunkin PC Suite yana bayyana a saman tebur ɗin kwamfutarka.



Saboda sigar yau-yau na PC Suite, je zuwa www.sonyericsson.com/support.

Siffar waya



- 1 Gurbin Memory Stick Micro™ (M2™)
- 2 Allo
- 3  Maballin zaɓi
- 4  Maballin Intanit
- 5  Maballin baya
- 6 Maballin kewayawa/*Kayan kiɗa iko*
- 7  Maballin kulle maballi
- 8  Maballin kunnawa/kashewa
- 9 Kamarar kiran bidiyo
- 10 Lasifikar kunni
- 11  Kara, Maballan zuko kamara mai lamba
- 12  Maballin zaɓi
- 13  Maballin menu na ayyuka
- 14  Maballin C (sharewa)
- 15  Maballin kamara
- 16  Maballin shiru
- 17 Mai haɗawa don caji, abin sawa akunni da kebul na USB
- 18 Ruwan tabarau na kamara

Don karin bayani ➡ *Kewayawa 14.*

Siffar Menu



PlayNow™*



Intaniti*



Nishadi

Ayyukan kan layi*
Wasanni
TrackID™
Kayan bidiyo
VideoDJ™
PhotoDJ™
MusicDJ™
Ramut
Yi rikodin sauti
Zagawar Demo



Kamara



Sako

Rubuta sabo
Ak. s. m. shig.
Email
Mai karanta RSS
Tsararr. sakonni
Akwt.sk.mai fita
Sakonnin da aka aika
Ajiye sakonni
Abokai nawa*
Kira skn. murya
Samfuri
Saituan



Kayan kida



Mai sarrafa fayil/****

Kundin kyamera
Kida
Hotuna
Bidiyo
Jigogi
Shafin yanar sadarwa
Wasanni
Aikace-aikace
Wasu



Lambobi

Sabuwar lamba



Rediyo



Kira**



Duk



An amsa



An buga



An rasa



Oganeza

Kararrawa
 Aikace-aikace
 Kiran bidiyo
 Kalanda
 Dawainiya
 Bayanan kula
 Synchronization
 Mai kidayar lokc.
 Agog. awon gudu
 Kalkaleta
 Memo na lamba



Saituna**



Gaba daya

Bayanan martaba
 Lokc. & kwn.wt.
 Yare
 Daukaka sabis
 Ikon murya
 Sab.abun aukuwa
 Gajerun hanyoyi
 Yanayin kaura
 Tsaro
 Saita maye
 Halin waya
 Sake saitin ainihi



Sauti da fadakarwa

Karan ringi
 Sautin ringi
 Yanayin shiru
 Ringi mai karuwa
 Fadakarwar jijjiga
 Fadakarwar sako
 Sautin maballi



Nuni

Fuskar bngn. waya
 Jigogi
 Allon farawa
 Mai boye allo
 Girman agogo
 Haske
 Shirya sunayen layi*



Kira

Bugn. kira na sauri
 Karkatar da kira
 Canja zuwa layi 2*
 Sarrafa kira
 Lokaci & farashi*
 Nun./boy.lamb.naw.
 Abin sawa akunni



Haduwa*


Bluetooth
 USB
 Aiki tare
 Mai hada na'ura
 Cibiyar sadrw.waya
 Data comm.
 Saitunan Intanit
 Saitunan yawo
 Na'urorin hadi

* Wasu menus-, cibiyar sadarwa- da biyan kuɗi-dogaron afareta ne.

** Yi amfani da maballan kewayawa don motsawa cikin menus mataimaka. Don karin bayani ➡ Kewayawa 14.

Kewayawa

Ana nuna menus na ainihi azaman gumaka. Wasu menu mataimaka suna kunshe da shafuka. Gungura zuwa shafi ta latsa  ko .



Maɓalli

-  Jeka zuwa menu na ainihi ko zaɓi abubuwan da aka sanyawa almar haske.

-  Matsa tsakanin menus da shafuka.

-  Zaɓi zaɓuɓɓuka da aka nuna saman waɗannan maɓallan akan allon.

-  Koma mataki ɗaya baya acikin menus. Latsa ka riƙe don komawa zuwa jiran aiki ko don ƙare aiki.

-  Share abubuwa, kamar hotuna, sautuna da lambobi. Yayin kira, latsa ka riƙe don cire muryar makirufo ɗin.

-  Buɗe menu na ayyuka ➔ *Menu na ayyuka 8.*

-  Buɗe mai lilon.

-  Latsa don ɗaukar hoto ko yin rikodin shirin bidiyo.

-  Daga jiran aiki, latsa ka riƙe don kiran sabis na saƙon murya naka (idan an saita).

-  -  Daga jiran aiki, latsa ka riƙe kowanne daga waɗannan maɓallan don isa ga lambar da tafara tareda wani takmammen harafi.

① - ⑨	<p>Daga jiran aiki, latsa maɓallin lamba kuma sannan ► Kira don bugun kiran sauri.</p> <p>Latsa don gajerun hanyoyi lokacin lilo ► <i>Don amfani da gajerun hanyoyin faifan maɓallin Intanit ko samun damar maɓallai 70.</i></p>
① +	<p>Duba jagorar gajeriyar hanya lokacin amfani da kamara.</p>
✖ 44 →	<p>Daga jiran aiki, latsa ka riƙe sannan ► Mk.mɓll. ko Buƙe don kulle ko buƙw maɓallan wayar.</p>
# →	<p>Kashe sautin ringi lokacin karɓar kira.</p> <p>Latsa ka riƙe don saita wayar zuwa shiru. Kararrawa tana sauti koda an saita wayar a shiru.</p>
▲	<p>Duba bayanin hali acikin jiran aiki.</p> <p>Dada karar yayin kira, ko lokacin amfani da Kayan kiɗa.</p> <p>Zuko waje lokacin amfani da kamara ko duna hotuna.</p> <p>Latsa ka riƙe don komawa kiɗan waka ɗaya.</p> <p>Larsa saubiyu don kin karɓar waya.</p> <p>Latsa ka riƙe don bihun kiran murya, ko ambaci kalmar sihirinka (in an saita) ► <i>Bugun kiran murya 31.</i></p>
▼	<p>Rage karar yayin kira, ko amfani da Kayan kiɗa.</p> <p>Zuko ciki lokacin amfani da kamara ko duba hotuna.</p> <p>Latsa ka riƙe don karkatar da wakan kiɗa ɗaya.</p> <p>Latsa ka riƙe don bugun kira na murya, ko ambaci kalmar sihiinka (in an saita) ► <i>Bugun kiran murya 31.</i></p>
► Bayani	<p>Nemi karin bayani, bayani ko tukwici gameda zaɓaɓɓun fasaloli, menus ko ayyuka samammu a wayarka ► <i>Taimako a wayarka 7.</i></p>
► Kari	<p>Shigar da lissafin zaɓuɓɓuka. Akwai zaɓuɓɓuka daban-daban acikin lissafin zaɓuɓɓukan ya danganta da inda kake a menus.</p>

Ma'aunin yanayi

Wasu gumakan da maiyuwa su bayyana:

Gunki Sifantawa



3G (UMTS) akwai cibiyar sadarwa.



GSM karfin isharar cibiyar sadarwar.



Halin baturi.



Cajin baturi, yana bayyana tareda halin gunkin baturi.



Kira mai shigowa da aka rasa.



Sakon rubutu da aka karɓa.



Sakon Email da aka karɓa.



Sakon hoto da aka karɓa.



Sakon murya da aka karɓa.



Kira mai tafiya.



Kulle maɓalli yana kunne.



An haɗa abin sawa a kunni



Mai tunin kalanda.



Mai tunin dawainiya.

Gajerun hanyoyi

Yi amfani da gajerun hanyoyin faifan maɓalli don zuwa menu da sauri, kuma zaka iya amfani da gajerun hanyoyin maɓllin kewayawa wanda aka ayyana don isa da sauri ga waɗansu ayyuka. Shirya gajerun hanyoyin maɓallin kewayawar don biyan bukatunka.

Amfani da gajerun hanyoyin faifan maɓalli

Daga jiran aiki, je zuwa menus ta latsa da kuma shigar da lambar menu. Lambar menu yana farawa ne daga gumki na hagu a sama kuma yana ketarawa kasa ta hanya hanya misali, lasta saboda abin menu na biyar. Saboda na goma, na shaɗaya da na shabiyo, latsa , kuma akai-akai. Don komawa jiran aiki, latsa ka rike .

Amfani da gajerun hanyoyi na maɓallin kewayawa

Daga jiran aiki, je zuwa gajerun hanyoyi ko aiki ta latsa , , da .

Don shirya gajeriyar hanyar maballin kewayawa

- Daga jiran aiki zaɓi **Menu** ▶ **Saituna** ▶ **Gaba ɗaya** shafin ▶ **Gajerun hanyoyi** kuma zaɓi gajeriyar hanya ▶ **Shirya**.

yaren waya

Zaɓi yaren waya don amfani a menu na wayar ko lokacin rubuta rubutu.

Don canja yaren wayar

- Daga jiran aiki zaɓi **Menu** ▶ **Saituna** ▶ **Gaba ɗaya** shafin ▶ **Yare** ▶ **Yaren waya**. Zaɓi yare.

Daga jiran aiki, kuma zaka iya latsa:

-  8888  don yare na atomatik.
-  0000  don Turanci.

 *Mafi yawan katinan SIM suna saita yaren menu ta atomatik ga kasar inda ka sayi katin SIM naka. In bahaka ba, yaren da aka ayyana shine Turanci.*

Don zaɓar yaren rubutu

- 1 Daga jiran aiki zaɓi **Menu** ▶ **Saituna** ▶ **Gaba ɗaya** shafin ▶ **Yare** ▶ **Yaren rubutu**.
- 2 Gungura zuwa yaren don amfani kuma yi masa alama. ▶ **Ajiye** don fita a menu.

Shigar da haruffa

Shigar da haruffa cikin ɗayan hanyoyi masu zuwa (hanyar shigar da rubutu), misali, lokacin rubuta sakonni:

- Shigar da rubutun taɓi dayawa
- T9™ Text Input

Don canja hanyar shigar da rubutu

- Kafin, ko lokacin shigar da haruffa, latsa ka riƙe  don canja hanyar.

Don canja yaren rubutu

- Kafin, ko lokacin shigar da haruffa, latsa ka riƙe  kuma zaɓi wani yare rubutu.

Zabuɓɓuka lokacin shigar da haruffa

▶ **Kari** don zaɓuɓɓuka lokacin rubuta sako.

Don shigar da haruffa ta amfani da shigarwar taɓi dayawa

- Latsa  -  maimaita harsai harafin da akeso ya bayyana.
- Latsa  don matsawa tsakanin manya da kananan haruffa.
- Latsa ka riƙe  -  don shigar da lambobi.
- Latsa  don share haruffa da lambobi.
- Latsa  don alamomin rubutu na gama gari.
- Latsa  don kara sarari.

T9™ Text Input

Hanyar Text Input T9™ yana aiki da kamus don gane kalmomin da aka fi aiki dasu ga kowacce latsawar maɓallai. Wannan hanyar, ka latsa kowane maɓalli sau ɗaya kawai, koda harafin da ka ke nema ba shi bane harafin farko a maɓallin.

Don shigar da haruffa ta amfani da T9 Text Input

- 1 Don shigar da rubutu, dole kazama a cikin aiki inda shigar da rubutu zai yiwu, misali, daga jiran aiki zaɓi **Menu** ► **Sako** ► **Rubuta sabuwa** ► **Sakon rubutu**.
- 2 Misali, don rubuta kalmar “Jane”, latsa (5), (2), (6), (3).
- 3 Idan kalmar da aka nuna itace wacce kake so, latsa (#~3) don karɓa da kara sarari. Don karɓar kalma batara da kara sarari ba, latsa [↵]. Idan harafin da bayyana bashi ne kake so ba, latsa [↵] ko [↵] akai-akai don duba maimako kalmomi. Karɓi kalma da kara sarari ta latsa (#~3).
- 4 Ci gaba da rubuta sakon. Don shigar da alamar rubutu, latsa (1) kuma sannan [↵] ko [↵] akai-akai latsa (#~3) don karɓa da kara wuri.

Don kara kalmomi zuwa kamus na T9 Text Input

- 1 Lokacin shigar da haruffa ► **Kari** ► **Tad.** bakin kalma.
- 2 Shirya kalma ta amfani da shigarwar taɓi da yawa. Yi amafani da [↵] kuma [↵] don motsa kibiya tsakanin haruffan. Don share harafi, latsa (C). Don share kalmar gabaɗaya, latsa ka riƙe (C). Lokacin da ka shirya kalmar ► **Sa**. An kara kalma zuwa kamus na T9 Text Input. Lokaci na gaba idan ka shigar da wananan kalmar ta amfani da T9 Text Input, zata bayyana a lissafin maimakon kalmomi.

Tsinkayar kalma ta gaba

Lokacin rubuta sako, zaka iya amfani da T9 Text Input don thinkayar kalmar ta gaba, idan da anyi amfani da ita a jumla.

Don kunna/kashe tsinkayar kalma ta gaba

- Lokacin shigar da haruffa ► **Kari** ► **Rubuta zabuka** ► **Kalma mai zuwa**.

Don amafani da tsinkayar kalma ta gaba

- Lokacin shigar da haruffa, latsa (#~3) don karɓa ko cigaba.


Mai sarrafa fayil

Yi amfani da **Mai sarrafa fayil** don rike abubuwa kamar hotuna, shirye-shiyen bidiyo, kiɗa, jigogi, shafukan yanar sadarwa, wasanni da aikace-aikace waɗanda aka ajiye a kwakwalwar ajiyar waya ko akan katin kwakwalwar ajiya.

Memory Stick Micro™ (M2™)

Wayarka tana goyan bayan Memory Stick Micro™ (M2™) katin kwakwalwar ajiya daɗin karin sararin ma'aji zuwa wayarka don ajiye fayiloli waɗanda suke kunshe da hotuna ko kiɗa, misali.

Don sakawa da cire katin kwakwalwar ajiya



- 1 Saka katin kwakwalwar ajiya kamar yadda aka nuna (tareda lambobin suna fuskantar sama).
- 2 Latsa gefen don saki da cire katin.

Hakanan zaka iya matsar da kwafe fayiloli tsakanin kwamfuta da katin kwakwalwar ajiyar. Lokacin da aka saka katin kwakwalwar ajiya, ana ajiye fayiloli ta atomatik zuwa gareshi idan baka zaɓi ajiye fayilolin zuwa kwakwalwar ajiyar waya ba.

Kirkiri manyan fayiloli mataimaka don matsar da ko kwafe fayiloli zuwa. Ana matsar da wasanni da aikace-aikace a tsakanin **Wasanni** da **Aikace-aikace** manyan fayiloli kuma daga kwakwalwar ajiyar wayar zuwa katin kwakwalwar ajiyar. Ana ajiye fayilolin da ba'a ganesu ba cikin **Wasu** babban fayil ɗin. Lokacin rike fayiloli, zaka iya zaɓar yawancin ko duk fayiloli a babban fayil a lokaci daya don duk abubuwa banda **Wasanni** kuma **Aikace-aikace**.

Halin kwakwalwar ajiya

Idan duk samammiyar kwakwalwar ajiya ta cika, ba zaka iya ajiye wasu fayiloli ba sai an share abun ciki. Bincika yanayin kwakwalwar ajiya don wayarka da katin kwakwalwar ajiya ta sa alamar haske a babban fayil ► **Kari** ► **Halin kwkl.ajiya**.

Shafukan menu na mai sarrafa fayil

An kasa mai sarrafa fayil cikin shafuka uku, kuma an sanya gumaka don nuna inda aka ajiye fayilolin.

- **Duk fayiloli** – duk abun ciki a kwakwalwar ajiyar wayar da kan katin kwakwalwar ajiyar.
- **A Memory Stick** – duk abun ciki kan katin kwakwalwar ajiyar.
- **Cikin waya** – duk abun ciki a kwakwalwar ajiyar wayar.

Bayanin fayil

Duba bayanin fayil ta sa masa alama ► **Kari** ► **Bayani**. Abubuwan da aka saukar, ko aka karɓa ta amfani da ɗayan samammun hanyoyin canja wuri, maiyuwa sunada kariyar haƙƙin mallaka. Idan ankare fayil, bazaka iya kwafe ko aika fayil ɗin ba. Fayil na haƙƙin mallaka mai kariya yana da alamar maɓalli.

Don amfani da fayil daga mai sarrafa fayil

- 1 Daga jiran aiki zaɓi **Menu** ► **Mai sarrafa fayil** kuma buɗe babban fayil.
- 2 Gungura zuwa fayil ► **Kari**.

Don matsar da ko kwafe fayil zuwa kwakwalwar ajiya

- 1 Daga jiran aiki zaɓi **Menu** ► **Mai sarrafa fayil** kuma zaɓi babban fayil.
- 2 Gungura zuwa fayil ► **Kari** ► **Sarrafa fayil** ► **Matsar** don matsawa da fayil ko ► **Kari** ► **Sarrafa fayil** ► **Kwafi** don kwafe fayil.
- 3 Zaɓi don matsar da ko kwafe fayil ɗin zuwa **Waya** ko **Memory Stick**.

Don matsar da ko kwafe fayiloli zuwa kwamfuta

- ► *Canja wurin fayiloli ta amfani da keɓul na USB 76.*

Don kirƙirar babban fayil mataimaki

- 1 Daga jiran aiki zaɓi **Menu** ► **Mai sarrafa fayil** kuma buɗe babban fayil.
- 2 ► **Kari** ► **Sabon bab. fayil** kuma shigar da suna don babban fayil ɗin.
- 3 ► **Ok** don ajiye babban fayil ɗin.

Don zaɓar fayiloli da yawa

- 1 Daga jiran aiki zaɓi **Menu** ► **Mai sarrafa fayil** kuma buɗe babban fayil.
- 2 ► **Kari** ► **Alama** ► **Alama a yawanci**.
- 3 Gungura don zaɓar fayiloli ► **Alama** ko **Cr. alama**.

Don zaɓar duk fayiloli a babban fayil

- Daga jiran aiki zaɓi **Menu** ► **Mai sarrafa fayil** kuma buɗe babban fayil ► **Kari** ► **Alama** ► **Alm. duk**.

Don share fayil ko babban fayil mataimaki daga mai sarrafa fayil

- 1 Daga jiran aiki zaɓi **Menu** ► **Mai sarrafa fayil** kuma buɗe babban fayil.
- 2 Gungura zuwa fayil ► **Kari** ► **Share**.

Zaɓuɓɓukan katin kwakwalwar ajiya

Bincika halin kwakwalwar ajiya ko tsara katin kwakwalwar ajiya don share duk bayani.

Don amfani da zaɓuɓɓukan katin kwakwalwar ajiya

- Daga jiran aiki zaɓi **Menu** ► **Mai sarrafa fayil** kuma zaɓi **A Memory Stick** shafin ► **Kari** saboda zaɓuɓɓuka.

Kira

Kira, kiran bidiyo, lambobi, lissafin kira, bugun kira na sauri, ikon murya, kungiyoyi, katunan kasuwanci.

Yin kira da karɓa

Kafin kayi kira ko karɓa, dole ka kunna wayarka kuma ka zamo tsakanin kewayon cibiyar sadarwa. ► **Kunna wayarka 6**. Don yin kiran bidiyo ► **Kiran bidiyo 24**.

Cibiyoyin sadarwa

Lokacin da ka kunna wayarka, tana zaɓan ɗakin cibiyar sadarwarka idan wannan yana cikin kewayo. Idan bata cikin kewayo, zaka iya amfani da wata cibiyar sadarwa, idan afaretan cibiyar sadarwarka yana da yarjejeniya wadda ta baka damar yin haka. Wannan ake kira yawo.

Zabi cibiyar sadarwa don amfani, ko zaka iya kara cibiyar sadarwa zuwa cibiyar sadarwar daka fi so. Zaka iya canja tsarin a cibiyoyin sadarwar da aka zaɓa yayi bincike ta atomic.

Wayarka kuma yana canjawa ta automatik tsakanin cibiyoyin sadarwar GSM da 3G (UMTS) dogaro da samuwa. Wasu afaretocin cibiyar sadarwa suna baka damar canja cibiyoyin sadarwa ta hannu, tunda binciken samammun cibiyoyin sadarwa yana cin wutar baturi.

Don duba samammun zaɓuɓɓukan cibiyar sadarwa

- Daga jiran aiki zaɓi **Menu** ▶ **Saituna** ▶ **Haɗuwa shafin** ▶ **Cibiyar sadarw. waya.**

Don canja cibiyoyin sadarwa

- 1 Daga jiran aiki zaɓi **Menu** ▶ **Saituna** ▶ **Haɗuwa shafin** ▶ **Cibiyar sadarw. waya** ▶ **Cib. sadar. t. GSM/3G.**
- 2 ▶ **GSM** da **3G** (automatik) ko ▶ **GSM kawai.**

Don karin bayani, tuntuɓi afaretan cibiyar sadarwarka.

Don yin kira

- 1 Shigar da lambar waya (tareda lambar kasar waje da lambar yanki, idan an zartar).
- 2 ▶ **Kira** don yin kiran murya ko ▶ **Kari** don duba zaɓuɓɓuka, kamar **Yi kiran bidiyo** ➤ **Kiran bidiyo 24.**
- 3 ▶ **Kas.kira** don kare kiran.

 **Zaka iya kiran lambobi daga lambobinka da lissafin kira** ➤ **Lambobi 25, kuma** ➤ **Lissafin kirat 29. Hakanan zaka iya amfani da muryarka don yin kira** ➤ **Ikon murya 30.**

Don yin kiran kasar waje

- 1 Latsa ka rike  harsai alamar + ta bayyana.
- 2 Shigar da lambar kasa, lambar yanki (batara da sifilin farko ba) da lambar waya. ▶ **Kira** don yin kiran bidiyo, ko ▶ **Kari** ▶ **Yi kiran bidiyo** don yin kiran bidiyo.

Don sake buga lamba

- Idan haɗin kira ya gaza kuma **Sake jarabawa?** yana bayyana ▶ **Ee.**

 **Kar ka rike wayar kusa da kunninka lokacin jira. Lokacin da kira ya haɗu, wayar tana bada sigina mai kara.**

Don amsa ko kin karɓar kira

- ▶ **Amsa** ko ▶ **Kan aiki.**

Don kashe makirufu

- 1 Latsa ka rike .
- 2 Don ci gaba da magana latsa ka rike  sake.

Don kunna lasifika ko kashewa yayin kiran murya

- ▶ **Kari** ▶ **Kunna lasifika ko Kashe lasifika.**

 *Kar ka riƙe wayar kusa da kunninka lokacin amfani da lasifika. Wannan zai iya lalata jinka.*

Don canja karar lasifikar kunni

- Latsa  don daɗa ko  don rage karan lasifikar kunni lokacin kira.

Kiran da aka rasa

Lokacin da aka saita menu na ayyuka zuwa tsoho, kiran da aka rasa suna bayyana acikin **Sab.abun aukuwa** shafin a jiran aiki. In an saita faɗakarwa zuwa tsoho **Kiran da aka rasa**: yana bayyana a jiran aiki ▶ **Menu na ayyuka 8.**

Don bincika kiran da aka rasa daga jiran aiki

- Idan an saita menu na ayyuka zuwa tsoho, latsa  ▶ **Sab.abun aukuwa** shafin. Gungura  ko  don zaɓar lamba kuma ▶ **Kira** don kira.
- Idan an saita faɗakarwa zuwa tsoho, ▶ **Kira** ▶ **An rasa** shafin. Gungura  ko  don zabin lamba da ▶ **Kira** don kira.

Kiran gaggawa

Wayarka tana goyon bayan lambobin gaggawa na kasashen waje, misali, 112, 911. waɗannan lambobi za'a iya amfani da su kamar yau da kullun don yin kiran gaggawa a kowace kasa, tareda ko ba tareda saka katin SIM ba, idan cibiyar sadarwar 3G (UMTS) ko GSM tana cikin kewayo.

 *A wasu kasashen, maiyuwa a bunkasa wasu lambobin gaggawa. Don haka maiyuwa afaretan cibiyar sadarwarka ya ajiye karin lambobin kiran gaggawa na gida a katin SIM din.*

Don yin kiran gaggawa

- Shigar da, misali, 112 (Lambar kiran gaggawa kasashen waje) ▶ **Kira.**

Don duba lambobin gaggawarka na gida

- Daga jiran aiki zaɓi **Menu** ▶ **Lambobi** ▶ **Kari** ▶ **Zaɓuɓɓuka** ▶ **Lambob.** n. musam. ▶ **Lambob. gaggawa.**

Kiran bidiyo

Duba mutum akan allo yayin kira.

Kafin ka fara

Don yin kiran bidiyo kai da wanda kake kira kuna bakatar biyan kudi wanda yake goyan bayan sabis na 3G (UMTS), kuma kana bukatar kasancewa cikin kewayon cibiyar sadarwar 3G(UMTS). Akwai sabis na 3G (UMTS) lokacin da gunkin 3G ya bayyana a ma'aunin halin.

Yanayin demo na kiran bidiyo

Zaka iya amfani da yawancin ayyukan kiran bidiyo ba tareda yin kira ba, misali, don shirya duba kamara kafin kira, daga jiran aiki zaɓi **Menu** ► **Oganeza** ► **Kir. bidiyo**.

Don yin kiran bidiyo

- Lokacin da akwai sabis na 3G (UMTS), zaka iya yin kiran bidiyo a dayan hanyoyi masu biyowa:
 - Shigar da lambar waya (fihirisar kasar waje da lambar yanki idan sun dace) ► **Kari** ► **Yi kiran bidiyo**.
 - Daga jiran aiki zaɓi **Menu** ► **Lambobi** kuma gungura lambar don kira. Yi amfani da  ko  don zaɓin lamba ► **Kari** ► **Yi kiran bidiyo**.

- Daga jiran aiki zaɓi **Menu** ► **Oganeza** ► **Kir. bidiyo** ► **Kira...** ► **Lambobi** don daukar lambar waya ► **Kira** don shigar da lambar waya ► **Kira**.

Don zuko bidiyo mai fita kusa ko nisa

- Latsa  don zuko bidiyo mai fita kusa kuma latsa  don zukowa waje.

Don karɓar kiran bidiyo mai shigowa

- ► **Amsa**.

Don kare kiran bidiyo

- ► **Kas.kira**.

Zabuɓɓukan kiran bidiyo

► **Kari** saboda zabuɓɓuka masu biyowa:

- **Sauya kamera** – don canjawa tsakanin na ainihin da kamarar kiran bidiyo. Yi amfani da kamarar ta ainihin don nuna cikakken hoton kewayenka ga mai karɓar.
- **Tsaida kyamera/Fara kamera** – kunna ko kashe kamarar bidiyo. Ana nuna wani hoto lokacin a kashe.
- **Ajiye hoto** – ajiye hoton wanda aka nuna a babban nuni, misali, hoton mai kira mai shigowa.

- **Kamara** – zaɓuɓɓuka
 - **Haske** – dai-daita matakin don hoton mai fita.
 - **Kunna yanay. dr.** – yi amfani lokacin yanayin haske mara kyau. Wannan saitin yana rinjayar bidiyo mai fita.
- **Sauti** – zaɓuɓɓuka yayin kiran bidiyo
 - **Kashe lasifika/Kunna lasifika** – sauti mai shigowa.
 - **Sa makirfo shiru/Cire ma mk. shiro** – makirfo a kashe ko a kunne.
 - **Canja wurin sauti** – don daga kayan aikin abin sawa a kunni na Bluetooth.
- **Shimfiɗa** – zaɓuɓɓuka
 - **Canja hotuna** – nuna bidiyo mai shigowa ko mai fita a cikakken girman nuni.
 - **Boye kramin. hot./Nuna karamin ht.**
 - **Hoton madubi** – nuna hoton kamara mai fita.
- **Saituna** – lokacin amsawa
 - **Yanayin amsa** – saita kamarar kiran bidiyon zuwa akunne ko akashe.
 - **Hoto. maimako** – saita hoto don nuna mai karɓar lokacin da kamara take akashe.
 - **Zaɓɓ. abu.ms.jiw.** – zaɓi idan makirfo, lasifika, ko gaba ɗayansu akunne ko akashe.
 - **Nagartan bidiyo** – zaɓi kimar hoto don kiran bidiyo. Canje-canje basa haifar da rinjaye yayin kira mai gudana.

Lambobi

Zaka iya ajiye bayanin lambarka a kwakwalwar ajiyar wayar ko a katin SIM.

Zaɓi bayanin wani lamaba – **Lambobin waya** ko **Lambobin SIM** – an nuna azaman tsoho.

Don duba bayani da saituna

- Daga jiran aiki zaɓi **Menu** ▶ **Lambobi** ▶ **Kari** ▶ **Zaɓuɓɓuka**.

Tsohuwar lamba

Idan **Lambobin waya** an zaɓi azaman tsoho, lambobinka suna nuna duk bayanin da aka ajiye a ciki **Lambobi**. Idan ka zaɓi **Lambobin SIM** azaman tsoho, lambobinka suna nuna bayanin da ya dogara da katin SIM ɗin.

Don zaɓar tsoffin lambobi

- 1 Daga jiran aiki zaɓi **Menu** ▶ **Lambobi** ▶ **Kari** ▶ **Zaɓuɓɓuka** ▶ **Na ci gaba** ▶ **Tsoffin lambobi**.
- 2 ▶ **Lambobin waya** ko **Lambobin SIM**.

Lambobin waya

Ajiye lambobi a wayar tareda sunaye lambobin waya da bayanin sirri.

Hakanan zaka iya kara hotuna da sautunan ringi zuwa lambobi. Yi amafani , ,  kuma  don gungurawa tsakanin shafuka da filayen bayanin su.

Don kara lambar waya

- 1 In **Lambobin waya** an zaɓi azaman tsoho, daga jiran aiki zaɓi **Menu** ► **Lambobi** ► **Sabuwar lamba** ► **Kara**.
- 2 Shigar da sunan ► **Ok**.
- 3 Shigar da lambar ► **Ok**.
- 4 Zaɓi zaɓin lamba.
- 5 Gungura tsakanin shafuka kuma zaɓi filayen don kara bayani. Don shigar da alama kamar **@**, ► **Kari** ► **Kara alama** kuma zaɓi alama ► **Sa**.
- 6 Lokacin da aka kara duk bayanin ► **Ajiye**.

Don share lamba

- 1 ► **Lambobi** kuma gungura zuwa lamba.
- 2 Latsa  kuma zaɓi **Ee**.

Don share duk lambobin waya

- In **Lambobin waya** an zaɓi azaman tsohuwa, daga jiran aiki **Menu** ► **Lambobi** ► **Kari** ► **Zabuɓɓuka** ► **Na ci gaba** ► **Share duk lambobi** ► **Ee** kuma ► **Ee**. Ba'a share sunaye da lambobin a katin SIM ba.

Lambobin SIM

Zaka iya ajiye lambobi a katin SIM naka.

Don kara lambar SIM

- 1 Idan **Lambobin SIM** an zaɓi azaman tsoho, daga jiran aiki zaɓi **Menu** ► **Lambobi** ► **Sabuwar lamba** ► **Kara**.
- 2 Shigar da sunan ► **Ok**.
- 3 Shigar da lambar ► **Ok** kuma zaɓi zaɓin lamba. Kara karin bayani idan akwai ► **Ajiye**.

Don ajiye sunaye da lambobin waya ta atomatik a katin SIM

- Lokacin da **Lambobin waya** an zaɓi azaman tsoho, daga jiran aiki zaɓi **Menu** ► **Lambobi** ► **Kari** ► **Zabuɓɓuka** ► **Na ci gaba** ► **Ajiy.t. atom. a SIM** kuma zaɓi **Kunnawa**.

Halin kwakwalwar ajiya

Adadin lambobin da zaka iya ajewa a wayar ko a katin SIM ɗin ya danganta da sararin kwakwalwar ajiya.

Don duba halin kwakwalwar ajiya

- Daga jiran aiki zaɓi **Menu** ► **Lambobi**
► **Kari** ► **Zabuɓɓuka** ► **Na ci gaba**
► **Halin kwkl.ajiya**.

Amfani da lambobi

Za'a iya amfani da lambobi ta hanyoyi dayawa. A kasa zaka iya ganin yadda:

- Wayar kira da lambobin SIM.
- Aika lambobin waya zuwa wata na'ura.
- Kwafi lambobi zuwa waya da katin SIM.
- Kara hoto ko sautin ringi zuwa lambar waya.
- Shiryar lambobi.
- Haɗa lambobinka aiki tare.

Don kiran lambar waya

- 1 Daga jiran aiki zaɓi **Menu** ► **Lambobi**. Gungura zuwa, ko shigar da harafin farko ko haruffan lambar.
- 2 Lokacin da aka sawa lamba alama latsa  ko  don zaɓin lamba ► **Kira** don yin kiran bidiyo, ko ► **Kari** ► **Yi kiran bidiyo** don yin kiran bidiyo.

Don kiran lambar SIM

- Idan **Lambobin SIM** tsohone daga jiran aiki zaɓi **Menu** ► **Lambobi** kuma lokacin da aka yiwa lambar alama latsa  ko  don zaɓin lamba. ► **Kira** don yin kiran bidiyo, ko ► **Kari** ► **Yi kiran bidiyo** don yin kiran bidiyo.
- Idan **Lambobin waya** an saita azaman tsoho daga jiran aiki zaɓi **Menu** ► **Lambobi** ► **Kari** ► **Zabuɓɓuka** ► **Lambobin SIM** kuma zaɓi lamba ► **Kira** don yin kiran murya, ko ► **Kari** ► **Yi kiran bidiyo** don yin kiran murya.

Don aika lamba

- ► **Lambobi** kuma zaɓi lamba ► **Kari** ► **Aika lamba** kuma zaɓi hanyar canja wuri.

Don aika duk lambobi

- Daga jiran aiki zaɓi **Menu** ► **Lambobi** ► **Kari** ► **Zabuɓɓuka** ► **Na ci gaba** ► **Aika duk lambobi** kuma zaɓi hanyar canja wuri.

Don kwafe sunaye da lambobi zuwa katin SIM dɪn

- 1 Daga jiran zaɓi **Menu** ► **Lambobi** ► **Kari** ► **Zabuɓɓuka** ► **Na ci gaba** ► **Kwafi zuwa SIM**.
- 2 Zaɓi wani zaɓi.

 Lokacin kwafe duk lambobi daga wayar zuwa katin SIM dɓn, za'a musanya duk bayanin katin SIM daya kasance.

Don kwafe sunaye da lambobi zuwa lambobin waya

- 1 Daga jiran aiki zaɓi **Menu ▶ Lambobi ▶ Kari ▶ Zabuɓɓuka ▶ Na ci gaba ▶ Kwafi daga SIM.**
- 2 Zabi wani zaɓi.

Don kara hoto, sautin ringi ko bidiyo zuwa lambar waya

- 1 Daga jiran aiki zaɓi **Menu ▶ Lambobi kuma zaɓi lambar ▶ Kari ▶ Shirya lamba.**
- 2 Zabi shafi mai alaka da juna sannan zaɓi **Hoto ko Sautin ringi ▶ Kara.**
- 3 Zabi wani zaɓi da kuma wani abu ▶ **Ajiye.**

 Idan biyan kuɗin ka yana goyan bayan sabis na shaidar kiran layi (CLI), zaka iya keɓance sautin ringi na sirri zuwa lambobi.

Don shirya lambar waya

- 1 Daga jiran aiki zaɓi **Menu ▶ Lambobi kuma zaɓi lamba ▶ Kari ▶ Shirya lamba.**
- 2 Gungurawa zuwa shafin mai dacewa kuma filin don shiryawa ▶ **Shirya.**
- 3 Shirya bayanana ▶ **Ajiye.**

Don shirya lambar SIM

- 1 Idan Lambobin SIM tsohuwace daga jiran aiki zaɓi **Menu ▶ Lambobi** kuma zaɓi sunan da lamba don shiryawa. Idan Lambobin waya tsohone daga jiran aiki zaɓi **Menu ▶ Lambobi ▶ Kari ▶ Zabuɓɓuka ▶ Lambobin SIM** kuma zaɓi sunan da lambar don shiryawa.
- 2 ▶ **Kari ▶ Shirya lamba** kuma shirya suna da lamba.

Aiki tareda lambobi

Zaka iya sa lambobinka aiki tareda lambobin aikace-aikace a yanar sadarwar. Don karin bayani ➡ *Aiki tare 72.*

Don ajiye da gyara lambobi tareda katin kwakwalwar ajiya

- Daga jiran aiki zaɓi **Menu ▶ Lambobi ▶ Kari ▶ Zabuɓɓuka ▶ Na ci gaba ▶ Ajiy. wari zw. M.S. ko Maida daga M.S.**

Don zaɓar yanayin jere don lambobi

- Daga jiran aiki zaɓi **Menu ▶ Lambobi ▶ Kari ▶ Zabuɓɓuka ▶ Na ci gaba ▶ Yanayin jere.**

Lissafin kira

Bayani gameda kiran kwanannan.

Don kiran lamba daga lissafin kira

- 1 Daga jiran aiki, ► **Kira** kuma zaɓi shafi.
- 2 Gungura zuwa sunan ko lamba don kira ► **Kira** don yin kiran murya, ko ► **Kari** ► **Yi** kiran bidiyo don yin kiran murya.

Don kara lambar lissafin kira zuwa lambobi

- 1 Daga jiran aiki, ► **Kira** kuma zaɓi shafi.
- 2 Gungura zuwa lambar don karawa ► **Kari** ► **Ajiye** lamba.
- 3 ► **Sabuwar** lamba don kirƙirar sabuwar lamba, ko zaɓar lambar data kasance don kara lambar zuwa gareta.

Don share lissafin kiran

- ► **Kira** ► **Duk** shafin ► **Kari** ► **Share** duk.

Bugun kiran sauri tareda hotuna

Ajiye lamaba a matsayi 1-9 a wayarka don samun damarsu a saukake. Bugun kiran sauri ya dogarane kan tsoffin lambobinka ► **Tsohuwar lamba 25**. Misali, zaka iya bugun kiran sauri da ajiyayyun lambobin katin SIM.

Idan ka kara lambobin tareda hotuna don bugun kiran sauri na matsayi, hotunan lambar suna bayyana don sassaukan la'akari ► **Don kara hoto, sautin ringi ko bidiyo zuwa lambar waya 28**.

Don shirya lambobin bugun kiran sauri

- 1 Daga jiran aiki zaɓi **Menu** ► **Lambobi** ► **Kari** ► **Zabuɓɓuka** ► **Bugn**. kiran na sauri.
- 2 Gungura zuwa wurin ► **Kara** ko ► **Kari** ► **Sauya**.

Don bugun kiran sauri

- Daga jiran aiki, shigar da lambar wuri ► **Kira**.

Sakon murya

Idan biyan kuɗinka ya kunshi sabis na amsawa, masu kira za su iya barin sakon murya lokacin da ba zaka iya amsa kira ba.



Tuntubi afaɗetan cibiyar sadarwarka don lambar sakon murya naka ko don karin bayani.

Don kiran sabis din sakon muryar naka

- Latsa ka rike (1). Idan ka shigar da lambar sakon murya, ► **Ee** kuma shigar da sunan.

Don shirya lambar sakon muryar naka

- Daga jiran aiki zaɓi **Menu** ► **Sako** ► **Saituna** ► **Lambr. skn. murya**.

Ikon murya

Sarrafa kira tareda muryarka ta kirkirar umarnin murya zuwa:

- Bugun kiran murya – kira wasu ta faɗin sunayen su.
- Kunna ikon murya ta ambatonb “kalmar sihiri”.
- Amsa ko ki amsa kira lokacin amfani da abin sawa a kunni.

Kafin bugun kiran murya

Kunna aikin bugun kiran muryar kuma yi rikodin umarnin muryarka. Wani gumki yana bayyana kusa da lambar wayar dake da umarnin murya.

Don kunna bugun kiran murya da rikodin sunaye

- 1 daga jiran aiki zaɓi **Menu** ► **Saituna** ► **Gaba ɗaya shafin** ► **Ikon murya** ► **Bugun kiran murya** ► **Kunna** ► **Ee** ► **Sabuwmuryaar** kuma zaɓi lamba.
- 2 Idan lambar tana da lamba fiye da ɗaya, yi amfani da  kuma  don duba lambobin. Zaɓi lambar don kara umarnin muryar gareta. Yi rikodin umarnin murya kamar “Wayar hannu ta John”.
- 3 Umarni zai bayyana. Jira don sautin kuma faɗi umarnin don yin rikodi. Ana sake kunna maka umarnin muryar.
- 4 Idan rikodin yayi sauti OK ► **Ee**. Idan bai yiba ► **A'a** kuma maimaita mataki na 3.
- 5 Don rikodin wani umarnin murya ga lamba ► **Sabuwmuryaar** ► **Kara** kuma maimaita taku 2-4 a sama.

Sunan mai kira

Ji sunan lambarka da akayi rikodi lokacin da ka karɓi kira daga wannan lambar.

Don kunna ko kashe sunan mai kiran

- Daga jiran aiki zaɓi **Menu** ► **Saituna** ► **Gaba ɗaya shafin** ► **Ikon murya** ► **Kun.sunan mai kira**.

Bugun kiran murya

Fara bugun kiran murya daga jiran aiki ta amfani da wayar, abin sawa akunni mai daukuwa, na'urar kai ta Bluetooth ko ta fadin kalmar sihirinka.

Don yin kira

- 1 Daga jiran aiki, latsa ka rike dayan maballan kara.
- 2 Jira sautin kuma fadi sunan da aka yi rikodi, misali "Wayar hannu ta John". Za'a sake kunna maka sunan kuma an hada kiran.

Don yin kira tareda abin sawa akunni

- Daga jiran aiki, latsa ka rike maballan abin sawa akunni, ko latsa maballan na'urar kai ta Bluetooth.

Kalmar sihirin

Yi rikodi da amfani da umarnin murya azaman kalmar sihiri don kunna ikon murya ba tareda latsa kowane maballi ba. Za'a iya amfani da kalmar sihirin kawai tareda abin sawa akunni.

-  *Zabi kalma mai tsayi, wacce ba'a saba ba ko yankin jumla wanda za'a iya gane shi a saukake daga bangon baya na magana gama gari.*

Don kunna da yin rikodin kalmar sihirin

- 1 Daga jiran aiki zabi Menu ► Saituna ► Gaba daya shafin ► Ikon murya ► Kalmar sihiri ► Kunna.
- 2 Umarni zai bayyana. ► Ci gaba. Jira sautin kuma fadi kalmar sihirin.
- 3 ► Ee don karba ko ► A'a don yin rikodin sabuwar kalmar sihiri.
- 4 Umarni zai bayyana. ► Ci gaba kuma zabi mahalli wanda acikin sa za'a kunna kalmar sihirinka.

Amsawar murya

Amsa ko ki amsa kira mai shigowa ta amfani da muryarka, lokacin amfani da abin sawa akunni.

-  *Zaka iya amfani da fayil na MIDI, WAV (16 kHz), eMelody ko iMelody azaman sautin ringi tareda amsawar murya.*

Don kunna amsawar murya da yin rikodin umarnin amsawar murya

- 1 Daga jiran aiki zabi Menu ► Saituna ► Gaba daya shafi ► Ikon murya ► Amsawar murya ► Kunna.
- 2 Umarni zai bayyana. ► Ci gaba. Jira sautin kuma fadi "Amsa", ko wata kalma.
- 3 ► Ee don karba ko ► A'a don sabon rikodi.

- 4 Umarni zai bayyana. ► **Ci gaba.** Jira sautin kuma fadī “akan aiki”, ko wata kalma.
- 5 ► **Ee** don karfa ko ► **A'a** don sabon rikodi.
- 6 Umarni zai bayyana. ► **Ci gaba** kuma zaɓi mahallin da acikin sa za'a kunna amsawar murya.

Don amsa ko kin amsa kira ta amfani da umamin murya

- Lokacin da wayar tayi ringi, fadī:
 - “Amsa” don haɗa kiran.
 - “Akan aiki” don kin karɓar kiran.

Don shirya umamin muryar naka

- 1 Daga jiran aiki zaɓi **Menu** ► **Lambobi** kuma gungura lamaba.
- 2 ► **Kari** ► **Shirya** lamba kuma gungura zuwa shafin maidacewa.

Don sake yin rikodin umamin murya

- 1 Daga jiran aiki zaɓi **Menu** ► **Saituna** ► **Gaba** ɗaya shafin ► **Ikon murya** ► **Bugun kiran murya** ► **Shirya sunaye.**
- 2 Zaɓi umarni ► **Kari** ► **Sauya murya.**
- 3 Jira sautin kuma fadī umarnin.



Karkata kira

Karkata kira, misali, zuwa sabis na amsawa.



Lokacin da aka kunna aikin karkata kira, ba'a samun wasu zaɓuɓɓukan karkata kira. ► Kuntataccen bugun kira 35.

Wayarka tana da zaɓuɓɓuka masu zuwa:

- **Karkatr. koyaushe** – duk kira.
- **Idan ana kan aiki** – idan kira yana gudana.
- **Ba za'a iya sm. ba** – idan an kashe ko ba'a sameshiba.
- **Babu amsa** – idan ba'a amsaba a kayyadadden lokaci.

Don kunna karkata kira

- 1 Daga jiran aiki zaɓi **Menu** ► **Saituna** ► **Kira** shafin ► **Karkatar da kira.**
- 2 Zaɓi nau'in kira da kuma zaɓin karkatawa ► **Kunna.**
- 3 Shigar da lambar wayar don karkatar da kiranka zuwa, ko latsa **Dubawa** don nemo lamba ► **Ok.**

Don kashe karkata kira

- Gungura zuwa zaɓin karkata kiran ► **Kashe.**

Fiye da kira ɗaya

karɓar fiye da kira ɗaya kai tsaye.



Sabis na jiran kira

Lokacin da aka kunna wannan zakaji kara idan ka karɓi kira na biyu.

Don kunna ko kashe sabis na jiran kiran

- Daga jiran aiki zaɓi **Menu** ▶ **Saituna**
▶ **Kira** shafin ▶ **Sarrafa kira** ▶ **Jiran kira**.

Don yin kira na biyu

- 1 ▶ **Kari** ▶ **Rike** don rike kira mai gudana.
- 2 Shigar da lambar don kira ▶ **Kari** ▶ **Kira**.

Don karɓar kiran murya na biyu

- Lokacin da ka karɓi kira na biyu, zaka iya:
 - ▶ **Amsa** kuma sanya kira mai gudana a rike.
 - ▶ **Kan aiki** don kin karaɓa da kuma ci gaba da kira mai gudana.
 - ▶ **Sauya kira mai aiki** don amsa da kare kira mai gudana.



Karɓar kiran murya biyu

Idan Kanada kira mai gudana da ariƙe, zaka iya:

▶ **Kari** don zaɓuɓɓuka:

- **Canja** – canja tsakanin kiran guda biyu.
- **Haɗa kira** – haɗa kiran guda biyu.
- **Canja wurin kira** – haɗa kiran guda biyu. An katse ka daga duk kiran biyu.

▶ **Kas.kira** saboda zaɓuɓɓuka:

- **Ee** – ɗauko da kira ariƙe.
- **A'a** – kare kira biyu.

Baza ka iya amsa kira na uku ba tareda kare ɗaya daga cikin kira biyun farko ba saidai haɗa su cikin kiran taro.

Kiran taro

Fara kiran taro ta haɗa kira mai gudana da kira ariƙe. Sannan sai ka sanya taron ariƙe kuma kara kusan yan takara biyar, ko yi wani kira.



Maiyuwa yazama akwai karin caji don kira wanda ya shafi ribanyayyun bangarori; tuntubi afaɗetan cibiyar sadarwarka don karin bayani.

Don haɗa kira guda biyu cikin kiran taro

- ▶ **Kari** ▶ **Haɗa kira**.

Don kara sabon ɗan takara

- ▶ **Kari** ▶ **Rike** don sanya haɗaɗɗun kira arike.
- ▶ **Kari** ▶ **Kara kira** kuma kira mutum na gaba don karawa zuwa kiran taron.
- ▶ **Kari** ▶ **Haɗa kira**.
- Maimaita taku 1-3 don kara karin yan takara.

Don sakin ɗan takara

- ▶ **Kari** ▶ **Saki ɓangare**, kuma zaɓi ɗantakarn don sakin sa daga kiran taron.

Don samun taɗi na sirri

- ▶ **Kari** ▶ **Yi magana da** kuma zaɓi ɗan takara don magana dashi.
- ▶ **Kari** ▶ **Haɗa kira** don cigaba da kiran taro.



Layin murya biyu

Yi kira aware da lambobin waya daban idan biyan kuɗinka yana goyan bayan sabis na layi na wucin gadi.

Don zaɓar layi don kira mai fita

- Daga jiran aiki zaɓi **Menu** ▶ **Saituna** ▶ **Kira shafin**. Zaɓi layi.

Don canja sunan layin

- Daga jiran aiki zaɓi **Menu** ▶ **Saituna** ▶ **Nuni shafin** ▶ **Shirya sunayen layi**. Zaɓi layin don shiryawa.

Lambobina

Duba, kara da shirya labobin wayarka.

Don bincika lambobin wayarka

- Daga jiran aiki zaɓi **Menu** ▶ **Lambobi** ▶ **Kari** ▶ **Zabuɓɓuka** ▶ **Lambb**. n. musam. ▶ **Lambobi nawa kuma zaɓi ɗaya daga cikin zaɓuɓɓukan**.

Karɓar kira

Karɓi kira kawai daga takamammen lambobin waya. Idan zaɓin karkatar da kira **Idan ana kan aiki** an kunna shi, ana karkatar da kira.

Don kara lambobi zuwa lissafin karɓaɓɓun masu kira

- Daga jiran aiki zaɓi **Menu** ▶ **Saituna** ▶ **Kira shafin** ▶ **Sarrafa kira** ▶ **Karɓa kira** ▶ **Daga liss. kawai** ▶ **Shirya** ▶ **Kara**.
- Zaɓi lamba ko ▶ **Kungiyoyi** ➔ **Kungiyoyi 37**.

Don karɓar duk kira

- Daga jiran aiki zaɓi **Menu** ▶ **Saituna** ▶ **Kira shafin** ▶ **Sarrafa kira** ▶ **Karɓa kira** ▶ **Duk masu kira**.



Kuntataccen bugun kira

Kuntata kira mai fita da shigowa. Ana bukaratar kalmar wucewa daga mai baka sabis.



Idan ka karkatar da kira mai shigowa, baza ka iya kunna wasu zabubbukan kuntata kira ba.

Za'a iya kuntata kira mai biyowa:

- **Duk mai fita** – duk kira mai fita.
- **Mai fita waje** – duk kira mai fita na kasashen duniya.
- **Yw. krn. wj. m. ft.** – duk kira mai fita na kasashen duniya banda zuwa kasarka.
- **Duk mai shigowa** – duk kira mai shigowa.
- **M. shg.in an. ywo.** – duk kira mai shigowa lokacin da kake kasashen waje ➤ *Cibiyoyin sadarwa 21.*

Don kunna ko kashe kuntata kira

- 1 Daga jiran aiki zaɓi Menu ► Saituna ► Kira shafin ► Sarrafa kira ► Kuntata kira. Zaɓi wani zaɓi.
- 2 Zaɓi Kunna ko Kashe, shigar da kalmar wucewa naka ► Ok.



Kafaffun bugun kira

Aikin kafaffun bugun kira yana ba kira damar yin su zuwa takmammun lambobi wadanda aka ajiye a katin SIM ɗin. Ana kare kafaffun lambobinka ta PIN2 naka.



Zaka kuma iya kiran lambar gaggawa ta kasashen waje, 112, koda lokacin da aikin kafaffen bugun kira yana kunne.

Za'a iya ajiye bangaren lambobi. Misali, ajiye 01232456 yana ba kira damar yinsu zuwa duk lambobi da suka fara da 012345.



Lokacin da aka kunn kafaffen bugun kira, baza abaka damar duba ko sarrafa kowacce lambobin waya ajiyayyu a katin SIM ba.

Don kunna ko kashe kafaffen bugun kira

- 1 Daga jiran aiki zaɓi Menu ► Lambobi ► Kari ► Zabubbuka ► Lambb. n. musam. ► Kafaffen bgn. kira kuma zaɓi Kunna ko Kashe.
- 2 Shigar da PIN2 naka ► Ok sannan ► Ok kuma don tabbatarwa.

Don ajiye kafaffiyar lamba

- Daga jiran aiki zaɓi **Menu ▶ Lambobi ▶ Kari ▶ Zabuɓɓuka ▶ Lambb. n. musam. ▶ Kafaffen bgn. kira ▶ Kafaffun lambobi ▶ Sabuwar lamba** kuma shigar da bayanin.



Lokacin kira da farashi

Yayin kira, ana nuna tsawon lokacin kiran. Zaka iya duba tsawon lokacin kiranka na karshe, kira masu fita da jimlar lokacin kiranka.

Don duba lokacin kiran

- Daga jiran aiki zaɓi **Menu ▶ Saituna ▶ Kira shafin ▶ Lokaci & farashi ▶ Ms. kiday. lok. kira.**

Karin ayyukan kira

Sigina na sauti

Yi amfani da sabis na bankin tarho ko sarrafa injin amsawa tareda sigina na sauti yayin kira.

Don amfani da sigina na sauti

- Latsa **(+)** - **(9)**, **(*)** → ko **(#)** don aika sautuna.
- ▶ **Kari ▶ Nakasa sautuna ko Bada damar saut.** don kashe sautuna da kunnawa yayin kira.
- Latsa **(C)** don share allon bayan kira.

Allon rubutu

Yi amfani da allon azaman allon rubutu don shigar da lambar waya yayin kira. Lokacin da ka kare kira, lambar zata zauna a allon don ka kira ko ajiyewa acikin lambobinka.

Don kira ko ajiye lamba daga allon rubutun

- ▶ **Kira** don kiran lambar.
- ▶ **Kari ▶ Ajiye lamba** kuma zaɓi lamba don ajiye lambar gareta.
- ▶ **Kari ▶ Sabuwar lamba** don kirkirar sabuwar lamba don ajiye lambar gareta.

Nuna ko boye lambarka

Idan biyan kuɗinka yana goyan bayan sabis na kuntata shaidar layin kira (CLIR), zaka iya boye lambar waya lokacin yin kira.

Don nuna ko boye lambar waya koyaushe

- 1 Daga jiran aiki zaɓi **Menu ▶ Saituna ▶ Kira shafin ▶ Nun./boy.lamb.na.**
- 2 Zaɓi **Nuna lamba, 'Boye lamba ko Tsoh. cib. sadar.**

Kungiyoyi

Kirkiri kungiyar lambobi da adiresoshin email don aika sako zuwa masu karba da yawa a lokaci daya ➤ *Sako 38.*

 *Idan ka aika sakon rubutu zuwa kungiya, za'a caje ka akan kowane dan kungiya.*

Hakanan zaka iya amfani da kungiyoyi (tareda lambobi) lokacin da ka kirkiri lissafin karbaɓɓun masu kira ➤ *Karɓar kira 34.*

Don kirkirar kungiyar lambobi da adiresoshin email

- 1 Daga jiran aiki zaɓi **Menu ▶ Lambobi ▶ Kari ▶ Zabuɓɓuka ▶ Kungiyoyi ▶ Sabuwar kungiya ▶ Kara.**
- 2 Shigar da suna don kungiyar ▶ **Ci gaba.**
- 3 ▶ **Sabo ▶ Kara** don nemo da zaɓar lambar lamba ko adiresoshin email.
- 4 Maimaita taku 3 dafa karin lambobi ko adresoshin email. ▶ **Anyi.**

Katunan kasuwanci

Kara katinka na kasuwanci azaman lamba.

Don kara katin kasuwancinka

- Daga jiran aiki zaɓi **Menu ▶ Lambobi ▶ Kari ▶ Zabuɓɓuka ▶ Kat. kasuwanci na** kuma kara bayani saboda katin kasuwancinka ▶ **Ajiye.**

Don aika katinka na kasuwanci

- Daga jiran aiki zaɓi **Menu ▶ Lambobi ▶ Kari ▶ Zabuɓɓuka ▶ Kat. kasuwanci na ▶ Aika kati nawa** kuma zaɓi hanyar canja wuri.

Sako

Sakon rubutu, sakon hoto, sakon murya, email, Abokaina.

Wayarka tana goyan bayan sabis na sakonni da yawa. Tuntubi mai baka sabis gameda sabis din da zaka iya amfani da, je zuwa www.sonyericsson.com/support.

Sakon rubutun (SMS)

Sako rubutu zai iya kunsar saukakan hotuna, rinjayan sauti, rayuwa, da launin wakoki. Hakanan zaka iya kirkirar da amfani da samfura don sakonninka.

Kafin ka fara

Ana bada lambar wurin sabis naka ta mai baka sabis kuma yawanci ana saita ta a katin SIM. In ba haka ba, zaka iya shigar da lambar da kanka

Don saita lambar wurin sabis

- 1 Daga jiran aiki zaɓi **Menu** ▶ **Sako** ▶ **Saituna** ▶ **Sakon rubutu** ▶ **Wurin sabis**. Idan an ajiye lambar wurin sabis kan katin SIM tana bayyana.
- 2 Idan babu lamba da ya bayyana ▶ **Shirya** ▶ **Sabo**. WurinSabis kuma shigar da lambar, haɗi da fihirisar duniya “+” da lambar kasa/yanki ▶ **Ajiye**.

Aika sakonnin rubutu

Don karin bayani gameda shigar da haruffa ▶ *Shigar da haruffa 17*.



Takamaiman haruffan wasu yaruka suna amfani da karin sarari. Don wasu yaruka zaka iya kashe National chars. don ajiye sarari.

Don rubuta da aika sakon rubutu

- 1 Daga jiran aiki zaɓi **Menu** ▶ **Sako** ▶ **Rubuta sabuwa** ▶ **Sakon rubutu**.
- 2 Rubuta sakonka ▶ **Ci gaba**. (Zaka iya ajiye sako don gaba a **Tsararr. sakonni ta latsa**  ▶ **Ajiye sako**.)
- 3 ▶ **Shig. da Im. waya** kuma shigar da lamba, ko ▶ **Duba lambobi** don dakko lamba ko kungiya daga **Lambobi**, ko ▶ **Shigar.adire.email** ko zaɓi daga masu karɓa na karshe da akayi amfani dasu ▶ **Aika**.



*Don aika sako zuwa adreshin email, kana bukatar saita lambar hanyar email, ▶ **Sako** ▶ **Saituna** ▶ **Sakon rubutu** ▶ **Hanyar email**. Ana kawo lambar daga mai bada sabis naka.*

Don kwafa da lika rubutu a sako

- 1 Lokacin rubuta sakonka ► **Kari**
► **Kwafe & manna.**
- 2 ► **Kwafi duk ko ► Alama& kwafe**
kuma latsa , ,  kuma  don
gungurwa da sawa rubutu alama
a sakonka.
- 3 ► **Kari ► Kwafe & manna ► Manna.**

Don saka abu a sakon rubutu

- 1 Lokacin rubuta sakonka ► **Kari ► Kara**
abu.
- 2 Zaɓi wani zaɓi kuma sannan abu,
misali, hoto.



*Zaka iya sauya sakon rubutunka zuwa sakon hoto. Lokacin rubuta sakonka ► **Kari ► Zuwa sakon hoto kuma cigaba da kirkirar sakon hoto, ► Sakon hoto (MMS) 41.***

Karɓar sakon rubutu

Lokacin da karɓi sakon rubutu, yana bayyana a menu na ayyuka idan **Sab.abun aukuwa** an saita **Menu na ayyuka.** ► **Duba** don karanta sakon.

Idan **Sab.abun aukuwa** an saita zuwa **Pop-up**, ana tambayarka idan kana so ka karanta sakon rubutun. ► **Ee** don karanta sakon ko ► **A'a** don karantashi a gaba. Lokacin da ka karanta sakon rubutun ► **Kari** saboda zaɓuɓɓuka ko latsa  don rufe sakon.

Don kiran lamba a sakon rubutu

- Zaɓi lambar wayar wanda ya nuna a sakon, ► **Kira.**

Ajiyewa da share sakonnin rubutu

Ana ajiye sakonnin rubutu waɗanda aka karɓa a kwakwalwar ajiyar wayar. Lokacin da kwakwalwar ajiyar wayar ta cika, share sakonnin ko matsar dasu zuwa katin SIM don samun damar karɓar sababbin sakonni. Sakonnin da aka ajiye a katin SIM suna zama harsai an share su.

Don ajiye sako

- 1 Daga jiran aiki zaɓi **Menu ► Sako ► Akw. s. m. shig.** kuma zaɓi sakon don ajiyewa.
- 2 ► **Kari ► Ajiye sako.**
- 3 ► **Ajiyayyu.** wasiku don ajiyewa a katin SIM ko ► **Samfura** don ajiye sakon azaman samfuri a wayar.

Don ajiye abu a sakon rubutu

- 1 Lokacin karanta sako, zaɓi lambar waya, hoto ko adreshin yanar sadarwa don ajiyewa ► **Kari**.
- 2 ► **Yi amfani** (lambar wayar da ka zaɓa yana bayya) ► **Ajiye lambar** don ajiye lambar wayar ko ► **Ajiye hoto** don ajiye hoto ko ► **Yi amfani** (alamar shafin da ka zaɓa yana bayyana) ► **Ajiye alamar shafi** don ajiye alamar shafi.

Don share sako

- 1 Daga jiran aiki zaɓi **Menu** ► **Sako** kuma zaɓi babban fayil.
- 2 Zaɓi sako don sharewa kuma latsa **C**.

Don ajiye ko share sakonni da yawa

- 1 Daga jiran aiki zaɓi **Menu** ► **Sako** kuma zaɓi babban fayil.
- 2 Zaɓi sako ► **Kari** ► **Shre. duk sakonni** don share duk sakonni a babban fayil ko ► **Alama a yawanci** gungura kuma zaɓi sakonni ta latsa **Alama** ko **Cr. alama**.
- 3 ► **Kari** ► **Ajiye sakonni** don ajiye sako ko ► **Share sakonni** don share sakonni.

Dogayen sakonni

Adadin haruffan da aka bada dama a sakon rubutu ya dogara da yaren da ake amfani dashi a rubutun. Zaka iya aika dogon sako ta haɗa sakonni biyu ko fiye. Ana cajin ka a kowane sakon da aka haɗa a dogon sako. Maiyuka mai karɓa bazai karɓi duk sassan dogon sako a lokaci ɗaya ba.



Bincika tareda mai baka sabis iyakar adadin sakonnin da za'a iya haɗawa.

Don kunna dogayen sakonni

- Daga jiran aiki zaɓi **Menu** ► **Sako** ► **Saituna** ► **Sakon rubutu** ► **Iyakar tsayin sako** ► **Iyaka da akwai**.

Samfura don sakonnin rubutu

Kara sabon samfuri ko ajiye sako azaman samfuri a wayarka ► **Don ajiye sako 39**.

Don kara samfuri

- 1 Daga jiran aiki zaɓi **Menu** ► **Sako** ► **Samfura** ► **Sabuwar samfuri** ► **Rubutu**.
- 2 Shigar da rubutu ► **Ok**.
- 3 Shigar da take ► **Ok**.

Don amfani da samfuri

- 1 Daga jiran aiki zaɓi **Menu ▶ Sako ▶ Samfura** zaɓi samfur ▶ **Yi amfani ▶ Sakon rubutu**.
- 2 Kara rubutu ko ▶ **Ci gaba** kuma zaɓi mai karɓa don aika sakon zuwa gareshi.

Zabuɓɓukan sako

Saita tsohuwar kima don zaɓuɓɓukan sako dayawa ko zaɓi saitunan akowane lokaci ka aika sako.

Don saita tsoffin zaɓuɓɓukan sakon rubutu

- Daga jiran aiki zaɓi **Menu ▶ Sako ▶ Saituna ▶ Sakon rubutu** kuma zaɓi zaɓuɓɓuka don canjawa.

Don saita zaɓuɓɓukan sako don takamammen sakon

- 1 Lokacin da aka rubuta sako kuma aka zaɓi mai karɓa ▶ **Kari ▶ Na ci gaba**.
- 2 Zabi wani zaɓi don canjawa ▶ **Shirya** kuma zaɓi sabon saiti ▶ **Anyi**.

Don bincika halin isar da sakon da aka aika

- Daga jiran aiki zaɓi **Menu ▶ Sako ▶ Sako da ak. aika** kuma zaɓi sakon rubutu ▶ **Duba ▶ Kari ▶ Duba hali**.

Sakon hoto (MMS)

Sakonnin hoto zai iya kunsar rubutu, hotuna, hotunan kamara, nunin faifai, sautin rikodi, shirye-shiryen bidiyo, sa hannu da hade-hade. Zaka iya aika sakonnin hoto zuwa wayar hannu ko adreshin email.

Kafin ka fara

Kai da mai karɓar dole yazama kuna da biyan kuɗi wanda ke goyan bayan sakon hoto.

Idan bayanin martabar Intanit ko uwar garken sako basu kasance ba, zaka iya karɓar duk saitunan don MMS ta atomatik daga afaretan cibiyar sadarwaka ko daga www.sonyericsson.com/support.

Kafin aika sako hoto, zaka iya bincika: Adireshin uwar garken sakonka da bayanin martabar Intanit an saita su. Daga jiran aiki zaɓi **Menu ▶ Sako ▶ Saituna ▶ Sakon hoto ▶ Bay. mrtbar MMS** kuma zaɓi bayanin martaba. ▶ **Kari ▶ Shirya ▶ Uwar garken sako** ko ▶ **Kari ▶ Shirya ▶ Bayn.mrtb. intanit**.

Don kirkira da aika sakon hoto

- 1 Daga jiran aiki zabi **Menu** ► **Sako** ► **Rubuta sabuwa** ► **Sakon hoto**.
- 2 Latsa  don kara abubuwa kamar hotuna, shirye-shiryen bidiyo ko sautuna. ► **Kari** don duba lissafin wasu zaɓuɓɓuka.
- 3 Lokacin da aka shirya aikawa ► **Ci gaba**.
- 4 ► **Shigar.adire.email** ko ► **Shig. da Im. waya** ko ► **Duba lambobi** don dakko lamba ko kungiya ko Lambobi ko zabi daga masu karɓa da akayi amfani da su akarshe ► **Aika**.



Lokacin rubuta da shirya sakonnin hoto zaka iya amfani da aikin kwafi da liki
► *Don kwafa da lika rubutu a sako 39.*

Don kirkirar sa hannunka don sakonnin hoto

- 1 Daga jiran aiki zabi **Menu** ► **Sako** ► **Saituna** ► **Sakon hoto**.
- 2 ► **Sa hannu** ► **Sabo. sa hannu** kuma kirkiri sa hannunka azaman sakon rubutu.

Don saita tsoffin zaɓuɓɓukan sakon rubutu

- Daga jiran aiki zabi **Menu** ► **Sako** ► **Saituna** ► **Sakon hoto** kuma zabi zaɓuɓɓuka don canjawa.

Karin zaɓuɓɓukan aikawa

Neman rahoton karantawa, rahoton isarwa, kuma saita fifiko don takamammen sako. Hakanan zaka iya kara karin masu karɓa zuwa sakon.

Don zaɓar karin zaɓuɓɓukan aikawa

- 1 Lokacin da aka kirkiro sakon kuma aka zabi mai karɓa ► **Kari**.
- 2 ► **Kara mai karɓa** don kara wani mai karɓa ko ► **Shiry masu karɓa** don shirya da kara masu karɓa. ► **Shirya take** don canja taken sakon ko ► **Na ci gaba** saboda karin zaɓuɓɓukan aikawa.

Karɓar sakonnin hoto

Zabi yadda zaka sauke sakonnin hotonka da yadda zaka ajiye abubuwa waɗanda ka karɓa a sakonnin hoto.

Don saita saukewar atomatik

- Daga jiran aiki zabi **Menu** ► **Sako** ► **Saituna** ► **Sakon hoto** ► **Saukw. ta atomat.** don duba da zaɓin ɗaya daga cikin masu biyowa:
 - **Koyaushe** – saukewar atomatik.
 - **Tamby.an. yawo** – tambayi don ajiyewa lokacin da ba'a cikin cibiyar sadarwa na gida ba.

- **Ba'a cikin yawo** – kar a sauke lokacin da ba'a cikin cibiyar sadarwa na gida ba.
- **Koysh. tambayi** – don saukewa.
- **A kashe** – sabon sako yana bayyana acikin Akw. s. m. shig. Zabi sakon kuma ► **Duba** don saukewa.

Don karɓar sakonnin hoto

- 1 Lokacin da ka karɓi sakon hoto wanda aka sauke ta atomatik, yana bayyana a menu na ayyuka idan **Sab.abun aukuwa** an saita **Menu na ayyuka**. ► **Duba** don karanta sakon. Idan **Sab.abun aukuwa** an saita **Pop-up**, ana tambayarka idan kana so ka karanta sakon hoton, ► **Ee** don karantawa ko kunnawa.
- 2 Latsa  don rufe sakon.

Don ajiye abu a sakon hoto

- Lokacin duba sakon hoto ► **Kari** ► **Ajiye abubuwa** kuma zabi abu don ajiyewa daga lissafin dake bayyana.

Share sakonnin hoto

Ana ajiye sakonnin hoto a kwakwalwar ajiyar wayar. Lokacin da kwakwalwar ajiyar waya ta cika, dolene ka share sakonni don samun damar karɓar sababbin sakonni. Zabi sako kuma latsa  don sharewa.

Samfura don sakonnin hoto

Kara sabon simfuri ko yi amfani da simfuri da aka riga aka ayyana.

Don kara samfuri

- 1 Daga jiran aiki zabi **Menu** ► **Sako** ► **Samfura** ► **Sabuwar samfuri** ► **Sakon hoto**.
- 2 ► **Kari** don kara sabbin abubuwa.
- 3 ► **Ajiye**, shigar da take ► **Ok** don ajiye samfuri.

Don amfani da samfuri

- 1 Daga jiran aiki zabi **Menu** ► **Sako** ► **Samfura** kuma zabi samfuri daga lissafin ► **Yi amfani** don amfani da samfuri kamar yadda yake ko ► **Kari** ► **Shirya samfuri** don shirya samfuri, ► **Ajiye**, shigar da take ► **Ok** don ajiye canje-canje.
- 2 ► **Ci gaba** kuma zabi mai karɓa don aika sako zuwa gareshi ko zabi samfuri daga lissafi ► **Yi amfani** ► **Ci gaba** idan an shirya samfuri.

Sakonnin murya

Aika kuma karɓi rikodin sauti azaman sakon murya.



Mai aikawa da mai karɓa dolene su sami goyan bayan biyan kuɗin sakon hoto.

Don yin rikodi da aika sakon murya

- 1 Daga jiran aiki zaɓi **Menu** ► **Sako** ► **Rubuta sabuwa** ► **Sakon murya**.
- 2 Yi rikodin sakonka. ► **Tsaida** don kare.
- 3 ► **Aika** don aika sakon.
- 4 ► **Shigar.adire.email** saboda mai karɓan email ko ► **Shig. da Im. waya** saboda mai karɓan lambar waya ko ► **Duba lambobi** saboda lamba ko kungiya a Lambobi ko zaɓi daga lissafi masu karɓa waɗanda akayi amfani dasu a karshe ► **Aika**.

karɓar sakonnin murya

Lokacin da ka karɓi sakon murya wanda aka sauke ta atomatik, sakon muryar yan bayyana acikin menu na ayyuka idan **Sab.abun aukuwa** an saita zuwa **Menu na ayyuka**. ► **Kunna** don sauraron sakon.

Idan **Sab.abun aukuwa** an saita zuwa **Pop-up**, ana tambayarka idan kana son sauraren sakon muryar. ► **Ee** don kunna sakon ko ► **A'a** idan kana son kunna sakon a gaba. Lokacin da ka saurari sakon muryar ► **Kari** don duba lissafin zaɓuɓɓuka. Latsa  don rufe sakon.



Email

Karanta sakonnin email naka a wayarka koyaushe. Rubuta sako, haɗa da hoton kamara, naɗin sauti ko shirin bidiyo, kuma aika su zuwa abokan ka ko abokan aikin ka. Zaka kuma iya amsa email da aka turo a wayarka, kamar yadda zaka iya yin haka a kwamfutar ka.

Adreshin email ɗin da kake amfani dashi a kwamfutar ka zaka kuma iya amfani dashi a wayarka. Don yin wannan wayarka tana bukatan saituna na email kamar waɗanda ake amfani dasu a kwamfutar ka saboda adreshin email. Don amfani da adreshin email na kwamfutar ka a wayarka, yi ɗaya daga cikin masu biyowa:

- **Karɓi saituna ta atomatik**
Hnaya mafi sauki shine ka sami saituna waɗanda aka aiko so kai tsaye zuwa wayarka. Yi amfani da Intanit a kwamfutar ka don zuwa www.sonyericsson.com/support.

- **Shigar da saituna da hannu**
 - Tambayi mai baka email don bayanin saituna. Mai bada email shine mutumin ko kamfani wanda yake kawo adreshin email dínka, misali mai kula da IT naka ko mai bada Intanit, ko
 - Zaka iya samun takaddar aiki a gida daga mai baka email tareda saitunan bayani, ko
 - Maiyuwa ka samo bayanin a saitunan shirye-shiryen email a kwamfutarka.

Wane bayani nake bukata?

Mafi karancin abinda kake bukata shine mai biyowa:

Nau'ukan saiti	Misalai
Nau'in haɗi	POP3 ko IMAP4
Adireshin email	joe.smith@example.com
Uwr. grk. m-shig.	mail.example.com
Sunan mai amfani	jsmith
Kalmar wucewa	zX123
Uw. garke mai fita	mail.example.com



Akwai masu bada email dayawa daban-daban. Maiyuwa isdílaihinsu da bayanin da ake bukata ya bambanta. Ba duk masu bada sabis ke bada damar email ba.

Hakanan kuma akwai umarnin saiti da bayanin taimako kamra yadda ka shigar da saituna.

Don shigar da saitunan email

- 1 Daga jiran aiki zaɓi **Menu** ► **Sako** ► **Email** ► **Saituna**.
- 2 Bayan an shigar da saituna, ► **Akw. s. m. shig.** ► **Kari** ► **Aika & karɓa** don samun damar email naka. Loakcin da aka shigar da saituna, wayarka zata iya haɗuwa da uwar garken email don aikawa da karɓar sakonnin email. Don karin bayani tuntuɓi mai baka email.

Don kirƙirar lissafin email

- 1 Daga jiran aiki zaɓi **Menu** ► **Sako** ► **Email** ► **Saituna** ► **Sabon lissafi** ► **Kara**.
- 2 Shigar da suna saboda lissafin ► **Ok**. Saboda taimako ► **Ummumin saiti**, ko latsa zuwa saiti ► **Bayani**.

- 3 Latsa ☐ zuwa saiti kuma shigar da mafi karancin satunn da ake bukata masu zuwa:
- **Fadakarwar email** kuma zaɓi sautin fadakarwar don sababbin sakonni.
 - **Hafa aiki** – kuma zaɓi lissafin bayanai (waɗanda mai sa aiki na cibiyar sadarwaka ya kawo, ► **Bayani**).
 - **Adireshin email** – shigar da adireshin email naka.
 - **Nau'in haɗi** – POP3 ko IMAP4.
 - **Uwr. grk. m-shig.** – shigar da sunan uwar garken.
 - **Sunan mai amfani** – shigar da sunan mai amfanin don lissafin email.
 - **Kalmar wucewa** – shigar da kalmar wucewar don lissafin email din.
 - **Uw. garke mai fita** – shigar da sunan uwar garken.

Don shigar da saitunan lissafin email na ci gaba (na ganin dama sau tari)

- 1 Daga jiran aiki zaɓi **Menu** ► **Sako** ► **Email** ► **Saituna**.
- 2 Zaɓi lissafi don shiryawa ► **Kari** ► **Shirya lissafi** ► **Babban saituna**.
- 3 Latsa ☐ don zaɓi da shigar da saituna, in mai bada email ya bukata, misali, **Duba tazara**.

Don karɓa da karanta sakonnin email

- 1 Daga jiran aiki zaɓi **Menu** ► **Sako** ► **Email** ► **Akw. s. m. shig.** ► **Aik. & kɓ.** lokacin da akwatin sakon mai shigowa ya zama fanko ko ► **Sako** ► **Email** ► **Akw. s. m. shig.** ► **Kari** ► **Aika & karɓa** don saukar da sabon sako. Wannan kuma yana aika kowane sakonni cikin akwatin sako mai fita.
- 2 Zaɓi sako a akwatin sako mai shiga ► **Duba** don karan tashi.

Don rubuta da aika sakon email

- 1 Daga jiran aiki zaɓi **Menu** ► **Sako** ► **Email** ► **Rubuta sabuwa**.
- 2 ► **Kara** don shigar da filin mai karɓar. ► **Shigar.adire.email** don rubuta adreshin email ► **Ok**, ko ► **Duba lambobi** don zaɓan mai karɓa daga Lambobi ► **Zaɓi**, ko zaɓi adreshin email daga lissafin masu karɓa waɗanda akayi amfani dasu akarshe ► **Zaɓi**.
- 3 ► **Shirya** don kara filin mai karɓar (bayan an kara ɗaya) don kara karin masu karɓa. Zaɓi **Zuwa**, **Cc** ko **Bcc** kuma zaɓi masu karɓa don karawa. Lokacin da ka zaɓi masu karɓa ► **Anyi**.
- 4 Latsa ☐ don zaɓar filin taken, buga taken email ► **Ok**. Don shirya taken ► **Shirya**.

- 5 Latsa ☐ don zaɓin filin rubutu, rubuta sakonka ► **Ok.** Don shirya sakon ► **Shirya.**
- 6 Latsa ☐ don zaɓar filin haɗe-haɗen. ► **Kara** kuma zaɓi nau'in haɗe-haɗe don karawa ► **Zaɓi** kuma zaɓi haɗe-haɗen don karawa. Don daɗa karin haɗe-haɗe ► **Kara** kuma.
- 7 ► **Ci gaba** ► **Aika** ko **Kari** ► **Ajji.** a akwt. **sako** don ajiyywa da aikawa a gaba.

💡 Lokacin rubuta da shirya sakonnin email zaka iya amfani da ayyukan kwafi da liki
 ➡ Don kwafa da lika rubutu a sako 39.

Don ajiye sakon email

- 1 Daga jiran aiki zaɓi **Menu** ► **Sako** ► **Email** ► **Akw. s. m. shig.**
- 2 Zaɓi sako ► **Kari** ► **Ajiye sako** ► **Ajajjen email.**

Don amsa sakon email

- 1 Zaɓi sakon daga akwatin sako mai shiga don bada amsa zuwa gareshi ► **Kari** ► **Amsa** ko buɗe sakon ► **Amsa.**
- 2 ► **Ee** don haɗa sakon asalin zuwa amsarka ► **A'a** don cire sakon asalin daga bada amsarka.
- 3 Rubuta sakonka a filin rubutu ► **Ok.** Don shirya sakon ► **Shirya.**
- 4 ► **Ci gaba** ► **Aika.**

Don duba ko ajiye haɗe-haɗe a sakon email

- Duba sako ► **Kari** ► **Haɗe-haɗe** ► **Duba** don duba abin ko zaɓi wani abu don ajiyyewa.

Lissafin email mai aiki

Idan kana da lissafin email dayawa, zaka iya canja wanda yake aiki

Don canja lissafin email mai aiki

- Daga jiran aiki zaɓi **Menu** ► **Sako** ► **Email** ► **Saituna** kuma zaɓi lissafi.

Samun email

Karɓi sanarwa a wayarka daga uwar garken email dɪnka cewa kanada sabon email, idan akwai goyan bayan mai baka email.

Don kunna sanarwar tura email

- Lokacin amfani da **Aika & karɓa,** ► **Ee** don kunnawa, in an bukata.
- Daga jiran aiki zaɓi **Menu** ► **Sako** ► **Email** ► **Saituna.** Zaɓi lissafi don shiryawa ► **Kari** ► **Shirya** lissafi ► **Babban saituna** ► **Tura email** kuma zaɓi wani zaɓi.

Don share sakon email na (POP3)

- 1 Daga jiran aiki zaɓi Menu ► Sako ► Email ► Akw. s. m. shig. ► Kari.
- 2 ► Alam.na sharewa ko ► Alama a yawanci ► Alama ko Cr. alama.

 *Za'a share sakonnin da aka sawa alama lokacin da ka kuma hadawa zuwa uwar garkenka.*

Don share sakon email na (IMAP4)

- 1 Daga jiran aiki zaɓi Menu ► Sako ► Email ► Akw. s. m. shig. ► Kari.
- 2 ► Alam.na sharewa ko ► Alama a yawanci ► Alama ko Cr. alama.
- 3 ► Kari ► Shr.akw.sk.m-shg. don share sakonni.

 *Za'a share duk sakonnin da aka sawa alama don sahrewa a wayar da kan uwar garken.*

Abokaina

Haɗa da kuma shiga zawa uwar garken abokaina don sadarwa a layi tareda abokanka da kafi so. Idan biyan kuɗinka yana goyan bayan sakon yanzu-yanzu da hallarrun sabis, zaka iya aikawa da karɓar sakonni da ganin halin lamba idan akan layi. Idan saituna basu kasance a wayarka ba, kana buƙatar shigar da saitunan uwar garke.

 *Tuntuɓi mai baka sabis don karin bayani.*

Don shigar da saitunan uwar garke

- 1 Daga jiran aiki zaɓi Menu ► Sako ► Abokai nawa ► Sanya.
- 2 Kara sunan mai amfani, kalmar wucewa, bayanin uwar garke kuma zaɓi bayanin martaba na Intanit don amfani dashi. Ana kawo bayanin ta mai baka sabis.

Don shiga cikin yana zuwa uwar garken abokaina

- Daga jiran aiki zaɓi Menu ► Sako ► Abokai nawa ► Shiga ciki.

Don fita daga yana

- ► Kari ► Fita daga yana.

Don kara lamba zuwa lissafin

- Daga jiran aiki zaɓi Menu ► Sako ► Abokai nawa ► Lambobi shafin ► Kari ► Kara lamba.

Don aika sakon taɗi daga abokaina

- 1 Daga jiran aiki zaɓi Menu ► Sako ► Abokai nawa ► Lambobi shafin kuma zaɓi lamba daga lissafin.
- 2 ► Taɗi kuma buga sakonka ► Aika.

 *Hakanan zaka iya cigaba da maganar taɗi daga Taɗi shafin.*

Hali

Nuna halinka zuwa lambobi kawai ko nuna shi zuwa duk masu amfani a uwar garken abokaina.

Don saita hali

- 1 Daga jiran aiki zaɓi **Menu** ▶ **Sako** ▶ **Abokai nawa** ▶ **Kari** ▶ **Saituna** kuma zaɓi **Nuna halin nawa**.
- 2 Zaɓi **Zuwa duk ko Ga lambo. kawai** ▶ **Zaɓi**.

Don canja hali naka

- Daga zaɓin jiran aiki **Menu** ▶ **Sako** ▶ **Abokai nawa** ▶ **Hali nawa** shafin da daukaka bayanin hali naka. Yi amfani  ko  don gungurawa tsakanin halin da filayen.

Kungiyar taɗi

Kungiyar taɗi zata iya farawa ta mai baka sabis, ta mai amfani na abokaina mutum ɗaya ko ta kai kanka. Zaka iya ajiye kungiyoyin taɗi ta ajiye gayyatar taɗi ko ta bincika takamammiyar kungiyar taɗi.

Don fara kungiyar taɗi

- 1 Daga jiran aiki zaɓi **Menu** ▶ **Sako** ▶ **Abokai nawa** ▶ **Kungiyoyin taɗi shafin** ▶ **Kari** ▶ **K. taɗi** ▶ **Sab. kungiyar taɗi**.
- 2 Zaɓi wanda zaka gayyata zuwa kungiyar taɗi daga lissafin lambobinka ▶ **Ci gaba**.
- 3 Shigar da gajeran rubutun gayyata ▶ **Ci gaba** ▶ **Aika**.

Don kara kungiyar taɗi

- 1 Daga jiran aiki zaɓi **Menu** ▶ **Sako** ▶ **Abokai nawa** ▶ **Kungiyoyin taɗi shafin** ▶ **Kari** ▶ **K. taɗi**.
- 2 ▶ **Ta ID na kungiya** don shigar da ID na kungiyar taɗi kai tsaye ▶ **Bincika** don bincika kungiyar taɗi.



An adana tarihin taɗi tsakanin fita daga da shiga cikin yana don ya barka ka komo zuwa sakonnin taɗi daga taɗin daya gabata.

Don ajiye taɗi

- 1 Daga jiran aiki zaɓi **Menu ▶ Sako ▶ Abokai nawa ▶ Taɗi shafin.**
- 2 Buɗe taɗi ▶ **Kari ▶ Aje taɗi.**

Don duba ajiyayyen taɗi

- Daga jiran aiki zaɓi **Menu ▶ Sako ▶ Abokai nawa ▶ Taɗi shafin ▶ Kari ▶ Aje magana.**

Don duba masu amfani masu kallo

- Daga jiran aiki zaɓi **Menu ▶ Sako ▶ Abokai nawa ▶ Lambobi shafin ▶ Kari ▶ Ganin mai aiki.** Lissafin masu amfani a uwar garɓen abokaina waɗanda suke kallon bayanin halinka yana bayyana.

Don duba ko shirya saituna

- Daga jiran aiki zaɓi **Menu ▶ Sako ▶ Abokai nawa ▶ Kari ▶ Saituna** kuma zaɓi wani zaɓi.

 *Tuntuɓi mai baka sabis don karin bayani.*

Yanki da bayanin cell



Zai yuwu a aika sakonnin bayani zuwa masu biyan kuɗi na cibiyar sadarwa tsakanin wani yanki ko cell.

Don kunna ko kashe bayani

- Daga jiran aiki zaɓi **Menu ▶ Sako ▶ Saituna ▶ Bayanin wuri ▶ Yanayin aiki** ko **Bayanin Cell.**

Hoto

Kamara, bidiyo, shafi, hotuna,
PhotoDJ™, jigogi.

Dauki hotuna ko yi rikodin shirye-shiryen bidiyo


Zuko ciki
ko waje

Dauki hotuna
Yi rikodin bidiyo



Zabubbukan allo
(sama dama)

Share



Zabubbukan allo
(sama hagu)

Baya

Canja zuwa kamara/bidiyo  ko 
Dai-daita haske  ko 

Don daukar hoto ko yin rikodin shirin bidiyo

- 1 Daga jiran aiki, latsa  don kunna kamarar.
- 2 Latsa  kuma  don canjawa tsakanin kamara da mai rikodin bidiyo.
- 3 **Kamara:** Press  don daukar hoto.



Bidiyo: Latsa  don fara rikodi. Don tsayar da rikodi, latsa  sake. An ajiye hotunanka da shirye-shiryen bidiyo ta atomatik a **Mai sarrafa fayil**
► **Kundin kyamera.**

- 4 Don daukar wani hoto ko yin rikodin wani shirin bidiyo, latsa  don komowa zuwa mai samfoti. Don tsayar da amfani da kamarar ko mai rikodin bidiyo, latsa .

Saitunan kamara

Lokacin da kake a mai samfoti
► **Saituna** saboda zaɓuɓɓuka don daidaitawa da haɓaka hotunanka da shirye-shiryen bidiyo kafin dauka ko rikodinsu.

 *Idan kayi kokarin yin rikodi tareda kakkarfar cibiyar wuta kamar hasken rana kai tsaye ko kwai a bangon, maiyuwa allon yayi baki ko maiyuwa hoton ya murɗe.*

Don amfani da zukowa

- Latsa  ko .

Don dai-daita haske

- Latsa  ko .

Zabuɓɓukan kamara da bidiyo

Lokacin da aka kunna kamara da bodiyo ► **Saituna** saboda zaɓuɓɓuka masu biyowa:

- **Cnj. zw. bidiyo kyamara** don yin rikodin shirin bidiyo ko **Cnj. zw tsayar da kam.** don ɗaukan hoto.
- **Yanayin ɗauka** (kamara):
 - **Na al'ada** – ba suna.
 - **Da yawa a daya** – haɗa hotuna dayawa cikin ɗaya.
 - **Firamomi** – kara firam zuwa hotonka.
 - **Fashewa** – ɗauki hotuna da sauri a jere.
- **Yanayin ɗauka** (bidiyo):
 - **Saboda sakon hoto**
 - **Bidiyo mai nagarta**
- **Girman hoto** (kamara) – zaɓi daga:
 - **2 MP** (1600x1200 fatsi-fatsi)
 - **1 MP** (1280x960 fatsi-fatsi)
 - **VGA** (640x480 fatsi-fatsi)
- **Kunna yanayin dare** – dai-daita don yanayin haske mara kyau.
- **Kun. mai kidayar lokaci** (kamara) – ɗauki hoto yan mintuna bayan latsa maɓallin kamarar.

- **Rinjayoyi** – zaɓi daga:
 - **A kashe** – ba rinjaye.
 - **Baki da fari** – ba launi.
 - **Dodo** – ajiyayyun launuka.
 - **Ruwan kasa** – launin ruwan kasa.
- **Ma'aunin launi** – da-daita launuka don yanayin haske. Zaɓi daga **Otomatik, Hasken rana, Launin gajimare, Farin haske** ko **Fitarwa**.
- **Nagartar hoto** (kamara):
 - **Na al'ada**
 - **Da kyau**
- **Kashe makarufo** (bidiyo) – saita makirufu.
- **Sautin ɗauka** (kamara) – zaɓi sautunan ɗauka daban.
- **Kunna lokaci da rana** (kamara) – kara lokaci da kwanan wata a hoto don bayyana azaman jan rubutu a kusurwar dama ta kasa. Duba cikin girman 1:1 ko yi amfani da zukowa lokacin duban hoto don ganin rubutun.
- **Saita lamb. fayil.** – sake saita mai kidayar lambar fayil (yana bukatar hotunan a katin kwakwalwar ajiyar).
- **Ajiye zuwa** – zaɓi don ajiyewa zuwa **Memory Stick** ko **Kwakwa. ajiyar waya**.

Gajerun hanyoyin kamara

Lokacin amfani da kamara, zaka iya kuma amfani da maballai azaman gajerun hanyoyi don zuwa zaɓuɓɓuka gama gari. Latsa  don jagorar maballin kamara.

Canja wurin hotuna

Canja zuwa kwamfutarka

Ta amfani da kebul na USB, zaka iya jawo da sauke hotunan kyamera zuwa kwamfuta ➡ *Canja wirin fayiloli ta amfani da kebul na USB 76.*

Don cigaban haɓaka da shirya hotunan kyamera akan kwamfuta, Windows® masu amfanin aikace-aikace zasu iya sa Adobe™ Photoshop™ Album Starter Edition, wanda aka haɗa akan CD tare da waya ko je zuwa www.sonyericsson.com/support.

Shafin hoto

Buga hotuna akan dakin yanar sadarwarka na sirri idan biyan kuɗinka yana goyan bayansa.



Sabis na yanar sadarwa maiyuwa ya buƙaci warerren lasisin yarjejeniya tsakanin ka da mai bada sabis. Cikin wasu wurare, karin dokoki da/ko caji mai yiwuwa a nema. Don karin bayani, tuntuɓi mai baka sabis.

Don aika hotunan kamara zuwa shafi

- 1 Lokacin duban hoton da kaɗauka yanzu-yanzu ► **Kari** ► **Yi Blog wannan.**
- 2 Bi umarni waɗanda suka bayyana a farkon lokacin amfani, misali, tabbatar da sharuɗɗa da halaye.
- 3 Kara take da rubutu ► **Ok** ► **Yaɗa** don aika hoto zuwa shafinka.

An aika sakon rubutu zuwa wayarka tareda adireshin yanar sadarwa da bayanin shiga cikin yana. Zaka iya tura sakon rubutun ga wasu don samun damar hotunan dakin yanar sadarwarka.

Don aika hotuna zuwa shafi

- 1 Daga jiran aiki zaɓi **Menu** ► **Mai sarrafa fayil** kuma zaɓi hoto a babban fayil.
- 2 ► **Kari** ► **Aika** ► **Zuwa blog.**
- 3 Kara take da rubutu ► **Ok** ► **Yaɗa.**

Don ziyartar adreshin shafi a lamba

- Daga jiran aiki zaɓi **Menu** ► **Lambobi** kuma zaɓi adireshin Yanar sadarwa na lamba ► **Je zuwa.**

Hotuna da shirye-shiryen bidiyo

Duba da amfani da hotuna da shirye-shiryen bidiyo.

Boye hotuna

Duba, kara, shirya ko share hotuna a **Mai sarrafa fayil**. Adadin hotunan da zaka iya ajiyewa ya dogara da girman hotunan. Nau'ukan fayil masu goyan baya sune, misali, GIF, JPEG, WBMP, BMP, PNG da SVG-Tiny.

Don duba da amfani da hotuna

- 1 Daga jiran aiki zaɓi **Menu** ► **Mai sarrafa fayil** ► **Hotuna**.
- 2 Zaɓi hoto ► **Duba ko** ► **Kari** ► **Yi amfn. azaman** kuma zaɓi wani zaɓi.

Don nuna hotuna a nunin faifai

- 1 Daga jiran aiki zaɓi **Menu** ► **Mai sarrafa fayil** ► **Hotuna** kuma zaɓi hoto.
- 2 ► **Duba** ► **Kari** ► **Nunin faifai**.

Don duba bayani gameda fayil

- 1 Daga jiran aiki zaɓi **Menu** ► **Mai sarrafa fayil** ► **Hotuna ko Bidiyo**, zaɓi fayil.
- 2 ► **Kari** ► **Bayani**.

Amfani da hotuna

Kara hoto zuwa lamba, yi amfani da shi yayin fara waya, azaman fuskar bangon waya a jiran aiki ko azaman uwar garken allo.



An saita rayarwa na fiye da 1MB azaman fuskar bangon waya maiyuwa ya rinjayi aiki.

Allon uwar garke

An kunna allon uwar garke ta atomatik lokacin wayar ta daina aiki na sakan kadan. Bayan wasu yaƙan karin sakan, allon uwar garken yana canjawa zuwa yanayin barci don ajiye wuta. Latsa kowane maɓalli don sake kunna allon.

Don shirya hotuna

► *PhotoDJ™ 56.*

Musanya hotuna

Zaka iya musanya hotuna ta amfani da daƙan wadatattun hanyoyin canja wuri. Kula ba'a yarda ka musanya wasu abubuwa masu kariyar hakkin mallaka ba. Don karin bayani kan hotuna a sakonni ► *Sako 38.*

Don aika hoto

- 1 Daga jiran aiki zaɓi **Menu ▶ Mai sarrafa fayil ▶ Hotuna** kuma gungura zuwa hoto.
- 2 ▶ **Kari ▶ Aika** kuma zaɓi hanyar canja wuri.

 Wasu wayoyi basa iya karɓar hoto mai girma.

Don karɓar hoto

- Daga jiran aiki zaɓi **Menu ▶ Saituna ▶ Haɗuwa** shafin kuma zaɓi hanyar canja wuri.

Don ajiye hoto a sako

- ➡ *Don ajiye abu a sakon rubutu 40 ko ➡ don ajiye abu a sakon hoto 43 ko ➡ Don duba ko ajiye haɗe-haɗe a sakon email 47.*

Ajiye hotuna da shirye-shiryen bidiyo

Lokacin da ka ɗauka hoto ko yin rikodin shirin bidiyo, waya tana ajiye shi a kwakwalwar ajiyar waya ko a katin kwakwalwara jaiya.

Idan kwakwalwar ajiyar wayar ko katin kwakwalwar ajiya ya cika, baza ka iya ajiye karin kowane hotuna ba ko shirye-shiryen bidiyo harsai ka share ko matsar da fayiloli ➡ **Mai sarrafa fayil 19.**

Aika hotuna da shirye-shiryen bidiyo

Lokacin da ka ɗauki hoto ko ka naɗi shirin bidiyo, zaka iya aika su azaman sakon hoto idan girman fayil ɗin bai wuce iyaka ba. Don musanya hotuna da shirye-shiryen bidiyo ta amfani da wasu hanyoyin canja wuri ➡ **Musanya hotuna 54.**

Don amfani da karin zaɓuɓɓukan shirin bidiyo ko hoto

- Yi rikodin shirin bidiyo ko ɗauki hot ▶ **Kari** kuma zaɓi wani zaɓi, misali, don ɗaukan sabon hoto.

Canja hotuna zuwa kwamfutarka

Ta amfani da keɓul na USB, zaka iya jawo da sauke hotunan kyamera zuwa kwamfuta ➡ **Canja wurin fayiloli ta amfani da keɓul na USB 76.**

Allon ramut

Yi amfani da na'urar haɗi wacce ta dace ta Bluetooth™ don duba allo mai nisa kamar TB. Ba'a sanya na'urar haɗi a wayarka ba. Don cikakken lissafi na na'urorin haɗi waɗanda suka dace, je zuwa www.sonyericsson.com/support.

Don haɗi zuwa allon ramut

- Daga jiran aiki zaɓi **Menu** ► **Mai sarrafa fayil** ► **Hotuna** ► **Duba** ► **Kari** ► **Allon nisa**. ► **Don kara na'ura zuwa wayarka 74.**

PhotoDJ™

Shirya hotuna ta amfani da PhotoDJ™.

Don shiryawa da ajiye hoto

- 1 Daga jiran aiki zaɓi **Menu** ► **Nishaɗi** ► **PhotoDJ™ ko** ► **Mai sarrafa fayil** ► **Hotuna** kuma zaɓi hoto ► **Kari** ► **Shiryawa** ► **PhotoDJ™**.
- 2 Zaɓi wani zaɓi.
- 3 Bayan ka shirya hoton da ka zaɓa ► **Kari** ► **Ajiye hoto**.

Jigogi

Canja bayyanar allon, misali ta cikin abubuwa kamar launuka da allon fuskar waya, ta amfani da jigogi. Wayarka tana da wasu jigogi waɗanda aka ayyana ba za'a iya sharesu ba in an karesu. Zaka iya kirkiro sabbin jigogi da saukar da su zuwa wayarka. Don karin bayani, je zuwa www.sonyericsson.com/support.

Don zaɓi ko canja jigogi

- Daga jiran aiki zaɓi **Menu** ► **Mai sarrafa fayil** ► **Jigogi** kuma zaɓi jigo.

Musayar jigogi

Musanya jigogi ta amfani da hanyar canja wuri.

Don aika jigo

- 1 Daga jiran aiki zaɓi **Menu** ► **Mai sarrafa fayil** ► **Jigogi** kuma zaɓi jigo.
- 2 ► **Kari** ► **Aika** kuma zaɓi hanyar canja wuri.

Don karɓa da ajiye jigo

- 1 Yi amfani da hanyar canja wuri kuma bude sakon da ka karɓi jigon ta shi.
- 2 Bi umarnin dake bayyana.

Nishadi

Mai kunna kiɗa, mai kunna bidiyo, rediyo, PlayNow™, mai rikodin sauti, wasanni.

Abin sawa a kunni mai ɗaukuwa na siteriyo



Don amfani da abin sawa akunni

- Hada abin sawa akunni na sitreyo ma daukuwa zuwa wayarka don amfani da shi saboda kira, sauraron kiɗa, bidiyo ko rediyo. Idan ka karɓi kira kuma ka kunna kiɗa, kiɗa yana tsayawa don ka amsa kira. Kiɗa zai ci gaba lokacin da kiran ya kare ko aka ki karɓa.

Mai kunna kiɗa da mai kunna bidiyo

Wayarka tana goyan bayan, misali, nau'in fayil mai biyowa: MP3, AAC, AAC+, eAAC+, WMA da AMR. Haka kuma wayarka tana goyan bayan jeren fayiloli waɗanda suka dace da 3GPP.

Don kunna shirye-shiryen bidiyo

- 1 Daga jiran aiki zabi **Menu** ► **Nishadi** ► **Kayan bidiyo**. Mai lilon mai kunnawa ya buɗe.
- 2 Yi loli saboda shirye-shiryen bidiyo.
- 3 Yiwa take alama ► **Kunna**. Akwai zaɓuɓɓuka masu biyowa:
 - Latsa  don tsayar da kunna rikodi. Sake latsawa don cigaba da kunnawa.
 - Latsa  don zuwa shirin bidiyo na gaba.
 - Latsa  don zuwa shirin bidiyo wanda yawuce.
 - Latsa ka riƙe  ko  don sauri gaba ko baya lokacin kunna shirye-shiryen bidiyo.
 - Lokacin kunna shirin bidiyo, ► **Kari** don zaɓuɓɓuka.
 - Latsa ka riƙe  don fita.

Don kunna kiɗa

- 1 Daga jiran aiki zaɓi **Menu** ► **Kayan kiɗa**. Mai **Kayan kiɗa** lilon ya buɗe.
- 2 Yi lilo don kiɗa ta ɗan wasa ko waka, ko a lissafin waka. Zaɓi lissafi ► **Buɗe**.
- 3 Yiwa take alama ► **Kunna**.
Zaɓuɓɓuka masu biyowa akwaisu:

- Latsa  don tsayar da kunna waka. Sake latsawa don cigaba da kunnawa.
- Latsa  don zuwa waka ta gaba.
- Latsa  don zuwa waka wacce ta gabata.
- Latsa ka riƙe  ko  don tura waka gaba ko baya da suri.
- Lokacin kunna waka, ► **Kari** don zaɓuɓɓuka na gaba.
- Latsa ka riƙe  don fita.

Canja wurin kiɗa

Software na kwamfutatar wayar disc2 da akwatunan USB an haɗa su a CD wanda ya zo tare da wayarka. Yi amfani da Disc2Phone don canja wurin kiɗa daga CD ko kwamfutarka zuwa katin kwakwalwa a wayarka.

Kafin ka fara

Masu biyowa sune mafin karancin tsarin aiki da ake bukata saboda amfani da Disc2Phone a kan kwamfutarka:

- Windows 2000 SP4 ko
- XP Home, ko XP Professional SP1.

Don shigar da Disc2Phone

- 1 Kunna kwamfutarka kuma saka CD wanda yazo tareda wayarka ko ziyarci www.sonyericsson.com/support. CD yana farawa ta atomatik kuma shigar da window yana buɗewa.
- 2 Zaɓi yare kuma kaɗa **OK**.
- 3 Kaɗa *shigar da Disc2Phone* kuma bi ummurni.

Don amfani da Disc2Phone

- 1 Haɗa wayarka zuwa kwamfuta tare da kebul na USB wanda ya zo tareda wayarka kuma zaɓi **Cnj. wur.fayil**.
- 2 **Kwamfuta:** Fara/Shirye-shirye/ Disc2Phone.
- 3 Saboda bayanai kan Canja wurin waka. koma zuwa taimakon Disc2Phone. Kaɗa **?** a kusurwar sama ta dama na Disc2Phone window.

 *Kada ka cire kebul na USB daga wayar ko kwamfuta yayin canja wuri, hakan mai yiwuwa ya lalata katin kwakwalwar. Baza ka iya duba fayilolin da aka canja masu wuri ba a wayarka harsai ka cire kebul na USB daga wayar.*

- 4 Zaka iya samun bayanin CD (ɗan wasa, waka da haka na huɗu.) ta Disc2Phone idan an haɗa ka da Intanit kuma ana cire kiɗa daga CD.

 *Saboda amintaccen cire haɗi na kebul ɗin USB a yanayin canja wurin fayil, yi kaɗin dama a gumkin disk na cirewa a Windows Explore kuma zaɓi Fita.*

Saboda karin bayani ➡ *Canja wurin fayiloli ta amfani da kebul na USB 76 ko www.sonyericsson.com/support.*

Don canja wurin fayiloli tareɗa kebul na USB wanda aka bayar

- ➡ *Canja wurin fayiloli ta amfani da kebul na USB 76.*

Yin lilo da fayiloli

Yi lilon fayilolin kiɗa da shirin bidiyo:

- **Yan wasa** – lissafa fayilolin kiɗa waɗanda ka canja masu wuri ta amfani da Disc2Phone.
- **Wakoki** – lissafin fayilolin kiɗa (ba sautunan ringi ba) a wayarka kan katin kwakwalwar ajiya.

- **Lissafin waka** – kirkiri ko kunna lissafin fayilolin kiɗa naka.
- **Bidiyo** – Lissafa duk shirin bidiyo a wayarka ko kan katin kwakwalwar ajiya.

Lissafin waka

Don daidaita sautin fayilolin mai jarida wanda aka ajiye a **Mai sarrafa fayil**, zaka iya kirkiro lissafin waka Zaka iya kara fayil zuwa fiye da lissafin waka ɗaya.

Lokacin da ka share lissafin waka ko fayil daga lissafin waka, ainihin fayil ɗin wakar ko bidiyo ba'a share su ba daga kwakwalwar ajiyar, lissafin wakar ya danganta zuwa gare su kawai. Zaka kuma iya kara fayil zuwa wani lissafin waka.

Don kirkirar lissafin waka

- 1 Daga jiran aiki zaɓi **Menu ▶ Kayan kiɗa ▶ Lissafin waka ▶ Sabon liss.waka ▶ Kara**. Shigar sa suna ▶ **Ok**.
- 2 zaɓi daga fayilolin samammu a cikin mai sarrafa fayil. Zaka iya kara fayiloli da yawa a lokaci kuma zaka iya kara manyan fayiloli. Duk fayiloli acikin zaɓaɓɓun mayan fayiloli za'a iya kara su zuwa lissafin waka.

Don kara fayiloli zuwa lissafin waka

- 1 Daga jiran aiki zaɓi **Menu ▶ Kayan kiɗa**
▶ **Lissafin waka** zaɓi lissafin waka
▶ **Buɗe ▶ Kari ▶ Kara mai jarida.**
- 2 Zaɓi daga fayilolin samammu a mai sarrafa fayil.

Don cire fayiloli daga lissafin waka

- 1 Daga jiran aiki zaɓi **Menu ▶ Kayan kiɗa**
▶ **Lissafin waka** zaɓi lissafin waka
▶ **Buɗe.**
- 2 Zaɓi fayil ɗin kuma latsa (C).

Don share lissafin waka

- Daga jiran aiki zaɓi **Menu ▶ Kayan kiɗa ▶ Lissafin waka** zaɓi lissafin waka kuma latsa (C).

Zaɓuɓɓukan mai kunna kiɗa

▶ **Kari** don zaɓuɓɓuka:

- **Yan. kun. yanzu** – je zuwa **Yan. kun. yanzu** duba.
- **Kara mai jarida** – kara fayiloli ko manyan fayiloli zuwa lissafin waka.
- **Jera daga** – kasawa ta ɗan wasa ko take.
- **Share** – cire fayil daga lissafin wakar. A lissafin waka na mai amfani wanda aka kikiro mai dangantaka zuwa fayil ne kawia aka cire Acikin **Wakofi** lissafin, an share fayil ɗin har abada daga kwakwalwar ajiyar.

- **Rage girma** – rage girman mai kunna kiɗa da komawa zuwa jiran aiki tareda kiɗa akunne har yanzu.
- **Sake suna** – sakewa lissafin waka suna da ka kirkira.
- **Shre. lissafi. waka** – share lissafin wakar mai amfani da aka kirkira. Ba'a share fayiloli daga mai sarrafa fayil ɗin ba.
- **Bayani** – duba bayani gameda fayil na yanzu ko bidiyo.
- **Yanayin kunnawa** – canja sake kunna tsarin wakoki da bidiyoyi. Zaɓi **Lale** don kunna fayilolin lissafin waka a tsari da ka, ko **Loopmaimaitawa** don sake fara lissafin wakar lokacin da aka gama kunna fayil ɗin karshe.
- **Mai ddt st.** – canja saituna hauhawar kara da sauti.
- **Aika** – aika fayil na kiɗa ko shirin bidiyo.
- **Faɗaɗa siteriyo** – canja fitar sauti.

Kiɗan kan layi da shirye-shiryen bidiyo

Duba shirye-shiryen bidiyo kuma saurari kiɗa ta yawo da su zuwa wayarka daga Intanit. Idan babu saituna a wayarka ▶ **Saituna 67.** Saboda karin bayani tuntubi mai sa aiki na cibiyar sadarwarka ko je zuwa www.sonyericsson.com/support.

Don zaɓar lissafin bayanai don jerin gwano

- Daga jiran aiki zaɓi **Menu ▶ Saituna ▶ Haɗuwa shafin ▶ Saitunan yawo** kuma zaɓi lissafin bayanai don amfani.

Don yawon bidiyo da mai jiwuwa

- 1 Daga jiran aiki zaɓi **Menu ▶ Intanit ▶ Kari ▶ Je zuwa ▶ Shigarda adreshi**.
- 2 Shigar ko zaɓi adreshin ɗakin yanar sadarwa kuma zaɓi hanyar haɗi don yin jere daga. Mai kunnawa yana buɗewa ta atomatik lokacin da aka zaɓi hanyar haɗi.

Don yawon ajiyayiyen kiɗa da shiryen bidiyo

- 1 Daga jiran aiki zaɓi **Menu ▶ Intanit ▶ Kari ▶ Je zuwa ▶ Alamomin shafi**.
- 2 zaɓi hanyar haɗi don gudana. Mai kunnawa yana buɗewa kuma yana kunna kiɗan ko bidiyo.

TrackID™

TrackID™ sabis ne na shaidar kiɗa kyauta. Zaka iya bincika take ta atomatik, ɗan wasa da sunayen kundi don waƙar da kaji akunne ta lasifika ko a rediyo.

Don bincika bayanin waka

- Daga jiran aiki zaɓi **Menu ▶ Nishaɗi ▶ TrackID™** lokacin jin waka.
- **▶ Kari ▶ TrackID™** lokacin da kaji waƙa yana kunne a rediyo.



Babu TrackID a duk kasashen. Don karin bayani tuntubi mai baka sabis.

Rediyo

Saurari rediyon FM. Haɗa abin sawa akunni zuwa wayar yayin da yake aiki azaman eriya.



Kada kayi amfani da wayar azaman rediyo a wuraren da aka hana.

Don sauraron rediyo

- Haɗa abin sawa akunni zuwa wayarka. Daga jiran aiki zaɓi **Menu ▶ Rediyo**.

Ikon rediyo

- **Bincika** – bincika mitar watsa labarai.
- Latsa  ko  don motsa 0.1 MHz.
- Latsa  ko  don tashoshin da aka saita.
- **Kari** – duba zaɓuɓɓuka.

Ajiye tashoshin rediyo

Ajiye har zuwa saitattun tashoshi 20.

Don ajiye tashoshin rediyo

- Daga jiran aiki zaɓi **Menu** ▶ **Rediyo** saita mita ▶ **Kari** ▶ **Ajiye** ko latsa ka riƙe (0+) - (9) don ajiyewa a wurare 1 zuwa 10.

Don zaɓin tashoshin rediyo

- Latsa (↩) kuma (↪) ko latsa (0+) - (9) don zaɓin ajiyayyir tasha a wurare 1 zuwa 10.

Zabuɓɓukan rediyo

▶ **Kari** saboda zaɓuɓɓuka masu biyowa:

- **Kashe** – kashe rediyon.
- **TrackID™** – bincika sunan ɗan wasa da sunna take ta atomic don wakar da take akunne a rediyon yanzu.
- **Ajiye** – ajiye sabuwar mita a wuri.
- **Tashoshi** – zaɓi, sake suna, maye gurbi ko share tashar da aka saita.
- **Ajiyar atomatik** – ajiye tashoshin karin waka a cikin wuri 1 zuwa 20. Ana maye gurbin ajiyayyun tashoshin da suka gabata.
- **Kunna lasifika** – yi amfani da lasifika.
- **Saita mita** – shigar da mita da hannu. Latsa (#→) don tafiya kai tsaye zuwa **Saita mita**.
- **RDS** – saita zaɓuɓɓuka saboda maimakon mita (AF) da bayanin tasha.

- **Kunna Mono** – kunna sautin mono.
- **Rage girma** – koma zuwa jiran aiki don amfani da wasu ayyuka lokacin amfani da rediyo.

Don dai-daita karan

- Latsa (▲) ko (▼) do rage ko daɗa kara.

PlayNow™

Saurari kiɗa kafin ka saya da sauke shi zuwa wayarka.



Wannan aikin cibiyar sadarwa ne- ko dogaron mai sa aiki. Tuntuɓi afaretan cibiyar sadarwarka don bayani gameda biyan kuɗinka da PlayNow™. A wasu kasashe zai yiwu ka iya sayan karin kiɗa daga wasu manyan yan wasan kiɗa na duniya.

Kafin ka fara

Idan saitunan da ake bukata ba su a wayarka ➡ *Saituna 67.*

Don sauraron kiɗan PlayNow™

- Daga jiran aiki zaɓi **Menu** ▶ **PlayNow™** don zaɓin kiɗa daga lissafi.

Saukewa daga PlayNow™

Farashin yana bayyana lokacin da ka zaɓi saukewa da ajiyewa a fayil na kiɗa. Ana bashin lissafin wayarka ko katin kuɗin da aka biya lokacin da aka karɓi saye. Hakanan ana bada sharuɗɗa da halaye cikin kwalin waya.

Don sauke fayil na kiɗa

- 1 Lokacin da ka saurari samfotin fayil ɗin kiɗa, zaka iya yarda don karɓar sharuɗɗa, ► **Ee** don saukewa.
- 2 Ana aika sakon rubutu don tabbatar da biya kuma akwai fayil da akayi don saukewa. An ajiye kiɗa a **Mai sarrafa fayil** ► **Kiɗa**.

Sautunan ringi da karin waka

Zaka iya musanya kiɗa, sautuna da wakoki, misali, kana mai amfani da ɗayan hanyoyin canja wuri wanda suke akwai.

 *Ba'a yarda ka musanya wani abin hakkin mallaka mai tsaro ba. Fayil na hakkin mallaka mai kariya yana da alamar maballi.*

Don zaɓar sautin ringi

- Daga jiran aiki zaɓi **Menu** ► **Saituna** ► **Sauti & faɗakarwa** shafin ► **Sautin ringi**.

Don kunna ko kashe sautin ringi

- Latsa ka riƙe (#) daga jiran aiki ko daga jiran aiki zaɓi **Menu** ► **Saituna** ► **Sauti & faɗakarwa** shafin saboda karin zaɓuɓbuka. Ana rinjayar duk sigina banda na kararrawa.

Don saita karan sautin ringi

- 1 Daga jiran aiki zaɓi **Menu** ► **Saituna** ► **Sauti & faɗakarwa** shafin ► **Karar ringi** kuma latsa ◀ ko ▶ don rage ko daɗa karan.
- 2 ► **Ajiye**.

Don saita faɗakarwan jijjiga

- ► **Saituna** ► **Sauti & faɗakarwa** shafin ► **Faɗakarwar jijjiga** kuma zaɓi wani zaɓi.

Sautuna da zaɓuɓbukan faɗakarwa

Daga jiran aiki zaɓi **Menu** ► **Saituna** ► **Sauti & faɗakarwa** shafin, zaka kuma iya saita:

- **Faɗakarwar sako** – zaɓi yadda za'a sanar da kai sako mai shigowa.
- **Sautin maballi** – zaɓi wani sauti zaka ji lokacin da ka latsa maballai.

MusicDJ™

Daidaita ka shirya karin wakokinka don amfani dasu azaman sautunan ringi. Karin waka ya kunshi nau'ukan wakoki huɗu – **Ganga, Basses, Chords**, kuma **Launin harshe**. Waka yana ɗauke da adadin toballi na kiɗa. Tobali yana tattare da sautuna da aka riga aka shirya tareda kalmomi daban-daban. An tattara tubalan cikin **Gabatarwa, Aya, Chorus**, kuma **Hutu**. Kana shirya karin waka ta kara tubalan kiɗa zuwa wakokin.

Don shirya karin waka

- 1 Daga jiran aiki zaɓi **Menu ▶ Nishaɗi ▶ MusicDJ™**.
- 2 ▶ **Sa**, Kwafi ko **Manna** tubala. Yi amfani da , ,  da  don matsawa tsakanin tobulla. Latsa  don share toballi. ▶ **Kari** don duba karin zaɓubbuka.

Don shirya karin wakar MusicDJ™

- Daga jiran aiki zaɓi **Menu ▶ Mai sarrafa fayil ▶ Kiɗa** kuma zaɓi karin waka ▶ **Kari ▶ Shirya**.

Musanya karin wakokin MusicDJ™

Aika kuma karɓi karin wakoki ta amfani da ɗayan wadatattun hanyoyin canja wuri. Ba'a yarda ka musanya abu wanda keda kariyar haƙƙin mallaka ba.



Ba zaka iya aika sautunan karin waka ko fayil na MP3 a cikin sakon rubutu ba.

Don aika karin waka

- 1 Daga jiran aiki zaɓi **Menu ▶ Mai sarrafa fayil ▶ Kiɗa** kuma zaɓi karin waka.
- 2 ▶ **Kari ▶ Aika** kuma zaɓi hanyar canja wuri.

Don karɓan karin waka ta amfani da hanyar canja wuri

- Zaɓi hanyar canja wuri kuma bi umarnin dake bayyana.

VideoDJ™

Daidaita kuma shirya shirin bidiyo naka ta amfani da shirin bidiyo, hotuna da rubutu. Zaka kuma iya datse bangarori na shirin bidiyo don gajarta shi.

Don kirkiro shirin bidiyo

- 1 Daga jiran aiki zaɓi Menu ► Nishaɗi ► VideoDJ™.
- 2 ► Kara ► Shirin bidiyo, Hoto, Rubutu ko Kamara ► Zaɓi.
- 3 Don kara karin abubuwa latsa  ► Kara.

Don shirya zaɓaɓɓen shirin bidiyo

- ► **Shirya** saboda zaɓuɓɓuka:
 - **Gyara** – gajarta shirin bidiyo.
 - **Kara rubutu** – kara rubutu zuwa shirin bidiyo.
 - **Share** – cire shirin bidiyon.
 - **Matsar** – matsarda shirin bidiyo zuwa wani wuri.
 - **Kwafi** – kwafi shirin bidiyo zuwa wani wuri.

Don shirya zaɓaɓɓen hoto

- ► **Shirya** saboda zaɓuɓɓuka:
 - **Tsawon lokaci** – zaɓi lokacin nuna hoton.
 - **Share** – cire hoton.
 - **Matsar** – matsarda hoton zuwa wani wuri.
 - **Kwafi** – Kwafi hoton zuwa wani wuri.

Don shirya zaɓaɓɓen rubutu

- ► **Shirya** saboda zaɓuɓɓuka:
 - **Shirya rubutu** – canja rubutun.
 - **Launuka** – kwam zaɓi **Bango baya** don saita bango ko **Launin rubutu** don saita launin rubutu.
 - **Tsawon lokaci** – zaɓi lokacin nuna rubutu.
 - **Share** – cire rbutun.
 - **Matsar** – matsarda rubutun zuwa wani wuri.
 - **Kwafi** – Kwafi rubutun zuwa wani wuri.

Zaɓuɓɓukan VideoDJ™

- ► **Kari** don zaɓuɓɓuka:
 - **Kunna** – duba shirin bidiyo.
 - **Aika** – aika da shirin bidiyo.
 - **Wakr. shiri. bidy.** – kara wakr. shiri. bidy.zuwa shirin bidiyo.
 - **Canji** – saita sauyi tsakanin shirye-shiryen bidiyo, hotuna da rubutu.
 - **Ajiye** – ajiye shirin bidiyon.
 - **Sa** – shigar da sabon shirin bidiyo, hoto ko rubutu.
 - **Sabuwar bidiyo** – kirkiro sabon shirin bidiyo.

Don shirya shirin bidiyo a mai sarrafa fayil

- 1 Daga jiran aiki zaɓi **Menu** ► **Mai sarrafa fayil** ► **Bidiyo** ► **Buɗe** kuma zaɓi fayil.
- 2 ► **Kari** ► **VideoDJ™** ► **Shirya**.

Aikawa da shirye-shiryen bidiyo

Zaka iya aikawa da shirin bidiyo ta amfani da ɗayan wadatattun hanyoyin canja wuri. Za'a iya aikawa da gajeron shirye-shiryen bidiyo ta amfani da sakon hoto. Idan shirin bidiyo yayi tsawo da yawa, zaka iya amfani da aikin datsawa don gajarta shirin bidiyo.

Don datse shirin bidiyo

- 1 Zaɓi shirin bidiyo da allon labari ► **Shirya** ► **Gyara**.
- 2 ► **Saiti** don saita wurin farawa kuma ► **Fara**.
- 3 ► **Saiti** don saita wurin karewa kuma ► **Kare**.
- 4 Maimaita taku 2 da 3 ko ► **Gyara**.

Sautin rikoda

Tareda rikodin sauti, zaka iya naɗe misali, sautin memo ko kira Sautin da aka yi rokodin shi zai kuma iya zama sautin ringi. Rikodin taɗi yana tsayawa idan ɗan takara ya tsaida kiran. Rikodin duk sautuna yana tsayawa ta atomatik idan ka karɓi kira.



A wasu kasashe ko jahohi doka na bukatan sanar da mutum kafin rikodin kira.

Don rikodin sauti

- 1 Daga jiran aiki zaɓi **Menu** ► **Nishaɗi** ► **Yi rikodin sauti**.
- 2 Jira har sai kaji sauti. Lokacin da rikodi yafara, **Rikodi** kuma mai kidaya lokaci ya bayyana.
- 3 ► **Ajiye** don karewa.
- 4 ► **Kunna** don sauraro ko ► **Kari** don zaɓubɓuka: **Yi rikodin sabo**, **Aika**, **Sake suna**, **Share**, **Sautinan da akayi rikodi**.

Don sauraron rikodi

- Daga jiran aiki zaɓi **Menu** ► **Mai sarrafa fayil** ► **Kiɗa** kuma zaɓi yin rekodi ► **Kunna** ko ► **Tsaida**.

Wasanni

Wayarka ta kunshi wasanni da yawa. Zaka kuma iya saukar da wasanni da aikace-aikace kaitsaye zuwa manyan fayiloli a wayarka. Akwai rubutun taimako don yawancin wasannin.

Don fara da kare wasa

- 1 Daga jiran aiki zaɓi **Menu** ► **Nishaɗi** ► **Wasanni** kuma zaɓi wasa.
- 2 Latsa ka rike  don kare wasan.

Aikace-aikace

Zaka iya saukarwa da gudanar da aikace-aikace na Java™, misali, don amfani da sabis. Kuma zaka iya duba bayani don saita matsayin izini daban-daban.

Don duba bayani saboda aikace-aikacen Java

- 1 ▶ **Mai sarrafa fayil** ▶ **Aikace-aikace** ko ▶ **Wasanni**.
- 2 Zaɓi aikace-aikace ko wasa ▶ **Kari** ▶ **Bayani**.

Don duba izini saboda aikace-aikacen Java

- 1 Daga jiran aiki zaɓi **Menu** ▶ **Mai sarrafa fayil** ▶ **Aikace-aikace** ko ▶ **Wasanni**.
- 2 Zaɓi aikace-aikace ko wasa ▶ **Kari** ▶ **Izinoni** kuma saita zaɓuɓɓuka.

Girman allon aikace-aikace na Java

An tsara wasu aikace-aikacen Java don takamaiman girman allo. Don karin bayani, tuntuɓi dillalin aikace-aikacen.

Don saita girman allo saboda aikace-aikace na Java

- 1 Daga jiran aiki zaɓi **Menu** ▶ **Mai sarrafa fayil** ▶ **Aikace-aikace** ko ▶ **Wasanni**.
- 2 Zaɓi aikace-aikace ko wasa ▶ **Kari** ▶ **Girman allo** kuma zaɓi wani zaɓi.

Haɗi

Saituna, Itanin, RSS, aiki tare, fasahar Bluetooth™, Kebul na USB, d'aukaka sabis.

Saituna

Zai yiwu anriga an shigar da saituna lokacin da ka sayi wayarka. Idan bahaka ba, tabbatar kana da aiki tare na waya wanda yake goyan bayan canja wurin bayanai (GPRS).

Zaka iya saukar da saituna zuwa wayarka saboda lilon itanin, email da sakon hoto. Wannan zai iya yiwuwa ta amfani da saitin maye a wayarka ko daga kwamfuta a www.sonyericsson.com/support.

Don sauke saituna ta amfani da wayarka

- Daga jiran aiki zaɓi **Menu** ▶ **Saituna** ▶ **Gaba ɗaya** shafin ▶ **Saita maye** ▶ **Saukar da saituna** kuma bi umarnin da ya bayyana.

Don sauke saituna ta kwamfuta

- 1 Je zuwa www.sonyericsson.com/support.
- 2 Zaɓi yanki da kasa.

- 3 Zaɓi *saitin wayar shafi*, kuma zaɓi samfur ɗin waya.
- 4 Zaɓi wane saiti don saukewa zuwa wayarka.

Amfani da Intanit

Yi amfani da Intanit don samun damar sabis kan layikamar labarai da banki kuma don bincikawa da yin lilon Yanar sadarwar.

Don fara lilo

- Daga jiran aiki zaɓi **Menu** ► **Intanit** kuma zaɓi sabis kamar ► **Kari** ► **Je zuwa** ► **Binciken intanit** ko **Shigarda adireshe** zuwa kowane shafin yanar sadarwa.

Don duba zaɓuɓɓuka

- Daga jiran aiki zaɓi **Menu** ► **Intanit** ► **Kari**.

Don tsaida lilo

- ► **Kari** ► **Fita mai lilo**.



Don karin bayani tuntuɓi mai sa aiki na cibiyar sadarwa naka ko jeka zuwa www.sonyericsson.com/support.

Zaɓuɓɓuka lokacin lilo

- **Kari** don duba zaɓuɓɓuka. Menu yana kunsar masu biyowa amma ya dogara da ɗakin yanar sadarwar da kake ziyarta:
 - ► **Ciyarwa RSS** – zaɓi wadatattun ciyarwar don shafin yanar sadarwar.
 - ► **Je zuwa** don mai biyowar:
 - **Sony Ericsson** – jeka zuwa zauran gidan yanar da aka ayyana wanda aka saita saboda sabon bayanin martaba.
 - **Alamomin shafi** – kirkiri, yi amfani da ko shirya alamun shafi zuwa shafin yana.
 - **Shigarda adireshe** – shigar da adreshin shafin yanar sadarwa.
 - **Binciken intanit** – yi amfani da Google don bincike.
 - **Tarihi** – lissafin shafukan yanar sadarwa wadanda aka riga aka ziyarta.
 - **Aje shafi** – lissafin shafin yanar sadarwar da aka ajiye.
 - ► **Kayan aiki** don mai biyowar:
 - **Kara alamar shafi** – kara sabon alamar shafi.
 - **Ajiye hoto** – ajiye hoto.
 - **Ajiye shafi** – ajiye sabon shafin yanar sadarwa.

- **Sak. maimait.shafi** – maimaita sabon shafin yanara sadarwa.
 - **Aika hanyar haɗi** – aika haɗi zuwa shafin yanar sadarwa.
 - **Yi kira** – yi kira lokacin yin lilon Intanit.
 - ▶ **Kari** ▶ **Kas.kira** don kare kiran da ci gaba da lilo.
 - ▶ **Duba** don mai biyowar:
 - **Cika fuska** – zaɓi na al'ada ko cikakken allo.
 - **Daji,yanayin fili** – zaɓi daji ko allon hoton mutum.
 - **Rubutu kawai** – zaɓi cikakken abun ciki ko rubutu kawai.
 - **Zukowa** – zuko ciki ko waje a shafin yanar sadarwa.
 - **Zuko zu.na al'ada** – saita zukowa zuwa tsoho.
 - ▶ **Zabuɓɓuka** ▶ **Lilo** shafin saboda masu biyowa:
 - **Smart-Fit** – daidaita shafin yanar sadarwa zuwa allon.
 - **Nuna hotuna** – saita a kunne ko a kashe.
 - **Nuna rayarwa** – saita a kunne ko a kashe.
 - **Kunna sautina** – saita a kunne ko a kashe.
 - **Izinin cookies** – saita a kunne ko a kashe.
 - **Ynyi. faifan maɓal.** – zaɓi daga **Gajeron hanyoyi** saboda maɓallan mai lilo **Maballan shiga** saboda kewayon shafin yanar sadarwa mafi sauri, in akwai.
 - ▶ **Zabuɓɓuka** ▶ **Wasu** shafin saboda masu biyowa:
 - **Share cookies**
 - **Share ma'ajiyi**
 - **Shre. kalmr. wcew.**
 - **Hali** – nuna bayanin haɗi.
 - ▶ **Fita** mai lilo don cire haɗi.
- Amfani da alamun shafi**
- Yi amfani da, kirkiƙiri kuma shirya alamun shafi azaman hanyar haɗi mai sauri zuwa daƙunan yanar sadarwar don mai lilo.
- Don aiki tareda alamun shafi**
- 1 Daga jiran aiki zaɓi **Menu** ▶ **Intanit** ▶ **Kari** ▶ **Je zuwa** ▶ **Alamomin shafi** kuma alamar shafi ▶ **Kari**.
 - 2 Zaɓi wani zaɓi, kamar aika alamar shafi azaman sakon rubutu.
- Gajeron hanyoyi na Intanit**
- Lokacin amfani da Intanit, zaka iya amfani da gajeron hanyoyin faifan maɓallai zuwa zaɓuɓɓuka menu.

Don amfani da gajerun hanyoyin faifan maballin Intanit ko samun damar maballai

- 1 Lokacin yin lilo, latsa ka riƙe (#→) don zaɓar **Gajerun hanyoyi ko Maballan shiga**.
- 2 Idan ka zaɓi **Gajerun hanyoyi**, zaka iya latsa maɓalli don aiki kamar yadda ya biyo:

Maballi Gajeriyyar hanya

①	Alamomin shafi
②	Shigarda adireshe
③	Binciken intanit
④	Tarihi
⑤	Sak. maimait.shafi
⑥	Mika
⑦	Shafi sama
⑧	Wanda ba'ayi amfani dashi ba
⑨	Shafi a kasa - daya a lokaci
✳ →	Cika fuska ko Daji,yanayin fili ko Allo na al'ada
□ +	Zukowa
#→	Gajerun hanyoyi

Saukewa

Sauke fayiloli, masali, hotuna, jigogi, wasanni da sautunan ringi daga shafin yanar sadarwa.

Don saukewa daga shafin yanar sadarwa

- Lokacin lilo, zaɓo fayil don saukewa kuma bi ummurni wanda ke bayyana.

Bayanan martaba na Intanit

Zaka iya zaɓar wani bay. martab. Intanit idan Kanada fiye da ɗaya.

Don zaɓar bayanin martaba na Intanit don mai lilo na Intanit

- Daga jiran aiki zaɓi **Menu ► Saituna ► Haɗuwa shafin ► Saitunan intanit ► Bayn.mrtb. intanit** kuma zaɓi bayanin martaba.

Bayanin martaba na Intanit don aikace-aikacen Java™

Wadansu aikace-aikacen Java™ suna buƙatar haɗi zuwa Intanit don karɓar bayani, masali, wasanni waɗanda suke sauke sababbin mataƙai daga uwar garƙen wasa.

Kafin ka fara

Idan babu saituna a wayarka
➡ *Saituna 67.*

Don zaɓar bayanin martaba saboda Java

- Daga jiran aiki zaɓi **Menu ▶ Saituna ▶ Haɗuwa shafin ▶ Saitunan Intanin ▶ Saitin Java** kuma zaɓi bayanin martabar Intanin.

Bayanin da aka ajiye

Lokacin lilo, zaka iya ajiye bayani mai biyowa:

- Cookies – gyara ingancin samun damar shafin yanar sadarwa.
- Kalmar wucewa – gyara ingancin samun damar uwar garke.



Ana bada shawar ka share duk wani mahimmin bayani daga sabis na Intanin na ziyarar da ta gabata. Wannan don kaucewa mu'amala mara kyau na bayanin sirri idan ka manta inda ka ajiye wayarka, ta bace ko an sace.

Don izinin cookies

- Daga jiran aiki zaɓi **Menu ▶ Intanin ▶ Kari ▶ Zabubbuka ▶ Lilo shafin ▶ Izinin cookies ▶ Kunnawa.**

Don share cookies, suto ko kalmar wucewa

- Daga jirana aiki zaɓi **Menu ▶ Intanin ▶ Kari ▶ Zabubbuka ▶ Wasu shafin** kuma zaɓi wani zaɓi ▶ **Ee.**

Tsaro na Intanin da takaddun shaida

Wayarka tana goyan bayan tsararren lilo. Takamammen sabis na Intanin, kamar harkar banki, yana bukarar takaddun shaida a cikin wayarka. Zai yiwu wayarka tariga takunshi takaddun shaida lokacin da kasaya ko ka iya sauke sababbin takaddun shaida.

Don bincika takaddun shaida a cikin wayarka

- Daga jiran aiki zaɓi **Menu ▶ Saituna ▶ Gaba ɗaya shafin ▶ Tsaro ▶ Takaddun shaida.**

Mai karanta RSS

Lokacin lilo, zaka iya samun abun ciki sau da yawa wanda aka ɗaukaka, kamar mahimman kanun labarai, yayin da ciyarwa ke amfani da shafin yanar sadarwa. Zaka iya lilo zuwa shafin yanar sadarwa don sabuwar ciyarwa, idan akwai. An saita zaɓuɓɓukan Really Simple Syndication (RSS) suna amfani da mai karanta RSS kuma an nuna a mai lilo na Intanin.

Don kara sabuwar ciyarwa saboda shafin yanar sadarwa

- Lokacin lilo ▶ **Kari ▶ Ciyarwa RSS.**

Don kirƙirar sabuwar ciyarwa

- 1 Daga jiran aiki zaɓi **Menu ▶ Sako ▶ Mai karanta RSS ▶ Kari ▶ Sabon ciyarwa.**
- 2 Shigar da adreshi kuma zaɓi **Je zuwa.**

Don saitawa da amfani da zaɓuɓɓukan mai karanta RSS

- Daga jiran aiki zaɓi **Menu ▶ Sako ▶ Mai karanta RSS ▶ Kari** kuma zaɓi wani zaɓi.

Aiki tare

Haɗa aiki tare da lambobin waya, alƙawarurruka, dawainiya da bayanin lura kana mai amfani da fasaha mara waya ta Bluetooth™, sabis na Intanit ko keɓul na USB wanda aka haɗa tare da wayar.

Aiki tare da kwamfuta

Shigar software na aiki tare don kwamfutarka wadda aka samo a cikin Sony Ericsson PC akan CD, wanda aka haɗa tare da wayar. Software ya kunshi bayanin taimako. Zaka kuma iya zuwa www.sonyericsson.com/support don saukar da software ko **aiki tare** da kwamfuta Jagoran farawa.

Aiki tare na nisa yana amfani da Intanit

Yi aiki tare akan layi kana mai amfani da sabis na Intanit.

Kafin ka fara

- Idan babu saituna a wayarka
 ▶ **Saituna 67.**
- Yi rijistar lissafin aiki tare akan layi.
- Shigar da saitunan aiki tare na nisa.

Don shigar da saitunan aiki tare na nisa

- 1 Daga jiran aiki zaɓi **Menu ▶ Oganeza ▶ Aiki tare ▶ Ee** don kirƙiro sabon lissafin da farko ko **Sabon lissafi ▶ Kara** don kara wani sabon lissafi.
- 2 Shigar da suna don sabon lissafin
 ▶ **Ci gaba.**
- 3 Shigar da mai biyowa:
 - **Adrsh. uwar garke** – uwar garke URL.
 - **Sunan mai amfani** – sunan mai amfani na lissafi.
 - **Kalmar wucewa** – kalmar wucewa na lissafi.
 - **Haɗi** – zaɓi bayanin martaba na Intanit.
 - **Aikace-aikace** – yiwa aika-aikace alama don aiki tare.
 - **Kayan saiti** – zaɓi aikace-aikace kuma shigar da sunan tushan bayanai, in an bukata, sunan mai amfani da kalmar wucewa.

- **Tazaran aiki tare** – saita kamar sau nawa don aiki tare.
- **Farawar nisa** – zaɓi karɓa koda yausha, kar a taɓa karɓa ko tambaya koda yausha lokacin aiki tare daga sabis.
- **Tsaro daga nisa** – saka ID na uwar garke da kalmar wucewa ta uwar garke.

4 ▶ **Ajiye** don ajiye sabon lissafinka.

Don fara aiki tare na nisa

- Daga jiran aiki zaɓi **Menu** ▶ **Oganeza** ▶ **Aiki tare** kuma zaɓi lissafi ▶ **Fara**.

Fasaha mara waya ta Bluetooth™

Aikin Bluetooth™ yana sa haɗi mara waya zuwa wasu na'urorin Bluetooth yazama mai yuwuwa. Zaka iya:

- haɗa zuwa na'urar abin sawa akunni.
- haɗa zuwa abin sawa akunni na siteriyo.
- haɗa zuwa na'ururi da waya a lkaci guda.
- haɗa zuwa kwafutoci kuma sami damar Intanit.
- haɗa aikin bayani tareda kwafutoci.
- yin amfani da aikace-aikacen ikon ramut na kwamfuta.

- yi amfani da na'urorin haɗi na mai duba mai jharida.
- abubuwan musanyawa.



Munyi wasiya da kewayo tsakanin mita10 (kafa33), ba cikin tsakani abubuwa daskararru ba, don sadarwar Bluetooth.

Kafin ka fara

- Kunna aikin Bluetooth don sadarwa tare da wasu na'urorin.
- Gama na'urorin Bluetooth tare da wayarka don sadarwa da.



Bincika idan dokokin kasa ko ka'idoji sun takaita amfanin fasaha mara waya ta Bluetooth. Idan ba'a yarda da fasaha mara waya ta Bluetooth ba, dole ka tabbatar cewa an kashe aikin Bluetooth.

Don kunna aikin Bluetooth

- Daga jiran aiki zaɓi **Menu** ▶ **Saituna** ▶ **Haɗuwa shafin** ▶ **Bluetooth** ▶ **Kunna**.

Ware na'urori tareda wayarka

Shigar da lambar wucewa don saita hanyar haɗi mai tsaro tsakanin wayarka da na'ura. Shigar da lambar wucewa iri ɗaya akan na'ura lokacin gami. Na'ura mara sararin mai amfani, kamar abin sawa akunni, zai sami tsararriyar lambar wucewa. Duba jagorar mai amfani na na'ura don karin bayani.



Tabbatar cewa na'urar da kake son ka kara tana da aikin Bluetooth akunne kuma za'a iya gani.

Don kara na'ura zuwa wayarka

- 1 Daga jiran aiki zaɓi **Menu** ► **Saituna** ► **Haɗuwa** shafin ► **Bluetooth** ► **Na'urori nawa** ► **Sabuwar na'ura** don bincika samammun na'urori. Tabbatar ana iya ganin ɗaya na'urar.
- 2 Zaɓi na'ura daga lissafin.
- 3 Shigar da lambar wucewa, idan an bukata.

Don bawa haɗi izini ko shirya lissafin na'uraraka

- 1 Daga jiran aiki zaɓi **Menu** ► **Saituna** ► **Haɗuwa** shafin ► **Bluetooth** ► **Na'urori nawa** kuma zaɓi na'ura daga lissafin.
- 2 ► **Kari** don duba lissafin zaɓuɓɓuka.

Don kara abin sawa akunni na Bluetooth

- 1 Daga jiran aiki zaɓi **Menu** ► **Saituna** ► **Haɗuwa** shafin ► **Bluetooth** ► **Abin sawa** akunni.

- 2 ► **Ee** idan kana kara abin sawa a kunni na Bluetooth da farko ko ► **Abn.saw. akun.nw.** ► **Sab. abn.sw.akun.** ► **Kara** idan kana kara wani abin sawa a kunni na Bluetooth. Tabbatar cewa abin sawa akunni naka yana cikin yanayi mai kyau. Duba jagorar mai amfani na na'ura don karin bayani.

Ajiye wuta

Kunna don rage jan wuta ta karfafa wayarka saboda amfani tareda sigina na na'urar Bluetooth. Kashe don haɗawa tareda na'urori dayawa na Bluetooth a lokaci guda.

Don ajiye wuta

- Daga jiran aiki zaɓi **Menu** ► **Saituna** ► **Haɗuwa** shafin ► **Bluetooth** ► **Ajiye wuta** ► **Kunnawa**.

Sunan waya

Shigar da suna don wayarka wanda za'a nuna a lokacin da wata na'ura ta nemo shi.

Don shigar da sunan waya

- Daga jiran aiki zaɓi **Menu** ► **Saituna** ► **Haɗuwa** shafin ► **Bluetooth** ► **Sunan waya**.

Gani

Zabi don sa wayarka mai ganuwa ga wasu na'urorin Bluetooth ko a'a. Idan an saita wayar a buya, na'urori kawai a **Menu ► Saituna ► Haɗuwa shafin ► Bluetooth ► Na'urori nawa** ke iya nemo wayarka ta amfani da fasaha mara waya ta Bluetooth.

Don nuna ko boye wayarka

- Daga jiran aiki zabi **Menu ► Saituna ► Haɗuwa shafin ► Bluetooth ► Ganuwa ► Nuna waya ko Boye waya**.

Musayar abubuwa

Aika ko karɓi abubuwa ta amfani da fasaha mara waya ta Bluetooth azaman hanyar canja wuri. Zabi na'ura daga lissafin na'urorin da aka samo.

Don aika abu

- 1 Zabi abu, misali daga jiran aiki zabi **Menu ► Lambobi** kuma zabi lamba.
- 2 ► **Kari ► Aika lamba ► Ta Bluetooth**.
- 3 Zabi na'urarar da zaka aika abu zuwa gareta ► **Zabi**.

Don karɓan abu

- 1 Daga jiran aiki zabi **Menu ► Saituna ► Haɗuwa shafin ► Bluetooth ► Kunna**.
- 2 ► **Ganuwa ► Nuna waya**.
- 3 Lokacin da karɓi wani abu, bi umarni wanda ke bayyana.

Canja wurin sauti

Zaka iya canja wurin sauti don kira lokacin amfani da abin sawa akunni na Bluetooth™.

Zaka kuma iya canja wurin sauti don kira lokacin ta amfani da faifan maɓalai ko maɓallin abin sawa akunni kamar yadda yake biyowa:

- Latsa maɓallin abin sawa akunni saboda sauti a abin sawa akunni.
- Latsa maɓallin waya ko maɓalli (in an saita zuwa **Cikin waya**) saboda sauti a waya.
- Latsa kowane maɓalli (in an saita zuwa **A abin sw. akun.**) saboda sauti a abin sawa akunni.

Don canja wurin sauti lokacin amfani da abin sawa akunni na Bluetooth

- Yayin kira, ► **Kari ► Canja wurin sauti** kuma zabi na'ura.

Don canja wurin sauti lokacin amsa kira tareda abin sawa akunni

- 1 Daga jiran aiki zabi **Menu** ► **Saituna** ► **Haduwa shafin** ► **Bluetooth** ► **Abin sawa akunni** ► **Kira mai shigowa**.
- 2 ► **Cikin waya** don zuwa wayar kaitsaye ko ► **A abin sw. akun.** don kaitsaye zuwa abin sawa akunni.

Ikon ramut

Yi amfani da wayarka azaman na'urar ramut don sarraf aikace-aikacen kwamfuta kamar mai jaridar waka ko kaddamar Microsoft® PowerPoint® ko na'urori masu goyan bayan bayanin martaba na Bluetooth HID.

Don zaɓar ramut

- 1 ► **Don kara na'ura zuwa wayarka 74,** in an bukata.
- 2 Daga jiran aiki zabi **Menu** ► **Nishaɗi** ► **Ramut**.
- 3 Zabi aikace-aikace don amfani da kuma kwamfuta ko na'ura don haɗawa gareta.

Canja wurin fayil

Idan kwamfutarka tana goyan bayan fasaha mara waya ta Bluetooth, zaka iya shigar da Sony Ericsson PC Suite don aik tare, canja wurin fayiloli, yi amfani da wayar azaman abin haɗi da karin amfanin sadarwar Bluetooth. Shigar da Sony Ericsson PC Suite daga CD da yazo tareda wayar ko saukar da shi a www.sonyericsson.com/support. Hakanan PC Suite ya kunshi taimako.

Canja wurin fayiloli ta amfani da kebul na USB

Haɗa wayarka zuwa kwamfuta, ta amfani da kebul na USB. Don canja wurin fayil yi amfani da **Cnj. wur.fayil** yanayi kuma kuma don aiki tareda da bayanai yi amfani da **Yanay. waya**.

Canja wurin fayil


Jawo kuma sauke fayiloli tsakanin katin kwaƙwalwar ajiya naka da kwamfuta a Microsoft Windows Explorer.

Yi amfani da Sony Disc2Phone (canja wurin kiɗa) ko Adobe™ Photoshop™ Album Starter Edition (cnj. wur. hoto/ma'aji). Ana samun waɗannan aikace-aikacen akan CD wanda yazo tareda wayar ko a www.sonyericsson.com/support, kuma za'a iya amfani da shi kawai tareda hanyar canja wuri.

 Yi amfani da kebul na USB wanda yazo tare da wayar kawai, kuma haɗa kebul USB din kai tsaye zuwa kwamfutarka. Kada ka cire kebul na USB din daga wayar ko kwamfutar yayin canja wuri saboda wannan zai yuwu ya bata katin kwakwalwar ajiyar.

Don amfani da yanayin canja wuri

- 1 Haɗa kebul na USB zuwa wayar da kwamfutar.



- 2 **Waya:** Zabi Cnj. wur.fayil ko daga jiran aiki zabi **Menu** ► **Saituna** ► **Haɗuwa shafin** ► **USB** ► **Haɗin USB** ► **Cnj. wur. fayil**.
- 3 Dakata harsai katin kwakwalwar ajiya naka ya bayyana azaman disk na waje a Windows Explorer. Zaka iya amfani da:
 - Windows Explorer don jawo da sauke fayiloli tsakanin katin kwakwalwar ajiya naka da kwamfuta.
 - Sony Disc2Phone don canja wurin kiɗa zuwa katin kwakwalwar ajiya naka.
 - Adobe™ Photoshop™ Album Starter Edition, don canja wuri da daidaita hotunanka kan kwamfutarka.

Don cire haɗin kebul na USB a amince

- 1 Lokacin amfani da yanayin canja wurin fayil, yi kaɗi-dama a gumkin disk a Windows Explorer kuma zabi **Fitar**.
- 2 Cire kebul na USB daga wayarka.

Yanayin waya

Haɗa aiki tare da lambobi da kalanda, canja wurin fiyiloli, yi amfani da wayar azaman abin haɗi da kari daga kwamfutarka. Aikace-aikace da suka bada goyan baya a yanayin waya sun haɗa da: Aiki tare, Mai sarrafa fayil da mayen cibiyar sadarwa na wayar hannu. Don wasu aikace-aikacen, yi amfani da yanayin canja wurin fayil.

Kana bukar shigarwa da amfani da Sony Ericsson PC Suite, wanda yake haɗe da CD wanda yazo tareda wayar ko aka samo a www.sonyericsson.com/support.



Kwamfutarka tana bukatar daya daga cikin tsarukan aiki masu biyowa don ta sami damar amfani da wannan fsalin: Windows 2000 tareda SP3/SP4, Windows XP (Pro da Home) tareda SP1/SP2. An shigar da masu tuka USB ta atomatik tareda PC Suite software.

Don amfani da yanayin waya

- 1 **Kwamfuta:** Shigar da Sony Ericsson PC Suite daga CD wanda yazo tareda wayarka.
- 2 **Kwamfuta:** Fara PC Suite daga *Start/Programs/Sony Ericsson/PC Suite*.

- 3 Haɗa kebul na USB zuwa wayar da kwamfutar.
- 4 **Waya:** Zaɓi **Yanay. waya** ko daga jiran aiki zaɓi **Menu ▶ Saituna ▶ Haɗuwa shafin ▶ USB ▶ Haɗin USB ▶ Yanay. waya**.
- 5 **Kwamfuta:** Dakata yayin da Windows yake shigar da mutukan da aka bukata.
- 6 **Kwamfuta:** Lokacin da PC Suite ya nemo wayarka ana sanar dakai. Duk aikace-aikacen da zaka iya amfani dasu tareda haɗaɗɗiyar wayarka ana samun su acikin Sony Ericsson PC Suite.

Daukaka sabis

Koyaushe bar wayarka a daukake tareda sabuwar software don inganta aiki. Baza kayi asarar bayanin sirri ko na yawa ba, misali sakonni ko saituna yayin daukakawa.

Akwai hanyoyi biyu don daukaka wayarka:

- Bisa iska ta amfani da wayarka.
- Ta amfani da kebul na USB da aka bayar da kwamfuta mai haɗin Intanet.



Sabis na ɗaukakawa yana bukatar samun damar bayanai (GPRS). Afaretanka zai baka bayanin biyan kuɗi tareda samun damar bayanai da bayanin farashi.

Kafin ka fara

Idan saitunan da ake bukata ba su a wayarka ► *Saituna 67.*

Don amfani da ɗaukaka sabis bisa iska

- 1 Daga jiran aiki zabi **Menu ► Saituna ► Gaba ɗaya** shafin ► **Sabis na ɗaukaka.**
- 2 ► **Binciken ɗaukaka** don bincika samammiyar sabuwar software.
- 3 Fara sarrafa ɗaukakawar ta bin umamin shigarwa, ko ► **Sigar software** don nuna software ɗin yau-yau a wayarka, ko ► **Mai tuni** don saita lokacin bincika sabuwar software.

Don amfani da ɗaukaka sabis ta amfani da kwamfuta

- 1 Jeka zuwa www.sonyericsson.com/support.
- 2 Zabi yanki da kasa.
- 3 Shigar da sunan samfur ɗin.
- 4 Zabi sabis na ɗaukakawa na Sony Ericsson kuma bi umurni.

karin fasali

Agogon kararrawa, kalanda, ɗawainiya, bayanan martaba, lokaci da kwanan wata, kulle katin SIM da kari.

Kararrawa

Saita Kararrawa don takamaiman lokaci ko takamammun ranaku don sake aukuwa.

Don amfani da kararrawa

- 1 Daga jiran aiki zabi **Menu ► Oganeza ► Kararrawa** kuma zabi kararrawa don saitawa ► **Shirya.**
- 2 **Lokacin:** ► **Shirya** kuma saita lokaci ► **Ok.** Zabi karin zaɓuɓɓuka, idan an bukata:
 - **Mai dawowa:** ► **Shirya** kuma saita rana ko ranaku ► **Alama ► Anyi.**
 - **Sgnl. na kararra.:** ► **Shirya** kuma saita sauti.
 - Latsa  don shirya rubutu, hotuna da yanayin shiru don kararrawa.
- 3 ► **Ajiye.**

Don kashe sigina na kararrawa lokacin da yake sauti

- Latsa kowane maɓalli. Idan baka son maimaita kararrawar ► **Kashe.**

Don soke kararawa

- Daga jiran aiki zaɓi **Menu** ▶ **Oganeza**
▶ **Kararawa** kuma zaɓi kararawa,
▶ **Kashe**.

Kalanda

Zaka iya amfani da kalanda don adana bibiyar mahimmin taro. Za'a iya haɗa kalanda aiki tareda kalandar kwamfuta ko tareda kalandar kan yanar sadarwa
➡ *Aiki tare 72.*

Alkawura

Kara sabbin alkawura ko yi amfani da alkawura masu kasancewa azaman samfura.

Don kara sabon alkawari

- 1 Daga jiran aiki zaɓi **Menu** ▶ **Oganeza**
▶ **Kalanda** kuma saita kwanan wata
▶ **Zaɓi** ▶ **Sabuwar alkawari** ▶ **Kara**.
- 2 Zaɓi daga zaɓuɓɓuka masu biyowa kuma tabbatar da kowace shigarwa, in an bukata:
 - **Gaba ɗaya** shafi - take, fara lokaci, tsawon lokaci, mai tuni, fara kwanan wata.
 - **Bayanai** shafi - wurin, sifantawa, duk rana, sake aukuwa.
- 3 ▶ **Ajiye**.

Don duba alkawari

- 1 Daga jiran aiki zaɓi **Menu** ▶ **Oganeza**
▶ **Kalanda** kuma zaɓi rana (an yiwa ranakun alkawari kakkaurar alama).
- 2 Zaɓi alkawari ▶ **Duba**.

Don duba satin kalanda

- Daga jiran aiki zaɓi **Menu** ▶ **Oganeza**
▶ **Kalanda** ▶ **Kari** ▶ **Duba sati**.

Don saita lokacin da masu tuni zasu yi sauti

- 1 Daga jiran aiki zaɓi **Menu** ▶ **Oganeza**
▶ **Kalanda** ▶ **Kari** ▶ **Na ci gaba** ▶ **Masu tuni**.
- 2 ▶ **Koyaushe** don mai tuni yayi sauti ko da lokacin da aka kashe wayar ko saita ta a shiru. Lokacin da mai tunan yake sauti ▶ **Ee** don karanta alkawarin ko ▶ **A'a** don kashe mai tunin. An saita zaɓin mai tuni a rinjayen kalanda an saita zaɓin mai tuni a dawainiya.

Kewayawa a cikin kalandarka

Latsa , ,  kuma  don matsawa tsakanin ranaku ko makonni. A cikin dube-duben watan da makonnin, zaka iya kuma amfani da faifan maballin kamar mai biyowa.

⑥ *Kwanan watan yau*

① *Mako ɗaya baya* ③ *Mako na gaba*

④ *Wata ɗaya baya* ⑤ *Wata na gaba*

⑦ *Shekara ɗaya baya* ⑧ *Shekara ta gaba*

Saitunan kalanda

Daga jiran aiki zaɓi **Menu ▶ Oganeza ▶ Kalanda ▶ Kari** don zaɓin wani zaɓi:

- **Duba sati** – duna alkawurnn sati.
- **Sabuwar alkawari** – kara sabon alkawari.
- **Canja kwan. wata** – jeka zuwa wani kwanan wata a kalandar.
- **Na ci gaba** – nemo alkawari, saita masu tuni ko zaɓi ranar farawa a makon.
- **Share** – share tsoho ko duk alkawurnn.
- **Taimako** – don karin bayani.

Musayar alkawurra

Musaya alkawurra ta amfani da hanyar canja wuri. Zaka iya haɗa alkawura aiki tare da kwamfuta ➡ *Aiki tare 72.*

Don aika alkawari

- Zaɓi alkawari a lissafi don takamaimiyar rana ▶ **Kari ▶ Aika** kuma zaɓi hanyar canja wuri.

Dawainiya

Kara sabbin alkawurra ko yi amfani da dawainiya masu kasancewa azaman samfura. Zaka kuma iya saita masu tuni saboda dawainiya.



Mafi girman lambobin dawainiya ya danganta da sararin kwakwalwar ajiya kamar yadda aka saita a software.

Don kara sabuwar dawainiya

- 1 Daga jiran aiki zaɓi **Menu ▶ Oganeza ▶ Dawainiya ▶ Sabu. dawainiya ▶ Kara.**
- 2 ▶ **Dawainiya** ko **Kiran waya.**
- 3 shigar da bayanai kuma tabbatar da kowacce shigarwa.

Don duba dawainiya

- Daga jiran aiki zaɓi **Menu ▶ Oganeza ▶ Dawainiya** kuma zaɓi dawainiya ▶ **Duba.**

Don saita lokacin da masu tuni zasu yi sauti

- 1 Daga jiran aiki zaɓi **Menu ▶ Oganeza ▶ Dawainiya** kuma zaɓi dawainiya ▶ **Kari ▶ Masu tuni**.
- 2 ▶ **Koyaushe** don mai tuni yayi sauti ko da lokacin da aka kashe wayar ko saita ta a shiru. Lokacin da mai tuni yake sauti ▶ **Ee** don karanta dawainiyar, ko don kiran lambar wayar a dawainiyar waya. ▶ **A'a** don kashe mai tuni. Zaɓin mai tuni wanda aka saita a dawainiya yana rinjayar zaɓin mai tuni wanda aka saita a kalanda.

Musanya dawainiya

Musanya dawainiya ta amfani da hanyar canja wuri. Zaka iya aiki tare da dawainiya da kwamfuta ➡ **Aiki tare 72**.

Don aika dawainiya

- Zaɓi dawainiya a lissafin dawainiyar don takamamiyar rana ▶ **Kari ▶ Aika** kuma zaɓi hanyar canja wuri.

Bayanan kula

Yi bayanan kula kuma ka ajiye su a lissafi. Hakanan zaka iya nuna bayanin kula acikin jiran aiki.



Mafi girman lambobin bayanan kula ya danganta da sararin kwakwalwar ajiya, kamar yadda aka saita a software.

Don kara bayanin kula

- Daga jiran aiki zaɓi **Menu ▶ Oganeza ▶ Bayanan kula ▶ Sab. bayanin kula ▶ Kara** kuma shigar da bayanin kular ▶ **Ajiye**.

Don shirya bayanan kula

- 1 Daga jiran aiki zaɓi **Menu ▶ Oganeza ▶ Bayanan kula** kuma lissafi yana bayyana.
- 2 Zaɓi bayanin kula ▶ **Kari** kuma zaɓi wani zaɓi.

Musayar bayanan kula

Musanya bayanan kula ta mai amfani da dayan wadatattun hanyoyin canja wuri. Hakanan zaka iya aiki tare da bayanan kula tare da kwamfuta ➡ **Aiki tare 72**.

Don aika bayanin kula

- Zaɓi bayanin kula ▶ **Kari ▶ Aika** kuma zaɓi hanyar canja wuri.

Mai kidaya lokaci

Wayarka tana da mai kidayar lokaci. Lokacin da sigina yayi sauti, latsa kowane maɓalli don kashe ta ko zaɓi Fara.

Don saita mai kidaya lokacin

- ▶ **Oganeza** ▶ **Mai kidyr. lokaci** kuma saita awoyi, mintuna da sakan don kidaya.

Agog. aw. gudu

Wayarka tanada agogon awon gudu wanda zai iya ajiye juyi dayawa. Agogon awon gudu zai cigaba da gudana lokacin da kake amsa kira mai shigowa.

Don amfani da agogon awon gudu

- 1 Daga jiran aiki zaɓi **Menu** ▶ **Oganeza** ▶ **Aggn.awn. gudu** ▶ **Fara**.
- 2 ▶ **Tsaida ko** ▶ **Sabw. juyi** don sabon lokacin juyi.
- 3 Don sake saita agogon awon gudun ▶ **Tsaida** ▶ **Sake saiti**.

Kalkaleta

Kalkuleta zai iya kara, debewa, rabawa da ruɓanyawa.

Don amfani da kalkaleta

- Daga jiran aiki zaɓi **Menu** ▶ **Oganeza** ▶ **Kalkaleta**.
 - Latsa  ko  don zaɓi + x - + . % = .
 - Latsa  don share harafi.
 - Press   don shigar da digon goma.

Memo na lamba

Aje lambobin tsaro, kamar azaman katin lamuni, acikin lambar memo. Saita lambar wucewa don buɗe lambar memo.

Duba kalma da tsaro

Don tabbatar da cewa lallai ka shigar da lambar wucewa daidai dole ka shigar da kalmar bincike.

Lokacin da ka shigar da lambar wucewarka don buɗe lambar memo, ana nuna duba kalmar atakaice. Idan lambar wucewa tayi daidai, ana nuna lambobin da suke daidai. Idan ka shigar da lambar wucewa ba daidai ba, duba kalma da lambobin da aka nuna suma ba daidai bane.

Don buƙe memo na lamba da farko

- 1 Daga jiran aiki zaɓi **Menu** ► **Oganeza** ► **Memo na lamba**. Sako tare da umarni yana bayyana ► **Ci gaba**.
- 2 Shigar da lambar wucewa guda-huɗu ► **Ci gaba**.
- 3 Sake shigar da sabuwar lambar wucewa don tabbatarwa.
- 4 Shigar da duba kalma (mafi yawa haruffa 15) ► **Anyi**. Duba kalmar zai iya kunsar duka biyu haruffa da lambobi.

Don kara sabuwar lamba

- 1 Daga jiran aiki zaɓi **Menu** ► **Oganeza** ► **Memo na lamba** kuma shigar da lambar wucewa ► **Sabuwar lamba** ► **Kara**.
- 2 Shigar da sunan dake haɗe da lambar ► **Ci gaba**.
- 3 Shigar da lambar ► **Anyi**.

Don canja lambar wucewa

- 1 Daga jiran aiki zaɓi **Menu** ► **Oganeza** ► **Memo na lamba** kuma shigar da lambar wucewa ► **Kari** ► **Canj.lamb. wcew**.
- 2 Shigar da sabuwar lambar wucewarka ► **Ci gaba**.
- 3 Sake shigar da sabuwar lambar wucewar ► **Ci gaba**.
- 4 Shigar da bincika kalma ► **Anyi**.

Manta lambar wucewarka?

Idan kamanta lambar wucewar ka, dole ne ka sake saita memo na lamba.

Don sake saita memo na lamba

- 1 Daga jiran aiki zaɓi **Menu** ► **Oganeza** ► **Memo na lamba** kuma shigar da kowace lambar wucewa don samun damar memo na lamba. Duba kalma da lambobi waɗanda alokacin da aka nuna su ba daiadai bane.
- 2 ► **Kari** ► **Sake saiti**.
- 3 **Sake saitin memo na lamba?** yana bayyana ► **Ee**. An sake saita memo na lamba kuma an share du waɗanda aka shigar. Lokaci na gaba da ka shigar da lambar memo, dole kafara a ► **Don buƙe memo na lamba da farko 84**.

Bayanan martaba

Wayarka tanada tsararrun bayanan martaba waɗanda aka saita. Wasu, misali, karan ringi da wasu zaɓuɓɓuka mai yiwuwa a daidaitasu ta atomatik don su dace da takamammen halin wuri ko na'urar haɗi Zaka iya sake saita duk saitunan bayanan martaba zuwa yadda aka saita su lokacin da ka sayi wayarka.

Don zaɓar bayanin martaba

- Latsa ① kuma zaɓi bayanin martaba, ko daga zaɓin jiran aiki **Menu ▶ Saituna ▶ Gaba ɗaya shafin ▶ Bayanan martaba** kuma zaɓi bayanin martaba.

Don duba da shirya bayanin martaba

- Daga jiran aiki zaɓi **Menu ▶ Saituna ▶ Gaba ɗaya shafin ▶ Bayanan martaba ▶ Kari ▶ Duba ka ashirya.**



Ba zaka iya sake sunan bayanin martaba na al'ada ba.

Don sake saita bayanan martaba

- Daga jiran aiki zaɓi **Menu ▶ Saituna ▶ Gaba ɗaya shafin ▶ Bayanan martaba ▶ Kari ▶ Sk. st.bay. mart.**

Lokc.da kwn.wata

Lokacin yana bayyana koda yausha a jiran aiki.

Don saita lokaci da tsarin lokaci

- 1 Daga jiran aiki zaɓi **Menu ▶ Saituna ▶ Gaba ɗaya shafin ▶ Lokc. & kwn.wt. ▶ Lokaci.**
- 2 Shigar da lokacin.
- 3 ▶ **Tsari** kuma zaɓi wani zaɓi.
- 4 ▶ **Ajiye.**

Don saita kwanan wata da tsarin kwanan wata

- Daga jiran aiki zaɓi **Menu ▶ Saituna ▶ Gaba ɗaya shafin ▶ Lokc. & kwn.wt. ▶ Kwanan wata.**

Kulle katin SIM

Kulle katin SIM yana kare biyan kuɗinka, amma ba wayar kanta ba, daga amfani mara izini. Idan ka canza katinan SIM, wayarka har yanzu zata yi aiki da sabon katin SIM.

Mafi yawan katinan SIM suna kulle a lokacin saye. Idan kulle katin SIM yana kunne, dole ka shigar da PIN (Personal Identity Number) duk lokacin da ka kunna wayarka.

Idan ka shigar da PIN naka kuskure sau uku ajere, za'a katange katin SIM. An nuna wannan ta sakon **An katange PIN**. Don buɗe ta, kana bukatar shigar da PUK naka (Personal Unblocking Key). PIN naka da PUK ana bada su ta afaretan cibiyar sadarwa. Zaka iya shirya PIN naka kuma zaɓi lambar PIN huɗu zuwa takwas.



Idan sakon Lambobi basu jitu ba yana bayyana lokacin da ka shirya PIN naka, ka shigar da sabon PIN kuskure. Idan sakon PIN mara daidai yana bayyana, wanda aka bishi da Tsohuwar PIN, ka shigar da tsohon PIN naka ba daidai ba.

Don cire katangar katin SIM naka

- 1 Lokacin da **An katange PIN** yana bayyana, shigar da PUK naka ► **Ok**.
- 2 Shigar da sabuwar lambar PIN huɗu zuwa takwas ► **Ok**.
- 3 Sake shigar da sabon PIN don tabbatarwa ► **Ok**.

Don shirya PIN naka

- 1 Daga jiran aiki zaɓi **Menu** ► **Saituna** ► **Gaba ɗaya shafin** ► **Tsaro** ► **Mukullai** ► **Kariyar SIM** ► **Canja PIN**.
- 2 Shigar da PIN naka ► **Ok**.
- 3 Shigar da sabuwar lambar PIN huɗu zuwa takwas ► **Ok**.
- 4 Sake shigar da sabon PIN don tabbatarwa ► **Ok**.

Don kunna kulle katin SIM ko kashewa

- 1 Daga jiran aiki zaɓi **Menu** ► **Saituna** ► **Gaba ɗaya shafin** ► **Tsaro** ► **Mukullai** ► **Kariyar SIM** ► **Kariya kuma zaɓi Kunnawa ko A kashе**.
- 2 Shigar da PIN naka ► **Ok**.

Kulle waya

Kare wayarka daga amfani mara izini idan aka sace kuma aka sauya katin SIM ɗin. Zaka iya canja lambar kulle wayar (0000) zuwa lambobi na sirri huɗu zuwa takwas.

Kulle waya ta atomatik

Idan an saita kulle waya ta atomatik, baka bukatar shigar da lambar kulle waya naka harsai an saka katin SIM daban acikin waya.



Yana da mahimmanci ka tuna sabuwar lambarka. Idan ka manta ta, dole ne ka ɗauki wayarka zuwa wakilin Sony Ericsson na gida.

Don saita kulle wayar

- 1 Daga jiran aiki zaɓi **Menu** ► **Saituna** ► **Gaba ɗaya shafin** ► **Tsaro** ► **Mukullai** ► **Kariyar waya** ► **Kariya kuma zaɓi wani zaɓi**.
- 2 Shigar da lambar kulle wayar ► **Ok**.

Don buɗe waya

- Idan makullin wayar na kunne, shigar da lambarka ► **Ok**.

Don shirya lambar kulle wayarka

- Daga jiran aiki zaɓi **Menu** ► **Saituna** ► **Gaba ɗaya shafin** ► **Tsaro** ► **Mukullai** ► **Kariyar waya** ► **Canja lamba**.

Kulle faifan maballi

Kulle faifain maballi don nisanta buga lamba na bazata.

 za'a iya yin kira zuwa lambobin gaggawa na kasashen waje 112, koda lokacin da faifain maballi ke kulle.

Kulle maballi ta atomatik

Yi amfani da maballin kullewa ta atomatik a cikin jiran aiki don kulle faifan maballi jim kaɗan bayan maballi na karshe da aka latsa.

Don saita maballin kullewa ta atomatik

- Daga jiran aiki zaɓi **Menu** ▶ **Saituna** ▶ **Gaba ɗaya** shafin ▶ **Tsaro** ▶ **Kull. mɓil.ta atmat.**

Don kulle faifan maballi da hannu

- Daga jiran aiki, latsa  ▶ **Mk.mɓil.** Za ka iya amsa kira mai shiga kuma faifan maballi na kulle bayan kira. Faifan maballin zai zauna akulle har sai lokacin da ka buɗe da hannu.

Don buɗe faifan maballi da hannu

- Daga jiran aiki, latsa  ▶ **Buɗe.**

Fara allon fuska



Zaɓi fara allon don bayyana lokacin da ka kunna wayarka ➡ **Amfani da hotuna 54.**

Don zaɓar fara allo

- Daga jiran aiki zaɓi **Menu** ▶ **Saituna** ▶ **Nuni shafin** ▶ **Allon farawa** kuma zaɓi wani zaɓi.

Haske

Daidaita haske a allon.

Don saita haske

- Daga jiran aiki zaɓi **Menu** ▶ **Saituna** ▶ **Nuni shafin** ▶ **Haske.**

Shirya matsala

Me yasa wayar bata aiki yanda nakeso tayi?

Wannan babin yana lissafa wasu matsaloli waɗanda zaka iya fuskanta lokacin amfani da wayarka. Waɗansu matsaloli suna buƙatar ka kira afaretan cibiyar sadarwarka, amma zaka iya gyara mafi yawan matsalolin da kanka a saukake.

Koyaya, in kana buƙatar ɗaukar wayarka zuwa gyara, kula da cewa maiyuwa ka rasa bayani da abun ciki wanda ka ajiye a wayarka. An baka shawara ka yi kwafin wannan bayanin kafin kai wayarka gyara.

Don karin goyan baya je zuwa www.sonyericsson.com/support.

Inada matsala tareda faɗin kwakwalwar ajiya ko wayar tana aiki a hankali

Dalili mai yiwuwa: Kwakwalwar ajiyar wayar tacika ko ba'a tsara abubuwan cikin kwakwalwar ajiyar yadda yakamata ba.

Magani: Sake kunna wayarka kullum don sanya kwakwalwar ajiya fanko da kuma kara faɗin wayarka.

Kuma kanada zabin yin **Sake saitin ainihi**. Za'a rasa wasu bayani na sirri da saituna waɗanda kayi lokacin da kayi wannan ➡ *Sake saitin ainihi 91*.

Babu gunkin baturi daya bayyana lokacin da nafara cajin wayar

Dalili mai yiwuwa: Baturin fanko ne ko ba'a yi aiki da shi ba na lokaci mai tsawo.

Magani: Zai iya ɗaukar kamar minti 30 kafin gunkin baturin ya bayyana a allon.

Wasu zabubbukan menu suna bayyana cikin ruwan toka

Dalili mai yiwuwa: Ba'a kunna sabis ba ko biyan kudinka baya goyan bayan aikin.

Magani: Tuntubi afaretan cibiyar sadarwarka.

Dalili mai yiwuwa: Tunda ba zaka iya aika jigogi ba, hotuna da sautuna waɗanda aka kare ta hakkin mallaka **Aika** babu menu wasu lokuta.

Bana fahimtar yaren menu

Dalili mai yiwuwa: An saita yaren kuskure a wayar.

Magani: Canja yaren ➡ *Yaren waya 17*.

Bazan iya kunna wayar ba.

Dalili mai yiwuwa: An cire cajin baturin

Magani: Yi cajin baturin ➡ *Don cajin baturi 6.*

Magani: Kunna wayar tareda caji a haɗe. Idan wayar tafara, sake kunna wayar batareda caji a haɗe ba.

Bazan iya cajin wayar ba ko damar baturi tayi kasa

Dalili mai yiwuwa: Cajar bata haɗu da wayar kamar yadda yakamata ba.

Magani: Tabbatar da cewa mai haɗa caji yana kaɗawa yadda yakamata cikin wuri lokacin da aka haɗa shi ➡ *Don cajin baturi 6.*

Dalili mai yiwuwa: Haɗin baturi baida kyau.

Magani: Cire baturi kuma tsaftace masu haɗawa. Zaka iya amfani da ɗaya daga cikin masu boyowa waɗanda aka tsomasu a tsanake cikin alkwal; brushi mai taushi, kyalle ko hankici. Tabbatar baturin ya bushe tsaf kafin ka maida shi. Bincika cewa masu haɗin baturi a wayar basu lalace ba.

Dalili mai yiwuwa: Baturin ya lalace yana bukatan canji.

Magani: Gwada wani baturi da caji na irin samfur ɗin, ko ziyarci wakilanka kuma tanbaye su don ka tabbatar idan baturin da cajar suna aiki yadda yakamata.

Wayar tana kashe kanta

Dalili mai yiwuwa: ① an tura maɓallin bada niyya ba.

Magani: Kunna kulle maɓalli ta atomatik, ko kulle faifan maɓalli da hannu ➡ *Kulle faifan maɓalli 87.*

Dalili mai yiwuwa: Haɗin baturi baida kyau.

Magani: Tabbatar an shigar da baturin daidai ➡ *Don saka baturin 6.*

Bana iya amfani da sakonnin rubutun/ SMS a wayata

Dalili mai yiwuwa: Saituna suna bacewa ko kuskure.

Magani: Tuntubi mai sa aiki na cibiyar sadarwa naka don gano saitin wurin sabis na SMS daidai ➡ *Sakon rubutun (SMS) 38.*

Bana iya amfani da sakon hoto na MMS a wayata

Dalili mai yiwuwa: Biyan kuɗinka bai kunshi damar bayanai ba.

Magani: Tuntuƙi afaretan cibiyar sadarwa naka.

Dalili mai yiwuwa: Saituna suna bacewa ko buskure.

Magani: ➡ *Taimako a wayarka 7* ko jeka zuwa www.sonyericsson.com/support, Zabi yankinka da kasarka, kuma zabi saitin waya. Sannan zabi samfurin wayarka, kada bisa Karanta kari karkasin Sakon hoto (MMS) kuma bi ummurni ➡ *Saituna 67*.

Bana iya amfani da Intanit

Dalili mai yiwuwa: Biyan kuɗinka bai kunshi damar bayanai ba.

Magani: Tuntuƙi afaretan cibiyar sadarwa naka.

Dalili mai yiwuwa: Saituna suna bacewa ko kuskure.

Magani: ➡ *Taimako a wayarka 7* ko jeka zuwa www.sonyericsson.com/support, Zabi yankinka da kasarka, kuma zabi saitin waya. Sannan zabi samfurin wayarka, kada bisa Karanta kari karkashin Intanit na wayar ahnnu (WAP) kuma bi ummurni ➡ *Saituna 67*.

Wasu masu amfani ba zasu iya gano wayar ba ta amfani da fasaha mara waya ta Bluetooth™

Dalili mai yiwuwa: Baka kunna aikin Bluetooth ba.

Magani: Tabbata cewa aikin Bluetooth yana kunne kuma an saita gani don nuna waya ➡ *Don karban abu 75*.

Bana iya aiki tare ko canja wurin bayanai tsakanin wayata da kwamfuta ta, lokacin amfani da kebul na USB da aka bayar

Dalili mai yiwuwa: Ba'a sanya kebul ɗin yadda yakamata kuma ba'a gano shi ba a kwamfutarka ba, ko ba'a sanya software wanda yazo tareda wayarka a kwamfutar yadda yakamata ba.

Magani: Jeka www.sonyericsson.com/support, zabi yankinka da kasarka, kuma zabi samfurin wayarka. Sannan zabi Koyi kari - An fara. Jagoran *dake aiki tareda kwamfuta* ya kunshi umarnin shigarwa da jagorar shirya matsala, wanda zai yiwu ya taimake ka acikin warware matsalar.

Sake saitin ainihi

Za'a share canje canje da kayi zuwa saituna da abun ciki wanda ka kara ko ka shirya.

Idan ka zaɓi **Sake saitin saitina**, za'a share canje-canjen da kayi zuwa saituna.

Idan ka zaɓi **Sake satin duk**, kari ga canje-canjen saitunanka za'a kuma a share duk lambobi, sakonni, bayanan sirri, da abun ciki wanda ka saukar, wanda ka karɓa ko ka shirya.

Don sake saita wayar

- 1 Daga jiran aiki zaɓi **Menu** ► **Saituna** ► **Gaba daya** shafin ► **Sake saitin ainihi**.
- 2 ► **Sake saitin saitina** ko ► **Sake satin duk**.
- 3 Lokacin da umarni ya bayyana ► **Ci gaba**.



*Idan ka zaɓin **Sake satin duk**, za'a kuma share abun ciki kamar launukan waka da hotuna waɗanda ka saukar, waɗanka karɓa ko ka shirya*

Kuskuren sakonni

Sa SIM

Dalili mai yiwuwa: Babu katin SIM a cikin wayar ko maiyuwa ka saka shi kuskure.

Magani: Shigar da katin SIM ► *Don saka katin SIM 6.*

Dalili mai yiwuwa: Masu haɗin katin SIM suna bukatar tsaftacewa.

Magani: Cire katin SIM kuma ka shigar daidai. Bincika kuma ko katin ya lalace da inda ba zaka iya haɗa shi zuwa masu haɗi na wayar ba. Tun da haka ne, tuntuɓi afaretan cibiyar sadarwarka don tambayar sabon katin SIM.

Sa katin SIM mai kyau

Dalili mai yiwuwa: An saita wayar don kawai aiki tareda takamaiman katinan SIM.

Magani: Bincika idan kana amafani da afaretan katin SIM mai kyau don wayarka.

PIN mara daidai/PIN2 mara daidai

Dalili mai yiwuwa: Ka shigar da PIN ko PIN2 naka kuskure.

Magani: Shigar da PIN ko PIN2 daidai
▶ **Ee** ➡ *Kulle katin SIM 85.*

An katange PIN/An katange PIN2

Dalili mai yiwuwa: Ka shigar da lambar PIN ko PIN2 naka kuskure sau uku a jere.

Magani: Don cire katanga ➡ *Kulle katin SIM 85.*

Lambobi basu jitu ba

Dalili mai yiwuwa: Lambobi biyu waƙanda ka shigar basu dace ba.

Magani: Lokacin da kake son canja lambar tsaro, (misali, PIN naka) Dolene ka tabbatar da sabuwar lambar ta sake shigar da wanna lambar daidai wadaida. ➡ *Kulle katin SIM 85.*

Bab. kway.cb.sadr.

Dalili mai yiwuwa: Wayarka tana cikin yanayin kaura.

Magani: Sake kunna wayar a yanayi naal'ada ➡ *Menu na yanayin kaura 8.*

Dalili mai yiwuwa: Wayarka bata karɓar sigina na rediyo, ko sigina da aka karɓa yana da rauni kwarai.

Magani: Tuntubi afaretan cibiyar sadarwarka kuma a tabbata cewa cibiyar sadarwa yana kewaye in da kake. Don bincika cibiyar sadarwa,
▶ **Saituna** ▶ **Haɗuwa sahfin** ▶ **Cibiyar sadrw.waya** ▶ **Sabuwar bincike.**

Dalili mai yiwuwa: Katin baya aiki yadda yakamata.

Magani: Sa katin SIM naka cikin wata wayar. Idan har yanzu kana samun sako iri ɗaya ko makamanci, tuntubi afaretan cibiyar sadarwa.

Dalili mai yiwuwa: Waya bata aiki yadda yakamata.

Magani: Sa katin SIM naka cikin wata wayar. Idan wannan yana aiki, da alama wayace ke haifar da matsala. Tuntubi wurin sabis na Sony Ericsson mafi kusa.

Kiran gaggw. kawai

Dalili mai yiwuwa: Kana tsakanin yankin cibiyar yanar sadarwa, amma ba ka da damar amfani da ita. Koyaya, a gaggawa, wadansu masu sa aikin cibiyar sadarwa suna baka damar kiran lambar gaggawa ta kasashen waje 112.

Magani: Dole ka matsa don samun sigina wanda ke da isasshen karfi. Tuntuɓi afaretan cibiyar yanar sadarwarka kuma tabbatar cewa kana da damar biyan kuɗi ➡ *kiran gaggawa 23.*

Kulle waya

Dalili mai yiwuwa: An kulle wayar.
Magani: Don buɗe wayar ➡ *Kulle waya 86.*

Lmb. kle. waya:

Dalili mai yiwuwa: Ana bukatar lambar kulle wayar.

Magani: Shigar da lambar kulle waya. Wayarka tana da tshohuwar lambar makullin waya 0000 ➡ *Kulle waya 86.*

An cire katanga PUK. Tuntuɓi mai sa aiki.

Dalili mai yiwuwa: Ka shigar da lambar maballin budewarka na sirri (PUK) kuskure sau goma a jere.

Magani: Tuntuɓi afaretan cibiyar sadarwarka.

Yin caji, bakon baturi

Dalili mai yiwuwa: Baturin da kake amfani dashi ba amintaccen baturin Sony Ericsson bane.

Magani: ➡ *Baturi 97.*

Muhimmin bayani

Gidan yanar sadarwar mai amfani na Sony Ericsson, sabis da goyan baya, aminci da ingantaccen amfani, kare yarjejeniyar lalasisin mai amfani, garanti, bayanin tabbatarwa.

Mal amfani da gidan yanar sadarwa na Sony Ericsson

A www.sonyericsson.com/support yankin goyon baya ne inda taimako da tukwici suke a kadawa kaƙan waje kawai. Anan zaka sami ɗaukaka software na sabuwar kwamfuta da tikwici na yadda za kayi amfani da samfur naka da inganci sosai.

Sabis da goyan baya

Daga yanzu zaka sami damar zuwa fa'idojin jakar kebentaccen sabis kamar:

- Dakunan yanar sadarwa na duniya dana gida na gabatar da goyan baya.

Kasa

Ostiraliya
Ajantina
Austiriyar
Baljiyam
Burazil
Kanada
Afirika ta cakiya
Cili
Cana

Lambar waya

1-300 650 050
800-333-7427
0810 200245
02-7451611
4001-0444
1-866-766-9374
+27 112589023
123-0020-0656
4008100000

- Cibiyar sadarwa ta duniya ta wuraren kira
- Babbar cibiyar sadarwar abokan sabis na Sony Ericsson
- Lokacin garanti. Kara koyo gameda sharuɗɗan garanti a wannan jagorar mai amfanin Akan www.sonyericsson.com, karkashin bangaren goyan baya a yaren zabin ka, zaka sami sababbin kayan aiki masu bada goyan baya da bayani, kamar ɗaukaka software, cibiyar ilimi, Saita waya da karin taimako lokacin da ka bukata shi.

Don takamaiman afaretan sabis da fasali, tuntuɓi afaretan cibiyar sadarwarka don karin bayani.

Zaka kuma iya tuntuɓan Wuraren Kira. Yi amfani da lambar waya don wurin kira mafi kusa acikin lissafi mai zuwa. Idan kasar ka/yanki bai fito acikin lissafi ba, ka tuntuɓi dila na yankinka. (Lambobin wayar na kasa sunyi dai-dai a lokacin fitar da su. Zaka iya samun sababbin ɗaukaka koyausha akan www.sonyericsson.com).

Acikin abin aukuwa wanda ba'a soba cewa samfur naka yana buƙatar sabis, tuntuɓi dilan da aka saya daga wurinsa, ko ɗaya daga abokan sabis namu. Ajiye shaidar sayanka, zaka buƙaceta idan kana buƙatar garanti.

Za'a cajeka a kira zuwa ɗaya daga Wuraren Kiran mu gwargwadon kimar kuɗin kasa, haɗi da harajin gida, sai dai idan lambar wayar lambar kyauta ce.

Adreshin email

questions.AU@support.sonyericsson.com
questions.AR@support.sonyericsson.com
questions.AT@support.sonyericsson.com
questions.BE@support.sonyericsson.com
questions.BR@support.sonyericsson.com
questions.CA@support.sonyericsson.com
questions.CF@support.sonyericsson.com
questions.CL@support.sonyericsson.com
questions.CN@support.sonyericsson.com

Kwalambiya	18009122135	questions.CO@support.sonyericsson.com
Kurwatiya	062 000 000	questions.HR@support.sonyericsson.com
Jumhuriyar ciz	844 550 055	questions.CZ@support.sonyericsson.com
Denmak	33 31 28 28	questions.DK@support.sonyericsson.com
Finlanda	09-299 2000	questions.FI@support.sonyericsson.com
Faransa	0 825 383 383	questions.FR@support.sonyericsson.com
Jamus	0180 534 2020	questions.DE@support.sonyericsson.com
Giris	801-11-810-810	questions.GR@support.sonyericsson.com
	210-89 91 919 (daga wayar hannu)	
Hon Kon	8203 8863	questions.HK@support.sonyericsson.com
Hongeriya	+36 1 880 47 47	questions.HU@support.sonyericsson.com
Indiya	1800 11 1800 (lambar kyauta)	questions.IN@support.sonyericsson.com
	39011111 (daga wayar hannu)	
Indonesiya	021-2701388	questions.ID@support.sonyericsson.com
Irlanda	1850 545 888	questions.IE@support.sonyericsson.com
Italiya	06 48895206	questions.IT@support.sonyericsson.com
Litaniya	8 700 55030	questions.LT@support.sonyericsson.com
Malesiya	1-800-889900	questions.MY@support.sonyericsson.com
Meziko	01 800 000 4722	questions.MX@support.sonyericsson.com
Nezalan	0900 899 8318	questions.NL@support.sonyericsson.com
New Zilanda	0800-100150	questions.NZ@support.sonyericsson.com
Nowey	815 00 840	questions.NO@support.sonyericsson.com
Fakistan	111 22 55 73	questions.pk@support.sonyericsson.com
	Wajen Karaci: (92-21) 111 22 55 73	
Filifiniya	+ 63 (02) 7891860	questions.PH@support.sonyericsson.com
Folan	0 (Fihirisa) 22 6916200	questions.PL@support.sonyericsson.com
Fotugal	808 204 466	questions.PT@support.sonyericsson.com
Romaniya	(+4021) 401 0401	questions.RO@support.sonyericsson.com
Rasha	8(495) 787 0986	questions.RU@support.sonyericsson.com
Singafora	67440733	questions.SG@support.sonyericsson.com
Sulbakiya	02-5443 6443	questions.SK@support.sonyericsson.com
Afirka ta kudu	0861 632222	questions.ZA@support.sonyericsson.com
Isfaniya	902 180 576	questions.ES@support.sonyericsson.com
Suwidin	013-24 45 00	questions.SE@support.sonyericsson.com
Suwizalad	0848 824 040	questions.CH@support.sonyericsson.com
Taiwan	02-25625511	questions.TW@support.sonyericsson.com

Tailand	02-2483030
Taki	0212 47 37 777
Ukraniya	(+380) 44 590 1515
Kasar imarat	43 919880
Burtaniya	08705 23 7237
Amurka	1-866-766-9374
Benzawela	0-800-100-2250

Jagororin don aminci da ingantaccen amfani

Karanta wannan bayanin kafin amfani da wayarka ta hannu.

An yi nufin waɗannan umarni don amincinka. Bi waɗannan jagororin. Idan samfur yazama dalili ga kowane yanayi da aka lissafa a kasa ko kana da kowane kokwanto ga ingancin aikinsa ka tabbatar da abokin sabis mai takardar sheda yaduba su kafin biya ko amfani dashi. Rashin yin haka zai iya haifar da hadari na lalata samfur koma cutar ga lafiyarka.



Yabo don amincin amfanin samfur (wayar hannu, batURI, caji da wasu na'urorin haɗi)

- Yi mu'amala da samfurin ka koyausha da kulawa kuma ajiye shi cikin wuri mai tsabta mara kura.
- **Gargadi!** Zai iya fashewa idan anyi kusa da wuta.
- Karka bijirar da samfurinka ga ruwa damshi laima.
- Karka bijirar da samfurinka ga babba ko karancin zafi. Kada ka bijirar da batURI zuwa yanayin zafi sama da +60°C (+140°F).
- Kada ka bijirar da samfurinka zuwa buɗeɗɗen harshen wuta ko garin taba mai wuta.



questions.TH@support.sonyericsson.com
 questions.TR@support.sonyericsson.com
 questions.UA@support.sonyericsson.com
 questions.AE@support.sonyericsson.com
 questions.GB@support.sonyericsson.com
 questions.US@support.sonyericsson.com
 questions.VE@support.sonyericsson.com

- Kar ka saki, jifa ko kokarin tankwara samfur naka.
- Kar ka yiwa samfur naka fenti.
- Ka rkayi yunkurin kwakkwance ko gyaggyara samfur naka. Kebantaccen mai zibin na Sony Ericsson kawai zai yi sabis.
- Kada kayi amfani da samfur naka kusa da kayan aikin likitanci ba tare da neman izini daga mai kiwon lafiyarka ko malamin lafiya mai izini.
- Kada kayi amfani da samfur naka lokacin cikin, ko kusa da jirgin sama ko wurare masu alamar "turn off two-way radio".
- Kada kayi amfani da samfur naka a wuri inda yuwuwar fashewar yanayi ke kasancewa.
- Kada ka sanya samfur naka ko shigar da kayan aiki marasa waya a wuri sama da jakar iska a motarka.
- Gargaɗi: Tagagge ko karyayyen nuni yana haifar da kaifancin gefuna ko gutsatsari waɗanda zasu iya cutar da lamba.



YARA

AJE NESA DA ISAN YARA. KADA KA BARI YARA SUYI WASA DA WAYARKA TA HANNU KO NA'URORINTA. ZASU IYA CUTAR DA KANSU KO WASU, KO DA TSAUTSAYI SU LALATA WAYAR HANNUN KO NA'URAR. WAYARKA TA HANNU KO NA'URARTA ZAI IYA KUNSAR KANANAN SASSA WADANDA ZASU IYA ZAMA YANKAKKU KUMA DA KIRKIRAN HADARI MAI CUTARWA.



(Caja) Mai bada wuta

Hadā adafar wutar AC kawai zuwa cibiyar wuta kamar yadda akayi alama akan samfurin. Tabbatar agiya na wurinta don haka bazata zama dalilin lalacewa ko damuwa ba. Don rage hadarin jan lantarki, cire kidaya daga kowacce cibiyar wuta kafin yunkurin tsabta shi. Dole baza ayi amfani da adafar wutar AC a waje ko cikin lalatattun wurare ba. Kar ataba canza agiya ko filogi. Idan filogi bai dace da mafita ba, shigar da mafita mai dacewa ta kwararren mai aikin lantarki.

Yi amfani kawai da kwakkwarar cajar asali ta Sony Ericsson da akayi nufi don amfani tareda wayarka ta hannu. Zai yiwu wasu cajojin ba'a kerasu da amincin irir ɗaya ba da kuma matakin aiki.

Baturi

Mun bada shawara cewa kayi cikakken cajin baturi kafin kayi amfani da wayarka ta hannu da farko. Sabon baturi ko wanda aka jima ba'a yi amfani dashi ba zai iya rage karfi 'yan lokutan farko da akayi amfani dashi. Za'a yi cajin baturi ne kawai cikin yanayin zafi tsakanin +5°C (+41°F) da +45°C (+113°F).

Yi amfani kawai da kwararrun baturan asali na Sony Ericsson da akayi nufi don amfani tareda wayarka ta hannu. Yin amfani da wasu baturan zai iya zama hadari.

Magana da lokutan jiran aiki sun dogara da yanayi daban-daban kamar karfin signal, yanayin zafin aiki, samfuran amfanin aikace-aikace, zaɓaɓɓun fasalulluka da murya ko watsa bayanai lokacin da ake amfani da wayar hannu.

Kashe wayarka ta hannu kafin cire baturin. Kada ka sanya baturi a cikin bakinka. Wutar baturi zai zama mai guba idan an hadiya. Kada ka bar karfen hadi na baturi ya taɓa wani abin karfe. Yin wannan zai iya gajarta da'ira da lalata baturi. Yi amfani da baturi don dalilin da akayi nufi kawai.

Na'urorin likitanci na sirri

Wayoyin hannu zasu iya rinjayar aikin masu auna bugun zuciya da wani shukakken abin aiki. Guji sanya wayar hannu saman mai auna bugun zuciya, misali a aljihun nononka. Lokacin amfani da wayar hannu, yi amfani da ita a kunni akan gefen akasin jiki zuwa mai auna bugun zuciya. Idan karamar tazara ta cm 15 (inci 6) tana tsakanin wayar hannu da mai auna bugun zuciya, hadarin kutsawa zai zama iyakantacce. Idan Kanada kowane dalilin zargin cewa kutsawa na faruwa, kashe wayarka ta hannu da gaggawa. Tuntuɓi likitan ka na zuciya don karin bayani.

Don wasu na'urorin lafiya, shawarci malamin lafiyar ka da makerin na'ura.

Tuki

Bincika idan dokokin gida da ka 'idoji sun killace amfanin wayar hannu yayin tuki ko nemi direba yayi amfani da hallin abin sawa a kunni. Muna ba da shawara cewa kayi amfani da abin sawa akunni na Sony Ericsson kawai wanda akayi nufi don amfani tareda samfur naka.

Kula cewa saboda yiyuwar kutsawa zuwa kayan lantarki, wasu makeran abin hawa suna hana amfani da wayoyin hannu a cikin abin hawan su sai dai idan an saukar da abin sawa a kunni tareda eryar waje.

Bada cikakkiyar kulawa ga tuki koyaushe da barin titi kuma tsaya kafin yin ko amsa kira idan halin tuki ya bukaci haka.

Kiran gaggawa

Wayoyin hannu suna aiki ta amfani da sigina na rediyo, wanda bai bada garantin haɗi a cikin duk hali. Don haka kada kafiyar dogaro da kowacce wayar hannu don mahimman sadarwa (e.g. magani na gaggawa).

Kiran gaggawa bazai yiyu ba a cikin duk yankuna, akan duk cibiyoyin sadarwa na wayar salula, ko lokacin da takamaiman sabis na cibiyar sadarwa da/ko fasalolin wayar hannu ke cikin amfani. Bincika tare da mai baka sabis na gida.

Eriya

Wannan wayar ta kunshi ginanniyar eriyar ciki. Amfani da na urorin eriya bana kasuwanci ta Sony Ericsson musamman wannan kirar zai iya lalata wayarka ta hannu, rage aiki, kuma zai kirkiri matakai na SAR a saman iyakoki waƙanda aka kafa. (kalli kasa).

Amfani mai inganci

Rike wayarka ta hannu kamar yadda zakayawa kowace waya. Kada ka rufe saman wayarka ta hannu lakacin da take cikin aiki, saboda wannan yana rinjayar ingancin kira kuma zai iya sa waya aiki ta kakkarfan matakin wuta fiye da yadda ake bukata, don haka yan gajartadda magana da lokutan jiran aiki.

Mitar rediyo (RF) fiddawa da Kimar Takmammen Shagaltuwa (SAR)

Wayarka ta hannu tana da karamar wutar rediyon watsawa da karɓa. Lokacin da aka kunna ta, tana fitarda kananar matakai na kuzarin mitar rediyo (kuma an sansu azaman igiyoyin rediyo ko filayan mitar rediyo).

Gwamnatocin duniya sun karɓi jagororin lafiya na waje wanda aka fahimta, ginannu ta kungiyoyin ilimin kimiyya da fasaha, misali, ICNIRP (International Commission on Non-Ionizing Radiation Protection) da IEEE (The Institute of Electrical and Electronics Engineers Inc.), ta hanayar juyi da kimanta karatun ilimin kimiyya da fasaha. Waƙannan jagororin sun kafa matakan izini na fiddawar igiyar rediyo don adadi gaba daya. Matakan sun haɗa da kerarren murfi don tabbatar da lafiyar duk mutane, bada la'akari da shekaru da lafiya ba, da yin bayani don kowanne banbanci cikin aunawa.

Specific Absorption Rate (SAR) kiɗaya ne na aunawa don adadin karfin mitar rediyo samamme ta jiki lokacin amfani da wayar hannu. An kudurta kimar SAR a mafi girman matakin wuta a cikin yanayin wurin binciken fasaha, amma ainihin matakin SAR na wayar hannu yayin aiki zai iya zama kasa da wannan kimar. Saboda wayar hannu an kerata don amfani da karamar wuta da aka bukata don isa ga cibiyar sadarwa.

Bambanci a cikin SAR kasan jagororin fiddawa na mitar rediyo baya nufin cewa akwai bambanci a cikin lafiya. Yayin yiwuwar samun banbance banbance cikin matakan SAR tsakanin wayoyin hannu, duk sababun kirar wayar hannu na Sony Ericsson an kera su don gamuwa da jagororin faddawa na mitar rediyo.

Don wayoyin da aka sayar a cikin Amurka, kafin sabuwar kirar waya ya wadata don sayarwa ga jama'a, dole ne babbar hukumar sadarwa ta kasa (FCC) ta gwada ta da shaida cewa barta wuce iyaka kafafiyi ya gwamnati na karbabɓun abubuwan bukata don amintacciyar fiddawa. Anayin gwaje gwaje a cikin matsayi da wurare (shine, a kunne da sanyawa akan jiki) kamar yadda FCC ta bukata a kowane kira. Don sawa a jiki, An gwada wannan wayar kuma tagamu da jagororin fiddawa na FCC RF lokacin da wayar hannu take a matsayin karancin m1515 daga jiki ba tareda kowane sassa na karfe a cikin kusancin waya ko lokacin amfani tareda na 'urar asali ta Sony Ericsson wadda akayi nufi don wannan wayar da sawa a jiki. Amfanin wasu na 'urori bazai iya tabbatar da haɗin kai tareda jagororin fiddawa na FCC RF.

Wararren sharhi tareda bayanin SAR gameda wannan sabuwar kira na wayar hannu ya haɗa da kayan aikin dake rakiyar wannan wayar hannu. Za'a iya kuma samun wannan bayanin, tareda karin bayani akan fiddawa na mitar rediyo da SAR, akai: www.sonyericsson.com/health.

Hanyoyin Halli/Bukatan musamman

Don wayoyin da aka sayar cikin US, zaka iya amfani da alamar TTY taka tareda wayar hannu ta Sony Ericsson taka (tareda na'urar tilas). Sabida bayani akan Hanyar Magani saboda muatane tareda mahimman bukatu kira Wurin Mahimman Bukatu na Sony Ericsson a 877 878 1996 (TTY) ko 877 207 2056 (murya), ko ziyarci Wurin Mahimman Bukatu na Sony Ericsson a www.sonyericsson-snc.com.

Zubar da tsoffin kayan wuta da lantarki



Wannan alamar na nuni da cewa duk wayoyin lantarki da kayan wuta da aka haɗar ba za'a iya ma'amala dasu azaman marasa amfani na gida ba. Maimako haka za'a barta a matattara mai dacewa don sake kirar kayan wuta da lantarki. Ta tabbatar da wannan samfur din an zubar da shi daidai, za ka taimaka wajen kare abubuwa masu cutarwa sadoda yanayi da lafiyar dan adam, wanda zai iya haifar da asara ta kula da samfuri. Juyin kayayyaki zai taimaka wurin kiyaye arzikin kasa. Don karin cikakken bayani game da juyin wannan samfur, tuntuɓi ofishin gari na gida naka, sabin naka mai kula da zubar d'ashara na gida ko kanti inda ka sayi samfuri.

Zubar da baturi



Bincika dokokin gida don tsara batūra ko kira wurin kiran Sony Ericsson na gida don bayani. Wajibine kada a aje baturi a sharar gari. Amfani da wurin zubar da baturi in akwai.

Katin kwakwalwar ajiya

An sa samfur naka tareda mai karanta katin kwakwalwar ajiya. Bincika ingancin katin kwakwalwar ajiya kafin siya ko amfani. An tsara katunan kwakwalwar ajiya gaba daya kafin ɗauka a jirgin ruwa. Don sake tsarin katin kwakwalwar ajiya, yi amfani da na'ura mai dacewa. Kada ka yi amfani da tabbataccen salon aikin tsari lokacin tsara katin kwakwalwar ajiya akan PC. Don cikakken bayani, koma zuwa umamin aikin na'ura ko tuntuɓi goyan bayan mai sayarwa.

Gargadi:

Idan na'urar ka tana bukatar adafta don sanyawa cikin waya ko wata na'urar, kada ka saka kati kai tsaye ba tare da adaftan da ake bukata ba.

Kariya akan amfanin katin kwakwalwar ajiya

- Kada ka bijirar da katin kwakwalwar ajiya a damshi.
- Kada ka taba hade-haden tasha da hannunka ko da wani abin karfe.
- Kada ka goge, tankwara, ko jifa da katin kwakwalwar ajiyar.
- Kada kayi yunkurin kwakkwance ko gyaggyara katin kwakwalwar ajiyar.
- Kada kayi amfani da ko adana katin kwakwalwar ajiyar cikin danshi ko matsattsun wurare ko cikin matsanancin zafi kamar ruffaffiyar mota cikin da rani, cikin hasken rana kaitsaye ko kusa da hita, da sauransu.
- Kada ka latsa ko tankwara karshen adaftar katin kwakwalwar ajiya da matsanancin karfi.
- Kada ka bar datti, kura, ko bakin abubuwa su shiga cikin zangon kowane adaftar katin kwakwalwar ajiya. Bincika ka saka katin kwakwalwar ajiyar dai-dai.
- Saka katin kwakwalwar ajiyar har sai ya shiga cikin kowane adaftar katin kwakwalwar ajiya yadda ake bukata. Katin kwakwalwar ajiya bazai yi aiki dakyau ba harsai an sashi baki daya.
- Mun bada shawara cewa kayi ajiyayyen kwafin mahimman bayanai. Bamu da alhakin kowacce asara ko lalacewar abun ciki wanda ka adana akan katin kwakwalwar ajiya.
- Zai yiwu rikodin bayanai ya lalace ko bacewa lokacin da ka cire katin kwakwalwar ajiya ko adaftar katin kwakwalwar ajiya, kashe wuta yayin tsara, karanta ko rubuta bayanai, ko amfani da katin kwakwalwar ajiya cikin wurare masu tsayayyiar lantarki ko manyan filayan matattarar lantarki.

Kariya na bayanan sirri

Don amintaccen gadin sirrin ka da hana bayani samun damar zuwa bangare na uku, yakamata kashare bayanan sirri kafin sayar ko zubar da samfur. Don share bayanan sirri, yi sake saiti zuwa na ainihi kuma cire katin kwakwalwar ajiya. SHARE KAYA DAGA KATIN KWAKWALWAR AJIYA BAYA TABBATAR DA CEWA BAYANIN DA AKA FADA BAZA A IYA DAWO DASU TA MAI AMFANI NA YANZU BA. SONY ERICSSON BAZAI BADA GARANTI GA MAI AMFANIN YANZU NA NA'URA WUCEWA ZUWA BAYANIN KA KUMA BAZAI DAUKI KOWANE ALHAKI DON BUDEWA MAI BIYOWA NA BAYANIN DA AKA FADA KO DA ANYI SAKE SAITI ZUWA NA AINIHI. Idan irin wannan yiuwar fallasawar tashafeka rike na'urararka ko kiyaye tabbatacciyar fashewarta.

Na'urorin hadi

Sony Ericsson yana bada shawarar amfani da na'urorin hadi na Sony Ericsson na asali don aminci da aiwataccen amfanin samfuri sa. Amfanin na'urorin hadi na bangare na uku zai iyfa rage aiki ko sanya hadari ga lafiyarka ko amincika.

GARGADI DA BABBAR MURYA:

Dai-daita karan mai jujuwa a tsanake lokacin amfani da na'urorin hadi masu jujuwa na bangare na uku don kiyaye matakan kara waɗanda zai yiwu su zama cutarwa ga jinka. Sony Ericsson Bai gwada amfanin na'urorin hadi na bagare na uku tareda wannan wayar hannu ba. Sony Ericsson ya bada shawarar amfani kawai da na'urorin hadi masu jujuwa na asali na Sony Ericsson.

Kare Lasisin Yarjejeniyar Mai amfani

Wannan na'ura mara waya wanda ya taradda rashin iyakar kowane mai jarida da aka bayar tare da na'ura, ("Na'ura") ya kunshi software na Sony Ericsson Mobile Communications AB da kamfanoni masu haɗin gwaiwa da shi ("Sony Ericsson") da wakilai da masu lasisin sa na bangare na uku ("Software").

Azaman mai amfani da wannan na'ura, Sony Ericsson ya baka lasisi wanda ba kebabbe ba, wanda baza a iya canja masa wuri ba, wanda baza a iya sa hannu don amfani da software kawai a cikin rinti tare da na'ura wanda a kanta aka shigar kuma/ko aka bayar tare. Babu wani abu da a ka sanya da za'a iya tawili azaman sayar da software don na'urar mai amfani.

Ba za ka iya sake, gyaggyara, sauyawa, hadawa, watsa, sai dai sami ko kayi amfani da kowace manufa don buɗe lambar tushe na software ko kowane abin da yashafi software. Don nisantar shakku, akowane lokaci ana baka dama don cana wurin hakkokin mallaka da wajibai zuwa software zuwa bangare na uku, tare da na'ura da ka karbi software kawai, ana badawa akoyaushe cewa bangare na uku ya mance a rubuce cewa ya amince da waɗanan dokoki.

Kana da garantin wannan lasisi na amfanin tsawon rayuwar wannan na'ura. Zaka iya lalata wannan lalasin ta canja wurin duk hakkokin Na'urar da ka karbi software ta ita zuwa bangare na uku a rubuce. Idan ka gaza bada haɗin kai ga kowane sharuɗɗa saitattu a cikin lasisi, zai kare da rinjayen gaggawa.

Sony Ericsson da wakilan sa na bangare na uku da masu lasisin sa sune ainihin kababbun mamallakan da riƙe duk hakkokin mallaka, take da tattali cikin da zuwa Software. Sony Ericsson, da, zuwa mutuka cewa software ta kunshi kaya ko lambar bangare na uku, bangaren na uku, za'a bashi taken riba na uku na waɗannan sharuɗɗa.

Nagarta, kira da aikin wannan lasisi suna karkashin dokokin Sweden. Kayan zasu yi aiki sosai da izinin da aka bada ta kayan aiki da damar hakkin mabukatan.

Garanti mai iyaka

Sony Ericsson Mobile Communications AB, Nya Vattentornet, SE-221 88 Lund, Sweden, (Sony Ericsson) ko kamfanin tarayyar sa, ya bada wannan iyakantancen garanti do wayarka ta hannu da na'urar haɗi ta asali da aka bayar tare da wayar ta hannu (nan gaba koma zuwa ga "Product").

Shin samfurin ka zai bukaci sabis na garanti, mai dashi zuwa dilan da aka saya daga wurinsa, ko tuntubi wurin kiran Sony Ericsson na gida (zai yiwu ayi aiki da kimar kuɗin kasa) ko ziyarci www.sonyericsson.com don samun bayani na gaba.

Garantinmu

Bugu da kari ga halayen wannan garanti mai iyaka, Sony Ericsson yayi garantin wannan samfurin don wofinta daga aibin kira, kayan aiki da ma aikacin sana'a a asalin lokacin da mai bukata ya sheya. Wannan garanti mai iyaka zai ɗauki tsawon shekara (1) daya kamar daga asalin kwanan watan sayan samfur.

Me zamuyi

Idan,yayin lokacin garanti, wannan samfurin ya kasa aiki a karkashin amfani da sabis na al'ada, saboda matsalar kira, kayan aiki ko da ma'aikatan sana'a, masu rabawa ko abokan sabis, a cikin kasa inda kasayyi samfur, zasu, a zabubbukan su, ko gyara ko sauya samfur dangane da sharuɗɗa da halaye da aka shimfiɗa a ciki.

Sony Ericsson da abokan na sabis sun tanadi hakkin biyan kuɗi idan samfur da aka dawo dashi baya karkashin garanti dangane da halaye na kasa.

Lura cewa waɗansu saitunan ka na sirri, saukewa da wani bayani zasu iya baɗewa lokacin da aka gyara ko sauya samfurin ka na Sony Ericsson. A halin yanzu zartattun dokoki suna iya kiyaye Sony Ericsson, waɗansu ka'idoji ko kuntatawa na fasaha daga yin kwafin ajiya na takamaimiyar saukewa. Sony Ericsson bazai ɗauki kowane alhakin baɗewar kowane irin bayani kuma bazai mayar maka da kowacce irin asara ba. Kayi koyaushe kwafin duk bayanan da suke ajiyayyu akan samfurin ka na Sony Ericsson kamar saukewa, kalanda da lambobi kafin bada samfurin ka na Sony Ericsson don gyara ko sauyawa.

Sharuɗɗa

- 1 Wannan garanti mai iyaka yana aiki ne kawai idan tabbacin asalin sayan wannan samfur anyi shi ne ta dila mai izini na Sony Ericsson dayake kididdige kwanan watan saya da lambar serial**, da aka gabatar tare da samfur don gyara ko sauyawa. Sony Ericsson ya tanadi damar kin sabis na garanti idan an cire ko canja wannan bayani bayan asalin sayan samfur daga wurin dila.

- 2 Idan Sony Ericsson yana gyara ko sauya samfur, gyara don illa ya shafi, ko samfur da aka sauya za'a bashi garanti zuwa ragowar lokacin garanti na asali ko zuwa kwana (90) daga ranar gyara, komai tsawon sa. Gyara ko sauyawa na iya kuste a amfanin kayan aiki wanda suke dai-dai da matsayin kiɗaya. Juzu'ai da aka sauya ko aka gyara zasu zama mallakar Sony Ericsson.
- 3 Wannan garantin bazai maye kowace asarar samfur sakamakon lalacewa da tsagewa ta al'ada, ko sakamakon wulakanta, ya haɗa da amma bai iyakance don amfani fiyeda yanayin amfani na al'ada dangane da umarnin Sony Ericsson don amfani da kiyaye samfur. Haka nan wannan garantin baya maye gurbin orwane lalacewar samfur saka makon haɗari, gyara ko dai-dai ta software ko hardware, yin Allah ko lalacewa saka makon shigar ruwa.

Za'a iya caji ko cire cajin baturi mai cajuwa fiye da sau ɗari. Ko yaya, zai lalace a karshe - wannan ba illa bane kuma yana dacewa da lalacewa da yagewa na al'ada. Lokacin magana ko jiran aiki an kula yayi gajarta, lokacin ake sauya baturi. Sony Ericsson yabada shawara cewa kayi amfani da batura ko caji yardaddu ta Sony Ericsson.

Kananan sabani a cikin nunin haske da launi zai yiwu yafaru tsakanin wayoyi. Zai yiwu a sami kanana haske da digon duhu akan nuni. Akwi fatsi-fatsin na bayana da zaran kebantaccen digon ya sami matsala kuma ba za'a iya daidai tawa ba. Ana ɗaukar waɗannan fatsi-fatsin biyu ba matsala bane.

Kananan bambanci a cikin bayyanar hoton kamara zai yiwu yafaru tsakanin wayoyi. Wannan ba wani abune da ba'a saba dashi ba kuma ba'a la'akari dashi azaman bacin kamara a koyaushe.

- 4 Tunda tsarin salula wanda akansa samfur zai yi aiki ta mai dauka mai cin gashi kansa daga Sony Ericsson, Sony Ericsson bazai dauki alhakin aiki, samuwa, daukar hoto, sabis ko kewoyon wannan tsarin.
- 5 Wannan garantin bazai maye gurbin lalacewar samfur ba wanda yafaru ta shigarwa, dai-dai tawa, ko gyarawa ko bude samfur ta wani mutum mara izinin Sony Ericsson.
- 6 Garantin baya shafar lalacewar samfur wanda ya faru saboda amfani da na'urorin haɗi ko wasu nau'urori wadanda basu da alamar Sony Ericsson ta asali wacce akai nufin amfani da ita a samfuri.
- 7 Barna da kowane tambarin dake kan samfuri zai bata garanti.
- 8 **BABU GARANTIN GAGGAWA, RUBUTACCE KO NA BAKA, SABANIN WANNAN BUGAGGEN GARANTI MAI IYAKA. DUK GARANTIN DA AKA GABATAR, BA TARE DA IYAKANCE GARANTIN CINIKI KO CANTANTA DON AIKI NA MUSAMMAN, SUN TSAYA A KAN LOKACIN DA AKA KIYASTA NA WANNAN GARANTI. BABU WANI ABIN FARUWA DA SONY ERICSSON DA MASU LASHINTA ZASU DAUKI ALHAKIN DOKA DON LALACEWAR BAZATA KO MAI SABABI NA KOWANE HALI KOWANE IRI YA KUNSA AMMA MARA IYAKA DON RIBAR DA AKA RASA KO BACEWAR CINIKI; ZUWA MATUKAR IYAKA DOKA BA ZATA YARDA DA WANNAN LALACEWA BA.**

Wasu kasashe/jahohi basu bada damar wariya ko iyakancewar barna na bazata ko mai sanadi, ko iyakancewar lokacin garanti da aka nuna, saboda haka iyakancewar data gabata ko wariya mai yiwuwa bazata zartu gareka ba.

Garanti da aka bada ba zai tasiri ba a dokokin hakkin amsu saya a karkashin zartaccen kundin zari, ko hakokin mai saya akan dila wanda yataso daga kwantiragin sayarwa/saye nasu.

Gwargwadon nisan garantin na jogurafi

Idan ka sayi samfur dinka a cikin kasa 'yar kungiyar kashashin tattalin arziki na kasshen turai (EEA) ko a Switzerland ko Turkiyya kuma anyi nufin sayar da samfur din a cikin EEA ko Switzerland ko Turkiyya, samfur din zai iya aiki a kowane kasar EEA ko cikin Switzerland ko cikin Turkiyya, karkashin sharuɗɗa garanti da suka fi samuwa a kasar da kake bukatar sabis, idan har cewa ana sayar da samfur din a cikin wannan kasar ta mai rabawa na Sony Ericsson mai izini. Don gano idan ana sayar da samfur dinka a kasar da kake, kira wurin kiran Sony Ericsson na gida. Kiyaye cewa takamaimen sabis bazai yiwu a wani wuri ba acikin kasar asalin saya ba, misali a hakika samfura dinka zai iya samin bam-bamcin ciki ko waje daga irinsa wanda aka sayar a wasu kasashe. Lura kari da cewa mai yiwuwa wasu lokuta ba zai yiwu a gyara samfura masu kullalan SIM.

** A wasu kasashe/jihohi zai yiwu a bukaci karin bayani (kamar katin garanti mai aiki).

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.



Declaration of Conformity

We, **Sony Ericsson Mobile Communications AB** of Nya Vattentornet SE-221 88 Lund, Sweden

declare under our sole responsibility that our product

Sony Ericsson type AAD-3022091-BV

and in combination with our accessories, to which this declaration relates is in conformity with appropriate standards 3GPP TS 51.010-1, EN 300 328, EN 301908-1, EN 301908-2, EN 301 489-7, EN 301489-24, EN 301 489-17 and EN 60950, following the provisions of, Radio Equipment and Telecommunication Terminal Equipment Directive **99/5/EC** with requirements covering EMC Directive **89/336/EEC**, and Low Voltage Directive **73/23/EEC**.

Lund, May 2007

CE 0682

A handwritten signature in black ink, appearing to read 'Shoji Nemoto', written over a horizontal line.

Shoji Nemoto,

Head of Product Business Group GSM/UMTS

Mun cika sharu'dan Bayanin R&TTE (**99/5/EC**).

Fihirisa

A

abin sawa akunni	11, 25, 30, 31
Bluetooth	74
Abokaina	48
agogon awon gudu	83
aikace-aikace	67
aikawa	

alkawurra da dawainiya	81
bayanankula	82
hotuna	54, 55
jigogi	56
katunan kasuwanci	37
launukan waka da	
sautukan ringi	64

aiki tare	72–73
allon rubutu	36
allon uwar garke	54
alkawurra	80
amfani mai lafiya da inganci	96
amsa murya	31

B

baturi	
sawa da caji	6
zubarwa	99
baturi, amfani da kula	97

bayanankula	82
bayanankumarta	84–85
bugun kiran sauri	29

B

boye lamba	36
------------------	----

C

canja wuri	
fayiloli	76
hotunan kamara	53
kiɗa	58
cibiyoyin sadarwa	22
cire katangar katin SIM	86

D

Declaration of Conformity	104
Disc2Phone	58
dogayen sakonni	40

D

daukaka sabis	78
dawainiya	81–82

E

email	44
-------------	----

F		cookies da kalmomin	
fara allo	54, 87	wucucewa	71
Fasaha mara waya ta Bluetooth	73	saituna	67
		shafi	53
		tsaro da takaddun shaida	71
G		J	
Gajerun hanyoyi	16	jagororin kiyayewa	96
garanti	101	jigogi	56
garanti mai iyaka	101	jiran aiki	7
girman hoto	52	jiran kira	33
gumaka	16		
H		K	
halin kawowa	41	kafaffen bugun kira	35
halin kwakwalwar ajiya	19	kakuleta	83
hanyar canja wuri		kalanda	80–81
Fasaha mara waya ta Bluetooth	73	kalmar sihiri	31
USB	76	kamara	51
hoton fusk. waya	54	karkata kira	32
hotuna	54	Katin SIM	
allon uwar garke	54	kulle kuma cire katanga	85
shirya	56	kwafi zuwa/daga	27, 28
		tuntubi lambobi	26
I		katin kwakwalwar ajiya	19, 99
ikon murya	30–32	katunan kasuwanci	37
Intanit		Kebul na USB	76
alamomin shafi	69		
bayanana martaba	70		

kira	
amsa da kin amsa	22
bidiyo	24
gaggawa	23
karɓa	34
karɓan kira biyu	33
na kasashen waje	22
rikodi	66
sanyawa a riko	33
wanda aka rasa	23
yin bayanana kula yayin	36
yin kira da karɓa	8, 22
kuntatawa	35
kiran taro	33
kida	
canja wuri	58
kunnawa/kashewa	
Fasaha mara waya ta Bluetooth ...	73
kiyaye makullin SIM	86
makullin waya	86
kwanan wata	85

K	
kara	
lasifikar kunni	23
sautin ringi	63
kararrawa	79
kungiyana taɗi	37

L	
lambar memo	83
lambar PIN	
caji	86
cire katanga	5
lambobi	
aiki tare	72
tsoffin lambobi	25
kara lambobin waya	26
kungiyoyin taɗi na	37
lambobina	34
lambobin kira a sako	39
lissafin kira	29
lissafin waka	59
lokaci	85
lokacin kira	36

M	
M2™	99
Mai karanta RSS	71
mai kunna bidiyo	57
Mai kunna kida	57
mai sarrafa fayil	19
mai kida. lokc	83
makurfon	22
makulli	
faifan maɓalli	87
Katin SIM	85
waya	86

makullin faifan maɓalli	15, 87
maɓallai	10, 14
Menu na ayyuka	8
menus	14
menus na kwayawa	14
MusicDJ™	64

N

nuna, haske	87
-------------------	----

P

PhotoDJ™	56
PlayNow™	62
PUK	5, 85, 86

R

ramut	76
rayarwa	54
rigakafi, katin kwakwawar ajiya	100

S

sabis da goyan baya	94
sabis ɗin amsa	29
saita maye	6
saituna	
Intanit	67
Java™	70
nuna haske	87

sake bugun kira ta atomatik	22
samfuri	40, 43
SAR	98
sauti, canja wuri da fuskantarwa	75
saukar da fayiloli	70
sautin rikoda	66
sautin ringi	63
sakon murya	29
sakonni	
email	44
halin kawowa	41
hoto	41
murya	43
rubutu	38
yanki da bayanin kira	50
sakonnin hoto	41–43
sakonnin murya	43
sakonnin rubutu	38–41
shafi	53
shafi na hoto	53
shigar da haruffa	17
shirye-shiryen bidiyo	54
siffar menu	12
siffar waya	10
SMS <i>Duba</i> sakonnin rubutu.....	38
SOS <i>Duba</i> lambobin gaggawa	23

T

T9™ Text Input	18
taimako	7
takamammen sautin ringi na mai kira .	28
TrackID™	61

V

VideoDJ™	64
----------------	----

W

wasanni	66
waya	
hadawa	5
makulli	86
yare	17
wuraren kira	94

Y

yare	88
yarukan rubutu	17

Z

zubarwa	
baturi	99
zuko	
kamara	52
Dakin yana	69