

Taya murna game da siyanka Sony Ericsson K850i.
Kama kuma yi tarayyar ingancin lokuta. Don karin
abun cikin waya, je zuwa www.sonyericsson.com/fun.

Yi rijista yanzu don samun kayan aiki masu dacewa,
ma'ajin kan layi kyauta, tayi na musamman, labarai
da gasa a www.sonyericsson.com/myphone.

Don goyanbayan samfur, je zuwa
www.sonyericsson.com/support.

Na'urorin haɗi - Kari don wayarka

IPK-100 kwalin waya mai kamara
Kariyar inshora don wayarka.



HBH-IV835 na'urar kai ta
Bluetooth™

Salon hankali tareda sauti mai armashi.



Mazaunin CDS-65

Mafi kyawun mataimakin wayarka:
Haɗa kebul na USB, caja da abin
sawa akunni mai ɗaukuwa.



Wadannan nau'urorin haɗin za'a iya sayansu daban amma
maiyuwa ba za'a same su a kowacce kasuwa ba. Don duba
cikakken kewayo je zuwa www.sonyericsson.com/accessories.

This is the Internet version of the User's guide. © Print only for private use.

Abubuwan ciki

Farawa5

Haɗawa	5
Kunna wayar	6
Taimako a wayarka	7
Cajin baturi	7
Siffar waya	8
Takaitaccen bayanan Menu	10
Kewayawa	12
Mai sarrafa fayil.....	13
Yaren waya	15
Shigar da rubutu.....	16

Kira17

Yin kira da karɓa	17
Lambobi	19
Lissafin kira	23
Bugun kiran sauri	23
Sakon murya.....	23
Ikon murya	24
Karkata kira	25
Fiye da kira ɗaya.....	26
Lambobina	27
Karɓar kira	27
Kuntataccen bugun kira	28
Kafaffen bugun kira	28
Lokacin kira da farashi	29

Sako29

Sakonnin rubutu	30
Sakonnin hoto	30
Zabubbukan sako.....	32
Samfuri	32
Sakonnin murya	33
Email	33
Abokaina	35
Bayanin wuri da salula	37

Hoto38

Kamara da mai rikodin bidiyo.....	38
Kamara da mai rikodin bidiyo.....	38
Amfani da kamara.....	39
Samun ƙari daga kamarar.....	39
Gumakan kamara da saituna.....	40
Gajerun hanyoyin kamara	41
Canja wurin hotuna	41
Fitarwar kamara	42
Hotuna.....	42
PhotoDJ™ da VideoDJ™	44
Jigogi.....	44

Nishadi45

Abin sawa akunni mai daukuwa na siteriyo.....	45
Kiɗa da masu kunna bidiyo.....	45
Canja wurin kiɗa daga kwamfuta	46
TrackID™	48
Rediyo	49
PlayNow™	49
Sautunan ringi da karin waka.....	50
MusicDJ™	51
Mai rikodin sauti	51
Wasanni	52
Aikace-aikace.....	52

Hadi53

Saituna	53
Sunan waya	54
Amfani da Intanit	54
Ciyarwar yanar sadarwa	55
Fasaha mara waya ta Bluetooth™	56
Amfani da Intanit	58
Aiki tare	59
Daukaka sabis	61

Karin fasali.....63

Kararrawa.....	63
Kalanda	64
Dawainiya	65
Bayanan kula	66
Mai kidayar lokaci, agogon awon gudu da kalkaleta	66
Memo na lamba	67
Bayanan martaba.....	68
Lokc.da kwn.wata.....	68
Makullai	69

Shirya matsala.....71

Tambayoyi gama gari.....	71
Kuskuren sakonni.....	73

Muhimman bayanai74

Kare lasin yanjejeniyar mai amfani .	81
Garanti mai iyaka	81
FCC Statement	84

Fihirisa.....85

Sony Ericsson K850i

UMTS 2100 GSM 900/1800/1900

An buga wannan jagorar mai amfanin ta Sony Ericsson Mobile Communications AB ko kamfanonin haɗin gwiwarsu, ba tare da wani garanti ba. Cigaba da canje-canje ga wannan jagorar mai amfanin wanda kusukuran rubutu ya haifar, rashin dacewar bayanin yanzu, ko cigaba zuwa tsare-tsare da/ko kayan aiki, zai yiwu Sony Ericsson Mobile Communications AB ya gudanar dasu akowane lokaci kuma ba tare da sanarwa ba. Irin waɗannan canje-canje za'a, ko yaya, shigar dasu cikin sababbin bugun wannan jagorar mai amfanin.

An adana duk hakkoiki.

©Sony Ericsson Mobile Communications AB, 2007

Lambar bugawa: 1202-5297.1

Kula:

Wasu daga cikin waɗanan sabis basu da goyan bayan duk cibiyoyin sadarwa. *Kuma ana aiwatar da wannan zuwa ga GSM lambar gaggawa ta kasar waje 112.*

Tuntuɓi afaɗetan cibiyar sadarwarka ko mai bada sabis in kana shakka ko zaka iya amfani da wani sabis ko a'a.

Karanta Jagorori don aminci da ingantaccen amfani kuma *Garanti mai iyaka* babuka kafin kayi amfani da wayarka ta hannu.

Wayarka nada damar saukewa, ajiyewa da tura karin abin ciki, misali: sautunan ringi. Amfani da abin cikin nan zai yiwu an takaita ko an haramta ta hakkin mallaka na ɓangare na uku, yana tattare da sai dai ba a iyakance ba zuwa takaitawa karkashin zartattun dokokin hakkin mallakar. Kai ne, ba Sony Ericsson ba ke da cikakken alhakin don karin abin ciki wanda ka saukar zuwa ko ka tura daga wayarka ta hannu. Kafin amfaninka na kowane karin abin ciki, Ka tabbatar da amfanin da kake nufi na da lasisi ko kuma yana da izini.

Sony Ericsson baya bada garantin kyautatata aiki, nagarta ko ingancin wani karin abin ciki ko wani abin ciki na wani ɓangare na uku. Babu dalili da zai ba Sony Ericsson ya zama abin dogaro ta kowace hanya don amfaninka mara kyau na karin abin ciki ko wani abin ciki na ɓangare na uku.

Bluetooth™ alamace ta kasuwanci ko alamar kasuwanci mai rijista ta Bluetooth SIG Inc.

Tambarin farin dutse, BestPic, PlayNow, MusicDJ, PhotoDJ, TrackID da VideoDJ alamune na kasuwanci ko alamun kasuwanci masu rijista na Sony Ericsson Mobile Communications AB.

Sony da Cyber-shot alamun kasuwanci ne na Sony Corporation.

Memory Stick Micro™ da M2™ alamun kasuwanci ne na Sony Corporation.

Ericsson alamace kasuwanci ko alamar kasuwanci mai rijista ta Telefonaktiebolaget LM Ericsson.

Adobe® Photoshop® Album Starter Edition alamace ta kasuwanci ko alamar kasuwanci mai rijista ta Adobe Systems Incorporated a Amurka da/ko wasu kasashe.

Microsoft, Windows, PowerPoint, Outlook da Vista alamun kasuwanci ne na Microsoft Corporation a Amurka da wasu kasashe.

MicroSD alamar kasuwanci ce ko alamar kasuwanci mai rijista ta SanDisk Corporation.

T9™ Text Input alamar kasuwanci ce ko alamar kasuwanci mai rijista ta Tegic Communications.

T9™ Text Input an yi lasisinsa karkashin ɗaya ko fiye na masu zuwa: U.S. Pat. Nos. 5,818,437, 5,953,541, 5,187,480, 5,945,928, da 6,011,554; Dan Kanada Pat. No. 1,331,057, Burtaniya Pat. No. 2238414B; Hon Kon Standard Pat. No. HK0940329; Republic of Jumhuriyar Singafora Pat. No. 51383; Euro.Pat. No. 0 842 463(96927260.8) DE/DK, FI, FR, IT, NL, PT, ES, SE, GB; da kuma karin hakkoiki aiwatarwa na duniya masu jiran zartarwa.

Java da duk tabbatawun alamun kasuwanci alamun kasuwanci ne ko alamun kasuwanci masu rijista na Sun Microsystems, Inc. a Amurka da wasu kasashe.

Kara yarjejeniyar lasisin mai amfani don Sun™ Java™ J2ME™.

Takaitawa: Software asirtaccen bayanin hakkin mallaka ne na Sun kuma an riƙe take da duk kwafi a Sun da/ko masu lasisinsa. Abokin ciniki bazai gyaggyara, watsa, tarwatsa, lalata, kwace, ko kuma yin baya da fasahar software ba. Software bazai yuwu ayi hayarsa, raba aikinsa, ko yin lasisinsa, gaba ɗaya ko a sashi.

Dokokin fitarwa: Software, gamida bayanan fasaha, an tsara shi da dokokin sarrafa fitarwar Amurka, gamida tsarin aikin fitarwar Amurka da dokokinta masu dangantaka, kuma maiyuwa tsari ne na dokokin fitarwa ko shigarwa na wasu kasashe. Abokin ciniki ya amince da cikakken bada haɗin kai ga duk irin waɗannan dokoki kuma da sanin cewa tana da alhakin samun lasisi don fitarwa, sake fitarwa ko shigo da software. Software bazai yuwu a sauke shiba, ko kuma fitar dashi ko sake fitar dashi (i) cikin, ko zuwa na kasa ko mazaunin, Kyuba, Iraki, Iran, Koriya ta Arewa, Libya, Sudan, Siriya (azaman wannan lissafin za'a rika bita daga lokaci zuwa lokaci) ko kowace kasa wacce Amurka ta sawa takunkumin kaya; ko (ii) ga kowane ma'aikatan Amurka da aka keɓance na musamman ko ma'aikatan kasuwancin da baitul malin Amurka masu oda ta musamman.

Takaitattun hakkoƙi: Amfani, kwafi ko kwakkwafi ga hukumar Amurka batune na takaitawa azaman na huɗu hakkoƙi cikin bayanan fasaha da software na kwamfuta sayayye cikin DFARS 252.227-7013(c) (1) (ii) da FAR 52.227-19(c) (2) azaman abin zartarwa.

Wani samfur da sunayen kamfani da aka ambata nan ciki maiyuwa alamun kasuwanci ne na masu mallakar su.

An adana haƙkoƙin da ba'a fayyace garantunsu nan ciki ba.

Duk zanuka don zanene kawai kuma maiyuwa baza su dace da ainihin wayar ba.

Alamomin umarni

Masu biyowa suna bayyana cikin jagorar mai amfani:

! Kula

💡 Tukwici

⚠️ Gargadi

📶 Waɗannan sabis ko aiki sun dogara da cibiyar sadarwa ko biyan kuɗi. Tuntubi afaretan cibiyar sadarwarka don cikakkun bayanai.


> Yi amfani da maɓallin zaɓi ko kewayawa don gungurawa da zaɓi. Duba *Kewayawa* a shafi na 12.

Farawa

Hadawa


Kafin kafara amfani da wayarka, kana bukatar saka katin SIM da baturin.

Don saka katin SIM dɪn



- 1 Cire murfin baturi.
- 2 Zamar da katin SIM dɪn cikin marikinsa tareda lambobi masu launin zinare suna fuskantar kasa.


Don saka baturin



- 1 Saka baturin tareda lambar gefen kasa da masu hadawa suna fuskantar juna.
- 2 Zamar da marufin baturi zuwa cikin wajen.

Kunna wayar

Don kunna wayar



- 1 Latsa ka riƙe kasa ①.
- 2 Zabi yanayi:
 - **Yanayi na al'ad** – cikakkun ayyuka.
 - **Yanayin kaura** – Ayyuka masu iyaka.
- 3 Shigar da katin PIN ɗin katin SIM ɗin, idan an bukata kuma zabi **Ok**.
- 4 Zabi yare.
- 5 Zabi **Ci gaba** > **Ee** don amfani da saita maye yayin da ake sauke saituna.

💡 *Idan kana son gyara kuskure lokacin shigar da PIN ɗinka, latsa (C).*

Katin SIM

Katin (Farin dutsen Shaidar Mai biyan kuɗi) SIM, wanda kasamu daga afaɗetan cibiyar sadarwarka, yana

kunshu da bayani game da biyan kuɗinka. Kashe wayarka koda yaushe kuma zare caji kafin sanya ko cire katin SIM.

💡 *Zaka iya ajiye lambobi a katin SIM ɗin kafin cire shi daga wayarka. Duba Don kwafar sunaye da lambobi zuwa katin SIM a shafi na 21.*

PIN

Maiyuwa ka bukaci PIN (Kaɓaɓɓiyar Lambar Shaida) don kunna sabis a wayarka. Ana bada PIN ɗinka ta afaɗetan cibiyar sadarwarka. Kowace lambar PIN tana bayyana kamar *, sai dai idan ta fara da lambar gaggawa, misali, 112 ko 911. Zaka iya duba kiran lambar gaggawa ba tare da shigar da PIN ba.

💡 *Idan ka shigar da PIN kuskure sau uku a jere, ana katange katin SIM ɗin. Duba Makullin katin SIM a shafi na 64.*

Yanayin kaura

acikin **Yanayi na al'ad** Ana kashe cibiyar sadarwar da rediyo mai watsawa dakarba don hana damun kayan aiki masu tasiri.

💡 *Zaka iya amfani da aikin Bluetooth™ a yanayin kaura.*



Allon farawa

Allon farawa yana bayyana lokacin da ka kunna wayarka. Duba *Amfani da hotuna* a shafi na 42.

Jiran aiki

Bayan ka kunna wayarka da shigar da PIN dinka, sunan afaretan cibiyar sadarwa yana bayyana. Wannan ake kira jiran aiki.

Taimako a wayarka

Akwai taimako da bayani a wayarka. Duba *Kewayawa* a shafi na 12.

Don amfani da saita mayen

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Saita maye](#).
- 2 Zaɓi wani zaɓi.

Don duba bayani game da ayyuka

- Gungura zuwa aiki kuma zaɓi [Bayani](#), idan akwai. A wasu matsaloli, [Bayani](#) yana bayyana karkashin [Zabuka](#).

Don duba gwajin wayar

- Daga jiran aiki zaɓi [Menu](#) > [Nishaɗi](#) > [Zagawar Demo](#).

Don duba bayanin hali


- Daga jiran aiki latsa maɓallin kara sama.

Cajin baturi


An ɗanyi cajin baturin lokacin daka saya.

Don cajin baturin

1



2




- 1 Haɗa cajar zuwa wayar. Wannan yakan kusa ɗaukar awa 2.5 don cikakken cajin baturin. Latsa wani maɓalli don duba allon.
- 2 Cire cajar ta karkata fulogi sama.




Zaka iya amfani da wayarka lokacin da take caji. Zaka iya cajin baturi koda yausha kuma fiye da awa 2.5 ko kasa da haka. Zaka iya katse caji batara da bata baturin ba.

Siffar waya

- 1 Lasifikar kunni
- 2 Allo
- 3 Zabuɓɓukan tabawa
- 4 Maballin menu na kunnawa
- 5 Maballin kira
- 6 Maballin kewayya
- 7 Kamara kiran bidiyo
- 8 Kara kara, maballan zukowa na dijital
- 9 Maballin C (sharewa)
- 10 Maballin karewa
- 11 Maballin yanayin sauya kamara
- 12 Maballin kamara
- 13 Maballin kunnakashe kamara
- 14 Maballin shiru
- 15 Mai haɗawa don caji, abin sawa akunni da kebul na USB



- 16 Maballin kunna/kashe
- 17 Ruwan tabarau na kamara
- 18 Filasha



Siffar menu



PlayNow™+



Intanit*



Nishad!

Ayyukan kan layi*
Wasanni
TrackID™
VideoDJ™
PhotoDJ™
MusicDJ™
Ramut
Yi rikodin sauti
Zagawar Demo



Cyber-shot™



Sako

Rubuta sabuwa
Akwati.sak.m-shig.
Email
Yanar sadarwa. cyrw.
Tsararrun sakonni
Akwati.sak.mai fita
Sako da aka aika
Sakon da aka ajiye
Abokai nawa*
Kira sakon murya
Samfura
Shirya sako
Saituna

Mai jarida



Kararrawa



Lambobi

Ni kaina
Sabuwar lamba



Rediyo



Duk



An amsa



An buga



An rasa



Oganeza

Mai sarrafa fayil**
Aikace-aikace
Kiran bidiyo
Kalanda
Dawainiya
Bayanan kula
Aiki tare
Mai kidayar lokaci
Agogo.awon gudu
Kalkaleta
Memo na lamba



Gabadaya

Bayanan martaba
Loc. & kwn.wat.
Yare
Sabis na daukaka
Ikon murya
Sabuw.abun akuwa
Gajerun hanyoyi
Yanayin kaura
Tsaro
Saita maye
Bada hanya
Halin waya
Sake saitzuwa ainh.



Sauti & fadakarwa

Karar ringi
Sautin ringi
Yanayin shiru
Ringi mai karuwa
Fadakarwar jijjiga
Fadakarwar sako
Sautin maballi



Nuni

Fuskar bangan waya
Jigogi
Allon farawa
Mai boye allo
Girman agogo
Haske
Shirya sunayen layi*



Kira

Bugun kira na sauri
Bincike mai wayau
Karkatar da kira
Canja zuwa layi 2*
Sarrafa kira
Gamin bidiyo*
Lokaci & farashi*
Nun./boy.lamb.naw.
Abin sawa akunni



Haduwa*

Bluetooth
USB
Sunan waya
Hadin yana
Aiki tare
Masu sarrafa na'ura
Cibiyar sadarw.waya
Saitunan intanit
Saitunan yawo
Shirya sako*
Na'urorin hadi


* Wasu menu sun dogara ga afareta-, cibiyar yanar sadarwa- da saye.

** Zaka iya amfani da maballin kewayawa don gungurawa tsakanin shafuka a menu mataimaki. Don karin bayani, duba Kewayawa a shafi na 12.

Kewayawa

Ana nuna manyan menus azaman gumaka. Wasu menus mataimaka sun haɗa da shafuka.

Don kewayawa menus na wayar




- 1 Daga jiran aiki zaɓi **Menu**.
- 2 Yi amfani da maɓallin kewayawa don motsawa ta cikin menus.

Don gungurawa tsakanin shafukan

- Gungura zuwa shafi ta latsa maɓallin kewayawar haggi ko dama.

Don amfani da zaɓuɓɓukan taɓawa

Zaɓuɓɓukan taɓawa



- Zaɓi aikin da aka nuna a maɓallin allon ta latsa hagin, tsakiyar ko dama zaɓin taɓawa.

Don duba zaɓuɓɓuka don wani abu

- Zaɓi **Zaɓuka** don, misali, shiryawa.

Don komawa jiran aiki

- Latsa .


Don kare aiki

- Latsa .

Don kewayawa mai jaridarka

- 1 Daga jiran aiki zaɓi **Mai jarida**.
- 2 Yi amfani da maɓallin kewayawa don motsawa sama, kasa, hagu da dama ta cikin menus.





Don share abubuwa

- Latsa  don share abubuwa kamar lambobi, haruffa, hotuna da sautuna.




Gajerun hanyoyi

Zaka iya amfani da gajerun hanyoyin faifan maballi don zuwa kai tsaye ga menu. Lambar menu tana farawa daga gunkin hagu a sama kuma yana ketarawa sannan kasa layi-layi.

Don zuwa kai tsaye ga menu na ainihi

- Daga jiran aiki zaɓi **Menu** kuma latsa  – ,  ko .

Don amfani da gajerun hanyoyin maballin kewayawa

- Daga jiran aiki zaɓi ,  ko  don zuwa kai tsaye ga aiki.

Don shirya gajeriyar hanyar maballin kewayawa

- 1 Daga jiran aiki zaɓi **Menu > Saituna > Gaba daya** shafin > **Gajerun hanyoyi**.
- 2 Gungura zuwa wani zaɓi kuma zaɓi **Shirya**.
- 3 Gungura zuwa zaɓin menu kuma zaɓi **gajeriyar hanya**.

Menu na ayyuka

Menu na ayyuka yana baka dama mai sauri zuwa takamaiman ayyuka.

Don buɗe menu na ayyuka

- Latsa .

Shafukan menu na ayyuka

- **Sab.ab.auku** – kiran da aka rasa da sababbin sakonni.
- **Gudun apps** – aikace-aikace waɗanda suke gudana a bango.
- **Gajer.hanya nawa** – kara ayyukanka waɗanda kafi so don samun damarsu da sauri.
- **Intanit** – samun dama mai sauri zuwa **Intanit**.

Mai sarrafa fayil


Zaka iya amfani da mai sarrafa fayil don karɓar ajiyayyun fayiloli a kwakwalwar ajiyar wayar ko a katin kwakwalwar ajiyar.

- ! *Zaka iya sayan katin kwakwalwar ajiya daban.*

Katin kwakwalwar ajiya


Wayarka tana goyan bayan Memory Stick Micro™ (M2™) ko katin kwakwalwar ajiya na Micro SD™ yana kara karin sararin ma'aji zuwa wayarka. Hakanan za'a iya amfani da shi azaman katin kwakwalwar ajiya mai daukuwa tareda wasu na'urori masu jituwa.

Don saka katin kwakwalwar ajiya



- Buɗe murfin baturin. Saka Memory StickMicro™ (M2™) katin kwakwalwar ajiyar tareda lambobi masu launin zinare suna fuskantar sama ko saka MicroSD™ katin kwakwalwar ajiyar tareda lambobi masu launin zinare suna fuskantar kasa.

Don cire katin kwakwalwar ajiya



- Buɗe murfin baturin kuma latsa gefen katin kwakwalwar ajiyar don saki da cire shi.

Don duba zabubbukan katin kwakwalwar ajiya

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Mai sarrafa fayil](#) > [A katin kwakwalwar](#) shafin.
- 2 Zaɓi [Zabuka](#).

Karɓar fayiloli

Zaɓi iya motsa da kwafar fayiloli tsakanin wayarka, kwamfuta da katin kwakwalwar ajiya. Ana ajiye fayiloli a katin kwakwalwar ajiya da farko sannan a kwakwalwar ajiyar wayar. Ana ajiye fayilolin da ba'a gane su ba a [Wasu](#) babban fayil.

Zaka iya kirƙirar manyan fayiloli mataimaka don motsa da kwafe fayiloli gare su. Zaka iya zaɓar fiye da ɗaya ko duk fayiloli a babban fayil a lokaci ɗaya don duk manyan fayiloli banda [Wasanni](#) kuma [Aikace-aikace](#).

Idan kwakwalwar ajiya ta cika, share wasu abubuwan ciki don kirƙirar sarari.

Shafukan mai sarrafa fayil

Ana kasa mai sarrafa fayil zuwa shafuka uku, , kuma gumaka suna nuna inda aka ajiye fayilolin.

- **Duk fayiloli** – duk abubuwan ciki a kwakwalwar ajiyar wayar da kan katin kwakwalwar ajiya
- **Cikin waya** – duk abubuwan ciki a kwakwalwar ajiyar wayar
- **A katin kwakwalwar** – duk abubuwan ciki kan katin kwakwalwar ajiya

Don duba bayani game da fayiloli

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Mai sarrafa fayil](#).
- 2 Nemo fayil kuma zaɓi [Zabuka](#) > [Bayani](#).

Don motsa fayil a mai sarrafa fayil


- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Mai sarrafa fayil](#).
- 2 Nemo fayil kuma zaɓi [Zabuka](#) > [Sarrafa fayil](#) > [Matsar](#).
- 3 Zaɓi wani zaɓi.

Don zaɓar fayil fiye da ɗaya a babban

fayil

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Mai sarrafa fayil](#).
- 2 Gungura zuwa babban fayil kuma zaɓi [Buɗe](#).
- 3 zaɓi [Zabuka](#) > [Alama](#) > [Alama a yawanci](#).
- 4 Don kowane fayil dinda kake son yiwa alama, gungura zuwa fayil dɪn kuma zaɓi [Alama](#).

Don share fayil dɪn daga mai sarrafa fayil

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Mai sarrafa fayil](#).
- 2 Nemo fayil dɪn kuma latsa .


Yaren waya

Zaka iya zaɓr yare don amfani a wayarka.


Don canja yaren wayar

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Yare](#) > [Yaren waya](#).
- 2 Zaɓi wani zaɓi.


Shigar da rubutu

Zaka iya amfani da shigar darubutu na tabi dayawa ko T9™ Text Input  don shigar da rubutu. Hanyar T9 Text Input tana amfani da ginannen kamus na ciki.



Don canja hanyar shigar da rubutu

- Lokacin da kake shigar da rubutu latsa ka riƙe kasa .


Don motsawa tsakanin manya da kananan haruffa

- Lokacin da kake shigar da rubutu, latsa .



Don shigar da lambobi








- Lokacin da kake shigar da rubutu, latsa ka riƙe kasa  - .

Don shigar da aya da wakafi






- Lokacin da kake shigar da rubutu, latsa .

Don shigar da rubutu ta amfani da T9™ Text Input

- 1 Daga jiran aiki zaɓi, misali, [Menu](#) > [Sako](#) > [Rubuta sabuwa](#) > [Sakon rubutu](#).
- 2 Idan  ba'a nuna ba, latsa ka riƙe kasa  don canjawa zuwa T9 Text Input.

- 3 Latsa kowane maɓalli sau ɗaya, koda harafin da kake so ba shine farkon harafi a maɓallin ba. Misali, don rubuta kalmar “Jane”, latsa , , , . Rubuta duk kalmar kafin duban shawarwarin.
- 4 Yi amfani da  ko  don duba shawarwari.
- 5 Latsa  don karɓar shawara.

Don shigar da rubutu ta amfani da shigar da rubutu na tabi dayawa

- 1 Daga jiran aiki zaɓi, misali, [Menu](#) > [Sako](#) > [Rubuta sabuwa](#) > [Sakon rubutu](#).
- 2 Idan  an nuna, latsa ka riƙe kasa  don canja shigar da rubutu na tabi dayawa.
- 3 Latsa  -  akai-akai har sai harafin da ake so ya fito.
- 4 Lokacin da aka rubuta kalma, latsa  don kara sarari.

Don kara kalmomi zuwa ginannen kamus na ciki


- 1 Lokacin da ka shigar da rubutu ta amfani da T9 Text Input, zaɓi [Zabuka](#) > [Tad. bakin kalma](#).
- 2 Rubuta kalma ta amfani da shigarwar tabi dayawa [Sa](#).


Kira

Yin kira da karɓa



Kana buƙatar kunna wayarka da kasancewa cikin kewayon cibiyar sadarwa.

Don yin kira

- 1 Daga jiran aiki shigar da lambar waya (tareda lambar kasar waje da lambar yanki, in sun dace).
- 2 Latsa .
Duba *Kiran bidiyo* a shafi na 19.


 Zaka iya kiran lamba daga lambobinka da lissafin kira. Duba *Lambobi a shafi na 19*, da *Lissafin kira a shafi na 23*. Hakanan zaka iya amfani da muryarka don yin kira. Duba *Ikon murya a shafi na 23*.

Don yin kiran kasar waje

- 1 Daga jiran aiki latsa  alamar “+” ta bayyana.
- 2 Shigar da lambar kasa, lambar wuri (batara da sifilin farko ba) da lambar waya.
- 3 Latsa .

Don sake buga lamba

- Lokacin da [Sake jarrabawa?](#) ya bayyana **Ee**.

 Kar ka riƙe waya kusa da kunnenka lokacin da kake jira. Lokacin da kiran ya shiga, wayarka zata bada siginar kara.

Don amsa kira

- Latsa .



Don kin amsa kira

- Latsa .

Don canja karar lasifikaƙar kunni yayin kira


- Daga jiran aiki latsa maƙallin karar sama ko kasa.

Don cire muryaƙar makirufo yayin kira



- 1 Latsa ka riƙe kasa .
- 2 Latsa ka riƙe kasa  sake don ci gaba.

Don kunna lasifikaƙar yayin kira

- Zabi [Kun. Sp.](#)

 Kar ka riƙe wayarka ga kunnenka lokacin amfani da lasifika. Wannan zai iya lalata jinka.

Don duba kiran da aka rasa daga jiran aiki

- Latsa  kuma gungura zuwa [Sabuw. abun aukuwa](#) shafin kuma zaɓi lamba.
- Latsa  don buɗe lissafin kiran.

Cibiyoyin sadarwa

Wayarka tana canjawa ta atomatik

tsakanin cibiyoyin sadarwar GSM da 3G (UMTS) ya dogara da samuwa. Wasu afaretotin cibiyar sadarwa suna baka damar canja cibiyoyin sadarwa da hannu.

Don canja cibiyoyin sadarwa da hannu


- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Haduwa](#) shafin > [Cibiyar sadarw. waya](#) > [Cib.sadr.ta GSM/3G](#).
- 2 Zaɓi wani zaɓi.

Kiran gaggawa

Wayarka tana goyan bayan lambobin gaggawa na kasar waje, misali, 112 da 911. Za'a iya amfani da waɗannan lambobi koyausha don yin kiran gaggawa a kowace kasa, tare ko ba tareda saka katin SIM ba, idan cibiyar sadarwar 3G (UMTS) ko GSM tana cikin kewayo.

- ! A wasu *kasashe*, Ana haɓaka wasu lambobin gaggawa. Afaretan cibiyar sadarwarka maiyuwa don haka ya ajiye karin lambobin gaggawa na gida a katim SIM din.


Don yin kiran gaggawa

- Daga jiran aiki shigar da 112 (lambar gaggawa ta kasar waje) kuma latsa .

Don duba lambobinka na kiran gaggawa na cikin gida

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Gungura zuwa [Sabuwar lamba](#) kuma zaɓi [Zabuka](#) > [Lambobi na musam.](#) > [Lambobin gaggawa](#).



Kiran bidiyo

Duba mutum a allon yayin kira. Duk bangarorin biyu suna bukatar biyan kuɗi mai goyan bayan sabis na 3G (UMTS), kuma kana bukatar kasancewa tsakanin kewayon cibiyar sadarwar 3G (UMTS). Akwai sabis na 3G (UMTS) lokacin da  ya bayyana.

Don yin kiran bidiyo

- 1 Daga jiran aiki shigar da lambar waya (tareda lambar kasar waje da lambar yanki, in sun dace).
- 2 Zaɓi [Zabuka](#) > [Yi kiran bidiyo](#).

Don amfani da zukowa tareda kiran bidiyo mai fita

- Latsa  ko .

Don duba zaɓuɓɓukan kiran bidiyo

- Yayin kiran, zaɓi [Zabuka](#).

Lambobi

Zaka iya ajiye sunaye, lambobin waya da bayanin sirri a [Lambobi](#). Za'a iya ajiye bayani a kwakwalwar ajiyar wayar ko a katin SIM dɓin.

Tsofaffin lambobi

Zaka iya zaɓar wanne bayanin lamba aka nuna azaman tsoho. Idan [Lambobin waya](#) an zaɓa azaman tsoho, lambobinka suna nuna duk bayanin da aka ajiye a [Lambobi](#). Idan ka zaɓi [Lambobin SIM](#) azaman tsoho, lambobinka suna nuna sunaye da lambobin da aka ajiye a katin SIM dɓin.

Don zaɓar tsafaffin lambobi

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Gungura zuwa [Sabuwar lamba](#) kuma zaɓi [Zabuɓɓuka](#) > [Babba](#) > [Tsoffin lambobi](#).
- 3 Zabi wani zaɓi.

Lambobin waya


Lambobin waya zasu iya kunsar sunaye, lambobin waya da bayanin sirri. An ajiye su a kwakwalwar ajiyar wayar.




Don kara lambar waya

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Gungura zuwa [Sabuwar lamba](#) kuma zaɓi [Kara](#).
- 3 Shigar da sunan kuma zaɓi [Ok](#).
- 4 Shigar da lambar kuma zaɓi [Ok](#).
- 5 Zabi wani zaɓin lamba.
- 6 Gungura tsakanin shafuka kuma zaɓi filaye don kara bayani.
- 7 Zabi [Ajiye](#).


Lambobin kira

Don kiran lambar waya

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Gungura zuwa lamba kuma latsa .

 Don zuwa kai tsaye ga lamba, daga jiran aiki latsa ka riƙe kasa  - .

Don kiran lambar SIM daga lambobin waya

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Gungura zuwa [Sabuwar lamba](#) kuma zaɓi [Zabuɓɓuka](#) > [Lambobin SIM](#).
- 3 Gungura zuwa lamba kuma latsa .

Don kira tareda bincike mai waya

- 1 Daga jiran aiki latsa (1) – (9) don shigar sunan lamba ko lambar waya. Duk shigarwar da suka dace da jeren lambobi ko haruffa ana nunawa a lissafi.
- 2 Gungura zuwa lamba ko lambar waya kuma zaɓi ↶.

Don kunna ko kashe bincike mai waya

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Kira](#) shafin > [Bincike mai wayau](#).
- 2 Zaɓi wani zaɓi.

Shirya lambobi

Don kara bayani zuwa lambar waya

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Gungura zuwa lamba kuma zaɓi [Zabuka](#) > [Shirya lamba](#).
- 3 Gungura tsakanin shafukan kuma zaɓi [Kara](#).
- 4 Zaɓi wani zaɓi da wani abu don karawa.
- 5 Zaɓi [Ajiye](#).

💡 *Idan biyan kuɗinka yana goyan bayan sabis din Calling Line Identification (CLI), zaka iya raba kebabun sautunan ringi zuwa lambobi.*

Don kwafar sunaye da lambobi zuwa katin SIM

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Gungura zuwa [Sabuwar lamba](#) kuma zaɓi [Zabuɓɓuka](#) > [Na ci gaba](#) > [Kwafi zuwa SIM](#).
- 3 Zaɓi wani zaɓi.

Don ajiye sunaye da lambobin waya ta atomatik a kan katin SIM

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Gungura zuwa [Sabuwar lamba](#) kuma zaɓi [Zabuka](#) > [Babba](#) > [Kwafi zuwa SIM](#).
- 3 Zaɓi wani zaɓi.

Don ajiye lambobi a katin kwakwalwar ajiya

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Gungura zuwa [Sabuwar lamba](#) kuma zaɓi [Zabuka](#) > [Babba](#) > [Taimako ga katin kw](#).

Lambobin SIM

Lambobin SIM zasu iya kunsar sunaye da lambobi kawai. An ajiye su a katin SIM din.

Don kara lambar SIM

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Gungura zuwa [Sabuwar lamba](#) kuma zaɓi [Kara](#).
- 3 Shigar da sunan kuma zaɓi [Ok](#).
- 4 Shigar da lambar kuma zaɓi [Ok](#).
- 5 Zaɓi wani zaɓin lamba kuma kara karin bayani, idan akwai.
- 6 Zaɓi [Ajjiye](#).

! Lokacin da ka kwafe duk lambobi daga wayarka zuwa katin SIM dɪn, za'a maye gurbin duk bayanin da yake a katin SIM.

Don kiran lambar SIM

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Gungura zuwa lamba kuma latsa ↵.

Don kwafe sunaye da lambobi zuwa lambobin waya

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Gungura zuwa [Sabuwar lamba](#) kuma zaɓi [Zabuka](#) > [Babba](#) > [Kwafi daga SIM](#).
- 3 Zaɓi wani zaɓi.

Share lambobi

Don share lamba

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Gungura zuwa lamba kuma latsa (C).

Don share duk lambobin waya

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Gungura zuwa [Sabuwar lamba](#) kuma zaɓi [Zabuka](#) > [Babba](#) > > [Share duk lambobi](#).

Aika lambobi

Don aika lamba

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Gungura zuwa lamba kuma latsa [Zabuka](#) > [Aika lamba](#).
- 3 Zaɓi hanyar canja wuri.

! Tabbatar da na'urar da aka karɓa tana goya bayan hanyar canja wuri da ka zaɓa.

Halin kwakwalwar ajiya

Adadin lambobin da zaka iya ajiyewa a wayarka ko a katin SIM ya dogara da girman kwakwalwar ajiya.

Don duba halin kwakwalwar ajiya

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Gngura zuwa [Sabuwar lamba](#) kuma zaɓi [Zabuka](#) > [Babba](#) > [Halin kwkl. ajiya](#).

Lambobin aiki tare

Za'a iya haɗa lambobi aiki tare da Microsoft Exchange Server (Microsoft® Hangen nesa®). Don karin bayani duba *Aiki tare* a shafi na 59.

Ni kaina


Zaka iya shigar da bayani game da kanka da, misali, aika katin kasuwancinka.

Don shigar da bayanin kaina


- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Gungura zuwa [Ni kaina](#) kuma zaɓi [Buɗe](#).
- 3 Gungura zuwa wani zaɓi kuma shirya bayanin.
- 4 Zaɓi [Ajiye](#).

Don kara katin kasuwancinka

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Gungura zuwa [Ni kaina](#) kuma zaɓi [Buɗe](#).
- 3 Gungura zuwa [Bayanin lamba na](#) kuma zaɓi [Kara](#) > [Kirkiri sabo](#).
- 4 Gungura tsakanin shafuka kuma zaɓi filaye don kara bayani.
- 5 Shigar da bayanin kuma zaɓi [Ajiye](#).

 *Don shigar da alama zaɓi [Zabuka](#) > [Kara alama](#) > [Sa](#).*

Don aika katin kasuwancinka

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
 - 2 Gungura zuwa [Ni kaina](#) kuma zaɓi [Buɗe](#).
 - 3 Gungura zuwa [Bayanin lamba na](#) kuma zaɓi [Aika](#).
 - 4 Zaɓi hanyar canja wuri.
-  *Tabbatar da na'urar da aka karɓa tana goya bayan hanyar canja wuri da ka zaba.*

Kungiyoyi

Zaka iya kirkirar kungiyar lambobin waya da adireshin email daga [Lambobin waya](#) don aika sako zuwa. Duba *Sako* a shafi na 29. Zaka kuma iya amfani da kungiyoyi (tareda lambobin waya) lokacin da ka kirkiri karɓaɓɓen lissafin masu kira. Duba *Karɓar kira* a shafi na 27.

Don kirkirar kungiyar lambobi da adresoshin email



- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Gungura zuwa [Sabuwar lamba](#) kuma zaɓi [Zabuɓɓuka](#) > [Kungiyoyi](#).
- 3 Gungura zuwa [Sabuwara kungiya](#) kuma zaɓi [Kara](#).
- 4 Shigar da suna don kungiyar kuma zaɓi [Lamba](#).
- 5 Gungura zuwa [Sabo](#) kuma zaɓi [Kara](#).

- 6 Don kowacce lambar wayar sadarwa ko adireshin email dinda kake son yiwa alama, gungura zuwa gare shi kuma zaɓi [Alama](#).
- 7 Zaɓi [Lamba](#). > [Anyi](#).


Lissafin kira

Zaka iya duba bayani game da kiran kwanannan.


Don kiran lamba daga lissafin kiran

- 1 Daga jiran aiki latsa  kuma gungura zuwa shafi.
- 2 Gungura zuwa suna ko lamba kuma latsa .

Don kara lissafin lamba zuwa lambobi

- 1 Daga jiran aiki latsa  kuma gungura zuwa shafi.
- 2 Gungura zuwa lambar kuma zaɓi [Ajiye](#).
- 3 Zaɓi [Sabuwar lamba](#) don kirƙirar sabuwar lamba ko zaɓar lambar da ta kasance don kara lambar gareta.

Don share lissafin kiran

- 1 Daga jiran aiki latsa .
- 2 Gungura zuwa [Duk](#) shafin kuma zaɓi [Zabuka](#) > [Share duk](#).


Bugun kiran sauri

Bugun kiran sauri zai barka ka zaɓi lambobi tara waɗanda zaka iya bugawa da sauri. Za'a iya ajiye lambobin a wurare 1-9.

Don kara lambobi zuwa lambobin bugun kiran sauri

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Gungura zuwa [Sabuwar lamba](#) kuma zaɓi [Zabubbuka](#) > [Bugun kira na sauri](#).
- 3 Gungura zuwa lambar wuri kuma zaɓi [Kara](#).
- 4 Zaɓi lamba.

Don bugun kiran sauri

- Daga jiran aiki shigar da lambar wurin kuma latsa .



Sakon murya

Idan siyanka ya kunshi sabis dɪn amsawa, masu kira zasu iya barin sakon murya lokacin da bazaka iya amsa kira ba.

Don shigar da lambar sakon muryarka

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Saituna](#) > [Lambo](#). sakon murya.
- 2 Shigar da lambar kuma zaɓi [Ok](#).

Don kiran sabis dɪn sakon muryarka

- Daga jiran aiki latsa ka riƙe kasa 1.

Ikon murya

Ta kirkirar umarnin murya, zaka iya:

- Bugun murya – kira wasu ta hanyar kiran sunayensu
- Kunna bugun kiran murya ta faɗin “kalmar sihiri”
- Amsawa da kin amsa kira lokacin da kake amfani da abin sawa akunni

Don yin rikodin ikon murya ta amfani da bugun kiran murya

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Ikon murya](#) > [Bugun kiran murya](#) > [Kunna](#).
- 2 Zaɓi [Ee](#) > [Sabon umurnin mya](#). kuma zaɓi lamba. Idan lambar tana da lamba fiye da ɗaya, zaɓi lambar don kara umarnin murya gareta.
- 3 Yi rikodin umarnin murya kamar “John mobile”.
- 4 Bi umarnin da ya bayyana. Jira sautin kuma faɗi umarnin don yin rikodi. Za'a kunna maka umarnin muryar.
- 5 Idan rikodin yayi sauti OK, zaɓi [Ee](#). Idan baiba, zaɓi [A'a](#) kuma maimaita mataakai 3 da 4.

- ! Ana ajiye umarnin murya a kwakwalwar ajiyar wayar kawai. Ba za'a iya amfani da su a wata wayar ba.

Don sake-rikodin umarnin murya

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Ikon murya](#) > [Bugun kiran murya](#) > [Shirya sunaye](#).
- 2 Gungura zuwa umarni kuma zaɓi [Zabuka](#) > [Sauya murya](#).
- 3 Jira sautin kuma faɗi umarnin.

Bugun kiran murya

Zaka iya jin sunan lambarka da aka yi rikodi lokacin da ka karɓi kira daga wannan lambar.

Don bugun kiran murya

- 1 Daga jiran aiki latsa ka riƙe maɓallin kara kasa.
- 2 Jira sautin kuma faɗi sunan da aka yi rikodi, misali “John mobile”. Ana kunna maka sunan kuma an haɗa kiran.

Kalmar sihiri

Zaka iya yin rikodi da amfani da umarnin murya azaman kalmar sihiri don kunna bugun kiran murya ba tareda latsa kowane maɓalli ba. Dolene ka haɗa abin sawa akunni zuwa wayarka lokacin amfani da kalmar sihirin.

- ! Zaka zaɓar doguwa kalma, wacce ba safai ba ko yankin jumla wanda za'a iya rarrabeshi daga maganar bangon kamus. Abin sawa akunni na Bluetooth baya goyan bayan wannan fasalin.

Don kunna da yin rikodin kalmar sihirin

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Ikon murya](#) > [Kalmar sihiri](#) > [Kunna](#).
- 2 Bi umarnin da ya bayyana kuma zaɓi [Ci gaba](#). Jira sautin kuma faɗi kalmar sihirin
- 3 Zaɓi [Ee](#) don karɓa ko [A'a](#) don sabon rikodi.
- 4 Bi umarnin da ya bayyana kuma zaɓi [Lamba](#)
- 5 Zabi inda za'a kunna kalmar sihirinka.

Don yin kira ta amfani da kalmar sihirin

- 1 A jiran aiki tabbata 🗨️ yana ganuwa.
- 2 Faɗi kalmar sihirin.
- 3 Jira sautin kuma faɗi umarnin muryar.

Amsawar murya

Lokacin da kake amfani da abin sawa a kunni, zaka iya amsa ko kin amsa kira mai shigowa da muryarka.

Don kunna amsa murya da rikodin umarnin amsa murya

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Ikon murya](#) > [Amsawar murya](#) > [Kunna](#).
- 2 Bi umarnin da ya bayyana kuma zaɓi [Ci gaba](#). Jira sautin kuma faɗi "Amsa", ko wata kalma.
- 3 Zaɓi [Ee](#) don karɓa ko [A'a](#) don sabon rikodi.
- 4 Bi umarnin da ya bayyana kuma zaɓi [Ci gaba](#). Jira sautin kuma faɗi "akan aiki", ko wata kalma.
- 5 Zaɓi [Ee](#) don karɓa ko [A'a](#) don sabon rikodi.
- 6 Bi umarnin da ya bayyana kuma zaɓi [Ci gaba](#).
- 7 Zabi inda za'a kunna amsawar muryarka.

Don amsa kira ta amfani da umarnin murya

- Faɗi "Amsa".

Don kin amsa kira ta amfani da umarnin murya

- Faɗi "Akan aiki".



Karkata kira

Zaka iya karkata kira, misali, zuwa sabis ɗin amsawa.

- ! Lokacin da **Kuntata kira** aka yi amfani dashi, wasu zaɓuɓɓukan karkata kira basa samuwa. *Duba Kuntataccen bugun kira a shafi na 28.*

Zabuɓɓukan karkata kira

Tabbatattun zaɓuɓɓuka sune:

- **Karkatar koyaushu** – karkatar da duk kiranka
- **Idan ana kan aiki** – idan kira yana gudana
- **Ba za'a iya kaiw.ba** – idan wayarka tana kashe ko ba za'a iya samun ta ba
- **Babu amsa** – idan ba'a amsa kira a takamaiman lokaci ba

Don karkata kira

- 1 Daga jiran aiki zaɓi **Menu > Saituna > Kira** shafin > **Karkatar da kira**.
- 2 zaɓi nau'in kira da zaɓin karkatawa.
- 3 Zaɓi **Kunna**.
- 4 Shigar da lambar don karkata kira zuwa kuma zaɓi **Ok**.



Fiye da kira ɗaya

Zaka iya karɓar fiye da kira ɗaya lokaci guda. Misali, zaka iya sanya kira mai tafiya a rike, yayin da kake yi ko amsa kira na biyu. Zaka kuma iya canjawa tsakanin kira biyu. Ba zaka iya amsa kira na uku ba tareda gama ɗaya daga cikin kira biyun ba.


Jiran kira

Loacin da ake amfani da jiran kira, za ka ji kara idan ka karɓi kira na biyu.


Don kunna jiran kira

- Daga jiran aiki zaɓi **Menu > Saituna > Kira** shafin > **Sarrafa kira > Jiran kira > Kunna**.

Don yin kira na biyu

- 1 Yayin kiran, zaɓi **Zabuka > Rife**. Wannan yana sanya kira mai gudana arike.
- 2 Zaɓi **Zabuka > Kara kira**.
- 3 Shigar da lambar don kira kuma latsa .

Don amsa kira na biyu

- Yayin kiran, latsa . Wannan yana sanya kira mai gudana arike.

Don kin amsa kira na biyu

- Yayin kiran, latsa  kuma ci gaba da kira mai gudanar.

Don kare kira mai gudana da amsa kira na biyu

- Yayin kiran, zaɓi **Sauya kira mai aiki**.

Karɓar kiran murya biyu

Zaka iya samun kira mai gudana da kira arike lokaci guda.

Don canjawa tsakanin kira biyu.

- Yayin kiran, latsa 🏹.

Don haɗa kira biyu

- Yayin kiran, zaɓi [Zabuka](#) > [Haɗa kira](#).

Don haɗa kira biyu

- Yayin kiran, zaɓi [Zabuka](#) > [Canja wurin kira](#). An katse ka daga duk kiran biyu

Don kare kira mai gudana da ci gaba da kira na riƙe

- Da farko latsa 🏹 kuma sannan 🏹.

Karɓar kiran murya na uku

Ba zaka iya amsa kira na uku ba tareda kare ɗaya daga cikin kira biyun ba.



Kiran taro

Tareda kiran taro, zaka iya samun hirar da aka haɗa tareda kusan mutum biyar.

Don kara sabon ɗan takara

- 1 Yayin kiran, zaɓi [Zabuka](#) > [Riƙe](#). Wannan yana sanya kiran da aka haɗa ariƙe.
- 2 Zaɓi [Zabuka](#) > [Kara kira](#).
- 3 Shigar da lambar don kira kuma latsa 🏹.

- 4 Zaɓi [Zabuka](#) > [Haɗa kira](#) don kara sabon ɗan takara.
- 5 Maimaita wannan ɗawainiyar don kara karin yan takara.

Don saƙin ɗan takara

- 1 Zaɓi [Zabuka](#) > [Saki ɓangare](#).
- 2 Zaɓi ɗan takarar don saki.

Don yiɗin maganar sirri

- 1 Yayin kiran, zaɓi [Zabuka](#) > [Yi magana da](#) kuma zaɓi ɗan takarar don magana dashi.
- 2 Don ci gaba da kiran taron, zaɓi [Zabuka](#) > [Haɗa kira](#).

Lambobina

Zaka iya duba, kara da shirya lambobin wayarka.

Don bincika lambobin wayarka


- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Gungura zuwa [Sabuwar lamba](#) kuma zaɓi [Zaɓuɓɓuka](#) > [Lambobi na musam.](#) > [Lambobi nawa](#).
- 3 Zaɓi wani zaɓi.

Karɓar kira

Zaka iya zaɓar karɓar kira daga wasu takmaman lambobin waya kawai.

Don kara lambobi zuwa karɓabben lissafin masu kira

- 1 Daga jiran aiki zaɓi **Menu** > **Saituna** > **Kira** shafin > **Sarrafa kira** > **Karɓa kira** > **Daga lissafi kawai**.
- 2 Gungura zuwa **Sabo** kuma zaɓi **Kara**.
- 3 Gungura zuwa lamba ko zaɓi **Kungiyoyi**.

 *Duba Kungiyoyi a shafi na 22.*

Don karɓar duk kira

- Daga jiran aiki zaɓi **Menu** > **Saituna** > **Kira** shafin > **Sarrafa kira** > **Karɓa kira** > **Duk masu kira**.

Kuntataccen bugun kira

Zaka iya kuntata kira mai gudana da mai shigowa. Ana buƙatar kalmar wucewa daga mai baka sabis.

- ! *Idan ka karkatar da kira mai shigowa, bazaka iya amfani da zaɓuɓɓukan kuntata kira ba.*

Zaɓuɓɓukan kuntata kira

Tabbatattun zaɓuɓɓuka sune:

- **Duk mai fita** – duk kira masu fita
- **Mai fita waje** – duk kiran kasar waje masu fita
- **Mai fita yawon waje** – duk kiran kasar waje masu fita banda zuwa kasarka

- **Duk mai shigowa** – duk kira masu shigowa
- **Mai shig.in ana yawo.** – duk kira masu shigowa lokacin da kake kasar waje

Don kuntata kira

- 1 Daga jiran aiki zaɓi **Menu** > **Saituna** > **Kira** shafin > **Sarrafa kira** > **Kuntata kira**.
- 2 Zaɓi wani zaɓi.
- 3 Zaɓi **Kunna**.
- 4 Shigar da kalmar wucewarka kuma zaɓi **Ok**.

Kafaffen bugun kira

Kafaffen bugun kira yana bada damar yin kira zuwa takamaiman lambobin da aka ajiye a katin SIM kawai. An kare kafaffun lambobinka ta PIN2 dinka.

Za'a iya ajiye sashin lambobi. Misali, ajiye 0123456 yana bada damar kiran duk lambobin da suka fara da 0123456.

- ! *Lokacin da ake amfani da kafaffen bugun kira, ba zaka iya duba ko sarrafa ko wane lambobin waya da aka ajiye a katin SIM ba amma har yanzu zaka iya kiran lambar gaggawa ta kasar waje, 112.*

Don amfani da kafaffen bugun kira

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Gungura zuwa [Sabuwar lamba](#) kuma zaɓi [Zabuka](#) > [Lambobi na musam.](#) > [Kafaffen bugun kira](#) > [Kunna](#).
- 3 Shigar da PIN2 naka kuma zaɓi [Ok](#).
- 4 Zaɓi [Ok](#) sake don tabbatarwa.

Don ajiye kafaffiyar lamba

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Gungura zuwa [Sabuwar lamba](#) kuma zaɓi [Zabuka](#) > [Lambobi na musam.](#) > [Kafaffen bugun kira](#) > [Kafaffun lambobi](#) > [Sabuwar lamba](#).
- 3 Shigar da bayanin kuma zaɓi [Ajiye](#).



Lokacin kira da farashi

Yayin kira, ana nuna tsawon lokacin kiran. Zaka iya duba lokacin kiran karshe naka, kira masu fita da jimlar lokutan kiran naka.

Don duba lokacin kiran

- Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Kira shafin](#) > [Lokaci & farashi](#) > [Masu kiday.](#) lok. kira.

Sako

Karɓa da ajiye sakonni

Ana sanar da kai lokacin da ka karɓi sako. Ana ajiye sakonni ta atomatik a kwakwalwar ajiyar wayar. Lokacin da kwakwalwar ajiyar wayar ta cika, zaka iya share sakonni ko ajiye su a katin kwakwalwar ajiya ko a katin SIM dɪn.

Don ajiye sako a katin kwakwalwar ajiya

- Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Saituna](#) > [Gaba ɗaya](#) > [Ajiye a](#) > [Katin kwakwalwar](#).


Don ajiye sako a katin SIM

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) kuma zaɓi babban fayil.
- 2 Gungura zuwa sako kuma zaɓi [Zabuka](#) > [Cigaba da rubutu](#).

Don duba sako daga akwatin sako mai shiga

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Akwati.sak.m-shig](#).
- 2 Gungura zuwa sako kuma zaɓi [Duba](#).

Don share sako

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) kuma zaɓi babban fayil.
- 2 Gungura zuwa sakon kuma latsa .

Sakonnin rubutu

Sakonnin rubutu zasu iya taradda hotuna masu sauki, rinjayen sauti, rayarwa, da karin waka.

Kafin kayi amfani da sako

Dole ka sami lambar wurin sabis. Ana kawo lambar ta mai baka sabis kuma mafi yawa ana ajiye ta a katin SIM. Idan ba'a ajiye lambar wurin sabis dinka a katin SIM ba, dolene ka shigar da lambar da kanka.

Don shigar da lambar wurin sabis

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Saituna](#) > [Sakon rubutu](#) kuma gungura zuwa [Wurin sabis](#). Lambar zata fito idan an ajiye ta a katin SIM din.
- 2 Idan ba'a nuna wata lamba ba, zaɓi [Shirya](#).
- 3 Gungura zuwa [Sabuwar WurinSabis](#) kuma zaɓi [Kara](#).
- 4 Shigar da lambar tareda alamar kasar waje "+" da lambar kasa.
- 5 Zaɓi [Ajiye](#).


Don rubuta da aika sakon rubutu

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Rubuta sabuwa](#) > [Sakon rubutu](#).
 - 2 Rubuta sakon kuma zaɓi [Ci gaba](#) > [Duba lambobi](#).
 - 3 Zaɓi mai karɓa kuma zaɓi [Aika](#).
- ! *Idan ka aika sakon rubutu zuwa gungiya, za'a cajeka kan duk ɗan kungiya. Duba Kungiyoyi a shafi na 22.*

Don kara abu zuwa sakon rubutu

- 1 Lokacin da kake rubuta sakon, zaɓi [Zabuka](#) > [Kara abu](#).
- 2 Zaɓi wani zaɓi sannan wani abu.

Don kiran lamba a sakon rubutu

- Lokacin da kake rubuta sakon, gungura zuwa lambar wayar kuma latsa .

Sakonnin hoto

Sakonnin hoto zasu iya kunsar rubutu, hotuna, nunin faifai, rikodin sauti, shirye-shiryen bidiyo, sa hannu da haɗe-haɗe. Zaka iya aika sakonnin hoto zuwa wayar hannu ko adreshin email.

Kafin kayi amfani da sakon hoto

Dole ka saita baynin martaba na Intanit da adreshin uwar garken sakonka. Idan babu bayanin martaba na Intanit ko uwar garken sako zaka iya karɓar duk saituna ta atomatik daga afaretan cibiyar sadarwarka ko a www.sonyericsson.com/support.



Don zaɓar bayanin martabar MMS

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Saituna](#) > [Sakon hoto](#) > [Bay. martabar MMS](#).
- 2 Zaɓi bayanin martaba.

Don saita adreshin uwar garken sakon

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Saituna](#) > [Sakon hoto](#).
- 2 Gungura zuwa [Bay. martabar MMS](#) kuma zaɓi [Shirya](#).
- 3 Zaɓi [Zabuka](#) > [Shirya](#).
- 4 Gungura zuwa [Uwar garken sako](#) kuma zaɓi [Shirya](#).
- 5 Shigar da adireshe kuma zaɓi [Ok](#) > [Ajije](#).

Don kirƙira da aika sakon hoto

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Rubuta sabuwa](#) > [Sakon hoto](#).
- 2 Shigar da rubutu. Don ƙara abubuwa zuwa sakon, latsa  gungura  kuma zaɓi wani abu.
- 3 Zaɓi [Ci gaba](#) > [Duba lambobi](#).
- 4 Zaɓi mai karɓa kuma zaɓi [Aika](#).

Karɓar sakonnin hoto

Zaka iya zaɓar yadda za'a sauke sakonnin hotonka. Tabbatattun zaɓuɓɓuka lokacin da ka sauke sakonnin hoto sune:

- [Koyaushe](#) – saukewar atomatik.
- [Tambyana yawo](#) – tambayi don saukewa lokacin da ba cikin cibiyar sadarwar gida ba.
- [Ba'a cikin yawo ba](#) – kar a sauke lokacin da ba cikin cibiyar sadarwar gida ba.
- [Tambaya koyaushe](#) – tambayi don saukewa.
- [A kashe](#) – sababbin sakonni suna bayyana a [Akwati.sak.m-shig](#).

Don saita saukewar atomatik

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Saituna](#) > [Sakon hoto](#) > [Saukewa ta atomat](#).
- 2 Zaɓi wani zaɓi.

Don ajiye wani abu a sakon hoto

- Lokacin da ka duba sakon hoto zaɓi [Zabuka](#) > [Ajiye abubuwa](#) kuma zaɓi wani abu.

Don share sako

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) kuma zaɓi babban fayil.
- 2 Zaɓi sakon kuma latsa (C).

Zabuɓɓukan sako

Zaka iya saita tabbatattun zaɓuɓɓuka don duk sakonnin ko zaɓi takamaiman saituna duk lakacin da ka aika sako.

Don saita zaɓuɓɓukan sakon rubutu

- 1 Daga jirana aiki zaɓi [Menu](#) > [Sako](#) > [Saituna](#) > [Sakon rubutu](#).
- 2 Gungura zuwa wani zaɓi kuma zaɓi [Shirya](#).

Don saita zaɓuɓɓukan sakon hoto

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Saituna](#) > [Sakon hoto](#).
- 2 Gungura zuwa wani zaɓi kuma zaɓi [Shirya](#).

Don saita zaɓuɓɓukan sakon don takmaiman sako

- 1 Lokacin da aka shirya sakon kuma aka zaɓi mai karɓa, zaɓi [Zabuka](#) > [Babba](#).
- 2 Gungura zuwa wani zaɓi kuma zaɓi [Shirya](#).

Samfuri

Idan kana yawan amfani da yankin jumla iri daya da hotuna a sako, zaka iya ajiye sakon azaman samfuri.



Don kara samfuri sakon rubutu

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Samfura](#) > [Sabuwar samfuri](#) > [Rubutu](#).
- 2 Saka rubutu ko zaɓi [Zabuka](#) don kara abubuwa. Zaɓi [Ok](#).
- 3 Shigar da take kuma zaɓi [Ok](#).

Don amfani da samfurin sakon rubutu

- 1 Daga jiran aiki zabi [Menu](#) > [Sako](#) > [Samfura](#).
- 2 Gungura zuwa samfuri kuma zabi [Yi amfani](#).
- 3 Lokacin da aka shirya sakon, zabi [Ci gaba](#) > [Duba lambobi](#).
- 4 Zabi mai karɓa kuma zabi [Aika](#).

Don kara samfurin sakon rubutu

- 1 Daga jiran aiki zabi [Menu](#) > [Sako](#) > [Samfura](#) > [Sabuwar samfuri](#) > [Sakon hoto](#).
- 2 Shigar da rubutu. Don kara abubuwa zuwa sakon, latsa , gungura  kuma zabi wani abu.
- 3 Zabi [Ee](#), shigar da take kuma zabi [Ok](#).

Don ajiye sako azaman samfuri

- 1 Daga jiran aiki zabi [Menu](#) > [Sako](#) > [Akwati.sak.m-shig](#).
- 2 Gungura zuwa sakon kuma zabi [Zabuka](#) > [Ajiye azw. samfuri](#).



Sakonnin murya

Zaka iya aika da karɓar rikodin sauti azaman sakon murya.

- ! *Dolene mai aikawar da mai karɓar su zama suna da goyan bayan biyan kuɗin sakon hoto.*

Don yin rikodi da aika sakon murya

- 1 Daga jiran aiki zabi [Menu](#) > [Sako](#) > [Rubuta sabuwa](#) > [Sakon murya](#).
- 2 Yi rikodin sakon kuma zabi [Tsaida](#) > [Aika](#) > [Duba lambobi](#).
- 3 Zabi mai karɓa kuma zabi [Aika](#).



Email

Zaka iya amfani da tabbatattun ayyukan email da adreshin email din kwamfutarka a wayarka.

Kafin kayi amfani da email

Zaka iya amfani da saita mayen zuwa bincika idan akwai saituna donlissafin email dinka ko ka shigar dasu da hannu. Zaka kuma iya karɓar saituna a www.sonyericsson.com/support.

Don kirƙirar lissafin email

- 1 Daga jiran aiki zabi [Menu](#) > [Sako](#) > [Email](#) > [Lissafi](#).
- 2 Gungura zuwa [Sabon lissafi](#) kuma zabi [Kara](#).



Idan ka shigar da saituna da hannu, zaka iya tuntuɓar mai baka email don karin bayani. Mai bada email zai iya zama kamfanin da ya bada adreshin email dinka.

Don rubuta da aika sakon email

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Email](#) > [Rubuta sabuwa](#).
- 2 Zaɓi [Kara](#) > [Shigar.adiresh.email](#). Shigar da adireshin email kuma zaɓi [Ok](#).
- 3 Don shigar da karin masu karɓa, zaɓi [Shirya](#). Gungura zuwa wani zaɓi kuma zaɓi [Kara](#) > [Shigar.adiresh.email](#). Shigar da adireshin email kuma zaɓi [Ok](#). Lokacin da ka shirya, zaɓi [Anyi](#).
- 4 Gungura zuwa [Take](#):: Zaɓi [Ok](#) kuma shigar da take.
- 5 Gungura zuwa [Rubutu](#):: Zaɓi [Ok](#) kuma shigar da taken.
- 6 Gungura zuwa [Haɗe-haɗe](#):: Zaɓi [Kara](#) kuma zaɓi fayil don hadawa.
- 7 Zaɓi [Ci gaba](#) > [Aika](#).

Don karɓa da karanta sakon email

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Email](#) > [Akwati.sak.m-shig](#). > [Zabuka](#) > [Aika&rikd](#).
- 2 Gungura zuwa sakon kuma zaɓi [Duba](#).

Don ajiye sakon email

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Email](#) > [Akwati.sak.m-shig](#).
- 2 Gungura zuwa sakon kuma zaɓi [Zabuka](#) > [Ajiye safo](#).

Don amsa ga sakon email

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Email](#) > [Akwati.sak.m-shig](#).
- 2 Gungura zuwa sakon kuma zaɓi [Zabuka](#) > [Amsa](#).
- 3 Rubuta amsar kuma zaɓi [Ok](#).
- 4 Zaɓi [Ci gaba](#) > [Aika](#).

Don duba haɗe-haɗe a sakon email

- Lokacin da ka duba sakon, zaɓi [Zabuka](#) > [Haɗe-haɗe](#) > [Duba](#).

Don ajiye haɗe-haɗe a sakon email

- Lokacin da ka duba sakon, zaɓi [Zabuka](#) > [Haɗe-haɗe](#) > [Duba](#) > [Ajiye](#).

Email na aiki tare

Za'a iya haɗa email aiki tare da Microsoft Exchange Server (Microsoft® Hangen nesa®). Don karin bayani duba *Aiki tare* a shafi na 59.

Kunna lissafin email

Idan kana da lissafin email dayawa, zaka iya canja wanda yake aiki.

Don canja lissafin email mai aiki

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Email](#) > [Lissafi](#).
- 2 Zaɓi wani lissafi.

Don share email dɪn (POP3)

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Email](#) > [Akwati.sak.m-shig](#).
- 2 Gungura zuwa sakon kuma zaɓi [Zabuka](#) > [Alam.na sharewa](#).

- ! *Sakonnin da aka sawa alama za'a share su lokacin da ka sake hadawa zuwa uwar garkenka.*

Don share email dɪn (IMAP4)

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Email](#) > [Akwati.sak.m-shig](#).
- 2 Gungura zuwa sakon kuma zaɓi [Zabuka](#) > [Alam.na sharewa](#).
- 3 Zaɓi [Zabuka](#) > [Shar.akw.sk.m-shg](#).

- ! *Za'a share sakonnin da aka yiwa alama a wayar da kan uwar garken.*

Tura email

Zaka iya karɓar sanarwa a wayarka daga uwar garken email dɪnka cewa kasami sababbin sakonnin email.

Don kunna sanarwar tura email

- Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Email](#) > [Saituna](#) > [Samun email](#).

Abokaina

Zaka iya hadawa da shiga zuwa uwar garken Abokaina don sadarwar kan layi tareda sakonnin taɗi.

Kafin kayi amfani da Abokaina

Idan babu saituna a wayarka, kana bukatar shigar da saitunan uwar garke. Mai baka sabis zai iya bada tabbataccen bayanin saituna kamar:

- Sunan mai amfani
- Kalmar wucewa
- Adireshin uwar garke
- Bayanin martabar Intanin

Don shigar da saitunan uwar garken Abokaina

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Abokai nawa](#) > [Sanya](#).
- 2 Gungura zuwa saiti kuma zaɓi [Kara](#).

Don shiga cikin uwar garken Abokaina

- Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Abokai nawa](#) > [Shiga ciki](#).

Don fita daga uwar garken Abokaina

- Zaɓi [Zabuka](#) > [Fita daga yana](#).

Don kara lambar taɗi

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Abokai nawa](#) > [Lambobi](#) shafin.
- 2 Zaɓi [Zabuka](#) > [Kara lamba](#).

Don aika sakon taɗi

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Abokai nawa](#) > [Lambobi](#) shafin.
- 2 Gungura zuwa lamba kuma zaɓi [Taɗi](#).
- 3 Rubuta sakon kuma zaɓi [Aika](#).

Hali

Zaka iya nuna halika, misali, [Farin ciki](#) ko [Kan aiki](#), zuwa lambobinka kawai. Zaka kuma iya nuna halinka ga duk masu amfani a uwar garken Abokaina.

Don nuna halina

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Abokai nawa](#) > [Zabuka](#) > [Saituna](#) > [Nuna halin nawa](#).
- 2 Zaɓi wani zaɓi.

Don haɓaka halinka

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Abokai nawa](#) > [Hali nawa](#) shafin.
- 2 Shirya bayanin.

Kungiyar taɗi

Kungiyar taɗi zata iya farawa ta mai baka sabis, ta mai amfani na Abokaina mutum ɗaya ko ta kai kanka. Zaka iya ajiye kungiyoyin taɗi ta ajiye gayyatar taɗi ko ta bincika takamammiyar kungiyar taɗi.

Don kirƙirar kugiyar taɗi

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Abokai nawa](#) > [Kungiyoyin taɗi](#) shafin.
- 2 Zaɓi [Zabuka](#) > [K. taɗi](#) > [Sab. kungiyar taɗi](#).
- 3 Zaɓi wanda zaka gayyata daga lissafin lambobinka kuma zaɓi [Ci gaba](#).
- 4 Shigar da gajeran rubutun gayyata kuma zaɓi [Ci gaba](#) > [Aika](#).

Don kara kungiyar taɗi

- 1 Daga jirana iki zaɓi [Menu](#) > [Sako](#) > [Abokai nawa](#) > [Kungiyoyin taɗi](#) shafin > [Zabuka](#) > [K. taɗi](#).
- 2 Zaɓi wani zaɓi.

! *An ajiye tarihin magana tsakanin fita da lokacin da ka sake shiga don baka damar komawa zuwa sakonnin magana daga maganar da ta gabata.*

Don ajiye magana

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Abokai nawa](#) > [Taɗi](#) shafin.
- 2 Gungura zuwa magana kuma zaɓi [Zabuka](#) > [Babba](#) > [Aje magana](#).

Don duba ajiyayiyar magana

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Abokai nawa](#) > [Taɗi](#) shafin.
- 2 Zaɓi [Zabuka](#) > [Aje magana](#).



Bayanin wuri da salula

Bayanin wuri da salula sune sakonnin rubutu, misali, rahotonnin hanya na gida waɗanda aka aika zuwa masu biyan kuɗi tsakanin takamaiman wurin cibiyar sadarwa.

Don kunna bayanin wuri

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Saituna](#) > [Bayanin wuri](#).
- 2 Gungura zuwa [Yanayin aiki](#) kuma zaɓi [Shirya](#) > [Kunnawa](#).


Hoto

Kamara da mai rakodin bidiyo

Zaka iya daukar hotuna da rikodin shirye-shiryen bidiyo don gani, ajiyewa ko aikawa.

Kamara da mai rikodin bidiyo

- 1 Zuko ciki ko waje
- 2 Maƙallin yanayin sauya kamara
- 3 Don ɗaukar hotuna da shirye-shiryen bidiyo
- 4 Kunna kamara ko kashewa







Amfani da kamara


Don kunna kamarar

- Lokacin da aka kunna wayar, latsa .




Don daukar hoto

- 1 Kunna kamarar kuma yi amfani da  don zaɓar kamara. 
- 2 Latsa  kasa kaɗan don amfani da juyin mudubi na atomatik.
- 3 Lokacin da ɗigo da firam ɗin juyin mudubi suka yi kore, latsa kasa gaba ɗaya don ɗaukar hoto.
- 4 Ana ajiye hoton ta atomatik a katin kwakwalwar ajiyar.


 *Kar a kalli filashar Xe ɗin kamarar wayar kai tsaye ta amfani da na'urar karin girma. Gaza bada haɗin kai ga wannan gargadin zai iya lalata idanuwanka.*

 *Kar ayi rikodi da kakkarfan tushen haske a bangon. Saka abin tsakanin firam ɗin juyin mudubi. Yi amfani da goyan baya ko lokacin saitin don kawar da hoto mara kyau.*

Don rikodin shirin bidiyo

- 1 Kunna kamarar kuma yi amfani da  don zaɓar mai rikodin bidiyo. 
- 2 Latsa  kasa gaba ɗaya don fara rikodi.



Don tsayar da rikodi

- 1 Latsa .
- 2 Ana ajiye shirin bidiyon ta atomatik a katin kwakwalwar ajiyar.

Don amfani da zukowa

- Latsa maɓallan karar sama ko kasa.






Don daidaita haske

- Latsa  ko .



Samun kari daga kamarar

BestPic™ yana taimakonka kama ingantaccen lokaci. Zaka iya inganta hoton da bai fito ba da Photo fix.

Don amfani da BestPic™



- 1 Kunna kamarar kuma yi amfani da  don zaɓar kamara.
- 2 Zaɓi  > Yanayin dauka > BestPic™.
- 3 Latsa  kasa kaɗan don amfani da juyin mudubi.
- 4 Lokacin da ɗigo da firam ɗin juyin mudubi suke yi kore, latsa kasa gaba ɗaya don gama ɗauka.
- 5 Zaɓi [Ajiy duk](#) ko latsa  ko  don zaɓar hoton mafi kyau kuma zaɓi [Ajiye](#).

Don inganta hoto da Photo fix

- 1 Kunna kamarar kuma yi amfani da  don zaɓar kamara.
- 2 Zaɓi  > Saituna.
- 3 Tabɓatar **Dubawa** an saita zuwa **Kunnawa**.
- 4 Dauki hoto.
- 5 Yayin dubawa, zaɓi **Zabuka** > **Gyara hoto**.


Don duba hotuna da shirye-shiryen bidiyo



- 1 Kunna kamarar kuma yi amfani da  don zaɓar dubawa.
- 2 Gungura zuwa abun.
- 3 Latsa  don duba shirin bidiyo.

Gumakan kamara da saituna

Gumakan kan allon suna bayanin menene sabon saiti. Akwai karin saitunan kamara a [Saituna](#).

 Yi amfani da abokin hoto don koyo game da ayyukan kamara. Abokin hoto shine hulɗar koyarwa, wanda aka haɗa a wayarka.

Gunki


Sifantawa



[Yanayin dauka](#)



[Mahalli](#). Ayyanannun saituna don halayen hotuna gama gari



[Girman hoto](#)



[Dubu](#)



[Filasha](#)



[Mai kidayar lokaci](#)



[ISO](#). Tasirin hasken kamarar



[Ynayin. awon mita](#)



[Ma'aunin launi](#). Don daidaita sautunan launi zuwa yanayin hasken






[Girman bidiyo](#). Don sakonnin hoto, an iyakance girman



[Bidiyo: rikodi](#)




[Zukowa](#)

	Juyin mudubi ta atomatik
	firam ɗin juyin mudubi
300+	Kamara: ragowar hotuna
	Filasha tana caji

Don canja saituna

- Kunna kamarar kuma zaɓi .


Don duba bayani game da saituna

- Gungura zuwa saiti kuma zaɓi .


Gajerun hanyoyin kamara


Maballi Gajeriyar hanya

 Kamara: [Yanayin dauka](#)
Bidiyo: [Girman bidiyo](#)

 Kamara: [Mahalli](#)
Bidiyo: [Yanayin dare](#)

 [Mai kidayar lokaci](#)

 Jagorar maɓallin kamara

 Kamara: [Filasha](#)
Bidiyo: [Wtr. hoton AF](#)

Canja wurin hotuna

Canja wuri zuwa kuma daga kwamfutarka

Zaka iya amfani da fasaha mara waya ta Bluetooth™ da kebul ɗin USB don canja wurin hotuna da shirye-shiryen bidiyo tsakanin kwamfutarka da waya. Duba *Fasaha mara waya ta Bluetooth™* a shafi na 55 da *Amfani da kebul ɗin USB* a shafi na 54 don karin bayani.

Zaka iya duba, haɓaka da shirya hotunanka da shirye-shiryen bidiyo a kwamfutarka ta shigar da *Adobe™ Photoshop™ Album Starter Edition* ko *Mai sarrafa Mai jarida na Sony Ericsson*. An hada waɗannan a CD ɗinda yazo tareda wayarka kuma akwai don saukewa a www.sonyericsson.com/support.

Shafin hoto

Shafin hoto shine keɓaɓɓen ɗakin yanar sadarwa. Idan biyan kuɗinka yana goyan bayan wannan sabis, zaka iya aika hotuna zuwa shafi.

- ! *Maiyuwa sabis ɗin yanar sadarwa ya bukaci wararriyar yarjejeniyar lasisi tsakaninka da mai bada sabis. Maiyuwa ya shafi karin dokoki da/ko kuɗi. Tuntubi mai baka sabis.*

Don aika hotunan kamara zuwa shafi

- 1 Daga jiran aiki zaɓi [Mai jarida](#) kuma gungura zuwa [Hoto](#) > [Kundin kyamera](#).
- 2 Gungura zuwa wata da hoto. Zaɓi [Duba](#).
- 3 Zaɓi [Zabuka](#) > [Aika](#) > [Zuwa blog](#).
- 4 Kara take da rubutu.
- 5 Zaɓi [Ok](#) > [Yafa](#).

Don zuwa adireshin shafi daga lambobi

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Gungura zuwa lamba kuma zaɓi adireshin yanar sadarwa.
- 3 Zaɓi [Je zuwa](#).

Don aika hoto ko shirin bidiyo

- 1 Daga jiran aiki zaɓi [Mai jarida](#).
- 2 Gungura zuwa wani abu kuma zaɓi [Zabuka](#) > [Aika](#).
- 3 Zaɓi hanyar canja wuri.

- ! *Tabbatar da na'urar da aka karɓa tana goya bayan hanyar canja wuri da ka zaɓa.*

Don karɓar hoto ko shirin bidiyo

- Bi umarnin daya bayyana.

Fitarwar kamara

Zaka iya fitar da hotunan kamara ta amfani da kebul dɪn USB wanda aka haɗa zuwa firinta mai dacewa.



Zaka kuma iya fitarwa ta amfani da firinta mai dacewa ta Bluetooth.

Don fitar da hotunan kamara ta amfani da kebul dɪn USB

- 1 Daga jiran aiki zaɓi [Mai jarida](#) kuma gungura zuwa [Hoto](#) > [Kundin kyamera](#).
- 2 Gungura zuwa wata da hoto.
- 3 Zaɓi [Zabuka](#) > [Fitar](#).
- 4 Zaɓi wani zaɓi.
- 5 Haɗa kebul dɪn USB zuwa wayar.
- 6 Haɗa kebul dɪn USB zuwa firintar.
- 7 Jira bayani a wayar kuma zaɓi [Ok](#).
- 8 Shigar da saitunan firinta, idan an buƙata kuma zaɓi [Fitar](#).



Cire haɗin kebul dɪn USB ka sake haɗawa idan akwai kuskuren firinta.

Hotuna

Zaka iya duba, kara, shirya ko share hotuna a [Mai jarida](#).

Amfani da hotuna

Zaka iya kara hoto zuwa lamba, yiamfani da shi yayin fara waya, azaman fuskar bangon waya a jiran aiki ko azaman uwar garken allo.

Don amfani da hotuna

- 1 Daga jiran aiki zaɓi [Mai jarida](#) kuma gungura zuwa [Hoto](#) > [Kundin kyamera](#).
- 2 Gungura zuwa wata da hoto. Zaɓi [Duba](#).
- 3 Zaɓi [Zabuka](#) > [Yi amfani azaman](#).
- 4 Zaɓi wani zaɓi.




Don nuna hotuna a nunin faifai

- 1 Daga jiran aiki zaɓi [Mai jarida](#) kuma gungura zuwa [Hoto](#) > [Kundin kyamera](#).
- 2 Gungura zuwa wata da hoto. Zaɓi [Duba](#).
- 3 Zaɓi [Zabuka](#) > [Nunin faifai](#).
- 4 Zaɓi yanayi.


Shafukan hoto

Zaka iya sawa hotuna shafi don bambance su.

Don sawa hotuna shafi

- 1 Daga jiran aiki zaɓi [Mai jarida](#) kuma gungura zuwa [Hoto](#) > [Kundin kyamera](#).
- 2 Gungura zuwa wata da hoto. Zaɓi [Duba](#).
- 3 Latsa  kuma gungura zuwa shafi.
- 4 Latsa tsakiyar zaɓin taɓawa.
- 5 Don kowane hoton da kake son sawa shafi, yi amfani da  ko  don gungurawa zuwa hoton kuma latsa tsakiyar zaɓin taɓawa.

Don kirkirar sabon shafin hoto

- 1 Daga jiran aiki zaɓi [Mai jarida](#) kuma gungura zuwa [Hoto](#) > [Kundin kyamera](#).
- 2 Gungura zuwa wata da hoto. Zaɓi [Duba](#).
- 3 Latsa  kuma zaɓi [Zabuka](#) > [Sabuwar alama](#).
- 4 Shigar da suna kuma zaɓi [Ok](#).
- 5 Zaɓi gunki.
- 6 Latsa tsakiyar zaɓin taɓawa don sawa hoton shafi.

PhotoDJ™ da VideoDJ™

Zaka iya shirya hotuna da shiryeshiryen bidiyo.

Don shiyawa da ajiye hoto

- 1 Daga jiran aiki zaɓi [Mai jarida](#) kuma gungura zuwa [Hoto](#) > [Kundin kyamera](#).
- 2 Gungura zuwa wata da hoto. Zaɓi [Dubu](#).
- 3 Zaɓi [Zabuka](#) > [Shiry.a PhotoDJ™](#).
- 4 Shirya hoton.
- 5 Zaɓi [Zabuka](#) > [Ajiye](#).

Don shiryawa da ajiye shirin bidiyo

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Mai sarrafa fayil](#) > [Bidiyo](#).
- 2 Gungura zuwa shirin bidiyo kuma zaɓi [Bude](#) > [Zabuka](#) > [VideoDJ™](#).
- 3 Shirya shirin bidiyon.
- 4 Zaɓi [Zabuka](#) > [Ajiye](#).

Don gyara shirin bidiyo

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Mai sarrafa fayil](#) > [Bidiyo](#).
- 2 Gungura zuwa shirin bidiyo kuma zaɓi [Bude](#) > [Zabuka](#) > [VideoDJ™](#) > [Shirya](#) > [Gyara](#).

- 3 Zaɓi [Saiti](#) don saita wurin farawa kuma zaɓi [Fara](#).
- 4 Zaɓi [Saiti](#) don saita wurin gamawa kuma zaɓi [Kare](#).
- 5 Zaɓi [Gyara](#) > [Ajiye](#).

Jigogi

Zaka iya canja bayyanar allon ta abubuwa kamar launuka da fuskar bangan waya. Zaka kuma iya kirkirar sababbin jigogi da saukar da su. Don karin bayani, je zuwa www.sonyericsson.com/support.

Don saita jigo

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Mai sarrafa fayil](#).
- 2 Gungura zuwa [Jigogi](#) kuma zaɓi [Bude](#).
- 3 Gungura zuwa jigo kuma zaɓi [Saiti](#).

Nishaɗi

- 💡 *Don kewayawa mai jaridarka duba Kewayawa a shafi na 12.*

Abin sawa akunni mai ɗaukuwa na siteriyo



Don amfani da abin sawa akunni

- Haɗa abin sawar akunni mai ɗaukuwa. Kiɗa yana tsayawa lokacin da ka karɓi kira kuma yana ci gaba lokacin da kiran ya kare.

Kiɗa da masu kunna bidiyo

Don kunna kiɗa

- 1 Daga jiran aiki zaɓi **Mai jarida** kuma gungura zuwa **Kiɗa**.
- 2 Gungura zuwa take kuma zaɓi **Kunna**.

Don kunna bidiyo

- 1 Daga jiran aiki zaɓi **Mai jarida** kuma gungura zuwa **Bidiyo**.
- 2 Gungura zuwa take kuma zaɓi **Kunna**.

Ikon kiɗa da bidiyo

Don tsaida kunna kiɗa

- Latsa tsakiyar zaɓin tabawa.



Don ci gaba da kunna kiɗa

- Latsa zaɓin tsakiyar tabawa.



Don canja karar

- Lokacin da kake sauraren kiɗa, latsa maballan karar sama ko kasa.

Don matsawa tsakanin wakoi

- Lokacin da kake sauraren kiɗa, latsa  ko .

Don sauri gaba da baya

- Lokacin da kake sauraren kiɗa, latsa ka riƙe kasa  ko .

Don komawa zuwa menus ɗin mai kunnawa

- Zaɓi **Baya**.

Don komawa zuwa masu kunnawa

- Zaɓi **Zabuka** > **Dawowa**.

Don fita menus ɗin mai kunnawa

- Latsa ka riƙe kasa .

Don aika kida

- 1 Daga jiran aiki zabi **Mai jarida** kuma gungura zuwa **Kida**.
- 2 Gungura zuwa take kuma zabi **Zabuka > Aika**.
- 3 Zabi hanyar canja wuri.

! *Tabbatar da na'urar da aka karɓa tana goya bayan hanyar canja wuri da ka zaba.*

Don karɓar kida

- Bi umarnin daya bayyana.

Canja wurin kida daga kwamfuta

Tareda **Mai sarrafa Mai jarida** na *Sony Ericsson*, ahade a CD tareda wayarka, zaka iya canja wurin kida daga CDs, kwafutarka ko kuma ka saya zuwa kwakwalwar ajiyar wayar ko katin kwakwalwar ajiya.

💡 *Akwai kuma software na **Mai sarrafa Mai jarida** na *Sony Ericsson* don saukewa a www.sonyericsson.com/support.*

Kafin kayi amfani da Mai sarrafa Mai jarida

Kana bukatar dayan waɗannan tsarukan aikin don amfani da *Mai sarrafa Mai jarida* a kwafutarka:

- Windows Vista™ (32 kafan da 64 yar sigar: Na karshe, Tafiyar da abu, Kasuwanci, Gida, Kudɓin inshora, Tushan Gida)
- Windows XP (Pro ko Home)

Don shigar da Mai sarrafa Mai jarida

- 1 Kunna kwamfutarka kuma saka CD dɓin. CD zai fara ta atomatik kuma window dɓin shigarwa zai buɗe.
- 2 Zabi yare kuma kada Yayi.
- 3 Kada *Shigar da Mai sarrafa Mai jarida* na *Sony Ericsson* kuma bi umarnin.

Don amfani da Mai sarrafa Mai jarida

- 1 Hada wayar zuwa kwamfuta da kebul dɓin USB wanda yazo tareda wayar.
- 2 **Kwamfuta:** *Farawa/Tsare-tsare/Sony Ericsson/Mai sarrafa Mai jarida*.
- 3 **Waya:** Duba **Aje kayyayaki > Menu > Saituna > Haɗuwa** shafin **> USB > Yanayin USB > Aje kayyayaki**.
Wayar zata mutu a wannan yanayin amma zata sake kunnuwa lokacin da aka cire haɗinta da kebul dɓin USB.

! *Kar ka cire kebul na USB dɪn daga wayarka ko kwamfuta yayin canja wurin, saboda wannan zai iya lalata katin kwakwalwar ajiyar ko kwakwalwar ajiyar wayar.*

4 Don amintaccen cire haɗin kebul dɪn USB a dɪnbin yanayin ma'aaji, kada-daman gunkin disk mai curuwa a *Windows Explorer* kuma zaɓi *Cire*. Duba *Ta amfani da kebul dɪn USB* a shafi na 57.

Don cikakkun bayanai kan canja wurin kiɗa, koma zuwa *Taimakon Mai sarrafa Mai jarida*. Kada (?) a saman kusurwar dama na *Mai sarrafa Mai jarida* window.

Fayilolin lilo

An ajiye fayilolin kiɗa da bidiyo kuma an rarraba su.

- **Yan wasa** – lissafa wakokin da ka canjawa wuri ta amfani da *Mai sarrafa Mai jarida*.
- **Kundaye** – lissafa wakokin kiɗa ta kundi a wayarka da kan katin kwakwalwar ajiya.
- **Wakoki** – lissafa duk wakokin kiɗa a wayarka da kan katin kwakwalwar ajiya.
- **Littafin kaset** – lissafa littattafan abubuwa masu jiwuwa da ka canjawa wuri daga kwamfutarka.

- **Kwasfar hask** – lissafa duk fayilolin kiɗa da ka canjawa wuri daga kwamfutarka.
- **Lissafin waka** – kirkiri lissafin wakokin mallaka.
- **Bidiyo** – lissafin duk shirye-shiryen bidiyo a wayarka ko kan katin kwakwalwar ajiya.

Lissafin waka

Zaka iya kirkirar lissafin waka don shirya fayiloli. Zaka iya tsara fayilolin ta dan wasa ko take. Za'a iya kara fayiloli zuwa lissafin waka fiye da ɗaya.

Share lissafin waka, ko fayil daga lissafin waka, baya share fayil daga kwakwalwar ajiyar, sai dai makoma fayil dɪn.

Don kirkirar lissafin waka

- 1 Daga jiran aiki zaɓi *Mai jarida* kuma gungura zuwa *Kiɗa* > *Lissafin waka*.
- 2 Gungura zuwa *Sabon lissafin waka* kuma zaɓi *Kara*.
- 3 Shigar da suna kuma zaɓi *Ok*.
- 4 Gungura zuwa waka kuma zaɓi *Alama*.
- 5 Zaɓi *Kara* don kara wakar zuwa lissafin wakar.

Don kara fayiloli zuwa lissafin waka

- 1 Daga jiran aiki zaɓi [Mai jarida](#) kuma gungura zuwa [Kida](#) > [Lissafin waka](#).
- 2 Gungura zuwa lissafin wakar kuma zaɓi [Buɗe](#).
- 3 Zaɓi [Zabuka](#) > [Kara mai jarida](#).
- 4 Gungura zuwa waka kuma zaɓi [Alama](#).
- 5 Zaɓi [Kara](#) don kara wakar zuwa lissafin wakar.

Don cire fayiloli daga lissafin waka

- 1 Daga jiran aiki zaɓi [Mai jarida](#) kuma gungura zuwa [Kida](#) > [Lissafin waka](#).
- 2 Gungura zuwa lissafin waka kuma zaɓi [Buɗe](#).
- 3 Gungura zuwa lissafin wakar kuma latsa [C](#).

Don share lissafin waka

- 1 Daga jiran aiki zaɓi [Mai jarida](#) kuma gungura zuwa [Kida](#) > [Lissafin waka](#).
- 2 Gungura zuwa lissafin waka kuma latsa [C](#).

Don duba bayani game da waka

- Gungura zuwa lissafin waka kuma zaɓi [Zabuka](#) > [Bayani](#).

Kidan kan layi da shirye-shiryen bidiyo

Zaka iya duba shirye-shiryen bidiyo da sauraron kida ta gudanar dasu zuwa wayarka daga Intanit. Idan saituna basa shirye a wayarka, duba *Saituna* a shafi na 53. Don karin bayani, tuntuɓi afaretan cibiyar sadarwarka ko jeka zuwa www.sonyericsson.com/support.

Don zaɓar lissafin bayanai don jerin gwano

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Haɗuwa](#) shafin > [Saitunan yawo](#).
- 2 Zaɓi lissafin bayanai don amfani.

Don jera kida da shirye-shiryen bidiyo

- 1 Daga jiran aiki zaɓi [Menu](#) > [Intanit](#).
- 2 Zaɓi > [Zabuka](#) > [Je zuwa](#) > [Alamomin shafi](#).
- 3 Zaɓi hanyar haɗfi don yin jere daga.

TrackID™

TrackID™ karɓaɓɓen sabis dɪn kida ne kyauta. Bincika taken waƙoƙi, yaƙ wasa da sunayen kundi.

Don bincika bayanin waka

- Lokacin da kake jin waka ta cikin lasifika, daga jiran aiki zaɓi [Menu](#) > [Nishadi](#) > [TrackID™](#).
- Lokacin da rediyo take akunne zaɓi [Zabuka](#) > [TrackID™](#).

Rediyo

- ! *Kada kayi amfani da wayarka azaman rediyo a wuraren da aka hana.*

Don sauraron rediyo

- 1 Haɗa abin sawa akunni zuwa waya.
- 2 Daga jiran aiki zaɓi [Menu](#) > [Rediyo](#).



Don canja karar

- Lokacin da rediyo take akunne, latsa maɓallan kara sama ko kasa.



Don bincika tashoshin rediyo ta atomatik

- Lokacin da rediyon take akunne, zaɓi [Bincika](#).

Don bincika tashoshin rediyo da hannu

- Lokacin da rediyo take akunne, latsa  ko .

Don canjawa tsakanin saitattun tashoshi

- Lokacin da rediyo take akunne, latsa  ko .

Ajiye tashoshin rediyo

Zaka iya ajiye har zuwa tashoshi 20 da aka saita.



Don ajiye tashoshin rediyo

- Lokacin da ka samo tashar rediyo zaɓi [Zabuka](#) > [Ajiye](#).



Don zaɓar ajiyayyun tashoshin

- 1 Daga jiran aiki zaɓi [Menu](#) > [Rediyo](#) > [Zabuka](#) > [Tashoshi](#).
- 2 Zaɓi tashar rediyo.

Don ajiye tashoshi a wurare 1 zuwa 10

- Lokacin da ka samo tashar rediyo, latsa ka riƙe kasa  - .

Don zaɓar ajiyayyun tashoshi a wurare 1 zuwa 10

- Lokacin da rediyo take akunne, latsa  - .



PlayNow™

Zaka iya sauraron kiɗa kafin ka siya da sauke shi zuwa wayarka.

- ! *Babu wannan sabis ɗin a duk kasashe. A wasu kasashe zaka iya siyan kiɗa daga wasu manyan yan wasan kiɗa na duniya.*

Kafin kayi amfani da PlayNow™

Dolene ya zama kana da saitunan da ake bukata a wayarka. Duba *Saituna* a shafi na 53.

Don sauraron kiɗan PlayNow™

- 1 Daga jiran aiki zaɓi [Menu](#) > [PlayNow™](#).
- 2 Zaɓi kiɗa daga lissafi.

Saukewa daga PlayNow™

Farashin yana bayyana lokacin da ka zaɓi saukewa da ajiye fayil ɗin kiɗa. Ana bashin lissafin wayarka ko katin kuɗin da aka biya lokacin da aka karɓi saye.

Don sauke fayil ɗin kiɗa

Lokacin da ka saurari samfotin fayil ɗin kiɗa, zaka iya yarda da karɓar sharuɗɗan.



- 1 Zaɓi [Ee](#) don saukewa.
- 2 Ana aika sakon rubutu don tabbatar da biya kuma akwai fayil da akayi don saukewa.

Sautunan ringi da karin waka



Don saita sautunan ringi

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Sauti & faɗakarwa](#) shafin > [Sautin ringi](#).
- 2 Nemo kuma zaɓi sautin ringi.

Don saita karar sautin ringi

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Sauti & faɗakarwa](#) shafin > [Karar ringi](#).
- 2 Latsa  ko  don canja karar.
- 3 Zaɓi [Ajiye](#).

Don kashe sautin ringi

- Daga jiran aiki latsa ka rike kasa ( ).
- ! Ana rinjayar duk siginino banda siginar kararrawa.

Don saita faɗakarwar girgiza

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Sauti & faɗakarwa](#) shafin > [Faɗakarwar jijjiga](#).
- 2 Zaɓi wani zaɓi.

Don aika sautin ringi

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Mai sarrafa fayil](#).
- 2 Gungura zuwa [Kida](#) kuma zaɓi [Buɗe](#).
- 3 Gungura zuwa sautin ringi kuma zaɓi [Zabuka](#) > [Aika](#).
- 4 Zaɓi hanyar canja wuri.

! *Tabbatar da na'urar da aka karɓa tana goya bayan hanyar canja wuri da ka zaɓa.*

Don karɓar sautin ringi

- Bi umarnin daya bayyana.

! *Ba'a baka damar sauya kayan aiki mai kiriyar hakkin mallaka ba. Fayil dinda aka kare yana da 🗑️ gunku.*

MusicDJ™

Zaka iya tsara da shirya karin wakarka don amfani azaman sautunan ringi. Karin waka ya kunshi nau'ukan wakoki huɗu – [Ganga](#), [Basses](#), [Chords](#), kuma [Launin harshe](#). Waka tana ɗauke da adadin tubalan kida. Tubala suna tattare da shiryayyun sautuna tareda kalmomi daban-daban. An tattara tubalan cikin [Gabatarwa](#), [Aya](#), [Chorus](#), kuma [Hutu](#). Zaka iya shirya karin waka ta kara tubalan kida zuwa wakokinka.

Don shirya karin waka

- 1 Daga jiran aiki zaɓi [Menu](#) > [Nishadi](#) > [MusicDJ™](#).
- 2 Zaɓi zuwa [Sa](#), [Kwafi](#) ko [Manna](#) tubala.
- 3 Yi amfani da 🗑️, 📁, 📄 or 📄 don gungurawa tsakanin tubalan.
- 4 Zaɓi [Zabuka](#) > [Ajiye launin waka](#).

Don aika karin waka

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Mai sarrafa fayil](#).
- 2 Gungura zuwa [Kida](#) kuma zaɓi [Buɗe](#).
- 3 Nemo karin waka kuma zaɓi [Zabuka](#) > [Aika](#).
- 4 Zaɓi hanyar canja wuri.

! *Tabbatar da na'urar da aka karɓa tana goyan bayan hanyar canja wuri da ka zaɓa.*

Don karɓar karin waka

- Bi umarnin daya bayyana.

! *Baza ka iya aika sautunan karin waka ko fayil din MP3 a sakon rubutu ba.*

Mai rikodin sauti

Zaka iya rikodin memo na murya ko kira. Hakanan za'a iya saita sautunan da akayi rikodi azaman sautunan ringi.

! *A wasu kasashe ko jahohi doka ta bukaci sanar da mutum kafin ɗaukar kiran.*

Don rikodin sauti

- Daga jiran aiki zaɓi [Menu](#) > [Nishadi](#) > [Yi rikodin sauti](#)

Don sauraron rikodi

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Mai sarrafa fayil](#).
- 2 Gungura zuwa [Kida](#) kuma zaɓi [Bude](#).
- 3 Gungura zuwa rikodi kuma zaɓi [Kunn](#).

Wasanni

Wayarka ta kunshi wasanni da yawa. Zaka kuma iya saukar da wasanni. Akwai rubutun taimako don mafi yawan wasannin.

Don fara wasa

- 1 Daga jiran aiki zaɓi [Menu](#) > [Nishadi](#) > [Wasanni](#).
- 2 Zaɓi wasa.

Don kare wasa

- Latsa .

Ikon wasa

Za'a iya amfani da maɓallan wayarka don ayyukan ikon wasa daban-daban. Don wasu wasanni zaka iya karkata duk wayar hagu, dama, sama da kasa don ikon wasa.

Aikace-aikace

Zaka iya saukarwa da gudanar da aikace-aikacen Java™. Kuma zaka iya duba bayani ko saita izini daban-daban.

Kafin kayi amfani da aikace-aikacen Java™

Idan ba'a riga an shigar da saituna a wayarka ba, duba *Saituna* a shafi na 53.

Don zaɓar aikace-aikacen Java

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Aikace-aikace](#).
- 2 Zaɓi aikace- aikace.

Don duba bayani game da aikace aikacen Java

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Aikace-aikace](#).
- 2 Gungura zuwa aikace-aikace kuma zaɓi [Zabuka](#) > [Bayani](#).

Don saita izini don aikace-aikacen Java

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Aikace-aikace](#).
- 2 Gungura zuwa aikace-aikace kuma zaɓi [Zabuka](#) > [Izinoni](#).
- 3 Saita bada izini.

Girman allon aikace-aikacen Java

An tsara wasu aikace-akacen Java don takamaiman girman allo. Don karin bayani, tuntubi mai siyar da aikace-aikacen.

Don saita girman allon don aikace-aikacen Java

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Aikace-aikace](#).
- 2 Gungura zuwa aikace-aikace kuma zaɓi [Zabuka](#) > [Girman allo](#).
- 3 Zaɓi wani zaɓi.

Bayanan martaba na Intanit don aikace-aikacen Java

Wasu aikace-aikacen Java suna buƙatar haɗi zuwa Intanit don karɓar bayani. Mafiyawan aikace-aikacken Java suna amfani da saitunan Intanit iri ɗaya azaman mai lilon yanar sadarwa.

Haɗi

Saituna

Kafin kayi amfani da Intanit, PlayNow™, Abokaina, Java, aiki tare na nisa, sakon hoto, email da shafin hoto kana buƙatar samun saituna a wayarka.

Zaka iya sauke saituna ta saita maye acikin wayarka ko daga kwamfuta a www.sonyericsson.com/support.

Don sauke saituna ta amfani da saita maye

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Saita maye](#) > [Saukar da saituna](#).
- 2 Bi umarnin dake bayyana.



Tuntubi mai sa aiki na cibiyar sadarwa ko mai baka sabis don karin bayani.

Don sauke saituna ta amfani da kwamfuta

- 1 Je zuwa www.sonyericsson.com/support
- 2 Bi umarni akan allon.

Sunan waya

Zaka iya shigar da suna ga wayar don nunawa lokacin da wasu na'urori suka samo shi.

Don shigar da sunan waya

- 1 Daga jiran aiki zabi [Menu](#) > [Saituna](#) > [Haɗuwa](#) shafin > [Sunan waya](#).
- 2 Shigar da sunan wayar kuma zabi [Ok](#).

Amfani da Intanit

Zaka iya mafani da Intanit don samun damar sabis ɗin kan layi.


Don fara lilo

- 1 Daga jiran aiki zabi [Menu](#) > [Intanit](#).
- 2 Zabi [Zabuka](#) > [Je zuwa](#).
- 3 Zabi wani zabi.

Don fita mai lilo

- Lokacin da kake lilo a Intanit, zabi [Zabuka](#) > [Fita mai lilo](#).

Don yin kira lokacin lilo

- Lokacin da kake lilo a Intanit, zaɓ .

Don ajiye abu a sakon rubutu

- 1 Lokacin da kake lilo a Intanit, zabi wani abu.
- 2 Zabi [Zabuka](#) > [Kayan aiki](#) kuma ajiye abin.

Don samun rubutu a shafin yanar sadarwa

- 1 Lokacinda kake lilon Intanit ɗin, zabi [Zabuka](#) > [Kayan aiki](#) > [Nema a shafi](#).
- 2 Shigar da rubutu kuma latsa [Nema](#).

Don aika hanyar haɗi

- 1 Lokacin da kake lilon Intanit ɗin, zabi [Zabuka](#) > [Kayan aiki](#) > [Aika hanyar haɗi](#).
- 2 Zabi wani zabi.

Amfani da alamar shafi

Zaka iya kirkira da shirya alamar shafi azaman hanyar haɗi mai sauri zuwa shafin yanar sadarwar ka da kafi so.

Don kirkirar alamar shafi

- 1 Lokacin da kake lilon Intanit ɗin, zabi [Zabuka](#) > [Kayan aiki](#) > [Kara alamar shafi](#) > [Alamomin shafi](#).
- 2 Shigar da taki kuma da adreshi. Zabi [Ajiye](#).

Don zaɓar alamar shafi

- 1 Daga jiran aiki zabi [Menu](#) > [Intanit](#).
- 2 Zabi [Zabuka](#) > [Je zuwa](#) > [Alamomin shafi](#).
- 3 Gungura zuwa alamar shafi kuma zabi [Je zuwa](#).

Gajerun faifan maballan Intanit

Zaka iya amfani da faifan maballi don tafiya kai tsaye zuwa aikin mai lilo na Intanit.

Don zaɓar gajerun hanyoyin faifan maballin Intanit

- 1 Daga jiran aiki zaɓi [Menu](#) > [Intanit](#).
- 2 Zaɓi [Zabuka](#) > [Babba](#) > [Yanayin faifan mabal.](#) > [Gajerun hanyoyi](#).

Maballi	Gajeriyyar hanya
1	Alamomin shafi
2 - 9	Shigar da rubutu zuwa Shigarda adireshi , Binciken intanit ko bincika a Alamomin shafi .
*aa--	Cika fuska ko Daji,yanayin fili ko Allo na al'ada .
0 +	Zukowa
#-->	Matsa & Zukowa (lokacin Smart-Fit yana kashe).


Tsaro na Intanit da takaddun shaida

Wayarka tana goyan bayan tsararren lilo. Takamammen sabis na Intanit, kamar harkar banki, yana buƙatar takaddun shaida a cikin wayarka. Zai yiwu wayarka tariga takunshi takaddun shaida lokacin da kasaya ko ka iya sauke sababun takaddun shaida.

Don bincika takaddun shaida a wayarka

- Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Tsaro](#) > [Takaddun shaida](#).

Ciyarwar yanar sadarwa

Lokacin lilo, zaka iya samun ɗaukakakken abun ciki akai-akai, kamar mahimman kanun labarai. Zaka iya kara ciyarwa don shafi, idan yana da  gunki.

Don karin sabuwar ciyarwa don shafin yanar sadarwa

- Lokacin da kake lilon shafi a Intanit ɗin dake da ciyarwar yanar sadarwa, zaɓi [Zabuka](#) > [Yan. sadar. cyrwa](#).

Don kirkirar sabuwar ciyarwa

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Yanar sadarwa. cyrw.](#) > [Zabuka](#) > [Sabon ciyarwa.](#)
- 2 Shigar da adreshin kuma zaɓi [Je zuwa.](#)


Don saita zabubbuka don ciyarwar yanar sadarwa

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Yanar sadarwa. cyrw.](#)
- 2 Gungura zuwa ciyarwar yanar sadarwa kuma zaɓi [Zabuka.](#)
- 3 Zabi wani zaɓi.

Fasaha mara waya ta Bluetooth™

Aikin Bluetooth yana sa haɗi mara waya zuwa wasu na'urorin Bluetooth mai yuwuwa. Zaka iya, misali:

- Haɗa zuwa na'urar abun sawa akunni.
- Haɗa zuwa na'urori da yawa lokaci guda.
- haɗa zuwa kamfutoci kuma sami damar Intanit.
- Musanya abubuwa kuma kunna wasannin multiplayer.

 *Mun yi wasiyya da kewayo tskanin mita 10, batara da abubuwa daskararu a tsakani ba, don sadarwar Bluetooth.*

Kafin kayi amfani da fasaha mara waya ta Bluetooth

Dole ne ka kashe aikin Bluetooth™ don sadarwa zuwa waɗansu na'urorin. kuma dolene ka ware wayarka tareda waɗansu na'urorin Bluetooth.

Don kunna aikin Bluetooth™

- Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Haɗuwa](#) shafin > [Bluetooth](#) > [Kunna.](#)
- ! *Tabbata cewa na'urar da kake son ka ware wayarka da ita tana da aikin Bluetooth akunne kuma za'a iya gani.*

Don ware wayar tareda na'ura

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Haɗuwa](#) shafin > [Bluetooth](#) > [Na'urori nawa.](#)
- 2 Gungura zuwa [Sabuwar na'ura](#) kuma zaɓi [Kara](#) don bincika samammun na'urori.
- 3 Zabi na'ura.
- 4 Shigar da lambar wucewa, in an bukata.

Don bawa haɗi dama zuwa wayar

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Haɗuwa](#) shafin > [Bluetooth](#) > [Na'urori nawa.](#)
- 2 Zabi na'ura daga lissafi.
- 3 Zabi [Zabuka](#) > [Bada izinin haɗi.](#)

Don ware wayar tareda abin sawa akunni na Bluetooth da farko

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Haɗuwa](#) shafin > [Bluetooth](#) > [Abin sawa akunni](#).
- 2 Zaɓi [Ee](#).
- 3 Shigar da lambar wucewa, in an bukata.

Don ware wayar tareda abin sawa akunni na Bluetooth fiye da ɗaya

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Haɗuwa](#) shafin > [Bluetooth](#) > [Abin sawa akunni](#) > [Abn.saw.akun.nawa](#) > [Sab. abn.saw.akunni](#).
- 2 Gungura zuwa na'ura kuma zaɓi [Kara](#).

Ajiye wuta

Zaka iya ajiye wutar baturi tareda aikin aikin wuta. Zaka kuma iya haɗawa tareda na'ura ɗaya ta Bluetooth. Dolene ka kashe wannan aikin idan kana son haɗawa tareda na'urar Bluetooth fiye da ɗaya a lokaci guda.

Don kunna ajiye wuta

- Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Haɗuwa](#) > [Bluetooth](#) > [Ajiye wuta](#) > [Kunnawa](#).

Ganuwa

Idan kana son wasu na'urorin Bluetooth su sami ikon gano wayarka, zaka iya zaɓar yin wayarka mai ganuwa.

Don samun abu

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Haɗuwa](#) shafin > [Bluetooth](#) > [Ganuwa](#) > [Nuna waya](#).
- 2 Lokacin da kasami wani abu, bi umarni wanda ke bayyana.

Canja wurin sauti zuwa kuma daga abin sawa akunni na Bluetooth

Zaka iya canja wurin sauti zuwa kuma daga abin sawa akunni na Bluetooth ta amfani da mabballin waya ko maballin abin sawa akunnin.

Don canja wurin sauti

- 1 Daga jiran aiki [Menu](#) > [Saituna](#) > [Haɗuwa](#) shafin > [Bluetooth](#) > [Abin sawa akunni](#) > [Kira mai shigowa](#).
- 2 Zaɓi wani zaɓi. [Cikin waya](#) yana canja wurin sauti zuwa waya. [A abin saw. akunni](#) yana canja wurin sauti zuwa abin sawa akunni.

Canja wurin fayil

Zaka iya aiki tare da canja wurin fayiloli ta amfani da fasaha mara ta Bluetooth. Duba *Aiki tare ta amfani da kwamfuta* kan sahfi 56.

Amfani da Intanit

Zaka iya haɗa wayarka zuwa kwamfuta tareda kebul na USB cable don canja wurin fayiloli ta amfani da [Aje kayyayaki](#) ko [An sauya mai jard](#). Zaka iya kuma aiki tare, canja wurin fayil kuma yi amfani wayarka a zaman abin haɗi ta amfani da [Yanayin waya](#). Don karin bayani Jeka bangaren Farwa a www.sonyericsson.com/support.

Kafin kayi amfani da kebul na USB ɗin

Kana bukatar ɗayan waɗannan bukaton tsarin aiki don canja wurin fayiloli ta amfani da kebul USB:

- Windows® 2000
- Windows XP (Pro ko Home)
- Windows Vista (32 kaɗan da 64 siga kaɗan na: Karshe, Shirin abu, Kasuwanci, Home Premium, Tushan Shafi)

Canja wurin mai jarida da Dinbin ajiya

Zaka iya jawo da sauke fayiloli tsakanin wayarka da katin kwakwalwar ajiya da kwamfuta acikin *Microsoft Windows Explorer*.

- ! *Kayi amfani kawai da kebul na ISB wanda wayarka ke goyan baya. Kar a cire kebul na USB ɗin daga wayarka ko kwamfuta yayin canja wurin fayil saboda wannan zai iya lalata kwakwalwar ajiyar wayar ko katin kwakwalwar ajiyar.*

Canja wurin mai jarida da Dinbin ajiya



- 💡 *Kafin canja wurin fayiloli dole ka shigar da Sony Ericsson PC Suite software kan kwamfuta. Duba Don saukar da Sony Ericsson PC Suite kan shafi 60.*
- 1 Haɗa kebul na USB zuwa wayar da kwamfuta.
 - 2 **Waya:** Zabi [Aje kayyayaki](#) > [Menu](#) > [Saituna](#) > [Haɗuwa](#) shafin > [USB](#) > [Yanayin USB](#) > [Aje kayyayaki](#).

Wayar zata mutuw a wannan yanayin kuma zata sake kunnuwa lokaci da aka cire hadinta da kebul na USB.

- 3 Waya:** Zabi [An sauya mai jard](#) kuma weayar zata saura a kunne yayin canja wurin fayil.
- 4 Kwamfuta:** Jira har sai kwakwalwar ajiyar wayar da katin kwakwalwar ajiya sun bayyana azaman disk na waje a *Windows Explorer*.
- 5 Jawo** kuma ya da zaɓaɓɓun bayiloli tsakanin wayar da kwamfutarka.

Don cire hadin kebul na USB a amince

- 1** Kada gunkin disk mai cira dama a *Windows Explorer*.
- 2** Zabi *Fitar*.
- 3** Cire hadin kebul na USB lokacin da sako mai biyowa ya bayyan a wayar: [An kare aje gamuwa, zaka yi fitar da kebul na USB yanzu.](#)

Yanayin waya

Kafin aiki tare ko amfani da wayar a zama abin haɗi dole ka shigar da *Sony Ericsson PC Suite software* kan kwamfutarka. Duba *Don shigar da Sony Ericsson PC Suite* kan shafi 60.

Don amfani da yanayin waya

- 1 Kwamfuta:** Fara *PC Suite* daga *Start/Programs/Sony Ericsson/PC Suite*.
- 2** Hada kebul na USB zuwa wayar da kwamfutarka.
- 3 Waya:** Zabi [Yanayin waya](#) > [Menu](#) > [Saituna](#) > [Haduwa](#) shafin > [USB](#) > [Yanayin USB](#) > [Yanayin waya](#).
- 4 Kwamfuta:** Lokacin da aka sanar da kai cewa *Sony Ericsson PC Suite* ya sami wayarka, zaka iya fara amfani da aikace-akacen yanayin wayar.



Sboda bayanan mu'amala, duna Sony Ericsson bangaren Taimako na PC Suite har in an shigar da software kan kwamfutarka.

Aiki tare

Zaka iya amfani da kebul ba USB ko fasaha mara waya ta Bluetooth don aiki tare da lambobi, alƙawurra, alamun shafi, dawainiya da baya nan kula tareda shirye shiryen kwamfuta kamar Microsoft Outlook. Zaka iya kuma aiki tareda sabis din Intanin ta amfani da SyncML ko Microsoft® Exchange Server ta amfani da Exchange ActiveSync. Don karin bayani Jeka bangaren Farwa a www.sonyericsson.com/support.



Kayi amfani da hayoyin aiki tare daya kawai a lokaci tareda wayarka.

Aiki tare ta amfani da kwamfuta

Kafin aiki tare kana bukarar shigar da *Sony Ericsson PC Suite* daga CD wanda aka haɗoshi tare da wayarka. Software yana taradda bayanin taimako. Zaka kuma iya zuwa ga www.sonyericsson.com/support don saukar da software.

Kana bukarar dayan waɗannan bukatun tsarin aiki don amfani da Disc2Phone a kwamfutarka:

- Windows XP (Pro ko Home)
- Windows Vista (32 kaɗan da 64 siga kaɗan na: Karshe, Shirin abu, Kasuwanci, Home Premium, Tushan Shafi)

Don shigar da Sony Ericsson PC Suite

- 1 Kunna kwamfutarka kuma shigar da CD ɗin CD zai fara atomatik kuma saukar window zai buɗe.
- 2 Zabi yare kuma kaɗa *Yayi*.
- 3 Kaɗa *shigar da Sony Ericsson PC suite* kuma bi umarnin shigar da a kan allon.

Aiki tare ta amfani da sabis na Intanit

Zaka iya aiki tare akan layi ta amfani da sabis ɗin Intanit tareda wayarka. Idan babu saitunan Intanit a wayarka, duba *Saituna* kan safi 53.

Don fara aiki tare

Dole kashigar da saitunan don aiki tare na SyncML kuma yi rijistar lissafin aiki tare kan layi tareda mai bada sabis. Saitunan da ake bukata sune:

- [Adireshin uwar garki](#) – uwar garke URL
- [Sunan task.bayanai](#) – cibiyar bayanai do aiki tare da

Shigar da saituna don SyncML

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Aiki tare](#).
- 2 Gungura zuwa [Sabon lissafi](#) kuma zaɓi [Kara](#) > [Aikin tarecML](#).
- 3 Shigar da suna don sabon lissafi kuma zaɓi [Ci gaba](#).
- 4 Gungura zuwa [Adireshin uwar garki](#). Shigar da baynin da aka bukata kuma zaɓi [Ok](#).
- 5 Shigar [Sunan mai amfani](#) kuma [Kalmar wucewa](#), in an bukata.
- 6 Gungura zuwa [Aikace-aikace](#) sahfin don sa alama zaɓuɓɓukan da kake so kai aiki tare.
- 7 Gungura zuwa [Kayan saiti](#) shafin kuma zaɓi aikace-aikace.
- 8 Zabi [Sunan task.bayanai](#) kuma shigar da bayanin da ake bukata.
- 9 Gungura zuwa [Babba](#) shafin don shigar da karin saituna don aiki tare.
- 10 Zabi [Ajiye](#).

Don share lissafi


- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Aiki tare](#).
- 2 Gungura zuwa lissafi kuma zaɓi [Zabuka](#) > [Share](#).

Don fara aiki tare

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Aiki tare](#).
- 2 Gungura zuwa lissafi kuma zaɓi [Fara](#).

Aiki tare ta amfani da Microsoft® Exchange Server

Zaka iya samun dama da aiki tare da bayanin musaya na haɗin gwuiwa kaman email, lambobi da shigar kalanda tareda Microsoft® Exchange Server ta amfani da wayarka.

 *Don karin bayani kan saitunan aiki tare, tuntubi mai kula da IT naka.*

Kafin kafara aiki tare

Dole ka shigar da saituna don Exchange ActiveSync don samun damar Microsoft Exchange Server. Saitunan da ake bukata sune:

- [Adireshin uwar garki](#) – uwar garke URL.
- [Wurin iko](#) – fagen uwar garke
- [Sunan mai amfani](#) – sunan mai amfani na lissafi.
- [Kalmar wucewa](#) – kalmar wucewa ta lissafi.

Shigar da saituna don Exchange SyncML

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Aiki tare](#) > [ActiveSync](#).
- 2 Shigar da suna don sabon lissafi kuma zaɓi [Ci gaba](#).
- 3 Shigar da saitunan da ake bukata.
- 4 Gungura trsakanin shafukan don shigar da karin saituna.
- 5 Zaɓi [Ajije](#).

Don fara aiki tare

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Aiki tare](#).
- 2 Gungura zuwa lissafi kuma zaɓi [Fara](#).



Daukaka sabis

Zaka iya daukaka wayarka da software mafi sabunta. Baza karasa bayanin sirri ba ko bayanin waya ba.

Akwai hanyoyi biyu don daukaka wayarka:

- Bisa iska ta amfani da wayarka
- Ta amfani da kebul na USB wanda aka bayar da kwamfuta mai haɗin Intanet



Sabis na daukaka na Sony Ericsson yana bukar samun damar bayanai (GPRS).

Kafin kayi amfani da daukaka sabis

Idan babu saituna a wayarka duba *Saituna* kan shafi 50.

Don duba software na yanzu acikin wayarka

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Sabis na ɗaukaka](#).
- 2 Zaɓi [Sigar software](#).

Don amfani da ɗaukaka sabis ta amfani da wayar

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Sabis na ɗaukaka](#).
- 2 Zaɓi [Binciken ɗaukaka](#) kuma bi umarnin da ya bayyana.

Don amfani da ɗaukaka sabis ta amfani da keɓul na USB

- 1 Je zuwa www.sonyericsson.com/support ko kaɗa *Daukaka sabis na Sony Ericsson a PC Suite software* if installed on your computer. Duba *Don saukar da Sony Ericsson PC Suite* kan shafi 60.
- 2 Zaɓi yanki da kasa.
- 3 Bi umarni akan allon.

Don saita mai tuni don amfani da ɗaukaka sabis

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Sabis na ɗaukaka](#) > [Saituna](#) > [Mai tuni](#).
- 2 Zaɓi wani zaɓi.

Karin fasali

Kararrawa

Zaka iya saita sauti ko rediyo azaman sigina na kararrawa. Kararrawa tana yin sauti ko da an saita wayar zuwa shiru ko kashewa. Lokacin da kararrawa ke sauti zaka iya sata shiru zuwa minti 9 ko ka kashe ta.

Don saita kararrawa

- 1 Daga jiran aiki zaɓi [Menu](#) > [Kararrawa](#).
- 2 Gungura zuwa kararrawa kuma zaɓi [Shirya](#).
- 3 Gungura zuwa [Lokacin](#): kuma zaɓi [Shirya](#).
- 4 Shigar da lokaci kuma zaɓi [Ok](#) > [Ajiye](#).

Don saita maimaita kararrawa

- 1 Daga jiran aiki zaɓi [Menu](#) > [Kararrawa](#).
- 2 Gungura zuwa kararrawa kuma zaɓi [Shirya](#).
- 3 Gungura zuwa [Mai dawowa](#) kuma zaɓi [Shirya](#).
- 4 Gungura zuwa rana kuma zaɓi [Alama](#).
- 5 Don zaɓin wani rana, gungura zuwa ranar kuma zaɓi [Alama](#).
- 6 Zaɓi [Anyi](#) > [Ajiye](#).

Don saita sigina na kararrawa

- 1 Daga jiran aiki zaɓi [Menu](#) > [Kararrawa](#).
- 2 Gungura zuwa kararrawa kuma zaɓi [Shirya](#).
- 3 Gungura zuwa [Signal na kararrawa](#): kuma zaɓi [Shirya](#).
- 4 Sami kuma zaɓi siginar kararrawa. Zaɓi [Ajiye](#).

Don sa kararrawa shiru

- Lokacin da kararrawa take sauti, latsa kowane maɓalli.
- Don maimaita kararrawar, zaɓi [Munshari](#).

Don kashe kararrawa

- Lokacin da kararrawa take sauti, latsa [Kashe](#).


Don soke kararrawa

- 1 Daga jiran aiki zaɓi [Menu](#) > [Kararrawa](#).
- 2 Gungura zuwa kararrawa kuma zaɓi [Kashe](#).

Kararrawar tana cikin yanayin shiru

Zaka iya saita kararrawar kar tayi sauti lokacin da wayar ke halin shiru.

Don saita kararrawa tayi sautyi ko a'a a yanayin shiru

- 1 Daga jiran aiki zabi [Menu](#) > [Kararrawa](#).
- 2 Gungura zuwa kararrawa kuma zabi [Shirya](#).
- 3 Gungura zuwa  shafin.
- 4 Gungura zuwa [Yanayin shiru](#) kuma zabi [Shirya](#).
- 5 Zabi wani zabi.

Kalanda

Kalanda zai iya aiki tare da kalendar kwamfuta, ko tareda kalanda akan yanar sadarwa ko tareda Microsoft® Exchange Server (Microsoft® Hangen nesa®). Don karin bayani duba *Aiki tare* a shafi 59.

Duba tsohuwa

Zaka iya zaban duba wata, sati ko rana zai bayyana da farko lokacin ka buɗe kalnada.

Don saita duba tsohuwa

- 1 Daga jiran aiki zabi [Menu](#) > [Oganeza](#) > [Kalanda](#).
- 2 Zabi [Zabuka](#) > [Babba](#) > [Duba tsohuwa](#).
- 3 Zabi wani zabi.

Alkawurra

Zaka iya kara sabuwar alkawurra ko sake amfani da alkawurra da su ke kasancewa.

Don kara alkawari

- 1 Daga jiran aiki zabi [Menu](#) > [Oganeza](#) > [Kalanda](#).
- 2 Zabi kwanan wata.
- 3 Gungura zuwa [Sabuwar alkawari](#) kuma zabi [Kara](#).
- 4 Shigar da bayani kuma tabbatar da kowacce shigarwa.
- 5 Zabi [Ajiye](#).

Don duba alkawari

- 1 Daga jian aiki zabi [Menu](#) > [Oganeza](#) > [Kalanda](#).
- 2 Zabi kwanan wata.
- 3 Gungura zuwa alkawari kuma zabi [Duba](#).

Don duba alkawari

- 1 Daga jiran aiki zabi [Menu](#) > [Oganeza](#) > [Kalanda](#).
- 2 Zabi kwanan wata.
- 3 Gungura zuwa alkawari kuma zabi [Duba](#).
- 4 Zabi [Zabuka](#) > [Shirya](#).
- 5 Shirya alkawari kuma tabbatar da kowacce shigarwa.
- 6 Zabi [Ajiye](#).

Don aika alƙawari

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Kalanda](#).
- 2 Zaɓi kwanan wata.
- 3 Gungura zuwa alƙawari kuma zaɓi [Zabuka](#) > [Aika](#).
- 4 Zaɓi hanyar canja wuri.

! *Tabbatar da na'urar da aka karɓa tana goya bayan hanyar canja wuri da ka zaɓa.*

Don duba satin kalanda

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Kalanda](#).
- 2 Zaɓi kwanan wata.
- 3 Zaɓi [Zabuka](#) > [Duba sati](#).

Don saita lokacin da masu tuni zasu yi sauti

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Kalanda](#).
- 2 Zaɓi kwanan wata.
- 3 Zaɓi [Zabuka](#) > [Babba](#) > [Masu tuni](#).
- 4 Zaɓi wani zaɓi.

! *Zaɓin masu tuni da aka saita a kalanda yana rinjayar zaɓin masu tuni da aka saita a dawainiya.*

Dawainiya

Zaka iya kara sababbin dawainiya ko sake amfani da dawainiya mai gudana.

Don kara dawainiya

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Dawainiya](#).
- 2 Gungura [Sabuwar dawainiya](#) kuma zaɓi [Kara](#).
- 3 Zaɓi wani zaɓi.
- 4 Shigar da cikakkun bayanai kuma tabbatar da kowacce shigarwa.

Don duba dawainiya

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Dawainiya](#).
- 2 Gungura zuwa dawainiya kuma zaɓi [Duba](#).

Don sake amfani da dawainiya mai gudana

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Dawainiya](#).
- 2 Gungura zuwa dawainiya kuma zaɓi [Duba](#).
- 3 Zaɓi [Zabuka](#) > [Shirya](#).
- 4 Shirya dawainiyar kuma zaɓi [Ci gaba](#).
- 5 Zaɓi don saita mai tuni.

Don aika dawainiya

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Dawainiya](#).
- 2 Gungura zuwa lamba kuma latsa [Zabuka](#) > [Aika](#).
- 3 Zaɓi hanyar canja wuri.

! *Tabbatar da na'urar da aka karɓa tana goyan bayan hanyar canja wuri da ka zaɓa.*

Don saita lokacin da masu tuni zasu yi sauti

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Dawainiya](#).
- 2 Gungura zuwa dawainiya kuma zaɓi [Zabuka](#) > [Masu tuni](#).
- 3 Zaɓi wani zaɓi.

! *Zabin masu tuni da aka saita a kalanda yana rinjayar zabin masu tuni da aka saita a dawainiya.*

Bayanan kula

Zaka iya yin bayanan kula kuma ka ajiye su. Hakanan zaka iya nuna bayanin kula acikin jiran aiki.

Don kara bayanin kula

- 1 Daga jian aiki zaɓi [Menu](#) > [Oganeza](#) > [Bayanan kula](#).
- 2 Gungura zuwa [Sabuw.bayanin kula](#) kuma zaɓi [Kara](#).
- 3 Rubuta bayanin kula kuma zaɓi [Ajiye](#).

Don nuna bayanin kula acikin jiran aiki

- 1 Daga jian aiki zaɓi [Menu](#) > [Oganeza](#) > [Bayanan kula](#).
- 2 Gungura zuwa bayanin kula kuma zaɓi [Zabuka](#) > [Nuna a jiran aiki](#).

Don aika bayanin kula

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Bayanan kula](#).
- 2 Gungura zuwa bayanin kula kuma zaɓi [Zabuka](#) > [Aika](#).
- 3 Zaɓi hanyar canja wuri.

! *Tabbatar da na'urar da aka karɓa tana goyan bayan hanyar canja wuri da ka zaɓa.*

Don ajiye abu a bayanin kula

- 1 Lokacin da ka duba bayanin kula, zaɓi lambar waya, email ko adreshin yanar sadarwa.
- 2 Zaɓi [Zabuka](#) > [Yi amfani](#).
- 3 Zaɓi wani zaɓi.

Mai kidayar lokaci, agogon awon gudu da kalkaleta

Don amfani da mai kidayar lokaci

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Mai kidayar lokaci](#).
- 2 Shigar da awoyi, mintoci da sakan.
- 3 Zaɓi [Fara](#).

Don amfani da agogon awon gudu

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Agogo.awon gudu](#) > [Fara](#).
- 2 Don duba lokacin juyi, zaɓi [Cinya](#).

Don amfani da kalkaleta

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Kalkaleta](#).
- 2 Latsa \square ko \square don zaɓi $+ x - + . \% =$.

Memo na lamba

Zaka iya ajiye lambobin tsaro, misali, katunan kuɗi. Dolene ka saita lambar wucewa don buɗe memo na lamba.

Duba kalma

Duba kalma yana tabbatar da cewa kashigar da lambar wucewa daidai. Idan lambar wucewa daidai ne, lambobin daidai za su nuna. Idan lambar wucewar ba daidai bace, ana nuna duba kalma da lambobin suma ba daidai bane.

Don buɗe memo na lamba da farko

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Memo na lamba](#).
- 2 Bi umarnin da ya bayyana kuma zaɓi [Ci gaba](#).

- 3 Shigar da lambar wucewa kuma zaɓi [Ci gaba](#)
- 4 Tabbatar da lambar wucewar kuma zaɓi [Ci gaba](#)
- 5 Shigar da duba kalma kuma zaɓi [Anyi](#).

Don kara lamba

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Memo na lamba](#).
- 2 Shigar da lambar wucewa kuma zaɓi [Ci gaba](#).
- 3 Gungura zuwa [Sabuwar lamba](#) kuma zaɓi [Kara](#).
- 4 Shigar da suna mai dangantaka da lambar kuma zaɓi [Ci gaba](#).
- 5 Shigar da lambar kuma zaɓi [Anyi](#).

Don canja lambar wucewa

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Memo na lamba](#).
- 2 Shigar da lambar wucewarka kuma zaɓi [Zabuka](#) > [Canj.lamb.wucew](#).
- 3 Shigar da sabuwar lambar wucewarka kuma zaɓi [Ci gaba](#)
- 4 Sake shigar da sabuwar lambar wucewar kuma zaɓi [Ci gaba](#)
- 5 Shigar da duba kalma kuma zaɓi [Anyi](#).

Manta lambar wucewarka?

Idan kamanta lambar wucewar ka, dole ne ka sake saita kwakwalwar ajiya na lamba. Wannan yana nufin cewa an share duk abubuwan da aka shigar a memo. Lokaci na gaba in kana shigar da memo na lamba ɗin, dolene ka gudanar kamar kana buɗe shi da farko. Duba *Don buɗe memo na lamba da farko* a shafi 67.

Don sake saita lamabr memo

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Memo na lamba](#).
- 2 Shigar da kowace lambar wucewa don samun damar memo na lambar. Duba kalmar da lambobin da aka nuna alokacin ba daidai bane.
- 3 Zaɓi [Zabuka](#) > [Sake saiti](#).
- 4 [Sake saitin memo na lamba?](#) yana bayyana.
- 5 Zaɓi [Ee](#).

Bayanan martaba

Bayanan martaba suna amsar saitunan wasu wayoyi ta atomic, misali, karrar ringi mai yiwuwa ya amsu don dacewa da takamaiman wuri ko na'urorin haɗi. Zaka iya sake saita duk bayanana martaba zuwa yadda aka saita su lokacin ka sayi wayarka.

Don zaɓar bayanin martaba

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Bayanan martaba](#).
- 2 Zaɓi bayanin martaba.

Don duba da shirya bayanin martaba

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Bayanan martaba](#).
- 2 Gungura zuwa bayanin martaba kuma zaɓi [Zabuka](#) > [Duba ka ashirya](#).

! *Bazaka iya sake sunan bayanin martaba na al'ada ba.*

Don sake saita duk bayanana martaba

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Bayanan martaba](#).
- 2 Zaɓi [Zabuka](#) > [Sa. sait.bay. mart.](#)

Lokc.da kwn.wata

Don saita lokaci

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Lokc. & kwn. wat.](#) > [Lokaci](#).
- 2 Shigar da lokaci kuma zaɓi [Ajiye](#).

Don saita kwanan wata

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Lokc. & kwn. wat.](#) > [Kwanan wata](#).
- 2 Shigar da kwanan watan kuma zaɓi [Ajiye](#).

Don saita shiyyar lokaci

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Lokc. & kwn. wat.](#) > [Lokacin ka](#).
- 2 Zaɓi shiyyar lokacin inda kake ta gari.

- ! *Idan ka zaɓi birni, [Lokacin ka](#) kuma yana ɗakaka lokacin lokacin da lokacin ajiye hasken rana ke canjawa.*

Makullai

Makullin katin SIM

Wannan makullin yana kare biyan kuɗinka ne kawai. Wakarka zata yi aiki da sabon katin SIM Idan makullin yana kunne, dolene ka shigar da PIN (Kebabɓiyar Lambar Shaida).

Idan ka shigar da PIN ɗinka kuskure sau uku ajere, ana katange katin SIM kuma kana bukatar shigar da PUK ɗinka (Kebabɓen Maɓallin Cire katanga). PIN naka da PUK ana bada su ta afaretan cibiyar sadarwa.

Don cire katangar katin SIM ɗin

- 1 Lokacin da [An katange PIN](#) ya bayyana, shigra PUK ɗinka kuma zaɓi [Ok](#).
- 2 Shigar lambar PIN sabuwa daga huɗu zuwa takwas kuma zaɓi [Ok](#).
- 3 Sake shigar da sabon PIN ɗin kuma zaɓi [Ok](#).

Don shirya PIN ɗin

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Tsaro](#) > [Mukullai](#) > [Kariyar SIM](#) > [Canja PIN](#).
- 2 Shigar da PIN naka kuma zaɓi [Ok](#).
- 3 Shigara da lambar PIN sabuwa da huɗu zuwa takwas kuma zaɓi [Ok](#).
- 4 Sake shigar da sabon PIN ɗin kuma zaɓi [Ok](#).

- ! *Idan [Lambobi basu jitu ba](#) yana bayyana, ka shigar da sabon PIN ba daidai ba. Idan [PIN mara daidai](#) ya bayyana, yana biye dashi [Tsohuwar PIN](#); ka shigar da tsohon Pin ɗinka kuskure.*

Don amfani da Makullin katinSIM

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Tsaro](#) > [Mukullai](#) > [Kariyar SIM](#) > [Kariya](#).
- 2 Zaɓi wani zaɓi.
- 3 Shigar da PIN naka kuma zaɓi [Ok](#).

Kulle waya

Zaka iya dakatar da amfani mara izini na wayarka. Canja lambar makullin waya (0000) zuwa kowacce lamba huɗu zuwa takwas na lambar sirri.

- ! *Yana da mahimmanci cewa kana tuna sabuwar lambarka. Idan ka manta ta, dole ne ka dauki wayarka zuwa wakilin Sony Ericsson na gida.*

Don amfani da makullin wayar

- 1 Daga jiran aikin zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Tsaro](#) > [Mukullai](#) > [Kariyar waya](#) > [Kariya](#).
- 2 Zaɓi wani zaɓi.
- 3 Shigar da lambar makullin wayar kuma zaɓi [Ok](#).

Don canja lambar makullin wayar

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafi > [Tsaro](#) > [Mukullai](#) > [Kariyar waya](#) > [Canja lamba](#).
- 2 Shigar da tsohuwar lambar kuma zaɓi [Ok](#).
- 3 Shigar da sabuwar lambar kuma zaɓi [Ok](#).
- 4 Maimaita lambar kuma zaɓi [Ok](#).

Makullin faifan maɓallai

Zaka iya saita wannan makullin don gudun bugun kiran da ba'ayi niya ba. Za'a iya amsa kira mai shigowa batara da buɗe faifan maɓallai ba.

- ! *Har yanzu za'a iya kiran lambar gagawa ta kasar waje 112.*

Don amfani da kulle maɓalli na atomatik

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Tsaro](#) > [Kull. maɓll.ta atomat](#).
- 2 Zaɓi wani zaɓi.

Don kulle faifan maɓalli da hannu

- Daga jiran aiki latsa [*aa->](#) kuma zaɓi [Kulle](#).

Don buɗe faifan maɓalli da hannu

- Daga jiran aiki latsa [*aa->](#) kuma zaɓi [Buɗe](#).

Lambar IMEI

Aje kwafi na lambar IMEI naka (International Mobile Equipment Identity) koda za'a sace wayarka.

Don duba lambar ka ta IMEI

- Daga jiran aiki latsa [*aa->](#), [#->](#), [0+](#), [6](#), [#->](#).

Shirya matsala

Wasu matsaloli suna bukatar ka kira mai sa aikin cibiyar sadarwa naka.

Daga karin goyan baya je zuwa www.sonyericsson.com/support.

Tambayoyi gama gari

Ina da matsala da damar kwakwalwar ajiya ko wayar tana aiki a hankali

Sake fara wayar kullun don samun sararin kwakwalwar ajiya ko yi [Sake saitizuwa ainh](#).

Sake saitin zuwa na ainihi

Idan ka zaɓi [Sake saitin saitina](#), za'a share canje-canjen da kayi ga saituna.

Idan ka zaɓi [Sake satin duk](#), gubu da kari ga canje-canjenka ga saituna, duk lambobi, sakonni, keɓaɓɓun bayanai, da abun ciki wanda ka saukar, karɓa ko shiryawa suma za'a share su.

Don sake saita wayar

- 1 Daga jiran aiki zaɓi [Menu > Saituna > Gaba ɗaya](#) shafin > [Sake saitizuwa ainh](#).
- 2 Zaɓi wani zaɓi.
- 3 Bi umarnin dake bayyana.

Bazan iya cajin waya ba ko damar baturi tayi kasa

Ba'a haɗa caji daidai ba ko haɗin baturin ba shi da kyau. Cire baturin ka tsafatace masu haɗawar.

Baturin ya lalace kuma yana bukatar sauyawa. Duba *Cajin baturi* a shafi 7.

Babu gunkin baturi daya bayyana lokacin da nafara cajin waya

Zai iya ɗaukar yan mintuna kafin gunkin baturin ya bayyana a allon.

Wasu zaɓuɓɓukan menu suna bayyana cikin ruwan toka

Ba'a kunna sabis ba. Tuntuɓi afaɗetan cibiyar yanar sadarwarka.

Bana iya amfani da sakonnin rubutun/ SMS a wayata

Saituna suna baɗewa ko kuskure. Tuntuɓi afaɗetan cibiyar sadarwarka don gano hakikanin saitin wurin sabis na SMS saiti. Duba *Sakonnin rubutu* a shafi 30.

Bana iya amfani da sakonnin hoto a wayata

Biyar kuɗin ka bai kunshi damar bayanai ba. Saituna suna baɗewa ko kuskure. Tuntuɓi mai sa aikin cibiyar sadarwa naka.

Duba *Taimako a wayarka*
a shafi 6 ko je zuwa
www.sonyericsson.com/support don
tsara saitunakuma bi umarni akan
allon. Duba *Saituna* a shafi 53.

Ta yaya zan kunna da kashe T9 Text Input lokacin rubutu?

Lokacin da kake shigar da rubutu
latsa ka rike kasa (←) . Zaka ga **T9** a
saman allon T9 Text Input a kunne.

Ta yaya zan canza yaren waya?

- 1 Daga jiran aiki zaɓi **Menu** > **Saituna**
> **Gaba ɗaya** shafin > **Yare** > **Yaren**
waya.
- 2 Zaɓi wani zaɓi.

Bazan iya amfani da Intanit ba

Biyun kuɗin ka bai kunshi damar
bayanai ba. Saituna Intanit suna
ɓacewa ko kuskure. Tuntubi mai
sa aikin cibiyar sadarwa naka.

Duba *Taimako a wayarka*
a shafi 6 ko je zuwa
www.sonyericsson.com/support don
tsara saituna kuma bi umarni akan
allon. Duba *Saituna* a shafi 50.

Wasu na'urori baza su iya gano wayar ta amfani da fasaha mara waya ta Bluetooth ba


Baka kunna aikin Bluetooth ba.

A tabbatar cewa an saita iya ganuwa
don nuna waya. Duba *Don karɓar*
wani abu a shafi 57.

Bana iya aiki tare ko canja wurin bayanai tsakanin wayata da kwamfuta ta, lokacin amfani da kebul na USB ba

Kebul ɗin ko software ɗin da suka
zo tareda wayarka ba'a shigar da
su dai-dai ba. Je zuwa
www.sonyericsson.com/support don
karanta Jagororin farawa wanda ya
kunshi bayyanan umarnin shigarwa
da jagororin shirya matsala.

A ina zan iya samun abin tsara bayani kamar lambar IMEI nawa idan ba zan iya kunna waya?



Kuskuren sakonni

Sa SIM

Babu katin SIM acikin wayarka ko zai yiwu ka saka shi kuskure.

Duba *cajin baturi* a shafi 7.

Masu haɗin katin SIM suna bukatar tsaftacewa. Idan katin ya lalace tuntubi afaretan cibiyar sadarwarka.

Sa katin SIM mai kyau

An saita wayarka don kawai aiki tareda takamaiman katinan SIM. Bincika idan kana amfani da katin SIM ɗin afareta dai-dai.

PIN mara daidai/ PIN2 mara daidai

Kashigar da PIN naka ko PIN2 kuskure.

Shigar da PIN ɗin dai-dai ko PIN2 kuma zaɓi [Ee](#). Duba *Don saka katin SIM* a shafi 5.

An katange PIN/An katange PIN2

Ka shigar da lambar PIN ko PIN2 naka kuskure sau uku a jere.

Don cire katanga, duba *Makullin katin SIM* a shafi 69.

Lambobi basu jitu ba

Lambobin da ka shigar basu dace ba. Lokacin da kake son canja lambar tsaro, misali PIN ɗinka dole ka tabbatar da sabuwar lambar. Duba *Makullin katin SIM* a shafi 69.

Babu keway.cb.sadr.

Wayarka tana cinkin yanayin kaura. Duba *Yanayin kaura* a shafi 6.

Wayarka bata karɓar signal na rediyo, ko signal da aka karɓa yana da rauni kwarai. Tuntuɓi mai sa aikin cibiyar sadarwar ka kuma a tabbata cewa cibiyar yanar sadarwa ya kewaye in da kake.

Katin SIM baya aiki yadda ya kamata. Sa katin SIM naka cikin wata wayar. Idan wannan yana aiki, da alama wayarka ce ke haifar da matsalar. Tuntuɓi wurin sabis na Sony Ericsson mafi kusa.

Kiran gaggw. kawai

Kana tsakanin yankin cibiyar yanar sadarwa, amma ba ka da damar amfani da ita. Ko kaka, acikin gaggawa, wasu afaretocin cibiyar sadarwa suna baka dama don kiran lambar gaggawa ta kasar waje 112. Duba *Kiran gaggawa* a shafi 18.

An cire katanga PUK. Tuntubi mai sa aiki.

Ka shigar da lambar maƙallin cire katanga na sirri (PUK) kuskure sau goma a jere.

Yin caji, bakon baturi

Baturin da kake amfani da shi ba amintaccen baturin Sony Ericsson bane. Duba *Baturi* a shafi 77.

Muhimman bayanai

Mai amfani da gidan yanar sadarwa na Sony Ericsson

A kunne www.sonyericsson.com/support akwai yankin goyon baya inda taimako da tukwici suke a kada kawai waje. Anan zaka sami sabon ɗaukaka software na kwamfuta da tikwici akan yadda zaka yi amfani da samfur naka da nagarta sosai.

Sabis da goyan baya

Daga yanzu har ka sami hanyar haɗi don samun keɓantar gatan sabis kamar:

- Na duniya da shafin yanar sadarwa na gida na gabatar da goyan baya.
- Cibiyar yanar sadarwa na duniya na wuraren kira.
- Babbar cibiyar sadarwar abokan sabis na Sony Ericsson.
- Lokacin garanti. kara koyo game da yanayin garanti a wannan jagoran mai amfani.

Kan www.sonyericsson.com, karkashin sashin goyan bayan a zabin harshe , za ka sami kayan aikin sabon goyan baya da bayani, kamar ɗaukaka software, bayanan ilimi, saitin waya da karin taimako lokacin da ake bukatr sa.

Don afaretan sabis na musamman da fasaloli, tutubi afaretan cibiyar sadarwarka don karin bayani.

Kuma zaka iya truntuban Wurin Kiranmu. Duba lambar wayar don mafi kusan cibiya a lissafin dake kasa. Idan kasar ka/nahiya bai fito acikin lissafi ba, ka tuntubi dila na yankin ka. (Lambobin waya na kasa daidai suke a lokacin zuwa fitarwa. A kunne www.sonyericsson.com akoyaushe zaka iya samun ɗaukaka sabo.)

In abin da ba a so ya faru wanda na'urar ka ke bukatan sabis.

Ka tuntubi dilar daka saya a wajan shi ko daya daga cikin mambobin sabis namu. Aje shedan sayen ka na asali, zaka bukace shi idan kana bukatar samun garanti.

Kiran daya daga cikin cibiyoyim kiran mu za a caje ka gwargwadon kimar na gida, gami da harajin gida, sai dai idan lambar wayar lambar kyauta ce.

Kasa

lambar waya

Ostiraliya	1-300 650 050
Ajantina	800-333-7427
Ostiriya	0810 200245
Baljiyam	02-7451611
Burazil	4001-0444
Kanada	1-866-766-9374
Afirka ta tsakiya	+27 112589023
Cile	123-0020-0656
Cana	4008100000
Kolambiya	18009122135
Kurwatiya	062 000 000
Jumhuriyar ciz	844 550 055
Denmak	33 31 28 28
Finlanda	09-299 2000
Faransa	0 825 383 383
Gamani	0180 534 2020
Gires	801-11-810-810
	210-89 91 919 (daga wayar hannu)
Hon Kon	8203 8863
Hungari	+36 1 880 47 47
Indiya	1800 11 1800 (Lambar kiran kyauta)
	39011111 (daga wayar hannu)
Indunusiya	021-2701388
Irlanda	1850 545 888
Italiya	06 48895206
Litaniya	8 700 55030
Maleziya	1-800-889900
Megziko	01 800 000 4722
	(lambar kiran kyauta ta kasar waje)

Adireshin email

questions.AU@support.sonyericsson.com
questions.AR@support.sonyericsson.com
questions.AT@support.sonyericsson.com
questions.BE@support.sonyericsson.com
questions.BR@support.sonyericsson.com
questions.CA@support.sonyericsson.com
questions.CF@support.sonyericsson.com
questions.CL@support.sonyericsson.com
questions.CN@support.sonyericsson.com
questions.CO@support.sonyericsson.com
questions.HR@support.sonyericsson.com
questions.CZ@support.sonyericsson.com
questions.DK@support.sonyericsson.com
questions.FI@support.sonyericsson.com
questions.FR@support.sonyericsson.com
questions.DE@support.sonyericsson.com
questions.GR@support.sonyericsson.com
questions.HK@support.sonyericsson.com
questions.HU@support.sonyericsson.com
questions.IN@support.sonyericsson.com
questions.ID@support.sonyericsson.com
questions.IE@support.sonyericsson.com
questions.IT@support.sonyericsson.com
questions.LT@support.sonyericsson.com
questions.MY@support.sonyericsson.com
questions.MX@support.sonyericsson.com

Nezalanda	0900 899 8318
New Zaland	0800-100150
Nowey	815 00 840
Fakistan	111 22 55 73
	Autsayid Karaci: (92-21) 111 222 55 73
Filifin	+63 (02) 7891860
Foland	0 (Fihirisa) 22 6916200
Fotugal	808 204 466
Romaniya	(+4021) 401 0401
Rasha	8(495) 787 0986
Singafora	67440733
Sulobakiya	02-5443 6443
Afirka ta kudu	0861 632222
Isbaniya	902 180 576
Suwidin	013-24 45 00
Suwizaland	0848 824 040
Taiwan	02-25625511
Tailand	02-2483030
Taki	0212 47 37 777
Ukraniya	(+380) 44 590 1515
Kasar imarat	43 919880
Kasar burtaniya	08705 23 7237
Amurka	1-866-766-9374
Benzawela	0-800-100-2250

questions.NL@support.sonyericsson.com
 questions.NZ@support.sonyericsson.com
 questions.NO@support.sonyericsson.com

questions.PK@support.sonyericsson.com
 questions.PH@support.sonyericsson.com
 questions.PL@support.sonyericsson.com
 questions.PT@support.sonyericsson.com
 questions.RO@support.sonyericsson.com
 questions.RU@support.sonyericsson.com
 questions.SG@support.sonyericsson.com
 questions.SK@support.sonyericsson.com
 questions.ZA@support.sonyericsson.com
 questions.ES@support.sonyericsson.com
 questions.SE@support.sonyericsson.com
 questions.CH@support.sonyericsson.com
 questions.TW@support.sonyericsson.com
 questions.TH@support.sonyericsson.com
 questions.TR@support.sonyericsson.com
 questions.UA@support.sonyericsson.com
 questions.AE@support.sonyericsson.com
 questions.GB@support.sonyericsson.com
 questions.US@support.sonyericsson.com
 questions.VE@support.sonyericsson.com

Bayanai don lafiya da rinjayen amfani

Ka karanta wannan bayanai kafin amfani da wayar hannu

Wadannan bayanai an yi su ne don lafiyar ka Ka bi wadannan bayanai. Iɗan na'ura an shigar da ita cikin kowane sharaɗi da aka lissafa a kasa ko kana



shakku azaman cikakken aiki tabbata ka sami bincikar na'ura ta mamba amini na sabis kafin caji ko amafani da ita. Gaza yin wani abu zai iya zama haɗari ga na'ura ko cutar da lafiyar ka.

Yabo don amfani mai lafiya da samfur (wayar hannu, baturi caji, da wasu na'urori)

- Koyaushe yi mu'amala da na'ura tare kula da barin ta cikin tsafta da wuri mara datti.
- **Gargadi!** Zata iya fashewa idan aka kusanta ta da wuta.
- Kada ka bijirar da na'urar ka zuwa ruwa ko gumi ko zafi.
- Kada ka bijirar da na'urar ka zuwa zafi kwairai ko rashin zafi kwairai. Kada ka bijirar da baturi zuwa yanayin zafi sama da +60°C (+140°F).
- Kada ka bijirar da na'urar ka ga buɗaɗɗen harshen wuta ko kayan taba masu kama wuta.
- Kada ka yada, jefarwa ko kokarin tankwara na'urara ka.
- Kada kayi wa na'urar ka fainti
- Kada ka yi korarin sake haɗa ko kara na'urar ka. mai izini daga Sony Ericsson kawai zai yi sabis.
- Kada ka yi amfani da na'urarka kusa da kayan likita ba tare da samun izini ba daga masu gwajin kimiyya ko ma'aikatan haɗin magani.
- kada ka yi amfani da na'urar ka ciki ko a kusa da jirgin sama, ko a yankin da aka nuna alamar "turn off two-way radio"..
- Kada kayi amfani da na'urar ka a yankin da yake akwai sinadari na fasaha wanda zai iya fashewa.
- Kada ka aje na'urar ka ko sa kayar mara sa waya a yankin da iska ke kadawa a motar ka.
- **Gargadi:** Tsagagge ko karyayyen nuni maiyuwa ha haifar da kaifafan gefuna ko fatsi-fatsi wanda zasu iya zama cutarwa ga lamba.



YARA

AJE NESA DA ISAN YARA. KADA KA BARI YARA SU YI WASA TARE DA WAYARKA TA HANNU KO NA'URARTA. ZA SU IYA JIWA KANSU CIWO KANSU KO WASU. KO ZAI IYA BATA WAYAR TAFI DA GIDANTA KO NA'URA. WAYARKA TA HANNU KO NA'URORINTA ZASU IYA KUNSAR KANANAN SASSA WADANDA ZASU IYA BALLEWA KUMA SU KAWO HADARIN SHAKAWA.



Mai bada wuta(caji)

hada abin hada karfin wutan AC kawai don karfin da aka keɓancewa cibiyar karfi azaman alamar na'ura. Tabbata cewa igiya na wurin sa don haka zata iya aje lalacewa da aka aje ko saukar. Don rage hadarin karfin wuta, shiga yanki daga ko wane cibiyar kafin shirin sharewa ta. Karfin wutan adaftar AC dole yayi amfani da kofofin fita ayanki. Ba zai iya kunna ko kashewa ba. Idan shiga bai dace ba zuwa waje, ka sami wuta asukewar ciki ta tsararrun lantarki.

Yi amfani kawai da kwakkwarar cajar asali na Sony Ericsson da akayi nufi don amfani tareda wayarka ta hannu. Wasu cajin zai yiwu ba a sa su a kiyayewa daya ba da aikata nagartacce.

Baturi

Mun bada shawara cewa kayi cikakken cajin baturi kafin kayi amfani da wayarka ta hannu da farko. Sabon baturi ko wani da aka jima ba a yi amfani dashi ba zai rage karfin sa na dan lokacin sake amfani dashi. Za'a yi cajin baturi ne kawai a yanayin zafi tsakanin +5°C (+41°F) da +45°C (+113°F).

Yi amfani kawai da kwararrun baturan asali na Sony Ericsson da akayi nufi don amfani tareda wayarka ta hannu. Amfani da batura da na'uorin caji zai iya zama hadari.

Magana da lokacin jiran aiki ya dogara ne da wasu yanayi dabam dabam kamar karfi, aikin zafi, aikace aikacen sashi, zaɓaɓɓukan fasaloli da murya ko watsa bayanai lokacin da ake aiki da wayar hannu. Kashe wayarka ta hannu kafin cire baturi. Kada ka sanya baturi a bakin ka. Wutan baturi zai zama mai guba idan aka haɗiye shi. Kada kabar karfen haɗi na baturi ya haɗu da wani karfe. Yin wannan zai iya yanke soket da bata baturi. Amfani da baturi kawai kan abubuwan da ake da muradi.

Na'uorin likita naka

Wayoyin tafi da gidan ka zai iya rinjayen aiki na alamun fuska da wasu kayan da aka aje. Ka nisanci sanya wayar hannu asaman na'urar bugun zuciya, misali acikin aljihun nono. Lokacin amfani da wayar tafi da gidan ka, amfani da ita a kunningi kishiyar sashi na jiki zuwa na'urar bugun zuciya. Idan mafi girman nisa na 15 cm (inci 6) an aje tsakanin wayar hannu da na'urar bugun zuciya, haɗarin kutse zai iyakance. Idan kana da kowane dalili na shakun cewa kutse ya shiga, kashe wayarka ta hannu cikin gaggawa. Tuntuɓi likitan zuciyyar ka don karin bayani. Don wasu na'urar likita, ka shawarci likitan ka da masu sana'anta na'ura.

Tuki

ka bincika koda dokokin gida da ka'idoji sun killace amfani da wayarka ta hannu lokacin tuki ko ko ana bukatan direbobi suyi amfani da abun sawa a kunningi. Muna ba da shawara cewa kayi amfani da hallin abun sawa akunni na Sony Ericsson kawai wanda akayi nufi don amfani tareda samfurinka.

Ka kula cewa saboda yiwuwar kutse zuwa kayan lantarki, wasu kamfanonin kera motoci ba sa karɓar

wayar hannu a a motocin su sai an sa abun sawa akunni mai eriya tawaje.

Koyaushe kula da tuki da hanya da wurin fakɓn kafin yi ko amsa kira idan yanayi tukin na bukata.

Kiran gaggawa

Injin wayar hannu na aiki da sigina rediyo, wanda bai da tabbacin sadarwa a cikin dukkan yanayi. Kada ka dogara kawai akan wayar hannu gameda sadarwa mai mahimmanci. (misalin maganin gaggawa).

Kiran gaggawa ba zai yiwu ba a duk yankuna, a kowane cibiyar yanar sadarwar salula, ko lokacin da hidimomin cibiyar yanar sadarwa da/ko fasalolin wayar hannu ke cikin aiki. Binciki mai bada sabis naka na gida.

Eriya

Wannan wayar ta kunshi eriyar ciki. Yin amfani da nau'rorin eriya waɗanda basu da alamar Sony Ericsson musamman kirar zai iya lalata wayar hannunka, rage karfin aiki, dayin matakan SAR na saman kafafun iyakoki (duba kasa).

Amfani nagari

Rike wayarka ta hannu kamar kowace waya. Kada ka rufe saman waya lokacin da take aiki, kuma wanan zai iya tasiri a nagartar kira zai iya sanya waya ta yi aiki a yanayi wuta mai karfi sosai fiye da yadda ake bukata, kuma zai rage magana da lokacin jiran aiki.

Mitar radiyo (RF) karfi da darajar musamman (SAR)

Wayarka ta hannu nada karamin karfin tashar rediyo da karɓa. Lokacin kunna rediyo, zai ɗauki karamin matakin karfin (kuma kamar yadda aka san tasoshin rediyo ko wuraren kamasu).

Hukomomi na duniya sukan sanya jagororon lafiya mai karfi na kasa da kasa, wanda aka yi daga kungiyoyin ilimi, misali ICNIRP (Kungiyar kasa da kasa masu kula da yanayin na'urorin sinadarai) da IEEE (Cibiyar lantarki da injiniyoyin lantarki) karkashin bincike bincike na ilimi. Wadannan jagorori sun bada matakin iyakoki gudun tashoshi da wayoyi don jam'a baki daya. Matakan sun haɗa da alamomin kula da lafiya don dabbatar da lafiya ga kowa, gameda shekara da lafiya, da kuma awon lissafin bayanai daban daban.

Dajajar aiki na musamman(SAR) da awon yawan karfin yawan tashoshi da yake ajiki lokacin amfani da wayar hannu. Kimar SAR ya iyakance mafi girman karfin da ake bukata a awon yanayi, har da matakin karfin SAR na wayar hannu lokacin aiki wanda zai biyo kasar wannan kima. Saboda wayar hannu an yi shi ne don amfani da mafi karancin wuta da ake bukata a kowane cibiyar yanar sadarwa.

Tashoshin tafiyar rediyo da dama a SAR suna da jagorori ba ya nuɓin cewa duka suna lafiya. Yayin yiwuwar samun banbance banbance cikin matakan SAR tsakanin wayoyin hannu, duk sababun kirar wayar hannu na Sony Ericsson an kera su don gamuwa da jagororin faddawa na mitar rediyo.

Don wayoyin da aka sayar a cikin Amurka, kafin sabuwar kirar waya ya wadata don sayarwa ga jama'a, dole ne babbar hukumar sadarwa ta kasa (FCC) ta gwada ta da shaida cewa bata wuce iyaka kafaffiya a gwamnati na karɓabɓun abubuwan bukata don amintacciyar fiddawa. Gwajin da za a yi a wuri da matsayi(shine, a kunne da kuma sawa a jiki) kamar yadda FCC ta bukata a kowane kira. Don sawa a jiki, An gwada wannan wayar kuma gamu da jagororin fiddawa na FCC RF lokacin da wayar hannu take a matsayin karancin m1515 daga jiki ba tare da kowane sassa na karfe a cikin kusancin waya ko lokacin amfani

tare da 'urar asali ta Sony Ericsson wadda akayi nufi don wannan wayar da sawa a jiki. Amfani da na'urori zai tabbatar da amincewa FCC RF yaduwar jagorori.

A bayanai na daban na SAR gameda kirar wayar hannu wanda ya haɗa da kayyakin da aka haɗa wannan wayar hannu. Wannan bayani za a iya samu kuma, tare da karin bayani a tashoshin yaduwar rediyo da SAR, a: www.sonyericsson.com/health.

Hanyoyin taimako/Bukatun musamman

Don wayoyin da aka sayar cikin Amurka, zaka iya amfani da alamar TTY taka tare da wayar Sony Ericsson taka (tare da na'ura mai mahimmanci). Don karin bayani akan abubuwan taimako na bukatun kanka ko na musamman kira cibiyar kirar Sony Ericsson a 877 878 1996(TTY) ko 877 207 2056(murya), ko ziyarci cibiyar Sony Ericsson bukatun musamman a www.sonyericsson-snc.com.

Zubar da tsoffin kayan wuta da lantarki



Wannan alamar na nuni da cewa duk wayoyin lantarki da kayan wuta da suka haɗa ba za a yi ma'amala dasu azaman marasa amfani na gida. Maimako haka za a bar ta a ahade haɗe da ke nuni ga wayoyi na lantarki da kayayyakin wutan lantarki. Ta tabbatar da wannan n'ura za shirya shi daidai, za ka taimaka kare abubuwa masu cutarwa sadoda yanayi da lafiyar dan adam, amin da kuma zai iya haifar da asarar amfanin samun wannan sana'a. Kayayyakin kira zai taimaka wurin hallaka abubuwa na dabi'a. Don karin bayanai gameda wannan sana'a, tunɓuɓii ofishin gida naka, mai daukan tsara sabis na yanki ka ko shagon da ka saye wannan na'ura daga garesu.

Zubar da baturin

Ka binciki ka'idojin gida don zubar da baturi ko kira cibiyar sadarwar Sony Ericsson don karin bayani.

Wajibi kada a aje baturi a sharar gari. Amafani da wurin zubar da baturi in akwai.



Katin kwakwalwar ajiya

Na'urar ka ta zo hade tare da katin kwakwalwar ajiya mai fita. Gabaɗaya yadace tare da na'urar kai da aka saya amma ba zai dace da wasu na'urorin ba ko karfin katin kwakwalwar ajiyar su. Binciki wasu na'urorin don karfinsu kafin ka saya ko amfani.

Katin kwakwalwa ajiyar an tsara shi don cirewa. Don sake tsarin katin kwakwalwa ajiyar, amfani da na'ura da ta dace. Kada ka yi amfani da tsari na musamman tsayyaye lokacin tsara katin kwakwalwar ajiya a PC. Don cikakun bayanai, koma zuwa umarnin aikin na'ura ko tuntuɓi goyan bayan abokin ciniki.

Gargadi

Idan wayarka na bukatar adafta don sanyawa cikin na'ura ko wata na'urar, kada ka saka kai kai tsaye ba tare da adaftan da ake bukata ba.

Kariya akan amfanin katin kwakwalwar ajiya

- Kada ka ajiye katin kwakwalwa a daushi.
- Kada ka taba wurin sadarwa da hannunka ko wani karfe.
- Kada ka gode, ja, ko dankwafar da katin kwakwalwar ajiyar.
- Kada ka yikorarin sake hada ko kara katin kwakwalwar ajiyar.
- kada a yi amfani ko ajiye katin kwakwalwar ajiyar a wuri mai gumi ko zafi ko yayayi kusa da mota alokacin zafi, a hasken rana kai tsaye ko kusa da zafi da sauransu.

- Kada ka latsa ko lankwasa mahadin karshe katin kwakwalwar ajiyar da karfi mai yawa.
- Kada a bar shi da datti, kura, koko wani abu bako awurin da ya shiga cikin zongon adaftar kowane katin kwakwalwar ajiya.
- Bincika cewa an saka katin kwakwalwar ajiyar a daidai.
- Saka katin kwakwalwar ajiyar yadda zai tafi inda ya dace a mahadin katin kwakwalwar ajiyar. Katin kwakwalwar ajiyar ba zai aiki cikakke ba sai an saka adaidai duka.
- Muna ba da shawara cewa ka tabbatar ka ajiye kwafin bayanai. Ba za mu dauki alhakin duk wani rashiba ba ko lalacewar a bun ciki da ka ajiye a katin kwakwalwar ajiyar.
- Bayanan da aka dauka zasu iya lalacewa ko rasa su su lokacin cire katin kwakwalwar ajiyar ko mahadin katin kwakwalwar ajiyar, kashe wuta lokacin tsarawa, karantawa korubuta bayanai, ko amfani da katin kwakwalwar ajiyar a wurin da ya dace a wuta mare motsi ko sakin wuta fiye da kima.

Kariya na bayanan sirri

Don amintaccen gadin sirrin ka da kiyaye bayani samun damar zuwa mutum na uku, yakamata kashare bayanan sirri kafin sayar ko tsara abin sana a. Don share bayanan sirri, yi sake saiti zuwa na ainihi kuma cire katin kwakwalwar ajiya. SHARE KAYA DAGA KATIN KWAKWALWAR AJIYA BAYA TABBATAR DA CEWA BAYANIN DA AKA FADA BAZA A IYA DAWO DASU TA MAI AMFANI NA YANZU BA. SONY ERICSSON BAZAI BADA GARANTI GA MAI AMFANIN YANZU NA NA'URA WUCEWA ZUWA BAYANIN KA KUMA BAZAI DAUKI KOWANE ALHAKI DON BUDEWA MAI BIYOWA NA BAYANIN DA AKA FADA KO DA ANYI SAKE SAITI ZUWA NA AINIHI. Idan irin wannan kwakwafi ya shafeka kyautata na'uraraka ko kiyaye fashewar ta mai dawwama.

Na'urorin haɗi

Sony Ericsson ya bada shawarar amfani da na'urorin Sony Ericsson don aminci da isasshen amfanin samfur. Amfanin na'urorin haɗi na mutun na uku zai iya rage aikin ko sanya hadari zuwa lafiyar ka ko aminci.

GARGADI DA BABBAR MURYA:

Dai-dai ta karar abu mai juuwuwa akai-akai lokacin amfani da na'urorin haɗi na mutun na uku don kiyaye matakan kara wanda zai iya zama cutarwa ga jinka. Sony Ericsson bai gwada amfanin na'urorin haɗin na mutun na uku tare da wannan wayar hannu ba. Sony Ericsson ya bada shawarar amfani kawai da na'urorin haɗi masu juuwuwa na asali na Sony Ericsson.

Kare lasin yanjejeniyar mai amfani

Wannan na'ura mara waya wanda ya taradda rashin iyakar kowane mai jarida da aka bayar tare da na'ura, ("Na'ura") ya kunshi software Sony Ericsson Mobile Communications AB da kamfanonin tarayyar sa ("Sony Ericsson") da wakilai da masu lasisin sa na uku ("Software").

Azaman mai amfani da wannan na'ura, Sony Ericsson ya baka lasisi wanda ba keɓantacce, wanda baza a iya canja masa wuri, wanda baza a iya sa hannu don amfani da software kawai a cikin rintsi tare da na'ura wanda a kanta aka shigar kuma/ko aka bayar tare. Babu wani abu da aka sanya azaman sayar da saofware don na'urar mai amfani.

Ba za ka iya sake gyrawa, karawa, sauyawa, haɗawa, watsa, da sauransu ko amfani da kowane abu don buɗe lambar tushe na software ko duk

abin da software ya kunsu. Don nisantar shakku, akowane lokaci ana haɗa ka da canja wurin hakkin mallaka da hakkoki zuwa software zuwa wakili na uku, tare da na'ura da ka karɓi software kawai, ana bada wa akoyaushe cewa wakili na uku ya amince a rubuce cewa ya amince da waɗanan dokoki.

Kana da garantin wannan lasisi na amfanin tsawon rayuwar wannan na'ura. Zaka iya mayar da duk hakkokin lasisi zuwa na'urar da ta karɓi software wakili na uku, a rubuce. Idan baka bada haɗin kai ga kowane dokoki da halaye da aka shmfida a cikin wannan lasisi, zai tsaya da gaggawa.

Sony Ericsson da wakilan sa na uku da masu lasisi sune keɓantattun masu da kiyaye duk hakkokin mallaka, take da sha'awa cikin da zuwa software. Sony Ericsson, da, zuwa mutuka cewa software ta kunshi kaya ko lambar mutum na uku, mutumin na uku, za'a bashi taken riba na uku na waɗannan tsawon lokutan.

Nagarta, kira da aikin wannan lasisi suna karkashin dokokin Sweden. Kayan zasu yi aiki sosai da izinin da aka bada ta kayan aiki da damar hakkin mabukatar.

Garanti mai iyaka

Sony Ericsson sardarwar tafi da gidan ka AB, SE-221 88 Lund, Sweden, (Sony Ericsson) ko kamfanin su na cikin gida, suna bada kayyadajjen garanti na wayar hannu da na'urorin haɗe-haɗe na asali da aka kawo da kan waya (nan gaba ka koma ga "na'ura").

shin na'urarka zata bukaci garantin sabis, ka maida ta wajen wanda aka saya, ko ka tuntuɓi ofishin cibiyar kiran Sony Ericsson (Za a yi aiki da kiman kuɗin kasarka) ko ziyarci www.sonyericsson.com don samun bayani na gaba.

Garantinmu

Bugu da kari ga halayen wannan garanti mai iyaka, Sony Ericsson yayi garanti wannan samfur don zama mai ingancin kira, kayan aiki da ma aikacin sana'a a asalin lokacin da dankausuwa ya saya. Wannan garanti mai iyaka zai dauki tsawon shekara (1) daya kamar daga asalin kwanan watan sayan samfur.

Abin da zamu yi

Idan, yayin lokacin garanti, wannan samfur ya kasa aiki a karkashin amfani da sabis na al'ada, saboda matsalar kira, kayan aiki ko da ma aikacin sana'a, masu rabawa ko abokan sabis, a cikin kasa* inda kasayi samfur, zasu, a zabubbukan su, ko gyara kosauya samfur dangane da sharuɗɗa da halaye da aka shimfiɗa a ciki.

Sony Ericsson da abokansa na sabis sun tanadi hakkin biyan kuɗi idan samfurin da aka dawo dashi baya karkashin garanti dangane da halaye na kasa.

Lura cewa waɗansu saitunan ka na sirri, saukewa da wani bayani zasu iya bacewa lokacin da aka gyara ko sauya samfur naka Sony Ericsson. A halin yanzu zartattun dokoki suna iya kiyaye Sony Ericsson, waɗansu ka'idoji ko kuntatawa na fasaha daga yin kwafin takamammen saukewa. Sony Ericsson bazai dauki dauki kowane alhakin bacewar kowane irin bayani kuma bazai mayar makaɗa da kowacce irin asara ba. Kayi koyaushe kwafin duk bayanana da suke ajiyyayu akan samfur naka na Sony Ericsson kamar saukewa, kalanda da lambobi kafin bada samfur naka na Sony Ericsson don gyara ko sauyawa.

Sharuɗɗa

- 1 Wannan garanti mai iyaka yana aiki ne kawai idan tabbacin asalin sayan wannan abin sana'a anyi shi ne ta dila mai izini na Sony Ericsson dayake kididdige kwanan watan saya da lambar serial**, da aka gabatar tare da samfur don gyara ko sauyawa. Sony Ericsson ya tanadi damar kin

sabis na garanti idan an cire ko canja wannan bayani bayan asalin sayan abin sana'a daga wurin dila.

- 2 Idan Sony Ericsson yana gyara ko sauya samfur gyara don illa ya shafi, ko samfurin da aka sauya za'a bashi garanti zuwa ragowar lokacin garanti na asali ko zuwa kwana (90) daga ranar gyara, komai tsawon sa. Gyara ko sauyawa na iya kuste a amfanin kayan aiki wanda suke daidai da matsayin waya na da. Juzu'ai da aka sauya ko aka gyara zasu zama mallakar Sony Ericsson.
- 3 Wannan waranti ba zai maye abin da aka bata ko wulakanta na na'ura ko mammunan aiki, wanda ya haɗa da wuce aikin sa na ka'ida, a yadda Sony Ericsson ya bada wajen kula da na'ura. haka nan wannan garantin baya maye gurbin kowane lalacewar samfur saka makon haɗari, gyara ko dai-dai ta software ko hardware, yin Allah ko lalacewa saka makon shigar ruwa. Za'a iya caji ko cire cajin baturi mai cajuwa fiye da sau dari. Ko yaya, zai lalace a karshe - wannan ba matsala kuma yayi dace da lalacewa ta al'ada. Lokacin magana ko jiran aiki an kula yayi gajarta, lokacin ake sauya baturi. Sony Ericsson yabada shawara cewa kayi amfani da batura ko caji yardaddu ta Sony Ericsson.
- Kananan sabani a cikin nunin haske da launi zai yiwu yafaru tsakanin wayoyi. Za a iya ganin kananan haske da ɗigon duhu a fuskar. Wannan fatsi-fatsin na bayyana da zaran ɗigon haske ya sami matsala kuma ba za a yi gyara ba. Baɗattun fatsi-fatsi guda biyu ana baukar su karɓabɓue.
- Karamin sabani a cikin bayyanar hoton kamara zai yiwu tsakanin wayoyi. Wannan ba wani abune da ba'a saba dashi ba kuma ba'a la'akari dashi azaman bacin kamara a koyaushe.
- 4 Tunda tsarin selula na aiki wanda aka kawo ta mai ɗauka wanda kecin gashin kanshi daga Sony Ericsson, Sony Ericsson ba zai dauki nauyin aiki, samuwa, daukar foto, sabis ko kewayon wannan salon.

- 5 Wannan garanti ba zata ɗauke nauyin lalacewa ta hanyar shigar da sabbin kayan aiki ba, haɓakawa ko gyara ta hanyar buɗe kan waya a wajen wanda ba dillalan Sony Ericsson bane.
- 6 Garantin bata ɗauke da nauyin lalacewa ta hanyar aiki da wasu kayan na'urar hade-hade wanda basu da nasaba da kayan Sony Ericsson na asali, wanda suka dace da na'urar.
- 7 Balle wasu kananan takardu da aka makala a jikin injin waya zai bata garantin.
- 8 BABU GARANTIN KAI TSAYE A RUBUCE KO FADE SABANIN WANDA AKA BUGA A JIKIN NA'URA. DUK GARANTIN DA AKA GABATAR, BA TARE DA IYAKANCE GARANTIN CINIKI KO CANCANTA DON AIKI NA MUSAMMAN, SUN TSAYA A KAN LOKACIN DA AKA KIYASTA NA WANNAN GARANTI. BABU WANI ABIN FARUWA DA SONY ERICSSON DA MASU LASISINTA ZASU ALHAKIN DOKA DON BAZATA KO LALACEWA MAI BIYO BAYA NA KOWANE HALI KOWANE IRI YAGAMA DA AMMA MARA IYAKA DON RIBAR DA AKA RASA KO BACEWAR CINIKI; ZUWA MATUKAR IYAKA DOKA BAZA TA YARDA DA WANNAN LALACEWA BA.

Wasu kasashe/jahohi basa izinin hani ko iyakance lalacewa mai biyo baya ko ta bazata, ko iyakance lokacin tabbataccen garanti, don haka iyakancewar data gabata ko hani baza tayi aiki a kanka ba.

Garanti da aka bada ba zai tasiri a matsayin hakkin na dokokin ka'idar da aka dorawa mabukata na al'ada, ko hakkokin mabukata akan dila ana iya daga shi daga cinikin su/sallamawa.

***Gwargwadon tsawin garanti na jogarafi**

Idan ka sayi samfur naka a cikin kasa 'yar kungiyar shashin tattalin arziki na kasshen turai (EEA) ko a Switzerland ko Turkey kuma anyi nufin asyar da samfurin a cikin EEA ko Switzerland ko Turkey, samfur naka zai iya aiki a kowane kasar EEA ko cikin Switzerland ko cikin Turkey, karkashin sharuɗɗa masu mallaka a cikin kasar da kake bukarat sabis, idan har cewa ana sayar da samfurin a cikin wannan kasar ta mai rabawa na Sony Ericsson mai izini. Don gano idan ana sayar da samfur naka a cikin kasar da kake ciki, kira wurin kiran Sony Ericsson na gida. Kiyaye cewa takamammen sabis bazai yiwu a wani wuri ba acikin kasar asalin saya ba, misali a hakika abin samfur naka zai iya samin banbancin ciki ko waje daga irinsa wanda aka sayar a wasu kasashe. Lura cikin kari cewa bazai yiwu wasu lokuta a gyara kayan rufe sim.

****** A wasu kasashe/jihohi zai yiwu a bukaci karin bayani (kamar katin garanti mai aiki).

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.



Declaration of Conformity

We, **Sony Ericsson Mobile Communications AB** of Nya Vattentornet SE-221 88 Lund, Sweden

declare under our sole responsibility that our product

Sony Ericsson type AAD-3252011-BV

and in combination with our accessories, to which this declaration relates is in conformity with the appropriate standards 3GPP TS 51.010-1, EN 301908-1, EN 301489-7, EN 301489-24, EN 300328, EN 301489-17 and EN 60950, following the provisions of, Radio Equipment and Telecommunication Terminal Equipment directive **99/5/EC** with requirements covering EMC directive **89/336/EEC**, and Low Voltage directive **73/23/EEC**.

Lund, April 2007

CE 0682

A handwritten signature in black ink, appearing to read 'Shoji Nemoto'.

Shoji Nemoto, *Head of Product Business Group GSM/UMTS*

Mun cika sharadin bayanin R&TTE (**99/5/EC**).

Fihirisa

A

abin sawa a kunni	24, 45
Fasahar Bluetooth	57
Abokaina	35
agogon gudu	66
aikace-aikace	52
aikawa	
alkawurra da dawainiya	65
bayanana kula	66
hotuna	42
katunan kasuwanci	22
kiɗa	46
launukan waka da sautin ringi	51
aiki tare	59
allon farawa	7
Alkawurra	64
amsa murya	25

B

Baturi	
amfani da kula	77
Caji	7
sakawa	5
bayanana kula	66
bayanana martaba	68

C

canja wuri	
fayiloli	58
hotunan kamara	41
kiɗa	46
sauti	57
cire katangar katin SIM	69
Ciyarwar yanar sadarwa	55

D

Daukaka sabis	61
declaration of conformity	84

E

e-mail	33
--------------	----

F

Fasaha mara waya	
ta Bluetooth™	56

G

Gajerun hanyoyi	13
Garanti mai iyaka	81

H

halin kwakwalwar ajiya	21
hanyar canja wuri	
Fasahar Bluetooth	56
USB	58
harshe	15

hadawa	5
hotuna	42
shiryawa	44

I

ikon murya	24
Intanit	
alamun shafi	54
saituna	53
tsaro da takaddun shaida	55

J

jagorar kiyayewa	76
Java™	52
jiran aiki	7

K

Kafaffen bugun kira	28
Kalanda	64
Kalkuleta	66
kalmar sihiri	24
kara	
lasifikar kunni	17
sautin ringi	50
karamin menu	12
Kararrawa	63
karkata kira	25
katin SIM	
kulle kuma cire katanga	69
kwafi zuwa/daga	20, 21
katin kwakwalwar ajiya	13
katunan kasuwanci	22

kayan kida	45
------------------	----

kira

amsa da kin amsa	17
bidiyo	18
gaggawa	18
karba	27
karbar kira biyu	26
sanyawa a riko	26
waje	17
Yin kira da karba	17
yin rikodi	51
ɗauka	51
Kiran taro	27
Kungiyar taɗi	22
kunnawa/kashewa	
Bluetooth	56
kiyaye makullin SIM	69
makullin waya	70
kwanan wata	68
kyamera	
saituna	40
siffa	38

L

Lambana	27
Lambar IMEI	70
lambar memo	67
lambar PIN	
caji	69
cire katanga	6
lambobi	

aiki tare	59
Tsofaffin lambobi	19
kara lambobin waya	19
lambobin gaggawa	18
lambobin kira a sako	30
lissafin kira	23
lokaci	68
lokacin kira	29

M

mai kunna bidiyo	45
mai rikodin bidiyo	38
mai rikodin sauti	51
mai sarrafa fayil	13
Mai sarrafa Mai jarida	46
mai kdy. lokc.	66
makirufon	17
makulli	
faifan maballi	70
katin SIM	69
waya	70
Makullin faifan maballi	70
maballai	8
Menu na ayyuka	13
menu na kewayawa	12
menus	12
MMS	30
MusicDJ™	51

P

PhotoDJ™	44
pictures	
shirya	44
PlayNow™	49
PUK	6, 69

S

Sabis na amsa	24
sabis na amsa	23
saituna	
Intanit	53
Java™	53
sake bugun kira na atomatik	17
sake saitin ainihi	71
samfura	32
samun email	35
saurin bugun kira	23
sautin kararawa	50
sakon murya	23
sakonni	
bayanin wuri da salula	37
email	33
hotuna	30
murya	33
rubutu	30
sakonnin murya	33
shafukan hoto	43
Shigar da rubutu	16
shiyar lokaci	69
SMS	30
Sunan waya	54

T

T9™ Text Input	16
taimako	7
takaitaccen bayanana menu	10
takamaiman sautunan ringin mai kira	20

W

wasanni	52
---------------	----

Z

Zabubbukan tabawa	12
zukowa	39