

Godiya a gareka don siyan Sony Ericsson W350i.
Ji daɗin kiɗanka duk inda kaje.

Don karin abun cikin waya, je zuwa *www.sonyericsson.com/fun*.

Yi rijista yanzu do samun ingantattun kayan aiki, ma'ajin
kan layi kyauta, tayi na musamman, labarai da gasa
a *www.sonyericsson.com/myphone*.

Don goyan bayan samfur, jeka *www.sonyericsson.com/support*.

Na'urorin haɗi – Kari don wayarka

MPS-70 Lasifikoki masu Daukuwa

Kanana amma karfafan lasifikoki
masu dacewa da aljihunka



HPM-83 Abin sawa akunni mai Daukuwa na Sitiriyo

Salon-hanya na'urar kai mai
maɗaurin wuya tare da mafificin
aikin mai juwuwa



HBH-DS200 na'urar kai ta Bluetooth™ na sitiriyo

Ji daɗin kiɗa mara waya ba tare
da rasa kira ba

Waɗannan nau'urorin haɗin za'a iya sayansu
daban amma maiyuwa ba za'a same su a
kowacce kasuwa ba. Don duba cikakken
kewayon je zuwa

www.sonyericsson.com/accessories.



Abubuwan ciki

Farawa 5

Hadawa	5
Kunna waya	6
Taimako a wayarka	7
Cajin baturi	8
Siffar waya	9
Sifar Menu	11
Gunkin sandar yanati	12
Kewayawa	13
Gajerun hanyoyi	15
Mai sarrafa fayil	16
Yaren waya	18
Shigar da rubutu	18

Walkman® da kiɗa 19

Canja wurin kiɗa zuwa da daga kwamfuta	19
Mai kunna Walkman®	21
PlayNow™	23
TrackID™	24

Kira 24

Yin kira da karɓa	24
Kiran gaggawa	25
Lambobi	25
Kungiyoyi	28

Lissafin kira	29
Bugun kiran sauri	29
Sakon murya	29
Karkatar da kira	30
Fiye da kira ɗaya	30
Karɓan kiran murya guda biyu	31
Kiran taro	31
Lambobi nawa	32
Karɓi kira	32
Kuntataccen bugun kira	32
Kafaffen bugun kira	33
Lokacin kira da farashi	33
Katunan kasuwanci	34

Sako 34

Sakonnin rubutu	34
Sakonnin hoto	36
Samfura	37
Sakonnin murya	38
Email	38
Abokai nawa	41
Bayanin wuri da salula	43

Hoto 43

Kamara	43
Canja wurin hotuna	45
Hotuna	46

Nishafi	47	Jigogi	67
Rediyo	47	Makullai	67
Sautunan ringi da launukan waka ...	48	lambar IMEI	68
MusicDJ™	49	Shirya matsala	69
Mai rikodin sauti	50	Tambayoyi na gama gari	69
Mai kunna bidiyo	50	Kuskuren sakonni	71
Wasanni	50	Muhimman bayanai	72
Aikace-aikace	50	Bayanai don lafiya da rinjaye	
Haƙi	52	amfani	74
Saituna	52	Garanti mai iyaka	78
Amfani da Intanet	52	FCC Statement	80
Mai karanta RSS	54	Declaration of Conformity	
Fasaha mara waya ta Bluetooth™ ..	54	for W350i	81
Amfani da kebul na USB	56	Fihirisa	82
Aiki tare	58		
Daukaka sabis	59		
Karin fasali	61		
Kararrawa	61		
Kalanda	61		
Dawainiya	63		
Bayanan kula	64		
Mai kidayar lokaci, agogon awon			
gudu da kalkaleta	64		
Memo na lamba	65		
Bayanan martaba	66		
Lokc.da kwn.wata	66		

Sony Ericsson W350i

GSM 900/1800/1900

An buga wannan jagorar mai amfani ta Sony Ericsson Mobile Communications AB ko kamfanin hadin gwiwarsu na gida, batareta wani garanti ba. Ingantawa da canje-canje ga wannan jagorar mai amfannin wanda kuskuren rubutu ya haifar, rashin daidaiton bayanin yanzu, ko inganta tsare-tsare da/kokayan aiki, mai yiyuwa a aiwatar da su ta Sony Ericsson Mobile Communications AB ko abokan hadin gwiwarta akowani lokaci batareta sanarwa ba. Irin wadannan canje-canjen zasu, koyaya, kasance cikin wannan sabon jagorar mai amfanin.

An adana duk hakkoki.

©Sony Ericsson Mobile Communications AB, 2008

Lambar daba'a: 1209-1193.2

Kula:

Wasu sabis a wannan jagorar mai amfanin basu da goyan bayan duk cibiyoyin sadarwa. *Wannan kuma ya shafi GSM Lambar Gaggawa ta Kasashen waje 112.*

Tuntuɓi afaretan cibiyar sadarwarka ko mai bada sabis idan kana cikin shakka ko zaka iya amfani da sabis na musamman ko a'a.

Karanata *Shafukan bayani mai mahimmanci* Kafin amfaninka da wayarka na hannu.

Wayarka ta hannu tana da damar saukewa, ajewa da tura karin abun ciki, misali sautin ringi. Zai iya amfani da abin ciki mai yiyuwa a kuntata ko haramta ta hakkin bangare na uku, amma ba iyakance ga kuntatawa karkashin zartattun dokokin hakkin mallaka ba. Kaine, ba kuma Sony Ericsson, ke da alhakin karin abun ciki wanda ka sauke zuwa ko ka tura daga wayarka ta hannu. Kafin amfaninka ga kowane karin abun ciki, tabbatar cewa amfanin da kayi nufi yana da lasisi mai kyau ko kuma yana da izini. Sony Ericsson baya bada garantin daidai, mutunci ko ingancin kowane karin abun ciki ko

kowane abun ciki na bangare na uku. Babu wani dalili da zaisa Sony Ericsson yazama abin dogaro na gameda amfaninka mara inganci na karin abun ciki ko lamba na wani bangare na uku.

Bluetooth alamar kasuwanci ce ko alamar kasuwanci ce mai rijista na Bluetooth SIG Inc. Kuma duk wani amfani na irin wannan alamar ta Sony Ericsson yana karkashin lasisi.

Ruwan tambarin sheda, PlayNow, TrackD da MusicDJ alamun kasuwanci ne ko alamun kasuwan ne masu rijista na Sony Ericsson Mobile Communications AB.

Tambarin Sony, Memory Stick Micro, M2, WALKMAN da WALKMAN alamune na kasuwancu ko alamun kasuwanci ne masu rijista na Sony Corporation.

Ericsson alamar kasuwanci ce ko alamar kasuwanci mai rijista ta Telefonaktiebolaget LM Ericsson.

Adobe® Photoshop® Album Starter Edition alamun kasuwanci ce ko alamun kasuwanci masu rijista ta Adobe Systems Incorporated a Amurka da/ko wasu kasashe.

TrackID ikon Gracernote Mobile MusicID™.

Gracernote da Gracernote Mobile MusicID alamune na kasuwanci ko alamune na kasuwanci masu rijista na Gracernote, Inc.

Microsoft, Windows, Outlook and Vista alamune na kasuwanci ko alamune ma kasuwanci wasu rijista na of Microsoft Corporation a Amurka da/ko wasu kasashe.

T9™ Text Input alamar lasuwanci ce ko alamar kasuwanci ce nai rijista na Tegic Communications. T9™ Text Input anyi lasinsinsa karkashin daya ko fiye na masu biyowa: U.S. Pat. Nos. 5,818,437, 5,953,541, 5,187,480, 5,945,928, da 6,011,554; na Kanada Pat. No. 1,331,057, Burtaniya Pat. No. 2238414B; Hon Kon Standard Pat. No. HK0940329; Jumhuriyar Singafo Pat. No. 51383; Euro.Pat. No. 0 842 463(96927260.8) DE/DK, FI, FR, IT, NL, PT, ES, SE, GB; da kuma karin hakkokin aiwatarwa na duniya masu jiran zartarwa.

Java da duk kafaffun alamun kasuwanci na Java da tambura alamun kasuwanci ne ki alamun kasuwanci ne masu rijista na Microsystems, Inc. a Amurka da wasu kasashe.

Kare yarjejeniyar lasisin mai amfani na Sun™ Java™ J2ME™.

Kuntatawa: Software bayanin hakkin mallaka ne na sirri na Sun kuma an rike duk take na kwafi ta Sun da/ko masu lasisinsa. Abokin ciniki bazai gyaggyara, watsa, tarwatsa, sauya, cire, ko kuma baya da fasahar Software ba. Software bazai yuwu ayi hayarsa, raba aikinsa, ko yin lasisinsa, gaba daya ko a sashi ba.

Dokokin fitarwa: Software, gamida bayanana fasaha, an tsara shi da dokokin sarrafa fitarwar Amurka, gamida tsarin aikin fitarwar Amurka da dokokinta masu dangantaka, kuma maiyuwa tsari ne na dokokin fitarwa ko shigarwa na wasu kasashe. Abokin ciniki ya amince da bin duk waɗannan dokokin kuma ya sani cewa tana da alhakin lasisi don fitarwa, sake-fitarwa, ko shigo da Software. Software bazai yuwa a saukeshi, ko kuma fitar dashi ko sake-fitar dashi, (i) cikin, ko zuwa ɗan kasa ko mazaunin, Kyuba, Iraki, Iran, Koriya ta Arewa, Libiya, Sudan, Siriya (kamar yadda aka fahimci wannan lissafin za'a rika bita daga lokaci zuwa lokaci) ko kowace kasa wanda Amurka ta sawa takunkumin kaya; ko (ii) ga kowane mutum a lissafin Zababɓun ma'aikata na Musamman Keɓabɓu a Ma'aikatar Kudɓi ta Al'ummar Amurka ko Teburin Dokokin Inkari na Ma'aikatar Cinikin Amurka.

Takaitattun hakkoƙi: Amfani, kwafi ko kwakƙwafi ga hukumar Amurka batune na takaitawa azaman na huɗu hakkoƙi cikin bayanana fasaha da software na kwamfuta sayayye cikin DFARS 252.227-7013(c) (1) (ii) da FAR 52.227-19(c) (2) azaman abin zartarwa. Wani samfurin da sunayen kamfani ambatattu nan ciki sa iya zama alamun kasuwancine na masu mallakarsu.

An adana hakkoƙin da ba'a fayyace garantunsa nan ciki ba.

Duk zanuka don zanene kawai kuma maiyuwa baza su dace da ainihin wayar ba.

Alamun Umarni

Masu biyowa suna bayyana a jagorar mai amfani.



Bayanin kula



Tukwici



Gargaɗi



Sabis ko aiki sun dogara da cibiyar sadarwa ko biyan kudi. Tuntubi afaretan cibiyar sadarwarka don cikakkun bayanai.

- > Yi amfani da maɓallin zaɓi ko kewayawa don gungurawa da zaɓi. Duba *Kewayawa* a shafi na 13.



Latsa tsakiyan maɓallin kewayawa.



Latsa saman maɓallin kewayawa sama.



Latsa maɓallin kewayawa kasa.



Latsa maɓallin kewayawa hagu.



Latsa maɓallin kewayawa dama.


Farawa

Hadawa

Lafin kafara amfani da wayarka, kana bukatar saka katin SIM da baturi.


- ! Dole a cire baturi kafin ka fin shigar da katin SIM ko cirewa.

Don saka katin SIM



- 1 Cire murfin baturin.
- 2 Zamar da katin SIM dɓn cikin marikinsa tareda lambobi suna fuskantar kasa.


Don saka baturi



- 1 Saka baturin tare da lambar gefe kasa kuma masu haɗin suna fuskantar juna.
- 2 Sake sa murfin baturin.

Don cire baturi

- 1 Cire murfin baturin.
- 2 Shigar da Kunbarka a sararin farkon rubutu.
- 3 Cire baturi.



Kunna waya

Don kunna wayar



- 1 Latsa ka rike kasa (☎).
 - 2 Zabi yanayi:
 - **Na al'ada** – cikakkun ayyuka.
 - **Yanayin kaura** – ayyuka masu iyaka.
 - 3 Shigar da PIN na katin PIN naka, idan an nema.
 - 4 Zabi yare.
 - 5 Zabi **Ee** don amfani da saitin maye.
- ! **Idan kana son ggyara kuskure lokacin da ka shigar da PIN naka, latsa (☎).**

Katin SIM

Katin (Farin dutsen Asalin Mamba) SIM, wanda ka samo daga afaretan cibiyar sadarwarka, ya kunshi bayanin kuɗin shiga naka. Koyausha kashe wayarka kuma cire caji da baturi kafin saka ko cire katin SIM.

- *Zaka iya ajiye lambobi a katin SIM naka kafin ka cire shi daga wayarka. Duba Don kwafe sunaye da lambobi zuwa katin SIM a shafi na 26.*

PIN

Maiyuwa ka bukaci PIN (Personal Identification Number) don kunna sabis a wayarka. Ana kawo PIN naka ta afaretan cibiyar sadarwarka. Kowane PIN yana bayyana azaman *, saidai in ya fara da lambar gaggawa, misali, 112 ko 911. Zaka iya dubawa da kiran lambar gaggawa ba tare da shigar da PIN ba.

Don share lambobi daga nunin

- Latsa (C_o).

- *Idan ka shigar da PIN kuskure sau uku a jere, An katange PIN yana bayyana. Don bude shi, kana bukatar shigar da PUK naka (Personal Unblocking Key). Duba Kulle katin SIM a shafi na 67.*

Yanayin kaura

A **Yanayin kaura** cibiyar sadarwa da watsa radiyo ana kashe su don kare tsangwama ga kayan aiki mai mahimmanci.

- *Zaka iya amfani da aikin Bluetooth™ a yanayin kaura.*



Allon farawa

Allon farawa yana bayyana lokacin da ka kunna wayarka. Duba *Amfani da hotuna* a shafi na 46.

Jiran aiki

Bayan ka kunna wayarka da shigarda PIN naka, sunan afaretan cibiyar sadarwarka yana bayyana a allon. Wannan ake kira jiran aiki.

Taimako a wayarka

Akwai taimako da bayani acikin wayarka ako wane lokaci. Duba *Kewayawa* a shafi na 13.

Don amfani da saita maye

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba daya](#) shafin > [Saita maye](#).
- 2 Zaɓi wani zaɓi.

Don duba bayani gameda ayyuka

- Gungura zuwa aiki kuma zaɓi [Bayani](#), idan akwai. A wasu halaye, [Bayani](#) yana bayyana karkashin [Kari](#).
- **Don duba siffar waya**
 - Daga jiran aiki zaɓi [Menu](#) > [Nishaɗi](#) > [Zagawar Demo](#).

Sauke saituna

Zaka iya sauke saituna zuwa wayarka. Wadannan saitunan zasu baka damar amfani da ayyuka waɗanda suke buƙatar lissafin intanet, misali, yin sakon hoto da email.

Don sauke saituna

- Daga jiran aiki zaɓi **Menu > Saituna > Gaba ɗaya shafin > Saita maye > Saukar da saituna.**

! Tuntuɓi afaretan cibiyar sadarwarka ko mai bada sabis don karin bayani.

Cajin baturi

An ɗanyi cajin baturin wayar lokacin daka saya.

Don cajin baturi



- 1 Haɗa caji zuwa waya. Yana ɗaukar kimanin awa 2.5 don cikar cajin baturi.
- 2 Cire cajar ta karkatar da filogi sama.

💡 Zaka iya amfani da wayarka yayin da take caji. Zaka iya cajin baturi a kowane lokaci kuma fiye ko kasa da awa 2.5. Zaka iya katse caji ba tare da bata baturin ba.

Siffar waya

- 1 Kulle maballin kiɗa
- 2 Walkman® player control
- 3 Allo
- 4 Zabi maballi
- 5 Maɓallin baya
- 6 Mai haɗi saboda caja, abin sawa a kunni da kebul na USB
- 7 Maɓallin sharewa
Maɓallin kunnawa/kashewa
- 8 Maɓallin kewayawa
- 9 Maɓallin shiru
- 10 saurin turawa (maɓalin kiɗa)
- 11 Kunna/Tsayar/Dagatar (maɓallin kiɗa)
- 12 Koma baya (maɓallin kiɗa)
- 13 kwankwasawa



- 14 Ruwan tabarau na kamara
- 15 Kara, maɓallai daidaita haske
- 16 Lasifika



Sifar Menu



PlayNow™*



Intanit*



Nishadi

Ayyukan kan layi*
Wasanni
TrackID™
Kayan bidiyo
MusicDJ™
Yi rikodin sauti
Zagawar Demo



Kamara



Sako

Rubuta sabuwa
Akw. s. m. shig.
Email
Mai karanta RSS
Tsararr. sakonni
Akwt.sk.mai fita

Sako da ak. aika
Ajiyayyu. wasiku
Abokai nawa*
Kira skn. murya
Samfura
Saituna



WALKMAN



Mai sarrafa fayil**



Lambobi



Rediyo



Kira**



Duk



An amsa



An buga



An rasa



Oganeza

Kararrawa
Aikace-aikace
Kalanda
Dawainiya
Bayanan kula
Aiki tare
Mai kidy. lokaci
Aggn.awn. gudu
Kalkaleta
Memo na lamba



Saituna**



Gaba daya

Bayanan martaba
Locc. & kwn.wt.
Yare
Sabis na ɗaukaka
Sab.abun aukuwa
Gajerun hanyoyi
Yanayin kaura
Tsaro
Saita maye
Halin waya
Sake saitin ainihi



Sauti & fadakarwa

Karar ringi
Sautin ringi
Yanayin shiru
Ringi mai karuwa
Faɗakarwar jijjiga
Faɗakarwar gajo
Sautin maballi



Nuni

Fuskar bngn. waya
Jigogi
Allon farawa
Mai boye allo
Haske
Shirya sunayen Iyi.*



Kira

Bugn. kira na sauri
Karkatar da kira
Canja zuwa layi 2*
Sarrafa kira
Lokaci & farashi*
Nun./boy.lamb.na.
Abin sawa akunni
Buɗe domin amsa



Haduwa

Bluetooth
Haɗin USB
Aiki tare
Mai haɗa na'ura
Cbyr. sdrwr. waya
Bayanan sadarwa
Saitunan intanit
Na'urorin haɗi

* Wasu menu sun dogara da afareta-, cibiyar sadarawa- da bayan kudi.

** Zaka iya amfani da maballin kewayawa don gungurawa tsakanin shafuka a karamin menu. Saboda karin bayani, duba Kewayawa shafi 13.

Gunkin sandar yanati

Mai yiwuwa wasu daga waɗannan gumakan su bayyana a allon don nuna halaye da sabbin abin aukuwa.

Gunki Sifantawa



Karfin sigina na cibiyar sadarwar GSM



Yanayin baturi



Cajin baturi, yana bayyana tareda gunkin yanayin baturi



Kira mai shigowa da aka rasa



Sakon rubutu da aka karɓa



Sakon email da aka karɓa



Sakon hoto da aka karɓa



Sakon murya da aka karɓa



Kira mai gudana



An haɗa abin sawa akunni



Rediyo tana kunne a bango



Mai tunin kalanda



Mai tunin ɗawainiya

Kewayawa


Ana nuna menu na ainihi azaman gumaka. Wasu kanan menu sun kunshi shafuka.

Don kewayawa menu na waya

- 1 Daga jiran aiki zabi [Menu](#).
- 2 Yi amfani da maballin kewayawa don motsawa ta cikin menu.

Don gungurawa tsakanin shafuka

- Gungura zuwa shafi ta latsa maballin kewayawa hagu ko dama.



Maballi



Je zuwa menu na ainihi ko don zaɓar abubuwa



Gungurawa tsakanin menu da shafukan



Zabi zaɓuɓɓukan da aka nuna gab da saman waɗannan maɓallan akan allon.



Koma baya mataki ɗaya a menu.

Latsa ka riƙe kasa don komawa zuwa jiran aiki ko don ƙare aiki.



Share abubuwa kamar hotuna, sautuna da lambobi.

Latsa ka riƙe kasa don cire sautin makirufo yayin kira.

Kunna/kashe wayar.







Buɗe Walkman® player.


Latsa don matsawa tsakanin Walkman® player da fayilolin kiɗa.





Latsa ka riƙe kasa don kiran sabis na sakon murya naka (idan an saita).


 -  Latsa ka rike maballin lamba kasa don isa ga lamba da tafara da takamaiman harafi.


 -  Latsa maballin lamba kuma zaɓiKira don saurin bugun kira.

 Latsa don kashe sautin ringin lokacin da ka karɓi kira. Latsa ka rike kasa don saita waya zuwa shiru. Kararrawar tana sigina koda an saita wayar a shiru.

 Latsa don canja halin harafi lokacin rubuta sako. Latsa ka rike kasa don saita T9™ Text Input a kashe da a kunne lokacin rubuta sako.

 Kunna kwankwasawa:
Dakatar/Tsayar/kuma kunna(maballin kiɗa).
Lpkacinda ka rufe kwankwasawa ka kunna Walkman® player.
Latsa bincika tashoshin rediyo ta atomatik.
Latsa sama ko kasa bincika tashoshin rediyo na yanzu.

 Kunna kwankwasawa:
Tsanlaka zuwa waƙar data gabata lokacin amfani da mai kunna Walkman®.
Bncika tashoshin rediyo.

 Kunna kwankwasawa:
Tsanlaka zuwa waka ta gaba lokacin amfani da mai kunna Walkman®.
Bncika tashoshin rediyo.



Kunna gefen wayar.
Duba bayanin hali a jiran aiki.
Rage kara lokacin kiran, ko lokacin da kake amfani da mai kunna waka Walkman®.
Kara haske lokacin amfani da kamara.
Latsa sau biyu don kin amsa kira.
A jiran aiki, latsa saudaya don sa kira mai shigowa shiru.



Kunna gefen wayar:
Rage kara lokacin kiran, ko lokacin da kake amfani da mai kunna waka Walkman®.
Rage haske lokacin amfani da kamara

Gajerun hanyoyi

Zaka iya amfani da gajerun hanyoyin faifan maɓalli don tafiya zuwa menu. Kidayar menu tana farawa daga gunkin hagu na sama kuma tana ketarawa kuma sannan kasa layi-layi.

Don zuwa kai tsaye ga menu na bakwai

- Daga jiran aiki latsa [Menu](#) kuma zaɓi

Don amfani da gajerun hanyoyin maɓallin kewayawa

- Daga jiran aiki zaɓi , , ko don tafiya kai tsaye zuwa aiki.

Don shirya gajerar hanyar maɓallin kewayawa

- 1 Daga jiran aiki zaɓi i [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Gajerun hanyoyi](#).
- 2 Gungura zuwa zaɓi kuma zaɓi [Shirya](#).
- 3 Gungura zuwa zaɓin menu kuma zaɓi [Gj. hanya](#).

Mai sarrafa fayil


Zaka iya amfani da mai sarrafa fayil don mu'amala da ajiyyayon fayiloli a kawakwalwar ajiyar wayar ko a katin kwakwalwar ajiyar waya.

! Zaka iya sayan katin kwakwalwa ajiya daban.

Katin kwakwalwar ajiya

Wayarka tana goyan bayan Memory Stick Micro™ (M2™) katin kwakwalwar ajiya kara dadin sararin ma'aji zuwa wayarka. Hakanan za'a iya amfani da shi azaman katin kwakwalwar ajiya mai daukuwa tareda wasu na'urori masu jituwa.

Don saka katin kwakwalwar ajiya



- 1 Buxw marikin katin kwakwalwar ajiya.
- 2 Saka katin kwakwalwar ajiyar tareda lambobi masu launin zinare suna fuskantar kasa.
- 3 Rufe marikin katin kwakwalwar ajiya.
- 4 Sabule latin kwakwalwar ajiya don rufe ta.
- 5 Sake sa murfin baturin.

Don duba zaɓuɓɓukan katin kwakwalwar ajiya

- 1 Daga jiran aiki zaɓi [Menu](#) > [Mai sarrafa fayil](#) > [A Memory Stick](#) shafin.
- 2 Zaɓi [Kari](#).

Karɓar fayiloli

Zaka iya matsawa da kwafe fayiloli tskanin wayarka, a kwamfuta da katin kwakwalwar ajiya. An ajiye fayiloli a katin kwakwalwar ajiya da farko sannan a kwakwalway ajiya wayar. Fayilolin da ba'a kula da suba an ajiye su a [Wasu](#) manyan fayiloli.

Zaka iya kirƙiran manyan fayiloli mataimaka do matsarw ko kwafe fayiloli zuwa garesu. Lokacinda kake mu'amala da fayiloli, zaka iya zaɓar fiye da ɗaya ko duk fayiloli a babban fayil a lokaci ɗaya don duk abubuwa banda [Wasanni](#) kuma [Aikace-aikace](#).

Idan kwakwalwar ajiya ta cika, share wasu abubuwan ciki don samun sarari.

Shafukan mai sarrafa fayil

Ana rarraba mai sarrafa fayil zuwa shafuka uku, kuma gumaka suna nuna inda aka ajiye fayilolin.

- [Duk fayiloli](#) – duk abubuwan ciki a kwakwalwar ajiyar wayar da kan katin kwakwalwar ajiya.

- [A Memory Stick](#) – duk abubuwan ciki kan katin kwakwalwar ajiya.
- [Cikin waya](#) – duk abubuwan ciki a kwakwalwar ajiyar wayar.

Don duba bayani game da fayiloli

- 1 Daga jiran aiki zaɓi [Menu](#) > [Mai sarrafa fayil](#).
- 2 Gugura zuwa babban fayil kuma zaɓi [Buɗe](#).
- 3 Gungura zuwa fayil kuma zaɓi [Kari](#) > [Bayani](#).

Don matsar fayil a mai sarrafa fayil

- 1 Daga jiran aiki zaɓi [Menu](#) > [Mai sarrafa fayil](#).
- 2 Gugura zuwa babban fayil kuma zaɓi [Buɗe](#).
- 3 Gungura zuwa fayil kuma zaɓi [Kari](#) > [Sarrafa fayil](#) > [Matsar](#).
- 4 Zaɓi wani zaɓi.

Don zaɓar fayil fiye da ɗaya a babban fayil

- 1 Daga jiran aiki zaɓi [Menu](#) > [Mai sarrafa fayil](#).
- 2 Gugura zuwa babban fayil kuma zaɓi [Buɗe](#).
- 3 Zaɓi [Kari](#) > [Alama](#) > [Alama a yawanci](#).
- 4 Zaɓi [Alama](#) don sawa fayiloli alama.

Don share fayil daga mai sarrafa fayil

- 1 Daga jiran aiki zaɓi **Menu** > **Mai sarrafa fayil**.
- 2 Nemo fayil dɪn kuma latsa **C**.

Yaren waya

Zaka kuma iya zaɓar yare don amfani dashi a wayarka.

Don canja yaren waya

- 1 Daga jiran aiki zaɓi **Menu** > **Saituna** > **Gaba ɗaya** shafin > **Yare** > **Yaren waya**.
- 2 Zaɓi wani zaɓi.

Shigar da rubutu

Zaka iya amfani da shigar darubutu na taɓi dayawa ko T9™ Text Input **T9** don shigar da rubutu. Hanyar T9 Text Input tana amfani da ginannen kamus na ciki.

Don canja hanyar shigar da rubutu

- Lokacin da ka shigar da rubutu, latsa ka riƙe kasa *****.

Don matsawa tsakanin manya da kananan haruffa

- Lokacin da ka shigar da rubutu, latsa *****.

Don shigar da lambobi

- Lokacin da kake shigar da rubutu, latsa ka riƙe kasa **0** – **9**.

Don shigar da aya da wakafi

- Lokacin da ka shigar da rubutu, latsa **1**.

Don shigar da rubutu ta amfani da T9™ Text Input

- 1 Daga jiran aiki zaɓi, misali, **Menu** > **Sako** > **Rubuta sabuwa** > **Sakon rubutu**.
- 2 Idan **T9** bai bayyana ba, latsa ka riƙe kasa ***** don canjawa zuwa T9 Text Input.
- 3 Latsa kowane maɓalli sau ɗaya kawai, koda harafin da kake so ba shine farkon harafi a maɓallin ba. Misali, idan kanaso ka rubuta kalmar “Jane”, latsa **5**, **2**, **6**, **3**. Rubuta duk kalmar kafin duba shawarwari.

- 4 Yi amfani da ☺ ko ☹ don duba shawarwari.
- 5 Latsa (# →) don karɓar shawara.

Don shigar da rubutu ta amfani da taɓi dayawa

- 1 Daga jiran aiki zaɓi, misali, **Menu** > **Sako** > **Rubuta sabuwa** > **Sakon rubutu**.
- 2 Idan **T9** ya bayyana, latsa ka riƙe kasa (*a/n) don canjawa zuwa shigar da rubutu na taɓi d ayawa.
- 3 Latsa (2) – (9) akai-akai harsai harafin da kake so ya bayyana.
- 4 Lokacin da aka rubutu kalma, latsa (# →) don kara asarari.

Don kara kalmomi zuwa ginannen kamus na ciki

- 1 Lokacin da ka shigar da rubutu ta amfai da T9 Text Input, zaɓi **Kari** > **Tad. bakin kalma**.
- 2 Rubuta kalmar ta amfani da shigar da rubutun taɓi dayawa kuma zaɓi **Sa**.

Walkman® da kiɗa

Saurari kiɗa, da safukan mai jiyuwa da podcast. Yi amfani da *Sony Ericsson Media Manager* don canja wurin abun ciki zuwa wayarka.

Canja wurin kiɗa zuwa da daga kwamfuta

Amfani da kebul naUSB da *Sony Ericsson Media Manager*, zaka iya canja wurin abun ciki daga CDs, kwamfutarka ko wayar.



Software na Sony Ericsson Media Manager

An kunsar waɗannan a CD dinda yazo tare da wayarka kuma akwai don saukewa a www.sonyericsson.com/support.

Tsarukan aiki da ake bukata

Kana bukatar ɗaya da cikin waɗannan tsarukan a kwamfutarka don amfani da *software wanda aka sa a CD*:

- Microsoft® Windows Vista™ (32 da 64 yan sigogin na: Karshe, Shirin abu, Kasuwanc, Inshorar Gida Tushan Shafi)
- Microsoft Windows® XP (Pro ko Gida), kunshin Sabis 2 ko mafi girma

Don shigar da Media Manager

- 1 Kunna kwamfutarka kuma saka CD din. D din yana farawa ta atomatik kuma window na shigarwa yana budewa.
- 2 Zabi yare kuma kaɗa OK.
- 3 Kada *Shigar da Sony Ericsson Media Manager* kuma bi umarnin.

Don amfani da abun ciki ta amfani da

- 1 Hada wayar zuwa kwamfuta tare da kebul na USB wanda yazo tare da wayar.
- 2 Kwamfuta: *Farawa/Shirye-shirye/Sony Ericsson/Media Manager*. Jira Media Manager ya fara.
- 3 Waya: Zabi [Cnj. wur. fyil](#). Wayar ka tana kashewa kuma tana bayyana zuwa canja wur fayiloli.

! *Kada ka cire kebul na USB daga wayarka ko kwamfuta yayin canja wuri, saboda wannan zai iya lalata katin kwakwalwar ajiya ko kwakwalwar ajiyar waya.*

- 4 Kwamfuta: Jira har sai wayar tana bayyana a Media Manager.
- 5 Matsar da fayiloli tsakanin wayarka da kwmuta a Media Manager.
- 6 Saboda amintaccen cire haɗi na kebul na USB a yanayin canja wajen fayil kaɗa a dama a gumkin dis mai ciruwa a *Windows Explorer* kuma zaɓi *Fita*.

💡 *Don cikakken bayani akan canja wurin kida, koma ga Taimakon Media Manager. Kada ? asama kususwar dama na window na mai sarrafa mai jarida.*

Abin sawa a kunni mai daukuwa na siteriyo



Don amfani da abin sawa akunni

- Hada abin sawa akunni mai daukuwa. Kida yana tsayawa lokacin da ka karɓi kira kuma yana ci gaba lokacin da kira ya kare.

Mai kunna Walkman®

Don kunna kiɗa

- 1 Daga jiran aiki zaɓi [Menu](#) > [WALKMAN](#).
- 2 Gungura zuwa take kuma zaɓi [Kunna](#).


Ikon mai kunna Walkman®

Zaka iya iko da mai kunna Walkman® tare da waya a buɗe.



Don tsaida kunna kiɗa

- Latsa  .



Don ci gaba da kunna kiɗa

- Daga jiran aiki latsa  kuma zaɓi [Kunna](#).


Don saurin turawa gaba da baya

- Lokacin da kake sauraron kiɗa, latsa ka riƙe kasa  ko .

Don matsawa tsakanin waƙoƙi

- Lokacin da kake sauraron kiɗa, latsa  ko .

Don samun damar fayilolin kuɗa

- Latsa  don sauyawa tsakanin mai kunna Walkman® da fayilolin kiɗa.

Don canja kara

- Latsa  ko .

Maballan kiɗa

Ana amfani da maɓallan kiɗa don iko da mai kunna Walkman® da kwankwasawa a rufe.





Don fara kunna kiɗa

- Latsa .


Don tsaida kunna kiɗa

- Latsa .



Don saurin turawa gaba da baya

Lokacin da kake sauraron kiɗa, latsa ka riƙe kasa  ko .

Don samun waƙoƙi a kunne daidai

- Lokacin da kake sauraron kiɗa, latsa  sama ko kasa.

Don matsawa tsakanin waƙoƙi

- Lokacin da kake sauraron kiɗa, latsa  ko .

Kulle maɓallin kiɗa

Lokacin da wayar ke rufe zaka iya amfani da makullin maɓallin kiɗa don kullewa da buɗe maɓallin kiɗa.

Don kullewa da buɗe maɓallin kiɗa

- Zamar da mai sauya makullin maɓallin kiɗa.

Fayilolin lilo

An ajiye fayilolin kiɗa da bidiyo kuma an rarraba su.

- **Yan wasa** – jera waƙoƙin daka canjawa wuri ta amfani da mai sarrafa mai jarida.
- **Kundaye** – jera waƙoƙi ta kundi.
- **Waƙoƙi** – lissafa duk waƙoƙin kiɗa a wayarka da kan katin kwakwalwar ajiya.
- **Lissafin waka** – lissafin waƙoƙin mallaka.

Lissafin waƙoƙi

Zaka iya kirƙirar lissafin waƙoƙi don tsara fayiloli a **Mai sarrafa fayil**. Za'a iya kara fayiloli zuwa lissafin waka fiye da ɗaya.

Share lissafin waka, ko fayil daga lissafin waka, baya share fayil din daga kwakwalwar ajiya, saidai batun fayil din kawai.


Don kirƙirar lissafin waƙoƙi

- 1 Daga jiran aiki zaɓi **Menu** > **WALKMAN** > **Kari** > **Kiɗa na**.
- 2 Gungura zuwa **Lissafin waka** kuma zaɓi **Buɗe**.
- 3 Gungura zuwa **Sabon liss.waka** kuma zaɓi **Kara**.
- 4 Shigar da suna kuma zaɓi **Ok**.
- 5 Gungura zuwa waka kuma zaɓi **Alama**.
- 6 Zaɓi **Kara** don kara waka zuwa lissafin kira.


Don kara fayiloli zuwa lissafin waka

- 1 Daga jiran aiki zaɓi **Menu** > **WALKMAN** > **Kari** > **Kiɗa na**.
- 2 Gungura zuwa **Lissafin waka** kuma zaɓi **Buɗe**.
- 3 Gungura zuwa lissafin waka kuma zaɓi **Buɗe**.
- 4 Zaɓi **Kari** > **Kara mai jarida**.
- 5 Gungura zuwa waka kuma zaɓi **Alama**.
- 6 Zaɓi **Kara** don kara waka zuwa lissafin kira.

Don cire waƙoƙi daga lissafin waka

- 1 Daga jiran aiki zaɓi **Menu** > **WALKMAN** > **Kari** > **Kiɗa na**.
- 2 Gungura zuwa lissafin waka kuma zaɓi **Buɗe**.
- 3 Gungura zuwa wakar kuma latsa .

Don share lissafin waka

- 1 Daga jiran aiki zaɓi [Menu](#) > [WALKMAN](#) > [Kari](#) > [Kida na](#) > [Lissafin waka](#).
- 2 Gungura zuwa lissafin waka kuma latsa .

Don duba bayani game da waka

- Gungura zuwa waka kuma zaɓi [Kari](#) > [Bayani](#).

Aika kida da karɓa

Zaka iya aika kida da karɓa a sakon hoto, email ko ta amfani da Bluetooth.

Don aika kida

- 1 Daga jiran aiki zaɓi [Menu](#) > [WALKMAN](#).
- 2 Gungura zuwa take kuma zaɓi [Kari](#) > [Fayil](#) > [Aika](#).
- 3 Zaɓi hanyar canja wuri.

- ! *Tabbata na'urar da aka karɓa tana goyan bayan hanyar canja wuri daka zaba.*

Don karɓar kida

- Bi umarnin daya bayyana.

Kulle maɓallin kida

Lokacin da wayar ke rufe zaka iya amfani da makullin maɓallin kida don kullewa da buɗe maɓallin kida.

Don kullewa da buɗe maɓallin kida

- Zamar da mai sauya makullin maɓallin kida.

PlayNow™

Haɗa zuwa PlayNow™ don saukar da sautin ringi, wasanni, jigogi, da allon fuska. Zaka iya rigayar sauraron abun ciki kafin ka saya da saukar dashi zuwa wayarka.

- ! *Babu wannan sabis din a duk kasashe.*
- *Tuntubi afaretan cibiyar sadarwarka don karin bayani.*

Kafin kayi amfani da PlayNow™

Dolene ka bukaci saitunan Intanit a wayarka. Duba *Saituna* a shafi na 52.

Don sauraron kida PlayNow™

- 1 Daga jiran aiki zaɓi [Menu](#) > [PlayNow™](#).
- 2 Gungura zuwa dakin yanar sadarwar PlayNow™ kuma bi umarnin siffantawa da sayan abun ciki.

Saukarwa daga PlayNow™

Farashi yana bayyana lokacin da ka saukar kuma ka ajiye fayil na kida. Ana bashin lissafin wayarka ko katin kuɗin da ake bin bashi lokacin da aka karɓi saye.

Don sauke fayil na kida

- 1 Lokacin daka saurari samfotin fayil na kida, zaka iya amincewa da karɓar sharuɗɗan.
- 2 Zaɓi [Ee](#) don saukewa.

TrackID™

TrackID™ sabis ne mai shaida na kiɗa kyauta. Zaka iya bincika taken wakoki, yan wasa da sunayen kundi.

Don bincika bayanin waka

- 1 Lokacin da kaji waka ta cikin lasifika, daga jiran aiki zaɓi [Menu](#) > [Nishadi](#) > [TrackID™](#) > [Fara](#).
- 2 Lokacin da rediyo ke kunne zaɓi [Kari](#) > [TrackID™](#).

Kira

Yin kira da karɓa


Kana bukatar kunna wayarka kuma ka kasance cikin kewayon cibiyar sadarwa.

- ! *Kada ka rife pasar wayar lokacin amfani da ita, azaman wannan yana rinjayar ingancin kira.*

Don yin kira


- 1 Daga jiran aiki shigar da lambar waya (tare da lambar kasar waje da lambar yanki, idan an zartar).
 - 2 Zaɓi [Kira](#).
- 🔊 *Zaka iya kiran lambobi daga lambobinka da lissafin kira. Duba Lambobi shafi 25, da Lissafin kira shafi 29.*

Don yin kiran ta duniya

- 1 Daga jiran aiki latsa ka rike kasa  har sai alamar “+” ta bayyana.
- 2 Shigar da lambar kasa, lambar yanki (ba tare da sifilin farko ba) da lambar waya.
- 3 Zaɓi [Kira](#).

Don sake buga lamba

- Lokacin da [Sake jarrabawa?](#) ya bayyana zaɓi [Ee](#).

 *Kada ka riƙe wayarka a kunnenka lokacin jira. Lokacin da kiran ya haɗu, wayarka tana bada sigina mai kara.*

Don amsa kira

- Zaɓi [Amsa](#).
- Buɗe kwankwasawa.



Don kin karɓar kira

- Zaɓi [Kan aiki](#).

Don canja karar lasifikar kunni yayin kira


- Latsa  ko .

Don sa makirufo shiru yayin kira

- 1 Latsa ka riƙe kasa .
- 2 Latsa ka riƙe kasa  sake don ci gaba.


Don kunna lasifika yayin kira

- Zaɓi [Kari](#) > [Kunna lasifika](#).

 *Kada ka riƙe wayarka na kunnenka lokacin amfani da lasifika. Wannan zai iya lalata jinka.*

Kiran gaggawa

Wayarka tana giyan bayan lambobin gaggawa na kasashen waje, misali, 112 da 911. Waɗannan lambobin akasari ana amfani dasu don yin kiran gaggawa a kowace kasa, da ko ba tare da sanya katin SIM ba, idan cibiyar sadarwar GSM tana cikin kewayo.

 *A wasu kasashe, kuma ana iya aiwatar da wasu lambobin gaggawar. Maiyuwa saboda haka afaɗetan cibiyar sadarwarka ya ajiye karin lambobin gaggawa na gida a katin SIM.*

Don yin kiran gaggawa

- Daga jiran aiki shigar da 112 (lambar gaggawa ta kasar waje) kuma latsa [Kira](#).

Don duba lambobin gaggawarka na gida

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Gungura zuwa [Sabuwar lamba](#).
- 3 Zaɓi [Zabuɓɓuka](#) > [Lambb. n. musam.](#) > [Lambob. gaggawa](#).

Lambobi

Zaka iya ajiye lambobi, lambobin waya bayani na sirri a [Lambobi](#). Za' a iya ajiye bayani a kwakwalwar ajiyar waya ko a katin SIM.

Tsohuwar lamba

Zaka iya zaɓar wani bayanin lamba – **Lambobin waya** ko **Lambobin SIM** – aka nuna azaman tsoho.

Idan **Lambobin waya** an zaɓa azaman tsoffi, lambobinka suna nuna duk bayanin da aka ajiye a **Lambobi**. In ka zaɓi **Lambobin SIM** azaman tsoho, lambobinka suna nuna sunaye da lambobi ajiyayyu a katin SIM.

Don zaɓar tsaffin lambobi

- 1 Daga jiran aiki zaɓi **Menu** > **Lambobi**.
- 2 Gungura zuwa **Sabuwar lamba** kuma zaɓi **Zabuɓɓuka** > **Na ci gaba** > **Tsoffin lambobi**.
- 3 Zaɓi wani zaɓi.

Lambobin waya

Lambobin waya zasu iya kunsar sunaye, lambobin waya da bayanan sirri. An ajiye su a kwakwalwar ajiyar waya.


Don kara lambar waya

- 1 Daga jiran aiki zaɓi **Menu** > **Lambobi**.
- 2 Gungura zuwa **Sabuwar lamba** kuma zaɓi **Kara**.
- 3 Shigar da sunan kuma zaɓi **Ok**.
- 4 Sgigar da lambar kuma zaɓi **Ok**.
- 5 Zaɓi zaɓin lamba.
- 6 Gungura tsakanin shafuka kuma zaɓi filaye don kara bayani.

- 7 Zaɓi **Ajiye**.


Don kara wani abu zuwa lambar waya

- 1 Daga jiran aiki zaɓi **Menu** > **Lambobi**.
- 2 Gungura zuwa lamba kuma zaɓi **Kari** > **Shirya lamba**.
- 3 Gungura tsakanin shafuka kuma zaɓi **Kara**.
- 4 Zaɓi wani zaɓi da abu don karawa.
- 5 Zaɓi **Ajiye**.

 Idan biyan kuidinka yana goyann bayan sabis na Shaidar Layin Kira (CLI), zaka iya kebance sautunan riniga zuwa lambobi.

Don kwife sunaye da lambobi zuwa katin SIM


- 1 Daga jiran aiki zaɓi **Menu** > **Lambobi**.
- 2 Zaɓi **Kari** > **Zabuɓɓuka** > **Na ci gaba** > **Kwafi zuwa SIM**.
- 3 Zaɓi wani zaɓi.

 Lokacin daka kwife duk lambobi daga wayarka zuwa katin SIM, ana maye gurbin duk bayanin katin SIM daya kasance.

Don kiran lambar waya

- 1 Daga jiran aiki zaɓi **Menu** > **Lambobi**.

2 Gungura zuwa lamba kuma zaɓi [Kira](#).

 *Don tafiya kai tsaye zuwa lamba, daga jiran aiki latsa (2) – (9). Duba Bugun kiran sauri a shafi na 29.*

Don kiran lamba SIM daga lambobin waya

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#) > [Kari](#) > [Zabuɓɓuka](#) > [Lambobin SIM](#).
- 2 Gungura zuwa lamba kuma zaɓi [Kira](#).

Don ajiye sunaye da lambobin waya ta atomatik a katin SIM

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Zaɓi [Kari](#) > [Zabuɓɓuka](#) > [Na ci gaba](#) > [Ajjy.t. atom. a SIM](#).
- 3 Zaɓi wani zaɓi.

Lambobin SIM

Lambobin SIM zasu iya kunsar sunaye da lambobi kawai. An ajiye su a katin SIM.

Don kara lambar SIM

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Gungura zuwa [Sabuwar lamba](#) kuma zaɓi [Kara](#).
- 3 Shigar da sunan kuma zaɓi [Ok](#).
- 4 Shigar da lambar kuma zaɓi [Ok](#).
- 5 Zaɓi zaɓin lamba kuma kara karin bayani, idan akwai.
- 6 Zaɓi [Ajiye](#).

Don kware sunaye da lambobi zuwa lambobin waya

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Zaɓi [Kari](#) > [Zabuɓɓuka](#) > [Na ci gaba](#) > [Kwafi daga SIM](#).
- 3 Zaɓi wani zaɓi.

Don kiran lambar SIM

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Gungura zuwa lamba kuma zaɓi [Kira](#).

Share lambobi

Don share lamba

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Gungura zuwa lamba kuma latsa (C).


Don share duk lambobin waya

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Zaɓi [Kari](#) > [Zabuɓɓuka](#) > [Na ci gaba](#) > [Share duk lambobi](#).

Aika lambobi

Don aika lamba

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Gungura zuwa lamba kuma zaɓi [Kari](#) > [Aika lamba](#).
- 3 Zaɓi hanyar canja wuri.

 *Tabbatar da na'urar da aka karɓa tana goyan bayan hanyar canja wuri daka zaɓa.*

Halin Kwakwalwar ajiya

Adadin lambobi waƙanda zaka iya ajiyewa a wayarka ko a katin SIM ya danganta da samuwar kwakwalwar ajiya.

Don duba halayen kwakwalwar ajiya

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Zaɓi [Kari](#) > [Zabuɓɓuka](#) > [Na ci gaba](#) > [Halin kwklr.ajiya](#).

Don ajiye lambobi a katin kwakwalwa

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Zaɓi [Kari](#) > [Zabuɓɓuka](#) > [Na ci gaba](#) > [Ajiy. wari zw. M.S.](#)

Aiki tare da lambobi

Lambobi zasu iya aiki tare da kwamfutarka da wasu aikace-aikacen yanar sadarwa. Saboda karin bayani, duba *Aiki tare* shafi 58.

Kungiyoyi

Zaka iya kirkirar kungiyar lambobin waya da adiresoshin email don aika saƙo gare su. Duba *Sako* a shafi na 34. Kuma zaka iya amfani da kungiyoyi (tareda lambobin waya) lokacinda ka kirkiri lissafin mai kira karɓaɓɓe. Duba *Karɓi kira* a shafi na 32.

Don kirkirar kungiyar lambobi da adiresoshin email

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#) > [Zabuɓɓuka](#) > [Kungiyoyi](#) > [Sabuwar kungiya](#).
- 2 Shigar da suna don kungiyar kuma zaɓi [Ci gaba](#).

- 3 Zabi [Sabo](#) don nemo da zaɓar lambar lamba ko adireshin email.
- 4 Maimaita mataki na 3 don kara karin lambobin waya ko adiresoshin email.
- 5 Zabi [Anyi](#).

Lissafin kira

Zaka iya duba bayani game da kiran kwana kwanannan.

Don kiran lamba daga lissafin kira

- 1 Daga jiran aiki zaɓi [Kira](#) kuma gungura zuwa shafi.
- 2 Gungura zuwa suna ko lamba kuma latsa [Kira](#).

Don kara lambar lissafin zuwa lambobi

- 1 Daga jiran aiki zaɓi [Kira](#) kuma gungura zuwa shafi.
- 2 Gungura zuwa lambar kuma zaɓi [Kari](#) > [Ajiye lamba](#).
- 3 Zabi [Sabuwar lamba](#) don kirƙirar sabuwar lamba ko zaɓar lambar data kasance don kara lambar gareta.

Don share lissafin kira

- Daga jiran aiki zaɓi [Kira](#) > [Duk](#) shafin > [Kari](#) > [Share duk](#).

Bugun kiran sauri

Bugun kiran sauri zai baka damar zaɓar lambobi tara waɗanda zaka iya gubuwa da sauri. Za'a iya ajiye lambobi a wurare 1-9.

Don kara lambobi zuwa lambobin bugun kiran sauri

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Zabi [Zabuɓɓuka](#) > [Bugn. kira na sauri](#).
- 3 Gungura zuwa lambar wuri kuma zaɓi [Kara](#).
- 4 Zabi lamba.

Don bugun kiran sauri

- Daga jiran aiki shigar da lambar wuri kuma zaɓi [Kira](#).



Sakon murya

Idan biyan kuɗinka ya kunshi sabis na amsawa, masu kira zasu iya barin sako lokacin da ba zaka iya amsa kira ba.

Don shigar da lambar saƙon muryarka

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Saituna](#) > [Lambr. skn. murya](#).
- 2 Shigar da lambar kuma zaɓi [Ok](#).

Don kiran sabis na saƙon murya naka

- Daga jiran aiki latsa ka rike kasa .

Don shirya lambar sakon murya naka

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Saituna](#) > [Lambr. skn. murya](#).
- 2 Shigar da lambar kuma zaɓi [Ok](#).



Karkatar da kira

Zaka iya karkata kira, misali, zuwa sabis din amsawa.



Lokacin da aka yi amfani Kuntata kira, wasu zaɓuɓɓukan karkata kira basa samuwa. Duba Kuntataccen bugun kira a shafi na 32.

Zabuɓɓukan karkata kira

Tabbatattun zaɓuɓɓuka sune:

- [Karkatr. koyaushe](#) – karkatar da duk kira
- [Idan ana kan aiki](#) – idan kira yana gudana
- [Ba za'a iya sm. ba](#) – idan an kashe yawa ko ba'a isar masr ba
- [Babu amsa](#) – idan ba'a amsa waya a wani takmammen lokaci.

Don karkata kira

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Kira](#) shafin > [Karkatar da kira](#).
- 2 Gungura don kiran nau'i da zaɓin karkatawa kuma zaɓi [Kunna](#).

- 3 Shigar da lambar don karkata kira gareta kuma zaɓi [Ok](#).



Fiye da kira ɗaya

Zaka iya karɓar fiye da kira ɗaya lokaci guda. Misali, zaka iya sa kira mai gudana a riƙe, lokacin da kake kira ko amsa kira na biyu. Zaka kuma iya sauyawa tsakanin kiran guda biyu. Ba zaka iya amsa kira na uku ba batara da kare ɗaya daga cikin kira biyu ba.

Kiran jira

Lokacin da ake amfani da kiran jira, zaka ji kara idan ka sami kira na biyu.

Don kunna kiran jira

- Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Kira](#) shafin > [Sarrafa kira](#) > [Jiran kira](#) > [Kunna](#).

Don yin kira na biyu

- 1 Yayin kiran, zaɓi [Kari](#) > [Rike](#). Wannan yana sanya kira mai gudana a riƙe.
- 2 Shigar da lambar don kira kuma zaɓi [Kari](#) > [Kira](#).

Don amsa kira na biyu

- Yayin kiran, zaɓi [Amsa](#). Wannan yana sanya kira mai gudana a riƙe.

Don kin karɓar kira na biyu

- Yayin kiran, zaɓi **Kan aiki** kuma ci gaba da kira mai gudana.

Don kare kira mai gudana da amsa kira na biyu

- Yayin kiran, zaɓi **Sauya kira mai aiki**.



Karɓan kiran murya guda biyu

Zaka iya samun kira mai gudan da kira arike a lokaci guda.

Don canjawa tsakanin kira biyu

- Yayin kiran, zaɓi **Kari** > **Canja**.

Don haɗa kira biyu

- Yayin kiran, zaɓi **Kari** > **Haɗa kira**.

Don haɗa kira biyu

- Yayin kiran, zaɓi **Kari** > **Canja wurin kira**. An cire ka daga haɗin biyu.

Don kare kira mai gudana da komawa zuwa kira arike

- Zaɓi **Kas.kira** > **Ee**.

Don kare kira

- Zaɓi **Kas.kira** > **A'a**.

Karɓar kiran murya na uku

Baza ka iya amsa kira na uku ba tare da kare ɗayan kira biyun farko ko haɗa su ba acikin kiran taro.



Kiran taro

Tareda kiran tari, zaka iya samun haɗin taɗi tareda fiye da mutane biyar.

Don haɗa kira biyu

- Yayin kiran, zaɓi **Kari** > **Haɗa kira**.

Don kara sabon ɗan takara

- 1 Yayin kiran, zaɓi **Kari** > **Rike**. Wannan yana sanya kira da aka haɗa a riƙe.
- 2 Zaɓi **Kari** > **Kara kira**.
- 3 Shigar da lambar don kira kuma zaɓi **Kira**.
- 4 Zaɓi **Kari** > **Haɗa kira** don kara sabon ɗan takara.
- 5 Maimaita wannan ɗawainiyar don kara taɗin yan takara.

Don barin ɗan takara

- 1 Zaɓi **Kari** > **Saki bangare**.
- 2 Zaɓi ɗan takara don saki.

Don samun taɗi na sirri

- 1 Yayin kira, zaɓi **Kari** > **Yi magana da kuma zaɓi ɗan takara don magana dashi**.
- 2 Don ci gaba da kiran taro, zaɓi **Kari** > **Haɗa kira**.



Idan biyan kuɗinka yana goyan bayan Maimakon Sabis na Layi (ALS), zaka iya yin kira da lambobi daban.

Lambobi nawa

Zaka iya dubawa, karawa da shirya lambobin wayarka.

Don bincika lambobin wyarka

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#) > [Zabuɓɓuka](#) > [Lambb. n. musam.](#) > [Lambobi nawa.](#)
- 2 Zaɓi wani zaɓi.

Karɓi kira

Zaka iya zaɓar karɓar kira daga wasu takmairan lambobin waya kawai.

Don kara lambobi zuwa karɓaɓɓun lissafin masu kira

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Kira shafin](#) > [Sarrafa kira](#) > [Karɓa kira](#) > [Daga liss. kawai](#) > [Sabo.](#)
- 2 Gungura zuwa lamba ko zaɓi Kungiyoyi.
Duba *Kungiyoyi* a shafi na 28.

Don karɓan duk kira

- Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Kira shafin](#) > [Sarrafa kira](#) > [Karɓa kira](#) > [Duk masu kira.](#)



Kuntataccen bugun kira

Zaka iya kuntata kira mai fita da mai shiga. Ana bukatar kalmar wucewa daga mai baka sabis.



Idan ka karkatar da kira mai shiga, baza ka iya amfani da wasu kuntatattun zaɓuɓɓukan kira ba.

Zaɓuɓɓukan kuntata kira

Tabbatattun zaɓuɓɓuka sune:

- [Duk mai fita](#) – duk kira mai fita
- [Mai fita waje](#) – duk kiran mai fita na kasar waje
- [Yw. krn. wj. m. ft.](#) – duk kira mai fita na kasar waje banda zuwa kasar
- [Duk mai shigowa](#) – duk kira mai shiga
- [M. shg.in an. ywo.](#) – duk kira mai shiga lokacin da kake kasar waje.

Don kuntata kira

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Kira shafin](#) > [Sarrafa kira](#) > [Kuntata kira.](#)
- 2 Zaɓi wani zaɓi.
- 3 Shigar da kalmarwucewa kuma zaɓi [Ok.](#)



Kafaffen bugun kira

Kafaffin bugun kira yana ba kira izinin kira kwai zuwa takamammen ajajjen lamba a katin SIM din. An kare kafaffun lambobi ta PIN2.



Lokacin da aka yi amfani da kafaffen bugun kira za'a iya yin kira zuwa lambar gaggawa ta duniya 112.

Za'a iya ajiye sashin lambobi. Misali, ajiye 0123456 yana bada damar yin kira zuwa duk lambobin da suka fara da 0123456.



Lokacin da aka amfani da kafaffen bugun kira, ba zaka iya amfani da lambobin waya da aka ajiye a kan katin SIM.

Don amfani da kafaffen gubun kira

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Zaɓi [Kari](#) > [Zaɓuɓɓuka](#) > [Lambb. n. musam.](#) > [Kafaffen bgn. kira](#) > [Kunna](#).
- 3 Shigar da PIN2 naka kuma zaɓi [Ok](#).
- 4 Zaɓi [Ok](#) sake don tabbatarwa.

Don ajiye kafaffen lamba

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Zaɓi [Kari](#) > [Zaɓuɓɓuka](#) > [Lambb. n. musam.](#) > [Kafaffen bgn. kira](#) > [Kafaffun lambobi](#) > [Sabuwar lamba](#).
- 3 Shigar da bayani kuma zaɓi [Ajiye](#).



Lokacin kira da farashi

Yayin kira, tsowon likacin kira yana bayya. Zaka iya duba lokacin kiran karshe naka, kira masu fita da jimlar lokacin kiran naka.

Don duba lokacin kira

- Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Kira shafin](#) > [Lokaci & farashi](#) > [Ms. kiday. lok. kira](#).

Katunan kasuwanci

Don kara katin kasuwanci naka

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Zaɓi [Kari](#) > [Zabuɓɓuka](#) > [Kat. kasuwanci na](#).
- 3 Gungura tsakanin shafuka kuma zaɓi filaye don kara bayani. Don shigar da alama zaɓi [Kari](#) > [Kara alama](#) > [Sa](#).
- 4 Shigar da bayani kuma zaɓi [Ajiye](#).

Don aika katin kasuwancinka

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Zaɓi [Kari](#) > [Zabuɓɓuka](#) > [Kat. kasuwanci na](#) > [Aika kati nawa](#).
- 3 Zaɓi hanyar canja wuri.



Tabbatar da na'urar da aka karɓa tana goyan bayan hanyar canja wuri daka zaɓa.

Sako

Sakonnin rubutu

Sakonnin rubutu zasu iya kunsar saukakan hotuna, rinjayen sauti, rayarwa, da karin waƙa.

Kafin kayi amfani da sako

Dole ka sami lambar wurin sabis. Ana kawo lambar ta mai baka sabis kuma mafi yawa ana ajiye ta a katin SIM. Idan ba'a ajiye lambar wurin sabis dinka a katin SIM ba, dolene ka shigar da lambar da kanka.

Shigar da lambar wurin sabis

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Saituna](#) > [Sakon rubutu](#) > [Wurin sabis](#). Ana nuna lambar idan an ajiyeta a katin SIM.
- 2 Idan babu lamba da ya bayyana, zaɓi [Shirya](#) > [Sabo](#). [WurinSabis](#) Shigar da lambar, gamida alamar ta duniya “+” da lambar kasa.
- 3 Zaɓi [Ajiye](#).

Aika sakonni

Saboda bayani gameda shigar da haruffa, duba *Shigar da rubutu* a shafi 18.

Don rubuta da aika sakon rubutu

- 1 Daga jiran aiki zabi [Menu](#) > [Sako](#) > [Rubuta sabuwa](#) > [Sakon rubutu](#).
- 2 Rubuta sakon kuma zabi [Ci gaba](#) > [Duba lambobi](#).
- 3 Zabi mai karɓa kuma zabi [Aika](#).

! *Idan ka aika sakon rubutu zuwa gungiya, za'a cajeka kan duk ɗan kungiya. Duba Kungiyoyi a shfi na 28.*

Don zaɓar fayil fiye da ɗaya a babban fayil

- 1 Daga jiran aiki zabi [Menu](#) > [Sako](#) kuma babban fayil.
- 2 Gungura zuwa sako kuma zabi [Kari](#) > [Alama a yawanci](#).
- 3 Zabi [Alama](#) don sawa fayiloli alama.

Don kara abu zuwa sakon rubutu

- 1 Lokacin da ka rubuta sakon, zabi [Kari](#) > [Kara abu](#).
- 2 Zabi wani zabi kuma sannan abu.

Karɓan sakonnin rubutu

Ana sanar da kai lokacin da ka karɓi sako. Sakonnin da aka karɓa ana ajiye su a akwatin sako mai shiga.

Don duba sakon hoto daga akwatin sako mai shiga

- 1 Daga jiran aiki zabi [Menu](#) > [Sako](#) > [Akw. s. m. shig.](#)
- 2 Gungura zuwa sakon kuma zabi [Duba](#).

Don rufe sakon rubutu ko na hoto

- Latsa .

Don kiran lamba a sakon rubutu

- Lokacin da ka duba sakon, gungura zuwa lambar wayar kuma latsa [Kira](#).

Ajiyewa da share sakonnin rubutu

Sakonnin da aka karɓa ana ajiye su a kwakwalwar ajiyar waya. Lokacin da kwakwalwar ajiyar waya ta cika, share sakonni ko matsa dasu zuwa katin SIM.


Don ajiye sako a katin SIM

- 1 Daga jiran aiki zabi [Menu](#) > [Sako](#) kuma babban fayil.
- 2 Gungura zuwa sakon kuma zabi [Kari](#) > [Ajiye sako](#) > [Ajiyayyu](#). wasiku.

Don ajiye abu a sakon rubutu

- 1 Lokacin da ka duba sakon, zabi abun.
- 2 Zabi [Kari](#) > [Yi amfani](#).
- 3 Zabi wani zabi.

Don share sako

- 1 Daga jiran aiki zabi [Menu](#) > [Sako](#) kuma babban fayil.
- 2 Gungura zuwa sako kuma latsa .

Sakonnin hoto

Sakonnin hoto zasu iya kunsar rubutu, hotuna. nunin faifai, rikodin sauti, shirye-shiryen bidiyo, sa hannu da haɗe-haɗe. Zaka iya aika sakonnin hoto zuwa wayar hannu ko adreshin email.

Kafin kayi amfani da sakon hoto

Dole kasaita bayanin martabar Intanit da adreshin uwar harken sakonka. Idan babu bayanin martaba na Intanit ko uwar garken sako zaka iya karɓar duk saituna ta atomatik daga afaretan cibiyar sadarwarka ko a www.sonyericsson.com/support.

Don zaɓar bayanin martabar intanit

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Saituna](#) > [Sakon hoto](#) > [Bay. mrtbar MMS](#).
- 2 Zaɓi bayanin martaba.


Don saita adreshin uwar garken sako

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Saituna](#) > [Sakon hoto](#) > [Bay. mrtbar MMS](#).
- 2 Gungura zuwa bayanin martaba kuma zaɓi [Kari](#) > [Shirya](#) > [Uwar garken sako](#).
- 3 zaɓi [Shirya](#) kuma shigar da adreshi.

Aika sakonni

Saboda bayani gameda shigar da haruffa, duba *Shigar da rubutu* a shfin na 18.

Don kirƙira da aika sakon hoto

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Rubuta sabuwa](#) > [Sakon hoto](#).
- 2 Shigar da rubutu kuma latsa  don kara abu a rubutun.
- 3 Zaɓi [Ci gaba](#) > [Duba lambobi](#).
- 4 Zaɓi mai karɓa kuma zaɓi [Aika](#).

Karɓar sakonnin hoto

Zaka iya zaɓar yadda zaka sauke sakonnin hotonka. Tabbatattun zaɓuɓɓuka lokacin da kake sauke sakonni sune:

- [Koyaushe](#) – saukewar atomatik.
- [Tamby.an.yawo](#) – tambayi don saukewa lokacin da ba cikin cibiyar sadarwar gida ba.
- [Ba'a cikin yawo](#) – kar a sauke lokacin da ba cikin cibiyar sadarwar gida ba.
- [Koysh.tambayi](#) – tambayi don saukewa.
- [A kashe](#) – sabbin sakonni suna bayyana a [Akw. s. m. shig.](#)

Don saita saukewar atomatik

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Saituna](#) > [Sakon hoto](#) > [Saukw. ta atomat.](#)
- 2 Zaɓi wani zaɓi.

Don duba saƙon hoto daga akwatin saƙo mai shiga

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Akw. s. m. shig.](#)
- 2 Gungura zuwa saƙon kuma zaɓi [Duba](#).


Don rufe saƙon rubutu ko na hoto

- Latsa .

Don ajiye abu a saƙon hoto

- Lokacin da ka duba saƙon hoto zaɓi [Kari](#) > [Ajiye abubuwa](#) kuma zaɓi abu.

Don share saƙo

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) kuma zaɓi babban fayel.
- 2 Gungura zuwa saƙo kuma latsa .

Zabuɓɓukan saƙo

Zaka iya saita tabbatattun zaɓuɓɓuka saboda duk saƙonni ko zaɓi takamammun saituna kowani likaci ka aika saƙo.

Don saita zaɓuɓɓukan saƙon rubutu

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Saituna](#) > [Sakon rubutu](#).
- 2 Gungura zuwa zaɓi kuma zaɓi [Shirya](#).

Don saita zaɓuɓɓukan saƙon hoto

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Saituna](#) > [Sakon hoto](#).
- 2 Gungura zuwa zaɓi kuma zaɓi [Shirya](#).

Aika zaɓuɓɓuka

zaka iya neman rahoton karantwa ko rahoto ahoton isarwa, kuma saita fifiko saboda takamammen saƙo. Zaka kuma iya kara karin masu karɓa zuwa saƙon.

Don saita aika zaɓuɓɓuka

- 1 Lokacin da aka shirya saƙo kuma aka zaɓi mai karɓa, zaɓi [Kari](#) > [Na ci gaba](#).
- 2 Gungura zuwa zaɓi kuma zaɓi [Shirya](#).

Samfura

Idan wasu lokata kana amfani dayankin jumla da hotuna iri ɗaya a saƙo, zaka iya ajiye saƙon azaman samfuri.

Don amfani da samfurin saƙon rubutu

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Samfura](#).
- 2 Gungura zuwa samfurin kuma zaɓi [Yi amfani](#) > [Sakon rubutu](#).
- 3 Kara rubutu kuma zaɓi [Ci gaba](#) kuma zaɓi mai karɓ.


Don amfani da samfotin sakon hoto

- 1 Daga jiran aiki zabi [Menu](#) > [Sako](#) > [Samfura](#).
- 2 Gungura zuwa samfoti kuma zabi [Yi amfani](#).
- 3 Lokacin da aka shirya sako, zabi [Ci gaba](#) kuma zabi mai karɓa.

Don kara samfur na sakon rubutu

- 1 Daga jiran aiki zabi [Menu](#) > [Sako](#) > [Samfura](#) > [Sabuwar samfuri](#) > [Rubutu](#).
- 2 Saka rubutu ko zabi [Kari](#) don kara abubuwa. Zabi [Ok](#).
- 3 Shigar da take kuma zabi [Ok](#).

Don kara samfotin sakon hoto

- 1 Daga jiran aiki zabi [Menu](#) > [Sako](#) > [Samfura](#) > [Sabuwar samfuri](#) > [Sakon hoto](#).
- 2 Shigar da rubutu kuma latsa  don kara abu a rubutun.
- 3 Zabi [Ajiye](#), shigar da take kuma zabi [Ok](#).

Don shirya samfuri

- 1 Daga jiran aiki zabi [Menu](#) > [Sako](#) > [Samfura](#).
- 2 Gungura zuwa samfuri kuma zabi [Kari](#) > [Shirya samfuri](#) > [Ajiye](#).

Don ajiye sako azaman samfuri

- 1 Daga jiran aiki zabi [Menu](#) > [Sako](#) > [AkW. s. m. shig.](#)
- 2 Gungura zuwa sakon kuma zabi [Kari](#) > [Ajiye sako](#) > [Samfura](#).



Sakonnin murya

Zaka iya aika da karɓan rakodin murya azaman sakon murya.



Dolene mai aikawa da karɓa ya zama suna da biyan kudi mai goyann bayan sakon hoto.

Don dauka da aika sakon murya

- 1 Daga jiran aiki zabi [Menu](#) > [Sako](#) > [Rubuta sabuwa](#) > [Sakon murya](#).
- 2 Yi rikodin sakon kuma zabi [Tsaida](#) > [Aika](#) > [Duba lambobi](#).
- 3 Zabi mai karɓa kuma zabi [Aika](#).



Email

Zaka iya amfani da tabbatattun ayyukan email da adreshin email na kwafutarka a wayarka.

Kafin kayi amfani da email

Dole a shigar da saitin email cikin wayarka. Zaka iya samun waɗanan saitunan da aka aiko kai tsaye zuwa wayarka daga Sony Ericsson support site, ko zaka iya shigar da su da hannu.

Saitunan email ta amfani da Intanit

Zaka kuma iya karɓar saituna a www.sonyericsson.com/support.

Shigar da saituna da hannu

Kuma zaka iya shigar da saitunan email da hannu. Don yin haka, tambayi mai baka email saboda bayanin saituna:

Nau'ukan saiti	Misalai
----------------	---------

Nau'in haɗi	POP3 ko IMAP4
-------------	---------------

Adireshin email	joe.smith@example.com
-----------------	--

Uwr. grk. m-shig.	mail.example.com
-------------------	--

Sunan mai amfani	jsmith
------------------	------------------------

Kalmar wucewa	zX123
---------------	-----------------------

Uw. garke mai fita	mail.example.com
--------------------	----------------------------------

Mai bada email zai iya zama kamfani wanda yake kawo adreshin email dɓnka, misali mai kula da IT naka a aiki ko mai bada Intanit.

Mai yiwuwa kasami baynin saituna a saitunan shirin email dɓn kwamfutarka, ko a takardun aiki daga mai baka email.

! *Akwai masu bada email dabamdaban. Isɗilahinsu da bayanin da ake bukata mai yiwuwa ya sha bamban. Ba ko wasu masu bada sabis suke bada damar email.*

Don shigar da saitunan email

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Email](#) > [Saituna](#).
- 2 Shigar da saitunan. Taimako yana bayyana lokacin da ka shiga saituna.

! *Saboda karin bayani, tuntubi afaretan cibiyar sadarwa naka ko je zuwa www.sonyericsson.com/support.*

Don rubuta da aika sakon email

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Email](#) > [Rubuta sabuwa](#).
- 2 Zaɓi [Kara](#) > [Shigar.adire.email](#). Shigar da adireshin email dɓn kuma zaɓi [Ok](#).
- 3 Don shigar da karin masu karɓa, zaɓi [Shirya](#). Gungura zuwa zaɓi kuma zaɓi [Kara](#) > [Shigar.adire.email](#). Shigar da adireshin email dɓn kuma zaɓi [Ok](#). Lokacin da ka shirya, zaɓi [Anyi](#).

- 4 Latsa ☑ don gungurawa zuwa [Take](#):. Zabi [Shirya](#) kuma shigar da take.
- 5 Latsa ☑ don gungurawa zuwa [Rubutu](#):. Zabi [Shirya](#) kuma shigar da rubutu.
- 6 Latsa ☑ don gungurawa zuwa [Hade-hade](#):. Zabi [Kara](#) kuma zabi fayil don haɗawa.
- 7 Zabi [Ci gaba](#) > [Aika](#).

Don karɓa da karanta sakon email

- 1 Daga jiran aiki zabi [Menu](#) > [Sako](#) > [Email](#) > [Akw. s. m. shig.](#) > [Aik. & kb.](#)
- 2 Gungura zuwa sakon kuma zabi [Duba](#).

Don ajiye sakon email

- 1 Daga jiran aiki zabi [Menu](#) > [Sako](#) > [Email](#) > [Akw. s. m. shig.](#)
- 2 Gungura zuwa sakon kuma zabi [Kari](#) > [Ajiye sako](#) > [Ajajjen email](#).

Don bada amsa ga sakon email

- 1 Daga jiran aiki zabi [Menu](#) > [Sako](#) > [Email](#) > [Akw. s. m. shig.](#)
- 2 Gungura zuwa sakon kuma zabi [Kari](#) > [Amsa](#).
- 3 Rubuta amsar kuma zabi [Ok](#).
- 4 Zabi [Ci gaba](#) > [Aika](#).

Don duba haɗe-haɗe a sakon email

- Lokacin da ka duba sakon, zabi [Kari](#) > [Hade-hade](#) > [Duba](#).

Don ajiye haɗe-haɗe a sakon email

- Lokacin da ka duba sakon, zabi [Kari](#) > [Hade-hade](#) > [Duba](#) > [Ajiye](#).

Lissafin email mai aiki

Idan kana da lissafin email dayawa, zaka iya canja wanda yake aiki.

Don canja lissafin email mai aiki

- 1 Daga jiran aiki zabi [Menu](#) > [Sako](#) > [Email](#) > [Saituna](#).
- 2 Zabi lissafin.

Don share sakon email (POP3)

- 1 Daga jiran aiki zabi [Menu](#) > [Sako](#) > [Email](#) > [Akw. s. m. shig.](#)
- 2 Gungura zuwa sakon kuma zabi [Kari](#) > [Alam.na sharewa](#) > [Ee](#).

! *Sakonnin da aka sawa alama za'a share su lokacin da kayi haɗi na gaba zuwa uwar garkenka.*

Don share sakon email (IMAP4)

- 1 Daga jiran aiki zabi [Menu](#) > [Sako](#) > [Email](#) > [Akw. s. m. shig.](#)
- 2 Gungura zuwa sakon kuma zabi [Kari](#) > [Alam.na sharewa](#) > [Ee](#).
- 3 Zabi [Kari](#) > [Shr.akw.sk.m-shg.](#)

! *Za'a share sakonnin email masu alama a wayar da kan uwar garke.*

Samun email

Zaka iya karɓar sanarwa a wayarka daga uwar garekn email taka cewa kana da sakonnin email.

Don kunna sanarwar samun email

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Email](#) > [Saituna](#).
- 2 Gungura zuwa lissafi don shiryawa da zaɓi [Kari](#) > [Shirya lissafi](#) > [Babban saituna](#) > [Tura email](#).
- 3 Zaɓi wani zaɓi.

Abokai nawa

Zaka iya haɗawa da kuma shiga zawa uwar garken abokai nawa don sadarwa tareda sakonnin taɗi akan layi.

Kafin kayi amfani da Abokai nawa

Idan saiti bai kasance a wayrka ba, kana bukatan shigar da saitunan uwar garke. Tabbataccen bayanai saituna wanda mai bada sabis ke bada sune:

- sunan mai amfani
- kalmar wucewa
- adireshin uwar garke
- bayanin martabar Intaniti

Don shigar da saitunan uwar garken abokai nawa

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Abokai nawa](#) > [Sanya](#).
- 2 Zaɓi [Kara](#) kuma shigar da saituna.

Don shirya saitunan abokai nawa

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Abokai nawa](#).
- 2 Zaɓi [Kari](#) > [Saituna](#).
- 3 Gungura zuwa saiti latsa kuma [Zaɓi](#).

Don sa hannun shiga zuwa uwar garken abokai Nawa

- Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Abokai nawa](#) > [Shiga ciki](#).

Don fita daga uwar garken Abokai nawa

- Zaɓi [Kari](#) > [Fita daga yana](#).

Don kara lambar taɗi

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Abokai nawa](#) > [Lambobi shafin](#).
- 2 Zaɓi [Kari](#) > [Kara lamba](#).

Don aikawa da sakon taɗi

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Abokai nawa](#) > [Lambobi shafin](#).
- 2 Gungura zuwa lamba kuma zaɓi [Taɗi](#).
- 3 Rubuta sakon kuma zaɓi [Aika](#).

Hali

Zaka iya nuna halinka, misali, [Farin ciki](#) ko [Kan aiki](#), zuwa lambobinka kawai. Kuma zaka iya nuna halinka zuwa duk masu amfani a uwargen abokai Nawa.

Don nuna hali nawa

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Abokai nawa](#) > [Kari](#) > [Saituna](#) > [Nuna halin nawa](#).
- 2 Zaɓi wani zaɓi.

Don dawakaka hali naka

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Abokai nawa](#) > [Hali nawa](#) shafin.
- 2 Gungura tsakanin shafuka kuma zaɓi filaye don kara bayani.

Kungiyar taɗi

Kungiyar taɗi zata ita farawa ta mai bada sabis, ta mutum mai amfanin Abokai nawa ko da kanka. Zaka iya aje kungiyar taɗi ta gayyatar taɗi ko ta binciken wani takmammen kungiyar taɗi.

Don kirkiro kugiyar taɗi

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Abokai nawa](#) > [Kungiyoyin taɗi](#) shafin.
- 2 Zaɓi [Kari](#) > [K. taɗi](#) > [Sab. kungiyar taɗi](#).
- 3 Zaɓi wanda zaka gayyata daga lissafin lambobinka kuma zaɓi [Ci gaba](#).
- 4 Shigar da karamin rubutun gayyata kuma zaɓi [Ci gaba](#) > [Aika](#).

Don kara kungiyar taɗi

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Abokai nawa](#) shafin > [Kungiyoyin taɗi](#) > [Kari](#) > [K. taɗi](#).
- 2 Zaɓi wani zaɓi.

! An ajiye tarihin taɗi tsakanin sa hannun fita da lokacin daka sake shiga don baka damar zuwa sakonnin taɗi daga taɗi daya gabata.

Don ajiye taɗi


- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Abokai nawa](#) > [Taɗi](#) shafin.
- 2 Shigar da taɗi.
- 3 Zaɓi [Kari](#) > [Na ci gaba](#) > [Aje taɗi](#).

Don duba ajiyayyen taɗi

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Abokai nawa](#) > [Taɗi](#) shafin.
- 2 Zaɓi [Kari](#) > [Aje magana](#).

Bayanin wuri da salula

Bayanin wuri da salula sune sakonnin rubutu ne, misali, rahotonnin hanya na gida wafanda aka aika zuwa masu biyan kuɗi tsakanin wata wurin cibiyar sadarwa.

 *Tuntubi mai baka sabis Saboda karin bayani.*

Don kunna bayanin yanki

- 1 Daga jiran aiki zaɓi **Menu** > **Sako** > **Saituna** > **Bayanin wuri**.
- 2 Gungura zuwa **Yanayin aiki** kuma zaɓi **Shirya** > **Kunnawa**.

Hoto

Kamara

Zaka iya ɗaukan hoto da rikodin shirye-shiryen bidiyo don dubawa, ajiye ko aika.



- 1 Daidaita haske
- 2 Zuko kusa

3 Dauki hotona

4 Zuko nisa


Don kunna kamara


- Daga jiran aiki zaɓi [Menu](#) > [Kamara](#).

Don ɗaukar hoto

1 Kunna kamara.

2 Zaɓi [Dauka](#) don ɗaukan hoto.

3 Latsa  don ɗaukan wani hoto.

4 Latsa ka riƙe kasa  son tsaida kamara.

Don amfani da zukowa

Wayarka tana da mai zukowar lokaci.

Dodaro da girman zaɓaɓɓen hoto, akwai matakin zukowa mai biyowa:

- Girman hoto 1 MP – babu zukowa
- Girman hoto VGA (640x480) – 2x zukowa
- Girman hoto QVGA (320x240) – 4x zukowa.

Don amfani da zukowa

- Latsa  ko .

Don daidaita haske

- Latsa  ko .

Don ajiye da share hotuna

- 1 Daga jiran aiki zaɓi [Menu](#) > [Mai sarrafa fayil](#) > [Kundin kamara](#).

2 Gungura zuwa abu kuma zaɓi [Kari](#).


Don dubaw hotuna

- 1 Daga jiran aiki zaɓi [Menu](#) > [Mai sarrafa fayil](#) > [Kundin kamara](#).
- 2 Gungura zuwa abu kuma zaɓi [Duba](#).

Don bincika hotunan kamara ta layin lokaci

- 1 Daga jiran aiki zaɓi [Menu](#) > [Mai sarrafa fayil](#) > [Kundin kamara](#).
- 2 Don lilon hotunan kamara wanda aka adana ta kwanan wata, zaɓi [Kari](#) > [Duba layin lokaci](#).

Don share hotuna

- 1 Daga jiran aiki zaɓi [Menu](#) > [Mai sarrafa fayil](#) > [Kundin kamara](#).
- 2 Gungura zuwa wani abu kuma latsa .

Saitunan kamara

Zaka iya zaɓar saituna daban kafin ka dauki hoto.





Don duba saituna

- Loakcinda aka kunna kamara, zaɓi [Kari](#).

Don duba bayani game da saituna

- Gungura zuwa saituna kuma zaɓi [Bayani](#).

Gajerun hanyoyin kamara

Maballi	Gajerar hanya
	Yanayin dauka
	Girman hoto
	Yanayin dare
	Jagorar maballi

Canja wurin hotuna

Canja wuri zuwa ko daga kwafutarka

Zaka iya amfani da Bluetooth da sakonnin hoto don canja wurin hotuna zuwa kwamfutarka. Zaka iya kuma amfani da keɓul na USB don jawo da sauke hotunan kamara. Suba *Fasaha mara waya ta Bluetooth™* da *Amfani da keɓul na USB* a shafi na 56.

Zaka iya duna, haɓaka da tsara hotunanka da shirye-shiryen bidiyonka a kwamfuta ta shigarwa *Adobe™ Photoshop™ Album Starter Edition* ko *Sony Ericsson Media Manager*. An tattara waɗannan a CD dinda yazo tare da wayarka kuma akwai don saukewa a www.sonyericsson.com/support.

Shafin hoto

Shafin hoto daƙin Yanar sadarwa ne na sirri. Idan biyan kuɗinka yana goyann bayan wannan sabis, zaka iya aika hotuna zuwa shafi.

! *Sabis na yanar sadarwa zai iya buƙatar wararren lasisin yarjejeniya tsakaninka da mai bada sabis. Maiyuwa ya shafi karin dokoki da/ko kuɗi. Tuntubi mai baka sabis.*

Don aika hotunan kamara zuwa shafi

- 1 Daga jiran aiki zaɓi [Menu](#) > [Mai sarrafa fayil](#) > [Kundin kamara](#).
- 2 Gungura zuwa hoto kuma zaɓi [Kari](#) > [Aika](#) > [Zuwa blog](#).
- 3 Kara take da rubutu.
- 4 Zaɓi [Ok](#) > [Yada](#).

Don tafiya zuwa adreshin shafi daga lambobi

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Gungura zuwa lamba.
- 3 Gungura zuwa adreshin yana kuma zaɓi [Je zuwa](#).

Hotuna

Zaka iya duba, kara, kwafe ko share hotuna a [Mai sarrafa fayil](#). Nu'ukan fayil masu goyan baya sune, misali, GIF, JPEG, BMP da PNG.

Amfani da hotuna

Zaka iya kara hoto zuwa lamba, yi amfani da shi yayin farawa, azaman fuskar bangon waya ko azaman uwar garken allo.

Don duba hotunanka

- 1 Daga jiran aiki zaɓi [Menu](#) > [Mai sarrafa fayil](#) > [Hotuna](#).
- 2 Gungura zuwa hoto kuma zaɓi [Duba](#).

Don amfani da hotuna

- 1 Daga jiran aiki zaɓi [Menu](#) > [Mai sarrafa fayil](#) > [Hotuna](#).
- 2 Gungura zuwa hoto kuma zaɓi [Kari](#) > [Yi amfn. azaman](#).
- 3 Zaɓi wani zaɓi.

Don duba hotuna a nunin faifai

- 1 Daga jiran aiki zaɓi [Menu](#) > [Mai sarrafa fayil](#) > [Hotuna](#).
- 2 Gungura zuwa hoto kuma zaɓi [Duba](#) > [Kari](#) > [Nunin faifai](#).

Aikawa da karɓa

Zaka iya aikawa da karɓar hotuna azaman sakon hoto, email ko amfani da Bluetooth.

Don aika hoto

- 1 Daga jiran aiki zaɓi [Menu](#) > [Mai sarrafa fayil](#) > [Hotuna](#).
- 2 Gungura zuwa hoto kuma zaɓi [Kari](#) > [Aika](#).
- 3 Zaɓi hanyar canja wuri.

! *Tabbatar da na'urar da aka karɓa tana goyan bayan hanyar canja wuri daka zaba.*

Don karɓar hoto

- Bi umarnin daya bayyana.

Nishadi



Rediyo

! *Kada kayi amfani da wayarka azaman rediyo a wuraren da aka hana.*

Don sauraron rediyo


- 1 Haɗa abin sawa akunni zuwa wayar.
- 2 Daga jiran aiki zaɓi [Menu](#) > [Rediyo](#).

Don canja kara


- Lokacin da rediyo take a kunne, latsa  ko .



Don bincika tashoshin rediyo ta atomatik

- Lokacin da redsiyo take a kunne, zaɓi [Bincika](#).

💡 *Kuma zaka iya latsawa  don bincika tashan rediyo ta atomatik.*

Don bincika tashoshin rediyo da hannu

- Lokacin da rediyo take a kunne, latsa  ko .

💡 *Kuma zaka iya latsawa  ko  don bincika tashan rediyo ta atomatik.*

Don bincika saitattun tashoshi

- Lokacin da rediyo take a kunne, latsa (🔊) ko (🔇).

💡 **Latsa** (▶️) sama ko **kasa bincika tashoshin rediyo na yanzu**.

Ajiye tashoshin rediyo

Zaka iya ajiye har zuwa tashoshi 20 da aka saita.

Don aje tashoshin rediyo

- 1 Daga jiran aiki zaɓi **Menu** > **Rediyo**.
- 2 Zaɓi **Bincika** don samo tashan rediyo.
- 3 Zaɓi **Kari** > **Ajiye**.
- 4 Gungura zuwa wuri kuma zaɓi **Sa**.

Don zaɓin tashoshin radiyo da aka ajiye

- 1 Daga jiran aiki zaɓi **Menu** > **Rediyo** > **Kari** > **Tashoshi**.
- 2 Zaɓi tashar rediyo.

Don ajiye tashoshin rediyo a wurare 1 zuwa 10

- Lokacin da ka samo tashar rediyo, latsa ka riƙe kasa (0+) - (9).

Don ajiye tashoshin rediyo a wurare 1 zuwa 10

- Lokacin da rediyo take a kunne, latsa (0+) - (9).

Don duba zaɓuɓɓukan rediyo

- Lokacin da redsiyo take a kunne, zaɓi **Kari**.

Sautunan ringi da launukan waka

Don saita sautin ringi

- 1 Daga jiran aiki zaɓi **Menu** > **Saituna** > **Sauti & faɗakarwa** shafin > **Sautin ringi**.
- 2 Zaɓi wani zaɓi.

Don saita karar sautin ringi

- 1 Daga jiran aiki zaɓi **Menu** > **Saituna** > **Sauti & faɗakarwa** shafin > **Karar ringi**.
- 2 Latsa (⏪) ko (⏩) don canja karar.
- 3 Zaɓi **Ajiye**.

Don kashe sautin ringi

- Daga jiran aiki latsa ka riƙe kasa (#-🔊). Ana rinjayar duk siginoni banda siginar kararrawa.

Don saita faɗakarwar jijjiga

- 1 Daga jiran aiki zaɓi **Menu** > **Saituna** > **Sauti & faɗakarwa** shafin > **Faɗakarwar jijjiga**.
- 2 Zaɓi wani zaɓi.

Don aika sautin ringi

- 1 Daga jiran aiki zaɓi [Menu](#) > [Mai sarrafa fayil](#) > [Kida](#) > [Sautinan ringi](#).
- 2 Gungura zuwa sautin ringi kuma zaɓi [Kari](#) > [Aika](#).
- 3 Zaɓi hanyar canja wuri.

! *Tabbatar da na'urar da aka karɓa tana goyan bayan hanyar canja wuri daka zaba.*

Don karɓar sautin ringi

- Bi umarnin daya bayyana.

! *Ba'a yarda ka musanya wasu kayan aiki masu kariyar hakkin mallaka ba. Fayil din da kaka kare yana da alamar maɗalli.*

MusicDJ™

Zaka iya tsara da shirya karin wakarka don amfani azaman sautunan ringi. Karin waka yana kunshe da nau'ukan waka guda huɗu – [Ganga](#), [Basses](#), [Chords](#) kuma [Launin harshe](#). Waka yana dauke da adadin katangar kida. Tubala suna tattare da shiryayyun sautuna tareda kalmomi daban-daban. An tsara tobula cikin [Gabatarwa](#), [Aya](#), [Chorus](#) kuma [Hutu](#). Zaka shirya launin waka da kara katanga na kida zuwa wakokin.

Don shirya launin waka

- 1 Daga jiran aiki zaɓi [Menu](#) > [Nishadi](#) > [MusicDJ™](#).
- 2 Zaɓi don [Sa](#), [Kwafi](#) ko [Manna](#) katangewa.
- 3 Yi amfani da ⏪, ⏩, ⏴ ko ⏵ don gungurawa tsakanin katangu.
- 4 Zaɓi [Kari](#) > [Ajiye launin waka](#).

Don aika karin waka

- 1 Daga jiran aiki zaɓi [Menu](#) > [Mai sarrafa fayil](#).
- 2 Gungura zuwa [Kida](#) kuma zaɓi [Buɗe](#).
- 3 Gungura zuwa karin waka kuma zaɓi [Kari](#) > [Aika](#).
- 4 Zaɓi hanyar canja wuri.

! *Tabbatar da na'urar da aka karɓa tana goyan bayan hanyar canja wuri daka zaba.*

Don karɓan launin waka

- Bi umarnin daya bayyana.
- ! *Baza ka iya aika sautunan karin waka ko fayil din MP3 a sakon rubutu ba.*

Mai rikodin sauti

Zaka iya rikodin memo na murya. Sautunan da aka yi rokodi za'a iya saita su azaman sautunan ringi.

Don rakodin sauti

- Daga jiran aiki zaɓi [Menu](#) > [Nishaɗi](#) > [Yi rikodin sauti](#).

Don sauraron rakodi

- 1 Daga jiran aiki zaɓi [Menu](#) > [Mai sarrafa fayil](#) > [Kiɗa](#).
- 2 Gungura zuwa rikodi kuma [Kunna](#).

Mai kunna bidiyo

Don kunna bidiyo

- 1 Daga jiran aiki zaɓi [Menu](#) > [Nishaɗi](#) > [Kayan bidiyo](#).
- 2 Gungura zuwa take kuma zaɓi [Kunna](#).

Ikon bidiyo



Don tsaida kunna bidiyo

- Latsa .

Don ci gaba da kunna bidiyo

- Latsa .

Je zuwa shirin gaba ko wanda yawuce

- Lokacin kunna shirye-shiryen bidiyo, latsa  ko .

Don saurin turawa gaba ko baya

- Lokacin kunna shirye-shiryen biudiyo latsa ka riƙe kasa  ko .

Don canja kara

- Latsa  ko .

Wasanni

Wayarka ta kunshe wasanni da aka riga aka loda. Zaka kuma iya saukar da wasanni. Akwai rubutun taimako saboda mafi yawan wasanni.

Don fara wasa

- 1 Daga jiran aiki zaɓi [Menu](#) > [Nishaɗi](#) > [Wasanni](#).
- 2 Zaɓi wasa.

Don kare wasa

- Latsa ka riƙe kasa .

Aikace-aikace

Kafin kayi amfani da aikace-aikacen Java™

Idan ba'a riga an shigar da saituna a wayarka ba, duba *Saituna* a shafi na 52.

Zaka iya saukarwa da gudanar da aikace-aikacen Java. Zaka iya kuma duba bayani ko saita izini daban-daban.

Don zaɓar aikace-aikacen Java

- 1 Daga jiran aiki zaɓi [Menu](#) > [Mai sarrafa fayil](#) > [Aikace-aikace](#).
- 2 Zaɓi aikace-aikace.

Don duba bayani game da aikace-aikacen Java

- 1 Daga jiran aiki zaɓi [Menu](#) > [Mai sarrafa fayil](#) > [Aikace-aikace](#).
- 2 Gungura zuwa aikace-aikace kuma zaɓi [Kari](#) > [Bayani](#).

Don saita izini saboda aikace-aikacen Java

- 1 Daga jiran aiki zaɓi [Menu](#) > [Mai sarrafa fayil](#) > [Aikace-aikace](#).
- 2 Gungura zuwa aikace-aikace kuma zaɓi [Kari](#) > [Izinoni](#).

Don saita girman allo saboda aikace-aikacen Java

- 1 Daga jiran aiki zaɓi [Menu](#) > [Mai sarrafa fayil](#) > [Aikace-aikace](#).
- 2 Gungura zuwa aikace-aikace kuma zaɓi [Kari](#) > [Girman allo](#).
- 3 Zaɓi wani zaɓi.

Bayanan martaba na Itanit saboda aikace-aikacen Java

Wasu aikace-aikacen Java suba bukar hadi zuwa Intanit don karɓar bayani.

Don zaɓar bayanin martaba na Inatanit don aikace-aikace Java

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Haduwa shafin](#) > [Saitunan intanit](#) > [Saitin Java](#).
- 2 Zaɓi wani zaɓi.

Haɗi

Saituna

Kafin kayi amfani da Intanit, PlayNow™, Abikai nawa, Java, ramute aike tare, aika hoto, email da da shafin hoto kana buɓatar samun saituna a wayarka.

Idan ba a riga anshigar da saituna ba, ka tabbata wayarka tana goyan bayan bayanan canja wuri. Zaka iya sauke saituna ta amfani da saita maye ko daga www.sonyericsson.com/support.

Don sauke saituna ta amfani da Saita maye

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Saita maye](#) > [Saukar da saituna](#).
- 2 Bi umarnin kan allon.

Don sauke saituna ta amfani da kwamfuta

- 1 Je zuwa www.sonyericsson.com/support.
- 2 Bi umarnin kan allon.

Amfani da Intanit

Zaka iya amfani da Intanit don samun damar sabis na kan layi.

- ! *Idan haxinka na Intaniy baya aiki, duba Saituna a shafi na 52, ko tuntubi mai sa aikin cibiyar sadarwa naka.*

Don fara lilo

- Daga jiran aiki zaɓi [Menu](#) > [Intanit](#).

Don fita mai lilo

- Lokacin da kake lilo a Intanit, zaɓi [Kari](#) > [Fita mai lilo](#).

Don duba zaɓuɓɓuka

- Lokacin da kake lilo a Intanit, zaɓi [Kari](#).

Lokacin da kake lilo a Intanit

Zaka iya yin kira ko aika hanyar haɗi lokacin da kake lilo a Intanit ɗin.

Don yin kira

- Lokacin da kake lilo a Intanit, zaɓi [Kari](#) > [Kayan aiki](#) > [Yi kira](#).

Don aika hanyar haɗi

- 1 Lokacin da kake lilo a Intanit, zaɓi [Kari](#) > [Kayan aiki](#) > [Aika hanyar haɗi](#).
- 2 Zaɓi wani zaɓi.

Amfani da alamun shafi

Zaka iya kirkira da shirya alamun shafi azaman hanyoyin haɗi masu sauri zuwa dakunan Yanar sadarwarka da kafi so.

Don kirkirar alamar shafi

- 1 Daga jiran aiki zaɓi [Menu](#) > [Intanit](#) > [Kari](#) > [Je zuwa](#) > [Alamomin shafi](#).
- 2 Gungura zuwa [Sbuw. alamar shafi](#) kuma zaɓi [Kara](#).
- 3 Shigar da bayani kuma zaɓi [Ajiye](#).

Don zaɓar alamar shafi

- 1 Daga jiran aiki zaɓi [Menu](#) > [Intanit](#) > [Kari](#) > [Je zuwa](#) > [Alamomin shafi](#).
- 2 Gungura zuwa alamar shafi kuma zaɓi [Je zuwa](#).

Faifan maɓallin gaj. hanyar Intanit

Zaka iya amfani faidan maɓallin don zuwa aikin mai lilo na Intanit kai tsaye.

Don zaɓar gajerun hanyoyin faifan maɓallin Intanit

- Daga jiran aiki zaɓi [Menu](#) > [Intanit](#) > [Kari](#) shafin > [Zabuɓɓuka](#) > [Lilo](#) > [Ynyi](#). [faifan maɓal.](#) > [Gajerun hanyoyi](#).

Maɓalli Gajerar hanya

	Alamomin shafi
	Shigarda adireshi
	Binciken intanit
	Tarihi
	Sak. maimait.shafi
	Mika
	Shafi a sama
	kasa shafi
	Cika fuska ko Allo na al'ada.
	Zukowa
	Gajerun hanyoyi

Saukewa

Zaka iya sauke fayiloli, masali, hotuna, jigogi, wasanni da sautin ringi daga shafin yanar sadarwa.

Don saukewa daga dakin yanar sadarwa

- 1 Lokacin da kake lilo a Intanit, zaɓi fayil don saukewa.
- 2 Bi umarnin kan allon.

Bayanan martaba

Zaka iya zaɓar wani bay. martab. Intanit idan Kanada fiye da dāya.

Don zaɓar bay. martab. Intanit don mai lilo na Intanit

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Haɗuwa](#) shafin > [Saitunan intanit](#) > [Bayn.mrtb. intanit](#).
- 2 Zaɓi wani zaɓi.

Tsaro na Intanit da takaddun shaida

Wayarka tana goyan bayan lilo mai mai tsaro. Wasu sabis na Intanit, kamar harkar banki, suna bukatar takaddun shaida a wayarka. Zai yiwu wayarka tariga takunshi takaddun shaida lokacin da kasaya ko ka iya sauke sababun takaddun shaida.

Don duba takardun shaida a waya

- Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Tsaro](#) > [Takaddun shaida](#).

Mai karanta RSS

Zaka iya karɓar ɗaukakakken abin ciki akai-akai, kamar kanun labarai, azaman ciyarwa, ta amfani da Really Simple Syndication (RSS).

Don karin sabuwar ciyarwa saboda shafin yanar sadarwa

- Lokacin da kake lilo a Intanit, zaɓi [Kari](#) > [Ciyarwa RSS](#).

Don kirkirar sabuwar ciyarwa

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Mai karanta RSS](#) > [Kari](#) > [Sabon ciyarwa](#).
- 2 Shigar da Takmammen adreshin RSS (misali http://rss.cnn.com/rss/cnn_topstories.rss) kuma zaɓi [Je zuwa](#).

Don saita da amfani da zaɓuɓɓukan mai karanta RSS

- 1 Daga jiran aiki zaɓi [Menu](#) > [Sako](#) > [Mai karanta RSS](#) > [Kari](#).
- 2 Zaɓi wani zaɓi.

Fasaha mara waya ta Bluetooth™

Aikin Bluetooth yana sa alama haɗi mara waya zuwa na'urorin masu yiwuwa. Zaka iya, misali:

- Haɗa zuwa na'urar abun sawa akunni.
- Haɗa zuwa na'urar kai na sitiriyo.
- Haɗawa zuwa na'ura fiye da ɗaya a lokaci guda.
- haɗa zuwa kamfutoci kuma sami damar Intanit.
- Aiki tare na bayani tareda kamfuyutoci.
- Yi amfani da na'urorin haɗin mai duban mai jarida.
- Musanya abuɓuwa kuma kunna wasannin multiplayer.

- ! Munyi wasiya da kewayo tsakanin mita 10 (kafa 33), ba tareda daskararrun abubuwa ba, don sadarwar Bluetooth.

Kafin kayi amfani da fasaha mara waya ta Bluetooth

Dolene ka kashe aikin Bluetooth don sadarwa zuwa waɗansu na'urorin. Kuma dolene ka ware wayarka tareda waɗansu na'urorin Bluetooth.

Don kunna aikin Bluetooth

- Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Haɗuwa](#) shafin > [Bluetooth](#) > [Kunna](#).
- ! *Tabbatar cewa na'urar da kake son ware wayarka da ita tana da aikin Bluetooth a kunne kuma za'a iya gani.*

Don ware waya tare da na'ura

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Haɗuwa](#) shafin > [Bluetooth](#) > [Na'urori nawa](#) > [Sabuwar na'ura](#) don bincika samammun na'urori.
- 2 Zaɓi na'ura.
- 3 Shigar da lambar wucewa, idan an bukata.

Don bawa haɗi dama zuwa waya

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Haɗuwa](#) shafin > [Bluetooth](#) > [Na'urori nawa](#).
- 2 Zaɓi na'ura daga lissafin.
- 3 Zaɓi [Kari](#) > [Bada izinin haɗi](#).

Don ware waya tare da abin sawa akunni na Bluetooth da farko

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Haɗuwa](#) shafin > [Bluetooth](#) > [Abin sawa akunni](#).
- 2 Zaɓi [Ee](#).
- 3 Shigar da lambar wucewa, idan an bukata.

Don ware waya tare da abin sawa akunni na Bluetooth fiye da ɗaya

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Haɗuwa](#) shafin > [Bluetooth](#) > [Abin sawa akunni](#) > [Abn.saw.akun.nw](#) > [Sab. abn.sw.akun](#).
- 2 Gungura zuwa na'ura kuma zaɓi [Kara](#).

Ajiye wuta

Zaka iya ajiye wutar baturi tareda wannan aikin. Zaka iya haɗawa kawai tare da na'urar Bluetooth guda ɗaya. Dole ne ka kashe wannan aikin idan kana son haɗawa tare da na'urar Bluetooth fiye da ɗaya a lokaci guda.

Don kunna ajiye wuta

- Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Haɗuwa](#) shafin > [Bluetooth](#) > [Ajiye wuta](#) > [Kunnawa](#).

Sunan waya

Zaka iya shigar da suna ga wayar don nunawa lokacin da wasu na'urori suka samo shi.

Don shigar da sunan waya

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Haɗuwa](#) shafin > [Bluetooth](#) > [Sunan waya](#).
- 2 Shigar da sunan wayar kuma zaɓi [Ok](#).

Ganuwa

Idan kana son wasu na' urorin Bluetooth su iya gano wayarka, zaka iya zaqar sanya wayarka mai ganuwa.

Don nuna da wayaka

- Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Haɗuwa](#) shafin > [Bluetooth](#) > [Ganuwa](#) > [Nuna waya](#).

Musayar abubuwa

Aika ko karɓi abubuwa ta amfani da fasaha mara waya na Bluetooth azaman hanyar canja wuri. Zaɓi na'ura daga lissafin na'urorin da aka samo.

Don aika lamba

- 1 Daga jiran aiki zaɓi [Menu](#) > [Lambobi](#).
- 2 Gungura zuwa lamba kuma zaɓi [Kari](#) > [Aika lamba](#) > [Ta Bluetooth](#).
- 3 Zaɓi na'ura don aika abu zuwa gareta.

Don karɓan abu

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Haɗuwa](#) shafin > [Bluetooth](#) > [Kunna](#).
- 2 Zaɓi [Ganuwa](#) > [Nuna waya](#).
- 3 Lokacin da ka karɓi wani abu, bi umarnin kan allon.

Canja wurin sauti zuwa kuma daga abin sawa akunni na Bluetooth

Zaka iya canja wurin sauti zuwa kuma daga abin sawa akunni na Bluetooth ta amfani da maballin waya ko maballin abin sawa akunni.

Don canja wurin sauti

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Haɗuwa](#) shafin > [Bluetooth](#) > [Abin sawa akunni](#) > [Kira mai shigowa](#).
- 2 Zaɓi wani zaɓi. [Cikin waya](#) yana canja wurin sauti zuwa wayar. [A abin sw. akun](#). yana canja wurin sauti zuwa abin sawa akunni.


Canja wurin fayil

Zaka iya aiki tare da kuma canja wurin fayil ta amfani da fasaha mara wata ta Bluetooth. Duba [Aiki tare ta amfani da kwamfuta](#) a shafi na 58.

Amfani da kebul na USB

Zaka iya haɗa wayarka zuwa kwamfuta tare da kebul na USB don canja wurin fayiloli ta amfani da [Cnj](#).

wur. fiyl. Hakanan zaka iya aiki tare, canja wurin fayiloli da amfani da wayaka azaman abin haɗi ta amfani da **Yanay. waya**. Don karin bayani jeka yankin farawa a www.sonyericsson.com/support.



Kafin kayi amfani da kebul na USB

- Duba *Tsarukan aiki da ake bukata* a shafi na 19.
- ! Yi amfani kawai da kebul na USB wanda keda goyan bayar wayarka. Kar a cire kebul na USB din daga wayarka ko kwamfuta yayin canja wurin fayil saboda wannan zai iya lalata kwakwalwar ajiyar wayar ko katin kwakwalwar ajiyar.

Don cire haɗin kebul na USB a amince

- 1 Kada daman gunkin disk mai curuwa a *Windows Explorer*.
- 2 Zabi *Cire*.
- 3 Cire haɗin kebul na USB lokacin da aka nuna sako mai biyowa a wayar: *Haɗin USB ya kare*. Yanzu akwai aminci don cire kebul na USB.

Jawo ka aje fayilolin mai jarida

Zaka iya jawuwa da asaiki fayiloli mai jarida tsakanin wayarka ko katin kwakwalwar ajiya da kuma kwamfuta a *Microsoft Windows Explorer*.


Don Jawowa da aje fayilolin mai jarida

- 1 Haɗa wayarka zuwa kwamfutar tareda kebul na USB.
- 2 Waya: Zabi **Cnj. wur. fiyl**. Wayar zata saura a kunne yayin canja wurin fayil.
- 3 Kwamfuta: Jira harsai kwakwalwar ajiyar waya da katin kwakwalwar ajiya sun bayyana azaman disks na waje a *Windows Explorer*.
- 4 Jawo da sauke ajiyayyun fayiloli tsakanin waya da kwamfuta.

Aiki tare


Zaka iya aiki tare ta hanya biyu da bandabam:

- Zaka iya amfani da kebul na USB ko fasaha mara waya ta Bluetooth don aiki tare da lambobin waya, alƙawura, alamun shafi, dawainiya dabayanin kula tare da tsarin kwamfuta kamar Microsoft Outlook®.
- Zaka kuma iya aiki tare da sabis na Intanet. Don karin bayani jeka yankin farawa a www.sonyericsson.com/support.

 Yi amfani kawai da ɗayan hanyoyin aiki tare a lokaci ɗaya tare da wayarka.

Aiki tare ta amfani da kwamfuta


Kafin aiki tare kana bukatar shigar da *Sony Ericsson PC Suite*.

 *Sony Ericsson PC Suite* an kunsar dashi a CD ɗinda yazo tareda wayarka kuma akwai don saukewa a www.sonyericsson.com/support.

Duba *Tsarukan aiki da ake bukata* a shafi na 19.

Don shigar da Ericsson PC Suite


- 1 Kunna kwamfutarka kuma saka CD ɗin. CD ɗin yana farawa ta atomatik kuma window na shigarwa yana buɗewa.

 *Idan CD bai bara kaɗa Farawa/gudana... kuma nau'in D: Exe kuma kaɗa OK.*

- 2 Zaɓi yare kuma kaɗa OK.
- 3 *Kaɗa Shigar da Sony Ericsson PC Suite* kuma bi umarnin kan allon.

Don aiki tare ta amfani da PC Suite

- 1 **Kwamfuta:** Fara *PC Suite* daga *Farawa/Tasre-tsare/Sony Ericsson/PC Suite*.
- 2 Bi umarnin a *PC Suite* don inda zaka yi haɗ.
- 3 **Waya:** Zaɓi **Yanay. waya**.
- 4 **Kwamfuta:** Lokacin da aka sanar da kai cewa *Sony Ericsson PC Suite* ya samo wayar, zaka iya fara amfani da aikace-aikacen yanayin wayar.

 *Don cikakkun bayani, duba yankin taimako na Sony Ericsson PC Suite inhar an shigar da software a kwamfutarka.*

Aiki tare ta amfani da sabis na Intanit

Zaka iya iya aiki atre akan layi ta amfani da sabis na Intanit tare da wayarka. In babu saitunan Intanit a wayarka, duba *Saituna* a shafi na 52.

Kafin kafara aiki tare ta amfani da sabis na Intanit

Dole ka shigar da saitunan kafin aiki tare na ramut da rijistan lissafin aiki tare a lyi tareda mai bada sabis.

Saitunan da ake bukata sune:

- [Adrsh. uwar garke](#) – uwar garke URL
- [Sunan mai amfani](#) – sunan mai amfani na lissafi.
- [Kalmar wucewa](#) – kalmar wucewa ta lissafi.
- [Haƙi](#) – zaɓi bayanin martabar Intanit.
- [Aikace-aikace](#) – yiwa aika-aikace alama don aiki tare.
- [Kayan saiti](#) – zaɓi aikace-aikace kuma shigar da sunan tushan bayanai, kuma idan an bukaci, sunan mai amfani da kalmar wucewa.
- [Tazaran aiki tare](#) – saita ko yausha zaka yi aiki tare da.
- [Farawar nisa](#) – zaɓi wani zaɓi don amfani da shi lokacin da ka fara aiki tare daga sabis.
- [Tsaro daga nisa](#) – shigar da ID na uwar garke da kalmar wucewa ta uwar garke.

Don shigar da saitunan aiki tare na nisa

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Aiki tare](#).
- 2 Gungura zuwa [Sabon lissafi](#) kuma zaɓi [Kara](#).
- 3 Shigar da suna don sabon lissafi kuma zaɓi [Ci gaba](#).
- 4 Shigar da saituna kuma zaɓi [Ajiye](#).

Don share lissafi

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Aiki tare](#).
- 2 Gungura zuwa lissafi kuma zaɓi [Kari](#) > [Share](#).

Don fara aiki tare na ramut

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Aiki tare](#).
- 2 Gungura zuwa lissafi kuma zaɓi [Fara](#).



Ɗaukaka sabis

Zaka iya ƙaukaka wayarka tare da sabuwar software. Ba zaka rasa bayani na sirri ko na waya ba.

Akwai hanyoyi biyu don ƙaukaka wayarka:

- Bisa iska ta amfani da wayarka
- Ta amfani da kebul na USB wanda aka bayar da kwamfuta mai haƙin Intanit

- ! *Sabis na daukakawa yana buƙatar samun damar bayanai (GPRS).*

Kafin kayi amfani da daukaka sabis

Idan babu saituna a wayar, duba *Saituna* a shafi na 52.

Don duba software na yau a wayar

- 1 Daga jiran aiki zabi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Sabis na daukaka](#).
- 2 Zabi [Sigar software](#).

Don amfani da sabis na Daukakawa ta amfani da wayar

- 1 Daga jiran aiki zabi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Sabis na daukaka](#).
- 2 Zabi [Binciken daukaka](#) Kuma bi umarni a kan allon.

Don amfani da sabis na daukakawa ta amfani da kebul na USB

- 1 Je zuwa www.sonyericsson.com/support ko kada *Sony Ericsson Update service* a *PC Suite* software in an shigar a kwamfutarka. Duba *Don shigar da Ericsson PC Suite* a shafi na 58.
- 2 Zabi yanki da kasa.
- 3 Bi umarnin akan allon.

Don saita mai tuni don amfani da daukaka sabis

- 1 Daga jiran aiki zabi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Sabis na daukaka](#) > [Mai tuni](#).
- 2 Zabi wani zabi.

Karin fasali

Kararrawa

Zaka iya saita sauti ko rediyo azaman sigina na kararrawa. Kararrawa tana yin sauti ko da an saita wayar zuwa shiru ko an akashe. Lokacin da kararrawa ke sauti zaka iya sata shiru zuwa minti 9 ko ka kashe ta.

Don saita kararrawa

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Kararrawa](#).
- 2 Gungura zuwa kararrawa kuma zaɓi [Shirya](#).
- 3 Gungura zuwa [Lokacin](#): kuma zaɓi [Shirya](#).
- 4 Shigar da lokaci kuma zaɓi [Ok](#) > [Ajiye](#).

Don saita maimaita kararrawa

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Kararrawa](#).
- 2 Gungura zuwa kararrawa kuma zaɓi [Shirya](#).
- 3 Gungura zuwa [Mai dawowa](#): kuma zaɓi [Shirya](#).
- 4 Gungura zuwa rana kuma zaɓi [Alama](#).
- 5 Zaɓi [Anyi](#) > [Ajiye](#).

Don saita siginar kararrawa

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Kararrawa](#).
- 2 Gungura zuwa kararrawa kuma zaɓi [Shirya](#).
- 3 Gungura zuwa [Sgnl. na kararra.](#): kuma zaɓi [Shirya](#).
- 4 Gungura zuwa zaɓi kuma zaɓi [Ajiye](#).

Don sa kararrawa shiru

- Lokacin da kararrawa tayi sauti, latsa kowane maɓalli.

Don sa kararrawar rediyo shiru

- Lokacin da kararrawa tayi sauti, zaɓi [Munsh](#).

Don kashe kararrawa

- Lokacin da kararrawa tayi sauti, zaɓi [Kashe](#).

Don soke kararrawa

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Kararrawa](#).
- 2 Gungura zuwa kararrawa kuma zaɓi [Kashe](#).

Kalanda

Za'a iya haɗa kalanda aiki tare da kalandar kwamfuta ko tareda kalanda a yanar sadarwa. Duba *Aiki tare* a shafi na 58.

Alkawurra

Zaka iya kara sabuwar alkawari ko sake amfani da alkawari mai gudana.

Don kara alkawari

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Kalanda](#).
- 2 Zaɓi kwanan wata.
- 3 Gungura zuwa [Sabuwar alkawari](#) kuma zaɓi [Kara](#).
- 4 Shigar da bayani kuma tabbatar da kowace shigarwa.
- 5 Zaɓi [Ajiye](#).

Don duba alkawari

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Kalanda](#).
- 2 Zaɓi kwanan wata.
- 3 Gungura zuwa alkawari kuma zaɓi [Duba](#).

Don sake amfani da alkawari mai gudana

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Kalanda](#).
- 2 Zaɓi kwanan wata.
- 3 Gungura zuwa alkawari kuma zaɓi [Duba](#).
- 4 Zaɓi [Kari](#) > [Shirya](#).
- 5 Shirya alkawari kuma tabbatar da kowace shigarwa.
- 6 Zaɓi [Ajiye](#).

Don aika alkawari

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Kalanda](#).
- 2 Zaɓi kwanan wata.
- 3 Gungura zuwa alkawari kuma zaɓi [Kari](#) > [Aika](#).
- 4 Zaɓi hanyar canja wuri.

! *Tabbatar da na'urar da aka karɓa tana goyan bayan hanyar canja wuri daka zaɓa.*

Don duba satin kalanda

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Kalanda](#).
- 2 Zaɓi kwanan wata.
- 3 Zaɓi [Kari](#) > [Duba sati](#).

Don saita lokacin da masu tuni zasu yi sauti


- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Kalanda](#).
- 2 Zaɓi kwanan wata.
- 3 Zaɓi [Kari](#) > [Na ci gaba](#) > [Masu tuni](#).
- 4 Zaɓi wani zaɓi.

! *Zabin masu tuni da aka saita a kalanda yana rinjayar zabin masu tuni da aka saita a dawainiya.*

Kewayawa kalandarka

Yi amfani da maɓalliin kewayawa don matsawa tsakanin kwanaki ko makonni. A duban watan, zaka iya amfani da gajerun hanyoyin faifan maɓalli.

Maɓalli Gajerar hanya

1  Mako ɗaya baya

4 Wata ɗaya baya

7 Shekara ɗaya baya

C  Kwanan watan yau

3 mako na gaba

6 Wata na gaba

9 Shekara ta gaba

Saitunan kalanda

Don duba zaɓuɓɓukan kalanda

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Kalanda](#).
- 2 Zaɓi [Kari](#).

Dawainiya

Zaka iya kara sabuwar dawainiya ko sake amfani da dawainiyar data kasance.

Don kara dawainiya

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Dawainiya](#).
- 2 Zaɓi [Sabu. dawainiya](#) > [Kara](#).
- 3 Zaɓi wani zaɓi.
- 4 Shigar da cikakken bayani kuma tabbatar da kowace shigarwa.

Don duba dawainiya

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Dawainiya](#).
- 2 Gungura zuwa dawainiya kuma zaɓi [Duba](#).

Don sake amfani da dawainiya wanda ya kasance

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Dawainiya](#).
- 2 Gungura zuwa dawainiya kuma zaɓi [Duba](#).
- 3 Zaɓi [Kari](#) > [Shirya](#).
- 4 Shirya dawainiyar kuma zaɓi [Ci gaba](#).
- 5 Zaɓi don saita mai tuni.

Don aika dawainiya

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Dawainiya](#).
- 2 Gungura zuwa dawainiya kuma zaɓi [Kari](#) > [Aika](#).
- 3 Zaɓi hanyar canja wuri.

- ! *Tabbatar da na'urar da aka karɓa tana goyan bayan hanyar canja wuri daka zaɓa.*

Don saita lokacin da masu tuni zasu yi sauti

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Dawainiya](#).
- 2 Gungura zuwa dawainiya kuma zaɓi [Kari](#) > [Masu tuni](#).
- 3 Zaɓi wani zaɓi.

- ! *Zabin masu tuni da aka saita a dawainiya yana rinjayar zabin masu tuni da aka saita a kalanda.*

Bayanan kula

Zaka iya yin bayanin kula da ajiye su. Zaka kuma iya nuna bayanin kula a jiran aiki.

Don kara bayanin kula

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Bayanan kula](#).
- 2 Zaɓi [Sab.bayanin kula](#) > [Kara](#).
- 3 Rubuta bayanin kula kuma zaɓi [Ajiye](#).

Don nuna bayanin kula a jiran aiki

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Bayanan kula](#).
- 2 Gungura zuwa bayanin kula kuma zaɓi [Kari](#) > [Nuna a jiran aiki](#).

Don shirya bayanin kula

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Bayanan kula](#).
- 2 Gungura zuwa bayanin kula kuma zaɓi [Kari](#) > [Shirya](#).
- 3 Shirya bayanin kula kuma zaɓi [Ajiye](#).

Don aika bayanin kula

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Bayanan kula](#).
- 2 Gungura zuwa bayanin kula kuma zaɓi [Kari](#) > [Aika](#).
- 3 Zaɓi hanyar canja wuri.

- ! *Tabbatar da na'urar da aka karɓa tana goyan bayan hanyar canja wuri daka zaɓa.*

Mai kidayar lokaci, agogon awon gudu da kalkaleta



Don amfani da mai kidayar lokaci

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Mai kidyr. lokaci](#).
- 2 Shigar da awa, minti da sakan.
- 3 Zaɓi [Fara](#).

Don amfani da agogon awon gudu

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Aggn.awn. gudu](#) > [Fara](#).
- 2 Don duba sabon lokacin juyi, zaɓi [Sabn. juyi](#).

Don amfani da kalkaleta

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Kalkaleta](#).
- 2 Latsa  ko  don zaɓin ÷ x - + . % =.

Memo na lamba

Zaka iya jije lambar tsaro, misali, saboda katin judi. Dole ka saita lambarwucewa don boɗi memo.

Kalmarbinciki

Kalmarbincike tana tabbatar da cewa ka shigae da lambarwucewa na yanzu. Idan lambaewucewa daidai ce, na yanzun zai bayyan. Idan kalmarwucewa ba dai-dai bane kjalmarbincikle da lambobi zasu bayyan ba dai-dai ba.

Don buɗe memo na lamba da farko

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Memo na lamba](#).
- 2 Bi umarni a kan allon kuma zaɓi [Ci gaba](#).
- 3 Shigar da lambarwucewa kuma zaɓi [Ci gaba](#).
- 4 Tabbatar da lambarwucewa kuma zaɓi [Ci gaba](#).
- 5 Shigar da dubakalma kuma zaɓi [Anyi](#).

Don kara lamba

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Memo na lamba](#).
- 2 Shigar da lambarwucewa kuma zaɓi [Sabuwar lamba](#) > [Kara](#).
- 3 Shigar da suna abokin aiki lambar kuma zaɓi [Ci gaba](#).
- 4 Shigar da lambar kuma zaɓi [Anyi](#).

Don canja lambar wucewa

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Memo na lamba](#).
- 2 Shigar da lambar wucewa taka kuma zaɓi [Kari](#) > [Canj.lamb.wcew](#).
- 3 Shigar da sabuwar lambar wucewa taka kuma zaɓi [Ci gaba](#).
- 4 Sake shigar da sabuwar lambar wucewar kuma zaɓi [Ci gaba](#).
- 5 Shigar da dubakalma kuma zaɓi [Anyi](#).

Manta kalmarwucewa?

Idan kamanta kalmarwucewarka, dole ka sake saita meno na lamba. Hanyar da duk masu shiga a memo na lamba a sharesu. Lokaci na gaba da shigar da memo na lamba, dole ka gudanar kamar kana shigarwa da farko. Duba *Don buɗe memo na lamba da farko* a shafi na 65.

Don sake saitin memo na lamba

- 1 Daga jiran aiki zaɓi [Menu](#) > [Oganeza](#) > [Memo na lamba](#).
- 2 Shigar da kowace lambarwucewa don samun damar memo. Dubakalma da lambobi waɗanda aka nuna a sannan bai dai-dai bane.
- 3 Zaɓi [Kari](#) > [Sake saiti](#).
- 4 [Sake saitin memo na lamba?](#) yana bayyana.
- 5 Zaɓi [Ee](#).

Bayanan martaba

Bayanan martaba suna haɗa wayarka zuwa yanayi daban-daban, misali, yayin cikin taro ko lokacin tuki. Wasu saitunan bayanan martaba, misali, karrar ringi zai yuwu a dai-daitasu ta atomatik don dacewa da takamaiman wuri ko na'urorin haɗi. Zaka iya sake saita duk saitunan bayanan martaba zuwa yadda aka saita su lokacin ka sayi wayarka.

Don zaɓar bayanin martaba

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Bayanan martaba](#).
- 2 Zaɓi bayanin martaba.

Don duba da shirya bayanin martaba

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Bayanan martaba](#).
 - 2 Gungura zuwa bayanin martaba kuma zaɓi [Kari](#) > [Dubu ka ashirya](#).
- ! *Bazaka iya sake sunan bayanin martaba na al'ada ba.*

Don sake saita bayanan martaba

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Bayanan martaba](#).
- 2 Gungura zuwa bayanin martaba kuma zaɓi [Kari](#) > [Sk. st.bay. mart.](#)

Lokc.da kwn.wata

Don saita lokaci

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Lokc. & kwn.wt.](#) > [Lokaci](#).
- 2 Shigar da lokacin kuma zaɓi [Ajiye](#).

Don saita kwanan wata

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Lokc. & kwn.wt.](#) > [Kwanan wata](#).
- 2 Shigar kwanan wata kuma zaɓi [Ajiye](#).

Jigogi

Zaka iya canja bayyanar allo ta abubuwa kamar launuka da fuskar bangon waya. Kuma zaka iya kirkirar sabbin jigogi da saukesu. Don karin bayani tafi zuwa www.sonyericsson.com/support.

Don saita jigo

- 1 Daga jiran aiki zaɓi [Menu](#) > [Mai sarrafa fayil](#) > [Jigogi](#).
- 2 Gungura zuwa jigo kuma zaɓi [Saiti](#).

Makullai

Kulle katin SIM

Wannan makullin yana kare biyan kuɗinka ne kawai. Wayarka zatayi aiki da sabon katin SIM. Idan makulli yana kunne, dole ka shigar da PIN naka (Lambar Shaida ta Sirri).

Idan ka shigar da PIN naka kuskure sau uku a jere, Ana katange katin SIM kuma kana bukatar shigar da PUK naka (Maɓallin Cire katanga na Sirri). Ana bada PIN da PUK naka ta afaretan cibiyar sadarwarka.

Don cire katangar katin SIM

- 1 Lokacin da [An katange PIN](#) ya bayyana, shigar da PUK naka kuma zaɓi [Ok](#).
- 2 Shigar da sabuwar lambar PIN huɗu zuwa takwas kuma zaɓi [Ok](#).
- 3 Sake shigar da sabon PIN kuma zaɓi [Ok](#).

Don shirya PIN

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Tsaro](#) > [Mukullai](#) > [Kariyar SIM](#) > [Canja PIN](#).
- 2 Shigar da PIN naka kuma zaɓi [Ok](#).
- 3 Shigar da sabuwar lambar PIN huɗu zuwa takwas kuma zaɓi [Ok](#).
- 4 Sake shigar da sabon PIN kuma zaɓi [Ok](#).

! *Idan Lambobi basu jitu ba ya bayyana, ka shigar da sabon PIN kuskure. Idan PIN mara daidai yana bayyana, wanda aka bishi da Tsohuwar PIN:, ka shigar da tsohon PIN ba daidai ba.*

Don amfani da makullin katin SIM

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Tsaro](#) > [Mukullai](#) > [Kariyar SIM](#) > [Kariya](#).
- 2 Zaɓi wani zaɓi.
- 3 Shigar da PIN naka kuma zaɓi [Ok](#).

Makullin waya

Zaka iya tsaida amfani mara izini na wayarka. Canja lambar makullin wayar (0000) zuwa kowacce kebabbiyar lamba huɗu zuwa takwas.

- ! *Yana da mahimmanci katuna sabuwar lambarka. Idan ka manta ta, dole ne ka dauki wayarka zuwa wakilin Sony Ericsson na gida.*

Don amfani da makullin waya

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Tsaro](#) > [Mukullai](#) > [Kariyar waya](#) > [Kariya](#).
- 2 Zaɓi wani zaɓi.
- 3 Shigar da lambar kulle waya kuma zaɓi [Ok](#).

Don canja lambar makullin waya

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba ɗaya](#) shafin > [Tsaro](#) > [Mukullai](#) > [Kariyar waya](#) > [Canja lamba](#).
- 2 Shigar da tsohuwar lambar kuma zaɓi [Ok](#).
- 3 Shigar da sabuwar lambar kuma zaɓi [Ok](#).
- 4 Maimaita lambar kuma zaɓi [Ok](#).

lambar IMEI

Adana kwafin lambarka ta (Asalin Kayan aikin Wayar hannu na Duniya) IMEI koda za'a sace wayarka.

Don duba lambar IMEI


- Daga jiran aiki zaɓi [*a#](#), [#-#](#), [□ +](#), [6](#), [#-#](#).

Shirya matsala

Me yasa wayar bata aiki yanda nakeso tayi?

Wasu matsalolin zasu bukaci ka kira afaretan cibiyar sadarwarka.

Me zaka yi idan murfin ya ballo?



Ana iya cire haɗin murfin.

- 1 Lokacin da ka sake haɗa murfin yana da mahimmanci cewa kusurwar murfin daidai take.
- 2 Sanya hinjin murfi na hagu kewayen maratayi.
- 3 A nitse ka jawo hinjin murfi na dama cikin wurin.

Lokacin da aka sanya murfin cikin nasara yana ballawa lokacin da ka rufe shi.

Don wasu karin goyan baya jeka www.sonyericsson.com/support.

Tambayoyi na gama gari

Ina da matsala da damar kwakwalwar ajiya ko wayra tana aiki a hankali

Sake kunna wayarka ko wata rana don yanta kwakwalwar ajiya ko yi [Sake saitin ainihi](#).

Sake saitin zuwa na ainihi

Idan ka zaɓa [Sake saitin saitina](#), chance-canje waɗan da kayi za'a share su.

Idan ka zaɓi [Sake satin duk](#), karin canje-canje zuwa saitun, Duk lambobi, sakonni, bayanai na sirri, da loambar da kasaukar, ka karɓa ko ka shirya suma za'a share su.

Don sake saita wayar

- 1 Daga jiran aiki zaɓi [Menu](#) > [Saituna](#) > [Gaba daya](#) shafin > [Sake saitin ainihi](#) > [Sake saitin saitina](#).
- 2 Bi umarni a kan allon kuma zaɓi [Ci gaba](#).

Bazan iya cajin waya ba ko damar baturi tayi kasa

Ba'a haɗa baturi yadda yakamata ba ko haɗin baturi bai da kyau. Cire baturin kuma tsaface mai haɗi.

Baturin ya lalace yana bukaratar canji. Duba [Cajin baturi](#) a shafi na 8.

Babu gunkin baturi daya bayyana lokacin da nafara cajin waya

Zai iya daukar yan mintuna kafin gunkin baturin ya bayyana a allon.

Wasu zaɓuɓɓukan menu suna bayyana a launin toka

Ba'a kunna sabis ba. Tuntubi afaretan cibiyar sadarwarka.

Bana iya amfani da SMS/sakonnin rubutu a wayata


Saituna suna bacewa ko kuskure. Tuntubi afaretarka na cibiyar sadarwa don gano saitunan wurin sabis na SMS. Duba *Sakonnin rubutu* a shafi na 34.

Bana iya amfani da sakonnin hoto a wayata

Bayarn kuɗinka bai kunshi damar bayanai ba. Saituna suna bacewa ko kuskure. Tuntubi mai sa aikin cibiyar sadarwa naka.

Duba *Taimako a wayarka* a shafi na 7 ko je zuwa www.sonyericsson.com/support don tsara saituna ka bi umarnin kan allon. Duba *Saituna* a shafi na 52.

Ta yaya zan kunna da kashe shigar da rubutun T9 lokacin rubuta sakon rubutu?

Lokacin da ka shigar da rubutu, latsa ka riƙe kasa . Zaka gani a saman lokacin da aka kunna allon T9 Text Input.

Tayaya zan cnaja yaren waya?

- 1 Daga jiran aiki zaɓi **Menu > Saituna > Gaba daya** shafin > **Yare > Yaren waya**.
- 2 Zaɓi wani zaɓi.

Bazan iya amfani da Intanit ba

Biyan kuɗinka bai kunshi damar bayanai ba. Saituna Intanit suna bacewa ko kuskure. Tuntubi mai sa aikin cibiyar sadarwa naka.

Duba *Taimako a wayarka* a shafi na 7 ko je www.sonyericsson.com/support don tsara saitin Intanit, kuma bi umarni a allon. Duba *Saituna* a shafi na 52.

Wasu na'urori baza su iya gano wayar ta amfani da fasaha mara waya ta Bluetooth ba

Baka kunna aikin Bluetooth ba.

Tabbbatar cewa an saita ganuwa don nuna wayar. Duba *Don karɓan abu* a shafi na 56.

Bana iya aiki tare ko canja wurin bayanai tsakanin wayata da kwamfuta, lokacin amfani da kebul na USB.

Kebul ko software wanda yazo da kwamfutarka ba'a shigar dashi yadda ya kamata ba. Je zuwa www.sonyericsson.com/support, don karata jagoran farwa wanda ya kunshi bayyananun umarni umarni da jagoran shirya matsala.

Kuskuren sakonni

Sa SIM

Babu katin SIM a wayarka ko ka shigar da shi ba daida ba.

Duba *Cajin baturi* a shafi na 8.

Mai haɗa katin SIM yana bukatar tsafatawa. Katin ta lalace, tuntuɓi afaretanka na cibiyar sadarwa.

Sa katin SIM mai kyau

An saita wayar don aiki tareda takamammen katunan SIM. Bincika idan kana amfani afareton katin SIM dai-dai.

PIN mara daidai/PIN2 mara daidai

Ka shigar da PIN ko PIN2 naka kuskure.

Shigar da PIN ko PIN2 mai kyau kuma zaɓi [Ee](#). Duba *Don saka katin SIM* a shafi na 5.

An katange PIN/An katange PIN2

Ka shigar da lambar PIN ko PIN2 naka kuskure sau uku a jere.

Duba *Kulle katin SIM* a shafi 67.

Lambobi basu jitu ba

Lambobin da ka shigar basu dace ba. Lokacin da kake so ka canja lambar tsaro, misali PIN naka, dole ka tabbatar da sabuwar lamba. Duba *Kulle katin SIM* a shafi na 67.

Bab. kway.cb.sadr.

Wayarka yana yanayin kaura. Duba *Yanayin kaura* a shafi na 7.

Wayarka bata karɓar signa na radiyo, ko signa da aka karɓa yana da rauni kwarai. Tuntuɓi mai sa aikin cibiyar sadarwar ka kuma a tabbata cewa cibiyar yanar sadarwa ya kewaye in da kake.

Katin SIM baya aiki yadda ya kamata. Sa katin SIM naka cikin wata wayar. Idan wannan yana aiki, da alama wayarka ce ke haifar da matsalar. Tuntuɓi wurin sabis na Sony Ericsson mafi kusa.

Kiran gaggw. kawai

Kana cikin kewayo na cibiyar sadarwa, sai dai baka da izinin amfani da ita. Ko kaka, acikin gaggawa, wasu afaretocin cibiyar sadarwa suna baka dama don kiran lambar gaggawa ta duniya 112. Duan *Kiran gaggawa* a shafi 25.

An cire katanga PUK. Tuntuɓi mai sa aiki.

Ka shigar da lambar maɓallin cire katanga na sirri naka (PUK) kuskure sau 10 a jere.

Yin caji, bakon baturi

Baturin da kake amfani ba ba wanda Sony Ericsson-ya yard da shi bane. Duba *Baturi* a shafi na 75.

Goyan baya

Argentina	800-333-7427
Australia	1-300650-600
Belgique/België	02-7451611

Muhimman bayanai

Mai amfani da gidan yanar sadarwa na Sony Ericsson

A www.sonyericsson.com/support akwai yankin goyon baya inda taimako da tukwici suke a kada kawai waje. Anan zaka sami sabon daukaka software na kwamfuta da tukwici akan yadda zaka yi amfani da abin sana'arka da nagarta sosai.

Hidima da goyan baya

Daga yanzu har ka sami hanyar haɗi don samun kebantar gatan sabis kamar:

- Gidajen yanar sadarwa na duniya da na gida suna bada goyan baya.
- Cibiyar sadarwa ta duniya na Wuraren Kira.
- Babbar cibiyar sadarwar abokan sabis na Sony Ericsson.
- Lakacin garanti. Kara koyo gameda sharuɗɗan garanti a wannan jagorar mai amfanin. Don karin bayani jeka yankin farawa a www.sonyericsson.com/support. Don takamammen sabis na afareta da fasaloli, tuntuɓi afaretan cibiyar sadarwarka don karin bayani. Zaka kuma iya tuntuɓar Wuraren Kiranmu. Idan kasar ka/nahiyai bai fito acikin lissafi ba, ka tuntuɓi dila na yankin ka. Za'a caje ka don kira zuwa ɗaya daga wuraren kiran mu dangane da kimar cikin gida, gami da harajin gida, sai dai lambar waya idan kyauta ce.

Acikin abin aukuwa wanda ba'a so cewa samfur yana bukarar sabis, tuntuɓi dila wanda daga wurin sa aka saya, ko ɗaya daga abokan sabis namu. Saboda da'awar garanti, ajiye shaidar saye.

questions.AR@support.sonyericsson.com
questions.AU@support.sonyericsson.com
questions.BE@support.sonyericsson.com

Brasil	4001-04444	questions.BR@support.sonyericsson.com
Canada	1-866-766-9374	questions.CA@support.sonyericsson.com
Central Africa	+27 112589023	questions.CF@support.sonyericsson.com
Chile	123-0020-0656	questions.CL@support.sonyericsson.com
Colombia	18009122135	questions.CO@support.sonyericsson.com
Česká republika	844550 055	questions.CZ@support.sonyericsson.com
Danmark	33 31 28 28	questions.DK@support.sonyericsson.com
Deutschland	0180 534 2020	questions.DE@support.sonyericsson.com
Ελλάδα	801-11-810-810 210-89 91 919	questions.GR@support.sonyericsson.com
España	902 180 576	questions.ES@support.sonyericsson.com
France	0 825 383 383	questions.FR@support.sonyericsson.com
Hong Kong/香港	8203 8863	questions.HK@support.sonyericsson.com
Hrvatska	062 000 000	questions.HR@support.sonyericsson.com
India/भारत	39011111	questions.IN@support.sonyericsson.com
Indonesia	021-2701388	questions.ID@support.sonyericsson.com
Ireland	1850 545 888	questions.IE@support.sonyericsson.com
Italia	06 48895206	questions.IT@support.sonyericsson.com
Lietuva	8 70055030	questions.LT@support.sonyericsson.com
Magyarország	+36 1 880 4747	questions.HU@support.sonyericsson.com
Malaysia	1-800-889900	questions.MY@support.sonyericsson.com
México	01 800 000 4722	questions.MX@support.sonyericsson.com
Nederland	0900 899 8318	questions.NL@support.sonyericsson.com
New Zealand	0800-100150	questions.NZ@support.sonyericsson.com
Norge	815 00 840	questions.NO@support.sonyericsson.com
Österreich	0810 200245	questions.AT@support.sonyericsson.com
Pakistan	111 22 55 73 (92-21) 111 22 55 73	questions.PK@support.sonyericsson.com
Philippines/Pilipinas	02-6351860	questions.PH@support.sonyericsson.com
Polska	0 (prefiks) 22 6916200	questions.PL@support.sonyericsson.com
Portugal	808 204 466	questions.PT@support.sonyericsson.com
România	(+4021) 401 0401	questions.RO@support.sonyericsson.com
Россия	8 (495) 787 0986	questions.RU@support.sonyericsson.com
Schweiz/Suisse/Svizzera	0848 824 040	questions.CH@support.sonyericsson.com
Singapore	67440733	questions.SG@support.sonyericsson.com
Slovensko	02-5443 6443	questions.SK@support.sonyericsson.com
South Africa	0861 6322222	questions.ZA@support.sonyericsson.com

Suomi	09-299 2000
Sverige	013-24 45 00
Türkiye	0212 473 77 71
Україна	(+0380) 44 590 1515
United Kingdom	08705 23 7237
United States	1-866-7669347
Venezuela	0-800-100-2250
الإمارات العربية المتحدة	43 919880
中国	4008100000
台灣	02-25625511
ไทย	02-2483030

questions.FI@support.sonyericsson.com
 questions.SE@support.sonyericsson.com
 questions.TR@support.sonyericsson.com
 questions.UA@support.sonyericsson.com
 questions.GB@support.sonyericsson.com
 questions.US@support.sonyericsson.com
 questions.VE@support.sonyericsson.com
 questions.AE@support.sonyericsson.com
 questions.CN@support.sonyericsson.com
 questions.TW@support.sonyericsson.com
 questions.TH@support.sonyericsson.com

Bayanai don lafiya da rinjayen amfani

Ka bi wadannan bayanai. Gaza yin wani abu zai iya zama hadari ga na'ura ko cutar da lafiyar ka. Idan na'ura an shigar da ita cikin kowane sharadi da aka lissafa a kasa ko kana shakku azaman cikakken aiki tabbata ka sami bincikar na'ura ta mamba amini na sabis kafin caji ko amafani da ita.



Yabo na amincin samfuri nmu

- Koyaushe yi ma'amala da samfur naka da kulawa kuma adana shi a tsafataccen wuri mara kura.
- **Gargadi!** Zai yiwu yafashe in an zubar cikin wuta.
- Kada a bijirar da samfur ga ruwa ko danshi ko laima.
- Kada a bijirar da baturi ga yanayin zafi/sanyi. Kada a bijirar da baturi ga yanayin zafi ko sanyi sama da +60°C (+140°F).
- Kada ka bijirar da samfur naka ga buɗadɗen harshen wuta ko kunnanniyar taba.
- Kada ka saki, jifa ko kokarin lankwasa samfur naka.



- Kada ka yi fenti ko yunkurin kwakkwance ko gyaggyara samfur naka. Kabantaccen mai izini na Sony Ericsson kawai zai yi sabis.
- Shawarci ma'aikacin lafiya mai izini da umarni na masu pera na'urorin likitanci kafin amfani da samfuri naka kusa da mai auna bugun zuciya ko ko wasu na'urori na likitanci ko kayan aiki.
- Tsada cigaba da amfani da na'urorin lantarki ko hana aikin rabawa ba reɗiyu na ma'ura inda ake bukata ko aka nemi haka.
- Kada kayi amfani da samfuri naka a cikin yanki inda yiwuwar fashewar yanayi kefaruwa.
- Kada ka yi amfani da samfur naka ko shigar da kayan aiki marasa waya a wuri sama da jakar iska a motarka.
- Tsanaki: Tsagaggya ko karyayyar fuska zata iya haifar da kaifafan gefuna ko fatsi-fatsi wanda zasu iya cutar da lamba.
- Kada kayi amfani da Abin kai na Bluetooth Headset a waje da bai daceba ko zai zama matsawa.



YARA

Gargadi! Ajiye nesa da isar yara. ka bari yara suyi wasa da wayarka ta hannu ko nkada a'urorin had inta.



zasu iya cutar da kansu ko wasu. mai yiwuwa samfura suk unsar k ananan sassa waƙ anda zasu iya b allewa kuma su kawo haƙ arin shak ewa.

Mai bada wuta(caji)

Hada caji zuwa mafarin wutar kamar yadda aka yi alama a samfuri. Kada kayi amfani a waje ko waje mai laima. Kada ka canja bujirar da alamar ga lalacwa ko matsi. Cire fulogi na sashi kafin tsaftaceta. Karka taba canja fukogi. Idan bata baidace da gurbi ba, sami gurbi mai dacewa da aka sauke ta kwararren masanin lantarki. Lokacin da aka haxa mai kawo wuta akwai karamar magudana na wuta. Don kuacewa wannan karamar bara na makamashi, cire haƙin kawo wuta lokacin da caji samfuri yacika. Amfani da na' urori caji waƙan da basu da caji alama ta Sony Ericsson mai yiwuwa ya tilasta hadurra na aminci.

Baturi

Sabo ko baturi mara kyau zai iya samun ragaggen iko na lokaci. Yi cikakken canji baturi kafin amfani na farko. Amfani da baturi kawai kan abubuwan da ake da muradi. Yi caji baturi ne kawai a yanayin zafi tsakanin +5°C (+41°F) da +45°C (+113°F). Kada ka sanya baturi a bakin ka. Kada kabar baturi yarik haɗuɗ da wani karfe. Kashe samfurinka kafin cire baturi. Aiki yana dogara ne da yanayin sany/zafi kafin sigina, salullukan da aka zaɓa da murya ko yaɗa bayanai. Abikan aikin Sony Ericsson kawai sune zasu cire ko sauya wajen ginannen batura. Amfani da baturan da da basu da alama ta Sony Ericsson mai yiwuwa ya tilasta haɗurra na aminci.

Na'urorin likita naka

Wayoyin hannu mai yiwuwa surinjayi kafaffun kayan aikin likitanci. Rage haxarun kutse ta aje nisa mafi karanci na canti mita 15 (inci 6) tsakanin waya da na'ura. Yi amfani da wayar a kuninika na dama.

Kada ka ɗauke waya a aljuhun gaba. Kashe wayar in kana zargin kitse. Don duk na'urorin likita, shawarci likitan ka da masu kerata.

Tuki

Wasu kamfanonin kera motoci sun hana wayoyin hannu a motocin su sai an sa abun sawa akunni mai eriya tawaje. Binciki wakilin mai kera motarka don ka tabbatar cewa wayarka ta hannu ko abin sawa akunni na ba zai rinjayi tsarukan lantarki a motarka. Dole a bada cikakkiyar kula don tuki a kowane lokaci da dokokin da ke kuntata amfani na'urori dole ne a kula dasu.

GPS/Kafaffun ayyukan wurare

Wasu samfura suna bada GPS/Kafaffun ayyukan wurare. An bada kayyadaddun ayyukan wurare "azaman cewa" da "da dukan kurakurai". Sony Ericsson baya bada kowane wakili ko garanti domin kwarewar wannan bayanin wurin. Amfanin kafaffen bayanin wuri ta na'ura bazai katse ko zama mara kuskure ba kuma yana iya zama mai dogaro da samuwar sabis na cibiyar sadarwa. Kula cewa ayyuka na iya raguwa ko gazawa cikin takamaiman mahalli kamar cikin gini ko wurare tsakiyar gine-gine. Tsanaki: Kada ayi amfani da ayyukan GPS cikin hanya wacce ke haifar da fashewa daga tuki.

Kiran gaggawa

Ba za'a iya garantin kira karkashin kowane sharaɗi ba. Kada ka dogara gaba ɗaya kan wayoyin hannu saboda sadarwa mai mahimmanci. Kira bazai yuwu a kowane wuri ba, ko a duk cibiyoyin sadarwa salula, ko lokacin takamaiman sabis na cibiyar sadarwa da ko fasalolin wayar hannu ke cikin aiki.

Eriya

Amfani da na'urorin eriya mara alamar Sony Ericsson ta musamman don wannan kirar zai iya bata maka wayarka ta hannu, rage aiki, da

sanya matakan SAR sama da kafaffun iyakoki. Kada ka rufe eriyar da hannunka wannan yana rinjayar ingancin kira, matakan wuta da rakaita kira da lokutan jiran aiki.

Amfani nagari

Rike wayar hannunka kamar yadda zaka yiwa kowace waya. Kada ka rufe saman waya lokacin da take aiki, kuma wanan zai iya tasiri a nagartar kira zai iya sanya waya ta yi aiki a yanayi wuta mai karfi sosai fiye da yadda ake bukata, kuma zai rage magana da lokacin jiran aiki.

Mitar radiyo (RF) karfi da darajar musamman (SAR)

Lokacin da wayarka ko Bluetooth ke kunne, tana fitar da matakan wuta mara daraja makamashin mitar radiyo. An bakaka jagororin aminci na duniya ta lokuta da ta kimar karatun kimiyya. Wadannan jagorori sun kafa matakiya masu izini na bayyanar wayar radiyo. Jagororin suna konsar surar iyakn aminci don tabbatar da aminci ka kuwwa da kidaya don kowane saqani na mauni.

Specific Absorption Rate (SAR) an amfani da shi ne don auna adadin karfin mitar radiyo a jiki lokacin amfani da wayar hannu. Wannan kima ta SAR ya kudurta gamsashin matakin wuta mafi girma a dakin bincike, amma an tsara wayar don amfani da mafi karancin wuta na tilasa don samun damar zabaɓɓen cibiyar sadarwa, matakin SAR na hakika zai iya zama pasa kwarar da wannan kimar. Babu shaida na banbancin aminci ginanne kan banbancin kima a SAR.

Samfuri tareda masu yaxa rediyu waxanda aka saida a Amurka dole su sami gamsuwar Federal Communications Commission (FCC). Lokacinda nema, ana gwaji-gwage lokacin da aka sa wayar a kunni ko a jiki. Don aikin-sawa a jiki, An gwada wannan waya lokacin da akayi mata wuri mafi paramci daga 15 mm daga jiki ba tareda kowane

sassa na karfe a cikin kusancin waya ko lokacin amfani tareda na 'urar haɗi ta asali ta Sony Ericsson wadda akayi nufi don wannan wayar da sawa a jiki. Don karin bayani game da SAR da bayyanar mitar radiyo je wuza: www.sonyericsson.com/health.

Malware

Malware (short for malicious software) software ne wanda zai iya cutar da wayarka ta hannu da wasu kwamfutoci. Malware ko aikace-aikace masu cutarwa zasu iya punsar kwyyoyin cuta tsutsotsi, spyware, da wasu shirye-shiryе da ba'a so. Lokacinda na'uraruka bata yi ama'aunai na tsaro ba don ountata irin waxannan pwazon ba Sony Ericsson ba a garanti ko wakitar cewa na'uraruka zai zama yana da kariya na gabatarwar malware. Koyaya zaka iya rage hadarin harin malware ta amfani da kula lokacin saukar da abun ciki ko karbar aikace-aikace, kuacewa budewa ko amsa sakonni daga mafari wanda ba'a sani ba, amfani da amintaccen sabis don samun damar Intaniti, kuma saukar da abun ciki zuwa wayarka ta hanu daga wanda aka sani kawai, amintaccen mafari.

Na'urorin haɗi

Yi amfani da na'urorin haɗi ta asali mai alamar Sony Ericsson da gamsassun abokan sabis kawai. Sony Ericsson bai gwada amfanin na'urorin haɗi na bangare na uku. Mai yiwuwa na'urorin haxa suyi tasiri ga Bayyanar RF, aikin radiyo karar sauti amincin lantarki da kuma wasu wurare. Mai yiwuwa na'urorin haɗi na bangare na uku ya shirya hadari ga lafiyarka ko aminci ko ya rage aiki.

Hanyoyin taimako/Bukatun musamman

Amurka, wayoyin Sony Ericsson da suka dace mai yiwuwa suye tayi tareda tashoshin TTY (tareda amfani da na'urar haɗi na tilas). Don karin bayani

kira Sony Ericsson Special Needs Center on 877 878 1996 (TTY) or 877 207 2056 (voice), ko je zuwa www.sonyericsson-snc.com.

Zubar da tsohon kayan wuta da kayan lantarki

Kada a hada kayan lantarki ta batura a sharar gida amma tilasa abar su a wrin matattara da ya dace don sake sana'antasu. Wannan yana taimakawa wajen sakamako mara kyau mai yiwuwa ga yanayin wiru da lafiyan dan adam. Bincika dokokin gida ta tuntuqar ofis din mazaɓa mai zubar da sharar gidanka, da shagon da kasai samfurin ko kira Sony Ericsson Call Center.



Zubar da baturin

Bincika dokokin gida ko kira Sony Ericsson Call Center don bayani. Kar kataba amfani da sharar gari.



Katin kwakwalwar ajiya

Idan samfur naka yazo da cikakke tareda katin kwakwalwar ajiya mai ciruwa, baki daya yana dacewa da wayarka ta hannu da aka saye tare amma iya kin dacewa da wasu na'urorin ko damar katunan kwakwalwar ajiyarsu. Binciki wasu na'urorin don karfinsu kafin ka saye ko amfani. Idan an sawa samfurinka mai karanta katin kwakwalwar ajiya, ka binciki dai-dai din katin kwakwalwar ajiya kafin saye ko amfani.

Katukan kwakwalwar ajiya ana tsara sune gabada kafin aunasu a jirgin ruwa. Don sake tsarin katin kwakwalwar ajiya, yi amfani da na'ura da ta dace. Kada ka yi amfani da tsari na musamman tsayyaye lokacin tsara katin kwakwalwar ajiya a PC. Don cikakkun bayanai, koma zuwa umarnin aikin na'ura ko tuntuɓi goyann bayan abokin ciniki.

GARGADI:

Idan na'urarka na bukatar adafta don sanyawa cikin wayarka ta hannu ko wata na'urar, kada ka saka kati kai tsaye ba tare da adaftan da ake bukata ba.

Kariya akan amfanin katin kwakwalwar ajiya

- Kada a bijirar da katin kwakwalwar ajiya ga laima.
- Kada a taɓa tashar haɗi da hannunka ko da wani abun karfe.
- Kada a goge, lankwasa, ko jifa da katin kwakwalwar ajiya.
- Kada ayi yunkurin baɓɓɓalla ko gyaggyara katin kwakwalwar ajiya.
- Kada ayi amfani da ko ajiye katin kwakwalwar ajiya a wurare masu laima ko lalatattu ko cikin matsanancin zafi kamar rufaffiyar mota laokacin rani, cikin hasken rana kai tsaye ko kusa da hita, dasauransu.
- Kada a latsa ko lankwasa karshen adaftan katin kwakwalwar ajiya da matsanancin karfi.
- Kada a bar datti, kura, ko bakin abubuwa su shiga cikin zangon kowane adaftan katin kwakwalwar ajiya.
- Bincika ka shigar da katin kwakwalwar ajiyar dai-dai.
- Saka katin kwakwalwar ajiya har iyakacin yadda ake bukata ya shiga cikin kowane adaftan katin kwakwalwar ajiya. Katin kwakwalwar ajiya bazai yi aiki ba harsai an saka shi gaba daya.
- Mun bada shawara cewa kayi kwafin ajiyar mahimman bayanai. Baza mu dauki alhakin kowacce asara ko lalacewar abun cikin daka ajiye a katin kwakwalwar ajiya ba.
- Bayanai da aka yi rikodi mai yiwuwa sun lalace ko sun bata lokacin da katin kwakwalwar ajiya ko adaftan katin kwakwalwar ajiya. Kashe wuta lokacin tsarawa, karantawa ko rubuta bayanai. Kada kayi amfani da katin kwakwalwar ajiya a wurin tabbataccen lantarki ko fili mai karfim wutan lantarki a waje.

Kariya na bayanan sirri

Share bayanai na sirri kafin zubda samfurin. Don bayanai, sake saiti na ainihi. Share bayanai daga pwapwalwar ajiyar waya baya tabbatar da cewa ba za'a iya dawo da ita ba. Sony Ericsson baya garantin dawo da bayani kuma baya pkaddara daukan alhakin bayanar kowani bayani koda bayan sake saiti na ainihi.

Na'urorin hadi

Sony Ericsson ya bada shawarar amfani da na'urorin hadi na asali na Sony Ericsson don aminci da ingantaccen amfani. Amfanin na'urorin hadi na mutun na uku zai iya rage aikin ko sanya hadari zuwa lafiyar ka ko aminci.

GARGADIN KARA:

Guji matakan kara waxanda mai yiwuwa su cutar da jinka.

Kare Yajejeniyar Lasisin mai Amfani

Software da aka kawo tareda wannan na'urar da mai jaridarta mallakar Sony Ericsson Mobile Communications AB, da/ko kamfanioninta na hadin gwiwa da masu kawo mata kaya da kuma masu lasis.

Sony Ericsson ya baka lasisi wanda ba kebantacce ba mara iyaka don amfani da Software kawai cikin rintsi tareda na'ura wadda a kanta aka shigar kuma/ko aka bayar tare. Ba'a saida mallakar Software, canja wuri ko kuma dauke shi.

Kada kayi amfani da wasu menu don gano alamar mafari ko haxin Software, sake fitarwa da raba Software, ko gyara Software. Kana damar canja wiru happin mallak da wajibai zuwa Software ga wani bangare na uku gabaxaya tareda Na'urar da ka karbi Software, kawo yardae bangare na uku daure da sharuɗɗar wannan lasisin.

Wannan lasisi na amfanin tsawon rayuwar wannan Na'ura. Zata iya karar da ita ta canja wurin hakkoƙinka zuwa Na'ura zuwa bangare na uku a rubuce.

Idan baka bada haɗin kai ga waxannan sharuɗɗa da da halaye zai parar da lasisin kai tsaye.

Sony Ericsson da wakilan sa na uku da masu lasisi sune kebantattun masu da kiyaye duk hakkoƙin mallaka, take da sha'awa cikin da zuwa software. Sony Ericsson, da, zuwa mutuka cewa software ta kunshi kaya ko lambar mutum na uku, mutumin na uku, za'a bashi taken riba na uku na wadannan sharuɗɗan.

Wannan lasisin mulkin doka ne na Suwidin. Lokacin mai zartuwa, wanda yawuce yana zartuwa zuwa dokan hakin mai amfani.

A abubuwan aukuwa masu tafiya sa Software ko aka kawo a rinci tareda na'uraruka an kawone tareda parin sharuɗɗa da halaye, irin wannan guzurin shine ke hukuncin mallakanka da amfani na Software.

Garanti mai iyaka

Sony Ericsson Mobile Communications AB, Nya Vattentornet, SE-221 88 Lund, Sweden, (Sony Ericsson) ko kamfaninsu na hadin gwiwa na cikin gida, suna bada kayyadajjen garanti na wayarka ta hannu da na'urorin haɗe-haɗe na asali da aka kawo da kan waya (nan gaba ka koma ga "Na'ura").

Shin samfurinka yana buƙatar sabis na garanti, mai dashi wajen dilan da aka saya, ko tuntubi wurin kiran Sony Ericsson ta gida (ana iya aiki na kimar gida) ko ziyarci www.sonyericsson.com don bayani na gaba.

Garanti namu

Bugu da kari ga halayen wannan garanti mai iyaka, Sony Ericsson yayi garantin wannan abin sana'ar don zama mai ingancin kira, kayan aiki da ma aikacin sana'a a asalin lokacin da dankasuwa ya

saya. Wannan garanti mai iyaka zai dauki tsawon shekara (1) daya kamar daga asalin kwanan watan sayan samfur.

Me zamu yi

Idan, yayin lokacin garanti, wanna samfurin ya kasa aiki a karkashin amfani da sabis na al'ada, saboda matsalar kira, kayan aiki ko sana'a, masu rabawa ko abokan sabis na Sony Ericsson, a cikin kasa* inda kasayi abin sana'a, zasu, a zaɓuɓɓukan su, ko gyara kosauya abin sana'a dangane da sharuɗɗa da halaye da aka shimfiɗa a ciki.

Sony Ericsson da abokan sabis nasa sun tanadi hakkin cajin kuɗin karɓa idan an sami samfurin ba karkashin garanti dangane da sharuɗɗan kasa ba. Kula cewa wasu saitunanka na sirri, abubuwan da aka sauke da wani bayani zai iya bacewa lokacin da aka sauya ko gyara samfur naka na Sony Ericsson. A halin yanzu Sony Ericsson zartattun dokoki suna iya kiyaye, waɗansu ka'idoji ko kuntatawa na fasaha daga yin kwafin takamaimiyar saukewa.

Sony Ericsson bazai dauki kowane alhakin bacewar kowane irin bayani kuma bazai mayar maka da kowacce irin asara ba. Kayi koyaushe kwafin duk bayanana da suke ajiyayyu akan samfur naka Sony Ericsson kamar abubuwan da aka sauke, kalanda da lambobi kafin miƙa samfura naka na Sony Ericsson don gyara ko sauyawa.

Sharuɗɗa

- 1 Wannan garantin yana aiki ne kawai in shaidar asalin sayan wannan samfur anyita ta dila na Sony Ericsson dake kididdige kwanan watan saya da lambar siriyal**, an gabatar dasu tare da samfur don gyarawa. Sony Ericsson ya tanadi damar kin sabis na garanti idan an cire ko canja wannan bayani bayan asalin sayan abin sana'a daga wurin dila.
- 2 In Sony Ericsson ya gyara ko ya sauya samfurin, lalacewar da aka kula da shi da gyra lalacewar da aka kula d'ashi, ko samfurin da aka canja zai zama

mai garanti zuwa lokacin raguwar garantin na asali ko zuwa ranaku (90) daga kwanana watar gyaran, duk tsawansu. Gyara ko sauyawa na iya kuste a amfanin kayan aiki wanda suke daidai da matsayin waya na da. Bangarorin da aka sauya ko aka gyara zasu zama mallakar Sony Ericsson.

- 3 Wannan garanti bazai maye kowace gazawar samfur saboda lalacewar al'ada, ko don rashin iya amfani, gamida amma bai iyakance don amfani cikin yanayi sama da na al'ada ba, dangane da sharuɗɗan amfani na Sony Ericsson da alkinta samfur. haka nan wannan garantin baya maye gurbin kowane lalacewar samfur saka makon hadari, gyara ko dai-dai ta software ko hardware, yin Allah ko lalacewa saka makon shigar ruwa. Za'a iya caji ko cire cajin batuni mai cajuwa fiye da sau dari. Ko yaya, zai lalace a karshe - wannan ba matsala kuma yayi dace da lalacewa ta al'ada. Lokacin magana ko jiran aiki an kula yayi gajarta, lokacin ake sauya batuni. Sony Ericsson yabada shawara cewa kayi amfani da batuna ko caji yaddaddu ta Sony Ericsson.

Kananan sabani a cikin nunin haske da launi zai yiwu yafaru tsakanin wayoyi. Zai yiwu karamin haske ko digo mai duhu akan nuni. Wannan fatsi-fatsin na bayyana da zaran d'igon haske ya sami matsala kuma ba za a yi gyara ba. Batattun fatsi-fatsi guda biyu ana daukar su karɓaɓɓue.

Karamin sabani a cikin bayyanar hoton kamara zai yiwu tsakanin wayoyi. Wannan ba wani abune da ba'a saba dashi ba kuma ba'a la'akari dashi azaman bacin modal na kamara a koyaushe.

- 4 Tunda salon salula wanda kansa samfur ke aiki an bada shi ta d'an kasuwa mai cin gashin kansa daga Sony Ericsson, Sony Ericsson bazai dauki alhakin aiki, samuwa, kewayo, sabis ko kewayon salo ba.
- 5 Wannan garanti bazi dauk nauyin lalacewa ta hanyar shigarwa, sauyawa, ko gyara ko bude waya a wajen wanda ba dillalan Sony Ericsson mai izini ba.

- 6 Garantin bazai dauki da nauyin lalacewa samfur wanda ya faru ta amfani da wasu na'urorin hadi wadanda amintattun na'urorin asali na Sony Ericsson wanda akayi nufin amfani tareda wannan samfur.
- 7 Balle wasu kanaan takardo da aka makala a jikin injin waya zai bata garantin.
- 8 BABU GARANTIN KAI TSAYE A RUBUCE KO FADE SABANIN WANDA AKA BUGA A JIKIN NA'URA. DUK GARANTIN DA AKA GABATAR, BA TARE DA IYAKANCE GARANTIN CINIKI KO CANCANTA DON AIKI NA MUSAMMAN, SUN TSAYA A KAN LOKACIN DA AKA KIYASTA NA WANNAN GARANTI. BABU WANI DALILI DA SONY ERICSSON KO MMASU LASINSZA ZASU ZAMA ABIN DOGARO DON LALACEWAR BAZATA KO MAI SABABI KO WACE IRICE, GAMI DA AMMA BAI IYAKANCE GA ASARAR RIBA KO TALLA; DOKA ZATA NEMI WADANNAN ABUBWAN.

Wasu kasashe/jahohi basa izinin hani ko iyakance lalacewa mai biyo baya ko ta bazata, ko iyakance lokacin tabbataccen garanti, don haka iyakancewar daga gabata ko hani baza tayi aiki a kanka ba. Garanti da aka bada ba zai tasiri a matsayin hakkin na dokokin ka'idar da aka dorawa mabukata na af'ada, ko hakokin mabukata akan dila ana iya daga shi daga cinikin su/sallamawa.

*Gwargwadon jografai na garanti

In ka sayi samfur naka a cikin kasa 'yar kungiyar shashin tattalin arziki na kasshen turai (EEA) ko a Suwizalan ko Taki kuma anyi nufin sayar da samfurin a cikin EEA ko Switzalan ko Taki, samfur naka zai iya aiki a kowane kasar EEA ko cikin Suwizilan ko cikin Turkey, karkashin sharu'uda masu mallaka a cikin kasar da kake bukatar sabis, idan har cewa ana sayar da samfurin a cikin wannan kasar ta mai rabawa mai izini na Sony Ericsson. Don gano idan ana sayar da abin sana'aruka a cikin kasar da kake ciki, kira wurin kiran Sony Ericsson na gida. Kiyaye cewa takamammen

sabis bazai yiwu a wani wuri ba acikin kasar asalin saya ba, misali a hakika abin sana'aruka zai iya samin banbancin ciki ko waje daga irinsa wanda aka sayar a wasu kasashe. Lura cikin kari cewa bazai yiwu wasu lokuta a gyara kayan rufe SIM ba. ** A wasu kasashe/jihohi zai yiwu a bukaci karin bayani (kamar katin garanti mai aiki).

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:



- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Any change or modification not expressly approved by Sony Ericsson may void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Industry Canada Statement

This device complies with RSS-210 of Industry Canada.

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Declaration of Conformity for W350i

We, Sony Ericsson Mobile Communications AB of Nya Vattentornet

SE-221 88 Lund, Sweden

declare under our sole responsibility that our product

Sony Ericsson type AAB-1022121-BV

and in combination with our accessories, to which this declaration relates is in conformity with the appropriate standards EN 301511:V9.0.2, EN 301489-7:V1.3.1, EN 301489-17:V1.2.1, EN 300328:V1.7.1 and EN 60950-1:2006, following the provisions of, Radio Equipment and Telecommunication Terminal Equipment directive 99/5/EC.

Lund, January 2008

CE 0682



Shoji Nemoto,

Head of Product Business Group GSM/UMTS

Mun cika sharadin bayanin R&TTE (99/5/EC).

Fihirisa

A

abin sawa akunni	19, 20
Fasahar Bluetooth™	55
Abokai nawa	41
adawa	5
agogon awon gudu	64
aikace-aikace	50
aikawa	
hotuna	47
katunan kasuwanci	34
kiɗa	23
launukan waka da sautin ringi	49
aiki tare	58
alkawurra	62

B

baturi	
amfani da kula	75
caji	8
sakawa	5
bayanan kula	64
bayanan martaba	66
bugun kiran sauri	29

C

canja wuri	
fayiloli	56
kiɗa	19

Canja wurin hotuna	45
cire katangar katin SIM	67

D

declaration of conformity	81
Don saita faɗakarwar jijjiga	48

D

ɗaukaka sabis	59
ɗawainiya	63

E

email	38
-------------	----

F

fara allo	7
fasaha mara waya ta Bluetooth™	54
fayilolin kiɗa	22

G

gajerun hanyoyi	15
garanti	78

H

halin kwakwalwar ajiya	28
hanyar canja wuri	
Fasahar Bluetooth™	54
USB	56
hotuna	46

I		Kira	
Intanit		amsa	25
alamun shafi	53	karɓa	32
bayanan martaba	53	karɓan kira biyu	31
Saituna	52	na duniya	24
tsaro da takaddun shaida	54	sake bugun kira	25
		sanyawa a riko	30
		Yi	24
J		kira	
jagororin aminci	74	ki	25
Java™	50	rikodi	50
jigogi	67	Kiran gaggawa	25
jiran aiki	7	kiran taro	31
		kulle maballin kida	9, 23
		Kunna wayar	6
K		kunnawa/kashewa	
kafaffun bugun kira	33	kiyaye makullin SIM	68
kalanda	61	makullin waya	68
kalkuleta	64	Kuskuren sakonni	71
kamara		kwanan wata	66
Saituna	45		
siffa	43	K	
karkata kira	30	kara	
katin kwakwalwar ajiya	16	lasifikar kunni	25
Katin SIM		sautin ringi	48
sakawa	5	karamin menu	13
katin SIM		kararawa	61
kulle da cire katanga	67	kungiyoyi	28
kwafi daga	27	Kuntata kira	32
kwafi zuwa	26		
katunan kasuwanci	34		
kida			
canja wuri	19		

L			
lambar IMEI	68	Media Manager	19
Lambar kira a sako	35	menu	13
lambar memo	65	menu na kewayawa	13
lambar PIN		MusicDJ™	49
canji	67	P	
lambobi		PlayNow™	23
aiki tare	58	PUK	67
kara lambobin waya	26	R	
kungiyoyi na	28	rediyoyi	47
tsoffin lambobi	26	rubutu	18
lambobi nawa	32	S	
lissafin kira	29	sabis na amsa	29
lissafin wakoki	22	Saituna	
lokaci	66	Intaniti	52
lokacin kira	33	Java™	51
M		sake bugun kira na atomatik	25
maballai	9, 13	sake saitin zuwa na ainihi	69
Maballan kida	21	sakon murya	29
Mai karanta RSS	54	sakonni	34
mai kunna bidiyo	50	email	38
mai kunna kida	19	murya	38
Mai kunna Walkman®	19	sakonnin hoto	36
Mai kidayan lokaci	64	sakonnin rubutu	34
mai rikodin sauti	50	samfuri	37
Mai sarrafa fayil	16	wuri da bayanin kira	43
makirufon	25	sakonnin hoto	36
makulli		sakonnin murya	38
katin SIM	67	sakonnin rubutu	34
waya	68		

samfurn sakon	37
samun email	41
Sauke fayiloli	53
sautunan ringi	48
Shigar da rubutu	
shigarda rubutu na tabi dayawa ...	19
T9™ Text Input	18
Shirya matsala	69
siffar menu	11
Siffar waya	9

T

taimako	7
takamaiman sautin ringi na mai kira	26
TrackID™	24

W

wasanni	50
waya	
makulli	68
yare	18

Y

yanayin kaura	7
---------------------	---

Z

zukowa	44
--------------	----