

Abubuwan ciki

Farawa 4

Hadawa, katin SIM, baturi, kunnawa, taimako, yanayin kaura, kira, menu na ayyuka, PC Suite, kamara, shafi.

Fara sanin wayar 10

Maballai, menus, kewayawa, gumaka, gajerun hanyoyi, yaren waya, shigar da haruffa, mai sarrafa fayil, katin kwakwalwar ajiya.

Kira 22

Kira, lambobi, lissafin kira, bugun kira na sauri, ikon murya, zabubukan kira, katunan kasuwanci.

Sako 36

Sakon rubutu, sakon hoto, sakon murya, email, Abokaina.

Hoto 48

Kamar, bidiyo, shafi, hotuna.

Nishadi 55

Abin sawa akunni, mai kunna Walkman®, mai kunna Bidiyo, TrackID™, PlayNow™, sautunan ringi MusicDJ™, VideoDJ™, sautin rikoda, wasanni, aikace-aikace.

Sony Ericsson W610i

Hadl 65

Saituna, Intanit, RSS, aiki tare, fasahar Bluetooth™, Kebul na USB, daukaka sabis.

Karin fasaloli 77

Agogon kararrawa, kalanda, dawainiya, bayanan martaba, lokaci da kwanan wata, makullin kati SIM da kari.

Shirya matsala 85

Me yasa wayar bata aiki yanda nakeso tayi?

Muhimmin bayani 91

Mai amfani da gidan yanar sadarwa na Sony Ericsson, sabis da goyan baya, kare la lasisin mai amfani, garanti, bayanin tabbarawa.

Fihirisa 102

Sony Ericsson

GSM 850/900/1800/1900

Sony Ericsson Mobile Communications AB itaca ta buga wannan jagorar mai amfanin ko abokan ta rayyarta na cikin gida, batareda wani garanti ba. Cigaba da canje-canje ga wannan jagorar mai amfanin wanda kusakuran rubutu ya haifar, rashin dacewar bayanin yanzu, ko cigaba zuwa tsare-tsare da/ka kayan aiki, zai yiwu Sony Ericsson Mobile Communications AB ya gudanar dasu akowane lokaci kuma ba tareda sanarawa ba. Irin wadannan canjin ako wani hali za'a shigardashi a sabon bugu na jagorar mai amfan. An kiyaye duk hakköki.

©Sony Ericsson Mobile Communications AB, 2006

Lambar daba'a: HA/LZT 108 9053 R1A

Kula:

Wasu sabis acikin wannan jagorar mai amfanin basu da goyan bayan duk cibiyoyin sadarwa.

Haka nan ana aiwatar da wannan zuwa ga GSM lambar gaggawa ta duniya 112.

Tuntubi afaretanku ko mai buda sabis idan kana cikin kowane shakku ko zaka nya amfanid da wani sabis na musamman ko a'a.

Karanta Jagororin mai amfanin don aminci da ingantaccen amfanid da kuma babukan Garanti mai iyaka kafin kayi amfanid da wayarka ta hannu.

Wayarka tanada damar sauweka, aijyewa da tura karin abun ciki, misali, sautunan ringi. Zai yuwu a takaita amfanin wannan abun ciki ko haramta shi ta hakkin bangarori na uku, tattare da saidai ba'a iyakance zuwa takaitawa karkashin zartattun dokokin haikkim mallaka ba. Kai, ba Sony Ericsson ba, ke da cikakken alhaki don karin abun ciki wanda ka saukar zuwa ko ka tura daga wayarka ta hannu. Mafifici ga amfanin ka na kowane karin abun ciki, tabbatar cewa amfanin da kake nufi yana da lasisi ko kuma yana da izini. Sony Ericsson bai da garantin daidai, mutunci ko ingancin kowane karin abin ciki ko kowane abun

ciki na wani bangare na uku. Babu wani dalili da Sony Ericsson zai zama abin dogaro ta kowace hanya don amfanin ka mara kyau na karin abun ciki ko wani bangare na uku.

Bluetooth™ alamace ta kasuwanci ko alama ta kasuwanci mai rijista na Bluetooth SIG Inc.

PlayNow™, MusicDJ™, PhotoDJ™, TrackID™ da VideoDJ™ alamune na kasuwanci ko alamune na kasuwanci masu rijista na Sony Ericsson Mobile Communications AB.

Memory Stick Micro™ (M2™), WALKMAN da WALKMAN logo alamne na kasuwanci na Sony Corporation.

Alamar WALKMAN® da alama alamune na kasuwanci mai rijista na Sony Corporation.

Real alanmace ta suwanci ko alamace ta

kasuwanci mai rijista na RealNetworks, Inc.

RealPlayer® saboda yawayar hannu wacce aka hadarda ita karkashin lasisi daga RealNetworks, Inc. hakkin mallaka 1995-2004, RealNetworks, Inc. Ankiyaya duk hakköki.

Adobe™ Photoshop™ Album Starter Edition alamar kasuwanci ce ko alamar kasuwanci mai rijista ta Adobe Systems Incorporated.

Microsoft, Windows da PowerPoint alamun kasuwancine ko dai masu rijista ko alamun kasuwanci na Microsoft Corporation a cikin Amurka da wasu kasashe.

T9™ Text Input alamar kasuwanci ce ko alamar kasuwanci mai rijista na Tegic Communications.

T9™ Text Input Anyi masa lasisi a karkashin daya ko fiye na mai zuwa: U.S. Pat. Nos. 5,818,437, 5,953,541, 5,187,480, 5,945,928, da 6,011,554; Dan Kanada Pat. No. 1,331,057, Burtaniya Pat. No. 2238414B; Hon Kon Standard Pat. No. HK0940329; Singafora Pat. No. 51383; Euro. Pat. No. 0 842 463(96927260.8) DE/DK, FI, FR, IT, NL, PT, ES, SE, GB; da ratayayyun karin fasahohi na duniya.

Java da duk kafaffun alamun kasuwanci da alamu na Java alamun kasuwancine ko alamun

kasuwanci mai rijista na Sun Microsystems, Inc. acikin Amurka da wasu kasas.

Yajejeniyar kare lasisin mai amfani don Sun™ Java™ J2ME™.

- 1 Takaitawa: Software bayanin asirtaccen hakkin mallakana na Sun kuma an rike take da duk kwafia ta Sun da/ko masu lasisinsa. Abokin ciniki ba zai gyara, watsa, tarwatsa, lalata, cire, ko kuma yin baya da fasahar Software. Software bazai yiwu a bada aronsa, bayar dashi, ko yin lasisinsa ba gaba daya ko cikin wani sashi.
- 2 Dokokin fitarwa: Software, gamida bayanan fasaha, suna karkashin dokokin ikon fitarwa na Amurka, gamida hukumar fitarwa ta Amurka Act da dokokinta masu danganta, kuma mai yuwa yama a karkashin dokokin fitarwa a wasu kasashen. Abokin ciniki ya amince da bada cikakken hadin kai tareda duk wadannan dokoki da ilimi da alhakin samun lasisin fitarwa, sake fitarwa, ko shigar da Software. Software bazai yiwu a saukeshi, ko kuma fitar dashi ko sake fitar dashi (i) cikin, ko zuwa wata kasa ko mazaunna, Kyuba, Iraki, Iran, Arewacin Koriya, Libya, Sudan, Siriya (kamar yadda za'a iya bitar wannan lissafin daga lokaci zuwa lokaci) ko kuma kowace kasa wacce Amurka ta sawa takunkumin kaya; ko (ii) zuwa kowane mutum a jerin kebtattun ma'aikata na musamman na Amurka ko ma'aikatan Amurka masu oda ta musamman.
- 3 Takaitattun Hakkokki: Amfani, kwafewa ko Kwakkwafi na hukumar Amurka ya dogara ga takaitawa kamar yadda aka daidaita shi azaman na huđu a hakkokin cikin bayanan fasaha da software na kwamfuta da aka sanya acikin DFARS 25.227-7013(c) (1) (ii) da FAR 52.227-19(c) (2) azaman abin zartarwa.
Sashin software a wannan samfurin shine hakkin mallaka © SyncML initiative Ltd. (1999-2002). An kiyye duk hakkoki.
Wani samfur da sunayen kamfanin da aka ambata a nan za su iya zama alamar kasuwanci na masu mallakar su.

Kowane hakkoki wadanda ba'a fayyace izininsu ba anan an kiyye su.

Duk zanuka saboda zane ne kawai ba dole kuma su dace da inihin wayar ba.

Alamun umurni

Masu biyowa suna bayyana a jagorar mai amfani:

Kula



Sabis ko aiki suna dogara da cibiyar sadarwa ko biyan kudi. Tuntubi afaretanka na cibiyar sadarwa don cikakken bayani.

- ▶ Duba shafi kuma...
- ▶ Yi amfani da zabi ko maballin kewayawa don gungurawa kuma zabi ➡ 14 Kewayawa.
- Latsa tsakiyar maballin kewayawa.
- Latsa bangaren sama a maballin kewayawa.
- Latsa bangaren kasa a maballin kewayawa.
- Latsa bangaren hagu na maballin kewayawa.
- Latsa bangaren dama na maballin kewayawa.

Farawa

Hadawa, katin SIM, baturi, kunnawa, taimako, yanayin kaura, kira, menu na ayyuka, PC Suite, kamara, shafi.

Akwai karin bayani da saukewa a www.sonyericsson.com/support.

Hadawa

Don amfani da wayarka

- 1 Saka katin SIM kuma yi cajin baturin.
- 2 Yi cajin baturi.
- 3 Kunna wayarka.

Katin SIM

Lokacin da ka yi rajista azaman mai biyan kudi tare da afaretan cibiyar sadarwa, zaka sami katin (Bangaren shaidar mai biyan kudi) SIM. Katin SIM ya kunshi bangaren kwamfuta wanda ke rike da turbar abubuwa kamar lambar wayarka, sabis da aka hada acikin biyan kudinka, da sunaye da lambobi acikin lambobinka.

 *Ajiye bayanin lamba akan katinka na SIM kafin cire shi daga wata waya. Maiyuwa an ajiye lambobi acikin kwakwalwar waray.*

PIN

Maiyuwa ka bukaci PIN (Personal Identification Number) don katin SIM naka don fara wayarka da kunna sabis. Lokacin da kashigar da PIN naka, kowace lamba tana bayyana azaman*, saidai in tafara da lambobi irin lamabar gaggawa, misali 112. Wannan yana bada dama don kiran gaggawa ba tareda shigar da PIN ba. Latsa  don gyara kurakurai.


 *Idan ka shigar da PIN kuskure sau uku a jere, An katange PIN yana bayyana. Don cire mashi katanga, kana bukatar shigar da PUK naka (Personal Unblocking Key) ➡ 83 Makullin katin SIM.*

Baturi

Wasu ayyuka suna amfani da wutar baturi fiye da wasu kuma maiyuwa ya haifar da bukatar sake caji da yawa. Idan an kula lokacin magana da jiran aiki yazama mafi gajarta, maiyuwa dole ka sauya baturin. Yi amfani da kawai da amintattun batura daga Sony Ericsson ➡ 94 Baturi.


Katin SIM da baturi

Don saka katin SIM da baturi



- 1 Cire murfin baturi ta latsa shi da sumbule shi kamar yadda aka nuna a hoton.
- 2 Zamar da katin SIM din cikin marikinsa tareda lambobin suna fuskantar kasa.
- 3 Saka baturin tareda alamar gefen sama da masu hadin suna fuskantar juna.
- 4 Zamar da murfin baturin cikin wuri.

Don cajin baturi



- 1 Hadha fulogin caja zuwa wayar tareda lambar tana fuskantar sama.
- 2 Maiyuwa ya dauki minti 30 kafin gunkin baturin ya bayyana.
- 3 Jira kusan awa 2.5 ko har gunkin baturi ya nuna cewa baturi ya cika da caji. Latsa wani maballi don kunna allon.
- 4 Cire caja ta karkatar da filogin sama.

Kunna wayarka

Tabbatar da wayar tayi caji kuma an saka katin SIM kafin kunna wayar. Bayan kunnawa, yi amfani da saita maye saboda shirya wayar don amfani.

Don kunna wayar



- 1 Latsa ka rike ①. Maiyuwa saitin farko ya dauki mintuna kadan.
- 2 Zabi don amfani da wayar a:
 - Na al'ada – cikakkun ayyuka ko
 - Ynyin. kaura – Ayyuka masu iyaka tareda cibiyar sadarwa, rediyon FM da masu watsa Bluetooth™ a kashe
➡ 7 *Menu na Yanayin kaura*.
- 3 Shigar da PIN dinka na katin SIM, idan an bukata.
- 4 A farkon farawa, zabi yare don menus na wayarka.
- 5 ➤ Ee don saita maye ya taimakeka.
- 6 Bi umarni don gama saiti.

💡 Mai yuwa ayyanannun saituna sun riga sun kasance acikin wayarka. Zai yiwu a tambayeka don rijistar wayarka a Sony Ericsson. Idan ka karbi yin rijistar wayarka, ba bayanan sirri, kamar lambar wayarka, da za'a canja masu wuri zuwa ko sarrafasu ta Sony Ericsson.

Jiran aiki

Bayan ka kunna waya da shigarda PIN naka, sunan mai sa aiki na cibiyar sadarwa zai bayyana akan allon. Wannan ake kira yanayin jiran aiki.

Taimako acikin wayarka

Akwai taimako da bayani a wayarka ako wane lokaci.

Don amfani da saita maye

- Saituna ► Gaba daya shafin ► Saita maye kuma zabi wani zabi:
- Saukar da saituna
 - Basic setup
 - Tips and tricks

Don duba bayani gameda ayyuka

Gungura zuwa aiki ► Kari ► Bayani, idan akwai.

Don duba gwajin wayar

► Nishadi ► Zagawar Demo.

Saukar da saituna

An saita ayyuka ta atomatik a wayarka wanda yake amfani da Intanit; Intanit, sakon hoto, email, Abokaina, aiki tare, daukaka sabis, shafi da jerin yawo.

Zaka iya amfani da **Saukar** da saituna idan:

- SIM naka yana goyan bayan sabi
- An hada wayarka zuwa cibiyar sadarwa
- Wayarka tana farawa a yanayi na al'ada kuma bata riga tasami ayyanannun saituna ba.

 *Tuntubi afaretan cibiyar sadarwarka ko mai baka sabis don Karin bayani.*

Menu na yanayin kaura

Idan ka kunna wayar kuma **Ynyin. kaura** an kunna menu, zabi daga Na al'ada tareda cikakkun ayyuka ko **Ynyin. kaura** tareda iyakantattun ayyuka. A Yanayin kaura, cibiyar sadarwa, radiyo da Bluetooth transceivers da Radyo na FM suna kashe saboda kare damuwa zuwa kayan aiki masu mahimmanci. Zaka iya, misali, kunna kida ko rubuta sakon rubutu don aikawa daga baya amma ba yin kira ba.

 *Bi umarnin hawa jirgi, umarnin ma'aikatan jirgi don amfanin na'urorin lantarki.*

Don duna Ynyin. kaura zabubbukan menu

► Saituna kuma gungura zowa **Gaba daya shafin** ► **Yanayin kaura** kuma zabi wani zabi.

Yin kira

Dole wayar tazama a yanayi na al'ada (ba'a yanayin kaura ba).

Don yin kira

- 1 Shigar da lambar waya (tareda fihirisar kasar waje da lambar yanki idan an zartar dasu).
- 2 ► **Kiradon** yin kiram murya.
- 3 ► **Kari** don zabubbuka yayin kiran.
- 4 ► **Kas.kira** don kare kiran.

Don hada kira guda biyu cikin kiran taro

- 1 Kira mutum na farako don sa shi a taron.
- 2 ► **Kari** ► **Rike** don rike kira mai gudana.
- 3 Kira mutumin na biyu.
- 4 ► **Kari** ► **Hada kira**.

Menu na ayyuka

Zaka iya bude menu na ayyukan kusan ko ina a menu na wayar don dubawa da tafiyar da sab.ab.auku., da samun damar alamun shafi da gajerun hanyoyi.

Don bude da rufe menu na ayyuka

Latsa 

Shafukan menu na ayyuka

- **Sab.ab.auku** – kamar kiran da aka rasa da sakonni. Lokacin da sab. ab.auku. ya wakana, shafin yana bayyana. Latsa  don fidda abin aukuwa daga shafin abin aukuwa. Madadin haka kuma za'a iya saita sab.ab.auku.don bayyana azaman rubutun fadakarwa, ► Saituna ► Gaba daya shafin ► Sab.ab.auku. ► Pop-up.
- **Running apps** – aikace-aikace masu gudana a bango. Zabi aikace-aikace don koma mata ko latsa  don kare shi.
- **My shortcuts** – kara, share kuma canja tsarin gajerun hanyoyi. Lokacin da ka zabi gajerar hanya kuma aikace-aikacen suka bude, an rufe wasu shirye-shirye ko an rage girmansu.

• **Intanit** – alamun shafin intanit naka. Lokacin da ka zabi alamar shafi kuma mai lilon ya bude, ana rufe ko rage girman wasu shirye-shirye.

PC Suite software



Habaka kwarewar wayarka ta shigar da PC Suite software a kwamfutarka. Wannan zai baka damar, misali, hada aiki tareda kalandar wayarka da kalandar kwamfuta.

Don shigar da PC Suite software

- 1 Kunna kwamfutarka kuma saka CD wanda yazo tareda wayarka cikin mai tuka CD na kwamfutarka. CD yana farawa ta atomic kuma shigar da window yana budewa.
- 2 **Kwamfuta:** Zabi yare kuma kada OK.
- 3 **Kwamfuta:** Kada *Shigar* cikin bangaren PC Suite kuma bi umarnin kan allon. Lokacin da shigarwar ya cika, gunkin PC Suite yana bayyana akan tebur din kwamfutarka.

Don sigar yau-yau na PC Suite, ziyarci www.sonyericsson.com/support.

Dauki hotuna ko yi rikodin shirye-shiryen bidiyo



Don daukar hoto ko rikodin bido

- 1 Daga jiran aiki, latsa ka rike don kunna kamarar.
- 2 Yi amfani da maballin kewayawa don canjawa tsakanin kamara da mai rikodin bido.
- 3 **Kamara:** Latsa don daukar hoto.
Bidiyo: Latsa don fara rikodi. Don tsayar da rikodi, latsa sake. An ajiye hotunanka da shirye-shiryen bido ta atomatik acikin **Mai sarrafa fayil** ► Kundin kyamera.
- 4 Don daukar wani hoto ko yin rikodin wani shirin bido,, latsa don komowa zuwa mai samfoti. Don dakatar da amfani da kamarar ko mai rikodin bido, latsa ka rike .



Dakin yanar sadarwarka na sirri

Buga hotunanka a dakin yanar sadarwarka. Wayar tana kirkirar dakin yanar sadarwarka domin ka.



Don sawa hoto shafi

- 1 Dauki hoto ► Kari ► Yi Blog wannan.
- 2 Bi umarnin don amfanin farko.
- 3 Kara take da rubutu ► Ok ► Yada.
- 4 Zaka sami sakon rubutu tareda adireshin yanar sadarwarka da bayanan shiga cikin yana.

Fara sanin wayar

Maballai, menus, kewayawa, gumaka, gajerun hanyoyi, yaren waya, shigar da haruffa, mai sarrafa fayil, katin kwakwalwar ajiya.

Siffar waya



💡 Maiyuwa wasu gumaka akan maballai su bambanta.

- 1 ① Maballin kunn/kashe wuta
- 2 ➤ Maballin kunnawa/tsayawa
- 3 Allo
- 4 — Maballin zabi
- 5 Ⓜ Maballi Walkman®
- 6 ↲ Maballin komawa baya
- 7 Maballin kewayawa/ikon mai kunna Walkman®
- 8 Memory Stick Micro™ (M2™) gurbin hadi (karkashin murfin baturin)
- 9 *a/Arc Maballin kulle maballi
- 10 Lasifikar kunni
- 11 Ⓡ Kara/Maballan zuko kamara mai dijital
⌚
- 12 — Maballin zabi
- 13 ⌚ Maballin menu na ayyuka
- 14 C Maballin sharewa
- 15 📱 Maballin kamara
- 16 #♫ Maballin shiru
- 17 Mai hadawa don caja, abin sawa akunni da kebul na USB
- 18 Ruwan tabarau na kamara

Saboda karin bayani ➤ 14 Kewayawa.

Siffar Menu



PlayNow™*



Intanit*



Nishadi



Kamara



Sako



WALKMAN

Rubuta sabuwa
Akw. s. m. shig.
Email
Mai karanta RSS
Tsararr. sakonni
Akwt.sk.mai fita
Sako da ak. aika
Ajiyayyu. wasiku
Abokai nawa*
Kira skn. murya
Samfura
Saituna



Mai sarrafa fayil***

Kundin kyamera
Kida
Hotuna
Bidiyo
Jigogi
Dku. yn. sdr.
Wasanni
Aikace-aikace
Wasu

12 Fara sanin wayar

This is the Internet version of the User's guide. © Print only for private use.



Lambobi

Sabuwar lamba



TrackID™*



Kira**



Duk



An amsa



An buga



An rasa



Oganeza

Kararrawa
Aikace-aikace
Kalanda
Dawainiya
Bayanan kula
Aiki tare
Mai kidyr. lokaci
Aggn.awn. gudu
Wutar hoto
Kalkaleta
Memo na lamba



Saituna**



Gaba daya
Bayanan martaba
Lokc. & kwn.wt.
Yare
Sabis na daukaka
Ikon murya
Sab.abun aukawa
Gajerun hanyoyi
Yanayin kaura



Sauti & fadakarwa
Karar ringi
Sautin ringi
Yanayin shiru
Ringi mai karuwa
Fadakarwar jijiga
Fadakarwar sako
Sautin maballi



Nuni
Fuskar bngn. waya
Jigogi
Allon farawa
Mai boye allo
Girman agogo
Haske
Shirya sunayen layi*



Kira
Bugn. kira na sauri
Karkatar da kira
Canja zuwa layi 2*
Sarrafa kira
Lokaci & farashi*
Nun./boy.lamb.na.
Abin sawa akunni



Haduwa*
Bluetooth
Hanyar infrared
USB
Aiki tare
Mai hada na'ura
Cibiyar sadrw.waya
Bayanan sadarwa
Saitunan intanit
Saitunan yawo
Shirya sako

Tsaro
Saita maye
Halim waya
Sake saitin ainihi


* Wasu menu sun dogara ga mai sa aiki-, cibiyar sadarwa- da mai dogaron biyan kudi.

** Yi amfani da maballin kewayawa don ketara shafuka acikin menu mataimaki. Saboda karin bayani

► 14 Kewayawa.

Kewayawa

Ana nuna menus na ainihi azaman gumaka. Wasu menu mataimaka suna hadawa da shafuka. Gungura zuwa shafi ta latsa maballin kewayawa sashin hagu ko dama.



Maballi

- ① Je zuwa menus na ainihi ko zabi abubuwa masu alamar haske.
- ② Matsa tsakanin menus da shafuka.
- ③ Zabi zabubbuka da aka nuna saman wadannan maballan akan allon.
- ④ Koma matakai daya baya acikin menus. Latsa ka rike don komawa zuwa jiran aiki ko don kare aiki.
- ⑤ Share abubuwa, kamar hotuna, sautuna da lambobi. Yayin kira, latsa ka rike don cire muryar makirufo din.
- ⑥ Bude menu na ayyukan ➔ **8 Menu na ayyuka.**
- ⑦ Bude ko tsaida **WALKMAN**.
- ⑧ Latsa ka rike don daukar hoto ko rikodin shirn bidyo.
- ⑨ Latsa ka rike don kirin sabis na murya naka (in an saita).
- ⑩ - ⑪ Latsa ka rike kowanne daga wadannan maballan don isa ga lambar da tafara da takamammen harafi.

(1) - (9)

Latsa maballin lamba kuma sannan ▶ **Kira** don bugun kiran sauri.
Latsa don gajerun hanyoyi lokacin lilo ➡ 68 *Don amfani da gajerun hanyoyin faifan maballin intanit.*

(0 +)

Duba jageriar gajeriyan hanya lokacin amfani da kamara.

(* a/A=0)

Latsa sannan ▶ **Mk.mfll.** ko **Bude** don kulle ko bude mallian wayar.

(# - ∞)

Kashe sautin ringi lokacin karbar kira.
Latsa ka rike don saita wayar zuwa shiru. Kararrawa tana sigina koda an saita wayar zuwa shiru.

(▲)

Duba bayanin hali acikin jiran aiki.
Dada karar yavin kira, ko lokacin amfani da **WALKMAN**.
Zuko waje lokacin amfani da kamarar ko duba hotuna.
Latsa ka rike don komawa baya zuwa kidan waka daya.
Latsa saubiyu don kin karban kira.
Latsa ka rike don bugun kiran murya, fadi kalmar sihirinka ta wata hanya daban (idan an saita) ➡ 29 *Bugun kiran murya.*

(▼)

Rage karar yavin kira, ko lokacin amfani da **WALKMAN**.
Zuko ciki lokacin amfani da kamara ko duba hotuna.
Latsa ka rike don zuwa gaba ga wakar kifa daya.
Latsa ka rike, fadi kalmar sihirinka ta wata hanya daban (in an saita) ➡ 29 *Bugun kiran murya.*

▶ Bayani

Samo karin bayani, bayanai ko tukwici bisaga zababbun fasaloli, ko tukwici menus ko samammun ayyuka a wayarka ➡ 6 *Taimako a wayarka.*

▶ Kari

Shigar da lissafin zabubbuka. Akwai hanyoyi daban masu bambanci acikin lissafin zabubbukan yana danganta da inda kake a menu.

Ma'aunin yanayi

Wasu gumakan da maiyuwa su bayyana:

Gunki Sifantawa

 GSM karfin sigina na cibiyar sadarwar.
 Halin baturi.

-  Cajin baturi, yana bayyana tareda halin gunkin baturi.
Kira mai shigowa da aka rasa.
-  Sakon rubutu da aka karba.
-  Sakon Email da aka karba.
-  Sakon hoto da aka karba.
-  Sakon murya da aka karba.
-  Kira mai tafiya.
-  Kulle maballi yana kunne.
-  An hada abin sawa a kunni rediyon zai cigaba akunne a bangon.
-  Mai tunin kalanda.
-  Mai tunin dawainiya.

Gajerun hanyoyi

Yi amfani da gajerun hanyoyin faifan maballii don zuwa menu da sauri, kuma zaka iya amfani da gajerun hanyoyin maballin kewayawa wanda aka ayyana don isa da sauri ga wadansu ayyuka. Shirya gajerun hanyoyin maballin kewayawar don biyan bukatunka.

Amfani da gajerun hanyoyin faifan maballi

Daga jiran aiki, je zuwa menus ta latsa  kuma shigar da lambar menu. Lambar menu yana farawa ne daga gunki na hagu a sama kuma yana ketarawa kasa ta hanya hanya, misali, lasta  saboda abun menu na biyar. Saboda na goma, na shadaya da na shabiyo, latsa ,  kuma  akai-akai. Don komawa jiran aiki, latsa ka rike .

Amfani da gajerun hanyoyi na maballin kewayawa

a jiran aiki, jeka zuwa gajerun hanyoyi ko aiki ta latsa , ,  ko .

Don shirya gajeriyan hanyar maballin kewawa

- Saituna ► Gaba daya shafin
- Gajerun hanyoyi kuma zabi gajeriyan hanya ► Shirya.

Yaren waya

Zabi yaren don amfani dashi a menu na wayar ko lokacin rubuta rubutu.

Don canja yaren wayar

- Saituna ► Gaba daya shafin ► Yare
- Yaren waya. Zabi yare.

Daga jiran aiki, kuma zaka iya latsa:

- ☎ 8888 ☎ don yare na atomatik.
- ☎ 0000 ☎ don Turanci.

 Mafi yawan katinan SIM suna saita yare menu ta atomatik zuwa kasar da ka sayi katinka na SIM. In bahaka ba, yaren da aka ayyana shine Turanci.

Don zabar yaren rubutu

- 1 ► Saituna ► Gaba daya shafin ► Yare
► Yaren rubutu.
- 2 Gungura zuwa yaren don amfani kuma yi masa alama. ► Ajiye don fita a menu.

Shigar da haruffa

Shigar da haruffa cikin dayan hanyoyi masu zuwa (hanyar shigar da rubutu), misali, lokacin rubuta sakonni:

- Shigar da rubutu na tabi dayawa
- T9™ Text Input

Don shigar da rubutu, dole kazama a cikin aiki inda shigar da rubutu zai yiwu, misali, ► **Sako** ► **Rubuta sabuwa** ► **Sakon rubutu**.

Don canja hanyar shigar da rubutun

Kafin, ko lokacin shigar da haruffa, latsa  kuma zabi wani yaren rubutu.

Don canja yaren rubutu

Kafin, ko lokacin shigar da haruffa, latsa  kuma zabi wani yaren rubutu.

Zabubbuka lokacin shigar da haruffa

- Kari don zabubbuka lokacin rubuta sako.

Don shigar da haruffa ta amfani da shigarwar tabi dayawa

- Latsa (2) - (9) akai-akai har sai harafin da kake so ya bayyana.
- Latsa (#-#) don matsawa tsakanin kanana da manyan haruffa.
- Latsa ka rike (0+) - (9) don shigar da lamba.
- Latsa (c) don share haruffa ko lambobi.
- Latsa (1) don alamun rubutu gamagari.
- Latsa (#-#) don kara wuri.

T9™ Text Input

Hanyar shigar da T9™ Text Input tana amfani da kamus ginanne aciki don gane kalmar da akafi amfani da ita ga kowane bibiyar latse-latsen maballi. Wannan hanyar, ka latsa kowane maballi sau daya kawai, koda harafin da kake nema ba shi bane harafin farko a maballin.

Don shigar da haruffa ta amfani da Shigar da T9 Text Input

- 1 Misali, don rubuta kalmar "Jane", latsa (5), (2), (6), (3).
- 2 Idan kalmar da aka nuna itace wacce kake so, latsa (#-#) don karba da kara sarari. Don karban kalma batareda kara sarari ba, latsa (c). Idan kalmar

da aka nuna ba itace wacce kake nema ba, latsa (c) ko (c) akai-akai don duba maimokon kalmomi. Karbi kalma kuma kara sarari ta latsawa (#-#).

- 3 Ci gaba da rubuta sakon. Don shigar da alamun rubutu, latsa (1) sannan (c) ko (c) akai-akai, latsa (#-#) don karba da kara sarari.

Don kara kalmomi zuwa kamus na T9 Text Input

- 1 Lokacin shigar da haruffa ► **Kari**
► **Tad. bakin kalma**.
- 2 Shirya kalma ta amfani da shigarwar tabi da yawa. Yi amafani da (c) kuma (c) dom motsa kibiya tsakanin haruffan. Don share harafi, latsa (c). Don share kalmar gaba daya, latsa karike (c).

Lokacin da ka shiryia kalmar ► **Sa**. An kara kalma zuwa kamus na T9 Text Input. Lokaci na gaba idan ka shigar da wananan kalmar ta amfani da T9 Text Input, zata bayyana a maimako kalmomi.

Kalmar gaibu ta gaba

Lokacin rubuta sako, zaka iya amfani da T9 Text Input don kalmar gaibu ta gaba, idan da anyi amfani da ita a jumla.

Don kunna/kashe kalmar gaibu ta gaba

Lokacin shigar da haruffa ► Kari

► Rubuta zabuka ► Kalma mai zuwa.

Don amafani da kalmar gaibu ta gaba

Lokacin shigar da haruffa, latsa  don karba ko ci gaba.

Mai sarrafa fayil


Yi amfani da mai sarrafa fayil don rike abubuwa kamar hotuna, shiryeshiyen bidiyo, jigogi, shafukan yanar sadarwa, wasanni da aikace-aikace wadanda aka ajiye a kwakwalwar ajiyar wayar ko akan katin kwakwalwar ajiyar.

Memory Stick Micro™ (M2™)

Wayarka tana goyan bayan

Memory Stick Micro™ (M2™) katin kwakwalwar ajiya dadin karin sararin ma'aji zuwa wayarka don ajiye fayiloli wandanda suke kunshe da hotuna ko kida, misali.

Don sakawa da cire katin kwakwalwar ajiya



1 Bude murfin.

2 Saka katin kwakwalwar ajiya kamar yadda aka nuna (tareda lambobin suna fuskantar kasa). Latsa gefen don saki da cire katin.

Hakanan zaka iya matsar da kwafe fayiloli tsakanin kwamfuta da katin kwakwalwar ajiyar. Lokacin da aka saka katin kwakwalwar ajiya, ana ajiye fayiloli ta atomatik zuwa gareshi idan baka zabi ajiye fayilolin zuwa kwakwalwar ajiyar waya ba.

Kirkiri manyan fayiloli mataimaka don matsar da ko kwafe fayiloli zuwa. Ana matsar da wasanni da aikace-aikace a tsakanin **Wasanni da Aikace-aikace** manyan fayiloli kuma daga kwakwalwar ajiyar wayar zuwa katin kwakwalwar ajiyar. Ana ajiye fayilolin da ba'a

ganesu ba cikin **Wasu** babban fayil din. Lokacin rike fayiloli, zaka iya zabar yawancin ko duk fayiloli a babban fayil a lokaci daya don duk abubuwa banda **Wasanni** kuma **Aikace-aikace**.

Halin kwakwalwar ajiya

Idan duk samammiyar kwakwalwar ajiya ta cika, ba zaka iya ajiye wasu fayiloli ba sai an share abun ciki. Bincika yanayin kwakwalwar ajiya don wayarka da katin kwakwalwar ajiya ta sa alamar haske a babban fayil ► **Kari** ► **Halin kwkl.ajiya**.

Shafukan menu na mai sarraf fayil

Ana kasa mai sarrafa fayil zuwa shafuka uku, kuma gumaka suna nuna inda aka ajiye fayiloli.

- **Duk fayiloli** – duk abun cikin kwakwalwar ajiyar waya da kan katin katin kwakwalwar ajiya.
- **A Memory Stick** – duk abun ciki kan katin kwakwalwar ajiya.
- **Cikin waya** – duk abun ciki a kwakwalwar ajiyar wayar.

Bayanin fayil

Duba bayanin fayil ta sa masa alamar haske ► **Kari** ► **Bayani**. Abubuwan da aka saukar, ko aka karba ta amfani da dayan samammun hanyoyin canja wuri, maiyuwa sunada kariyar hakkin mallaka. Idan ankare fayil, bazaka iya kwafe ko aika fayil din ba. Fayil na hakkin mallaka mai kariya yana da alamar maballi.

Don amfani da fayil daga mai sarrafa fayil

- 1 ► Mai sarrafa fayil kuma bude babban fayil.
- 2 Gungura zuwa fayil ► **Kari**.

Don matsar da ko kwafe fayil zuwa kwakwalwar ajiya

- 1 ► Mai sarrafa fayil kuma zabi babban fayil.
- 2 Gunguta zuwa fayil ► **Kari** ► **Sarrafa fayil** ► **Matsar** don matsar da ► **Kari** ► **Sarrafa fayil** ► **Kwafi** don kwafe fayil din.
- 3 Zabi don matsawa ko kwafe fayil din zuwa **Waya** ko **Memory Stick** ► **Zabi**.

Don matsar da ko kwafe fayiloli zuwa kwamfuta

► 74 Canja wurin fayiloli ta amfani da kebul na USB.

Don kirkirar babban fayil mataimaki

- 1 ► Mai sarrafa fayil kuma bude babban fayil.
- 2 ► Kari ► Sabon bab. fayil kuma shigar da suna don babban fayil din.
- 3 ► Ok don ajiye babban fayil din.

Don zabar fayiloli da yawa

- 1 ► Mai sarrafa fayil kuma bude babban fayil.
- 2 ► Kari ► Alama ► Alama a yawanci.
- 3 Gungura don zabar fayiloli ► Alama ko Cr. alama.

Don zabar duk fayiloli a babban fayil

► Mai sarrafa fayil kuma bude babban fayil ► Kari ► Alama ► Alm. duk.

Don share fayil ko babban fayil mataimaki daga mai sarrafa fayil

- 1 ► Mai sarrafa fayil kuma bude babban fayil.
- 2 Gungura zuwa fayil ► Kari ► Share.

Zabubbukan katin kwakwalwar ajiya

Bincika halin kwakwalwar ajiya ko tsara katin kwakwalwar ajiya don share duk bayani.

Don amfani da zabubbukan katin kwakwalwar ajiya

► Mai sarrafa fayil kuma zabi A Memory Stick shafin ► Kari don zabubbuka.

Kira

Kira, lambobi, lissafin kira, bugun kira na sauri, ikon murya, zabubukan kira, katunan kasuwanci.

Yin kira da karba

Kafin kayi kowane kira ko karba, dole ka kunna wayarka kuma ka zama a tsakanin kewayon cibiyar sadarwa.

► 5 Kunna wayarka.

Cibiyoyin sadarwa

Lokacin da ka kunna wayar, tana zabar cibiyar sadarwarka na gida ta automatic idan wannan yana cikin kewayo. Idan bata cikin kewayo, zaka iya amfani da wata cibiyar sadarwa, idan afaretan cibiyar sadarwarka yana da yarjejeniya wadda ta baka damar yin haka. Wannan ake kira yawo.

Zabi cibiyar sadarwar don amfani, ko zaka iya kara cibiyar sadarwa zuwa cibiyoyin sadarwarka wanda kafi so. Hakanan zaka iya canja tsari wanda acikin sa aka zabi cibiyoyin sadarwa yayin bincike na automatik.

Don duba samammun zabubukan cibiyar sadarwa

► Saituna kuma yi amfani da ◉ ko ◉ don gungurawa zuwa **Haduwa shafi** ► Cibiyar sadrwaya.

Don yin kira

- 1 Shigar da lambar waya (tareda lambar kasar waje da lambar yanki, idan an zartar).
- 2 ► **Kira** don yin kiran murya ko ► **Kari** don duba zabubuka.
- 3 ► **Kas.kira** don kare kiran.

💡 Zaka iya kiran lambobi daga lambobinka da kuma lissafin kira ► 24 Lambobi, da ► 27 Lissafin kira. Kuma zaka iya amfani da muryar ka don yin kira ► 28 Ikon murya.

Don yin kiran kasar waje

- 1 Latsa ka rike (◉+) harsai alamar + ta bayyana.
- 2 Shigar da lambar kasa, lambar yanki (batare da sifilin farko ba) da lambar waya. ► **Kira** don yin kiran murya.

Don sake buga lamba

Idan hadin kira ya gaza kuma **Sake jarabawa?** yana bayyana ► **Ee**.

💡 Kar ka rike wayar kusa da kunninka lokacin jira. Lokacin da kira ya hadu, wayar tana bada sigina mai kara.

Don amsa ko kin karbar kira

► Amsa ko ► Kan aiki.

Don kashe makirufo

- 1 Latsa ka rike **(C)**.
- 2 Don ci gaba da magana latsa ka rike **(C)** sake.

Don kunna lasifika ko kashewa yayin kiran murya

► Kari ► Kunna lasifika ko **Kashe lasifika**.

 Kar ka rike wayar kusa da kunninka lokacin amfani da lasifika. Wannan zai iya lalata jinka.

Don canja karar lasifikar tunni

Latsa **(▲)** don kara **(▼)** don rage karan lasifikar tunni lokacin kira.

Kiran da aka rasa

Lokacin da aka saita menu na ayyuka zuwa tsoho, kiran da aka rasa suna bayyan acikin **Sab.abun aukuwa shafin a jiran aiki**. Idan an saita fadakarwa zuwa tsohuwa **Kiran da aka rasa**: tana bayyana a jiran aiki
► 8 Menu na ayyuka.

Dun bincika kiran da aka rasa daga jiran aiki

- Idan an saita menu na ayyuka zuwa tsoho, latsa  kuma yi amfani da **(◐)** ko **(◑)** don gungurawa zuwa **Sab.abun aukuwa shafin**. Gungura **(◐)** ko **(◑)** don zabar lamba kuma ► **Kira** don kira.
- Idan an saita fadakarwa zuwa tsohuwa, ► **Kira** kuma yi amfani da **(◐)** ko **(◑)** don gungurawa zuwa **An rasa shafin**. Gungura **(◐)** ko **(◑)** don zabar lamba kuma ► **Kira** don kira.

Kiran gaggawa

Wayarka tana goyan bayan lambobin gaggawa na kasa da kasa, misali, 112, 911. Za'a iya amfani da wadannan lambobi kamar yadda aka saba don yin kiran gaggawa a kowake kasa, tareda ko ba tareda an saka katin SIM ba.

 A wasu kasashen, zai yiwu a daukaka wasu lambobin gaggawa. Afaretan cibiyar sadarwarka maiyuwa saboda haka ya ajiye karin lambar gaggawar ta cikin gida a katin SIM.

Don yin kiran gaggawa

Shigar da 112 (Lambar gaggawar kasa da kasar) ► **Kira**.

Don duba lambobin gaggawa naka na gida

- Lambobi ► Kari ► Zabubbuka
- Lambb. n. musam. ► Lambob. gaggawa.

Lambobi

Zaka iya ajiye bayanin lambar ka a kwa'kwalwar ajiyar wayar ko kan katin SIM.

Zabi wane bayanin lamba – **Lambobin waya** ko **Lambobin SIM** – aka nuna azaman tsoho.

Don bayani da saituna masu amfanı
► Lambobi ► Kari ► Zabubbuka.

Tsoaffin lambobi

Idan **Lambobin waya** an zaba azaman tsoho, lambobinka suna nuna duk bayanin da aka ajiye aciki **Lambobi**. Idan ka zabi **Lambobin SIM** azaman tsoho, lambobinka suna nuna bayanin da ya dogara da katin SIM dín.

Don zabar tsoffin lambobi

- 1 ► Lambobi ► Kari ► Zabubbuka
- Na ci gaba ► Tsoffin lambobi.
- 2 ► Lambobin waya ko Lambobin SIM.

Lambobin waya

Ajiye lambobi a wayar tareda sunaye< lambobin waya da bayanin sirri. Hakanan zaka iya kara hotuna da sautunan ringi zuwa lambobi. Yi amafani , ,  kuma  don gungurawa tsakanin shafuka da filayen bayanin su.

Don kara lambar waya

- 1 Idan **Lambobin waya** an zaba azaman tsoho, ► **Lambobi** ► **Sabuwar lamba**
► **Kara**.
- 2 Shigar da sunan ► Ok.
- 3 Shigar da lambar ► Ok.
- 4 Zabi zabin lamba.
- 5 Gungura tsakanin shafuka kuma zabi filayen don kara bayani. Don shigar da alamu kamar @, ► **Kari** ► **Kara** alama kuma zabi alama ► Sa.
- 6 Lokacin da aka kara duk bayani ► Ajiye.

Don share lamba

- 1 ► **Lambobi** kuma gungura zuwa lamba.
- 2 Latsa  kuma zabi Ee.

Don share duk lambobin waya

Idan **Lambobin waya** an zaba azaman tsohuwa, ► **Lambobi** ► **Kari**
► **Zabubbuka** ► **Na ci gaba** ► **Share** duk lambobi ► Ee kuma ► Ee. Ba'a share sunaye da lambobi akan katin SIM ba.

Don ajiye sunaye da lambobin waya ta automatik a kan katin SIM

► Lambobi ► Kari ► Zabubbuka ► Na ci gaba ► Ajiy.t. atom. a SIM kuma zabi Kunnewa.

Lambobin SIM

Ajiye lambobi a kan katin SIM naka.

Don kara lambar SIM

- 1 Idan Lambobin SIM an zaba azaman tsohuwa, ► Lambobi ► Sabuwar lamba ► Kara.
- 2 Shigar da sunan ► Ok.
- 3 Shigar da lambar ► Ok kuma zabi zabin lamba. Kara karin bayani idan akwai ► **Ajiye**.

Yanayin kwakwalwar ajiya

Adadin lambobin da zaka iya ajiyewa a wayar ko a katin SIM din ya dogara da sararin kwakwalwar ajiya.

Don duba halin kwakwalwar ajiya

► Lambobi ► Kari ► Zabubbuka ► Na ci gaba ► Halin kwkl.ajiya.

Amfani da lambobi

Z'a iya amfani da lambobi ta hanyoyi dayawa. A kasa zaka iya ganin yadda:

- Wayar kira da lambobin SIM.
- Aika lambobin waya zuwa wata na'ura.
- Kwafe lambobi zuwa waya da katin SIM.
- Kara hoto ko sautin ringi zuwa lambar waya.
- Shirya lambobi.
- Hada lambobinka aiki tare.

Don kiran lambar waya

- 1 ► Lambobi. Gungura zuwa, ko shigar da harafin farko ko haruffan lambar.
- 2 Lokacin da aka sawa lambar alamar haske latsa ☺ ko ☺ don zabar lamba
► Kira don yin kiran murya.

Don kiran lambar SIM

- Idan Lambobin SIM tsohuwace kuma lokacin da akaiwa lamba alamar haske latsa ☺ ko ☺ don zabar lamba. ► Kira don yin kiran murya.
- Idan Lambobin waya an saita azaman tsohuwa ► Lambobi ► Kari ► Zabubbuka ► Lambobin SIM kuma zabi lambar don kira ► Kira don yin kiran murya.

Don aika lamba

- Lambobi kuma zabi lamba ► Kari
- Aika lamba kuma zabi hanyar canja wuri.

Don aika duk lambobi

- Lambobi ► Kari ► Zabubbuka ► Na ci gaba ► Aika duk lambobi kuma zabi hanyar canja wuri.

Don kwafe sunaye da lambobi zuwa katin SIM din

- 1 ► Lambobi ► Kari ► Zabubbuka ► Na ci gaba ► Kwafi zuwa SIM.
- 2 Zabi dayan maimakon.

 Lokacin kwafe duk lambobi daga wayar zuwa katin SIM din, za'a musanya duk bayanin daya kasance na katin SIM.

Don kwafe sunaye da lambobi zuwa lambobin waya

- 1 ► Lambobi ► Kari ► Zabubbuka ► Na ci gaba ► Kwafi daga SIM.
- 2 Zabi dayan maimakon.

Don kara hoto, sautin ringi ko bidiyo zuwa lambar waya

- 1 ► Lambobi kuma zabi lambar ► Kari ► Shirya lamba.
- 2 Zabi shafin da ya dace kuma sannan zabi Hoto ko Sautin ringi ► Kara.
- 3 Zabi wani zabi da wani abu ► Ajiye.

 Idan biyan kudinka yana goyan bayan sabis na shaidar kiran layi (CLI), zaka iya kebance sautin ringi na sirri zuwa lambobi.

Don shirya lambar waya

- 1 ► Lambobi kuma zabi lamba ► Kari ► Shirya lamba.
- 2 Gungura zuwa shafin da ya dace kuma zabi fili don shiryawa ► Shirya.
- 3 Shiya bayanin ► Ajiye.

Don shirya lambar SIM

- 1 Idan lambobin SIM tsöffine ► Lambobi kuma zabi sunan da lambar don shiryawa. Idan lambobin wayar tsöffine ► Lambobi ► Kari ► Zabubbuka ► Lambobin SIM kuma zabi sunan da lambar don shiryawa.
- 2 ► Kari ► Shirya lamba kuma shirya sunan da lambar.

Don ajiye da gyara lambobi tareda katin kwakwalwar ajiya

- Lambobi ► Kari ► Zabubbuka ► Na ci gaba ► Ajiy. wari zw. M.S. ko Maida daga M.S.

Don zabar yanayin jere don lambobi

- Lambobi ► Kari ► Zabubbuka ► Na ci gaba ► Yanayin jere.

Aiki tareda lambobi

Zaka iya sa lambobinka aiki tareda lambobin aikace-aikace a yanar sadarwar. Don karin bayani ➤ 70 Aiki tare.

Lissafin kira

Bayani gameda kiran kwanannan.

Don kiran lamba daga lissafin kira

- 1 Daga jiran aiki, ➤ **Kira** kuma zabi shafi.
- 2 Gungura zuwa sunan ko lambar don kira ➤ **Kira** don yin kiran murya.

Don kara lambar lissafin kira zuwa lambobi

- 1 Daga jiran aiki, ➤ **Kira** kuma zabi shafi.
- 2 Gungura zuwa lamba don kara ➤ **Kari** ➤ **Ajiye lamba**.
- 3 ➤ **Sabuwar lamba** don kirkirar sabuwar lamba, ko zabi lambar data kasance don kara lambar zuwa gare ta.

Don share lissafin kira

- **Kira** kuma **Zabi** **Duk** **shafin** ➤ **Kari**
- **Share** **duk**.

Bugun kira na sauri tareda hotuna

Ajiye lamaba a matsayi 1-9 a wayarka don samun damarsu a saukake. Bugun kiran sauri ya dogara da tsoffin lambobinka ➤ 23 *Tsohuwar lamba*, misali, zaka iya bugun kira na sauri da lambobin da aka ajiye a katin SIM din.

Idan ka kara lambobi tareda hotuna zuwa wurin bugun kira na sauri, hotunan lambar suna bayyana saboda sassaukar alaka ➤ 26 *Don kara hoto*, sautin *ringi* ko *bidiyo* zuwa lambar waya.

Don shirya lambobin bugun kira na sauri

- 1 ➤ **Lambobi** ➤ **Kari** ➤ **Zabubbuka** ➤ **Bugn.** **kira** **na** **sauri**.
- 2 Gungura zuwa matsayin ➤ **Kara** ko ➤ **Kari** ➤ **Sauya**.

Don bugun kiran na sauri

Daga jiran aiki, shigar da lambar matsayi ➤ **Kira**.

Sakon murya

Idan biyan kudinka ya kunshi sabis na amsawa, masu kira za su iya barin sakon murya lokacin da ba zaka iya amsa kira ba.



Tuntubi afaretan cibiyar sadarwarka don lambar sakon murya naka ko don karin bayani.

Don kiran sabis din sakon muryar naka

Daga jiran aiki, latsa ka rike 1.
Idan ka shigar da lambar sakon murya,
► Ee kuma shigar da sunan.

Don shirya lambar sakon muryar naka

► Sako ► Saituna ► Lambr. skn. murya.

Ikon murya

Sarrafa kira tareda muryarka ta kirkirar umarnin murya zuwa:

- Bugun murya – kira wasu ta hanyar ambaton sunayen su.
- Kunna ikon murya ta ambaton “kalmar sihiri”.
- Amsa ko kin amsa kira ta amfani da abin wasa akunni.

Kafin bugun kiran murya

Kunna aikin bugun kiran muryar kuma yi rikodin umarnin muryarka. Wani gunki yana bayyana kusa da lambar wayar dake da umarnin murya.

Don kunna bugun kiran murya da rikodin sunaye

- 1 ► Saituna ► Gaba daya shafin ► Ikon murya ► Bugun kiran murya ► Kunna ► Ee ► Sabuwlmuryaar kuma zabi lamba.
- 2 Idan lambar tana da lamba fiye da daya, yi amfani da ④ kuma ④ don duba lambobin. Zabi lambar don kara umarnin muryar greta. Yi rikodin umarnin murya kamar “Wayar hannu ta John”.
- 3 Umarni yana bayyana. Jira sautin kuma fadí umarnin don rikodi. Ana sake kunna maka umarnin muryar.
- 4 Idan rikodin yayi sauti OK ► Ee. Idan bai yiba ► A'a kuma maimaita matakina 3.
Don rikodin wani umarnin murya saboda lamba ► Sabuwlmuryaar
► Kara kuma maimaita taku 2-4 a sama.

Sunan mai kira

Ji sunan lambarka da akayi rikodi lokacin da ka karbi kira daga wannan lambar.

Don kunna ko kashe sunan mai kiran

► Saituna ► Gaba daya shafin ► Ikon murya ► Kun.sunan mai kira.

Bugun kiran murya

Fara bugun kiran murya daga jiran aiki ta amfani da wayar, abin sawa akunni mai dakuwa, na'urur kai ta Bluetooth ko ta fadin kalmar sihirinka.

Don yin kira

- 1 Daga jiran aiki, latsa ka riKE dayan maballan kara.
- 2 Jira sautin kuma fadi sunan da aka yi rikodi, misali "Wayar hannu ta John". Za'a sake kunna maka sunan kuma an hada kiran.

Don yin kira tareda abin sawa akunni

Daga jiran aiki, latsa ka riKE maballin abin sawa akunnin, ko latsa maballin na'urur kai ta Bluetooth.

Kalmar sihirin

Yi rikodi da amfani da umarnin murya azaman kalmar sihiri don kunna ikon murya ba tareda latsa kowane maballin ba. Za'a iya amfani da kalmar sihirin kawai tareda abin sawa akunni.

 *Zabi mai tsayi, ya wanci kalma ko yankin jumla wanda za'a iya gane shi a sauake daga bangon baya na maganan gama gari.*

Don kunna da yin rikodin kalmar sihirin

- 1 ► Saituna ► Gaba daya shafin ► Ikon murya ► Kalmar sihiri ► Kunna.
- 2 Umarni zai bayyana. ► Ci gaba. Jira sautin kuma fadi kalmar sihirin.
- 3 ► Ee don karba ko ► A'a don yin rikodin sabuwarr kalmar sihiri.
- 4 Umarni zai bayyana. ► Ci gaba kuma zabi maballin da acikin sa za'a kunna kalmar sihirinka.

Amsa murya

Amsa ko ki amsa kira mai shigowa ta amfani da muryarka, lokacin amfani da abin sawa akunni.

 *Zaka iya amfani da fayil na MIDI, WAV (16 kHz), eMelody ko iMelody azaman sautin ringi tareda amsa murya.*

Don kunna amsawar murya da yin rikodin umarnin amsawar murya

- 1 ► Saituna ► Gaba daya shafin ► Ikon murya ► Amsawar murya ► Kunna.
- 2 Umarni zai bayyana. ► Ci gaba. Jira sautin kuma fadi "Amsa", ko wata kalma.
- 3 ► Ee don karba ko ► A'a don sabon rikodi.
- 4 Umarni zai bayyana. ► Ci gaba. Jira sautin kuma fadi "akan aiki", ko wata kalma.
- 5 ► Ee don karba ko ► A'a don sabon rikodi.
- 6 Umarni zai bayyana. ► Ci gaba kuma zabi mahallin da acikin sa za'a kunna amsawar murya.

Don amsawa ko kin karban kira ta amfani da umarnin murya

Lokacin da wayar tayi ringi, ambaci:

- "Amsa" don hada kira.
- "Kan aiki" don kin karban kira.

Don shirya umarnin muryar naka

- 1 ► Lambobi kuma gungura zuwa lamba.
- 2 ► Kari ► Shirya lamba kuma gungura zuwa shafin maidacewa.

Don sake yin rikodin umarnin murya

- 1 ► Saituna ► Gaba daya shafin ► Ikon murya ► Bugun kiran murya ► Shirya sunaye.
- 2 Zabi umarni ► Kari ► Sauya murya ► Ee.
- 3 Jira sautin kuma fadi umarnin.



Karkata kira

Karkata kira, misali, zuwa sabis na amsawa.

Lokacin da aka kunna aikin karkata kira, ba'a samun wasu zabubukan karkata kira. ► 33 Kuntataccen bugun kira.

Wayarka tana da zabubuka masu zuwa:

- Karkatr. koyaushe – duk kira.
- Idan ana kan aiki – idan kira yana gudana.
- Ba za'a iya sm. ba – idan an kashe ko ba'a sameshi ba.
- Babu amsa – idan ba'a amsaba a kayyadadden lokaci.

Don kunna karkata kira

- 1 ► Saituna ► Kira shafin ► Karkatar da kira.
- 2 Zabi nau'in kira da zabin karkatarwa ► Kunna.

- 3 Shigar da lambar wayar don karkatar da kiranka zuwa, ko latxa **Dubawa** don nemo lamba ► Ok.

Don kashe karkata kira

Gungura zuwa zabin karkata kiran
► **Kashe.**

Fiyē da kira daya

karbar fiye da kira daya kai tsaye.

Sabis na jiran kira

Lokacin da aka kunna wannan zaka ji kara idan ka karbi kira na biyu.

Don kunna ko kashe sabis na jiran kiran

► Saituna ► Kira shafin ta amfani da
⌚ ko ⌚ kuma ► Sarrafa kira ► Jiran kira.

Don yin kira na biyu

- 1 ► **Kari** ► **Rike** don riķe kira mai gudana.
- 2 Shigar da lambar don kira ► **Kari** ► **Kira.**

Karban kiran murya na biyu

Lokacin da ka karbi kira na biyu, zaka iya:

► **Amsa** kuma sanya kira mai gudana arike.

► **Kan aiki** don kin karba da cigaba da kiran mai gudana.

► **Sauya kira mai aiki** don amsa da kare kiran mai gudana.



Karbar kiran murya biyu

Idan kanada kira mai gudana da arike, zaka iya:

► **Kari** don zabubbuka:

- **Canja** – canja tsakanin kiran guda biyu.
- **Hada kira** – hada kiran guda biyu.
- **Canja wurin kira** – hada kiran guda biyu. An katse ka daga duk kiran biyu.

► **Kas.kira** don zabubbuka:

- **Ee** – dawo da kira arike.
- **A'a** – kare kira biyu.

Baza ka iya amsa kira na uku ba tareda kare daya daga cikin kira biyun farko ba saidai ka hada su cikin kiran taro.

Kiran taro

Fara kiran taro ta hada kira mai gudana da kira arike. Sannan sanya taron arike kuma kara kusan yan takara biyar, ko yi wani kira.



Maiyuwa yazama akwai karin caji don kira wanda ya shafi ribanyayyun bangarori; tuntubi afaretan cibiyar sadarwarka don karin bayani.

Don hada kira guda biyu cikin kiran taro

► Kari ► Hada kira.

Don kara sabon dan takara

- 1 ► Kari ► Rike don sanya kira wađanda aka hada arike.
- 2 ► Kari ► Kara kira kuma kira mutum na gaba don karawa zuwa kiran taron.
- 3 ► Kari ► Hada kira.
- 4 Maimaita taku 1-3 don kara karin yan takara.

Don sakin dan takara

► Kari ► Saki bangare. kuma zabi dan takara don saki daga kiran taro.

Don samun tadī na sirri

- 1 ► Kari ► Yi magana da kuma zabi dan takara don magana da.
- 2 ► Kari ► Hada kira don cigaba da kiran taro.



Layukan murya biyu

Yi kira aware da lambobin waya daban idan biyan kudinka yana goyan bayan sabis na layin wucin gadi.

Don zabar layi don kira mai fita

► Saituna kuma yi amfani da ◇ ko ◇ don gungurawa zuwa **Kira shafin**. Zabi layi 1 ko 2.

Don canja sunan layin

► Saituna kuma yi amfani da ◇ ko ◇ don gungurawa **Nuni shfin** ► **Shirya sunayen layi**. Zabi layi don shiryawa.

Lambana

Duba, kara da shirya labobin wayarka.

Don bincika lambobin wayarka

► Lambobi ► Kari ► Zabubbuka ► Lambb. n. musam. ► Lambobi nawा kuma zabi dayan zabubbukan.

Karbi kira

Kawai karbi kira daga takamammun lambobin waya. Idan zabin karkatar da kira **Idan ana kan aiki** an kunna shi, ana karkatar da kira.

Don kara lambobi zuwa lissafin karbabbun masu kira

► Saituna kuma yi amfani ☺ ko ☺ don gungurawa zuwa Kira shafin ► Sarrafa kira ► Karba kira ► Daga liss. kawai ► Shirya ► Sabo ► Kara. Zabi lamba ko Kungiyyoi 40 Kungiyyoi.

Don karbar duk kira

► Saituna ► Kira shafin ► Sarrafa kira ► Karba kira ► Duk masu kira.

Kuntataccen bugun kira

Kuntata kira mai fita da shigowa. Ana bukatar kalmar wucewa daga mai baka sabis.

 *Idan ka karkatar da kira mai shigowa, baza ka iya kunna wasu zabubbukan kuntata kira ba.*

Za'a iya kuntata kira mai biyowa:

- **Duk mai fita** – duk kira mai fita.
- **Mai fita waje** – duk kira mai fita na kasashen dunia.
- **Yw. krn. wj. m. ft.** – duk kira mai fita na kasashen dunia banda zuwa kasarka.
- **Duk mai shigowa** – duk kira mai shigowa.
- **M. shg.in an. ywo.** – duk kira mai shigowa lokacin da kake kasar waje
► 22 Cibiyoyin sadarwa.

Don kunna ko kashe kuntata kira

- 1 ► Saituna kuma yi amfani da ☺ ko ☺ don gungurawa zuwa **Kira shafin**
- **Sarrafa kira** ► **Kuntata kira.** Zabi wani zabi.
- 2 **Zabi Kunna ko Kashe**, shigar da kalmar wucewarka ► **Ok.**

Kafaffen bugun kira

Aikin kafaffen bugun kira yana bada damar yin kira zuwa takamammen lambobi ajiyayyu a katin SIM. Ana kare kafaffun lambobi ta PIN2 naka.

 *Har yan zu zaka iya kirian lambar gaggawa ta kasashen dunia, 112, koda lokacin an kunna aikin kafaffen bugun kira.*

Za'a iya ajiye lambobin da basu cika ba. Misali, ajiye 0123456 yana bada damar kiran duk lambobin da suka fara da 0123456.

 *Lokacin da aka kunn kafaffen bugun kira, ba za'a baka damar duba ko sarrafa wasu lambobin waya ajiyayyu a katin SIM ba.*

Don kunna ko kashe kafaffen bugun kira

- 1 ► **Lambobi** ► **Kari** ► **Zabubbuka**
- **Lambb. n. musam.** ► **Kafaffen bgn.**
- kira kuma zabi Kunna ko Kashe.**
- 2 Shigar da PIN2 naka ► **Ok** kuma sannan ► **Ok** sake don tabbatarwa.

Don ajiye kafaffiyar lamba

- Lambobi ► Kari ► Zabubbuka
- Lambb. n. musam. ► Kafaffen bgn. kira ► Kafaffun lambobi ► Sabuwar lamba kuma shigar da bayanin.



Lokacin kira da farashi

Yayin kira, ana nuna tsawon lokacin kiran. Zaka iya duba tsawon lokacin kiranka na karshe, kira masu fita da jimillar lokacin kiranka.

Don duba lokacin kiran

- Saituna kuma yi amfani da Ⓛ ko ⓘ don gungurawa zuwa **Kira shafin**
- Lokaci & farashi ► Ms. kiday. lok. kira.

Karin ayyukan kira

Sautin sigina

Yi amfani da sabis na bankin tarho ko sarrafa injin amsawa tareda sigina na sauti yayin kira.

Don amfani da sigina na sauti

- Latsa ⓘ+ – ⓘ, ⓘ ⓘ ⓘ ko ⓘ ⓘ don aika sautuka.
- ► Kari ► Nakasa sautuna ko **Bada** damar saut. don kunna ko kashe sauti lokacin kira.
- Latsa ⓘ don share allon bayan kira.

Allon rubutu

Yi amfani da allon azaman allon rubutu don shigar da lambar waya yayin kira. Lokacin da ka kare kira, lambar zata zauna a allon don ka kira ko ajiyewa acikin lambobinka.

Don kira ko ajiyewa daga allon rubutu

- Kira don kiran lambar.
- Kari ► Ajiye lamba kuma zabi lamba don ajiye lambar zuwa ga ko
- Sabuwar lamba don kirkiro sabuwar lamba saboda ajiyewa zuwa.

Nuna ko boye lambarka

Idan biyan kufinka yana goyan bayan sabis na kuntata shaider layin kira (CLIR), zaka iya boye lambar waya lokacin yin kira.

Don nuna ko boye lambar waya koyaushe

- 1 ► Saituna ► Kira shafin ► Nun./boy. lamb.na.
- 2 Zabi Nuna lamba, Boye lamba ko Tsoh. cib. sadar.

Kungiyoyi

Kirkiri kungiyar lambobi da adiresoshin email don aika sakonni zuwa yawancin masu karba a lokaci guda ► 36 Sakonni.

💡 *Idan ka aika sakon rubutu zuwa kungiya, za'a caje ka akan kowane dan kungiya.*

Hakanan zaka iya amfani da kungiyoyi (tareda lambobi) lokacin da ka kirkiri lissafin karbabbn masu kira ► 32 Karbi kira.

Don kirkirar kungiyar lambobi da adiresoshin email

- 1 Idan Lambobin wayaLambobi
 - Kungiyoyi ► Sabuwar kungiya
 - Kara.
- 2 Shigar da suna don kungiyar ► Ci gaba.
- 3 ► Sabo ► Kara don nemo da zabar lambar lamba ko adireshin email.
- 4 Maimaita taki 3 don kara karin lambobi ko adireshin email. ► Anyi.

Katunan kasuwanci

Kara katinka na kasuwanci azaman lamba.

Don kara katin kasuwancin ka

► Lambobi ► Kari ► Zabubbuka ► Kat. kasuwnci na kuma kara bayani don katin kasuwancinka ► Ajiye.

Don aika katinka na kasuwanci

► Lambobi ► Kari ► Zabubbuka ► Kat. kasuwnci na ► Aika kati nawa kuma zaibi hanyar canja wuri.

Sako

Sakon rubutu, sakon hoto, sakon murya, email, Abokaina.

Wayarka tana goyan bayan sabis na sakonni da yawa. Tuntubi mai baka sabis bisaga sabis dinda zaka iya amfani dasu, saboda karin bayani, ziyci www.sonyericsson.com/support.

Sakon rubutun (SMS)

Sako rubutu zai iya kunsan hotuna masu sauksi, rinjayan sauti, rayarwa, da launin wakoki. Hakanan zaka iya kirkirar da amfani da samfura don sakonninka.

Kafin ka fara

Ana bada lambar wurin sabis naka ta mai baka sabis kuma yawanci ana saita ta a katin SIM. In ba haka ba, zaka iya shigar da lambar da kanka

Don saita lambar wurin sabis

- 1 ► Sako ► Saituna ► Sakon rubutu
► Wurin sabis. Idan an ajiye lambar wurin sabis kan katin SIM tana bayyana.
- 2 Idan ba'a nuna lamba ba ► Shirya
► Sabo. WurinSabis kuma shigar da lambar, gamida fihirisar kasashen duniya "+" da lambar kasa/yanki ► Ajiye.

Aika sakonni ruburu

Saboda bayani bisaga shigar da haruffa ► 17 Shigar da haruffa.

 *Takamaiman haruffan wasu yaruka suna amfani da karin sarari. Don wasu yaruka zaka iya kashe National chars. don ajiye sarari.*

Don rubuta da aika sakon rubutu

- 1 ► Sako ► Rubuta sabuwa ► Sakon rubutu.
- 2 Rubuta sakonka ► Ci gaba. (Zaka iya ajiye sako saboda gaba a Tsararr. sakonni ta latsa  ► Ajiye sako.)
- 3 ► Shig. da Im. waya kuma shigar da lamba, ko ► Duba lambobi don dauko lamba ko kungiya daga Lambobi, ko ► Shigar.adire.email ko zabi daga masu karba wadanda akayi amfani dasu na karshe ► Aika.

 *Don aika sako zuwa adreshin email, kana bukatan saita lambar hanyar email, ► Sako ► Saituna ► Sakon rubutu ► Hanyar email. Ana kawa lambar daga mai bada sabis naka.*

Don kwafa da lika rubutu a sako

- 1 Lokacin rubuta sakonka ► **Kari**
► Kwafe & manna.
- 2 ► Kwafi duk ko ► **Alama& kwafe** kuma yi amfani da maballin kewayawa don gungurawa da yiwa rubutu alama a sakonka.
- 3 ► **Kari** ► **Kwafe & manna** ► **Manna**.

Don saka abu a sakon rubutu

- 1 Lokacin rubuta sakonka ► **Kari** ► **Kara abu**.
 - 2 Zabi wani zabi kuma sannan abu, misali, hoto.
-  **Zaka iya sauya sakon rubutunka zuwa sakon hoto. Lokacin rubuta sakonka**
► **Kari** ► **Zuwa sakon hoto kuma ci gaba da kirkiro sakon hoto**, ► 39 **Sakon hoto** (MMS).

Karbar sakon rubutu

Lokacin da karbi sakon rubutu, yana bayyan a menu na ayyuka idan **Sab.** abun aukuwa an saita zuwa **Menu na ayyuka**. ► **Duba** don karanta sakon.
► 8 **Shafuka menu na ayyuka**.

Idan **Sab.** abun aukuwa an saita zuwa **Pop-up**, ana tambayarka idan kana so ka karanta sakon rubutun.

► **Ee** don karanta sakon ko ► **A'a** don karanta shi a gaba. Lokacin da ka karanta sakon rubutu ► **Kari** saboda zabubbuka ko latsa (➡) don rufe sakon. ► 8 **Shafuka menu na ayyuka**.

Don kiran lamba a sakon rubutu

Zabi lambar wayar da aka nuna a sakon rubutun, ► **Kira**.

Ajiyewa da share sakonnin rubutu

Ana ajiye sakonnin rubutu wadanda aka karba a kwakwalwar ajiyar wayar. Lokacin da kwakwalwar ajiyar wayar ta cika, share sakonnin ko matsar dasu zuwa katin SIM don samun damar karbar sababbin sakoni. Sakonnin da aka ajiye a katin SIM suna zama harsai an share su.

Don ajiye sako

- 1 ► **Sako** ► **Akw. s. m. shig.** kuma zabi sakon don ajiya.
- 2 ► **Kari** ► **Ajiye sako**.
- 3 ► **Ajiyayyu.** wasiku don ajiyewa a katin SIM ko ► **Samfura** don ajiye sakon azaman samfuri a wayar.

Don ajiye abu a sakon rubutu

- 1 Lokacin karanta sako, zabi lambar wayar, hoto ko adireshin yanar sadarwa don ajiya ► **Kari.**
- 2 ► **Yi amfani** (Lambar wayar da ka zaba tana bayyana) ► **Ajiye lamba** don ajiye lambar wayar ko ► **Ajiye hoto** don ajiye hoto ko ► **Yi amfani** (Alamar shafin da ka zaba tana bayyana) ► **Ajiye alamar shafi** don ajiye alamar shafi.

Don share sako

- 1 ► **Sako** kuma zabi babbani fayil.
- 2 Zabi sakon don sharewa kuma latsa **C.**

Don ajiye ko share sakonni da yawa

- 1 ► **Sako** kuma zabi babbani fayil.
- 2 Zabi sako ► **Kari** ► **Shre.** duk sakonni don share duk sakonni a babbani fayil ko ► **Alama a yawanci** Gungura kuma zabi sakonni ta latsa **Alama** ko **Cr.** alama.
- 3 ► **Kari** ► **Ajiye sako** don ajiyr sako ko ► Share sakonni don share sako.

Dogayen sakonni

Adadin haruffan da aka bada dama a sakon rubutu ya dogara da yaren da ake amfani dashi a rubutun. Zaka iya aika dogon sako ta hada sakonni

biyu ko fiye. Ana cajin ka a kowane sakon da aka hada a dogon sako. Mai karba zai yiwu ba zai karbi duk sashin dogon sako ba a lokaci daya.



Bincika tareda mai baka sabis iyakar adadin sakonni da za'a iya hadawa.

Don kunna dogayen sakonni

- **Sako** ► **Saituna** ► **Sakon rubutu**
- **Iyakar tsayin** sako ► **Iyaka** da **akwai.**

Samfura don sakonni rubutu

Kara sabon samfuri ko ajiye sako azaman samfuri a wayarka ► **37 Don ajiye sako.**

Don kara samfuri

- 1 ► **Sako** ► **Samfura** ► **Sabuwar samfuri**
- **Rubutu.**
- 2 **Saka rubutu** ► **Ok.**
- 3 **Shigar** da take ► **Ok.**

Don amfani da samfuri

- 1 ► **Sako** ► **Samfura** zabi samfuri ► **Yi amfani** ► **Sakon rubutu.**
- 2 Kara rubutu ko ► **Ci gaba** kuma zabi mai karba don aika sakon zuwa gareshi.

Zabubbukan sako

Saita tsohuwar kima don zabubbukan sako dayawa ko zabi saitunan akowane lokaci ka aika sako.

Don saita tsoffin zabubbukan sakon rubutu

► Sako ► Saituna ► Sakon rubutu kuma zabi zabubbukan don canzawa.

Don saita zabubbukan sako saboda takamammen sakon

- 1 Lokacin da aka rubuta sakon kuma aka zabi mai karba ► Kari ► Na ci gaba.
- 2 Zabi wani zabi don canzawa ► Shirya kuma zabi sabon saiti ► Anyi.

Don bincika halin isar da sakon da aka aika

► Sako ► Sako da ak. aika kuma zabi sakon rubutu ► Duba ► Kari ► Duba hali.

Sakon hoto (MMS)

Sakonnin hoto zai iya kunsar rubutu, hotuna, hotunan kamara, majigi, sautin rikodi, shirye-shiryen bidojo, sa hannu da hafe-hade. Zaka iya aika sakonnin hoto zuwa wayar hannu ko adireshin email.

Kafin ka fara

Kai da mai karbar dole yazama kuna da biyan kudi wanda ke goyan bayan sakon hoto.

Idan bayanin martabar intanit ko uwarr garken sako basu kasance ba, zaka iya karbar duk saitunan don MMS ta atomatik daga afaretan cibiyar sadarwaka ko daga www.sonyericsson.com/support.

Kafin aika sako hoto, zaka iya bincika an saita adreshin uwarr garken sakon ka da bayanin martabar intanit:
SakoSaitunaSakon hoto ► Bay. mrtbar MMS kuma zabi bayanin martaba. ► Kari ► Shirya ► Uwar garken sako da ► Kari ► Shirya ► Bayn.mrtb. intanit.

Don kirkira da aika sakon hoto

- 1 ► Sako ► Rubuta sabuwa ► Sakon hoto. Gungura ☺ don amfani da zabubbukan akwatin kayan aiki. Gungura ☺ ko ☺ don zabi wani zabi.
- 2 Lokacin da aka shirya aikawa ► Ci gaba.
- 3 ► Shigar.adire.email ko ► Shig. da lm. waya ko ► Duba lambobi don daukan lamba ko kungiyar a lambobi ko zabi daga masu karba wanda akayi amfani dasu na karke ► Aika.

 *Lokacin rubutu da shirya sakon rubutu zaka iya amfani da aikin kwafi da liki*
► 37 Don kwafi da lika rubutu a sako.

Don kirkirar sa hannunka don sakonnin hoto

- 1 ► Sako ► Saituna ► Sakon hoto.
- 2 ► Sa hannu ► Sabo. sa hannu kuma kirkiri sa hannunka azaman sakon hoto.

Don saita tsoffin zabubukan sakon hoto

- Sako ► Saituna ► Sakon hoto kuma zabi zabubuka don canzawa.

Karin zabubukan aikawa

Neman rahoton karantawa, rahoton isarwa, kuma saita fifiko don takamammen sako. Hakanan zaka iya kara karin masu karba zuwa sakon.

Don zabar karin zabubukan aikawa

- 1 Locacin da aka gama sakon kuma aka zabi mai karba ► **Kari**.
- 2 ► Kara mai karba don kara wani mai karba ko ► **Shiry masu karba** don shirya da kara masu karba. ► **Shiryta** take don canza taken sakon ko
► **Na ci gaba** don karin zabubukan aikawa.

Karbar sakonnin hoto

Zabi yadda zaka sauke sakonnin hotonka da yadda zaka ajiye abubuwa wadanda ka karba a sakonnin hoto.

Don saita saukewa ta atomatik

► Sako ► Saituna ► Sakon hoto
► Saukw. ta atomat. don duba da zabar dayan masu biyowar:

- **Koyaushe** – saukewar atomatik.
- **Tamby.an. yawo** – tambayi don saukewa lokacin da ba'a cikin cibiyar sadarwa na gida.
- **Ba'a cikin yawo** – kar a sauке lokacin da ba'a cikin cibiyar sadarwa na gida ba.
- **Koys. tambayi** – koyaushe tambaya don saukewa.
- **A kashe** – sabon sako yana bayyan acikin **Akw. s. m. shig.** Zabi sakon kuma ► **Duba** don saukewa.

Don karbar sakonnin hoto

Lokacin da ka karbi sakon hoto wanda aka sauке ta atomatik, yana bayyan a menu na ayyuka idan **Sab.** abun aukuwa an saita zuwa **Menu** na ayyuka. ► **Duba** don karanta sakon.
► 8 **Shafuka** menu na ayyuka.

Idan **New events** an saita zuwa **Pop-up**, ana tambayarka idan kana so ka karanta sakon hoton, don karantawa ko kunnawa. ► **8 Shafuka menu na ayyuka.**

Latsa (S) don rufe sakon.

Don ajiye abu a sako hoto

Lokacin duban sakon hoto ► **Kari**
► **Ajiye abubuwa** kuma zabi abu don ajiyewa daga lissafin da ya bayyana.

Share sakonnin hoto

Ana ajiye sakonnin hoto a kwakwalwar ajiyar wayar. Lokacin da kwakwalwar ajiyar waya ta cika, dolene ka share sakoni don samun damar karbar sababbin sakonni. Zabi sako kuma latsa (C) don sharewa.

Samfura saboda sakonnin hoto

Kara sabon samfuri ko yi amfani da samfurin da aka riga aka ayyana.

Don kara samfuri

- 1 ► Sako ► Samfura ► Sabuwar samfuri
► **Sakon hoto.**
- 2 ► **Kari** don kara sababbin abubuwa.
- 3 ► **Ajiye**, shigar da take ► **Ok** don ajiye samfurin.

Don amfani da samfuri

- 1 ► Sako ► Samfura kuma zabi samfuri daga lissafin ► **Yi amfani** don amfani da samfurin azaman shine ko ► **Kari**
► **Shirya samfuri** don shirya samfurin,
► **Ajiye**, shigar da take ► **Ok** don ajiye caje-canjen.
- 2 ► **Ci gaba** kuma zabi mai karba don aika sakon gareshi ko zabi samfuri daga lissafin ► **Yi amfani** ► **Ci gaba** idan an shirya samfurin.

Sakonnin murya

Aika kuma karbi rikodin sauti azaman sakon murya.



Mai aikawa da mai karba dolene su sami goyan bayan biyan kuđin sakon hoto.

Don yin rikodi da aika sakon murya

- 1 ► Sako ► Rubuta sabuwa ► **Sakon murya.**
- 2 ► **Yi rikodin sakonka.** ► **Tsaida** don karewa.
- 3 ► **Aika** don aika sakon.
- 4 ► **Shigar.adire.email** don email mai karba ko ► **Shig. da Im. waya** don lambar wayar mai karba ko ► **Duba lambobi** don lamba ko kungiya a lambobi ko zabi daga karshen masu karba wandanda aka yi amfani dasu ► **Aika.**

Karbar sakonnin murya

Lokacin da ka karbi sakon murya wanda aka sauke ta automatik, sakon muryar yana bayyan acikin menu na ayyuka idan Sab.abun aukuwa an saita zuwa **Menu na ayyuka.** ► Kunna don sauraren sakon. ► 8 Shafuka menu na ayyuka.

Idan **Sab.abun aukuwa an saita zuwa Pop-up**, ana tambayarka idan kana son sauraren sakon muryar. ► Ee don kunna sakon ko ► A'a idan kana son kunna sakon a gaba. Lokacin da ka saurari sakon muryar ► **Kari** don duba lissafin zabubbuka. Latsa (✉) don rufe sako. ► 8 Shafuka menu na ayyuka.



Email

Karanta sakon email naka a wayarka koda yaushe. Rubuta sako, hada da hoton kamara, rikodin sauti ko shirin bidiyo, kuma aika shi zuwa abokanka ko abokan aikinka. Hakanan kuma zaka iya amsa da tura email a wayarka, kamar dai yadda zaka iya a kwamfutarka.

Hakanan kuma adreshin email din da kake amfani dashi a kwamfutarka zaka iya amfani dashi a wayarka. Wayarka tana bukatan saituna na email kamar wadanda ake amfani dasu a kwamfutarka saboda adreshin email. Don amfani da adreshin email na kwamfutarka a wayarka, yi daya daga cikin masu biyowa:

- **Karbi saituna ta atomatikk**

Hnaya mafi sauksi shine ka sami saituna wadanda aka aiko so kai tsaye zuwa wayarka. Yi amfani da intanit kan kwamfutarka don zuwa ga www.sonyericsson.com/support.

- **Shigar da saituna da hannu**

- Tambayi mai baka email saboda bayanin saituna. Mai bada email shine wani mutum ko kamfani wanda yake kawo adreshin email dinka, misali mai kula da IT naka ko mai bada intanit.
- Maiyuwa kasami takardun aiki a gida daga mai baka email tareda bayanin saituna, ko.
- Maiyuwa kasami baynin a saitunen shirin email din kwamfutarka.

Wane bayani nake bukata?

Mafi karancin abinda kake bukata
shine mai biyowa:

Nau'ukan saiti

Nau'in hadī

Adireshin email

Uwr. grk. m-shig.

Sunan mai amfani

Kalmar wucewa

Uw. garke mai fita

Misalai

POP3 ko IMAP4

*joe.smith@
example.com*

mail.example.com

jsmith

zX123

mail.example.com

Don karin bayani tuntubi mai baka
email.

Don kirkirar lissafin email

- 1 ► Sako ► Email ► Saituna ► Sabon lissafi ► Kara.
- 2 Shigar da suna don lissafin ► Ok. Don taimako ► Ummurnin saiti, ko latsa Ⓜ zuwa saiti ► Bayani.
- 3 Latsa Ⓜ zuwa saiti kuma shigar da mafi karancin satunn da ake bukata masu zuwa:

- **Fadakarwar email** kuma zabi sautin fadakarwar don sababbin sakonni.
- **Hada aiki** kuma zabi lissafin bayanai (wadanda mai sa aiki na cibiyar sadarwa yakawo, ► Bayani).
- **Adireshin email**, shigar da adireshin email naka.
- **Nau'in hadī** (POP3 ko IMAP4).
- **Uwr. grk. m-shig.**, shigar da sunan uwargarken.
- **Sunan mai amfani**, shigar da sunan mai amfanin don lissafin email.
- **Kalmar wucewa**, shigar da kalmar wucewar don lissafin email din.
- **Uw. garke mai fita**, shigar da sunan uwargarken.

Don shigar da saitunan email

1 ► Sako ► Email ► Saituna.

2 Bayan an shigar da saituna, ► Akw. s. m. shig. ► Kari ► Aika & karbadon samun damar email naka.

Lokacin da aka shigar da saituna, wayarka zata iya haduwa da uwargarken email don aikawa da karbar sakonni email.

Don shigar da saitunan lissafin email na ci gaba (na ganin dama sau tari)

- 1 ► Sako ► Email ► Saituna.
- 2 Zabi lissafi don shiryawa ► Kari
► Shirya lissafi ► Babban saituna.
- 3 Press ⌂ Don zabi da shiga saituna,
in mai baka email ya bukaci haka,
misali, Duba tazara.

Don karba da karanta sakonnin email

- 1 ► Sako ► Email ► Akw. s. m. shig.
► Aik. & kb. lokacin da akwatin
sakon mai shigowa ya zama fanko
ko ► Sako ► Email ► Akw. s. m. shig.
► Kari ► Aika & karba don sauke
sababbin sakonni. Wannan kuma
yana aika kowane sakonni cikin
akwatin sako mai fita.
- 2 Zabi sako a akwatin sako mai fita
► Duba don karanta shi.

Don rubuta da aika sakon email

- 1 ► Sako ► Email ► Rubuta sabuwa.
- 2 ► Kara don shiga filin mai karbar.
► Shigar.adire.email don buga
adireshin email ► Ok, ko ► Duba
lambobi don zabar mai karba daga
Lambobi ► Zabi, ko zabi adireshin
email daga karshen masu karba
wandanda aka yi amfani da su ► Zabi.

- 3 ► Shirya don kara filin mai karbar
(bayan an kara daya) don kara karin
masu karba. Zabi Zuwa, Cc ko Bcc
kuma zabi masu karba don karawa.
Lokacin da ka zabi masu karba
► Anyi.
- 4 Latsa ⌂ don zabar filin taken, buga
taken email ► Ok. Don shirya taken
► Shirya.
- 5 Latsa ⌂ don zabin filin rubutu, rubuta
sakonka ► Ok. Don shirya sakon
► Shirya.
- 6 Latsa ⌂ don zabar filin hade-haden.
► Kara kuma zabi nau'in hade-haden
don karawa ► Zabi don zabar hade-
haden don karawa. Don kara karin
hade-hade ► Kara.
- 7 ► Ci gaba ► Aika ko Kari ► Ajiy. a
akwt. sako don ajiyewa da aikawa
a gaba.

 Likacin rubuta sa shirya sakonnin email
zaka iya amfani da aikin kwafi da liki
► 42 Don kwafe da lika rubutu a sako.

Don ajiye sakon email

- 1 ► Sako ► Email ► Akw. s. m. shig.
- 2 Zabi sako ► Kari ► Ajiye sako
► Ajajjen email.

Don amsa sakon email

- 1 Zabi sakon acikin akwatin sako mai shigowa don amsawa gareshi ► Kari
► Amsa ko bude sakon ► Amsa.
- 2 ► Ee don hada sakon asalin a amsarka ko ► A'a don fidda sakon asalin daga amsarka.
- 3 Rubuta sakonka a filin rubutu ► Ok.
Don shirya sakon ► Shirya.
- 4 ► Ci gaba ► Aika.

Don duba ko ajiye hade-hade a sakon email

Duba sako ► Kari ► Hade-hade
► Duba don duba abu ko zabar abu don ajiyewa.

Lissafin email mai aiki

Idan kana da lissafin email dayawa, zaka iya canja wanda yake aiki

Don canja lissafin email mai aiki

► Sako ► Email ► Saituna kuma zabi lissafi.

Samun email

Karbi sanarwa a wayarka daga uwar garken email dinka cewa kanada sabon email, idan akwai goyan bayan mai baka email.

Don kunna sanarwar samun email

- Lokacin amfanin aikawa da karba,
► Ee don kunna, in an bukata ko
- ► Sako ► Email ► Saituna. Zabi lissafin don shiryawa ► Kari ► Shirya lissafi ► Babban saituna ► Tura email kuma zabi wani zabi.

Don share sakon email na (POP3)

- 1 ► Sako ► Email ► Akw. s. m. shig.
► Kari.
- 2 ► Alam.na sharewa ko ► Alama a yawanci ► Alama ko Cr. alama.

💡 Za'a share sakonnin da aka sawa alama lokacin da ka kuma hadawa zuwa uwar garkenka.

Don share sakon email na (IMAP4)

- 1 ► Sako ► Email ► Akw. s. m. shig.
► Kari.
- 2 ► Alam.na sharewa ko ► Alama a yawanci ► Alama ko Cr. alama.
- 3 ► Kari ► Shr.akw.sk.m-shg. don share sakoni.

💡 Duk sakonnin da aka sawa alamar sharewa a wayar da kan uwar garke za'a share su.

Abokaina

Hada da kuma shiga zawa uwär garken abokaina don sadarwa a layi tareda abokanka da kafi so. Idan biyan kudinka yana goyan bayan sakon yanzu-yanzu da hallararrun sabis, zaka iya aikawa da karbar sakonni da ganin halin lamba idan akan layi. Idan saituna basu kasance a wayarka ba, kana bukatar shigar da saitunan uwär garke.



Tuntubi mai baka sabis don karin bayani.

Don shigar da saitunan uwär garke

- 1 ► Sako ► Abokai nawa ► Sanya.
- 2 Kara sunan mai amfani, kalmar wucewa, bayanin uwär garke kuma zabi bayanin martaba na Intanit don amfani dashi. Ana kawo bayanin ta mai baka sabis.

Don shiga cikin uwär garken Abokaina

- Sako ► Abokai nawa ► Shiga ciki.

Don fita

- Kari ► Fita daga yana.

Don kara lamba zuwa lissafin

- Sako ► Abokai nawa ► Lambobi shafin ► Kari ► Kara lamba.

Don aika sakon tadi daga abokaina

- 1 ► Sako ► Abokai nawa ► Lambobi shafin kuma zabi lamba daga lissafin.
- 2 ► Tadi kuma buga sakonka ► Aika.
 *Hakanan zaka iya cigaba da maganar tadi daga Tadi shafin.*

Hali

Nuna halinka zuwa lambobi kawai ko nuna shi zuwa duk masu amfani a uwär garken abokaina.

Don saita wanda zai ga halinka

- 1 ► Sako ► Abokai nawa ► Kari
► Saituna kuma zabi Nuna halin nawa.
- 2 Zabi Zuwa duk ko Ga lambo. kawai ► Zabi.

Don canja hali naka

- Sako ► Abokai nawa ► Hali nawa shafin da daukaka bayanin hali naka. Yi amfani ☺ ko ☹ don gungurawa tsakanin halin da filayen.

Kungiyar tadi

Kungiyar tadi zata iya farawa ta mai baka sabis, ta mai amfani na abokaina mutum daya ko ta kai kanka. Zaka iya ajiye kungiyoyin tadi ta ajiye gayyatar tadi ko ta bincika takamammiyar kungiyar tadi.

Don fara kungiyar tadi

- 1 ► Sako ► Abokai nawa ► Kungiyoyin tadi shafin ► Kari ► K. tadi ► Sab. kungiyar tadi.
- 2 Zabi wa zaka gayyata zuwa kungiyar tadin daga lissafin lambobinka ► Ci gaba.
- 3 Shigar da gajeran rubutun gayyata ► Ci gaba ► Aika.

Don kara kungiyar tadi

- 1 ► Sako ► Abokai nawa ► Kungiyoyin tadi shafin ► Kari ► K. tadi.
- 2 ► Ta ID na kungiya don shigar da ID na kungiyar tadi kai tsaye ko ► Bincika don bincika kungiyar tadi.

 An adana tarihin tadi tsakanin fita daga da shiga cikin yana don ya barka ka komo zuwa sakonnin tadi daga tadin daya gabata.

Don ajiye tadi

- Sako ► Abokai nawa ► Tadi shafin kuma bude tadi ► Kari ► Ajye tadi.

Don duba ajiyayyen tadi

- Sako ► Abokai nawa ► Tadi shafin ► Kari ► Aje magana.

Don duba masu amfani masu kallo

- Sako ► Abokai nawa ► Lambobi shafin ► Kari ► Ganin mai aiki. Lissafin masu amfani a uwarr garken abokaina wadanda suke kallon bayanin halinka yana bayyan.

Don duba ko shirya saituna

- Sako ► Abokai nawa ► Kari
► Saituna kuma zabi wani zabi:
 - Nuna halii nawa: Zabi idan duk masu amfani a uwarr garken ko lambobinka kawai zasu ga halinka
 - Jera lambobi: Ta samuwa ko ta haruffa
 - Fadakarwar tadi: Saita halin fadakarwa
 - Saitunan uwarr garke: Saita takardun shaidar shiga
 - Shiga ta atomatik: Saita idan sabis din yakamata yashiga ta atomatik lokacin fara waya
 - Bada izinin hadi: Saita idan sabis din yakamata yashiga ta atomatik lokacin fara waya



Tuntubi mai baka sabis don karin bayani.

Yanki da bayanin cell

Zai yuwu a aika sakonnin bayani zuwa masu biyan kudi na cibiyar sadarwa tsakanin wani yanki ko cell.

Don kunna ko kashe bayani

- Sako ► Saituna ► Bayanin wuri
- Yanayin aiki ko Bayanin Cell.

Hoto

Kamar, bidiyo, shafi, hotuna.

Kamara da mai rikodan bidiyo

Dauki hoto kuma yi rakodin shirye-shiryen bidiyo don ajiyewa, duba kuma aika a sakonni.

Maballan kamara da maballai


Zoko ciki ko waje

Dauki hotuna
Nadi bidiyo



Zabubukan allo
(sama a dama)

Share



Zabubukan allo
(maballi a dama)

Canja kamara/bidiyo ko
Daidaita haske ko

Don daukar hoto ko rikodin bidiyo

- 1 Zabi kamara.
- 2 Yi amfani da maballin kewayawa don canjawa tsakanin kamara da mai rikodin bidiyo
- 3 **Kamara:** Latsa  kasa tsaka-tsaki don amfani juyin madubi ta automatik sannan kasa gabadaya don daukan hoto.
Bidiyo: Latsa  kasa tsaka-tsaki don juyin mudubi ta automatik sannan kasa gabadaya don fara rakodi. Don dakatar da rakodi, latsa  kuma.
- Don daukar wani hoto ko rakodin wani shirin bidiyo, latsa don komawa zuwa mai samfoti.
- Don dakatar da amfani da kamara ko mai rakodin bidiyo kuma koma zuwa jiran aiki, latsa ka rike  ko rufe murfin ruwan madubi.
An ajiye hotuna da shirye-shiryen bidiyo a Mai sarrafa fayil ► Kundin kyamera.



 Idan kayi korarin rakodi tareda cibiyar haske mai karfi kamar hasken rana na kai tsaye ko fitila a bangon baya, allon fuskar zai iya fitar da baki ko hoto zai iya duhu.

Don amfani da zukowa

Yi amfani da maballan kara don zukowa ciki ko waje.

Don dai-dai ta haske

Yi amfani da maballin kewayawa don kara ko rage haske.

Don amfani da juyin madubi ta automatik

Latsa  kasa tsaka-tsaki. Zaka ji sauti in an saita juyin madubi ta automatik cikin firam din da yake bayyana.

Zabubbukan kamara da bodiyo

Lokacin da aka kunna kamara da bodiyo ► Saituna saboda zabubbuka masu biyowa:

- **Switch to video camera** don rakodin shirin bidiyo **Switch to still camera** don daukan hoto.
- **Shoot mode (camera):**
 - Normal – no frame.
 - Panorama – hada hotuna dayawa a cikin daya.

Saitunan kamara

Lokacin da kake a mai samfoti
► **Saituna** saboda zabubbuka don daidaitawa da habaka hotunan ka da shirye-shiryyen bidiyo kafin dauka ko rakodin su.

- **Frames** – kara firam ga hotonka.
- **Fashewa** – dauki hotuna da sauri a jere.
- **Yanayin dauka (Bidiyo)**: Saboda sakon hoto ko Bidiyo mai nagarta.
- **Scenes (kamara)** – zabi daga:
 - **Auto** – saituna ta atomatik.
 - **Twilight landscape** – hoton daji da daddare.
 - **Twilight portrait** – misali, saboda hoton abu da daddare.
 - **Landscape** – hoton daji.
 - **Portrait** – misali, hoton abu.
 - **Beach/Snow** – yi amfani a yanayin hasken wuri, misali, a bakin kogi ko lokacin nutso.
 - **Sports** – yi amfani saboda abubuwa masu motsi da saurin.
 - **Picture size (kamara)** – zabi daga:
 - **2 MP (1632x1224 piksil)**
 - **1 MP (1280x960 piksil)**
 - **VGA (640x480 piksil)**
- **Focus** – zabi daga:
 - **Auto** – juvin madubi ta atomatik saboda rufewa.
 - **Macro** – yi amfani saboda bayanan rufewa.
 - **Infinite** – yi amfani don juvin madubi a duk dajuka.
- **Turn on light** – habaka halayen haske.
- **Kunna yanayin dare (bidiyo)** – dai-dai ta zuwa yanayin haske mara kyau.
- **Turn on self-timer (kamara)** – dauki hoto bayan latsa maballin kamara na sakan kadan.
- **Effects** – zabi daga:
 - **Off** – babu rinjaye.
 - **Black & white** – babu launi.
 - **Negative** – ajiyayyun launuka.
 - **Sepia** – launin ruwan kasa.
 - **Solarize** – fitarwa fiye da yadda yakamatka.
- **Ma'aunin launi** – dai-daita launuka don yanayin haske. Zabi daga Otomatik, Hasken rana, Launin gajimare, Farin haske ko Fitarwa.
- **Ynayin. awon mita** – dai-daita fitarwa don duk ko don tsakiyan hoton ko bidiyo. Zabi daga **Na al'ada ko Waje**.
- **(kamara): Da kyau ingancin hoto.**
- **Kashe makarufo (bidiyo)** – saita makirufo.
- **Sautin dauka (kamara)** – zabi sautunan dauka dabamdban.
- **Kunna lokaci da rana (kamara)** – kara lokaci da kwanan wata a hoto don bayyana azaman koren rubutu a kusurwar dama ta kasa. Duba cikin girman 1:1 ko yi amfani da zukowa lokacin duban hoto don ganin rubutu.
- **Ajiye zuwa** – zabi don ajiyewa zuwa **Memory Stick** ko **Kwakwa. ajiyar waya**.

Gajern hanyoyi na kamara

Lokacin amfani da kamara, zaka iya kuma amfani da maballai azaman gajerun hanyoyi zuwa zaibubuka. Latsa don jagorar maballin kamara.

Canja wurin hotuna

Canja wuri zuwa kwamfutarka

Amfani da kebul na USB, zaka iya tura da sauke hotunan kamara zuwa kwamfuta ➡ 74 *Canja wurin fayiloli ta amfani da kebul na USB*.

Don amfani na gaba da shirya hotunan kamara kan kwamfuta, masu amfani da Windows® zasu iya shigar da Adobe™ Photoshop® Album Starter Edition, wanda aka hadashi da CD tareda waya ko ziyarci www.sonyericsson.com/support.

Shafi a kan itanit

Aika da hotuna don yada su a shafi Idan biyan kudinka yana goyan bayan wannan.

Sabis na yanar sadarwa zai yiwu ya bukaci warerren lasisin yarjejeniya tsakanin ka da mai bada sabis. Cikin wasu wurare, karin dokoki da/ko caji maiyuwa ya zartu. Don karin bayani, tutubi mai baka sabis.

Don aika hotunan kamara zuwa shafi

- 1 Lokacin duban hoton da kadauka yanzu-yanzu ► **Kari** ► **Yi Blog** wannan.
- 2 Bi umarni wadanda suka bayana a farkon lokacin amfani, misali, tabbarat da sharudda da halaye.
- 3 Kara take da rubutu ► **Ok** ► **Yada** don aika hoto zuwa blog naka.
An aika sakon rubutu zuwa wayarka tareda adireshin yanar sadarwa da bayanin shiga cikin yana. Zaka iya tura sakon rubutun ga wasu don samun damar hotunan dakin yanar sadarwarka.

Don aika hotuna zuwa blog

- 1 ► **Mai sarrafa fayil** don zabin hoto a babban fayil.
- 2 ► **Kari** ► **Aika** ► **Zuwa blog**.
- 3 Kara take da rubutu ► **Ok** ► **Yada**.

Don ziyartar adresheen shafi a lamba

► **Lambobi** kuma zabi adresheen lambar yanar sadarwa ► **Je zuwa**.

Fitar kundin kamara

An ajiye hotunan kamara a ► **Mai sarrafa fayil** ► **Kundin kyamera**. Zaka iya fitarda hotunan kundin kamara a wayarka ta hanyar kebul na USB wanda aka hada shi zuwa firintar da

ta dace na PictBridge™. Kuma zaka iya ajiye hotuna zuwa Memory Stick Micro™ (M2™) kuma ka fitar da su daga baya, idan firintarka tana goyan baya wannan.

 **Kuma zaka iya wankewa ta firintar Bluetooth wacce ta dace.**

Don duba hotun'an kamara naka

- 1 ► Mai sarrafa fayil ► Kundin kyamera.
- 2 Ana nuna hotuna a takaitaccen dubawa. Saboda cikakken duba hoto
► **Duba.**

Don wanke hotun'an kamara ta USB

- 1 ► Mai sarrafa fayil ► Kundin kyamera.
- 2 ► Kari ► Alama ► Alama a yawanci ko Alm. duk hotuna don wankewa.
- 3 ► Kari ► Fitar kuma bi umarni.
- 4 Hada kebul na USB zuwa wayar.
- 5 Connect the USB cable to the printer.
- 6 Jira saboda amsa a wayar ► **Ok.**
- 7 Saita saitunan firinta, in an bukata
► **Fitar.**

 **Cire hadi kuma sake hada kebul na USB idan akwai kuskuran firinta.**

Don wanke hotun'an kamara ta USB

- 1 Bincika takradon firinta saboda bayani akan saituna, katin kwakwalwar ajiya da goyan bayan PictBridge.

2 Lokacin duba hotun'an kamara wadanda aka ajiye kan katin kwakwalwar ajiya, ► **Kari ► Alama ► Alama a yawanci ko Alm. duk hotuna don wankewa.**

- 3 ► **Kari ► Fitar ► DPOF (M.S.) ► Ajiye.** An kirkiri kuma na ajiye fayil na umarnin wankewa (DPOF) kan katin kwakwalwar ajiya.
- 4 Cire katin kwakwalwar ajiya daga wayarka kuma sa shi cikin gurbin katin kwakwalwar ajiya a firintarka.
- 5 Bi umarnini mai bayyana kan firintar da takardun firintar.

Hotuna da shirye-shiryen bidiyo

Duba kuma yi amfani da hotuna da shirye-shiryen bidiyo.

Boye hotuna

Duba, kara, shirya ko share hotuna a mai sarraf fayil. Adadin hotun'an da zaka iya ajiywya ya dogara da girman hotun'an. Nau'ukan fayil masu goyan baya sune, misali, GIF, JPEG, WBMP, BMP, PNG da SVG-Tiny.

Don duba da amfani da hotuna

- 1 ► Mai sarrafa fayil ► Hotuna.
- 2 Zabi hoto ► **Duba ko ► Kari ► Yi amfn. azaman kuma zabi wani zabi.**

Don nuna hotuna a nunin majigi

- 1 ► Mai sarrafa fayil ► Hotuna kuma zabi hoto.
- 2 ► Duba ► Kari ► Nunin faifai.

Don duba bayani gameda fayil

- 1 ► Mai sarrafa fayil ► Hotuna ko Bidiyo, zabi fayil.
- 2 ► Kari ► Bayani.

Amfani da hotuna

Kara hoto zuwa lamba, yi amfani da shi yayin fara waya, azaman fuskar bangon waya a jiran aiki ko azaman uwarr garken allo.

 Rayarwa na fiye da 1MB wanda aka saita azaman fuskar bangon waya maiyuwa ya rinjayi aiki.

Allon uwarr garke

An kunna allon uwarr garke ta atomatik lokacin wayar ta daina aiki na sakan kadan. Bayan wasu yan karin sakan, allon uwarr garken yana canjawa zuwa yanayin barci don ajiye wuta. Latsa kowane maballi don sake kunna allon.

Don shirya hotuna

► 54 PhotoDJ™.

Musayan hotuna

Zaka iya musanya hotuna ta amfani da dayan wadatattun hanyoyin canja wuri. Kula ba'a yarda ka musanya wasu abubuwa masu kariyar hakkin mallaka ba. Saboda karin bayani kan hotuna a sakonni ► 36 Sako.

Don aika hoto

► Mai sarrafa fayil ► Hotunakuma gungura zuwa hoto. ► Kari ► Aika kuma zabi hanyar canja wuri.

 Wasu wayoyi basa goyan bayan girman hoto fiye da fiksil 160 x 120.

Don karbar hoto

► Saituna ► Haduwa kuma zabi hanyar canja wuri

Don ajiye hoto a sako

- 37 Don ajiye abu a sakon rubutu ko
- 41 Don ajiye abu a sakon hoto ko
- 45 Don duba ko ajiye hade-hade a sakon email.

Ajiye hotuna da shirye-shiryen bidiyo

Lokacin da ka dauki hoto ko yin rikodin shirin bidiyo, wayar tana ajiye shi a kwakwalwar ajiyar waya ko kan Memory Stick Micro™ (M2™), idna an sa.

Idan kwa'kwalwar ajiyar waya ko Memory Stick Micro™ (M2™) sun cika, ba zaka iya ajiye wani karin hotuna ko shirye-shiryen bidiyo ba har sai ka share ko matsar da fayiloli

► 19 Mai sarraf fayil.

Aika hotuna da shirye-shiryen bidiyo

Lokacin da ka d'auki hoto ko ka nad'i shirin bidiyo, zaka iya aika su azaman sakon hoto idan girman fayil din bai wuce iyaka ba. Don musanya hotuna da shirye-shiryen bidiyo ta amfani da wasu hanyoyin canja wuri

► 53 Musanya hotuna.

Don amfani da karin zabubukan shirin bidiyo ko hoto

Nadi shirin bidiyo ko d'auki hoto ► Kari kuma zabi wani zabi, misali, don d'aukan sabon hoto.

Canja hotuna zuwa kwamfutarka

Amfani da kebul na USB, zaka iya tura da sauke hotunan kamara zuwa kwamfuta ► 74 Canja wurin fayiloli ta amfani da kebul na USB.

Allon ramut

Yi amfani da na'urar hadi wacce ta dace ta Bluetooth™ don duba allo mai nisa kaman TB. Ba'a sanya na'urar hadi a wayarka ba. Don cikakken lissafi na na'urorin hadi wadanda suka dace, je zuwa www.sonyericsson.com/support don saukarda shi.

Don hadi zuwa allon ramut

► Mai sarrafa fayil ► Hotuna ► Duba ► Kari ► Allon nisa. ► 72 Don kara na'ura zuwa wayarka.

PhotoDJ™

Shirya hotuna ta amfani da PhotoDJ™.

Don shiryawa da ajiye hoto

- 1 ► Nishadi ► PhotoDJ™ ko ► Mai sarrafa fayil ► Hotuna kuma zabi fayil ► Kari ► Shir.y.a PhotoDJ™.
- 2 Zabi wani zabi.
- 3 Bayan ka shirya zabebben hoto ► Kari ► Ajiye hoto.

Jigogi

Canja bayyanar allon, misali ta cikin abubuwa kaman launuka da allon fuskar waya, ta amfani da jigogi. Wayarka tana da wasu jigogi wadanda aka ayyana ba za'a iya sharesu ba in an karesu. Zaka iya kirkiro sabbin jigogi da saukar da su zuwa wayarka. Don karin bayani, ziyarci www.sonyericsson.com/support.

Don zabi ko canja jigogi

- Mai sarrafa fayil ► Jigogi kuma zabi jigo.

Musanya jigogi

Musanya jigogi ta amfani da hanyar canja wuri.

Don aika jigo

- 1 ► Mai sarrafa fayil ► Jigogi kuma zabi jigo.
- 2 ► Kari ► Aika kuma zabi hanyar canja wuri.

Don karba da ajiye jigo

- 1 Yi amfani da hanyar canja wuri kuma bude sakon da ka karbi jigon ta shi.
- 2 Bi umarnin dake bayyana.

Nishadi

Abin sawa akunni, mai kunna Walkman®, mai kunna Bidiyo, TrackID™, PlayNow™, sautunan ringi MusicDJ™, VideoDJ™, sautin rikoda, wasanni, aikace-aikace.

Abin sawa a kunni mai daukuwa na siteriyo



Don amfani da abin sawa akunni

Hada abin sawa akunni na sitreyo ma daukuwa zuwa wayarka don amfani da shi saboda kira, sauraran kida, bidiyo ko rediyo. Idan ka karbi kira kuma an kunna kida, kida yana tsayawa da baka dama don amsa kira. Kida zai ci gaba lokacin da kiran ya kare ko aka ki karba.

Mai kunna Walkman® da mai kunna bidiyo

Wayarka tana goyan bayan, misali nau'ukan fayiloli masu biyowa: MP3, MP4, M4A, 3GP, AAC, AAC+, Enhanced AAC+, AMR, MIDI, IMY, EMY, WAV (16 kHz iyakan girman kima mai sauki) da Real®8. Hakanan kuma wayarka tana goyan bayan jeren fayiloli wadanda suka dace da 3GPP.

Don kunna bidiyo

- 1 ► Nishadi ► **Kayan bidiyo**. Mai lilon mai kunnawa ya bude.
- 2 Yi lilo saboda shirye-shiryen bidiyo kuma sawa take almar haske
► **Kunna**.
Zabubbuka masu biyowa akwaisu :
 - ◎ don tsaida sake kunnawa. Sake latsawa don cigaba da kunnawa.
 - Latsa ◎ don zuwa shirin bidiyo na gaba.
 - Latsa ◎ don zuwa shirin bidiyo wanda yawuce.
 - Latsa ka rike ◎ ko ◎ don sauri gaba ko baya lokacin kunna shirye-shiryen bidiyo.
 - Lokacin kunna shirin bidiyo, ► **Kari** saboda zabubbuka.
 - Latsa ka rike ◎ don fita.

Don kunna kida

- 1 ► **WALKMAN**. Mai lilon mai kunna Walkman® yana bude.
- 2 ► **Kari** ► **Kida na** don lilo ta yan wasa, Kundi, Waka ko Lissafin waka ko
► **Kunna** to listen to all your tracks in a play queue.
Zabubbuka masu biyowa akwaisu :
 - ◎ don tsaida sake kunnawa. Sake latsawa don cigaba da kunnawa.
 - Latsa ◎ don zuwa waka ta gaba.
 - Latsa ◎ don zuwa wakar da ta gabata.
 - Latsa ka rike ◎ ko ◎ don tura waka gaba ko baya da suri.
 - Lokacin kunna waka, ► **Kari** saboda zabubbuka.
 - Latsa ka rike ◎ don fita.

Canja wurin kida

Software na kwamfutar wayar disc2 da akwaturan USB an hada su a CD wanda ya zo tare da wayar ka. Yi amfani da Disc2Phone don canja kida daga CD ko kwamfutar ka zuwa kwakwalwar ajiyar wayar ko katin kwakwalwar ajiya a wayarka.

Kafin ka fara

Masu biyowa sune mafin karancin tsarin aiki da ake bukata saboda amfani da Disc2Phone a kwamfutarka:

- Windows 2000 SP4 ko
- XP Home, ko XP Professional SP1.

Don shigar da Disc2Phone

- 1 Kunna kwamfutarka kuma saka CD wanda yazo tareda wayarka ko ziyci www.sonyericsson.com/support don sauke aikace-aikacen Disc2Phone. CD yana farawa ta atomatik kuma window na shigawa yana budewa.
- 2 zabi yare kuma kada Yayi.
- 3 Kada shigar da Disc2Phone kuma bi umarni.

Don amfani da Disc2Phone

- 1 Hada wayar zuwa kwamfuta tareda kebul na USB wanda ya zo tareda wayarka kuma zabi [Cnj. wur.fayil.](#) Wayar tana kashewa kuma tana shiryawa don canja wurin fayiloli. Don karin bayan ➡ 74 Canja wurin fayiloli ta amfani da kebul na USB.
- 2 **Kwamfuta:** Fara/Shirye-shirye/Disc2Phone.
- 3 Don cikakken bayani kan canja wurin kida, koma zuwa taimako na Disc2Phone. Kada ? a kusurwar sama ta dama na Disc2Phone window.

💡 *Kada a cire kebul na USB daga wayar ko kwamfuta yayin canja wuri, saboda wannan maiyuwa ya lalata katin kwakwalwar ajiyar. Baza ka iya duba fayilolin da aka canja masu wuri ba a wayarka harsai ka cire kebul na USB daga wayar.*

Zaka iya samun bayanin CD (dan wasa, waika da haka na hudu.) ta Disc2Phone idan an hada ka da Intanit kuma ana cire kida daga CD.

💡 *Don amintaccen cire hadin kebul na USB a yanayin canja wurin fayil, kada-daman gunkin disk mai curuwa a mai bincika® Windows kuma zabi cirewa.*

Karin bayani bisaga matsawa da fayiloli zuwa katin kwakwalwar ajiya wacce akwaita a www.sonyericsson.com/support.

Don canja wurin fayiloli tareda kebul na USB wanda aka bayar

➡ 74 Canja wurin fayiloli ta amfani da kebul na USB.

Yin illo da fayiloli

Yi lilon fayilolin kida da shirin bidiyo:

- **Yan wasa** – lissafin fayilolin kida ta danwasa.
- **Kundaye** – lissafin fayilolin kida ta kundi.

- **Wakoki** – lissafin fayilolin kida (ba sautunan ringi ba) a wayarka kan katin kwakwalwar ajiya.
- **Lissafin waka** – kikiri ko kunna lissafinka na fayilolin kida.
- **Tash. kan layi** – lissafin alamun littafi saboda gudanar bidiyo da kida.

Lissafin waka

Don shirya fayilolin mai jarida ajiyayyu a mai sarrafa fayil, zaka iya kirkirar lissafin waka. Zaka iya kara fayil zuwa fiye da lissafin waka daya.

Lokacin da ka share lissafin waķa ko fayil daga lissafin waķa, ainihin fayil din waķar ko bidiyo ba'a share su ba daga kwakwalwar ajiyar, lissafin waķar ya danganta zuwa gare su kawai. Zaka kuma iya kara fayil zuwa wani lissafin waka.

Don kirkirar lissafin waka

- 1 ► **WALKMAN** ► **Kari** ► **Kida na**
 ► **Lissafin waka** ► **Sabon liss.waka**
 ► **Kara**. Shigar da suna ► **Ok**.
- 2 zabi daga fayilolin samammu a cikin mai sarrafa fayil. Zaka iya kara fayiloli da yawa a lokaci kuma zaka iya kara manyan fayiloli. Duk fayilolin da suke cikin zababbun mayan fayiloli za'a kara su zuwa lissafin waka.

Don kara fayiloli zuwa lissafin waka

- 1 ► **WALKMAN** ► **Kari** ► **Kida na**
 ► **Lissafin waka** zabi lissafin waka
 ► **Bude** ► **Kari** ► **Kara mai jarida**.
- 2 Zabi daga fayilolin samammu a mai sarrafa fayil.

Don cire fayiloli daga lissafin waka

- 1 ► **WALKMAN** ► **Kari** ► **Kida na**
 ► **Lissafin waka** zabi lissafin waka
 ► **Bude**.
- 2 Zabi fayil din kuma lasta **(c)**.

Don share lissafin waka

- **WALKMAN** ► **Kari** ► **Kida na**
 ► **Lissafin waka** zabi lissafin waka kuma latsa **(c)**.

WALKMAN zabubbuka

- **Kari** don **zabubbuka**:
- **Kida na** – yi lilon fayilolin kida.
- **Saituna** saboda mai biyowa:
- **Yanayin** **kunnawa** – canja tsarin sake **kunnawa** na **wakoki**. Zabi **Lale** don kunna lissafin waka a da **ka Loopmaimaitawa** don sake fara lissafin waķar lokacin da aka kunna waķar karke.
- **Mai** **ddt st.** – canja **saitunan** daga da rage sauti.

- **Fadada siteriyo** – canja fitar sautin.
 - **Yiwuan gani** – canja kwatanci don yarakka kidar.
 - **Jikuna** – canja launin bango.
- **Fayil** saboda masu biyowa:

- **Aika** – aika fayil na kida ko shirin bidiyo.
- **Bayani** – duba bayani bisaga fayil na yanzu.
- **Share** – cire fayil. An cire lissafin waka wanda ka kirkira kawai dangane da fayil dín. Acikin **Wakoki lissafin**, an share fayil dín har abada daga kwakwalwar ajyar.

- **Aje lissafin waka** – kirkiri lissafin waka naka.
- **Rage girma** – rage girman mai kunna kida da komawa zuwa jiran aiki tareda kuma kida akunne.

Kidan kan layi da bidiyo

Duba bidiyo da sauraren kida ta jera su zuwa wayarka daga Intanit. Idan dama babu saitunan a wayarka
 ➔ 65 Saituna. Saboda Karin bayani, tuntubi mai sa aiki na cibiyar sadarwaka ko ziyci
www.sonyericsson.com/support.

Don zabar lissafin bayanai don jerin gwano

- Saituna ► Haduwa shafin
- Saitunan yawo kuma zabi lissafin bayanai don amfani.

Don jera bidiyo da mai juwuwa

- 1 ► Intanit ► Kari ► Je zuwa ► Shigarda adireshi.
- 2 Shigar ko zabi adireshin dakin yanar sadarwa kuma zabi hanyar hadi don yin jere daga. Mai kunnawa yana budewa ta atomatik lokacin da aka zabi hanyar hadi.

TrackID™

TrackID™ sabis ne na shaidar kida kyauta. Zaka iya bincika take ta atomatik, dan wasa da sunayen kundi gameda wakar da kake ji akunne ta lasifikasi ko akunne a rediyo. Babu TrackID™ a duk kasashe.

Don bincika bayanin waka

- ► TrackID™ lokacin da kake jin waka.
- ► Kari ► TrackID™ lokacin da ka ji waka akunne a redyon.



Don bayani farashi, tuntubi mai baka sabis.

Rediyo

Saurari rediyon FM. Hada abin sawa akunni zuwa wayar yayin da yake aiki azaman eriya.

 *Kada kayi amfani da wayar azaman radiyo a wuraren da aka hana.*

Don sauraron rediyo

Hada abin sawa akunni zuwa wayarka
► Nishadi ► Rediyo.

Ikon rediyo

- **Bincika** don mitar yada labarai.
- Latsa  ko  don motsa 0.1 MHz.
- Latsa  ko  don saitattun tashoshi.
- **Kari** don zabubbuka.

Ajiye tashoshin rediyo

Ajiye har zuwa saitattun tashoshi 20.

Don ajiye tashoshin radiyo

► Nishadi ► Rediyo saita mitar ► Kari
► Ajiye ko latsa ka rike  +  9
don ajiyewa awuri 1 zuwa 10.

Don zabin tashoshin radiyo

Yi amfani da maballin kewayawa ko latsa  +  9 don zabin ajiyayyen tasha a wuri 1 zuwa 10.

Zabubbukan radiyo

► **Kari** don zabubbuka masu biyowa:

- **Kashe** – kashe rediyon.
- **Ajiye** – ajiye mitar yanzu a wuri.
- **Tashoshi** – zabi, sake sa suna, maye gurbii, ko share saitacciyar tasha.
- **Ajiyar atomatik** – zabi tashoshi masu waka a wuri 1 zuwa 20. Ana maye gurbin ajiyayyun tashoshin da suka gabata.
- **TrackID™** – bincika sunan dan waya da sunan take ta atomatik don wakar da take akunne a rediyo yanzu.
- **Kunna lasifika** – yi amfani da lasifikar.
- **Saita mita** – shigar da mita da hannu. Latsa  -  don tafiya kai tsaye zuwa **Saita mita**.
- **RDS** – saita zabubbuka don maimakon mita (AF) da bayanin tasha.
- **Kunna Mono** – kunna sautin mono.
- **Rage girma** – koma zuwa jiran aiki don amfani da wasu ayyuka lokacin amfani da rediyo.

Don dai-daita karar

Latsa maballan kara don dada ko rage kara.

PlayNow™

Saurari kida kafin ka saya da sauke shi zuwa wayarka.



Wannan aikin cibiyar sadarwa ne- ko dogaron mai sa aiki. Tuntubi afaretan cibiyar sadarwaka don bayani gameda biyan kudinka da PlayNow™. A wasu kasashe zai yiwu ka iya sayan karin kida daga wasu manyan yan wasan kida na duniya.

Babu wannan sabis din a duk kasashe.

Kafin ka fara

Idan babu saitunan da ake bukata a wayarka ► 65 Saituna.

Don sauraron kidan PlayNow™

► PlayNow™ kuma zabi kida daga lissafi.

Saukewa daga PlayNow™

Farashin yana bayyana lokacin da ka zabi saukewa da ajiyewa a fayil na kida. Lissafin wayarka ko katin da ba'a biya ba bashine lokacin da aka karbi saye. Hakanan ana bada sharudda da halaye cikin kwalin waya.

Don sauke fayil na kida

- 1 Lokacin da ka saurari samfotin fayil na kida, zaka iya yarda ka karbi sharuddan ► Ee don saukewa.
- 2 Ana aika sakon rubutu don tabbatar da biya kuma akwai fayil da akayi don saukewa. An ajiye kida a Mai sarrafa fayil ► Kida.

Sautunan ringi da karin waka

Zaka iya musanya kida, sautuna da wakoki, misali, ta amfani da dayan samammun hanyoyin canja wuri.

Ba'a yarda ka musanya wani abin hakkin mallaka mai tsaro ba. Fayil na hakkin mallaka mai kariya yana da alamar maballi.

Don zabar sautin ringi

- Saituna ► Sauti & fadakarwa shafin
- Sautin ringi.

Don kunna ko kashe sautin ringi

Latsa ka rike daga jiran aiki ko
► Saituna ► Sauti & fadakarwa shafin saboda zabubbuka. Ana rinjayar duk sigina banda na kararrawa.

Don saita karan sautin ringi

- 1 ► Saituna ► Sauti & fadakarwa shafin
► Karar ringi kuma latsa ☺ ko ☺ don rage ko tada karan.
- 2 ► Ajye.

Don saita fadakarwar jijigaru

- Saituna ► Sauti & fadakarwashafin
- Fadakarwar jijiga kuma zabi wani zabi.

Sautuna da zabubbukan fadakarwa

Daga Saituna ► Sauti & fadakarwa shafin, zaka kuma iya saita:

- **Fadakarwar sako** – zabi yadda za'a sanar da kai sako mai shigowa.
- **Sautin maballi** – zabi wane sauti don ji lokacin da ka latsa maballai.

MusicDJ™

Daidaita ka shirya karin wakokinca don amfani dasu azaman sautunan ringi. Karin waka ya kunshi nau'ukan wakoki huđu – **Ganga, Basses, Chords**, kuma **Launin harshe**. Waka tana dauke da adadin tubalan kida. Tubalan sun kunshi sautuna da aka riga aka shirya tareda kalmomi dabon-daban. An tattara tubalan cikin **Gabatarwa, Aya, Chorus**, kuma **Hutu**. Kana shirya karin waka ta kara tubalan kida zuwa wakokin.

Don shirya karin waka

- 1 ► Nishadi ► MusicDJ™.
- 2 ► Sa, Kwafi ko Manna tobalilluka. Yi amfani da ☺, ☺, ☺ ko ☺ don motsawa tsakanin tubalan. Latsa ☺ don share tubali. ► **Kari** don duba karin zabubbuka.

Don shirya launin wakar MusicDJ™

- Mai sarrafa fayil ► **Kida** kuma zabi karin wakan ► **Kari** ► **Shiryia**.

Musanya karin wakokin MusicDJ™

Aika kuma karbi karin wakoki ta amfani da dayan wadatattun hanyoyin canja wuri. Ba'a yarda ka musanya abu wanda keda kariyar hakkin mallaka ba.

 *Baza ka iya aika sautunan karin waka ko fayil na MP3 a sakon rubutu ba.*

Don aika karin waka

- 1 ► Mai sarrafa fayil ► **Kida** kuma zabi karin waka.
- 2 ► **Kari** ► Alikakuma zabi hanyar canja wuri.

Don karbar karin waka ta amfani da hanyar canja wuri

Zabi hanyar canja wuri kuma bi umarnin dake bayyana.

VideoDJ™

Daidaita kuma shirya shirin bidiyo naka ta amfani da shirin bidiyo, hotuna da rubutu. Zaka kuma iya datse bangarori na shirin bidiyo don gajarta shi.

Don kirkirar shirin bidiyo

- 1 ► Nishadi ► VideoDJ™.
- 2 ► Kara ► Shirin bidiyo, Hoto, Rubutu ko Kamara ► Zabi.
- 3 Don dada karin abubuwa latsa ◎
► Kara.

Don shirya zababben shirin bidiyo

► **Shirya** don zabubbuka:

- Gyara – don gajarta shirin bidion.
- Kara rubutu – kara rubutu zuwa shirin bidiyo.
- Share – don cire shirin bidion.
- Matsar – don matsar da shirin bidiyo zuwa wani wuri.

Don shirya zababben hoto

► **Shirya** don zabubbuka:

- Tsawon lokaci – don zabar lokacin nuna hoton.
- Share – don cire hoton.
- Matsar – don matsar da hoton zuwa wani wuri.

Don shirya zababben rubutu

► **Shirya** don zabubbuka:

- Shirya rubutu – don canja rubutun.
- Launuka – kuma zabi **Bango** baya don saita bango ko Launin rubutu don saita launin rubutu.
- Tsawon lokaci – don zabar lokacin nuna rubutun.
- Share – don cire rubutun.
- Matsar – don matsar da rubutun zuwa wani wuri.

Zabubbukan VideoDJ™

► **Kari** don zabubbuka:

- Kunna – don duba shirin bidion.
- Aika – don aika shirin bidion.
- Wakr. shiri. bidy. – don kara sautin waka zuwa shirin bidion.
- Canji – don saita sauyawa tsakanin shirin bidiyo, hotuna da rubutu.
- Ajiye – don ajiye shirin bidiyo.
- Sa – don saka sabon shirin bidiyo, hoto ko rubutu.
- Sabuwar bidiyo – don kirkirar sabon shirin bidiyo.

Don shirya shirin bidiyo a mai sarrafa fayil

- 1 ► Mai sarrafa fayil ► Bidiyo ► Bude kuma zabi fayil.
- 2 ► Kari ► VideoDJ™ ► Shirya.

Aikawa da shirin bidiyo

Zaka iya aikawa da shirin bidiyo ta amfani da dayan wadatattun hanyoyin canja wuri. Za'a iya aika gajeran shirin bidiyo ta amfani da sakon hoto. Idan shirin bidiyo yayi tsawo da yawa, zaka iya amfani da aikin datsawa don gajarta shirin bidiyo.

Don datse shirin bidiyo

- 1 Zabi shirin bidiyo daga allon alabari
► **Shiryा** ► **Gyara**.
- 2 ► Saiti don saita wurin farawa kuma
► **Fara**.
- 3 ► Saiti don saita wurin karewa kuma
► **Kare**.
- 4 Maimaita taku 2 da 3 ko ► **Anyi**.

Mai rikodin sauti

Tareda mai rikodin sauti, zaka iya yin rikodi, misali, memo na murya ko kira. Hakanan za'a iya saita sautin da akayi rikodi azaman sautunan ringi. Rikodin tadi yana tsayawa idan dan takara ya tsaida kiran. Rikodin duk sautuna yana tsayawa ta atomatik idan ka karbi kira.

 A wasu kasashe ko jahohi doka ta bukaci cewa ka sanar da mutumin kafin yin rikodin kira.

Don yin rikodin sauti

- 1 ► Nishadi ► **Yi rikodin sauti**.
- 2 Jira har sai kaji sauti. Lokacin da rikodi yafara, **Rikodi** kuma mai kidaya lokaci ya bayyana.
- 3 ► **Ajiye** don karewa.
- 4 ► **Kunna** don sauraro ko ► **Kari** don zabububuka: **Yi rikodin sabo**, **Aika**, **Sake suna**, **Share**, **Sautinan** da akayi rikodi.

Don sauraron rikodi

- **Mai sarrafa fayil** ► **Kida** kuma zabi yin rakodi ► **Kunna**.

Wasanni

Wayarka tana kunshi wasanni da yawa. Zaka kuma iya saukar da wasanni da aikace-aikace kai tsaye zuwa manyan fayiloli a wayarka. Akwai rubutun taimako don yawancin wasannin.

Don fara da kare wasa

- 1 ► Nishadi ► **Wasanni**, **zabi wasa**
► **Zabi**.
- 2 Latsa ka rike  don kare wasan.

Aikace-aikace

Saukar ka gudanar da aikace-aikacen Java™, misali, don amfani da sabis. Kuma zaka iya duba bayani ko saita matakan izini daban-daban.

Don duba bayani saboda aikace-aikacen Java™

- 1 ► Mai sarrafa fayil ► Aikace-aikace ko ► Wasanni.
- 2 Zabi aikace-aikace ko wasa ► Kari ► Bayani.

Don saita izini saboda aikace-aikacen Java

- 1 ► Mai sarrafa fayil ► Aikace-aikace ko ► Wasanni.
- 2 Zabi aikace-aikace ko wasa ► Kari ► Izinoni kuma saita zabubbuka.

Girman allon aikace-aikacen Java

An tsara wasu aikace-aikacen Java don takamaiman girman allo. Don karin bayani, tuntubi dillalin aikace-aikacen.

Don saita girman allo don aikace-aikacen Java

- 1 ► Mai sarrafa fayil ► Aikace-aikace ko ► Wasanni.
- 2 Zabi aikace-aikace ko wasa ► Kari ► Girman allo kuma zabi wani zabi.

Hadi

Saituna, Intanit, RSS, aiki tare, fasahar Bluetooth™, Kebul na USB, daukaka sabis.

Saituna

Zai yiwu anriga an shigar da saituna lokacin da ka sayi wayarka. Idan bahaka ba, tabbatar kana da aiki tare na waya wanda yake goyan bayan canja wurin bayanai (GPRS).

Zaka iya saukar da saituna zuwa wayarka saboda lilon itanit, email da sakon hoto. Za'a iya yin wannan ta saita mayen a wayarka ko daga kwamfuta a www.sonyericsson.com/support.

Don sauke saituna ta wayarka

- Saituna ► Gaba daya shafin ► Saita maye ► Saukar da saituna kuma bi ummurnin dake bayana.

Don sauke saituna ta kwamfuta

- 1 Yi liro zuwa www.sonyericsson.com/support.
- 2 Zabi yanki da kasa.
- 3 Zabi shafin saita wayar, kuma zabi samfur na waya.
- 4 Zabi wane saiti don saukewa zuwa wayarka.

Amfani da intanit

Yi amfani da intanit don samun damar sabis na kan layi misali, labarai da banki, bincika kuma yi lilon yanar sadarwar.

Don fara lilo

- Intanit kuma zabi sabi kamar
- Kari ► Je zuwa ► **Binciken intanit** ko Shigarda adireshi zuwa kowace yanar sadarwa.

Don duba zabubbuka

- Intanit ► Kari.

Don tsaida lilo

- Kari ► Fita mai lilo.



Saboda karin bayani tuntubi mai sa aikin cibiyar sadarwarka ko ziyarci
www.sonyericsson.com/support.

Zabubbuka lokacin lilo

► **Kari** don duba zabubbuka. Menu yana kunsar masu biyowa amma ya dogara da dakin yanar sadarwar da kake ziyyarta:

► **Ciyarwa RSS** – zabi wadatattun ciyarwa saboda shafin yanar sadarwa.

► Je zuwa saboda masu biyowa:

- Sony Ericsson – Je zuwa saatin zauren gidan yana wanda aka ayyana don bayanin martaba na yanzu.
- Alamomin shafi – kirkiri, yi amfani da ko shirya alamun shafi zuwa dakunan yanar sadarwa.
- Shigarda adireshi – shigar da adireshin dakin yanar sadarwa.
- **Binciken intanit** – yi amfani da Google don bincike.
- Tarihi – lissafin dakunan yanar sadarwa wadanda aka riga aka ziyyarta.
- Aje shafi – lissafin ajiyayyun dakunan yanar sadarwa.

► Kayan aiki saboda masu biyowa:

- Kara alamar shafi – kara sabuwar alamar shafi.
- Ajiye hoto – ajiye hoto.
- Ajiye shafi – ajiye dakin yanar sadarwa na yanzu.
- Sak. maimait.shafi – maimaita dakin yanar sadarwar na yanzu.
- Aika hanyar hadi – aika hanyar hadi zuwa dakin yanar sadarwa na yanzu.
- Yi kira – yi kira lokacin yin lilon Intanit. ► Kari ► **Kas.kira** don kare kira da cigaba da lilo.

► **Duba saboda mai biyuwa:**

- Cika fuska – zabi allo na al'ada ko cikakke. Kula Akwai cikakke/na al'ad kawai tareda hotom mutum.
- Hoton mutum – yana wadata lokacin da nunin yake a yanayin daji.
- Daji, yanayin fili – zabi yanayin allon daji.
- Rubutu kawai – zabi cikakken abun ciki ko rubutu kawai.
- Zukowa – zoko ciki ko waje kan shafin yanar sadarwa.
- Zuko zu.na al'ada – saita zakowa zuwa tsohuwa.

► **Zabubbuka ► Lilo shfin saboda:**

- Smart-Fit – daidaita gidan yanar sadarwa zuwa allon.
- Nuna hotuna – saita akunne ko akashe.
- Nuna rayarwa – saita akunne ko akashe.
- Kunna sautina – saita akunne ko akashe.
- Izinin cookies – saita akunne ko akashe.
- Ynyi. faifan mabal. – zabi daga Gajerun hanyoyi don maballan mai lilo ko Maballan shiga don kewayawar gidan yanar sadarwa mafi sauri, idan akwai.

► **Zabubbuka ► Wasu shafin saboda:**

- Share cookies
 - Share ma'ajiyi
 - Shre. kalmr. wcew.
 - Hali – nuna bayanin hadi.
- **Fita mai lilo don cire hadi.**

Amfani da alamun shafi

Yi amfani, kirkiri kuma shirya alamun shafi azaman hanyar hadi mai sauri zuwa shafin yanar sadarwar da kafi so.

Don aiki tareda alamun shafi

- 1 ► Intanit ► Kari ► Je zuwa ► Alamomin shafi kuma zabi alamar shafi ► Kari.
- 2 Zabi wani zabi, kamar aika alamar shafi azaman sakon rubutu.

Gajerun hanyoyi na intanit

Lokacin amfani da itanit, zaka iya amfani da gajeron hanyoyin faifan maballi zuwa zabubbukan menu.

Don amfani da gajerun hanyoyin faifan maballin intanit ko samun damar maballai

- 1 Lokacin lilo, latsa ka riķe (#-#) don zabi Gajerun hanyoyi ko Maballan shiga.
- 2 Idan ka zabi Gajerun hanyoyi, zaka iya latsa maballi don aiki kamar yadda yake biyowa:

Maballi Gajeriyan hanya

- | | |
|--------|---|
| 1 | Alamomin shafi |
| 2 | Shigarda adireshi |
| 3 | Binciken intanit |
| 4 | Tarihi |
| 5 | Sak. maimait.shafi |
| 6 | Mika |
| 7 | Shafi a sama |
| 8 | Wanda ba'ayi amfani dashi ba |
| 9 | Shafi a kasa - daya a lokacin |
| *a/A=0 | Cika fuska ko Daji,yanayin fili ko Allo na al'ada |
| 0 + | Zukowa |
| #-# | Gajerun hanyoyi |

Saukewa

Sauke fayiloli, masali, hotuna, jigogi, wasanni da sautunan ringi daga shafin yanar sadarwa.

Don saukewa daga dakin yanar sadarwa

Lokacin lilo, zabi fayil don saukewa kuma bi umarni wanda ke bayyana.

Bayanan martaba na intanit

Zaka iya zabar wani bayanin martaba na intanit idan kanada fiye da daya.

Don zabar bayanin martaba na intanit don mai lilo na intanit

► Saituna kuma yi amfani da Ⓛ ko Ⓛ don gungurawa zuwa Haduwa shafin
► Saitunan intanit ► Bayn.mrtb. intanit kuma zabi bayanin martba.

IBayanin martaba na Intanit don aikace-aikacen Java™

Wadansu aikace-aikacen Java™ suna bukatar hadi zuwa Intanit don karbar bayani, masali, wasanni wadanda suke sauke sababbin matakai daga uwarr garken wasa.

Kafin ka fara

Idan babu saituna a wayarka

► 65 Saituna.

Don zabar bayanin martaba saboda Java

► Saituna ► Haduwa shafin ► Saitunan intanit ► Saitin Java kuma zabi bayanin martabar intanit.

Ajiyayyen bayani

Lokacin lilo, zaka iya ajiye bayani mai biyowa:

- Cookies – gyara ingancin samun damar dakin yanar sadarwa.
- Kalmomin wucewa – gyara ingancin samun damar uwar garke.

 *Ana bada shawara don share duk wani mahimmin bayani daga sabis na Intanit na ziyarar da ta gabata. Wannan don kaucewa mu'amala mara kyau na bayanin sirri idan ka manta inda ka ajiye wayarka, ta bace ko an sace.*

Don bawa cookies dama

► Intanit ► Kari ► Zabubbuka ► Lilo shafin ► Izinin cookies ► Kunnawa.

Don share cookies, suto ko kalmar wucewa

► Intanit ► Kari ► Zabubbuka ► Wasu shafin kuma zabi wani zabi ► Ee.

Tsaro na Intanit da takaddun shaida

Wayarka tana goyan bayan tsararen lilo. Takamammen sabis na intanit, kamar harkar banki, yana bukatar takaddun shaida a wayarka. Zai yiwu wayarka tariga takunshi takaddun shaida lokacin da kasaya ko ka iya sauke sababbin takaddun shaida.

Don bincika takaddun shaida a wayarka

► Saituna ► Gaba daya shafin ► Tsaro ► Takaddun shaida.

Mai karanta RSS

Lokacin lilo, zaka iya samun abun ciki sau da yawa wanda aka daukaka, kamar mahimman kanun labarai, azaman ciyarwa ta gidan yanar sadarwa. Zaka iya lilo zuwa dakin yanar sadarwa don sabuwar ciyarwa, idan akwai. An saita zabubbukan Really Simple Syndication (RSS) ta mai karanta RSS kuma an nuna a mai lilo na intanit.

Don kara sabuwar ciyarwa ga dakin yanar sadarwa

Lokacin lilo ► Kari ► Ciyarwa RSS.

Don kirkirar sabuwar ciyarwa

- 1 ► Sako ► Mai karanta RSS ► Kari
► Sabon ciyarwa.
- 2 ► Zabi daga lissafi ko Nema ta
adireshi kuma shiga adreshin.

Don salta da amfani da zabubukan mai karanta RSS

- Sako ► Mai karanta RSS ► Kari
kuma zabi wani zabi.

Aiki tare

Hada aiki tare da lambobin waya, alkawarurruka, dawainiya da bayanin lura ta fasaha mara waya ta Bluetooth™, sabis na Intanit ko kebul USB wanda aka hada tareda wayar.

Aiki tare da kwamfuta

Shigar software na aiki tare don kwamfutarka wadda aka samo a Sony Ericsson PC Suite akan CD, wanda aka hada tareda wayar. Software ya kunshi bayanin taimako. Zaka kuma iya ziyartan www.sonyericsson.com/support don saukar da software ko takardun aiki Fara aiki tare da kwamfuta.

Aiki tare na nisa ta intanit

Yi aiki tare akan layi ta sabis din inatanit.

Kafin ka fara

- Idan babu saituna a wayarka
► 65 Saituna.
- Yi rijistar lissafin aiki tare akan layi.
- Shigar da saitunan aiki tare na nisa.

Don shigar da saitunan aiki tare na nisa

- 1 ► Oganeza ► Aiki tare ► Sabon lissafi
► Ee don kirkiro sabon lissafin.
- 2 Shigar da suna saboda sabon lissafdin ► Ci gaba.
- 3 Shigar da mai biyowar:
 - Adrsh. uwār garke – uwār garke URL.
 - Sunan mai amfani – sunan mai amfani na lissafi.
 - Kalmar wucewa – kalmar wucewa na lissafi.
 - Hadi – zabi bayanin martaba na intanit.
 - Aikace-aikace – yiwa aika-aikace alama don aiki tare.
 - Kayan saiti – zabi aikace-aikace kuma shigar da sunan tushan bayanai, kuma idan an bukaci, sunan mai amfani da kalmar wucewa.

- **Tazaran aiki tare** – saita kamar sau nawa don aiki tare.
 - **Farawar nisa** – zabi don karfa koyaushe, kar a taba karba ko tambayi koyaushe lokacin fara aiki tare daga sabis.
 - **Tsaro daga nisa** – saka ID na uwarr garke da kalmar wucewa ta uwarr garke.
- 4 ► Ajiye don ajiye sabon lissafinka.

Don fara aiki tare na nisa

► Oganeza ► Aiki tare kuma zabi lissafi ► Fara.

Fasaha mara waya ta Bluetooth™

Aikin Bluetooth™ yana sa hadi mara waya zuwa wasu na'urorin Bluetooth yazama mai yuwuwa. Zaka iya:

- Hada zuwa na'urar abun sawa akunni.
- Hada zuwa na'urar kai na sitiryo.
- Hada zuwa na'urori da yawa a lokaci daya.
- hada zuwa kawmfutoci kuma sami damar intanit.

- Hada bayani aiki tare da kamfutoci.
- Yi amfan da aikace-aikacen kwamfuta mai ramut.
- Yi amfan da na'urorin hadin mai duba mai jarida.
- Musanya abubuwa.

💡 *Munyi shawarar kewayo tsakanin mita 10, ba tareda daskararrun abubuwa a tsakani ba, don sadarwar Bluetooth.*

Kafin ka fara

- Kunna aikin Bluetooth don sadarwa tare da wasu na'urori.
- Kara na'urorin Bluetooth zuwa wayarka don sadarwa tare.

💡 *Bincika idan dokokin gida ko ka'idoji sun takaita amfanin fasaha mara waya na Bluetooth. Idan ba'a yarda da fasaha mara waya ta Bluetooth ba, dole ka tabbarat cewa an kashe aikin Bluetooth. Iyakacin wutara fita wacce aka bada dama na rediyon Bluetooth a wayar ana dai-dai tashi ta atomatik gwargwadon yiwiwar takaitawar cikin gida. Wannan yana nufin maiyuwa kewayo ya canza.*

Don kunna aikin Bluetooth

- Saituna ► Haduwa shafin
► Bluetooth ► Kunna.

Kara na'urori zuwa wayarka

Shigar da lambar wucewa don saita hanyar hadi mai tsaro tsakanin wayarka da na'uror. Shigar da lambar wucewa iri daya a na'uror lokacin sauri. Na'ura mara sararin mai amfani, kamar abin sawa akunni, zai sami tsararriyar lambar wucewa. Shawarci jagorar mai amfani na na'uror don karin bayani.

 *Tabbatar cewa na'urar da kake son ka kara tana da aikin Bluetooth akunne kuma za'a iya gani.*

Don kara na'ura zuwa wayarka

- 1 ► Saituna ► Haduwa shafin
► Bluetooth ► Na'urori nawa
► Sabuwar na'ura don bincika wadataccen na'uara. Tabbatar ana iya ganin daya na'urar.
- 2 Zabi na'ura daga lissafin.
- 3 Shigar da lambar wucewa, idan an bukata.

Don bawa hadi dama ko shirya lissafin na'urarka

- 1 ► Saituna ► Haduwa shafin
► Bluetooth ► Na'urori nawa
kuma zabi na'ura daga lissafin.
- 2 ► Kari don duba lissafin zabubbuka.

Don kara abin sawa akunni na Bluetooth

- 1 ► Saituna ► Haduwa shafin
► Bluetooth ► Abin sawa akunni.
- 2 ► Ee Idan kana kara abin sawa a kunni na Bluetooth da farko ko ► Abn. saw.akun.nw. ► Sab. abn.sw.akun.
► Kara idan kana kara wani abin sawa a kunni na Bluetooth. Tabbatar cewa abin sawa akunni naka yana cikin yanayi mai kyau. Shawarci jagorar mai amfani na na'uror don karin bayani.

Ajiye wuta

Kunna don rage shan wuta ta kyautata wayarka don amfani tareda warin na'uror Bluetooth. Kashe don hadawa tareda na'urori dayawa na Bluetooth a lokaci guda.

Don ajiye wuta

- Saituna ► Haduwa shafin
► Bluetooth ► Ajiye wuta ► Kunnawa.

Sunan waya

Shigar da suna don wayarka wanda za'a nuna a lokacin da wata na'ura ta nemo shi.

Don shigar da sunan waya

- Saituna ► Haduwa shafin
- Bluetooth ► Sunan waya.

Gani

Zabi don sa wayarka mai ganuwa ga wasu na'urorin Bluetooth ko a'a. Idan an saita wayarka don boyewa, kawai na'urori a ► Saituna ► Haduwa shafin
► Bluetooth ► Na'urori nawa sunada damar gano wayarka ta fasaha mara waya na Blurtooth.

Don nuna ko boye wayarka

- Saituna ► Haduwa shafin
- Bluetooth ► Ganuwa ► Nuna waya ko Boye waya.

Musayar abubuwa

Aika ko karbi abubuwa ta amfani da fasaha mara waya na Bluetooth azaman hanyar canja wuri. Zabi na'ura daga lissafin na'urorin da aka samo.

Don aika abu

- 1 Zabi abu, misali ► Lambobi kuma zabi lamba.
- 2 ► Kari ► Aika lamba ► Ta Bluetooth.
- 3 Zabi na'uarar da zaka aika abu zuwa gareta ► Zabi.

Don karbar abu

- 1 ► Saituna ► Haduwa shafin
- Bluetooth ► Kunna.
- 2 ► Ganuwa ► Nuna waya.
- 3 Lokacin da karbi wani abu, bi umarni wanda ke bayyana.

Canja wurin sauti

Canja wurin sautin don kira lokacin amfani da abin sawa akunni na Bluetooth™.

Hakanan zaka iya canja wurin sautin don kira ta amfani da faifan maballi ko maballin abin sawa akunni kamar yadda yake biyowa:

- Latsa maballin abin sawa akunni don sauti a abin sawa akunni.
- Latsa maballin waya ko maballi (idan an saita zuwa **Cikin waya**) don sauti a waya.
- Latsa kowane maballi (idan an saita zuwa **A abin sw. akun.**) don sautin a abin sawa akunni.

Don canja wurin sauti lokacin amfani da abin sawa akunni na Bluetooth

Yayin kira, ► Kari ► Canja wurin sauti kuma zabi na'ura.

Don canja wurin sauti lokacin amsa kira da abin sawa akunni

- 1 ► Saituna ► Hađuwa shafin
 - Bluetooth ► Abin sawa akunni
 - Kira mai shigowa.
- 2 ► Cikin waya don kaitsaye zuwa wayar ko ► **A abin sw. akun.** don kaitsaye zuwa abin sawa akunni.

Ramut

Yi amfani da wayarka azaman na'urar ramut don sarrafa aikace-aikacen kwamfuta kamar mai jaridar wařa ko gabatar da Microsoft® PowerPoint® ko na'ura mai goyan bayan bayanin martabar Bluetooth HID.

Don zabar ramut

- 1 ► 72 *Don kara na'ura zuwa wayarka, idan an bukata.*
- 2 ► **Nishadî** ► **Ramut.**
- 3 Zabi aikace-aikace don amfani da kuma kwamfuta ko na'ura don hadawa gareta.

Canja wurin fayil

Idan kwamfutarka tana goyan bayan fasaha mara waya ta Bluetooth, zaka iya shigar da Sony Ericsson PC Suite don aiki tare, canja wurin fayiloli, yi amfani da wayar azaman abin hadî da karin ta sadarwar Bluetooth.

Shigar da Sony Ericsson PC Suite daga CD wanda yazo tareda wayar ko saukar da shi a www.sonyericsson.com/support. Hakanan PC Suite ya kunshi taimako.

Canja wurin fayiloli ta amfani da kebul na USB

Hada wayarka zuwa kwamfuta, ta kebul naUSBB, don amfani da wayarka a dayan masu biyowa: **Cnj. wur.fayil** ko **Yanay. waya.**

Canja wurin fayil


Jawo kuma sakko da fayiloli tsakanin katin kwakwalwar ajija naka da kwamfuta a Microsoft Windows Explorer.

Yi amfani da Sony Disc2Phone (canja wurin kida) ko Adobe™ Photoshop™ Album Starter Edition (canja wurin hoto/ma'aji). Ana samun wadannan aikace-aikacen akan CD wanda yazo tareda wayar ko a www.sonyericsson.com/support, kuma za'a iya amfani da shi kawai tareda hanyar canja wuri.

 Kawai yi amfani da kebul na USB wanda yazo tareda wayar, kuma hada kebul na USB kai tsaye zuwa kwamfutarka. Kada ka cire kebul na USB din daga wayar ko kwamfutar yayin canja wurin fayil saboda wannan maiyuwa ya bata katin kwakwalwar ajiyar.

Don amfani da yanayin canja wuri

- 1 Hada kebul na USB zuwa wayar da kwamfutar.



- 2 **Waya:** Zabi Cnj. wur.fayil ko ► Saituna ► Haduwa shafin ► USB ► Hadin USB ► Cnj. wur.fayil. Wayar tana rufewa.
- 3 Dakata harsai katin kwakwalwar ajiya naka ya bayyana azaman disk na waje a Windows Explorer. Zaka iya amfani da:
 - Windows Explorer don jawo da sakko da fayiloli tsakanin katin kwakwalwar ajiya naka da kwamfuta.

- Sony2Phone don canja wurin kida zuwa katin kwakwalwar ajiya naka.
- Adobe Photoshop Album Starter Edition, don canja da daidai ta wurin hotunanka a kwamfutarka.

Don cire hadin kebul na USB a amince

- 1 Lokacin amfani da yanayin canja wurin fayil, kada-dama na gunkin faifai mai ciruwa a Windows Explorer kuma zabi Fitarwa.
- 2 Cire kebul na USB daga wayarka.

Yanayin waya

Hada aiki tare da lambobi da kalanda, canja wurin fayiloli, yi amfani da wayar azaman abin hadi da kari daga kwamfutarka. Aikace-aikacen da suka bada goyan baya a yanayin waya sun hada da: Aiki tare, Mai sarrafa fayil da mayen cibiyar sadarwa na wayar hannu. Don wasu aikace-aikacen, yi amfani da yanayin canja wurin fayil.

Kana bukatar shigarwa da amfani da Sony Ericsson PC Suite, wanda yake hade da CD wanda yazo tareda wayar ko aka samo a www.sonyericsson.com/support.

 **Kwamfutarka tana bukata samun dayan tsarukan aiki masu biyowa don samun damar amfani da wannan fasalin:**
Windows 2000 tareda SP3/SP4,
Windows XP (Pro da Home) tareda
SP1/SP2.

An shigar da masu tuka USB ta automatik tareda software na PC Suite.

Don amfani da yanayin waya

- 1 Kwamfuta:** Shigar da Sony Ericsson PC Suite daga CD wanda yazo tareda wayarka.
- 2 Kwamfuta:** Fara PC Suite daga Start/ Programs/Sony Ericsson/PC Suite.
- 3 Hada kebul na USB zuwa wayar da kwamfutar.
- 4 Waya:** Zabi Yanay. waya ko ► Saituna ► Haduwa shafin ► USB ► Hadin USB ► Yanay. waya.
- 5 Kwamfuta:** Dakata yayin da Windows yake shigar da mutukan da aka bukata.
- 6 Kwamfuta:** Lokacin da PC Suite ya nemo wayarka ana sanar dakai.
Duk aikace-aikacen da zaka iya amfani dasu tareda wayarka mai hadi ana samun su a Sony Ericsson PC Suite.

Daukaka sabis

Koyaushe bar wayarka a daukake tareda sabuwar software don inganta aiki. Baza kayi asarar bayanin sirri ko bayanin waya ba, misali sakonni ko saituna yayin daukakawa.

Akwai hanyoyi biyu don daukaka wayarka:

- Bisa iska ta wayarka.
- Ta kebul na USB wanda aka bayar da kwamfuta mai hadin intanit.



Sabis na daukakawa yana bukatar samun damar bayanai (GPRS).

Afaretanka zai baka bayanin biyan kudi tareda samun damar bayanai da bayanin farashi.

Kafin ka fara

Idan babu saitunan da ake bukata a wayarka ► 65 Saituna.

Don amfani da daukaka sabis bisa iska

- 1 ► Saituna ► Gaba daya shafin ► Sabis na daukaka.
- 2 don bincika sabuwar samammiyar software.
- 3 Fara aikin daukakawa ta bin umarnin shigarwa, ko ► **Sigar software** don nuna sabon software a wayarka ko ► Mai tuni don saitawa lokacin bincika sabon software.

Don amfani da daukaka sabis ta kwamfuta

- 1 Ziyarci
www.sonyericsson.com/support.
- 2 Zabi yanki da kasa.
- 3 Shigar da sunan samfur din.
- 4 Zabi sabis na daukakawa na Sony Ericsson kuma bi umarni.

Karin fasaloli

Agogon kararrawa, kalanda, dawainiya, bayanan martaba, lokaci da kwanan wata, makullin katin SIM da kari.

Krarrawa

Saita kararrawa don takamaiman lokaci ko takamaiman ranaku don sake aukuwa. Zaka iya saita sigina na kararrawa azaman sauti ko rediyo.

Don amfani da kararrawa

- 1 ► Oganeza ► Kararrawa kuma zabi wani kararrawa don saitawa ► Shirya.
- 2 Lokacin: ► Shirya kuma saita lokaci ► Ok. Zabi karin zabubbuka, idan an bukata:
 - Mai dawowa: ► Shirya kuma saita rana ko ranku ► Alama ► Anyi.
 - Sgnl. na kararra.: ► Shirya kuma zabi radiyon ko sauti.
 - Latsa ⓧ don shirya rubutu, hotuna da yanayin shiru don kararrawa.
- 3 ► Ajiye.

Don kashe sigina na kararrawa lokacin da yake sauti

Latsa kowani maballi, idan an zabi radiyo azaman sigina na kararrawal
► **Munsh.** Idan baka son maimaita kararrawar ► **Kashe.**

Don soke kararrawa

► **Oganeza** ► **Kararrawa** kuma zabi kararrawa, ► **Kashe.**

Kalandia

Zaka iya amfani da kalandia don adana bibiyar mahimmin taro. Za'a iya hada kalandia aiki tareda kalandar kwamfuta ko tareda kalandar yanar sadarwa ► **70 Aiki tare.**

Alkawurra

Kara sabbin alkawurra ko yi amfani da alkawurra masu kasancewa azaman samfura.

Don kara sabon alkawari

1 ► **Oganeza** ► **Kalandia** kuma zabi kwannan wata ► **Zabi** ► **Sabuwar alkawari** ► **Kara.**

2 Zabi daga zabubbuka masu biyowa kuma tabbatar da kowacce shigarwa, in an bukata:

- **Gaba daya** shafi – take, fara lokaci, tsawon lokaci, mai tuni, fara kwanan wata.
- **Bayanai** shafi – wurin, sifantawa, duk rana, sake aukwa.

3 ► **Ajiye.**

Don duba alkawari

1 ► **Oganeza** ► **Kalandia** kuma zabi rana (ranakun alkawari wadanda aka yiwa alama da firam).

2 Zabi alkawari ► **Duba.**

Don duba satin kalanda

► **Oganeza** ► **Kalandia** ► **Kari** ► **Duba sati.**

Don saita lokacin da masu tuni zasu yi sauti

1 ► **Oganeza** ► **Kalandia** ► **Kari** ► **Na ci gaba** ► **Masu tuni.**

2 ► **Koyaushe** don mai tuni yayi sauti koda lokacin da aka kashe wayar ko aka saita ta a shiru An saita zabin mai tuni a rinjayan kalandia an saita zabin mai tuni a dawainiya.

Kewayawa a cikin kalandarka

Yi amfani da maballin kewayawa don matsawa tsakanin ranaku da makonni. A cikin dube-duben watan da makonnin, zaka iya kuma amfani da faifan maballin kamar mai biyowa.

(C) Kwanan
watan yau

(1) Sati daya baya (3) Sati na
gaba

(4) Wata daya
baya (6) Wata na
gaba

(7) Shekara daya
baya (9) Shekara ta
gaba

Saitunyan kalandarka

► Oganeza ► Kalandarka ► Kari don
zabin wani zabi:

- Duba sati – duba alkawurran satin.
- Sabuwar alkawari – kara sabon alkawari.
- Canja kwan. wata – je zuwa wani kwanan wata a kalandar.
- Na ci gaba – nemo alkawari, saita masu tuni ko zabi ranar farawa don satin.
- Share – share tsofaffi ko duk alkawurra.
- Taimako – don karin bayani.

Musanya alkawura

Musanya alkawurra ta amfani da hanyar canja wuri. Zaka kuma iya aiki tareda alkawurra da kwamfuta

► 70 Aiki tare.

Don aika alkawari

zabi alkawari a lissafin saboda takmammen rana ► Kari ► Aika kuma zabi hanyar canja wuri.

Dawainiya

Kara sabbin dawainiya ko yi amfani da dawainiya masu kasancewa azaman samfura. Zaka kuma iya saita masu tuni don dawainiya.

💡 Mafi girman lambobin bayanan kula ya danganta da sararin kwakwalwar ajiya, kamar yadda aka saita a software.

Don kara sabuwar dawainiya

1 ► Oganeza ► Dawainiya ► Sabu.
dawainiya ► Kara.

2 ► Dawainiya ko Kiran waya.

3 shigar da bayanai kuma tabbatar da kowacce shigarwa.

Don duba dawainiya

► Oganeza ► Dawainiya kuma share
dawainiya ► Duba.

Don saita lokacin da masu tuni zasu yi sauti

- 1 ► Oganeza ► Dawainiya kuma zabi dawainiya ► Kari ► Masu tuni.
- 2 ► Koyaushe don mai tuni yayi sauti koda lokacin da aka kashe wayar ko aka saita ta a shiru An saita zabin mai tuni a rinjayan kalanda an saita zabin mai tuni a dawainiya.

Musanya dawainiya

Musanya dawainiya ta amfani da hanyar canja wuri. Zaka kuna iya aike tareda dawainiya da kwamfuta
► 70 Aiki tare.

Don aika dawainiya

Zabi dawainiya a lissafin dawainiyoyi saboda takmammen rana ► Kari
► Aika kuma zabi hanyar canja wuri.

Bayanan kula

Yi bayanan kula ka ajiye su a lissafi. Hakanan zaka iya nuna bayanin kula a jiran aiki.

 *Iyakar ya dogara da wadatar kwakwalwar ajiya.*

Don kara bayanin kula

► Oganeza ► Bayanan kula ► Sab. bayanin kula ► Kara kuma shigar da bayanin kula ► Ajiye.

Don shirya bayanan kula

- 1 ► Oganeza ► Bayanan kula kuma lissafi yana bayyana.
- 2 zabi bayanin kula ► Kari kuma zabi wani zabi.

Musayar bayanan kula

Musanya bayanan kula ta mai amfani da dayan wadatattun hanyoyin canja wuri. Hakanan zaka iya aiki tare da bayanan kula da kwamfuta ► 70 Aika tare.

Don aika bayanin kula

Zabi bayanin kula ► Kari ► Aika kuma zabi hanyar canja wuri.

Mai kidayar lokaci

Wayarka tana da mai kidayar lokaci. Lokacin da sigina yayi sauti, latsa kowane maballii don kashe ta ko zabi Fara.

Don saita mai kidayar lokacin

► Oganeza ► Mai Kidyr. lokaci kuma saita awoyi, mintoci da sakan saboda kidaya.

Agogon awon gudu

Wayarka tanada agogon awon gudu wanda zai iya ajiye juyi dayawa.
Agogon awon gudu zai cigaba da gedana lokacin da kake amsa kira mai shigowa.

Don amfani da agogon awon gudu

- 1 ► Oganeza ► Aggn.awn. gudu ► Fara.
- 2 ► Tsaida ko ► Sabw. juyi saboda lokacin kewayan fili.
- 3 Don sake saita agogon awon gudu
► Tsaida ► Sake saiti.

Kalkaleta

Kalkuleta zai iya kara, debewa, rabawa da rubanyawa.

Don amfani da kalkuleta

- Oganeza ► Kalkaleta.
- Latsa ko don zabi + x - . % =.
- Latsa don share harafin.
- Latsa don shigar da digon goma.

Memo na lamba

Ajiye lambobin tsaro, kamar azaman katinan lamuni, a lambar memo. Saita lambar wucewa don bude lambar memo.

Duba kalma da tsaro

Don tabbatar da cewa ka shigar da lambar wucewa daidai dole ka shigar da duba kalma.

Lokacin da ka shigar da lambar wucewarka don bude lambar memo, ana nuna duba kalmar atakaice. Idan lambar wucewa tayi daidai, ana nuna lambobin da suke daidai. Idan ka shigar da lambar wucewa ba daidai ba, duba kalma da lambobin da aka nuna sumba da daidai bane.

Don bude memo na lamba da farko

- 1 ► Oganeza ► Memo na lamba. Sako tareda umarni suna bayyana ► Ci gaba.
- 2 Shigar da lambar wucewa guda huđu ► Ci gaba.
- 3 Sake shigar da sabuwarr lambar wucewa don tabbatarwa.
- 4 Shigar da kalmar bincike (mafi yawa haruffa 15) ► Anyi. Duba kalmar zai iya kunsar duka biyu haruffa da lambobi.

Don kara sabuwar lamba

- 1 ► Oganeza ► Memo na lamba kuma shigar da lambar wucewarka ► **Sabuwar lamba ► Kara.**
- 2 Shigar da sunan dake hade da lambar ► **Ci gaba.**
- 3 Shigar da lamabar ► **Anyi.**

Don canja lambar wucewar

- 1 ► Oganeza ► Memo na lamba kuma shigar da lambar wucewaraka ► **Kari ► Canj.lamb.wcew.**
- 2 Shigar da sabuwar lambar wucewarka ► **Ci gaba.**
- 3 Sake shigar da sabuwar lambar wucewa ► **Ci gaba.**
- 4 Shigar da kalmar bincike ► **Anyi.**

Manta lambar wucewarka?

Idan kamanta lambar wucewarka, dole ne ka sake saita memo na lamba.

Don sake saita memo na lamba

- 1 ► Oganeza ► Memo na lamba kuma shigar da kowace lambar wucewa don samun damar memo na lamba. Duba kalma da lambobi wadanda alokacin da aka nuna su ba daiadai bane.
- 2 ► **Kari ► Sake saiti.**

3 Sake saitin memo na lamba? yana bayyana ► **Ee.** An sake saita memo na lamba kuma an share du wadanda aka shigar. Lokaci na gaba da zaka shigar da memo na lamba, dole kafara a ► **81 Don bude memo na lamba da farko.**

Bayanan martaba

Wayarka tanada tsararrun bayanan martaba wadanda aka saita. Wasu, misali, karar ringi da wasu zabubbuka maiyuwa a daidai tasu ta atomatik don su dace da takamaiman halin wuri ko na'urur hadi. Zaka iya sake saita duk saitunan bayanan martaba zuwa yadda aka saita su lokacin da ka sayi wayarka.

Don zabar bayanin martaba

Latsa ① kuma zabi bayanin martaba, ko ► **Saituna ► Gaba daya shafi** ► **Bayanan martaba kuma zabi bayanin martaba.**

Don duba da shirya bayanin martaba

► **Saituna ► Gaba daya shafin** ► **Bayanan martaba ► Kari ► Duba ka ashirya.**



Bazaka iya sake sunan bayanin martaba na al'ada ba.

Don sake saita bayanan martaba

► Saituna ► Gaba daya shafin ► Bayanan martaba ► Kari ► Sk. st.bay. mart.

Lokaci da kwanan wata

Koyaushe ana nuna lokacin a jiran aiki.

Don saita lokaci da tsara lokaci

- 1 ► Saituna ► Gaba daya shafin ► Lokc. & kwn.wt. ► Lokaci.
- 2 Shigar da lokacin.
- 3 ► Tsari kuma zabi wani zabi.
- 4 ► Ajiye.

Don saita kwanan wata da tsara kwanan wata

► Saituna ► Gaba daya shafin ► Lokc. & kwn.wt. ► Kwanan wata.

Makullin katin SIM

Makullin katin SIM yana kare biyan kuđinka, amma ba wayar kanta ba, daga amfani mara izini. Idan ka canza katinan SIM, wayarka har yanzu zata yi aiki da sabon katin SIM.

Mafi yawan katinan SIM suna kulle a lokacin saye. Idan makullin katin SIM yana kunne, dole ka shigar da PIN (Personal Identity Number) duk lokacin da ka kunna wayarka. Idan ka shigar da PIN naka kuskure sau uku ajere, za'a katange katin SIM. An nuna wannan ta sakon **An katange PIN**. Don bude shi, kana bukatar shigar da PUK naka (Personal Unblocking Key). PIN naka da PUK ana bada su ta afaretan cibiyar sadarwarka. Zaka iya shiryu PIN naka kuma zabi lambar PIN huđu zuwa takwas.



Idan sakon Lambobi basu jitū ba yana bayyana lokacin da ka shiryu PIN naka, ka shigar da sabon PIN kuskure.

Idan sakon PIN mara daidai yana bayyana, an biyoshi da Tsohuwar PIN:, ka shigar da tsohon PIN naka kuskure.

Don cire katange katin SIM naka

- 1 Lokacin da **An katange PIN** yana bayyana, shigar da PUK naka ► Ok.
- 2 Shigar da sabowar lambar PIN huđu zuwa takwas ► Ok.
- 3 Sake shigar da sabon PIN don tabbatarwa ► Ok.

Don shirya PIN naka

- 1 ► Saituna ► Gaba daya shafin ► Tsaro ► Mukullai ► Kariyar SIM ► Canja PIN.
- 2 Shigar da PIN naka ► Ok.
- 3 Shigar da sabowar lambar PIN huđu zuwa takwas ► Ok.
- 4 Sake shigar da sabon PIN don tabbatara ► Ok.

Don kunna ko kashewa makullin katin SIM

- 1 ► Saituna ► Gaba daya shafin ► Tsaro ► Mukullai ► Kariyar SIM ► ► Kariya kuma zabi Kunnewa ko A kashe.
- 2 Shigar da PIN naka ► Ok.

Kulle waya

Kare wayarka daga amfani mara izini idan aka sare kuma aka sauva katin SIM din. Zaka iya canja lambar makullin wayar (0000) zuwa lambobi na sirri huđu zuwa takwas.

Makullin waya ta atomatik

Idan an saita makullin waya ta atomatik, baka bukatar shigar da lambar kulle wayarka harsai an saka katin SIM daban acikin waya.

 *Yana da mahimmanci cewa ka tuna sabuwarr lambarka. Idan ka manta ta, dole ne ka dauki wayarka zuwa wakilin Sony Ericsson na gida.*

Don saita makullin wayar

- 1 ► Saituna ► Gaba daya shafin ► Tsaro ► Mukullai ► Kariyar waya ► Kariya kuma zabi maimako.
- 2 Shigar da lambar makullin wayar ► Ok.

Don bude wayar

Idan makullin wayar na kunne, shigarda lambarka ► Ok.

Don shirya lambar makullin wayarka

- Saituna ► Gaba daya shafin ► Tsaro ► Mukullai ► Kariyar waya ► Canja lambar.

Makullin faifan maballi

Kulle faifain maballin don kawar da buga lambar ta hadari.

 *za'a iya yi kira zuwa lambobin gaggawa na kasa da kasa 112, koda lokacin da faifain maballi ke kulle.*

Kulle maballi ta atomatik

Yi amfani da kulle maballi ta atomatik a jiran aiki don kulle faifan maballi jim kadan bayan maballin karshe da aka latsa.

Don saita kulle maballi ta atomatik

- Saituna ► Gaba daya shafin ► Tsaro ► Kull.mblt.ta atmatis.

Don kulle faifan maballi da hannu

Daga jiran aiki, zaka iya latsa  ► **Mk.mbl.** don kulle faifan maballin da hannu. Har yanzu zaka iya amsa kira mai shiga kuma faifan maballi yana kullewa bayan kiran. Faifan maballin zai zauna akulle har sai lokacin da ka bude da hannu.

Don bude faifan maballin da hannu

Daga jiran aiki, lasta  ► **Bude.**

Fara allo

Zabi fara allon don bayyana lokacin da ka kunna wayarka ► **53 Amfani da hotuna.**

Don zabar fara allo

► **Saituna** ► **Nuni** shafin ► **Allon** farawa kuma zabi wani zabi.

Haske

Daidaita hasken allon.

Don saita hasken

► **Saituna** ► **Nuni** shafin ► **Haske.**

Shirya matsala

Me yasa wayar bata aiki yanda nakeso tayi?

Wannan babin yana lissafa wasu matsaloli wadanda zaka iya fuskanta lokacin amfani da wayarka. Wadansu matsaloli suna bukatar ka kira afaretan cibiyar sadarwarka, amma zaka iya gyara mafi yawan matsalolin da kanka a sauake.

Koyaya, in kana bukatar daukar wayarka zuwa gyara, kula da cewa maiyuwa ka rasa bayani da abun ciki wanda ka ajiye a wayarka. An baka shawara ka yi kwafin wannan bayanin kafin kai wayarka gyara.

Don karin goyan baya je zuwa www.sonyericsson.com/support.

Ina da matsala da fadin kwakwalwar ajiya ko wayar tana aiki a hankali

Dalili mai yiwuwa: Kwakwalwar ajiyar wayar tacika ko ba'a tsara abubuwani cikin kwakwalwar ajiyar yadda yakamata ba.

Magani: Sake kunna wayarka kulum don sanya kwakwalwar ajiya fanko da kuma kara fadin wayarka.

Kuma kana da zabubbukan yin **Sake saitín ainihi**. Za'a rasa wasu bayanan sirí da saituna wadanda kayi lokacín da kayi wannan ➡ 88 *Sake saiti na ainihi*.

Babu gunkin baturi daya bayyana lokacín da nafara cajin wayar

Dalili mai yiwuwa: Baturin fanko ne ko ba'a yi aiki da shi ba na lokaci mai tsawo.

Magani: Zai iya daukar kamar minti 30 kafin gunkin baturin ya bayyana a allon.

Wasu zabubbukan menu suna bayyana cikin ruwan toka

Dalili mai yiwuwa: Ba'a kunna sabis ba ko biyan kudinka baya goyan bayan aikin.

Magani: Tuntubi afaretan cibiyar sadarwarka.

Dalili mai yiwuwa: Tunda ba zaka iya aika jigogi ba, hotuna da sautuna wadanda aka kare ta hakkin mallaka **Aika** babu menu wasu lokuta.

I Bana fahimtar yaran menu

Dalili mai yiwuwa: An saita yaren kuskure a wayar.

Magani: Canja yaran ➡ 17 *Yaran waya*.

Bazan iya kunna wayar ba.

Dalili mai yiwuwa: An cire cajin baturin.

Magani: Yi cajin baturin ➡ 5 *Don cajin baturi*.

Magani: Kunna wayar tareda caja a hade. Idan wayar ta fara, sake kunna wayar batareda caja a hade ba.

Bazan iya cajin wayar ba ko damar baturi tayi kasa

Dalili mai yiwuwa: Cajar bata hadu da wayar kamar yadda yakamata ba.

Magani: Tabbatar mai hada caja yana kadawa yadda yakamata cikin wurin lokacín da aka hada shi ➡ 5 *Don cajin baturi*.

Dalili mai yiwuwa: Hadin baturi baida kyau.

Magani: Cire baturin kuma tsaftace masu hadawar. Zaka iya amfani da dayan masu boyowa wadanda aka tsomasu a tsanake cikin alkwal; brushi mai taushi, kyalle ko hankici. Tabbatar cewa baturin ya bushe tsaf kafin ka maida shi. Bincika cewa masu hadin baturi a wayar basu lalace ba.

Dalili mai yiwuwa: Baturin ya lalace kuma yana bukatar sauyawa.

Magani: Gwada wani baturi da caja na irin samfur dín, ko ziyarci wakilanka kuma tanbaye su don ka tabbatarwa idan baturin da cajar suna aiki yadda yakamata.

Wayar tana kashe kanta

Dalili mai yiwuwa: ① an tura maballin bada niyya ba.

Magani: Kunna makullin maballin automatik, ko kulle faifan maballi da hannu ➡ 84 *Makullin faifan maballi*.

Dalili mai yiwuwa: Hadin baturi baida kyau.

Magani: Tabbatar an shigar da baturi daidai ➡ 5 *Don shigar da katin SIM da baturi*.

Bana iya amfani da sakonnin rubutun/ SMS a wayata ba

Dalili mai yiwuwa: Saituna suna bacewa ko kuskure.

Magani: Tuntubi mai sa aikin cibiyar sadarwarka don gano saitin wurin sabis na SMS ➡ 36 *Sako rubutu (SMS)*.

Bana iya amfani da sakon hoto na MMS a wayata

Dalili mai yiwuwa: Biyan kuđinka bai kunshi damar bayanai ba.

Magani: Tuntubi afaretan cibiyar sadarwarka.

Dalili mai yiwuwa: Saituna suna bacewa ko kuskure.

Magani: ➡ 6 *Taimako a wayarka* ko je zuwa www.sonyericsson.com/support, zabi yanki da kasa, shafin saitin wayar da samfurin wayarka. Sannan zabi "Sakon Hoto (MMS)" kuma bi umarni ➡ 65 *Saituna*.

Bana iya amfani da intanit

Dalili mai yiwuwa: Biyan kuđinka bai kunshi damar bayanai ba.

Magani: Tuntubi afaretan cibiyar sadarwarka.

Dalili mai yiwuwa: Saitunan Intanit suna bacewa ko kuskure.

Magani: ► 6 Taimako a wayarka ko je zuwa
www.sonyericsson.com/support, zabi yanki da kasa, shafin saitin wayar da samfurin wayarka. Sannan zabi "Intanit na wayar hannu (WAP)" kuma bi umarnin ► 65 Saituna.

Wasu masu amfani baza su iya gano wayarka ta fasaha mara waya na Bluetooth™.

Dalili mai yiwuwa: Baka kunna aikin Bluetooth ba.

Magani: Tabbata cewa aikin Bluetooth™ yana kunne kuma an saita gani don nuna waya ► 73 Don karbar abu.

Bana iya aiki tare ko canja wurin bayanai tsakanin wayata da kwamfuta ta, lokacin amfani da kebul na USB da aka bayar

Dalili mai yiwuwa: Ba'a saka kebul din yadda yakamata ba kuma ba'a gano shi a kwamfutarka ba, ko ba'a saka software wanda yazo tareda wayarka a kwamfutar yadda yakamata ba.

Magani: Je zuwa
www.sonyericsson.com/support
Zabi yankinka da kasa, zabi samfurin wayarka, sannan zabi Koyi kari - Fara. Jagorar dake hada wayar aiki tareda kwamfuta yana kunsan umarnin shigarwa da jagorar shirya matsala, wanda zai yiwu ya taimake ka acikin warware matsalar.

Sake saitin ainihu

Z'a share canje-canjen da kayi zuwa saituna da abun ciki wanda ka kara ko ka shirya.

Idan ka zabi **Sake saitin saitina**, za'a share canje-canjen da kayi zuwa saituna.

Idan ka zabi **Sake satin duk**, kari ga canje-canjen saitunanka za'a kuma a share duk lambobi, sakonni, bayanan sirri, da abun ciki wanda ka saukar, wanda ka karba ko ka shirya.

Don sake saita wayar

- 1 ► Saituna ► Gaba daya shafin ► Sake saitin ainihu.
- 2 ► Sake saitin saitina ko ► Sake satin duk.
- 3 Lokacin da umarni ya bayyana ► Ci gaba.

 *Idan ka zabi Sake satin duk, hakanan ana share abun ciki kamar lauin waka da hotuna wanda ka saukar, karba ko shiryawa.*

Kuskuren sakonni

Sa SIM

Dalili mai yiwuwa: Babu katin SIM a cikin wayar ko maiyuwa ka saka shi kuskure.

Magani: Saka katin SIM ➡ 5 Don saka katin SIM da baturi.

Dalili mai yiwuwa: Masu hadin katin SIM suna bukatar tsaftacewa.

Magani: Cire katin SIM din ka tsaftace shi. Hakanan bincika cewa katin bai lalace ba don kar ka hadi shi zuwa masu hadin wayar. Tun da haka ne, tuntubi afaretan cibiyar sadarwarka don tambayar sabon katin SIM.

Sa katin SIM mai kyau

Dalili mai yiwuwa: An saita wayar don kawai aiki tareda takamaiman katinan SIM.

Magani: Bincika idan kana amafani da afaretan katin SIM mai kyau don wayarakka.

PIN mara daidai/PIN2 mara daidai

Dalili mai yiwuwa: Ka shigar da PIN ko PIN2 naka kuskure.

Magani: Shigar da PIN ko PIN2 daidai ➤ Ee ➡ 83 Makullin katin SIM.

An katange PIN/An katange PIN2

Dalili mai yiwuwa: Ka shigar da lambar PIN ko PIN2 naka kuskure sau uku a jere.

Magani: Don budewa ➡ 83 Makullin katin SIM.

Lambobi basu jitu ba

Dalili mai yiwuwa: Lambobi biyu wadanda ka shigar basu dace ba.

Magani: Lokacin da kake son canja lambar tsaro, (misali, PIN naka) Dolene ka tabbatar da sabuwar lambar ta sake shigar da wanna lambar daidai wadaida. ➡ 83 Makullin katin SIM.

Bab. kway.cb.sadr.

Dalili mai yiwuwa: Wayarka tana cikin yanayin kaura.

Magani: Sake kunna wayar a yanayi naal'ada ➡ 7 Menu na yanayin kaura.

Dalili mai yiwuwa: Wayarka bata karbar sigina na radiyo, ko sigina da aka karba yana da rauni kwarai.

Magani: Tuntubi afaretan cibiyar sadarwarka kuma a tabbata cewa cibiyar sadarwar ta kewaye inda kake. Idan hakane, bincika cibiyar sadarwa.

Dalili mai yiwuwa: Katin SIM din baya aiki yadda yakamata.

Magani: Saka katin SIM naka cikin wata wayar. Idan har yanzu kana samun makamanci ko sako iri daya, tuntubi afaretan cibiyar sadarwarka.

Dalili mai yiwuwa: Wayar bata aiki yadda ya kamata.

Magani: Saka katin SIM naka cikin wata wayar. Idan wannan yana aiki, da alama wayar ce take haifar da matsalar. Tuntubi wurin sabis na Sony Ericsson mafi kusa.

Kiran gaggw. kawai

Dalili mai yiwuwa: Kana tsakanin kewayen cibiyar sadarwa, amma ba'a yarda kayi amfani da ita ba. Koyaya, a gaggawa, wadansu masu sa aikin cibiyar sadarwa suna baka damar kirin lambar gaggawar ta kasa da kasa 112.

Magani: Dole ka matsa don samun sigina wanda ke da isasshen Karfi. Tuntubi mai sa aikin cibiyar sadarwarka do tabbatar da ka sami biyan kudi dai-dai ➡ 23 Kiran gaggawa.

Kulle waya

Dalili mai yiwuwa: An kulle wayar.

Magani: Don buđe wayar
➡ 84 Makullin waya.

Lmb. klle. waya:

Dalili mai yiwuwa: Ana bukatar lambar makullin wayar.

Magani: Shigar da lambar makullin waya. Wayarka tana da tshohuwar lambar makullin waya 0000
➡ 84 Makullin waya.

An cire katanga PUK. Tuntubi mai sa aiki.

Dalili mai yiwuwa: Kashigar da lambar maballin budewarka na sirri (PUK) kuskure sau 10 a jere.

Magani: Tuntubi afaretan cibiyar sadarwarka.

Yin caji, bakon baturi

Dalili mai yiwuwa: Baturin da kake amfani dashi ba amintaccen baturin Sony Ericsson bane.

Magani: ► 94 Baturi.

Muhimmin bayani

Mai amfani da gidan yanar sadarwa na Sony Ericsson, sabis da goyan baya, kare lalasisin mai amfani, garanti, bayanin tabbatarwa.

Gidan yanar sadarwar mai amfani na Sony Ericsson

A www.sonyericsson.com/support yankin goyan baya ne inda taimako da tukwici suke a kadawa kadan waje kawai. Anan zaka sami daukaka software na sabuwar kwamfuta da tikwici na yadda za kayi amfani da samfur naka da inganci sosai.

Sabis da goyan baya

Daga yanzu zaka sami damar zuwa fa'idojin jakar kebentaccen sabis kamar:

- Gidan yanar sadarwa na duniya da gida suna bada goyan baya
 - Cibiyar sadarwa na duniya na wuraren kira
 - Babbar cibiyar sadarwar Sony Ericsson ta abokan sabis
 - lokacin garanti. Kara koyo gameda sharuddan garanti a wannan jagorar mai amfanin kan www.sonyericsson.com, karkashin goyan baya yankin a yaren zabinka, zaka sami sababbin kayan aiki masu bada goyan baya da bayani, kamar daukak software, Cibiyar ilimi, Saita waya da karin bayani lokacin da ka bukace shi.
- Don takamaiman afaretan sabis da fasali, tuntubí afaretan cibiyar sadarwarka don karin bayani.

Zaka kuma iya tuntubar Wuraren Kiranmu. Yi amfani da lambar wayar don Wurin Kira mafi kusa a lissafin dake kasa. Idan kasarka/yankinka ba'a wakilta ta acikin lissafi ba tuntubi dilanka na gida. (Lambobin waya na kasa daidai suke a lokacin zuwa fitarwa. Koyaushe zaka iya samun sabuwar daukakawa a www.sonyericsson.com.)

Kasa	lambar waya
Ostiraliya	1-300 650 050
Ajantina	800-333-7427
Ostiriya	0810 200245
Baljiyam	02-7451611
Burazil	4001-0444
Kanada	1-866-766-9374
Afirka ta tsakiya	+27 112589023
Cile	123-0020-0656
Cana	4008100000
Kwalambiya	18009122135
Kurwatiya	062 000 000
Jumhuriyar ciz	844 550 055
Denmak	33 31 28 28
Finlanda	09-299 2000
Faransa	0 825 383 383
Janus	0180 534 2020
Gires	801-11-810-810 210-89 91 919 (daga wayar hannu)
Hon Kon	8203 8863
Hungari	+36 1 880 47 47
Indiya	1800 11 1800 (Lambar kiran kyauta) 39011111 (daga wayar hannu)
Indunusiya	021-2701388
Irlanda	1850 545 888
Italiya	06 48895206

Acikin abin aukuwa wanda ba'a soba cewa samfur naka yana bukatar sabis, tuntubi dilan da aka saya daga wurinsa, ko daya daga abokan sabis namu. Ajiye shaidar sayanka, zaka bukaceta idan kana bukatar garanti.

Za'a cajeeka a kira zuwa daya daga Wuraren Kiranmu gwargawdon kimar kudin kasa, hadi da harajin gida, sai dai idan lambar wayar lambar kyauta ce.

Adireshin email

questions.AU@support.sonyericsson.com

questions.AR@support.sonyericsson.com

questions.AT@support.sonyericsson.com

questions.BE@support.sonyericsson.com

questions.BR@support.sonyericsson.com

questions.CA@support.sonyericsson.com

questions.CF@support.sonyericsson.com

questions.CL@support.sonyericsson.com

questions.CN@support.sonyericsson.com

questions.CO@support.sonyericsson.com

questions.HR@support.sonyericsson.com

questions.CZ@support.sonyericsson.com

questions.DK@support.sonyericsson.com

questions.FI@support.sonyericsson.com

questions.FR@support.sonyericsson.com

questions.DE@support.sonyericsson.com

questions.GR@support.sonyericsson.com

questions.HK@support.sonyericsson.com

questions.HU@support.sonyericsson.com

questions.IN@support.sonyericsson.com

questions.ID@support.sonyericsson.com

questions.IE@support.sonyericsson.com

questions.IT@support.sonyericsson.com

Litaniya	8 700 55030	questions.LT@support.sonyericsson.com
Malesiya	1-800-889900	questions.MY@support.sonyericsson.com
Megziko	01 800 000 4722 (lambar kiran kyauta ta kasar waje)	questions.MX@support.sonyericsson.com
Nezalanda	0900 899 8318	questions.NL@support.sonyericsson.com
New Zealand	0800-100150	questions.NZ@support.sonyericsson.com
Nowey	815 00 840	questions.NO@support.sonyericsson.com
Fakistan	111 22 55 73	questions.PK@support.sonyericsson.com
Filifin	Autsayid Karaci: (92-21) 111 222 55 73	questions.PH@support.sonyericsson.com
Foland	+63 (02) 7891860	questions.PL@support.sonyericsson.com
Fotugal	0 (Fihirisa) 22 6916200	questions.PT@support.sonyericsson.com
Romaniya	808 204 466	questions.RO@support.sonyericsson.com
Rasha	(+4021) 401 0401	questions.RU@support.sonyericsson.com
Singafora	8(495) 787 0986	questions.SG@support.sonyericsson.com
Sulobakiya	67440733	questions.SK@support.sonyericsson.com
Afirka ta kudu	02-5443 6443	questions.ZA@support.sonyericsson.com
Isbaniya	0861 632222	questions.ES@support.sonyericsson.com
Suwidin	902 180 576	questions.SE@support.sonyericsson.com
Suwizaland	013-24 45 00	questions.CH@support.sonyericsson.com
Taiwan	0848 824 040	questions.TW@support.sonyericsson.com
Tailand	02-25625511	questions.TH@support.sonyericsson.com
Taki	02483030	questions.TR@support.sonyericsson.com
Yukren	0212 47 37 777	questions.UA@support.sonyericsson.com
Kasar imarat	(+380) 44 590 1515	questions.AE@support.sonyericsson.com
Kasar burtaniya	43 919880	questions.GB@support.sonyericsson.com
Amurka	08705 23 7237	questions.US@support.sonyericsson.com
Benzawela	1-866-766-9374	questions.VE@support.sonyericsson.com
	0-800-100-2250	

Jagorori don aminci da Ingantaccen Amfani

Karanta wannan bayanin kafin amfani da wayarka ta hannu.

An yi nufin wannan umarnin don amincinka. Bi wađannan jagorori. Idan samfur yazama dalili ga kowane



yanayi da aka lissafa a kasa ko kana da kowane kokwanto ga inganci aikinsa ka tabbatdar abokin sabis mai takardar sheda yaduba samfurin kafin biya ko amfani dashi. Gaza yin haka zai iya haifar da hadari na lalata samfur koma yuwuar cutarwa ga lafiyarka.

Yabo don amincin amfanin samfur (wayar hannu, baturi, caja da wasu na'urorin hadi)

- Koyaushe yi mu'amala da samfur naka da kulawa kuma alkinta shi cikin tsaftacacen wuri mara kura.
- **Gargadil** Zai yiwu yafashe in an zubar cikin wuta.
- Kada ka bijirar da samfurinka zuwa ruwa ko gumi ko danshi.
- Kada ka bijirar da samfurinka zuwa madaukauki ko makankancin zafi. Kada ka bijirar da baturi zuwa zafi sama da +60°C (+140°F).
- Kada ka bijirar da samfurinka zuwa budadden harshen wuta ko kunnanniyar taba.
- Kada ka yar, jifa ko kokarin lankwasa samfurinka.
- Kada ka yiwa samfurinka fenti.
- Kada kayi kokarin warware ko gyara samfurinka. Kabantaccen mai izini na Sony Ericsson kawai zai yi sabis.
- Kada kayi amfani da samfurinka kusa da kayan aikin likitanci ba tareda neman izini daga malamin lifiya naka ko likita mai izini.
- Kada kayi amfani da samfurinka lokacin cikin, ko daura da jirgin sama, ko wurare masu nuna alamar "turn off two-way radio".
- Kada kayi amfani da samfurinka cikin wuri inda sinadarin abin fashewa ke faruwa.
- Kada ka saka abin samfurinka ko shigar da kayan aiki marasa waya cikin wuri sama da jakar iska a motarka.

YARA

AJIYE NESDA ISAR YARA.
KADA KA BARI YARA SUYI WASA
DA WAYARKA TA HANNU KO
NA'URORIN HADINTA. ZASU IYA
CUTAR DA KANSU KO WASU, KO
DA TSAUTSAYI SU LALATA WAYAR HANNUN



KO NA'URAR HADINTA. WAYARKA TA HANNU KO NA'URAR HADINTA ZATA IYA KUNSAR KANANAN SASSA WADANDA ZASU IYA ZAMA YANKAKKU KUMA DA HAIFAR DA HADARI MAI CUTARWA.

(Caja) Mai bada wuta

Hada adaftar wutar AC zuwa tsarrun cibiyoyin wuta kawai kamar yadda akai alama a samfurin. Tabbarat agiyar na wurinta don haka bazata zama dalilin lalacewa ko damuwa ba. Don rage hadarin jan lantarki, cire kidaya daga kowacce cibiyar wuta kafin yunkurin tsabtace ta. Dole baza ayi amfani da adaftar wutar AC a waje ko cikin lataltattin wurare ba. Kar ataba canza agiya ko filogi. Idan filogi baidace da gurbii ba, sami gurbii mai dacewa da aka shigar ta kwararren mai lantarki.

Yi amfani kawai da Kwakkwar cajar asali ta Sony Ericsson da akaiy nufi don amfani tareda wayarka ta hannu. Zai yiwu wasu cajojin ba'a kerasu da amincin irir daya ba da kuma matakinti aiki.

Baturi

Mun bada shawara cewa kayi cikakken cajin baturi kafin kayi amfani da wayarka ta hannu da farko. Sabon baturi ko wanda aka jima ba'a yi amfani dashi ba zai iya rage karfi 'yan lokutan farko da akaiy amfani dashi. Za'a yi cajin baturin ne kawai cikin yanayin zafi tsakanin +5°C (+41°F) da +45°C (+113°F).

Yi amfani kawai da kwararrun baturan asali na Sony Ericsson da akaiy nufi don amfani tareda wayarka ta hannu. Yin amfani da wasu baturan zai iya zama hadari.

Magana da lokutan jiran aiki sun dogara da yanayi dabban-dabban kamar karfin sigina, yanayin zafin aiki, samfuram amfanin aikace-aikace, zababbin fasaloli da murya ko watsa bayanai lokacin da ake amfani da wayar hanun.

Kashe wayarka ta hannu kafin cire baturin. Kada ka sanya baturi a cikin bakinka. Wutar baturi zai zama mai guba idan an hadiya. Kada kabar karfen da yahadu da baturi ya taba wani abun karfe. Yin wannan zai iya gjarta da'ira da latata baturin. Yi amfani da baturi don dalilin da akayi nufi kawai.

Na'urorin likitanci na sirri

Wayoyin hannu zasu iya rinjayar aikin abubuwa masu bugawa da wani shukkaken kayan aiki. Guji sanya wayar hannun saman abu mai bugawa, misali, a cikin alijhun nono. Lokacin amfani da wayar hannun, yi amfani da ita a kunne akan gefen jiki daura da abu mai bugawa. Idan kamarar tazara ta cm 15 (inci 6) tana tsakanin wayar hannu da abu mai bugawa, hadarin kutsawa ya iyakance. Idan kanada kowane dallilin zargin cewa kutsawa na faruwa, kashe wayarka ta hannu da gaggawa. Tuntubi likitanka na zuciya don karin bayani.

Don wasu na'urorin lafiya, shawarci malamin lafiyarka da makerin na'ur.

Tuki

Bincika idan dokokin gida da ka'idoji sun killace amfani wayar hannu yayin tuki ko nemi direbobi suyi amfani da hallin abun sawa a kunni. Muna ba da shawara cewa kayi amfani da hallin abun sawa akunni na Sony Ericsson kawai wanda akayi nufin amfani tareda samfurinka.

Kula cewa saboda yiyuwat kutsawa zuwa kayan lantarki, wasu makeran abin hawa suna hana amfani da wayar hannu a cikin abin hawansu sai dai idan or shigar da abun sawa a kunni tareda eriyar waje.

Bada cikakkイヤ Kulawa ga tuki koyaushe da barin titi da tsawayo kafin yin ko amsa kira idan halin tuki ya bukaci haka.

Kiran gaggawa

Wayoyin hannu masu aiki da amfanin sigina na rediyo, wanda ba garantin hadi a cikin dukkan yanayi. Don haka kada kafiyi dogaro da kowacce wayar hannu don mahimmiyar sadarwa (misali magani na gaggawa).

Kiran gaggawa bazai yiwu ba a cikin duk yankuna, akan duk cibiyoyin sadarwar salula, ko lokacin da takamaiman sabis na cibiyar sadarwa da/ko fasalolin wayar hannu ke cikin amfani. Bincika tareda mai baka sabis na gida.

Eriya

Wannan wayar ta kunshi ginanniyar eriyar ciki. Amfani da na'urorin eriya bana kasuwanci ta Sony Ericsson musamman don wannan kirar zai iya latata wayarka ta hannu, rage aiki, kuma zai kirikiri matakai na SAR a saman iyakokin da aka kafa (kalli kasa).

Ingantacen amfani

Rike wayarka ta hannu kamar yadda zakayiwa kowace waya. Kada ka rufe saman wayar lakacin da take cikin aiki, saboda wannan yana rinjayar ingancin kira kuma zai iya sa waya aiki ta kakkarfan matakai wuta fiye da yadda ake bukata, don haka gajeriyar magan da lokutan jiran aiki.

Mitar rediyo (RF) fiddawa da Specific Absorption Rate (SAR)

Wayarka ta hannu tana da kamarar wutar watsawa da karba. Lokacin da aka kunna ta, tana bude matakai karfi na kasa na mitar rediyo (kamar yadda aka sansu da igiyoyi ko filayan mitar rediyo).

Gwammatocin duniya sun karbi jajororin lafiya na waje wanda aka fahimta, ginannu ta kungiyoyin ilimin kimiyya da fasaha, misali, ICNIRP (International Commission on Non-Ionizing

Radiation Protection) da IEEE (The Institute of Electrical and Electronics Engineers Inc.), ta hanyar juyi da kimanta karatun ilimin kimiyta da fasaha. Wadannan jagororin sun kafa matakhan izini na fiddawar igiyar rediyo don adadi gaba daya. Matakhan sun hada da keraren murfi don tabbatar da lafiyar duk mutane, bada la'akari da shekuru da lafiya ba, da yin bayani don kowanne banbanci cikin aunawa.

Specific Absorption Rate (SAR) sashi ne na aunawa don adadin kuzarin mitar rediyo samamme ta jiki lokacin amfani da wayar hanna. Kimar SAR an dai-dai tata a mafi girman tabbataccen matakhan wuta a cikin yanayin wurin binciken fasaha, amma ainihin matakhan SAR na wayar hanna yayin aiki zai iya zama kasa da wannan kimar. Wannan saboda wayar hanna an kerata ne don amfani da karamar wuta da aka bukata don isga ca biciyari sadarwa.

Sabani a cikin SAR kasan jagororin fiddawa na mitar rediyo bayan nufin cewa akwai sabani a cikin lafiya. Yayin da zai yiwu a sami banbance a cikin matakhan SAR tsakanin wayoyin hanna, duk sababbin kira na wayoyin hanna na Sony Ericsson an tsarasu don saduwa da jagororin fiddawa na mitar rediyo. Don wayoyin da aka sayar a Amurka kafin samun waya sabuwar kira don sayarwa ga jama'a, dolene babbar hukumar sadarwa ta kasa ta shaida (FCC) cewa bata ketare iyakar abubuwun da gwammnati takafa ba saboda amincin fitarwa. Anayin gwaje-gwaje a matsayi da wurare (shine, a kunnai da sanyawa akan jiki) kamar yadda FCC ta bukata a kowace kira. Don sawa a jiki, An gwada wannan wayar kuma tagamu da jagororin fiddawa na FCC RF lokacin da wayar hanna take a matsayin karancin 15 m daga jiki ba tareda kowanee sassa na karfe a cikin kusancin waya ko lokacin amfani tareda na'urur hadi ta asali ta Sony Ericsson wadda akayi nufi don wannan wayar da sawa a jiki. Amfanin wasu na'ururin hadi bazai iya tabbatar da hadin kai tareda jagororin fiddawa na FCC RF.

Wararren sharhi tareda bayanin SAR gameda wannan sabuwar kira na wayar hanna gamida kayan aiki suna rakiyar wannan wayar hanna. Hakanan za'a iya samun wannan bayanin, tareda karin bayani gameda fitarwa na mitar rediyo da SAR, a: www.sonyericsson.com/health.

Hanyoyin Magani/Bukatun musamman

Don wayoyin da aka sayar a Amurka, zaka iya amfani da alamar TTY taka tareda wayar hanna ta Sony Ericsson taka (tareda na'urur hadi mai mahimmanci). Don bayani akan hanyoyin halli ga kowane mutum mai bukata ta musamman kira wurin bukata na musamman na Sony Ericsson a 877 878 1996 (TTY) ko 877 207 2056 (murya), ko ziyarci Wurin Bukatu na Musamman na Sony Ericsson a www.sonyericsson-snc.com.

Zubar da tsofaffin kayan wuta da lantarki

Wannan alamar tana nuni cewa duk kayan wuta da lantarki da suka kunsa baza ayi ma'amala dasu azaman marasa amfani na gida ba. Maimakon haka za'a barta a matattara mai dacewa don sake kirar kayan wuta da lantarki. Ta tabbatar da an zubar da wannan samfur dai-dai, zaka taimaka kiyye yiwiwar abinda zai biyo baya na akasi ga mahalli da lafiyar dan adan, wanda in ba haka ba zai iya faruwa ta batacciyar ma'amala mara dacewa ga samfur. Juyin kayayyaki zai taimaka wurin kiyye arzikin kasa. Don karin cikakken bayani game da juyin wannan samfur, tuntubi ofishin garin na gida naka, sabis naka na zubar da marasa amfani na gida ko kantin inda ka sayi samfur.



Zubar da baturin

Bincika dokokin gida don zubar da baturu ko kira wurin kiran Sony Ericsson na gida don bayani.

Kar a taba ajiye baturi a sharar gari. Yi amafani da wurin zubar da baturi in akwai.



Katin kwakwalwar ajiya

Samfurinka yazo cikakke tareda katin Kwakwalwar ajiya wanda za'a iya cirewa. Gaba daya mai dacewane tareda wayar hannun da aka saya amma maiyuwa bazai dace da wasu na'urori ko fadin katinan kwakwalwar ajiyaruso ba. Bincika wasu na'urorin don dacewaa kafin sayo ko amfani.

An tsara katin kwakwalwar ajiyar kafin dauka a jirgin ruwa. Don sake tsarin katin kwakwalwar ajiya, yi amfani da na'ura mai dacewa. Kada ka yi amfani da tabbataccen salon aikin tsari lokacin tsara katin kwakwalwar ajiyar akan PC. Don cikakken bayani, koma zuwa umarnin aiki na na'uror ko tutubi goyan bayan mai karfa.

GARGADI:

Idan na'urarka tana bukatar adalta don sakawa a cikin wayar ko wata na'ura, kada ka saka katin kai tsaye ba tareda adalta da ake bukata ba.

Gargadi akan amfani da katin kwakwalwar ajiya:

- Kada ka aje katin kwakwalwar ajiya a danshi.
- Kada ka taba wurin hade-hade da hannunka ko da wani abin karfe.
- Kada ka goge, lankwasa, ko jefar da katin kwakwalwar ajiyar.
- Kada kayi kokarin warware ko gyaggyara katin kwakwalwar ajiyar.
- Kada kayi amfani ko aje katin kwakwalwar ajiya cikin gumi ko wurare masu zagwanyewa ko cikin hucin zafi kamar kullaliyar mota cikin kaka, cikin hasken rana kai tsaye ko kusa da mai dumama ruwa, da sauransu.
- Kada ka latsa ko lankwasa karshen adalta katin kwakwalwar ajiya da karfi wanda yawuce iyaka.
- Kada abar datti, kura ko bakon abubuwa su shiga zangon sa kowane adalta kwakwalwar ajiya.
- Bincika ka kasa katin kwakwalwar ajiyar dai-dai.
- Sa katin kwakwalwar ajiyar indan har zai shiga cikin kowane adalta katin kwakwalwar ajiya ke bukata. Katin kwakwalwar ajiyar bazai yi aiki dai-dai ba hrsai an sa shi duka.
- Mun bada shawara cewa kayi kwafin ajiya na mahimman bayani. Baza mu dauki alhakin kowane rashii ko lalacewar abun ciki da kai ajiye akan katin kwakwalwar ajiya ba.
- Bayanai da akayi rakodi zasu iya lalacewa ko bacewa lokacin da ka cire adalta katin kwakwalwar ajiya, kashe wuta yayin tsara, karanta ko rubuta bayanai, ko amfani da katin kwakwalwar ajiya a cikin wurare masu taken rikicewar lantarki ko fili mai bada madaukakin lantarki.

Na'urorin hadi

Sony Ericsson yana bada shawarar amfani da na'urorin hadi na Sony Ericsson na asali don aminci da ingantaccen amfanin samfurinsa. Amfanin na'urorin hadi na bangare na uku zai iya rage aiki ko haifar da hadari ga lafiya ko amincinka.

GARGADI DA BABBAR MURYA:

Dai-daita karar mai juwuwa a tsanake lokacin amfani da na'urorin hadi masu juwuwa na bangare na uku don kaucewe matakana sauti wadafanda zai yiwu su zama cutarwa ga jinka. Sony Ericsson Bai gwada amfanin na'urorin hadi na bagare na uku tareda wannan wayar hannu ba. Sony Ericsson ya bada shawarar amfani kawai da na'urorin hadi masu juwuwa na asali na Sony Ericsson.

Kare Lasisin Yarjejeniyar Mai amfani

Wannan na'urar mara waya, gamida rashin iyakar kowane mai jarida da aka bayar tareda na'urar, ("Na'ura") ta kunshi software na sadarwar waya na Sony Ericsson AB da kamfanonin tarayyar sa ("Sony Ericsson") da wakilai da masu lasisinsa na bangare na uku ("Software").

Azaman mai amfani da wannan Na'urar, Sony Ericsson ya baka lasisi wanda ba kebabbe ba, wanda baza a iya canja masa wuri ba, wanda baza a iya sa hannu don amfani da software kawai a cikin rintsi tareda na'urar wadda a kanta aka shigar kuma/ko aka bayar tare. Babu wani abu acikin nan da za'a iya tawili azaman sayar da software ga mai amfanin wannan Na'urar.

Baza ka sake fitarwa, gyaggyarawa, rarrabawa, dawo da injiniya baya, harhada, sai dai canja ko amfani da kowace manufa don gane lambar tushe ta Sony Ericsson ko kowane abin da ya sahi software. Don kaucewa shakku, akowane lokaci ana haifa ka da canja wurin hakkin mallaka da wajibai zuwa software zuwa bangare na uku, tareda Na'urar da ka karbi software kawai, idan har wannan bangaren na uku ya amince a rubuce cewa ya amince da wadanan dokoki.

Kana da garantin wannan lasisi na amfanin tsawon rayuwat wannan na'ura. Zaka iya karar da wannan lasisi ta canja wurin duk hakkokin mallaka zuwa Na'urar wacce akanta ka sami software zuwa bangare na uku a rubuce. Idan ka gaza bada haafin kai ga kowane sharuduwa shiryayyu a wannan lasisin, zai kare da rinjayan gaggawa Sony Ericsson da wakilan sa na bangare na uku da masu lasisinsa sune ainihin karbabun masu mallaka da rike duk hakkokin mallaka, take da fa'ida a da zuwa Software. Sony Ericsson, da, zuwa mutuka cewa software ta kunshi kaya ko lambar bangare na uku, bangaren na uku, za'a bashi taken riba na uku na wadannan sharudda.

Inganci, gini da aikin wannan lasisi zasu kasance karkashin dokokin Suwidin. Kayan zasu yi aiki sosai da izinin da aka bayar ta, lokacin aiwatarwa da damar hakkokin mabukata.

Garanti mai iyaka

Saadarwar waya na Sony Ericsson AB, SE-221 88 Lund, Sweden, (Sony Ericsson) ko kamfanin su na cikin gida, suna bada kayyadajien garanti don wayarka ta hannu da na'urar hadi ta asali da aka kawo tareda wayarka ta hannu (nan gaba ka koma ga "Samfuri").

Shin samfurinka yana bukatar sabis, komar dashi wurin dilan da aka saya a wurinsa, ko tuntubi Wurin Kiran Sony Ericsson na gida (za'a iya amfani da kimar kudin kasa) ko ziayrci www.sonyericsson.com don samun bayani na gaba.

GARANTINMU

Karkashin sharuddan wannan garantin mai iyaka, Sony Ericsson yayi garantin wannan samfurin, don zama mai inganci kira, kayan aiki da kwarewa ma'aikata a asalin lokacin da mai karba ya saya, kuma don lokacin amfani na shekara daya (1).

ME ZA MUYI

Idan, yayin lokacin garanti, wannan samfurin ya gaza aiki karkashin amfani da sabis na al'ada, saboda matsalar kira, kayan aiki ko kwarewa, masu rabawa na Sony Ericsson masu izini ko abokan sabis, acikin Kasar/yankin* inda ka sayi Samfurinka, zasu, a zabubukansu, kodai gyara ka musanya Samfurin gwargwadon sharuddan da halayen da aka shimpida aciki.

Sony Ericsson da abokan sabis nasa sun tanadi haksi don cajin karba kyauta idan Samfurin an same shi baya karkashin garanti gwargwadon sharuddan kasa.

Lura cewa wasu saitunanka na sirri, saukewa ko wani bayani maiyuwa ya bace lokacin da aka gyara ko musanya Samfurinka na Sony Ericsson. A halin yanzu zartattun dokoki suna iya kiyaye Sony Ericsson, wadansu ka'idoji ko kuntatawa na fasaha daga yin kwafin takamammiyar saukewa. Sony Ericsson baszai dauki kowane alhakin bacewar kowane irin bayani ba kuma bazai mayar maka da kowacce irin asara ba. Kayi koyaushe kwafin ajiya na duk ajiyyayen bayani akan Samfurinka na Sony Ericsson kamar saukewa, kalanda da lambobi kafin bada samfurinka na Sony Ericsson don gyara ko sauyawa.

SHARUDDA

- 1 Garantin yana aikin ne da idan akwai shedar sayen na asali daga hannun dillali mai wakilcin Sony Ericsson, da tabbacin taririn saye da lambar siriyal**, don wannan Samfur, wanda aka bada shi tareda Samfurin don gyara ko sauyawa. Sony Ericsson ya tanadi hakkin kin sabis na garanti idan an cire ko canja wannan bayanin bayan asalin sayen Samfurin daga dilan.
- 2 Idan Sony Ericsson na gyara ko sauya Samfur, Samfur da aka gyara ko aka sauya, za'a bashi garanti zuwa raguwar loakacin garanti na asali ko kwana (90) daga kwanan watan da aka gyara, duk tsawon sa. Gyara ko sauyawa zai iya shafar amfanin aikin gyararriyar kidaya dai-dai. Juzu'ai da aka sauya ko aka gyara zasu zama mallakar Sony Ericsson.
- 3 Wannan garantin bazai maye kowace asarar samfur sakamakon lalacewa da tsagewa ta al'ada, ko sakamakon rashin iya ma'amala, gami da amma bai iyakance don amfani fiyeda yanayin amfani na al'ada dangane da umarnin Sony Ericsson don amfani da kiyaye Samfur. Hakanan wannan garantin bayi maye gurbin kowace lalacewar Samfur sakamakon hadari, gyara ko dai-dai ta software ko hardware, yin Allah ko lalacewa sakamakon shigar ruwa.
- 4 Tunda salon salulua wanda akan sa Samfur zaiyi aiki an bida shi ta mai daukai maicin gashin kansa daga Sony Ericsson bazai dauki nauyin aiki, samuwa, daukar hoto, sabis ko keyawon wangan salon ba.
- 5 Wannan garantin bazai maye gurbin lalacewar Samfur ba wanda yafaru ta shigarwa, dai-dai tawa, ko gyarawa ko bude samfur ta wani mutum mara izinin Sony Ericsson.
- 6 Garanti bazai maye gurbin lalacewar Samfur wanda yafaru ta amfani da na'urorin hadi ko wasu na'urorin kewayewa marasa alamar kusuwancin Sony Ericsson na asalin na'urorin hadi da akayi nufin amfani tareda Samfurin.
- 7 Barnatar da kowane tambarin dake kan Samfurin zai bata garanti.
- 8 BABU GARANTIN GAGGAWA, RUBUTACCE KO NA BAKA, SABANIN WANNAN BUGAGGEN GARANTI MAI IYAKA. DUK GARANTIN DA AKA GABATAR, BA TARE DA IYAKANCE GARANTIN CINIKI KO CANCANTA DON DALILII NA MUSAMMAN, AN IYAKANCE SU ZUWA LOKACIN WANNAN GARANTIN MAI IYAKA. BABU WANNA ABIN FARUWA DA

Za'a iya caji da cire cajin baturi mai cajuwa sau dari. Ko yaya, daga karshe zai lalace-wannan ba matsala bace. Yayin da aka kula lokacin magana ko jiran aiki yayi gajarta, lokacin zaka sauya baturinka. Sony Ericsson ya bada shawara cewa kayi amfani da batura ko caja yardaddu ta Sony Ericsson.

Kananan sabani a hasken nuni da launi maiyuwa yafaru tsakanin wayoyi. Zai yiwu kanana haske da digon duhu akan nuni. Akwi fatsi-fatsin na bayana da zaran kebantacen digon ya sami matsala kuma ba za'a iya daidai tawa ba. Ana matukar karbar fatsi-fatsa biyu marasa inganci.

Kananan sabani acikin bayyanar hoton kamara maiyuwa yafaru tsakanin wayoyi. Wannan ba sabon abu bane a kamarori masu lamba, kuma baya nufin cewa kamarar ta baci ta kowace hanya.

Tunda salon salulua wanda akan sa Samfur zaiyi aiki an bida shi ta mai daukai maicin gashin kansa daga Sony Ericsson bazai dauki nauyin aiki, samuwa, daukar hoto, sabis ko keyawon wangan salon ba.

Wannan garantin bazai maye gurbin lalacewar Samfur ba wanda yafaru ta shigarwa, dai-dai tawa, ko gyarawa ko bude samfur ta wani mutum mara izinin Sony Ericsson.

Garanti bazai maye gurbin lalacewar Samfur wanda yafaru ta amfani da na'urorin hadi ko wasu na'urorin kewayewa marasa alamar kusuwancin Sony Ericsson na asalin na'urorin hadi da akayi nufin amfani tareda Samfurin.

Barnatar da kowane tambarin dake kan Samfurin zai bata garanti.

BABU GARANTIN GAGGAWA, RUBUTACCE KO NA BAKA, SABANIN WANNAN BUGAGGEN GARANTI MAI IYAKA. DUK GARANTIN DA AKA GABATAR, BA TARE DA IYAKANCE GARANTIN CINIKI KO CANCANTA DON DALILII NA MUSAMMAN, AN IYAKANCE SU ZUWA LOKACIN WANNAN GARANTIN MAI IYAKA. BABU WANNA ABIN FARUWA DA

SONY ERICSSON DA MASU LASINSA ZASU
DAUKI ALHAKIN DOKA DON LALACEWAR
BAZATA KO MAI SABABI NA KOWANE HALI
KOWANE IRI YA KUNSA AMMA MARA IYAKA
DON RIBAR DA AKA RASA KO BACEWAR
CINIKI; ZUWA MATUKAR IYAKA DOKA BAZA
TA YARD A DA WANNAN LALACEWA BA.

Wasu kasashe/jahobi basu bada damar wariya ko
iyakancewar barna na bazata ko mai sanadi, ko
iyakancewar lokacin garanti da aka nuna, saboda
haka iyakancewar data gabata ko wariya mai
yiwuwa bazata zartu gareka ba.

Garantin da aka bayar baya tasiri ga dokar
hakkokin mallaka na mabukata karkashin dokar
shara'a maidacewa, bakuma hakkokin mallakar
mabukata akan dila wanda suka taso daga
yajejeniyar saye / sayarwa.

*TARAYYAR TURAI (EU)

Idan ka sayi Samfurinka a kasar tarayyar turai EU
Samfurinka zai yi sabis, a karkashin sharuddan
da aka shifida a sama, tsakanin lokacin garantin
a kowacce kasar tarayyar turai EU inda ake
saida irin Samfurin ta mai rabawa mai izinin
Sony Ericsson. Don gano idan Samfurinka ana
saida shi a kasar tarayyar turai EU inda kake, kira
Wurin Kiran Sony Ericsson na gida. Kula cewa
wasu takamaiman sabis baza su yiwu a wani wuri
inba cikin kasar asalin saya ba, misali saboda
batu na gaskiya shine mai yuwa Samfurinka
yana ginin ciki ko na waje wanda ya banbanta da
irinsa wanda aka sayar a wasu kasashen tarayyar
turai. Bazai yiwu a gyara samfura masu kulallen
SIM ba.

** A wasu kasashe/yankuna ana bukatar karin
bayani. Idan haka ne, An nuna wannan sarai a
ingantacciyar shaider saya.

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.



Fasaha mara waya ta Bluetooth

Bluetooth™ Kwararriyar Kirar ID itace B011122.

Declaration of Conformity

We, **Sony Ericsson Mobile Communications AB** of
Nya Vattentornet

SE-221 88 Lund, Sweden

declare under our sole responsibility that our product

Sony Ericsson type AAC-1052022-BV

and in combination with our accessories,

to which this declaration relates is in

conformity with the appropriate standards

3GPP TS 51.010-1, EN 301489-7, and EN 60950,

following the provisions of, Radio Equipment and

Telecommunication Terminal Equipment directive

99/5/EC with requirements covering EMC

directive **89/336/EEC**, and Low Voltage directive

73/23/EEC.

Lund, November 2006

CE 0682

A handwritten signature in black ink, appearing to read "Shoi Nemoto". It is written in a cursive style with a horizontal line underneath it.

Shoi Nemoto,
Head of Product Business Group GSM/UMTS
Mun cika sharuddan Bayanin R&TTE (99/5/EC).

Fihirisa

A

abin sawa akunni	11, 28, 29, 55
na'urar Bluetooth™	72
Abokaina	46
agogon awon gudu	81
aikace-aikace	65
aikawa	
alkawura da dawainiya	79
bayanan kula	80
hotuna	53
jigogi	55
katunan kasuwanci	35
launukan waka	
da sautunan ringi	62
aiki tare	70, 71
allon rubutu	34
alkawura	78
amsawar murya	29

B

baturi	
amfani da kula	94
sawa da yin caji	5
bayanan kula	80
bayanan martaba	82, 83
bugun kiran sauri	27
B	
boye lamba	34

C

canja wuri	
fayiloli	74
hotunan kamara	51
kida	57
cibiyoyin sadarwa	22
cire katangar katin SIM	83

D

Disc2Phone	56
dogayen sakonni	38

D

Daukaka sabis	76
dawainiya	79, 80

E

email	42
-------------	----

F

fara allo	53, 85
Fasaha mara waya ta Bluetooth ...	71
fuskar bangon waya	53

G

Gajerun hanyoyi	16
garanti	98
girman hoto	49
gumaka	16

H

halin kawowa	39
halin kwakwalwar ajiya	20
hanyar canja wuri	
Fasaha mara waya ta Bluetooth	71
USB	74
hotuna	52, 53
shiryawa	54
uwar garke allo	53

I

ikon murya	28, 30
Intanit	
alamun shafi	67
bayanan martaba	68
cookies da kalmomin	
wucucewa	69
saituna	65
shafi	51
tsaro da takaddun shaida	69

J

jagororin aminci	93
jigogi	55
jiran aiki	6
jiran kira	31

K

kafaffen bugun kira	33
kakuleta	81
kalanda	78, 79
kalmar sihiri	29
kamara	9
saituna	49
siffa	48
zabububuka	49
karkata kira	30
katin SIM	
kullewa da cire katanga	83
kwafi zuwa/daga	26
lambobin lamba	25
katin kwakwalwar ajiya	19, 97
katunan kasuwanci	35
Kebul na USB	74
kira	
amsa da kin amsa	23
gaggawa	23
karba	32
karbar kira biyu	31
na kasashen waje	22
sanyawa a riko	31
wanda aka rasa	23
yin bayanan kula yayin	34
yin kira da karba	7, 22
yin rikodi	64

kiran taro	31
kida	
canja wuri	57
fayilolin bidiyo	56
kullewa	
faifan maballi	84
katin SIM	83
waya	84

kunnawa/kashewa

Fasaha mara waya ta Bluetooth	71
kiyaye makullin SIM	84
makullin waya	84

kwanan wata	83
-------------	----

K

kara	
lasifikar tunni	23
sautin ringi	62
kararrawa	77
kungiyoyi	35

L

lambar PIN	
caji	84
cire katanga	4
lambobi	
aiki tare	70
tsoffin lambobi	24
kara lambobin waya	24
kungiyoyin tadi na	35

lambobina	32
lambobin kira a sako	37
lissafin kira	27
lissafin waka	58
lokaci	83
lokacin kira	34

M

M2™	11, 97
Mai karanta RSS	69
mai rikodin bidiyo	48
mai rikodin sauti	64
mai sarrafa fayil	19
mai kidayar lokaci	80
makirufo	23
makullin faifan maballi	15, 84
maballai	10, 14
memo na lamba	81
Menu na ayyuka	8
menus	14
menus na kewayawa	14
MusicDJ™	62

N

nuni, haske	85
-------------	----

P

PhotoDJ™	54
PlayNow™	61
PUK	4, 83

R	sakonnin hoto	39, 41
ramut	74	
rayarwa	53	
S	sakonnin murya	41
sabis d'in amsa	28	
saita maye	5	
saituna		
email	42	
hasken nuni	85	
Intanit	65	
Java™	68	
sake bugun kira ta atomatik	22	
sake saitin zuwa na ainihu	88	
samfura	38, 41	
saukar da fayiloli	68	
sauti, canja wuri da fuskantarwa ..	73	
sautunan ringi	61, 62	
sakon murya	28	
sakonni		
email	42	
halin kawowa	39	
hoto	39	
murya	41	
rubutu	36	
yanki da bayanin cell	48	
sakonnin rubutu	36, 39	
shafi	51	
shigar da haruffa	18	
siffar menu	12	
siffar waya	10	
SMS Duba sakonnin rubutu	36	
SOS Duba lambobin gaggawa	23	
T	T9™ Text Input	18
taimako	6	
takamaiman sautin ringi na mai kira ..	26	
tasiri, kamara	50	
TrackID™	59	
U	uwarr garke allo	53
V	VideoDJ™	63

W

wasanni	64
waya	
hadawa	4
kullewa	84
yare	17

Y

yare	86
yarukan rubutu	17

Z

zukowa	49
Dakin yanar sadarwa	67