

suprema



suprema Xpass

Smart IP Access Reader

TCP/IP Ready
Wiegand/RS485 Interfaces
IP65 Waterproof
Power over Ethernet

Contents

Safety precautions	3
Product components	5
Optional accessories	6
Names of each parts	7
Product Dimension	10
Cables and Connectors	11
Power Connection	14
LAN Connection	16
RS485 Connection	18
Relay Connection	20
Digital Input Connection	23
Wiegand Input/Output	25
Output	26
Installation of Wall-mount Bracket	27
Installation Reference	28
Specification	31
Electrical Specification	32
FCC Rules	33

Safety precautions



Do not install the device in a place subject to direct sun light, humidity, dust or soot.



Do not place the device next to heating equipments.



Do not place a magnet near the product.

▶ It may cause a damage or a failure to the product.




In cleaning, do not splash water on the device but wipe it out with smooth cloth or towel.



Be careful not to let liquid like water, drinks or chemicals leak inside the device.

▶ It may cause a failure.



Clean the device often to remove dust on it.

The list below is to keep user's safety and prevent any loss. Please read safety precautions carefully before use.

Safety precautions



Do not drop the device.



Do not disassemble, repair or alter the device.

▶ The warranty does not apply to any product damage caused by an arbitrary installation or repair.



Do not let children touch the device without supervision.



Do not use the device for any other purpose than specified.



Do not damage the device.



Contact your nearest dealer in case of a trouble or problem.


▶ The list above is to keep user's safety and prevent any loss. Please read safety precautions carefully before use.

Product components

Basic components



Xpass



bracket




Extended Ethernet Cable



Wall mounting screws
(2 ea)



Knife Blocks
(2 ea)



Shrinkable Tubes



Software CD

 The components shown above may differ depending on the installation environment.


Optional accessories




Secure I/O



Plastic stand




Extended bracket




adaptor

Names of each parts




● LED status



LED Status per Color		
Color	Sound	Description
Green	Beep Beep Beep	Authorization Success
Red	Be~ep	Authorization Fail
Pink	Beep!	On Processing
Flicker Blue/Sky-Blue Color per 2sec	No sound	Normal
Flicker Red/Pink Color per 2sec	No sound	Locked
Flicker Blue/Red Color per 2se	No sound	Initialized Time due to the Internal Battery Discharge
Flicker Blue /Yellow Color per 2sec	No sound	IP address is not assigned when terminal is set as 'Use' in the 'DHCP' of 'TCP/IP Setting'
For first operation, red LED is blinking by every 2 seconds.	No sound	Failed. Please contact to your distributor or Suprema
For normal operation, red LED is blinking by every 2 seconds.	No sound	Security status
Yellow LED is blinking shortly.	No sound	Terminal is send or received a packet to get IP address when terminal is set as 'Use' in the Idle status or 'TCP/IP Setting'

● Initialization of network setting

When you install the Xpass or forget the network setting's value of Xpass in use, can initial the network setting's value (TCP/IP address, RS-485 setting) in the switch of Xpass's back side as follows;




Initializing the network setting

1. Press the Reset button in the switch of Xpass's back side for 3 second or above.
2. Connect between Xpass and Biostar Client(Ver.1.25 or higher) by using TCP/IP or RS-485.
 - Network default setting value
 - TCP/IP Address(Fixed): 192.168.0 bps(Not Checked: Use Server)
 - RS-485 : PC Connection, 115200 bps
3. Enter th desired value of TCP/IP address or RS-485 to change setting value. And save setting value.
4. After delete the Xpass among devices list, re-connect bewteen Xpass and BioStar using the new TCP/IP address or RS-485 setting.

Product Dimension


(unit : mm)




< Front View >



< Side View >




< Bracket >




< Extended bracket >

Cables and Connectors




A Cross Section of Cable



No	Pin Name	Color
1	485 GND	White (black string)
2	Wiegand-GND	Black
3	485 -	Yellow (black string)
4	Wiegand-1	White
5	485 +	Blue (white string)
6	Wiegand-0	Green
7	Input-1	Brown
8	Relay Open	Gray (white string)
9	Input-GND	Gray
10	Relay Com	Green (white string)
11	Input-0	Purple
12	Relay Close	Orange (black string)
13	TX+ (LAN)	Pink
14	Power IN+	Red
15	TX- (LAN)	Orange
16	Power IN-	Black (white string)
17	RX+ (LAN)	Blue
18	Power OUT+	Light Blue
19	RX- (LAN)	Yellow
20	Power OUT-	Black (white string)
21	VB1	Green (black string)
22	VB2	Brown (white string)
23	VB1	Green (black string)
24	VB2	Brown (white string)

Cables and Connectors

● Cable Specification




Pin	Pin Name	Color	
1	Relay	RLY NC	Orange (black string)
2		RLY COM	Green (white string)
3		RLY NO	Gray (white string)
4	Wiegand	WGD D0	Green
5		WGD D1	White
6		WGD GND	Black
7	Switch	IN 0	Purple
8		IN 1	Brown
9		IN GND	Gray
10	485	485+	Blue (white string)
11		485-	Yellow (black string)
12		485 GND	White (black string)




Pin	Pin Name	색상	
3	Power	POWER OUT -	Black (white string)
		POWER OUT +	Light Blue
		POWER IN -	Black (white string)
		POWER IN +	Red

LAN cable



Pin	Pin Name	Color
1	RX-	Yellow
2	RX+	Blue
3	TX-	Orange
4	TX+	Pink
5	VB1	Green (black string)
6	VB1	Green (black string)
7	VB2	Brown (white string)
8	VB2	Brown (white string)


Ethernet extension cable



Modular Jack (A)	Connector (B)	Pin Name	Color
1	4	TX+	Blue
2	3	TX-	Orange
3	2	RX+	Black
4	1	RX-	Yellow
5	5	VB1	Red
6	6	VB1	Green
7	7	VB2	Brown
8	8	VB2	Gray

Power Connection 1

Pin	Pin Name	Color
14	POWER IN+	Red
16	POWER IN-	Black (white string)




Recommended power supply

12V \pm 10%, at least 500mA.

Comply with standard IEC/EN 60950-1.

To share the power with other devices, use a power supply with higher current ratings.


Power Connection 2




Recommended power supply

Please use the distance of LAN cable within 100m in case of POE power.

LAN Connection




LAN Connection (Direct connection with PC)




RS485 Connection for Host Communication

Pin	Pin Name	Color
1	485 GND	White (black string)
3	485 -	Yellow (black string)
5	485 +	Blue (white string)



RS485 Connection for Secure I/O

Pin	Pin Name	Color
1	485 GND	White (black string)
3	485 -	Yellow (black string)
5	485 +	Blue (white string)




Max number of devices

Maximum eight(8) devices (including Master) interworks in an RS485 loop.


Relay Connection – Fail safe lock

Pin	Pin Name	Color
10	RLY COM	Green (white string)
12	RLY NC	Orange (black string)




Relay Connection – Fail secure lock

Pin	Pin Name	Color
8	RLY NO	Gray (white string)
10	RLY COM	Green (white string)




Relay Connection - Automatic door

Pin	Pin Name	Color
8	RLY NO	Gray (white string)
10	RLY COM	Green (white string)




Digital Input Connection (Alarm, Emergency S/W)

Pin	Pin Name	Color
7	IN 1	Brown
9	IN GND	Gray
11	IN 0	Purple




Digital Input Connection (RTE, Door sensor)




Wiegand Input/Output

Wiegand Input




Wiegand Output



Output


Pin	Pin Name	Color
10	RLY COM	Green (white string)
12	RLY NC	Orange (black string)
18	PWR OUT +	Light Blue
20	PWR OUT -	Black (white string)




Caution : Max. 700mA is supplied using adapter for the external output.
Be careful to satisfy the power capacity in use.

Installation of Wall-mount Bracket


- Fix wall mount bracket on a wall using wall mounting screws




- Hook Xpass on the wall mount bracket




- Fix Xpass and wall mounting bracket using a wall mounting screw.




Installation Reference 1 - Stand alone



Installation Reference 2 – Standalone (Secure)



Installation Reference 3 – Network



Specification

CPU	32 bit Micro-processor
Memory	8MB FLASH + 16MB SDRAM
RF Card	13.56 MHz Mifare (XPM) 125 KHz EM Prox (XPE) 125 KHz HID Prox (XPH)
User Capacity	40000 user
Log Capacity	50000 log
Network interfaces	TCP/IP, RS485
IP Rate	IP 65 class
Sound	Multi-tone buzzer
LED	Multi-color LED
RTC	Lithium-ion rechargeable batteries
I/O	Relay x 1 Tamper x 1 Switch input x 2 Wiegand x 1
Power	12Vdc, POE
Operating Temperature	-20 ~ 50° C
Size	45 x 130 x 27mm (W x H x D)
Certificates	CE, FCC, KCC, IP65



Caution for RTC Battery

It may be occurred the risk of explosion for improper replacement of battery.
Please use the specified battery according to proper instruction.

Electrical Specification

	Min.	Typ.	Max.	Notes
Power				
Voltage (V)	10.8	12	13.2	Use regulated DC power adaptor only
Current (mA)	-		140	
Switch Input				
VIH (V)	-	TBD	-	
VIL (V)	-	TBD		
Pull-up resistance (Ω)	-	4.7k	-	The input ports are pulled up with 4.7k resistors
TTL/Wiegand Output				
VOH (V)	-	5	-	
VOL (V)	-	0.8	-	
Pull-up resistance (Ω)	-	4.7k	-	The outputs ports are open drain type, pulled up with 4.7k resistors internally
Relay				
Switching capacity (A)	-	-	1 0.3	30V DC 125V AC
Switching power (resistive)	-	-	30W 37.5V A	DC AC
Switching voltage (V)	-	-	110 125	DC AC

FCC Rules

Caution

Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interface, and (2) this device must accept any interface received, including interference that may cause undesired operation.

Information to User

This equipment has been tested and found to comply with the limit of a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, user and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation; if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more the following measures:

1. Reorient / Relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit difference from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help



Suprema Inc.
16F Parkview Office Tower, Jeongja-dong, Bundang-gu,
Seongnam, Gyeonggi, 463-863 Korea
E-mail : support@supremainc.com
Website : www.supremainc.com

Functions and specifications of the product are subject to changes without notice due to quality enhancement or function update. For any inquiry on the product, please contact Suprema Inc.