

Quick Start Guide

For more information about how to use the phone, please go to www.alcatelone-touch.com to download complete user manual. Also on our website you can find helpful FAQs, software upgrade, etc.

ALCATELone touch.


English - CJB3281ALAAB

Table of contents

1	Your mobile.....	3
2	Getting started.....	8
3	Making a call.....	9
4	Menu arrange.....	10
5	Messaging.....	10
6	Email.....	11
7	Contacts.....	12
8	Call log.....	12
9	Media applications.....	13
10	Internet.....	14
11	Apps.....	15
12	Facebook.....	15
13	Entertainment.....	15
14	Camera.....	16
15	Profiles.....	16
16	File manager.....	17
17	Bluetooth™.....	17
18	Wi-Fi.....	17
19	Tethering.....	18
20	Others.....	18
21	Settings.....	20
22	Making the most of your mobile.....	20
23	Input mode.....	22

Your mobile

1.1 Keys and connectors



⚠ Prolonged exposure to music at full volume on the music player may damage the listener's hearing. Set your phone volume safely. Use only headphones recommended by TCT Mobile Limited and its affiliates.

4 Menu arrange

It is designed to vary according to your preference.

Change the order

Access the main menu, focus on the main menu item you want to move, select "Options"Move", and tick "N" will be shown on the item you selected, then release it to your favorite destination.

Show/Hide

Access the main menu, select "Options"Add and remove menu", and select the left check box of the selected menu once to show/hide, and then select "Done" to save the operation.

5 Messaging

5.1 Access

You may access this menu using the following options:

- Access from the main menu by selecting "Messaging".
- Select from widget bar, and then enter the sub-menu you require.

5.2 Conversational On (Off) mode

In conversational on mode, you can view chat history in chronological order. In conversational off mode, you may have access to the following folders: **Inbox, Outbox, Sent, Drafts, Voicemail, Broadcast SMS, Empty folder, Archive, Templates, Settings.** Conversational view mode is set as default. You may switch to conventional mode by selecting "Options"Settings"Switch view mode".

5.3 Write message

You can select "Messaging"Write new SMS/MMS" from the main menu or access from widget to write text/multimedia message. One or more recipients can be added from contact list and you can remove a recipient by pressing Delete key. Press "Contacts" through key to multi-select recipients from Contacts.

An SMS will be converted to MMS automatically when images, videos, audio, slides or attachments are inserted; Subject, CC/BCC/email address is added; or the message contains more than 8 pages of text.



An SMS message of more than a certain number of characters (the number of characters depends on your language) will be charged as several SMS. An MMS message containing photos and/or sounds may also be billed as more than one message. Specific letters (accent) will increase the size of the SMS, this may cause multiple SMS to be sent to your recipient.

6 Email.....

Your phone has an email client with the settings pre-defined for a few popular email services like - Gmail, Yahoo, AOL, etc. Besides this, you can set up other POP3 or IMAP4 email accounts that you may be using.

7 Contacts.....

7.1 Accessing your contacts

You can access this function by selecting "Contacts" from the main menu.

7.2 Adding a contact

You can add a new contact to phone or SIM card by selecting "Create new".

8 Call log

8.1 Access

You can access the function using the following options:

- Select from main menu
- Press key from Home screen
- Select from widget bar, and then enter the sub-menu you require.

8.2 Available options

When you press "Options", you can have access to **Send message, Dial, Missed calls, Call settings, Edit before call, Delete, etc.**

- Press to go left/right/up/down
- Press to confirm an option

- Answer/Send a call
- Enter Call log

- Press: End a call
Return to the Home screen
- Press and hold: Power on/off

- Vibrate alert

- Press and hold: Access your voicemail

- Press to input capitalized characters

- Press once: Input a top-half character
- Press twice: Lock the keyboard in top-half key input mode

- Press and hold: Input top-half characters only until key is released
- Fn + B: Access Bluetooth
- Fn + M: Access Music
- Fn + P: Access Profiles
- Fn + J: Access Java applications

- Press: Enter a space (on edit mode)
Confirm an option (on edit mode)
Unlock the keypad (on Home screen)
- Press and hold: Access language list (on edit mode)
Lock the keypad (on Home screen)

⁽¹⁾ The icons and illustrations in this guide are provided for informational purposes only.

9 Media applications.....

9.1 Music.....

You can access this feature from the main menu by selecting "Music". You will have full flexibility of managing music both on your mobile and SD card.

9.2 Images.....

A library links to the images both in phone and SD card to be shown in list, slide, multi-mark, set as wallpaper, power on/off display and incoming call image or sent by MMS, Email, Bluetooth, to Facebook.

9.3 Video.....

Contains all video clips both in phone and SD card and enables you to play, send, set as power on/off display, delete, rename, sort, etc.

9.4 Radio.....

Your phone is equipped with a radio⁽¹⁾ with RDS⁽²⁾ functionality. You can use the application as a traditional radio with saved channels or with parallel visual information related to the radio program on the display, if you tune to stations that offer Visual Radio service. You can listen to it while running other applications.

⁽¹⁾ The quality of the radio depends on the coverage of the radio station in that particular area.

⁽²⁾ Depending on your network operator and market.

- Press to enter Facebook main menu.

- Press: Confirm an option
Enter the next line (on edit mode)

1.2 Status bar icons ⁽¹⁾

Battery charge level.

Vibrate alert: Your phone vibrates, but does not ring or beep with the exception of the alarm.

Bluetooth status (Activated).

Bluetooth status (Connected to an audio device).

Java status (Activated).

Headset connected.

Call forwarding activated: Your calls are forwarded.

Alarm or appointments programmed.

Level of network reception.

Voicemail message arrived.

Missed calls.

⁽¹⁾ Depending on your network operator.

10 Internet ⁽¹⁾.....

10.1 WEB.....

WEB not only gives you the full Web experience where you stay in touch with your friends, obtain information, do your online banking etc., but also saves time by using compressed web pages.

10.2 WAP.....

Access WAP options: **Homepage, Bookmarks, Go to URL, Open file, Last web address, Recent pages, Offline pages, Service inbox, Settings.**

10.3 News.....

It is a huge time saver providing news updates from a website in a simple form.

Once subscribed to a channel, it gives you the ability to track and manage all your favorite RSS content on your mobile phone at anytime, anywhere!

10.4 Weather.....

Your phone is equipped with a weather function for consulting up to 3-day forecast of favorite cities.

10.5 mTweet.....

Twitter is a social networking and microblogging service that has gained notability and popularity worldwide. This feature enables phone users to exchange news updates and ideas with a community in the form of messages or posts. Posts are displayed on the author's profile page and delivered to the author's subscribers or followers. To open an account online, please go to: <http://m.twitter.com>.

⁽¹⁾ Depending on your network operator. May cause additional network charges for data flow to provide this service. Extra fees might also be charged in roaming states.

Call in progress.

Stopwatch is active.

Radio is on.

Email unread.

WAP messages ⁽¹⁾.

Roaming.

SD card scanning completed.

Line switching ⁽¹⁾: Indicates the selected line.

GPRS connection status (Activated).

GPRS connecting.

EDGE connecting.

EDGE attached.

2G network available.

3G network available.

Music active.

⁽¹⁾ Depending on your network operator.

11 Apps

Apps store is an online software store, where you can download and install applications and games to your phone.

12 Facebook

Facebook is a social utility that connects people with friends and others who work, study and live around them. You can select "Facebook" in main menu or press key on the keypad to enter the Facebook page, then you can access to **NewsFeed, Me, Messages, Friends, Photos, Events, Search, Notification and Settings.**

13 Entertainment.....

13.1 Stopwatch.....

The stopwatch is a simple application for measuring time with the possibility to register several results and suspend/resume measurement.

13.2 Ebook.....

A bookshelf contains the electronic books (.txt and .pdb file only). While reading the book, you may add bookmark, or reach the text by searching words, phrases (**Options**Find, **Options**Jump to).

⁽¹⁾ Depending on your country or your operator.

MMS receipt in progress.

Sending an SMS.

Sending a MMS.

Silence mode: your phone does not ring, beep or vibrate with the exception of the alarm.

SMS unread.

MMS unread.

(Flickering) Message list is full: Your phone cannot accept any new messages. You must access the message list and delete at least one message on your SIM card.

Flight mode.

1.3 Home screen

You can customize your Home screen by selecting "Personalize" through Right softkey.

1.3.1 Widget bar

Widgets are convenient shortcuts for quick access from the Home screen.

1.3.2 Change wallpaper

You can select a folder to choose one image as favorite wallpaper by selecting "Change wallpaper".

13.3 Java

Your ALCATEL ONE TOUCH phone may include ⁽¹⁾ some Java™ applications and games. You can also download new applications and games to your phone.

14 Camera.....

Your mobile phone is fitted with a camera for taking photos and shooting videos that you can use in different ways:

- store them as your creations in SD card or phone.
- send them in a multimedia message (MMS) to a mobile phone or an email address.
- send them directly by MMS, Email, Bluetooth, to Facebook.
- customize your Home screen.
- select them as incoming call image to a contact in your Contacts.
- transfer them by data cable or microSD card to your computer.

15 Profiles

With this menu, you may personalize ringtones for different events and environments.

⁽¹⁾ Depending on your country or your operator.

2 Getting started.....

2.1 Set-up

Removing or installing the back cover



Inserting or removing the SIM card

You must insert your SIM card to make phone calls. Please power off your phone and remove battery before inserting or removing the SIM card.



Place the SIM card with the chip facing downwards and slide it into its housing. Make sure that it is correctly inserted. To remove the card, press and slide it out.

Installing or removing the battery



Insert and click the battery into place, then close the telephone cover. Unclip the cover, then remove the battery.

16 File manager

You will have an access to all audio and visual files stored in phone or SD card in File manager. You can access a number of items with this option: **Audios, Images, Videos, Ebook, Creations, etc.**

Inserting the SD card:



Firstly, release the microSD card holder. Then insert the microSD card with the golden contact downward. Finally, turn down the microSD holder.

17 Bluetooth™


Access this feature by pressing "Menu" through Left softkey from the Home screen to enter the main menu, then selecting "Bluetooth".

18 Wi-Fi

To access this function, press "Menu" to enter the main menu, and select .

⁽¹⁾ Depending on your network operator.

Charging the battery



Connect the battery charger to your phone and outlet respectively.

⚠ To reduce power consumption and energy waste, when battery is fully charged, disconnect your charger from the plug; switch off Wi-Fi, Bluetooth or background-running applications when not in use; reduce the backlight time, etc.

2.2 Power on your phone

Hold down the key until the telephone powers on.

2.3 Power off your phone

Hold down the key from the Home screen.

3 Making a call

Dial the desired number then press the key to place the call. The number you entered can be saved to Contacts by selecting "Save". If you make a mistake, you may press Right softkey to delete the incorrect digits one by one, or you may press and hold Right softkey to delete all.

To end the call, press the key.

⁽¹⁾ Depending on your network operator.

19 Tethering.....

Tethering is a method for connecting a computer or other devices to the internet via an internet-capable mobile phone.

Access this feature by pressing "Menu" through Left softkey from the Home Screen to enter the main menu, then selecting "Tethering".

20 Others.....

20.1 Calendar.....

Once you enter this menu from main menu, there is a monthly-view calendar for you to keep track of important meetings, appointments, etc. Days with events entered will be marked in color.

ALCATEL is a trademark of Alcatel-Lucent and is used under license by TCT Mobile Limited.

All rights reserved © Copyright 2012 TCT Mobile Limited.

TCT Mobile Limited reserves the right to alter material or technical specification without prior notice.

⚠ Prolonged exposure to music at full volume on the music player may damage the listener's hearing. Set your phone volume safely. Use only headphones recommended by TCT Mobile Limited and its affiliates.



20.2 Calculator

Access this feature by selecting "Calculator" from the main menu. Enter a number, select the type of operation to be performed using the navigation keys, and enter the second number, then select "=" to display the result.

20.3 Notes

You can create a note in text format by accessing "Notes" from the main menu.

20.4 Memo

Accessing "Voice memo" from the main menu allows you to make voice or sound recordings.

20.5 Tasks

Enables you to easily manage and track the progress of a task with priorities. All the tasks will be sorted by due date.

20.6 Alarm

Your mobile phone has a built-in alarm clock with a snooze feature.

20.7 World clock

The World clock shows current local time and the time zone in different cities.

20.8 Converter

You can use the Weight and Length conversion by selecting the unit you wish to convert, then press to input the digits. Finally confirm with "OK".

21 Settings

From the main menu, select the menu icon and select the function of your choice in order to customize your telephone: **Phone settings, Call settings, Flight mode, Security settings, Networks, Connectivity, Check software update.**

22 Making the most of your mobile

PC suite

You can download PC Suite for free by visiting www.alcatelonetouch.com. The PC suite includes:

- **Backup/restore**
You can backup the important data in your mobile and restore them when needed.
- **GPRS modem**
Use your mobile phone to connect PC to the internet.
- **Multimedia Personalization**
Customize your mobile with images, animations and melodies.
- **Messages**
You can compose SMS/MMS easily on your PC and transfer them to your phone.

Supported Operating Systems

Windows XP/Vista/Windows 7.

19

20

The World Health Organization (WHO) considers that present scientific information does not indicate the need for any special precautions for use of mobile phones. If individuals are concerned, they might choose to limit their own or their children's RF exposure by limiting the length of calls, or using "hands-free" devices to keep mobile phones away from the head and body. (fact sheet n°193). Additional WHO information about electromagnetic fields and public health are available on the following website: <http://www.who.int/peh-emf>.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

For the receiver devices associated with the operation of a licensed radio service (e.g. FM broadcast), they bear the following statement: This device complies with Part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.

For other devices, they bear the following statement: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference (2) this device must accept any interference received, including interference that may cause undesired operation. Your mobile phone is equipped with a built-in antenna. For optimal operation, you should avoid touching it or degrading it.

28

