

# ALCATEL 30-20G ALCATEL 30-20D

## Quick Start Guide

For more information about how to use the phone, please go to [www.alcatelone-touch.com](http://www.alcatelone-touch.com) to download complete user manual. Also on our website you can find helpful FAQs, realize software upgrade, etc.



This product meets applicable national SAR limits of 1.6 W/kg. The specific maximum SAR values can be found in the RADIO WAVES section of this user guide.

[www.sar-tick.com](http://www.sar-tick.com)

When carrying the product or using it while worn on your body, either use an approved accessory such as a holster or otherwise maintain a distance of 10 mm from the body to ensure compliance with RF exposure requirements. Note that the product may be transmitting even if you are not making a phone call.




### PROTECT YOUR HEARING

To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding your device near your ear while the loudspeaker is in use.



**ALCATEL**  
**one touch**

## Your mobile .....



- 1 Navigation key: Menu/Confirm an option
- 2 Left softkey
- 3 Right softkey
- 4 Facebook key
- 5 Wi-Fi key
- 6 Answer/Send call
- 7 Call log (Idle screen)
- 8 Switch on/ Switch off
- 9 End call
- 10 Vibrate alert (press and hold)
- 11 Fn key

### 1.1 Keys

Navigation key  
Confirm an option (press the middle of the key)

Answer/Send a call  
Press: Enter Call log  
Press and hold: Enter Fake call

Press: End a call  
Return to the Home screen  
Press and hold: Power on/off

Left softkey

Right softkey

Press to enter Facebook main menu

Enter Wi-Fi list and refresh

Access your voicemail (press and hold)

In idle screen:  
Press and hold: Lock the keypad  
In edit mode:  
Press: input space  
Press and hold: switch language

### Fn

In idle screen:  
Press to access shortcuts  
Fn + B: Access to Bluetooth  
Fn + M: Access to Music  
Fn + P: Access to Profiles  
Fn + S: Access to Settings

In edit mode:  
Press once: Input a top-half character  
Press twice: Lock the keyboard in top-half character input mode, then press again to unlock top-half character input mode

Delete one by one (press)  
Delete one by one quickly (press and hold)

Move cursor to the next line

In edit screen:  
Press: Switch the uppercase and lowercase

### 1.2 Status bar icons <sup>(1)</sup>

#### In 3020G:

- Battery charge level.
- Vibrate alert: your phone vibrates, but does not ring or beep with the exception of the alarm.
- Bluetooth status (Activated).
- Bluetooth status (Connected to an audio device).
- Keypad locked.
- Headset connected.
- Alarm or appointments programmed.
- Voice message arrived.
- Missed calls.
- Radio is on.
- Roaming.
- SD card scanning completed.
- MMS receipt in progress.
- Sending a MMS.

### In 3020D:

- Call forwarding activated: your calls are forwarded.
- Level of network reception.
- EDGE connection status (Activated).
- EDGE connecting.

### 1.3 Home screen

#### 1.3.1 Widget bar

Widgets are convenient shortcuts for quick access from the Home screen. You can customize widget bar by "Settings\Phone settings\Widget bar".

#### 1.3.2 Change wallpaper

You can select a folder to choose one image as favorite wallpaper by selecting "Options\Set as Wallpaper".

<sup>(1)</sup> The icons and illustrations in this guide are provided for informational purposes only.

## 4 Messages.....

### 4.1 Access

You may access this menu using the following options:

- Access from the main menu by selecting "Messages".
- Select from widget bar, and then enter the sub-menu you require.

### 4.2 Write message

You can select "Messages\Write new SMS/MMS" from the main menu or access from widget to write text/multimedia message. For dual SIM model, you can type a message and select to send it to a recipient in either the SIM1 or SIM2 directory<sup>(1)</sup>. One or more recipients can be added from contact list and you can remove a recipient by pressing Delete key. Press "Contacts" through key to multi-select recipients from Contacts.

An SMS will be converted to MMS automatically when images, videos are inserted.



An SMS message of more than a certain number of characters (the number of characters depends on your language) will be charged as several SMS. An MMS message containing photos and/or sounds may also be billed as more than one message. Specific letters (accent) will increase the size of the SMS, this may cause multiple SMS to be sent to your recipient.

<sup>(1)</sup> 3020D only  
English - CJB271AALAAAN

<sup>(1)</sup> 3020D only