

Quick Start Guide

For more information about how to use the phone, please go to www.alcatelonetouch.com to download complete user manual (English version only). Also on our website you can find helpful FAQs (English version only).



www.sar-tick.com

This product meets applicable national SAR limits of 1.6 W/kg. The specific maximum SAR values can be found in the RADIO WAVES section of this user guide. When carrying the product or using it while worn on your body, either use an approved accessory such as a holster or otherwise maintain a distance of 15 mm from the body to ensure compliance with RF exposure requirements. Note that the product may be transmitting even if you are not making a phone call.




PROTECT YOUR HEARING

To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding your device near your ear while the loudspeaker is in use.



ALCATEL onetouch

Your mobile.....



- Navigation key: Menu/Confirm an option
- Left softkey
- Camera key
- Answer/Send call
- Call log (Idle screen)
- Right softkey
- Wi-Fi key
- Switch on/Switch off
- Vibrate alert (press and hold)
- Fn key

1.1 Keys

- Navigation key: Confirm an option (press the middle of the key)
- Answer: Send a call; In idle screen: Access call log (Redial) (press)
- Switch on/Switch off the telephone (press and hold); End call; Return to idle screen
- Left softkey
- Right softkey
- Access your voicemail (press and hold)

Fn

- In idle screen: Press and hold: Lock the keypad; In edit mode: Press: input space
- In edit mode: Press once: Input a top-half character; Press twice: Lock the keyboard in top-half key input mode, then press again to unlock top-half character input mode
- Delete one by one (press)
- Move cursor to the next line
- In edit mode: Press: Switch the input method
- Press: Open camera menu
- Press: Open Wi-Fi menu

1.2 Main screen icons (1)

- Battery charge level.
- Vibrate alert: your phone vibrates, but does not ring or beep.
- Headset connected.
- Keypad locked.
- Call forwarding activated: your calls are forwarded.
- Alarm programmed.
- Level of network reception.
- Missed calls.
- Roaming.
- GPRS connection status (Activated).
- GPRS connecting.
- Silence mode: your phone does not ring, beep or vibrate.
- SMS unread.
- Flight mode.
- Wi-Fi connected;
- Wi-Fi on but disconnected

(1) The icons and illustrations in this guide are provided for information purposes only.

2 Getting started.....

2.1 Set-up

Removing and installing the back cover



Removing and installing the battery



Removing and inserting the SIM card



Place the SIM card with the chip facing downwards and slide it into its housing. Make sure that it is correctly inserted. To remove the card, press it and slide it out.

Charging the battery (1)



Connect the battery charger to your phone and outlet respectively.

- The charging may take about 20 minutes to start if the battery is flat.
- Be careful not to force the plug into the socket.
- Make sure the battery is correctly inserted before connecting the charger.
- The outlet must be near to the phone and easily accessible (avoid electric extension cables).
- When using your telephone for the first time, charge the battery fully (approximately 3 hours). You are advised to fully charge the battery ().
- To reduce power consumption and energy waste, when battery is fully charged, disconnect your charger from the plug; reduce the backlight time, etc.



The charge is complete when the animation stops.

(1) Depending on your country.

2.2 Power on your phone

Hold down the key until the phone powers on.

2.3 Power off your phone

Hold down the key from the main screen.

3 Calls.....

3.1 Making a call

Dial the desired number then press the key to place the call. If you make a mistake, you can delete the incorrect digits by pressing the Right softkey. To hang up the call, press the Right softkey or the key.

Making an emergency call

If your phone is covered by the network, dial emergency number and press the key to make an emergency call. This works even without a SIM card and without typing the PIN code or unlocking the keypad.

3.2 Calling your voicemail (1)

To access your voicemail, hold down the W key.

(1) Contact your network operator to check service availability.

3.3 Receiving a call

When you receive an incoming call, press the key to talk and then hang up using the key.

3.4 Available functions during the call

During a call, you can use your contacts, messages, etc. without hanging up or dropping the call.

4 Messages.....

4.1 Create message

From the main menu select "Messages" to create message. While writing a message, select "Options" to access all the messaging options.



Specific letters (accent) will increase the size of the SMS, this may cause multiple SMS to be sent to your recipient.

5 Contacts.....

5.1 Consulting your contacts

To access the contacts from the main screen, press the key and select the icon from the menu.

5.2 Adding a contact

You can add a new contact to phone or SIM card by selecting "New" from the menu "Options".

6 Call log.....

You can access your call memory by pressing from the idle screen, and you will see Call log(s), Missed call(s), Dialed call(s), received call(s), Rejected call(s).

7 Facebook.....

From the main menu select "Facebook" to enter: <http://m.facebook.com/> by web-link.

8 Twitter.....

From the main menu select "Twitter" to enter: <http://m.twitter.com/> by web-link.

9 Browser.....

This function enables you to surf the Internet using the mobile phone.

Note: Consulting the local network operator for related fee and specific setup.

10 Camera.....

Your mobile phone is fitted with a camera for taking photos that you can use in different ways:

- store them in your "PhoneMemoryCard".
- customize your main screen.

Make sure that microSD card is well inserted before taking photos.

11 Music.....

Access this feature from the main menu by selecting "Music". You will have full flexibility of managing music on memory card.

Make sure that microSD card is well inserted before activating music.

12 Images.....

A library links to the images in memory card to be set as Wallpaper, Contact icon.

13 Videos.....

Use this function to play video files. Press to play/pause the video player, short press and to tune volume; press or to last or next video.

14 FM radio.....

Your phone is equipped with a radio (1). You can use the application as a traditional radio with saved channels or with parallel visual information related to the radio program on the display if you tune to stations that offer Visual Radio service. You can listen to it while running other applications.

To access volume interface, please press the key. Then you can adjust the volume by pressing the key.

15 Recorder.....

Use this function to record audio files. The phone support WAV, AMR or MP3. The recording file you stopped will be stored in my music list automatically.

(1) The quality of the radio depends on the coverage of the radio station in that particular area.

16 My files.....

You will have access to all audio and visual files stored in memory card in My files.

Inserting and removing the memory card:



Aim at the microSD card slot of the phone and metal surface of microSD card face downward, then push the microSD card gently, and the card will be inserted correctly. To remove the microSD card, slide it out.

Do not support hot plugging for microSD card.

17 Email.....

Your phone has an email client with the settings pre-defined for a few popular email services link - Gmail, Foxmail, Hotmail, etc. Besides this, you can set up other POP3 or IMAP4 email accounts that you may be using.

18 Alarm.....

Your mobile phone has a built-in alarm clock with a snooze feature.

19 Calculator.....

Enter a number, select the type of operation to be performed, and enter the second number, then press "=" to display the result.

20 Calendar.....

Once you enter this menu from the main menu, there is a monthly-view calendar for you to view.

21 Bluetooth.....

You can transfer data, such as music to other device using Bluetooth. Search the device and accept/transfer data. The received data is automatically stored in the directory.

22 World clock.....

The World clock shows current local time and the time zone in different cities.

23 Converter.....

Conversion support weight conversion and length conversion.

24 Fake call.....

You can create fake call through this function.

25 Call filter.....

Management and preview the whitelist and blacklist, and can enable blacklist, enable whitelist, also can turn off this feature.

26 Profiles.....

With this menu, you may personalize ringtones for different events and environments.

27 Wi-Fi.....

Using Wi-Fi, you can connect to the Internet when your phone is within range of a wireless network. Wi-Fi can be used on the phone even without a SIM card inserted.

28 Settings.....

From the main menu, select the menu icon and select the function of your choice in order to customize your telephone: Call settings, Phone settings, Display, Security, Connections.

29 STK.....

Contact your network operator to check service availability.

30 Latin input mode

To write messages, there are two writing methods:

- Normal (for English): this mode allows you to type a text by choosing a letter or a sequence of characters associated with a key.

- Predictive with the Cstar mode (for other languages): This mode speeds up the writing of your text.

Fn key Fn: Press once: Input a top-half character; Press twice: Lock the keyboard in top-half key input mode, then press again to unlock top-half character input mode

Space key : Press: input space

Shift key : Press: switch input mode

Del key : Press: delete one by one

