

## Advanced Functions

### 【Closed Caption】

Adjust Closed Captioning settings. only available under TV and AV source.  
Press OK / ► button to enter.

### Close Caption

#### 【CC Mode】

Turn Closed Captioning on/off.  
Press ◀ / ► button to select(CC Off / CC On / CC On Mute).

#### 【Analog CC】

Set Closed Captioning for standard(analog) program.  
Press ◀ / ► button to select(CC1 / CC2 / CC3 / CC4 / Text1 / Text2 / Text3 / Text4).

#### 【Digital CC】

Set Closed Captioning for digital program.  
Press ◀ / ► button to select(Off / Service1 / Service2 / Service3 / Service4 / Service5 / Service6).

### Close Caption

#### 【Option】

Adjust the digital Closed Captioning setting.  
Press OK / ► button to enter.

#### 【Mode】

Set the Mode of digital Closed Captioning. Automatic uses broadcaster's style.  
Press ◀ / ► button to select(Default / Custom).

#### 【Font Style】

Select from 8 font styles.  
Press ◀ / ► button to select(Default / Font 0 / Font 1 / Font 2 / Font 3 / Font 4 / Font 5 / Font 6 / Font 7).

#### 【Font Size】

Adjust the size of the digital Closed Captioning font.  
Press ◀ / ► button to select(Default / Normal / Small / Large).

#### 【Font Edge Style】

Adjust the edge of the digital Closed Captioning box.  
Press ◀ / ► button to select(Default / None / Raised / Depressed / Uniform / Left Shadow / Right Shadow).

#### 【Font Edge Color】

Adjust the color of the digital Closed Captioning box.  
Press ◀ / ► button to select(Default / Black / White / Red / Green / Blue / Yellow / Magenta / Cyan).

#### 【FG Color】

Adjust the color of the digital Closed Captioning font.  
Press ◀ / ► button to select( Default / White / Red / Green / Blue / Yellow / Magenta / Cyan).

#### 【BG Color】

Adjust the digital Closed Captioning background color.  
Press ◀ / ► button to select(Default/ Black / Red / Green / Blue / Yellow / Magenta / Cyan).

### 【FG Opacity】

Adjust the transparency of the digital Closed Captioning font.  
Press ◀ / ► button to select(Default / Solid / Flashing / Translucent / Transparent).

### 【BG Opacity】

Adjust the digital Closed Captioning background transparency.  
Press ◀ / ► button to select(Default / Solid / Flashing / Translucent / Transparent).

**\*Note:** All the options can be adjust while the mode is Custom.

### 【Input Label】

Press OK / ► button to enter.



### 【Other Settings】

Set the parameter of audio only.  
Press OK / ► button to enter.

### 【Audio Only】

Play the audio with the picture turned off. When you turn the Audio Only on, the panel will be dark; and except VOL+, VOL-, POWER and MUTE buttons, press any key to exit the Audio Only status.  
Press ◀ / ► button to select(On / Off).  
*Note: In Audio Only state, press POWER, TV will be on standby mode.*

### 【Restore Default】

Restore the settings of user interface to the default.  
Press OK / ► button to enter.

### 【Setup Wizard】

Set the first time installation.  
Press OK / ► button to enter.  
For detail please refer to page 8.

### 【CEC】

Press ▼ button to select CEC, then press OK / ► button to enter CEC menu.



### 【CEC Control】

## Advanced Functions

On/Off can be selected(default: Off) to turn on or turn off CEC function.  
Press **▶** button to select On in **CEC Control**, the following functions can work.

### 【Device Auto Power Off】

On/Off can be selected(default: On) to decide CEC device goes to standby mode when TV is on standby .

### 【TV Auto Power ON】

On/Off can be selected(default: On) to decide TV can be opened with the opening of outer CEC device.

### 【Audio Receiver】

On/Off can be selected(default: On) to decide whether support ARC function or not.

### 【Device list】

Display linked TV CEC devices

### 【Connect】

Link to corresponding device and open signal output.

### 【Root menu】

Press it, it can switch to corresponding CEC device source, the function is the same as Connect. But when DVD is play, press it, it can go to DVD menu.

## Lock


1. Press **MENU** to enter the main menu, Press **◀ / ▶** button to select.
2. Press **▼** to enter.
3. Enter your 4-digital password. Default password is 0000.

Note: If you forget the password, enter 0432 to override any existing codes.



4. Press **▲ / ▼** button to select among Change Password / System Lock / Input Block / US Rating / Canada Rating / RRT Setting / Reset RRT.
5. Press **MENU** again to exit or back to parent menu.

## Lock



### 【Change Password】

1. Press **OK / ▶** button to enter.
2. Enter a new 4-digital password then re-enter it to confirm.

### 【System Lock】

Lock or unlock the buttons on the TV.  
Press **◀ / ▶** button to select(Off / On).

### 【Input Block】

Block or unblock the input sources.  
Press **OK / ▶** button to enter.  
Press **◀ / ▶** button to select(Unblock / Block).



### 【US Rating】

Restrict movie and TV programs by US Ratings.  
Only available when "System Lock" is "on".  
Press **OK / ▶** button to enter.

### 【Canada Rating】

Only available when "System Lock" is "on".  
Press **OK / ▶** button to enter.  
Restrict movie and TV programs by Canadian Ratings..  
For detail please refer to page 12.

### 【RRT Setting】

Display an advance V-Chip rating table for digital channels.  
The item is available only When current stream has downloadable rating data.

### 【Reset RRT】


Reset the RRT to default.  
The item is available only When current stream has downloadable rating data.

### US Rating

For the United States, the rating setting basically include the following options: TV, MPAA.

### TV

The TV rating compose of two aspects: age-based and content-based.



## Advanced Functions

Age	Define
TV-Y	General audience
TV-Y7	Parental guidance suggested
TV-G	Parents strongly cautioned
TV-PG	Restricted
TV-14	No one 17 and under admitted
TV-MA	Adult audience only

**Note:** The content ratings will increase depending on the level of the age-based rating. For example, a program with a TV-PG V (violence) rating may contain moderate violence, while a TV-14 V (violence) rating may contain intense violence. So locking a higher level option will automatically cause locking the options that has more sensitive level.

### MPAA

This system defines the rating control which come from MPAA rules.

Rating	Define as
Off	Close
G	General audience. All ages admitted.
PG	Parental guidance suggested. Some material may not be suitable for children.
PG-13	Parents strongly cautioned. Some material may be inappropriate for children under 13.
R	Restricted. Children under 17 require accompanying parent or adult guardian.
NC-17	No one 17 and under admitted.
X	Adult audience only.

### Canada Rating

For Canada, the rating setting include the following options: Canada English, Canada French.

### Canada English

These ratings are for programs which are using English rating system.

Rating	Defined as
Off	Close
C	Children
C8+	Children 8 years and older
G	General programming
PG	Parental guidance
14+	Viewers 14 and older
18+	Adult programming

### Canada French

The ratings are for programs which are using French rating system.

Rating	Defined as
Off	Close
G	General
8 ans+	Not recommended for children under age 8
13 ans+	Not recommended for children under age 13
16 ans+	Not recommended for children under age 16
18 ans+	This program is restricted to adults

## Channel

Press **MENU** to enter the main menu, Press **◀ / ▶** button to select.




1. Press **▼** to enter.
2. Press **▲ / ▼** button to select among Air/Cable, Auto Scan, Favorite, Channel List, Show/Hide, Channel Number, Channel Label.
3. Press **◀ / ▶** button to adjust.
4. Press **MENU** again to exit or back to parent menu.

### 【Air/Cable】

Select signal type. Press **◀ / ▶** button to select(Air/Cable).

### 【Auto Scan】

Automatically search for channels. Press **OK / ▶** button to enter.




### 【Favorite】

Add channels to create a favorite list. Press **OK / ▶** button to enter.

### 【Channel List】

Press **▲ / ▼** button to adjust.



### 【Show/Hide】

Show or hide the channels in your program list. Press **OK / ▶** button to enter.

### 【Channel Number】

Show the channel number. Press **◀ / ▶** button to adjust.

### 【Channel Label】

Create labels for channels, up to 7 characters.

## Advanced Functions

### PC

Press **INPUT** to select PC source.  
Press **MENU** to enter the main menu, Press ◀ / ▶ button to select Setup menu.  
Press ▼ to select PC Settings.



1. Press OK / ▶ to enter.
2. Press ▲ / ▼ button to select among H-Pos / V-Pos / Clock / Phase / Auto .
3. Press ◀ / ▶ button to adjust.
4. Press **MENU** again to exit or back to parent menu.



#### 【H-Pos】

Adjust the horizontal position of the picture.  
Press ◀ / ▶ button to adjust.

#### 【V-Pos】

Adjust the vertical position of the picture.  
Press ◀ / ▶ button to adjust.

#### 【Clock】

Minimize vertical stripes in the screen image.  
Press ◀ / ▶ button to adjust.

#### 【Phase】

Minimize horizontal distortion.  
Press ◀ / ▶ button to adjust.

#### 【Auto】

Adjust to the PC signal timing automatically.  
Press ▶ / OK button to enter.

#### Notes:

1. Advanced settings in Picture menu is different, other descriptions are the same as that for TV mode. Select Advanced settings in Picture menu, Aspect Ratio can select Full 100% or Point to Point. Noise Reduction and Dynamic Contrast is invalid.
2. TIME menu and description are the same as that for TV mode.
3. Close Caption in SETUP menu is invalid.
4. US, Canada, RRT Setting and Reset RRT in LOCK menu is invalid.
5. PC mode has no CHANNEL menu.

### AV / COMPONENT / HDMI

1. PICTURE menu and description are the same as that for TV mode.
2. TIME menu and description are the same as that for TV mode.
3. The function of Close Caption is available only in AV/TV mode.
4. US Rating, Canada Rating is available only in AV /TV mode. RRT Setting and Reset RRT in LOCK menu is invalid.
5. AV / COMPONENT / HDMI mode has no CHANNEL menu.


### Media

Note: Before operating **Media** menu, Plug in USB device, then press **INPUT** button to set the Input Source to **Media**.

Press ▲ / ▼ button to select **Media** in the Source menu, then press **OK** button to enter.



Press ◀ / ▶ button to select the option you want to adjust in the main **Media** menu, then press **OK** button to enter.



---

## Advanced Functions

---

### Photo

Press ◀ / ▶ button to select PHOTO in the main menu, then press **OK** button to enter.

Press ◀ / ▶ button to select drive disk you want to watch, then press **OK** button to enter.

Press ◀ / ▶ button to select return option to back to the previous menu.



Press ◀ / ▶ button to select the file you want to watch in the file selecting menu, then press **OK** button to display picture.



**Note:** Only support JPG format

### Music

Press ◀ / ▶ button to select MUSIC in the main menu, then press **OK** button to enter.

Press ◀ / ▶ button to select drive disk you want to watch, then press **OK** button to enter.

Press ▲ / ▼ button to select return option to back to the previous menu.



Press ▲ / ▼ button to select the file you want to watch in the file selecting menu, then press **OK** button to play. Press **OK** button again to display and operate file details. When highlighting the option you select, the file information will appear on the right.



Press ◀ / ▶ button to select menu in the bottom you want to run, then press **OK** button to operate.

**Note:** Only support MP3 format

### Troubleshooting

Most problems you encounter with your TV can be corrected by consulting the following troubleshooting list.

#### No picture, no sound

1. Check if the fuse or circuit breaker is working.
2. Plug another electrical device into the outlet to make sure it is working or turned on.
3. Power plug is in a bad contact with the outlet.
4. Check the signal source.

#### No color

1. Change the color system.
2. Adjust the saturation.
3. Try another channel. Black-white program may be received.

#### Remote control does not work

1. Change the batteries.
2. Batteries are not installed correctly.
3. Main power is not connected.

#### No picture, normal sound

1. Adjust the brightness and contrast.
2. Broadcasting failure may happen.

#### Normal picture, no sound

1. Press the **Vol+** button to increase volume.
2. Volume is set to mute, press the mute button to restore sound.
3. Change the sound system.
4. Broadcasting failure may happen.

#### Unorderly ripples on the picture

It is usually caused by local interference, such as cars, daylight lamps and hair driers. Adjust the antenna to minimize the interference.

#### Blank screen in VGA mode

Perhaps the TV can not recognize the resolution set by the PC. Suggest to change to the best resolution or other standard resolutions of the Windows system.

#### Snowy dots and interference

If the antenna is located in the fringe area of a television signal where the signal is weak, the picture may be marred by dots. When the signal is extremely weak, it may be necessary to install a special antenna to improve the reception.

1. Adjust the position and orientation of the indoor/outdoor antenna.
2. Check the connection of antenna.
3. Fine tune the channel.
4. Try another channel. Broadcasting failure may happen.

#### Ignition

Black spots or horizontal streaks appear, or the picture flutters or drifts. This is usually caused by interference from car ignition system, neon lamps, electric drills, or other electrical appliance.


#### Ghost

Ghosts are caused by the television signal following two paths. One is the direct path, the other is reflected from tall buildings, hills, or other objects. Changing the direction or position of the antenna may improve the reception.

#### Radio frequency interference

This interference produces moving ripples or diagonal streaks, and in some case, loss of contrast in the picture. Find out and remove the radio interference source.

### Base Installation



To fix the double support base on the unit by screws, the installation is completed.

**Battery Caution & Disposal Information**

1. For best results, use alkaline type batteries.
2. Install only new batteries of the same type in your product.
3. Failure to insert batteries in the correct polarity, as indicated in the battery compartment, may shorten the life of the batteries or cause batteries to leak.
4. Do not mix old and new batteries.
5. Do not use Rechargeable (Nickel Cadmium) or (Nickel Metal Hydride) batteries.
6. Do not mix Alkaline, Standard (Carbon-Zinc) or Rechargeable (Nickel Cadmium) or (Nickel Metal Hydride) batteries.
7. Do not dispose of batteries in fire.
8. Batteries should be recycled or disposed of as per state and local guidelines.

**Care and Cleaning**

Caution: Turn OFF your TV before cleaning.

You can clean the TV as required, using a soft lint-free cloth. Be sure to occasionally dust the ventilation slots in the cabinet to help assure adequate ventilation.

**IMPORTANT:** Never use strong cleaning agents, such as ammonia-based cleaners, or abrasive powder. These types of cleaners will damage the TV. The TV's screen may be cleaned with a soft, lint-free cloth as well. Take care not to scratch or mar the screen. If necessary, you may use a cloth dampened with warm water. While cleaning, do not spray liquid directly on the screen, or allow liquid to run down the screen and inside the TV. Also, never place drinks or vases with water on top of the TV. This could increase the risk of fire, shock hazard or damage to the TV.

**Television Specifications**

Broadcasting system	US System NTSC-M ATSC standard (8VSB), QAM
Receiving Channels	VHF2-13 UHF14-69 CATV 14-36 (A)-(W) 37-59 (AA)-(WW) 60-85 (AAA)-(ZZZ) 86-94 (86)-(94)95-99 (A-5)-(A-1) 100-135 (100)-(135) 01 (4A)
Tuner type	Frequency synthesized
Operating Temperature	5°C to 35°C (41°F to 95°F)
Operating Humidity	20% to 80%,non-condensing
Storage Temperature	-15°C to 45°C (5°F to 113°F)
Storage Humidity	10% to 90%,non-condensing

## TTE Technology, Inc. (“TTE”) Limited Warranty

All LCD/LED Models.

**What your warranty covers:** Defects in materials or workmanship to the original owner of this TCL product when purchased as new from an Authorized Dealer of TCL brand products in the United States and packaged with this warranty statement.

### New LCD/LED Televisions (Non-Commercial Use)

**For how long after your purchase:**

- One (1) year from date of purchase for parts and labor for non-commercial use.

### New LCD/LED Televisions (Commercial Use)

**For how long after your purchase:**

- Six (6) months from date of purchase for parts and labor for commercial use.
- Commercial use includes, but is not limited to, the use of this product in a commercial or business environment, the use of this product in an institution or for institutional purposes, or other commercial purposes including rental purposes.

**What we will do:**

- At TTE’s discretion, (1) pay an Authorized TCL Service Center for both labor charges and parts to repair your television, or (2) replace your television with a new or refurbished/remanufactured equivalent value product. The decision to repair or replace will be made solely by TTE. See “How to get service”.

**How to get service:**

- Call 1-877-300-8837 (for mainland 48 States), or 1-877-800-1269 (for AK, HI, and Puerto Rico).
- Please have your original purchase receipt or proof of purchase (bill of sale or receipted invoice), the unit’s date of purchase, place of purchase and model/serial number ready. The model/serial number information can be found on the back of your unit.
- A representative will troubleshoot your problem over the telephone. If it is determined that your unit requires service, the service location will be at the sole discretion of TTE based upon the TTE Limited Warranty Statement.
- At the sole discretion of TTE, television screen sizes 32” and smaller will either be repaired at an Authorized TCL Service Center or directly exchanged for a new or refurbished/remanufactured unit. At the sole discretion of TTE, television screen sizes 33” through 55” or larger will either be repaired at an Authorized TCL Service Center or repaired in-home.
- If repaired at an Authorized TCL Service Center, TTE is not responsible for transportation costs to the Authorized TCL Service Center. However, TTE will pay for return shipping. TTE will provide instructions for packaging and shipping the unit.
- Proof of purchase in the form of a bill of sale or receipted invoice from an Authorized Dealer which is evidence that the product is within the warranty period must be presented to obtain warranty service.
- PRE-AUTHORIZATION MUST BE OBTAINED BEFORE (1) SENDING ANY PRODUCT TO AN AUTHORIZED TCL SERVICE CENTER, OR (2) OBTAINING ANY IN-HOME REPAIR/REPLACEMENT/ RENTAL SERVICES.

**What your warranty does not cover:**

- Customer instruction. (Your Owner’s Manual describes how to install, adjust, and operate your unit. Any additional information should be obtained from your Authorized Dealer).
- Installation and related adjustments, or damage resulting from installation.
- Damage resulting from non-approved installation methods.
- Signal reception problems not caused by your unit.
- Damage from misuse, abuse, neglect, normal wear and tear, cosmetic damage, mishandling, faulty installation, or power line surges.
- Markings or images on the television’s panel resulting from viewing fixed images (including but not limited to certain 4:3 images on wide screen televisions, or data or images in fixed screen locations from banners, video games, or certain broadcast networks).
- Batteries.



- A television that has been modified or incorporated into other products.
- A unit purchased or serviced outside the USA.
- A unit sold in "As-Is", "Factory Reconditioned", "Factory Re-Certified", or "Refurbished" condition or with faults.
- Acts of nature or God, such as but not limited to earthquake or lightning damage.
- Special, incidental or consequential damages.

**Product Registration:**

Please register your TCL purchase on-line at [www.tclusa.com](http://www.tclusa.com). It will make it easier to contact you should it ever be necessary. Registration is not required for warranty coverage.

**LIMITATION OF WARRANTY**

- THE WARRANTY STATED ABOVE IS THE ONLY WARRANTY APPLICABLE TO THIS PRODUCT. NO VERBAL OR WRITTEN INFORMATION GIVEN BY TTE TECHNOLOGY, INC., ITS AGENTS OR EMPLOYEES SHALL CREATE A GUARANTY OR IN ANY WAY INCREASE OR MODIFY THE SCOPE OF THIS WARRANTY.
- REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. TTE TECHNOLOGY, INC. SHALL NOT BE LIABLE FOR SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. THIS DISCLAIMER OF WARRANTIES AND LIMITED WARRANTY ARE GOVERNED BY THE LAWS OF THE STATE OF CALIFORNIA. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE APPLICABLE WARRANTY AND WARRANTY PERIOD SET FORTH ABOVE. THIS WARRANTY IS SUBJECT TO CHANGE WITHOUT NOTICE. PLEASE VISIT [WWW.TCLUSA.COM](http://WWW.TCLUSA.COM) TO VIEW THE MOST CURRENT VERSION.

**How State Law relates to this warranty:**

- Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you.
- This warranty gives you specific legal rights, and you also may have other rights that vary from state to state.

**If you purchased your unit outside the United States or seek warranty coverage outside the United States:** This warranty does not apply. Contact your dealer for warranty information.

**Service calls which do not involve defective materials or workmanship are not covered by this warranty. Costs of such service calls are the sole responsibility of the purchaser.**

## **Legal Statement of TCL**

### **- Manufacturer of this TV set**

Due to the various capabilities of products featuring the Smart TV - Services, as well as limitations in the available content, certain features, applications, and services may not be available on all devices or in all territories. Some features on Smart TV may also require additional peripheral devices or membership fees that are sold separately. Please visit our website for more information on specific device information and content availability. The services and availability of content through Smart TV are subject to change from time to time without prior notice.

All content and services accessible through this device belong to third parties and are protected by copyright, patent, trademark and/or other intellectual property laws. Such content and services are provided solely for your personal noncommercial use. You may not use any content or services in a manner that has not been authorized by the content owner or service provider. Without limiting the foregoing, unless expressly authorized by the applicable content owner or service provider, you may not modify, copy, republish, upload, post, transmit, translate, sell, create derivative works, exploit, or distribute in any manner or medium any content or services displayed through this device.

You expressly acknowledge and agree that use of the device is at your sole risk and that the entire risk as to satisfactory quality, performance and accuracy is with you. The device and all third party content and services are provided "as is" without warranty of any kind, either express or implied. TCL expressly disclaims all warranties and conditions with respect to the device and any content and services, either express or implied, including but not limited to, warranties of merchantability, of satisfactory quality, fitness for a particular purpose, of accuracy, of quiet enjoyment, and non-infringement of third party rights. TCL does not guarantee the accuracy, validity, timeliness, legality, or completeness of any content or service made available through this device and does not warrant that the device, content or services will meet your requirements, or that operation of the device or services will be uninterrupted or error-free. Under no circumstances, including negligence, shall TCL be liable, whether in contract or tort, for any direct, indirect, incidental, special or consequential damages, attorney fees, expenses, or any other damages arising out of, or in connection with, any information contained in, or as a result of the use of the device, or any content or service accessed by you or any third party, even if advised of the possibility of such damages.

Third party services may be changed, suspended, removed, terminated or interrupted, or access may be disabled at any time, without notice, and TCL makes no representation or warranty that any content or service will remain available for any period of time. Content and services are transmitted by third parties by means of networks and transmission facilities over which TCL has no control. Without limiting the generality of this disclaimer, TCL expressly disclaims any responsibility or liability for any change, interruption, disabling, removal of or suspension of any content or service made available through this device. TCL may impose limits on the use of or access to certain services or content, in any case and without notice or liability. TCL is neither responsible nor liable for customer service related to the content and services. Any question or request for service relating to the content or services should be made directly to the respective content and service providers.



This product incorporates HDMI technology.  
HDMI, the HDMI logo, and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC.



Manufactured under license from Dolby Laboratories.

“Dolby” and the double-D symbol are registered trademarks of Dolby Laboratories.

## FCC Information

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This Class B digital apparatus complies with Canadian ICES-003.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Please do not send any products to the California address listed in this manual or on the carton. This will only add delays in service for your product.

Figures and illustrations in this User's Guide are provided for reference only and may differ from actual product appearance. Product design and specifications may be changed without notice.

## **TTE**

TTE Technology, Inc.

2455 Anselmo Drive, Suite 101, Corona, CA 92879

TCL and associated marks are trademarks of TCL S.A. used under license to TTE Corporation.

Part No.: 72-28D270-E399A