

# **TASCAM.**

## **US-122**

### **Download Installation**

Below are the detailed and complete installation instructions for the Tascam US-122 for Windows XP. These instructions are to be followed if the user is unable to install with the instructions provided with the US-122

**BEFORE YOU BEGIN,  
MAKE SURE THE US122 IS NOT PLUGGED IN  
DO NOT PLUG IN YOUR US122 UNTIL YOU ARE INSTRUCTED TO.**

**TURN OFF YOUR ANTI VIRUS  
TURN OFF YOUR HYPER THREADING**

(1A)

**IF YOU HAVE PREVIOUSLY ATTEMPTED TO INSTALL THE US-122  
PERFORM A CLEAN UNINSTALL BEFORE PROCEEDING.**

The US122 **Clean Uninstall document** can be found on your CD with in the **Application notes** or **Documentation** folder, **English, CleanWin2k\_Eng.**  
Please note that the instructions in that document direct you to the /WINNT folder for **Windows 2K**. This folder is named /WINDOWS in **XP**.

Go to the **TASCAM** website ([www.tascam.com](http://www.tascam.com)).  
Under the **TASCAM** Logo, in the “**Select a Product**” box choose **US-122**  
On the **left** hand side of the screen, under “**Software Downloads**”  
Select Windows XP/2000 driver version 3.24. *note: the Version number might change*

After the file has downloaded go to the location you saved it to.  
Double click on “**US122\_Win2K\_Install\_3\_(xx) exe**”.

A **"Windows Logo testing warning"** screen may appear.  
If so, click on **CONTINUE ANYWAY**.  
The **"Welcome"** screen will appear.  
Follow the Closing of Programs instruction if it is applicable to your situation.  
Click on **NEXT**.  
The "Read me Information" screen will appear.  
Click on **NEXT**.  
The **"Start install"** screen will appear.  
Click on **NEXT**.  
The **"Reboot computer"** screen will appear.  
This screen will inform you that some components were not installed and it will ask you to reboot your computer  
Select **"Yes, reboot my computer now"**.  
Click on **NEXT**.

**AFTER YOUR COMPUTER FULLY REBOOTS, PLUG IN YOUR US-122 DIRECTLY INTO YOUR COMPUTER USING THE CABLE THAT IS PROVIDED. UNPLUG ANY USB DEVICE OR HUB THAT IS USING THE SAME BUS EXCEPT FOR YOUR KEYBOARD AND MOUSE.**

**(2A)**  
**Found New Hardware** Screen should pop up.  
The **"Hardware Wizard"** screen will appear.  
Under **"What do you want the wizard to do?"**  
Select **"Install from a list or a specific location (Advanced)"**.  
Click on **NEXT**.  
The **"Please choose your search and installation options"** screen will appear.  
Put a Check in the box next to **"Include this location in the search"**.  
Verify that **"C:\Programs Files\US122\_Install"** is in the location window.  
If not, click on **BROWSE** to select it.  
**UNCHECK** "Search removable media Floppy, CD-ROM" if checked.  
Click **NEXT**.  
A **"Windows Logo testing warning"** screen may appear.  
If so, click on **CONTINUE ANYWAY**.  
The **"Completing the Found New Hardware Wizard"** screen will appear.  
Click on **FINISH**.

**"FOUND NEW HARDWARE" SCREEN SHOULD POP UP, AGAIN.**

**Found New Hardware** Screen should pop up.

The "**Hardware Wizard**" screen will appear.  
Under "**What do you want the wizard to do?**"  
Select "**Install from a list or a specific location (Advanced)**".  
Click on **NEXT**.  
The "**Please choose your search and installation options**" screen will appear.  
Put a Check in the box next to "**Include this location in the search**".  
Verify that "**C:\Programs Files\US122\_Install**" is in the location window.  
**UNCHECK** "Search removable media Floppy, CD-ROM" if checked  
If not, click on **BROWSE** to select it.  
Click **NEXT**.  
A "**Windows Logo testing warning**" screen may appear.  
If so, click on **CONTINUE ANYWAY**.  
The "**Completing the Found New Hardware Wizard**" screen will appear.  
Click on **FINISH**.

**"FOUND NEW HARDWARE" SCREEN SHOULD POP UP, FOR THE THIRD TIME!**

**Found New Hardware** Screen should pop up.  
The "**Hardware Wizard**" screen will appear.  
Under "**What do you want the wizard to do?**"  
Select "**Install from a list or a specific location (Advanced)**".  
Click on **NEXT**.  
The "**Please choose your search and installation options**" screen will appear.  
Put a Check in the box next to "**Include this location in the search**".  
Verify that "**C:\Programs Files\US122\_Install**" is in the location window.  
If not, click on **BROWSE** to select it.  
**UNCHECK** "Search removable media Floppy, CD-ROM" if checked  
Click **NEXT**.  
A "**Windows Logo testing warning**" screen may appear.  
If so, click on **CONTINUE ANYWAY**.  
The "**Completing the Found New Hardware Wizard**" screen will appear.  
Click on **FINISH**.

A balloon Screen should pop up indicating "**Your new hardware is installed and ready to use**". The **USB light** should be lit on the **US-122**. If your USB light is not on go back to **(1A)**.

**YOU HAVE COMPLETED THE INSTALLATION PROCESS.**