

**THALES**

86, Bushey Road  
Raynes Park, London  
SW20 0JW  
Tel: +44 (0)20 8946 8011  
Fax: +44 (0)20 8946 7530

# **INSTALLATION AND MAINTENANCE MANUAL**

## **Satellite Data Unit (SDU)**

### **82155 Series**

## **SDU Configuration Module (SCM)**

### **82158 Series**

Revision No. 01  
First Issue: Jun 30/2008

© THALES AVIONICS Ltd. This document and any  
information included are the property of Thales Avionics.  
They cannot be reproduced, disclosed or utilized without the  
company's prior written approval

**1**  
**Jun 30/2008**



**Installation Maintenance Manual**  
SDU 82155 Series  
SCM 82158 Series

**THIS PAGE INTENTIONALLY BLANK**

**Installation Maintenance Manual**  
SDU 82155 Series  
SCM 82158 Series

<b>Section 1</b>	<b>INTRODUCTION</b>	<b>Page</b>
1.1.	Purpose of Manual . . . . .	1-1
1.2.	Special Precautions . . . . .	1-1
1.3.	Contact Information . . . . .	1-2
1.4.	Scope of Manual . . . . .	1-2
1.5.	Reference documents . . . . .	1-2
1.6.	Compliance to Regulations . . . . .	1-3
	A. Federal Communication Commission . . . . .	1-3
	B. European Aviation Safety Agency . . . . .	1-3
<b>Section 2</b>	<b>DESCRIPTION</b>	<b>Page</b>
2.1.	TFS Satellite Communication System Domain . . . . .	2-1
2.2.	TFS System Overview . . . . .	2-1
2.3.	system Configurations . . . . .	2-2
	A. Single Aisle TFS System . . . . .	2-2
	B. SDU Type 82155D TFS system . . . . .	2-3
2.4.	SDU Component Description . . . . .	2-4
	A. Hardware . . . . .	2-4
	(1) SDU Type 82155A . . . . .	2-4
	(2) SDU Type 82155D . . . . .	2-4
	B. Functionality . . . . .	2-5
	(1) SDU Type 82155A . . . . .	2-5
	(2) SDU Type 82155D . . . . .	2-5
	C. Software . . . . .	2-6
	D. ORT Parameters . . . . .	2-6
	E. General Operation . . . . .	2-6
	F. Sub-modules Basic Detailed Operation . . . . .	2-7
	G. Operating Environment . . . . .	2-8
	(1) Normal Operating temperature: . . . . .	2-8
	(2) Cooling: . . . . .	2-8
	(3) Heat dissipation: . . . . .	2-8
	H. Environment Conditions . . . . .	2-8
	I. Identification Label . . . . .	2-10
	J. Weight and Dimensions . . . . .	2-12
	(1) SDU Type 82155A . . . . .	2-12
	(2) SDU Type 82155D . . . . .	2-12
	K. SDU Electrical Characteristics . . . . .	2-15
2.5.	System Interfaces . . . . .	2-15
	A. Aircraft Power Utility Service . . . . .	2-15
	B. Avionics Interfaces . . . . .	2-16
	C. Cockpit Interfaces (SDU Type 82155D only) . . . . .	2-17
	D. Maintenance System Interfaces . . . . .	2-17
2.6.	SDU Configurable Pinout and Pin Description . . . . .	2-17
	A. Mandatory Configuration Pins . . . . .	2-18

## Installation Maintenance Manual

SDU 82155 Series

SCM 82158 Series

2.7.	SDU Interconnect Data . . . . .	2-18
A.	ARINC 600 Standard Interwiring Connector . . . . .	2-18
	(1) ARINC 600 Pin Assignment . . . . .	2-19
B.	Electrical Interconnection Diagrams . . . . .	2-24
C.	Interconnection Cables . . . . .	2-35
	(1) RF Coaxial Cables . . . . .	2-35
	(2) Power Cables . . . . .	2-36
	(3) ARINC 429 Connections . . . . .	2-36
	(4) Ethernet . . . . .	2-36
2.8.	SCM Component Description . . . . .	2-36
A.	Hardware . . . . .	2-36
	(1) External Description . . . . .	2-36
	(2) Internal Description . . . . .	2-37
B.	ORT Parameters . . . . .	2-38
C.	ORT Synchronisation . . . . .	2-39
D.	Basic Operation . . . . .	2-39
E.	Environment Condition . . . . .	2-39
F.	Identification Label . . . . .	2-40
G.	SCM Electrical Characteristics . . . . .	2-41
H.	Weight and Dimensions . . . . .	2-41
I.	SCM Connector . . . . .	2-42
J.	Equipment Electrical Interconnection Diagram . . . . .	2-42

### Section 3      **INSTALLATION GUIDELINES** **Page**

3.1.	Introduction . . . . .	3-1
3.2.	Interchangeability . . . . .	3-1
3.3.	SDU/SCM Location and Accessibility Guidelines . . . . .	3-2
3.4.	Mounting Tray . . . . .	3-2
3.5.	Cooling . . . . .	3-3
3.6.	Power Requirements . . . . .	3-3
3.7.	SDU RF Connections . . . . .	3-4
	D. Insertion Losses . . . . .	3-4
	E. Product InterModulation (PIM) . . . . .	3-5
	F. VSWR . . . . .	3-5
	G. Torque Settings . . . . .	3-5
	H. Cleaning . . . . .	3-5
3.8.	Bonding Requirements . . . . .	3-5

### Section 4      **INSPECTION AND SYSTEM CHECKOUT** **Page**

4.1.	Inspection/Check Procedure . . . . .	4-1
A.	Check Wiring and RF cables . . . . .	4-1
B.	Check SDU . . . . .	4-1
C.	Check SCM . . . . .	4-2
4.2.	System checkout . . . . .	4-2
A.	Post-Installation Test . . . . .	4-2

<b>Section 5</b>	<b>FAULT ISOLATION</b>	<b>Page</b>
5.1.	Bite Function . . . . .	5-1
5.2.	Test Functions . . . . .	5-2
	A. OMS or CFDS . . . . .	5-2
	B. BITE . . . . .	5-2
	(1) POST . . . . .	5-3
	(2) PAST . . . . .	5-4
5.3.	fault isolation . . . . .	5-5
	A. Failures . . . . .	5-5
	B. Front Panel Indications . . . . .	5-5
	C. Fault Logging . . . . .	5-8
	D. Service Availability Discretets . . . . .	5-8
	E. Service Availability Discrete Lamps . . . . .	5-9
	F. CFDS/ARINC 604 BITE . . . . .	5-9
<b>Section 6</b>	<b>MAINTENANCE Practices</b>	<b>Page</b>
6.1.	General . . . . .	6-1
6.2.	Equipment and Materials . . . . .	6-1
6.3.	Procedure For The SDU . . . . .	6-2
	A. Removal and Installation Procedure . . . . .	6-2
	(1) Remove the SDU . . . . .	6-2
	(2) Install the SDU . . . . .	6-3
	B. Adjustment Procedure . . . . .	6-3
	C. Repair Procedure . . . . .	6-3
	D. Return to Service Procedures . . . . .	6-3
6.4.	Procedure For The SCM . . . . .	6-4
	A. Removal and Installation Procedure . . . . .	6-4
	(1) Remove the SCM . . . . .	6-4
	(2) Install the SCM . . . . .	6-4
	B. Adjustment Procedure . . . . .	6-5
	C. Repair Procedure . . . . .	6-5
	D. Return to Service Procedures . . . . .	6-5
6.5.	Cleaning of Mechanical Parts . . . . .	6-5
6.6.	Periodic Checks . . . . .	6-6
6.7.	Cabling and Connections . . . . .	6-6
6.8.	Instructions For Continued Airworthiness . . . . .	6-6
<b>Section 7</b>	<b>COMMISSIONING</b>	<b>Page</b>
7.1.	General . . . . .	7-1
	A. Registration . . . . .	7-1
	B. Classic Packet Data Verification . . . . .	7-3
	C. Classic Cockpit Voice Calls . . . . .	7-3
	D. SBB Cabin Wifi Data Connectivity (Background Context) . . . . .	7-3
	E. SBB Cabin Wifi Data Connectivity (Streaming Context) . . . . .	7-4
	F. Cabin VoIP service . . . . .	7-5
	G. Cabin ISDN Data service . . . . .	7-5
	H. Cabin ISDN Voice service . . . . .	7-6
	I. Cabin GSM Call and SMS Service . . . . .	7-7



**Installation Maintenance Manual**  
SDU 82155 Series  
SCM 82158 Series





**Installation Maintenance Manual**  
SDU 82155 Series  
SCM 82158 Series

**THIS PAGE INTENTIONALLY BLANK**



## Installation Maintenance Manual

SDU 82155 Series

SCM 82158 Series

<b>List of Abbreviations</b>	
ac	Alternating Current
ACARS	Aircraft Communication Addressing and Reporting System
ADL	Airborne Data Loader
AES	Aeronautical Earth Station
AGS	Airborne GSM Server
AIM	Antenna Interface Mounting
AMO	Approved Maintenance Organization
AMU	Audio Management Unit
AOR-E	Atlantic Ocean Region-East
AOR-W	Atlantic Ocean Region-West
APM	Avionics Processor Module
ARINC	Aeronautical Radio Inc
ATE	Automatic Test Equipment
BGAN	Broadband Global Area Network
BITE	Built In Test Equipment
BSU	Beam Steering Unit
CCM	Channel Card Module
CDU	Control Display Unit
CFDS	Centralised Fault Display System
CMM	Component Maintenance Manual
CMU	Communication Management Unit
CPM	Communication Processor Module
dc	Direct Current
DLNA	Diplexer and Low Noise Amplifier
EASA	European Aviation Safety Agency

## Installation Maintenance Manual

SDU 82155 Series

SCM 82158 Series

<b>List of Abbreviations</b>	
ECM	External Configuration Memory
ECS	Environmental Control System
EMC	Electromagnetic Compatibility
ESD	Electro Static Discharge
ESDS	Electro Static Discharge Sensitive
FMHPA	Flange Mounted High Power Amplifier
FPL	Front Panel LED
GES	Ground Earth Station
GNSS	Global Navigation Satellite System
GPS	Global Positioning System
HPA	High Power Amplifier
IGA	Intermediate Gain Antenna
IMEI	International Mobile Equipment Identity
IMM	Installation and Maintenance Manual
IMSI	International Mobile Subscriber Identity
INMARSAT	International Maritime Satellite Organization
IOR	Indian Ocean Region
IP	Internet Protocol
IPC	Illustrated Parts List
IRS	Inertial Reference System
I/O	Input/Output
ISDN	Integrated Service Digital Network
LED	Light Emitting Diode
LES	Land Earth Station
LRU	Line Replaceable Unit
mA	MilliAmpere
MCDU	Multi-function Control and Display Unit

## Installation Maintenance Manual

SDU 82155 Series

SCM 82158 Series

<b>List of Abbreviations</b>	
MCU	Modular Concept Unit
MEL	Minimum Equipment Level
MES	Mobile Earth Station
MIB	Management Information Base
NVM	Non Volatile Memory
OMS	Onboard Monitoring System
ORT	Owner Requirements Table
OCXO	Oven Controlled Crystal Oscillator
PAST	Person Activated Self Test
PC	Personal Computer
PLMN	Public Land Mobile Network
PNR	Part Number
POR	Pacific Ocean Region
POST	Power On Self-Test
PPPoE	Point To Point Protocol over Ethernet
PSM	Power Supply Module
PSTN	Public Switched Telephone Network
RF	Radio Frequency
SA	Single Aisle
SATCOM	Satellite Communication
SBB	SwiftBroadband
SCDU	Satellite Control Display Unit
SCM	SDU Configuration Module
SDU	Satellite Data Unit
SIM	Subscriber Identity Module
SIS	Standalone Interface System
SNMP	Simple Network Management Protocol

## Installation Maintenance Manual

SDU 82155 Series

SCM 82158 Series

<b>List of Abbreviations</b>	
SRU	Shop Replaceable Unit
STC	Supplemental Type Certificate
SW	Software
TCP/IP	Transmission Control Protocol/Internet Protocol
TFS	TopFlight Satcom
UMTS	Universal Mobile Telecommunication System
USIM	Universal Subscriber Identity Module
Wi Fi	Wireless Fidelity
WLAN	Wireless Local Area Network
WOW	Weight On Wheels

## SECTION 1

### INTRODUCTION

#### 1.1. PURPOSE OF MANUAL

This manual sets forth installation and maintenance guidelines, and theory of operation for the THALES TopFlight Satcom (TFS) Satellite Data Unit (SDU), and SDU Configuration Module (SCM). The SDU and SCM installation specific and general guidelines contained within this manual are supported by mechanical and electrical interconnection drawings and interface information. Drawings should be reviewed by the installation organisation, and any requirements specific to a particular airframe should be assessed before installation is commenced.

The Manual covers the following topics:

- a. Title Page
- b. Record of Revisions
- c. Table of Content
- d. Introduction
- e. Description
- f. Installation Guidelines
- g. Inspection and System Checkout
- h. Fault Isolation
- i. Maintenance Practices
- j. Commissioning.

#### 1.2. SPECIAL PRECAUTIONS

Advisory notes presented within this manual such as: 'Warnings, Cautions and Notes' are applicable to the TFS system as follows:

- a. A WARNING is used to alert the reader to possible hazard which may cause loss of life or physical injury
- b. A CAUTION is used to denote the possibility of damage to materiel but not danger to personnel
- c. A NOTE is used to convey, or draw attention to, information that is extraneous to the immediate subject of the text.

## 1.3. CONTACT INFORMATION

For any queries related to information contained within this Manual contact the following:

THALES TFS Project Manager  
86 Bushey Road  
Raynes Park, London  
SW20 0JW, UK

Tel. +44 (0)20 8946 8011  
Fax. +44 (0)20 8946 7530

## 1.4. SCOPE OF MANUAL

The Thales SDU and SCM comply with the design requirements set forward in the ARINC 781 Characteristic. An ARINC 781 compliant system is intended to support one or more of the Inmarsat aeronautical services known as ‘Classic-Aero’, ‘Swift 64’, and ‘SwiftBroadband’.

This manual provides information specific for the SDU and SCM capable of providing those services highlighted above. The SDU and SCM covered in this manual support Inmarsat Class 3A, 6 and 7 services only.

## 1.5. REFERENCE DOCUMENTS

The following publications provide additional useful information:

Table 1.1 Reference Documents

THALES SCM Component Maintenance Manual	44-35-33
THALES SDU Component Maintenance Manual	44-35-32
EMS AMT-3500 Intermediate Gain Antenna Subsystem Installation Manual	MN-1242-20047
Mark 33 Digital Information Transfer System	ARINC 429
Air Transport Avionics Equipment Interfaces	ARINC 600
Airborne Computer High speed Data Loader	ARINC 615
Ethernet Based Data loading	ARINC 615A
Mark III Aviation Satellite Communication (Satcom) System Avionics	ARINC 781

## **1.6. COMPLIANCE TO REGULATIONS**

### **A. Federal Communication Commission**

The SDU is designed to be compliant with part 15 and part 87 of the Federal Communication Commission (FCC) regulations

### **B. European Aviation Safety Agency**

The installation must be compliant to the following European Aviation Safety Agency (EASA) regulations:

- EASA/FAR 25.869 Fire protection: systems
- EASA 25X0899 Electrical bonding and protection against lightning and static electricity
- EASA/FAR 25.1301 Equipment, general, function and installation
- EASA/FAR 25.1309 Equipment, systems and installations
- EASA 25X1316 System lightning protection
- EASA/FAR 25.1353 Electrical equipment and installations
- EASA/FAR 25.1357 Circuit protective devices
- EASA 25X1360 Precautions against injury
- EASA/FAR 25.1431 Electronic equipment
- EASA 25.561 Emergency Landing.



**Installation Maintenance Manual**  
SDU 82155 Series  
SCM 82158 Series

**THIS PAGE INTENTIONALLY BLANK**



## SECTION 2

### DESCRIPTION

#### 2.1. TFS SATELLITE COMMUNICATION SYSTEM DOMAIN

Satellite Communications (SATCOM) systems provide users with long-range voice and data communication by accessing global satellite and ground communications networks. The introduction of Pico-Cells on aircrafts, and the I3 and I4 INMARSAT constellation of geostationary satellites have been the enabling technologies for the development of significantly smaller, more capable terminals such as the Thales TopFlight Satcom system.

SwiftBroadband (SBB) is the aeronautical service, which operates on the INMARSAT Broadband Global Area Network (BGAN) infrastructure. SBB supports Circuit Switched and always-on TCP/IP data (packet switched) services. Thales SBB TopFlight Satcom system supports the Inmarsat Classes of service 3A, 6, 7 and Classic Aero H+.




Figure 2.1 Example of TFS communications system overview

#### 2.2. TFS SYSTEM OVERVIEW

The TFS system conforms to the Aeronautical Radio Incorporated (ARINC) 781 Characteristic, and interfaces with onboard avionics and communication equipment to provide the aircraft with a range of communication services by transmitting and

receiving L Band signals to and from the fourth generation of INMARSAT satellites. For this purpose the INMARSAT satellite constellation is connected to the ground backbone telecommunication network through Satellite Access Stations (SAS) operated by service providers.

## 2.3. SYSTEM CONFIGURATIONS

TFS Satcom may be installed in different aircraft configurations, some examples are as follows:

### A. Single Aisle TFS System

The Single Aisle TFS System consists of the following Line Replacement Units (LRU):

- One Satellite Data Unit (SDU)
- One SDU Configuration Module (SCM)
- One Diplexer Low Noise Amplifier (DLNA)
- One Intermediate Gain Antenna (IGA) or High Gain Antenna (HGA)
- RF cables.

Figure 2.2 illustrates a typical aircraft installation of the TFS for a Single Aisle Aircraft.




Figure 2.2 Example of Single Aisle TFS system interfacing

## B. SDU Type 82155D TFS system

The TFS System consists of the following Line Replacement Units (LRU):

- One Satellite Data Unit (SDU)
- One SDU Configuration Module (SCM)
- One Diplexer Low Noise Amplifier (DLNA)
- One Intermediate Gain Antenna (IGA) or High Gain Antenna (HGA)
- One Flange-Mounted High Power Amplifier (FMHPA) (If required)
- RF cables.

Figure 2.3 illustrates a typical aircraft installation of the SDU Type 82155D System.




Figure 2.3 Example of SDU Type 82155D TFS system interfacing

## 2.4. SDU COMPONENT DESCRIPTION

### A. Hardware

**NOTE:** SDU hardware is targeted at RTCA/DO-254 level C.

The SDU hardware meets RTCA/DO-254 level D requirements, and it is composed of the following internal sub-assemblies (Refer to Figure 2.4):

- (1) SDU Type 82155A
  - High Power Amplifier (HPA)
  - Channel Card Module (CCM) x 1
  - Communication Processor Module (CPM)
  - Power Supply Module (PSM)
  - Oven Controlled Crystal Oscillator (OCXO)
  - Avionics Processor Module (APM)
  - Backplane
  - Front Panel.
- (2) SDU Type 82155D
  - HPA
  - CCM x 2
  - CPM
  - PSM
  - OCXO
  - APM
  - Backplane
  - Front Panel.

The SDU enclosure is constructed of machined lightweight aluminium alloy and it is packaged in an ARINC 600 6 Modular Concept Unit (MCU) housing suitable for mounting in the equipment bay of an aircraft.

Two hold-down clamps are used to secure the SDU, permitting it to be firmly held in position in the mounting rack. A handle fitted on the front panel of the SDU permits removal, installation and carrying of the SDU.

## Installation Maintenance Manual SDU 82155 Series SCM 82158 Series




Figure 2.4 Example of SDU sub-system modules exploded

### B. Functionality

The Functionality of the SDU is as follows:

- (1) SDU Type 82155A.

Single Channel Class 3A SBB Services.

- (2) SDU Type 82155D.

Dual Channel Class 6 and 7 SBB Services with reversion to Dual S64 Services.

Classic Aero Voice and Data Services (Aero I , Aero H+ (up to 2 x Voice and 1 x Data)).

# THALES

## Installation Maintenance Manual SDU 82155 Series SCM 82158 Series

### C. Software

The software in the SDU can be considered as being supplied in two elements, one contained within the CCM the other operating on the SDU processors (CPM & APM).

The SDU's application software primarily functions as the system controller providing system level tasks such as CCM control, BITE reporting, Avionics interfacing via ARINC-429 (including Inertial Reference System (IRS)) and providing external interfaces (such as Ethernet) as well as routing functions between the external interfaces and the CCM as necessary.

The SDU's APM and CPM application software meets RTCA/DO-178B level D requirements, and the CCM application software meets RTCA/DO-178 level E (Level D for Classic only) requirements.

### D. ORT Parameters

The primary source of Owner Requirement Table (ORT) is the SCM ORT and is also stored inside the SDU. The ORT database contains configuration data that is used to customize the operation of the TFS system. It allows various preferences to be set to enable the efficient use of the equipment in normal operation. The SDU is delivered to customers with a default ORT.

### E. General Operation

The SDU controls and processes all essential data in order to manage the reception and transmission of data through the satellite link. The SDU controls the set-up of the required channel types, providing modulation/demodulation, error correction, coding, and data rates associated with the satellite communication channel(s).

The SDU is of modular design and can be configured for use on a wide variety of aircraft. That is cabin only, cockpit only or cabin and cockpit services.

The SDU converts digital/audio inputs to Radio Frequency (RF), and contains a HPA function providing the necessary output power to support communication between the aircraft and the satellite. It also controls the associated antenna sub-system and uses the SCM for its own configuration data purposes.

When the distance between the SDU and the DLNA would require an RF cable with a loss of >1.4dB or if more than 30W of RF power is required when cable loss is < 1.4dB, an FMHPA may be placed between the SDU and the DLNA to amplify the signal. The SDU internal HPA will then run at a reduced power output.

# THALES

## Installation Maintenance Manual SDU 82155 Series SCM 82158 Series

The SDU operates within set frequency bandwidths:

- RX range is between 1525 to 1559 MHz
- TX is tuned over the range 1626.5 to 1660.5 MHz

### **F. Sub-modules Basic Detailed Operation**

The Front Panel assembly gives visual indications for system status, external maintenance interface connections, the SDU Person Activated Self-Test (PAST) push button and a connector for the Standalone Interface System (SIS).

The Backplane assembly makes interconnections between external interfaces and the SDU internal sub-assemblies.

The APM provides interfacing to external avionics. It receives aircraft position, speed and heading information from external avionics via ARINC 429, and updates the CCM with position information every second. The APM manages satellite selection based on aircraft position, and maintains antenna pointing to the wanted satellite beam steering via ARINC 429. The APM manages RF resources and set CCM transmit power levels, taking into consideration antenna gain and cable losses stored within the ORT.

The CPM handles and controls all communications interfaces (Ethernet, RS232 and RS422) and analog audio (cockpit 4-wire).

The CCM converts user's input/output data to signals suitable for transmitting and receiving L-Band signals using the satellite link.

The HPA module amplifies the low level RF signals from the CCM to produce high power output prior to connection to the antenna.

The PSM operates from 115 Vac and supplies low level dc power supplies to SRUs within the SDU and 12 Vdc to the SCM.

The OCXO provides 10 MHz clock reference signal for the CCM circuit.

# THALES

## Installation Maintenance Manual SDU 82155 Series SCM 82158 Series

### G. Operating Environment

(1) Normal Operating temperature:

Between -15° C (5° F) and +70° C (158° F)

**NOTE:** Short term operating Temperature - 40°C

(2) Cooling:

Forced air type in accordance with ARINC 600, requiring minimum airflow rate of 50 kg/hr, blowing from bottom to top. Maximum inlet air temperature +70° C (158° F)

(3) Heat dissipation:

250W (assuming 100% duty cycle with HPA operating at 30W output).

**NOTE:** Typically 170W with dual SBB channels.

### H. Environment Conditions

The SDU complies with the RTCA/DO-160-E (ED-14E). The environmental qualifications categories complied with, are as per listed refer (Table 2.1).

Table 2.1 Environmental Test categories for SDU and SCM

RTCA DO-160E (ED-14E) Environmental Categories		
Section	Condition	Category
4.0	Temperature/Altitude	A2
4.5.4	Loss of Cooling	V
5.0	Temp Var	B
6.0	Humidity	B
7.0	Shock/Crash	B,E
8.0	Vibration	R
	Vibration Curve	C
9.0	Explosion	E
10.0	Waterproof	X
11.0	Fluids	X
12.0	Sand/Dust	X
13.0	Fungus	F



# THALES


**Installation Maintenance Manual**  
SDU 82155 Series  
SCM 82158 Series

<b>RTCA DO-160E (ED-14E) Environmental Categories</b>		
<b>Section</b>	<b>Condition</b>	<b>Category</b>
14.0	Salt Fog	X
15.0	Magnetic Effect	A
16.0	Power Input	A(CF), A(NF), A(WF)
	Harmonics	H
17.0	Voltage Spike	A
18.0	Conducted Audio Susceptibility	K(CF), K(NF) K(WF)
19.0	Induced Signal Susceptibility	CW
20.0	RF Susceptibility	TT
21.0	RF Emissions	M
22.0	Lightning Induced	A3G33 (SDU 82155A only)
23.0	Lightning Direct Effects	X
24.0	Icing	X
25.0	ESD	TBC
26.0	Fire, Flammability	TBD

## Installation Maintenance Manual SDU 82155 Series SCM 82158 Series

### I. Identification Label

Figure 2.5 represent the SDU Front Panel Identification Panel, for detailed description of the numbered field Refer to Table 2.2.



Tav\_e\_0000727\_00

Figure 2.5 Example of SDU Front Panel Legend

# THALES

**Installation Maintenance Manual**  
SDU 82155 Series  
SCM 82158 Series

Table 2.2 SDU Front Panel Legend

<b>SDU Front Panel Legend</b>	
1	Manufacturer's Name
2	Voltage Supply, Compass Safe Distance
3	Manufacturer's Code
4	Equipment Serial Number
5	Date of Final Factory Inspection (month and year)
6	Amendment Label
7	Inspection Stamp
8	Standalone Identification System, Weight of Equipment, FCC ID, Hardware and Software Compliance Reference
9	Caution labels
10	Carrying Handle
11	Hold Down Lugs
12	Status Light Emitting Diodes (LEDs)
13	Ethernet RJ45 Maintenance Connector
14	Field Loadable Software Warning
15	Push To Test Switch
16	Software Part Number
17	Hardware Minor Revision
18	Hardware Part Number

# THALES

## Installation Maintenance Manual SDU 82155 Series SCM 82158 Series


### J. Weight and Dimensions

**NOTE:** Weights and measurements in this manual use both U.S (inches) and S.I. (metric, m.m.) values.

- (1) SDU Type 82155A
  - For overall dimensions (refer to Figure 2.6)
  - Form Factor: ARINC 600, 6 MCU
  - Mass: 9.5 kg (21 lb) maximum.
- (2) SDU Type 82155D
  - For overall dimensions (refer to Figure 2.6)
  - Form Factor: ARINC 600, 6 MCU
  - Mass: 11 kg (24 lb) maximum.

# THALES

## Installation Maintenance Manual SDU 82155 Series SCM 82158 Series



Tav\_e\_0000733\_00

Figure 2.6 SDU Overall Dimensions.

# THALES

**Installation Maintenance Manual**  
SDU 82155 Series  
SCM 82158 Series

**THIS PAGE INTENTIONALLY BLANK**

## K. SDU Electrical Characteristics

- Normal Operation, Supply voltage: 100 to 122 Vrms, ac, Frequency Range 360 Hz to 800 Hz
- Power consumption: 280W maximum
- RF Power Rating: Internal HPA variable up to 30W depending upon services required.

## 2.5. SYSTEM INTERFACES

The SDU interfaces with various aircraft systems.

### A. Aircraft Power Utility Service

The TFS interfaces with the aircraft primary power generator (Refer to Figure 2.7):




Figure 2.7 TFS example of aircraft Power Distribution diagram

## B. Avionics Interfaces

The following avionics interfaces are supported:

- External 35W FMHPA
- Specific to type Cabin Network domain
- ARINC 781 High Gain Antennas (HGA) and Intermediate Gain antennas (IGA)
- ARINC 429 interfaced equipment (IRS, Global Positioning System (GPS), MCDU, CMU, CMS)
- EASA/FAR 25.1309 Equipment, systems and installations
- DLNA
- SCM
- Nav Data from Navigation Systems.

In order to comply with transmit burst time, INMARSAT requires the SDU to be provided with the aircraft present position within 1500m in three dimensions, referenced to WGS-84 (GPS) . In order to comply with this requirement the TFS SDU requires ARINC 429 Nav Data labels (Refer to Table 2.3). The values apply to aircraft where only one Nav Data bus is connected.

For Classic and S64 only IRS present position is required.

Table 2.3 ARINC 429 Nav Data Labels - Hybrid

PARAMETERS	ARINC 429 LABELS
Latitude GNSS - Hybrid/Inertial	254/Inertial
Longitude GNSS - Hybrid/Inertial	255/Inertial
Ground Speed GNSS - Hybrid	175
Track Angle True GNSS – Hybrid	137
True Heading – Hybrid	132
Pitch Angle	324
Roll Angle	325
GNSS Height (HAE) or Hybrid Altitude MSL	370 or 261
GNSS UTC (Binary)	150
GNSS Date	260



# THALES

## Installation Maintenance Manual SDU 82155 Series SCM 82158 Series

PARAMETERS	ARINC 429 LABELS
GNSS Sensor Status	273
GNSS HDOP	101

### C. Cockpit Interfaces (SDU Type 82155D only)

- Cockpit Audio Management Unit (AMU)
- Centralised Fault Display System (CFDS)
- Communications Management Unit (CMU)
- Multi-Purpose Control and Display Unit (MCDU).

### D. Maintenance System Interfaces

The SDU supports the following maintenance system interfaces:

- Aircraft Data Loader (ADL), ARINC 615/615A
- Portable Data Loader (PDL), ARINC 615A
- Thales Maintenance Terminal.

**NOTE:** For more information concerning data loading tools contact the Thales TFS product support representative at the following address:

86 Bushey Road  
Raynes Park, London  
SW20 0JW, UK

Tel. +44 (0)20 8946 8011 (Switchboard)

Tel. +44 (0)20 8946 5169 (Hot desk).

## 2.6. SDU CONFIGURABLE PINOUT AND PIN DESCRIPTION

In the case of using the mandatory configuration straps the SDU is configurable via the SDU ARINC 600 configuration straps as defined in ARINC 781.

The straps input values will be read only at unit power-up to determine the system configuration. The SDU configuration will be selectable by multiplexing the Configuration Straps inputs with the service availability discrete outputs as per ARINC 781 Attachment 1-4.

## A. Mandatory Configuration Pins

The link between pins Top plug (TP)3D and TP3E must be removed when an external FMHPA is connected. They are used as hardware implemented safety override to force the internal HPA function into low power mode.

Pin TP3G must be used on all aircraft installations since one of its functions is to indicate whether all other configuration pins (excluding TP3D, TP3E, TP3F, TP3G, and TP4D) should be used by the SDU. Pin TP4D should be used on all aircraft installations since it indicates the SDU number (1 or 2).

Pin TP3F must be used on all aircraft installations since it indicates that the number of all configuration pins (excluding TP3D) including the parity pin itself connected to service availability discrete (or TP3D) is odd.

## 2.7. SDU INTERCONNECT DATA

### A. ARINC 600 Standard Interwiring Connector

The SDU ARINC 600 connector provides:

- Input/Output connections
- EMC filtering to input and output interfaces
- ESD (Electrostatic Discharge) (Refer DO-160 E section 25 Cat A).

The SDU is provided with a low insertion force, size 2-shell receptacle in accordance with ARINC 600 Attachment 19. This connector accommodates coaxial and signal interconnections in the TP insert, Quadrax and signal interconnections in the middle plug (MP) insert, and coaxial, fibre and power interconnections in the Bottom Plug (BP) insert. The contact arrangements are as follows:

- Insert arrangement 08 receptacle in accordance with ARINC Specification 600, Attachment 11 for the top insert (Size 1 Coax cavity and Size 22 Signal sockets)
- Insert arrangement 120Q2 receptacle in accordance with ARINC Specification 600, Attachment 20, Figure 20-6.5.5 for the middle insert (Size 8 Quadrax cavities for pin components and Size 22 Signal sockets)
- Insert arrangement 12F5C2 receptacle in accordance with ARINC Specification 600, Attachment 19, and Figure 19-49.19 for the bottom insert (Size 12 Electrical pins, Size 16 Electrical pin, Size 5 Coax cavities, and Size 16 Optical cavities).

## Installation Maintenance Manual

SDU 82155 Series

SCM 82158 Series

- Index pin code 081 in accordance with ARINC Specification 600, Attachment 18 should be used on both the SDU and the aircraft rack connectors

### (1) ARINC 600 Pin Assignment

The layout of the rear panel ARINC 600 connector and the Pin assignment are shown in the figures 2.8, 2.9, 2.10 and 2.11. For further Information regarding the ARINC 600 connector refer ARINC 781 (Refer to Figure 2.8).

# THALES

## Installation Maintenance Manual

SDU 82155 Series

SCM 82158 Series





Figure 2.8 ARINC 600 Connector Layout

**Installation Maintenance Manual**  
SDU 82155 Series  
SCM 82158 Series



Tav\_e\_0000735\_00

Figure 2.9 ARINC 600 Top Plug

## Installation Maintenance Manual

SDU 82155 Series

SCM 82158 Series




Figure 2.10 ARINC 600 Bottom Plug

## Installation Maintenance Manual SDU 82155 Series SCM 82158 Series

	A	B	C	D	E	F	G	H	J	K
1	Data from MCDU 1 A	Data from MCDU 1 B	Call Place/End Discrete Input 1	SCM Pwr +12V	Multi-Control Output A	Multi-Control Output B	Resv Ext Reset Discrete Input	Call Place/End Discrete Input 2	Data from MCDU 2 A	Data from MCDU 2 B
2	Data from primary IRS A	Data from primary IRS B	CP Voice Chime Signal Contact	SCM Pwr Return 0V	BITE Input from HPA A	BITE Input from HPA B	RSVD Mfr-Specific 0-28V Discrete Output	CP Voice Chime Signal Contact	Data from secondary IRS A	Data from secondary IRS B
3	Data from CMU 1 A	Data from CMU 1 B	Cockpit Voice Call Light Output 1	SDU Data to SCM A	Spare Discrete Output	Spare Discrete Input	SPARE	Cockpit Voice Call Light Output 2	Data from CMU 2 A	Data from CMU 2 B
4	Cockpit Audio Input 1 High	Cockpit Audio Input 1 Low	Cockpit Voice Mic On Input 1	SDU Data to SCM B	Spare Discrete Output	Spare Discrete Input	SPARE	Cockpit Voice Mic On Input 2	Cockpit Audio Input 2 High	Cockpit Audio Input 2 Low
5	Cockpit Audio Output 1 High	Cockpit Audio Output 1 Low	CP Voice Go Ahead Chime Reset 1	SCM Data to SDU A	Spare Discrete Output	Spare Discrete Input	Spare ARINC 429 Output A	Spare ARINC 429 Output B	Cockpit Audio Output 2 High	Cockpit Audio Output 2 Low
6	Spare Discrete Input	Spare Discrete Input	Spare Discrete Input	SCM Data to SDU B	Ethernet 5 10 Base T (spare) from SDU to User+	Ethernet 5 10 Base T (spare) from SDU to User-	Spare ARINC 429 Input A	Spare ARINC 429 Input B	Spare ARINC 429 Input A	Spare ARINC 429 Input B
7	AES ID Input A	AES ID Input B	WOW Discrete Input	WOW Input 1	Ethernet 5 10 Base T (spare) from User to SDU +	Ethernet 5 10 Base T (spare) from User to SDU -	Spare ARINC 429 Output A	Spare ARINC 429 Output B	Data to CMU 1 & 2 A	Data to CMU 1 & 2 B
8	Data from CFDS A	Data from CFDS B	BITE Input Top/Port BSU/Ant A	BITE Input Top/Port BSU/Ant B	Data Loader Link A	TX Mute Input	BITE Input STBD BSU A	BITE Input STBD BSU B	Data to CFDS A	Data to CFDS B
9	From Airborne Data Loader A	From Airborne Data Loader B	Crosstalk from other SDU A	Crosstalk from other SDU B	Dual System Select Discrete I/O	Dual System Disable Discrete Inp.	Crosstalk to other SDU A	Crosstalk to other SDU B	To Airborne Data Loader A	To Airborne Data Loader B
10	Data from MCDU 3 A	Data from MCDU 3 B	Port BSU HPA Mute Input A	Port BSU HPA Mute Input B	LNA On / Off Control	BITE Input from LNA	STBD BSU HPA Mute Input A	STBD BSU HPA Mute Input B	Data to MCDU 1, 2, 3 A	Data to MCDU 1, 2, 3 B
11	POTS 1 A	POTS 1 B	Cabin CEPT-E1 Data Output A	Cabin CEPT-E1 Data Output B	Service Availability Discretes 1	Service Availability Discretes 2	Cabin CEPT-E1 Data Input A	Cabin CEPT-E1 Data Input B	POTS 2 A	POTS 2 B
12					Service Availability Discretes 3	Service Availability Discretes 4				
13					Service Availability Discretes 5	Service Availability Discretes 6				
14					Service Availability Discretes 7	Service Availability Discretes 8				
15					Service Availability Discretes 9	Service Availability Discretes 10				

Tav\_e\_0000725\_00

Figure 2.11 ARINC 600 Connect Arrangement For Middle Plug Insert

## **B. Electrical Interconnection Diagrams**

The SDU interconnection diagrams (refer to 2.12 to 2.16) illustrate all the necessary connection between the SDU and all the other interfaced equipment.



## Installation Maintenance Manual SDU 82155 Series SCM 82158 Series





Figure 2.12 TFS System Interconnection Block Diagram - SDU Type 82155A (Single Aisle Configuration)



**Installation Maintenance Manual**  
SDU 82155 Series  
SCM 82158 Series

**THIS PAGE INTENTIONALLY BLANK**

## Installation Maintenance Manual SDU 82155 Series SCM 82158 Series



### Notes

- Note 1 : System interconnections are as per ARINC781 - refer to ARINC 781 for clarification / further detail.
- Note 6 : Uses "Star-Quad" cable as defined in ARINC 664 Part 2. Cross-over to be provided in cable.
- Note 7 : Pins not required are not listed and should be left 'Not-Connected'.
- Note 8 : Cross-over to be provided in cable, when using standard RJ-45 Ethernet connections.
- Note 9 : Radial P/No: 620-600-700 does not include all necessary contacts; 1 x Size 5 Crimp Socket Coaxial Contact must also be ordered: Radial P/No: 620-021.
- Note 10 : Pigtails for wiring shields/screens are to be made as short as possible to reduce susceptibility to interference.
- Note 11 : Uses "Shielded, Twisted Pair" cable as defined in ARINC 664 Part 2.
- Note 12 : The Maintenance Terminal interface will only be connected during maintenance activities.
- Note 13 : For the External Reset discrete input signal, ground state defined as input voltage less than 3.5V and resistance to airframe dc ground less than 20 mohms. Open state defined as input voltage higher than 14V and resistance to airframe dc ground higher than 100000 ohms.

#### Note 2 RF Cable Losses

		RF Loss	
SDU to D/LNA	Loss	1.4 dB	
D/LNA to Antenna	Loss	0.3 dB	
D/LNA to SDU	Loss	25 dB	

The IGA mount RF connector (J2), the DLNA mount Antenna connector (J1) and the DLNA mount RX (SDU input) connector (J2) are all TNC Jack (female) type connectors.


The DLNA mount TX (SDU output) connector (J3) is a N-Type Jack (female) type connector.

#### Note 3 SCM Connector

Pin	Signal	Description
1	Data to SDU A (RS422)	Data to SDU A
2	Data to SDU B (RS422)	Data to SDU B
3	Data from SDU A (RS422)	Data from SDU A
4	Data from SDU B (RS422)	Data from SDU B
5	Reserved/ RS232 GND	Connection Not required
6	Spare	Connection Not required
7	Chassis Ground	Chassis Ground
8	Power Input +8 to +15V	SCM Power Input
9	Reserved/ Enable RS232	Connection Not required
10	Reserved/ 0V strap output	Connection Not required
11	Spare	Connection Not required
12	Reserved/ RS232 Tx	Connection Not required
13	Reserved/ RS232 Rx	Connection Not required
14	Spare	Connection Not required
15	Power Return 0V	SCM Power Return

The SCM connector is a DB15 male connector, mating with a DB-15 female connector on the cable, in accordance with MIL-DTL-24308 (15 pins - gauge 20)


#### Note 4 IGA/HGA Power and Control Connector



The IGA/HGA Connector is a receptacle - 13-35 insert of the MIL-C-38999 Series III family, D38999/24FC35PN which mates with D38999/26FC35S on the cable

PIN No	SIGNAL	DESCRIPTION
1	+28 Vdc	Connection Not Required
2	28 Vdc RTN	Connection Not Required
3	Antenna BITE A	ARINC 429 from antenna
4	Antenna BITE SCRIN	Screen for ARINC 429
5	Antenna BITE B	ARINC 429 from antenna
6	Antenna Control A	ARINC 429 to antenna
7	Antenna Control SCRIN	Screen for ARINC429
8	Antenna Control B	ARINC 429 to antenna
9	D/LNA BITE	BITE from D/LNA
10	D/LNA SCRIN	Screen/RTN for D/LNA
11	D/LNA CTL	D/LNA on/off control from antenna
12	Serial SCRIN	Connection Not Required
13	RS422 RXD A	Connection Not Required
14	RS422 RXD B	Connection Not Required
15	RS422 TXD A	Connection Not Required
16	RS422 TXD B	Connection Not Required
17	ATE Pin	Connection Not Required
18	115 Vac Hot	Aircraft ac power
19	115 Vac Return	Aircr aft ac power
20	--	Connection Not Required
21	--	Connection Not Required
22	Chassis Ground	Chassis Ground

#### Note 5 D/LNA Power and Control Connector



The D/LNA Connector is MS3470L1210P which mates with MS3476L1210S on the cable

Pin	Signal	Description
Pin A	Chassis Ground	Chassis Ground
Pin B	LNA Control	LNA Control
Pin C	Future Spare	Connection Not required
Pin D	Future Spare	Connection Not required
Pin E	115 Vac Cold	Aircraft AC Power
Pin F	115 Vac Hot	Aircraft AC Power
Pin G	+28V DC Hot	Connection Not required
Pin H	LNA BITE	LNA Bite
Pin J	LNA BITE Return	LNA BITE Return
Pin K	+28V DC Return	Connection Not required

Tav\_e\_0000737\_00

Figure 2.13 SDU Type 82155A Interconnection Diagram Notes



**Installation Maintenance Manual**  
SDU 82155 Series  
SCM 82158 Series

**THIS PAGE INTENTIONALLY BLANK**

## Installation Maintenance Manual SDU 82155 Series SCM 82158 Series




Figure 2.14 TFS System Interconnection Block Diagram - SDU Type 82155D (with External FMHPA) - HGA




**Installation Maintenance Manual**  
SDU 82155 Series  
SCM 82158 Series

**THIS PAGE INTENTIONALLY BLANK**

## Installation Maintenance Manual SDU 82155 Series SCM 82158 Series

### Notes



Note 1: System interconnections are per ARINC 781-1

Note 3: An RF attenuator may be needed if loss in DLNA to SDU cable does not fall within range specified in Note 4.

Note 8: Ethernet and ISDN connections should use "star Quad" cable as defined in ARINC 664 part 2. Cross-over to be provided in cable.

Note 9: SDU Pins not required are not listed and should be left "Not-connected".

Note 10: HPA power and control connector.

Note 11: Radial P/N:620-600-700 does not include all necessary contacts; 1x Size 5 crimp Socket Coaxial Contact must also be ordered, Radial P/N:620-021.

Note 12: Pigtails for wiring shields/screens are to be made as short as possible to reduce susceptibility to interference. Shielded cabled and EMI backshells should be used where possible

Note 13: A-429 (shielded twisted pair).

Note 14: Discrete.

Note 15: Power.

Note 16: Male quadrax insert.

Note 17: Connection of shields and grounding for SDU and Cabin/EFB Server are as shown. Connection of shields for SCM and ethernet ports is as per airframe manufacturers grounding and shielding policy.

Note 18: RS-422 (shielded/twisted pair).

### Assumptions

1: As per ARINC 781 attachment 1-4, note 15. If hybrid IRS data is not available, then connection to separate, autonomous inertial and GNSS navigation equipment may be required. It is assumed that hybrid IRS data is not available. If at least one IRS bus is not providing GNSS or hybrid labels as per ARINC 781-1 attachment 1-4, note 15, connection to AES ID is required for GPS derived latitude and longitude.

2: Mandatory configuration pins are not connected since an external HPA is fitted.

**Note 4**

### RF Cable Losses

RF Loss	
SDU to DLNA	Loss 1.4 dB
DLNA to Antenna	Loss 0.3 dB
DLNA to SDU	6 dB Loss 25 dB

The IGA mount RF connector (J2), the DLNA mount Antenna connector (J1) and the DLNA mount RX (SDU input) connector (J2) are all TNC Jack (female) type connectors.

The DLNA mount TX (SDU output) connector (J3) is a N-Type Jack (female) type connector.

**Note 6**

### IGA/HGA Power and Control Connector

PIN No	SIGNAL	DESCRIPTION
1	+28 Vdc	Connection Not Required
2	28 Vdc RTN	Connection Not Required
3	Antenna BITE A	ARINC 429 from antenna
4	Antenna BITE SCRIN	Screen for ARINC 429
5	Antenna BITE B	ARINC 429 from antenna
6	Antenna Control A	ARINC 429 to antenna
7	Antenna Control SCRIN	Screen for ARINC429
8	Antenna Control B	ARINC 429 to antenna
9	DLNA BITE	BITE from DLNA
10	DLNA SCRIN	Screen/RTN for DLNA
11	DLNA CTL	DLNA on/off control from antenna
12	Serial SCRIN	Connection Not Required
13	RS422 RXD A	Connection Not Required
14	RS422 RXD B	Connection Not Required
15	RS422 TXD A	Connection Not Required
16	RS422 TXD B	Connection Not Required
17	ATE Pin	Connection Not Required
18	115 Vac Hot	Aircraft ac power
19	115 Vac Return	Airor alt ac power
20	--	Connection Not Required
21	--	Connection Not Required
22	Chassis Ground	Chassis Ground

The IGA/HGA Connector is a receptacle - 13-35 insert of the MIL-C-38999 Series III family D38999/26FC35S on the cable

**Note 5**

### SCM Connector

Pin	Signal	Description
1	Data to SDU A (RS422)	Data to SDU A
2	Data to SDU B (RS422)	Data to SDU B
3	Data from SDU A (RS422)	Data from SDU A
4	Data from SDU B (RS422)	Data from SDU B
5	Reserved/ RS232 GND	Connection Not required
6	Spare	Connection Not required
7	Chassis Ground	Chassis Ground
8	Power Input +8 to +15V	SCM Power Input
9	Reserved/ Enable RS232	Connection Not required
10	Reserved/ 0V strap output	Connection Not required
11	Spare	Connection Not required
12	Reserved/ RS232 Tx	Connection Not required
13	Reserved/ RS232 Rx	Connection Not required
14	Spare	Connection Not required
15	Power Return 0V	SCM Power Return

The SCM connector is a DB15 male connector, mating with a DB-15 female connector on the cable, in accordance with MIL-DTL-24308 (15 pins - gauge 20)

**Note 7**

### D/LNA Power and Control Connector

Pin	Signal	Description
Pin A	Chassis Ground	Chassis Ground
Pin B	LNA Control	LNA Control
Pin C	Future Spare	Connection Not required
Pin D	Future Spare	Connection Not required
Pin E	115 Vac Cold	Aircraft AC Power
Pin F	115 Vac Hot	Aircraft AC Power
Pin G	+28V DC Hot	Connection Not required
Pin H	LNA BITE	LNA BITE
Pin J	LNA BITE Return	LNA BITE Return
Pin K	+28V DC Return	Connection Not required

The D/LNA Connector is MS3470L1210P which mates with MS3476L1210S on the cable

ARINC 600 - Shell Size #2 Connector  
View above is looking at the SDU mount connector, Radial Part Number: 620-600-703.  
Tray-mount mating half is supplied with all necessary inserts, except 1 x Size 5 Socket Coax insert (male centre contact) (Radial P/N: 620-021), which should be ordered separately. See Radial specification for 620-600-700 for further details on supplied inserts.  
Fibre inserts are not required and will not be populated on the SDU mount connector, filler plugs will be used to fill cavities. Size 5 Coax insert BP-6 is not required on the SDU mount connector and will not be populated, a filler plug will be used to fill cavity.  
Index Code: 81 (5,2,2)  
(Top Insert: 08 / Middle Insert: 120Q2 / Bottom Insert: 12F5C2)  
For the index code pins above, the dark colour represents the post.

Tav\_e\_0000708\_00

Figure 2.15 SDU Type 82155D Interconnection Diagram Notes



**Installation Maintenance Manual**  
SDU 82155 Series  
SCM 82158 Series

**THIS PAGE INTENTIONALLY BLANK**



Tav\_e\_0000710\_00




Figure 2.16 TFS System Interconnection Block Diagram - SDU Type 82155D Full Cockpit Interfaces



**Installation Maintenance Manual**  
SDU 82155 Series  
SCM 82158 Series

**THIS PAGE INTENTIONALLY BLANK**

## C. Interconnection Cables

### (1) RF Coaxial Cables

The SDU is connected to the DLNA or FMHPA and Antenna (refer to Figures 2.12 to 2.15), by means of a RF low loss coaxial cable. The distance between the devices, and the cable selected for the installation must be such that the cable losses remains within the limits indicated within Figure 2-15, Note 4. If the cable losses cannot remain within the limits then an FMHPA must be installed between the SDU and the DLNA (Refer to Figure 2.13). All coaxial cable should be 50 Ohms nominally.

**NOTE:** Interconnect cables should be routed away from sources of potential electromagnetic interference. Use shielded wires and cables where necessary.

#### a. SDU to DLNA Tx Port

RF cable characteristics for the SDU or FMHPA to DLNA Tx port are as follows:.

Table 2.4

Maximum Path Loss	Nominal Max Power	Frequency Range
1.4 dB (see Note)	60 W	1626.5 – 1660.5 MHz

#### b. DLNA to SDU Rx Port

RF cable characteristics for the DLNA to SDU Rx port

Table 2.5

Loss Range	Nominal Max Power	Frequency Range
6 – 25 dB (see Note)	0.5 W	1525 – 1559 MHz

#### c. DLNA to Antenna Port

RF cable characteristics for the DLNA to Antenna port

Table 2.6

Max Path Loss	Nominal Max Power	Frequency Range	5th Order Inter-modulation	7th order Inter-modulation
0.3 dB (see Note)	46 W	1525 – 1660.5 MHz	(see ARINC 781)	(see ARINC 781)

# THALES

## Installation Maintenance Manual

SDU 82155 Series

SCM 82158 Series

### d. SDU to FMHPA

RF cable characteristics for the SDU to FMHPA

Table 2.7

Maximum Path Loss	Nominal Max Power	Frequency Range
8-18 dB (see Note)	200 mW	1626.5 – 1660.5 MHz

**NOTE:** Applied to the complete RF cable path and not to each component within the RF path.

#### (2) Power Cables

The SDU mains power cable must be able to handle 115 Vac/7.5A (see note).

**NOTE:** SDU switch on surge is approximately 7A for the duration of 200ms.

The SDU to SCM power cable must be able to handle 12Vdc. Cable size is 22 AWG.

#### (3) ARINC 429 Connections

ARINC 429 connection cable must be a size 22 single twisted and shielded pair of wires cable.

#### (4) Ethernet

The recommended Aerospace Grade 100Base Ethernet cable is P/N NF 24Q100. The conductor AWG size (19 strands) is size 24.

Flammability requirements for this cable meet or exceed FAR25.869 requirements.

## 2.8. SCM COMPONENT DESCRIPTION

### A. Hardware

The only SCM Part Number available is 82158D Series and all other different SDU configurations. The SCM hardware meets RTCA/DO-254 level D requirements.

The SCM contains four USIM (Universal Subscriber Identity Module) cards. The SCM also contains an External Configuration Memory (ECM) storing the Owner Requirement Table.

#### (1) External Description

The SCM is composed by the following external elements (Refer to Figure 2.17):

- The body of the SCM with one main identification label (1).

# THALES

## Installation Maintenance Manual SDU 82155 Series SCM 82158 Series

- The 15-way D-type (male) socket (2)
- The mounting plate with four attaching holes (3)




Figure 2.17 Example of SCM External View

### (2) Internal Description

The SCM is composed of the following internal parts (Refer to Figure 2.18):

- One gasket between the D-type connector and the Body of the SCM (2)
- One PEC card with a D-type connector attached (5)
- Four USIM cards holders (4)
- A plate attached to the body by four screws and washers (3)
- A body attached to the single PEC card by four screws and washers (1)

## Installation Maintenance Manual SDU 82155 Series SCM 82158 Series




Figure 2.18 SCM exploded view

### B. ORT Parameters

The ORT is represented by a database containing a set of configuration data for the exclusive use of the SDU. The ORT is partitioned for two types of parameters in accordance with ARINC 781:

- User parameters, for operator use
- Secure parameters, for aircraft specific configurations

The ORT parameters are stored within the SCM and/or SDU, and are used to customise the operation of the TFS system, allowing various preferences to be set to enable the

# THALES

## Installation Maintenance Manual SDU 82155 Series SCM 82158 Series

efficient use of the equipment within different platform configurations. The SDU and SCM are delivered with a default ORT.

### C. ORT Synchronisation

At each power up the SDU reads the ORT from the SCM, and compares it with its locally stored copy. In normal condition the SDU and SCM ORTs should be the same, but if different the SDU overwrites the local copy with the ORT read from the SCM. The SDU uses that ORT until the SDU is powered down.

A small number of System Configuration Pins are mandatory. The others may be optionally used by installers to define additional configuration details. If the optional System Configuration Pins are not used then the configuration information may be found in the Owner Requirements Table (ORT). TP3G is used to define whether the optional System Configuration Pins should be read by the SDU.

The SDU stores the local copy of the SCM Secure and User ORTs over a power down in case one of the ORTs from the SCM is not valid when the SDU next powers up.

**NOTE:1.** For more information concerning the operation of the SDU when it determines that an ORT is not valid refer to the ARINC 781 specification section 3.4.2 'Configuration & Identification Data'.

**NOTE:2.** For more information concerning changes or updates regarding ORT contact the Thales TFS product support representative.

### D. Basic Operation

When operating, the SCM interfaces with the SDU CCM via the SDU CPM. The SCM operation will not commence until an input voltage from the SDU is detected. Alternatively, when removed from the aircraft the SCM will also acknowledge an input voltage from a personal computer (PC), and will operate as if it were connected to an SDU.

A single USIM card is required for each Swift Broadband channel operated by the SDU.

The SCM contains an External Configuration Memory (ECM). The ECM is a non-volatile memory, which stores the ORT database.

### E. Environment Condition

Refer (Table 2.1)


# THALES

## Installation Maintenance Manual SDU 82155 Series SCM 82158 Series

### F. Identification Label

The main manufacturer label gives the following information (Refer to Figure 2.19):

- HW PNR: Equipment part number in alphanumeric form and bar code form
- Minor rev: Minor revisions
- SW PNR: For Owner Requirement Table (ORT)
- MFR: Manufacturer code in alphanumeric and bar code form
- SER: Basic part number and serial numbering alphanumeric and barcode form
- DMF: Date of final factory inspection (month and year)
- Amdt: Amendments
- CSD: Compass Safe Distance
- Wt: Weight
- FAA TC: Federal Aviation Administration Type Certificate (Blank)
- FCC id: Federal Communications Commission identification (Blank).



Tav\_e\_0000724\_00

Figure 2.19 Example of SCM Identification Label



## G. SCM Electrical Characteristics

Electrical characteristics of the SCM are as follows:

- Power input: 8 to 15 Vdc. SDU typical supplied voltage 12 Vdc
- Power consumption: 3.6 W or less
- Max current: 300 mA at 12 Vdc.

## H. Weight and Dimensions

Weight and dimensions of the SCM are as follows:

- For overall dimensions Refer to Figure 2.20
- Mass = 0.25kg (0.44Lbs).





Figure 2.20 SCM Overall Dimensions

## I. SCM Connector

The SCM connector is a DB15 (15 pins – gauge 20) male connector (Refer to Figure 2.21), mating with a DB-15 female connector on the cable. For complete description of Pin Assignment refer to Figure 2-13 Note 3.



Tav\_e\_0000729\_00

Figure 2.21 Front View of 15 Pin D-Type Connector

## J. Equipment Electrical Interconnection Diagram

The SDU interconnection diagram (Refer to Figure 2.22). The diagram illustrates all the necessary connection between the SCM and the SDU. For description of detailed pin-to-pin connection refer to Figure 2.12 (SDU Type 82155A) and Figure 2.14 (SDU Type 82155D).

# THALES

## Installation Maintenance Manual

SDU 82155 Series

SCM 82158 Series




Figure 2.22 SDU/SCM Interconnection Diagram



**Installation Maintenance Manual**  
SDU 82155 Series  
SCM 82158 Series

**THIS PAGE INTENTIONALLY BLANK**

## SECTION 3

### INSTALLATION GUIDELINES

#### 3.1. INTRODUCTION

The SDU and SCM should be installed in the aircraft in a manner consistent with acceptable workmanship and engineering practices, and in accordance with the instructions set forth in this manual.

To ensure that the system has been properly and safely installed in the aircraft the installer should make a through visual inspection and conduct an overall operational check of the system on the ground prior to commissioning to the Customer and or a flight.

**NOTE:** Before installing any components or cabling, read all notes contained within drawings.

#### 3.2. INTERCHANGEABILITY

The TFS comprises two major sub-systems and a number of individual units. System interchangeability for each of the major sub-systems and unit interchangeability for the individual units. The first major sub-system comprises the SDU and the SCM. The second is the antenna sub-system, comprising two LRUs, the antenna with its integrated beam steering function, and the DLNA. Interchangeability is also desired for the FMHPA.

There are two instances whereby individual units are defined to be functional doublets. This means that the interwiring and pin out definitions are interchangeable, but due to unique protocol implementations, the supply and acquisition of these units are manufacturer specific. Functional Doublets are different from Matched Pairs in that each unit of the Functional Doublet may fail and be changed independently, whereas in Matched Pairs both units must be changed regardless of which unit has failed.

The Functional Doublets are as follows:

- SDU and SCM
- SDU and FMHPA.

### 3.3. SDU/SCM LOCATION AND ACCESSIBILITY GUIDELINES

**CAUTION:** BEFORE EQUIPMENT INSTALLATION ENSURE THAT THE AIRCRAFT POWER SUPPLY CIRCUIT BREAKER IS POSITIONED IN THE OFF CONDITION.

The SDU must be installed in a pressurized zone that is also partially temperature controlled, and mounted on an appropriate ARINC 600 compliant mounting rack. The SDU requires external forced air-cooling (refer Section 2 G).

The SCM should be installed as close to the SDU as possible in order to keep the cable runs to a maximum 10 feet.

To determine the best location, the installer must select equipment locations to allow easy access to these components and their connectors. Equipment location will vary with aircraft type and design/installation specifications.

The location of LRUs must comply with ARINC 781 limitations. The electronic bay is the preferred location to install this unit.

The SDU must be installed in a location that allows the following facilities to be accessible:

- a. Front Panel LEDs
- b. Front Panel TFS system Test Push Button
- c. Front Panel Test Port, Software loading RJ45 connector
- d. Front Panel SIS connector.

### 3.4. MOUNTING TRAY

The mounting tray used for the installation of the SDU must comply with the design specifications for the 6 MCU (Modular Concept Unit) form factor. Refer to the ARINC 600 Specification for detailed information regarding the design of compatible equipment and airframe installations.



Figure 3.1 Example of an ARINC 600, 6 MCU Mounting Tray

### 3.5. COOLING

The SDU is designed to accept an installation configuration able to provide forced air-cooling as defined in Section 3.5 of the ARINC Specification 600.

In normal operation the SDU will be cooled by forced convection with air supplied from the platform services at a maximum flow rate of 50 kg/hr and a temperature of up to 40oC. The cooling air must enter the equipment chassis at the bottom via a plenum chamber and exhaust at the top.

### 3.6. POWER REQUIREMENTS

It is the responsibility of the installer to select the appropriate gauge of wire for power connections, and to ensure that the required safety and voltage drop requirements are complied with.

For SDU power supply specifications refer to:

- a. 2.3.K: SDU Electrical Characteristics.
- b. Figure 2.7: Aircraft Power Distribution.
- c. Figures 2.12 to 2.16: TFS System Interconnection Diagrams.

For SCM power supply specifications refer to:

- a. 2.7.G: SCM Electrical Characteristics.
- b. Figure 2.12 to 2.16: TFS System Interconnection Diagrams.

## 3.7. SDU RF CONNECTIONS

**CAUTION:** DO NOT EXCEED MINIMUM CABLE RADIUS OF CURVATURE FOR THE COAXIAL CABLE. USE DUMMY CABLES FOR A FIRST INSTALLATION TO DETERMINE CABLE RUNS. INSTALL FINAL CABLES AFTER THIS MODELLING OPERATION.

**CAUTION:** ONLY PREFORMED RF CABLES SHALL BE CONNECTED TO THE SATCOM SYSTEM EQUIPMENT. ATTEMPTING TO FORM CABLES OR APPLYING STRESS TO THE CABLES WHILE THEY ARE CONNECTED TO THE EQUIPMENT CONNECTORS MAY CAUSE DAMAGE TO THE EQUIPMENT.

The SDU or FMHPA is connected to the DLNA through a RF coaxial cable. Installation designer must be aware that the shorter the cable is, the better system performance.

As the SDU/DLNA low loss cable is sometimes almost rigid and it could have a diameter not compatible with the IGA and DLNA connectors, it is recommended to install a short portion of a smaller and more flexible cable at each end of this low loss cable (pig tail type installation).

If necessary, secure the cable by means of evenly spaced collars to prevent the cable from chafing on aircraft parts and surfaces. These collars must be of a design, which avoids damaging the cable.

**NOTE:** Interconnect cables should be routed away from sources of potential electromagnetic interference. Use shielded wires and cables where necessary.

### D. Insertion Losses

The SDU RF interface with the Antenna via a DLNA device. The diplexer and LNA are combined into one unit for installation. The Diplexer function couples transmit signals from the SDU to the respective antenna. The LNA amplifies the very low level L-band receive signal from its respective antenna and couples this amplified signal to the SDU.

For detailed RF insertion losses refer to Section 2 C. To ensure these requirements are met, some installations need the SDU to be installed in close proximity to the antenna subsystem components or the use of low loss coaxial cable.

The total loss between the DLNA and the SDU must be in the range 6 to 25 dB. If the RF cable type being used for a short cable length is less than 6 dB, an attenuator must be fitted to ensure the required loss is achieved.



## **E. Product InterModulation (PIM)**

Specific care should be taken to ensure that the RF cables and connectors do not produce intermodulation products at levels higher than those specified in ARINC 781.

## **F. VSWR**

The Voltage Standing Wave Ratio (VSWR) of all RF cables should be 1.2:1 or better.

## **G. Torque Settings**

The cables are to be tightened to the torque settings recommended by the cable manufacturer.

## **H. Cleaning**

Refer to Section 6.5 for cleaning.

### **3.8. BONDING REQUIREMENTS**

The bonding of all units to the airframe must not exceed 20 milliohms. However some aircraft manufacturers or design/installation organisation may require a lower value than the recommended 20 milliohms.

**NOTE:** To assure proper grounding of the TFS system, the surface of the mountings and units must be clean bare metal.



**Installation Maintenance Manual**  
SDU 82155 Series  
SCM 82158 Series

**THIS PAGE INTENTIONALLY BLANK**

## SECTION 4

### INSPECTION AND SYSTEM CHECKOUT

#### 4.1. INSPECTION/CHECK PROCEDURE

The visual check procedures that follow should be performed during or after the SDU/SCM installation, or as a periodic maintenance inspection check of the installation:

##### A. Check Wiring and RF cables

- a. Ensure that a continuity check of all the installation wiring harness has been carried out, and that all the sources are correctly rated on the correct pins.
- b. Check that none of the cables have been damaged, and cannot be damaged by components that are installed later.
- c. Check that the cable runs are spaced away from any moving or hot part that could damage cables when in use.
- d. Verify that the various RF cables are within their minimum radius of curvature tolerances.
- e. Check that any attenuators that may have been used for the installation have not been omitted or mismatched.

##### B. Check SDU

- a. Examine the assembly for external condition (absences of fractures, dents, deformations, cracks, and/or any other abnormal damage).
- b. Visually examine all the external surfaces for possible damage. Check dust cover and external connector for dust, corrosion or damage.
- c. Check that the unit is properly installed and that hold down clamps are firmly tightened.
- d. Check screws and nuts general condition.
- e. Check that the contact resistance between the SDU/SCM and a point on the aircraft structure close to the component does not exceed 20 milliohms.
- f. Check that the correct air cooling and air flow is provided to the SDU.

## C. Check SCM

- a. Examine the assembly for external condition (absences of fractures, dents, deformations, cracks, and/or any other abnormal damage).
- b. Visually examine all the external surfaces for possible damage. Check dust cover and external connector for dust, corrosion or damage.
- c. Check that the unit is properly installed, that all fixing screws are firmly tightened, and the cable to the SDU is secure.

## 4.2. SYSTEM CHECKOUT

At this stage of the installation it is assumed that a continuity check of the wiring has been made, a visual check of the installation harness and RF cabling has been performed, and that the inspection/check procedure has been carried out.

### A. Post-Installation Test

**WARNING: THE RF POWER RADIATED BY THE TFS SYSTEM ANTENNA CAN CAUSE BODILY HARM. A PERSON IS IN DANGER IN A ZONE WHERE THE POWER FLUX IS 1 MW/CM<sup>2</sup>, OR GREATER. DURING SATCOM OPERATION THE SAFETY DISTANCE FROM THE ANTENNA MUST BE NO LESS THAN 3.5M OR 12 FEET. SINCE THERE ARE VARIOUS POSSIBLE ANTENNA LOCATIONS, IT IS THE RESPONSIBILITY OF THE OPERATOR TO DETERMINE THE AREA OF HAZARD FOR THEIR TFS SYSTEM CONFIGURATION AND TO TRAIN PERSONNEL IN GROUND SAFETY PROCEDURES.**

**WARNING: DURING ANTENNA OPERATION (TRANSMISSION), MAKE SURE PERSONNEL ARE NOT EXPOSED TO ANY REFLECTED, SCATTERED, OR DIRECT BEAMS. ENSURE PERSONNEL ARE OUTSIDE THE MINIMUM DISTANCE SPECIFIED.**

## Installation Maintenance Manual

SDU 82155 Series

SCM 82158 Series

- CAUTION:** WHEN TESTING THE COMPLETE TFS SYSTEM (ANTENNA SYSTEM INCLUDED) REFER TO THE APPLICABLE ANTENNA IMM FOR FURTHER SAFETY REQUIREMENTS AND SPECIFICATIONS. THE SDU MUST NOT BE POWERED WITHOUT AN ANTENNA OR SUITABLE LOADCONNECTED ON THE HIGH POWER TRANSMIT OUTPUT PORT.
- CAUTION:** NEVER CONNECT OR DISCONNECT A SATCOM LRU WHEN POWER IS APPLIED.
- CAUTION:** NEVER APPLY HIGH-LEVEL RF SIGNAL TO A POWERED-DOWN LRU.
- CAUTION:** NEVER DISCONNECT RF CABLES WHEN SYSTEM OPERATING.
- CAUTION:** NEVER POWER-UP ANY LRU UNTIL ALL CONNECTIONS IN THE SYSTEM ARE MADE.
- CAUTION:** ENSURE THAT THE APPROPRIATE ORT DATABASE IS INSTALLED IN THE SCM AND/OR SDU BEFORE PERFORMING SYSTEM OPERATIONS.

This test requires that all the Satcom system LRUs (SDU, SCM, FMHPA, DLNA, Antenna and cables) be connected and operating properly, with a means of displaying any system faults detected by the LRU during the Built-In Test Equipment (BITE) test. The results of the test are indicated on the SDU front panel LED.

Type 82155D SDU bite is also sent to the CFDS.

If no system faults are indicated by the BITE test, then the subsystem installation should be considered acceptable. If any subsystem LRU fails the test, it must be returned to the vendor (refer to your vendor customer support).

Refer to the Section 5 Fault Isolation for information on the SDU fault detection capabilities.



**Installation Maintenance Manual**  
SDU 82155 Series  
SCM 82158 Series

**THIS PAGE INTENTIONALLY BLANK**

## SECTION 5

### FAULT ISOLATION

#### 5.1. BITE FUNCTION

The primary purpose of BITE is to assist aircraft maintenance personnel in the correct maintenance of avionics equipment in a cost effective manner. The BITE does not contribute to the required function of the TFS system, but makes it easier to test or debug it.

The SDU controls the TFS system BITE. It collects BITE information from other LRU, and can request other LRU to run tests. The BITE automatically detects failures, providing a mechanism to discover erroneous behaviour of TFS system components.

Fault information is reported to a local maintenance system (e.g. CFDS system or other OMS), and this information is made available to maintenance personnel by means of discretes and/or LED on the SDU front panel. Failures can also be reported to a dedicated local maintenance function through Simple Network Management Protocol (SNMP) and the Management Information Base (MIB).

The System BITE failure data is stored in the SDU within a Non-Volatile Memory (NVM) area. The BITE operates at various levels as indicated in Figure 6-1.

## Installation Maintenance Manual SDU 82155 Series SCM 82158 Series




Figure 5.1 Example of BITE communication for TFS system

## 5.2. TEST FUNCTIONS

### A. OMS or CFDS

Fault information can be displayed from an OMS/CFDS when the aircraft is so equipped. Faults that occur at anytime are stored in fault memory and reported to the OMS or CFDS.

### B. BITE


An operator can verify the operational serviceability of the SDU and SCM by means of a set of testing facilities installed within the SDU. The SDU performs two distinctive types of test:

- A Power-On Self Test (POST) is automatically activated at SDU start up.
- An Person-Activated Self Test (PAST) can be initiated by an operator by depressing the Test push button located on the front panel of the SDU, (see Figure 2-5 item 17). PAST can also be initiated from the CFDS.



(1) POST

At SDU start up (Power On), and with aircraft in the 'on ground' condition the Front Panel LED (FPL) will display the following test sequence:



Tav\_e\_0000716\_00

Figure 5.2 POST LEDs Sequence

**NOTE:** Type 82155D SDU durations are longer, approximately 90 seconds.

## Installation Maintenance Manual

SDU 82155 Series

SCM 82158 Series

### (2) PAST

The PAST function is initiated by depressing the front panel TEST Button (This function is only possible with aircraft on ground). To acknowledge PAST initialisation all the front panel LED start to flash green at the frequency of 2Hz. After approximately 75 seconds the SDU will transit into Operational Mode with the LED displaying the TFS system serviceability condition.

This feature represents an interactive, manual test facility, which assists in the following:

- Active search of failures by triggering a series of system diagnostic tests
- Verification testing e.g. after the installation of a replacement unit
- Failure confirmation purpose.

**NOTE:** PAST can only be initiated after the POST has completed.




Figure 5.3 PAST LEDs Sequence

## 5.3. FAULT ISOLATION

### A. Failures

Failures are reported to an operator by means of a set of multicoloured LED located on the SDU front panel. LED can enter the following steady states:

- Normal equipment operation indicated by the relevant LED displayed in a steady Green condition
- Equipment Hard Failures are indicated by all relevant LED displayed in a steady Red condition
- Partial equipment failures are indicated by all relevant LED displayed in a steady Amber condition
- An LED in OFF (extinguished) condition indicates that the relevant equipment and or a resource is not active or not installed.

**NOTE:** A fault with an interconnecting cable may prevent an LED from illuminating.

### B. Front Panel Indications

Table 5.1 provides LED status decoding information.

## Installation Maintenance Manual SDU 82155 Series SCM 82158 Series

Table 5.1 Front Panel Indications

LED	Flashing Green	Steady Green	Amber	Red	Off
<b>SDU</b>	SDU in Self-Test	SDU ok	Partial Failure (Not Indicted) <sup>1</sup> or ARINC 429/AFDX/RS-422 Bus	SDU Failed (Indicted) <sup>2</sup>	SDU Not Powered
<b>SCM</b>	SDU in Self-Test	SCM/USIM ok	SCM Memory Fail (Not Indicted) <sup>1</sup> or RS-422 Bus Failure <sup>3</sup>	USIM Read/Write Fail. No attempt at SSB registration	SCM Not Installed or SDU Not Powered
<b>Antenna</b>	SDU in Self-Test	Antenna ok	Partial Failure (Not Indicted) <sup>1</sup> or ARINC 429 Bus Failure <sup>3</sup>	Antenna Failed (Indicted) <sup>2</sup>	SDU Not Powered
<b>DLNA</b>	SDU in Self-Test	DLNA ok	N/A	DLNA Failed (Indicted) <sup>2</sup>	SDU Not Powered
<b>Ext. HPA</b>	SDU in Self-Test	N/A	N/A	N/A	N/A
<b>Ext. BSU</b>	SDU in Self-Test	N/A	N/A	N/A	N/A
<b>Ext. Data Bus</b>	SDU in Self-Test	All Data Buses (ARINC 429/AFDX/RS-422) ok	Nav Data not available. ARINC 429 Bus from IRS inactive or IRS Data invalid <sup>4</sup>	Bus Failed <sup>3</sup> (ARINC 429 / AFDX/RS-422)	SDU Not Powered
<b>ORT/ Config.</b>	SDU in Self-Test	ORT / Hardware Configuration Straps	ORT Minor Failure <sup>5</sup> (Not Indicted)	ORT Major Failure <sup>6</sup> or Hardware Configuration Straps Parity Failure(Indicted) <sup>2</sup>	SDU Not Powered
<b>Sat. Link #1</b>	SDU in Self-Test	Channel #1 Service available, ie Logged-On or Registered	Channel #1 attempting Log-On or Registration	N/A	Channel #1 Not attempting Log-On or Registration <sup>7</sup>
<b>Sat.Link #2</b>	SDU in Self-Test	Channel #2 Service available, ie Logged-On or Registered	Channel #2 Service available, ie Logged-On or Registered	N/A	Channel #2 Not attempting Log-On or Registration <sup>7</sup>

**Installation Maintenance Manual**  
SDU 82155 Series  
SCM 82158 Series

List of Explanatory Notes for Table 5.1:

1. Not Indicted means that there is an equipment 'partial' failure such that service Registration / Log-On is still attempted.
2. Indicted means that there is an equipment failure such that Registration / Log-On is not attempted.
3. In the event of a Bus Inactive Failure, the 'Data Bus' LED illuminates Red and the appropriate LRU status LEDs illuminate Amber, e.g. if the SDU reports that the Antenna to SDU bus is inactive or the Antenna reports that the SDU to Antenna bus is inactive, then the 'Data Bus' LED illuminates Red and the SDU and Antenna LED illuminates Amber
4. This is a special case. There will be frequent legitimate occurrences of IRS being switched off whilst On-Ground and even after an IRS is switched on; there is an alignment period, during which the Nav Data is invalid. Under these circumstances, the only action is to illuminate the 'Data Bus' LED Amber, irrespective of whether in On-Ground or In-Air state
5. The ORT/Configuration LED illuminate Amber in the following circumstances:
  - Type 1 ORT Synchronization Minor Failure – Secure ORT within SCM - If the Secure ORT read from the SCM is not valid and if 'local copy' Secure ORT is valid.
  - Type 4 ORT Synchronization Failure - User ORT within SCM - If the User ORT read from the SCM is not valid AND if 'local copy' User ORT is valid.
  - Type 5 ORT Synchronization Failure - User ORT in SDU - if SDU User ORT is invalid.
6. The ORT/Configuration LED illuminates Red in the following circumstances:
  - Type 1 ORT Synchronization Major Failure - Secure ORT within SCM
  - If the Secure ORT read from the SCM is not valid AND if 'local copy' Secure ORT is not valid
  - Type 2 ORT Synchronization
  - Type 3 ORT Synchronization Failure - Secure ORT in SDU that is integral part of SW - if SDU Secure ORT is invalid.
  - Hardware Straps Parity Failure. SDU be indicted.

**Installation Maintenance Manual**  
SDU 82155 Series  
SCM 82158 Series

7. There are many reasons why a channel will not attempt Log-On or Registration, including (but not limited to), OCXO warming up, equipment indictment, commanded Log-Off or De-Registration.

## C. Fault Logging

All information of degraded and abnormal equipment function will be logged internally and made available to a dedicated local maintenance system (e.g. CFDS).

## D. Service Availability Discretes

The status of various system functions can be reported by means of the Service Availability Discretes available on the ARINC 600 connector.

Table 5.2 SDU Serviceability Discretes

Function	Pin Allocation	Steady State Open Circuit	Steady Ground1
SDU	MP 15F	SDU Powered	SDU Not Powered
System Failed	MP 11F	System ok	System Failed <sup>2</sup>
SDU Failed	MP 12E	SDU ok	SDU Failed <sup>3</sup>
SCM Failed	MP 12F	SCM ok or not installed	SCM Failed <sup>4</sup>
Ext. HPA Failed	MP 13E	Ext. HPA ok or not installed	Ext. HPA Failed
DLNA Failed	MP 13F	DLNA ok	DLNA Failed
Antenna Failed	MP 14E	Antenna ok	Antenna Failed
Ext. BSU Failed	MP 14F	BSU ok or not installed	BSU Failed
BUS Failed <sup>5</sup>	MP 15E	All external data buses ok (ARINC 429/AFDX/RS422)	Bus Failed (ARINC 429/AFDX/RS422)
Sat Link #1 Not available	MP 11E	Satcom Channel #1 Logged On/Registered	Satcom Channel #1 Not Logged On/Not Registered
Sat Link #2 Not available	TP 01K	Satcom Channel #2 Logged On/Registered	Satcom Channel #2 Not Logged On/Not Registered

List of Explanatory Notes for Table 5.2:

1. The 'Steady Ground' state corresponds to the equivalent LED Red state, except for the Sat Link #1 and #2 Not Available discretes, for which the 'Steady Ground' state corresponds to the equivalent LED Off or Amber states.
2. The System Failed discrete 'Steady Ground' state corresponds to one or more LEDs being illuminated red.
3. SDU Failed discrete only to be asserted in the event that an SDU H/W or S/w failure is detected, not in the event that there is an ORT or configuration straps parity failure. In the latter case, only the System Failed discrete should be asserted.
4. SCM Failed discrete only to be asserted in the event that an SCM H/W failure is detected, not in the event that there is an ORT failure. In the latter case, only the System Failed discrete should be asserted.
5. The Bus Failed discrete provides no indication of activity on the Ethernet buses.

## **E. Service Availability Discrete Lamps**

The Service Availability Discretes have open circuit and ground states that are capable of driving incandescent lamps connected to an external supply.

Typically, each discrete is fed via one or two (in parallel) incandescent lamps to an aircraft 28 Vdc supply. This 28 Vdc supply can be dimmed to approximately 14 Vdc for night time operation. The 28 Vdc is a nominal value and can vary as defined in RTCA/DO-160E A typical incandescent lamp would be 28Vdc, 20mA.

Each Service Availability Discrete is able to continuously sink at least 50mA and be capable of holding a cold inrush current of up to 490mA during the first 10 millisecond of activation as per ARINC 781.

## **F. CFDS/ARINC 604 BITE**

The SDU reports BITE status and faults to the CFDS using ARINC 429, 350 series words.

The SDU software can raise a fault, a fault may or may not indict a particular Resource, many detailed faults may indict a single resource.

Resources also have a hierarchy defined, so a tier 1 resource may ripple up to a tier 2 resource, and so on. Faults typically indict a tier 1 resource. An example of tier 1

# THALES

## Installation Maintenance Manual

SDU 82155 Series

SCM 82158 Series

resource might be ethernet Port1 (there are 4 in total), there also may be a tier 2 resource that represents the state of all tier 1 ethernet ports.

The status of the ARINC 429, 350 series of labels are driven by the resources. If a particular resource is indicated, then it may have a consequential impact on one or more Bits in the 350 words.

Refer to ARINC 781 Attachment 2B for a definition of all the 350 words and the definition of each Bit within the words.



## SECTION 6

### MAINTENANCE PRACTICES

#### 6.1. GENERAL

This section provides instructions for the removing, reinstalling and adjusting of the SDU and SCM that has been previously installed by the aircraft manufacturer or completion center.

**CAUTION:** TO AVOID INJURY TO PERSONNEL OR DAMAGE TO EQUIPMENT, ENSURE ADEQUATE PRECAUTIONS ARE TAKEN WHILE PERFORMING ANY WORK IF THE ELECTRICAL POWER IS APPLIED TO THE LRU.

**CAUTION:** TO PREVENT DAMAGE TO EQUIPMENT, TURN AIRCRAFT POWER OFF BEFORE REMOVING OR INSTALLING LRU.

Field lubrication or other maintenance procedures are not required. The design of the SDU and SCM is such that they do not require field maintenance to maintain airworthiness. If functional problems occur, the SDU Built-in Test Equipment (BITE) capability identifies the faulty LRU. The SDU and SCM maintenance is limited to replacement on verified failure.

#### 6.2. EQUIPMENT AND MATERIALS


**CAUTION:** BEFORE YOU USE A MATERIAL, REFER TO THE MANUFACTURERS, MATERIAL SAFETY DATA SHEETS FOR SAFETY INFORMATION. SOME MATERIALS CAN BE DANGEROUS.

## 6.3. PROCEDURE FOR THE SDU

**CAUTION:** THE SDU IS ELECTROSTATIC DISCHARGE SENSITIVE EQUIPMENT. OBSERVE STANDARD ESD PROCEDURES WHEN HANDLING THE EQUIPMENT.

### A. Removal and Installation Procedure

- (1) Remove the SDU
  - a. Ensure that electrical supply to the SDU is switched off.
  - b. Loosen mounting tray Hold Down Clamps (counter clockwise). Ensure that the Hold Down Clamps are loosened so that the SDU is uniformly extracted out of the mounting tray back connector. Clear the retaining hooks on the front of the SDU.
  - c. Separate the SDU from the mounting tray back connector and extract the SDU by pulling on the carrying handle at the front of the SDU.
  - d. Visually check the SDU ARINC 600 connector and then install an ESD protection cap on the SDU ARINC 600 back connector.




Tav\_e\_0000722\_00

Figure 6.1 SDU Removal from ARINC 600 Mounting Tray

**Installation Maintenance Manual**  
SDU 82155 Series  
SCM 82158 Series

- (2) Install the SDU
  - a. Remove ESD protective cap from the SDU ARINC 600 back connector.
  - b. Carefully place the SDU on its mounting tray and slide it towards the mounting tray back connector.
  - c. When the SDU is fully engaged into the connector raise the mounting tray Hold Down Clamps over the hooks of the SDU and hand tight in the clockwise direction.
  - d. As the LRU is tightened into position, and in order to prevent electrical pins from bending, ensure that the SDU is uniformly inserted into the mounting tray back connector.

**CAUTION:** ENSURE THAT THE THUMBSCREW HOLD DOWN CLAMPS ARE FASTENED, AND THAT THE LRU IS SECURELY HELD IN PLACE.



Tav\_e\_0000721\_00

Figure 6.2 SDU Installation on to ARINC 600 Mounting Tray

## **B. Adjustment Procedure**

Not Applicable.

## **C. Repair Procedure**

Not Applicable.

## **D. Return to Service Procedures**


Do the Post-Installation Test Procedures referenced in the Inspection and System Checkout Section of this manual.

## 6.4. PROCEDURE FOR THE SCM

**CAUTION:** THE SCM IS ELECTROSTATIC DISCHARGE SENSITIVE EQUIPMENT. OBSERVE STANDARD ESD PROCEDURES WHEN HANDLING THE EQUIPMENT.

### A. Removal and Installation Procedure

- (1) Remove the SCM
  - a. Ensure that electrical supply to the SCM is switched off (switch off the SDU).
  - b. Loosen the two (2) screw locks that secure the 15-pin D Type connector to the SCM.
  - c. Disconnect the D connector. Bag and stow the cable as required.
  - d. Install an ESD protection cap on the SCM D Type connector.
  - e. Assuming that the mounting fixture is equipped with anchor nuts, loosen and remove the four fixings screws that retain the SCM to its mounting fixture while supporting the SCM. Retain the screws for future installation.
  - f. Remove the SCM, and visually inspect it for any signs of damage



Tav\_e\_0000719\_00

Figure 6.3 SCM Removal

- (2) Install the SCM
  - a. Remove the ESD protection cap on the D Type connector.

## Installation Maintenance Manual


SDU 82155 Series

SCM 82158 Series

- b. Place the SCM to the dedicated mounting fixture and insert the four fixing screws to finger tightness only. After all four fixing screw have been inserted tight the screws with an appropriate tool

**CAUTION:** ENSURE THAT THE FIXING SCREWS HAVE BEEN FASTENED, AND THAT THE LRU IS SECURELY HELD IN POSITION.

- c. Insert the cable from the SDU to the D Type connector (other half from the SDU) and tighten the aircraft mating connector into the two female screw locks.



Tav\_e\_0000720\_00

Figure 6.4 SCM Installation

### B. Adjustment Procedure

Not Applicable.

### C. Repair Procedure

Not Applicable.

### D. Return to Service Procedures

Do the Post-Installation Test Procedures referenced in the Inspection and System Checkout Section of this manual.

## 6.5. CLEANING OF MECHANICAL PARTS

**CAUTION:** MOISTURE AND DIRT CAN CAUSE DAMAGE TO EQUIPMENT

Equipment chassis covers give the necessary protection to keep dust away from electronic circuits. If cleaning is required this has to be limited to the removal of particles

## Installation Maintenance Manual SDU 82155 Series SCM 82158 Series

of dust, oil, grease, condensation, etc and only limited for those equipment accessible parts. Before any cleaning action is carried out ensure that the equipment is disconnected from all electrical power sources, and all the necessary ESD precautions are observed.

- a. For dust removal use a cleaning wipe, a silk paintbrush or low-pressure compressed air
- b. For removal of finger marks, grease, etc, clean the parts with a cleaning wipe and isopropyl alcohol, exercising care to not damage information labels.

### 6.6. PERIODIC CHECKS

See Inspection/ Check procedure in Section 4.1.

### 6.7. CABLING AND CONNECTIONS

Periodically check cable connectors (recommended) and if required, remove connector, inspect and re-connect connector to required torque values as specified by the cable manufacture.

### 6.8. INSTRUCTIONS FOR CONTINUED AIRWORTHINESS

Maintenance requirements and instructions for continued airworthiness of the TFS SDU and SCM components are contained in the paragraphs that follow.

Installation of SDU and SCM on an aircraft by an amendment to the Type Certificate (TC), Supplemental Type Certificate (STC) or Form 337 obligates the aircraft operator to include the maintenance information supplied by this manual (and listed below) in the operator, Aircraft Maintenance Manual and the operator, Aircraft Scheduled Maintenance Program.

- a. Maintenance information for SDU and SCM, TFS LRU (system description, removal, installation, testing, etc.).
- b. The part numbers (see section 2) of the LRU being installed (SDU and SCM) should be placed into the aircraft operator, appropriate aircraft Illustrated Parts Catalogue (IPC).
- c. Wiring connection information contained in this manual (see sections 2 and 3) should be placed into the aircraft operator, appropriate Wiring Diagram Manual.
- d. The SDU maintenance is considered as an , “On-condition”, and as such no additional maintenance is required other than a check for security and operation at normal inspection intervals.

## Installation Maintenance Manual

SDU 82155 Series

SCM 82158 Series

- e. The SCM equipment is subject to minimal preventative maintenance, which is specific to life limitations associated to the internal USIM cards. For further details refer to your Thales representative.
- f. If a system LRU is inoperative remove the specific unit, secure cables and wiring, collar applicable switches and circuit breakers, and placard them inoperative. Revise equipment list and weight and balance as applicable prior to flight and make a log book entry that the unit was removed (refer to section 91.213 of the FAR or the aircraft, Minimum Equipment List (MEL)).
- g. SDU and SCM can be repaired by an Approved Maintenance Organization or an appropriately rated FAA Part 145 repair station.
- h. Once repaired, reinstall the LRU in the aircraft in accordance with the original Form 337 approved data or instructions in this manual. Perform a Return to Service test of the system and approve it for return to service with a logbook entry required by section 43.9.
- i. Once repaired, install the LRU in the aircraft in accordance with the original Form 337 approved data or instructions in this manual. Do a Return to Service test of the system and approve it for return to service with a log book entry in accordance with the requirements specified in FAR Part 43.9.



**Installation Maintenance Manual**  
SDU 82155 Series  
SCM 82158 Series

**THIS PAGE INTENTIONALLY BLANK**



## SECTION 7

### COMMISSIONING

#### 7.1. GENERAL

The purpose of the following tests is to confirm functionality of the services supported by the SDU and associated equipment, both to confirm the installation has been successful and to demonstrate that the functionality is present to the customer.

All but one of these tests (the SMS and GSM Test, I.) can be performed on the ground. Regulatory issues require that the GSM Pico cell not be operated below 10 000 feet, so this test should be carried out on the next available test flight.

Not all tests are run for all installations - which tests should be run depends on the capabilities fitted to the aircraft, as per the following table:

Table 7.1 Commissioning Tests Applicability

Capability	A	B	C	D	E	F	G	H	I
<b>Baseline SDU+SCM</b>	Yes	No	No	No	No	No	No	No	No
<b>+ Cockpit audio/avionics</b>	Yes	Yes	Yes	No	No	No	No	No	No
<b>+ Wifi AP or wired Ethernet</b>	Yes	No	No	Yes	Yes	Yes	No	No	No
<b>Cabin ISDN</b>	Yes	No	No	No	No	No	Yes	Yes	No
<b>+ GSM Pico cell</b>	Yes	No	No	No	No	No	No	No	Yes

#### A. Registration

- a. Power on the AGS (when fitted).
- b. Power on the TFS System and wait until the LEDs reach the following state (Refer to Table 7.2):

**Installation Maintenance Manual**  
SDU 82155 Series  
SCM 82158 Series

Table 7.2 SDU LEDs

LED	SDU - 82155A	SDU - 82155D
SDU	GREEN	GREEN
SCM	GREEN	GREEN
Antenna	GREEN	GREEN
DLNA	GREEN	GREEN
FMHPA	OFF(see Note)	OFF(see Note)
Ext. BSU	OFF	OFF
Ext. Data Bus	GREEN	GREEN
ORT/Config.	GREEN	GREEN
Sat. Link #1	GREEN	GREEN
Sat. Link #2	OFF	OFF

**NOTE:** Unless an FMHPA is installed, in which case should be GREEN.

- c. Connect a laptop to the Test port on the SDU.

Either:

- d. If an MCDU is present:
  - i Enter the Satcom main menu.
  - ii Both Sat-1 (and Sat-2 if Dual Channel) should be “READY”.
  - iii Press Page Down.
  - iv Select “CHANNEL STATUS”
  - v Sat Modem1 should be in “SWIFT BB” with status “LOGGED ON”

Or:

- e. If the cabin control panel is fitted:
  - vi If the “Service is available” LED is lit then the Satcom system is registered.

## B. Classic Packet Data Verification

If Cockpit functionality is fitted:

- a. Using any MCDU:
  - i Press the “Menu” key to display the menu page.
  - ii Select “ACARS”.
  - iii Via the “MAINTENANCE”, “COMM CONTROL” or equivalent ACARS page, verify that Satcom is “AVAILABLE”.
  - iv Send and receive several “FREE TEXT” ACARS messages.
  - v Verify correct receipt of all messages.

## C. Classic Cockpit Voice Calls

If Cockpit functionality is fitted:

- a. Using any MCDU:
  - i Enter the Satcom main menu.
  - ii Both Sat-1 (and Sat-2 if Dual Channel) should be “READY” .
  - iii Using the correct procedure based on the ORT options selected, place and receive Cockpit Voice calls using each of the available channels from the Audio Control Panels.
  - iv In each case, verify correct operation.

## D. SBB Cabin Wifi Data Connectivity (Background Context)

If either a Wifi access point or a wired Ethernet to the cabin is fitted:

- a. Start up a laptop (with Wifi capability if Wifi is to be used).
- b. Connect to the access point or wired Ethernet.
- c. Open a browser window and follow the instructions to gain default background access (if any).
- d. Open a command window (Start, Run, “cmd”).
  - i Type “ping www.google.com -n 10 -w 10000”.
  - ii 10 replies should be received.
  - iii Type “ping www.google.com -l 1400 -n 10 -w 10000”.
  - iv 10 replies should be received.

**Installation Maintenance Manual**  
SDU 82155 Series  
SCM 82158 Series

- e. Go to Google homepage and search for a random string to check HTML connectivity.
- f. Start an FTP client:
  - i. Connect to the Inmarsat FTP server.
  - ii. Change directory to a test directoryt.
  - iii. “Put” a file onto a server. The transfer should complete successfully.
  - iv. “Get” a file from the server. The transfer should complete successfully.
  - v. Disconnect the FTP client.
- g. Disconnect from the access point or wired Ethernet.

## **E. SBB Cabin Wifi Data Connectivity (Streaming Context)**

If either a Wifi access point or wired Ethernet to the cabin is fitted:

- a. Start up a laptop (with Wifi capability if Wifi is to be used).
- b. Connect to the access point or wired Ethernet.
- c. Open a browser window and follow the instructions to gain access to a guaranteed streaming connection -32k.
- d. Set the Traffic Flow Template by associating the streaming connection with the FTP client.
- e. Open the billing/connection monitoring section of the local site, or open the properties for each network connection.
- f. Open a command window (Start, Run, “cmd”).
  - i. Type “ping www.google.com -n 10 -w 10000”.
  - ii. 10 replies should be received.
  - iii. Check that the traffic generated by this command went via the Background context and not the Streaming connection.
- g. Go to Google homepage and search for a random string to check HTML connectivity.
- h. Start an FTP client:
  - i. Connect to the Inmarsat FTP server.
  - ii. Change directory to a test directoryt.

## Installation Maintenance Manual

SDU 82155 Series

SCM 82158 Series

- iii “Put” a file onto a server. The transfer should complete successfully.
- iv The traffic should have gone via the streaming context and the data rate should have been comparable to the guaranteed rate.
- v “Get” a file from the server. The transfer should complete successfully.
- vi The traffic should have gone via the streaming context and the data rate should have been comparable to the guaranteed rate.
- vii Disconnect the FTP client.
  - i. Disconnect the streaming connection.
  - j. Disconnect from the access point or wired Ethernet.

### F. Cabin VoIP service

If either a Wifi access point or wired Ethernet to the cabin is fitted:

- a. Ensure that the SDU is powered on and connected.
- b. Connect a laptop with headset or VoIP phone to the Cabin Wireless Access Point.
- c. Open a browser window and follow the instructions to gain default background access (if any):
  - i Make a phone call to a PSTN number and have a short conversation. audio quality should be good.
  - ii Arrange a call back and hang up. When the phone rings, answer and have a short conversation. Audio quality should be good.

### G. Cabin ISDN Data service

If ISDN to the cabin is fitted:

- a. Connect an ISDN modem to the laptop.
- b. Connect an ISDN modem to the ISDN port.
- c. Dial a suitable ISDN number for a data connection to the internet:
  - i The modem should be able to receive the “on hook” status and dial a number.
  - ii Arrange a call back and hang up. When the phone rings, answer and have a short conversation. Audio quality should be good.
  - iii The connection should be set up over Satcom to the number dialed.

## Installation Maintenance Manual SDU 82155 Series SCM 82158 Series

- iv Type “ping www.google.com -n 10 -w 10000”.
- v 10 replies should be received.
- vi Type “ping www.google.com -l 1400 -n 10 -w 10000”.
- vii 10 replies should be received.
- d. Go to the Google homepage and search for a random string to check HTML connectivity.
- e. Start an FTP client:
  - i Connect to the Inmarsat FTP server.
  - ii Change directory to a test directory.
  - iii “Put” a file onto a server. The transfer should complete successfully.
  - iv The data rate should have been comparable to the expected 64kbit rate.
  - v “Get” a file from the server. The transfer should complete successfully.
  - vi The data rate should have been comparable to the expected 64kbit rate.
  - vii Disconnect the FTP client.
- f. Disconnect the ISDN connection.

### H. Cabin ISDN Voice service

If ISDN to the cabin is fitted:

- a. Connect an ISDN phone to the ISDN port.
- b. Dial a suitable ISDN number for an ISDN voice connection:
  - i The modem should be able to receive the “on hook” status and dial a number.
  - ii The connection should be set up over Satcom to the number dialed.
  - iii Have a short conversation. The voice quality should be good.
  - iv Request a call back and hang up.
  - v The ISDN modem should be able to accept an ISDN ground to air voice call.
  - vi Have a short conversation. The voice quality should be good.

vii Hang up.

## **I. Cabin GSM Call and SMS Service**

If a GSM Pico cell is fitted:

- a. Ensure that the AGS is powered on and the call disable is off.
- b. Ensure that the SDU is powered on and connected.
- c. Switch on a GSM mobile phone.
  - i The phone should register to the Pico cell, with the configured network name.
  - ii Make a phone call to a PSTN number and have a short conversation. Audio quality should be good.
  - iii Arrange a call back and hang up. when the phone rings, answer and have a short conversation. Audio quality should be good.
  - iv Send an SMS message to a remote GSM phone, asking for a reply. The text message should reach recipient.
  - v The SMS reply should be received.
  - vi Switch on the call disable.
  - vii Attempt to place a call from the GSM phone. The call should be blocked.
  - viii Send an SMS message asking for a call back and a reply.
  - ix The external call should be blocked and the SMS message should still be received.
- d. Power off the GSM phone and disable the Pico cell.



**Installation Maintenance Manual**  
SDU 82155 Series  
SCM 82158 Series

**THIS PAGE INTENTIONALLY BLANK**