

DEREGISTRATION
1YES 2NO

6. Use the touch-tone pad to enter 1YES, or use the CALLER ID/VOL (- or +) button to scroll to 1YES.
7. Press MUTE/PROG and *MOVE NEAR TO BASE* displays until you move the handset closer to the base.

MOVE NEAR TO
BASE

Then the handset displays *CONFIRM? 1YES 2NO*.

CONFIRM
1YES 2NO

8. Use the touch-tone pad to enter 1YES or use CALLER ID/VOL (- or +) button to scroll to 1YES.

NOTE: Press the *EXIT button once to keep the previous setting and return to the main menu screen.

9. Press the MUTE/PROG button to confirm the deregistration. *DE-REGISTER...* displays for 30 seconds, then *HANDSET # DE-REGISTERED* displays for one second followed by *HANDSET NEEDS REGISTRATION*

HANDSET NEEDS
REGISTRATION

GLOBAL DE-REGISTRATION

If one or more handsets becomes lost, you should de-register all handsets to ensure proper system operation. Follow the steps below to deregister both handsets at the same time.

1. Press and hold the PAGE button on the base of GE 25831, 25833, or 25835 until the CHARGE/IN USE indicator on the base flashes.
2. Press and hold the PAGE button on the base of GE 25831, 25833, or 25835 again until the CHARGE/IN USE indicator on the base flashes rapidly.
3. Press and release the PAGE button on the base of GE 25831, 25833, or 25835 once. All handsets are deregistered and *HANDSET NEEDS REGISTRATION* shows in the display.

IMPORTANT : It is strongly recommended that a handset not be de-registered unless absolutely necessary.

DEFAULT

As you become familiar with this system, you may prefer to use the system's original settings. Follow the steps below to return to the factory default settings.

1. Make sure your phone is **OFF** (not in talk mode).
2. Press the MUTE/PROG button to display main menus: *ROOM MONITOR and HANDSET SETUP*.
3. Use CALLER ID/VOL - button to locate to *HANDSET SETUP* and then press MUTE/PROG button to select.
4. Use CALLER ID/VOL - / + button to locate the *DEFAULT SETTING* and then press MUTE/PROG button to select.
5. Then the handset shows *DEFAULT SETTING 1YES 2NO* in display.
6. Use the touch-tone pad on your handset to enter 1YES or 2NO, or use the CALLER ID/VOL - / + button on your handset to scroll to 1YES or 2NO. "2NO" is the default setting.

DEFAULT SETTING
1YES 2NO

NOTE: If you choose "YES" all settings in the programmable menu return to the factory default settings.

NOTE: Press the *EXIT button once to keep the previous setting and return to the main menu.

7. Press the MUTE/PROG button to save your selection, and return to the main menu. The default setting you choose shows on the display for two seconds, and you will hear a confirmation tone.

DEFAULT SETTING
YES

PAGING ALL HANDSETS FROM A HANDSET

1. Make sure the originating phone is **OFF** (not in talk mode).
2. Press and release the INT button on a handset. *PAGING EXTENSION?* shows in the display.
3. Use the touch-tone pad to enter the handset number you want to page. (1=to page Handset 1, 2=to page handset 2, 3=to page handset 3, 4=to page handset 4, and 5=to page all handsets)
4. To cancel the page on the originating handset, press the *EXIT, INT, or TALK/CALLBACK button.

REPLACING THE BATTERY



CAUTION: to reduce the risk of fire or personal injury, use only the 5-2660 replacement battery listed on the accessory order form, which is compatible with this unit.

CAUTION: To ensure the phone/battery performance, use ONLY 25832 charging cradle, and 25831, 25833, or 25835 base for battery charging only.

1. Make sure the telephone is OFF before you replace battery.
2. Remove the battery compartment door.
3. Disconnect the cord attached to the battery pack from the jack inside the battery compartment and remove the battery pack from the handset.
4. Insert the new battery pack and reconnect the battery plug.
5. Put the battery compartment door back on.
6. Place handset in the base to charge. If you don't charge the handset battery properly (for 16 hours) when you first set up the phone and/or when you install a new battery pack, the battery's long-term performance will be compromised.

NOTE: If the battery is not properly installed in the handset, or if the battery pack is not properly connected to the jack inside the battery compartment. "NO BATTERY" shows in the display when the handset is placed in the charging cradle.

BATTERY SAFETY PRECAUTIONS

- Do not burn, disassemble, mutilate, or puncture. Like other batteries of this type, toxic materials could be released which can cause injury.
- Keep batteries out of the reach of children.
- Remove batteries if storing over 30 days.



NOTE: The RBRC seal on the battery used in your ATLINKS USA, Inc. product indicates that we are participating in a program to collect and recycle Nickel Cadmium batteries throughout the United States. Please call 1-800-8-BATTERY for information or contact your local recycling center.

HEADSET AND BELT CLIP INSTALLATION

CONNECTING AN OPTIONAL HEADSET TO THE HANDSET



For hands free conversation.

1. Insert the headset plug into the headset jack.
2. Adjust the headset to rest comfortably on the ear.
3. Move the microphone to approximately 2 to 3 inches from your mouth.
4. Press the TALK/CALLBACK button to answer or place a call while using the headset.

CONNECTING THE BELT CLIP

There are two slots, one on each side of the handset.

Attach the belt clip by inserting the sides of the belt clip into the slots. Snap the ends of the belt clip into place.



GENERAL PRODUCT CARE

To keep your unit working and looking good, follow these guidelines:

- Avoid putting the phone near heating appliances and devices that generate electrical noise (for example, motors or fluorescent lamps).
- DO NOT expose to direct sunlight or moisture.
- Avoid dropping the handset, as well as other rough treatment to the phone.
- Clean the phone with a soft cloth.
- Never use a strong cleaning agent or abrasive powder because this will damage the finish.
- Retain the original packaging in case you need to ship the phone at a later date.
- Periodically clean the charge contacts on the handset and base with a clean pencil eraser.

CAUSES OF POOR RECEPTION

- Aluminum siding.
- Foil backing on insulation.
- Heating ducts and other metal construction that can shield radio signals.
- You're too close to appliances such as microwaves, stoves, computers, etc.
- Atmospheric conditions, such as strong storms.
- Base is installed in the basement or lower floor of the house.
- Base is plugged into AC outlet with other electronic devices.
- Baby monitor is using the same frequency.
- Handset battery is low.
- You're out of range of the base.

SERVICE

If trouble is experienced with this equipment, for repair or warranty information, please contact customer service at **1-800-448-0329**. If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved.

This product may be serviced only by the manufacturer or its authorized service agents. Changes or modifications not expressly approved by ATLINKS USA, Inc. could void the user's authority to operate this product. For instructions on how to obtain service, refer to the warranty included in this guide or call customer service at **1-800-448-0329**.

Or refer inquiries to:

ATLINKS USA, Inc.
 Manager, Consumer Relations
 P O Box 1976
 Indianapolis, IN 46206

Attach your sales receipt to the booklet for future reference or jot down the date this product was purchased or received as a gift. This information will be valuable if service should be required during the warranty period.

Purchase date _____

Name of store _____