

1. Make sure the phone is **ON** (in talk mode) by pressing the TALK/CALL BACK or SPEAKER button.
2. Press the MEMORY button, and then press 07.
3. When you hear the access tone, press the MEMORY button, and then press 08.
4. At the next access tone, press the MEMORY button and then 09.

## BELT CLIP AND OPTIONAL HEADSET

### Connecting the Belt Clip

1. To attach the belt clip, insert the sides of the belt clip into the slots on each side of the handset.
2. Snap the ends of the belt clip into place.

### Connecting an Optional Headset to the Handset

Each handset can be used with an optional headset hands free operation.

1. Connect the headset to the headset jack on the side of the handset. The handset receiver and microphone are disabled when the headset is connected.
2. Adjust the headset to rest comfortably on top of your head and over your ear. Move the microphone to approximately two to three inches from your mouth.
3. Press the TALK/CALL BACK button to answer a call or make calls using the headset.
4. To return to normal operation, unplug the headset from the jack.

## CHANGING THE BATTERY

**CAUTION: To reduce the risk of fire or personal injury, use only the ATLINKS USA, Inc. Nickel-metal Hydride battery model 5-2660, which is compatible with this unit.**

1. Make sure the telephone is **OFF** (not in TALK mode) before you replace battery.
2. Remove the battery compartment door.
3. Disconnect the cord attached to the battery pack and remove the battery pack from the handset.
4. Insert the new battery pack and connect the cord to the jack inside the battery compartment.
5. Put the battery compartment door back on.
6. Place handset in the base or handset charge cradle to charge. **Allow the handset battery to properly charge (for 16 hours) prior to first use or when you install a new battery pack. If you do not properly charge the phone, battery performance will be compromised.**

## Battery Safety Precautions

- Do not burn, disassemble, mutilate, or puncture. Like other batteries of this type, toxic materials could be released which can cause injury.
- To reduce the risk of fire or personal injury, use only the **Nickel-metal Hydride** battery listed in the User's Guide.
- Keep batteries out of the reach of children.
- Remove batteries if storing over 30 days.

## Display Messages

The following messages shows the status of the phone, provides Caller ID information, or helps you set up and use your phone.

<b>BLOCKED NUMBER</b>	Indicates the person is calling from a number which is blocked from transmission.
<b>CHARGING...</b>	Indicates the handset needs to charge for a period of time before it can resume normal function.
<b>DELETE ALL?</b>	Prompt asking if you want to erase all CID records.
<b>DELETE CALL ID?</b>	Prompt asking if you want to erase the CID record showing on the display.
<b>DELETE?</b>	Prompt asking if you want to erase one of the 50 records stored in the phone's memory.
<b>DUPLICATE NUMBER</b>	Under VIP melody feature, if the desired number/record was selected in any one of TEN VIP melody records before, <i>DUPLICATE NUMBER</i> shows in the display.
<b>END OF LIST</b>	Indicates that there is no additional information in CID memory.
<b>ENTER NAME</b>	Prompt telling you to enter a name in one of the 50 memory locations.
<b>ENTER TEL NUMBR</b>	Prompt telling you to enter a telephone number in one of the 50 memory locations.
<b>NEW</b>	Indicates call or calls which have not been reviewed.
<b>HANDSET NAME</b>	Prompt telling you to enter the user name for the registered handset.

### HANDSET NEEDS REGISTRATION

Indicates you must register a non-registered handset prior to use.

### INCOMPLETE DATA

Caller information is interrupted during transmission or the phone line is excessively noisy.

### LINE IN USE

Displays on handset while the line is in use.

### LONG DISTANCE

Indicates CID record is from a long distance call.

### LOW BATTERY

Indicates the battery needs to be charged.

### MESSAGE WAITING

Indicates voice mail has not been retrieved from service provider.

### MSG WAITING OFF

Indicates voice mail has been retrieved from service provider.

### NEW CALL XX

XX represents the number of new CID records not reviewed.

### NO BATTERY

Indicates the battery is not properly installed in the handset, or the battery pack is not properly connected to the jack inside the battery compartment.

### NO CALLS

Indicates there are no CID records in memory.

### NO DATA

Indicates no CID information was received, you are not subscribed to CID service, or CID service is not working.

### NO USER MEMORY

Indicates the memory location contains no user memories and the user is trying to mark a specific user record for VIP MELODY.

### OUT OF RANGE

Indicates handset is too far away from the base. Move closer to the base.

### PAGING or PAGING FROM

Someone pressed the PAGE button on the base or INTERCOM button on the handset

### REPT

Indicates a repeat call message. Indicates a new call from the same number was received more than once.

### SEARCHING

Indicates handset is searching for the base.

### SPKR

Indicates the handset is in speakerphone mode.

### UNKNOWN CALLER/ NAME/NUMBER

Indicates incoming call is from an area not serviced by CID or the CID information was not sent.

## Handset Sound Signals

<i>Signal</i>	<i>Meaning</i>
A long warbling tone (with ringer on)	Signals an incoming call
Three short beeps (several times)	Page signal
One beep every 7 seconds	Low battery warning

## Troubleshooting Guide

### Telephone Solutions

No dial tone

- Check or repeat installation steps:
  - Make sure the base power cord is connected to a working electrical outlet.
  - Make sure the telephone line cord is connected to the base and the wall jack.
- Connect another phone to the same jack. If it doesn't work, the problem might be your wiring or local service.
- The handset may be out of range of the base. Move closer to the base.
- Make sure the battery is properly charged (for 16 hours).
- Make sure the battery pack (in the handset) is properly installed.
- The handset should beep when you press the TALK/CALL BACK button, and the charge indicator on the base should be lit when the handset rests in the cradle. If not, the battery may need to be charged.
- Place handset in charge cradle for at least 20 seconds to reset the unit.

Handset does not ring

- Make sure the handset ringer software switch is set to on.
- The handset may be out of range of the base. Move closer to the base.
- You may have too many extension phones on your line. Try unplugging some extensions.
- Check for a dial tone.

You experience static, noise, or fading in and out

- The handset may be out of range of the base. Move closer to base.
- Make sure base is not plugged into an electrical outlet with another household appliance. If necessary, relocate the base.
- Charge the battery (for 16 hours).

Unit beeps

- Clean the charging contacts on the cordless handset and base charge cradle with a soft cloth or an eraser.
- See solutions for "No dial tone" on previous page.
- Replace the battery.