

EXHIBIT A
[FCC Ref. 2.1033(b)(3)]

"Installation and Operating Instructions
Furnished to the User"

Exhibit A(1) - User's Guide

STORING A NUMBER IN MEMORY

- Make sure the phone is **OFF** (not in talk mode).
- Press the desired memory location (0 through 9).
- Press the desired memory location. The display shows **ENTER NUMBER**.
- Press the memory button again. The display shows **ENTER NUMBER**.
- Use the touchtone pad to enter the telephone number you want to store in memory. Press **SEND**.
- Press the memory button again to store the number.

CHANGING A STORED NUMBER

Use the touchtone pad to change a stored number as you do to store a number. To change a stored number, press the memory button, then the number you want to replace. The display shows **REPLACE MEMORY**. Press the memory button again to replace the number.

DIALING A STORED NUMBER

- Make sure the phone is **ON** by pressing the **TALK** button.
- Press the memory button.
- Press the number (0-9) for the desired memory location. The number dials automatically.

OR -

- Make sure the phone is **OFF** (not in talk mode).
- Press the memory button.
- Press the number (0-9) for the desired memory location. The number dials automatically.

INSERTING A PAUSE IN THE DIALING SEQUENCE

Pause in dialing sequence. Press the **PAUSE** button to insert a delay in the dialing sequence. Press the **PAUSE** button again to resume dialing. A pause is required to wait for a dial tone. For example, after you dial 9 for an outside line, or to wait for a computer modem to dial, you can insert a pause by pressing the **PAUSE** button. Press **SEND** to complete the dialing sequence.

REVIEWING AND DELETING STORED NUMBERS

- Press the memory button (0-9) to review the number stored in memory.
- Press the memory button (0-9) to delete the number stored in memory.
- Press the memory button (0-9) to delete the number stored in memory.

CHANGING DIALING FROM MEMORY

Use the touchtone pad to change a stored number as you do to store a number. To change a stored number, press the memory button, then the number you want to replace. The display shows **REPLACE MEMORY**. Press the memory button again to replace the number.

STORING A NUMBER IN MEMORY

- Make sure the phone is **OFF** (not in talk mode).
- Press the desired memory location (0 through 9).
- Press the desired memory location. The display shows **ENTER NUMBER**.
- Press the memory button again. The display shows **ENTER NUMBER**.
- Use the touchtone pad to enter the telephone number you want to store in memory. Press **SEND**.
- Press the memory button again to store the number.

CHANGING A STORED NUMBER

Use the touchtone pad to change a stored number as you do to store a number. To change a stored number, press the memory button, then the number you want to replace. The display shows **REPLACE MEMORY**. Press the memory button again to replace the number.

DIALING A STORED NUMBER

- Make sure the phone is **ON** by pressing the **TALK** button.
- Press the memory button.
- Press the number (0-9) for the desired memory location. The number dials automatically.

OR -

- Make sure the phone is **OFF** (not in talk mode).
- Press the memory button.
- Press the number (0-9) for the desired memory location. The number dials automatically.

INSERTING A PAUSE IN THE DIALING SEQUENCE

Pause in dialing sequence. Press the **PAUSE** button to insert a delay in the dialing sequence. Press the **PAUSE** button again to resume dialing. A pause is required to wait for a dial tone. For example, after you dial 9 for an outside line, or to wait for a computer modem to dial, you can insert a pause by pressing the **PAUSE** button. Press **SEND** to complete the dialing sequence.

REVIEWING AND DELETING STORED NUMBERS

- Press the memory button (0-9) to review the number stored in memory.
- Press the memory button (0-9) to delete the number stored in memory.
- Press the memory button (0-9) to delete the number stored in memory.

CHANGING DIALING FROM MEMORY

Use the touchtone pad to change a stored number as you do to store a number. To change a stored number, press the memory button, then the number you want to replace. The display shows **REPLACE MEMORY**. Press the memory button again to replace the number.

CLOCK RADIO OPERATION

Use the **FM/AM** switch to adjust the brightness of the display.

AM ANTENNA

A built-in antenna is used for AM reception. Rotating the antenna will improve reception for distant AM stations.

FM ANTENNA

The AC power cord acts as the FM antenna. For best reception, hold the power cord straight out. Do not coil the power cord around the phone. Do not coil the power cord around the phone.

POWER

Press the **RADIO ON/OFF** button to turn the radio on or off.

SETTING THE BROADCAST BAND

Use the **FM/AM** switch to select the listening level. Use the **VOLUME** or **LOUDNESS** buttons to adjust the listening level. Use the **VOLUME** or **LOUDNESS** buttons to adjust the listening level.

CHANGING STATIONS

Press the **PRESET** button to store a station. Press the **PRESET** button to store a station. Press the **PRESET** button to store a station.

DIGITAL CLOCK

The base has a digital real time clock, which displays hour and minute information. This is not affected by incoming calls. ID information.

SETTING THE TIME

- Turn off the radio. The default time is 12:00am.
- Set the **LOCK/WAKE** time switch to time position.
- Press the **WAKE/STOP** or **WAKE/STOP** buttons to set the minute. If you find either button down for more than two seconds, the time will be set to 12:00am.
- Press the **WAKE/STOP** or **WAKE/STOP** buttons to set the hour. If you find either button down for more than two seconds, the time will be set to 12:00am.

SETTING THE WAKE TIME

- While the radio is **OFF**, set the **LOCK/WAKE** time switch to the **WAKE** position.
- Press **WAKE/STOP** or **WAKE/STOP** buttons to adjust the wake time. If you find either button down for more than two seconds the time will be set to 12:00am.
- Press the **WAKE/STOP** or **WAKE/STOP** buttons to set the hour. If you find either button down for more than two seconds, the time will be set to 12:00am.

SETTING THE ALARM

The **WAKE** to **Alarm** mode and **WAKE** to **Radio** mode can be activated by setting the **OFF/AM/SL/ALARM** switch. When the **OFF/AM/SL/ALARM** switch is set to the **OFF** position, the wake function is disabled.

SNOOZE MODE

If you press the **SNOOZE** button when the alarm sounds, the alarm is silenced for approximately nine minutes. Do you press the **SNOOZE** button, the radio will stop. Press the **SNOOZE** button. Sleep mode will be cancelled.

SLEEP MODE

When the radio is **OFF**, press the **SLEEP** button and use the **WAKE/STOP** or **WAKE/STOP** buttons to set the sleep time. The default is 60 minutes. The maximum sleep time is 120 minutes and the minimum is 15 minutes.

ADJUSTING THE DISPLAY

Use the **FM/AM** switch to adjust the brightness of the display.

ADJUSTING THE DISPLAY

Use the **FM/AM** switch to adjust the brightness of the display.

CHANGING THE BATTERY

- Remove the battery compartment cover.
- Disconnect the cord standard to the battery pack and remove the battery pack from the handset.
- Insert the new battery pack into the handset.
- Press the **RADIO ON/OFF** button to turn the radio on or off.
- Place the handset in the base to charge.

MESSAGE WAITING

Indicates a message is waiting. Press the **MESSAGE WAITING** button to check for a message. Press the **MESSAGE WAITING** button to check for a message.

HANDSET SOUND SIGNALS

Signal Meaning
A long ringing tone Signals an incoming call (with ringer on)
One short and one long beep Page signal (several times)
One long and one short beep Low battery warning

GENERAL PRODUCT CARE

- Keep your telephone working and looking good, follow these guidelines:
 - Avoid putting the phone near heating appliances and motors or fluorescent lamps.
 - DO NOT expose to direct sunlight or moisture.
 - Avoid dripping and other rough treatment to the phone.
 - Clean with a soft cloth.

CAUSES OF POOR RECEPTION

- Aluminum siding
- Flat roofing on installation
- Heat pipes and other metal construction can shield radio signals.
- You're too close to appliances such as microwaves, stoves, computers, etc.
- Atmospheric conditions, such as strong storms.
- Base is installed in the basement or lower floor of the house.

DISPLAY MESSAGES

The following indicators show the status of a message or at the unit.
INCOMPLETE DATA Caller information not interpreted during transmission. The phone line is excessively noisy.
ENTER NAME Prompt telling you to enter the name for one of the 10 memory locations.
ENTER NUMBER Prompt telling you to enter the telephone number for one of the 10 memory locations.
Delete Call (C) /Delete? Prompt asking if you want to erase Caller ID records or one of the 10 numbers stored in the phone's outgoing memory.
DELETE ALL? Prompt asking if you want to erase all Caller ID records.
DELETED Memory records is erased.
END OF LIST Indicates that there is no additional information in Caller ID memory.
NEW Indicates call or calls have not been received.

UNKNOWN NAME/ CALLER NUMBER

The incoming call is from an area not serviced by Caller ID. The battery information was not sent.

BLOCKED CALL

Someone has pressed the page button on the base. The call is blocked from transmission.

BLOCKED NAME REPT

The caller's name or number is blocked from transmission. Repeat call message. Indicates that a battery pack and remove the battery pack from the handset.

NO DATA

No Caller ID information was received more than once.

EMPTY

Indicates a memory location is vacant.

NO CALLS

Indicates no CID records have been stored.

MESSAGE WAITING

Indicates a message is available. Press the **MESSAGE WAITING** button to check for a message.

Did the handset beep when you pressed the TALK button? Did the ID indicator come on? The battery indicator is OK, but can't dial out

- Make sure the touchtone setting is programmed correctly.
- Make sure the handset is fully charged.
- Make sure the handset is fully charged.

Handset does not ring

- Make sure the **RINGER** switch on the handset is turned on.
- Do you have too many extension phones on your line. Try unplugging some phones.
- See solutions for "No dial tone."

Change channels, noise, or fading in and out

- The handset might be out of range of the base. Move closer to the base.
- Relocate the base.
- Charge the battery.
- Make sure base is not plugged into an outlet with another household appliance.

Unit beeps

- Press handset in the base for 30 seconds to reset the security code. If that doesn't work, charge the battery for 12 hours.
- Clean the charging contacts on the handset and base.
- See solutions for "No dial tone."

Memory beeping

- Do you follow program the memory location keys correctly?
- Do you follow proper dialing sequence?
- Make sure the telephone is properly programmed.
- Power outage or battery reinsertion.

INTERFERENCE INFORMATION

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference that may be received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause interference to other electronic equipment. No guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, you can try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna (that is, the radio or television).
- Reorient or relocate and increase the separation between the telecommunications equipment and receiving antenna.
- Connect the telecommunications equipment into an outlet on a circuit different from that to which the interfering equipment is connected.

If these measures do not eliminate the interference, please contact your dealer or an experienced radio/television technician for additional suggestions. Also, the Federal Communications Commission has prepared a helpful booklet titled "Protecting Your Radio and TV from Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20540.

Make sure the battery is properly charged (12 hours).
Make sure the battery pack is installed correctly.

SERVICE

If trouble is experienced with this equipment, for repair or warranty information, please contact customer service at 1-800-339-4376. It is suggested that you have the telephone number of your nearest authorized service center handy when you call. This warranty does not cover damage caused by misuse or accident.

WARRANTY

This product may be serviced only by the manufacturer or an authorized service center. For more information, contact customer service at 1-800-339-4376. This warranty does not cover damage caused by misuse or accident.

LIMITED WARRANTY

This product is warranted against defects in materials and workmanship for a period of one year from the date of purchase. This warranty does not cover damage caused by misuse or accident.

ACCESSORY ORDER FORM

For more information, please contact customer service at 1-800-339-4376. This warranty does not cover damage caused by misuse or accident.

REPLACEMENT BATTERY

Replacement battery 5-2573 5-2586 5-2586

POWER SUPPLY

Power supply 5-2573 5-2586 5-2586

ACCESSORY ORDER FORM

For more information, please contact customer service at 1-800-339-4376. This warranty does not cover damage caused by misuse or accident.

REPLACEMENT BATTERY

Replacement battery 5-2573 5-2586 5-2586

POWER SUPPLY

Power supply 5-2573 5-2586 5-2586

ACCESSORY ORDER FORM

For more information, please contact customer service at 1-800-339-4376. This warranty does not cover damage caused by misuse or accident.

REPLACEMENT BATTERY

Replacement battery 5-2573 5-2586 5-2586

POWER SUPPLY

Power supply 5-2573 5-2586 5-2586

ACCESSORY ORDER FORM

For more information, please contact customer service at 1-800-339-4376. This warranty does not cover damage caused by misuse or accident.

REPLACEMENT BATTERY

Replacement battery 5-2573 5-2586 5-2586