

DynaVox T10/T15 User's Guide



Copyright © 2014 DynaVox Systems LLC

All rights reserved. No part of this book may be reproduced, stored in a retrieval system, or transmitted in any form, by any means (electronic, photocopying, recording, or otherwise) without the prior written permission of the publisher.

Copyright protection claimed includes all forms and matters of copyrightable material and information allowed by statutory or judicial law or hereafter granted, including without limitation, material generated from the software programs which are displayed on the screen such as screen displays, menus, etc.

Although every precaution has been taken in the preparation of this book, the publisher assumes no responsibility for errors or omissions.

In North America:

For information, write to:

DynaVox Systems LLC

2100 Wharton Street, Suite 400

Pittsburgh, Pennsylvania 15203 USA

The European Authorized Representative is: DynaVox Systems Ltd.

Pure Offices Plato Close

Tachbrook Park

Leamington Spa

Warwickshire

United Kingdom

CV34 6WE

DynaVox® is a registered trademark of DynaVox Systems LLC.

DynaVoxT10™ is a registered trademark of DynaVox Systems LLC.

All other brand and product names mentioned are trademarks or registered trademarks of their respective holders.

Third Edition

Part Number 401438

Published May 2014

Created in the United States of America

Table of Contents

Introduction	1
Resources	1
myDynaVox	1
Additional Documentation	2
Support	2
Hardware Overview	3
DynaVox T10 Overview	4
DynaVox T15 Overview	7
Adapter	10
Charging the Battery	11
Temperature/Humidity/Atmospheric Pressure Ranges	12
Mounting/Transporting Your T10/T15	12
Product Cleaning/Handling	12
Turning the T10/T15 On For The First Time	13
The Tool Bar	15
The Settings Menu	16
Open the Settings Menu	17
Settings	18
Page Browser	18
Page Creator	19
Vocabulary	20
Interface Settings	24
Access Method Settings	27
Toolbar Editor	29
Voice Settings	30
Rate Enhancement Settings	33
Camera Settings	35
Media Library	36
Backup/Restore Settings	37
Help	39
Levels	40
The Editing Toolbar at a Glance	41
Editing a Button	51
Cautions - Handling, Storage, and Shipping	57
Important Information About Your Device	58
Intended Use of This Product	59
Caution	60

Introduction

The DynaVox® T10 and T15 are an integrated hardware and software solution for AAC, which feature the DynaVox Compass™ communication software.

This **User's Guide** provides an overview of the basic operation of your T10 and T15 Android 4.0.4 tablets. It points out key hardware features, briefly explains how to customize the pages and their content, and describes the most frequently-used features and functions of your device.

Resources

This **User's Guide** is only a brief, introductory reference for your DynaVox device. Many other resources are available.



NOTE

On your device open the *Settings* menu. Then select **Help**. A menu will open with links to myDynaVox.com to access documentation, Help Videos, and the Knowledgebase.

myDynaVox

myDynaVox.com is your personal online storage and administration website that you can use to manage the Compass software running on your device. It is available to you from anywhere via the web.

Go to www.myDynaVox.com to register for an account.

Your myDynaVox account integrates you with a community of clinicians, technical experts, and your peers and provides you with a responsive community of help and support.

After you set up your account, you can access it from anywhere on the web to:

- Register your device
- Upload, download, and share communication pages
- Receive software updates and new communication content
- Backup and restore page sets
- Access implementation and therapy supports and tools
- View and participate in discussion forums
- Find technical support and documentation resources
- Search the Knowledgebase
- View help videos
- Manage your user profile

Additional Documentation

A Quick Start Guide was shipped with your DynaVox device. This guide provides an overview of your device, walks you through starting up and customizing it, and provides information on resources available to you on both *myDynaVox.com* and through the *Help* menu on your device.

Support

Technical Support

www.myDynaVox.com > Community & Support > myDynaVox Community

Visit the online library to access Knowledgebase articles, research product tips, and perform custom searches, or visit the Community Q&A section.

Or - if you have a problem with your device, start the repair process by opening a new case.




NOTE

Before you open a new case, write down the serial number of your device. It can be found on the bottom edge of your device..


My serial number is: _____

Hardware Overview

T10 BLOCK DIAGRAM



T15 BLOCK DIAGRAM



DynaVox T10 Overview

Front:




Top:



Back:



Bottom:



Front:	1 Charging Indicator: Lit amber when the battery is charging. Turns blue when the battery is fully charged.
	2 Power Button: To turn the T10 on, press and hold until the splash screen appears. Press and release to put to sleep. To shut down the T10, press and hold until the shutdown menu appears.
	3 Front-facing Camera: Takes photographs of people and objects in view of the T10 screen - for example, self portraits.
	4 Ambient Light Sensor: Adjusts the screen brightness based on the surrounding light.
Top	5 Speakers: Dual speakers provide an extensive range of volume.
	6 Volume Rocker Switch: Press on the + side of the switch to increase volume. Press on the - side of the switch to decrease volume.
Right Side	7 Speaker/Headphone/External Microphone Jack: Connect an external speaker, headphones for private audio, or an external microphone.
Back	8 Rear-facing Camera: Use for taking custom photos to share with others or to put on your communication pages.
	9 Lanyard connections: Provide attachment points for the T10 strap.
Bottom	10 Charger Port: Plug in the adapter/charger to charge the battery.
	11 Micro USB Port: Connect to a micro-USB to full-size USB cable adaptor. (DynaVox does NOT recommend the use of a USB hub.)
	12 30-Pin Dock Connector: (for future use)
	13 Micro HDMI Port: Connect an external monitor to your T10.
	14 Built-in Microphone: Record speech and custom sounds.



CAUTION

The LCD may show "image persistence" if the same image or page is displayed for four (4) consecutive hours or longer. The visual artifacts may or may not be noticeable or distracting. They will not cause permanent damage to the LCD.

DynaVox T15 Overview

Front:



Top/Right Side:



Back:



Bottom:









Front:	1 Power Button: To turn the T15 on, press and hold until the splash screen appears. Press and release to put to sleep. To shut down the T15, press and hold until the shutdown menu appears.
	2 Front-facing Camera: Takes photographs of people and objects in view of the T15 screen - for example, self portraits.
	3 Ambient Light Sensor: Adjusts the screen brightness based on the surrounding light.
	4 Charging Indicator: Lit amber when the battery is charging. Turns blue when the battery is fully charged.
Top/Right Side	5 Speakers: Dual speakers provide an extensive range of volume.
	6 Volume Rocker Switch: Press on the + side of the switch to increase volume. Press on the - side of the switch to decrease volume.
	7 Front-Facing Infrared Window: Sends and receives infrared signals. Use your T15 as a universal remote control.
	8 Micro SD Card: Connect to a micro SD card, for personal storage only.
	9 Full-Size USB Port: Connect to a full-size USB drive. (Maximum current for the full-size USB is 2.0≤1A.)
	10 Speaker/Headphone/External Microphone Jack: Connect an external speaker, headphones for private audio, or an external microphone
	11 Switch Jacks(2): Connect external switch(es) for scanning access.
Back	12 Rear-facing Camera: Use for taking custom photos to share with others or to put on your communication pages.
	13 Rear-Facing Infrared Window: Sends infrared signals.
	14 Lanyard connections: Provide attachment points for the T15 strap.
Bottom	15 Lanyard connections: Provide attachment points for the T15 strap.
	16 30-Pin Dock Connector: (for future use)
	17 Charger Port: Plug in the adapter/charger to charge the battery.
	18 Micro USB Port: Connect to a micro-USB to full-size USB cable adaptor. (DynaVox does NOT recommend the use of a USB hub.)
	19 Micro HDMI Port: Connect an external monitor to your T15.
	20 Built-in Microphone: Record speech and custom sounds.



CAUTION

The LCD may show "image persistence" if the same image or page is displayed for four (4) consecutive hours or longer. The visual artifacts may or may not be noticeable or distracting. They will not cause permanent damage to the LCD.

	Federal Communications Commission. The device complies with Part 15, Class B of the FCC Rules.
	WEEE Directive. WEEE encourages the collection, treatment, recycling and recovery of waste electrical and electronic equipment. WEEE makes producers and importers responsible for financing of the collection, treatment and recovery of WEEE.
	The CE marking is the manufacturer's declaration that the product meets the requirements of the applicable EC directives. It is a mandatory conformity marking for products sold in the European Economic Area since 1993.
	Electric shock TYPE B.
	Warning
	Please refer to the user manual.

Adapter

For safe and optimal performance, the adapter should be kept within the following parameters:

Adapter Model:	MTP451BX - 120300
DC Max Rating:	12V 3A
Adapter Voltage Range:	100-240V, 50/60Hz, 1.5A

Charging the Battery

When the battery charge is low, the device will emit an audible beep. You should plug in your device and recharge the battery immediately.

1. Plug the charger supplied with your device into a wall outlet.
2. Connect the charger to the charger port on the device.

The charging indicator will glow amber while your device is charging. It will turn blue when it is fully charged.

3. After your device is fully charged, disconnect the charger.

You **can't** overcharge the battery. It is fine to charge the battery overnight.

You **can** use the device while the battery is charging.

The T10 battery model is 5860103P/4000mAh/7.4V.

The T15 battery model is HX-5570138/5850mAH/7.4V.



CAUTION

Because of internal chemical reactions, battery performance may deteriorate over time. In addition, failure to keep the conditions of use (charge, discharge, ambient temperature, etc.) within specified ranges may shorten the battery life expectancy, or damage your device. If the battery cannot maintain a charge for long periods of time, even when it is charged correctly, it may need to be replaced.



CAUTION

For safe and proper operation of your DynaVox device, use only chargers, batteries, and accessories that have been approved by DynaVox Technologies.

Temperature/Humidity/Atmospheric Pressure Ranges

For optimal device performance, the T10/T15 should be kept within the following ranges:

Activity	Temperature Range
Using the device	32°F - 104°F (0°C - 40°C)
Charging the battery	32°F - 113°F (0°C - 45°C)
Storing	14°F - 113°F (-10°C - 45°C)
Relative humidity	Up to 90%
Atmospheric pressure	80 - 106kPa

NOTE

Run time will be shortened at the high and low ends of the temperature range.

Mounting/Transporting Your T10/T15

If you use your device while in a wheelchair, you should have it properly mounted for both communication and transportation purposes. Wheelchair mounting systems are available through DynaVox.

Protective and accessible carrying cases are also available. Consult the DynaVox website (www.dynavoxtech.com) or your DynaVox sales consultant for more information.

Product Cleaning/Handling

To clean your device, first turn it off and then wipe it gently with a damp cloth or soft paper towel. You may dampen the towel with a mild window cleaner to remove fingerprints, food particles, and dust. Do not use tape or stickers on either the touch screen or the case, as they are difficult to remove and may damage the device surface. Tape, stickers, and other sticky materials can damage the touch screen and interfere with the operation of the device.

Be sure to avoid getting your device wet. Never submerge it in water (e.g., dishwasher). If your unit accidentally gets wet, be sure to shut it down and allow it dry thoroughly. If after 24 hours you find that the device seems to function normally, there is probably no damage. If it fails to function or behaves abnormally, go to www.myDynaVox.com > *Community & Support* > *myDynaVox Community* to start the repair process by creating a new case. You may need to ship it to DynaVox for repairs.

Be careful not to drop it. Such treatment is not recommended and can shorten the life of your device. Do not use a sharp object to make selections on the touch panel, as this can cause damage. Use your finger or a special capacitive stylus.

CAUTION

Never, under any circumstances, disassemble your device. Doing so for any reason will void the warranty, and you will be responsible for the cost of any required repairs.

Turning the T10/T15 On For The First Time


Press the Power button to turn on your device. Select the DynaVox icon on your desktop.

DYNAVOX ICON ON DESKTOP



The *Setup Wizard* screen will open.

SETUP WIZARD SCREEN



The Setup Wizard will walk you through the steps to create a new user and choose an appropriate page set.

When setup is complete, a *Congratulations* screen will open.




CAUTION

If your device freezes or hangs or presents error messages, you may need to close programs or reset the device to regain functionality.



CAUTION

Any system upgrade or installation must be done by a DynaVox technician. If you are not a resident of North America, please call the dealer from whom you purchased the device. DynaVox can provide the Standard Operating Procedure for the upgrade or installation of any DynaVox system apps.

CONGRATULATIONS SCREEN

From the *Congratulations* screen, you can:

- View orientation videos. (The **Orientation** tab will, by default, be open. Select the video thumbnail to launch the orientation videos.)
- Select the **myDynaVox** tab for information on the *myDynaVox.com* website. (See **myDynaVox**.)
- Select the **Resources** tab for a list of resources available on the *myDynaVox.com* website to support your use of the DynaVox Compass software.

When you have viewed the videos and learned about the *myDynaVox.com* website, select the **Start Communicating** button. You are now ready to start communicating!

The Tool Bar

TOOLBAR (EXAMPLE)



Depending on the pageset you are using, a Toolbar may be present on your screen. The Toolbar is designed to give you quick access to your most-used tools and pages.


The appearance of the Toolbar may vary. It can be customized and configured to your specifications - you can add or remove buttons and folders, hide the Toolbar, and even move it from the left side of the screen to the top, bottom, or right side of the screen. (See **Interface Settings**.)

The Settings button in the Toolbar (circled in the illustration to the left) opens the *Settings* menu, which provides you with easy access to the tools you need to customize the DynaVox Compass software. (See **The Settings Menu** below.)

The Settings Menu

The *Settings* menu gives you access to the *Page Browser*, *Page Creator*, *Vocabulary*, *Interface* and *Toolbar* settings, *Voice Settings*, *Rate Enhancement* components, the camera and media library, access method settings, backup and restore functions, as well as links to help documentation and videos.

SETTINGS MENU



NOTE

Depending on the pageset you are using, a *Levels* button may be present in the *Settings* menu. See **Levels**.

Open the Settings Menu

There are two methods of opening the *Settings* menu, depending on whether or not your Toolbar is visible onscreen:


Open the Settings Menu if the Toolbar is Visible:

Simply select the Settings button on the Toolbar.  The *Settings* menu will open.


Open the Settings Menu if the Toolbar is **Not** Visible

1. Select the Edit button in the top right corner of your screen.

EDIT BUTTON



If the Toolbar is hidden, a dialog will open presenting you with two options:



2. Select the **Settings** button. The *Settings* menu will open.



REFERENCE

When the Toolbar is enabled, the Settings button will always be visible on your screen. See ***Interface Settings*** for instructions on enabling the Toolbar.


Settings

Page Browser

The *Page Browser* is the quickest way to open or edit a page. You can search for a page by name, or look through the folders and see preview images of pages before opening them.

Open the *Settings* menu. (See **Open the Settings Menu.**) Then select **Page Browser**.

PAGE BROWSER (EXAMPLE)



The icons at the top right of the screen (circled in the illustration above) enable you to display the pages and folders as a grid (default) or list.

Use the arrow button at the upper left of the screen (circled in the illustration above) to move up through the layers of folders. Select a folder to open it and display the pages inside. Select a page, and a large thumbnail of the page will open.

SELECTED PAGE IN PAGE BROWSER




Simply select **Open** to open the selected page or **Editor** to edit the page.

Page Creator

Create an entirely new page - either from a template, or based on the layout of an existing page. You can customize your new pages with your own content - vocabulary, symbols, media files, etc.

Open the *Settings* menu. (See **Open the Settings Menu.**) Then select **Page Creator**.



The icons at the top right of the screen (circled in the illustration above) enable you to display the pages and folders as a grid (default) or list.

Select from a number of templates (blank or by activity type or instructional area) or select the **Like Page** tab to create a new page using the layout of an existing page. You can also use the **Search** text field to find a page you would like to use as a template.

Use the arrow button at the upper left of the screen (circled in the illustration above) to move up through the layers of folders. Select a folder to open it and display the pages inside. Select a page, and then select **Create** at the top right corner of the screen. A dialog will open - name the page and browse for a location for it. You can then edit the page to your exact specifications.

Vocabulary

Your vocabulary (your talk topic choices, word lists, and phrases) was selected when you used the Setup Wizard to set up your user account and is based on your input regarding your age, gender, condition, and communication level.


Most vocabulary items are stored in folders. You can edit, copy, delete, change the order of appearance onscreen, and add new vocabulary items using the *Vocabulary* menu.

Open the *Settings* menu. (See **Open the Settings Menu.**) Then select **Vocabulary**.

VOCABULARY MENU



Select the **Word Lists**, **My Phrases**, or **Topics** button.



Navigate through the folders (use the arrow button at the upper left of the screen - circled in the illustration above) - to move up through the layers of folders. Select a folder to open it.

When you find the folder or item you wish to edit, select **Manage** at the top right corner of the screen.



NOTE


















If you are adding a new folder or item, navigate to the level at which you want to add the folder or item, then select **Manage**.

EDIT VOCABULARY MENU (EXAMPLE)

Vocabulary

Done

Edit Copy To Order New Folder New Item

 camouflage	 checked	 clean	 color	 cotton
 creased	 dirty	 extra large	 fade	 fancy
 fit	 flowery	 high heel	 just right	 knot
 large	 logo	 long sleeve	 loose	 medium

When you select the **Manage** button, a button bar will open.

BUTTON BAR ON VOCABULARY SCREEN



Select the item you want to modify. Then select the applicable button on the button bar.

- **Edit** - The Vocabulary Properties panel will open to the default **Edit** tab.

VOCABULARY PROPERTIES PANEL




Enter a new label, browse for a symbol, and add or change the message.

NOTE

The **Message** field will not be present when you are editing a folder.

Select the **Properties** tab in the Vocabulary Properties panel to change the age and ability level for the item you are editing.

- **Copy To** - The *Select a Folder* screen will open. Navigate through the levels to find the destination folder.
- **Order** - Use the **First**, left arrow, right arrow, or **Last** buttons at the top of the screen to reorder the selected item.
- **New Folder** - Create a new folder. Use the onscreen keyboard to enter a label and symbol for the new folder. Select the **Properties** tab in the Vocabulary Properties panel to define the age and ability level for the new folder.
- **New Item** - Create a new item. Use the onscreen keyboard to enter a label, symbol, and message for the new item. Select the **Properties** tab in the Vocabulary Properties panel to define the age and ability level for the new item.
- **Delete item** - Select the trash can icon .

Interface Settings

The *Interface Settings* menu enables you to adjust or define how certain objects are presented onscreen. The *Interface Settings* menu is organized by tab, with each tab pane presenting a different group of controls and options.

Open the *Settings* menu. (See **Open the Settings Menu.**) Then select **Interface**. The *Interface Settings* menu will open to the default *General Settings* tab.

INTERFACE SETTINGS - GENERAL SETTINGS


The screenshot shows the 'Interface Settings - GENERAL SETTINGS' window. At the top, there is a title bar with 'Cancel' on the left, 'Interface Settings' in the center, and a green 'Done' button on the right. Below the title bar are four tabs: 'General', 'Message Window', 'Buttons', and 'Age & Ability Level'. The 'General' tab is selected. The settings are organized into several sections:

- Toolbar:** A checkbox labeled 'Enabled' is currently unchecked.
- Toolbar Location:** A dropdown menu is set to 'Left'.
- Navigation Bar Location:** A dropdown menu is set to 'Left'.
- Home Page:** A placeholder box is shown next to a blue 'Browse' button.
- Keyboard Page:** A keyboard layout preview is shown next to a blue 'Browse' button, a red 'Reset' button, and a 'Disable' checkbox.
- Settings and Editing Password:** A text input field is provided.

General Settings - Enable or disable (hide) the Toolbar, choose a location on the screen for the Toolbar and the Navbar. Select a *Home Page* and *Keyboard* page. Password protect page editing and access to the *Settings* menu.

When you have finished customizing your general settings, select the green **Done** button at the top right corner of the screen.


INTERFACE SETTINGS - MESSAGE WINDOW SETTINGS



Message Window Settings - Customize the settings for your message window: use symbols, auto-capitalize words at the beginning of a sentence, auto-space between words, use a thicker, more visible cursor, clear the message window after speech, speak as words are entered into the message window, and/or show misspellings.

When you have finished customizing your message window settings, select the green **Done** button at the top right corner of the screen.


INTERFACE SETTINGS - BUTTON SETTINGS



Button Settings - Animate the symbols on your buttons and track button usage.


When you select **Enabled** and **Display Usage**, usage counts will appear on each button. (See the illustration below.)

DISPLAY BUTTON USAGE (EXAMPLE)



When you have finished customizing your button settings, select the green **Done** button at the top right corner of the screen.

INTERFACE SETTINGS - AGE & ABILITY LEVEL



Age & Ability Level Settings - Changes the content based on your selection of age and ability level.


When you have finished customizing your age and ability level settings, select the green **Done** button at the top right corner of the screen.

Access Method Settings

The DynaVox device allows you to choose and refine a selection method that best suits your needs.

Open the *Settings* menu. (See **Open the Settings Menu**). Then select **Access Method**.

ACCESS METHOD SETTINGS WITH SCANNING SELECTED



Simply select the access method that you would like to use.




NOTE

Simple Touch is the default selection method.

When you make a selection on the *Access Method* menu, a *Settings* button will appear (circled in the above illustration). Select the **Settings** button to open a menu that will enable you to customize the settings for your selected selection method. (For example, to set hold and release times for the Touch Enter and Touch Exit selection methods.)

The *Settings* menu for the Scanning selection method is pictured below.

EXAMPLE OF ACCESS METHODS SETTINGS MENU

Use the access method *Settings* menu to customize the access method you have selected. When you have chosen your preferred settings, select the green **Done** button at the top right corner of the screen.

**NOTE**


T15 only: You may use the Switch Ports 1 - 2 for your scanning needs.

Toolbar Editor

You can personalize the Toolbar - add a new button or folder, edit or delete buttons or folders, move them up or down the Toolbar, and hide items on the Toolbar.


Open the *Settings* menu. (See **Open the Settings Menu.**) Then select **Toolbar Editor**. This menu shows all of the buttons and folders - both hidden and visible - in your Toolbar.


CONFIGURE TOOLBAR SETTINGS



Select **Manage** at the top right corner of the screen to edit the Toolbar. A button bar will open at the top of the *Configure Toolbar* menu that will let you edit your Toolbar.

BUTTON BAR ON CONFIGURE TOOLBAR MENU



Select **New Button** or **New Folder** to open a dialog and add a new button or folder, or select a folder or button (a blue check mark will appear on the item), and then select **Edit**, **Move Up**, **Move Down**, **Hide (Show)**, or select the trash can icon  to delete the item.

NOTE


Selecting a hidden item in the list will change the **Hide** button to **Show** on the button bar.

When you have finished customizing your Toolbar settings, select the green **Done** button at the top right corner of the screen.

Voice Settings

You can select and customize a speaking voice for your device as well as manage pronunciation exceptions for frequently used words.

Open the *Settings* menu. (See **Open the Settings Menu.**) Then select **Voice Settings**.






- Select a speaking voice from the **Voice** drop-down list.
- Select the **Download & Manage Voices** button on your DynaVox device to delete voices or to download voices from *myDynaVox.com* and install them.

NOTE

The **Download & Manage Voices** button will only be enabled on your T10/T15 device.

When you select the **Download & Manage Voices** button, the *Manage Voices* menu will open.

MANAGE VOICES MENU

Select the trash can icon  to delete a voice, or the **Install** button  to download and install a voice.

 **NOTE**

Preinstalled voices are designated as *Read Only* and cannot be deleted.

- **Manage Pronunciations:**

The speaking voice may not always say words correctly - especially in the case of proper names and some foreign-derived words. You can save alternate text or phonetic spellings of words to correct any pronunciation problems.

Select the **Manage Pronunciations** button to open the *Pronunciation Exceptions* dialog. Select the **Manage** button at the top right corner of the screen and then select either the **New Text Exception** or the **New Phoneme Exception** button. A dialog will open. Use the onscreen keyboard to type the word, and then type the phonetic spelling (or select the appropriate phonemes). Then select **Save** (or **OK** for phonemes) to close the dialog and save the pronunciation exception.

TEXT EXCEPTION DIALOG (EXAMPLE)

The image shows a dialog box titled "New Text Exception". It has two input fields: "Word" containing "Sean" and "Pronunciation" containing "shawn". At the bottom right, there are two buttons: a green "Save" button and a white "Cancel" button.

- Use the **Volume** slider to adjust the speaking volume.
- Use the **Rate** slider to adjust the speaking rate. Dragging the slider from left to right increases the speech rate.
- Select the **Speak** button next to **Voice Preview** to hear how the voice sounds at the selected volume and rate of speech.
- Words in the message window will, by default, be highlighted as they are spoken - select **Disabled** from the **Highlighting** drop-down list if you don't want spoken words to be highlighted. To customize highlighting, select the **Configure** button. On the *Highlighting* menu that opens, select a highlighting type and style from the drop-down lists.

When you're satisfied, select the green **Done** button in the upper right corner of the screen.


Rate Enhancement Settings

The DynaVox Compass software offers rate enhancement features that can help you communicate more quickly and efficiently.

Both abbreviation expansions and word prediction allow you to use the onscreen keyboard to enter only a few letters in the message window, and the software will anticipate word choices.

Open the *Settings* menu. (See **Open the Settings Menu.**) Then select **Rate Enhancement**.

RATE ENHANCEMENT SETTINGS



Abbreviation Expansions

You can compile your own list of abbreviations for frequently used words (for example, names of friends, family, places, pets, etc.).



NOTE

Make sure that the **Auto Expand Abbreviations** check box is selected to use the abbreviations you create.


1. Select the **Manage Abbreviations** button, and the *Abbreviation Expansions* menu will open.

ABBREVIATION EXPANSIONS MENU



2. Select the **Manage** button.
3. Select the **New** button, and the *Edit Abbreviation Expansion* dialog will open.

ABBREVIATION EXPANSIONS MENU WITH EDIT ABBREVIATION EXPANSION DIALOG OPEN



4. In the **Abbreviation** text box, use the system keyboard to type a few letters that represent the word you are abbreviating. (For example, enter "fl" for "Fluffy.")
5. Type the entire word in the **Expansion** text box.
6. Select **Save**.
7. Select **Done** in the upper right corner of the screen.

To expand the abbreviation, just type it into the message window. It will automatically expand after entering a space.

NOTE

Please note that the abbreviation must be entered into the message window exactly as it appeared when you created it. For example, if the abbreviation you created is "als" (without spaces between the letters), entering "a l s" into the message window will not expand.

Word Prediction

Word prediction can be used on any page that includes predictor buttons. As you compose a message, the prediction feature anticipates your word choices and displays vocabulary options for quick selection - these vocabulary options are displayed on the predictor buttons.


You can activate and deactivate prediction features using the *Rate Enhancement Settings* menu. Select or clear the following check boxes on the *Rate Enhancement Settings* menu to enable/disable the following word prediction features:

- **Enable Prediction** - Word prediction is enabled by default. Clear the check box to disable automatic word prediction.
- **Show Symbols with Predictions** - This feature is also enabled by default. Clear the check box to hide symbols.
- **Predict Words only Once** - When the **Predict Words only Once** check box is selected, you have only one chance to select a word in a predictor button. If you do not select a word, that word will not be predicted again until after you complete the word you are entering - by adding ending punctuation or a space.

Camera Settings

Open the *Settings* menu. (See *Open the Settings Menu*.) Then select **Camera**.

CAMERA




- 1 Opens your Media Library, and, if an image has been snapped, also saves that image.
- 2 Switches the camera from rear facing to front facing.
- 3 Select to snap a photograph. After an image has been snapped, the *Snap Image* button updates to *New Image*. Selecting **New Image** saves the current image to your Media Library and snaps another image.

Media Library

The Media Library is a viewer for all of your photos and videos. Videos and any photos that you take from your device's camera will be displayed in folders under the *Images* and *Videos* tabs.

Open the *Settings* menu. (See **Open the Settings Menu.**) Then select **Media Library**.

MEDIA LIBRARY (EXAMPLE - IMAGES)



When you select a folder under the **Images** tab and then select a specific image, a full-screen photo viewer will open.




Use the **Previous** and **Next** buttons at the top of the screen to scroll through all of the images in the folder.

Select the **Videos** tab to open your video library. Select a videos folder, and then select the video file you want to play. Then select **Open** on the *Options* dialog.

Backup/Restore Settings

When you completed the Setup Wizard in a page set, you saved many settings for the page set, vocabulary, media library, rate enhancement information, selection method settings, etc. A backup file saves these customized settings.

Open the *Settings* menu. (See **Open the Settings Menu.**) Then select **Backup/Restore**.



You can backup and restore your user file either locally (to a folder on your device or a USB drive) or to myDynaVox.

Backup to myDynaVox.com

1. Select the **Backup to myDynaVox** button.
2. If you are prompted, sign in to your account by entering your username and password.
3. Enter a name (and description [optional]) for your backup file in the text box. (It's a good idea to include the date in the file name.)
4. Select **OK**.

Backup Locally

You can back up on the device or to a USB drive.

- T10 - You must use the Micro USB OTG adapter. (Insert the adapter into the micro USB port on your device. Then plug the USB drive into the adapter.)

- T15 - You can back up using either the Micro USB adapter or a full-size USB drive. (Either insert the Micro USB adapter into the micro USB port on your device, and then plug the USB drive into the adapter, or insert a full-size USB drive into the USB port on your device.)
1. Select the **Backup Locally** button.
 2. On the screen that opens, select a destination directory (*backups* is the default backup folder). Use the arrow button at the upper left of the screen to move up through the layers of directories. Select a directory in which to save your backup file or locate your USB drive.
 3. Select the green **Select** button in the top right corner of the screen.
 4. Enter a name for your backup file in the text box. (It's a good idea to include the date in the file name.)
 5. Select **OK**.


CAUTION

Backing up locally to your device does not save your backup file "off system" if your device is lost or damaged.

Restore from *myDynaVox.com*

1. Select the **Restore from myDynaVox** button.
2. If prompted, sign in to your account by entering your username and password.
3. The *Select Backup File* screen will open. Select the backup file you want to restore. If necessary, use the arrow button at the upper left of the screen to move up through the layers of directories. Then select the green **Select** button in the top right corner of the screen.
4. Select **OK**. A progress bar will appear.


CAUTION

Selecting this option will reset the device and overwrite all user data, settings, and content.

Restore Locally

- T10 - You must use the Micro USB OTG adapter. (Insert the adapter into the micro USB port on your device. Then plug the USB drive into the adapter.)
 - T15 - You can restore using either the Micro USB adapter or a full-size USB drive. (Either insert the Micro USB adapter into the micro USB port on your device, and then plug the USB drive into the adapter, or insert a full-size USB drive into the USB port on your device.)
1. Select the **Restore Locally** button. The *Select Backup File* screen will open, displaying all of the backup files in the *Backups* folder.
 2. Locate the file you want to restore. If necessary, use the arrow button at the upper left of the screen to move up through the layers of directories. Select your backup file or locate the file on your USB drive.

3. Select the backup file you want to restore. Then select the green **Select** button in the top right corner of the screen.
4. Select **OK**. A progress bar will appear.



CAUTION

Selecting this option will reset the device and overwrite all user data, settings, and content.

Manage Login


Sign out/sign in to your account.

Help

Links to *myDynaVox.com* to access documentation, help videos, and the Knowledgebase are available on the *Help* menu. Use the *Help* menu to check for updates or find the *End-User License Agreement* and information on the software version and serial number of your device.

Open the *Settings* menu. (See **Open the Settings Menu.**) Then select **Help**.

HELP MENU



Levels

Depending on the pageset you are using, a *Levels* button may be present on the *Settings* menu. The *Levels* menu enables you to quickly and easily choose among ability levels to get the most appropriate tools and content and grid size.

The *Levels* menu also provides access to overview videos and allows you to configure your topic and keyboard layouts

Open the *Settings* menu. (See *Open the Settings Menu.*) Then select **Levels**.

LEVELS SETTINGS (NAVBAR PAGESET)

1. Select an appropriate level from the *Ability Level* tabs at the top of the screen.

NOTE

Select the **Intro to Levels** button at the top left of the screen and watch the video for more information on levels.

2. Customize your settings Under *Configure Tools*.
3. When you are done, select the green **Done** button at the top right corner of the screen.


The Editing Toolbar at a Glance

The Editing Tolobar contains all of the tools that you will need for creating and editing pages.

EDITING TOOLBAR




1. File



New	Create a new page.
New From Template	Create a new page from a template or "like" an existing page.
Save	Save all the changes you have made to the page that is currently open.
Open	Opens the <i>Select Page</i> menu to open a new page to edit. (Opening a new page will close the currently open page.)
Revert	Cancel all the changes you have made to the currently open page since you last saved it.
Page Size	Select a page size (or create a custom page size) that anticipates the positions of the Navbar and Toolbar (Left, Right, Top, Bottom, or Off).
Macros	Opens the <i>Macro Editor</i> .
Preferences	Change editor preferences.

2. Edit




NOTE

The *Edit* options will vary, depending on the selected object(s) on the page. For example, if a tab control is selected, there will be an option for adding a new tab. (The options shown in the illustration above are for a group button.)

Undo	Undo the last change you made. (The Compass software allows multiple levels of undo and redo.)
Redo	Redo the last change you made. (The Compass software allows multiple levels of undo and redo.)
Delete	Permanently remove the selected object from the page.
Duplicate	Copy the selected object and place the copy immediately next to the selected object.
Cut	Remove the selected object(s) from the page and save to the clipboard so the object(s) can be pasted back onto the page or onto another page.
Copy	Make a duplicate of the selected object(s) and save to the clipboard so the object(s) can be pasted back onto the page or onto another page.
Select Parent	Change the selection to contain the "parent" object of the object that was originally selected. For example, if a button within a group box is selected, the "parent" of the button would be the group box.
Select Content	Select all content (including label, symbol, and all objects in a group button or group box) in the selected object.
Clear Contents	Remove all content (including label, symbol, audio cue, and all objects in a group button or group box) from the selected object.

3. Select



Select	Select a single object on the page (or the page itself).
Multi Select	Select multiple objects on the page. (This tool replicates holding down the Ctrl key on a keyboard while clicking on multiple objects with a mouse.)
Spray	Spray out copies of a selected object to make a rectangular grid.
Scan Order	Set the order in which the objects on the page will scan.
Lock	“Lock” an object so that it will not be editable. Selecting the Lock tool will place lock icons  on each object on the page (including the page itself). Select each object that you want to lock. Its lock icon will change from green to red, indicating that it is locked. (To unlock the object, select the Lock tool again and then select the object you want to unlock.)
Measure	Gives the measurements of the selected object or area.

4. Buttons




Standard	Place a "standard" (rectangular) button.
Group	Place a group button. (A group button is a button into which you can place other objects [a "multi-object" button]).
Word Predictor	Place a word predictor button. (A word predictor button anticipates the user's word choices as a message is composed in the message window.)
Phrase Predictor	Place a phrase predictor button. (A phrase predictor button works on the same principle as a word predictor button but will predict a phrase.)
Rectangular Hotspot	Place a rectangular hot spot. (Hot spots are usually placed over portions of images or visual scenes on a page. Then the hot spot is programmed so that when it is selected, an action will be performed.)
Invisible Hotspot	Place an invisible hot spot. (An invisible hot spot can have actions assigned to it, but it has no borders, color, symbol, or other visible characteristics.)
Freeform Button	Draw a button of any shape you want. (Touch the screen and move your finger [or mouse if using the editing software] around the page until the button is the size and shape you want.)

To place a button on the page, simply select the appropriate button tool and then select a location on the page.

To draw out a button on the page, touch the screen and use your finger (or mouse if using the editing software) to draw out the button.

To resize the button, select it, and then move your finger (or mouse) over the edge or corner of the button until a double arrow appears. Drag until the button is the size and shape you want.

After you have drawn the button, select it, then select the Properties button in the top left corner of the button. (See the illustration below.)

PROPERTIES BUTTON

The Button Properties panel will open. Use the Button Properties panel to assign a label, message, and symbol to the button, change its appearance, and apply actions. See **Editing a Button**.

5. Label (Non-button Objects)

Label	Place text anywhere on the page.
Symbol	Place a symbol anywhere on the page. After you have placed the symbol - a bounding box (or "placeholder") will appear on the page - select the Properties button in the top left corner of the bounding box. The Symbol Properties panel will open and enable you to select the symbol you want.
Message Window	Place a message window on the page.
Tab Control	Place a tab control. (To add additional tabs, select the tab control. Then select Edit > New Tab .)
Group Box	Place a group box on the page. (A group box acts as a "container" for groups of buttons, check boxes, radio buttons, or other objects.)
Vocabulary Grid	Place a vocabulary grid on the page. After you have placed the vocabulary grid, select the Properties button in the top left corner of the grid to browse for and select a vocabulary source.
Video	Place a video object on the page. After you have placed the video object, select the Properties button in the top left corner of the object to select a video.
Line	Place a line on the page. (To draw out a line on the page, touch the screen and use your finger [or mouse if using the editing software] to draw out the line).

Text Box	Place a text box on the page. (Text boxes are similar to message windows in that they display text messages entered by keyboard input. They differ from message windows, however, in that text boxes are used for short text entries - only one word or line of text.)
Check Box Radio Button	Place a check box or radio button on the page. By default, each radio button/check box includes a frame in which a symbol will appear when it is selected. Radio buttons and check boxes share the same properties. The major difference between them is that in each group of radio buttons, only one selection is allowed. Check boxes, however, work independently of one another and are useful when multiple selections are allowable.


6. Layout



NOTE

The Layout options will vary, depending on the selected object(s) on the page. (The options shown in the illustration above are for two buttons - with labels - selected.)


Arrange



Arrange objects on the page. (Objects on a page are layered and can overlap.)

- **Bring Forward** - Move the selected object up one layer.
- **Bring to Front** - Reposition the selected object as the top item on the page.
- **Send Backward** - Move the selected object down one layer.
- **Send to Back** - Reposition the selected object as the bottom item on the page.


Align



Adjust the relative positions of multiple selected objects on the page by aligning the selected objects on the page based on the position of the primary object.


NOTE
 If you have multiple objects selected on a page, the "primary" object is the object displaying the Properties button.

Center




Center the selected objects on the page horizontally, vertically, or both horizontally and vertically.

Size



Resize all of the selected objects. The resulting size is based upon the primary object - the object displaying the Properties button. (That is, all selected objects will be resized to match the size of the primary object.)

- **Same Width** - Resize the selected objects to the same width.
- **Same Height** - Resize the selected objects to the same height.
- **Same Size** - Resize the selected objects to the same size.
- **Fill in Parent** - Resize the selected objects to the size of their parent object while retaining their shape.
- **Gridify** - Resize the selected objects to fit within the background gridlines.
- **Gridify in Parent** - Resize and reshape the selected objects to fill their parent object.


 **NOTE**
 If only one object on a page is selected, the options available in the *Size* menu are **Full Width**, **Full Height**, and **Full Size**. (The selected object will fill the width of the page, the height of the page, or fill the entire page.)

Alphabetize




Adjust the relative positions of objects on a page alphabetically - based on their labels.

Swap




Exchange the positions of two selected objects. (The contents of the objects will remain with the original object)
 (This option is only available if two objects on the page are selected.)

Spacing



Adjust the horizontal and vertical spacing of three or more selected objects on the page.
 (This menu option is only available if three or more objects on the page are selected.)

7. Exit



Closes the Editing Toolbar.
 (A confirmation dialog will appear asking if you want to save changes to the page.)

Editing a Button

Editing a button is a fast, easy way to quickly customize your pages.


1. Select the Edit button in the top right corner of your screen. (See the illustration below.)



NOTE


If the Toolbar is disabled, when you select the Edit button, a dialog will open with two options: *Edit Page* or *Settings* (to open the Settings menu). Select the **Edit Page** button.

EDIT BUTTON



2. Select the button to be modified.
3. Select the Properties button in the top left corner of the button. (See the illustration below.)

SELECT THE PROPERTIES BUTTON



The *Button Properties* panel will open.

BUTTON PROPERTIES PANEL - CONTENT TAB OPEN



The Button Properties panel contains five tabs:

Content Tab

On the **Content** tab, you can assign a label, a message, a symbol, and apply actions that will execute when that button is selected.

1. **Label** - the label will appear on the face of the button.
 - a. Select the **Label** field.
 - b. Type the new label using the onscreen keyboard.
 - c. Select **OK**.

2. Message


The message will not appear on the face of the button. Messages can be used for a more lengthy or more complex line of text. For example, if the label of the button is "Address," the message could be the user's actual address. When using messages, be sure to assign corresponding actions. (See **Actions** below.)

- a. Select the **Message** field
- b. Select the **Replace** button.
- c. Type the new message using the onscreen keyboard.
- d. Select **OK**.

3. Symbol

Symbols help users associate concepts more quickly and easily. To assign a symbol:

- a. Select the blue **Select...** button next to the *Symbol* field. Symbols based on the label you entered will be suggested, but you can search for different symbols using the search field at the top of the screen. Just select the **Search** field, and use the onscreen keyboard to type what you're searching for. As you are typing, a dynamic search will return symbols that match your search criteria.
- b. Touch the symbol to select it. When a symbol is selected, a blue check mark will appear over the symbol. To choose a different symbol, just select a new one. The first choice will automatically deselect.



c. Select the green **Select** button at the top right corner of the screen.


4. Actions

Actions make the button *do* something. Whether you want to speak a label directly from a button or compose text in a message window, you'll need to assign actions to your button.


To assign actions:

- a. Select the **Edit...** button next to *Actions...*
- b. From the drop-down list, select what kinds of actions you're looking for. For example, if you're assigning actions to a button, select **Buttons** from the list. This will show you a list of popular button actions.

SCRIPT EDITOR-PULL-DOWN MENU




- c. A list of available actions will display in the window on the left. For example, if you selected **Buttons**, button actions will be displayed with a brief description of each action.
- d. Select the action to assign to your button. As you make your selections, actions assigned to your button will appear in a list in the window on the right.

To delete actions, make selections from the list of assigned actions, and select the red trash can icon  at the top of the screen.


- e. After assigning actions, select the green **Done** button at the top right corner of the screen.

Font Tab

Font choices are available for all text, including button labels. Select the **Font** tab to choose font types, styles, sizes, and colors.



Layout Tab



The *Layout* tab enables you to change the button type. If you wish to change the button type, use the **Type** drop-down list to select a new button type from the following button type choices:

- **Standard** - buttons most often contain a label, a symbol, and have assigned actions.
- **Group** - buttons contain multiple, smaller buttons. Using group buttons can often help those who use the scanning access method easily make faster choices.
- **Word Prediction** - A Word Prediction button anticipates the next logical word choice and displays various options for quick selection. Typically used on keyboard and spelling pages, these buttons can greatly enhance the rate at which the user communicates.
- **Phrase Prediction** - Similar to Word Prediction, Phrase Prediction buttons anticipate logical phrases.

In addition, various layout options (placement of symbol and label) are available to accommodate the user's preferences and needs. Select the **Layout** drop-down list to choose a layout for the button.

Style Tab

Many style choices are available, including theme styles and colors, border colors and thickness, and button shapes.

STYLE TAB



Misc Tab


For auditory scanning users, a field for an audio cue is provided. To enter an audio cue:

1. Select **Replace**.
2. Type the new audio cue using the onscreen keyboard.
3. Select **OK**.

To hide the button, select the check box next to *Hidden*.

If you wish, assign an object name to the button. (An object name is a unique property that identifies an object on a page for programming purposes.)

MISC TAB








NOTE

Did you make a mistake? Just select **Edit** from the Editing Toolbar. You can *Undo*, *Redo*, or even *Duplicate* a button. If you've made several changes, but want to revert back to the original state of the page when you entered Edit mode, select **File** from the toolbar, then select **Revert**.

Cautions - Handling, Storage, and Shipping

While handling, storing, or shipping, please pay attention to the labeling on the package.

	This Side Up
	Fragile
	Guard against Damp
	Warehouse Stack Limit (6 Cartons)
	Storage Temperature: 0 °C-45 °C

Important Information About Your Device

Your DynaVox device meets all necessary international safety standards and has been tested to meet IEC 60601-1 requirements. The DynaVox T10/T15 systems are considered to be portable devices that are intended for continuous operation, not intermittent use. The devices have electrical input ratings of 12 VDC/3.0 Amps. These devices comply with Part 15, Class B of the FCC Rules. Operation is subject to the following two conditions: (1) these devices may not cause harmful interference, and (2) these devices must accept any interference received, including interference that may cause undesired operation. These devices are also tested to Canadian standard ICES-003. To ensure safe operation, you should take care to note the following cautionary items:

**CAUTION**

Your DynaVox device contains a Lithium Ion battery. A safety hazard may develop when the battery is placed in or near fires or stoves, or in locations with temperatures above 113 ° F (45 ° C). These conditions may cause the battery to generate heat or explode.

**CAUTION**

Do not perforate, disassemble or modify the battery. If you must dispose of the battery, do so in accordance with the local laws that apply to the area where you live.

**CAUTION**

For safe and proper operation of your DynaVox device, use only chargers, batteries, and accessories that have been approved by DynaVox Technologies.

**CAUTION**

This device presents a risk of electrical shock if the casing is opened. Do not open the casing that surrounds the device.

**CAUTION**

The DynaVox devices are not suitable for use in the presence of flammable anesthetics.

When you are charging your device, remember that the main outlet that you will be using to power the adapter must be accessible from within 6 feet (2 meters) of the device. There should be no switches or disconnect devices in the ground conductor. The devices require no routine maintenance other than a periodic inspection of the power cords for signs of wear and damage. If the power cords show signs of wear and damage, they should be replaced.

**CAUTION**

Do not modify this equipment without authorization from the manufacturer.

**CAUTION**

The device may be mounted to a wheelchair or fixed on a table. Running the device for a long time may cause the temperature to temporarily rise to above 105 ° F (41 ° C). Please power off the device if it is overheating.

**CAUTION**

In case of need, a DynaVox technician can provide a schematic diagram or other technical files.

Intended Use of This Product

The DynaVox T10 and T15 devices are intended for use as an augmentative communication aid, computer access, and environmental control unit for those with speech, language, physical, and cognitive disabilities. Their intended purpose is to compensate for lack of speech due to injury or handicap, and to provide a means of controlling the environment for persons who are unable to reach environmental control equipment due to injury or handicap.

Your device is intended for everyday communication situations. It should not be relied upon as a means of communicating emergency medical information. We recommend having multiple ways to communicate information during a medical emergency.

Caution

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF Warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC RF Exposure Statement

The exposure standard for wireless devices employs a unit of measurement known as the Specific Absorption Rate (SAR). The SAR limit set by the FCC is 1.6 W/kg. The highest SAR level measured for this device is 0.425W/kg, so this device meets the FCC Requirement.

IC Warning

English:

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

French:

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio Exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Declaration of Conformity

[DynaVox Systems LLC] hereby declares that this [T15] is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.