



Service Manual

(Models 30603, 30605, 30607 and 30609)

Groundsmaster[®] 4000-D & 4010-D

Preface

The purpose of this publication is to provide the service technician with information for troubleshooting, testing and repair of major systems and components on the Groundsmaster 4000-D (Models 30605 and 30609) and Groundsmaster 4010-D (Models 30603 and 30607).

REFER TO THE OPERATOR'S MANUAL FOR OPERATING, MAINTENANCE AND ADJUSTMENT INSTRUCTIONS. For reference, insert a copy of the Operator's Manual and Parts Catalog for your machine into Chapter 2 of this service manual. Additional copies of the Operator's Manual and Parts Catalog are available on the internet at www.Toro.com.

The Toro Company reserves the right to change product specifications or this publication without notice.



This safety symbol means DANGER, WARNING, or CAUTION, PERSONAL SAFETY INSTRUCTION. When you see this symbol, carefully read the instructions that follow. Failure to obey the instructions may result in personal injury.

NOTE: A NOTE will give general information about the correct operation, maintenance, service, testing or repair of the machine.

IMPORTANT: The IMPORTANT notice will give important instructions which must be followed to prevent damage to systems or components on the machine.



Groundsmaster 4000-D

This page is intentionally blank.

Table Of Contents

Chapter 1 - Safety

General Safety Instructions	1 - 2
Jacking Instructions	1 - 5
Safety and Instruction Decals	1 - 6

Chapter 2 - Product Records and Maintenance

Product Records	2 - 1
Maintenance	2 - 1
Equivalents and Conversions	2 - 2
Torque Specifications	2 - 3

Chapter 3 - Yanmar Diesel Engine

Specifications	3 - 2
General Information	3 - 5
Service and Repairs	3 - 10
YANMAR TNV (Tier 4i) SERIES SERVICE MANUAL	
YANMAR TNV (Tier 4i) SERIES TROUBLE-SHOOTING MANUAL	
YANMAR TNV (Tier 4) SERIES SERVICE MANUAL	
YANMAR TNV (Tier 4) SERIES TROUBLESHOOTING MANUAL	

Chapter 4 - Hydraulic System

Specifications	4 - 2
General Information	4 - 4
Hydraulic Schematic	4 - 10
Hydraulic Flow Diagrams	4 - 12
Special Tools	4 - 28
Troubleshooting	4 - 33
Testing	4 - 40
Adjustments	4 - 70
Service and Repairs	4 - 71
SAUER-DANFOSS H1 CLOSED CIRCUIT AXIAL PISTON PUMPS SERVICE MANUAL	
SAUER-DANFOSS K and L FRAME VARIABLE MOTORS SERVICE MANUAL	
EATON PARTS AND REPAIR INFORMATION: 5 SERIES STEERING CONTROL UNITS	

Chapter 5 - Electrical System

General Information	5 - 2
Special Tools	5 - 6
InfoCenter Display	5 - 8
Troubleshooting	5 - 15
Adjustments	5 - 25
Electrical System Quick Checks	5 - 29
Component Testing	5 - 30
Service and Repairs	5 - 63

Chapter 6 - Axles, Planetaries and Brakes

Specifications	6 - 2
General Information	6 - 3
Adjustments	6 - 4
Service and Repairs	6 - 6

Chapter 7 - Chassis

General Information	7 - 1
Service and Repairs	7 - 2

Chapter 8 - Cutting Decks

Specifications	8 - 2
General Information	8 - 3
Troubleshooting	8 - 4
Service and Repairs	8 - 6

Safety

Product Records and Maintenance

Yanmar Diesel Engine

Hydraulic System

Electrical System

Axles, Planetaries and Brakes

Chassis

Cutting Decks

This page is intentionally blank.

Table Of Contents (Continued)

Chapter 9 - Operator Cab

General Information	9 - 2
Service and Repairs	9 - 3
SANDEN SD COMPRESSOR SERVICE GUIDE	

Chapter 10 - Foldout Drawings

Electrical Drawing Designations	10 - 2
Hydraulic Schematic	10 - 3
Electrical Schematics	10 - 4
Wire Harness Drawings	10 - 9



This page is intentionally blank.



Table of Contents

GENERAL SAFETY INSTRUCTIONS 2
 Before Operating 2
 While Operating 3
 Maintenance and Service 4
JACKING INSTRUCTIONS 5
SAFETY AND INSTRUCTION DECALS 6

General Safety Instructions

The Groundsmaster 4000-D and 4010-D are tested and certified by Toro for compliance with existing safety standards and specifications. Although hazard control and accident prevention partially are dependent upon the design and configuration of the machine, these factors are also dependent upon the awareness, concern and proper training of the personnel involved in the operation, transport, maintenance and storage of the machine. Improper use or maintenance of the machine can result in injury or death. To reduce the potential for injury or death, comply with the following safety instructions.



Before Operating

1. Review and understand the contents of the Operator's Manual and Operator's DVD before starting and operating the vehicle. Become familiar with the controls and know how to stop the vehicle and engine quickly. Additional copies of the Operator's Manual are available on the internet at www.Toro.com.
2. Keep all shields, safety devices and decals in place. If a shield, safety device or decal is defective, illegible or damaged, repair or replace it before operating the machine. Also tighten any loose nuts, bolts or screws to ensure machine is in safe operating condition.
3. Assure interlock switches are adjusted correctly so engine cannot be started unless traction pedal is in NEUTRAL and cutting decks are DISENGAGED.
4. Since diesel fuel is flammable, handle it carefully:
 - A. Use an approved fuel container.
 - B. Do not remove fuel tank cap while engine is hot or running.
 - C. Do not smoke while handling fuel.
 - D. Fill fuel tank outdoors and only to within an inch of the top of the tank, not the filler neck. Do not overfill.
 - E. Wipe up any spilled fuel.

While Operating

1. Sit on the seat when starting and operating the machine.
2. Before starting the engine:
 - A. Apply the parking brake.
 - B. Make sure traction pedal is in neutral and the PTO switch is OFF (disengaged).
3. After engine is started, release parking brake and keep foot off traction pedal. Machine must not move. If movement is evident, there may be a problem with traction pedal calibration or the piston (traction) pump that needs to be corrected before using the machine.
4. Do not run engine in a confined area without adequate ventilation. Exhaust fumes are hazardous and could possibly be deadly.
5. Do not touch engine, radiator or exhaust system while engine is running or soon after it is stopped. These areas could be hot enough to cause burns.
6. Before getting off the seat:
 - A. Ensure that traction pedal is in neutral.
 - B. Fully lower and disengage cutting decks. Wait for blades to stop.
 - C. Apply the parking brake.
 - D. Stop engine and remove key from switch.
7. Toro recommends that anytime the machine is parked (short or long term), the cutting decks should be lowered to the ground. This relieves hydraulic pressure from the deck lift circuit and eliminates the risk of the cutting decks unexpectedly lowering to the ground.
8. Do not park on slopes unless wheels are chocked or blocked.

Maintenance and Service

1. Before servicing or making adjustments, lower decks, stop engine, apply parking brake and remove key from the ignition switch.
2. Make sure machine is in safe operating condition by keeping all nuts, bolts and screws tight.
3. Never store the machine or fuel container inside where there is an open flame, such as near a water heater or furnace.
4. Make sure all hydraulic connectors are tight and all hydraulic hoses and lines are in good condition before applying pressure to the hydraulic system.
5. Keep body and hands away from pin hole leaks in hydraulic lines that eject high pressure hydraulic fluid. Use cardboard or paper to find hydraulic leaks. Hydraulic fluid escaping under pressure can penetrate skin and cause injury. Fluid accidentally injected into the skin must be surgically removed within a few hours by a doctor familiar with this form of injury or gangrene may result.
6. Before disconnecting or performing any work on the hydraulic system, all pressure in system must be relieved by lowering cutting decks to the ground and stopping engine.
7. If major repairs are ever needed or assistance is desired, contact an Authorized Toro Distributor.
8. To reduce potential fire hazard, keep engine area free of excessive grease, grass, leaves and dirt. Clean protective screen on machine frequently.
9. If engine must be running to perform maintenance or an adjustment, keep hands, feet, clothing and other parts of the body away from cutting decks and other moving parts. Keep bystanders away.
10. To assure safety and accuracy, check maximum engine speed.
11. Shut engine off before checking or adding oil to the crankcase.
12. Disconnect battery before servicing the machine. Disconnect negative cable first and positive cable last. If battery voltage is required for troubleshooting or test procedures, temporarily connect the battery. Reconnect positive cable first and negative cable last.
13. Battery acid is poisonous and can cause burns. Avoid contact with skin, eyes and clothing. Protect your face, eyes and clothing when working with a battery.
14. Battery gases can explode. Keep cigarettes, sparks and flames away from the battery.
15. At the time of manufacture, the machine conformed to the safety standards for riding mowers. To assure optimum performance and continued safety certification of the machine, use genuine Toro replacement parts and accessories. Replacement parts and accessories made by other manufacturers may result in non-conformance with the safety standards and the warranty may be voided.
16. When changing attachments, tires or performing other service, use correct supports, hoists and jacks. Make sure machine is parked on a solid level surface such as a concrete floor. Prior to raising the machine, remove any attachments that may interfere with the safe and proper raising of the machine. Always chock or block wheels. Use appropriate jack stands to support the raised machine. If the machine is not properly supported by jack stands, the machine may move or fall, which may result in personal injury (see Jacking Instructions in this chapter).
17. When welding on machine, disconnect all battery cables to prevent damage to machine electronic equipment. Disconnect negative battery cable first and positive cable last. Also, disconnect wire harness connector from both of the TEC controllers, disconnect and remove the engine ECM and disconnect the terminal connector from the alternator. Attach welder ground cable no more than two (2) feet (0.6 meters) from the welding location.
18. Make sure to dispose of potentially harmful waste (e.g. fuel, oil, engine coolant, filters, battery) in an environmentally safe manner. Follow all local codes and regulations when recycling or disposing of waste.

Jacking Instructions



CAUTION

When changing attachments, tires or performing other service, use correct jacks and supports. Make sure machine is parked on a solid, level surface such as a concrete floor. Prior to raising machine, remove any attachments that may interfere with the safe and proper raising of the machine. Always chock or block wheels. Use jack stands to support the raised machine. If the machine is not properly supported by jack stands, the machine may move or fall, which may result in personal injury.

Safety




Figure 1

1. Front jacking point 2. Front tire

Jacking the Front End (Fig. 1)

1. Set parking brake and chock both rear tires to prevent the machine from moving.
2. Position jack securely under the frame, just to the inside of the front tire. Jack front wheel off the ground.
3. Once the machine is raised, position jack stand under the frame as close to the wheel as possible to support the machine.

Jacking the Rear End (Fig. 2)

1. Set parking brake and chock both front tires to prevent the machine from moving.
2. Place jack securely under the center of rear axle. Jack rear of machine off the ground.
3. Once the machine is raised, use jack stands under the axle to support the machine.




Figure 2

1. Rear axle jacking point 2. Rear tire

Safety and Instruction Decals

Numerous safety and instruction decals are affixed to your Groundsmaster machine. If any decal becomes illegible or damaged, install a new decal. Decal part numbers are listed in your Parts Catalog.



Product Records and Maintenance

Table of Contents

PRODUCT RECORDS	1
MAINTENANCE	1
EQUIVALENTS AND CONVERSIONS	2
Decimal and Millimeter Equivalents	2
U.S. to Metric Conversions	2
TORQUE SPECIFICATIONS	3
Fastener Identification	3
Using a Torque Wrench with an Offset Wrench ..	3
Standard Torque for Dry, Zinc Plated and Steel Fasteners (Inch Series)	4
Standard Torque for Dry, Zinc Plated and Steel Fasteners (Metric)	5
Other Torque Specifications	6
Conversion Factors	6

Product Records

Insert Operator's Manuals and Parts Catalogs for your Groundsmaster at the end of this chapter. Additionally, if any optional equipment or accessories have been installed to your machine, insert the Installation Instructions, Operator's Manuals and Parts Catalogs for those options at the end of this chapter.

Maintenance

Maintenance procedures and recommended service intervals for your Groundsmaster are covered in the Operator's Manual. Refer to that publication when performing regular equipment maintenance.

Equivalents and Conversions

Decimal and Millimeter Equivalents

Fractions	Decimals	mm	Fractions	Decimals	mm
	1/64	0.015625	—	0.397	
	1/32	0.03125	—	0.794	
	3/64	0.046875	—	1.191	
1/16	—	0.0625	—	1.588	
	5/64	0.078125	—	1.984	
	3/32	0.09375	—	2.381	
	7/64	0.109275	—	2.778	
1/8	—	0.1250	—	3.175	
	9/64	0.140625	—	3.572	
	5/32	0.15625	—	3.969	
	11/64	0.171875	—	4.366	
3/16	—	0.1875	—	4.762	
	13/64	0.203125	—	5.159	
	7/32	0.21875	—	5.556	
	15/64	0.234375	—	5.953	
1/4	—	0.2500	—	6.350	
	17/64	0.265625	—	6.747	
	9/32	0.28125	—	7.144	
	19/64	0.296875	—	7.541	
5/16	—	0.3125	—	7.938	
	21/64	0.328125	—	8.334	
	11/32	0.34375	—	8.731	
	23/64	0.359375	—	9.128	
3/8	—	0.3750	—	9.525	
	25/64	0.390625	—	9.922	
	13/32	0.40625	—	10.319	
	27/64	0.421875	—	10.716	
7/16	—	0.4375	—	11.112	
	29/64	0.453125	—	11.509	
	15/32	0.46875	—	11.906	
	31/64	0.484375	—	12.303	
1/2	—	0.5000	—	12.700	
	1 mm = 0.03937 in.			0.001 in. = 0.0254 mm	
				33/64	0.515625
				17/32	0.53125
				35/64	0.546875
			9/16	—	0.5625
				37/64	0.578125
				19/32	0.59375
				39/64	0.609375
			5/8	—	0.6250
				41/64	0.640625
				21/32	0.65625
				43/64	0.671875
			11/16	—	0.6875
				45/64	0.703125
				23/32	0.71875
				47/64	0.734375
			3/4	—	0.7500
				49/64	0.765625
				25/32	0.78125
				51/64	0.796875
			13/16	—	0.8125
				53/64	0.828125
				27/32	0.84375
				55/64	0.859375
			7/8	—	0.8750
				57/64	0.890625
				29/32	0.90625
				59/64	0.921875
			15/16	—	0.9375
				61/64	0.953125
				31/32	0.96875
				63/64	0.984375
			1	—	1.000

U.S. to Metric Conversions

	To Convert	Into	Multiply By
Linear Measurement	Miles	Kilometers	1.609
	Yards	Meters	0.9144
	Feet	Meters	0.3048
	Feet	Centimeters	30.48
	Inches	Meters	0.0254
	Inches	Centimeters	2.54
	Inches	Millimeters	25.4
Area	Square Miles	Square Kilometers	2.59
	Square Feet	Square Meters	0.0929
	Square Inches	Square Centimeters	6.452
	Acre	Hectare	0.4047
Volume	Cubic Yards	Cubic Meters	0.7646
	Cubic Feet	Cubic Meters	0.02832
	Cubic Inches	Cubic Centimeters	16.39
Weight	Tons (Short)	Metric Tons	0.9078
	Pounds	Kilograms	0.4536
	Ounces (Avdp.)	Grams	28.3495
Pressure	Pounds/Sq. In.	Kilopascal	6.895
	Pounds/Sq. In.	Bar	0.069
Work	Foot-pounds	Newton-Meters	1.356
	Foot-pounds	Kilogram-Meters	0.1383
	Inch-pounds	Kilogram-Centimeters	1.152144
Liquid Volume	Quarts	Liters	0.9463
	Gallons	Liters	3.785
Liquid Flow	Gallons/Minute	Liters/Minute	3.785
Temperature	Fahrenheit	Celsius	1. Subtract 32°
			2. Multiply by 5/9

Torque Specifications

Recommended fastener torque values are listed in the following tables. For critical applications, as determined by Toro, either the recommended torque or a torque that is unique to the application is clearly identified and specified in this Service Manual.

These Torque Specifications for the installation and tightening of fasteners shall apply to all fasteners which do not have a specific requirement identified in this Service Manual. The following factors shall be considered when applying torque: cleanliness of the fastener, use of a thread sealant (e.g. Loctite), degree of lubrication on the fastener, presence of a prevailing torque feature (e.g. Nylock nut), hardness of the surface underneath the fastener's head or similar condition which affects the installation.

As noted in the following tables, torque values should be **reduced by 25% for lubricated fasteners** to achieve the similar stress as a dry fastener. Torque values may also have to be reduced when the fastener is threaded into aluminum or brass. The specific torque value should be determined based on the aluminum or brass material strength, fastener size, length of thread engagement, etc.

The standard method of verifying torque shall be performed by marking a line on the fastener (head or nut) and mating part, then back off fastener 1/4 of a turn. Measure the torque required to tighten the fastener until the lines match up.

Fastener Identification




Figure 1




Figure 2

Using a Torque Wrench with an Offset Wrench

Use of an offset wrench (e.g. crowfoot wrench) will affect torque wrench calibration due to the effective change of torque wrench length. When using a torque wrench with an offset wrench, multiply the listed torque recommendation by the calculated torque conversion factor (Fig. 3) to determine proper tightening torque. Tightening torque when using a torque wrench with an offset wrench will be lower than the listed torque recommendation.

Example: The measured effective length of the torque wrench (distance from the center of the handle to the center of the square drive) is 18".

The measured effective length of the torque wrench with the offset wrench installed (distance from the center of the handle to the center of the offset wrench) is 19".

The calculated torque conversion factor for this torque wrench with this offset wrench would be $18 / 19 = 0.947$.

If the listed torque recommendation for a fastener is from 76 to 94 ft-lb, the proper torque when using this torque wrench with an offset wrench would be from 72 to 89 ft-lb.




Figure 3

Standard Torque for Dry, Zinc Plated and Steel Fasteners (Inch Series)

Thread Size	Grade 1, 5 & 8 with Thin Height Nuts	SAE Grade 1 Bolts, Screws, Studs & Sems with Regular Height Nuts (SAE J995 Grade 2 or Stronger Nuts)		SAE Grade 5 Bolts, Screws, Studs & Sems with Regular Height Nuts (SAE J995 Grade 2 or Stronger Nuts)		SAE Grade 8 Bolts, Screws, Studs & Sems with Regular Height Nuts (SAE J995 Grade 5 or Stronger Nuts)	
	in-lb	in-lb	N-cm	in-lb	N-cm	in-lb	N-cm
# 6 - 32 UNC	10 ± 2	13 ± 2	147 ± 23	15 ± 2	169 ± 23	23 ± 3	262 ± 34
# 6 - 40 UNF				17 ± 2	192 ± 23	25 ± 3	282 ± 34
# 8 - 32 UNC	13 ± 2	25 ± 5	282 ± 30	29 ± 3	328 ± 34	41 ± 5	463 ± 56
# 8 - 36 UNF				31 ± 4	350 ± 45	43 ± 5	486 ± 56
# 10 - 24 UNC	18 ± 2	30 ± 5	339 ± 56	42 ± 5	475 ± 56	60 ± 6	678 ± 68
# 10 - 32 UNF				48 ± 5	542 ± 56	68 ± 7	768 ± 79
1/4 - 20 UNC	48 ± 7	53 ± 7	599 ± 79	100 ± 10	1130 ± 113	140 ± 15	1582 ± 169
1/4 - 28 UNF	53 ± 7	65 ± 10	734 ± 113	115 ± 12	1299 ± 136	160 ± 17	1808 ± 192
5/16 - 18 UNC	115 ± 15	105 ± 15	1186 ± 169	200 ± 25	2260 ± 282	300 ± 30	3390 ± 339
5/16 - 24 UNF	138 ± 17	128 ± 17	1446 ± 192	225 ± 25	2542 ± 282	325 ± 33	3672 ± 373
	ft-lb	ft-lb	N-m	ft-lb	N-m	ft-lb	N-m
3/8 - 16 UNC	16 ± 2	16 ± 2	22 ± 3	30 ± 3	41 ± 4	43 ± 5	58 ± 7
3/8 - 24 UNF	17 ± 2	18 ± 2	24 ± 3	35 ± 4	47 ± 5	50 ± 6	68 ± 8
7/16 - 14 UNC	27 ± 3	27 ± 3	37 ± 4	50 ± 5	68 ± 7	70 ± 7	95 ± 9
7/16 - 20 UNF	29 ± 3	29 ± 3	39 ± 4	55 ± 6	75 ± 8	77 ± 8	104 ± 11
1/2 - 13 UNC	30 ± 3	48 ± 7	65 ± 9	75 ± 8	102 ± 11	105 ± 11	142 ± 15
1/2 - 20 UNF	32 ± 4	53 ± 7	72 ± 9	85 ± 9	115 ± 12	120 ± 12	163 ± 16
5/8 - 11 UNC	65 ± 10	88 ± 12	119 ± 16	150 ± 15	203 ± 20	210 ± 21	285 ± 28
5/8 - 18 UNF	75 ± 10	95 ± 15	129 ± 20	170 ± 18	230 ± 24	240 ± 24	325 ± 33
3/4 - 10 UNC	93 ± 12	140 ± 20	190 ± 27	265 ± 27	359 ± 37	375 ± 38	508 ± 52
3/4 - 16 UNF	115 ± 15	165 ± 25	224 ± 34	300 ± 30	407 ± 41	420 ± 43	569 ± 58
7/8 - 9 UNC	140 ± 20	225 ± 25	305 ± 34	430 ± 45	583 ± 61	600 ± 60	813 ± 81
7/8 - 14 UNF	155 ± 25	260 ± 30	353 ± 41	475 ± 48	644 ± 65	667 ± 66	904 ± 89

NOTE: Reduce torque values listed in the table above by 25% for lubricated fasteners. Lubricated fasteners are defined as threads coated with a lubricant such as engine oil or thread sealant such as Loctite.

NOTE: Torque values may have to be reduced when installing fasteners into threaded aluminum or brass. The specific torque value should be determined based on the fastener size, the aluminum or base material strength, length of thread engagement, etc.

NOTE: The nominal torque values listed above for Grade 5 and 8 fasteners are based on 75% of the minimum proof load specified in SAE J429. The tolerance is approximately ± 10% of the nominal torque value. Thin height nuts include jam nuts.

Standard Torque for Dry, Zinc Plated and Steel Fasteners (Metric Series)

Thread Size	Class 8.8 Bolts, Screws and Studs with Regular Height Nuts (Class 8 or Stronger Nuts)		Class 10.9 Bolts, Screws and Studs with Regular Height Nuts (Class 10 or Stronger Nuts)	
M5 X 0.8	57 ± 6 in-lb	644 ± 68 N-cm	78 ± 8 in-lb	881 ± 90 N-cm
M6 X 1.0	96 ± 10 in-lb	1085 ± 113 N-cm	133 ± 14 in-lb	1503 ± 158 N-cm
M8 X 1.25	19 ± 2 ft-lb	26 ± 3 N-m	28 ± 3 ft-lb	38 ± 4 N-m
M10 X 1.5	38 ± 4 ft-lb	52 ± 5 N-m	54 ± 6 ft-lb	73 ± 8 N-m
M12 X 1.75	66 ± 7 ft-lb	90 ± 10 N-m	93 ± 10 ft-lb	126 ± 14 N-m
M16 X 2.0	166 ± 17 ft-lb	225 ± 23 N-m	229 ± 23 ft-lb	310 ± 31 N-m
M20 X 2.5	325 ± 33 ft-lb	440 ± 45 N-m	450 ± 46 ft-lb	610 ± 62 N-m

NOTE: Reduce torque values listed in the table above by 25% for lubricated fasteners. Lubricated fasteners are defined as threads coated with a lubricant such as engine oil or thread sealant such as Loctite.

NOTE: The nominal torque values listed above are based on 75% of the minimum proof load specified in SAE J1199. The tolerance is approximately ± 10% of the nominal torque value.

NOTE: Torque values may have to be reduced when installing fasteners into threaded aluminum or brass. The specific torque value should be determined based on the fastener size, the aluminum or base material strength, length of thread engagement, etc.

Other Torque Specifications

SAE Grade 8 Steel Set Screws

Thread Size	Recommended Torque	
	Square Head	Hex Socket
1/4 - 20 UNC	140 ± 20 in-lb	73 ± 12 in-lb
5/16 - 18 UNC	215 ± 35 in-lb	145 ± 20 in-lb
3/8 - 16 UNC	35 ± 10 ft-lb	18 ± 3 ft-lb
1/2 - 13 UNC	75 ± 15 ft-lb	50 ± 10 ft-lb

Wheel Bolts and Lug Nuts

Thread Size	Recommended Torque**	
7/16 - 20 UNF Grade 5	65 ± 10 ft-lb	88 ± 14 N-m
1/2 - 20 UNF Grade 5	80 ± 10 ft-lb	108 ± 14 N-m
M12 X 1.25 Class 8.8	80 ± 10 ft-lb	108 ± 14 N-m
M12 X 1.5 Class 8.8	80 ± 10 ft-lb	108 ± 14 N-m

** For steel wheels and non-lubricated fasteners.

Thread Cutting Screws (Zinc Plated Steel)

Type 1, Type 23 or Type F	
Thread Size	Baseline Torque*
No. 6 - 32 UNC	20 ± 5 in-lb
No. 8 - 32 UNC	30 ± 5 in-lb
No. 10 - 24 UNC	38 ± 7 in-lb
1/4 - 20 UNC	85 ± 15 in-lb
5/16 - 18 UNC	110 ± 20 in-lb
3/8 - 16 UNC	200 ± 100 in-lb

Thread Cutting Screws (Zinc Plated Steel)

Thread Size	Threads per Inch		Baseline Torque*
	Type A	Type B	
No. 6	18	20	20 ± 5 in-lb
No. 8	15	18	30 ± 5 in-lb
No. 10	12	16	38 ± 7 in-lb
No. 12	11	14	85 ± 15 in-lb

* Hole size, material strength, material thickness and finish must be considered when determining specific torque values. All torque values are based on non-lubricated fasteners.

Conversion Factors

$$\text{in-lb} \times 11.2985 = \text{N-cm}$$

$$\text{ft-lb} \times 1.3558 = \text{N-m}$$

$$\text{N-cm} \times 0.08851 = \text{in-lb}$$

$$\text{N-m} \times 0.7376 = \text{ft-lb}$$



Yanmar Diesel Engine

Yanmar
Diesel Engine

Table of Contents

SPECIFICATIONS	2
Models 30603 and 30605	2
Models 30607 and 30609	3
GENERAL INFORMATION	5
Operator's Manuals	5
Yanmar Service and Troubleshooting Manuals ..	5
Stopping the Engine	5
Engine Electronic Control Unit (ECU)	6
Yanmar Engine: Models 30603 and 30605	7
Yanmar Engine: Models 30607 and 30609	8
SERVICE AND REPAIRS	10
Air Cleaner System	10
Fuel System	12
Check Fuel Lines and Connections	13
Empty and Clean Fuel Tank	13
Priming the Fuel System	13
Fuel Tank Removal	13
Fuel Tank Installation	13
Radiator and Oil Cooler Assembly	14
Engine	18
Engine Removal	19
Engine Installation	21
Spring Coupler	24
Exhaust System (Models 30607 and 30609) ...	26
YANMAR TNV (Tier 4i) SERIES SERVICE MANUAL	
YANMAR TNV (Tier 4i) SERIES TROUBLESHOOTING	
MANUAL	
YANMAR TNV (Tier 4) SERIES SERVICE MANUAL	
YANMAR TNV (Tier 4) SERIES TROUBLESHOOTING	
MANUAL	

Specifications (Models 30603 and 30605)

Item	Description
Make / Designation	Yanmar Model 4TNV84T-ZMTR: 4-Cycle, 4 Cylinder, Water Cooled, Turbocharged, Tier 4i Diesel Engine
Bore	3.307 in (84 mm)
Stroke	3.543 in (90 mm)
Total Displacement	121.7 in ³ (1995 cc)
Firing Order	1 (closest to flywheel end) - 3 - 4 (farthest from flywheel) - 2
Direction of Rotation	Counterclockwise (viewed from flywheel)
Fuel	Diesel or Biodiesel (up to B20) Fuel with Low or Ultra Low Sulfur Content
Fuel Tank Capacity	21 U.S. gallons (79.5 liters)
Fuel Injection Pump	Yanmar MP2 Distributor Type Pump
Fuel Injection Type	Direct Injection
Starting Aid	Intake Air Heater
Governor	Electronic All Speed
Low Idle (no load)	1200 RPM
High Idle (no load)	2600 RPM
Engine Oil	API CH-4, CI-4 or higher
Engine Oil Viscosity	See Operator's Manual
Crankcase Oil Capacity	6 U.S. quarts (5.7 liters) with Filter
Oil Pump	Trochoid Type
Coolant Capacity Groundsmaster 4000-D (Model 30605) Groundsmaster 4010-D (Model 30603)	9 U.S. quarts (8.5 liters) 14.5 U.S. quarts (13.7 liters)
Alternator/Regulator	12 VDC, 80 amp
Engine Weight (Dry)	375 U.S. pounds (170 kg)

Specifications (Models 30607 and 30609)

Item	Description
Make / Designation	Yanmar Model 4TNV86CT-DTR: 4-Cycle, 4 Cylinder, Water Cooled, Turbocharged, Tier 4 Diesel Engine
Bore	3.386 in (86 mm)
Stroke	3.543 in (90 mm)
Total Displacement	127.5 in ³ (2090 cc)
Firing Order	1 (closest to flywheel end) - 3 - 4 (farthest from flywheel) - 2
Direction of Rotation	Counterclockwise (viewed from flywheel)
Fuel	Diesel or Biodiesel (up to B7) Fuel with Ultra Low Sulfur Content
Fuel Capacity	21 U.S. gallons (79.5 liters)
Fuel Pump	Yanmar Supply Pump
Fuel Injection Type	Common Rail with Direct Injection
Governor	Electronic All Speed
Low Idle (no load)	1000 RPM
High Idle (no load)	2700 RPM
Engine Oil	API CJ-4 or higher
Engine Oil Viscosity	See Operator's Manual
Crankcase Oil Capacity	6 U.S. quarts (5.7 liters) with Filter
Oil Pump	Trochoid Type
Coolant Capacity Groundsmaster 4000-D (Model 30609) Groundsmaster 4010-D (Model 30607)	9 U.S. quarts (8.5 liters) 14.5 U.S. quarts (13.7 liters)
Alternator/Regulator (see NOTE below)	12 VDC, 80 Amp
Engine Weight (Dry)	496 U.S. pounds (225 kg)

NOTE: Groundsmaster 4000-D (Model 30609) machines with serial numbers below 314000000 are equipped with a 40 amp alternator.

This page is intentionally blank.

General Information

This Chapter gives information about specifications and repair of the diesel engine used in Groundsmaster 4000-D and 4010-D machines.

General maintenance procedures are described in your Operator's Manual. Information on engine troubleshooting, testing, disassembly and reassembly is identified in the Yanmar Service Manual.

Most repairs and adjustments require tools which are commonly available in many service shops. Special

tools are described in the Yanmar Service Manual. The use of some specialized test equipment is explained. However, the cost of the test equipment and the specialized nature of some repairs may dictate that the work be done at an engine repair facility.

Service and repair parts for Yanmar engines are supplied through your Authorized Toro Distributor. If no parts list is available, be prepared to provide your distributor with the Toro model and serial number of your machine.

Operator's Manuals

The Operator's Manual provides information regarding the operation, general maintenance and maintenance intervals for your Groundsmaster machine. The Yanmar Operator's Manual includes information specific to the engine used in your Groundsmaster. Refer to these publications for additional information when servicing the machine.

Yanmar Service and Troubleshooting Manuals

The engine that powers your Groundsmaster machine is either a Yanmar model 4TNV84T-Z (used on Groundsmaster models 30603 and 30605) (Tier 4i) or a Yanmar model 4TNV86CT (used on Groundsmaster models 30607 and 30609) (Tier 4). Both the Yanmar Service Manual and Yanmar Troubleshooting Manual are available for these engines. Make sure that the correct engine manuals are used when servicing the engine on your Groundsmaster.

Stopping the Engine

IMPORTANT: After mowing or full load operation on machines with a turbo-charged engine, cool the turbo-charger by allowing the engine to run at low idle speed for five (5) minutes before stopping the engine. Failure to do so may lead to turbo-charger trouble.

Engine Electronic Control Unit (ECU)

The Yanmar engine that powers your Groundsmaster uses an electronic control unit (ECU) for engine management and also to communicate with the machine TEC controllers and the operator Info Center display on the machine. All wire harness electrical connectors should be plugged into the engine ECU before the machine ignition switch is moved from the OFF position to either the ON or START position.

NOTE: On models 30607 and 30609, a ground wire is used to ground the engine ECU to the machine frame. The ground wire is connected to the ECU with one of the mounting screws and is connected to the frame at the engine mount.

The engine electrical components (e.g. engine ECU, fuel injectors, EGR, exhaust DPF) are identified and matched in the engine ECU program. If engine electrical components are replaced on the engine, the Yanmar electronic tool must be used to update the engine ECU program which will ensure correct engine operation.

If the engine ECU identifies that an engine problem exists, the engine speed may be reduced or the engine might stop. The Yanmar electronic tool and troubleshooting manual should be used to provide assistance in identifying the cause of the problem and the repairs that are necessary. Contact your Toro distributor for assistance in Yanmar engine troubleshooting.

IMPORTANT: Do not plug or unplug the engine ECU for a period of thirty (30) seconds after the machine key switch is turned OFF. The ECU may remain energized even though the ignition switch is OFF.

If the engine ECU is to be disconnected for any reason, make sure that the ignition switch is in the OFF position with the key removed before disconnecting the engine ECU. Also, to prevent possible ECU damage when welding on the machine, disconnect and remove the engine ECU from the machine before welding.




Figure 1

1. Electronic control unit (30603 / 30605)
2. Alternator




Figure 2

1. Electronic control unit (30607 / 30609)
2. Alternator

Yanmar Engine: Models 30603 and 30605

The engine used on Groundsmaster models 30603 and 30605 is a Yanmar TNV Series, turbocharged, diesel engine that complies with EPA interim Tier 4 emission regulations. Engine features include an electronic control unit (ECU) controlled direct fuel injection and electronic governor. An air heater in the intake system is used to assist starting the engine. Numerous engine sensors are used to allow the engine electronic control unit (ECU) to monitor and control engine operation for optimum engine performance.

During machine operation, if an engine fault occurs, the machine InfoCenter display can be used to identify the fault. Also, the Yanmar SMARTASSIST-Direct electronic control diagnostics service system is available to confirm real-time engine running status and to offer timely technical services.




Figure 3

Yanmar Engine: Models 30607 and 30609

The engine used on Groundsmaster models 30607 and 30609 is a Yanmar TNV Series, turbocharged, diesel engine that complies with EPA Tier 4 emission regulations. Engine features include an electronic control unit (ECU) that controls a common rail fuel injection system with direct injection, water-cooled exhaust gas recirculation (EGR), an electronic governor, an exhaust system diesel oxidation catalyst (DOC) and an exhaust diesel particulate filter (DPF) with active regeneration. Glow plugs are used to assist starting the engine. Numerous engine sensors are used to allow the engine ECU to monitor and control engine operation for optimum engine performance.

During machine operation, if an engine fault occurs, the machine InfoCenter display can be used to identify the fault. Also, the Yanmar SMARTASSIST-Direct electronic control diagnostics service system is available to confirm the real-time engine running status and to offer timely technical services.

The exhaust system DPF has four (4) modes for maintenance: passive regeneration, assist regeneration, reset regeneration and stationary regeneration.

Passive regeneration is the primary mode regeneration that occurs during normal operation. When the engine is running at normal loads, the exhaust temperature will keep the DPF above the minimum temperature for regeneration so normal particulate matter (PM) accumulation in the DPF is expected.

Assist regeneration occurs if the engine ECU senses that the DPF backpressure has increased to its maximum threshold. During assist regeneration, the intake throttle valve limits the air flow into the engine while the injectors add additional fuel. This process increases the DPF temperature which allows accumulated particulate to burn off, without changing the load on the engine. Burning of the accumulated PM decreases the pressure across the DPF. The assist regeneration is completed automatically when necessary. A small icon will be displayed on the InfoCenter during assist regeneration (Fig. 5) to inform the operator. The machine can continue to be used during an assist regeneration.

Reset regeneration takes place at a time interval (every 100 hours) to reset the baseline sensor readings in the DPF. The reset regeneration ensures that the engine is running at peak efficiency. During this mode, post injection is the means of increasing the DPF temperature. The reset regeneration is completed automatically when necessary. A small icon will be displayed on the InfoCenter during reset regeneration (Fig. 5) to inform the operator. The machine can continue to be used during a reset regeneration.




Figure 4




Figure 5

NOTE: If the engine is turned off during an assist or reset regeneration process, the regeneration will resume once the engine is restarted and required temperature level is reached.

Stationary regeneration is requested by the engine ECU if the assist and reset regenerations do not return the DPF particulate level to an acceptable level. During the stationary regeneration, the engine ECU controls engine speed, load and air/fuel mixture to perform a controlled burn of the particulate collected in the DPF. This type of regeneration is not a normal condition and may indicate that the DPF will require service soon, that an engine problem exists (e.g. incorrect engine fuel or oil) or that a DPF pressure sensor is failing. If a stationary regeneration is necessary, an advisory will occur on the InfoCenter and the necessary steps will be listed. A large icon will be displayed on the InfoCenter instead of the temperature gauge during stationary regeneration (Fig. 5). During the stationary regeneration process, the InfoCenter display will identify the percent completed during the process. The machine cannot be used during a stationary regeneration.

When the regeneration process is completed, the InfoCenter will remove the stationary regeneration icon and cease periodic regeneration messages. The engine will return to low idle speed with operator controls returned to normal.

IMPORTANT: A stationary regeneration should ONLY be initiated if an InfoCenter display advisory requests that this be done.

IMPORTANT: During a stationary regeneration, make sure that the machine is parked on a hard, level surface in a well ventilated area. This process runs the machine at a higher exhaust temperature for a period of approximately thirty (30) minutes to burn off collected particulate in the DPF.

Service and Repairs

Air Cleaner System




Figure 6

- 1. Air cleaner assembly
- 2. Tank support
- 3. Indicator
- 4. Adapter
- 5. Air cleaner strap
- 6. Flat washer (4 used)

- 7. Cap screw (2 used)
- 8. Lock nut (2 used)
- 9. Flat washer (2 used)
- 10. Lock nut (2 used)
- 11. Spring (2 used)
- 12. Flat washer (2 used)

- 13. Socket head screw (2 used)
- 14. Hose clamp
- 15. Air cleaner inlet hose
- 16. Hose clamp
- 17. Air cleaner outlet hose (tier 4)
- 18. Air cleaner outlet hose (tier 4i)

Removal (Fig. 6)

1. Park machine on a level surface, lower cutting decks, stop engine, apply parking brake and remove key from the ignition switch.
2. Raise and support hood.
3. Remove air cleaner components as needed using Figure 6 as a guide.

Installation (Fig. 6)

IMPORTANT: Any leaks in the air cleaner system will cause serious engine damage. Make sure that all air cleaner components are in good condition and are properly secured during assembly.

1. Assemble air cleaner system using Figure 6 as a guide.

A. If service indicator (item 4 in Fig. 6) and adapter (item 15 in Fig. 6) were removed from air cleaner housing, apply thread sealant to adapter threads before installing adapter and indicator to housing. Install adapter so that grooves in adapter hex and adapter filter element are installed toward service indicator (shown in Fig. 8). Torque indicator from **12 to 15 in-lb (1.4 to 1.6 N-m)**.

B. When installing air cleaner, orientate the vacuum valve on the air cleaner cover so that the valve is pointing in a downward position and between 5:00 to 7:00 (approximate clock position) when viewed from the end.

C. When securing air cleaner in air cleaner strap, tighten cap screws (item 14) only enough to prevent air cleaner from rotating in strap.

D. When installing air cleaner outlet hose between air cleaner and engine, position hose to allow maximum clearance between air cleaner hose and muffler bracket.

E. Make sure that air cleaner hoses do not contact the engine or exhaust system after assembly. To ensure clearance, move and/or rotate air cleaner body in air cleaner strap if necessary.

2. After all air cleaner components have been installed, lower and secure hood.




Figure 7

- | | |
|--------------------------|----------------------|
| 1. Air cleaner housing | 4. Air cleaner cover |
| 2. Safety filter element | 5. Vacuum valve |
| 3. Air filter element | |




Figure 8

- | | |
|-------------------------|------------|
| 1. Air cleaner assembly | 3. Adapter |
| 2. Service indicator | |

Fuel System




Figure 9

- | | | |
|----------------------------------|-----------------------------|--------------------------------|
| 1. Carriage screw (2 used) | 14. Fuel sender | 27. Lock nut (2 used) |
| 2. Retaining ring (2 used) | 15. Gasket | 28. Spring (2 used) |
| 3. Flat washer (2 used) | 16. Fuel cap | 29. Flat washer (2 used) |
| 4. Flange nut (6 used) | 17. Fuel supply hose | 30. Socket head screw (2 used) |
| 5. Vent hose | 18. Fuel return hose | 31. Indicator |
| 6. Fuel tank | 19. RH latch bracket | 32. Adapter |
| 7. Hose clamp (2 used) | 20. Tank support assembly | 33. Air cleaner assembly |
| 8. Elbow fitting (2 used) | 21. Flange nut (2 used) | 34. Air cleaner strap |
| 9. Stand pipe | 22. Fuel tank bracket | 35. Cap screw (2 used) |
| 10. Grommet (3 used) | 23. Carriage screw (2 used) | 36. Screw (4 used) |
| 11. Hose clamp | 24. Lock nut (2 used) | 37. LH latch bracket |
| 12. Lock washer (5 used) | 25. Flat washer (2 used) | 38. Cap screw (4 used) |
| 13. Phillips head screw (5 used) | 26. Flat washer (4 used) | |



DANGER

Because diesel fuel is flammable, use caution when storing or handling it. Do not smoke while filling the fuel tank. Do not fill fuel tank while engine is running, hot or when machine is in an enclosed area. Always fill fuel tank outside and wipe up any spilled diesel fuel before starting the engine. Store fuel in a clean, safety-approved container and keep cap in place. Use diesel fuel for the engine only; not for any other purpose.

Check Fuel Lines and Connections

Check fuel lines and connections periodically as recommended in the Operator's Manual. Check lines for deterioration, damage, leaking or loose connections. Replace hoses, clamps and connections as necessary.

Empty and Clean Fuel Tank

Empty and clean the fuel tank periodically as recommended in the Operator's Manual, if the fuel system becomes contaminated or if the machine is to be stored for an extended period.

IMPORTANT: Follow all local codes and regulations when recycling or disposing waste fuel.

To clean fuel tank, flush tank out with clean diesel fuel. Make sure tank is free of contaminants and debris.

Priming the Fuel System

The fuel system needs to be primed before starting the engine for the first time, after running out of fuel or after fuel system maintenance (e.g. draining the filter/water separator, replacing a fuel hose). To prime the fuel system, make sure that the fuel tank has fuel in it. Then, turn the ignition key to the RUN position for 10 to 15 seconds which allows the fuel pump to prime the fuel system. **DO NOT** use the engine starter motor to crank the engine in order to prime the fuel system.

Fuel Tank Removal (Fig. 9)

1. Park machine on a level surface, lower cutting decks, stop engine, apply parking brake and remove key from the ignition switch.
2. Raise and support operator seat and hood.
3. Use a fuel transfer pump to remove fuel from the fuel tank and into a suitable container.

NOTE: Fuel sender may have two (2) wire harness terminals (shown in Fig. 10) or a single harness connector.

4. Disconnect wire harness connections from the fuel sender (item 14).
5. Disconnect fuel supply, vent and return hoses from elbow fittings in top of tank (Fig. 10).
6. Remove fuel tank using Figure 9 as a guide. Tank is secured to frame with fasteners (items 1, 2, 3 and 4) on the forward side and bracket (item 22) on the rear side.

Fuel Tank Installation (Fig. 9)

1. Install fuel tank using Figure 9 as a guide. When securing tank to frame, follow the following sequence:
 - A. Loosely install fasteners on front of tank (items 1, 2, 3 and 4).
 - B. Install and tighten bracket (item 22) at rear of tank.
 - C. Torque two (2) flange nuts (item 4) from **60 to 80 in-lb (7 to 9 N-m)**.
2. Connect fuel supply hose to the standpipe and vent and return hoses to the elbow fittings (Fig. 10). Secure hoses with clamps.
3. Secure wire harness connector(s) to fuel sender. On senders with two (2) wire harness terminals, apply skin-over grease (see Special Tools in this chapter) to harness terminals after installation.
4. Lower and secure operator seat and hood.
5. Fill fuel tank with new fuel.
6. Prime the fuel system (see above).
7. Before returning machine to operation, make sure that no fuel leaks exist.




Figure 10

- | | |
|---------------------|----------------|
| 1. Fuel supply hose | 3. Return hose |
| 2. Vent hose | 4. Fuel sender |

Radiator and Oil Cooler Assembly




Figure 11

- | | | |
|-------------------------------|---------------------------|-----------------------------------|
| 1. LH radiator support | 13. Cap screw (2 used) | 25. Air cleaner inlet hose |
| 2. Cap screw (2 used) | 14. Hose | 26. Radiator/hydraulic oil cooler |
| 3. Flange nut (12 used) | 15. Coolant reservoir | 27. Bulb seal |
| 4. Hose clamp (3 used) | 16. Tank mount | 28. RH radiator support |
| 5. Hose | 17. Flat washer (7 used) | 29. Straight hydraulic fitting |
| 6. Flange nut (6 used) | 18. Cap screw (6 used) | 30. Intake bracket |
| 7. Foam plug (2 used) | 19. Lower radiator hose | 31. 90° hydraulic fitting |
| 8. Flange head screw (6 used) | 20. Hose clamp (4 used) | 32. Pipe plug |
| 9. Flange head screw (9 used) | 21. Upper radiator hose | 33. Hex plug with O-ring |
| 10. Foam strip | 22. Lower radiator shroud | 34. Foam pad (2 used) |
| 11. Hose bracket | 23. Upper radiator shroud | 35. Draincock |
| 12. R-clamp (2 used) | 24. Hose clamp | 36. Cap screw (2 used) |

Removal (Fig. 11)

1. Park machine on a level surface, lower cutting decks, stop engine, apply parking brake and remove key from the ignition switch. Open and support hood.

**CAUTION**

Do not open radiator cap or drain coolant if the radiator or engine is hot. Pressurized, hot coolant can escape and cause burns. Ethylene-glycol antifreeze is poisonous. Dispose of coolant properly or store it in a properly labeled container away from children and pets.

2. Drain radiator into a suitable container either by using the draincock (item 35) near the lower left side corner of the radiator or by removing the lower radiator hose from the radiator.

IMPORTANT: Follow all local codes and regulations when recycling or disposing engine coolant.

3. Disconnect radiator hoses from the radiator. Groundsmaster 4010-D machines with a Tier 4 compliant engine (model 30607) use the lower radiator hose assembly shown in Figure 12.

4. Remove air cleaner inlet hose (item 25).

5. Read the General Precautions for Removing and Installing Hydraulic System Components in the Service and Repairs section of Chapter 4 - Hydraulic System.

6. Thoroughly clean hydraulic lines at lower radiator shroud (Fig. 13) and oil cooler ports (Fig. 14). Disconnect hydraulic lines and put caps or plugs on lines to prevent contamination. Label disconnected hydraulic lines for proper installation.

7. Disconnect hood rods from hood and radiator supports (see Hood in the Service and Repairs section of Chapter 7 - Chassis).

8. Remove flange head screws (item 8) and flange nuts (item 6) that secure the radiator supports (items 1 and 28) to the frame.

9. Carefully raise radiator assembly with shrouds, fan motor assembly and supports from the machine.

10. Disassemble radiator/oil cooler assembly as needed using Figures 11 and 13 as guides.

11. If necessary, remove hydraulic fittings (items 29 and 31) from oil cooler and discard O-rings.

12. Plug all radiator and hose openings to prevent contamination.




Figure 12

- | | |
|------------------------|---------------------|
| 1. Radiator/oil cooler | 4. Radiator fitting |
| 2. Lower radiator hose | 5. Hose clamp |
| 3. Hose clamp | 6. Radiator hose |




Figure 13

- | | |
|---------------------------|--------------------------|
| 1. Radiator/oil cooler | 4. Flange nut (6 used) |
| 2. Motor and fan assembly | 5. Lower radiator shroud |
| 3. Cap screw (6 used) | |

Installation (Fig. 11)

1. Inspect seals (items 7, 10, 27 and 34) around radiator location for wear or damage. Replace seals if necessary.

2. Remove all plugs placed during the removal procedure.

3. If hydraulic fittings (items 29 and 31) were removed from oil cooler, lubricate and place new O-rings onto fittings. Install fittings into port openings and tighten fittings (see Hydraulic Fitting Installation in the General Information section of Chapter 4 - Hydraulic System).

4. Assemble radiator/oil cooler using Figures 11 and 13 as guides.

A. If fan motor bracket was removed, position bracket as far as possible from radiator to maximize distance between radiator and fan motor location.

B. Make sure that clearance between radiator shrouds and cooling fan is at least **0.180" (4.6 mm)** at all points.

5. Carefully lower radiator assembly with shrouds, fan motor assembly and supports to the machine frame.

6. Secure radiator supports (items 1 and 28) to the frame with flange head screws (item 8) and flange nuts (item 6).

7. Connect hydraulic lines to fittings in oil cooler ports (Fig. 14) and at lower radiator shroud (Fig. 13) (see Hydraulic Hose and Tube Installation in the General Information section of Chapter 4 - Hydraulic System).

8. Connect upper and lower radiator hoses to the radiator.

9. Install and secure air cleaner inlet hose (item 25).

10. Make sure radiator draincock is closed. Fill radiator with coolant.

11. Connect hood rods to radiator supports and hood (see Hood in the Service and Repairs section of Chapter 7 - Chassis).

12. Close and secure hood.




Figure 14

- | | |
|------------------------|-------------------|
| 1. Radiator/oil cooler | 4. 90° fitting |
| 2. Straight fitting | 5. Hydraulic hose |
| 3. Hydraulic tube | 6. Hydraulic tube |

This page is intentionally blank.

Engine




Figure 15

- | | | |
|----------------------------------|----------------------------------|--------------------------|
| 1. Engine (model 30603 shown) | 9. Engine mount bracket (2 used) | 16. Exhaust pipe |
| 2. Cap screw (4 used) | 10. Cap screw (14 used) | 17. Wire harness bracket |
| 3. Rebound washer (4 used) | 11. Lock washer (18 used) | 18. Cap screw (3 used) |
| 4. Flange nut (12 used) | 12. Cap screw (2 used) | 19. Wire harness bracket |
| 5. Engine mount (4 used) | 13. Exhaust bracket | 20. Lock washer (2 used) |
| 6. Cap screw (2 used per mount) | 14. Cap screw (2 used) | 21. Cap screw (2 used) |
| 7. Engine mount bracket (2 used) | 15. Flange nut (2 used) | 22. Clamp assembly |
| 8. Lock washer | | |

Engine Removal (Fig. 15)

1. Park machine on a level surface, lower cutting decks, stop engine, apply parking brake and remove key from the ignition switch.
2. Disconnect negative battery cable from battery terminal and then disconnect positive cable from battery (see Battery Service in the Service and Repairs section of Chapter 5 - Electrical System).
3. Raise and support hood.



CAUTION

Do not open radiator cap or drain coolant if the radiator or engine is hot. Pressurized, hot coolant can escape and cause burns. Ethylene-glycol antifreeze is poisonous. Dispose of coolant properly or store it in a properly labeled container away from children and pets.

4. Drain coolant from the radiator into a suitable container (see Radiator and Oil Cooler Assembly in this section). Disconnect upper and lower hoses from the radiator.
5. Remove air cleaner assembly from engine (see Air Cleaner System in this section).
6. Remove exhaust pipe (item 16 in Fig. 15) and exhaust bracket (item 13 in Fig. 15 or item 6 in Fig. 20) from engine.
7. Note location of cable ties used to secure wire harness to the machine. Disconnect wires and/or electrical connections from the following electrical components:
 - A. The engine wire harness from the machine wire harness.
 - B. The positive battery cable from the engine starter motor (Fig. 16).
 - C. The fusible link harness from the main wire harness (Fig. 16).
 - D. The negative battery cable at the engine block (Fig. 16).

8. Carefully disconnect engine wire harness connector from engine ECU.

9. Disconnect fuel supply and return hoses from engine (Fig. 17 or 18). Position fuel hoses away from engine.

10. Remove fasteners that secure the coolant reservoir tank mount to the radiator and radiator shrouds (Fig. 19). Position and support coolant reservoir with mount away from the engine.

Groundsmaster 4000-D/4010-D




Figure 16

1. Positive battery cable
2. Negative battery cable
3. Fusible link harness




Figure 17

1. Tier 4 engine
2. Hose clamp
3. Fuel supply hose
4. Hose clamp
5. Fuel return hose
6. Front lift bracket




Figure 18

1. Tier 4i engine
2. Hose clamp
3. Fuel supply hose
4. Hose clamp
5. Fuel return hose

11. On machines with a Tier 4 compliant engine (models 30607 and 30609):

A. Remove fuel tank to allow engine to be raised from machine (see Fuel System in this section).

B. Install lift bracket to front of engine cylinder head (item 6 in Fig. 17). Front lift bracket was included with new machine or is available as a service part (refer to parts catalog for part number).

12. On Groundsmaster 4010-D machines:

A. Remove air conditioning compressor from compressor mount (see Air Conditioning Compressor in the Service and Repairs section of Chapter 9 - Operator Cab). Position compressor away from engine taking care to not damage compressor or AC hoses. Support compressor to make sure it will not fall during engine removal.

B. Disconnect coolant hoses from fittings on engine water flange. On Groundsmaster 4010-D machines with a Tier 4 compliant engine (model 30607), disconnect coolant hose from fitting on lower radiator hose assembly. Label coolant hoses for proper assembly.

IMPORTANT: The hydraulic pump assembly can remain in machine during engine removal. To prevent pump from shifting or falling, make sure to support pump assembly before the fasteners that secure pump assembly to engine are removed.

13. Support hydraulic pump assembly. Remove fasteners that secure pump assembly to engine (see Pump Assembly in the Service and Repairs section of Chapter 4 - Hydraulic System).

14. Note location of all cable ties securing the wire harness, fuel lines and hydraulic hoses to the engine for assembly purposes. Remove cable ties as needed for engine removal.

15. Connect lift or hoist to the lift brackets on engine.

16. Remove flange nuts, rebound washers and cap screws that secure the engine mount brackets to the engine mounts.




Figure 19

- 1. Radiator/oil cooler
- 2. Tank Mount
- 3. Coolant reservoir




Figure 20

- 1. Exhaust pipe
- 2. Flange screw (2 used)
- 3. Flange nut
- 4. Idler pulley
- 5. Carriage screw
- 6. Exhaust bracket
- 7. Compressor mount
- 8. Cap screw (2 used)
- 9. Cap screw (4 used)
- 10. Lock washer
- 11. Cap screw (3 used)
- 12. Pulley



CAUTION

One person should operate lift or hoist while a second person guides the engine out of the machine.

IMPORTANT: Make sure to not damage the engine, radiator assembly, fuel lines, hydraulic lines, electrical wire harness or other components while removing the engine.

17. Slowly move the engine assembly away from the hydraulic pump assembly to allow the pump input shaft to slide out of the spring coupler on the engine flywheel. Once the engine has cleared the pump input shaft, carefully remove the engine from the machine.

18. If necessary, remove engine mount brackets from the engine using Figure 15 or 20 as a guide.

Engine Installation (Fig. 15)

1. Make sure that all parts removed from the engine during maintenance or rebuilding are installed to the engine.
2. If removed, install engine mount brackets to the engine using Figure 15 or 20 as a guide.
3. Connect lift or hoist to the engine lift brackets.



CAUTION

One person should operate lift or hoist while a second person guides the engine into the machine.

IMPORTANT: Make sure to not damage the engine, radiator assembly, fuel lines, hydraulic lines, electrical wire harness or other components while installing the engine.

4. Carefully lower engine into the machine. Slowly move the engine assembly toward the hydraulic pump assembly to allow the pump input shaft to slide into the spring coupler on the engine flywheel.

5. Align engine to the engine mounts. Secure engine to engine mounts with cap screws, rebound washers and flange nuts.

6. Secure hydraulic pump assembly to engine (see Pump Assembly in the Service and Repairs section of Chapter 4 - Hydraulic System).

7. On machines with a Tier 4 compliant engine (models 30607 and 30609):

A. Remove lift bracket from front of engine cylinder head (item 6 in Fig. 17). The bracket must be removed before fuel tank installation. Retain lift bracket and fasteners for future use.

B. Install and secure fuel tank to machine (see Fuel System in this section).

8. Position coolant reservoir with mount to the radiator. Secure reservoir tank mount to the radiator and radiator shrouds with removed fasteners.

9. Connect fuel supply and return hoses to the engine fittings (Fig. 17 or 18).

10. On Groundsmaster 4010-D machines:

A. Install air conditioning compressor to compressor mount (see Air Conditioning Compressor Installation in the Service and Repairs section of Chapter 9 - Operator Cab). Make sure that drive belt is properly tensioned.

B. Connect coolant hoses to fittings on engine water flange.

11. Connect wires and/or electrical connections to engine locations.

A. The engine wire harness from the machine wire harness.

B. The positive battery cable from the engine starter motor (Fig. 16).

C. The fusible link harness from the main wire harness (Fig. 16).

D. The negative battery cable at the engine block (Fig. 16).

12. Carefully connect engine wire harness connector to engine ECU.

13. Install and secure exhaust bracket (item 13 in Fig. 15 or item 6 in Fig. 20) and exhaust pipe (item 16 in Fig. 15) from engine.

14. Install air cleaner assembly to the engine (see Air Cleaner System in this section).

15. Connect coolant hoses to the radiator. Make sure radiator draincock is closed. Fill radiator and coolant reservoir with coolant.

16. Secure the wire harness, fuel lines and hydraulic hoses to the engine with cable ties as noted during engine removal.

17. Check position of electrical wires, fuel lines and hydraulic lines for proper clearance with rotating, high temperature and moving components.

18. Connect positive battery cable to positive battery terminal first and then connect negative cable to battery (see Battery Service in the Service and Repairs section of Chapter 5 - Electrical System).

19. Check and adjust engine oil as needed.

20. Check and adjust oil level in hydraulic reservoir as needed.

21. Prime the fuel system (see Fuel System in this section).

22. Start engine and operate hydraulic controls to properly fill hydraulic system (see Charge Hydraulic System in the Service and Repairs section of Chapter 4 - Hydraulic System).

23. Close and secure hood.

This page is intentionally blank.

Spring Coupler




Figure 21

- 1. Cap screw (8 used)
- 2. Washer (8 used)
- 3. Flywheel plate

- 4. Cap screw (8 used)
- 5. Washer (8 used)

- 6. Spring coupler
- 7. Engine (model 30603/30605 shown)

Coupler Removal (Fig. 21)

NOTE: The hydraulic pump assembly needs to be removed from engine before coupler can be removed.

1. If engine is in machine, remove hydraulic pump assembly from machine (see Piston (Traction) Pump Removal in the Service and Repairs section of Chapter 4 – Hydraulic System).
2. Remove flywheel plate and spring coupler from engine using Figure 21 as a guide.

Coupler Installation (Fig. 21)

1. Position spring coupler to engine flywheel and align mounting holes. Make sure that coupling hub is away from engine flywheel (Fig. 22).
2. Secure coupler to flywheel with eight (8) cap screws and washers. Torque cap screws in a crossing pattern from **29 to 33 ft-lb (40 to 44 N-m)**.
3. Position flywheel plate to engine. Secure flywheel plate with eight (8) cap screws (item 1) and washers using a crossing pattern tightening procedure. Torque cap screws in a crossing pattern from **28 to 32 ft-lb (38 to 43 N-m)**.
4. If engine is in machine, install hydraulic pump assembly to machine (see Piston (Traction) Pump Installation in the Service and Repairs section of Chapter 4 – Hydraulic System).




Figure 22

1. Coupler

2. Engine flywheel

Exhaust System (Models 30607 and 30609)




Figure 23

- | | | |
|--|--|---|
| <ul style="list-style-type: none"> 1. Gasket 2. Exhaust assembly stay 3. Exhaust assembly stay 4. Exhaust assembly stay 5. Exhaust assembly stay 6. Nut 7. DOC temp sensor (inlet) 8. DOC temp sensor (outlet) 9. Nut (4 used) 10. DOC assembly 11. Nut (3 used) 12. DPF assembly 13. Nut 14. Outlet flange 15. DPF gasket (2 used) | <ul style="list-style-type: none"> 16. Bolt (20 used) 17. DPF lifter 18. DPF stiffener (5 used) 19. DPF stiffener 20. DPF stiffener 21. DPF stiffener 22. Bolt (2 used) 23. Nut (20 used) 24. Bolt (2 used) 25. Pipe joint bolt (2 used) 26. Exhaust pressure pipe (DPF inlet) 27. Sensor gasket (4 used) 28. Exhaust pressure pipe (DPF outlet) 29. Exhaust hose 30. Bolt (2 used) | <ul style="list-style-type: none"> 31. Hose clip (2 used) 32. Hose 33. Bolt (3 used) 34. Hose clip (2 used) 35. Pressure sensor 36. Sensor bracket 37. Bolt (2 used) 38. Bolt (2 used) 39. Clip band 40. Band 41. Connector clip (2 used) 42. Bolt (2 used) 43. Bolt (2 used) 44. Bolt (2 used) |
|--|--|---|

Groundsmaster models that are powered by a diesel engine that complies with EPA Tier 4 emission regulations are equipped with an exhaust system that includes a diesel oxidation catalyst (DOC) and a diesel particulate filter (DPF). These exhaust components require service or component replacement at intervals identified in your Operator's Manual. Additionally, the exhaust assembly uses two (2) temperature sensors and a pressure differential sensor which are used as inputs for the engine ECU to monitor the operation of the exhaust system.

The diesel particulate filter (DPF) is cleaned periodically through a regenerative process that is controlled by the engine ECU (see Yanmar Engine: Models 30607 and 30609 in the General Information section of this chapter). The InfoCenter display will identify the status of DPF regeneration. At recommended intervals, DPF reconditioning is necessary which will require exhaust system disassembly, DPF removal and DPF reconditioning by a company that has the necessary equipment. Once the DPF has gone through the reconditioning process, it can be re-installed in the exhaust system. Contact your Toro Distributor for information on reconditioning the DPF.

The diesel oxidation catalyst (DOC) has a service life expectancy and requires replacement at recommended intervals. Replacement of the DOC will require exhaust system disassembly, removal of the existing DOC and installation of the new DOC.

Refer to the Parts Catalog to identify individual components for the exhaust system on your Groundsmaster.

Removal (Figs. 23 and 24)

NOTE: The exhaust system DPF and DOC can be removed from the exhaust system without removing the entire exhaust from the engine. Certain engine service procedures (e.g. rocker cover removal for valve clearance adjustment) will require removal of the exhaust system assembly.

CAUTION

The muffler and exhaust pipe may be hot. To avoid possible burns, allow the engine and exhaust system to cool before working on the exhaust system.

1. Raise and support hood to gain access to exhaust system. Allow engine and exhaust to cool before doing any disassembly of exhaust system components.

2. Remove exhaust system components from the engine as necessary using Figure 23 and 24 as guides. Discard all removed gaskets (items 1 and 15 in Fig. 23 or item 6 in Fig. 24).

Installation (Figs. 23 and 24)

NOTE: Make sure that all exhaust system flanges and sealing surfaces are free of debris or damage that may prevent a tight seal.

1. Make sure to install **new** gaskets in place of all gaskets that were removed. Do not use any type of gasket sealant on gasket or flange surfaces.

2. Assemble all removed exhaust system components using Figure 23 and 24 as guides.

A. If exhaust sensors (items 7 and 8 in Fig. 23) were removed, torque sensors from **19 to 29 ft-lb (25 to 40 N-m)**.

B. If exhaust pressure pipes (items 26 and 28 in Fig. 23) were removed, replace sensor gaskets (item 27) on both sides of the pressure pipe fitting.

C. If DPF stiffeners (items 18, 19, 20 and 21 in Fig. 23) were loosened or removed, tighten fasteners that secure stiffeners before tightening fasteners that secure exhaust system to DPF stays.




Figure 24

- | | |
|-------------------|------------------------|
| 1. Engine | 4. Flange nut (4 used) |
| 2. Exhaust pipe | 5. Exhaust flange |
| 3. Clamp assembly | 6. Exhaust gasket |

This page is intentionally blank.



Hydraulic System

Hydraulic System

Table of Contents

SPECIFICATIONS	3	Check Hydraulic Lines and Hoses	72
GENERAL INFORMATION	4	Priming Hydraulic Pumps	72
Operator's Manual	4	Flush Hydraulic System	73
Check Hydraulic Fluid	4	Filtering Closed-Loop Traction Circuit	74
Relieving Hydraulic System Pressure	4	Charge Hydraulic System	75
Towing Traction Unit	5	Hydraulic Reservoir	76
Traction Circuit Component Failure	5	Radiator and Oil Cooler Assembly	78
Hydraulic Hoses	6	Gear Pump	80
Hydraulic Hose and Tube Installation	7	Gear Pump Service	84
Hydraulic Fitting Installation	8	Piston (Traction) Pump	86
HYDRAULIC SCHEMATIC	10	Piston (Traction) Pump Service	90
HYDRAULIC FLOW DIAGRAMS	12	Rear Axle Motor	92
Traction Circuit: LOW Speed (Mow)	12	Front Wheel Motors	94
Traction Circuit: HI Speed (Transport)	14	Rear Axle and Front Wheel Motor Service	96
Lower Cutting Deck Circuit	16	Rear Traction Manifold	98
Raise Cutting Deck Circuit	18	Rear Traction Manifold Service	100
Mow Circuit	20	Front Traction Manifold	102
Mow Circuit Cutting Deck Blade Braking	22	Front Traction Manifold Service	104
Steering Circuit	24	Combination Manifold	106
Engine Cooling Fan Circuit	26	Combination Manifold Service	108
SPECIAL TOOLS	28	Control Manifold Cartridge Valve Service	110
TROUBLESHOOTING	33	Steering Control Valve	112
TESTING	40	Steering Control Valve Service	114
Traction Circuit Charge Pressure	42	Steering Cylinder	116
Traction Circuit Relief Pressure	44	Steering Cylinder Service	118
Counterbalance Pressure	46	Engine Cooling Fan Motor	120
Reverse Traction Circuit Reducing Valve (PR) Pressure	48	Engine Cooling Fan Motor Service	124
Rear Traction Circuit Relief Valve (RV) Pressure	50	Cutting Deck Motors	127
Piston (Traction) Pump Flow	52	Cutting Deck Motor Service (Sauer-Danfoss) .	128
Cutting Deck Circuit Pressure	54	Cutting Deck Motor Service (Casappa)	132
PTO Relief Pressure	56	PTO Manifold	134
Cutting Deck Motor Case Drain Leakage	58	PTO Manifold Service	136
Lift/Lower Circuit Relief Pressure	60	Side Deck Lift Cylinders	138
Steering Circuit Relief Pressure	62	Center Deck Lift Cylinders	140
Steering Cylinder Internal Leakage	64	Lift Cylinder Service	142
Engine Cooling Fan Circuit	66	SAUER-DANFOSS H1 CLOSED CIRCUIT AXIAL PIS- TON PUMPS SERVICE MANUAL	
Gear Pump Flow	68	SAUER-DANFOSS K and L FRAME VARIABLE MO- TORS SERVICE MANUAL	
ADJUSTMENTS	70	EATON PARTS AND REPAIR INFORMATION: 5 SERIES STEERING CONTROL UNITS	
Adjust Control Manifold Relief Valves	70		
SERVICE AND REPAIRS	71		
General Precautions for Removing and Installing Hydraulic System Components	71		

This page is intentionally blank.

Specifications

Item	Description
Piston (Traction) Pump Maximum Displacement (per revolution) System Relief Pressure: Forward System Relief Pressure: Reverse Charge Pressure	Sauer-Danfoss Variable Displacement Axial Piston Pump 2.75 in ³ (45 cc) 4350 PSI (300 bar) 5000 PSI (345 bar) 250 PSI (17 bar)
Front Wheel Motors Displacement (per revolution)	Sauer-Danfoss 2-Position Axial Piston Motors 1.19 in ³ (19.55 cc) Maximum / 0.64 in ³ (10.55 cc) Minimum
Rear Axle Motor Displacement (per revolution)	Sauer-Danfoss 2-Position Axial Piston Motor with Loop Flushing Valve 2.14 in ³ (35.00 cc) Maximum / 1.16 in ³ (18.99 cc) Minimum
Gear Pump Section P1/P2 Displacement (per revolution) Section P3 Displacement (per revolution) Section P4 Displacement (per revolution)	Casappa 4 Section, Positive Displacement Gear pump 1.29 in ³ (21.14 cc) 0.40 in ³ (6.6 cc) 0.30 in ³ (4.96 cc)
Steering Control Valve Displacement (per revolution)	Eaton Steering Unit, Series 5 6.1 in ³ (100 cc)
Steering Circuit Relief Pressure	1350 PSI (93 bar)
Lift/Lower Circuit Relief Pressure	1600 PSI (110 bar)
Cutting Deck Motors Displacement (per revolution)	Gear Motor 1.17 in ³ (19.2 cc)
PTO Circuit Relief Pressure Front and Left Side Right Side	3000 PSI (207 bar) 2000 PSI (138 bar)
Engine Cooling Fan Motor Displacement (per revolution)	Casappa Gear Motor 0.51 in ³ (8.4 cc)
Engine Cooling Fan Circuit Relief Pressure	3250 PSI (224 bar)
Hydraulic Filters In-line Suction Strainer	Spin-on Cartridge Type 100 Mesh (In Reservoir)
Hydraulic Reservoir	7.75 U.S. Gallons (29.3 Liters)
Hydraulic Oil	See Operator's Manual

NOTE: The pressure specifications listed above are component settings. When using pressure gauges to measure circuit pressures, values may be different than these specifications. See the Testing section of this chapter for hydraulic test procedures and expected test results.

General Information

Operator's Manual

The Operator's Manual provides information regarding the operation, general maintenance and maintenance intervals for your Groundsmaster machine. Refer to that publication for additional information when servicing the machine.

Check Hydraulic Fluid

The Groundsmaster hydraulic system is designed to operate on anti-wear hydraulic fluid. The hydraulic reservoir located beneath the operator seat holds approximately **7.75 U.S. gallons (29.3 liters)** of hydraulic fluid. **Check level of hydraulic fluid daily.** See Operator's Manual for fluid level checking procedure and oil recommendations.




Figure 1

1. Hydraulic reservoir
2. Reservoir cap

Relieving Hydraulic System Pressure

Before disconnecting or performing any work on the hydraulic system, all pressure in the hydraulic system must be relieved. Park machine on a level surface, make sure that PTO switch is OFF, lower cutting decks fully, stop engine and engage parking brake. Wait for all moving parts to come to a complete stop.

System pressure in lift circuit is relieved when the cutting decks are fully lowered.

System pressure in mow circuit is relieved when the PTO switch is disengaged.

To relieve hydraulic pressure in traction circuit, turn ignition switch to ON (engine not running) and move traction pedal to both forward and reverse directions. Turn ignition switch to OFF after relieving traction circuit pressure.

To relieve hydraulic pressure in steering circuit, rotate steering wheel in both directions.

After all hydraulic system pressures have been relieved, remove key from ignition switch.

Towing Traction Unit

IMPORTANT: If towing limits are exceeded, severe damage to the piston (traction) pump may occur.

If it becomes necessary to tow (or push) the machine, tow (or push) in a **forward direction only** and at a speed **below 3 mph (5 kph)**. The piston (traction) pump relief valves (both forward and reverse) need to be loosened three (3) revolutions to allow the machine to be moved (Fig. 2). To prevent leakage from relief valves, do not loosen them more than three (3) revolutions. Refer to your Operator's Manual for additional towing instructions.

IMPORTANT: Do not loosen relief valves when engine is running.

Before returning machine to service, tighten both of the relief valves until seated. Then, torque relief valves to **52 ft-lb (70 N-m)**.

IMPORTANT: If the machine must be pushed or towed in reverse, the check valve in the rear traction manifold must also be bypassed. To bypass this check valve, connect a hydraulic hose assembly to the reverse traction pressure test port, located on the piston (traction) pump, and on the port located in-between ports M8 and P2 on the rear traction manifold which is located behind the front tire. Use Toro part numbers 95-8843 (hydraulic hose), 95-0985 (quantity 2) (coupler fitting) and 340-77 (quantity 2) (hydraulic fitting).




Figure 2

1. Piston pump
2. Relief valve (forward)
3. Relief valve (reverse)

Traction Circuit Component Failure

The traction circuit on Groundsmaster 4000-D and 4010-D machines is a closed loop system that includes the piston (traction) pump, two (2) front wheel motors and the rear axle motor. If a component in the traction circuit should fail, debris and contamination from the failed component will circulate throughout the traction circuit. This contamination can damage other components in the circuit so it must be removed to prevent additional component failure.

The recommended method of removing traction circuit contamination would be to temporarily install the Toro high flow hydraulic filter (see Special Tools in this chapter) into the circuit. This filter should be used when connecting hydraulic test gauges in order to test traction circuit components or after replacing a failed traction circuit component (e.g. traction (piston) pump or wheel motor). The filter will ensure that contaminants are removed from the closed loop and thus, do not cause additional component damage.

Once the Toro high flow hydraulic filter kit has been placed in the circuit, raise and support the machine with all wheels off the ground. Then, operate the traction circuit to allow oil flow throughout the circuit. The filter will remove contamination from the traction circuit during operation. Because the Toro high flow filter is bi-directional, the traction circuit can be operated in both the forward and reverse direction. The filter should be removed from the machine after contamination has been removed from the traction circuit. See Filtering Closed-Loop Traction Circuit in the Service and Repairs section of this chapter for additional information on using the Toro high flow hydraulic filter.

The alternative to using the Toro high flow hydraulic filter kit after a traction circuit component failure would be to disassemble, drain and thoroughly clean all components, hydraulic tubes and hydraulic hoses in the traction circuit. If any debris remains in the traction circuit and the machine is operated, the debris can cause additional circuit component failure.

Hydraulic Hoses

Hydraulic hoses are subject to extreme conditions such as pressure differentials during operation and exposure to weather, sun, chemicals, very warm storage conditions or mishandling during operation and maintenance. These conditions can cause hose damage and deterioration. Some hoses are more susceptible to these conditions than others. Inspect all machine hydraulic hoses frequently for signs of deterioration or damage:

Hard, cracked, cut, abraded, charred, leaking or otherwise damaged hose.

Kinked, crushed, flattened or twisted hose.

Blistered, soft, degraded or loose hose cover.

Cracked, damaged or badly corroded hose fittings.

When replacing a hydraulic hose, be sure that the hose is straight (not twisted) before tightening the fittings. This can be done by observing the imprint (layline) on the hose. Use two (2) wrenches when tightening a hose; hold the hose straight with one wrench and tighten the hose swivel nut onto the fitting with the second wrench (see Hydraulic Hose and Tube Installation in this section). If the hose has an elbow at one end, tighten the swivel nut on that end before tightening the nut on the straight end of the hose.

For additional hydraulic hose information, refer to Toro Service Training Book, Hydraulic Hose Servicing (Part Number 94813SL).



WARNING

Before disconnecting or performing any work on hydraulic system, relieve all pressure in system (see Relieving Hydraulic System Pressure in this section).

Keep body and hands away from pin hole leaks or nozzles that eject hydraulic fluid under high pressure. Use paper or cardboard, not hands, to search for leaks. Hydraulic fluid escaping under pressure can have sufficient force to penetrate the skin and cause serious injury. If fluid is injected into the skin, it must be surgically removed within a few hours by a doctor familiar with this type of injury. Gangrene may result from such an injury.

Hydraulic Hose and Tube Installation (O-Ring Face Seal Fitting)

1. Make sure threads and sealing surfaces of the hose/tube and the fitting are free of burrs, nicks, scratches or any foreign material.

2. As a preventative measure against leakage, it is recommended that the face seal O-ring be replaced any time the connection is opened. Make sure the O-ring is installed and properly seated in the fitting groove. Lightly lubricate the O-ring with clean hydraulic oil.

3. Place the hose/tube against the fitting body so that the flat face of the hose/tube sleeve fully contacts the O-ring in the fitting.

4. Thread the swivel nut onto the fitting by hand. While holding the hose/tube with a wrench, use a torque wrench to tighten the swivel nut to the recommended installation torque shown in Figure 5. This tightening process will require the use of an offset wrench (e.g. crowfoot wrench). Use of an offset wrench will affect torque wrench calibration due to the effective length change of the torque wrench. Tightening torque when using a torque wrench with an offset wrench will be lower than the listed installation torque (see Using a Torque Wrench with an Offset Wrench in the Torque Specifications section of Chapter 2 - Product Records and Maintenance).

5. If a torque wrench is not available or if space at the swivel nut prevents use of a torque wrench, an alternate method of assembly is the Flats From Wrench Resistance (F.F.W.R.) method (Fig. 2).

A. Using a wrench, tighten the swivel nut onto the fitting until light wrench resistance is reached (approximately 30 in-lb).

B. Mark the swivel nut and fitting body. Hold the hose/tube with a wrench to prevent it from turning.

C. Use a second wrench to tighten the nut to the correct Flats From Wrench Resistance (F.F.W.R.). The markings on the nut and fitting body will verify that the connection has been properly tightened.

Size	F.F.W.R.
4 (1/4 in. nominal hose or tubing)	1/2 to 3/4
6 (3/8 in.)	1/2 to 3/4
8 (1/2 in.)	1/2 to 3/4
10 (5/8 in.)	1/2 to 3/4
12 (3/4 in.)	1/3 to 1/2
16 (1 in.)	1/3 to 1/2




Figure 3




Figure 4

Fitting Dash Size	Hose/Tube Side Thread Size	Installation Torque
4	9/16 - 18	18 to 22 ft-lb (25 to 29 N-m)
6	11/16 - 16	27 to 33 ft-lb (37 to 44 N-m)
8	13/16 - 16	37 to 47 ft-lb (51 to 63 N-m)
10	1 - 14	60 to 74 ft-lb (82 to 100 N-m)
12	1 3/16 - 12	85 to 105 ft-lb (116 to 142 N-m)
16	1 7/16 - 12	110 to 136 ft-lb (150 to 184 N-m)
20	1 11/16 - 12	140 to 172 ft-lb (190 to 233 N-m)

Figure 5

Hydraulic Fitting Installation (SAE Straight Thread O-Ring Fitting into Component Port)

Non-Adjustable Fitting (Fig. 6)

1. Make sure all threads and sealing surfaces of fitting and component port are free of burrs, nicks, scratches or any foreign material.
2. As a preventative measure against leakage, it is recommended that the O-ring be replaced any time the connection is opened.
3. Lightly lubricate the O-ring with clean hydraulic oil. Fitting threads should be clean with no lubricant applied.

IMPORTANT: Before installing fitting into port, determine port material. If fitting is to be installed into an aluminum port, installation torque is reduced.

4. Install the fitting into the port. Then, use a torque wrench and socket to tighten the fitting to the recommended installation torque shown in Figure 7.

NOTE: Use of an offset wrench (e.g. crowfoot wrench) will affect torque wrench calibration due to the effective length change of the torque wrench. Tightening torque when using a torque wrench with an offset wrench will be less than the recommended installation torque. See Using a Torque Wrench with an Offset Wrench in the Torque Specifications section of Chapter 2 - Product Records and Maintenance to determine necessary conversion information.

5. If a torque wrench is not available, or if space at the port prevents use of a torque wrench, an alternate method of assembly is the Flats From Finger Tight (F.F.F.T.) method.

A. Install the fitting into the port and tighten it down full length until finger tight.

B. If port material is steel, tighten the fitting to the listed F.F.F.T. If port material is aluminum, tighten fitting to 60% of listed F.F.F.T.

Size	F.F.F.T.
4 (1/4 in. nominal hose or tubing)	1.00 ± 0.25
6 (3/8 in.)	1.50 ± 0.25
8 (1/2 in.)	1.50 ± 0.25
10 (5/8 in.)	1.50 ± 0.25
12 (3/4 in.)	1.50 ± 0.25
16 (1 in.)	1.50 ± 0.25




Figure 6

Fitting Dash Size	Fitting Port Side Thread Size	Installation Torque Into Steel Port	Installation Torque Into Aluminum Port
4	7/16 - 20	15 to 19 ft-lb (21 to 25 N-m)	9 to 11 ft-lb (13 to 15 N-m)
5	1/2 - 20	18 to 22 ft-lb (25 to 29 N-m)	11 to 15 ft-lb (15 to 20 N-m)
6	9/16 - 18	34 to 42 ft-lb (47 to 56 N-m)	20 to 26 ft-lb (28 to 35 N-m)
8	3/4 - 16	58 to 72 ft-lb (79 to 97 N-m)	35 to 43 ft-lb (48 to 58 N-m)
10	7/8 - 14	99 to 121 ft-lb (135 to 164 N-m)	60 to 74 ft-lb (82 to 100 N-m)
12	1 1/16 - 12	134 to 164 ft-lb (182 to 222 N-m)	81 to 99 ft-lb (110 to 134 N-m)
14	1 3/16 - 12	160 to 196 ft-lb (217 to 265 N-m)	96 to 118 ft-lb (131 to 160 N-m)
16	1 5/16 - 12	202 to 248 ft-lb (274 to 336 N-m)	121 to 149 ft-lb (165 to 202 N-m)
20	1 5/8 - 12	247 to 303 ft-lb (335 to 410 N-m)	149 to 183 ft-lb (202 to 248 N-m)

Figure 7

Adjustable Fitting (Fig. 8)

1. Make sure all threads and sealing surfaces of fitting and component port are free of burrs, nicks, scratches or any foreign material.
2. As a preventative measure against leakage, it is recommended that the O-ring be replaced any time the connection is opened.
3. Lightly lubricate the O-ring with clean hydraulic oil. Fitting threads should be clean with no lubricant applied.
4. Turn back the lock nut as far as possible. Make sure the back up washer is not loose and is pushed up as far as possible (Step 1 in Figure 9).

IMPORTANT: Before installing fitting into port, determine port material. If fitting is to be installed into an aluminum port, installation torque is reduced.

5. Install the fitting into the port and tighten finger tight until the washer contacts the face of the port (Step 2 in Figure 9). Make sure that the fitting does not bottom in the port during installation.

6. To put the fitting in the desired position, unscrew it by the required amount to align fitting with incoming hose or tube, but no more than one full turn (Step 3 in Figure 9).

7. Hold the fitting in the desired position with a wrench and use a torque wrench to tighten the lock nut to the recommended installation torque shown in Figure 7. This tightening process will require the use of an offset wrench (e.g. crowfoot wrench). Use of an offset wrench will affect torque wrench calibration due to the effective length change of the torque wrench. Tightening torque when using a torque wrench with an offset wrench will be lower than the listed installation torque (see Using a Torque Wrench with an Offset Wrench in the Torque Specifications section of Chapter 2 - Product Records and Maintenance).

8. If a torque wrench is not available, or if space at the port prevents use of a torque wrench, an alternate method of assembly is the Flats From Finger Tight (F.F.F.T.) method. Hold the fitting in the desired position with a wrench and, if port material is steel, tighten the lock nut with a second wrench to the listed F.F.F.T (Step 4 in Figure 9). If port material is aluminum, tighten fitting to 60% of listed F.F.F.T.

Size	F.F.F.T.
4 (1/4 in. nominal hose or tubing)	1.00 ± 0.25
6 (3/8 in.)	1.50 ± 0.25
8 (1/2 in.)	1.50 ± 0.25
10 (5/8 in.)	1.50 ± 0.25
12 (3/4 in.)	1.50 ± 0.25
16 (1 in.)	1.50 ± 0.25




Figure 8




Figure 9

This page is intentionally blank.

Traction Circuit: LOW Speed (Mow)

The traction circuit piston pump is a variable displacement pump that is directly coupled to the engine flywheel. This pump utilizes an integral electro-hydraulic servo piston assembly that controls the rate and direction of hydraulic flow. Pressing the traction pedal rotates a potentiometer that provides an input to the machine TEC controller. The controller in turn sends a corresponding PWM (Pulse Width Modulation) output to the electronic pump control to rotate the pump swash plate accordingly to control pump output and direction. Traction circuit oil is directed to the dual displacement front wheel and rear axle motors. Operating pressure on the high pressure side of the closed traction circuit loop is determined by the amount of load developed at the wheel and axle motors. As the traction load increases, circuit pressure can increase to relief valve settings: 4350 PSI (300 bar) in forward and 5000 PSI (345 bar) in reverse. If traction circuit pressure exceeds the relief setting, oil flows through the piston pump relief valve to the low pressure side of the closed loop traction circuit. Traction circuit pressure can be measured at test ports attached to the sides of the piston pump. The forward traction port is on the right side of the pump and the reverse traction port is on the left side.

Front wheel and rear axle motors are positive displacement, two speed variable motors that allow operation in either LOW (mow) or HI (transport) speed. The motors are spring biased to maximum displacement for LOW speed and are hydraulically shifted to minimum displacement for HI speed. The rear axle motor includes a flushing valve that bleeds off a small amount of hydraulic oil for cooling of the closed loop traction circuit. The charge circuit replaces oil that is bled from the circuit by the flushing valve.

The Smart Power™ feature prevents the engine from slowing down in heavy load conditions (e.g. cutting tall grass) by automatically decreasing the traction speed if necessary. With a reduced traction speed, the cutting blades can continue to be at optimum speed.

A traction circuit flow divider splits traction pump hydraulic flow between the front wheel motors (approximately 45%) and rear axle motor (approximately 55%) to prevent excessive circuit flow going to a spinning wheel. The flow divider is located in the front traction manifold mounted to the right, rear side of the front frame.

Traction circuit components use small amounts of hydraulic oil for internal lubrication. Fluid is designed to leak across traction pump and motor components into the case drain. This leakage results in the loss of hydraulic oil from the closed loop traction circuit that is replaced by the charge circuit. The gear pump sections that supply the steering, cooling fan and lift/lower circuits also provide charge circuit oil.

Gear pump flow for the charge circuit is directed through the oil filter and to the low pressure side of the closed loop traction circuit. Charge pressure is limited to 250 PSI (17 bar) by a relief valve located in the piston pump.

Forward Direction

With the armrest console HI/LOW speed switch in the LOW speed (mow) position, solenoid valve (S12) in the combination manifold is not energized which keeps the front wheel motors and rear axle motor at their maximum displacement. With the motors at maximum displacement, a lower traction speed is available for mowing conditions.

When the HI/LOW switch is in the LOW speed (mow) position and the traction pedal is pushed in the forward direction, oil from the piston pump passes through the front traction manifold. Oil flow for the front wheel motors leaves front traction manifold port M1 to drive the front wheel motors in the forward direction and then returns to the piston pump. Oil flow from front traction manifold port M2 is directed to drive the rear axle motor in the forward direction. Oil returning from the axle motor enters the rear traction manifold at the M8 port. Flow bypasses the PR cartridge through the CV check valve, out manifold port P2 and returns to the piston pump.


When going down a hill, the tractor becomes an over-running load that drives the front wheel and rear axle motors. In this condition, the rear axle motor could lock up as the oil pumped from the motor increases pressure as it returns to the piston pump. To prevent rear wheel lock up, an adjustable relief valve (RV) in the rear traction manifold reduces rear axle motor pressure created in down hill, dynamic braking conditions.

Reverse Direction

The traction circuit operates essentially the same in reverse LOW speed (mow) as it does in the forward direction. However, the flow through the circuit is reversed. Oil flow from the piston pump is directed to the front wheel motors and also to the rear traction manifold. The oil to the front wheel motors drives them in the reverse direction and then returns to the piston pump through the front traction manifold. The oil to the rear traction manifold enters the manifold at port P2 and flows through pressure reducing valve (PR) which limits the downstream pressure to the rear axle motor to 380 PSI (26 bar) so the rear wheels will not scuff the turf during reverse operation. This reduced pressure flow is directed out rear traction manifold port M8 to drive the rear axle motor in reverse. Return oil from the rear motor returns to the piston pump through the front traction manifold.

Traction Circuit: HI Speed (Transport) (Forward Shown)

- Working Pressure
- - - Low Pressure (Charge)
- · - · - Return or Suction
- ▶ Flow



Traction Circuit: HI Speed (Transport)

The traction circuit piston pump is a variable displacement pump that is directly coupled to the engine flywheel. This pump utilizes an integral electro-hydraulic servo piston assembly that controls the rate and direction of hydraulic flow. Pressing the traction pedal rotates a potentiometer that provides an input to the machine TEC controller. The controller in turn sends a corresponding PWM (Pulse Width Modulation) output to the electronic pump control to rotate the pump swash plate accordingly to control pump output and direction. Traction circuit oil is directed to the dual displacement front wheel and rear axle motors. Operating pressure on the high pressure side of the closed traction circuit loop is determined by the amount of load developed at the wheel and axle motors. As the traction load increases, circuit pressure can increase to relief valve settings: 4350 PSI (300 bar) in forward and 5000 PSI (345 bar) in reverse. If traction circuit pressure exceeds the relief setting, oil flows through the piston pump relief valve to the low pressure side of the closed loop traction circuit. Traction circuit pressure can be measured at test ports attached to the sides of the piston pump. The forward traction port is on the right side of the pump and the reverse traction port is on the left side.

Front wheel and rear axle motors are positive displacement, two speed variable motors that allow operation in either LOW (mow) or HI (transport) speed. The motors are spring biased to maximum displacement for LOW speed and are hydraulically shifted to minimum displacement for HI speed. The rear axle motor includes a flushing valve that bleeds off a small amount of hydraulic oil for cooling of the closed loop traction circuit. The charge circuit replaces oil that is bled from the circuit by the flushing valve.

A traction circuit flow divider splits traction pump hydraulic flow between the front wheel motors (approximately 45%) and rear axle motor (approximately 55%) to prevent excessive circuit flow going to a spinning wheel. The flow divider is located in the front traction manifold mounted to the right, rear side of the front frame.

Traction circuit components use small amounts of hydraulic oil for internal lubrication. Fluid is designed to leak across traction pump and motor components into the case drain. This leakage results in the loss of hydraulic oil from the closed loop traction circuit that is replaced by the charge circuit. The gear pump sections that supply the steering, cooling fan and lift/lower circuits also provide charge circuit oil.

Gear pump flow for the charge circuit is directed through the oil filter and to the low pressure side of the closed loop traction circuit. Charge pressure is limited to 250 PSI (17 bar) by a relief valve located in the piston pump.

Forward Direction

With the armrest console HI/LOW speed switch in the HI speed (transport) position, solenoid valve (S12) in the combination manifold is energized. The energized solenoid valve directs charge pressure to shift the front wheel motors and rear axle motor to their minimum displacement. With the motors at their minimum displacements, a higher traction speed is available for transport.

When the HI/LOW switch is in the HI speed (transport) position and the traction pedal is pushed in the forward direction, oil from the piston pump passes through the front traction manifold. Oil flow for the front wheel motors leaves front traction manifold port M1 to drive the front wheel motors in the forward direction and then returns to the piston pump. Oil flow from front traction manifold port M2 is directed to drive the rear axle motor in the forward direction. Oil returning from the axle motor enters the rear traction manifold at the M8 port. Flow bypasses the PR cartridge through the CV check valve, out manifold port P2 and returns to the piston pump.


When going down a hill, the tractor becomes an over-running load that drives the front wheel and rear axle motors. In this condition, the rear axle motor could lock up as the oil pumped from the motor increases pressure as it returns to the piston pump. To prevent rear wheel lock up, an adjustable relief valve (RV) in the rear traction manifold reduces rear axle motor pressure created in down hill, dynamic braking conditions.

Reverse Direction

The traction circuit operates essentially the same in reverse HI speed (transport) as it does in the forward direction. However, the flow through the circuit is reversed. Oil flow from the piston pump is directed to the front wheel motors and also to the rear traction manifold. The oil to the front wheel motors drives them in the reverse direction and then returns to the piston pump through the front traction manifold. The oil to the rear traction manifold enters the rear traction manifold at port P2 and flows through pressure reducing valve (PR) which limits the down stream pressure to the rear axle motor to 380 PSI (26 bar) so the rear wheels will not scuff the turf during reverse operation. This reduced pressure flow is directed out rear traction manifold port M8 to drive the rear axle motor in reverse. Return oil from the rear motor returns to the piston pump through the front traction manifold.

Lower Cutting Deck (LH Deck Shown)

- Working Pressure
- Low Pressure (Charge)
- Return or Suction
- Flow



Lower Cutting Deck Circuit

A four section gear pump is coupled to the piston (traction) pump. The third gear pump section supplies hydraulic flow to the lift/lower circuit, the engine cooling fan circuit and the traction charge circuit.

Each of the cutting decks (center, right and left) can be lowered independently with the use of three (3) switches on the armrest console. Pressing the front of a lift switch provides an input for the TEC controller to lower a cutting deck. The controller provides electrical outputs to solenoids in the combination manifold to allow appropriate manifold valve shift that causes a cutting deck to lower.

A relief valve (RV2) located in the combination manifold limits lift/lower circuit pressure to 1600 PSI (110 bar). An adjustable pressure relieving valve (PR) in the combination manifold maintains back pressure (counterbalance) on the deck lift cylinders to allow some of the cutting deck weight to be transferred to the traction unit to improve traction.

When the lift/lower circuit is not being used (all lift switches in the neutral position), solenoid valve S1 in the combination manifold is not energized and gear pump section oil flow is directed toward the engine cooling fan motor.

NOTE: To lower a cutting deck, the operator must be in the operator seat and the traction speed must be in the LOW speed (mow) position.

Lower Center Cutting Deck

To lower the center cutting deck, the front of the center console lift switch is depressed. The switch signal is an input to the TEC controller which provides an electrical output to solenoid valve S6 in the combination manifold. The energized solenoid valve shifts to allow a passage for oil flow from the barrel end of the center deck lift cylinders. The weight of the cutting deck causes the center deck lift cylinders to retract and lower the center cutting deck. Check orifice OR5 (.070) under the manifold fitting in port C2 controls the lowering speed of the cutting deck. Oil from the retracting cylinders is directed to pressure reducing valve (PR). As return oil pressure increases, the PR valve will shift to direct circuit oil to the oil filter and then to the traction charge circuit.

Lower Right Cutting Deck

To lower the right wing deck, the front of the right console lift switch is pushed as an input to the TEC controller. The controller provides an electrical output to solenoid valves S1, S8 and S9 in the combination manifold. The energized solenoid valves shift to allow a passage for circuit oil flow to the rod end of the right deck lift cylinder. Shifted S1 allows gear pump section oil flow to be available for the lift/lower circuits. Shifted S8 allows an oil path to the rod end of the right lift cylinder to retract the lift cylinder and lower the right cutting deck. Check orifice OR7 (.070) controls the lowering speed of the cutting deck. Oil from the retracting cylinder is directed through energized S9, de-energized S7 and then to pressure reducing valve (PR). As return oil pressure increases, the PR valve will shift to direct circuit oil to the oil filter and then to the traction charge circuit.

Lower Left Cutting Deck

To lower the left wing deck, the front of the left console lift switch is pushed as an input to the TEC controller. The controller provides an electrical output to solenoid valves S1, S3 and S4 in the combination manifold. The energized solenoid valves shift to allow a passage for circuit oil flow to the left deck lift cylinder rod end. Shifted S1 allows gear pump section oil flow to be available for the lift/lower circuits. Shifted S3 allows an oil path to the rod end of the left lift cylinder to retract the lift cylinder and lower the left cutting deck. Check orifice OR3 (.070) controls the lowering speed of the cutting deck. Oil from the retracting cylinder is directed through energized S4, de-energized S2 and then to pressure reducing valve (PR). As return oil pressure increases, the PR valve will shift to direct circuit oil to the oil filter and then to the traction charge circuit.

Cutting Deck Float

Cutting deck float allows the fully lowered cutting decks to follow ground surface contours. Combination manifold solenoid valves S4 (left deck), S6 (center deck) and S9 (right deck) are energized when the decks are fully lowered. These energized solenoids provide an oil passage to and from the lift cylinders to allow cylinder and cutting deck movement while mowing. Counterbalance pressure (PR) will affect deck float operation.

NOTE: If a deck is already fully lowered when the ignition switch is moved from OFF to RUN, the deck will not be in float until the appropriate deck lift/lower switch is momentarily pressed to lower.

Raise Cutting Deck Circuit

A four section gear pump is coupled to the piston (traction) pump (Fig. 10). The third gear pump section supplies hydraulic flow to the lift/lower circuit, the engine cooling fan circuit and the traction charge circuit.

A relief valve (RV2) located in the combination manifold limits lift/lower circuit pressure to 1600 PSI (110 bar). An adjustable pressure relieving valve (PR) in the combination manifold maintains back pressure (counterbalance) on the deck lift cylinders to allow some of the cutting deck weight to be transferred to the traction unit to improve traction.

Each of the cutting decks (center, right and left) can be raised independently with the use of three (3) lift switches on the armrest console. Pressing the rear of a switch provides an input for the TEC controller to raise a cutting deck. The controller provides electrical outputs to solenoids in the combination manifold to allow appropriate hydraulic valve shift to cause a deck to raise.

When the lift/lower circuit is not being used (all lift switches in the neutral position), solenoid valve S1 in the combination manifold is not energized and gear pump section oil flow is directed toward the engine cooling fan motor.

NOTE: To raise a cutting deck, the operator must be in the operator seat.

Raise Center Cutting Deck

To raise the center cutting deck, the rear of the center console lift switch is depressed. The switch signal is an input to the TEC controller which provides an electrical output to solenoid valves S1 and S5 in the combination manifold. The energized solenoid valves shift to allow a passage for circuit oil flow to the barrel end of the center deck lift cylinders. Shifted S1 allows gear pump section oil flow to be available for the lift/lower circuits. Shifted S5 allows an oil path to the barrel end of the front lift cylinders causing the lift cylinders to extend and raise the center cutting deck. Check orifice OR5 under the fitting in manifold port C2 allows oil flow to bypass the orifice when the center deck is raising. An orifice in manifold port OR4 (.040) exists to control the raise speed of the cutting deck.

When the lift switch is released, the manifold solenoids are de-energized and the center deck lift cylinders and center cutting deck are held in position.

Raise Right Cutting Deck

To raise the right deck, the rear of the right console lift switch is depressed as an input to the TEC controller. The controller provides an electrical output to solenoid

valves S1, S7 and S9 in the combination manifold. The energized solenoid valves shift to allow a passage for circuit oil flow to the barrel end of the right deck lift cylinder. Shifted S1 allows gear pump section oil flow to be available for the lift/lower circuits. Shifted S7 and S9 allow an oil path to the barrel end of the right lift cylinder to extend the lift cylinder and raise the right cutting deck. Orifice OR6 (.063) controls the raising of the cutting deck. Check orifice OR7 is bypassed when raising the right cutting deck. Oil from the extending cylinder is directed through S8 (de-energized), to the oil filter and then to the traction charge circuit.

When the lift switch is released, the manifold solenoids are de-energized and the lift cylinder and right cutting deck are held in position.

Raise Left Cutting Deck

To raise the left deck, the rear of the left console lift switch is depressed as an input to the TEC controller. The controller provides an electrical output to solenoid valves S1, S2 and S4 in the combination manifold. The energized solenoid valves shift to allow a passage for circuit oil flow to the barrel end of the left deck lift cylinder. Shifted S1 allows gear pump section oil flow to be available for the lift/lower circuits. Shifted S2 and S4 allow an oil path to the barrel end of the right lift cylinder to extend the lift cylinder and raise the right cutting deck. Orifice OR2 (.063) controls the raising of the cutting deck. Check orifice OR3 is bypassed when raising the left cutting deck. Oil from the extending cylinder is directed through S3 (de-energized), to the oil filter and then to the traction charge circuit.

When the lift switch is released, the manifold solenoids are de-energized and the lift cylinder and left cutting deck are held in position.




Figure 10

- 1. Piston (traction) pump
- 2. 3rd gear pump section

Mow Circuit

A four section gear pump is coupled to the piston (traction) pump. Hydraulic flow for the mow circuit is supplied by two sections of the gear pump. The gear pump section closest to the piston (traction) pump supplies hydraulic flow to the side cutting decks, while the next gear pump section supplies the front cutting deck.

Each cutting deck is controlled by a hydraulic manifold equipped with a proportional relief valve (PRV), a pilot directional valve (PD), a logic valve (LC1) and a relief valve (RV). The proportional relief valve is a solenoid operated valve that also functions as the circuit relief valve when energized. Circuit pressure can be measured at port (G) of the hydraulic manifold for each cutting deck.

NOTE: To engage the mow circuit, the operator must be in the operator seat, the traction speed must be in the LOW speed (mow) position, the PTO switch must be ON and the cutting deck(s) must be fully lowered and in float.

PTO Not Engaged

When the PTO switch is OFF or if the deck is raised with the PTO switch ON, the PTO manifold proportional relief valve (PRV) is not energized which allows a small amount of hydraulic flow through the valve. As this hydraulic flow returns to the hydraulic reservoir, a circuit pressure increase shifts logic valve LC1. The pump flow is routed through shifted LC1 and out manifold port P2 bypassing the cutting unit motor. Pilot direction valve PD and relief valve RV remain in the unshifted position to prevent any return flow from the deck motor which keeps the motor and cutting blades from rotating.

Return flow from the front and right PTO manifolds is routed through the oil cooler, oil filter and then to the gear pump input. Return flow from the left PTO manifold provides supply for the right deck.

PTO Engaged

When the PTO switch is turned ON and the decks are lowered, the PTO manifold proportional relief valve (PRV) is energized by the TEC controller. This shifted solenoid valve prevents any flow through the valve which allows the logic valve LC1 to be in its neutral position directing circuit flow toward the cutting deck motor. Gear pump flow entering the manifold is routed out manifold port M1 and to the cutting deck motor to cause the motor and cutting blades to rotate. As circuit pressure increases, pilot direction valve PD shifts to provide a return path for circuit flow. The return flow from the deck

motor re-enters manifold port M2, is routed through shifted PD, out manifold port P2, through the oil cooler and filter and then is routed to the gear pump input. The deck motor continues to rotate as long as proportional relief valve (PRV) is energized.

Deck motor case drain leakage returns to the hydraulic reservoir.

PTO Circuit Relief

Maximum mow circuit pressure is limited for each deck by proportional relief valve (PRV) in the PTO manifold. The center and left deck relief valves are set at 3000 PSI (207 bar) and the right deck relief valve is set at 2000 PSI (138 bar).

Proportional relief valve (PRV) and logic valve (LC1) work together as a two stage circuit relief. When increased circuit resistance is met (e.g. a cutting blade strikes an object), the pressure increase is felt at the proportional relief valve. If the pressure should exceed the relief valve setting, the relief valve will open, allowing a small amount of hydraulic flow through the valve. This flow causes a pressure increase that shifts logic valve LC1 and diverts circuit flow away from the deck motor to manifold port P2 (Fig. 11). When circuit pressure lowers, proportional relief valve (PRV) closes which returns logic valve LC1 back to its neutral position allowing flow to return to the deck motor.




Figure 11

Mow Circuit Cutting Deck Blade Braking

When the operator turns the PTO switch OFF or if a deck is raised with the PTO switch ON, PTO manifold proportional relief valve (PRV) is de-energized causing logic valve (LC1) to shift (refer to information in Mow Circuit in this section). This shifted cartridge directs oil return out of manifold port P2. As circuit pressure decreases, pilot direction valve PD is shifted to it's neutral position, preventing return flow from the deck motor and slows the cutting blades (Fig. 12).

The inertia of the rotating cutting blades, however, effectively turns the deck motor into a pump causing an increase in pressure as the flow from the motor comes up against the closed relief valve (RV). When this pressure builds to approximately 600 PSI (41 bar), relief valve (RV) opens which allows hydraulic flow to flow from the motor (Fig. 13). When return pressure drops below 600 PSI (41 bar), relief valve (RV) reseats to once again block return flow from the deck motor to further slow the cutting blades. This action of the brake relief valve opening occurs several times in a very short time frame as the blades finally come to a stop. Once the blades have stopped, relief valve (RV) remains seated to keep the deck motor from rotating.




Figure 12





Figure 13

This page is intentionally blank.

Steering Circuit (Right Turn Shown)

- Working Pressure
- - - Low Pressure (Charge)
- · - · - Return or Suction
- ▶ Flow



Steering Circuit

A four section gear pump is coupled to the piston (traction) pump. The fourth gear pump section (farthest from the piston pump) supplies hydraulic flow to the steering circuit, the engine cooling fan circuit and the traction charge circuit. Priority hydraulic flow from this gear pump section is provided to the steering circuit by the pressure compensator valve (EC) located in the combination manifold.

NOTE: The hydraulic schematic symbol for the pressure compensator valve (EC) appears to be a two (2) position valve. In operation, this valve will direct the gear pump section flow to the steering circuit as priority depending on steering input. The remainder of the gear pump section flow will be directed to the charge and engine cooling fan circuits. If there is no steering input, the compensator valve (EC) directs all gear pump section flow to the charge and engine cooling fan circuits.

The combination manifold controls the operation of the steering control valve, the engine cooling fan motor and the cutting deck lift cylinders. The pressure compensator valve (EC) in the manifold controls the oil flow to the steering control valve which is a closed center, load sensing valve. The steering control valve senses the oil flow that is needed for steering and the compensator valve (EC) will supply the correct amount. Oil flow not needed for the steering circuit is provided to the engine cooling fan motor and then to the traction charge circuit.

With the steering wheel in the neutral, at rest position and the engine running, hydraulic oil from the final gear pump section enters the combination manifold port P4, flows through the pressure compensator valve (EC) and to the steering control valve where it dead heads at the steering control spool. Oil is also sent to both ends of the compensator valve (EC) spool. On one end of the spool, oil is directed to the steering relief valve (RV1) and also is directed through the OR1 orifice and out the LS manifold port to the steering control valve. This flow provides steering load sense pressure and is directed through a small passage in the steering control valve spool and sleeve before returning to the hydraulic reservoir. While this load sense pressure is returning to the reservoir, the compensator valve (EC) spool shifts to direct pump flow to the engine cooling fan motor circuit and then to the traction charge circuit. Without steering input, no oil is flowing through the steering control valve to the steering cylinder.

Right Turn

When a right turn is made with the engine running, the turning of the steering wheel positions the steering control valve spool so that the load sense flow is blocked off. Without load sense flow, pressures on the ends of man-

ifold compensator valve (EC) start to equalize causing (EC) to move toward its neutral position which allows the needed oil flow to the steering control valve. Oil is routed out manifold port CF, into steering valve port P, through the steering control spool, is drawn through the rotary meter section and out the R port to the steering cylinder. Pressure extends the steering cylinder for a right turn. The rotary meter ensures that the oil flow to the cylinder is proportional to the amount of the turning on the steering wheel. Fluid leaving the cylinder flows back through the steering valve L port, the spool valve, out the T port and then returns to the hydraulic reservoir.

The steering control valve returns to the neutral position when turning is completed.

Left Turn

When a left turn is made with the engine running, the turning of the steering wheel positions the steering control valve spool so that the load sense flow is blocked off. Without load sense flow, pressures on the ends of manifold compensator valve (EC) start to equalize causing (EC) to move toward its neutral position which allows the needed oil flow to the steering control valve. Oil is routed out manifold port CF, into steering valve port P, through the steering control spool, is drawn through the rotary meter section and out the L port to the steering cylinder. Pressure retracts the steering cylinder for a left turn. The rotary meter ensures that the oil flow to the cylinder is proportional to the amount of the turning on the steering wheel. Fluid leaving the cylinder flows back through the steering valve R port, the spool valve, out the T port and then returns to the hydraulic reservoir.

The steering control valve returns to the neutral position when turning is completed.

Steering Relief Operation

When the steering cylinder reaches the end of its stroke or if a rear wheel should encounter an obstruction (e.g. a curb) while steering, the pressure in the steering circuit will rise. Relief valve (RV1) in the combination manifold senses this pressure increase. When steering circuit pressure builds to approximately 1350 PSI (93 bar), relief valve (RV1) opens and allows hydraulic flow to return to the hydraulic reservoir. This action causes flow across the relief valve side orifice of compensator valve (EC) which shifts the spool in (EC) to send oil away from the steering circuit to the fan motor circuit. Relief valve (RV1) controls the action of compensator valve (EC) and allows the compensator valve to divert only enough oil flow to the steering circuit to maintain relief pressure.

Engine Cooling Fan Circuit

A four section gear pump is coupled to the piston (traction) pump (Fig. 14). The fourth gear pump section (farthest from the piston pump) supplies hydraulic flow to the steering circuit, the engine cooling fan circuit and the traction charge circuit. The third gear pump section supplies hydraulic flow to the engine cooling fan circuit, the lift/lower circuit and the traction charge circuit.

So that there is sufficient oil flow for the engine cooling fan circuit, oil flow from either or both of the third or fourth gear pump section is used to drive the hydraulic cooling fan motor depending on what other machine functions are being used (steering, lift/lower). If additional oil flow is needed for cooling fan operation in extreme conditions (e.g. high ambient temperatures, cutting very heavy grass), the TEC controller can allow flow from the two pump sections to be combined.

Oil flow from the third gear pump section is routed to the combination manifold (port P3) where it is available either for the lift/lower circuit or the engine cooling fan circuit. When the lift/lower circuit is not being used (all lift switches in the neutral position), solenoid valve (S1) in the combination manifold is not energized and gear pump section oil flow is directed toward the engine cooling fan motor.

Priority oil flow from the fourth gear pump section is provided to the steering circuit. All excess flow from this gear pump section is normally routed to the traction charge circuit by energized solenoid valve (S11). This valve is energized by the TEC controller as long as the lift/lower function is not being used and the hydraulic oil and engine coolant temperatures are within normal ranges. If inputs to the TEC controller suggest additional oil flow is necessary for the cooling fan (e.g. lift/lower circuit is engaged or engine coolant temperature is elevated), solenoid valve (S11) will be de-energized allowing excess pump section oil flow to be directed toward the engine cooling fan motor.

Oil flow from the gear pump section(s) to the cooling fan motor is controlled by the proportional relief valve (PRV) in the combination manifold. This valve adjusts fan circuit pressure and flow based on a PWM (Pulse Width Modulation) signal from the TEC controller. The controller uses engine coolant and hydraulic oil temperatures as inputs to determine the proper PWM signal for the (PRV) valve. The fan circuit flow determines the speed of the cooling fan motor and thus, the speed of the cooling fan.

If the fan motor is stalled for any reason during machine operation, the manifold proportional relief valve (PRV) has a secondary function as a circuit relief to limit fan motor pressure to 3250 PSI (224 bar).

When the engine is shut off, the over-running inertia load of the engine cooling fan blades keeps driving the fan motor and turns it into a pump. The check valve (CV1) in the combination manifold will open to keep the motor circuit full of oil so the fan motor will not cavitate.

Forward Direction Fan Operation

During normal, forward direction fan operation, circuit oil flow is sent through the de-energized solenoid valve (S10) in the combination manifold to rotate the cooling fan motor. Return flow from the motor re-enters the manifold (port M2), through the de-energized solenoid valve (S10), to the oil filter and then out of the manifold (port CH2). After exiting the manifold, circuit oil is routed to the traction charge circuit.

Reverse Direction Fan Operation

The TEC controller can reverse the cooling fan to clean debris from the rear intake screen. If hydraulic oil and/or engine coolant temperatures increase to an unsuitable level, a high PWM signal is sent to the (PRV) valve to slow the cooling fan and direct all pump oil flow to the traction charge circuit. The controller then energizes solenoid valve (S10) in the combination manifold to reverse cooling fan motor oil flow so that the motor runs in the reverse direction. A lower PWM signal is sent to the (PRV) valve allowing oil flow to return to the fan motor but in the reverse direction causing the motor and cooling fan to run in reverse. The controller determines the length of time that the fan should be run in reverse before fan rotation is returned to the forward direction.

NOTE: The operator can manually cause the cooling fan to reverse by simultaneously pressing the right and left buttons on the InfoCenter display.




Figure 14

- | | |
|--------------------------------------|--------------------------------------|
| 1. Piston (traction) pump | 3. 3 rd gear pump section |
| 2. 4 th gear pump section | |

Special Tools

Order special tools from your Toro Distributor.

Hydraulic Pressure Test Kit

Use to take various pressure readings for diagnostic tests. Quick disconnect fittings provided attach directly to mating fittings on machine test ports without tools. A high pressure hose is provided for remote readings. Kit contains one each: 1000 PSI (70 bar), 5000 PSI (350 bar) and 10000 PSI (700 bar) gauges. Use gauges as recommended in the Testing section of this chapter.

Toro Part Number: **TOR47009**



Figure 15

15 GPM Hydraulic Tester Kit (Pressure and Flow)

Use to test hydraulic circuits and components for flow and pressure capacities as recommended in the Testing section of this chapter. This tester includes the following:

1. **INLET HOSE:** Hose connected from the system circuit to the inlet side of the hydraulic tester.
2. **LOAD VALVE:** A simulated working load is created in the circuit by turning the valve to restrict flow.
3. **PRESSURE GAUGE:** Glycerine filled 0 to 5000 PSI gauge to provide operating circuit pressure.
4. **FLOW METER:** This meter measures actual oil flow in the operating circuit with a gauge rated from 1 to 15 GPM (5 to 55 LPM).
5. **OUTLET HOSE:** A hose from the outlet side of the hydraulic tester connects to the hydraulic system circuit.
6. **FITTINGS:** An assortment of hydraulic fittings are included with this kit.

Toro Part Number: **TOR214678**



Figure 16

40 GPM Hydraulic Tester (Pressure and Flow)

Use to test hydraulic circuits and components for flow and pressure capacities as recommended in the Testing section of this chapter. This tester includes the following:

1. **LOAD VALVE:** A simulated working load is created in the circuit by turning the valve to restrict flow.
2. **PRESSURE GAUGE:** Glycerine filled 0 to 5000 PSI gauge to provide operating circuit pressure.
3. **FLOW METER:** This meter measures actual oil flow in the operating circuit with a gauge rated from 4 to 40 GPM (20 to 150 LPM).

Toro Part Number: **AT40002**

NOTE: This tester does not include hoses (see Hydraulic Hose Kit TOR6007 below).



Figure 17

Hydraulic Hose Kit

This kit includes fittings and hoses needed to connect 40 GPM hydraulic tester (AT40002) or high flow hydraulic filter kit (TOR6011) to machine hydraulic traction system components.

Toro Part Number: **TOR6007**




Figure 18

High Flow Hydraulic Filter Kit

The high flow hydraulic filter kit is designed with large flow (40 GPM/150 LPM) and high pressure (5000 PSI/345 bar) capabilities. This kit provides for bi-directional filtration which prevents filtered debris from being allowed back into the circuit regardless of flow direction.

If a component failure occurs in the closed loop traction circuit, contamination from the failed part will remain in the circuit until removed. When connecting hydraulic test gauges in order to test traction circuit components or after replacing a failed traction circuit component (e.g. piston pump or wheel motor), the high flow hydraulic filter can be installed in the traction circuit. The filter will ensure that contaminants are removed from the closed loop and thus, do not cause additional component damage.

Toro Part Number: **TOR6011**

NOTE: This kit does not include hoses (see Hydraulic Hose Kit TOR6007 above).

NOTE: Replacement filter element is Toro part number TOR6012. Filter element cannister tightening torque is **25 ft-lb (34 N-m)**.



Figure 19

O-Ring Kit

The O-ring kit includes O-rings in a variety of sizes for face seal and port seal hydraulic connections. It is recommended that O-rings be replaced whenever a hydraulic connection is loosened.

Toro Part Number: **117-2727**



Figure 20

Hydraulic Test Fitting Kit

This kit includes a variety of O-ring Face Seal fittings to enable you to connect test gauges into the system.

The kit includes: tee's, unions, reducers, plugs, caps and male test fittings.

Toro Part Number: **TOR4079**








TORO TEST FITTING KIT (TOR4079)			
FITTING	TOOL NUMBER	FITTING	TOOL NUMBER
	Swivel Nut Run Tee (2 ea.)		Union (1 ea.)
	Size Toro No.		Size Toro No.
	No. 4 TOR4079-3		No. 6 to No. 8 TOR4079-8
	No. 6 TOR4079-12		No. 10 to No. 8 TOR4079-2
No. 8 TOR4079-4	No. 10 TOR4079-5		Reducer (1 ea.)
No. 10 TOR4079-5	Size Toro No.		Size Toro No.
	Plug (2 ea.)	No. 10 to No. 8 TOR4079-7	No. 12 to No. 8 TOR4079-6
	Size Toro No.		Test Cap Fitting (2 ea.)
	No. 4 TOR4079-13		Size Toro No.
	No. 6 TOR4079-14		No. 4 TOR4079-10
No. 8 TOR4079-15	No. 6 TOR4079-11		
No. 10 TOR4079-16	No. 8 TOR4079-21		Test Fitting (2 ea.)
	Cap (2 ea.)		Size Toro No.
	Size Toro No.	3/16-20 ORB TOR4079-22	1/8" Pipe Thd. TOR4079-23
	No. 4 TOR4079-17		
	No. 6 TOR4079-18		
No. 8 TOR4079-19			
No. 10 TOR4079-20			

Figure 21

Measuring Container

Use this container for doing hydraulic motor efficiency testing (motors with case drain lines only). Measure efficiency of a hydraulic motor by restricting the outlet flow from the motor and measuring leakage from the case drain line while the motor is pressurized by the hydraulic system.

The table in Figure 23 provides gallons per minute (GPM) conversion for measured milliliter or ounce motor case drain leakage.

Toro Part Number: **TOR4077**



Figure 22

GPM	Milliliters in 15 sec.	Ounces in 15 sec.
.1	95	3.2
.2	189	6.4
.3	284	9.6
.4	378	12.8
.5	473	16.0
.6	568	19.2
.7	662	22.4
.8	756	25.6
.9	852	28.8
1.0	946	32.0

Figure 23

Hydraulic System

Remote Starter Switch

After flushing the hydraulic system or replacing a hydraulic component (e.g. gear pump, piston pump, wheel motor), it is necessary to prime the hydraulic pumps. A remote starter switch (Fig. 24) can be used for this purpose. Obtain a remote starter switch locally.

IMPORTANT: When using a remote starter switch, it is highly recommended to include a 20 amp inline fuse between the battery and switch connector for circuit protection.

A remote starter switch can also be constructed using Toro switch #106-2027, a length of 14 gauge wire, a 20 amp in-line fuse, two (2) alligator clips and necessary connectors. Connecting the wire to switch terminals 1 and 2 will allow the momentary switch contacts to be used for the remote starter switch (Fig. 25).

NOTE: For information on using the remote starter switch to prime the hydraulic pumps, see Flush Hydraulic System in the Service and Repairs section of this chapter.



Figure 24




Figure 25




Figure 26

- 1. Starter motor
- 2. Starter solenoid
- 3. B+ terminal

Troubleshooting

The charts that follow contain suggestions that can be used to assist in diagnosing hydraulic system performance issues. The suggestions are not all-inclusive. Also, consider that there may be more than one cause for a machine problem.

Review the hydraulic schematic and information on hydraulic system operation in the Hydraulic Flow Diagrams section of this Chapter. This information will be useful during the hydraulic troubleshooting process.

Refer to the Testing section of this Chapter for precautions and specific hydraulic test procedures.

General Hydraulic System Problems

Problem	Possible Cause
Hydraulic oil leaks from machine	Fitting(s), hose(s) or tube(s) is (are) loose or damaged. O-ring(s) or seal(s) is (are) missing or damaged.
Hydraulic system operates hot. NOTE: An indication that the hydraulic system is operating at excessive temperatures would be frequent reversing of the cooling fan and a normal engine coolant temperature.	Engine RPM is too low. Brakes are applied or sticking. Hydraulic reservoir oil level is low. Hydraulic oil is contaminated or the wrong type. Piston pump by-pass valve is open or damaged. Cooling system is not operating properly. Charge pressure is low. Traction circuit pressure is incorrect. Pump(s) or motor(s) are damaged.
Hydraulic oil in reservoir foams.	Hydraulic reservoir oil level is low. Wrong type of oil is in the hydraulic system. Air is leaking into a pump suction line.

Traction Circuit Problems

Problem	Possible Cause
Machine operates in one direction only.	<p>Piston (traction) pump by-pass valve is open or damaged.</p> <p>Traction relief valve is leaking or faulty.</p> <p>Piston (traction) pump servo control valve orifices or screens are plugged or damaged.</p> <p>Problem with TEC output to piston (traction) pump servo control exists (see Chapter 5 - Electrical System).</p>
Traction pedal response is sluggish.	<p>Traction pedal components are stuck or binding.</p> <p>Traction charge pressure is low.</p> <p>Piston (traction) pump servo control valve orifices are plugged or damaged.</p>
Machine travels too far before stopping when the traction pedal is released.	<p>Traction pedal components are stuck or binding.</p> <p>Traction charge pressure is low.</p> <p>Adjustment of relief valve (RV) in rear traction manifold is incorrect.</p> <p>Piston (traction) pump servo control valve orifices are plugged or damaged.</p>
Traction power is lost or machine will not operate in either direction.	<p>Hydraulic reservoir oil level is low (NOTE: Other hydraulic systems are affected as well).</p> <p>Piston (traction) pump by-pass valve is open or damaged.</p> <p>Traction charge pressure is low.</p> <p>Traction circuit pressure is low.</p> <p>Traction pedal position sensor is not plugged in or is faulty (see Chapter 5 - Electrical System).</p> <p>Problem with TEC output to piston (traction) pump servo control exists (see Chapter 5 - Electrical System).</p>
<p>LOW traction speed (mow) will not engage.</p> <p>NOTE: LOW (mow) will not engage when the cutting decks are lowered.</p>	<p>Electrical problem exists that prevents solenoid valve S12 from being de-energized (see Chapter 5 - Electrical System).</p> <p>Solenoid valve (S12) in combination manifold is faulty.</p>
LOW traction speed (mow) will not disengage.	<p>Electrical problem exists that prevents solenoid valve S12 from being energized (see Chapter 5 - Electrical System).</p> <p>Solenoid valve (S12) in combination manifold is faulty.</p>

Mow Circuit Problems

Problem	Possible Cause
<p>None of the cutting decks will operate.</p> <p>NOTE: To engage the mow circuit, the seat must be occupied, the cutting deck(s) must be fully lowered, the traction speed must be in the LOW (mow) position and the PTO switch must be ON.</p>	<p>Electrical problem exists that prevents PRV solenoid valve in PTO manifolds from being energized (see Chapter 5 - Electrical System).</p> <p>Front two (2) gear pump sections for mow circuits are worn or damaged.</p>
<p>One cutting deck will not operate.</p>	<p>Electrical problem (e.g. solenoid coil in PTO manifold, cutting deck position switch) exists (see Chapter 5 - Electrical System).</p> <p>Cutting deck problem exists (e.g. drive belt, deck spindle).</p> <p>System pressure to the affected cutting deck is low.</p> <p>Woodruff key on affected deck motor is damaged.</p> <p>Proportional relief valve (PRV) in PTO manifold for affected deck is faulty.</p> <p>Cartridge valve in PTO manifold for affected deck is damaged or sticking.</p> <p>Deck motor for affected deck is damaged (NOTE: if appropriate, transfer a suspected damaged motor to another cutting deck. If problem follows the motor, motor is faulty and needs repair or replacement).</p> <p>Gear pump section for affected deck is worn or damaged.</p>
<p>All cutting decks operate slowly.</p>	<p>Engine RPM is low.</p> <p>All deck motors are worn or damaged.</p> <p>Front two (2) gear pump sections for mow circuits are worn or damaged.</p>
<p>Cutting deck stops under load.</p>	<p>Proportional relief valve in PTO manifold for affected deck is bypassing.</p> <p>Deck motor has internal leakage (bypassing oil).</p> <p>Gear pump section for affected deck is worn or damaged.</p>

Lift Circuit Problems

Problem	Possible Cause
<p>Cutting decks will not raise.</p> <p>NOTE: Seat must be occupied in order to raise cutting decks.</p>	<p>Engine RPM is too low.</p> <p>Hydraulic oil level in reservoir is low (NOTE: Other hydraulic systems are affected as well).</p> <p>Solenoid valve (S1) in combination manifold is faulty.</p> <p>Electrical problem exists (see Chapter 5 - Electrical System).</p> <p>Lift arm pivots are binding.</p> <p>Lift/lower relief valve in combination manifold is stuck.</p> <p>Lift cylinder(s) is (are) damaged.</p> <p>Gear pump section for lift circuit is worn or damaged (NOTE: A worn or damaged gear pump section will also affect the steering, engine cooling fan motor and traction charge circuits).</p>
<p>Cutting decks raise, but will not stay up.</p> <p>NOTE: Lift cylinders cannot provide an absolutely perfect seal. A cutting deck will eventually lower if left in the raised position during storage.</p>	<p>Lift circuit hydraulic lines or fittings are leaking.</p> <p>Combination manifold cartridge valve(s) for lift/lower circuits has damaged seals or is faulty.</p> <p>Lift cylinder for affected deck is damaged.</p>
<p>Cutting decks will not lower.</p> <p>NOTE: To lower a cutting deck, the seat must be occupied and the traction speed must be in the LOW (mow) position.</p>	<p>Lift arm pivots are binding.</p> <p>Electrical problem exists (see Chapter 5 - Electrical System).</p> <p>Solenoid valve (S1) in combination manifold is faulty.</p> <p>Counterbalance pressure is excessive.</p> <p>Lift cylinder for affected deck is damaged.</p>

Steering Circuit Problems

Problem	Possible Cause
Steering inoperative or sluggish	<p>Steering components (e.g. tie rods, steering cylinder ends) are worn or binding.</p> <p>Steering cylinder is binding.</p> <p>Oil level in hydraulic reservoir is low (NOTE: Other hydraulic systems are affected as well).</p> <p>Steering relief valve (RV1) in combination manifold is stuck or damaged.</p> <p>The pressure compensator valve (EC) in combination manifold is stuck or damaged.</p> <p>Steering cylinder leaks internally.</p> <p>Steering control valve is worn or damaged.</p> <p>Gear pump section is worn or damaged (NOTE: A worn or damaged gear pump section will also affect the lift/lower, engine cooling fan motor and traction charge circuits).</p>

Engine Cooling Fan Circuit Problems

Problem	Possible Cause
Cooling fan runs only in forward direction (fan does not run in reverse direction).	<p>Solenoid cartridge valve (S10) in combination control manifold is faulty.</p> <p>Electrical problem exists that prevents combination control manifold solenoid valve (S10) operation (see Chapter 5 – Electrical System).</p>
Cooling fan does not rotate.	<p>Cooling fan motor is worn or damaged.</p> <p>Proportional relief valve (PRV) in combination manifold is stuck or damaged.</p> <p>Gear pump section for engine cooling fan circuit is worn or damaged (NOTE: A worn or damaged gear pump section will also affect the steering, lift/lower and traction charge circuits).</p>
Cooling fan always rotates at slow speed.	<p>Combination manifold cartridge valve seals are leaking.</p> <p>Check valve in combination manifold is not seating.</p> <p>Proportional relief valve (PRV) in combination manifold is stuck or damaged.</p> <p>Hydraulic fan motor is worn or damaged.</p>
Cooling fan always rotates at fast speed.	<p>Proportional relief valve (PRV) in combination manifold is faulty.</p> <p>Electrical problem exists that prevents correct operation of combination manifold proportional relief valve (PRV) (see Chapter 5 – Electrical System).</p>

This page is intentionally blank.

Testing

The most effective method for isolating problems in the hydraulic system is by using hydraulic test equipment such as pressure gauges and flow meters in the circuits during various operational checks (see the Special Tools section in this Chapter).

IMPORTANT: All obvious areas such as hydraulic oil supply, oil filters, binding components, loose fasteners or improper adjustments must be checked before assuming that a hydraulic component is the source of the problem.



CAUTION

Failure to use gauges with recommended pressure (PSI/bar) rating as listed in test procedures could result in damage to the gauge and possible personal injury from leaking hot oil.



WARNING

Keep body and hands away from pin hole leaks or nozzles that eject hydraulic fluid under high pressure. Do not use hands to search for leaks; use paper or cardboard. Hydraulic fluid escaping under pressure can have sufficient force to penetrate the skin and cause serious injury. If fluid is injected into the skin, it must be surgically removed within a few hours by a doctor familiar with this type of injury. Gangrene may result from such an injury.



WARNING

Before disconnecting or performing any work on the hydraulic system, all pressure in the system must be relieved. See Relieving Hydraulic System Pressure in the General Information section in this chapter.



CAUTION

All testing should be performed by two (2) people. One person should be in the seat to operate the machine, and the second person should read test instruments and record test results.

Precautions for Hydraulic Testing

1. Clean machine thoroughly before disconnecting or disassembling any hydraulic components. Always keep in mind the need for cleanliness when working on hydraulic equipment. Contamination will cause excessive wear of components.
2. Before conducting a hydraulic test, make sure hydraulic oil is at normal operating temperature by operating the machine under load for approximately ten (10) minutes.
3. Put metal caps or plugs on any hydraulic lines left open or exposed during testing or removal of components.
4. The engine must be in good operating condition. Use a phototac to determine engine speed when performing a hydraulic test. Engine speed will affect the accuracy of the tester readings. See Chapter 3 – Yanmar Diesel Engine for engine speed specifications.
5. When using the hydraulic tester with flow and pressure capabilities, the inlet and the outlet hoses must be properly connected and not reversed to prevent damage to the hydraulic tester or components.
6. When using the hydraulic tester with flow and pressure capabilities, completely open flow control valve on tester before starting the engine to minimize the possibility of damaging components.
7. Install fittings finger tight and far enough to make sure that they are not cross-threaded before tightening them with a wrench.
8. Position tester hoses to prevent rotating machine parts from contacting and damaging the hoses or tester.
9. Check oil level in the hydraulic reservoir. After connecting test equipment, make sure reservoir is full.
10. Check control linkages for improper adjustment, binding or broken parts.
11. After installing test gauges, run engine at low idle speed and check for any hydraulic oil leaks. Correct any leaks before proceeding with test procedure.
12. Before returning machine to use, make sure that hydraulic reservoir has correct fluid level.

Which Hydraulic Tests Are Necessary?

Before beginning any hydraulic test, identify if the problem is related to the traction circuit, cutting (mow) circuit, lift/lower circuit, steering circuit or engine cooling fan circuit. Once the faulty system has been identified, perform tests that relate to that circuit.

1. If a traction circuit problem exists, consider performing one or more of the following tests: Traction Circuit Charge Pressure, Traction Circuit Relief Pressure, Counterbalance Pressure, Reverse Traction Circuit Reducing Valve (PR) Pressure, Rear Traction Circuit Relief Valve (RV) Pressure, Piston (Traction) Pump Flow and/or Gear Pump Flow Tests.

IMPORTANT: Refer to Traction Circuit Component Failure in the General Information section of this chapter for information regarding the importance of removing contamination from the traction circuit.


2. If a cutting (mow) circuit problem exists, consider performing one or more of the following tests: Cutting Deck Circuit Pressure, PTO Relief Pressure, Cutting Deck Motor Case Drain Leakage and/or Gear Pump Flow Tests.

3. If a lift/lower circuit problem exists, consider performing one or more of the following tests: Lift/Lower Circuit Relief Pressure and/or Gear Pump Flow Tests.

4. If a steering circuit problem exists, consider performing one or more of the following tests: Steering Circuit Relief Pressure, Steering Cylinder Internal Leakage and/or Gear Pump Flow Tests.

5. If a engine cooling fan circuit problem exists, consider performing one or more of the following tests: Engine Cooling Fan Circuit and/or Gear Pump Flow Tests.

Traction Circuit Charge Pressure (Using Pressure Gauge)



The traction charge circuit is designed to replace loss of hydraulic fluid from the closed loop traction circuit. This test is used to make sure that traction charge pressure is correct.

Procedure for Traction Circuit Charge Pressure Test

	CAUTION
Prevent personal injury and/or damage to equipment. Read all WARNINGS, CAUTIONS and Precautions for Hydraulic Testing at the beginning of this section.	

1. Park machine on a level surface with the cutting decks lowered and off. Make sure hydraulic oil is at normal operating temperature, engine is off and the parking brake is applied.

2. Raise and support operator seat.

3. Connect a 1000 PSI (70 bar) pressure gauge to test fitting attached to tee fitting in final section of gear pump (Fig. 27).

NOTE: Make sure that steering wheel is not turned during charge pressure testing. Also, if engine coolant temperature is elevated, gear pump flow from the final pump section might be directed to the cooling fan motor which may affect charge pressure testing results.

4. Start engine and increase engine speed to high idle speed with no load on the hydraulic system.

GAUGE READING TO BE 200 to 300 PSI (13.8 to 20.6 bar).

5. Stop engine and record test results.

6. If there is no pressure or pressure is low, check for restriction in gear pump intake line. Also, inspect charge relief valve located in piston (traction) pump (see Piston (Traction) Pump Service in the Service and Repairs section of this chapter). A worn or damaged gear pump section could also be considered (see Gear Pump Flow Test in this section).

NOTE: If the gear pump section that supplies the charge circuit is worn or damaged, charge, steering, lift/lower and engine cooling fan circuits may all be affected.

7. Next, with the pressure gauge still connected to the charge pressure test port, take a gauge reading while operating the machine in forward and reverse. Start the engine and put throttle at high idle speed. Apply the brakes and push the traction pedal forward while monitoring the pressure gauge. Repeat for reverse direction. Stop engine and record test results.

8. If charge pressure meets specifications under no load conditions (step 5 above), but consistently drops more than 15% when under traction load, the piston (traction) pump and/or traction motor(s) should be suspected of wear and inefficiency. When the pump or motors are worn or damaged, the charge pump is not able to keep up with internal leakage in the traction system components.

9. When testing is completed, disconnect pressure gauge from test fitting. Secure dust cap to test fitting.

10. Lower and secure operator seat.





Figure 27

- | | |
|---------------------------|-------------------------|
| 1. Piston (traction) pump | 3. Charge pressure port |
| 2. Gear pump | |

Traction Circuit Relief Pressure (Using Pressure Gauge)



Procedure for Traction Circuit Relief Pressure Test

NOTE: The traction charge circuit is designed to replace loss of hydraulic fluid from the closed loop traction circuit.

**CAUTION**

Prevent personal injury and/or damage to equipment. Read all WARNINGS, CAUTIONS and Precautions for Hydraulic Testing at the beginning of this section.

1. Park machine on a level surface with the cutting decks lowered and off. Make sure hydraulic oil is at normal operating temperature, engine is off and the parking brake is applied.

**CAUTION**

When performing the traction circuit relief pressure test, move machine to an open area, away from people and obstructions.

2. Drive machine to an open area, lower cutting decks, turn the engine off and apply the parking brake.

3. Connect a 10,000 PSI (700 bar) pressure gauge to traction circuit test port for function to be checked (Fig. 28 or 29).

4. Start engine and increase engine speed to high idle speed. Release parking brake. Make sure that HI/LOW speed switch is in the HI (transport) position.

NOTE: If possible, turn off Smart Power™ by using the InfoCenter display protected menu. Machines with TEC software above revision level G will allow Smart Power™ to be disabled for testing. Check software revision level using the InfoCenter About screen.

5. Sit on seat, apply brakes fully and slowly depress the traction pedal in the appropriate direction (forward or reverse). While pushing traction pedal, look at pressure reading on gauge:

GAUGE READING TO BE:

Forward: **4100 to 4600 PSI (283 to 317 bar)**

Reverse: **4750 to 5250 PSI (328 to 362 bar)**

6. Release traction pedal and stop engine. Record test results.

7. If traction pressure is too low, inspect traction pump relief valves (Fig. 28 or 29). Clean or replace relief valves as necessary. These cartridge type valves are factory set, and are not adjustable. If relief valves are in good condition, traction pump or wheel motors should be suspected of wear and inefficiency.

8. When testing is completed, disconnect pressure gauge from test port. Secure dust cap to test fitting.




Figure 28

1. Forward traction port 2. Forward relief valve





Figure 29

1. Reverse traction port 2. Reverse relief valve

Counterbalance Pressure (Using Pressure Gauge)



Procedure for Counterbalance Pressure Test



CAUTION

Prevent personal injury and/or damage to equipment. Read all WARNINGS, CAUTIONS and Precautions for Hydraulic Testing at the beginning of this section.

1. Park machine on a level surface with the cutting decks lowered and off. Make sure hydraulic oil is at normal operating temperature, engine is off and the parking brake is applied.

2. Raise and support operator seat to gain access to combination manifold.

3. Connect a 1000 PSI (70 bar) pressure gauge to test port G1 on combination manifold (Fig. 30).

NOTE: The cutting decks need to be in the float position when checking counterbalance pressure. Also, make sure that all of the cutting deck castor wheels are on the ground when testing or adjusting counterbalance pressure.

IMPORTANT: While testing counterbalance pressure, DO NOT raise any of the cutting decks. If decks are raised, system pressure increase will damage pressure gauge.

4. Start engine and increase engine speed to high idle speed with no load on the hydraulic system. **Do not engage the cutting decks.**

GAUGE READING TO BE **approximately 325 PSI (22.4 bar)**.

NOTE: The recommended counterbalance pressure for your Groundsmaster is **325 PSI (22.4 bar)**.

5. Stop engine and record test results.

6. The pressure reducing valve on the combination manifold is used to set the counterbalance pressure (Fig. 31). If necessary, adjust pressure reducing valve:

NOTE: Because of valve design, the pressure reducing valve can be adjusted with the engine running. Do not remove the pressure reducing valve from the hydraulic manifold for adjustment.

A. Locate pressure reducing valve on combination manifold (Fig. 31). Loosen lock nut on pressure reducing valve.

B. Start engine and increase engine speed to high idle speed with no load on the hydraulic system. **Do not engage the cutting decks.**

C. To **increase** pressure setting, turn the adjustment screw on the valve in a clockwise direction. A 1/8 turn on the screw will make a measurable change in counterbalance pressure.

D. To **decrease** pressure setting, turn the adjustment screw on the valve in a counterclockwise direction. A 1/8 turn on the screw will make a measurable change in counterbalance pressure.

E. Tighten lock nut to secure adjustment. Check counterbalance pressure and readjust as needed.

7. When testing is completed, disconnect pressure gauge from manifold test port. Secure dust cap to test fitting. Lower operator seat.




Figure 30

- 1. Combination manifold
- 2. Test port G1
- 3. Pressure reducing valve





Figure 31

- 1. Combination manifold
- 2. Pressure reducing valve
- 3. Adjustment screw

Reverse Traction Circuit Reducing Valve (PR) Pressure (Using Pressure Gauge)



Procedure for Reverse Traction Circuit Reducing Valve (PR) Pressure Test

NOTE: When in reverse, pressure reducing valve (PR) limits the pressure to the rear axle motor to 380 PSI (26 bar) so the rear wheels will not scuff the turf.



CAUTION

Prevent personal injury and/or damage to equipment. Read all WARNINGS, CAUTIONS and Precautions for Hydraulic Testing at the beginning of this section.

1. Park machine on a level surface with the cutting decks lowered and off. Make sure hydraulic oil is at normal operating temperature, engine is off and the parking brake is applied.

NOTE: The #6 zero leak plug on the inside of rear traction manifold is a zero leak plug that has a tapered sealing surface on the plug head. Lightly rap the plug head using a punch and hammer before using an allen wrench to remove the plug; the impact will allow plug removal with less chance of damage to the socket head of the plug.

2. Locate rear traction manifold that is attached to the front frame next to the left side front wheel (Fig. 32). Remove #6 zero leak plug on the inside of rear traction manifold and install diagnostic fitting (Toro part number 59-7410) into manifold port.

3. Connect a 1000 PSI (70 bar) pressure gauge with hydraulic hose attached to installed diagnostic fitting.

4. Start engine and increase engine speed to high idle speed. Make sure that HI/LOW speed switch is in the LOW speed (mow) position and release parking brake.

5. Sit on seat, apply brakes fully and slowly depress the traction pedal in the reverse direction. While pushing traction pedal, carefully monitor the pressure gauge to identify the opening pressure of the pressure reducing (PR) valve:

GAUGE READING TO BE approximately **380 PSI (26 bar)** when the pressure reducing (PR) valve opens.

6. Stop engine and record test results.

7. The pressure reducing (PR) valve is located on the rear side of the rear traction manifold (Figs. 32 and 33). If test pressure is incorrect, adjust pressure reducing (PR) valve (see Adjust Control Manifold Relief Valves in the Adjustments section of this chapter). Recheck pressure reducing valve pressure after any adjustment.

NOTE: The rear traction circuit relief valve (RV) pressure test uses the same pressure gauge position as used to measure reverse traction circuit reducing valve (PR) pressure. If necessary, conduct the rear traction circuit relief valve (RV) pressure test before removing pressure gauge from rear traction manifold.

8. When testing is completed, disconnect pressure gauge from the installed diagnostic fitting. Remove diagnostic fitting from manifold and install removed plug into manifold. Torque plug to **25 ft-lb (34 N-m)**.




Figure 32

- | | |
|---------------------------|------------------------|
| 1. Rear traction manifold | 3. Relief (RV) valve |
| 2. #6 zero leak plug | 4. Reducing (PR) valve |





Figure 33

- | | |
|---------------------------|------------------------|
| 1. Rear traction manifold | 3. Relief (RV) valve |
| 2. #6 zero leak plug | 4. Reducing (PR) valve |

Rear Traction Circuit Relief Valve (RV) Pressure (Using Pressure Gauge)



Procedure for Rear Traction Circuit Relief Valve (RV) Pressure Test

NOTE: Adjustable relief valve (RV) in the rear traction control manifold reduces rear axle motor pressure created in down hill, dynamic braking conditions to prevent rear wheel lock up.

**CAUTION**

Prevent personal injury and/or damage to equipment. Read all WARNINGS, CAUTIONS and Precautions for Hydraulic Testing at the beginning of this section.

1. Park machine on a level surface with the cutting decks lowered and off. Make sure hydraulic oil is at normal operating temperature, engine is off and the parking brake is applied.

NOTE: This test uses the same pressure gauge position as used to measure reverse traction circuit reducing valve (PR) pressure.

NOTE: The #6 zero leak plug on the inside of rear traction manifold is a zero leak plug that has a tapered sealing surface on the plug head. Lightly rap the plug head using a punch and hammer before using an allen wrench to remove the plug; the impact will allow plug removal with less chance of damage to the socket head of the plug.

2. Locate rear traction manifold that is attached to the front frame next to the left side front wheel (Fig. 34). Remove #6 zero leak plug on inside of rear traction manifold and install diagnostic fitting (Toro part number 59-7410) into manifold port.

3. Connect a 1000 PSI (70 bar) pressure gauge with hydraulic hose attached to installed diagnostic fitting.

4. Start engine and increase engine speed to high idle speed. Make sure that HI/LOW switch is in the LOW (mow) position and release the parking brake.

5. Operate the machine in LOW speed (mow) with the cutting decks lowered. Drive down a slope in a forward direction, decrease pressure on the traction pedal and monitor the pressure gauge. Pressure should increase until the rear traction circuit relief valve lifts.

GAUGE READING TO BE approximately **650 PSI (45 bar)** when the rear traction relief valve (RV) opens.

6. Stop engine and record test results.

NOTE: If the rear traction circuit reducing valve (PR) pressure is excessive, operation of the rear traction relief valve (RV) may be affected. Before adjusting rear traction relief valve (RV), make sure that pressure reducing valve (PR) pressure is correct.

7. The rear traction circuit relief valve (RV) is located on the rear side of the rear traction manifold (Figs. 34 and 35). If test pressure is incorrect, adjust relief valve (RV) (see Adjust Control Manifold Relief Valves in the Adjustments section of this chapter).

8. When testing is completed, disconnect pressure gauge from the installed diagnostic fitting. Remove diagnostic fitting from manifold and install removed plug into manifold. Torque plug to **25 ft-lb (34 N-m)**.




Figure 34

- | | |
|---------------------------|------------------------|
| 1. Rear traction manifold | 3. Relief (RV) valve |
| 2. #6 zero leak plug | 4. Reducing (PR) valve |




Figure 35

- | | |
|---------------------------|------------------------|
| 1. Rear traction manifold | 3. Relief (RV) valve |
| 2. #6 zero leak plug | 4. Reducing (PR) valve |

Procedure for Piston (Traction) Pump Flow Test


This test measures piston (traction) pump output (flow). During this test, pump load is created at the flow meter using the adjustable load valve on the tester.

NOTE: Before performing piston pump flow test, make sure that traction speed is set to 100% using the InfoCenter settings menu.

IMPORTANT: Traction circuit flow for the Groundsmaster 4000/4010 is approximately 30 GPM (113.5 LPM). Use 40 GPM Hydraulic Tester #AT4002 (pressure and flow) for this test (see Special Tools in this chapter).



1. Park machine on a level surface with the cutting decks lowered and off. Make sure hydraulic oil is at normal operating temperature, engine is off and the parking brake is applied.



2. Raise and support machine so all wheels are off the ground (see Jacking Instructions in Chapter 1 – Safety).

3. Thoroughly clean junction of hydraulic hose and **right** side fitting on bottom of piston pump (forward port) (Fig. 36). Disconnect hose from right side pump fitting.

4. Install tester with pressure gauge and flow meter in series between piston pump fitting and disconnected hose to allow flow from traction pump to tester. Use hydraulic hose kit (see Special Tools in this chapter) to connect tester to machine. Make sure that fitting and hose connections are properly tightened. Also, make sure the flow control valve on tester is fully open.

5. Start engine and adjust engine speed to high idle speed.

NOTE: If possible, turn off Smart Power™ by using the InfoCenter display protected menu. Machines with TEC software above revision level G will allow Smart Power™ to be disabled for testing. Check software revision level using the InfoCenter About screen.

6. Slowly push traction pedal to fully forward position. Keep pedal fully depressed in the fully forward position.

7. Have second person watch pressure gauge on tester carefully while slowly closing the flow control valve until **1000 PSI (69 bar)** is obtained. Verify with the InfoCenter display that the engine speed is still at the correct high idle speed.

NOTE: If engine speed drops during testing, pump flow will decrease and flow test results will be inaccurate.

8. Observe flow gauge. Flow indication should be approximately **30 GPM (113 LPM)**.

9. Release traction pedal to neutral, open flow control valve on tester and shut off engine. Record test results.

10. If flow is less than **24 GPM (91 LPM)**, consider the following:

A. The traction pedal is not calibrated correctly (see Traction Pedal Calibration in the Adjustments section of Chapter 5 – Electrical System).

B. The piston pump swash plate is not being rotated fully (e.g. traction speed is not set to 100%).

C. The forward traction relief valve is faulty.

D. The piston pump needs to be repaired or replaced as necessary.

11. Make necessary repairs before performing any additional traction circuit tests.

12. When testing is complete, disconnect tester from pump fitting and machine hydraulic hose. Reconnect hose to pump fitting. Lower machine to ground.





Figure 36

1. Piston (traction) pump 2. Forward direction hose

Cutting Deck Circuit Pressure (Using Pressure Gauge)

FRONT DECK CIRCUIT PRESSURE TEST SHOWN



Procedure for Cutting Deck Circuit Pressure Test



CAUTION

Prevent personal injury and/or damage to equipment. Read all WARNINGS, CAUTIONS and Precautions for Hydraulic Testing at the beginning of this section.

1. Park machine on a level surface with the cutting decks lowered and off. Make sure hydraulic oil is at normal operating temperature, engine is off and the parking brake is applied.

2. Install 5000 PSI (350 bar) pressure gauge with hydraulic hose attached to manifold test port (G) for the deck to be tested (Fig. 37).



CAUTION

Cutting deck blades will rotate when cutting decks are lowered with PTO switch in ON position. Keep away from decks during test to prevent personal injury from rotating blades. Do not stand in front of the machine.

3. Start engine and increase engine speed to high idle speed. Release the parking brake.

4. Watch pressure gauge carefully while mowing with the machine.

5. Cutting deck circuit pressure should be as follows and will vary depending on mowing conditions:

LH Deck: 1000 to 3000 PSI (69 to 207 bar)

Center Deck: 1000 to 3000 PSI (69 to 207 bar)

RH Deck: 1000 to 2000 PSI (69 to 137 bar)

6. Disengage cutting decks. Shut off engine and record test results.

7. When testing is completed, disconnect pressure gauge with hose from manifold test fitting. Secure dust cap to test fitting.





Figure 37

1. PTO manifold (front) 2. Manifold test port

PTO Relief Pressure (Using Tester with Pressure Gauge and Flow Meter)



The PTO circuit relief pressure test should be performed to make sure that the PTO circuit relief pressures are correct.

Procedure for PTO Relief Pressure Test



CAUTION


Prevent personal injury and/or damage to equipment. Read all WARNINGS, CAUTIONS and Precautions for Hydraulic Testing at the beginning of this section.

1. Park machine on a level surface with the cutting decks lowered and off. Make sure hydraulic oil is at normal operating temperature, engine is off and the parking brake is applied.

2. Locate PTO (deck) manifold to be tested (Fig. 38). Disconnect hydraulic hose at PTO manifold port (M1).

NOTE: An alternative to using manifold port (M1) would be to disconnect the inlet hydraulic hose to the deck motor.

3. Install tester (flow and pressure) in series with the disconnected hose and PTO manifold port (M1) (or motor inlet if hose was disconnected at deck motor). Make sure the flow control valve on tester is fully open.



CAUTION

Cutting deck blades will rotate when cutting decks are lowered with PTO switch in ON position. Keep away from cutting decks during test to prevent personal injury from rotating blades. Do not stand in front of the machine.

4. Start engine and increase engine speed to high idle speed. Release the parking brake.

5. Watch pressure gauge carefully while slowly closing the tester flow control valve to fully closed.

6. As the PTO relief valve lifts, system pressure should be approximately:

2900 to 3100 PSI (200 to 213 bar) for the center and left decks

1900 to 2100 PSI (131 to 144 bar) for the right deck

7. Fully open tester flow control valve and disengage cutting decks. Shut off engine and record test results.

8. If relief pressure is incorrect, remove PRV valve on mow manifold and clean or replace valve (see PTO Manifold Service in the Service and Repairs section of this chapter). Also, if pressure is still low after PRV valve service, check for restriction in pump intake line. The front gear pump section (center cutting deck circuit) and/or the second gear pump section (side cutting deck circuits) could also be suspected of wear, damage or inefficiency (see Gear Pump Flow Test in this section).

9. When relief pressure testing is complete, disconnect tester from PTO manifold and hydraulic hose. Reconnect hydraulic hose that was disconnected for test procedure.




Figure 38

- 1. Center PTO manifold
- 2. LH PTO manifold
- 3. RH PTO manifold





Figure 39

- 1. PTO manifold
- 2. PRV valve

Cutting Deck Motor Case Drain Leakage (Using Tester with Pressure Gauge and Flow Meter)

CENTER CUTTING DECK MOTOR CASE DRAIN LEAKAGE TEST SHOWN



GPM	Milliliters in 15 sec.	Ounces in 15 sec.
.1	95	3.2
.2	189	6.4
.3	284	9.6
.4	378	12.8
.5	473	16.0
.6	568	19.2
.7	662	22.4
.8	756	25.6
.9	852	28.8
1.0	946	32.0

Procedure for Cutting Deck Motor Case Drain Leakage Test

NOTE: Over a period of time, a deck motor can wear internally. A worn motor may by-pass oil to its case drain causing the motor to be less efficient. Eventually, enough oil loss will cause the deck motor to stall under heavy cutting conditions. Continued operation with a worn, inefficient motor can generate excessive heat, cause damage to seals and other components in the hydraulic system and affect quality of cut.

NOTE: One method to find a failing or malfunctioning deck motor is to have another person observe the machine while mowing in dense turf. A bad motor will run slower, produce fewer clippings and may cause a different appearance on the turf.

**CAUTION**


Prevent personal injury and/or damage to equipment. Read all WARNINGS, CAUTIONS and Precautions for Hydraulic Testing at the beginning of this section.

1. Park machine on a level surface with the cutting decks lowered and off. Make sure hydraulic oil is at normal operating temperature, engine is off and the parking brake is applied.

NOTE: The side deck motors are connected in series. To isolate a faulty side deck motor, both motors in the circuit may have to be tested by starting with the left side motor first.

2. Disconnect hose from return of the motor to be tested (Fig. 40). Install tester (flow and pressure) in series with the motor and disconnected return hose. Make sure the flow control valve on tester is fully open.

3. Disconnect the motor case drain hose (small diameter hose) where it connects to hydraulic manifold tee fitting (not at the motor). Put a steel cap on the fitting at the tee fitting; leave the case drain hose open.

**CAUTION**

Cutting deck blades will rotate when cutting decks are lowered with PTO switch in ON position. Keep away from cutting decks during test to prevent personal injury from rotating blades. Do not stand in front of the machine.

4. Sit on seat and start the engine. With engine running, increase engine speed to high idle speed and release the parking brake. Engage the cutting decks.

5. While watching pressure gauge, slowly close flow control valve on tester until a pressure of **1200 PSI (83 bar)** is obtained.

NOTE: Use a graduated container, special tool TOR4077, to measure case drain leakage (Fig. 41).

6. Have a second person collect the flow from the case drain line for **15 seconds**, then move the PTO switch to OFF and stop the engine (Fig. 41). Record test results.

TEST RESULTS: Flow less than **22.4 ounces (662 ml) (0.7 GPM/2.6 LPM)** of hydraulic fluid in 15 seconds.

7. If flow is more than **22.4 ounces (662 ml) (0.7 GPM/2.6 LPM)** in 15 seconds, the motor is worn or damaged and should be repaired or replaced.

8. After testing is completed, disconnect tester from motor and hose. Reconnect hose to the deck motor. Remove cap from tee fitting and reconnect case drain hose to tee fitting.




Figure 40

- 1. Deck motor (RH shown)
- 2. Return hose
- 3. Case drain hose




Figure 41

The lift/lower circuit relief pressure test should be performed to make sure that the cutting unit lift and lower circuit relief pressure is correct.

Procedure for Lift/Lower Circuit Relief Pressure Test

NOTE: Before attempting to check or adjust lift/lower circuit relief pressure, make sure that counterbalance pressure is correctly adjusted (see Counterbalance Pressure Test in this section).

**CAUTION**

Prevent personal injury and/or damage to equipment. Read all WARNINGS, CAUTIONS and Precautions for Hydraulic Testing at the beginning of this section.

1. Park machine on a level surface with the cutting decks lowered and off. Make sure hydraulic oil is at normal operating temperature, engine is off and the parking brake is applied.

2. Raise and support operator seat.

3. Connect a 5,000 PSI (345 bar) pressure gauge to test fitting attached to tee fitting in third section of gear pump (Fig. 42).

4. Sit on the seat and start the engine. With engine running, increase engine speed to high idle speed.

5. While sitting on the seat, depress the rear of one of the lift switches to fully raise the cutting deck. Momentarily hold the switch with the deck fully raised while watching the pressure gauge.

GAUGE READING TO BE approximately **1550 to 1650 PSI (107 to 113 bar)**.

6. Release the lift switch, stop the engine and record test results.

7. If specification is not met, clean or adjust relief valve RV2 located in the combination control manifold (see Combination Manifold Service in the Service and Repairs section of this chapter).

A. If relief pressure is too high, adjust relief valve RV2 to reduce lift/lower circuit relief pressure (see Adjust Control Manifold Relief Valves in the Adjustments section of this chapter).

B. If relief pressure is too low, check for restriction in gear pump intake line. Check the lift cylinders for internal leakage. If pump intake line is not restricted and lift cylinders are not leaking, adjust relief valve RV2 to increase lift/lower circuit relief pressure (see Adjust Control Manifold Relief Valves in the Adjustments section of this chapter).

C. If pressure is still too low after relief valve adjustment, lift cylinder(s) or the third section of the gear pump should be suspected of wear or damage.

8. When relief pressure testing is completed, disconnect pressure gauge from test fitting. Secure dust cap to test fitting.

9. Lower and secure operator seat.




Figure 42

- | | |
|---|-------------------------|
| 1. Gear pump | 3. Combination manifold |
| 2. 3 rd section test fitting | 4. Relief valve RV2 |




Figure 43

- | | |
|-------------------------|---------------------|
| 1. Combination manifold | 2. Relief valve RV2 |
|-------------------------|---------------------|

The steering circuit relief pressure test should be performed to make sure that the steering circuit relief pressure is correct.

Procedure for Steering Circuit Relief Pressure Test



CAUTION

Prevent personal injury and/or damage to equipment. Read all WARNINGS, CAUTIONS and Precautions for Hydraulic Testing at the beginning of this section.

1. Park machine on a level surface with the cutting deck lowered and off. Make sure hydraulic oil is at normal operating temperature, engine is off and the parking brake is applied.
2. Raise and support operator seat.
3. Connect a 5000 PSI (350 bar) pressure gauge to test fitting attached to tee fitting in final section of gear pump (Fig. 44).
4. Start engine and increase engine speed to high idle speed.

IMPORTANT: Hold steering wheel at full lock only long enough to get a system relief pressure reading. Holding the steering wheel against the stop for an extended period can damage the steering control valve.

5. Turn steering all the way in one direction and momentarily hold the steering wheel against resistance.

GAUGE READING TO BE 1300 to 1400 PSI (90 to 96 bar).

6. Stop the engine and record test results.

7. If pressure is incorrect, inspect steering relief valve in steering control valve (see Steering Control Valve in the Service and Repairs section of this chapter). If relief valve is operating properly and if lift/lower problems also exist, flow divider in fan manifold and/or gear pump (third section) should be suspected of wear and inefficiency. If steering wheel continues to turn at end of cylinder travel (with lower than normal effort), steering cylinder or steering control valve should be suspected of wear or damage.

8. When testing is completed, disconnect pressure gauge from test fitting. Secure dust cap to test fitting.

9. Lower and secure operator seat.





Figure 44

- | | |
|---------------------------|-----------------|
| 1. Piston (traction) pump | 3. Test fitting |
| 2. Gear pump | |

Steering Cylinder Internal Leakage



The steering cylinder internal leakage test should be performed if a steering problem is identified. This test will determine if the steering cylinder is faulty.

Procedure for Steering Cylinder Internal Leakage Test

NOTE: Steering circuit operation will be affected by rear tire pressure, binding of steering cylinder, extra weight on the vehicle and/or binding of rear axle steering components. Make sure that these items are checked before proceeding with steering cylinder internal leakage test.



1. Park machine on a level surface with the cutting decks lowered and off. Make sure hydraulic oil is at normal operating temperature, engine is off and the parking brake is applied.
2. Turn the steering wheel for a right turn so that the steering cylinder rod is fully extended.
3. Thoroughly clean the area around the hydraulic hose at the rod end of the steering cylinder.

4. Place a drain pan under the steering cylinder. Remove hydraulic hose from the fitting on the rod end of the steering cylinder. Install a steel plug in the disconnected hose. Leave cylinder fitting open.

5. Remove all hydraulic oil from drain pan. Make sure that empty drain pan remains under the open fitting of the steering cylinder.


6. With the engine off, turn the steering wheel for a right turn. Observe the open fitting on the extended steering cylinder as the steering wheel is turned. If oil comes out of the fitting while turning the steering wheel, the steering cylinder has internal leakage and must be repaired (see Steering Cylinder and Steering Cylinder Service in the Service and Repairs section of this chapter). Check drain pan for any evidence of oil that would indicate cylinder leakage.

7. If a steering problem exists and the steering cylinder tested acceptably, the steering control valve requires service (see Steering Control Valve and Steering Control Valve Service in the Service and Repairs section of this chapter).

8. After testing is completed, remove plug from the hydraulic hose. Connect hose to the steering cylinder fitting.

9. Check oil level in hydraulic reservoir and adjust if needed.

Engine Cooling Fan Circuit (Using Pressure Gauge and Phototac)



The cooling fan circuit test should be performed to make sure that the engine cooling fan circuit has the correct system pressure and fan speed.

Procedure for Engine Cooling Fan Circuit Test

	CAUTION
Prevent personal injury and/or damage to equipment. Read all WARNINGS, CAUTIONS and Precautions for Hydraulic Testing at the beginning of this section.	

1. Park machine on a level surface with the cutting decks lowered and off. Make sure hydraulic oil is at normal operating temperature, engine is off and the parking brake is applied.

2. Raise and support hood to gain access to the hydraulic tubes that supply hydraulic flow to engine cooling fan motor (Fig. 45). Connect a 5,000 PSI (345 bar) pressure gauge with hydraulic hose attached to test port on hydraulic tube connected in the upper location on radiator shroud.

3. Raise seat to gain access to the combination manifold (Fig. 46). Locate PRV and S11 solenoid valves on manifold.

4. Have a phototac available to identify cooling fan speed once engine is running.

5. Start engine and increase engine speed to high idle speed. **DO NOT engage the cutting decks.**

6. While monitoring the pressure gauge and using the phototac to identify the cooling fan speed, disconnect the wire harness connectors from the PRV solenoid (white/green and black wires) and S11 solenoid (violet and black wires) on combination manifold (Fig. 46). Both fan speed and pressure should increase and stabilize after the solenoids are disconnected.

PRESSURE GAUGE READING TO BE approximately **3250 PSI (224 bar)**.

PHOTOTAC READING (FAN SPEED) TO BE approximately **2800 to 3000 RPM**.

NOTE: The cooling fan speed will depend on hydraulic oil temperature. Higher oil temperatures will result in slower fan speed.

7. Stop engine and record test results.

8. If circuit pressure rises to approximately **3250 PSI (224 bar)** but fan speed is low, consider that the fan motor is worn or damaged. If pressure and fan speed are both low, consider that the gear pump section is worn or damaged (see Gear Pump Flow Test in this section).

NOTE: If pressure and fan speed are both low and gear pump flow proves to be correct, suspect that engine cooling fan circuit cartridge valve seals in combination manifold (e.g. S10, S11, PRV) are leaking or faulty (see Combination Manifold Service in the Service and Repairs section of this chapter).

9. When testing is complete, remove pressure gauge from hydraulic tube test port and reconnect wire harness connectors to PRV and S11 solenoids. Lower and secure hood and operator seat.




Figure 45

1. Upper hydraulic tube 2. Test port





Figure 46

1. Combination manifold 3. S11 solenoid
2. PRV solenoid

Gear Pump Flow (Using Tester with Pressure Gauge and Flow Meter)



The gear pump flow test should be performed to make sure that the mow, steering, lift/lower, cooling fan and traction charge circuits have adequate hydraulic flow. The front gear pump section provides hydraulic flow for the side cutting decks (Fig. 47). The second gear pump section provides hydraulic flow for the center cutting deck. The third gear pump section provides hydraulic flow for the cooling fan, lift/lower and traction charge circuits. The fourth gear pump section provides hydraulic flow for the steering, traction charge and cooling fan circuits.

NOTE: Over a period of time, the gears and wear plates in the gear pump can wear. A worn pump will by pass oil and make the pump less efficient. Eventually, enough oil loss will occur to cause circuit problems (e.g. cutting deck motors stalling under heavy cutting conditions, lift or steering problems). Continued operation with a worn, inefficient gear pump can generate excessive heat and cause damage to the seals and other components in the hydraulic system.

Procedure for Gear Pump Flow Test



CAUTION

Prevent personal injury and/or damage to equipment. Read all WARNINGS, CAUTIONS and Precautions for Hydraulic Testing at the beginning of this section.

1. Park machine on a level surface with the cutting decks lowered and off. Make sure hydraulic oil is at normal operating temperature, engine is off and the parking brake is applied.
2. Raise and support operator seat to gain access to gear pump.
3. Determine which gear pump section is to be tested. Disconnect hydraulic hose from fitting in gear pump section that is to be tested (Fig. 47).
4. Install tester (flow and pressure) in series with the disconnected hose and hydraulic fitting in gear pump section.
5. Make sure the flow control valve on tester is fully open.
6. Start engine and increase engine speed to high idle speed. **Do not engage the cutting decks.**
7. Watch pressure gauge carefully while slowly closing the flow control valve until **1000 PSI (69 bar)** is obtained. Verify with the InfoCenter display that the engine is still running at the correct high idle speed.

NOTE: If engine speed drops during testing, pump flow will decrease and flow test results will be inaccurate.

8. Normal flow indication for the four (4) gear pump sections is listed in Figure 48.
9. Shut off engine and record test results.

10. If a pressure of **1000 PSI (69 bar)** cannot be obtained or flow was less than the minimum flow listed in Figure 48, check for restriction in the pump intake line. If line is not restricted, consider that the tested gear pump section is worn or damaged.

11. After testing is completed, disconnect flow tester from hydraulic hose and fitting in gear pump section. Reconnect hose to the pump fitting.

12. Lower and secure operator seat.




Figure 47

1. Front pump section (LH and RH PTO)
2. 2nd pump section (front PTO)
3. 3rd pump section (cooling fan, lift/lower and charge)
4. 4th pump section (steering, charge and cooling fan)

PUMP SECTION	NORMAL FLOW	MINIMUM FLOW
FRONT SECTION	14 GPM (53 LPM)	11 GPM (41.6 LPM)
SECOND SECTION	14 GPM (53 LPM)	11 GPM (41.6 LPM)
THIRD SECTION	4.3 GPM (16.3 LPM)	3.4 GPM (12.8 LPM)
FOURTH SECTION	3.2 GPM (12.1 LPM)	2.5 GPM (9.5 LPM)

Figure 48

Adjustments

Adjust Control Manifold Relief Valves

Several of the hydraulic control manifolds on your Groundsmaster include adjustable relief valves. The following procedure can be used to adjust these relief valves. Refer to the Testing section of this chapter for information on testing relief pressure.

NOTE: Do not remove relief valve from the hydraulic manifold for adjustment.

1. Locate relief valve on control manifold.
2. Remove cap on relief valve with an allen wrench.
3. To **increase** pressure setting, turn the adjustment socket on the valve in a clockwise direction. A 1/8 turn on the socket will make a measurable change in relief pressure.
4. To **decrease** pressure setting, turn the adjustment socket on the valve in a counterclockwise direction. A 1/8 turn on the socket will make a measurable change in relief pressure.
5. Install and tighten cap on relief valve.
6. Recheck relief pressure and readjust as needed.




Figure 49

1. Relief valve cap

2. Adjustment socket

Service and Repairs

General Precautions for Removing and Installing Hydraulic System Components

Before Repair or Replacement of Components

1. Before removing any parts from the hydraulic system, park machine on a level surface, apply parking brake, lower cutting decks or attachments and stop engine. Remove key from the ignition switch.
2. Clean machine before disconnecting, removing or disassembling any hydraulic components. Make sure that all hydraulic components, hose connections and fittings are cleaned thoroughly. Always keep in mind the need for cleanliness when working on hydraulic equipment.



WARNING

Before disconnecting or performing any work on the hydraulic system, all pressure in the system must be relieved. See Relieving Hydraulic System Pressure in the General Information section in this chapter.

3. Put caps or plugs on any hydraulic lines, hydraulic fittings and components left open or exposed to prevent contamination.
4. Put labels on disconnected hydraulic lines and hoses for proper installation after repairs are completed.
5. Note the position of hydraulic fittings (especially elbow fittings) on hydraulic components before removal. Mark parts if necessary to make sure they will be aligned properly when installing hydraulic hoses and tubes.

After Repair or Replacement of Components

1. Check oil level in the hydraulic reservoir and add correct oil if necessary. Drain and refill hydraulic system reservoir and change oil filters if component failure was severe or system is contaminated (see Flush Hydraulic System in this section).

IMPORTANT: Follow all local codes and regulations when recycling or disposing hydraulic fluid and filters.

2. Lubricate O-rings and seals with clean hydraulic oil before installing hydraulic components.
3. Make sure caps or plugs are removed from the hydraulic lines, hydraulic fittings and components before reconnecting.
4. Use proper tightening methods when installing hydraulic lines and fittings (see Hydraulic Hose and Tube Installation and Hydraulic Fitting Installation in the General Information section of this chapter).
5. After repairs, check control linkages or cables for proper adjustment, binding or broken parts.
6. If piston (traction) pump, front wheel motors or rear axle motor was removed from machine for service, fill housing through case drain with new hydraulic oil before starting engine. This will ensure that internal components have adequate lubrication during initial operation.
7. After disconnecting or replacing any hydraulic components, operate machine functions slowly until air is out of system (see Charge Hydraulic System in this section).
8. Check for hydraulic oil leaks. Shut off engine and correct leaks if necessary. Check oil level in hydraulic reservoir and add correct oil if necessary.

Check Hydraulic Lines and Hoses



WARNING

Keep body and hands away from pin hole leaks or nozzles that eject hydraulic fluid under high pressure. Use paper or cardboard, not hands, to search for leaks. Hydraulic fluid escaping under pressure can have sufficient force to penetrate the skin and cause serious injury. If fluid is injected into the skin, it must be surgically removed within a few hours by a doctor familiar with this type of injury. Gangrene may result from such an injury.

IMPORTANT: Check hydraulic lines and hoses daily for leaks, kinked lines, loose mounting supports, wear, loose fittings or any hose deterioration. Make all necessary repairs before operating.

Priming Hydraulic Pumps

Whenever the hydraulic system is flushed, the hydraulic system is charged or hydraulic components are installed, it is important to properly prime the hydraulic pumps. Hydraulic pump priming ensures that the gear pump and piston (traction) pump have adequate oil during initial start-up and running. The pumps can be primed by using a remote starter switch (see Special Tools in this chapter) to crank engine which allows the pumps to prime.

Use the following procedure to prime the hydraulic pumps:

1. Make sure that ignition switch is in the OFF position and key is removed from switch.
2. Check hydraulic reservoir oil level and adjust if necessary.

NOTE: A blue wire connects to the starter motor solenoid B+ terminal (Fig. 50). It is not necessary to remove this blue wire from the solenoid terminal for hydraulic pump priming.

3. Connect remote starter switch electrical leads to the starter motor solenoid B+ terminal and the positive post of the battery.

4. Engage remote starter switch and crank starter for thirty (30) seconds to prime hydraulic pumps. Wait thirty (30) seconds to allow the starter motor and starter solenoid to cool. Repeat cranking procedure a second time.

5. Disconnect remote starter switch leads from starter motor solenoid terminal and positive post of the battery.




Figure 50


- | | |
|---------------------|----------------|
| 1. Starter motor | 3. B+ terminal |
| 2. Starter solenoid | |

Flush Hydraulic System

IMPORTANT: Flush the hydraulic system any time there is a severe component failure or the system is contaminated. Contaminated oil may appear milky or black or may contain metal particles.

IMPORTANT: If a component failure occurred in the closed loop traction circuit (e.g. piston pump or wheel motor), filtering the traction circuit is recommended. See **Filtering Closed-Loop Traction Circuit** in this section.

1. Park machine on a level surface. Lower cutting decks to the ground, stop engine and apply parking brake. Remove key from the ignition switch.

 WARNING
Before disconnecting or performing any work on the hydraulic system, all pressure in the system must be relieved. See Relieving Hydraulic System Pressure in the General Information section in this chapter.

IMPORTANT: Make sure to clean around any hydraulic connections that will be disconnected for draining.

2. Drain hydraulic reservoir. Remove suction screen from reservoir and clean thoroughly. Consider removing and cleaning reservoir if necessary.

3. Drain hydraulic system. Drain all hoses, tubes and components while the system is warm.

4. Change and replace both hydraulic oil filters.

IMPORTANT: Follow all local codes and regulations when recycling or disposing hydraulic fluid and filters.

5. Inspect and clean hydraulic reservoir (see Hydraulic Reservoir in this section).

6. Connect all hydraulic hoses, lines and components that were disconnected while draining system.

IMPORTANT: When filling hydraulic reservoir, use only hydraulic fluids specified in Operator's Manual. Other fluids could cause system damage.

7. Fill hydraulic reservoir with **new** hydraulic fluid.

8. Prime hydraulic pumps (see Priming Hydraulic Pumps in this section).

9. Start engine and let it run at low idle speed for a minimum of two (2) minutes. Increase engine speed to high idle for minimum of one (1) minute under no load.

10. Raise and lower cutting decks several times. Turn steering wheel fully left and right several times.

11. Shut off engine and check for hydraulic oil leaks. Check oil level in hydraulic reservoir and add correct amount of oil if necessary.

12. Operate machine for two (2) hours under normal operating conditions.

13. Check condition of hydraulic oil. If the new fluid shows any signs of contamination, repeat steps 1 through 12 again until oil is clean.

14. Assume normal operation and follow recommended maintenance intervals.

Filtering Closed-Loop Traction Circuit

Filtering of a closed-loop hydraulic system after a major component failure (e.g. traction (piston) pump or front wheel motor) is a requirement to prevent debris from transmitting throughout the system. If a closed-loop hydraulic system filtering tool is not used to ensure system cleanliness, repeat failures, as well as subsequent damage to other hydraulic components in the affected system, will occur. To effectively remove contamination from closed-loop traction circuit, use of the Toro high flow hydraulic filter and hydraulic hose kits are recommended (see Special Tools in this chapter).

1. Park machine on a level surface with engine stopped and key removed from ignition switch.
2. Raise and support machine so all wheels are off the ground (see Jacking Instructions in Chapter 1 – Safety).

NOTE: If front wheel or rear axle motor was replaced, install high flow filter to the inlet of new motor instead of to the traction pump fitting. This will prevent system contamination from entering and damaging the new motor.

3. Thoroughly clean junction of hydraulic hose and **left** side fitting on bottom of piston (traction) pump (Fig. 51). Disconnect hose from left side pump fitting.
4. Connect Toro high flow hydraulic filter in series between piston pump fitting and disconnected hose. Use hydraulic hose kit (see Special Tools in this chapter) to connect filter to machine. Make sure that fitting and hose connections are properly tightened.

IMPORTANT: When filling hydraulic reservoir, use only hydraulic fluids specified in Operator's Manual. Other fluids could cause system damage.

5. After installing high flow filter to machine, check and fill hydraulic reservoir with new hydraulic oil as required.
6. Start engine and run at idle speed. Check for any hydraulic leakage from filter and hose connections. Correct any leaks before proceeding.

CAUTION

All wheels will be off the ground and rotating during this procedure. Make sure machine is well supported so it will not move and accidentally fall to prevent injuring anyone around machine.

IMPORTANT: While engaging the traction circuit, monitor the high flow hydraulic filter indicator. If the indicator should show red, either reduce traction pedal setting or reduce engine speed to decrease hydraulic flow through the filter.

7. With engine running at low idle speed, slowly move the traction pedal to the forward direction to allow flow through the traction circuit and high flow filter. Keep traction circuit engaged for five (5) minutes while gradually increasing both forward pressure on traction pedal and engine speed. Monitor filter indicator to make sure that green color is showing during operation.

8. With engine running at high idle speed and traction pedal moved to the forward direction, periodically apply brakes to increase pressure in traction circuit. While monitoring filter indicator, continue this process for an additional five (5) minutes.

IMPORTANT: If using a filter that is not the bi-directional Toro high flow filter, do not press the traction pedal in the reverse direction. If flow is reversed when using a filter that is not bi-directional, debris from the filter will re-enter the traction circuit.

9. With engine running at high idle speed, alternately move traction pedal from forward to reverse. While monitoring filter indicator, continue this process for an additional five (5) minutes.
10. Shut engine off and remove key from ignition switch.
11. Remove high flow hydraulic filter and hydraulic hose kit from machine. Connect hydraulic hose to right side piston (traction) pump fitting. Make sure to properly tighten hose (see Hydraulic Hose and Tube Installation in the General Information section of this chapter).
12. Lower machine to ground.
13. Check oil level in hydraulic reservoir and add correct oil if necessary.




Figure 51

1. Piston (traction) pump
2. Left side fitting/hose

Charge Hydraulic System

NOTE: When initially starting the hydraulic system with new or rebuilt components such as motors, pumps or lift cylinders, it is important that the hydraulic system be charged properly. Air must be purged from the system to reduce the chance of component damage.

IMPORTANT: Change hydraulic oil filters whenever hydraulic components are repaired or replaced.

1. Park machine on a level surface. Lower cutting decks, stop engine and apply parking brake. Remove key from the ignition switch.
2. Make sure all hydraulic connections, lines and components are secured tightly.
3. If hydraulic component failure was severe or the hydraulic system is contaminated, flush and refill hydraulic system and hydraulic reservoir (see Flush Hydraulic System in this section).

IMPORTANT: When filling hydraulic reservoir, use only hydraulic fluids specified in Operator's Manual. Other fluids could cause system damage.

4. Make sure hydraulic reservoir is full. Add correct hydraulic oil to reservoir if necessary.
5. Prime hydraulic pumps (see Priming Hydraulic Pumps in this section).



6. Raise machine so that all wheels are off the ground and place appropriate jack stands under the frame to support the machine.

IMPORTANT: During initial operation, check hydraulic reservoir oil level frequently and add oil as necessary.

7. Make sure traction pedal and lift switches are in **neutral**. Start engine and run at low idle speed. The gear pump should pick up oil and fill the hydraulic system. If there is no indication of fill in thirty (30) seconds, stop the engine and determine the cause.

8. After the hydraulic system starts to show signs of fill, actuate a lift switch until the lift cylinder rod moves in and out several times. If the lift cylinder does not move after **ten (10) to fifteen (15) seconds**, or if the pump emits abnormal sounds, shut the engine off immediately and determine cause or problem. Inspect for the following:

- A. Loose filter or suction lines.
- B. Blocked suction line.
- C. Faulty charge relief valve.
- D. Faulty gear pump.

9. Once the lift cylinder does move in **ten (10) to fifteen (15) seconds**, proceed to step 10.

10. Operate the traction pedal in the forward and reverse directions. The wheels should rotate in the proper direction.

- A. If the wheels rotate in the wrong direction, stop engine and check for proper hydraulic hose and electrical connections at traction pump and motors. Correct as needed.
- B. If the wheels rotate in the proper direction, stop engine.

11. Check operation of the traction interlock switch (see Check Interlock System in Chapter 5 - Electrical System).

12. With engine not running and ignition switch in the OFF position, remove jack stands that are supporting the machine and lower the machine to the ground.

13. If the piston (traction) pump or a traction motor was replaced or rebuilt, run the machine so all wheels turn slowly for ten (10) minutes.

14. Operate machine by gradually increasing its work load to full over a ten (10) minute period.

15. Stop the machine. Check hydraulic reservoir and fill if necessary. Check hydraulic components for leaks and tighten any loose connections.

Hydraulic Reservoir




Figure 52

- | | | |
|---------------------------|-------------------|-------------------------|
| 1. Hydraulic reservoir | 12. Dipstick | 22. Cap screw |
| 2. Cap screw | 13. Screen filter | 23. Plug |
| 3. Recess bumper (2 used) | 14. Tank strainer | 24. Hose clamp |
| 4. Thin spacer | 15. Cap screw | 25. Suction hose |
| 5. Flange nut | 16. Flat washer | 26. Hose clamp (4 used) |
| 6. Breather | 17. Thick spacer | 27. Hydraulic hose |
| 7. Bushing (3 used) | 18. Retainer nut | 28. Hydraulic hose |
| 8. Stand pipe (3 used) | 19. Tank mount | 29. O-ring |
| 9. Hose clamp | 20. Flange nut | 30. Hydraulic hose |
| 10. Reservoir cap | 21. Flat washer | 31. O-ring |
| 11. O-ring | | |

NOTE: The operator platform needs to be raised from the main frame so that the hydraulic reservoir can be removed from the machine (see Operator Platform in the Service and Repairs section of Chapter 6 - Chassis).

Removal (Fig. 52)

1. Park machine on a level surface, lower cutting decks, stop engine, apply parking brake and remove key from the ignition switch.

2. Read the General Precautions for Removing and Installing Hydraulic System Components at the beginning of the Service and Repairs section of this chapter.

3. Drain reservoir into a suitable container.

IMPORTANT: Follow all local codes and regulations when recycling or disposing hydraulic fluid.

IMPORTANT: Make sure to not damage the electrical wire harness, hydraulic hoses or other components while raising the operator platform.

4. Raise and support operator platform from the main frame to allow clearance to remove the hydraulic reservoir from the machine (see Operator Platform in the Service and Repairs section of Chapter 6 - Chassis).

5. Disconnect hydraulic hoses from reservoir. Label disconnected hydraulic hoses for proper installation. Put plugs on open hydraulic hoses and reservoir fittings to prevent contamination.

6. Loosen hose clamp (item 24) that secures suction hose to tank strainer. Remove suction hose (item 25) from strainer.

7. Remove tank strainer (item 14) from reservoir.

8. Remove cap screw (item 22) and flat washer (item 21) that secure tank mount (item 19) to left side of frame.

9. Carefully remove hydraulic reservoir and tank mount assembly (items 3, 15, 16, 17, 18 and 19) from machine.

Inspection

1. Clean hydraulic reservoir and tank strainer with solvent.

2. Inspect reservoir for leaks, cracks or other damage.

Installation (Fig. 52)

NOTE: Make sure that recess bumper (item 3) and thin spacer (item 4) are secured to right side of frame before hydraulic reservoir is installed to machine.

1. Position hydraulic reservoir to machine. Make sure that recess bumper (item 3) on right side of frame is inserted into tank slot.

2. Slide tank mount assembly (items 15, 16, 3, 17, 18 and 19) between frame and hydraulic reservoir and position bumper into slot on left side of reservoir. Align tank mount with hole in frame. Secure mount with cap screw and flat washer (Fig. 53).

3. Install tank strainer into reservoir port and torque from **80 to 88 ft-lb (109 to 119 N-m)**.

4. Remove plugs from hydraulic hoses and reservoir fittings that were placed during the removal process. Using labels placed during reservoir removal, connect hydraulic hoses to fittings on reservoir. Secure hoses with hose clamps.

IMPORTANT: Make sure to not damage the electrical wire harness, hydraulic hoses or other components while lowering the operator platform.

5. Carefully lower operator platform to the main frame (see Operator Platform in the Service and Repairs section of Chapter 6 - Chassis). Make sure that fasteners are properly torqued during assembly.

IMPORTANT: Use only hydraulic fluids specified in Operator's Manual. Other fluids could cause system damage.

6. Fill reservoir with new hydraulic oil to proper level.

7. Properly fill hydraulic system (see Charge Hydraulic System in this section).

8. Stop engine and check for hydraulic oil leaks. Check hydraulic reservoir oil level.




Figure 53

- | | |
|------------------------|----------------|
| 1. Hydraulic reservoir | 3. Flat washer |
| 2. Cap screw | 4. Tank mount |

Radiator and Oil Cooler Assembly




Figure 54

- | | | |
|-------------------------------|---------------------------|-----------------------------------|
| 1. LH radiator support | 13. Cap screw (2 used) | 25. Air cleaner inlet hose |
| 2. Cap screw (2 used) | 14. Hose | 26. Radiator/hydraulic oil cooler |
| 3. Flange nut (12 used) | 15. Coolant reservoir | 27. Bulb seal |
| 4. Hose clamp (3 used) | 16. Tank mount | 28. RH radiator support |
| 5. Hose | 17. Flat washer (7 used) | 29. Straight hydraulic fitting |
| 6. Flange nut (6 used) | 18. Cap screw (6 used) | 30. Intake bracket |
| 7. Foam plug (2 used) | 19. Lower radiator hose | 31. 90° hydraulic fitting |
| 8. Flange head screw (6 used) | 20. Hose clamp (4 used) | 32. Pipe plug |
| 9. Flange head screw (9 used) | 21. Upper radiator hose | 33. Hex plug with O-ring |
| 10. Foam strip | 22. Lower radiator shroud | 34. Foam pad (2 used) |
| 11. Hose bracket | 23. Upper radiator shroud | 35. Draincock |
| 12. R-clamp (2 used) | 24. Hose clamp | 36. Cap screw (2 used) |

NOTE: The hydraulic oil cooler on your Groundsmaster is combined with the radiator. See Radiator and Oil Cooler Assembly in the Service and Repairs section of Chapter 3 - Diesel Engine for information on removal and installation of the radiator/oil cooler assembly.

This page is intentionally blank.

Gear Pump




Figure 55

- | | | |
|-------------------------------|------------------------------------|---|
| 1. Hose clamp (3 used) | 10. Gear pump | 19. 90° hydraulic fitting |
| 2. Hose clamp (2 used) | 11. O-ring | 20. Test nipple (2 used) |
| 3. Hydraulic hose | 12. Hydraulic fitting | 21. Straight hydraulic fitting (2 used) |
| 4. Suction hose | 13. 45° hydraulic fitting | 22. Straight hydraulic fitting |
| 5. Tee fitting | 14. Hydraulic tee fitting (2 used) | 23. 90° hydraulic fitting |
| 6. Straight hydraulic fitting | 15. Dust cap (4 used) | 24. Engine (model 30603/30605 shown) |
| 7. Plug | 16. Piston pump | 25. Test fitting (2 used) |
| 8. Cap screw (2 used) | 17. 90° hydraulic fitting | 26. 90° barbed hydraulic fitting |
| 9. Flat washer (4 used) | 18. Cap screw (2 used) | 27. Hydraulic hose |

Removal (Fig. 55)

1. Park machine on a level surface, lower cutting decks, stop engine, apply parking brake and remove key from the ignition switch.
2. Raise and support machine to gain access to gear pump from the underside of the machine.
3. Drain the hydraulic reservoir.

IMPORTANT: Follow all local codes and regulations when recycling or disposing hydraulic fluid.

4. To prevent contamination of hydraulic system during removal, thoroughly clean exterior of pump and fittings.
5. Read the General Precautions for Removing and Installing Hydraulic System Components at the beginning of the Service and Repairs section of this chapter.
6. Disconnect hydraulic lines from gear pump and put caps or plugs on open hydraulic lines and fittings. Label disconnected hydraulic lines for proper installation.

IMPORTANT: Dry weight of gear pump is 23 pounds (10.2 kg).

7. Support gear pump assembly to prevent it from falling.
8. Remove two (2) cap screws and washers securing gear pump to piston pump. Lower and remove gear pump from machine.

NOTE: A case drain exists in the piston (traction) pump and a suction port is near the input shaft of the gear pump (Fig. 56). When the gear pump is removed from the piston pump, plug piston pump case drain hole to prevent draining the piston pump.

9. Remove O-ring (item 11) from between the gear pump and piston pump. Discard O-ring.

10. If hydraulic fittings are to be removed from gear pump, mark fitting orientation to allow correct assembly. Remove fittings from pump and discard O-rings.

Installation (Fig. 55)

1. If fittings were removed from gear pump, lubricate and place new O-rings onto fittings. Install fittings into pump openings using marks made during the removal process to properly orientate fittings. Tighten fittings (see Hydraulic Fitting Installation in the General Information section of this chapter).
2. Make sure mounting and O-ring sealing surfaces on the gear pump and piston pump are clean.
3. Apply clean hydraulic oil to gear pump flange O-ring (item 11). Place O-ring on the gear pump.




Figure 56

1. Piston pump case drain
2. Gear pump suction port

IMPORTANT: Position gear pump to the piston (traction) pump so that the gear pump inlet (suction) ports are facing down.

IMPORTANT: A case drain exists in the piston (traction) pump and a suction port is near the input shaft of the gear pump (Fig. 56). Before the gear pump is installed to the piston pump, make sure that plugs placed in either of these ports are removed. Failure to remove plugs will cause excessive pressure in the piston pump and damage seals. Also, before securing gear pump to piston pump, fill piston pump housing with clean hydraulic oil through case drain hole.

4. Remove plugs that were placed in piston pump case drain and gear pump suction port. Fill piston pump housing with clean hydraulic oil through case drain hole.
5. Position gear pump to the piston (traction) pump so that the pump inlet ports are facing down.
6. Align gear teeth and slide gear pump input shaft into piston pump shaft. Secure gear pump to piston pump with two (2) cap screws and flat washers.
7. Remove caps and plugs from hydraulic lines and fittings. Using labels placed during gear pump removal, properly install lines to gear pump (see Hydraulic Hose and Tube Installation in the General Information section of this chapter).
8. Fill piston pump housing through case drain (90° barbed fitting) with new hydraulic oil (Fig. 57). This will ensure that internal pump components have adequate lubrication during initial operation.
9. Lower machine to ground.

10. Replace hydraulic filters and fill hydraulic reservoir with new hydraulic oil.

11. Prime hydraulic pumps (see Priming Hydraulic Pumps in this section).

12. Properly fill hydraulic system (see Charge Hydraulic System in this section).

13. Stop engine and check for hydraulic oil leaks. Check hydraulic reservoir oil level.




Figure 57

- 1. Piston (traction) pump
- 2. Gear pump
- 3. Piston pump case drain

This page is intentionally blank.

Gear Pump Service




Figure 58

- | | | |
|-----------------------|---------------------------------------|------------------------|
| 1. Front cover | 10. Thrust plate (7 used) | 18. Body |
| 2. Dowel pin (4 used) | 11. Dowel pin (6 used) | 19. Body |
| 3. Pressure seal | 12. Splined connecting shaft (3 used) | 20. Idler gear |
| 4. Back-up gasket | 13. Flange (3 used) | 21. Drive gear |
| 5. Front thrust plate | 14. Back-up gasket | 22. Rear body |
| 6. Seal (8 used) | 15. Pressure seal | 23. Rear cover |
| 7. Front body | 16. Drive gear | 24. Washer (4 used) |
| 8. Idler gear | 17. Idler gear | 25. Cap screw (4 used) |
| 9. Drive shaft | | |

Disassembly (Fig. 58)

NOTE: The gear pump must be replaced as a complete assembly. Individual gears, housings and thrust plates are not available separately. Disassemble gear pump for cleaning, inspection and seal replacement only.

IMPORTANT: Keep bodies, gears, flanges and thrust plates for each pump section together; do not mix parts between pump sections.

1. Plug pump ports and thoroughly clean exterior of pump with cleaning solvent. Make sure work area is clean.

2. Use a marker to make a **diagonal** line across the gear pump for assembly purposes (Fig. 59).




Figure 59

IMPORTANT: Use caution when clamping gear pump in a vise to avoid distorting any pump components.

3. Secure the front cover of the pump in a vise with the drive shaft pointing down.
4. Loosen the four (4) cap screws that secure pump assembly.
5. Remove pump from vise and remove fasteners.
6. Support the pump assembly and gently tap the pump case with a soft face hammer to loosen the pump sections. Be careful to not drop parts or disengage gear mesh.

IMPORTANT: Mark the relative positions of the gear teeth and the thrust plates so they can be reassembled in the same position. Do not touch the gear surfaces as residue on hands may be corrosive to gear finish.

7. Remove the thrust plates and seals from each pump section. Before removing each gear set, apply marking dye to mating teeth to retain "timing". Pump efficiency may be affected if the teeth are not installed in the same position during assembly. Keep the parts for each pump section together; do not mix parts between sections.
8. Clean all parts. Check all components for burrs, scoring, nicks and other damage.
9. Replace the entire pump assembly if parts are excessively worn or scored.

Assembly (Fig. 58)

1. Apply clean hydraulic oil to all parts before assembling.

NOTE: Pressure seals and back-up gaskets fit in grooves machined into thrust plates. Body seals fit in grooves machined in body faces.

2. Assemble pump sections starting at front cover end. Apply grease or petroleum jelly to new section seals to hold them in position during gear pump assembly.
3. After pump has been assembled, tighten cap screws by hand. Rotate the drive shaft to check for binding. Protect the shaft if using a pliers.
4. Tighten the four (4) cap screws evenly in a crossing pattern to a torque of **33 ft-lb (45 N-m)**.




Figure 60

1. LH and RH PTO pump section
2. Front PTO pump section
3. Cooling fan, lift/lower and charge pump section
4. Steering, charge and cooling fan pump section

Piston (Traction) Pump




Figure 61

- | | | |
|-------------------------------|------------------------------------|---|
| 1. Hose clamp (3 used) | 10. Gear pump | 19. 90° hydraulic fitting |
| 2. Hose clamp (2 used) | 11. O-ring | 20. Test nipple (2 used) |
| 3. Hydraulic hose | 12. Hydraulic fitting | 21. Straight hydraulic fitting (2 used) |
| 4. Suction hose | 13. 45° hydraulic fitting | 22. Straight hydraulic fitting |
| 5. Tee fitting | 14. Hydraulic tee fitting (2 used) | 23. 90° hydraulic fitting |
| 6. Straight hydraulic fitting | 15. Dust cap (4 used) | 24. Engine (model 30603/30605 shown) |
| 7. Plug | 16. Piston pump | 25. Test fitting (2 used) |
| 8. Cap screw (2 used) | 17. 90° hydraulic fitting | 26. 90° barbed hydraulic fitting |
| 9. Flat washer (4 used) | 18. Cap screw (2 used) | 27. Hydraulic hose |

Removal (Fig. 61)

1. Park machine on a level surface, lower cutting decks, stop engine, apply parking brake and remove key from the ignition switch.

2. To prevent contamination of hydraulic system during removal, thoroughly clean exterior of pump assembly.

3. Raise and support machine to gain access to pump assembly from the underside of machine.

4. Label wire harness connectors that attach to the two (2) solenoid coils on left side of piston pump (Fig. 62). Disconnect harness connectors from solenoid coils on piston pump.

5. Read the General Precautions for Removing and Installing Hydraulic System Components at the beginning of the Service and Repairs section of this chapter.

6. For installation purposes, label all hydraulic lines that connect to gear pump and piston pump.

7. Put a drain pan below the pump assembly. Remove hydraulic lines connected to piston and gear pump fittings. Put plugs or caps on disconnected hydraulic lines and fittings to prevent contamination of the system.

NOTE: If fuel tank is removed from the machine, the gear pump and piston pump can be removed as a complete assembly.

8. Remove gear pump from machine (see Gear Pump in this section).

IMPORTANT: Dry weight of piston (traction) pump is 90 pounds (41 kg).

NOTE: A case drain exists in the piston (traction) pump and a suction port is near the input shaft of the gear pump (Fig. 63). When the gear pump is removed from the piston pump, plug piston pump case drain hole to prevent draining the piston pump.

9. Support the piston pump to prevent it from falling. Remove two (2) cap screws and washers retaining pump assembly to engine flywheel plate. Carefully pull pump assembly from flywheel plate and lower it out of the machine.

10. If hydraulic fittings are to be removed from piston pump, mark fitting orientation to allow correct assembly. Remove fittings from pump and discard O-rings.




Figure 62

- 1. Piston pump
- 2. Solenoid coil (forward)
- 3. Solenoid coil (reverse)




Figure 63

- 1. Piston pump case drain
- 2. Gear pump suction port

Installation (Fig. 61)

1. If fittings were removed from piston pump, lubricate and place new O-rings onto fittings. Install fittings into pump openings using marks made during the removal process to properly orientate fittings. Tighten fittings (see Hydraulic Fitting Installation in the General Information section of this chapter).

IMPORTANT: To prevent spring coupler damage, make sure that piston pump is properly supported and does not put side load into coupler during pump installation.

2. Carefully raise piston pump into the machine, align pump input shaft to spring coupler on engine and position it to the engine flywheel plate. Support pump to prevent it from producing any side load into coupler and also to align pilot diameter of pump to flywheel plate bore.

3. While maintaining pump alignment with spring coupler and flywheel plate, install two (2) cap screws and washers to secure piston pump to engine.

IMPORTANT: A case drain exists in the piston (traction) pump and a suction port is near the input shaft of the gear pump (Fig. 63). Before the gear pump is installed to the piston pump, make sure that plugs placed in either of these ports are removed. Failure to remove plugs will cause excessive pressure in the piston pump and damage seals. Also, before securing gear pump to piston pump, fill piston pump housing with clean hydraulic oil through case drain hole.

4. Remove plugs that were placed in piston pump case drain and gear pump suction port. Fill piston pump housing with new hydraulic oil through case drain hole.

5. Install gear pump to piston pump (see Gear Pump in this section).

6. Using labels placed during pump removal, connect wire harness connectors to the two (2) solenoid coils on left side of piston pump.

7. Fill piston (traction) pump housing with new hydraulic oil through the case drain (90° barbed fitting) at the top of the pump (Fig. 64). This will ensure that internal pump components have adequate lubrication during initial operation.

8. Remove plugs and caps from disconnected hydraulic lines and fittings of the pump assembly. Install hydraulic lines to correct location on gear and piston pumps (see Hydraulic Fitting Installation and Hydraulic Hose and Tube Installation in the General Information section of this chapter).

9. Lower machine to ground.

10. Install new hydraulic filter and fill hydraulic reservoir with correct oil.

IMPORTANT: Refer to Traction Circuit Component Failure in the General Information section of this chapter for information regarding the importance of removing contamination from the traction circuit.

11. Prime hydraulic pumps (see Priming Hydraulic Pumps in this section).

12. Properly fill hydraulic system (see Charge Hydraulic System in this section).

13. Stop engine and check for hydraulic oil leaks. Check hydraulic reservoir oil level.




Figure 64

- 1. Piston (traction) pump
- 2. Gear pump
- 3. Piston pump case drain

This page is intentionally blank.

Piston (Traction) Pump Service




Figure 65

Figure 65 (Continued)

- | | | |
|-------------------------------|--------------------------------------|---------------------------------|
| 1. Screen (2 used) | 20. Bearing | 38. O-ring |
| 2. Plug with O-ring (2 used) | 21. Screw (4 used) | 39. Seal carrier |
| 3. Plug with O-ring (2 used) | 22. Thrust plate | 40. Retaining ring |
| 4. Cylinder block assembly | 23. Forward relief valve assembly | 41. Coil nut (2 used) |
| 5. Valve plate | 24. Reverse relief valve assembly | 42. O-ring |
| 6. Servo piston | 25. Swash plate bearing assembly | 43. Forward solenoid coil |
| 7. Screw (4 used) | 26. Screw (2 used) | 44. Screw (3 used per solenoid) |
| 8. Orifice (2 used) | 27. Bracket (2 used) | 45. Solenoid (2 used) |
| 9. Screw (4 used) | 28. Charge relief valve assembly | 46. O-ring |
| 10. Plug with O-ring (4 used) | 29. Servo piston seal assembly | 47. Control housing |
| 11. Screw (2 used) | 30. Piston follower | 48. Screen (2 used) |
| 12. Plug | 31. Swashplate | 49. Retaining ring (2 used) |
| 13. Shaft | 32. Dowel pin (2 used) | 50. Gasket |
| 14. Bearing assembly | 33. Servo cylinder assembly (2 used) | 51. Lock nut |
| 15. Retaining ring | 34. Locking plate (2 used) | 52. Plug |
| 16. Gasket | 35. Dowel pin (2 used) | 53. Screw (6 used) |
| 17. Adapter | 36. Feedback pin | 54. Plug (2 used) |
| 18. Adapter seal | 37. Seal | 55. Reverse solenoid coil |
| 19. Coupling | | |

Piston (Traction) Pump Service (Fig. 65)

For service of the piston (traction) pump, see the Sauer-Danfoss H1 Closed Circuit Axial Piston Pumps Service Manual at the end of this chapter.

NOTE: The forward (item 43) and reverse (item 55) solenoid coils are identical.

Rear Axle Motor




Figure 66

- | | | |
|-----------------------------------|---------------------------------|---------------------------------|
| 1. Rear axle motor | 8. Flat washer (2 used) | 15. Dowel pin (2 used) |
| 2. 90° hydraulic fitting (2 used) | 9. O-ring | 16. Gasket |
| 3. 90° hydraulic fitting | 10. External snap ring (2 used) | 17. External snap ring (2 used) |
| 4. Straight hydraulic fitting | 11. Pinion gear (27T) | 18. Gear (45T) |
| 5. 90° hydraulic fitting | 12. Cap screw (6 used) | 19. Needle bearing |
| 6. Temperature sender | 13. Lock washer (6 used) | 20. Plug with O-ring |
| 7. Cap screw (2 used) | 14. Cover plate | 21. Drive axle assembly |

Removal (Fig. 66)

1. Park machine on a level surface, lower cutting decks, stop engine, apply parking brake and remove key from the ignition switch.
2. Drain lubricant from rear axle gearbox.
3. Read the General Precautions for Removing and Installing Hydraulic System Components at the beginning of the Service and Repairs section of this chapter.
4. To prevent contamination of hydraulic system during axle motor removal, thoroughly clean exterior of motor and fittings.
5. Disconnect wire harness connector from temperature sender (item 6) on rear axle motor.

NOTE: To ease installation, label the hydraulic lines to show their correct position on the axle motor.

6. Disconnect hydraulic lines from motor. Put caps or plugs on motor fittings and hydraulic line openings to prevent contamination.

IMPORTANT: Before loosening fasteners that secure rear axle motor, support motor to prevent it from falling during removal.

7. Remove motor from rear axle using Figure 66 as a guide.
8. If hydraulic fittings are to be removed from motor, mark fitting orientation to allow correct assembly. Remove fittings from motor and discard O-rings.
9. If necessary, remove temperature sender (item 6) from rear axle motor.
10. If necessary, remove pinion gear (item 11) from rear axle motor shaft.

Installation (Fig. 66)

IMPORTANT: Refer to Traction Circuit Component Failure in the General Information section of this chapter for information regarding the importance of removing contamination from the traction circuit.

1. If fittings were removed from axle motor, lubricate and place new O-rings onto fittings. Install fittings into port openings using marks made during the removal process to properly orientate fittings. Tighten fittings (see Hydraulic Fitting Installation in the General Information section of this chapter).
2. If temperature sender (item 6) was removed from rear axle motor, thread sender into motor port. Torque sender from **9 to 11 ft-lb (12.3 to 14.9 N-m)**.
3. If removed, install pinion gear (item 11) to axle motor. Make sure that retaining rings are fully seated into the grooves of the motor shaft.
4. Install O-ring (item 9) onto motor. Position motor to rear axle assembly and align gear teeth. Slide motor into place.
5. Secure motor to axle with cap screws and flat washers.
6. Remove plugs from motor fittings and hydraulic line openings. Using labels placed during motor removal, correctly attach hydraulic lines to axle motor fittings (see Hydraulic Hose and Tube Installation in the General Information section of this chapter).
7. Secure wire harness connector to temperature sender (item 6) on rear axle motor.
8. Fill rear axle gearbox with SAE 85W-140 weight gear lube. Gearbox capacity is approximately 16 fl. oz. (0.47 liters).
9. Fill reservoir with hydraulic fluid as required.
10. Properly fill hydraulic system (see Charge Hydraulic System in this section).
11. After assembly is completed, verify that hydraulic lines and fittings do not contact anything.

Front Wheel Motors




Figure 67

- | | | |
|--------------------------------|-----------------------------------|------------------------------------|
| 1. Front wheel motor | 6. Cap screw (2 used per motor) | 11. 90° hydraulic fitting (2 used) |
| 2. Internal retaining ring | 7. Flat washer (2 used per motor) | 12. Hydraulic connector |
| 3. Splined brake shaft | 8. O-ring | 13. Hydraulic tee fitting (2 used) |
| 4. RH brake assembly | 9. LH brake assembly | 14. 90° hydraulic fitting |
| 5. Planetary assembly (2 used) | 10. Hydraulic tee fitting | 15. Straight hydraulic fitting |

Removal (Fig. 67)

1. Park machine on a level surface, lower cutting decks, stop engine, apply parking brake and remove key from the ignition switch.
2. Read the General Precautions for Removing and Installing Hydraulic System Components at the beginning of the Service and Repairs section of this chapter.
3. To prevent contamination of hydraulic system during wheel motor removal, thoroughly clean exterior of motor and fittings.

NOTE: To ease installation, label the hydraulic lines to show their correct position on the wheel motor.

4. Disconnect hydraulic hoses and tubes from wheel motor. Put caps or plugs on motor ports and hose openings to prevent contamination.

IMPORTANT: Before loosening fasteners that secure wheel motor, support motor to prevent it from falling during removal.

5. Remove wheel motor using Figure 67 as a guide.
6. If hydraulic fittings are to be removed from wheel motor, mark fitting orientation to allow correct assembly. Remove fittings from motor and discard O-rings.

Installation (Fig. 67)

IMPORTANT: Refer to Traction Circuit Component Failure in the General Information section of this chapter for information regarding the importance of removing contamination from the traction circuit.

1. If fittings were removed from motor, lubricate and place new O-rings onto fittings. Install fittings into port openings using marks made during the removal process to properly orientate fittings. Tighten fittings (see Hydraulic Fitting Installation in the General Information section of this chapter).
2. Install new O-ring (item 8) onto motor.
3. Align splines on motor shaft and splined brake shaft. Slide motor into brake assembly.
4. Secure motor to brake assembly with cap screws and flat washers.
5. Remove plugs from wheel motor fittings and hydraulic line openings. Using labels placed during motor removal, correctly attach hydraulic hoses and tubes to wheel motor fittings (see Hydraulic Hose and Tube Installation in the General Information section of this chapter).
6. Fill reservoir with hydraulic fluid as required.
7. Properly fill hydraulic system (see Charge Hydraulic System in this section).

Rear Axle and Front Wheel Motor Service




Figure 68

- | | | |
|-------------------------------|----------------------------------|-------------------------------|
| 1. Plug with O-ring | 10. Dowel pin | 18. Housing |
| 2. Minimum angle stop | 11. Bearing | 19. Bearing |
| 3. Bias spring | 12. Gasket | 20. Retaining ring |
| 4. Servo piston | 13. Valve plate | 21. Retaining ring (2 used) |
| 5. O-ring | 14. Cylinder block kit | 22. Seal |
| 6. O-ring | 15. Swashplate | 23. Support washer |
| 7. Socket head screw (5 used) | 16. Swash plate bearing assembly | 24. Plug with O-ring (2 used) |
| 8. Endcap | 17. Output shaft | 25. Plug with O-ring |
| 9. Dowel | | |

NOTE: The front wheel motors on your Groundsmaster are identical (Fig. 68). The rear axle motor includes a flushing valve for cooling of the closed loop traction circuit and therefore has some differences from the front motors (Fig. 69). Service of the wheel and axle motors uses the same procedure.

NOTE: For service of the front wheel and rear axle motors, see the Sauer-Danfoss K and L Frame Variable Motors Service Manual at the end of this chapter.




Figure 69

- | | |
|----------------------------|---------------------|
| 1. Plug | 6. Plug |
| 2. O-ring | 7. O-ring |
| 3. Centering spring | 8. Centering spring |
| 4. Spring retaining washer | 9. Orifice poppet |
| 5. Shift spool | 10. Endcap |

Rear Traction Manifold




Figure 70

- | | | |
|-------------------------------|--------------------------|---------------------------|
| 1. Front frame | 7. 90° hydraulic fitting | 13. O-ring |
| 2. PTO manifold (center deck) | 8. O-ring | 14. O-ring |
| 3. Front traction manifold | 9. 45° hydraulic fitting | 15. 45° hydraulic fitting |
| 4. Rear traction manifold | 10. O-ring | 16. O-ring |
| 5. Cap screw (2 used) | 11. O-ring | 17. O-ring |
| 6. Flange nut (2 used) | 12. Straight fitting | 18. O-ring |

NOTE: The ports on the rear traction manifold are marked for easy identification of components. Example: P2 is a piston pump connection port and RV is the location for the relief valve (see Hydraulic Schematic in Chapter 10 - Foldout Drawings to identify the function of the hydraulic lines and cartridge valves at each port).

Removal (Fig. 70)

1. Read the General Precautions for Removing and Installing Hydraulic System Components at the beginning of the Service and Repairs section of this chapter.
2. To prevent contamination of hydraulic system during manifold removal, thoroughly clean exterior of manifold and fittings.
3. Disconnect hydraulic lines from manifold and put caps or plugs on open hydraulic lines and fittings. Label disconnected hydraulic lines for proper installation.
4. Remove hydraulic manifold from the frame using Figure 70 as a guide.
5. If hydraulic fittings are to be removed from manifold, mark fitting orientation to allow correct assembly. Remove fittings from manifold and discard O-rings.

Installation (Fig. 70)

1. If fittings were removed from manifold, lubricate and place new O-rings onto fittings. Install fittings into manifold openings using marks made during the removal process to properly orientate fittings. Tighten fittings (see Hydraulic Fitting Installation in the General Information section of this chapter).
2. Install hydraulic manifold to the frame using Figure 70 as a guide.
3. Remove caps and plugs from fittings and hydraulic lines. Using labels placed during manifold removal, properly connect hydraulic lines to manifold (see Hydraulic Hose and Tube Installation in the General Information section of this chapter).
4. Make sure hydraulic tank is full. Add correct oil if necessary before returning machine to service.

Rear Traction Manifold Service




Figure 71

- | | | |
|--------------------------------------|----------------------------------|-------------------------------|
| 1. Rear traction manifold body | 4. #4 zero leak plug with O-ring | 6. Check valve (port CV) |
| 2. Relief valve (port RV) | 5. #6 zero leak plug with O-ring | 7. Orifice (0.050) (port OR1) |
| 3. Pressure reducing valve (port PR) | | |

NOTE: The ports on the rear traction manifold are marked for easy identification of components. Example: P2 is a piston pump connection port and RV is the location for the relief valve (see Hydraulic Schematic in Chapter 10 - Foldout Drawings to identify the function of the hydraulic lines and cartridge valves at each port).

NOTE: The rear traction manifold uses several zero leak plugs. These plugs have a tapered sealing surface on the plug head that is designed to resist vibration induced plug loosening. The zero leak plugs also have an O-ring as a secondary seal. If zero leak plug removal is necessary, lightly rap the plug head using a punch and hammer before using an allen wrench to remove the plug; the impact will allow plug removal with less chance of damage to the socket head of the plug.

For rear traction manifold cartridge valve service procedures, see Control Manifold Cartridge Valve Service in this section. Refer to Figure 71 for rear traction manifold cartridge valve and plug installation torque.

IMPORTANT: A flow control orifice (item 7) is located beneath the hydraulic fitting in rear traction manifold port T/OR1. If the orifice is removed from this manifold port, make sure to label its position for assembly purposes. When installing the orifice in the manifold, make sure that the orifice is properly tightened in the port.

This page is intentionally blank.

Front Traction Manifold




Figure 72

- | | | |
|-------------------------------|--------------------------------|-------------------------|
| 1. Front frame | 8. Check fitting | 14. O-ring |
| 2. PTO manifold (center deck) | 9. O-ring | 15. Check adapter |
| 3. Rear traction manifold | 10. Hydraulic straight fitting | 16. O-ring |
| 4. Front traction manifold | 11. O-ring | 17. O-ring |
| 5. Cap screw (2 used) | 12. 90° hydraulic elbow | 18. 45° hydraulic elbow |
| 6. Flange nut (2 used) | 13. O-ring | 19. O-ring |
| 7. O-ring | | |

NOTE: The ports on the front traction manifold are marked for easy identification of components. Example: P1 is the gear pump connection port and HFD is the location for the flow divider valve (see Hydraulic Schematic in Chapter 10 - Foldout Drawings to identify the function of the hydraulic lines and cartridge valves at each manifold port).

Removal (Fig. 72)

1. Read the General Precautions for Removing and Installing Hydraulic System Components at the beginning of the Service and Repairs section of this chapter.
2. To prevent contamination of hydraulic system during manifold removal, thoroughly clean exterior of manifold and fittings.
3. Disconnect hydraulic lines from manifold and put caps or plugs on open hydraulic lines and fittings. Label disconnected hydraulic lines for proper reassembly.
4. Remove front traction manifold from the frame using Figure 72 as a guide.
5. If hydraulic fittings are to be removed from manifold, mark fitting orientation to allow correct assembly. Remove fittings from manifold and discard O-rings.

Installation (Fig. 72)

1. If fittings were removed from manifold, lubricate and place new O-rings onto fittings. Install fittings into manifold openings using marks made during the removal process to properly orientate fittings. Tighten fittings (see Hydraulic Fitting Installation in the General Information section of this chapter).
2. Install front traction manifold to the frame using Figure 72 as a guide.
3. Remove caps and plugs from fittings and hydraulic lines. Using labels placed during manifold removal, properly connect hydraulic lines to manifold (see Hydraulic Hose and Tube Installation in the General Information section of this chapter).
4. Make sure hydraulic tank is full. Add correct oil if necessary before returning machine to service.

Front Traction Manifold Service




Figure 73

- | | | |
|----------------------------------|------------------------------------|----------------------------------|
| 1. Flow divider valve (port HFD) | 4. Front traction manifold | 6. SAE #6 plug with O-ring |
| 2. SAE #4 plug with O-ring | 5. Check valve (ports CV1 and CV2) | 7. #4 zero leak plug with O-ring |
| 3. Orifice (0.063) (port OR) | | |

NOTE: The ports on the front traction manifold are marked for easy identification of components. Example: P1 is the gear pump connection port and HFD is the location for the flow divider valve (see Hydraulic Schematic in Chapter 10 - Foldout Drawings to identify the function of the hydraulic lines and cartridge valves at each manifold port).

Front Traction Manifold Service (Fig. 73)

For front traction manifold cartridge valve service procedures, see Control Manifold Cartridge Valve Service in this section. Refer to Figure 73 for front traction manifold cartridge valve and plug installation torque.

IMPORTANT: A flow control orifice is located beneath the plug in the front traction manifold port OR. If the orifice is removed from the manifold port, make sure to label its position for assembly purposes. When installing the orifice in the manifold, make sure that the orifice is properly tightened in the port.

Combination Manifold




Figure 74

1. Combination manifold
2. Flange nut (3 used)

3. Flat washer (3 used)
4. Mount (3 used)

5. Spacer (3 used)

NOTE: The ports on the combination manifold are marked for easy identification of components. Example: P3 and P4 are the gear pump connection ports, S1 is the location for solenoid valve S1 and OR6 is the location for orifice OR6 (see Hydraulic Schematic in Chapter 10 – Foldout Drawings to identify the function of the hydraulic lines and cartridge valves at each port).

Removal (Fig. 74)

1. Read the General Precautions for Removing and Installing Hydraulic System Components at the beginning of the Service and Repairs section of this chapter.

2. To prevent contamination of hydraulic system during manifold removal, thoroughly clean exterior of combination manifold and fittings.

3. Label all wire harness connectors that attach to solenoid coils on combination manifold. Disconnect wire harness connectors from solenoid coils on the combination manifold.

4. Disconnect hydraulic lines from combination manifold and put caps or plugs on open hydraulic lines and fittings. Label disconnected hydraulic lines for proper re-assembly.

NOTE: The combination manifold has three (3) studs on the bottom surface of the manifold used for securing the manifold to the machine.

5. Remove combination manifold from the frame using Figure 74 as a guide.

6. If hydraulic fittings are to be removed from manifold, mark fitting orientation to allow correct assembly (Fig. 75). Remove fittings from manifold and discard O-rings.

Installation (Fig. 74)

1. If fittings were removed from manifold, lubricate and place new O-rings onto fittings. Install fittings into manifold openings using marks made during the removal process to properly orientate fittings. Tighten fittings (see Hydraulic Fitting Installation in the General Information section of this chapter).

2. Install combination manifold to the frame using Figure 74 as a guide.

3. Remove caps and plugs from fittings and hydraulic lines. Using labels placed during manifold removal, properly connect hydraulic lines to manifold (see Hydraulic Hose and Tube Installation in the General Information section of this chapter).

4. Using labels made during manifold removal, connect wire harness connectors to the solenoid coils on the combination manifold.

5. Make sure hydraulic tank is full. Add correct oil if necessary before returning machine to service.




Figure 75

- | | |
|---------------------|-----------------------|
| 1. Manifold | 8. Straight fitting |
| 2. Straight fitting | 9. Barbed 90° fitting |
| 3. Straight fitting | 10. Hose clamp |
| 4. Straight fitting | 11. Hose |
| 5. Oil filter | 12. 90° fitting |
| 6. Straight fitting | 13. Test nipple |
| 7. Straight fitting | 14. Straight fitting |

Combination Manifold Service




Figure 76

- | | | |
|---------------------------------------|-------------------------------------|-------------------------------------|
| 1. Combination manifold | 9. Solenoid valve (S1) | 16. Solenoid valve (S12) |
| 2. #6 zero leak plug with O-ring | 10. Pressure reducing valve (PR) | 17. Orifice (0.070) (C2, C3 and C5) |
| 3. Check valve (CV3) | 11. Proportional relief valve (PRV) | 18. Orifice (0.030) (OR1 and OR9) |
| 4. #4 zero leak plug with O-ring | 12. Solenoid valve (S10) | 19. #4 zero leak plug with O-ring |
| 5. Solenoid valve (S4, S6 and S9) | 13. Solenoid valve (S11) | 20. Check valve (CV4) |
| 6. Solenoid valve (S5) | 14. Relief valve (RV1) | 21. Straight fitting |
| 7. Relief valve (RV2) | 15. Relief valve (RV3) | 22. Fitting adapter |
| 8. Solenoid valve (S2, S3, S7 and S8) | | |

NOTE: The ports on the combination manifold are marked for easy identification of components. Example: P4 is the gear pump connection port, S1 is the lift/lower solenoid valve and SV10 is the engine cooling fan solenoid valve (see Hydraulic Schematic in Chapter 10 – Foldout Drawings to identify the function of the hydraulic lines and cartridge valves at each port).



WARNING

If combination manifold is attached to machine, make sure that cutting units are fully lowered before loosening hydraulic lines or cartridge valves from combination manifold. If cutting units are raised as components are loosened in manifold, cutting units may drop unexpectedly.

NOTE: The combination manifold uses several zero leak plugs. These plugs have a tapered sealing surface on the plug head that is designed to resist vibration induced plug loosening. The zero leak plugs also have an O-ring as a secondary seal. If zero leak plug removal is necessary, lightly rap the plug head using a punch and hammer before using an allen wrench to remove the plug; the impact will allow plug removal with less chance of damage to the socket head of the plug.

Combination Manifold Service

For combination manifold cartridge valve service procedures, see Control Manifold Cartridge Valve Service in this section. Refer to Figures 76, 77 and 78 for combination manifold cartridge valve and plug installation torque.

IMPORTANT: A flow control orifice is located beneath several plugs in the combination control manifold. If an orifice is removed from a manifold port, make sure to label its position for assembly purposes. When installing the orifice in the manifold, make sure that the orifice is properly tightened in the port.

IMPORTANT: A flow control orifice is placed beneath hydraulic fittings in combination manifold ports C2, C3 and C5. If any of these fittings is removed from the manifold, make sure to remove orifice and label its position for assembly purposes. Also note location of groove in orifice for assembly purposes. When installing the orifice in the manifold, make sure that the orifice is flat in the base of the port.




Figure 77

- | | |
|----------------------|----------------------|
| 1. #4 zero leak plug | 5. Orifice (0.063) |
| 2. #6 zero leak plug | 6. Check valve |
| 3. Orifice (0.040) | 7. Compensator valve |
| 4. #4 zero leak plug | |




Figure 78

- | | |
|---------------------|---------------------|
| 1. #6 hex head plug | 2. #4 hex head plug |
|---------------------|---------------------|

Control Manifold Cartridge Valve Service

1. Make sure the control manifold is clean before removing the cartridge valve from the control manifold.

2. If cartridge valve is solenoid operated, remove nut securing solenoid coil to the cartridge valve. Carefully slide coil off the valve.

IMPORTANT: Use care when handling the cartridge valve. Slight bending or distortion of the stem tube can cause binding and malfunction. When removing cartridge valve from manifold, make sure that deep well socket fully engages the valve base.

3. Remove cartridge valve from manifold using a deep socket wrench. Note correct location for O-rings, sealing rings and backup rings. Remove seal kit from cartridge valve and discard removed seals.

4. Visually inspect the port in the manifold for damage to the sealing surfaces, damaged threads and contamination.

5. Visually inspect cartridge valve for damaged sealing surfaces and contamination.

A. Contamination may cause valves to stick or hang up. Contamination can become lodged in small valve orifices or seal areas causing malfunction.

B. If valve sealing surfaces appear pitted or damaged, the hydraulic system may be overheating or there may be water in the system.



CAUTION

Use eye protection such as goggles when using compressed air.

6. Clean cartridge valve using clean mineral spirits. Submerge valve in clean mineral spirits to flush out contamination. Particles as fine as talcum powder can affect the operation of high pressure hydraulic valves. If cartridge design allows, use a wood or plastic probe to push the internal spool in and out 20 to 30 times to flush out contamination. Be extremely careful not to damage cartridge. Use compressed air for cleaning.

7. Install the cartridge valve into the manifold:

A. Lubricate new seal kit components with clean hydraulic oil and install on valve. The O-rings, sealing rings and backup rings must be arranged properly on the cartridge valve for proper operation and sealing.

B. Dip assembled cartridge into clean hydraulic oil.

IMPORTANT: Use care when handling the valve cartridge. Slight bending or distortion of the stem tube can cause binding and malfunction. When installing cartridge valve into manifold, make sure that deep well socket fully engages the valve base.

C. Thread cartridge valve carefully into manifold port by hand until the top O-ring is met. The valve should go into manifold port easily without binding.

D. Torque cartridge valve using a deep socket wrench to value identified in control manifold illustration.

8. If cartridge valve is solenoid operated, carefully install solenoid coil to the cartridge valve. Secure coil to valve with nut and torque nut to **60 in-lb (6.8 N-m)**.

9. If problems still exist after assembly, remove valve and clean again or replace valve.

This page is intentionally blank.

Steering Control Valve




Figure 79

- | | | |
|--------------------------------|-------------------------------|----------------------------|
| 1. Steering wheel cover | 8. Steering shaft | 15. Valve mount plate |
| 2. Hex nut | 9. Flange bushing | 16. Steering control valve |
| 3. Flat washer | 10. Thrust washer (as needed) | 17. Steering column |
| 4. Steering wheel | 11. Cap screw (4 used) | 18. Cap screw (2 used) |
| 5. Foam collar | 12. Washer (4 used) | 19. Pivot hub (2 used) |
| 6. Steering seal | 13. Washer (4 used) | 20. Flange nut (2 used) |
| 7. External snap ring (2 used) | 14. Mount (4 used) | |

Removal (Fig. 79)

1. Park machine on a level surface, lower cutting decks, stop engine, apply parking brake and remove key from the ignition switch.
2. Remove steering tower cover to allow access to steering control valve.
3. Read the General Precautions for Removing and Installing Hydraulic System Components at the beginning of the Service and Repairs section of this chapter.
4. To prevent contamination of hydraulic system during steering control valve removal, thoroughly clean exterior of control valve and fittings.

NOTE: To ease installation, label the hydraulic lines to show their correct position on the steering control valve.

5. Remove hydraulic lines from steering control valve.
6. Remove steering control valve from machine using Figure 79 as a guide.
7. If hydraulic fittings are to be removed from steering control valve, mark fitting orientation to allow correct assembly. Remove fittings from valve and discard O-rings (Figs. 80 and 81).

Installation (Fig. 79)

1. If fittings were removed from steering control valve, lubricate and place new O-rings onto fittings. Install fittings into port openings using marks made during the removal process to properly orientate fittings (Figs. 80 and 81). Tighten fittings (see Hydraulic Fitting Installation in the General Information section of this chapter).
2. Install steering control valve using Figure 79 as a guide.
3. Using labels placed during steering control valve removal, properly install hydraulic lines to control valve (see Hydraulic Hose and Tube Installation in the General Information section of this chapter).
4. Make sure hydraulic tank is full.
5. Properly fill hydraulic system (see Charge Hydraulic System in this section).
6. Install steering tower cover to machine.




Figure 80

- | | |
|------------------------------|--------------------------|
| 1. Steering control valve | 4. 45° hydraulic fitting |
| 2. 45° hydraulic fitting | 5. Straight fitting |
| 3. Straight fitting (2 used) | |




Figure 81

- | | |
|---------------------------|----------------|
| 1. Steering control valve | 5. 45° fitting |
| 2. O-ring | 6. 45° fitting |
| 3. Straight fitting | 7. O-ring |
| 4. Straight fitting | 8. O-ring |

Steering Control Valve Service




Figure 82

- | | | |
|------------------------------|-----------------------|--------------------|
| 1. Steering valve housing | 9. Cap screw (7 used) | 17. Gerotor drive |
| 2. Dust seal | 10. End cap | 18. Wear plate |
| 3. O-ring | 11. O-ring | 19. Bearing race |
| 4. Spool | 12. Seal ring | 20. Thrust bearing |
| 5. Spring retaining ring | 13. O-ring | 21. Plug |
| 6. Pin | 14. Gerotor | 22. O-ring |
| 7. Sleeve | 15. O-ring seal | 23. Check ball |
| 8. Centering springs/spacers | 16. Quad seal | |

NOTE: For steering control valve repair procedures, see the Eaton Parts and Repair Information: 5 Series Steering Control Units at the end of this chapter.

This page is intentionally blank.

Steering Cylinder




Figure 83

- | | | |
|----------------------------|-----------------------------------|------------------------------|
| 1. Steering cylinder | 6. Grease fitting | 10. Axle washer |
| 2. Ball joint | 7. 90° hydraulic fitting (2 used) | 11. Slotted hex nut (2 used) |
| 3. Ball joint | 8. Drive axle assembly | 12. Cotter pin (2 used) |
| 4. Retaining ring (2 used) | 9. Ball joint spacer | 13. Bulkhead mount plate |
| 5. Grease fitting | | |

Removal (Fig. 83)

1. Park machine on a level surface, lower cutting decks, stop engine, apply parking brake and remove key from the ignition switch.
2. Read the General Precautions for Removing and Installing Hydraulic System Components at the beginning of the Service and Repairs section of this chapter.
3. To prevent contamination of hydraulic system during cylinder removal, thoroughly clean exterior of cylinder and fittings.

NOTE: To ease installation, label the hydraulic hoses to show their correct position on the steering cylinder.

4. Remove hydraulic hoses from steering cylinder (Fig. 84).
5. Remove cotter pins, slotted hex nuts, axle washer and ball joint spacer from the threaded ends of ball joints. Remove steering cylinder with ball joints from machine.
6. If hydraulic fittings are to be removed from steering cylinder, mark fitting orientation to allow correct assembly. Remove fittings from cylinder and discard O-rings.
7. If needed, remove ball joints from steering cylinder.

Installation (Fig. 83)

1. If removed, install ball joints into steering cylinder.
2. If fittings were removed from steering cylinder, lubricate and place new O-rings onto fittings. Install fittings into port openings using marks made during the removal process to properly orientate fittings. Tighten fittings (see Hydraulic Fitting Installation in the General Information section of this chapter).
3. Slide ram end ball joint through hole on steering arm. Secure with axle washer and hex slotted nut. Slide fixed end of cylinder through hole on axle. Secure with slotted hex nut. Torque slotted hex nuts from **79 to 84 ft-lbs (108 to 113 N-m)** and then continue tightening the nut until hex nut groove aligns with cotter pin hole in ball joint. Install cotter pin to nut and ball joint.

4. Install hydraulic hoses to steering cylinder (see Hydraulic Hose and Tube Installation in the General Information section of this chapter).
5. Fill reservoir with new hydraulic fluid as required.
6. Properly fill hydraulic system (see Charge Hydraulic System in this section).
7. After assembly is completed, operate steering cylinder to verify that hydraulic hoses and fittings are not contacted by anything.




Figure 84

- | | |
|----------------------|--------------------------|
| 1. Steering cylinder | 4. 90° hydraulic fitting |
| 2. Hydraulic hose | 5. Bulkhead mount plate |
| 3. Hydraulic hose | |

Steering Cylinder Service




Figure 85

- 1. Barrel
- 2. Rod
- 3. Piston
- 4. Head

- 5. Internal collar
- 6. Backup ring
- 7. O-ring
- 8. Dust seal

- 9. Rod seal
- 10. O-ring
- 11. Piston seal
- 12. Lock nut

Disassembly (Fig. 85)

1. Pump oil out of steering cylinder into a drain pan by slowly moving rod in and out of cylinder bore. After oil has been removed from cylinder, plug ports and clean outside of cylinder.

IMPORTANT: Prevent damage when clamping the cylinder in a vise, clamp on the clevis only. Use of a vise with soft jaws is recommended.

2. Mount steering cylinder securely in a vise by clamping on the clevis end of the barrel. Use of a vise with soft jaws is recommended.

3. Use a spanner wrench to loosen and remove internal collar (item 5) from barrel.

4. Grasp end of rod and use a twisting and pulling motion to carefully extract rod, piston and head assembly from cylinder barrel.

IMPORTANT: Do not clamp vise jaws against rod surface; the rod will be damaged.

5. Securely mount rod, piston and head assembly into vise with soft jaws.

6. Remove lock nut and then piston from the rod. Slide head and then internal collar off the rod.

7. Remove and discard all seals and O-rings from the piston and the head.



8. Wash cylinder parts in clean solvent. Dry parts with compressed air. Do not wipe parts dry with paper towels or cloth. Lint in a hydraulic system will cause damage.

9. Carefully inspect internal surface of barrel for damage (deep scratches, out-of-round, etc.). Inspect rod and piston for evidence of excessive scoring, pitting or wear. Replace steering cylinder if internal components are worn or damaged.

Assembly (Fig. 85)

1. Use a complete repair kit when rebuilding the steering cylinder. Put a coating of clean hydraulic oil on all new seals and O-rings.

2. Install new lubricated O-rings and seals to the piston and head.

IMPORTANT: Do not clamp vise jaws against the rod surface.

3. Mount rod securely in a vise by clamping on the clevis of the rod.

4. Lubricate rod with clean hydraulic oil. Carefully slide internal collar, head and then piston onto the rod.

5. Install and tighten lock nut onto rod. Torque lock nut **40 ft-lb (54 N-m)**.

6. Remove rod assembly from vise.

7. Put a coating of clean hydraulic oil on all cylinder parts to ease assembly.

8. Carefully slide rod assembly into cylinder barrel.

IMPORTANT: Prevent damage when clamping the cylinder in a vise, clamp on the clevis only. Use of a vise with soft jaws is recommended.

9. Mount steering cylinder securely in a vise by clamping on the clevis end of the barrel. Use of a vise with soft jaws is recommended.

10. Secure head in barrel by using a spanner wrench to install and tighten internal collar (item 5) into barrel.

Engine Cooling Fan Motor





Figure 86

- | | | |
|---------------------------------|--------------------------|---------------------------|
| 1. Hydraulic fan motor | 11. Cap screw (4 used) | 21. Hydraulic tube |
| 2. O-ring | 12. Washer (4 used) | 22. Hydraulic tube |
| 3. Fan bracket | 13. Fan | 23. Support shim |
| 4. Hydraulic fitting (2 used) | 14. Lock nut (2 used) | 24. Bulkhead nut (2 used) |
| 5. O-ring | 15. Cap screw (2 used) | 25. Bulkhead nut |
| 6. Radiator/oil cooler assembly | 16. Flat washer (2 used) | 26. Cap used (6 used) |
| 7. Fan hub | 17. O-ring | 27. Flange nut (6 used) |
| 8. Washer | 18. Hydraulic fitting | 28. Hydraulic tube |
| 9. Hex nut | 19. O-ring | 29. Hydraulic tube |
| 10. Lower radiator shroud | 20. Hydraulic tube | 30. Hydraulic tube |

Removal (Fig. 86)

1. Park machine on a level surface, lower cutting decks, stop engine, apply parking brake and remove key from the ignition switch.
2. Unlatch and raise hood.



3. Read the General Precautions for Removing and Installing Hydraulic System Components at the beginning of the Service and Repairs section of this chapter.

4. Thoroughly clean three (3) hydraulic tubes at lower radiator shroud. Disconnect hydraulic tubes and put caps or plugs on tubes to prevent contamination. Label disconnected hydraulic tubes for proper installation.

5. Remove air cleaner inlet hose and radiator shrouds (upper and lower) to allow easier access to hydraulic fan motor (Fig. 87).

6. Remove flange head screws and flange nuts that secure radiator supports to frame (items 11 and 12 in Fig. 87). This will allow radiator assembly to be moved slightly to ease removal of cooling fan motor and bracket assembly.

7. Remove four (4) cap screws (item 11) and washers used to secure fan to fan hub. Remove fan.

IMPORTANT: Make sure to not damage the radiator or other machine components while loosening and removing the fan motor and bracket assembly.

8. Remove cooling fan motor and bracket assembly.
 - A. To prevent contamination of hydraulic system, thoroughly clean exterior of fan motor and fittings.
 - B. Disconnect three (3) hydraulic tubes from fan motor. Put caps or plugs on fittings and tubes to prevent contamination. Label hydraulic lines for proper assembly.
 - C. Remove six (6) cap screws and flange nuts that secure fan motor bracket to radiator.
 - D. Carefully remove fan motor and bracket assembly from machine and place on suitable work surface.




Figure 87

- | | |
|--------------------------|----------------------------|
| 1. Radiator | 7. Cap screw (6 used) |
| 2. Upper radiator shroud | 8. Flat washer (7 used) |
| 3. Lower radiator shroud | 9. R-clamp |
| 4. Screw (4 used) | 10. Air cleaner inlet hose |
| 5. Flange nut (4 used) | 11. Screw (4 used) |
| 6. Cap screw (2 used) | 12. Flange nut (4 used) |

9. Remove hex nut (item 9) and washer (item 8) that secure fan hub to fan motor. Use suitable puller to carefully remove fan hub from fan motor shaft. Locate and retrieve woodruff key from motor shaft.

10. Remove two (2) cap screws (item 15), flat washers (item 16) and lock nuts (item 14) that secure fan motor to fan motor bracket. Remove fan motor from bracket.

11. If necessary, remove fittings from motor and discard O-rings.

Installation (Fig. 86)

1. If fittings were removed from fan motor, lubricate and place new O-rings onto fittings. Install and tighten fittings in port openings (see Hydraulic Fitting Installation in the General Information section of this chapter).
2. Position fan motor to fan motor bracket and secure with cap screws (item 15), flat washers (item 16) and lock nuts (item 14).
3. Thoroughly clean tapered surfaces of fan motor shaft and fan hub. Place woodruff key in slot in motor shaft.

4. Position fan hub onto motor shaft and secure with washer (item 8) and hex nut (item 9).

IMPORTANT: Make sure to not damage the radiator or other machine components while installing the fan motor and bracket assembly.

5. Carefully position fan motor and bracket assembly to radiator and secure with six (6) cap screws and flange nuts.

6. Secure radiator assembly to frame with removed fasteners (Fig. 87).

7. Connect three (3) hydraulic tubes to cooling fan motor (see Hydraulic Hose and Tube Installation in the General Information section of this chapter).

8. Position fan to fan hub and secure with four (4) cap screws and washers. Torque screws from **12 to 14 ft-lb (17 to 18 N-m)**.

9. Install radiator shrouds (lower and upper) and air cleaner hose (Fig. 87). Make sure that clearance between shrouds and cooling fan is at least 0.180" (4.6 mm) at all points.

10. Connect three (3) hydraulic tubes at lower radiator shroud (see Hydraulic Hose and Tube Installation in the General Information section of this chapter).

11. Lower and secure hood.

12. Make sure hydraulic tank is full.

13. Properly fill hydraulic system (see Charge Hydraulic System in this section).

This page is intentionally blank.

Engine Cooling Fan Motor Service




Figure 88

- | | | |
|---------------------|---------------------|------------------------|
| 1. Flange washer | 7. Shaft seal | 12. Idler gear |
| 2. O-ring | 8. Backup gasket | 13. Cap screw (4 used) |
| 3. Front flange | 9. Pressure seal | 14. Dowel (2 used) |
| 4. Dust seal | 10. Rear wear plate | 15. Drive gear |
| 5. Retaining ring | 11. Body | 16. Washer (4 used) |
| 6. Front wear plate | | |

NOTE: Internal components for a cooling fan motor are not available separately. Disassemble motor for cleaning, inspection and seal replacement only.

Disassembly (Fig. 88)

1. Plug motor ports and clean the outside of the motor thoroughly. After cleaning, remove plugs and drain any oil out of the motor.

2. Use a marker to make a **diagonal** line across the front flange and body for assembly purposes (Fig. 89).

IMPORTANT: Prevent damage when clamping the fan motor in a vise; clamp on the front flange only. Also, use a vise with soft jaws.

3. Clamp front flange of motor in a vise with soft jaws with the shaft end down.

4. Loosen cap screws from the rear of the body.

5. Remove motor from the vise. Turn motor so that the shaft end is facing down. Remove cap screws.

6. Carefully remove body. Lift body straight up to remove. Make sure the rear wear plate remains on the drive and idler gear shafts. Remove and discard O-rings from the body. Locate and retrieve dowel pins.




Figure 89

IMPORTANT: Note position of the open and closed side of the wear plates before removing. Also, identify wear plates (front and rear) with a marker for proper assembly.

7. Carefully remove rear wear plate, idler gear, drive gear and front wear plate from the front flange.

8. Remove and discard back-up gaskets and pressure seals from wear plates.

9. Turn front flange over, with seal side up.

IMPORTANT: Make sure not to damage the front flange counter bore when removing the seals from the front flange.

10. Carefully remove dust seal, retaining ring, flange washer and shaft seal from the front flange (Fig. 90). Note orientation of seal lips during removal. Discard removed seals.

Inspection

1. Remove any nicks and burrs from all parts with emery cloth.



2. Clean all parts with solvent. Dry all parts with compressed air.

3. Inspect drive gears and idler gears for the following (Fig. 91):

A. Gear shafts should be free of rough surfaces and excessive wear at bushing points and sealing areas. Scoring, rough surfaces or wear on gear shafts indicates need for replacement.

B. Gear teeth should be free of excessive scoring and wear. Any broken or nicked gear teeth must be replaced.

C. Inspect gear face edge for sharpness. Sharp edges of gears will mill into wear plates and, thus, must be replaced.

4. Inspect wear plates for the following:

A. Bearing areas should not have excessive wear or scoring.

B. Face of wear plates that are in contact with gears should be free of wear, roughness or scoring.

C. Thickness of wear plates should be equal.

5. Inspect front flange and body for damage or wear.




Figure 90

- | | |
|-------------------|------------------|
| 1. Dust seal | 3. Flange washer |
| 2. Retaining ring | 4. Shaft seal |




Figure 91

- | | |
|----------------------|-------------------|
| 1. Gear shaft spline | 3. Gear teeth |
| 2. Gear shaft | 4. Gear face edge |

Assembly (Fig. 88)

NOTE: When assembling motor, check the marker line on each part to make sure parts are properly aligned during assembly.

1. Lubricate O-rings, pressure seals, back-up gaskets and wear plate grooves with a thin coat of petroleum jelly. Lubricate all other internal parts freely with clean hydraulic oil.

2. Install new seals into front flange (Fig. 90). Note orientation of seal lips during installation:

A. Press shaft seal into front flange until it reaches the bottom of the bore.

B. Install flange washer into front flange and then install retaining ring into the groove of the front flange.

C. Install new dust seal into front flange.

3. Place front flange, seal side down, on a flat surface.
4. Install the pressure seals, flat side outward, into the grooves in the wear plates. Follow by carefully placing the backup gaskets, flat side outward, between the pressure seals and the grooves in the wear plate.
5. Apply a light coating of petroleum jelly to the exposed side of the front flange.
6. Lubricate the drive gear shaft with clean hydraulic oil. Insert the drive end of the drive shaft through the wear plate with the pressure seal side down and the open side of the pressure seal pointing to the inlet side of the motor. Carefully install shaft into front flange.
7. Lubricate the idler gear shaft with clean hydraulic oil. Install idler gear shaft into the remaining position in the front wear plate. Apply a light coating of clean hydraulic oil to gear faces.
8. Install rear wear plate with pressure seal side up and open side of the pressure seal pointing to the inlet side of the motor.
9. Apply a light coating of petroleum jelly to new O-rings and O-ring grooves in the body. Install new O-rings to the body.

10. Install locating dowels in body. Align marker line on the body and front flange.

IMPORTANT: Do not dislodge seals during installation.

11. Gently slide the body onto the assembly. Firm hand pressure should be sufficient to engage the dowels.

12. Install the four (4) cap screws with washers and hand tighten.

IMPORTANT: Prevent damage when clamping the fan motor into a vise; clamp on the front flange only. Also, use a vise with soft jaws.

13. Place front flange of the motor into a vise with soft jaws and alternately torque the cap screws **33 ft-lb (45 N-m)**.

14. Remove motor from vise.

15. Place a small amount of clean hydraulic oil in the inlet of the motor and rotate the drive shaft away from the inlet one revolution. If any binding is noted, disassemble the motor and check for assembly problems.

Cutting Deck Motors

Removal

1. Park machine on a level surface, lower cutting decks, stop engine, apply parking brake and remove key from the ignition switch.

2. Read the General Precautions for Removing and Installing Hydraulic System Components at the beginning of the Service and Repairs section of this chapter.

3. Thoroughly clean exterior of deck motor and fittings. Disconnect hydraulic lines from motor. Put caps or plugs on fittings and hoses to prevent contamination. Label hydraulic lines for proper installation.

4. Remove two (2) flange head screws that secure hydraulic motor to motor mount (Fig. 92).

5. Carefully remove hydraulic motor from cutting deck taking care not to damage spider hub attached to motor. Locate and remove spider from the deck.

6. If necessary, straighten tab washer and remove nut, tab washer and spider hub from motor shaft.

7. If hydraulic fittings are to be removed from motor, mark fitting orientation to allow correct assembly. Remove fittings from motor and discard O-rings (Fig. 93).

Installation

1. If fittings were removed from motor, lubricate and place new O-rings onto fittings. Install fittings into port openings using marks made during the removal process to properly orientate fittings. Tighten fittings (see Hydraulic Fitting Installation in the General Information section of this chapter).

2. If removed, install spider hub on motor shaft. Secure with tab washer and nut. Torque nut from **27 to 33 ft-lb (37 to 44 N-m)**. Bend small tab of washer into keyway and large tab against nut.

3. Position spider in spindle pulley. Carefully install hydraulic motor to the cutting deck taking care not to damage spider hub attached to motor.

4. Secure motor to cutting deck with two (2) flange head screws (Fig. 92).

5. Remove caps or plugs from fittings and hoses. Connect hydraulic hoses to deck motor (see Hydraulic Hose and Tube Installation in the General Information section of this chapter).

6. After assembly is completed, verify that hydraulic hoses and fittings are not contacted by moving components.




Figure 92

- | | |
|--------------------------|-----------------|
| 1. Cutting deck motor | 5. Spider hub |
| 2. Flange screw (2 used) | 6. Woodruff key |
| 3. Nut | 7. Spider |
| 4. Tab washer | |




Figure 93

- | | |
|------------------------|----------------------|
| 1. Motor (center deck) | 6. Hydraulic fitting |
| 2. O-ring | 7. O-ring |
| 3. Hydraulic fitting | 8. O-ring |
| 4. O-ring | 9. Hydraulic fitting |
| 5. O-ring | 10. O-ring |

Cutting Deck Motor Service (Sauer-Danfoss)




Figure 94

- | | | |
|-----------------|------------------|------------------------|
| 1. Rear cover | 6. Tab washer | 11. Body |
| 2. Drive gear | 7. Spider hub | 12. Idler gear |
| 3. Seal | 8. Pressure seal | 13. Cap screw (4 used) |
| 4. Woodruff key | 9. Back-up ring | 14. Front flange |
| 5. Nut | 10. O-ring | 15. Dowel pin |

NOTE: Internal components for a cutting deck motor are not available separately. Disassemble motor for cleaning, inspection and seal replacement only.

Disassembly (Fig. 94)

1. Plug motor ports and clean the outside of the motor thoroughly. After cleaning, remove plugs and drain any oil out of the motor.

2. Use a marker or scribe to make a **diagonal** mark across the front flange, body and rear cover for reassembly purposes (Fig. 95).

IMPORTANT: Prevent damage when clamping the deck motor into a vise; clamp on the front flange only. Also, use a vise with soft jaws.

3. Clamp mounting flange of motor in a vise with the shaft end down.

4. Loosen cap screws on the rear cover.

5. Take motor from the vise and remove cap screws.

6. Remove front flange from the body, then remove rear cover. Locate and remove dowel pins from body.




Figure 95

IMPORTANT: Mark the relative positions of the gear teeth and the bearing blocks so they can be re-assembled in the same position. Do not touch the gear surfaces as residue on hands may be corrosive to gear finish.

7. Place the motor on its side and push on the rear bearing block to remove the bearing block and gear set (Fig. 96).

8. Carefully remove and discard O-rings, pressure seals and back-up rings (Fig. 97) from motor. Do not cause any damage to the machined grooves during the removal process.

IMPORTANT: Make sure not to damage the counter bore when removing the shaft seal from the front plate.

9. Position front flange with seal side up. Carefully remove shaft seal taking care to not damage seal bore.

Inspection

1. Remove any nicks and burrs from all motor components with emery cloth.

	CAUTION
<p>Use eye protection such as goggles when using compressed air.</p>	

2. Clean all motor components with solvent. Dry all parts with compressed air.

3. Inspect drive gear, idler gear and bearing blocks (Fig. 98) for the following:

A. Gear shafts should be free of rough surfaces and excessive wear at bushing points and sealing areas. Scoring, rough surfaces or wear on gear shafts indicates need for replacement.

B. Gear teeth should be free of excessive scoring and wear. Any broken or nicked gear teeth must be replaced.

C. Inspect gear face edge for sharpness. Sharp edges of gears will mill into bearing blocks and, thus, must be replaced.

D. Bearing areas of bearing blocks should not have excessive wear or scoring.

E. Face of bearing blocks that are in contact with gears should be free of wear, roughness or scoring.

4. Inspect front flange, body and rear cover for damage or wear.




Figure 96

1. Motor body

2. Bearing block & gear set




Figure 97




Figure 98

1. Drive gear
2. Idler gear

3. Bearing block

Assembly (Fig. 94)

NOTE: When assembling the motor, check the identification marks made during disassembly to make sure the parts are properly aligned during assembly.

1. Lubricate O-rings, pressure seals, back-up gaskets and seal grooves with a thin coat of petroleum jelly. Lubricate all other internal parts freely with clean hydraulic oil.
2. Install new shaft seal into front flange.
3. Install lubricated pressure seals into the grooves in the front flange and rear cover. Follow by carefully placing the back-up rings into the grooves.
4. Install new O-rings to the body.
5. Lubricate gear faces and bearing surfaces of drive gear, idler gear and bearing blocks. Carefully assemble bearing blocks and gears noting identification marks made during disassembly.
6. Position the motor body on its side. Carefully slide bearing block and gear assembly into the body cavity using identification marks made during disassembly.
7. Remove any excess lubrication from mating surfaces of body, rear cover and front flange. Make sure that these surfaces are clean and dry.

8. Install dowel pins in body.

IMPORTANT: Do not dislodge O-rings, pressure seals or back-up rings during final assembly.

9. Gently slide the rear cover onto the assembly using marker or scribe mark for proper location. Firm hand pressure should be sufficient to engage the dowel pins.
10. Position the motor with rear cover downwards. Carefully slide the front flange onto the assembly using marker or scribe mark for proper location.
11. Install the four (4) cap screws and hand tighten.

IMPORTANT: Prevent damage when clamping the deck motor into a vise; clamp on the front flange only. Also, use a vise with soft jaws.

12. Place motor front flange in a vise and alternately torque the screws from **33 to 40 ft-lb (45 to 55 N-m)**.
13. Put a small amount of hydraulic oil in port on motor and rotate driveshaft one revolution. Protect the shaft if using a pliers. If drive shaft binds, disassemble motor and repeat assembly process.
14. Remove motor from vise.

This page is intentionally blank.

Cutting Deck Motor Service (Casappa)




Figure 99

- | | | |
|---------------------|---------------------|------------------------|
| 1. Flange washer | 7. Shaft seal | 13. Cap screw (4 used) |
| 2. O-ring | 8. Backup gasket | 14. Dowel (4 used) |
| 3. Front flange | 9. Pressure seal | 15. Drive gear |
| 4. Dust seal | 10. Rear wear plate | 16. Washer (4 used) |
| 5. Retaining ring | 11. Body | 17. Rear cover |
| 6. Front wear plate | 12. Idler gear | |

The Casappa cutting deck motors have similar construction as the cooling fan motor (also a Casappa brand) used on the Groundsmaster 4000-D and 4010-D. The deck motors have a separate rear cover (item 17 in Fig. 99) which is a difference from the cooling fan motor which includes the rear cover with the motor body. Orientation of the dust seal (item 4 in Fig. 99) is different in the deck motors than in the cooling fan motor.

For disassembly, inspection and assembly procedures of the Casappa cutting deck motors, refer to Engine Cooling Fan Motor Service in this section. When installing the seals into the front flange in a cutting deck motor, use the orientation shown in Figure 100.

NOTE: Internal components for a cutting deck motor are not available separately. Disassemble motor for cleaning, inspection and seal replacement only.




Figure 100

- | | |
|-------------------|------------------|
| 1. Dust seal | 3. Flange washer |
| 2. Retaining ring | 4. Shaft seal |

This page is intentionally blank.

PTO Manifold




Figure 101

- | | | |
|---|--|--------------------------------------|
| 1. Hydraulic PTO manifold (center deck) | 8. O-ring | 15. 90° hydraulic fitting |
| 2. Quick fitting (1 used per manifold) | 9. Hydraulic adapter | 16. Hydraulic PTO manifold (RH deck) |
| 3. Flange screw (2 used per manifold) | 10. Straight fitting | 17. Hex head plug |
| 4. O-ring | 11. Flange screw (2 used per manifold) | 18. 45° hydraulic fitting |
| 5. Hydraulic tee fitting | 12. Dust cap | 19. Hydraulic tee fitting |
| 6. O-ring | 13. 45° hydraulic fitting | 20. 90° hydraulic fitting |
| 7. O-ring | 14. Hydraulic PTO manifold (LH deck) | |

NOTE: The ports on the manifold are marked for easy identification of components. Example: PRV is the proportional relief valve and P1 is a gear pump connection port (see Hydraulic Schematic in Chapter 10 - Foldout Drawings to identify the function of the hydraulic lines and cartridge valves at each port).

Removal (Fig. 101)

1. Read the General Precautions for Removing and Installing Hydraulic System Components at the beginning of the Service and Repairs section of this chapter.
2. To prevent contamination of hydraulic system during manifold removal, thoroughly clean exterior of PTO manifold and fittings.
3. Disconnect wire harness connector from the proportional relief valve coil on the PTO manifold.
4. Disconnect hydraulic lines from manifold and put caps or plugs on open hydraulic lines and fittings. Label disconnected hydraulic lines for proper installation.
5. Remove PTO manifold from the frame using Figure 101 as a guide.

NOTE: The flange head screws that secure the right side PTO manifold also secures the controller mount to the frame (Fig. 102). Support controller mount before removing the right side PTO manifold.

6. If hydraulic fittings are to be removed from manifold, mark fitting orientation to allow correct assembly. Remove fittings from manifold and discard O-rings.

Installation (Fig. 101)

1. If fittings were removed from manifold, lubricate and place new O-rings onto fittings. Install fittings into manifold openings using marks made during the removal process to properly orientate fittings. Tighten fittings (see Hydraulic Fitting Installation in the General Information section of this chapter).
 2. Install PTO manifold to the frame using Figure 101 as a guide.
- NOTE:** Make sure that the controller mount is secured when installing the right side PTO manifold (Fig. 102).
3. Remove caps and plugs from fittings and hoses. Using labels placed during manifold removal, properly connect hydraulic lines to manifold (see Hydraulic Hose and Tube Installation in the General Information section of this chapter).
 4. Connect wire harness connector to the proportional relief valve coil on the PTO manifold.
 5. Make sure hydraulic tank is full. Add correct oil if necessary before returning machine to service.




Figure 102

1. RH PTO manifold
2. Controller mount
3. Flange screw (2 used)

PTO Manifold Service




Figure 103

- | | | |
|----------------------------------|---|--|
| 1. PTO manifold body | 5. Relief valve (port RV1) | 8. Nut |
| 2. NWD SAE #4 plug with O-ring | 6. Proportional relief valve (port PRV) | 9. Logic cartridge valve (port LC1) |
| 3. Orifice (0.025) (port OR) | 7. Solenoid coil | 10. Pilot directional valve (port PD1) |
| 4. #6 zero leak plug with O-ring | | |

NOTE: The ports on the manifold are marked for easy identification of components. Example: RV is the relief valve port and P1 is the gear pump connection port (see Hydraulic Schematic in Chapter 10 - Foldout Drawings to identify the function of the hydraulic lines and cartridge valves at each port location).

The manifolds for the three (3) cutting decks are very similar. The front and right side PTO manifolds are identical. The left side PTO manifold uses the same cartridges and plugs as the front and right side manifolds but also includes an additional orifice that threads into the manifold OR2 port (Fig. 104). **NOTE:** When servicing the PTO manifolds, **DO NOT** interchange parts from one manifold to another.

NOTE: The PTO manifold assembly includes zero leak plugs. These plugs have a tapered sealing surface on the plug head that is designed to resist vibration induced plug loosening. The zero leak plugs also have an O-ring as a secondary seal. If zero leak plug removal is necessary, lightly rap the plug head using a punch and hammer before using an allen wrench to remove the plug: the impact will allow plug removal with less chance of damage to the socket head of the plug.

PTO Manifold Service (Fig. 103)

For PTO manifold solenoid and control valve service procedures, see Control Manifold Cartridge Valve Service in this section. Refer to Figure 103 for PTO manifold cartridge valve and plug installation torque.




Figure 104

- 1. LH PTO manifold
- 2. Orifice (OR2 port)

Side Deck Lift Cylinders




Figure 105

- 1. Lift arm assembly (LH shown)
- 2. Shoulder screw
- 3. Flange nut
- 4. Pin assembly

- 5. Lock nut
- 6. Flat washer
- 7. Cylinder pin
- 8. Spring pin

- 9. Lift cylinder
- 10. 90° hydraulic fitting
- 11. 90° hydraulic fitting

Removal (Fig. 105)

1. Park machine on a level surface, lower cutting decks, stop engine, apply parking brake and remove key from the ignition switch.
2. Read the General Precautions for Removing and Installing Hydraulic System Components at the beginning of the Service and Repairs section of this chapter.
3. To prevent contamination of hydraulic system during lift cylinder removal, thoroughly clean exterior of cylinder and fittings.



NOTE: To ease installation, label the hydraulic hoses to show their correct position on the lift cylinder.

4. Disconnect hydraulic hoses from lift cylinder.
5. Remove shoulder screw and flange nut that secure the pin assembly (item 4) to the lift arm. Remove pin assembly from lift arm and cylinder rod clevis.
6. Remove lock nut and flat washer from the cylinder pin (item 7). Remove cylinder pin with spring pin from the frame and cylinder barrel clevis.
7. Remove lift cylinder from machine.
8. If hydraulic fittings are to be removed from lift cylinder, mark fitting orientation to allow correct assembly. Remove fittings from cylinder and discard O-rings.

Installation (Fig. 105)

1. If fittings were removed from lift cylinder, lubricate and place new O-rings onto fittings. Install fittings into cylinder port openings using marks made during the removal process to properly orientate fittings. Tighten fittings (see Hydraulic Fitting Installation in the General Information section of this chapter).
2. Position cylinder barrel clevis to frame and insert cylinder pin (item 7) through the frame and cylinder barrel clevis. Secure pin with flat washer and lock nut.
3. Insert pin assembly (item 4) through the lift arm and cylinder rod clevis. Secure pin assembly to lift arm with shoulder screw and flange nut.
4. Attach hydraulic hoses to lift cylinder (see Hydraulic Hose and Tube Installation in the General Information section of this chapter).
5. Fill reservoir with hydraulic fluid as required.
6. After installation is completed, operate lift cylinder to verify that lift cylinder, hydraulic hoses and fittings are not contacted by anything.

Center Deck Lift Cylinders




Figure 106

- 1. Front frame
- 2. Flange head screw
- 3. Flange nut
- 4. Pin assembly

- 5. Grease fitting
- 6. Cotter pin (2 used per pin)
- 7. Flat washer (4 used per pin)
- 8. Clevis pin

- 9. Lift cylinder (2 used)
- 10. RH lift arm assembly
- 11. LH lift arm assembly

Removal (Fig. 106)

1. Park machine on a level surface, lower cutting decks, stop engine, apply parking brake and remove key from the ignition switch.
2. Read the General Precautions for Removing and Installing Hydraulic System Components at the beginning of the Service and Repairs section of this chapter.
3. To prevent contamination of hydraulic system during lift cylinder removal, thoroughly clean exterior of cylinder and fitting.



4. Disconnect hydraulic hose from lift cylinder.
5. Remove flange nut and flange head screw that secure the pin assembly (item 4) to the lift arm. Remove pin assembly from lift arm and cylinder rod end which will free lift cylinder from lift arm.
6. Remove one (1) cotter pin and two (2) flat washers from one end of the clevis pin (item 8) that secures barrel end of lift cylinder to front frame. Pull clevis pin from frame and cylinder barrel.
7. Remove lift cylinder from machine.
8. If necessary, remove hydraulic fitting from cylinder and discard O-rings (Fig. 107).

Installation (Fig. 106)

1. If fitting was removed from lift cylinder, lubricate and place new O-rings onto fitting. Install fitting into cylinder port. Tighten fitting (see Hydraulic Fitting Installation in the General Information section of this chapter).
2. Make sure that cotter pin and two (2) flat washers are installed on one end of the clevis pin (item 8).
3. Position cylinder barrel to frame and insert clevis pin through frame and cylinder barrel. Secure clevis pin with two (2) flat washers and cotter pin.
4. Insert pin assembly (item 4) through lift arm and cylinder rod end. Secure pin to lift arm with flange nut and flange head screw.
5. Attach hydraulic hose to lift cylinder (see Hydraulic Hose and Tube Installation in the General Information section of this chapter).
6. Fill reservoir with hydraulic fluid as required.
7. After assembly is completed, operate center deck lift cylinders to verify that lift cylinders, hydraulic hoses and fittings are not contacted by anything.




Figure 107

- | | |
|------------------|---------------------|
| 1. Lift cylinder | 3. Straight fitting |
| 2. O-ring | 4. O-ring |

Lift Cylinder Service




Figure 108

- | | | |
|-----------------------|-----------------|--------------------|
| 1. Barrel with clevis | 7. Back-up ring | 12. Lock nut |
| 2. Retaining ring | 8. Head | 13. Grease fitting |
| 3. Shaft with clevis | 9. O-ring | 14. Bushing |
| 4. Dust seal | 10. Wear ring | 15. O-ring |
| 5. Rod seal | 11. Piston | 16. Seal |
| 6. O-ring | | |




Figure 109

- | | | |
|----------------------|-------------------|-------------------|
| 1. Barrel | 5. Retaining ring | 9. Grease fitting |
| 2. Seal | 6. O-ring | 10. Wear ring |
| 3. Shaft with clevis | 7. Back-up ring | 11. Piston |
| 4. Dust seal | 8. Head | 12. Lock nut |

Disassembly (Figs. 108 and 109)

1. Remove oil from lift cylinder into a drain pan by slowly pumping the cylinder shaft. Plug both ports and clean the outside of the cylinder.

IMPORTANT: Prevent damage when clamping the cylinder in a vise; clamp on the clevis only.

2. Mount lift cylinder securely in a vise by clamping on the clevis end of the barrel. Use of a vise with soft jaws is recommended.

3. Loosen head from barrel:

A. Use a spanner wrench to rotate head clockwise until the edge of the retaining ring (item 2 in Figure 108 or item 5 in Figure 109) appears in the barrel opening.

B. Insert a screwdriver under the beveled edge of the retaining ring to start the retaining ring through the opening. Then, rotate the head counter-clockwise to remove retaining ring from barrel and head.

4. Extract shaft with head and piston by carefully twisting and pulling on the shaft.

IMPORTANT: Do not clamp vise jaws against the shaft surface.

5. Mount shaft securely in a vise by clamping on the clevis of the shaft. Use of a vise with soft jaws is recommended.

6. Remove lock nut and piston from the shaft. Slide head off the shaft.

7. Remove and discard all seals and O-rings from the piston and the head.



8. Wash cylinder parts in clean solvent. Dry parts with compressed air. Do not wipe parts dry with paper towels or cloth. Lint in a hydraulic system will cause damage.

9. Carefully inspect internal surface of barrel for damage (deep scratches, out-of-round, etc.). Inspect shaft and piston for evidence of excessive scoring, pitting or wear. Replace lift cylinder if internal components are found to be worn or damaged.

Assembly (Figs. 108 and 109)

1. Make sure all cylinder components are clean before assembly.

2. Coat new seal kit components with clean hydraulic oil. Install new lubricated seals and O-rings to the piston and head.

IMPORTANT: Do not clamp vise jaws against the shaft surface.

3. Mount shaft securely in a vise by clamping on the clevis of the shaft. Use of a vise with soft jaws is recommended.

A. Coat shaft with clean hydraulic oil.

B. Carefully slide head and then piston onto the shaft. Secure piston to shaft with lock nut.

C. Torque lock nut to specification in Figure 108 (side deck cylinder) or Figure 109 (center deck cylinder).

4. Remove shaft assembly from vise.

IMPORTANT: Prevent damage when clamping the hydraulic cylinder into a vise; clamp on the clevis end of the barrel ONLY.

5. Mount barrel securely in a vise by clamping on the clevis end of the barrel. Use of a vise with soft jaws is recommended.

IMPORTANT: When installing the head into the barrel of the lift cylinder, pay careful attention to the retaining ring slot in the barrel to insure that the piston and head seals do not lodge in the slot.

6. Coat all internal parts with a light coat of clean hydraulic oil. Slide piston, shaft and head assembly into the barrel being careful to not damage the seals.

7. Secure head in barrel:

A. Align retaining ring hole in the head with the access slot in the barrel.

B. Insert the retaining ring hook into the hole and rotate head clockwise until the retaining ring is completely pulled into the barrel and the ring ends are covered.

C. Apply silicone sealer to barrel access slot.

This page is intentionally blank.



Electrical System

Table of Contents

GENERAL INFORMATION	2	Cruise Control Switch	36
Operator's Manual	2	Seat Switch	37
Toro Electronic Controllers (TEC)	2	Parking Brake Switch	38
Yanmar Engine Electronic Control Unit (ECU) ...	3	Service Brake Switches	39
Yanmar Engine Electrical Components	3	Headlight Switch (Groundsmaster 4010-D)	40
CAN-bus Communications	4	Windshield Wiper/Washer Switch (Grounds-	
Electrical Drawings	4	master 4010-D)	41
SPECIAL TOOLS	6	Air Conditioning Switch (Groundsmaster	
INFOCENTER DISPLAY	8	4010-D)	42
TROUBLESHOOTING	15	Turn Signal Switch (Groundsmaster 4010-D) ..	43
Operator Advisories	15	Flasher Switch (Groundsmaster 4010-D)	44
Fault Codes	16	Traction Pedal Position Sensor	45
Starting Problems	18	Relays with Four (4) Terminals	46
General Run & Transport Problems	20	Relays with Five (5) Terminals	48
Cutting Deck Operating Problems	21	Toro Electronic Controllers (TEC)	50
Cutting Deck Lift/Lower Problems	23	Hydraulic Solenoid Valve Coils	52
ADJUSTMENTS	25	Piston (Traction) Pump Control Solenoid Coils .	54
Cutting Deck Position Switch Adjustment	25	CAN-bus Termination Resistor	55
Traction Pedal Adjustment	26	Diode Assemblies	56
Traction Pedal Position Sensor Calibration	28	Resistor Assembly	56
ELECTRICAL SYSTEM QUICK CHECKS	29	Fuel Sender	57
Battery Test (Open Circuit)	29	Fuel Pump (Models 30603 and 30605)	58
Charging System Test	29	Fuel Pump (Models 30607 and 30609)	59
Check Operation of Interlock Switches	29	Cutting Deck Position Switches	60
COMPONENT TESTING	30	Hydraulic Oil Temperature Sender	61
Ignition Switch	30	Audio Alarm	62
Fuses	31	SERVICE AND REPAIRS	63
Operator Cab Fuses (Groundsmaster 4010-D) ..	32	Battery Care	63
Fusible Link Harness	33	Battery Storage	63
PTO Switch	34	Battery Service	64
HI/LOW Speed, Engine Speed and Cutting Deck			
Lift Switches	35		

Electrical System

General Information

Operator's Manual

The Operator's Manual provides information regarding the operation, general maintenance and maintenance intervals for your Groundsmaster machine. Refer to that publication for additional information when servicing the machine.

Toro Electronic Controllers (TEC)

Groundsmaster 4000-D and 4010-D machines use two (2) Toro Electronic Controllers (TEC) to manage machine electrical functions. The controllers are microprocessor controlled that sense the condition of various switches and sensors (inputs). The controllers then direct electrical power to control appropriate machine functions (outputs) based on the input state. Communication between the two (2) TEC controllers, the Yanmar engine electronic control unit (ECU) and the machine InfoCenter Display is provided with a CAN-bus system. The status of inputs to the controllers as well as outputs from the controllers can be monitored with the InfoCenter Display.

The TEC controllers are attached to the machine under the power center cover next to the operator seat. The TEC controllers are visually identical but they have different software and therefore cannot be interchanged.

IMPORTANT: To prevent machine electrical system damage while welding on the machine, disconnect the battery cables from the batteries, disconnect the wire harness connectors from both Toro Electronic Controllers, disconnect the wire harness connectors from the engine electronic control unit and disconnect the terminal connector from the alternator. Also, disconnect and remove the engine ECU from the machine before welding.




Figure 1

- 1. Front TEC controller
- 2. Rear TEC controller
- 3. Operator seat

Yanmar Engine Electronic Control Unit (ECU)

The Yanmar engine that powers the Groundsmaster 4000-D and 4010-D uses an electronic control unit (ECU) for engine management and also to communicate with the TEC controllers and the InfoCenter Display on the machine. All engine ECU electrical connectors should be plugged into the controller before the machine ignition switch is moved from the OFF position to either the RUN or START position. If the engine ECU is to be disconnected for any reason, make sure that the ignition switch is in the OFF position with the key removed for a minimum of thirty (30) seconds before disconnecting the engine ECU. See Chapter 3 - Yanmar Diesel Engine for additional engine ECU information.




Figure 2

1. Electronic control unit (model 30603 / 30605)
2. Alternator




Figure 3

1. Electronic control unit (model 30607 / 30609)
2. Alternator

Yanmar Engine Electrical Components

When servicing or troubleshooting the engine electrical components, use the correct engine service manual and troubleshooting manual. Also, the Yanmar SMART-ASSIST-Direct electronic control diagnostics service system is available to support the error diagnosis and maintenance services of engine electrical control devices.

CAN-bus Communications

The two (2) TEC controllers, the Yanmar engine electronic control unit and the InfoCenter Display used on the Groundsmaster 4000-D and 4010-D communicate with each other on a CAN-bus system. Using this system allows the traction unit to fully integrate all the different electrical components of the tractor and bring them together as one. The CAN-bus system reduces the number of electrical components and connections used on the machine and allows the number of wires in the wire harness to be significantly reduced. The integration of electrical functions also allows the InfoCenter Display to assist with electrical system diagnostics.

CAN identifies the Controller Area Network that is used between the controllers on the Groundsmaster. Two (2) specially designed, twisted wires form the bus. These wires provide the data pathways between the controllers (the TEC controllers and the Yanmar electronic control unit) and the InfoCenter Display used on the machine. The engineering term for these wires are CAN High and CAN Low. At the ends of the twisted pair of bus wires are 120 ohm termination resistors. One of these resistors is included in the wire harness and the second is inside the engine ECU.

Each of the components that is controlled by the CAN-bus link needs only four (4) wires to operate and communicate to the system: CAN High, CAN Low, B+ (power) and ground. The CAN-bus needs the ignition switch ON input for both the TEC and engine ECU to be activated.

Electrical Drawings

The electrical schematics and wire harness drawings for Groundsmaster 4000-D and 4010-D machines are located in Chapter 10 - Foldout Drawings.

This page is intentionally blank.

Special Tools

Order special tools from your Toro Distributor. Some tools may also be available from a local supplier.

Multimeter

The multimeter can test electrical components and circuits for current, resistance or voltage.

NOTE: Toro recommends the use of a DIGITAL Volt-Ohm-Amp multimeter when testing electrical circuits. The high impedance (internal resistance) of a digital meter in the voltage mode will make sure that excess current is not allowed through the meter. This excess current can cause damage to circuits not designed to carry it.




Figure 4

Dielectric Gel

Dielectric gel should be used to prevent corrosion of connection terminals. To ensure complete coating of terminals, liberally apply gel to both component and wire harness connector, plug connector to component, unplug connector, reapply gel to both surfaces and reconnect harness connector to component. Connectors should be thoroughly packed with gel for effective results.

Toro Part Number: **107-0342**



Figure 5

Battery Terminal Protector

Aerosol spray that should be used on battery terminals to reduce corrosion problems. Apply terminal protector after the battery cable has been secured to the battery terminal.

Toro Part Number: **107-0392**



Figure 6

Battery Hydrometer

Use the Battery Hydrometer when measuring specific gravity of battery electrolyte. Obtain this tool locally.



Figure 7

InfoCenter Display

The InfoCenter Display used on your Groundsmaster is a LCD device that is located on the console. The InfoCenter provides information for the machine operator during machine operation, provides electrical system diagnostic assistance for technicians and allows inputs for adjustable machine settings.

Power for the InfoCenter is available when energized by the main power relay (ignition switch in the RUN or START position). A CAN-bus system involving the machine TEC controllers, the Yanmar engine electronic control unit and the InfoCenter is used to provide necessary machine communication for InfoCenter operation.

Splash Screen

The two (2) InfoCenter splash screens (Figs. 8 and 9) are displayed when the ignition switch is initially turned to the RUN or START position. The splash screens allow basic machine information to be reviewed by the operator. After each of the splash screens has been on the InfoCenter for several seconds, the main information screen will be displayed on the InfoCenter.

The splash screens can be used to identify machine battery voltage, fuel level, hourmeter reading, hydraulic oil temperature and engine status.




Figure 8

- | | |
|--------------------|---------------------|
| 1. Battery voltage | 4. Right button |
| 2. Fuel gauge | 5. Down button |
| 3. Hour meter | 6. Menu/back button |




Figure 9

- | | |
|------------------------------|---------------------|
| 1. Battery voltage | 5. Right button |
| 2. Hydraulic oil temperature | 6. Down button |
| 3. Fuel gauge | 7. Menu/back button |
| 4. Engine RPM | |

Main Information Screen

The two (2) InfoCenter main information screens (Figs. 10 and 11) are displayed after the initial splash screen has been displayed for several seconds. During normal machine operation, the main information screens provide machine information for the operator. Toggling between the main information screens is done by pressing the right button on the InfoCenter.

The main information screens can be used to monitor engine coolant temperature, fuel level, hydraulic oil temperature, battery voltage, engine RPM and traction speed range. The screens will also identify if the parking brake is applied, if the PTO is engaged or if the cruise control is activated.

The main information screens will also display arrows whenever the cutting decks are either raising (up arrows) or lowering (down arrows).

If controls are not selected properly to allow certain machine operations, an advisory will be displayed on the InfoCenter Display. Typically, an advisory can be eliminated with a change in controls by the operator.

If a machine fault occurs during machine operation, the InfoCenter fault indicator will blink to notify the operator. Accessing the fault log is described below in Faults Screen.

If an electrical engine fault occurs during machine operation, the fault will be displayed on the InfoCenter to notify the operator. The engine fault will be retained in the engine ECU and can be viewed using the engine diagnostic tool. Engine faults are not stored in the TEC controller so they cannot be viewed using the InfoCenter Faults Screen.

The main menu and additional information screens can be accessed from the InfoCenter main information screen by pressing and releasing the menu/back button (left button) on the display. Information on the main menu and menu item screens is included below.




Figure 10

- | | |
|--------------------------|---------------------|
| 1. Parking brake applied | 5. Fuel gauge |
| 2. Traction speed | 6. Right button |
| 3. Coolant temperature | 7. Down button |
| 4. Fault indicator | 8. Menu/back button |




Figure 11

- | | |
|------------------------------|---------------------|
| 1. Battery voltage | 5. Engine RPM |
| 2. Hydraulic oil temperature | 6. Right button |
| 3. Fault indicator | 7. Down button |
| 4. Fuel gauge | 8. Menu/back button |

Main Menu Screen

The main menu screen can be accessed from the InfoCenter main information by pressing and releasing the menu/back button (left button) on the display. Once to the main menu screen (Fig. 12), navigation to the five (5) different menu items can occur. Pressing the move to menu item button (center button) allows a different menu item to be highlighted. Selection of the highlighted item is completed by pressing the choose item button (right button).

The main menu items include faults, service, diagnostics, settings and about. These menu items are described below.

To return to the main information screen from the main menu screen, press the back button (left button).




Figure 12

- | | |
|-----------------------|---------------------|
| 1. Main menu | 4. Choose menu item |
| 2. Menu items | 5. Back button |
| 3. Move to menu items | |

Faults Screen

The faults screen (Fig. 13) will list all machine electrical faults that have occurred since the faults were last cleared from the InfoCenter. The faults will be identified by a fault number and when the fault occurred. Faults that might occur on the machine are listed in Fault Codes in the Troubleshooting section of this chapter.

After entry of the PIN code, the InfoCenter fault log can be cleared by selecting the clear system faults menu item. The cleared faults will be removed from the InfoCenter list but will be retained in the TEC controller memory.

If a fault occurs during machine use, there may be a change in machine functionality due to the fault. Should there be machine operation issues due to a fault, a first step to remedy the issue would be to disengage the cutting decks, release the traction pedal, turn the ignition switch OFF and allow all machine functions to stop. Then, attempt to restart the machine to see if operation has returned to normal. Some faults will be reset during the restart and will then allow normal function. If a fault continues to occur, further system evaluation and possible component repair or replacement will be necessary.

To return to the main menu screen from the faults screen, press the back button (left button).




Figure 13

- | | |
|-----------------------|---------------------|
| 1. Fault menu | 4. Choose menu item |
| 2. Fault items | 5. Back button |
| 3. Move to menu items | |

Service Screen

The service screen (Fig. 13) contains machine operational information including hours and counts. Values listed for these service menu items cannot be changed. If the machine PIN has been entered to allow access to protected menu items in the settings screen, the protected service menu items will be listed and available in the service screen.

NOTE: If the protected menu items are available, PIN will be shown in the upper right corner of the InfoCenter display.

The options listed for hours include the following:

- **Key On** identifies the number of hours that the ignition switch has been in the RUN position.
- **Machine Run** identifies the number of hours that the engine has been running.
- **PTO On** identifies the number of hours that the machine has been operated with the cutting decks engaged.
- **High Range** identifies the number of hours that the machine has been operated in HI range speed (transport).
- **Service Due** identifies the number of hours before the next scheduled maintenance is due.

The options listed for counts include the following:

- **Starts** identifies the number of times that the engine has been started.
- **Left Deck** identifies the number of times that the left side cutting deck has been energized.
- **Center Deck** identifies the number of times that the center cutting deck has been energized.
- **Right Deck** identifies the number of times that the right side cutting deck has been energized.
- **Fan Reversals** identifies the number of times that the engine cooling fan has been operated in the reverse direction.
- **Fan - Coolant** identifies the number of times that engine coolant temperature caused the engine cooling fan speed to change.

- **Fan - Oil** identifies the number of times that hydraulic oil temperature caused the engine cooling fan speed to change.

- **Inlet** identifies the temperature of the inlet air into the engine intake system.

The protected menu items include the following:

- **DPF Regeneration** provides the necessary procedure for stationary regeneration for the exhaust system DPF (diesel particulate filter) on machines with a Tier 4 engine (models 30607 and 30609). If the engine ECU identifies that a stationary DPF regeneration is necessary, an advisory will occur on the InfoCenter and the necessary steps will be listed in the service screen menu.

- **Traction Pedal** allows the traction pedal sensor to be calibrated (see Traction Pedal Position Sensor Calibration in the Adjustments section of this chapter for calibration procedure).

- **Fan Reverse** provides the necessary inputs to cause the cooling fan to reverse direction. This protected menu item allows the demonstration of the fan reversal and would never be necessary to use on a normally functioning machine.

To return to the main menu screen from the service screen, press the back button (left button).




Figure 13

1. Service menu
2. Service items
3. Move to menu items
4. Choose menu item
5. Back button

Diagnostics Screen

The diagnostics screen (Fig. 16) lists the various states of machine electrical components. The diagnostics screen should be used to check operation of machine controls and to verify that switches and circuit wiring are functioning correctly.

For each of the diagnostics screen items, inputs, qualifiers and outputs are identified. The diagnostics screen includes the following:

- **Left Deck** identifies machine requirements to allow the left deck to raise and lower. Inputs indicate the state of the left deck lift/lower switch and whether the machine is in LOW range speed. Qualifiers include the LOW range speed, seat switch and parking brake position. Identified outputs consist of master, lower, raise and float solenoids.

- **Center Deck** identifies machine requirements to allow the center deck to raise and lower. Inputs indicate the state of the center deck lift/lower switch. Qualifiers include the LOW range speed, seat switch and parking brake position. Identified outputs consist of master, raise and float solenoids.

- **Right Deck** identifies machine requirements to allow the right deck to raise and lower. Inputs indicate the state of the right deck lift/lower switch. Qualifiers include the LOW range speed, seat switch and parking brake position. Identified outputs consist of master, lower, raise and float solenoids.

- **Traction Pedal** identifies position of the traction pedal. Inputs indicate the state of the traction pedal position sensor. Outputs indicate whether the traction circuit is in forward, neutral or reverse.

- **Traction** identifies machine requirements to allow the traction system to be engaged. Inputs indicate the state of the traction pedal. Qualifiers include the seat switch and parking brake position. Outputs indicate whether the piston (traction) pump is engaged in forward or reverse.

- **Hi/Low Range** identifies machine requirements to allow HI or LOW speed range to be engaged. Inputs indicate the state of the hi/low switch. Qualifiers identify the position of the PTO switch and the cutting decks (raised or lowered). Outputs indicate whether HI range is engaged (solenoid S12 is energized).

- **PTO** identifies machine requirements to allow the PTO to be engaged. Inputs indicate the state of the PTO switch. Qualifiers identify whether LOW speed range is selected, if the seat is occupied and if the cutting decks are lowered. Outputs indicate which cutting decks are engaged.

- **Engine Run** identifies whether necessary TEC outputs exist to allow the engine to run. Inputs indicate the state of the ignition switch. Qualifiers identify whether the PTO is off, if the traction pedal is in neutral, if the seat is occupied (or parking brake is applied) and if all deck lift switches are not activated. Outputs indicate that requirements have been met to allow engine to run or start. **NOTE:** The components for engine operation (i.e. glow plugs, starter) are controlled by the Yanmar engine electronic control unit.

- **Cruise Control** identifies machine requirements to allow the cruise control to be engaged. Inputs indicate the state of the cruise control switch and service brakes. Qualifiers identify whether the seat is occupied, if the parking or service brakes are applied and if the traction pedal is not in neutral. Outputs indicate that the cruise function is engaged.

- **Light Kit** identifies machine requirements to allow machine lights (if equipped) to be energized. Inputs indicate the state of the light switches. Outputs indicate that the lights are energized.

To return to the main menu screen from the diagnostics screen, press the back button (left button).




Figure 16

- | | |
|-----------------------|---------------------|
| 1. Diagnostics menu | 4. Choose menu item |
| 2. Diagnostics items | 5. Back button |
| 3. Move to menu items | |

Settings Screen

The settings screen identifies the InfoCenter language and units (English or Metric). The settings screen also allows the operator to customize the backlight (brightness) and contrast settings for the InfoCenter display.

If either the backlight (brightness) or contrast items are selected, the center button (-) or right button (+) can be used to change the display settings.

Protected menus allows the machine PIN to be entered so that hidden machine service screen items can be viewed and modified. The protected service items include traction pedal sensor calibration, cooling fan reversal demonstration, Smart Power™ ON/OFF and exhaust system DPF regeneration (Tier4 engines). If the protect settings is ON (see below), auto idle, mow speed, transport speed and counterbalance are also included in the protected menu.

To allow access to the protected menu items, enter the four (4) digit pin PIN using the center and right InfoCenter buttons. After PIN has been entered, a check mark should be visible above center InfoCenter button. Press center button and the InfoCenter display screen should indicate “PIN” in the upper right hand corner if the correct PIN number was entered. Use back button to return to Settings menu. The protected menu items should be available in the Service menu and can be changed as long as the ignition switch remains in RUN.

NOTE: The initial PIN will either be 1234 or 0000. If the PIN has been changed and is forgotten, a temporary PIN can be obtained from your Toro distributor.

Protect settings allows the settings for auto idle, mow speed and transport speed to be hidden so they cannot be changed unless the PIN is entered. If the protect settings is ON, these settings will not be seen when using the InfoCenter until the protected menus is selected and the machine PIN is entered. If protect settings is OFF (default setting), settings for these functions will be visible on the InfoCenter and can be adjusted by the operator.

Reset Defaults allows machine settings to be returned to factory defaults.

Auto Idle causes the engine speed to decrease to low idle after the machine has not been in use for the set time delay in seconds. Auto idle can be adjusted to 8, 10, 15, 20 or 30 seconds or the auto idle feature can be turned OFF.

Mow Speed allows the maximum traction speed to be adjusted when in LOW (mow) speed. Mow speed can be adjusted to 40%, 70% or 100%.

Trans. (Transport) Speed allows the maximum traction speed to be adjusted when in HI (transport) speed. HI speed can be adjusted to 40%, 70% or 100%.

Smart Power allows the Smart Power™ feature to be turned OFF and ON.

To return to the main menu screen from the settings screen, press the back button (left button).




Figure 17

- | | |
|-----------------------|---------------------|
| 1. Settings menu | 4. Change menu item |
| 2. Settings items | 5. Back button |
| 3. Move to menu items | |




Figure 18

- | | |
|---------------------|---------------------|
| 1. Settings menu | 5. Decrease setting |
| 2. Settings items | 6. Back button |
| 3. Current setting | 7. PIN activated |
| 4. Increase setting | |

About Screen

The about screen (Fig. 17) identifies the machine model number, serial number and software revisions for the TEC controllers, InfoCenter and engine electronic control unit (if available). The about screen also lists the CAN-bus status. Additional information is identified if the about screen is accessed after the protected menus have been accessed by entering the PIN.

To return to the main menu screen from the about screen, press the back button (left button).




Figure 17

- | | |
|-----------------------|---------------------|
| 1. About menu | 4. Choose menu item |
| 2. About items | 5. Back button |
| 3. Move to menu items | |

Troubleshooting

 CAUTION
<p>Remove all jewelry, especially rings and watches, before doing any electrical troubleshooting or testing. Also, disconnect the battery cables unless the test requires battery voltage.</p>

If the machine has any interlock switches by-passed, reconnect the switches for safety and efficient troubleshooting.

NOTE: Check the InfoCenter Display for possible operator advisories or faults whenever diagnosing machine electrical problems.

For effective troubleshooting and repairs, you must have a good understanding of the electrical circuits and components used on this machine (see electrical schematics and wire harness drawings in Chapter 10 - Foldout Drawings).

Operator Advisories

The list below identifies the operator advisories that are generated by the TEC controller. An advisory will be displayed on the InfoCenter Display. Typically, an advisory can be eliminated with a change in machine controls by the operator.

Advisory	Advisory Description
160	Inhibit start
161	Inhibit PTO
162	Inhibit cutting unit lower
163	Inhibit traction HIGH speed range
164	Inhibit traction LOW speed range
165	Inhibit traction
166	Inhibit cruise control
167	Derate traction setting
168	Inhibit traction teach (traction pedal calibration)
169	Engine shutdown
170	Recycle keyswitch (ignition switch)
171	Auto idle engaged
172	Calibrate (traction pedal)
173	Master address claim (front TEC controller)
174	Slave address claim (rear TEC controller)
175	Derate engine

Fault Codes

The list below identifies the fault codes that are generated by the TEC controller to identify an electrical system malfunction (fault) that occurred during machine operation. Use the InfoCenter Display for fault retrieval.

NOTE: The following list of fault codes identifies electrical problems that typically will prevent normal machine operation. The InfoCenter Display will identify existing faults if they should occur. Fault codes 13 through 25 identify problems with inputs (e.g. switches, sensors) to the TEC controllers. For input problems, use the InfoCenter Display to check the different switch positions before removing or replacing the component.

NOTE: Fault codes 26 through 62 identify problems with outputs (e.g. solenoid coils, light bulbs) from the TEC controllers. These output problems might involve issues with the wire harness or the actual output device (solenoid coil or bulb).

Fault Code	Fault Description
1	Excessive engine coolant temperature (above 105°C) caused PTO to disengage
2	Excessive engine coolant temperature (above 115°C) caused engine to stop
3	One of the TEC output fuses (7.5 Amp) is faulty
4	IPE voltage too low indicating that TEC controller is faulty
5	Main power relay is faulty
6	Ignition switch was held in the START position for more than 30 seconds or the ignition switch is faulty
7	TEC software needs to be reprogrammed (contact Toro Distributor)
8	Alternator charging is too high
9	Alternator charging is too low
10	Engine has not been seen on CAN-bus for 10 seconds
11	Rear TEC controller has not been seen on CAN-bus for 1 second
12	InfoCenter has not been seen on CAN-bus for 1 second
13	Ignition switch is faulty (check ignition switch)
14	Traction pedal position sensor is faulty (check traction sensor)
15	Engine speed switch is faulty (check engine speed switch)
16	Traction system HI/LOW speed switch is faulty (check HI/LOW speed switch)
17	Traction pedal position sensor is out of range
18	Hydraulic temperature sensor circuit has open or short
21	Center cutting deck lift switch is faulty (check center lift switch)
22	Left cutting deck lift switch is faulty (check left lift switch)
23	Right cutting deck lift switch is faulty (check right lift switch)
25	Cruise control switch is faulty (check cruise control switch)
26	Engine START output has open or short to ground
27	Engine RUN output has open or short to ground
28	Traction system HIGH range output has open or short to ground
29	RH turn/warning light output has open or short to ground
30	LH turn/warning light output has open or short to ground

Fault Code	Fault Description
31	Brake/RH turn light output has open or short to ground
32	Brake/LH turn light output has open or short to ground
33	Forward piston (traction) pump output has open or short to ground
34	Reverse piston (traction) pump output has open or short to ground
35	Reverse engine cooling fan output (solenoid valve S10) has open or short to ground
36	Disable dual engine cooling fan output (solenoid valve S11) has open or short to ground
38	Center PTO output has open or short to ground
39	LH PTO output has open or short to ground
40	RH PTO output has open or short to ground
41	Solenoid valve S1 (lift/lower enable) output has open or short to ground
42	Solenoid valve S2 (LH deck raise) output has open or short to ground
43	Solenoid valve S3 (LH deck lower) output has open or short to ground
44	Solenoid valve S4 (LH deck float) output has open or short to ground
45	Solenoid valve S5 (center deck raise) output has open or short to ground
46	Solenoid valve S6 (center deck float) output has open or short to ground
47	Solenoid valve S7 (RH deck raise) output has open or short to ground
48	Solenoid valve S8 (RH deck lower) output has open or short to ground
49	Solenoid valve S9 (RH deck float) output has open or short to ground
52	Engine cooling fan output has open or short to ground
63	Traction pedal position sensor is returning a voltage higher than 4.75V or lower than 0.25V (replace the traction pedal position sensor)
64	Traction pedal position sensor neutral switches do not align with calibrated sensor values (recalibrate traction pedal position sensor)
65	Traction pedal position sensor forward/reverse switches are indicating the pedal is in both positions at the same time (replace the traction pedal position sensor)
66	TEC controller overcurrent in traction circuit
67	Traction current validation failure: make sure TEC forward traction output is connected to the piston pump forward traction solenoid coil. If circuit is connected, replace the front TEC controller.

Starting Problems

NOTE: Check InfoCenter Display for possible operator advisories or faults whenever diagnosing machine electrical problems.

Problem	Possible Causes
<p>No electrical power to machine.</p>	<p>The battery is discharged.</p> <p>The battery cables are loose or corroded.</p> <p>Fuse F-D1 (2 Amp) is faulty.</p> <p>Fuse F-D2 (2 Amp) is faulty.</p> <p>Fuse M1 (60 Amp) is faulty.</p> <p>A faulty ground connection exists on machine.</p> <p>The ignition switch or circuit wiring is faulty.</p>
<p>Starter solenoid clicks, but starter will not crank.</p> <p>NOTE: If the solenoid clicks, the problem is not in the interlock circuit.</p>	<p>The battery is discharged.</p> <p>The battery cables are loose or corroded.</p> <p>A ground wire or cable is loose or corroded.</p> <p>The wiring at the starter motor is faulty.</p> <p>The starter solenoid is faulty.</p> <p>The starter motor is faulty.</p>
<p>Nothing happens when start attempt is made. InfoCenter display operates with the ignition switch in the RUN position.</p> <p>NOTE: Use InfoCenter Display to assist with identifying problem.</p>	<p>The traction pedal is not in the neutral position.</p> <p>The operator seat is unoccupied OR the parking brake is not applied.</p> <p>The PTO switch is ON (engaged).</p> <p>Fuses for TEC are faulty.</p> <p>The ignition switch or circuit wiring is faulty.</p> <p>Traction pedal position sensor is out of adjustment.</p> <p>Traction pedal position sensor or circuit wiring is faulty.</p> <p>The seat switch or circuit wiring is faulty.</p> <p>The parking brake switch or circuit wiring is faulty.</p> <p>The start relay or circuit wiring is faulty.</p> <p>The starter solenoid or starter motor is faulty.</p> <p>The engine or fuel system is malfunctioning (see Yanmar Service Manual).</p>

Starting Problems (Continued)

Problem	Possible Causes
Starter cranks, but should not, when the traction pedal is depressed.	Traction pedal position sensor is out of adjustment. Traction pedal position sensor or circuit wiring is faulty.
Engine cranks, but does not start.	The fuel tank is empty. The engine is not cranking fast enough. The fuel pump or circuit wiring is faulty. The engine or fuel system is malfunctioning (see Yanmar Service Manual).

General Run and Transport Problems

NOTE: Check InfoCenter Display for possible operator advisories or faults whenever diagnosing machine electrical problems.

Problem	Possible Causes
<p>Engine continues to run, but should not, when the ignition switch is turned off.</p>	<p>The ignition switch or circuit wiring is faulty.</p> <p>The alternator circuit is faulty (machines with 80 Amp alternator)</p> <p>The engine or fuel system is malfunctioning (see Yanmar Service Manual).</p>
<p>Machine continues to run without an InfoCenter Advisory, but should not, when the traction pedal is depressed with no operator in the seat.</p>	<p>The seat switch or circuit wiring is faulty.</p> <p>Traction pedal position sensor is out of adjustment.</p> <p>Traction pedal position sensor or circuit wiring is faulty.</p>
<p>Engine stops during operation, but is able to restart.</p> <p>NOTE: Excessive engine coolant temperature will cause the cutting decks to be disengaged and can lead to engine shutdown. If excessive coolant temperature causes engine shutdown, the operator can restart the engine to allow the machine to be moved a short distance. After a restart in this condition, the engine will run for approximately ten (10) seconds before the engine shuts down again.</p>	<p>The operator is lifting off the seat switch while mowing.</p> <p>The seat switch or circuit wiring is faulty.</p> <p>The ignition switch or circuit wiring is faulty.</p> <p>The engine coolant temperature is excessive.</p> <p>Machine is being operated on a slope with a low fuel level.</p> <p>The engine or fuel system is malfunctioning (see Yanmar Service Manual).</p>
<p>Battery does not charge.</p>	<p>Loose, corroded or broken wire(s) exist in charging circuit.</p> <p>The engine alternator belt is out of adjustment.</p> <p>The battery is faulty.</p> <p>The alternator is faulty.</p>

Cutting Deck Operating Problems

NOTE: Check InfoCenter Display for possible operator advisories or faults whenever diagnosing machine electrical problems.

NOTE: To engage the mow circuit, the operator must be in the operator seat, the traction speed must be in the LOW speed (mow) position, the PTO switch must be ON and the cutting deck(s) must be fully lowered and in float.

Problem	Possible Causes
The cutting decks remain engaged, but should not, with no operator in the seat.	<p>The seat switch or circuit wiring is faulty.</p> <p>A hydraulic problem in the mow circuit exists (see Troubleshooting section of Chapter 4 - Hydraulic System).</p> <p>The TEC controller is faulty.</p>
Cutting deck runs, but should not, when raised. Decks shut off with PTO switch.	<p>The deck position switch or circuit wiring is faulty.</p> <p>A hydraulic problem in the mow circuit exists (see Troubleshooting section of Chapter 4 - Hydraulic System).</p> <p>The TEC controller is faulty.</p>
Cutting decks run, but should not, when raised. Decks do not shut off with the PTO switch.	<p>Both the deck position switch or circuit wiring and PTO switch or circuit wiring are faulty.</p> <p>A hydraulic problem in the mow circuit exists (see Troubleshooting section of Chapter 4 - Hydraulic System).</p>

Cutting Deck Operating Problems (Continued)

Problem	Possible Causes
Cutting decks run, but should not, when lowered with PTO switch in the OFF (disengage) position.	<p>The PTO switch or circuit wiring is faulty.</p> <p>The TEC controller is faulty.</p>
Cutting deck(s) do not operate.	<p>The operator is lifting off the seat switch.</p> <p>The cutting decks are not fully lowered.</p> <p>Traction circuit is not in LOW speed (mow) mode.</p> <p>High temperature of engine coolant or hydraulic oil has disabled the cutting decks.</p> <p>Fuse is faulty preventing PTO manifold solenoids from being energized.</p> <p>The seat switch or circuit wiring is faulty.</p> <p>The PTO switch or circuit wiring is faulty.</p> <p>The deck position switch or circuit wiring is faulty.</p> <p>The HI/LOW speed switch or circuit wiring is faulty.</p> <p>Hydraulic valve solenoid(s) or circuit wiring to the affected deck(s) is faulty.</p> <p>A hydraulic problem in the mow circuit exists (see Troubleshooting section of Chapter 4 - Hydraulic System).</p> <p>The TEC controller is faulty.</p>

Cutting Deck Lift/Lower Problems

NOTE: Check InfoCenter Display for possible operator advisories or faults whenever diagnosing machine electrical problems.

NOTE: To lower a cutting deck, the operator must be in the operator seat and the traction speed must be in the LOW speed (mow) position. To raise a cutting deck, the operator must be in the operator seat.

Problem	Possible Causes
None of the cutting decks will lower.	<p>The HI/LOW speed switch is in the HI speed position.</p> <p>Operator is not fully depressing the seat switch.</p> <p>TEC fuse(s) are faulty.</p> <p>The seat switch or circuit wiring is faulty.</p> <p>The HI/LOW speed switch or circuit wiring is faulty.</p> <p>Combination control manifold solenoid coil S1 or circuit wiring is faulty.</p> <p>A hydraulic problem in the lift/lower circuit exists (see Troubleshooting section of Chapter 4 - Hydraulic System).</p> <p>The TEC controller is faulty.</p>
None of the cutting decks will raise.	<p>TEC fuse(s) are faulty.</p> <p>Combination control manifold solenoid coil S1 or circuit wiring is faulty.</p> <p>A hydraulic problem in the lift/lower circuit exists (see Troubleshooting section of Chapter 4 - Hydraulic System).</p> <p>The TEC controller is faulty.</p>
Center cutting deck will not raise or lower, but both side cutting decks will raise and lower.	<p>The center deck lift switch or circuit wiring is faulty.</p> <p>Combination control manifold solenoid coils S5 or S6 or circuit wiring is faulty.</p> <p>A hydraulic problem in the lift/lower circuit exists (see Troubleshooting section of Chapter 4 - Hydraulic System).</p> <p>The TEC controller is faulty.</p>

Cutting Deck Lift/Lower Problems (Continued)

Problem	Possible Causes
<p>Right side cutting deck will not raise or lower, but the center and left side cutting decks will raise and lower.</p>	<p>The RH deck lift switch or circuit wiring is faulty.</p> <p>Fuse is faulty.</p> <p>Combination control manifold solenoid coils S7, S8 or S9 or circuit wiring is faulty.</p> <p>A hydraulic problem in the lift/lower circuit exists (see Troubleshooting section of Chapter 4 - Hydraulic System).</p> <p>The TEC controller is faulty.</p>
<p>Left side cutting deck will not raise or lower, but the center and right side cutting decks will raise and lower.</p>	<p>The LH deck lift switch or circuit wiring is faulty.</p> <p>Combination control manifold solenoid coils S2, S3 or S4 or circuit wiring is faulty.</p> <p>A hydraulic problem in the lift/lower circuit exists (see Troubleshooting section of Chapter 4 - Hydraulic System).</p> <p>The TEC controller is faulty.</p>

Adjustments

Cutting Deck Position Switch Adjustment

Adjustment

1. Park machine on a level surface with front cutting deck raised and side cutting decks lowered. Stop engine, engage parking brake and remove key from the ignition switch.

2. There should be from **0.070" to 0.130" (1.8 to 3.3 mm)** clearance between the target surface end of position switch and the sensing plate on lift arm.

3. If necessary, loosen jam nuts on switch and adjust switch location to allow proper clearance between switch and sensing plate.

4. After adjustment, torque jam nuts from **165 to 195 in-lb (18.7 to 22.0 N-m)**. Check that proper clearance between switch and sensing plate still exists after tightening jam nuts.

NOTE: The cutting deck position switches include a LED on the cable end of the switch body. The switch LED **should be** illuminated when the cutting decks are fully lowered.




Figure 18

- | | |
|--------------------|------------------|
| 1. Front lift arm | 3. Sensing plate |
| 2. Position switch | 4. Switch LED |




Figure 19

- | | |
|-----------------------------|---------------|
| 1. Side lift arm (RH shown) | 4. Switch LED |
| 2. Position switch | 5. Clearance |
| 3. Sensing plate | |

Traction Pedal Adjustment

The traction pedal includes a neutral assembly that is used to adjust the traction neutral position (Fig. 20). Traction pedal adjustment may be necessary to make sure that traction pedal movement provides the correct full reverse and full forward positions for the traction pedal position sensor. The InfoCenter display can be used to check traction pedal adjustment using the following procedure.

1. Park machine on a level surface, lower cutting decks, engage parking brake and stop engine.

2. Turn ignition switch to RUN but do not start engine.

3. Use the InfoCenter Display Diagnostics menu (see InfoCenter Display in this chapter) to obtain and select the Traction Pedal menu item. Choose Inputs and the InfoCenter display should identify sensor voltage (Fig. 21).

4. Move traction pedal from full reverse to full forward positions while noting the range of voltage displayed on the InfoCenter.

A. Voltage in full reverse should be from 0.5 to 1.75V (approximate).

B. Voltage in full forward should be from 3.5 to 4.5V (approximate).

5. If voltage range from full reverse to full forward is incorrect, adjustment of the spring shaft and rod end bearing is necessary (Fig. 20).

A. Remove steering cover to access traction pedal components (see Steering Tower in the Service and Repairs section of Chapter 7 - Chassis).

B. Loosen hex nut that secures rod end bearing in spring shaft.

C. Rotate spring shaft which changes traction pedal position in relation to traction pedal position sensor.

D. Check range of voltage as described in step 4 above and make additional adjustments to the spring shaft until range of voltage is within specifications.

E. Tighten hex nut to secure rod end bearing. Check that traction pedal range of voltage is still correct after hex nut is tightened.

F. Install steering cover (see Steering Tower in the Service and Repairs section of Chapter 7 - Chassis).




Figure 20

- | | |
|--------------------------|--------------------|
| 1. Traction pedal | 4. Hex nut |
| 2. Pedal position sensor | 5. Rod end bearing |
| 3. Spring shaft | |




Figure 21

6. After any adjustment of the spring shaft and rod end bearing, use the InfoCenter Display Diagnostics menu (see InfoCenter Display in this chapter) to obtain and select the Traction Pedal menu item. Choose Outputs and the InfoCenter display will identify the traction pedal position (Fig. 22).

A. When the traction pedal is in the neutral position, the InfoCenter should display Neutral as ON and both Forward Range and Reverse Range as OFF.

B. Move traction pedal in the forward direction and the InfoCenter should display the Forward Range as ON and both Neutral and Reverse Range as OFF.

C. Return the traction pedal to neutral and then move pedal in the reverse direction. The InfoCenter should display the Reverse Range as ON and both Neutral and Forward Range as OFF.

D. If outputs are incorrect, additional adjustment of the spring shaft and rod end bearing are necessary.

7. After completing all adjustments and before returning the machine to operation, calibrate traction pedal position sensor (see Traction Pedal Position Sensor Calibration in this section of this chapter).




Figure 22

Traction Pedal Position Sensor Calibration

IMPORTANT: A properly installed and calibrated traction pedal position sensor is critical to accurate traction system response and for reliable sensor life. Use care when removing, installing and calibrating the traction pedal position sensor.

Calibration of the traction pedal position sensor ensures that the TEC controller can identify the traction neutral, forward and reverse positions.

1. Park machine on a level surface, lower cutting decks, engage parking brake and stop engine.

2. Turn ignition switch to RUN but do not start engine.

3. Use the InfoCenter Display Settings menu (see InfoCenter Display in this chapter) to obtain and select Protected Menus. Enter valid PIN for the machine to allow access to protected menu items including calibration of the traction pedal position sensor. The InfoCenter display screen should indicate "PIN" in the upper right hand corner when the correct PIN number has been entered.

4. Use the InfoCenter Display Service menu (see InfoCenter Display in this chapter) to obtain and select the Traction Pedal menu item. The InfoCenter display should indicate that the traction pedal calibration process is engaged (Fig. 24).

5. Follow the prompts on the InfoCenter display screen to calibrate the traction pedal position sensor. The calibration steps are listed below:

A. Slowly press traction pedal to the forward direction.

B. Press and hold traction pedal to the full forward position.

C. Allow traction pedal to return to the neutral position.

D. Slowly press traction pedal to the reverse direction.

E. Press and hold traction pedal to the full reverse position.

F. Check that InfoCenter display indicates a successful calibration process (Fig. 25).

6. Turn ignition switch to OFF which exits the traction pedal calibration menu.




Figure 23

1. Traction pedal

2. Pedal position sensor



Figure 24




Figure 25

Electrical System Quick Checks

Battery Test (Open Circuit)

Use a multimeter to measure the voltage between the battery terminals.

Set multimeter to the DC volts setting. The battery should be at a temperature of 60° to 100°F (16° to 38°C). The ignition key should be off and all accessories turned off. Connect the positive (+) multimeter lead to the positive battery post and the negative (-) multimeter lead to the negative battery post. The multimeter will display battery voltage.

NOTE: This test provides a relative condition of the battery. Load testing of the battery will provide additional and more accurate information.

Voltage Measured	Battery Charge Level
12.68 V (or higher)	Fully charged (100%)
12.45 V	75% charged
12.24 V	50% charged
12.06 V	25% charged
11.89 V	0% charged

Charging System Test

This is a simple test used to determine if a charging system is functioning. It will tell you if the charging system has an output, but not its capacity.

NOTE: The InfoCenter display can be used to identify battery voltage during machine operation.

Use a digital multimeter set to DC volts. Connect the positive (+) multimeter lead to the positive battery post and the negative (-) multimeter lead to the negative battery post. Keep the test leads connected to the battery posts and record the battery voltage.

NOTE: Upon starting the engine, the battery voltage will drop and then should increase once the engine is running.

NOTE: Depending upon the condition of the battery charge and battery temperature, the battery voltage will increase at different rates as the battery charges.


Start the engine and run at high idle. Allow the battery to charge for at least three (3) minutes. Record the battery voltage.

After running the engine for at least three (3) minutes, battery voltage should be at least 0.50 volt higher than initial battery voltage.

An example of a charging system that is functioning:

At least 0.50 volt over initial battery voltage.	
Initial Battery Voltage	= 12.30 v
Battery Voltage after 3 Minute Charge	= 12.95 v
Difference	= +0.65 v

Check Operation of Interlock Switches

**CAUTION**

Do not disconnect safety switches. They are for the operator's protection. Check the operation of the interlock switches daily for proper operation. Replace any malfunctioning switches before operating the machine.


Interlock switch operation is described in the Traction Unit Operator's Manual. Your Groundsmaster is equipped with two (2) Toro Electronic Controllers (TEC) which monitor interlock switch operation. Testing of individual interlock switches and relays is included in the Component Testing section of this Chapter.

NOTE: Use the InfoCenter Display when troubleshooting an electrical problem on your Groundsmaster.

Component Testing

For accurate resistance and/or continuity checks, electrically disconnect the component being tested from the circuit (e.g. unplug the ignition switch connector before checking continuity on the switch).

NOTE: For engine component testing information, see the Yanmar Workshop Manual and Yanmar Troubleshooting Manual.


CAUTION

When testing electrical components for continuity with a multimeter (ohms setting), make sure that power to the circuit has been disconnected.

Ignition Switch

The ignition (key) switch is located on the control panel and has three (3) positions: STOP, RUN and START (Fig. 26). The Toro Electronic Controller (TEC) monitors the operation of the ignition switch.

Testing

1. Park machine on a level surface, lower cutting decks, engage parking brake and stop engine. Remove key from ignition switch.
2. Before disconnecting the ignition switch for testing, the switch and its circuit wiring should be tested as a TEC electrical input using the InfoCenter Display (see InfoCenter Display in this chapter). If input testing verifies that the ignition switch and circuit wiring **are** functioning correctly, no further ignition switch testing is necessary. If, however, input testing determines that the ignition switch and circuit wiring **are not** functioning correctly, proceed with the following ignition switch testing procedure.
3. Remove control arm covers to gain access to ignition switch (see Control Arm in the Service and Repairs section of Chapter 7 - Chassis).
4. Make sure ignition switch is in the OFF position. Disconnect wire harness connector from ignition switch.
5. The ignition switch terminals are identified in Figure 26 and the circuitry of the switch is shown in the chart in Figure 27. With the use of a multimeter (ohms setting), the switch functions can be tested to determine whether continuity exists between the various terminals for each switch position. Verify continuity between switch terminals.
6. Replace ignition switch if testing determines that it is faulty.

7. If the ignition switch tests correctly and a circuit problem still exists, check wire harness (see Electrical Schematics and Wire Harness Drawings in Chapter 10 - Foldout Drawings).
8. After testing is complete, connect machine wire harness connector to ignition switch. Secure control arm covers to machine with removed fasteners (see Control Arm in the Service and Repairs section of Chapter 7 - Chassis).




Figure 26

SWITCH POSITION	CIRCUITS
STOP	1 + 6
RUN	1 + 3 + 4 + 5 + 6
START	1 + 2 + 4 + 5 + 6

Figure 27

NOTE: Ignition switch terminals 1 and 6 are connected internally. Terminals 4 and 5 are also connected internally. These terminals should have continuity regardless of switch position.

Fuses

The fuse block is located under the controller cover next to the operator seat (Fig. 28).

In addition to the fuses in the fuse block, a 60 Amp fuse is included in the wire harness to protect the power circuit for the operator cab. This fuse resides in a fuse holder near the fuse block (Fig. 28).

Fuse Identification and Function

Use Figure 29 to identify each individual fuse and its correct amperage in the fuse block. The fuses have the following functions.

Fuse A-1 (7.5 Amp) protects power supply for the outputs of the front TEC controller.

Fuse A-2 (7.5 Amp) protects power supply for the outputs of the rear TEC controller.

Fuse A-3 (10 Amp) protects turn signal light circuit (if equipped on models 30603 and 30605).

Fuse A-4 (10 Amp) protects headlight circuit (if equipped).

Fuse B-1 (7.5 Amp) protects power supply for the outputs of the front TEC controller.

Fuse B-2 (7.5 Amp) protects power supply for the outputs of the rear TEC controller.

Fuse B-3 (10 Amp) protects power supply to the engine ECU.

Fuse B-4 (10 Amp) protects operator air-ride seat circuit.

Fuse C-1 (7.5 Amp) protects power supply for the outputs of the front TEC controller.

Fuse C-2 (7.5 Amp) protects power supply for the outputs of the rear TEC controller.

Fuse C-3 (10 Amp) protects main power supply circuit.

Fuse C-4 (10 Amp) protects power point circuit.

Fuse D-1 (2 Amp) protects logic power circuit to the front TEC controller.

Fuse D-2 (2 Amp) protects logic power circuit to the rear TEC controller.

Fuse D-3 (2 Amp) protects power supply for the InfoCenter display.

Fuse D-4 (10 Amp) protects power supply for the horn (if equipped).

Fuse Testing

Turn ignition switch to the RUN position (do not start engine). With the fuse installed in the fuse block, use a multimeter to verify that 12 VDC exists at both of the terminal test points on the fuse. If 12 VDC exists at one of the fuse test points but not at the other, the fuse is faulty.

If fuse removal is necessary, make sure that ignition switch is OFF and key is removed from switch. Remove fuse from fuse block and check that fuse has continuity across the fuse terminals.




Figure 28

1. Fuse block
2. 60 Amp fuse
3. Operator seat




Figure 29

Operator Cab Fuses (Groundsmaster 4010-D)

The operator cab fuse blocks are located in the cab headliner (Fig. 30).

Identification and Function (Figs. 30 and 31)

Fuse F1-2 (15 Amp) protects the cab fan circuit.

Fuse F1-3 (30 Amp) protects the air conditioner circuit.

Fuse F2-1 (15 Amp) protects the windshield wiper/washer circuit.

Fuse F2-2 (15 Amp) protects the cab dome light circuit.

Fuses F1-1, F1-4, F2-3 and F2-4 are available for optional equipment.

Testing

Turn ignition switch to the RUN position (do not start engine). With the fuse installed in the fuse block, use a multimeter to verify that 12 VDC exists at both of the terminal test points on the fuse. If 12 VDC exists at one of the fuse test points but not at the other, the fuse is faulty.

If necessary, make sure that ignition switch is OFF and key is removed from switch. Remove fuse from fuse block and check that fuse has continuity across the fuse terminals.




Figure 30

1. Cab headliner

2. Cab fuse blocks




Figure 31




Figure 32

Fusible Link Harness

Your Groundsmaster uses two (2) fusible links for circuit protection. These fusible links are located in a harness that connects the starter B+ terminal to the wire harness (Fig. 33). If either of these links should fail, current to the protected circuits will cease. Refer to wire harness drawings in Chapter 10 - Foldout Drawings for additional fusible link information.

Testing

Make sure that ignition switch is OFF. Disconnect negative battery cable from battery terminal and then disconnect positive cable from battery (see Battery Service in the Service and Repairs section of this chapter). Locate and unplug fusible link connector from machine wire harness. Use a multimeter to make sure that continuity exists between the fusible link terminals. If either fusible link is open, replace the fusible link harness.

NOTE: It is not recommended to replace individual fusible link conductors of the fusible link harness. If any of the harness links are open (failed), replace the entire fusible link harness.

After fusible link testing is complete, make sure that fusible link harness is securely attached to starter B+ terminal and wire harness. Connect positive battery cable to battery terminal first and then connect negative cable to battery.




Figure 33

1. Starter motor

2. Fusible link harness




Figure 34

PTO Switch

The PTO switch is located on the control arm (Fig. 35). The PTO switch is pulled up to engage the PTO and pushed in to disengage the PTO.

The TEC controller monitors the position of the PTO switch (up or down). Using inputs from the PTO switch and other switches in the interlock system, the TEC controller controls the energizing of the hydraulic solenoid valves used to drive the cutting deck motors.

NOTE: To engage the PTO, the seat has to be occupied, traction speed has to be in LOW range and the cutting decks have to be fully lowered.

Testing

1. Before disconnecting the PTO switch for testing, the switch and its circuit wiring should be tested as a TEC input with the InfoCenter Display (see InfoCenter Display in this chapter). If the InfoCenter verifies that the PTO switch and circuit wiring **are** functioning correctly, no further switch testing is necessary. If, however, the InfoCenter determines that the PTO switch and circuit wiring **are not** functioning correctly, proceed with test.

2. Make sure ignition switch is OFF. Remove key from ignition switch.

3. Disassemble control arm to gain access to PTO switch (see Control Arm in the Service and Repairs section of Chapter 7 - Chassis).

4. Disconnect harness electrical connector from the PTO switch.

5. The switch terminals are marked as shown in Figure 36. The circuit logic of the PTO switch is shown in the chart below. With the use of a multimeter (ohms setting), the switch functions can be tested to determine whether continuity exists between the various terminals for each switch position. Verify continuity between switch terminals. Replace PTO switch if testing identifies that switch is faulty.

SWITCH POSITION	CLOSED CIRCUITS	OPEN CIRCUITS
OFF (DOWN)	COM B + NC B COM C + NC C	COM B + NO B COM C + NO C
ON (UP)	COM B + NO B COM C + NO C	COM B + NC B COM C + NC C

6. If PTO switch tests correctly and circuit problem still exists, check wire harness (see Electrical Schematics and Wire Harness Drawings in Chapter 10 - Foldout Drawings).

7. After testing is completed, connect the wire harness connector to the PTO switch.

8. Assemble control arm (see Control Arm in the Service and Repairs section of Chapter 7 - Chassis).




Figure 35

1. Control arm

2. PTO switch




Figure 36

1. COM B terminal

2. NO B terminal

3. NC B terminal

4. COM C terminal

5. NO C terminal

6. NC C terminal

NOTE: Only PTO switch terminals COM C and NO C are used on Groundsmaster 4000-D and 4010-D machines.

HI/LOW Speed, Engine Speed and Cutting Deck Lift Switches

The HI/LOW, engine speed and cutting deck lift switches are all identical momentary switches. These switches are located on the control arm (Fig. 37).

The HI/LOW speed switch is used as an input for the TEC controller to select either the HI (transport) or LOW (mow) traction speed.

The engine speed switch is used as an input for the engine electronic control unit to raise or lower the engine speed. When the switch is depressed and held in the forward position, the engine speed will increase. Conversely, when the rear of the switch is depressed, engine speed will decrease.

The cutting deck lift switches are used as inputs for the TEC controller to raise or lower the cutting decks. When the front of a lift switch is depressed, the controlled decks will lower. When the rear of a lift switch is depressed and held, the controlled decks will raise.

NOTE: To raise or lower the decks, the operator seat has to be occupied. Also, to lower the cutting decks, the traction speed has to be in LOW (mow) range.

Testing

1. Before disconnecting a switch for testing, the switch and its circuit wiring should be tested as a TEC input with the InfoCenter Display (see InfoCenter Display in this chapter). If the InfoCenter verifies that the switch and circuit wiring **are** functioning correctly, no further switch testing is necessary. If, however, the InfoCenter determines that the switch and circuit wiring **are not** functioning correctly, proceed with test.

2. Make sure ignition switch is OFF. Remove key from ignition switch.

3. Disassemble control arm to gain access to switch that is to be tested (see Control Arm in the Service and Repairs section of Chapter 7 - Chassis).

4. Disconnect harness electrical connector from the switch that is to be tested.

5. The switch terminals are marked as shown in Figure 38. The circuit logic of the switch is shown in the chart below. With the use of a multimeter (ohms setting), the switch functions may be tested to determine whether continuity exists between the various terminals for each position. Verify continuity between switch terminals. Replace switch if testing identifies a faulty switch.

SWITCH POSITION	CLOSED CIRCUITS	OPEN CIRCUITS
FRONT OF SWITCH PRESSED	2 + 3 5 + 6	2 + 1 5 + 4
NEUTRAL	NONE	ALL
REAR OF SWITCH PRESSED	2 + 1 5 + 4	2 + 3 5 + 6

6. If switch tests correctly and circuit problem still exists, check wire harness (see Electrical Schematics and Wire Harness Drawings in Chapter 10 - Foldout Drawings).

7. After testing is completed, connect wire harness connector to the switch.

8. Assemble control arm (see Control Arm in the Service and Repairs section of Chapter 7 - Chassis).





Figure 37

- 1. HI/LOW speed switch
- 2. Engine speed switch
- 3. RH deck lift switch
- 4. Center deck lift switch
- 5. LH deck lift switch



BACK OF SWITCH

Figure 38

Cruise Control Switch

The cruise control switch is used as an input for the TEC controller to maintain ground speed when engaged. The cruise control function is enabled when the switch is in the ON (center) position. Pressing the front of the switch to the momentary position sets the desired ground speed. The cruise control function is disengaged when the rear of the cruise control switch is depressed. On machine with serial numbers below 314000000, the cruise control switch is located on the operator side of the console arm (as shown in Fig. 39). On machine with serial numbers above 314000000, the cruise control switch is located on the outside the console arm.

NOTE: The cruise control function can also be disengaged if either brake pedal is pressed or if the traction pedal is pressed and held in the reverse direction.

Testing

1. Before disconnecting the cruise control switch for testing, the switch and its circuit wiring should be tested as a TEC input with the InfoCenter Display (see InfoCenter Display in this chapter). If the InfoCenter Display verifies that switch and circuit wiring **are** functioning correctly, no further switch testing is necessary. If, however, the Display determines that the switch and circuit wiring **are not** functioning correctly, proceed with test.

2. Make sure ignition switch is OFF. Remove key from ignition switch.

3. Disassemble control arm to gain access to the cruise control switch (see Control Arm in the Service and Repairs section of Chapter 7 - Chassis).

4. Disconnect harness electrical connector from the switch.

5. With the use of a multimeter (ohms setting), the switch functions may be tested to determine whether continuity exists between the various terminals for each position. The switch terminals are marked as shown in Figure 40. The circuitry of the cruise control switch is shown in the chart below. Verify continuity between switch terminals.

SWITCH POSITION	CLOSED CIRCUITS	OPEN CIRCUITS
CRUISE DISENGAGE	NONE	ALL
CRUISE ON (CENTER)	2 + 3	5 + 6
SPEED SET (MOMENTARY)	2 + 3 5 + 6	NONE

6. If switch tests correctly and circuit problem still exists, check wire harness (see Electrical Schematics and Wire Harness Drawings in Chapter 10 - Foldout Drawings).

7. After testing is completed, connect wire harness connector to the cruise control switch.

8. Assemble control arm (see Control Arm in the Service and Repairs section of Chapter 7 - Chassis).




Figure 39

1. Control arm

2. Cruise control switch




Figure 40

Seat Switch

The seat switch is normally open and closes when the operator is on the seat. This switch is used as an input for the TEC controller. The seat switch and its electrical connector are located in the seat assembly. If the traction system or PTO switch is engaged when the operator raises out of the seat, an operator advisory will be displayed on the InfoCenter. Testing of the switch can be done without seat removal by disconnecting the switch wire from the machine wire harness (Fig. 41).

Testing

1. Before disconnecting the seat switch for testing, the switch and its circuit wiring should be tested as a TEC input with the InfoCenter Display (see InfoCenter Display in this chapter). If the InfoCenter verifies that the seat switch and circuit wiring **are** functioning correctly, no further switch testing is necessary. If, however, the InfoCenter determines that the seat switch and circuit wiring **are not** functioning correctly, proceed with test.
2. Make sure ignition switch is OFF. Remove key from ignition switch.
3. Disconnect seat switch connector from the machine wire harness connector.
4. Check the continuity of the switch by connecting a multimeter (ohms setting) across the seat switch connector terminals.
5. With no pressure on the seat, there should be **no continuity** between the seat switch terminals.
6. Press directly onto the seat switch through the seat cushion. There should be **continuity** as the seat cushion approaches the bottom of its travel.
7. If testing determines that seat switch is faulty, replace seat switch (see Operator Seat Service in the Service and Repairs section of Chapter 7 - Chassis).
8. Connect seat switch connector to wire harness connector after testing is complete.




Figure 41

1. Seat switch electrical connector
2. Operator seat

Parking Brake Switch

The switch used for the parking brake is a normally open proximity switch that is located under the steering tower cover (Fig. 42). The parking brake switch is an input for the TEC controller. When the parking brake **is not** applied, a tab on the brake rod is positioned near the switch sense zone which causes the switch to close (continuity). When the parking brake **is** applied, the brake rod tab is positioned away from the switch allowing the switch to be in its normal, open position (no continuity).

Switch Testing

1. Before disconnecting the parking brake switch for testing, the switch and its circuit wiring should be tested as a TEC input with the InfoCenter Display (see InfoCenter Display in this chapter). If the InfoCenter verifies that the brake switch and circuit wiring **are** functioning correctly, no further switch testing is necessary. If, however, the InfoCenter determines that the brake switch and circuit wiring **are not** functioning correctly, proceed with test.

2. Make sure ignition switch is OFF. Remove key from ignition switch.

3. Remove front steering tower cover (see Steering Tower in the Service and Repairs section of Chapter 7 – Chassis).

4. Locate parking brake switch and unplug wire harness connector from switch.

5. Check the continuity of the switch by connecting a multimeter (ohms setting) across the connector terminals.

6. When the parking brake is not applied (brake rod tab close to brake switch), there should be **continuity** (zero resistance) between the switch terminals.

7. When the parking brake is applied (brake rod tab away from brake switch), there should be **no continuity** (infinite resistance) between the switch terminals.

8. Replace parking brake switch if necessary.

9. Correctly connect the wire harness connector to the parking brake switch after testing is completed.

10. Install front steering tower cover (see Steering Tower in the Service and Repairs section of Chapter 7 – Chassis).

Switch Adjustment

With the parking brake not applied (brake rod tab near the switch), there should be a **0.062" (1.6 mm)** gap between the switch and the brake rod tab.




Figure 42

- | | |
|-------------------------|-------------------------|
| 1. Lock nut | 4. Carriage bolt |
| 2. Parking brake switch | 5. Parking brake rod |
| 3. Switch plate | 6. Steering tower cover |

Service Brake Switches

The two (2) switches used for the service brakes are normally open switches that are located under the footrest panel (Fig. 43). The service brake switches provide inputs for the TEC controller. When a brake pedal is not depressed, the brake pedal assembly contacts the switch plunger to close the switch. When a brake is applied, the brake pedal assembly moves away from the switch plunger, allowing the switch plunger to extend and the switch to open.

Testing

1. Before disconnecting a service brake switch for testing, the switch and its circuit wiring should be tested as a TEC input with the InfoCenter Display (see InfoCenter Display in this chapter). If the InfoCenter verifies that the brake switch and circuit wiring **are** functioning correctly, no further switch testing is necessary. If, however, the InfoCenter determines that the brake switch and circuit wiring **are not** functioning correctly, proceed with test.

2. Make sure ignition switch is OFF. Remove key from ignition switch.

3. Remove brake cover and switch plate on operator platform to access service brake switches (Fig. 43).

4. Disconnect switch electrical connector from the machine wire harness.

5. Check the continuity of the switch by connecting a multimeter (ohms setting) across the connector terminals.

6. When the service brake switch plunger is depressed, there should be **continuity** (zero resistance) between the switch terminals.

7. When the service brake switch plunger is extended, there should be **no continuity** (infinite resistance) between the switch terminals.

8. Replace service brake switch if necessary.

9. Connect switch electrical connector to the machine wire harness after testing. Secure brake cover and switch plate to operator platform.

Adjustment

Adjust the service brake switch so that the switch plunger always makes full contact with the brake pedal. Tighten fasteners from **13 to 17 in-lb (1.5 to 1.9 N-m)**.




Figure 43

- | | |
|--------------------------|-------------------------|
| 1. Flange screw (3 used) | 5. Screw (2 per switch) |
| 2. Cover | 6. Switch nut (2 used) |
| 3. Switch bracket | 7. Clip (3 used) |
| 4. Brake switch (2 used) | |

Headlight Switch (Groundsmaster 4010-D)

The Groundsmaster 4010-D headlight switch is a two (2) position rocker switch that is located on the inside of the control arm. The headlight switch allows the headlights and taillights to be turned on and off.

Testing

1. Make sure ignition switch is OFF. Remove key from ignition switch.
2. Disassemble control arm to gain access to headlight switch (see Control Arm in the Service and Repairs section of Chapter 7 - Chassis).
3. Disconnect harness electrical connector from the headlight switch.
4. With the use of a multimeter (ohms setting), the switch functions may be tested to determine whether continuity exists between the various terminals for each switch position. The switch terminals are marked as shown in Figure 45. The circuitry of the switch is shown in the chart below. Verify continuity between switch terminals. Replace switch if testing identifies a faulty switch.

SWITCH POSITION	CIRCUIT 1	CIRCUIT 2
ON	2 + 3	5 + 6
OFF	2 + 1	5 + 4

5. If the headlight switch tests correctly and circuit problem still exists, check wire harness (see Electrical Schematics and Wire Harness Drawings in Chapter 10 - Foldout Drawings).
6. After testing is completed, connect wire harness connector to the headlight switch.
7. Assemble control arm (see Control Arm in the Service and Repairs section of Chapter 7 - Chassis).




Figure 44

1. Control arm
2. Headlight switch




Figure 45

NOTE: Switch terminals 1, 4, 5 and 6 are not used on Groundsmaster 4010-D machines.

Windshield Wiper/Washer Switch (Groundsmaster 4010-D)

The windshield wiper/washer switch is used to control operation of the windshield wiper and washer pump on the Groundsmaster 4010-D. The windshield wiper/washer switch is located in the cab headliner (Fig. 46).

Testing

1. Make sure ignition switch is OFF. Remove key from ignition switch.
2. Remove switch plate from cab headliner.
3. Locate windshield wiper/washer switch and unplug wire harness connector from switch.
4. The switch terminals are marked as shown in Figure 47. The circuit logic of the wiper/washer switch is shown in the chart below. With the use of a multimeter (ohms setting), the switch functions may be tested to determine whether continuity exists between the various terminals. Verify continuity between switch terminals. Replace wiper/washer switch if testing identifies a faulty switch.

SWITCH POSITION	CLOSED CIRCUITS	OPEN CIRCUITS
OFF	2 + 1	5 + 6
WIPER ON	2 + 3	5 + 6
WASHER and WIPER ON (MOMENTARY)	2 + 3 5 + 6	2 + 1

5. If switch tests correctly and circuit problem still exists, check wire harness (see Electrical Schematics and Wire Harness Drawings in Chapter 10 - Foldout Drawings).
6. Connect the wire harness connector to the switch after testing.
7. Install switch plate to cab headliner after switch testing is complete.




Figure 46

1. Cab headliner
2. Wiper/washer switch




Figure 47

Air Conditioning Switch (Groundsmaster 4010-D)

The air conditioning switch is used to control operation of the air conditioning system on the Groundsmaster 4010-D. The switch is located in the cab headliner (Fig. 48).

Testing

1. Make sure ignition switch is OFF. Remove key from ignition switch.
2. Remove switch plate from cab headliner.
3. Locate air conditioning switch and unplug wire harness connector from switch.
4. The switch terminals are marked as shown in Figure 49. The circuit logic of the air conditioning switch is shown in the chart below. With the use of a multimeter (ohms setting), the switch functions may be tested to determine whether continuity exists between the various terminals for each position. Verify continuity between switch terminals. Replace switch if testing identifies a faulty switch.

SWITCH POSITION	CLOSED CIRCUITS	OPEN CIRCUITS
AC OFF	2 + 1 5 + 4	2 + 3 5 + 6
AC ON	2 + 3 5 + 6	2 + 1 5 + 4

5. If switch tests correctly and circuit problem still exists, check wire harness (see Electrical Schematics and Wire Harness Drawings in Chapter 10 - Foldout Drawings).
6. Connect the wire harness connector to the air conditioning switch after testing.
7. Install switch plate to cab headliner after switch testing is complete.




Figure 48

1. Cab headliner 2. Air conditioning switch




Figure 49

Turn Signal Switch (Groundsmaster 4010-D)

On Groundsmaster 4010-D machines, the turn signal switch is used as an input for the TEC controller to provide power for the turn signals. The switch is located on the steering tower (Fig. 50).

Testing

1. Before disconnecting the turn signal switch for testing, the switch and its circuit wiring should be tested as a TEC input with the InfoCenter Display (see InfoCenter Display in this chapter). If the InfoCenter verifies that the turn signal switch and circuit wiring **are** functioning correctly, no further switch testing is necessary. If, however, the InfoCenter determines that the turn signal switch and circuit wiring **are not** functioning correctly, proceed with test.

2. Make sure ignition switch is OFF. Remove key from ignition switch.

3. Remove front steering tower cover (see Steering Tower in the Service and Repairs section of Chapter 7 - Chassis).

4. Locate turn signal switch and unplug wire harness connector from switch.

5. The switch terminals are marked as shown in Figure 51. The circuit logic of the turn signal switch is shown in the chart below. With the use of a multimeter (ohms setting), the switch functions may be tested to determine whether continuity exists between the various terminals. Verify continuity between switch terminals. Replace turn signal switch if testing identifies a faulty switch.

SWITCH POSITION	CLOSED CIRCUITS	OPEN CIRCUITS
RIGHT TURN	2 + 3 5 + 6	2 + 1 5 + 4
NEUTRAL	NONE	ALL
LEFT TURN	2 + 1 5 + 4	2 + 3 5 + 6

6. Connect the harness connector to the switch after testing.

7. If switch tests correctly and circuit problem still exists, check wire harness (see Electrical Schematics and Wire Harness Drawings in Chapter 10 - Foldout Drawings).

8. Install front steering tower cover (see Steering Tower in the Service and Repairs section of Chapter 7 - Chassis).




Figure 50

1. Steering column 2. Turn signal switch




Figure 51

Flasher Switch (Groundsmaster 4010-D)

On Groundsmaster 4010-D machines, the flasher switch is used as an input for the TEC controller to provide power for the four way flashers. The switch is located on the steering tower (Fig. 52).

Testing

1. Before disconnecting the flasher switch for testing, the switch and its circuit wiring should be tested as a TEC input with the InfoCenter Display (see InfoCenter Display in this chapter). If the InfoCenter verifies that the flasher switch and circuit wiring **are** functioning correctly, no further switch testing is necessary. If, however, the InfoCenter determines that the flasher switch and circuit wiring **are not** functioning correctly, proceed with test.

2. Make sure ignition switch is OFF. Remove key from ignition switch.

3. Remove front steering tower cover (see Steering Tower in the Service and Repairs section of Chapter 7 - Chassis).

4. Locate flasher switch and unplug wire harness connector from switch.

5. The switch terminals are marked as shown in Figure 53. The circuit logic of the flasher switch is shown in the chart below. With the use of a multimeter (ohms setting), the switch functions may be tested to determine whether continuity exists between the various terminals for each position. Verify continuity between switch terminals. Replace flasher switch if testing identifies a faulty switch.

SWITCH POSITION	CLOSED CIRCUITS	OPEN CIRCUITS
ON (LIGHT END DE-PRESSED)	2 + 3 5 + 6	2 + 1 5 + 4
OFF	2 + 1 5 + 4	2 + 3 5 + 6

6. Connect the harness connector to the switch after testing.

7. If switch tests correctly and circuit problem still exists, check wire harness (see Electrical Schematics and Wire Harness Drawings in Chapter 10 - Foldout Drawings).

8. Install front steering tower cover (see Steering Tower in the Service and Repairs section of Chapter 7 - Chassis).




Figure 52

1. Steering column 2. Flasher switch




Figure 53

Traction Pedal Position Sensor

The traction pedal position sensor is connected to the traction pedal assembly (Fig. 54). This position sensor determines the neutral band for the traction pedal, the direction of travel desired by the operator and the traction speed. The position sensor is a single analog, dual digital signal electronic device. The position sensor portion is a variable resistor that provides an analog signal for the TEC controller to determine the desired ground speed based on how far the traction pedal is moved. The traction pedal position sensor also houses two (2) switches that are used to determine the neutral position (deadband) and the indicated direction of travel (forward or reverse). As the traction pedal is depressed, the internal wiper of the position sensor moves and sends the analog signal to the TEC controller to determine machine direction and speed.

The traction pedal position sensor must be calibrated with the TEC controller to determine the neutral and full speed set points for both the forward and reverse directions. The position sensor calibration process can be completed using the InfoCenter display.

A properly installed and calibrated traction pedal position sensor is critical to accurate traction response and position sensor life. Use care when installing and calibrating the position sensor.

Before suspecting a faulty position sensor, the sensor and its circuit wiring should be tested as a TEC input with the InfoCenter Display (see InfoCenter Display in this chapter). If necessary, follow calibration procedures for the traction pedal position sensor found in the Adjustments section of this chapter. If position sensor replacement is necessary, refer to Traction Pedal in the Service and Repairs section of Chapter 7 - Chassis.




Figure 54

1. Traction pedal

2. Pedal position sensor

Relays with Four (4) Terminals

Your Groundsmaster uses a number of electrical relays that have four (4) terminals. A tag near the wire harness relay connector can be used to identify each relay.

The main power relay is used to provide current to most of the fuse protected circuits (operator seat, InfoCenter display, power point and optional electric equipment). The main power relay is energized when the ignition switch is in the RUN or START position.

The TEC power relay is used to provide current to the fuse protected circuits for the TEC controller. The TEC power relay is energized when the ignition switch is in the RUN or START position.

The cab power relay is used on Groundsmaster 4010-D machines to provide current to the operator cab electrical components. The cab power relay is energized when the ignition switch is in the RUN or START position.

The start relay is used to provide current to the engine starter motor solenoid. The start relay is energized by the engine ECU.

The air heater relay is used on models 30603 and 30605 to provide current for the engine air heater used for starting a cold engine. When necessary, the air heater relay is energized by the engine ECU.

The glow relay is used on models 30607 and 30609 to provide current to the engine glow plugs when energized by the engine ECU.

The main power, TEC power and cab power relays are located under the controller cover next to the operator seat (Fig. 55). The start, air heater and glow relays are attached to the controller mount on the right side of the engine (Fig. 56 or 57).

Testing

1. Park machine on a level surface, lower cutting decks, stop engine, engage parking brake and remove key from the ignition switch.
2. To make sure that machine operation does not occur unexpectedly, disconnect negative (-) cable from battery and then disconnect positive (+) cable from battery (see Battery Service in the Service and Repairs section of this chapter).
3. Locate relay that is to be tested.
4. Disconnect wire harness connector from relay. Remove relay from mounting bracket for testing.




Figure 55

- | | |
|---------------------|--------------------|
| 1. Main power relay | 3. Cab power relay |
| 2. TEC power relay | 4. Operator seat |




Figure 56

- | | |
|---------------------|---------------------|
| 1. Controller mount | 3. Start relay |
| 2. Engine ECU | 4. Air heater relay |




Figure 57

- | | |
|---------------------|----------------|
| 1. Controller mount | 3. Start relay |
| 2. Engine ECU | 4. Glow relay |

5. Using a multimeter, verify that coil resistance between terminals 86 and 85 is approximately 72 ohms.

6. Connect multimeter (ohms setting) leads to relay terminals 30 and 87. Ground terminal 86 and apply +12 VDC to terminal 85. The relay should make and break continuity between terminals 30 and 87 as +12 VDC is applied and removed from terminal 85.

7. Disconnect voltage and test leads from the relay terminals.

8. Secure relay to mounting bracket and connect wire harness connector to relay.

9. Secure all removed components to machine.

10. Connect positive (+) cable to battery and then connect negative (-) cable to battery (see Battery Service in the Service and Repairs section of this chapter).




Figure 58

Relays with Five (5) Terminals

Your Groundsmaster uses a number of electrical relays that have five (5) terminals. A tag near the wire harness connector can be used to identify each relay.

The air conditioning relay is used to control the air conditioning electrical power circuit on the Groundsmaster 4010-D. When energized by the air conditioning switch, the relay provides current for the air conditioning components.

The main relay is used on models 30603 and 30605 to provide current for several engine components when energized by the engine ECU.

The rack actuator relay is used on models 30603 and 30605 to provide current for the engine rack actuator when energized by the engine ECU.

The EGR relay is used on models 30607 and 30609 to provide current to the engine EGR valve when energized by the engine ECU.

The air conditioning relay is attached to the cab headliner above the switch panel. The main, rack actuator and EGR relays are attached to the controller mount on the right side of the engine (Fig. 59 or 60).

Testing

1. Park machine on a level surface, lower cutting decks, stop engine, engage parking brake and remove key from the ignition switch.
2. To make sure that machine operation does not occur unexpectedly, disconnect negative (-) cable from battery and then disconnect positive (+) cable from battery (see Battery Service in the Service and Repairs section of this chapter).
3. Locate relay that is to be tested.
4. Disconnect wire harness connector from relay. Remove relay from mounting bracket for testing.
5. Using a multimeter, verify that coil resistance between terminals 85 and 86 is from 71 to 88 ohms.
6. Connect multimeter (ohms setting) leads to relay terminals 30 and 87. Ground terminal 86 and apply +12 VDC to terminal 85. The relay should make and break continuity between terminals 30 and 87 as +12 VDC is applied and removed from terminal 85.
7. Disconnect voltage from terminal 85 and multimeter lead from terminal 87.




Figure 59

- | | |
|---------------------|------------------------|
| 1. Controller mount | 3. Main relay |
| 2. Engine ECU | 4. Rack actuator relay |




Figure 60

- | | |
|---------------------|--------------|
| 1. Controller mount | 3. EGR relay |
| 2. Engine ECU | |




Figure 61

- | | |
|--------------------|--------------------------|
| 1. Coil terminal | 3. Normally closed term. |
| 2. Common terminal | 4. Normally open term. |

8. Connect multimeter (ohms setting) leads to relay terminals 30 and 87A. Apply +12 VDC to terminal 85. The relay should make and break continuity between terminals 30 and 87A as +12 VDC is applied and removed from terminal 85.

9. After testing, disconnect voltage and multimeter test leads from the relay terminals. Secure relay to mounting bracket and connect wire harness connector to relay.

10. Secure all removed components to machine.

11. Connect positive (+) cable first to battery and then connect negative (-) cable to battery (see Battery Service in the Service and Repairs section of this chapter).

Toro Electronic Controllers (TEC)

Groundsmaster 4000-D and 4010-D machines use two (2) Toro Electronic Controllers (TEC) to control electrical system operation. The controllers are attached to the operator platform under the controller cover (Figs. 64 and 65).

Logic power is provided to the controllers as long as the battery cables are connected to the battery. A pair of 2 Amp fuses (fuse D-1 for the front controller and fuse D-2 for the rear controller) provide circuit protection for this logic power to the controllers.

The front TEC controller monitors the states of the following components as inputs: ignition switch, traction pedal position sensor, parking brake switch, HI/LOW speed switch, service brake switches, seat switch, engine speed switch, hydraulic temperature sender, turn signal switch (if equipped) and hazard switch (if equipped).

The front TEC controller controls electrical output to the engine ECU (start and run functions), fan drive solenoid coils (direction and flow source), traction (piston) pump solenoids (forward and reverse) and traction solenoid coil (HI/LOW speed). Additionally, electrical outputs for brake lights, turn lights and warning lights on Groundsmaster 4010-D machines are provided by the front TEC controller. Circuit protection for front TEC outputs is provided by three (3) 7.5 Amp fuses (fuse locations A-1, B-1 and C-1).

The rear TEC controller monitors the states of the following components as inputs: ignition switch, cutting deck lift switches, PTO switch, cruise control switch and deck position switches.

The rear TEC controller controls electrical output to the PTO solenoid coils, lift/lower solenoid coils and fan drive solenoid coil (speed). Circuit protection for rear TEC outputs is provided by three (3) 7.5 Amp fuses (fuse locations A-2, B-2 and C-2).

The InfoCenter display should be used to check inputs and outputs of the TEC controllers. Information on using the InfoCenter is included in the InfoCenter Display section of this chapter.

The diagram in Figure 66 depicts the connection terminal functions for the TEC controllers. Note that electrical power for controller outputs is provided through three (3) connectors (PWR 2, PWR 3 and PWR 4) each protected with a 7.5 amp fuse. A fifty (50) pin wire harness connector attaches to the controller. The connector pins are identified in the diagram in Figure 66. The layout of the wire harness connectors that plug into the TEC controllers is shown in Fig. 67.




Figure 64

- | | |
|--------------------------|----------------------------|
| 1. Controller cover | 7. Carriage screw (8 used) |
| 2. Screw (2 used) | 8. Flange nut (8 used) |
| 3. Flat washer (2 used) | 9. Front TEC controller |
| 4. Flange screw (2 used) | 10. Rear TEC controller |
| 5. Power mount | 11. Operator platform |
| 6. Relay mount | |




Figure 65

- | | |
|-------------------------|------------------|
| 1. Front TEC controller | 3. Operator seat |
| 2. Rear TEC controller | |

IMPORTANT: When testing for wire harness continuity at the connector for the TEC controller, take care to not damage the connector pins with multi-meter test leads. If connector pins are enlarged or damaged during testing, connector repair will be necessary for proper machine operation.

The machine electrical schematic and wire harness drawings in Chapter 10 - Foldout Drawings can be used to identify possible circuit problems between the controllers and the input/output devices (e.g. switches and solenoid coils).

Because of the solid state circuitry built into the TEC controllers, there is no method to test a controller directly. A controller may be damaged if an attempt is made to test it with an electrical test device (e.g. digital multi-meter or test light).

If removal of the TEC controllers is necessary, label the controllers to make sure they are properly connected to the machine. The two (2) TEC controllers are visually identical but they have different software and therefore cannot be interchanged. The power mount (item 5 in Fig. 64) can be separated from the operator platform and carefully lifted from the platform to access the controller fasteners.

NOTE: The TEC controllers used on the Groundsmaster 4000-D and 4010-D are matched for correct machine operation. If either of these components are replaced for any reason, system software needs to be reprogrammed by your Toro Distributor.

IMPORTANT: Before performing any welding on your Groundsmaster, disconnect both positive and negative battery cables from the battery, disconnect the wire harness connector from both of the TEC controllers and disconnect the terminal connector from the alternator. Also, disconnect and remove the engine ECU from the machine before welding. These steps will prevent damage to the machine electrical system.




Figure 66




Figure 67

Hydraulic Solenoid Valve Coils




Figure 66

- 1. Front PTO manifold
- 2. RH PTO manifold

- 3. LH PTO manifold

- 4. Combination manifold

Several hydraulic solenoid valve coils are used on the hydraulic control manifolds of Groundsmaster 4000-D and 4010-D machines. When energized by the TEC controller, these coils provide hydraulic circuit control.

Solenoid valve coils with two (2) different resistance specifications are used on the 4000-D and 4010-D. The correct resistance of a coil can be identified by measuring the height and diameter of the coil (Fig. 67). Resistance testing of the coils can be done with the coil remaining on the hydraulic valve.

NOTE: To assist in troubleshooting, identical solenoid coils can be exchanged. If the problem follows the exchanged coil, a problem with the coil likely exists. If the problem remains unchanged, something other than the solenoid coil is the problem source (e.g. switch, circuit wiring, hydraulic problem). Refer to your parts catalog to determine if solenoid coils are identical.

Testing

1. Park machine on a level surface, lower cutting decks, stop engine, engage parking brake and remove key from the ignition switch.

2. Locate hydraulic solenoid valve coil to be tested (Fig. 66). Disconnect wire harness connector from coil.

3. Identify coil resistance specification by measuring the coil diameter and coil height (Fig. 67).

NOTE: Prior to taking small resistance readings with a digital multimeter, short the meter test leads together. The meter will display a small resistance value (usually 0.5 ohms or less). This resistance is due to the internal resistance of the meter and test leads. Subtract this value from the measured value of the component you are testing.

4. Using a multimeter (ohms setting), measure resistance between the two (2) connector terminals on the solenoid valve coil. The correct resistance for the solenoid coil is identified below:

COIL DIAMETER	COIL HEIGHT	COIL RESISTANCE
1.34 in (34.0 mm)	1.53 in (38.9 mm)	5.4 ohm
1.84 in (46.7 mm)	1.96 in (49.9 mm)	7.1 ohm
1.41 in (35.8 mm)	1.43 in (36.3 mm)	8.8 ohm

NOTE: Solenoid valve coil resistance should be measured with solenoid at approximately 68°F (20°C). Resistance may be slightly different than listed at different temperatures. Typically, a failed solenoid coil will either be shorted (very low or no resistance) or open (infinite resistance).

5. If solenoid valve coil resistance is incorrect, replace solenoid coil:

A. Remove nut securing solenoid coil to the cartridge valve. Carefully slide coil off the valve.

B. Install new solenoid coil to the cartridge valve. Install and torque nut **5 ft-lb (6.7 N-m)**. Over-tightening may damage the solenoid coil or cause the cartridge valve to malfunction.

6. After testing is completed, connect wire harness connector to the solenoid coil.




Figure 67




Figure 68

- 1. Hydraulic manifold
- 2. Cartridge valve
- 3. Solenoid coil
- 4. Nut

Piston (Traction) Pump Control Solenoid Coils

The piston (traction) pump uses an electronic control assembly for swash plate rotation. Electrical outputs from the machine TEC controller are provided to two (2) solenoid coils for pump control. The piston pump control assembly is attached to the left side of the piston pump (Fig. 69).

NOTE: To assist in troubleshooting, the piston pump solenoid coils can be exchanged because they are identical. If the problem follows the exchanged coil, a problem with the coil likely exists. If the problem remains unchanged, something other than the solenoid coil is the problem source (e.g. traction pedal, circuit wiring, hydraulic problem).

Solenoid Coil Testing

1. Park machine on a level surface, lower cutting decks, stop engine, engage parking brake and remove key from the ignition switch.

2. Locate piston pump solenoid coil to be tested (Fig. 69). Disconnect wire harness connector from solenoid coil.

NOTE: Prior to taking small resistance readings with a digital multimeter, short the meter test leads together. The meter will display a small resistance value (usually 0.5 ohms or less). This resistance is due to the internal resistance of the meter and test leads. Subtract this value from the measured value of the component you are testing.

3. Using a multimeter (ohms setting), measure resistance between the two (2) connector terminals on the solenoid coil. Solenoid coil resistance should be **3.66 ohms**.

NOTE: Solenoid coil resistance should be measured with solenoid at approximately 68°F (20°C). Resistance may be slightly different than listed at different temperatures. Typically, a failed solenoid coil will either be shorted (very low or no resistance) or open (infinite resistance).

4. If solenoid coil resistance is incorrect, replace coil:

A. Use a 12 point, 26 mm socket to loosen and remove the coil nut that secures solenoid coil.

B. Slide solenoid coil and O-rings from valve stem. Clean all corrosion or dirt from the valve.

C. Slide new coil with O-rings onto the solenoid stem.

D. Use a 12 point, 26 mm socket to install and torque coil nut to **44 in-lb (5 N-m)** (do not over-tighten coil nut).

5. After testing is completed, connect wire harness connector to the solenoid coil.




Figure 69

- 1. Piston pump
- 2. Forward solenoid coil
- 3. Reverse solenoid coil




Figure 70

- 1. Solenoid coil
- 2. O-ring
- 3. Coil nut

CAN-bus Termination Resistor

System communication between electrical components on Groundsmaster 4000-D and 4010-D machines is accomplished on a CAN-bus communication system. Two (2) specially designed, twisted wires form the bus for the network used on the machine. These wires provide the data pathways between machine components. At the end of the twisted pair of bus wires near the InfoCenter display is a 120 ohm termination resistor.

The CAN-bus termination resistor plugs into the platform wire harness in the control arm. The resistor can be accessed by removing the cover plate on the right side of the control arm. The wire harness connector has a blue insert to identify the proper location for the termination resistor.

NOTE: The Groundsmaster 4000-D and 4010-D engine ECU includes the second CAN-bus system termination resistor. This resistor cannot be accessed for testing.

NOTE: Refer to the Electrical Schematics and Wire Harness Drawings in Chapter 10 - Foldout Drawings for additional information on termination resistor location and wire connections.

IMPORTANT: The termination resistor is required for proper electrical system operation.

Termination Resistor Test

The termination resistor (Fig. 73) can be tested using a digital multimeter (ohms setting). There should be 120 ohms resistance between terminals A and B of the termination resistor. Terminal C is not used on Groundsmaster 4000-D and 4010-D machines.




Figure 73

Diode Assemblies

The Groundsmaster engine wire harness contains a diode assembly that is used for circuit protection from voltage spikes when the engine starter solenoid is de-energized.

Groundsmaster models 30607 and 30609 use an additional diode assembly in the engine wire harness that protects the engine EGR circuit from reverse polarity.

The diode assemblies plug into the wiring harness near the engine starter motor (see engine wire harness drawing in Chapter 10 - Foldout Drawings). The diode assemblies can be identified by a black color and diode symbol on end of diode assembly body.

Testing

The diode can be tested using a digital multimeter (diode test or ohms setting) and the table to the right.




Figure 72

- | | |
|-------------------|----------------------|
| 1. Diode assembly | 3. Female terminal |
| 2. Male terminal | 4. End of diode body |

Multimeter Red Lead (+) on Terminal	Multimeter Black Lead (-) on Terminal	Continuity
Female	Male	YES
Male	Female	NO

Resistor Assembly

On Groundsmaster machines with an 80 Amp alternator (see Engine Specifications in Chapter 3 - Yanmar Diesel Engine), the engine wire harness contains a resistor that is necessary for ignition switch operation. The resistor plugs into the wiring harness near the engine starter motor (see engine wire harness drawing in Chapter 10 - Foldout Drawings).

The resistor assembly can be identified by its gray color and resistor symbol on end of resistor assembly body.

Testing

The resistor can be tested using a digital multimeter (ohms setting). The resistance across the resistor terminals should be 1.6K ohms.




Figure 73

- | | |
|----------------------|-------------------------|
| 1. Resistor assembly | 2. End of resistor body |
|----------------------|-------------------------|

Fuel Sender

The fuel sender is attached to the top of the fuel tank. The resistance of the fuel sender increases as the fuel level in the fuel tank decreases. The TEC controller uses the fuel sender as an input to generate an output for the InfoCenter fuel gauge.

Two (2) styles of fuel senders have been used on Groundsmaster 4000-D and 4010-D machines. Early production machines are equipped with a pivoting float design that has two (2) wire harness terminals (shown in Fig. 74). Later machines have a sliding float design and a single harness connector.

Testing

1. Make sure ignition switch is OFF. Remove key from ignition switch.
2. Disconnect wire harness connector(s) at fuel sender.



CAUTION

If testing circuit wiring, make sure wire connections at fuel sender are secure before turning ignition switch to RUN to prevent an explosion or fire from sparks.

3. To test the circuit wiring and InfoCenter fuel gauge, use a jumper wire to connect the two (2) harness wires leading to the fuel sender and turn ignition switch to RUN. InfoCenter fuel gauge should indicate full. Turn ignition switch OFF and continue testing fuel sender if circuit wiring and gauge are acceptable.

4. Remove screws and lock washers that secure the fuel sender to the fuel tank.

5. Carefully remove fuel sender and gasket from the fuel tank. Clean all fuel from the sender.

NOTE: Before taking small resistance readings with a digital multimeter, short meter test leads together. The meter will display a small resistance value. This internal resistance of the meter and test leads should be subtracted from the measured value of the component.



CAUTION

Make sure fuel sender is completely dry (no fuel on it) before testing. Perform test away from the fuel tank to prevent an explosion or fire from sparks.

6. Using a multimeter, check resistance of the sender with the float in the full and empty positions. Expected resistance values are shown in the table below.

CONNECTOR STYLE	RESISTANCE (FULL)	RESISTANCE (EMPTY)
Two Terminals	27.5 to 39.5 Ohms	240 to 260 Ohms
Single Connector	28 to 33 Ohms	240 to 250 Ohms

7. Replace sender as necessary. Carefully install sender into fuel tank and secure with removed fasteners.

8. Secure wire harness connector(s) to fuel sender. On two (2) terminal senders, apply skin-over grease (see Special Tools in this chapter) to sender terminals.




Figure 74

1. Fuel sender
2. White (+) lead
3. Black (-) lead




Figure 75

Fuel Pump (Models 30603 and 30605)

The fuel pump is attached to the fuel tank support above the fuel water separator (Fig. 76).

Operational Test

1. Park machine on a level surface, lower cutting decks, stop engine and apply parking brake. Raise hood to access fuel pump.
2. Disconnect fuel pump discharge hose from the fuel injection pump fitting on the engine (Fig. 77).
3. Make sure fuel hoses attached to the fuel pump are free of obstructions.
4. Place disconnected end of fuel pump discharge hose into a large, graduated cylinder sufficient enough to collect 1 quart (0.95 liter).

IMPORTANT: When testing fuel pump output, do not turn ignition switch to the START position.

5. Collect fuel in the graduated cylinder by turning ignition switch to the RUN position. Allow pump to run for fifteen (15) seconds, then turn switch to OFF.
6. The amount of fuel collected in the graduated cylinder should be approximately **16 fl oz (475 ml) after fifteen (15) seconds.**
7. Replace fuel pump as necessary.

IMPORTANT: If fuel pump is replaced, make sure that replacement pump is the correct pump for your Groundsmaster by using your Parts Catalog. If incorrect pump is used, fuel system components can be damaged.

8. Install fuel hose to the water separator and secure with hose clamp.
9. Prime fuel system (see Fuel System in the Service and Repairs section of Chapter 3 - Yanmar Diesel Engine).
10. Lower and secure hood.




Figure 76

1. Fuel water separator
2. Fuel pump
3. Pump inlet hose
4. Pump discharge hose




Figure 77

1. Tier 4i engine
2. Hose clamp
3. Fuel supply hose
4. Fuel return hose

Fuel Pump Specifications

Pump Capacity	64 fl oz/min (1.9 l/min)
Pressure	7 PSI (48.3 kPa)
Current Draw	2.0 Amp

Fuel Pump (Models 30607 and 30609)

The fuel pump is attached to the fuel tank support above the fuel water separator (Fig. 78).

Operational Test

1. Park machine on a level surface, lower cutting decks, stop engine and apply parking brake. Raise hood to access fuel pump.
2. Disconnect fuel pump discharge hose from the fuel filter attached to the engine (Fig. 79).
3. Make sure fuel hoses attached to the fuel pump are free of obstructions.
4. Place disconnected end of fuel pump discharge hose into a large, graduated cylinder sufficient enough to collect 1 quart (0.95 liter).

IMPORTANT: When testing fuel pump output, do not turn ignition switch to the START position.

5. Collect fuel in the graduated cylinder by turning ignition switch to the RUN position. Allow pump to run for thirty (30) seconds, then turn switch to OFF.
6. The amount of fuel collected in the graduated cylinder should be approximately **11.8 fl oz (350 ml) after thirty (30) seconds.**
7. Replace fuel pump as necessary.

IMPORTANT: If fuel pump is replaced, make sure that replacement pump is the correct pump for your Groundsmaster by using your Parts Catalog. If incorrect pump is used, fuel system components can be damaged.

8. Install fuel hose to the engine mounted fuel filter and secure with hose clamp.
9. Prime fuel system (see Fuel System in the Service and Repairs section of Chapter 3 - Yanmar Diesel Engine).
10. Lower and secure hood.




Figure 78

- | | |
|-------------------------|--------------------|
| 1. Fuel water separator | 3. Pump inlet hose |
| 2. Fuel pump | 4. Pump discharge |




Figure 79

- | | |
|------------------|------------------------|
| 1. Tier 4 engine | 3. Pump discharge hose |
| 2. Hose clamp | 4. Fuel return hose |

Fuel Pump Specifications

Pump Capacity	23.5 fl oz/min (700 ml/min)
Pressure	3.3 PSI (22.8 kPa)
Current Draw	0.9 Amp

Cutting Deck Position Switches

Three (3) cutting deck position switches are used on the Groundsmaster 4000-D and 4010-D. These switches are located on the traction unit frame (Figs. 80 and 81). The position switches are powered proximity switches that incorporate an internal reed switch and a LED. The deck position switches are used as inputs for the TEC controller to prevent deck operation when a cutting deck is raised. The switch sensing plates are attached to the cutting deck lift arms. The position switches for front and side decks are different.

The single front cutting deck position switch is a normally closed switch. When the front cutting deck is lowered, the sensing plate on the lift arm is away from the position switch so the switch is in its normally closed state. When the front cutting deck is raised, the sensing plate is moved near the position switch and the switch opens.

The two (2) side cutting deck position switches are normally open switches. When a side cutting deck is lowered, the sensing plate on the lift arm is near the position switch and the switch closes. When a side cutting deck is raised, the sensing plate is moved away from the position switch so the switch is in its normally open state.

Testing

1. The cutting deck position switches and their circuit wiring should be tested as a TEC input with the InfoCenter Display (see InfoCenter Display in this chapter). If the InfoCenter verifies that the position switches and circuit wiring **are** functioning correctly, no further switch testing is necessary. If, however, the InfoCenter determines that a position switch and circuit wiring **are not** functioning correctly, proceed with test.

2. Park machine on a level surface, lower cutting decks, stop engine and apply parking brake.

3. Turn ignition switch to the RUN position (do not start engine) and check LED on cable end of position switches (Fig. 80 or 81). Switch LED **should be** illuminated when the cutting decks are fully lowered.

4. Start engine, fully raise cutting decks and then stop engine. Then, turn ignition switch to the RUN position (do not start engine) and check LED on cable end of position switches. Switch LED **should not be** illuminated when the cutting decks are fully raised.

5. If a position switch LED did not function correctly:

A. Position cutting deck so sensing plate on the lift arm is near the position switch (front cutting deck raised and side cutting decks lowered).

B. Make sure that ignition switch is OFF and disconnect the switch connector from wire harness.




Figure 80

- | | |
|--------------------|------------------|
| 1. Front lift arm | 3. Sensing plate |
| 2. Position switch | 4. Switch LED |




Figure 81

- | | |
|-----------------------------|---------------|
| 1. Side lift arm (RH shown) | 4. Switch LED |
| 2. Position switch | 5. Clearance |
| 3. Sensing plate | |

C. Using a multimeter, verify that wire harness connector terminal for pink wire has 12 VDC when the ignition switch is RUN.

D. Make sure that clearance between end of position switch and sensing plate is from **0.070" to 0.130" (1.8 to 3.3 mm)**. If necessary, adjust position switch (see Cutting Deck Position Switches in the Adjustments section of this chapter). Recheck switch operation after adjustment.

E. If pink wire has system voltage present and gap is correct but switch LED does not function, replace position switch.

6. After testing is complete, make sure that position switch connector is plugged into wire harness.

Hydraulic Oil Temperature Sender

The Groundsmaster 4000-D and 4010-D use a temperature sender as an input for the TEC controller to identify if the hydraulic oil temperature has reached an excessive level. The hydraulic oil temperature sender is attached to the bottom of the rear axle motor (Fig. 82).

The InfoCenter will display fault code 18 if the hydraulic oil temperature sender inputs to the TEC controller are not in the normal range.

Testing

1. Locate temperature sender in rear axle motor. Disconnect wire harness connector from sender.
2. Place suitable drain pan under temperature sender in rear axle motor. Thoroughly clean area around temperature sender and remove sender from axle motor.
3. Put sensing end of sender in a container of oil with a thermometer and slowly heat the oil (Fig. 83).



NOTE: Prior to taking resistance readings with a digital multimeter, short the meter test leads together. The meter will display a small resistance value (usually 0.5 ohms or less). This resistance is due to the internal resistance of the meter and test leads. Subtract this value from the measured value of the component you are testing.

4. Check resistance of the sender with a multimeter (ohms setting) as the oil temperature increases.
 - A. The meter should indicate from 11.6 to 13.5 kilo ohms at 68°F (20°C).
 - B. The meter should indicate from 2.3 to 2.5 kilo ohms at 140°F (60°C).
 - C. The meter should indicate from 605 to 669 ohms at 212°F (100°C).
 - D. Replace sender if specifications are not met.

5. After allowing the sender to cool, install sender:
 - A. Install new O-ring on sender.
 - B. Install sender into port and torque from **9 to 11 ft-lb (12.3 to 14.9 N-m)**.
 - C. Connect wire harness connector to sender.
6. Check and fill hydraulic system to proper level.




Figure 82

1. Rear axle motor
2. Oil temp sender




Figure 83

Audio Alarm

The audio alarm sounds to notify the operator when a machine problem exists. Electrical current for the alarm is provided as an output from the TEC controller. The alarm is attached to the control arm next to the operator seat.

Testing

1. Make sure ignition switch is OFF. Remove key from ignition switch.
2. Disassemble control arm to gain access to the audio alarm (see Control Arm in the Service and Repairs section of Chapter 7 - Chassis).
3. Disconnect wire harness connector from alarm.

IMPORTANT: Make sure to observe polarity on the alarm terminals when testing. Damage to the alarm may result from an improper connection.

4. Correctly connect 12VDC source to the alarm terminals (Fig. 84).
5. Alarm should sound as long as 12VDC is connected to the alarm terminals.
6. Disconnect voltage source from the alarm. Reconnect harness connector to alarm.
7. Assemble control arm (see Control Arm Assembly in the Service and Repairs section of Chapter 7 - Chassis).




Figure 84


- | | |
|----------------------|--------------------------|
| 1. Alarm top view | 3. Positive (+) terminal |
| 2. Alarm bottom view | 4. Negative (-) terminal |

Service and Repairs

NOTE: For engine component repair information (e.g. starter motor), refer to the Yanmar Workshop Manual that is correct for your Groundsmaster model.

Battery Care

1. The top of the battery must be kept clean. If the machine is stored in a location where temperatures are extremely high, the battery will discharge more rapidly than if the machine is stored in a location where temperatures are cool.

 WARNING
<p>Wear safety goggles and rubber gloves when working with electrolyte. Charge battery in a well ventilated place so gasses produced while charging can dissipate. Since the gases are explosive, keep open flames and electrical sparks away from the battery; do not smoke. Nausea may result if the gases are inhaled. Unplug charger from electrical outlet before connecting or disconnecting charger leads to or from battery posts.</p>


IMPORTANT: Do not remove fill caps (if equipped) while cleaning the battery.

2. Check battery condition weekly or after every 50 hours of operation. Keep terminals and entire battery case clean because a dirty battery will discharge slowly.

A. Clean battery by washing entire case with a solution of baking soda and water. Rinse with clear water.

B. Coat battery posts and cable connectors with battery terminal protector (Toro Part No. 107-0392) or petroleum jelly to prevent corrosion.

3. Battery cables must be tight on terminals to provide good electrical contact.

 WARNING
<p>Connecting battery cables to the wrong battery post could result in personal injury and/or damage to the electrical system.</p>

4. If corrosion occurs at terminals, disconnect cables. Always disconnect negative (-) cable first. Clean clamps and terminals separately. Reconnect cables with positive (+) cable first. Coat battery posts and cable connectors with battery terminal protector (Toro Part No. 107-0392) or petroleum jelly to prevent corrosion.

5. If the battery electrolyte is accessible, check electrolyte level every 25 operating hours and every 30 days if machine is in storage. Maintain cell level with distilled water. Do not fill cells above the fill line.

Battery Storage

If the machine will be stored for more than 30 days:

1. Remove the battery and charge it fully (see Battery Service in this section).

2. Either store battery on a shelf or on the machine.

3. Leave battery cables disconnected if the battery is stored on the machine.

4. Store battery in a cool atmosphere to avoid quick deterioration of the battery charge.

5. To help prevent the battery from freezing, make sure it is fully charged (see Battery Service in this section).

Battery Service

The battery is the heart of the electrical system. With regular and proper service, battery life can be extended. Additionally, battery and electrical component failure can be prevented.



CAUTION

When working with batteries, use extreme caution to avoid splashing or spilling electrolyte. Electrolyte can destroy clothing and burn skin or eyes. Always wear safety goggles and a face shield when working with batteries.

Battery Specifications

BCI Group Size 34
690 CCA at 0°F (-18°C)
110 minutes reserve capacity at 80°F (27°C)

Electrolyte Specific Gravity

Fully charged: 1.265 corrected to 80°F (27°C)
Discharged: less than 1.240

Battery Removal and Installation (Fig. 85)

1. Open battery cover to access battery.
2. Loosen and remove negative cable from battery. After negative cable is removed, loosen and remove positive cable.
3. Loosen battery retainer and then carefully remove battery from machine.
4. Install battery in reverse order making sure to connect and tighten positive cable to battery before connecting negative cable.

NOTE: Before connecting the negative (ground) cable to the battery, connect a digital multimeter (set to DC Amps) between the negative battery post and the negative (ground) cable connector. The reading should be less than 0.1 Amp. If the reading is 0.1 Amp or more, the machine's electrical system should be tested for short circuits or faulty components and repaired.

5. Secure battery to machine with battery retainer. Close battery cover.




Figure 85

1. Negative battery post
2. Positive battery post
3. Battery retainer

Battery Inspection and Maintenance

1. Check battery for cracks. Replace battery if cracked or leaking.

2. Check battery terminal posts for corrosion. Use wire brush to clean corrosion from posts.

IMPORTANT: Before cleaning the battery, tape or block vent holes to the filler caps and make sure the caps are on tightly.

3. Check for signs of wetness or leakage on the top of the battery which might indicate a loose or missing filler cap, overcharging, loose terminal post or overfilling. Also, check battery case for dirt and oil. Clean the battery with a solution of baking soda and water, then rinse it with clean water.

4. Check that the cover seal is not broken away. Replace the battery if the seal is broken or leaking.

5. If the battery electrolyte is accessible, check the electrolyte level in each cell. If the level is below the tops of the plates in any cell, fill all cells with **distilled** water between the minimum and maximum fill lines. Charge at 15 to 25 Amps for fifteen (15) minutes to allow sufficient mixing of the electrolyte.

Battery Testing

1. Perform a high-discharge test with an adjustable load tester. This is one of the most reliable means of testing a battery as it simulates the cold-cranking test. A commercial battery load tester is **required** to perform this test.

	CAUTION
Follow the manufacturer's instructions when using a battery load tester.	

A. Check the voltage across the battery terminals prior to testing the battery. If the voltage is less than 12.4 VDC, charge the battery before performing a load test.

B. If the battery has recently been charged, use a battery load tester following the manufacturer's instructions to apply a 150 Amp load for fifteen (15) seconds. This step will remove the surface charge.

C. Make sure battery terminals are free of corrosion.

D. Estimate the internal temperature of the battery to the nearest 10 degrees F.

E. Connect a battery load tester to the battery terminals **following the manufacturer's instructions**. Connect a digital multimeter to the battery terminals.

F. Apply a test load of 345 Amps (one half the cranking performance rating of the battery) to the battery for fifteen (15) seconds.

G. Take a battery voltage reading at fifteen (15) seconds, then remove the load.

H. Using the table in the column to the right, determine the minimum voltage for the battery temperature reading. If the test voltage is below the minimum voltage for the battery temperature, replace the battery. If the test voltage is at or above the minimum, return the battery to service.

Minimum Voltage	Battery Temperature	
	70°F (and up)	21°C (and up)
9.6	70°F (and up)	21°C (and up)
9.5	60°F	16°C
9.4	50°F	10°C
9.3	40°F	4°C
9.1	30°F	-1°C
8.9	20°F	-7°C
8.7	10°F	-12°C
8.5	0°F	-18°C

2. If the battery electrolyte is accessible, the specific gravity of the electrolyte can be used to determine the battery condition.

IMPORTANT: Make sure the area around the cells is clean before opening the battery caps.

A. Measure the specific gravity of each cell with a hydrometer. Draw electrolyte in and out of the hydrometer barrel prior to taking a reading to warm-up the hydrometer. At the same time take the temperature of the cell.

B. Temperature correct each cell reading. For each 10°F (5.5°C) above 80°F (26.7°C) add 0.004 to the specific gravity reading. For each 10°F (5.5°C) below 80°F (26.7°C) subtract 0.004 from the specific gravity reading.

Example: Cell Temperature	100°F
Cell Gravity	1.245
100°F minus 80°F equals 20°F	
(37.7°C minus 26.7°C equals 11.0°C)	
20°F multiply by 0.004/10°F equals 0.008	
(11°C multiply by 0.004/5.5°C equals 0.008)	
ADD (conversion above)	<u>0.008</u>
Correction to 80°F (26.7°C)	1.253

C. If the difference between the highest and lowest cell specific gravity is 0.050 or greater or the lowest cell specific gravity is less than 1.225, charge the battery. Charge at the recommended rate and time given in **Charging** or until all cells specific gravity is 1.225 or greater with the difference in specific gravity between the highest and lowest cell less than 0.050. If these charging conditions can not be met, replace the battery.

Battery Charging

To minimize possible damage to the battery and allow the battery to be fully charged, the slow charging method is presented here. This charging method can be accomplished with a constant current battery charger which is readily available.



CAUTION

Follow the manufacturer's instructions when using a battery charger.

NOTE: Using specific gravity of the battery electrolyte is the most accurate method of determining battery condition.

1. Determine the battery charge level from either its open circuit voltage or electrolyte specific gravity (if electrolyte is accessible).

Battery Charge Level	Open Circuit Voltage	Specific Gravity
100%	12.6	1.265
75%	12.4	1.225
50%	12.2	1.190
25%	12.0	1.155
0%	11.8	1.120

2. Determine the charging time and rate **using the battery charger manufacturer's instructions** or the following table.

Battery Reserve Capacity (Minutes)	Battery Charge Level (Percent of Fully Charged)			
	75%	50%	25%	0%
80 or less	3.8 hrs @ 3 Amps	7.5 hrs @ 3 Amps	11.3 hrs @ 3 Amps	15 hrs @ 3 Amps
81 to 125	5.3 hrs @ 4 Amps	10.5 hrs @ 4 Amps	15.8 hrs @ 4 Amps	21 hrs @ 4 Amps
126 to 170	5.5 hrs @ 5 Amps	11 hrs @ 5 Amps	16.5 hrs @ 5 Amps	22 hrs @ 5 Amps
171 to 250	5.8 hrs @ 6 Amps	11.5 hrs @ 6 Amps	17.3 hrs @ 6 Amps	23 hrs @ 6 Amps
above 250	6 hrs @ 10 Amps	12 hrs @ 10 Amps	18 hrs @ 10 Amps	24 hrs @ 10 Amps



CAUTION

Do not charge a frozen battery because it can explode and cause injury. Let the battery warm to 60°F (16°C) before connecting to a charger.

Charge the battery in a well-ventilated place to dissipate gases produced from charging. These gases are explosive; keep open flame and electrical spark away from the battery. Do not smoke. Nausea may result if the gases are inhaled. Unplug the charger from the electrical outlet before connecting or disconnecting the charger leads from the battery posts.

3. **Following the battery charger manufacturer's instructions**, connect the charger cables to the battery. Make sure a good connection is made.

4. Charge the battery **following the battery charger manufacturer's instructions**.

5. While charging, occasionally check the battery. If the electrolyte is violently gassing or spewing or if the battery case feels hot to the touch, the charging rate must be lowered or temporarily stopped.

6. Determine if battery is fully charged before removing battery from charger. Either of the following procedures can be used:

A. Continue charging and reduce charging rate as needed until a two (2) hour period results in no increase in voltage. Open circuit voltage should be approximately 12.6 volts for a fully charged battery.

B. If the battery electrolyte is accessible, three (3) hours prior to the end of the charging, measure the specific gravity of a battery cell once per hour. The battery is fully charged when the cells are gassing freely at a low charging rate and there is less than a 0.003 change in specific gravity for three (3) consecutive readings.



Axles, Planetaries and Brakes

Table of Contents

SPECIFICATIONS	2
GENERAL INFORMATION	3
Operator's Manual	3
ADJUSTMENTS	4
Planetary Wheel Drive Assembly Endplay	4
SERVICE AND REPAIRS	6
Brake Assembly	6
Brake Inspection and Repair	10
Planetary Wheel Drive Assembly	12
Planetary Wheel Drive Service	14
Rear Axle Assembly	18
Rear Axle Service	22
Bevel Gear Case and Axle Case	24
Differential Shafts	28
Axle Shafts	29
Input Shaft/Pinion Gear	30
Differential Gear	32
Pinion Gear to Ring Gear Engagement	35

Specifications

Item	Specification
Tire pressure (front and rear)	25 to 30 PSI (172 to 207 kPa)
Rear wheel toe-in	0.250 in (6 mm)
Planetary gear drive oil System gear lube capacity (each wheel)	SAE 85W-140 wt. gear lube 22 fl. oz. (0.65 liters)
Rear axle lubricant System gear lube capacity	SAE 85W-140 wt. gear lube 80 fl. oz. (2.4 liters)
Rear axle gear box lubricant System gear lube capacity	SAE 85W-140 wt. gear lube 16 fl. oz. (0.5 liters)
Wheel lug nut torque	85 to 100 ft-lb (115 to 136 N-m), front and rear
Steering cylinder castle nut torque	79 to 84 ft-lb (107 to 113 N-m)
Planetary mounting screw torque	75 to 85 ft-lb (101 to 115 N-m)
Brake housing mounting screw torque	75 to 85 ft-lb (101 to 115 N-m)
Front wheel motor mounting screw torque	75 to 85 ft-lb (101 to 115 N-m)

General Information

Operator's Manual

The Operator's Manual provides information regarding the operation, general maintenance and maintenance intervals for your Groundsmaster machine. Refer to that publication for additional information when servicing the machine.


Adjustments

Planetary Wheel Drive Assembly Endplay

A front planetary wheel drive assembly that is properly operating should have no endplay. Any endplay in a planetary assembly indicates that there are potential problems with the planetary. Check planetary endplay at intervals specified in your Operator's Manual.

Endplay Checking Procedure

1. Park machine on a level surface, lower cutting decks, stop engine and remove key from the ignition switch.

 CAUTION
<p>When raising and supporting machine, use correct jacks and supports. Make sure machine is parked on a solid, level surface such as a concrete floor. Prior to raising machine, remove any attachments that may interfere with the safe and proper raising of the machine. Always chock or block wheels. Use jack stands to support the raised machine. If the machine is not properly supported by jack stands, the machine may move or fall, which may result in personal injury.</p>

2. Chock rear wheels and jack up front of machine (see Jacking Instructions in Chapter 1 - Safety). Support machine with jack stands.

3. Grasp front wheel and check for endplay in the planetary assembly as indicated by axial wheel movement. Make sure that there is no endplay in assembly.

4. If any endplay is detected, the planetary should be disassembled, inspected and serviced as necessary (see Planetary Wheel Drive Assembly in the Service and Repairs section of this chapter).

5. After planetary endplay checking is completed, lower machine to ground.

This page is intentionally blank.

Service and Repairs

Brake Assembly




Figure 1

- | | | |
|-----------------------------------|------------------------------------|-------------------------------------|
| 1. Front wheel motor | 9. LH brake assembly | 16. Flange screw (4 used per brake) |
| 2. Internal retaining ring | 10. Hydraulic tee fitting | 17. Jam nut |
| 3. Splined brake shaft | 11. 90° hydraulic fitting (2 used) | 18. Gasket |
| 4. RH brake assembly | 12. Hydraulic connector | 19. Flange screw (6 used per side) |
| 5. Planetary assembly (2 used) | 13. Hydraulic tee fitting (2 used) | 20. Front wheel assembly |
| 6. Cap screw (2 used per motor) | 14. 90° hydraulic fitting | 21. Lug nut (8 used per wheel) |
| 7. Flat washer (2 used per motor) | 15. Straight hydraulic fitting | 22. Brake cable (RH shown) |
| 8. O-ring | | |

Removal (Fig. 1)

1. Park machine on a level surface, lower cutting decks, stop engine and remove key from the ignition switch.
2. Drain oil from planetary wheel drive/brake assembly (Fig. 2).



CAUTION

When removing front wheel, use correct jacks and supports. Make sure machine is parked on a solid, level surface such as a concrete floor. Prior to raising machine, remove any attachments that may interfere with the safe and proper raising of the machine. Always chock or block wheels. Use jack stands to support the raised machine. If the machine is not properly supported by jack stands, the machine may move or fall, which may result in personal injury.

3. Chock rear wheels and jack up front of machine (see Jacking Instructions in Chapter 1 - Safety). Support machine with jack stands.
4. Remove front wheel assembly.
5. Remove hydraulic wheel motor (see Front Wheel Motors in the Service and Repairs section of Chapter 4 - Hydraulic System).
6. Disconnect brake cable from pull rod on brake assembly.
7. Support brake assembly to prevent it from falling.
8. Remove flange head screws (item 16) that secure brake assembly to frame.
9. Remove brake assembly from machine. Be careful to not drop splined brake shaft (item 3) as brake assembly is removed.
10. Remove splined brake shaft from brake assembly.
11. Remove and discard gasket (item 18). Make sure that all gasket material is removed from both brake and planetary assemblies.
12. Complete brake inspection and repair (see Brake Inspection and Repair in this section).

Installation (Fig. 1)

1. Install splined brake shaft (item 3) into brake assembly. **NOTE:** The stepped end of the splined brake shaft must be aligned toward the hydraulic wheel motor (Fig. 3).




Figure 2

1. Planetary drain
2. Brake drain




Figure 3

1. Splined brake shaft
2. Hydraulic motor end
3. Planetary assembly end




Figure 4

1. Pull rod jam nut
2. Brake cable
3. Brake cable hex

2. Apply gasket sealant to sealing surfaces of new gasket (item 18). Apply gasket to brake assembly.

3. Install brake assembly onto machine, aligning splined brake shaft with input shaft on planetary wheel drive. Make sure that brake pull rod is orientated toward rear of machine.

4. Secure brake assembly to planetary assembly with four (4) flange head screws (item 16). Tighten screws in a crossing pattern to a torque from **75 to 85 ft-lb (101 to 115 N-m)**.

5. Secure hex on end of brake cable to pull rod on brake assembly. Brake cable end should be completely threaded onto pull rod before tightening jam nut.

6. Install new O-ring on hydraulic wheel motor. Install wheel motor and torque cap screws from **75 to 85 ft-lb (101 to 115 N-m)**.

7. Install wheel assembly.

NOTE: While front wheel is off the ground, check planetary wheel drive assembly for endplay (see Planetary Wheel Drive Assembly Endplay in the Adjustments section of this chapter).

	WARNING
Failure to maintain proper wheel lug nut torque could result in failure or loss of wheel and may result in personal injury.	

8. Lower machine to ground. Torque lug nuts from **85 to 100 ft-lb (115 to 135 N-m)**.

9. Make sure drain plugs are installed in brake and planetary drive assemblies (Fig. 2).

10. Fill planetary wheel drive/brake assembly with SAE 85W-140 gear lube (Fig. 5). Capacity is approximately 22 fl. oz. (0.65 liters) per wheel.

11. Check and adjust brake cables for proper brake operation. If necessary, adjust hex on end of brake cable so that pull rod jam nut is positioned from **0.340" to 0.400" (8.7 to 10.1 mm)** from brake casting surface when brakes are disengaged (Fig. 4). Brakes should be adjusted so that both brake pedals have approximately 1" (25mm) of freeplay and have equal brake tension.




Figure 5

1. Check plug

2. Fill plug

This page is intentionally blank.

Brake Inspection and Repair




Figure 6

- | | | |
|-----------------------------|-----------------------------|-------------------------------|
| 1. Brake housing (LH shown) | 6. Hitch pin (2 used) | 11. Rotating actuator |
| 2. Seal | 7. Stationary disc (4 used) | 12. Extension spring (3 used) |
| 3. Pull rod | 8. Rotating disc (3 used) | 13. Ball (3 used) |
| 4. Clevis pin (2 used) | 9. Retaining ring | 14. Plug |
| 5. Link (2 used) | 10. Gasket | 15. O-ring |

Brake Inspection and Repair (Fig. 6)

1. Scrape gasket material (item 10) from brake housing and planetary wheel drive mounting surfaces.
2. Remove retaining ring (item 9) from brake housing groove.
3. Remove stationary discs (item 7) and rotating discs (item 8).
4. Remove extension springs (item 12).
5. Remove actuator assembly (items 11, 6, 5, 4 and 3) and balls (item 13).
6. Remove seal (item 2) from brake housing.
7. Wash parts in cleaning solvent. Inspect components for wear or damage.
8. Reverse steps 2 through 6 to assemble brakes, installing new parts as necessary. Install a new seal (item 2).
9. Use a new gasket (item 10) when installing brake assembly to machine.

This page is intentionally blank.

Planetary Wheel Drive Assembly





Figure 7

- | | | |
|-----------------------------------|------------------------------------|-------------------------------------|
| 1. Front wheel motor | 8. O-ring | 15. Straight hydraulic fitting |
| 2. Internal retaining ring | 9. LH brake assembly | 16. Flange screw (4 used per brake) |
| 3. Splined brake shaft | 10. Hydraulic tee fitting | 17. Jam nut |
| 4. RH brake assembly | 11. 90° hydraulic fitting (2 used) | 18. Gasket |
| 5. Planetary assembly (2 used) | 12. Hydraulic connector | 19. Flange screw (6 used per side) |
| 6. Cap screw (2 used per motor) | 13. Hydraulic tee fitting (2 used) | 20. Front wheel assembly |
| 7. Flat washer (2 used per motor) | 14. 90° hydraulic fitting | 21. Lug nut (8 used per wheel) |

NOTE: The planetary wheel drive assembly can be serviced with the planetary installed to machine (see Planetary Wheel Drive Service in this section). Use the following procedure to remove and install planetary wheel drive assembly from machine.

Removal (Fig. 7)

1. Park machine on a level surface, lower cutting decks, stop engine and remove key from the ignition switch.
2. Drain oil from planetary wheel drive/brake assembly (Fig. 8).

**CAUTION**

When removing front wheel, use correct jacks and supports. Make sure machine is parked on a solid, level surface such as a concrete floor. Prior to raising machine, remove any attachments that may interfere with the safe and proper raising of the machine. Always chock or block wheels. Use jack stands to support the raised machine. If the machine is not properly supported by jack stands, the machine may move or fall, which may result in personal injury.

3. Chock rear wheels and jack up front of machine (see Jacking Instructions in Chapter 1 – Safety). Support machine with jack stands.
4. Remove front wheel assembly.
5. Remove hydraulic wheel motor (see Front Wheel Motors in the Service and Repairs section of Chapter 4 – Hydraulic System).
6. Remove brake assembly (see Brake Assembly in this section).
7. Support planetary assembly to prevent it from falling. Loosen and remove flange head screws that secure planetary assembly to frame. Remove planetary assembly from machine.

Installation (Fig. 7)

1. Position planetary assembly to machine. Install flange head screws that secure planetary assembly. Torque screws in a crossing pattern from **75 to 85 ft-lb (101 to 115 N-m)**.
2. Install brake assembly (see Brake Assembly in this section).
3. Install hydraulic wheel motor (see Front Wheel Motors in the Service and Repairs section of Chapter 4 – Hydraulic System).
4. Install wheel assembly.

**WARNING**

Failure to maintain proper wheel lug nut torque could result in failure or loss of wheel and may result in personal injury.

5. Lower machine from jack stands. Torque lug nuts from **85 to 100 ft-lb (115 to 135 N-m)**.
6. Make sure drain plugs are installed in brake and planetary drive assemblies (Fig. 8).
7. Fill planetary wheel drive/brake assembly with SAE 85W-140 gear lube (Fig. 9). Capacity is approximately 22 fl. oz. (0.65 liters) per wheel.
8. Check and adjust brake cables for proper brake operation.




Figure 8

1. Planetary drain
2. Brake drain




Figure 9

1. Check plug
2. Fill plug

Planetary Wheel Drive Service




Figure 10

- | | | |
|--------------------------------|-------------------------------|--------------------------------|
| 1. Spindle | 11. Outer bearing cup | 20. End cap |
| 2. Boot seal | 12. Outer bearing cone | 21. Thrust plug |
| 3. Oil seal | 13. O-ring | 22. Thrust washer |
| 4. Inner bearing cone | 14. Thrust washer | 23. Retaining ring |
| 5. Inner bearing cup | 15. Retaining ring (external) | 24. Primary gear |
| 6. Wheel stud (8 used) | 16. Ring gear | 25. Drive shaft |
| 7. Socket head screw (16 used) | 17. Retaining ring (internal) | 26. Primary carrier assembly |
| 8. Lock washer (16 used) | 18. Plug (2 used) | 27. Secondary gear |
| 9. Housing | 19. O-ring (2 used) | 28. Secondary carrier assembly |
| 10. Dowel pin (2 used) | | |

NOTE: The planetary wheel drive assembly can be serviced with the planetary installed to machine. If the spindle (item 1) needs to be removed from machine, see Planetary Wheel Drive Assembly in this section.

Disassembly (Figs. 10 and 11)

1. If planetary wheel drive assembly is installed on machine:

A. Park machine on a level surface, lower cutting units, stop engine and remove key from the ignition switch.

B. Drain oil from planetary wheel drive/brake assembly.

C. Chock rear wheels and jack up front of machine (see Jacking Instructions in Chapter 1 - Safety). Support machine with jack stands.

D. Remove front wheel assembly.

2. Remove retaining ring (item 17).

3. Remove end cap (item 20). Thrust plug (item 21) and thrust washer (item 22) usually remain in end cap bore and should be removed for cleaning and inspection.

4. Remove drive shaft assembly (items 23, 24 and 25) If necessary, remove retaining ring and primary gear from shaft.

5. Remove primary carrier (item 26), secondary gear (item 27) and secondary carrier (item 28).

NOTE: Steps 6 through 10 are necessary only if inspecting or replacing bearings and/or seals.

IMPORTANT: Do not reuse retaining ring (item 10) after it has been removed.

6. Remove retaining ring (item 15) and thrust washer (item 14). Discard retaining ring.

7. Carefully remove housing (item 9) from spindle (item 1). Remove outer bearing cone (item 12).

8. Remove and discard seals (items 2 and 3) and O-rings (item 13) from housing.

9. Remove inner bearing cone (item 4) from housing. If necessary, remove bearing cups (items 5 and 11) from housing.

10. If wheel stud (item 6) removal is necessary, use press to extract stud(s) from housing.

11. If necessary, remove socket head screws (item 7) with lock washers (item 8) that secure ring gear (item 16) to housing. Remove ring gear and two (2) dowel pins (item 10) from housing.




Figure 11

Assembly (Figs. 10 and 11)

1. Thoroughly clean parts in solvent and dry completely after cleaning. Inspect parts for damage or excessive wear and replace as necessary.

2. If any wheel studs were removed, use a press to install new studs into housing. Make sure that stud shoulder is fully pressed against housing surface.

NOTE: Use new seal and shim kits when assembling planetary wheel drive.

3. If spindle and housing were separated:

A. Press bearing cups (items 5 and 11) into housing (item 9). Cups should be pressed fully to shoulder of the housing bore.

B. Set inner bearing cone (item 4) into inner bearing cup.

C. Make sure that seal bore in housing is thoroughly cleaned. If OD of seal (item 3) is not rubber or does not have a sealant coating, apply light coating of silicone sealant to seal bore in housing. Install seal into housing so it is flush with housing face. Lightly grease seal lips.

D. Pack boot seal (item 2) with grease and install on housing.

E. If ring gear was removed from housing, place dowel pins (item 10) in housing. Secure ring gear to housing with lock washers (item 8) and socket head screws (item 7). Torque socket head screws from **118 to 144 in-lb (13.3 to 16.3 N-m)**.

F. Lightly oil bearing journals on spindle shaft. Slide housing assembly onto spindle (item 1) taking care to not damage seal or spindle. Make sure that inner bearing in housing fully seats against spindle shaft shoulder.

G. Install outer bearing cone (item 12) onto spindle.

NOTE: The planetary shim kit includes the retaining ring and several thrust washers with thickness in incremental steps of 0.004 inch (0.10 mm). Refer to your Parts Catalog to identify the correct part number for the planetary shim kit.

H. Measure thickness of thrust washer (item 14) that was removed during disassembly. Choose new thrust washer of equal thickness or the next available thickness from thrust washers in the shim kit.

I. Apply a light coating of oil to spindle shaft, thrust washer (item 14) and new retaining ring (item 15). Install thrust washer onto spindle shaft.



WARNING

If retaining ring (item 15) is not fully installed in spindle groove, loss of wheel and personal injury may result.

J. Carefully install new retaining ring (item 15) into the spindle shaft groove taking care to not distort ring. If the proper thrust washer has been installed, the retaining ring should fit tightly between the thrust washer and spindle groove. Tap the OD of the retaining ring starting in the center and working out toward each end to ensure that the retaining ring is properly seated into the spindle groove. Make sure that retaining ring ID is fully seated to spindle shaft groove.

K. After retaining ring is installed, make sure that there is no endplay in assembly. If required, remove retaining ring and install a thrust washer of different thickness to adjust endplay.

L. Install new O-ring (item 13) into groove in housing.

4. Install secondary carrier (item 28), secondary gear (item 27) and primary carrier (item 26) making sure that carrier gear teeth align with ring gear and spline on spindle shaft.

5. If primary gear (item 24) was removed from drive shaft, slide gear onto shaft and secure with retaining ring (item 23).

6. Install drive shaft assembly (items 25, 24 and 23) making sure that drive shaft spline aligns with carrier gears.

7. Install thrust plug (item 21) and thrust washer (item 22) into end cap (item 20). Make sure that thrust plug and thrust washer are captive on inside of end cap (item 20).

8. Install new O-ring (item 13) to end cap and then install end cap. Secure cap with retaining ring (item 17).

9. Check operation of planetary wheel drive. With a constant turning force applied, rotation of the planetary should be consistent. If there is more drag at certain points, gears are not rolling freely and the planetary should be examined for improper assembly or damaged components.

10. If planetary wheel drive assembly is installed on machine:

A. Install front wheel assembly.



WARNING

Failure to maintain proper wheel lug nut torque could result in failure or loss of wheel and may result in personal injury.

B. Lower machine to ground. Torque wheel lug nuts in a crossing pattern from **85 to 100 ft-lb (115 to 135 N-m)**.

C. Make sure drain plug is installed in bottom of brake assembly. Fill planetary wheel drive/brake assembly with SAE 85W-140 gear lube to proper level. Capacity is approximately 16 oz. (0.47 l) per wheel.

This page is intentionally blank.

Rear Axle Assembly




Figure 12

- | | | |
|---------------------------------|------------------------------|----------------------------|
| 1. Plug with O-ring | 11. Slotted hex nut (2 used) | 21. Rear axle mount |
| 2. Lug nut (5 used per wheel) | 12. Washer | 22. Rear axle assembly |
| 3. Rear wheel assembly (2 used) | 13. Cap screw (4 used) | 23. Lock nut |
| 4. Cap screw (2 used) | 14. Lock washer (4 used) | 24. Thrust washer |
| 5. Flat washer (8 used) | 15. Bulkhead mount plate | 25. Rear axle pin |
| 6. Rear axle motor | 16. Grommet (2 used) | 26. Washer head screw |
| 7. O-ring | 17. Bulkhead nut (2 used) | 27. Grease fitting |
| 8. Steering cylinder | 18. Cap screw (6 used) | 28. Thrust washer (0.033") |
| 9. Spacer | 19. Frame assembly | 29. Thrust washer (0.018") |
| 10. Cotter pin (2 used) | 20. Lock nut (6 used) | |



CAUTION

When changing attachments, tires or performing other service, use correct jacks and supports. Make sure machine is parked on a solid, level surface such as a concrete floor. Prior to raising machine, remove any attachments that may interfere with the safe and proper raising of the machine. Always chock or block wheels. Use jack stands to support the raised machine. If the machine is not properly supported by jack stands, the machine may move or fall, which may result in personal injury.

Removal (Fig. 12)

1. Park machine on a level surface, lower cutting decks, stop engine, apply parking brake and remove key from the ignition switch.

2. Drain oil from rear axle and axle gearbox (Figs. 13 and 14).

3. Chock front wheels and jack up rear of machine (see Jacking Instructions in Chapter 1 - Safety). Support machine with appropriate jack stands.

4. Remove both wheels from rear axle.

5. Remove hydraulic motor from rear axle assembly (see Rear Axle Motor in the Service and Repairs section of Chapter 4 - Hydraulic System).

6. Remove steering cylinder from rear axle (see Steering Cylinder in the Service and Repairs section of Chapter 4 - Hydraulic System).

7. Remove cap screws and lock washers that secure bulkhead mount plate (item 15) to rear axle. Separate mount plate from rear axle and support it along with attached hydraulic hoses and tubes to allow the rear axle to be lowered from machine.

8. If required, remove tie rod ends from steering arms on rear axle (Fig. 15). Remove the cotter pins and castle nuts from the tie rod ball joints. Use a ball joint fork and remove the tie rod ends from the axle steering arms.

9. Support rear axle to prevent it from falling. Remove six (6) cap screws, flat washers and lock nuts that secure rear axle mount to machine frame. Lower rear axle and rear axle mount from machine.

10. Remove lock nut and washer from rear axle pin that attaches rear axle to rear axle mount. Remove washer head screw that secures flange of rear axle pin to axle mount (Fig. 16).

11. Remove rear axle pin from rear axle and mount. Separate rear axle mount from rear axle. Note location of thrust washers (items 28 and 29) on both ends of axle mounting boss.

Installation (Fig. 12)

1. Position rear axle mount to axle. Install thrust washers (items 28 and 29) between axle boss and axle mount. The thicker thrust washer should be installed on the hydraulic motor end of the axle (toward the rear of the machine). With washers installed, there should be from **0.002" to 0.020" (0.05 mm to 0.51 mm)** clearance between rear axle mount and axle mounting boss. Add thrust washers if needed to adjust clearance.




Figure 13

1. Center axle drain plug 2. Outside plug (2 used)




Figure 14

1. Gearbox drain plug 2. Gearbox fill plug




Figure 15

1. Tie rod 4. Castle nut
2. Dust cover 5. Tie rod end
3. Cotter pin 6. Steering arm (LH)

2. Secure rear axle to rear axle mount.

A. Slide rear axle pin through rear axle mount and rear axle. Install washer and lock nut onto rear axle pin.

B. Secure pivot pin to axle mount with washer head screw (Fig. 16).

C. Torque lock nut from **135 to 165 ft-lb (184 to 223 N-m)**. After tightening the lock nut, make sure that the rear axle pivots freely.

3. Position rear axle with attached mount under machine. With a jack, raise assembly to machine frame and align mounting holes of rear axle mount and machine frame.

4. Secure rear axle mount to frame with six (6) cap screws, flat washers and lock nuts.

5. If removed, install the tie rod to rear axle (Fig. 15). Tighten ball joint castle nuts and install new cotter pins.

6. Position bulkhead mount plate (item 15) with attached hydraulic hoses and tubes to rear axle. Secure mount plate to axle with cap screws and lock washers.

7. Install steering cylinder to rear axle assembly (see Steering Cylinder in the Service and Repairs section of Chapter 4 - Hydraulic System).

8. Install hydraulic motor to rear axle assembly (see Rear Axle Motor in the Service and Repairs section of Chapter 4 - Hydraulic System).




Figure 16

1. Rear axle pin 2. Washer head screw




Figure 17

1. Rear axle check plug 2. Rear axle fill plug

	WARNING
Failure to maintain proper wheel lug nut torque could result in failure or loss of wheel and may result in personal injury.	

9. Install rear wheels to axle.

10. Lower machine to ground. Torque wheel lug nuts from **85 to 100 ft-lb (115 to 135 N-m)**.

11. Fill gearbox and rear axle with SAE 85W-140 weight gear lube (Figs. 14 and 17). Lubricant capacity is approximately 16 fl. oz. (0.47 liters) for the gearbox and 80 fl. oz. (2.37 liters) for the rear axle assembly.

12. Check rear wheel toe-in and adjust if necessary.

13. Check steering stop bolt adjustment. When the steering cylinder is fully extended (right turn), a gap of 1/16" (1.6 mm) should exist between bevel gear case casting and stop bolt on left axle case. Figure 18 shows stop bolt location.




Figure 18

1. Steering stop bolt 2. Bevel gear case (LH)

This page is intentionally blank.

Rear Axle Service




Figure 19

Figure 19 (Continued)

1. LH axle support
2. Flange bushing (2 used)
3. Axle vent
4. Filter
5. Vent extension
6. Cap screw (4 used per gear case)
7. Shim set
8. Seal washer
9. Plug
10. Lock nut
11. Lock washer
12. Grease fitting
13. Ball bearing
14. Screw (2 used per steering arm)
15. Axle case support (LH shown)
16. Bolt (2 used)
17. Stud (2 used)
18. Shim set
19. Differential assembly
20. O-ring
21. Plug
22. O-ring
23. RH axle support
24. Input shaft assembly
25. Bolt (8 used)
26. O-ring
27. Differential shaft (LH shown)
28. Shim set
29. Ball bearing
30. Bevel gear (15 tooth)
31. Retaining ring
32. Bolt (4 used per knuckle)
33. Shim set
34. Dowel pin (2 used per axle case)
35. Bushing
36. Knuckle pin
37. O-ring
38. Bevel gear case (LH shown)
39. Bushing
40. Shaft seal
41. Stud (2 used per gear case)
42. Bolt (4 used per cover)
43. Collar
44. Bevel gear (17 tooth)
45. Bevel gear shaft
46. Axle case (LH shown)
47. Ball bearing
48. Bevel gear (29 tooth)
49. Shim set
50. Clip (2 used per axle case)
51. Axle cover
52. Screw (6 used per cover)
53. Wheel stud (5 used per axle)
54. Axle
55. Oil seal
56. Ball bearing
57. O-ring
58. Retaining ring
59. Spacer
60. Axle case cover
61. Seal washer
62. Plug
63. Bevel gear (17 tooth)
64. O-ring

NOTE: Figure 19 illustrates the rear axle used on the Groundsmaster 4000 and 4010. Service procedures for the rear axle is on the following pages of this section.

Bevel Gear Case and Axle Case

The following procedures assume the rear axle assembly has been removed from the machine.

Removal

1. Remove the mounting screws, nuts and lock washers. Remove the bevel gear case/axle case assembly and O-ring from the axle support (Fig. 20).

2. Mark both right and left bevel gear case/axle case assemblies.

IMPORTANT: Do not interchange right and left bevel gear case/axle case assemblies.




Figure 20

- | | |
|-------------------------|---------------------------------------|
| 1. Cap screw (4 used) | 5. Bevel gear case/axle case assembly |
| 2. Lock nut (2 used) | 6. O-ring |
| 3. Lock washer (2 used) | |
| 4. Axle support | |

3. Remove the axle cover mounting screws. Remove the axle cover from the axle case as an assembly (Fig. 21).




Figure 21

- | | |
|------------------------|-------------------|
| 1. Axle case | 3. Screw (6 used) |
| 2. Axle cover assembly | 4. O-ring |

4. Remove the axle case support mounting screws, the axle case support and the support shims (Fig. 22).




Figure 22

- | | |
|----------------------|-------------------|
| 1. Axle case | 3. Screw (2 used) |
| 2. Axle case support | 4. Support shim |

5. Remove the knuckle pin mounting screws and the knuckle pin. Remove the gasket and any remaining gasket material from either mating surface (Fig. 23).

6. While holding the bevel gear case, tap the upper end of the bevel gear shaft out of the upper bearing and upper bevel gear.

7. Pull the bevel gear case from the axle case and remove the upper bevel gear and collar from the gear case.

8. Remove the axle case cover screws, cover and the O-ring from the axle case.

9. Remove the plug and sealing washer from the center of the axle case cover. While holding the axle case cover, lightly tap the lower end of the bevel gear shaft out of the lower bearing and lower bevel gear.

10. Remove and discard bevel gear shaft seal from axle case (Fig. 23).




Figure 23

- | | |
|----------------------------|---------------------|
| 1. Knuckle pin | 9. Lower bevel gear |
| 2. Mounting screw (4 used) | 10. Lower bearing |
| 3. O-ring | 11. Axle case |
| 4. Bevel gear case | 12. Axle case cover |
| 5. Upper bearing | 13. O-ring |
| 6. Bevel gear shaft | 14. Shaft seal |
| 7. Collar | 15. Bushing |
| 8. Upper bevel gear | |

Inspection

1. Measure the knuckle pin O.D. and the axle case support bushing I.D. to determine the bushing to pin clearance (Fig. 24). Replace components as necessary.

BUSHING TO PIN CLEARANCE:
0.002 to 0.016 inch (0.05 to 0.40 mm)

KNUCKLE PIN O.D. (Factory Spec.):
0.982 to 0.983 inch (24.95 to 24.98 mm)

AXLE CASE SUPPORT BUSHING I.D. (Factory Spec.):
0.984 to 0.987 inch (25.00 to 25.08 mm)

2. Inspect all gears, shafts, bearings, cases and covers for damage and wear. Replace components as necessary.




Figure 24

- | | |
|----------------|----------------------|
| 1. Knuckle pin | 2. Axle case support |
|----------------|----------------------|

Installation

1. Coat new shaft seal with grease and install in axle case as shown (Fig. 25).




Figure 25

- 1. Axle case
- 2. Bevel gear case
- 3. Shaft seal

2. Install the lower bevel gear and bevel gear shaft in the axle case cover. Coat a new O-ring with grease and install the axle case cover (Fig. 26). Tighten cover screws from **17 to 20 ft-lb (23 to 27 N-m)**.

3. Slide the bevel gear case over the bevel gear shaft and install the bevel gear and collar. Make sure the bevel gear shaft is completely seated in the upper and lower bearings (Fig. 26).

4. Install the knuckle pin. Use medium strength thread-locking compound and tighten the knuckle pin mounting screws from **17 to 20 ft-lb (23 to 27 N-m)**.




Figure 26

- 1. Axle case cover
- 2. Lower bevel gear
- 3. Bevel gear shaft
- 4. Lower bearing
- 5. Upper bevel gear
- 6. Collar
- 7. Upper bearing
- 8. Knuckle pin

5. Determine necessary quantity of support shims.

A. Lubricate the axle case support bushing with a thin coat of grease and slide axle case support onto knuckle pin.

B. Position support shims that were removed during disassembly between axle case support and axle case. Install mounting screws into axle case. Slowly tighten screws while frequently checking for clearance (vertical endplay) between axle case support and knuckle pin. If binding of components is noted before screws are fully tightened, add additional support shims. Torque screws from **57 to 67 ft-lb (77 to 91 N-m)**.

C. Use dial indicator to measure vertical endplay of axle case (Fig. 27).

AXLE CASE ASSEMBLY ENDPLAY:

0.001 to 0.008 inch (0.02 to 0.20 mm)

D. Adjust endplay by increasing or reducing number of axle case support shims.

NOTE: Axle case support shims are available in 0.004 inch (0.1 mm), 0.008 inch (0.2 mm) and 0.016 inch (0.4 mm) thickness.

6. After correct support shims have been determined, remove mounting screws, apply heavy strength thread-locking compound to screw threads, reinstall screws and torque from **57 to 67 ft-lb (77 to 91 N-m)**.

IMPORTANT: Correct engagement between bevel gears is critical to axle performance and durability.

7. Temporarily install the bevel gear case/axle case assembly on the axle support. Position a dial indicator at the teeth center. Prevent the axle from turning and measure the upper bevel gear to differential shaft gear backlash (Fig. 28).

UPPER BEVEL GEAR BACKLASH:

0.004 to 0.016 inch (0.10 to 0.40 mm)

8. Adjust backlash by increasing or reducing axle bearing shim thickness (see Differential Shafts in this section of this manual).

NOTE: Axle bearing shims are available in 0.004 inch (0.1 mm), 0.008 inch (0.2 mm) and 0.020 inch (0.5 mm) thickness.




Figure 27

- | | |
|----------------------|--------------------------|
| 1. Axle case support | 4. Dial indicator |
| 2. Axle case | 5. Knuckle pin |
| 3. Bevel gearcase | 6. Support shim location |




Figure 28

- | | |
|----------------------------|-----------------------|
| 1. Axle support | 4. Dial indicator |
| 2. Upper bevel gear | 5. Axle bearing shims |
| 3. Differential shaft gear | |




Figure 29

- | | |
|------------------------|-----------------------|
| 1. Axle cover assembly | 4. Dial indicator |
| 2. Lower bevel gear | 5. Axle bearing shims |
| 3. Axle gear | |

9. Remove the bevel gear case/axle case assembly from the axle support. Coat a new O-ring with grease and temporarily install the axle cover assembly. Position a dial indicator at the tooth center. Prevent the axle from turning and measure the lower bevel gear to axle gear backlash (Fig. 29).

LOWER BEVEL GEAR BACKLASH:
0.004 to 0.016 inch (0.10 to 0.40 mm)

10. Adjust backlash by increasing or reducing axle bearing shim thickness (see Axle Shafts in this section of this manual).

NOTE: Axle bearing shims are available in 0.008 inch (0.2 mm), 0.012 inch (0.3 mm) and 0.020 inch (0.5 mm) thickness.

11. Tighten axle cover screws from **17 to 20 ft-lb (23 to 27 N-m)**.

12. Coat a new O-ring with grease and install the bevel gear case/axle case assembly on the axle support. Tighten mounting screws and nuts from **35 to 41 ft-lb (47 to 56 N-m)** (Fig. 30).

Differential Shafts

The following procedures assume the rear axle assembly has been removed from the machine.

Removal

IMPORTANT: Do not interchange right and left differential shaft assemblies.

1. Remove the mounting screws, nuts and lock washers. Remove the bevel gear case/axle case assembly and O-ring from the axle support (Fig. 30).
2. Mark and pull the differential shaft assembly from the axle support.
3. Remove the retaining ring and bevel gear (Fig 31).
4. Drive the differential shaft out of the bearings. Remove the bearings and bearing shims.
5. Inspect all gears, shafts, bearings and cases for damage and wear. Replace components as necessary.

Installation

1. Press bearings onto differential shaft. Place correct combination of bearing shims in axle support and drive differential shaft and bearing assembly into axle support.
2. Install bevel gear and retaining ring.
3. Coat new O-ring with grease. Align differential shaft splines with differential gear assembly and slide differential shaft assembly onto axle support.
4. Install bevel gear case/axle case assembly (see Bevel Gear Case/Axle Case Assembly in this section of this manual).




Figure 30

- | | |
|-------------------------|----------------------------------|
| 1. Cap screw (4 used) | 5. Bevel gear/axle case assembly |
| 2. Lock nut (2 used) | 6. O-ring |
| 3. Lock washer (2 used) | 7. Stud (2 used) |
| 4. Axle support | |




Figure 31

- | | |
|-----------------------|------------------|
| 1. Retaining ring | 4. Bearing |
| 2. Bevel gear | 5. Bearing shims |
| 3. Differential shaft | 6. O-ring |

Axle Shafts

The following procedures assume the rear axle assembly has been removed from the machine.

Removal

1. Remove the axle cover mounting screws. Remove the axle cover from the axle case as an assembly (Fig. 32).
2. Use a bearing puller to remove the bearing and bevel gear as shown (Fig. 33).
3. Remove the shims, spacer and retaining ring. Drive the axle out of the bearing and cover. Remove and discard the axle shaft seal.
4. Inspect all gears, shafts, bearings, spacers and cases for damage and wear. Replace components as necessary.

Installation

1. Coat new axle shaft seal with grease and install in axle cover as shown (Fig. 34).
2. Press the axle cover and bearing assembly onto the axle shaft. Press only on the inner race of the cover bearing (Fig. 34).
3. Install retaining ring, spacer and correct combination of bearing shims. Install bevel gear and bearing.
4. Coat a new O-ring with grease and install the axle cover assembly. Tighten axle cover screws from **17 to 20 ft-lb (23 to 27 N-m)**.




Figure 32

- | | |
|------------------------|-------------------|
| 1. Axle case | 3. Screw (6 used) |
| 2. Axle cover assembly | 4. O-ring |




Figure 33

- | | |
|---------------|-------------------|
| 1. Bearing | 4. Spacer |
| 2. Bevel gear | 5. Retaining ring |
| 3. Shims | |




Figure 34

- | | |
|--------------------|---------------|
| 1. Axle shaft seal | 3. Bearing |
| 2. Axle cover | 4. Axle shaft |

Input Shaft/Pinion Gear




Figure 35

- | | | |
|-------------------------|-----------------------------|-----------------------------|
| 1. Nut (2 used) | 9. Bearing | 17. Cover plate |
| 2. Lock washer (2 used) | 10. O-ring | 18. Dowel pin (2 used) |
| 3. Stud (2 used) | 11. Input shaft/pinion gear | 19. Lock washer (6 used) |
| 4. Lock nut | 12. Bearing case | 20. Cap screw (6 used) |
| 5. Stake washer | 13. Shim | 21. Retaining ring (2 used) |
| 6. Oil seal | 14. Screw (2 used) | 22. Driven gear (45 tooth) |
| 7. O-ring | 15. Gear case | 23. Needle bearing |
| 8. Seal collar | 16. Gasket | |

The following procedures assume the rear axle assembly has been removed from the machine.

Removal (Fig. 35)

1. Remove the cover plate, gasket and gear case assembly from the axle assembly. Remove the gasket and any remaining gasket material.
2. Remove the retaining rings, the driven gear and the needle bearing from the input shaft/pinion gear.
3. Remove input shaft/pinion gear assembly from the gear case. Remove the shims and bearing case O-rings.
4. Release the stake washer and remove the lock nut. Remove and discard the stake washer.
5. Drive the input shaft/pinion gear out from the outer bearing cone and bearing case. Remove and discard the oil seal and O-ring.
6. Inspect all gears, shafts, bearings, spacers and cases for damage and wear. Replace components as necessary.

NOTE: Replacement input shaft/pinion gear (item 11) is only available in matched set with differential ring gear.

Installation (Fig. 35)

NOTE: When installing bearing cones onto the input shaft/pinion gear, press only on the inner race of the bearing cone.

1. If the inner bearing cone was removed, press a new bearing cone all the way onto the input shaft/pinion gear.
2. Place the shaft and bearing assembly in the bearing case and install the outer bearing cone.

NOTE: The bearings must be completely seated. There should be no input shaft/pinion gear end play.

3. Coat a new oil seal with grease and install as shown in Figure 36. The seal should be installed with the garter spring towards the hydraulic motor location.
4. Coat new O-ring with grease. Install O-ring in the oil seal collar and install the collar.

5. Install a new stake washer. Install the lock nut finger tight.

6. Set the bearing preload by securing the bearing case in a vise. Thread a M12 x 1.5 hex head cap screw into the splined end of the input shaft/pinion gear and slowly tighten the lock nut until 4 to 6 in-lb (0.4 to 0.7 N-m) of force is required to rotate the input shaft/pinion gear in the bearing case.

7. Secure the lock nut with the stake washer.

8. Use a depth gauge to measure the distance from the end face of the input shaft/pinion gear to the mating surface of the bearing case. Subtract the "Design Cone Center Distance" from this distance to determine initial shim thickness (Fig. 37).

DESIGN CONE CENTER DISTANCE

(distance from mating surface of axle support to end face of pinion gear):

1.870 ± 0.002 inch (47.5 ± 0.05 mm)

NOTE: Bearing case shims are available in 0.004 inch (0.1 mm) and 0.008 inch (0.2 mm) thickness.

9. Coat new O-rings with grease and install the bearing case in the gear case. Place shims on the gear case and temporarily install gear case assembly into axle case. Tighten mounting nuts and screws from **35 to 41 ft-lb (47 to 56 N-m)**.

10. Insert a screwdriver through the drain plug hole to hold ring gear and measure the pinion gear to ring gear backlash (Fig. 38).

PINION GEAR TO RING GEAR BACKLASH:

0.004 to 0.016 inch (0.10 to 0.40 mm)

11. Adjust backlash by increasing or reducing gear case shim thickness.

12. Check pinion gear to ring gear engagement (see Pinion Gear to Ring Gear Engagement in this section of this manual).

13. Place the correct combination of shims on the gear case. Tighten mounting nuts and screws from **35 to 41 ft-lb (47 to 56 N-m)**.

14. Install retaining rings and driven gear on input shaft/pinion gear.

15. If the drive gear (on drive motor shaft) was removed, install the retaining rings and drive gear on the motor shaft.

16. Use a new gasket and install the cover plate. Use a new O-ring and install the drive motor.




Figure 36

- 1. Oil seal
- 2. Bearing case
- 3. Seal garter spring




Figure 37

- 1. Input shaft/pinion gear
- 2. Bearing case




Figure 38

- 1. Axle case
- 2. Screwdriver
- 3. Dial indicator
- 4. Input shaft/pinion gear

Differential Gear

The following procedures assume the rear axle assembly has been removed from the machine.

Removal

1. Remove bevel gear case/axle case assemblies (see Bevel Gear Case/Axle Case Assembly in this section of this manual).

IMPORTANT: Do not interchange right and left differential shafts assemblies.

2. Mark and pull the differential shaft assemblies from the axle support.

3. Remove input shaft/pinion gear assembly, shims and O-ring from the axle support (Fig. 39).

4. Remove the axle support case screws. Separate the axle support halves and remove the O-ring.

5. Remove the differential gear assembly, bearings and adjusting shims from the axle case.

6. Drive the spring pin from the differential case with a punch and hammer. Discard the spring pin (Fig. 40).

NOTE: Mark and arrange all components so they can be reassembled in their original position.

7. Remove the differential pinion shaft, pinion gears and pinion washers. Remove the differential side gears and side gear shims. Remove the ring gear only if it will be replaced (Fig. 41).

NOTE: Replacement ring gears are only available in matched ring and pinion sets.




Figure 39

- | | |
|-------------------------|------------------------|
| 1. Gear Case | 5. Case screw (8 used) |
| 2. Pinion Gear | 6. Differential gear |
| 3. Axle support (left) | 7. O-ring |
| 4. Axle support (right) | |




Figure 40

- | | |
|----------------------|---------------|
| 1. Differential case | 2. Spring pin |
|----------------------|---------------|




Figure 41

- | | |
|------------------------------|-------------------------|
| 1. Differential pinion shaft | 5. Side gear shims |
| 2. Pinion gear | 6. Ring gear |
| 3. Pinion washer | 7. Differential case |
| 4. Side gear | 8. Bolt/washer (8 used) |

Inspection

1. Measure the differential side gear O.D. and the differential case I.D. to determine the side gear to case clearance (Fig. 42). Replace components as necessary.

SIDE GEAR TO CASE CLEARANCE:
0.002 to 0.012 inch (0.05 to 0.30 mm)

SIDE GEAR O.D. (Factory Spec.):
1.335 to 1.337 inch (33.91 to 33.95 mm)

DIFFERENTIAL CASE I.D. (Factory Spec.):
1.339 to 1.341 inch (34.00 to 34.06 mm)

2. Measure the differential pinion shaft O.D. and the pinion gear I.D. to determine the pinion shaft to pinion gear clearance (Fig. 43). Replace components as necessary.

PINION SHAFT TO PINION GEAR CLEARANCE:
0.001 to 0.010 inch (0.03 to 0.25 mm)

PINION SHAFT O.D. (Factory Spec.):
0.550 to 0.551 inch (13.97 to 13.10 mm)

PINION GEAR I.D. (Factory Spec.):
0.551 to 0.552 inch (13.10 to 14.02 mm)

3. Inspect all gears, shafts, bearings, cases and covers for damage and wear. Replace components as necessary.




Figure 42

1. Side gear

2. Differential case




Figure 43

1. Pinion shaft

2. Pinion gear

Installation

1. If the ring gear was removed from the differential case, use medium strength Loctite thread locker and tighten the mounting screws from **22 to 25 ft-lb (30 to 34 N-m)**.

2. Apply molybdenum disulfide lubricant (Three Bond 1901 or equivalent) to the splines and bearing surfaces of the differential pinion gears, pinion washers and side gears.

3. Install the side gear shims and side gears in their original location in the differential case.

4. Place the differential pinion gears and pinion washers in their original location in the differential case. Temporarily install the differential pinion shaft.

5. Secure the differential case in a soft jawed vise. Position a dial indicator on a tooth of the differential pinion gear. Press the pinion and side gear against the differential case and measure the pinion gear to side gear backlash (Fig. 44).

PINION GEAR TO SIDE GEAR BACKLASH:
0.004 to 0.016 inch (0.10 to 0.40 mm)

6. Adjust backlash by increasing or reducing side gear shim thickness.

NOTE: Side gear shims are available in 0.043 inch (1.10 mm), 0.047 inch (1.20 mm) and 0.051 inch (1.30 mm) thickness.

7. Apply gear marking compound, such as DyKem® Steel Blue lightly over several gear teeth.

8. While applying a light load to either side gear, rotate either pinion gear until the side gears have made one complete revolution.

9. Ideal tooth contact should cover more than 35% of each tooth surface. The contact area should be in the center of each tooth and extend 1/3 to 1/2 way across each tooth from the toe (small) end (Fig. 45).

10. Adjust side gear shims if necessary to correct tooth contact. Recheck differential pinion gear to side gear backlash if any changes are made.

11. After backlash and tooth contact have been adjusted, align the hole in the differential pinion shaft with the hole in the differential case and install a new spring pin.




Figure 44

- 1. Vise
- 2. Differential gear case
- 3. Dial indicator




Figure 45

12. Install differential gear assembly in right side axle support half.

13. Coat a new o-ring with grease and install left side axle support half. Tighten axle support case screws from **35 to 41 ft-lb (47 to 56 N-m)**.

14. Install input shaft/pinion gear assembly (see Input Shaft/Pinion Gear in this section of this manual).

15. Coat new o-rings with grease, align differential shaft splines with differential gear assembly and slide differential shaft assemblies onto axle support.

16. Install bevel gear case/axle case assemblies (see Bevel Gear Case/Axle Case Assembly in this section of this manual).

Pinion Gear to Ring Gear Engagement

The final position of the pinion gear is verified by using the gear contact pattern method as described in the following procedure.

GEAR TOOTH DEFINITIONS (Fig. 46):

Toe – the portion of the tooth surface at the end towards the center.

Heel – the portion of the gear tooth at the outer end.

Top Land – top surface of tooth.

1. Paint the teeth of the ring gear, both drive and coast side, with a gear marking compound, such as DyKem® Steel Blue.

2. Install the input shaft/pinion gear assembly into axle case.

3. While applying a light load to the ring gear, rotate the pinion gear in the direction of forward travel until the ring gear has made one complete revolution.

Ideal tooth contact observed on the ring gear should cover more than 35% of each tooth surface. The contact area should be in the center of each tooth and extend 1/3 to 1/2 way across each tooth from the toe end (Fig. 47).

Adjustments to the gear contact position are made by moving the input shaft/pinion gear (bearing case shims) or by moving the differential gear case (differential bearing shims) (Fig. 48).

NOTE: Bearing case shims are available in 0.004 inch (0.10 mm) and 0.008 inch (0.20 mm) thickness.

NOTE: Differential bearing shims are available in 0.004 inch (0.10 mm), 0.008 inch (0.20 mm) and 0.016 inch (0.40 mm) thickness.

Study the different contact patterns (Figs. 49 and 50) and correct gear engagement as necessary.

NOTE: When making changes, note that two variables are involved (see Gear Pattern Movement Summary in this section of this manual).

Example: If the pinion gear to ring gear backlash is set correctly to specifications and the bearing case shim is changed to adjust tooth contact, it may be necessary to readjust backlash to the correct specification before checking the contact pattern.




Figure 46




Figure 47




Figure 48

- | | |
|----------------------------|-------------------------------|
| 1. Input shaft/pinion gear | 4. Differential bearing shims |
| 2. Bearing case shims | |
| 3. Differential gear case | |

Gear Pattern Movement Summary

Every gear has a characteristic pattern. The illustrations show typical patterns only and explain how patterns shift as gear location is changed.

1. If contact is toward the heel or base of the gear (Fig. 49):

A. Install thicker or additional bearing case shim(s) to move pinion shaft toward ring gear.

B. Install thinner or remove differential bearing shim(s) to move ring gear backward.

C. Repeat until proper tooth contact and pinion gear to ring gear backlash are correct.

2. If contact is toward the toe or tip of the gear (Fig. 50):

A. Install thinner or remove bearing case shim(s) to move pinion shaft away from ring gear.

B. Install thicker or additional differential bearing shim(s) to move ring gear forward.

C. Repeat until proper tooth contact and pinion gear to ring gear backlash are correct.




Figure 49




Figure 50



Table of Contents

GENERAL INFORMATION	1
Operator's Manual	1
SERVICE AND REPAIRS	2
Steering Tower	2
Center Deck Lift Arms	4
Side Deck Lift Arms	8
Side Deck Rear Arm Assembly	10
Lift Arm Joint Yoke	14
Control Arm	16
Traction Pedal	18
Operator Platform	20
Operator Seat	24
Operator Seat Service	26
Operator Seat Suspension	28
Hood	30

General Information

Operator's Manual

The Operator's Manual provides information regarding the operation, general maintenance and maintenance intervals for your Groundsmaster machine. Refer to that publication for additional information when servicing the machine.

Service and Repairs

Steering Tower




Figure 1

- | | | |
|--------------------------------|-------------------------------|-------------------------|
| 1. Steering wheel cover | 9. Flange bushing | 17. Steering column |
| 2. Hex nut | 10. Thrust washer (as needed) | 18. Cap screw (2 used) |
| 3. Flat washer | 11. Cap screw (4 used) | 19. Pivot hub (3 used) |
| 4. Steering wheel | 12. Washer (4 used) | 20. Flange nut (3 used) |
| 5. Foam collar | 13. Washer (4 used) | 21. Spacer |
| 6. Steering seal | 14. Mount (4 used) | 22. Cap |
| 7. External snap ring (2 used) | 15. Valve mount plate | 23. Tilt lever |
| 8. Steering shaft | 16. Steering control valve | 24. Cap screw |

Disassembly (Fig. 1)

1. Park machine on a level surface, lower cutting decks, stop engine, apply parking brake and remove key from the ignition switch.
2. Remove steering tower covers to access steering tower components (Fig. 2).
3. Disassemble steering tower as needed using Figure 1 as a guide.

Assembly (Fig. 1)

1. Assemble steering tower using Figures 1 and 2 as guides.
 - A. If steering column (item 17) was removed, torque cap screws (item 18) that secure steering column to frame bracket from **27 to 33 ft-lb (37 to 44 N-m)**.
 - B. Thrust washer(s) (item 10 in Fig. 1) on steering column are used as needed to remove end play of steering shaft.
 - C. If steering wheel was removed, torque hex nut that secures steering wheel from **20 to 26 ft-lb (28 to 35 N-m)**.




Figure 2

- | | |
|---------------------------|------------------|
| 1. Operator platform | 4. Clip (2 used) |
| 2. Flange screw (10 used) | 5. Rear cover |
| 3. Front cover | |

Center Deck Lift Arms





Figure 3

- | | | |
|---|--|--|
| <ul style="list-style-type: none"> 1. Center deck assembly 2. Grease fitting 3. Ball joint seal 4. Hydraulic deck motor 5. Flange head screw 6. RH lift arm 7. LH lift arm 8. Lift cylinder (2 used) 9. Pin (2 used) 10. Flange nut (2 used) 11. Jam nut (LH threads) (2 used) 12. Ball joint (LH threads) (2 used) 13. Cotter pin (2 used) 14. Ball joint mount (2 used) 15. Flange nut (2 per mount) | <ul style="list-style-type: none"> 16. Cap screw (2 per mount) 17. Sensor plate 18. Carriage screw 19. Flat washer 20. Flange nut 21. U-bolt (2 used) 22. Height-of-cut chain (2 used) 23. Flat washer (4 per u-bolt) 24. Hex nut (2 per u-bolt) 25. Lock nut (2 per u-bolt) 26. Clevis pin (2 used) 27. Hair pin (2 used) 28. Cap screw 29. Spherical rod end 30. Damper | <ul style="list-style-type: none"> 31. Clevis rod end 32. Spring pin 33. Grease fitting (2 used) 34. Spacer 35. Flat washer (2 used) 36. Slotted hex nut 37. Grease fitting 38. Lock nut (2 used) 39. Lift arm pin (2 used) 40. Spring pin (2 used) 41. Flat washer (4 used per pin) 42. Cotter pin (2 used per pin) 43. Clevis pin (2 used) 44. Front frame |
|---|--|--|

Removal (Fig. 3)

1. Park machine on a level surface, lower cutting decks, stop engine, apply parking brake and remove key from the ignition switch.

2. Remove center cutting deck (see Center Cutting Deck Removal in Chapter 8 - Cutting Decks).

**CAUTION**

When changing attachments, tires or performing other service, use correct jacks and supports. Make sure machine is parked on a solid, level surface such as a concrete floor. Prior to raising machine, remove any attachments that may interfere with the safe and proper raising of the machine. Always chock or block wheels. Use jack stands to support the raised machine. If the machine is not properly supported by jack stands, the machine may move or fall, which may result in personal injury.

3. Chock rear wheels and jack up front of machine. Support machine on jack stands.

4. Remove front wheel next to lift arm that is to be removed.

5. Remove cap screw, washers and lock nut that secure lift cylinder pin to lift arm. Remove pin and separate lift cylinder and lift arm.

6. Remove lock nut that secures lift arm pin. Support lift arm and slide pin from frame and lift arm. Remove lift arm from frame.

NOTE: The lift arm ball joint (item 12) and jam nut (item 11) have left hand threads.

7. Remove height-of-cut chain, ball joint mount and ball joint from removed lift arm as required.

Installation (Fig. 3)

1. Position lift arm to frame and insert lift arm pin. Engage roll pin into frame slots and install lock nut on pin. Torque lock nut from **60 to 70 ft-lb (81 to 94 N-m)**. Make sure that lift arm pivots freely after installation.

2. Align lift cylinder with lift arm. Slide pin through lift arm and cylinder end. Secure pin with cap screw, washers and lock nut.

3. Install front wheel assembly and lower machine to the ground. Make sure that wheel lug nuts are torqued from **85 to 100 ft-lb (115 to 135 N-m)**.




Figure 4

1. U-bolt

2. Height of cut chain




Figure 5

1. Lift arm

2. Ball joint

4. If sensing plate (item 32) was removed from lift arm, secure plate fully forward in lift arm slot.

5. If height-of-cut chain u-bolt was removed from lift arm, assemble u-bolt so that threaded portion extends **1.200" (30.5 mm)** above lift arm mounting plate (Fig. 4). This dimension is a starting point that might need additional adjustment for deck pitch correction (see step 12 below).

NOTE: The lift arm ball joint (item 12) and jam nut (item 11) have left hand threads.

6. If removed, install ball joint to lift arm. Distance from end of lift arm to center of ball joint should be from **2.210" to 2.390" (56.1 to 60.7 mm)** (Fig. 5). Make sure that ball joint is horizontal and that stud is centered in ball joint. Install deck before torquing ball joint jam nut (item 24).

7. Install ball joint mount to ball joint with slotted hex nut. Torque nut from **90 to 100 ft-lb (123 to 135 N-m)** while aligning cotter pin holes. Install cotter pin.

8. Install center cutting deck (see Center Cutting Deck Installation in Chapter 8 - Cutting Decks).

9. If ball joint was removed from lift arm, torque ball joint jam nut from **150 to 175 ft-lb (203 to 237 N-m)**.

10. Lubricate lift arm grease fittings.

11. After assembly is completed, raise and lower the cutting deck to verify that hydraulic hoses and fittings do not contact anything.

12. Check height-of-cut and deck pitch adjustment (refer to Operator's Manual).

This page is intentionally blank.

Side Deck Lift Arms




Figure 6

- | | | |
|-------------------------------|--|----------------------------------|
| 1. Lift cylinder pin | 13. Flat washer (5 used per side) | 25. Sensing plate |
| 2. Slotted roll pin | 14. Flange head screw (3 used per block) | 26. Carriage screw (2 per plate) |
| 3. Flange head screw | 15. Grease fitting | 27. Shoulder screw |
| 4. Rubber bumper | 16. Flange bushing (2 per hub) | 28. Cylinder pin |
| 5. Rivet (2 per bumper) | 17. Flange bushing (2 per hub) | 29. Lift cylinder |
| 6. Cap screw | 18. Grease fitting | 30. Plastic grip |
| 7. Thrust washer | 19. Flange bushing (2 per lift arm) | 31. Proximity switch |
| 8. Lift arm pivot shaft | 20. Jam nut (2 per switch) | 32. Crossmember |
| 9. Pivot hub | 21. Washer (2 per switch) | 33. Lock nut (2 per side) |
| 10. Thrust washer (as needed) | 22. Lift arm (LH shown) | 34. Washer (2 per latch) |
| 11. Spring pin | 23. Bushing (2 per lift arm) | 35. Latch (LH shown) |
| 12. Tapped block | 24. Flange nut (3 used per side) | |

NOTE: There are not bushings in the frame to support the lift arm pivot shaft (item 8) because the shaft is fixed in place by a roll pin (item 11). The lift arm (item 22) and pivot hub (item 9) rotate on the pivot shaft and have bushings that can be serviced.

NOTE: Allowable clearance between lift arm pivot shaft (item 8) and front frame bore (Fig. 7) is up to 0.025" (0.64 mm). Allowable clearance between lift arm pivot shaft and rear frame bore is up to 0.070" (1.78 mm).




Figure 7

- | | |
|---------------------|--------------------|
| 1. Front frame bore | 2. Rear frame bore |
|---------------------|--------------------|

Removal (Fig. 6)

1. Park machine on a level surface, lower cutting decks, stop engine, apply parking brake and remove key from the ignition switch.
2. Remove side deck from lift arm (see Side Cutting Deck Removal in Chapter 8 - Cutting Decks).
3. Remove side deck rear arm assembly from pivot hub (see Side Deck Rear Arm Assembly Removal in this section).
4. Remove lift cylinder pin (item 28) that secures lift cylinder to lift arm.
5. Drive out slotted roll pin (item 11) that retains lift arm pivot shaft. Discard roll pin.
6. Support lift arm and pull lift arm pivot shaft from lift arm and frame. Locate and remove thrust washers (item 10) during pivot shaft removal. Note location of thrust washers for assembly purposes.
 - A. If pivot shaft is difficult to remove, fabricate a puller as shown in Figure 8.
 - B. Attach puller to end of pivot shaft using bolt and flat washer.
 - C. Drive pivot shaft from lift arm and frame with hammer.
7. Remove lift arm from machine.

Installation (Fig. 6)

1. Apply anti-seize lubricant to lift arm pivot shaft.
2. Position lift arm to frame with thrust washers properly placed (Fig. 6). Make sure that there is a thrust washer placed between the rear of the lift arm and frame. Additional thrust washers can be used to remove end play of lift arm.
3. Slide pivot shaft into frame and lift arm until roll pin holes in shaft and frame align. Make sure that lift arm pivots freely after installation.
4. Install new slotted roll pin (item 11) to secure lift arm pivot shaft.
5. If pivot hub (item 9) was removed from pivot shaft, slide pivot hub onto shaft. Apply Loctite #242 (or equivalent) to cap screw threads and secure pivot hub with washer and cap screw. Torque cap screw from **77 to 96 ft-lb (105 to 130 N-m)**.

6. Align lift cylinder with lift arm. Secure lift cylinder to lift arm with lift cylinder pin (item 28). After lift cylinder is secured, make sure that upper hydraulic fitting on lift cylinder does not contact frame.
7. Install side deck rear arm assembly (see Side Deck Rear Arm Assembly Installation in this section).
8. If sensing plate (item 25) was removed from lift arm, secure plate so it is rotated as far as possible toward center of machine.
9. Position and install side cutting deck to machine (see Side Cutting Deck Installation in Chapter 8 - Cutting Decks).
10. Lubricate lift arm grease fittings after assembly is complete.
11. After assembly is completed, raise and lower the cutting deck to verify that hydraulic hoses and fittings do not contact anything.




Figure 8

Side Deck Rear Arm Assembly




Figure 9

- | | | |
|----------------------------|-------------------------------|-----------------------------------|
| 1. Cutting deck (LH shown) | 16. Plate | 30. Damper |
| 2. Deck mount (LH shown) | 17. Lock nut (2 per arm) | 31. Damper rod end (2 per damper) |
| 3. Cap screw | 18. Pivot shaft | 32. Cap screw (2 per damper) |
| 4. Lock nut | 19. Retaining ring | 33. Link tube |
| 5. Clevis pin | 20. Thrust washer (2 per arm) | 34. Lock nut |
| 6. Hair pin | 21. Flange bushing | 35. Flat washer |
| 7. Spacer | 22. Rear arm (LH shown) | 36. Bushing |
| 8. Rod end | 23. Lock nut (2 per damper) | 37. Damper spring |
| 9. Jam nut | 24. Lock washer | 38. Lock nut (4 per arm) |
| 10. Cap screw (4 per arm) | 25. Lock nut | 39. Jam nut (2 per arm) |
| 11. Straight bushing | 26. Grease fitting | 40. Rod end (2 per arm) |
| 12. Spring shaft | 27. Jam nut | 41. Cap screw (8 used) |
| 13. Flat washer | 28. Cap screw | 42. Lock washer (8 used) |
| 14. Compression spring | 29. Bell crank (LH shown) | 43. Flat washer (8 used) |
| 15. Plastic bearing | | |

Rear Arm Removal (Fig. 9)

1. Park machine on a level surface, lower cutting decks, stop engine, apply parking brake and remove key from the ignition switch.
2. Remove hair pin (item 6) and clevis pin (item 5) that connect damper link to cutting deck.
3. Remove cap screw (item 3) and lock nut (item 4) that secures rod end of rear arm to cutting deck. Locate and remove spacer from each side of rod end.
4. Remove lock nut (item 25) and lock washer (item 24) that secures rear arm pivot shaft. Slide pivot shaft from hub and rear arm. Remove rear arm assembly from machine.

Rear Arm Disassembly (Fig. 9)

1. Disassemble rear arm assembly using Figure 9 as a guide.

Rear Arm Assembly (Fig. 9)

1. Slide large flat washer, spring, plastic bearing, second large flat washer and small flat washer onto spring shaft. Thread one jam nut onto shaft and tighten so that spring is compressed to a length of **7.690" (195.3 mm)**.
2. Slide the straight bushing and plate onto spring shaft.
3. Insert assembly into rear arm housing.
4. Secure plate to rear arm housing with two (2) cap screws and lock nuts.

IMPORTANT: All free play must be removed from assembly to allow proper operation and ensure long life.

5. Grasp end of spring shaft. Push inward and pull outward on shaft to determine free play in assembly. Loosen jam nut, 1/2 turn at a time, until there is no free play in spring assembly.
6. Remove two (2) cap screws and nuts securing plate to rear arm housing. Remove spring shaft assembly from housing.
7. Thread remaining jam nut onto end of spring shaft and, while retaining inner jam nut to prevent it from moving, torque outer jam nut from **22 to 28 ft-lb (30 to 37 N-m)** to lock adjustment.

8. Thoroughly pack spring with grease. Install spring shaft assembly into housing and secure plate with four (4) cap screws and lock nuts.

9. Thread rod end (item 8) with jam nut (item 9) into end of spring shaft. Do not tighten jam nut at this time.

10. If rod ends (item 31) were removed from damper (item 30), apply Loctite #271 (or equivalent) to damper shaft threads before installing rod ends. Secure damper to bellcrank and rear arm with cap screws and lock nuts.

11. If damper link was disassembled, adjust the length of the link from **5.295" to 5.445" (134.5 to 138.3 mm)** (Fig. 11).

12. If damper springs (item 37) were removed, tighten lock nuts so that bushings (item 36) are free to rotate.




Figure 10

1. Lift arm (RH shown)
2. Rear arm
3. Damper




Figure 11

1. Rod end (2 used)
2. Jam nut (2 used)
3. Link tube

Rear Arm Installation (Fig. 9)

1. Position rear arm assembly to cutting deck and frame.
2. Slide pivot shaft through rear arm clevis and hub. Secure pivot shaft with lock washer (item 24) and lock nut (item 25).
3. Connect damper link to cutting deck with clevis pin (item 5) and hair pin (item 6).
4. Position spacers on both sides of rod end of rear arm assembly. Secure rod end of rear arm assembly to deck mount with cap screw (item 3) and lock nut (item 4).
5. Lubricate rear arm grease fittings.
6. Align cutting deck to traction unit as follows:
 - A. Make sure the machine is on a level, hard surface.
 - B. Place a square or straight edge against the deck weldment that contains the castor fork assembly (Fig. 12). Do not use the castor fork assembly itself.
 - C. Measure from the inset bead of the rim (not the outer edge of the rim) to the straight edge at two locations as indicated in Figure 12. Rim and paint irregularities make the rim outer edge an unreliable point of measure. These two measurements should be the same within a tolerance of 1/8" (3 mm).
 - D. Rotate spring shaft (item 12) in rear arm assembly until correct dimension is attained. Shaft should rotate freely inside the assembly. All adjustments must be made with the rod end of the rear arm bolted to the deck.
 - E. Raise and lower the deck and recheck dimensions for correct alignment.
 - F. When deck is properly aligned to traction unit, tighten rod end jam nut (item 9).

NOTE: Due to differences in turf conditions and the counterbalance setting of traction unit, it is advised that turf be cut and appearance checked before formal cutting is started. Refer to Operator's Manual for correcting cutting deck mismatch procedures.




Figure 12

This page is intentionally blank.

Lift Arm Joint Yoke




Figure 13

- | | | |
|-------------------------------------|--------------------------------------|--------------------------------------|
| 1. Side cutting deck (LH shown) | 8. Flat washer (8 used per mount) | 15. Cap screw (8 used per mount) |
| 2. Deck mount (LH shown) | 9. Joint yoke | 16. Lock washer (8 used per mount) |
| 3. Retaining ring (2 used per deck) | 10. Spacer | 17. Rear arm assembly |
| 4. Lock nut | 11. Thrust washer (0.125" thickness) | 18. Spacer |
| 5. Plate | 12. Hardened washer | 19. Cap screw |
| 6. Rubber plate | 13. Cotter pin | 20. Lock nut |
| 7. Cap screw | 14. Slotted hex nut | 21. Thrust washer (0.032" thickness) |

Removal (Fig. 13)

1. Park machine on a level surface, lower cutting decks, stop engine, apply parking brake and remove key from the ignition switch.

2. Remove cap screw (item 19) and lock nut (item 20) that secures rod end of rear arm assembly to cutting deck. Locate and remove spacer (item 18) from each side of rod end.

3. Remove eight (8) cap screws, lock washers and flat washers that secure deck mount to cutting deck (Fig. 14).

4. Remove cotter pin from joint yoke shaft. Make sure that deck mount is supported and remove slotted hex nut that secures joint yoke to lift arm. Take hardened washer (item 12) and thrust washers (items 21 and 11) from joint yoke shaft. Slowly raise lift arm enough to free joint yoke from lift arm. Remove thrust washer (item 11) and spacer (item 10) from yoke shaft.

5. Lift joint yoke and deck mount from lift arm and cutting deck.

Joint Yoke Disassembly

1. Remove retaining rings from yoke and deck mount.

IMPORTANT: Support yoke when removing cross and bearings to prevent yoke damage.

2. Use a press to remove yoke from deck mount:
 - A. Place a small socket against one bearing in the deck mount and a large socket on the opposite side of the mount.
 - B. While supporting the large socket, apply pressure on small socket to partially push the opposite bearing into the large socket.
 - C. Remove assembly from press, grasp partially removed bearing and tap on yoke to completely remove the bearing.
 - D. Repeat process for remaining bearing.
 - E. Remove yoke from mount.
3. Use a press and the above process to remove bearings and cross from yoke.
4. Thoroughly clean and inspect all components.

Joint Yoke Assembly

1. Make sure that rubber plate (item 6) and plate (item 5) are positioned in bottom of deck mount.
2. Apply a coating of grease to bearing bores of yoke and deck mount. Also, apply grease to bearings and seal of bearing assembly. Make sure that all bearing rollers are properly seated in bearing cage.
3. Use a press to install cross and bearings into yoke.

- A. Press one bearing partially into yoke.

IMPORTANT: Take care when installing cross into bearing to avoid damaging bearing seal.

- B. Carefully insert cross into bearing and yoke.
- C. Hold cross in alignment and press bearing in until it hits the yoke.
- D. Carefully place second bearing into yoke bore and onto cross shaft. Press bearing into yoke.

4. Use a press and the above process to install deck mount to yoke.

5. Install retaining rings to yoke and deck mount to secure bearings in place.

6. Make sure that assembled joint yoke moves without binding. Slight binding can usually be eliminated by lightly rapping the yoke lugs with a soft faced hammer. If binding continues, disassemble joint yoke and deck mount to identify and eliminate source of binding.

Installation (Fig. 13)

1. Position joint yoke with deck mount to cutting deck.
2. Secure deck mount to deck with eight (8) cap screws, lock washers and flat washers (Fig. 14).
3. Place spacer washer (chamfered ID side down) and then thrust washer (item 11) onto joint yoke shaft. Insert yoke shaft up through lift arm bushings. Place additional thrust washers (items 11 and 21) and then hardened washer (item 12) on yoke shaft and secure with slotted hex nut. Torque nut from **150 to 180 ft-lb (203 to 244 N-m)** while aligning hole in shaft with slot in nut. Install cotter pin.
4. Position spacers on both sides of rod end of rear arm assembly. Secure rod end of rear arm assembly to deck mount with cap screw and lock nut.
5. Grease joint yoke and lift arm bushings after installation on machine.
6. After assembly is completed, raise and lower the cutting deck to verify that hydraulic hoses and fittings do not contact anything.




Figure 14

- | | |
|------------------------|----------------------|
| 1. Lift arm (RH shown) | 4. Deck mount |
| 2. Joint yoke | 5. Cap screw/washers |
| 3. Rear arm assembly | |

Control Arm




Figure 15

- | | | |
|--------------------------------|--------------------------------|---------------------------------|
| 1. Flange nut (3 used) | 16. Flange head screw (6 used) | 30. RH cover |
| 2. Flange head screw (2 used) | 17. Flange nut (2 used) | 31. Cruise control switch |
| 3. Washer head screw (10 used) | 18. Hole plug | 32. Cover plate |
| 4. LH cover | 19. Rivet (2 used) | 33. Cap screw (2 used) |
| 5. Lock nut | 20. Switch panel | 34. Lift/lower switch (3 used) |
| 6. Control arm panel | 21. Arm rest | 35. Ignition key |
| 7. Ignition switch | 22. Power point | 36. Nut |
| 8. InfoCenter display | 23. Cap | 37. Screw (2 used) |
| 9. R-clamp | 24. Nut | 38. Switch step |
| 10. Audio alarm | 25. Flange spacer (2 used) | 39. Hex nut |
| 11. PTO switch | 26. Cover plate | 40. Hi-low speed switch |
| 12. Nut | 27. Flange head screw (2 used) | 41. Engine speed switch |
| 13. Bracket | 28. Plug (2 used) | 42. Hole plug (GM4000-D) |
| 14. U-nut (5 used) | 29. Screw | 43. Headlight switch (GM4010-D) |
| 15. Clip (2 used) | | |

Disassembly (Fig. 15)

1. Park machine on a level surface, lower cutting units, stop engine and engage parking brake. Remove key from ignition switch.

2. Remove two (2) flange head screws (item 27) and then cover plate (item 26) from outside of control arm. Locate and retrieve two (2) spacers (item 25).

3. At front of control arm, remove screw (item 29) and lock nut (item 5) that secure control arm covers to each other.

4. Remove five (5) washer head screws (item 3) that secure each cover to control arm panel.

5. Remove control arm covers from machine. As LH cover (item 4) is removed from control arm, unplug wire harness connector from headlight switch if equipped.

6. Remove electrical components from control arm as needed using Figure 15 as a guide.

7. If necessary, remove control arm panel and supports from machine using Figures 15 and 16 as guides.

Assembly (Fig. 15)

1. Install all removed electrical and control arm components using Figure 15 and 16 as guides.

2. Position covers to control arm. As LH cover (item 4) is placed, plug wire harness connector to headlight switch if equipped.

3. Secure each cover to control arm with five (5) washer head screws (item 3). Install screw (item 29) and lock nut (item 5) to secure covers at front of control arm.

4. Position cover plate and spacers to outside of control arm. Secure with two (2) flange head screws.




Figure 16

- | | |
|----------------------------|-------------------------|
| 1. Flat washer | 7. Screw |
| 2. Seat belt buckle | 8. Arm support |
| 3. Coupling nut | 9. Hex nut |
| 4. Spacer | 10. Support bracket |
| 5. Carriage screw (5 used) | 11. Flange nut (5 used) |
| 6. Cap screw | 12. Support channel |

Traction Pedal




Figure 17

- | | | |
|---------------------------|-------------------------------|------------------------------|
| 1. Carriage bolt (6 used) | 14. Cap screw | 27. Bushing hub |
| 2. Traction pedal | 15. Flange nut (2 used) | 28. Position sensor |
| 3. Bushing | 16. Lock washer | 29. Capture plate |
| 4. Operator platform | 17. Flange mount bearing | 30. Standoff spacer (2 used) |
| 5. Cap screw | 18. Cover plate | 31. Screw (2 used) |
| 6. Rod end bearing | 19. Butterfly plate | 32. Spring shaft |
| 7. Hex nut | 20. Butterfly bracket | 33. Flat washer |
| 8. Flange nut (10 used) | 21. Carriage screw | 34. Compression spring |
| 9. Traction pedal shaft | 22. Spacer | 35. Spring retainer |
| 10. Roll pin | 23. Threadlock screw (2 used) | 36. Flat washer |
| 11. Cap screw (2 used) | 24. Cap screw (5 used) | 37. Lock nut |
| 12. Clamp block (2 used) | 25. Lock nut (6 used) | 38. Spring bracket |
| 13. Lock nut | 26. Sensor bracket | |

IMPORTANT: A properly installed and calibrated traction pedal position sensor is critical to accurate traction system response and for reliable sensor life. Use care when removing, installing and calibrating the traction pedal position sensor.

Disassembly (Fig. 17)

1. Park machine on a level surface, lower cutting decks, stop engine, apply parking brake and remove key from the ignition switch.
2. Remove front steering tower cover (see Steering Tower in this section).
3. Disconnect machine wire harness connector from position sensor (item 28) on traction pedal.
4. If the traction pedal is to be removed from the traction pedal shaft, use a marker or paint pen on pedal and shaft to identify location of pedal for assembly purposes.
5. Disassemble traction pedal as needed using Figures 17 and 18 as guides. When removing roll pin (item 10 in Fig. 17), make sure to support shaft to prevent component damage.

Assembly (Fig. 17)

1. Assemble traction pedal using Figures 17 and 18 as guides noting the following items:
 - A. Apply grease to both the OD and ID of the spring retainer (item 35 in Fig. 17) before installation. Take care to not get grease on threads of spring shaft (item 32 in Fig. 17) or lock nut (item 37 in Fig. 17).
 - B. If lock nut (item 37 in Fig. 17) was removed, tighten nut until washer (item 36 in Fig. 17) does not rotate.
 - C. If traction pedal shaft (item 9 in Fig. 17) was removed, apply grease to the shaft areas that will be inside the bearings after assembly.
 - D. Use a press to install roll pin (item 10 in Fig. 17). DO NOT damage flange mount bearing (item 17 in Fig. 17) or cover plate (item 18 in Fig. 17) when installing roll pin. Also, take care to not distort roll pin during assembly.
 - E. Make sure that roll pin (item 10 in Fig. 17) is fully inside the butterfly groove of the shim plate (item 20 in Fig. 17). The roll pin should not contact the shim plate throughout the operating range.

F. To install the traction pedal position sensor (item 28 in Fig. 17), press and hold the traction pedal in the reverse direction slightly. Align the slot on the end of the pedal shaft with the slot in the position sensor. Slide position sensor onto screws and release pedal. Hold position sensor in position while installing capture plate (item 29 in Fig. 17) and lock nuts (item 25 in Fig. 17).

G. Torque screws (item 31 in Fig. 17) from **13 to 17 in-lb (1.5 to 1.9 N-m)**.

H. Leave the hex nut (item 7 in Fig. 17) loose so that the position sensor can be calibrated.

2. After traction pedal assembly, make sure that there is no binding in pedal movement and also that pedal returns to the centered position when released. Correct any sticking or binding before machine operation.
3. Plug machine wire harness connector into traction pedal position sensor (item 28 in Fig. 17).
4. After assembly of the traction pedal, adjust and calibrate the traction pedal and position sensor using the InfoCenter display (see Traction Pedal Adjustment and Traction Pedal Calibration in the Adjustments section of Chapter 5 - Electrical System).
5. Make sure that hex nut (item 7 in Fig. 17) is tightened after position sensor adjustment.
6. Install front steering tower cover (see Steering Tower in this section).




Figure 18

- | | |
|--------------------------|--------------------------|
| 1. Traction pedal | 4. Clamp block (2 used) |
| 2. Pedal position sensor | 5. Spring shaft assembly |
| 3. Traction pedal shaft | |

Operator Platform




Figure 19

- 1. Operator platform
- 2. Cap screw (2 used)
- 3. Flat washer (4 used)

- 4. Center mount (4 used)
- 5. Plain washer (4 used)

- 6. Lock nut (4 used)
- 7. Cap screw (2 used)

Some service procedures (e.g. removing the hydraulic reservoir) require the operator platform to be raised. The following steps can be used to raise the platform.

Disassembly (Fig. 19)

1. Park machine on a level surface, lower cutting decks, stop engine, apply parking brake and remove key from the ignition switch.

2. Disconnect negative battery cable from battery terminal and then disconnect positive cable from battery (see Battery Service in the Service and Repairs section of Chapter 5 - Electrical System).

3. Remove steering tower covers (see Steering Tower in this section).

4. Disconnect machine wire harness connector from position sensor on traction pedal assembly.

5. Remove fasteners that secure traction pedal assembly to operator platform and then remove traction pedal assembly from platform (Fig. 21).

6. Disconnect both brake cables from brake pedals and operator frame (Fig. 22). Access to brake cable jam nuts can be obtained by removing adjustment cover on operator platform (Fig. 23). Position brake cables away from operator platform.

7. Disconnect all electrical wire harness connections between operator platform components and main frame locations. As needed, label disconnected electrical connections for proper installation.

8. On Groundsmaster 4010 machines:

A. Remove operator cab from machine.

B. Remove cable ties that secure operator cab coolant and air conditioner hoses in engine compartment to allow the operator platform to be raised. Note location of cable ties for assembly purposes.

NOTE: If desired, operator seat can be removed from operator platform to reduce overall weight of operator platform assembly (see Operator Seat in this section).

9. Remove four (4) cap screws, flat washers, plain washers and lock nuts that secure operator platform to machine frame.

IMPORTANT: Make sure to not damage the electrical wire harness or other components while raising the operator platform.

10. Carefully raise operator platform as needed to access components to be serviced. Support platform to prevent it from moving or shifting.




Figure 20

- | | |
|---------------------------|------------------|
| 1. Operator platform | 4. Clip (2 used) |
| 2. Flange screw (10 used) | 5. Rear cover |
| 3. Front cover | |




Figure 21

- | | |
|----------------------------|------------------------|
| 1. Traction pedal assembly | 3. Flange nut (4 used) |
| 2. Carriage screw (4 used) | 4. Operator platform |




Figure 22

- | | |
|---------------------------|---------------------------|
| 1. Brake pedal (RH shown) | 5. Spring |
| 2. Cotter pin | 6. Brake cable (RH shown) |
| 3. Clevis pin | 7. Brake cable jam nuts |
| 4. Brake strap | |

Assembly (Fig. 19)

1. Make sure that all machine components are installed below operator platform before platform is lowered to frame.

IMPORTANT: Make sure to not damage the electrical wire harness or other components while lowering the operator platform.

2. Carefully lower operator platform and position over center mounts (item 4) that are installed in the frame.

3. Secure operator platform to machine frame with four (4) cap screws, flat washers, plain washers and lock nuts. Torque lock nuts from **95 to 115 ft-lb (129 to 155 N-m)**.

4. Connect all electrical wire harness connections between operator platform components and main frame locations.

5. On Groundsmaster 4010 machines:

A. Install operator cab to machine.

B. Secure operator cab coolant and air conditioner hoses in engine compartment with cable ties in locations noted during disassembly.

6. Connect both brake cables to brake pedals and operator frame. Adjust brakes so that both pedals have **1/2 to 1 inch (13 to 25 mm)** of free travel.

7. Position traction pedal assembly to operator platform and secure with removed fasteners (Fig. 21). Connect machine wire harness connector to position sensor on traction pedal assembly.

8. Secure steering tower covers to machine (see Steering Tower in this section).

9. Connect positive battery cable from battery terminal and then connect negative cable to battery (see Battery Service in the Service and Repairs section of Chapter 5 - Electrical System).




Figure 23

- | | |
|--------------------------|-------------------------|
| 1. Flange screw (3 used) | 5. Screw (2 per switch) |
| 2. Adjustment cover | 6. Switch nut (2 used) |
| 3. Switch bracket | 7. Clip (3 used) |
| 4. Brake switch (2 used) | |

This page is intentionally blank.

Operator Seat




Figure 24

- | | | |
|----------------------------|---------------------------------|----------------------------------|
| 1. Carriage screw (5 used) | 14. Seat latch | 27. Flat washer (3 used) |
| 2. Support channel | 15. Locking cotter pin | 28. Cotter pin (2 used) |
| 3. Support bracket | 16. Latch rod | 29. Clevis pin (2 used) |
| 4. Flange nut (6 used) | 17. Locking cotter pin (2 used) | 30. Locking cotter pin (2 used) |
| 5. Cap screw | 18. Clevis pin (2 used) | 31. Manual tube |
| 6. Flat washer (4 used) | 19. Flat washer (4 used) | 32. Seat and suspension assembly |
| 7. Arm support | 20. Cap screw (4 used) | 33. Flat washer |
| 8. Screw | 21. Seat belt latch | 34. Bushing |
| 9. Coupler nut | 22. Lock washer | 35. Compression spring |
| 10. Spacer | 23. Cap screw | 36. Seat plate |
| 11. Flange nut (4 used) | 24. Operator platform | 37. R-clamp (2 used) |
| 12. Seat belt | 25. Hex nut | 38. Flange head screw (2 used) |
| 13. Cap screw | 26. Prop rod | |

Removal (Fig. 24)

1. Park machine on a level surface, lower cutting decks, stop engine, apply parking brake and remove key from the ignition switch.
2. Disconnect seat electrical connector from machine wire harness (Fig. 25).
3. Support control arm assembly to prevent it from shifting.
4. Remove flange nut (item 4) and carriage screw (item 1) that secure support bracket (item 3) to support channel (item 2).
5. Remove screw (item 8) that secures control arm support (item 7) to coupler nut (item 9).
6. Remove cap screw (item 5), flat washers (item 6), spacer (item 10) and seat belt latch (item 21) from seat and control arm support (item 7).

IMPORTANT: Make sure to not damage the electrical harness, control cable or other parts while moving the control arm assembly.

7. Carefully move control arm assembly away from seat.
8. Remove four (4) torx head screws that secure seat to seat suspension (Fig. 26). Note that the screw near the seat adjustment handle is longer than the other three (3) screws.
9. Lift seat from seat suspension and remove from machine.

NOTE: Refer to Operator Seat Suspension in this section if seat suspension service is necessary.

Installation (Fig. 24)

1. Carefully position seat to seat suspension.
2. Secure seat to seat suspension with four (4) torx head screws (Fig. 26). Make sure that longer screw is positioned near the seat adjustment handle. Torque screws **18 ft-lb (25 N-m)**.

IMPORTANT: Make sure to not damage the electrical harness, control cable or other parts while moving the control arm assembly.

3. Position and secure control arm assembly to seat. Install all fasteners before fully tightening them.

A. Secure support bracket (item 3) and support channel (item 2) with flange nut (item 4) and carriage screw (item 1).

B. Secure control arm support (item 7) to coupler nut (item 9) with screw (item 8).

C. Place flat washer (item 6), seat belt latch (item 21) and spacer (item 10) between seat and control arm support (item 7). Secure with cap screw (item 5) and second flat washer (item 6).

D. Fully tighten all fasteners to secure control arm assembly to seat.

4. Connect seat electrical connector to machine wire harness (Fig. 25).




Figure 25

1. Operator seat
2. Seat switch connector
3. Suspension connector




Figure 26

1. Seat
2. Suspension assembly
3. Screw (M8x12) (3 used)
4. Screw (M8x16)

Operator Seat Service




Figure 27

- 1. Backrest cushion
- 2. Seat cushion
- 3. Armrest cover
- 4. LH armrest
- 5. Bushing (2 used)
- 6. Backrest
- 7. Plug (2 used)
- 8. Cable tie (3 used)
- 9. LH adjustment rail
- 10. Bumper (2 used)

- 11. Washer
- 12. Cap screw (2 used)
- 13. Seat
- 14. Nut
- 15. Spring (2 used)
- 16. Magnet
- 17. Seat switch
- 18. Rivet (4 used)
- 19. Mounting plate
- 20. Return spring

- 21. Torx screw (5 used)
- 22. RH adjustment rail
- 23. Rail stop
- 24. Torx screw
- 25. Torx screw (3 used)
- 26. Washer (3 used)
- 27. Handle
- 28. Nut
- 29. Support bracket
- 30. Cap screw

Disassembly (Fig. 27)

1. Disassemble operator seat as necessary using Figures 27 and 28 as guides.

Assembly (Fig. 27)

1. Assemble operator seat using Figures 27 and 28 as guides.




Figure 28

- | | |
|---------------------|----------------|
| 1. Operator seat | 5. Flat washer |
| 2. R-clamp (2 used) | 6. Seat belt |
| 3. Screw (2 used) | 7. Cap screw |
| 4. Manual tube | |

Operator Seat Suspension




Figure 29

- | | | |
|-------------------------|------------------------------|----------------------------|
| 1. Cover | 14. Washer (2 used) | 27. Clamp (2 used) |
| 2. Cover | 15. Tether | 28. Hose nipple |
| 3. Level control | 16. Rivet (2 used) | 29. Screw |
| 4. Air control valve | 17. Washer (4 used) | 30. Handle |
| 5. Shock absorber | 18. C-clip (4 used) | 31. Bumper |
| 6. Air spring | 19. Pin (2 used) | 32. Nut |
| 7. Air tube assembly | 20. Rivet (2 used) | 33. Plastic plug (23 used) |
| 8. Wire harness | 21. Washer (3 used) | 34. Screw (2 used) |
| 9. Compressor | 22. Screw (2 used) | 35. Roller (2 used) |
| 10. Bellows | 23. Washer | 36. Screw (4 used) |
| 11. Stop | 24. Housing support (4 used) | 37. Base plate |
| 12. Bumper set (2 used) | 25. Spacer (4 used) | 38. Suspension frame |
| 13. Roller (4 used) | 26. Hose nipple | 39. Upper plate |

NOTE: Most of the seat suspension components can be serviced with the seat suspension base mounted to the frame platform. If the air spring assembly (item 6) requires removal, the seat suspension base will have to be removed from the seat platform.

Disassembly (Fig. 29)

1. Remove operator seat from seat suspension (see Operator Seat Removal in this section).
2. Disconnect seat suspension connector from machine wire harness (Fig. 30).
3. If the air spring assembly (item 6) or base plate (item 37) requires removal, remove seat suspension from seat plate (Fig. 31):

- A. Raise and support seat plate assembly. Support seat suspension to prevent it from falling.
- B. Remove four (4) cap screws, flat washers and flange nuts that secure seat suspension to seat plate.
- C. Remove seat suspension from machine.

4. Remove seat suspension components as needed using Figure 29 as a guide.

Assembly (Fig. 29)

1. Install all removed seat suspension components using Figure 29 as a guide.
2. If seat suspension was removed from seat plate, secure suspension to seat plate (Fig. 31):
 - A. Position seat suspension onto seat plate.
 - B. Secure seat suspension to seat plate with four (4) cap screws, flat washers and flange nuts.
 - C. Lower and secure seat plate assembly.
3. Install operator seat to seat suspension (see Operator Seat Installation in this section).
4. Make sure that seat electrical connectors are connected to machine wire harness (Fig. 30).




Figure 30

- | | |
|--------------------------|-------------------------|
| 1. Operator seat | 3. Suspension connector |
| 2. Seat switch connector | |




Figure 31

- | | |
|-------------------------|------------------------|
| 1. Seat suspension | 4. Flange nut (4 used) |
| 2. Flat washer (4 used) | 5. Seat plate |
| 3. Cap screw (4 used) | |

Hood




Figure 32

- | | | |
|---|--|---|
| <ul style="list-style-type: none"> 1. Hood 2. Screen assembly 3. Bulb seal 4. Flange nut (2 used) 5. Screen pivot (2 used) 6. Hair pin (2 used) 7. Hood support 8. Plastite screw (4 used) 9. Door handle (2 used) 10. Bulb seal 11. Hood pivot (2 used) | <ul style="list-style-type: none"> 12. Flexible draw latch (2 used) 13. Corner screen seal (2 used) 14. Screw (8 used) 15. LH hood support 16. Hood rod (2 used) 17. Clevis pin (2 used) 18. R-clamp (2 used) 19. Hair pin (2 used) 20. Rear screen 21. Top screen | <ul style="list-style-type: none"> 22. Carriage bolt (24 used) 23. Carriage bolt (2 used) 24. Plastic plug (43 used) 25. Foam seal (2 used) 26. Flange nut (2 used) 27. Screw (2 used) 28. Cap screw (2 used) 29. Flange nut (24 used) 30. RH hood support 31. Pop rivet (8 used) |
|---|--|---|

Removal

1. Park machine on a level surface, lower cutting decks, stop engine, apply parking brake and remove key from the ignition switch.
2. Remove hood assembly from machine:
 - A. Remove hair pins (item 6) that retain screen pivots to hood pivots.
 - B. Slide hood assembly to disengage screen pivots from hood pivots and lift hood from machine.
3. Disassemble hood as needed using Figure 32 as a guide.

Installation

1. Assemble hood using Figure 32 as a guide.
2. Install hood to machine:
 - A. Position hood to machine and engage screen pivots to hood pivots.
 - B. Install hair pins (item 6) to secure screen pivots to hood pivots.
3. Align hood to machine to allow correct operation of hood latch and dust seals:
 - A. Place shim that is from 3/8" to 7/16" (9.5 to 11.1 mm) thick on top of frame (both RH and LH sides) near the sides of radiator/oil cooler (Figs. 33 and 34).
 - B. Close hood so that it rests on shims and fasten the hood latches.
 - C. Loosen hood pivots at frame to adjust vertical placement of pivots. Re-tighten hood pivot fasteners.
 - D. Loosen screen pivots to allow hood latches to pull hood against radiator support. Re-tighten screen pivot fasteners.
4. After hood is assembled to machine, check for the following:
 - A. Check that bulb and foam seals are equally compressed at all contact points with hood. Bulb and foam seals should compress from **0.125" to 0.375" (3.2 to 9.5 mm)** when hood assembly is correct.
 - B. Hood should open and close without contacting oil cooler hardware.
 - C. Hood should fit to fuel tank with no open gaps.




Figure 33

1. LH shim location
2. LH hood pivot
3. LH screen pivot




Figure 34

1. RH shim location
2. RH hood pivot
3. RH screen pivot

This page is intentionally blank.



Table of Contents

SPECIFICATIONS 2
GENERAL INFORMATION 3
 Operator’s Manual 3
 Castor Wheel Tire Pressure 3
 Blade Stopping Time 3
TROUBLESHOOTING 4
 Factors That Can Affect Quality of Cut 4
SERVICE AND REPAIRS 6
 Center Cutting Deck 6
 Side Cutting Decks 8
 Idler Assembly 10
 Blade Spindle Assemblies 12
 Blade Spindle Service 14
 Castor Forks and Wheels 16



Specifications



MOUNTING: Cutting decks are supported by lift arms controlled with individual lift switches.

CONSTRUCTION: Deck chamber is welded steel construction reinforced with channels and plates.

HEIGHT-OF-CUT RANGE: 1" to 5" (25.4 mm to 127 mm) in 1/2" (12.7 mm) increments. Center deck height-of-cut adjustment is achieved by changing spacers on castor wheels and adjusting length of deck support chains. Side deck adjustment requires adding or removing spacers from the castor forks, re-positioning the castor wheel axles in the castor forks and securing the pivot arms to the correct height-of-cut bracket holes.

DECK DRIVE: Closed loop hydraulic system operates hydraulic motor on each cutting deck. The motor drives one spindle directly with remaining deck spindle(s) driven by B section kevlar v-belt(s). Blade spindles are 1.250" (31.7 mm) shafts supported by greaseable, tapered roller bearings.

CUTTING BLADE: Cutting blade dimensions are 21.750" (552 mm) long, 2.500" (64 mm) wide and 0.250" (6.4 mm) thick. Anti-scalp cup installed on each cutting blade. Three (3) blades on front deck and two (2) blades on each side deck.

WIDTH OF CUT: Center deck provides 62" (1575 mm) width of cut. Each side deck has 42" (1067 mm) width of cut. Total width of cut is 132" (3353 mm) with 7" (128 mm) overlap.

DISCHARGE: Clippings are discharged from the rear of the cutting decks. Provided mounting holes allow attachment of optional Guardian Recycler Kit.

SUSPENSION SYSTEM: A fully floating suspension with hydraulic counterbalance. Center deck suspended at rear from lift arms and has two (2) castor wheels, two (2) adjustable skids and two (2) anti-scalp rollers. Each side deck supported by three (3) castor wheels and a spring damper system which connects the fourth deck corner to the traction unit. There is a main lift arm that provides counterbalance to the side decks along with a rear anti-rotation link which also provides bi-directional impact protection. Optional Guardian Recycler Kit includes one anti-scalp roller on each cutting deck.

General Information



CAUTION

Never install or work on the cutting decks or lift arms with the engine running. Always stop engine and remove key first.

Operator's Manual

The Operator's Manual provides information regarding the operation, general maintenance and maintenance intervals for your Groundsmaster machine. Refer to that publication for additional information when servicing and adjusting the cutting decks on your Groundsmaster.

Castor Wheel Tire Pressure

Castor tires on the front and side decks should be inflated to 50 PSI (345 kPa).

Blade Stopping Time

The blades of the cutting deck are to come to a complete stop in approximately five (5) seconds after the cutting deck engagement switch is shut down.

NOTE: Make sure the decks are lowered onto a clean section of turf or hard surface to avoid dust and debris.

To verify this stopping time, have a second person stand back from the deck at least twenty (20) feet and watch

the blades on one of the cutting decks. Have the operator shut the cutting decks down and record the time it takes for the blades to come to a complete stop. If this time is greater than seven (7) seconds, the braking valve on the hydraulic manifold may need adjustment.

Troubleshooting

There are a number of factors that can contribute to unsatisfactory quality of cut, some of which may be turf conditions. Turf conditions such as excessive thatch, uneven ground conditions, “sponginess” or attempting to cut off too much grass height may not always be overcome by adjusting the machine.

Remember that the “effective” or actual height-of-cut depends on cutting deck weight, tire pressures, hydraulic counterbalance settings and turf conditions. Effective height-of-cut will be different than the bench set height-of-cut.

Factors That Can Affect Quality of Cut

Factor	Possible Problem/Correction
1. Maximum governed engine speed.	Check maximum governed engine speed. Adjust speed to specifications if necessary.
2. Blade speed.	All deck blades should rotate at the same speed. See items in Troubleshooting Section of Chapter 4 - Hydraulic System.
3. Tire pressure.	Check air pressure of each tire including castor tires. Adjust to pressures specified in Operator’s Manual.
4. Blade condition.	Sharpen blades if their cutting edges are dull or nicked. Inspect blade sail for wear or damage. Replace blade if needed.
5. Mower housing condition.	Make sure that cutting chambers are in good condition. Keep underside of deck clean. Debris buildup will reduce cutting performance.
6. Height-of-cut.	Make sure all cutting decks are set at the same height-of-cut. Set decks as specified in the Operator’s Manual.
7. Cutting deck alignment and ground following.	Check lift arms and cutting deck pivot linkages for wear, damage or binding. Also, inspect for bent or damaged pivot shafts.
8. Roller and castor wheel condition.	All rollers and caster wheels should rotate freely. Replace bearings if worn or damaged.
9. Grass conditions.	Mow when grass is dry for best cutting results. Also, remove only 1” (25 mm) or 1/3 of the grass blade when cutting.

This page is intentionally blank.

Service and Repairs



CAUTION

Never install or work on the cutting decks or lift arms with the engine running. Always stop engine and remove key from ignition switch first.

Center Cutting Deck




Figure 1

- | | | |
|--------------------------------------|----------------------------------|-----------------------------|
| 1. Center deck assembly | 14. Ball joint mount (2 used) | 27. Hair pin (2 used) |
| 2. Grease fitting | 15. Flange nut (2 per mount) | 28. Cap screw |
| 3. Ball joint seal | 16. Cap screw (2 per mount) | 29. Spherical rod end |
| 4. Hydraulic deck motor | 17. Sensor plate | 30. Damper |
| 5. Flange head screw | 18. Carriage screw | 31. Clevis rod end |
| 6. RH lift arm | 19. Flat washer | 32. Spring pin |
| 7. LH lift arm | 20. Flange nut | 33. Grease fitting (2 used) |
| 8. Lift cylinder (2 used) | 21. U-bolt (2 used) | 34. Spacer |
| 9. Pin (2 used) | 22. Height-of-cut chain (2 used) | 35. Flat washer (2 used) |
| 10. Flange nut (2 used) | 23. Flat washer (4 per u-bolt) | 36. Slotted hex nut |
| 11. Jam nut (LH threads) (2 used) | 24. Hex nut (2 per u-bolt) | 37. Grease fitting |
| 12. Ball joint (LH threads) (2 used) | 25. Lock nut (2 per u-bolt) | 38. Front frame |
| 13. Cotter pin (2 used) | 26. Clevis pin (2 used) | |

Removal (Fig. 1)

1. Position machine on a clean, level surface. Lower cutting decks, stop engine, apply parking brake and remove key from the ignition switch.

2. Remove spring pin (item 32) that secures damper (item 30) to cutting deck. Position damper away from cutting deck.

NOTE: Removal of clevis pin from deck and height-of-cut chain is easier if deck is lifted slightly.

3. Remove hairpin and clevis pin that secure the height-of-cut chain to the rear of the cutting deck (Fig. 2).

4. Remove hydraulic motor from cutting deck (see Cutting Deck Motor Removal in the Service and Repairs Section of Chapter 4 - Hydraulic System).

5. Remove cap screws, washers and lock nuts securing ball joint mounts (item 14) to center deck castor arms (Fig. 4).

6. Slide the center cutting deck away from the traction unit.

Installation (Fig. 1)

1. Position machine on a clean, level surface. Lower lift arms, stop engine, apply parking brake and remove key from the ignition switch.

2. Position the center deck to the lift arms.

3. Align ball joint mounts (item 14) to center deck castor arms and secure with cap screws, washers and lock nuts (Fig. 4).

NOTE: Installation of clevis pin to deck and height-of-cut chain is easier if deck is lifted slightly.

4. Install clevis pin and hairpin that secure the height-of-cut chain to the rear of the cutting deck (Fig. 2).

5. Install hydraulic motor to cutting deck (see Cutting Deck Motor Installation in the Service and Repairs Section of Chapter 4 - Hydraulic System).

6. Position damper (item 30) to cutting deck bracket and secure with spring pin (item 32).

7. Lubricate grease fittings on cutting deck and lift arm assemblies.




Figure 2

1. Hairpin and clevis pin 2. Height-of-cut chain




Figure 3

1. Flange head screw 2. Hydraulic motor




Figure 4

1. Ball joint mount 3. Castor arm
2. Lift arm

Side Cutting Decks




Figure 5

- 1. Cutting deck (LH shown)
- 2. Flange head screw (2 used)
- 3. Hydraulic deck motor
- 4. Spider

- 5. Clevis pin
- 6. Hair pin
- 7. Deck mount (LH shown)
- 8. Cap screw (8 used per mount)

- 9. Lock washer (8 used per mount)
- 10. Flat washer (8 used per mount)
- 11. Lift arm (LH shown)

Removal (Fig. 5)

1. Position machine on a clean, level surface. Lower cutting decks, stop engine, apply parking brake and remove key from the ignition switch.

2. Remove hydraulic motor from cutting deck (see Cutting Deck Motor Removal in the Service and Repairs Section of Chapter 4 - Hydraulic System).

IMPORTANT: Do not change the length of the damper link (Fig. 8).

3. Remove hairpin and clevis pin that secure the damper link to the rear of the cutting deck (Fig. 8).

4. Remove eight (8) cap screws, lock washers and flat washers that secure deck mount to cutting deck (Fig. 6).

5. Raise lift arm enough to separate deck mount from cutting deck (Fig. 7).

6. Slide the cutting deck away from the traction unit.

Installation (Fig. 5)

1. Position machine on a clean, level surface. Stop engine, apply parking brake and remove key from the ignition switch.

2. Position the side cutting deck to the lift arm and deck mount.

3. Lower lift arm while aligning deck mount to cutting deck.

4. Install deck mount to cutting deck with (8) cap screws, lock washers and flat washers (Fig. 6). Tighten fasteners.

IMPORTANT: The length of the damper link should be from 5.295" to 5.445" (134 to 138 mm) measured between rod end centers.

5. Install clevis pin and hairpin that secure the damper link to the rear of the cutting deck (Fig. 8).

6. Install hydraulic motor to cutting deck (see Cutting Deck Motor Installation in the Service and Repairs Section of Chapter 4 - Hydraulic System).

7. Lubricate grease fittings on cutting deck and lift arm assembly.




Figure 6

- 1. Flange head screw
- 2. Hydraulic motor
- 3. Deck mount screw




Figure 7

- 1. Lift arm (RH shown)
- 2. Rear arm assembly
- 3. Deck mount




Figure 8

- 1. Damper link
- 2. Clevis pin

Idler Assembly




Figure 9

- | | | |
|---|----------------------|------------------------------------|
| 1. Cutting deck (front shown) | 9. Socket head screw | 17. Idler arm |
| 2. Flange nut | 10. Idler stop bolt | 18. Retaining ring |
| 3. Flange nut | 11. Flange nut | 19. Thrust washer |
| 4. Adjusting screw | 12. Cap screw | 20. Bushing (2 used per idler) |
| 5. Idler pulley | 13. Spacer | 21. Grease fitting |
| 6. Driven spindle (double pulley shown) | 14. Shoulder bolt | 22. Washer |
| 7. Flat washer | 15. Idler spring | 23. Driven spindle (single pulley) |
| 8. Lock washer | 16. Lock nut | 24. Drive belt |

NOTE: The front deck is shown in Figure 9. The idler assemblies used on the side decks use the same idler components.

Removal (Fig. 9)

1. Park machine on a level surface, lower cutting deck, stop engine, engage parking brake and remove key from the ignition switch.
2. Remove deck covers from top of cutting deck.



3. Use spring hook tool to unhook the idler spring (item 15) from the adjusting screw (item 4).
4. Remove drive belt(s) from deck pulleys.
5. Loosen flange nuts (item 11) that secure idler stop bolt (item 10) to cutting deck to allow clearance between idler arm and stop bolt.
6. Remove idler components as needed using Figure 9 as a guide. Note location of washers, idler spacer and screw as idler assemblies are being removed.

Installation (Fig. 9)

1. Install removed idler components using Figure 9 as a guide.

A. Make sure that one (1) thrust washer (item 19) is placed above and below the idler arm. Location of additional washer (item 22) depends on whether the idler pulley mounts on the bottom side of the idler arm or on the top of the idler arm.

B. Secure idler arm assembly to cutting deck with retaining ring.

C. If idler stop bolt (item 10) was removed from deck, make sure that it is installed in the hole that allows the stop bolt head to align with the idler arm.

2. Install drive belt to pulleys.



3. Use spring hook tool to attach the idler spring (item 15) onto the adjusting screw (item 4) and shoulder bolt on idler arm.
4. With the idler arm tensioning the drive belt, the idler spring hook to hook length should be from **3.250" to 3.750" (82.6 to 95.2 mm)** (Fig. 10). If necessary, disconnect spring and change position of adjusting screw. When idler spring is the correct length, tighten second flange nut to secure idler adjustment.
5. Adjust location of idler stop bolt so that the clearance between idler arm and idler stop bolt head is from **0.125" to 0.185" (3.2 to 4.6 mm)** (Fig. 10).
6. Lubricate idler arm grease fitting.
7. Install deck covers to cutting deck.




Figure 10

1. Idler stop bolt
2. Idler spring
3. Adjusting screw

Blade Spindle Assemblies




Figure 11

- 1. Center cutting deck
- 3. LH cutting deck
- 5. Driven spindle assembly
- 2. RH cutting deck
- 4. Drive spindle assembly
- 6. Grease fitting location

Removal (Figs. 11 and 12)

1. Park machine on a level surface, lower cutting decks, stop engine, apply parking brake and remove key from the ignition switch.

2. Remove covers from cutting deck to allow access to spindle assemblies.

3. If drive spindle assembly is to be serviced, remove hydraulic motor from cutting deck (see Cutting Deck Motor Removal in the Service and Repairs Section of Chapter 4 - Hydraulic Systems). Position motor away from spindle.

4. Loosen idler assembly to release drive belt tension (see Idler Assembly Removal in this section). Remove drive belt from spindle assembly that is to be serviced.

5. Start the engine and raise the cutting deck. Stop engine and remove key from the ignition switch. Latch or block up the cutting deck so it cannot fall accidentally.

6. Remove cutting blade, anti-scalp cup and blade bolt from spindle assembly that is to be serviced.

7. Remove spindle assembly from deck.

A. For driven spindle assemblies, remove eight (8) flange nuts that secure spindle assembly to deck.

B. For drive spindle assemblies, remove four (4) cap screws with washers that secure spindle assembly and hydraulic motor mount to deck. Remove motor mount. Then, remove four (4) flange nuts that secure spindle assembly to deck.

C. Lift spindle assembly from deck.

8. If necessary, press screws from spindle housing.

Installation (Figs. 11 and 12)

1. If screws were removed from spindle housing, press new screws into housing. Make sure that screw head is squarely seated against housing after installation.

2. Position spindle assembly on cutting deck noting orientation of grease fitting (Fig. 11). Secure spindle assembly to deck with removed fasteners.

3. Install cutting blade, anti-scalp cup and blade bolt to spindle. Tighten blade bolt from **88 to 108 ft-lb (120 to 146 N-m)**.

4. Slowly rotate cutting blades to verify that blades do not contact any deck components.

5. Install drive belt to spindle pulleys and idler pulley. Adjust drive belt tension (see Idler Assembly Installation in this section).

6. If drive spindle assembly was removed, install hydraulic motor to cutting deck (see Cutting Deck Motor Installation in the Service and Repairs Section of Chapter 4 - Hydraulic Systems).

IMPORTANT: Pneumatic grease guns can produce air pockets when filling large cavities and therefore, are not recommended to be used for proper greasing of spindle housings.

7. Attach a hand pump grease gun to grease fitting on spindle housing and fill housing cavity with grease until grease starts to come out of lower seal.

8. Install covers to cutting deck.




Figure 12

- | | |
|----------------------------|-------------------|
| 1. Deck (RH shown) | 6. Washer |
| 2. Driven spindle assembly | 7. Cap screw |
| 3. Drive spindle assembly | 8. Blade |
| 4. Flange nut | 9. Anti-scalp cup |
| 5. Drive belt | 10. Blade bolt |

Blade Spindle Service




Figure 13

- | | | |
|---------------------------------|--------------------------|--------------------------|
| 1. Lock nut | 6. Hydraulic motor mount | 10. Spacer set |
| 2. Hardened washer | 7. O-ring | 11. Spindle housing |
| 3. Driven pulley (single shown) | 8. Oil seal | 12. Grease fitting |
| 4. Spindle shaft | 9. Bearing cup and cone | 13. Spindle shaft spacer |
| 5. Drive pulley | | |

Disassembly (Fig. 13)

- Loosen and remove lock nut from top of spindle shaft. Remove hardened washer and pulley from spindle. For drive spindle, remove hydraulic motor mount.
- Remove the spindle shaft from the spindle housing which may require the use of an arbor press. The spindle shaft spacer should remain on the spindle shaft as the shaft is being removed.
- Carefully remove oil seals from spindle housing taking care to not damage seal bore in housing.
- Allow the bearing cones, inner bearing spacer and spacer ring to drop out of the spindle housing (Fig. 14).
- Using an arbor press, remove both of the bearing cups and the outer bearing spacer from the housing.
- The large snap ring can remain inside the spindle housing. Removal of this snap ring is very difficult.

Assembly (Fig. 13)

NOTE: A replacement spindle bearing set contains two (2) bearings, a spacer ring and a large snap ring (items 1, 2 and 3 in Fig. 14). These parts cannot be purchased separately. Also, do not mix bearing set components from one deck spindle to another.

NOTE: A replacement bearing spacer set includes the inner spacer and outer spacer (items 4 and 5 in Fig. 14). Do not mix bearing spacers from one deck spindle to another.

IMPORTANT: If new bearings are installed into a used spindle housing, it may not be necessary to replace the original large snap ring. If the original snap ring is in good condition with no evidence of damage (e.g. spun bearing), leave the snap ring in the housing and discard the snap ring that comes with the new bearings. If the large snap ring is found to be damaged, replace the snap ring.

- If large snap ring was removed from spindle housing, install snap ring into housing groove. Make sure snap ring is fully seated in housing groove.

2. Install outer bearing spacer into top of spindle housing. The spacer should fit against the snap ring.

3. Using an arbor press, push the bearing cups into the top and bottom of the spindle housing. The top bearing cup must contact the outer bearing spacer previously installed, and the bottom bearing cup must contact the snap ring. Make sure that the assembly is correct by supporting the first bearing cup and pressing the second cup against it (Fig 15).

4. Pack the bearing cones with grease. Apply a film of grease on lips of oil seals and O-ring.

5. Install lower bearing cone and oil seal into bottom of spindle housing. **Note:** The bottom seal must have the lip facing out (down) (Fig. 16). This seal installation allows grease to purge from the spindle during the lubrication process.

IMPORTANT: If bearings are being replaced, make sure to use the spacer ring that is included with new bearing set (Fig. 14).

6. Slide spacer ring and inner bearing spacer into spindle housing, then install upper bearing cone and oil seal into top of housing. **Note:** The upper seal must have the lip facing in (down) (Fig. 16). Also, upper seal should be flush or up to 0.060" (1.5 mm) recessed into housing.

7. Inspect the spindle shaft and shaft spacer to make sure there are no burrs or nicks that could possibly damage the oil seals. Lubricate the shaft and spacer with grease.

8. Install spindle shaft spacer onto shaft. Place thin sleeve or tape on spindle shaft splines to prevent seal damage during shaft installation.

9. Carefully slide spindle shaft with spacer up through spindle housing. The bottom oil seal and spindle spacer fit together when the spindle is fully installed.

10. Install O-ring to top of spindle shaft. For drive spindle, position hydraulic motor mount to top of spindle.

11. Install pulley (hub down), hardened washer and lock nut to spindle shaft. Tighten lock nut from **130 to 150 ft-lb (176 to 203 N-m)**.

IMPORTANT: Pneumatic grease guns can produce air pockets when filling large cavities and therefore, are not recommended to be used for proper greasing of spindle housings.

12. Attach a hand pump grease gun to grease fitting on housing and fill housing cavity with grease.

13. Rotate spindle shaft to make sure that it turns freely.




Figure 14

- | | |
|--------------------|-------------------------|
| 1. Bearing | 4. Inner bearing spacer |
| 2. Spacer ring | 5. Outer bearing spacer |
| 3. Large snap ring | |




Figure 15

- | | |
|-------------------------|---------------------|
| 1. Bearing cups | 4. Arbor press |
| 2. Large snap ring | 5. Support |
| 3. Outer bearing spacer | 6. Arbor press base |




Figure 16

- | | |
|-----------------------------|----------------------------|
| 1. Bottom seal installation | 2. Upper seal installation |
|-----------------------------|----------------------------|

Castor Forks and Wheels




Figure 17

- | | | |
|-----------------------------------|---|--------------------------|
| 1. Castor arm (center deck shown) | 13. Compression spring | 24. Inner bearing spacer |
| 2. Cap screw (5 used) | 14. Cap | 25. Wheel hub |
| 3. Castor fork | 15. Flat washer | 26. Wheel rim half |
| 4. Cap screw | 16. Lock nut (3 used per bracket) | 27. Castor tire |
| 5. Lock nut | 17. Carriage screw (3 used per bracket) | 28. Wheel rim half |
| 6. Castor spacer | 18. Castor fork bracket | 29. Plate |
| 7. Thrust washer | 19. Shim | 30. Flange nut |
| 8. Flange nut (5 used) | 20. Castor bracket | 31. Flat washer |
| 9. Grease fitting | 21. Hairpin | 32. Tension rod |
| 10. Flange bushing | 22. Cutting deck (RH shown) | 33. Flange nut |
| 11. Retaining ring | 23. Bearing | 34. Clevis pin |
| 12. Cap washer | | |

Disassembly

1. Disassemble castor wheel as needed using Figure 17 as a guide.

Assembly

1. Assemble castor wheel using Figure 17 as a guide.
2. If castor fork was removed, lubricate grease fitting.
3. Torque castor wheel lock nut (item 5) from **60 to 80 ft-lb (81 to 108 N-m)**.



Table of Contents

GENERAL INFORMATION	2
Operator's Manual	2
Electrical Components and Schematic	2
Air Conditioning System	2
Cab Heater System	2
SERVICE AND REPAIRS	3
General Precautions for Removing and Installing	
Air Conditioning System Components	3
Air Conditioning Compressor	4
Roof Assembly	6
Air Conditioning Condenser Assembly	8
Heater/Evaporator Assembly	10
Windshield Wiper	12
SANDEN SD COMPRESSOR SERVICE GUIDE	

General Information

The information in this chapter pertains to the operator cab on the Groundsmaster 4010-D.

Operator's Manual

The Operator's Manual provides information regarding the operation, general maintenance and maintenance intervals for your Groundsmaster. Refer to the Operator's Manual for additional information when servicing the machine.

Electrical Components and Schematic

Information regarding Groundsmaster 4010-D electrical cab components (switches and relay) is included in Chapter 5 - Electrical System. The electrical schematic and wire harness drawings for the operator cab are included in Chapter 10 - Foldout Drawings.

Air Conditioning System

The air conditioning system used on the Groundsmaster 4010-D consists of the following components:

1. A compressor mounted on the engine and driven by a v-belt.
 2. A condenser and condenser fan located on the top of the cab.
 3. A drier-receiver, an expansion valve and an evaporator (combined with the heater core) mounted in the headliner of the cab.
 4. The necessary hoses and tubes that connect the system components.
 5. A fan motor that provides air movement through the evaporator and into the cab. The fan motor is located in the cab headliner and is also used for the cab heater system.
 6. Operator controls to turn the air conditioning on, to adjust the fan speed and to control the cab air temperature.
-

Cab Heater System

The cab heater system used on the Groundsmaster 4010-D consists of the following components:

1. A heater core (combined with the A/C evaporator) located in the cab headliner.
2. Hoses to allow a circuit for engine coolant to circulate through the heater core. The heater core (combined with the A/C evaporator) is located in the headliner of the cab.
3. A fan motor that provides air movement through the heater core and into the cab. The fan motor is located in the cab headliner and is also used for the air conditioning system.
4. Operator controls to adjust the fan speed and to control the cab air temperature.

Service and Repairs

General Precautions for Removing and Installing Air Conditioning System Components

 CAUTION
The air conditioning system is under high pressure. Do not loosen any system fitting or component until after the system has been completely discharged by a certified A/C service technician.

 WARNING
Always wear safety goggles or a face shield when working with air conditioning system components. Also, do not allow refrigerant contact with your skin or eyes as there would be the possibility of serious injury.

 CAUTION
Never use compressed air to leak test or pressure test the air conditioning system. Under certain conditions, pressurized mixtures of refrigerant and air can be combustible.

1. Before servicing any air conditioning system components, park machine on a level surface, apply parking brake, lower cutting decks or attachments and stop engine. Remove key from the ignition switch.
2. Clean machine before disconnecting, removing or disassembling any air conditioning system components. Thorough cleaning will prevent system contamination while performing service procedures.
3. Put caps or plugs on any lines, fittings or components left open or exposed to prevent system contamination.
4. Before loosening or removing any air conditioning system hose or other component, have a certified air conditioning service technician recover the system refrigerant and then evacuate the air conditioning system completely. It is illegal to vent refrigerant to the atmosphere.

5. Put labels on disconnected lines and hoses for proper installation after repairs are completed.

6. If compressor is removed from machine, keep compressor in the same orientation as the installed position. This will prevent compressor oil from filling the compressor cylinders.

7. Note the position of fittings (especially elbow fittings) before removal. Mark parts if necessary to make sure they will be aligned properly when reinstalling hoses and tubes.

8. Always use a DOT approved tank for storing used and recycled refrigerants.

9. The Groundsmaster 4010-D air conditioning system uses R134a refrigerant. DO NOT use other refrigerants in the system. A/C system capacity is 1.35 pounds of R134a refrigerant.

10. Refrigerant containers (either full or empty) are under pressure that will increase if the containers are heated. DO NOT expose refrigerant containers to high heat sources or flame.

11. Be sure the work area is properly ventilated to prevent any accumulation of refrigerant or other fumes.

12. Make sure that caps are always placed on the pressure hose ports. These caps prevent refrigerant leakage from the system.

13. The drier-receiver component is used to collect moisture that will reduce air conditioning performance. If the air conditioning system is opened for component repair or replacement, drier-receiver replacement is recommended.

14. After installing air conditioning components, have a certified air conditioning service technician evacuate the air conditioning system completely, properly recharge the system with R134a refrigerant and then leak test the system.

Air Conditioning Compressor




Figure 1

- | | | |
|-------------------------|--------------------------------|--------------------------------|
| 1. Cap screw (2 used) | 8. O-ring | 15. Exhaust pipe |
| 2. Flat washer (4 used) | 9. A/C compressor | 16. Flange nut |
| 3. Lock washer (6 used) | 10. Cap screw (4 used) | 17. Carriage screw |
| 4. Hex nut (2 used) | 11. Cap screw (2 used) | 18. Idler pulley |
| 5. Conduit | 12. A/C compressor mount | 19. Compressor drive belt |
| 6. O-ring (2 used) | 13. Flange head screw (2 used) | 20. Engine (model 30603 shown) |
| 7. 90° fitting | 14. Exhaust bracket | 21. Clamp assembly |

Removal (Fig. 1)

1. Park machine on a level surface, lower cutting decks, stop engine, engage parking brake and remove key from the ignition switch.

2. Raise hood to allow access to engine.

3. Remove exhaust pipe (item 15).

4. Loosen flange nut that secures idler pulley. Move pulley to loosen A/C compressor drive belt. Remove drive belt from A/C compressor pulley.

5. Inspect compressor drive belt for glazing or damage. Replace belt if necessary.

6. Disconnect compressor electrical connector from machine wire harness.

7. Read the General Precautions for Removing and Installing Air Conditioning System Components at the beginning of the Service and Repairs section of this chapter.

	CAUTION
<p>The air conditioning system is under high pressure. Do not loosen any system fitting or component until after the system has been completely discharged by a certified A/C service technician.</p>	

8. Have refrigerant evacuated from air conditioning system by a certified A/C service technician.

9. Label and remove hoses from compressor. Immediately cap hoses and fittings to prevent moisture and contaminants from entering the system.

10. Support compressor to prevent it from shifting or falling.

NOTE: There may be shims mounted between compressor and compressor mount. When removing compressor, note shim location and quantity for assembly purposes.

11. Remove fasteners and washers that secure compressor to compressor mount.

IMPORTANT: To prevent compressor oil from filling the compressor cylinders, keep compressor in the same orientation as the installed position.

12. Carefully remove compressor from engine and machine.

NOTE: The replacement of the drier-receiver is recommended whenever A/C compressor is removed from the system (see Heater and Evaporator Assembly in this section).

NOTE: The air conditioning compressor used on the Groundsmaster 4010-D is a Sanden model SD5H09. For air conditioning compressor repair procedures, see the Sanden SD Compressor Service Guide at the end of this chapter.

Installation (Fig. 1)

1. Position compressor to compressor mount on engine.

NOTE: The clearance between the compressor mounting flanges and compressor mount must be less than 0.004" (0.10 mm). If necessary, install shims between compressor flanges and mount to adjust clearance. See Compressor Parts Catalog for shim kit.

2. Secure compressor to compressor mount with removed fasteners and spacers. Do not fully tighten fasteners.

IMPORTANT: After the compressor has been installed, make sure to rotate the compressor drive shaft several times to properly distribute oil in the compressor. Compressor damage due to oil slugging can occur if this procedure is not performed.

3. Manually rotate the compressor drive shaft at least ten (10) revolutions to make sure that no compressor oil is in the compressor cylinders.

4. Place drive belt onto compressor pulley.

5. Tension compressor drive belt with idler pulley. Make sure to tighten flange nut to secure belt adjustment.

6. Install exhaust pipe (item 15).

7. Remove caps that were placed on hoses and fittings during the removal process. Using labels placed during removal, properly secure hoses to compressor.

8. Connect compressor electrical connector to machine wire harness.

9. Have a certified air conditioning service technician evacuate the air conditioning system completely, properly recharge the system with R134a refrigerant and then leak test the system. A/C system capacity is 1.35 pounds of R134a refrigerant.

10. Lower and secure hood.




Figure 2

- 1. A/C compressor
- 2. Alternator
- 3. A/C compressor mount

Roof Assembly




Figure 3

- | | | |
|---------------------------|-------------------------|-----------------------------|
| 1. Roof | 7. Panel nut | 12. Front spacer (2 used) |
| 2. Screw (2 used) | 8. Roof mount | 13. Front fastener (2 used) |
| 3. Flat washer (6 used) | 9. Flange nut (2 used) | 14. Rubber washer |
| 4. Bushing (10 used) | 10. Flange nut (4 used) | 15. Cap screw |
| 5. Rear fastener (2 used) | 11. Headliner | 16. Hex nut (4 used) |
| 6. Rear spacer (2 used) | | |

To gain access to the heater core and air conditioning components that are located under the cab roof, the roof panel can be loosened, raised and supported.

Removal (Fig. 3)

1. Park machine on a level surface, lower cutting decks, stop engine, engage parking brake and remove key from the ignition switch.

2. Remove screw (item 2), flat washer (item 3) and bushing (item 4) that secure the rear of the roof to the roof mount.

3. Remove the cap screw (item 15) and rubber washer (item 14) that secure the front of the roof.

4. Remove four (4) hex nuts (item 16), flat washers (item 3) and bushings (item 4) that secure roof to front and rear fasteners.

5. Carefully lift front of roof while leaving rear of roof against headliner. Support front of roof in the raised position to allow access to heater and air conditioning components.

Installation (Fig. 3)

1. Make sure that all components in headliner and roof are installed and secure.

2. Remove support and carefully lower roof into position.

3. Secure roof to headliner with all removed fasteners.




Figure 4

- 1. Condensation drain hose (2 used)
- 2. Heater valve
- 3. A/C hose: evaporator to compressor
- 4. Heater hose: heater valve to heater core
- 5. A/C hose: compressor to condenser
- 6. A/C hose: condenser to drier
- 7. Heater hose: thermostat to heater valve
- 8. Heater hose: heater core to water pump

Air Conditioning Condenser Assembly




Figure 5

- | | | |
|----------------------------|----------------------------|--------------------------------|
| 1. Condenser cover | 5. Carriage screw (2 used) | 8. Bushing (4 used) |
| 2. Lock nut (4 used) | 6. Flat washer (8 used) | 9. Mounting strap |
| 3. Condenser fan | 7. Roof | 10. Button head screw (4 used) |
| 4. Condenser coil assembly | | |

Removal (Fig. 5)

1. Park machine on a level surface, lower cutting decks, stop engine, engage parking brake and remove key from the ignition switch.
2. Remove fasteners that secure roof in place. Raise and support roof to allow access to condenser assembly (see Roof Assembly in this section).
3. Disconnect wire harness connector from condenser fan motor.
4. Remove button head screws (item 10) that secure condenser fan and cover to condenser coil.
5. Remove fasteners (items 2, 6 and 8) that secure front of condenser cover to roof. Lift condenser fan and cover from roof.

6. Read the General Precautions for Removing and Installing Air Conditioning System Components at the beginning of the Service and Repairs section of this chapter.


CAUTION

The air conditioning system is under high pressure. Do not loosen any system fitting or component until after the system has been completely discharged by a certified A/C service technician.

7. Have refrigerant evacuated from air conditioning system by a certified A/C service technician.

8. Label and remove hoses from condenser coil. Immediately cap hoses and fittings to prevent moisture and contaminants from entering the system.

9. Remove condenser coil from roof using Figure 6 as a guide.

NOTE: The replacement of the drier-receiver is recommended whenever the air conditioning system is opened (see Heater/Evaporator in this section).

Installation (Fig. 5)

1. Install condenser coil to roof using Figure 6 as a guide.

2. Remove caps that were placed on hoses and fittings during the removal process. Using labels placed during removal, properly secure hoses to condenser coil.

3. Position condenser cover and condenser fan to roof. Secure cover and fan with removed fasteners (items 2, 6 and 8).

4. Secure condenser fan to condenser coil with button head screws (item 10).

5. Connect wire harness connector to condenser fan motor.

6. Make sure that all machine air conditioning components are installed and secure.

7. Have a certified air conditioning service technician evacuate the air conditioning system completely, properly recharge the system with R134a refrigerant and then leak test the system. A/C system capacity is 1.35 pounds of R134a refrigerant.

8. Lower and secure roof assembly (see Roof Assembly in this section).




Figure 6

- | | |
|----------------------------|------------------------------|
| 1. Bushing (4 used) | 12. Tray foam |
| 2. Condenser coil | 13. Screen frame |
| 3. Fan shroud | 14. End foam (2 used) |
| 4. Condenser fan | 15. Screen |
| 5. Isolator mount (4 used) | 16. Side foam (2 used) |
| 6. Coupler nut (4 used) | 17. Lock nut |
| 7. Screw (4 used) | 18. Latch plate |
| 8. Screw (4 used) | 19. Friction washer (2 used) |
| 9. Screw (4 used) | 20. Latch spacer |
| 10. Flat washer (4 used) | 21. Carriage screw |
| 11. Clip (4 used) | |

Heater/Evaporator Assembly




Figure 7

- | | | |
|-------------------------------|----------------------------|-------------------------|
| 1. Heater/evaporator assembly | 7. Speed nut (8 used) | 12. Blower fan assembly |
| 2. Top cover | 8. Panel nut (4 used) | 13. Expansion valve |
| 3. Flange head screw (2 used) | 9. Drier-receiver assembly | 14. Freeze switch |
| 4. Drier-receiver mount | 10. Screw (8 used) | 15. Screw (2 used) |
| 5. Bottom cover | 11. Screw (4 used) | 16. Screw (12 used) |
| 6. Hose clamp (2 used) | | |

Removal (Fig. 7)

1. Park machine on a level surface, lower cutting decks, stop engine, engage parking brake and remove key from the ignition switch.

2. Remove fasteners that secure roof in place. Raise and support roof to allow access to heater/evaporator assembly (see Roof Assembly in this section).

3. Disconnect wire harness connectors from fan motor and binary switch on drier-receiver.

4. Read the General Precautions for Removing and Installing Air Conditioning System Components at the beginning of the Service and Repairs section of this chapter.



5. Have refrigerant evacuated from air conditioning system by a certified A/C service technician.

6. Label and remove hoses from heater core, evaporator and drier-receiver. Immediately cap hoses and fittings to prevent moisture and contaminants from entering the system.

7. Loosen hose clamp that secures air duct hose to heater/evaporator assembly covers. Slide hose from covers.

8. Remove screws that secure top cover to bottom cover. Remove top cover to access heater/evaporator assembly.

9. Disassemble heater/evaporator assembly using Fig. 7 as a guide.

10. If necessary, remove fan resistor from blower fan assembly (Fig. 9).

NOTE: The replacement of the drier-receiver is recommended whenever the air conditioning system is opened.

Installation (Fig. 7)

1. Assemble heater/evaporator assembly using Fig. 7 as a guide. Make sure that expansion valve is covered with insulating tape to prevent condensation issues.

2. If removed, secure fan resistor to blower fan assembly (Fig. 9).

3. Position heater/evaporator assembly into bottom cover in headliner. Secure top cover to bottom cover with removed screws.

4. Slide air duct hose onto heater/evaporator assembly covers and secure with hose clamp.

5. Remove caps that were placed on hoses and fittings during the removal process. Using labels placed during removal, properly secure hoses to heater core, evaporator and drier-receiver.

6. Make sure that condensation hoses are secured to bottom housing of heater/evaporator assembly and are routed to cab frame for proper draining of condensate.

7. Connect wire harness connectors to fan motor and binary switch on drier-receiver.

8. Make sure that all machine air conditioning components are installed and secure.

9. Have a certified air conditioning service technician evacuate the air conditioning system completely, properly recharge the system with R134a refrigerant and then leak test the system. A/C system capacity is 1.35 pounds of R134a refrigerant.

10. Operate the heater system to make sure that no engine coolant leaks exist.

11. Lower and secure roof assembly (see Roof Assembly in this section).




Figure 8

- 1. Condensation drain hose (2 used)
- 2. Heater valve
- 3. A/C hose: evaporator to compressor
- 4. Heater hose: heater valve to heater core
- 5. A/C hose: compressor to condenser
- 6. A/C hose: condenser to drier
- 7. Heater hose: thermostat to heater valve
- 8. Heater hose: heater core to water pump




Figure 9

- 1. Fan resistor
- 2. Blower fan assembly
- 3. Clamp
- 4. Screw (2 used)

Windshield Wiper




Figure 10

- 1. Wiper motor
- 2. Gasket
- 3. Linkage bracket
- 4. Lock washer
- 5. Cap screw

- 6. Cap (2 used)
- 7. Washer
- 8. Nut
- 9. Flange nut (2 used)

- 10. Cover (2 used)
- 11. Wiper arm assembly
- 12. Wiper blade
- 13. Screw (2 used)

Disassembly (Fig. 10)

1. Park machine on a level surface, lower cutting decks, stop engine, engage parking brake and remove key from the ignition switch.
2. If access to wiper motor is necessary, remove fasteners that secure roof in place. Raise and support roof to allow access to condenser assembly (see Roof Assembly in this section).
3. Remove windshield wiper components as needed using Figure 10 as a guide.

Assembly (Fig. 10)

1. Assemble windshield wiper components using Figure 10 as a guide.
2. If roof was raised, lower and secure roof assembly (see Roof Assembly in this section).

This page is intentionally blank.



Table of Contents

ELECTRICAL DRAWING DESIGNATIONS 2
HYDRAULIC SCHEMATIC 3
ELECTRICAL SCHEMATICS
 Models 30605 and 30603 4
 Models 30609 and 30607 5
 Operator Cab 6
 International Light Kits 7
WIRE HARNESS DRAWINGS
 Platform Wire Harness Drawing 9
 Rear Wire Harness Drawing 12
 Engine Wire Harness Drawing (Models 30609
 and 30607) 14
 Engine Wire Harness Drawing (Models 30605
 and 30603) 16
 Operator Cab Wire Harness Drawing 18
 Operator Cab Interconnect Wire Harness
 Drawing 20

Electrical Drawing Designations


The following abbreviations are used for wire harness colors on the electrical schematics and wire harness drawings in this chapter.

<u>ABBREVIATION</u>	<u>COLOR</u>
BK	BLACK
BR or BN	BROWN
BU	BLUE
GN	GREEN
GY	GRAY
OR	ORANGE
PK	PINK
R or RD	RED
T	TAN
VIO	VIOLET
W or WH	WHITE
Y or YE	YELLOW

Numerous harness wires used on Groundsmaster 4000 and 4010 machines include a line with an alternate color. These wires are identified with the wire color and line color with either a / or _ separating the color abbreviations listed above (e.g. R/BK is a red wire with a black line, OR_BK is an orange wire with a black line).

NOTE: The electrical harness drawings in this chapter identify both the wire color and the wire gauge. For example, 16 BK on a harness diagram identifies a 16 gauge wire that has a black insulator.

NOTE: A splice used in a wire harness will be identified on the wire harness diagram by SP. The manufacturing number of the splice is also identified on the wire harness diagram (e.g. SP01 is splice number 1).




1. FLOWS SHOWN ARE CALCULATED AT HIGH IDLE AND 95% PUMP EFFICIENCY UNLESS OTHERWISE NOTED

Groundsmaster 4000-D/4010-D Hydraulic Schematic

Groundmaster 4000-D/4010-D
Models 30605 and 30603
Electrical Schematic


All relays and solenoids
are shown as de-energized.
All ground wires are black.



Groundsmaster 400-D/4010-D Models 30609 and 30607 Electrical Schematic


All relays and solenoids are shown as de-energized.
All ground wires are black.

NOTE: WHEN A WIRE FROM THIS SCHEMATIC CONTINUES TO THE OPERATOR CAB, A REFERENCE NUMBER WILL BE LISTED. THE CAB SCHEMATIC WILL ALSO INCLUDE THE REFERENCE NUMBER.



NOTE: REFER TO ELECTRICAL DRAWING DESIGNATIONS IN THIS CHAPTER FOR WIRE COLOR ABBREVIATIONS.

NOTE: REFER TO ELECTRICAL DRAWING DESIGNATIONS IN THIS CHAPTER FOR WIRE COLOR ABBREVIATIONS.




**Groundsmaster 4010-D
Operator Cab (shown with lights for US model)
Electrical Schematic**

All relays and solenoids are shown as de-energized.

All ground wires are black.

NOTE: THE OPERATOR CAB SCHEMATIC SHOULD BE USED WITH THE ELECTRICAL SCHEMATIC FOR THE APPROPRIATE MODEL NUMBER WHICH IS ON A SEPARATE PAGE. WHEN A WIRE FROM THIS CAB SCHEMATIC CONTINUES TO THE MACHINE SCHEMATIC, A REFERENCE NUMBER WILL BE LISTED.

NOTE: REFER TO ELECTRICAL DRAWING DESIGNATIONS IN THIS CHAPTER FOR WIRE COLOR ABBREVIATIONS.




Groundsmaster 4010-D
International Light Kits
Electrical Schematic

All relays and solenoids
are shown as de-energized.
All ground wires are black.


NOTE: THE OPERATOR CAB SCHEMATIC SHOULD BE USED WITH THE ELECTRICAL SCHEMATIC FOR THE APPROPRIATE MODEL NUMBER WHICH IS ON A SEPARATE PAGE. WHEN A WIRE FROM THIS CAB SCHEMATIC CONTINUES TO THE MACHINE SCHEMATIC, A REFERENCE NUMBER WILL BE LISTED.

This page is intentionally blank.



Groundsmaster 4000-D/4010-D
Platform Wire Harness Drawing


NOTE: THIS DRAWING IDENTIFIES WIRE GAUGE SIZE AND WIRE COLOR. REFER TO ELECTRICAL DRAWING DESIGNATIONS IN THIS CHAPTER FOR ADDITIONAL INFORMATION.



**Groundmaster 4000-D/4010-D
Platform Wire Harness Diagram
Sheet 1 of 2**


NOTE: THE PLATFORM WIRE HARNESS DIAGRAM IS SHOWN ON TWO (2) SHEETS. WHEN A CONDUCTOR CONTINUES ON ANOTHER SHEET, A REFERENCE NUMBER WILL BE IDENTIFIED.

NOTE: THIS DRAWING IDENTIFIES WIRE GAUGE SIZE AND WIRE COLOR. REFER TO ELECTRICAL DRAWING DESIGNATIONS IN THIS CHAPTER FOR ADDITIONAL INFORMATION.




**Groundsmaster 4000-D/4010-D
Platform Wire Harness Diagram
Sheet 2 of 2**


NOTE: THE PLATFORM WIRE HARNESS DIAGRAM IS SHOWN ON TWO (2) SHEETS. WHEN A CONDUCTOR CONTINUES ON ANOTHER SHEET, A REFERENCE NUMBER WILL BE IDENTIFIED.




Groundsmaster 4000-D/4010-D
Rear Wire Harness Drawing




Groundsmaster 4000-D/4010-D
Rear Wire Harness Diagram




Groundsmaster 4000-D/4010-D
 Models 30609 and 30607
 Engine Wire Harness Drawing




Groundsmaster 4000-D/4010-D
Models 30609 and 30607
Engine Wire Harness Diagram




Groundsmaster 4000-D/4010-D
 Models 30605 and 30603
Engine Wire Harness Drawing





Groundsmaster 4000-D/4010-D
Models 30605 and 30603
Engine Wire Harness Diagram



Groundsmaster 4010-D
Operator Cab Wire Harness Drawing



Groundsmaster 4010-D
Operator Cab Wire Harness Diagram



NOTE: THIS DRAWING IDENTIFIES WIRE GAUGE SIZE AND WIRE COLOR. REFER TO ELECTRICAL DRAWING DESIGNATIONS IN THIS CHAPTER FOR ADDITIONAL INFORMATION.