

Tranzeo TR-MX50-15

Quick Start Guide

Revision	1.0
Firmware	TR-MX50-15-0.1.4
Date	2014-09-24

Tranzeo Wireless Technologies Inc.

19473 Fraser Way
Pitt Meadows, BC
Canada V3Y 2V4

Contact Information

Toll Free Number	1.866.872.6936	General Inquiries	info@tranzeo.com
Technical Support	1.888.460.6366	Sales	sales@tranzeo.com
Local Number	1.604.460.6002	Technical Support	support@tranzeo.com
Fax Number	1.604.460.6005	Training	training@tranzeo.com

Website

Additional product information and support details are available on our web site:

<http://www.tranzeo.com>

About Tranzeo Wireless Technologies Inc TM

Tranzeo Wireless Technologies Inc. leads the wireless broadband industry for value, by producing high-performance wireless network equipment with a low cost of ownership and unparalleled service allowing communities and businesses to communicate without boundaries. Since the company's inception in 2000, Tranzeo's optimum cost effectiveness, premium quality and responsive support have attracted a growing number of devoted dealers and distributors worldwide.

Copyright

This document contains information, which is protected by copyright. Reproduction, adaptation, or translation without prior permission is prohibited, except as allowed under the copyright laws.

© Copyright 2014 Tranzeo Wireless Technologies Inc.

All Rights Reserved.

Feedback

Please direct any comments or suggestions about this document to: sales@tranzeo.com

Trademark Information

Tranzeo® is a registered trademark of Tranzeo Wireless Technologies Inc.

Disclaimer

Tranzeo Wireless Technologies Inc provides this manual without warranty of any kind, expressed or implied, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. Tranzeo Wireless Technologies Inc may make improvements and/or changes to the product and/or specifications of the product described in this manual, without prior notice. Tranzeo Wireless Technologies Inc will not be liable for any technical inaccuracies or typographical errors found in this guide. Changes are periodically made to the information contained herein and will be incorporated into later versions of the manual. The information contained is subject to change without prior notice.

Safety Information

FCC Compliance

This device has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the device is operated in a residential environment. This device generates, uses, and can radiate radio frequency energy. If not installed and used in accordance with the user guide, may cause harmful interference to radio communication. In case of harmful interference, the users will be required to correct the interference at their own expense.

The users should not modify or change this device without written approval from Tranzeo Wireless Technologies. Modification will void warranty and authority to use the device.

For safety reasons, people should not work in a situation where RF exposure limits could be exceeded. To prevent this situation, the users should consider the following rules:

- Install the antenna so that there is a minimum of 100cm (39.37”) of distance between the antenna and people.
- Do not turn on power to the device while installing the antenna.
- Do not connect the antenna while the device is in operation.
- Do not collocate or operate the antenna used with the device in conjunction with any other antenna or transmitter.

Industry Canada Compliance

Operation of this device is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Table of Contents

TR-MX50-15 OVERVIEW.....	7
Introduction	7
Applications	8
Key Features.....	8
Product Kit.....	9
Product Description	9
TR-MX50-15 Mounting	10
Led Information	11
OPERATING MODES	12
Access Point and Access Point WDS Mode.....	12
Access Point WDS Mode	12
Station Mode	13
Station WDS Mode.....	14
Router Mode.....	14
TR-MX50-15 QUICK INSTALL GUIDE.....	17
Installing the Ethernet Cable into the TR-MX50-15	17
TR-MX50-15 CONFIGURATION	21
MAIN MENU.....	21
Save Changes	21
STATUS.....	22
WIRELESS SETTINGS	24
WIRELESS MODES	25
NETWORK	27
LAN SETTINGS	27
SYSTEM	28
FIRMWARE UPGRADES	28
LED INTERPRETATION	29
WARRANTY	30
Limited Warranty	30
Warranty Conditions.....	30

SPECIFICATIONS31

TR-MX50-15 OVERVIEW

Introduction

TR-MX50-15 is an all-in-One AP/WDS/CPE device. Tranzeo's TR-MX50-15 series of wireless LAN products are IEEE 802.11b/g/n compliant, operate in the license-free 2.4GHz frequency band, and support data rates of up to 150 Mbps. The versatile multi-mode design supports both AP and CPE modes, as-well-as WDS and Bridge modes. It also features advanced networking and management capabilities including WEP/WPA/WPA2 security, WMM QoS, and NAT Routing.

The TR-MX50-15 offers new options such as up to 4 Virtual Access Points, VLANs, narrow channels, and Layer 2 transparent Bridging.

The compact TR-MX50-15 design features a high performance radio with up to +24 dBm output power. The all-in-one design comes complete with a passive PoE injector and DC adaptor, requiring a single CAT5 cable for power and data, yielding the lowest cost of ownership.

The TR-MX50-15 also features a weather-resistant enclosure that is compliant with the IP55 environmental standards, requiring minimal installation and maintenance costs in conditions ranging from -50° C to +60° C. The TR-MX50-15 family of products is also backed by a 1-Year Parts and Labor Warranty and Tranzeo's unparalleled Lifetime Technical Support for worry-free network operation.

It is PoE powered, which allows the radio to be used in areas where power outlets are not readily available. It also simplifies the installation by requiring a single Cat5e cable for supplying power and carrying data.


The access point also incorporates a unique set of advanced features such as: up to 4 Virtual AP's to deliver multiple services; long-range parameter fine-tuning which provide the access point with the ability to auto-calculate parameters such as slot time, ACK time-out and CTS time-out to maximize range.

Applications

Example applications for TR-MX50-15

Remote Data Acquisition	Internet Service (WISP)	Video Transmission
Security and Surveillance	Private Networks	Wi-Fi Hotspots
Building to Building (P2P)	Marinas / RV /Parks	Hotels

WISP network



Key Features

These are the main features of the TR- MX50-15:

- IEEE 802.11a/n Compliant
- Operates in 5.2 & 5.8 GHz band
- Integrated 15dBm Antenna
- 2 x 2 MIMO support
- Dual Ethernet ports
- AP/CPE/WDS/Bridge/Router Modes
- Up to 300 Mbps Data Rate
- +26dBm Transmit Power with Adjustable Output
- 20/40 MHz Channels
- Antenna Alignment LED's
- WEP/WPA/WPA2 Security and WMM QoS
- NAT Routing, VPN Pass-Through
- Traffic Shaping
- Power-over-Ethernet (PoE)
- HTTP/HTTPS Web Based Management Tools


Product Kit

The TR-MX50-15 Series product kit contains the items shown below. If any item is missing or damaged, contact your local dealer for support.



Product Description

The LED indicators, dual Ethernet ports, and the RESET button, are all located on the inside of the plastic cover, as shown in the picture.




TR-MX50-15 Mounting



Model	Package Contents
TR-MX50-15	TR-MX50-15 Radio, POE, Power Adaptor, Pole Mounting Straps (TR-MX50-15 Package)

Led Information

The LEDs will aid in antenna alignment and indicate link status, using the information below.


LED #	LED INDICATION	DESCRIPTION	
1	POWER LED	ON	Power is supplied to TR-EZ-2-N
		OFF	No power is supplied to TR-EZ-2-N
2	ETHERNET LINK	ON	Ethernet connection is established
		OFF	No Ethernet Connection is established
3	WIRELESS LINK	ON	Wireless link established
		OFF	No Wireless Link
4	SIGNAL STRENGTH (RSSI)		
5			
6			
		LED #	[1] [2] [3] [4] [5] [6]

The RSSI values are indicated by LED 4, LED 5 and LED 6 (See [LED INTERPRETATION](#) section)

OPERATING MODES

Access Point and Access Point WDS Mode

The Access Point Mode is the default mode of the device. It enables the bridging of wireless clients to wired network infrastructure and enables transparent access and communication with each other. The illustration below shows a typical resources sharing application example using this device. The wireless users are able to access the file server connected to the switch, through the access point in Access Point Mode.



Access Point WDS Mode


This mode is generally used for point-to-point or point-to-multi-point connections. It is mainly used with Station WDS to build the point and multi-point connections.

Station Mode

In **Station** mode the device acts as a wireless client.

When connected to an access point, it creates a network link between the Ethernet network connected at this client device, and the wireless Ethernet network connected at the access point.

In this example the workgroup PCs on the Ethernet network connected to the Station device can access the printer across the wireless connection to the access point where the printer is connected.




Station WDS Mode

Station WDS mode is similar to Station mode. The difference is Station WDS must connect to access point configured to Access Point WDS (or RootAP) mode.

Station WDS is mainly use for point-to-point connection between 2 buildings or locations as far as several kilometer away.

Point-to-Point	Point-to-MultiPoint
An access point setup as Access Point WDS (or RootAP) and other as Station WDS (Transparent Client).	An access point setup as Access Point WDS (or RootAP) and several other devices as Station WDS (or Transparent Client).

This mode is generally used for outdoor connections over long distances, or for indoor connections between local networks.



Router Mode


In Router Mode, the device also operates as a router.

Either the wireless or Ethernet can be setup as WAN connection to a broadband modem. Wireless as WAN is known as **Station + Router mode** (or **Wireless Routing Client mode**) and Ethernet as WAN is known as **AP + Router mode** (or **Gateway mode**). Device supports both types of broadband connections Static IP and dynamic IP. For setup details refer to the respective section.


The illustration below shows the Ethernet port is setup as the WAN port and the wireless connection as the LAN.

Station + Router connection example

**Wireless is use to connect to the broadband.
Ethernet is the local network (LAN)
sharing the broadband connection.**



AP + Router connection example
 Ethernet is use to connect to the broadband.
 Wireless is the local network (LAN)
 sharing the broadband connection.



Broadband Internet Access Type:

Static IP Address

Use Static IP Address you have subscribed a fixed IP or range IP addresses from your ISP.

Dynamic IP Address

With Dynamic IP Address the device automatically request IP address from modem or ISP.

PPP over Ethernet (PPPoE)

When using ADSL services provided by your ISP support PPPoE connection.


TR-MX50-15 QUICK INSTALL GUIDE

Installing the Ethernet Cable into the TR-MX50-15

Install using straight through Ethernet cables

Summary Steps

1.	Remove Bottom Cover as described above
2.	Connect a PC/laptop to Ethernet/LAN port of the POE
3.	Connect an Ethernet cable from the powered RJ45 POE port to TR-MX50-15
4.	Power the POE unit with the supplied power adaptor (connect only to a grounded outlet)
5.	Configure PC with a static IP address in the same subnet of the TR-MX50-15 (192.168.1.x) like 192.168.1.101
6.	From a web browser, connect to the configuration page http://192.168.1.100 (username/password as below)




Step 1:

Hold unit with release tabs facing up and the cover away from you.

Push down release tab at one end and pull away that corner with the other hand, just over the catch clip, leaving about a 2mm gap. Do the same on the other end and the cover can be pulled off easily to reveal the dual Ethernet ports and Reset pin. Ensure that the black cable inserts remain in place and do not fall out.

Mount the TR-MX50-15 on a suitable pole with the supplied straps as shown



Step 2:


Connect an Ethernet cable from the PC/Laptop to the PC connector on the POE LAN port.

Step 3:

Connect an Ethernet cable from the TR-MX50-15 unit to the POE port on the POE..

Step 4:

Power the POE unit with the supplied cord, and ensure power source has earth pin.



Step 4:

Connect a PC to the “LAN” Port of the POE, with a straight through Ethernet cable.

Note: Connect the radio to the “POE” port and the “LAN” port to PC/switch/router.


Step 5

Connecting to the TR-MX50-15 AP


Before accessing the configuration interface, you have to change the network connection settings in your computer to be on the same subnet as the radio. Alternatively, you could use the Victor Utility program to assign the radio a temporary IP alias that is on the same subnet as your computer.

Changing the IP Address - Windows 7


1. In your computer, open Control Panel > Network and Sharing Center then click change adaptor settings on the left hand menu. Select and right click the Local Area Connection icon.



2. Select and right click the Local Area Connection icon. Then click **Properties**.
3. In Local Area Connection Properties > Networking tab, select **Internet Protocol Version 4 (TCP/IP)** and click **Properties**.



4. In Internet Protocol (TCP/IP) Properties > General, select **Use the following IP address**.
5. Enter your **IP address** and **Subnet Mask (255.255.255.0)**. The default IP address of the radio is **192.168.1.100**, which cannot be used here. Use anything else in the same subnet like **192.168.1.101** for example.



6. Click **OK** and **Close**

Step 6

Web Configuration Page Access

Configuration of TR-MX50-15 features and options are accessible via the web page.

1. Open your Internet browser (such as Internet Explorer, Chrome, or Firefox).
2. In the address bar, type your IP address (default IP: <http://192.168.1.100>).
3. In the login dialog, enter your **Username** and **Password**.
4. Click **OK**. You will then access the configuration interface.

Setup and Configuration via Web GUI


Default IP Address	192.168.1.100
Default Username	admin
Default Password	default

TR-MX50-15 CONFIGURATION

Full comprehensive features are covered in the TR-MX50-15 User guide. These configurations pages serve as a quick start setup guide.

MAIN MENU

The top level main menu allows access to the Wireless, Network and System detail configuration options.



STATUS: Current device status and statistical information.


WIRELESS: Basic wireless network interface settings including operating mode, and security options.

NETWORK: Basic network interface including IP mode, IP settings, and DHCP server settings.

SYSTEM: System maintenance services including administrator account management, firmware upgrades, and backup/restore system configuration.

Save Changes

You need to apply changes to each page before navigating to another page; otherwise changes on the last page will be lost. When all the changes have been made and applied, then press Save to permanently save changes to flash, or click Discard to discard all changes.



STATUS

After successfully logging into the TR-MX50-15, the STATUS page will then be displayed. You could also navigate back to the STATUS page by clicking STATUS on the menu bar. The STATUS page displays a summary of the basic device configuration, network settings, current link status, and traffic statistics for all interfaces.

Status
Wireless
Network
System
Logout
Changes: 0

Overview
Firewall
Routes
Network Stats
Wireless List
Wireless Stats
System
System Log
Kernel Log

Realtime Graphs

Status Auto Refresh: on

Wireless

802.11bgn Wireless Controller	Device: wlan1_1 Mode: Access Point SSID: support-EZ2 MAC-Address: 00:C0:CA:7E:02:8A Channel: 6 (2.437 GHz) Noise: -102 dBm Encryption: WPA2 PSK (CCMP) Link Status: 2 client(s)
-------------------------------	--

Network

IP LAN Status	Device: br-lan Type: dhcp Address: 192.168.123.136 Netmask: 255.255.255.0 Gateway: 192.168.123.1 DNS 1: 192.168.123.75 DNS 2: 192.168.123.81 Connected: 5d 23h 43m 47s
Active Connections	<div style="border: 1px solid #ccc; display: inline-block; padding: 2px 10px;">20 / 16384 (0%)</div>
Ethernet	Device: eth0 MAC-Address: 00:C0:CA:7E:02:88 Link Status: linked Link Mode: 100Mb/s, Full, auto

System

Hostname	support-EZ2
Model	Tranzeo EZ2
Firmware Name	TR-EZ2-0.1.3
Build Date	2014/09/02 13:35
Kernel Version	3.10.49
Boot Loader	U-Boot 1.1.4--LSDK-9.5.5.36 (Jul 25 2014 - 09:54:44)
Local Time	Tue Sep 9 09:55:18 2014
Uptime	5d 23h 44m 32s

WIRELESS

Device:	Wireless LAN name
Mode:	Displays the current operating mode of the device.
SSID:	Displays the current SSID (Service Set Identifier) of device when operating in access point mode.
Channel:	Displays selected channel and operating frequency running in device.
MAC-Address:	Displays the MAC address or BSSID of the current active WLAN card running in device.
Noise:	Displays Noise Level in dBm
Encryption:	Display the current active security mode. WEP/WPA/WPA-2
Link Status:	Displays number of active clients

NETWORK


Device:	Ethernet LAN Name
Type:	Displays the mode used, either static or DHCP client.
Address:	Displays the current IP address of the LAN (Ethernet) interface.
Netmask:	Displays the Netmask of the gateway used in LAN.
Gateway:	Displays the IP address of the gateway used in LAN.
DNS 1:	Displays the Primary DNS IP address of the LAN setting.
DNS 2:	Displays the Secondary DNS IP address of the LAN setting.
Connected:	Displays time duration LAN has been connected.

SYSTEM

Uptime :	Displays device up time since boot up. The time is expressed in days, hours, minutes and seconds.
Host Name:	Displays the assigned device host name (ID).
System Time:	Display device current date and time. Accurate system date and time is retrieved from the internet services using NTP (Network Time Protocol) if device is setup and connected to internet. Otherwise, the date and time update from device own autonomous clock. NTP will be far more accurate.
Firmware Version:	Displays current firmware version in operation.
Boot Loader:	Displays current boot loader version of the device.


WIRELESS SETTINGS

This page displays the wireless configuration of the device. The contents are slightly different for access point and client modes. Use the WIF1 tab to set up the main AP, and click the General Setup button.



The screenshot shows the TRANZEO web interface. At the top right, it displays: **Device: support-EZ2 / Mode: Bridge** and **Wireless: 802.11gn / Mode: Access Point**. The navigation menu includes Status, **Wireless**, Network, System, and Logout. The 'Wireless' section is active, showing 'Overview' and 'WiFi1' tabs. The 'WiFi1' tab is selected, displaying the 'Wireless Interface' configuration page. The page has an 'Auto Refresh: on' indicator. A descriptive paragraph states: 'The *Device Configuration* section covers physical settings of the radio hardware such as channel, transmit power or antenna selection which is shared among all defined wireless networks (if the radio hardware is multi-SSID capable). Per network settings like encryption or operation mode are grouped in the *Interface Configuration*.' The 'Device Configuration' section has two tabs: 'General Setup' (selected) and 'Advanced Settings'. Under 'General Setup', the 'Status' is 'Access Point'. Other settings include: SSID: support-EZ2, MAC-Address: 00:C0:CA:7E:02:8A, Channel: 6 (2.437 GHz), Noise: -102 dBm, Encryption: WPA2 PSK (CCMP), Tx-Power: 23 dBm, and Country: US. A list of settings includes: 'Enable the Radio' (checked), 'Mode' (802.11gn), 'Bandwidth' (20MHz), 'Channel' (6 (2.437 GHz)), 'Transmit Power Cap' (30 dBm (1000 mW)), and 'Distance Optimization' (empty field with a help icon and text: 'Distance to farthest network member in meters.').


SSID and mode can be setup from the General Setup tab



The screenshot shows the 'Interface Configuration' section of the TRANZEO web interface. It has three tabs: 'General Setup' (selected), 'Wireless Security', and 'MAC-Filter'. Under 'General Setup', the 'Enable the Interface' is checked. The 'ESSID' is set to 'support-EZ2' and the 'Mode' is set to 'Access Point'. Other settings include: 'Hide ESSID' (unchecked), 'WMM Mode' (checked), 'Short Preamble' (checked), 'Isolate Clients' (checked with a help icon and text: 'Isolate wireless clients from each other'), and 'DTIM' (empty field with a help icon and text: 'Default 2; Range 1 - 255').

WIRELESS MODES

There are 4 modes available. Selected from the General setup tab in the Interfaces group.



Access Point

This mode is the default mode and enables wireless client to be connected to this AP, and then forwards all the traffic to the network devices connected to the Ethernet devices of the Station.

Access Point (WDS)

This mode can be connected to Client WDS mode. Using WDS protocol, it allows a client or station device to bridge wireless traffic transparently.

Client Mode

This is a client mode that can be connected to an Access Point mode. It is used to bridge the wireless connection to an Access Point. It forwards all the traffic to/from the network devices to the Ethernet interface. This mode translates all the packets that pass through device to its own MAC address, thus resulting in a lack of transparency.

Client (WDS) Mode


WDS is the acronym of Wireless Distribution System. It can be connected to the Access Point WDS mode. It enables packet forwarding at layer 2 level. Unlike Client mode, it is fully transparent at layer 2 level.

****Note:** for Client WDS, and Access Point WDS

WDS protocol used is not clearly defined within the standards, thus compatibility issues between equipment from different vendors will arise.

WIRELESS SECURITY

All the wireless security settings are set under this section.
The operation of the Keys is the same for ALL the Wireless modes.



The screenshot shows the 'Interface Configuration' window with the 'Wireless Security' tab selected. The configuration options are as follows:

Setting	Value
Encryption	WPA2-PSK
Cipher	CCMP (AES)
Group Rekey Interval in seconds	3600
Key

PSK (Default) – WPA or WPA2 with Pre-shared Key method cipher

TKIP - Temporal Key Integrity Protocol which uses RC4 encryption algorithm.

CCMP (AES) - Advanced Encryption Standard CCMP (AES) algorithm.

AUTO (Default) – Automatically select between both algorithms.

Preshared Key

This option is available when WPA or WPA2, with PSK selected.

The pre-shared key is an alpha-numeric password between 8 and 63 characters long.

*** Important:


802.11n network using WPA authentication should use AES cipher type for connection.

Only AES allows highest transmission speed and throughput operation.

Using WPA-TKIP cipher type device will limit maximum transmission speed of up to 54Mbps only

NETWORK

View network status, and set DHCP, DNS and LAN parameters from this tab when EDIT is clicked.




The screenshot shows the TRANZEO web interface. At the top right, it displays 'Device: support-EZ2 / Mode: Bridge' and 'Wireless: 802.11bgn / Mode: Access Point'. Below the navigation tabs (Status, Wireless, Network, System, Logout), the 'Network' tab is active. Underneath, there are sub-tabs for 'Interfaces', 'Traffic Shaping', and 'Diagnostics'. The 'Interfaces' sub-tab is selected, showing an 'Interface Overview' table. The table has three columns: Network, Status, and Actions. The 'LAN' interface is highlighted in green. Its status shows 'Uptime: 6d 3h 30m 6s', 'MAC-Address: 00:C0:CA:7E:02:88', 'Protocol: dhcp', 'IP-Address: 192.168.123.136/24', 'RX: 435.38 MB (5056639 Pkts.)', and 'TX: 764.25 MB (2083912 Pkts.)'. There are 'Reconnect' and 'Edit' buttons in the Actions column. A 'Switch to Router mode' button is located at the bottom left of the overview section.

Set DHCP, DNS and Gateway information from the Interfaces tab

LAN SETTINGS

Set the LAN network parameters from here.




The screenshot shows the TRANZEO web interface for configuring LAN settings. At the top right, it displays 'Device: support-EZ2 / Mode: Bridge' and 'Wireless: 802.11bgn / Mode: Access Point'. Below the navigation tabs, the 'Network' tab is active. Underneath, there are sub-tabs for 'Interfaces', 'Traffic Shaping', and 'Diagnostics'. The 'Interfaces' sub-tab is selected, showing 'Interfaces - LAN'. Below this, there is a description: 'On this page you can configure the network interfaces.' Underneath, there is a 'Common Configuration' section with three sub-tabs: 'General Setup', 'Advanced Settings', and 'VLAN settings'. The 'General Setup' sub-tab is selected. It shows a 'Status' section with 'Uptime: 6d 3h 27m 57s', 'MAC-Address: 00:C0:CA:7E:02:88', 'IP-Address: 192.168.123.136/24', 'RX: 435.27 MB (5055316 Pkts.)', and 'TX: 764.04 MB (2083324 Pkts.)'. Below this, there is a 'Mode' dropdown menu set to 'DHCP client'. There are input fields for 'Hostname to send when requesting DHCP' (containing 'support-EZ2'), 'Gateway', and 'DNS servers'. At the bottom right, there are 'Reset', 'Save', and 'Save & Apply' buttons.

SYSTEM

FIRMWARE UPGRADES

From time to time Tranzeo will release new firmware to enhance the feature set or fix any bugs discovered in the field. Use this section to accomplish firmware upgrades, backup and restore functions.



The screenshot shows the Tranzeo web interface. At the top right, it displays 'Device: support-EZ2 / Mode: Bridge' and 'Wireless: 802.11bgn / Mode: Access Point'. The navigation menu includes 'Status', 'Wireless', 'Network', 'System', and 'Logout'. The 'System' menu is expanded to show 'Backup / Flash Firmware', 'System', 'Web', 'SSH', 'SNMP', 'Watchcat', and 'Reboot'. The 'Backup / Flash Firmware' page has two tabs: 'Actions' and 'Configuration'. The 'Actions' tab is active and contains two main sections:

- Backup / Restore:** Includes instructions to click 'Generate archive' for a backup and 'Perform reset' for a factory reset. It features buttons for 'Generate archive', 'Perform reset', and 'Upload archive...'. A 'Restore backup' section has a 'Choose File' button (showing 'No file chosen') and an 'Upload archive...' button.
- Flash new firmware image:** Includes instructions to upload a firmware image and check 'Keep settings'. It shows 'Current Firmware: TR-EZ2-0.1.3 (Built on 2014/09/02)' and a checked 'Keep settings' checkbox. It features a 'Choose File' button (showing 'No file chosen') and a 'Flash image...' button.

Actions Tab – Flash new firmware image

Use this tab to find out current software version and update the device with the new firmware

Current Firmware: displays the version of the device firmware which is currently operating.

Choose File: activate Browse button to navigate to and select the new firmware file. The full path to the new firmware file location can be specified there. New firmware file is transferred to the system after Upload button is activated.

Flash image should be activated in order to proceed with firmware upgrade routine (new firmware image should be uploaded into the system first). Please be patient, as the firmware upgrade routine can take 3-7 minutes. The based device will be un-accessible until the firmware upgrade routine is completed.

Do not switch off, do not reboot and do not disconnect the device from the power supply during the firmware up- grade process as these actions will damage the device!


It is highly recommended to back up the system configuration data before uploading the new configuration.

LED INTERPRETATION

The state of the LEDs on the TR-MX50-15 is a useful diagnostic and system monitoring tool.

Dependent on the mode of use of the TR-MX50-15 the following tables enable the correct interpretation of the LED states.

TR-MX50-15 LEDs



CPE MODE

LED	INTERFACE	ON	OFF	BLINKING
1	Power	TR-MX50-15 Powered ON	TR-MX50-15 Powered OFF	-
2	Ethernet	Ethernet Linked	No Ethernet Link	Traffic
3	Wireless	Wireless Linked	No Wireless Link	Traffic
4	RSSI	RSSI > -85dBm	RSSI < -85dBm	-
5	RSSI	RSSI > -75dBm	RSSI < -75dBm	-
6	RSSI	RSSI > -65dBm	RSSI > -65dBm	-

Note: the RSSI thresholds are user configurable.

AP MODE

LED	INTERFACE	ON	OFF	BLINKING
1	Power	TR-MX50-15 Powered ON	TR-MX50-15 Powered OFF	-
2	Ethernet	Ethernet Linked	No Ethernet Link	Traffic
3	Security	Wireless Linked	No Wireless Link	Traffic
4	Wireless	5 GHz	-	2.4GHz
5	Wireless	ACL enabled	ACL disabled	-
6	WDS	WDS Enabled	WDS Disabled	-

Note: The wireless/radio LEDs is applicable only to the first active AP if there are multiple VAPs (Virtual APs)

WARRANTY

Limited Warranty

TRANZEO WIRELESS TECHNOLOGIES Inc (“TRANZEO WIRELESS”) warrants that the product(s) furnished hereunder (the “Product(s)”) shall be free from defects in material and workmanship for a period of one (1) year from the date of shipment by TRANZEO WIRELESS under normal use and operation.

TRANZEO WIRELESS’ sole and exclusive obligation and liability under the foregoing warranty shall be for TRANZEO WIRELESS, at its discretion, to repair or replace any Product that fails to conform to the above warranty during the above warranty period. The expense of removal and re-installation of any Product is not included in this warranty. The warranty period of any repaired or replaced Product shall not extend beyond its original term.

Warranty Conditions

The warranty does not apply if the Product:

- (a) Has been modified and/or altered, or an addition made thereto, except by Tranzeo Wireless, Or Tranzeo Wireless’ authorized representatives, or as approved by Tranzeo Wireless in writing;
- (b) Has been painted, rebranded or physically modified in any way;
- (c) Has been damaged due to errors or defects in cabling;
- (d) Has been subjected to misuse, abuse, negligence, abnormal physical, electromagnetic harm, including lightning strikes
- (e) Has been damaged or impaired as a result of using third party Firmware
- (f) Has no original Tranzeo MAC label, or is missing any other original Tranzeo label(s);
- (g) Has not been received by Tranzeo within 30 days of the RMA.

In addition, the above warranty shall apply only if the product has been properly installed and used at all times in accordance, and in all material respects, with the applicable Product documentation; all Ethernet cabling runs use CAT5 (or above), and for outdoor installations, shielded Ethernet cabling is used, and for indoor installations, indoor cabling requirements are followed.