

QUICK START GUIDE – TR-6000

Administrative Settings





Image File Name	Enter the location of the Bios update file then press 'Upgrade Software'
Factory Defaults Restore	Returns all settings to factory defaults.
Device Name	The network name of the device.
User Name	The access user name.
Password/Confirm Password	Enter the password for accessing the device
Ext. Info Enabled	Enable extended information.

QUICK START GUIDE – TR-6000

WDS



Enabled	Select this box to enable WDS
AP MAC Address 1-6	Enter the MAC addresses of the other APs

QUICK START GUIDE – TR-6000

Security Basic



Enabled	Turn On WEP
Authentication	Turn on Shared Key Authentication
Key Length	Level of Encryption. NOTE: 64 bit is called 40 bit on some systems
Default Key	Choose the default WEP key
Activate Keys	Enter your WEP keys. NOTE: Keys must be entered in HEX only.

QUICK START GUIDE – TR-6000

Security Advanced


Enabled	Turn On WPA
Cipher Type	Level of Encryption. TKIP or AES
PSK	Enter your password
Update Interval	Enter the update interval
Enabled	Turn on 802.1x RADIUS Server Authentication
RADIUS Server IP Address	Enter the server IP
Timeout (min)	Enter the timeout period

QUICK START GUIDE – TR-6000

RADIUS Server Shared Secret	Enter the name of the server
Server Port	Enter the port of the server

QUICK START GUIDE – TR-6000

Access Control



Enable Access Control	Select this box to enable access control.
Associated Wireless Devices	Click any devices to disassociate them
Wireless Devices Available	Click any wireless device that should be associated with the AP
Associate With This Station Manually	Enter the MAC address of a client and then click “add” to associate with it.

QUICK START GUIDE – TR-6000

Stations List

The screenshot shows a Microsoft Internet Explorer browser window displaying the Tranzeo Tr-AP-5a Configuration web interface. The address bar shows the URL <http://192.168.2.45/frameset.html>. The page is titled "Stations List" and features a navigation menu on the left side. The main content area is currently empty, with a table header visible at the top. The table header includes columns for "#", "MAC Address", "Status", "Quality", "Signal", and "Speed". A "Back to Information Page" button is located below the table header. The left navigation menu includes links for "AP Setup Menu", "Wireless Settings", "Administrative Settings", "WDS", "AP Security", "AP Status", "Stations List", "Network Configuration", and "Log Off". The Tranzeo logo and product information are also visible in the top left corner of the page.

Tranzeo
802.11b/2.4Ghz
Tr6-AP 2b

AP Setup Menu
[Wireless Settings](#)
[Administrative Settings](#)
[WDS](#)

AP Security
[Basic](#)
[Advanced](#)
[Access Control](#)

AP Status
[Stations List](#)

Network Configuration

Log Off

Copyright © 2004,2005 Tranzeo Wireless Technologies, Inc.


#	MAC Address	Status	Quality	Signal	Speed
---	-------------	--------	---------	--------	-------

[Back to Information Page](#)

This page displays a list of the stations associated with the AP and their connection statistics.

QUICK START GUIDE – TR-6000

Network Configuration



This page allows you to control the network configuration of the device. Enable the Router option to change the IP configuration for the LAN. You can also choose Static or DHCP IP configuration for both the device and any associated IP clients.

QUICK START GUIDE – TR-6000

APPENDIX A: LIGHTING INFORMATION

What is a proper Ground?

This antenna must be grounded to a proper Earth Ground.

According to the The National Electrical Code Sections 810-15s and 810-21, the grounding conductor shall be connected to the NEAREST accessible locations of the following:

- a) The building / structure grounding electrode
- b) The grounded interior metal water piping system
- c) the power service accessible means external to enclosure
- d) the metallic power service raceway
- e) the service equipment enclosure
- f) The grounding electrode conductor

The important thing is to connect to ground at the nearest point.

Why is coiling the LMR or CAT5 bad?

The myth is that lightning follows the path of least resistance. It actually follows the path of least impedance. Coiling cables creates an air-wound transformer, which lowers the impedance. This means you are in fact making your radios a more appealing target for surges.

What standard does Tranzeo Wireless equipment meet?

This radio exceeds International Standard IEC 61000-4-5 when properly grounded. For a copy of the full testing report, see *Report Number TRL090904 - Tranzeo Surge Protection board* located on the Tranzeo website.

Is lightning damaged covered by the Warranty?


No. Lightning is not covered by the warranty. If you follow the instructions, you chances of lightning damage are greatly reduced, but nothing can protect a radio from a direct lightning strike.

QUICK START GUIDE – TR-6000


Where to Ground the device

This radio must be grounded at the Pole **AND** at the POE. This is because the radio is between the Exterior Antenna and the POE ground. See the examples below

Ungrounded Radio




Grounded Radio




QUICK START GUIDE – TR-6000

Ungrounded POE




Grounded POE



QUICK START GUIDE – TR-6000

Best Practices

- 1) Always try to run the Cat5 and LMR inside of the mounting pole wherever possible. This helps to insulate the cable from any air surges.



- 2) Keep all runs as straight as possible. Never put a loop into the cables.
- 3) Test all grounds to ensure that you are using a proper Ground. If using an electrical socket for Ground, use a socket tester, such as Radio Shack 22-141
- 4) Buy a copy of the National Electrical Code Guide and follow it.
- 5) If you are in doubt about the grounding at the location, drive your own rod and bond it to the house ground. At least you will know that one Rod is correct in the system.