
INSTRUCTION MANUAL

836A
2000 WATT UHF
TRANSLATOR

AXCERA, LLC

103 FREEDOM DRIVE P.O. BOX 525 LAWRENCE, PA 15055-0525 USA
(724) 873-8100 • FAX (724) 873-8105
www.axcera.com • info@axcera.com



1.	Introduction:	
2.	System - 836A:	
	A. System Description	
	B. Specifications	
	C. Site Considerations	
	D. Unpacking and Installation Procedures	
	E. Translator Set Up and Operation Procedure	
	F. Meters, Switches and Indicators	
	G. Translator Detailed Alignment Procedure	
	H. Remote Control Interface Connections	
	I. Drawings:	
	1. 2 kW Translator Block Diagram	1276-3000
	2. 2 kW Translator Interconnect	1276-8000
	3. Remote Interface Assembly w/Moseley Interconnect	1276-8011
3.	AC Distribution Assembly, Narrow	
	A. Drawings:	
	1. Interconnect	1276-8200
4.	UHF Exciter	
	A. Drawings:	
	1. Block Diagram	1265-3300
	2. Interconnect	1265-8300
5.	VHF/UHF Receiver Tray	
	A. Drawings	
	1. Block Diagram	1265-3100
	2. Interconnect	1265-8100
6.	UHF Amplifier Tray	
	A. Drawings:	
	1. Block Diagram	1281-3100
	2. Interconnect	1281-8100
7.	Subassemblies:	

Refer to the Subassembly Section of the Instruction Manual for the Schematics, of the Boards and Modules that make up the 836A. A Subassembly Drawing List, which is a list of the drawings in the order they appear in the Section, is located in the front of the Subassembly Section.

8. Maintenance:

This section contains information on the operation and maintenance of the 836A. This section contains information on the Plugs, Jacks, Sockets and Pins that make up the Harness and Cable Assemblies in the 836A.



WARNING!!!

< HIGH VOLTAGE >

DO NOT ATTEMPT TO REPAIR OR TROUBLESHOOT THIS EQUIPMENT UNLESS YOU ARE FAMILIAR WITH ITS OPERATION AND EXPERIENCED IN SERVICING HIGH VOLTAGE EQUIPMENT. LETHAL VOLTAGES ARE PRESENT WHEN POWER IS APPLIED TO THIS SYSTEM. IF POSSIBLE, TURN OFF POWER BEFORE MAKING ADJUSTMENTS TO THE SYSTEM.

★ RADIO FREQUENCY RADIATION HAZARD ★

MICROWAVE AMPLIFIERS AND TUBES GENERATE HAZARDOUS RF RADIATION WHICH CAN CAUSE SEVERE INJURY INCLUDING CATARACTS, WHICH CAN RESULT IN BLINDNESS. SOME CARDIAC PACEMAKERS MAY BE AFFECTED BY THE RF ENERGY EMITTED BY MICROWAVE AMPLIFIERS. NEVER OPERATE A MICROWAVE SYSTEM WITHOUT A PROPERLY MATCHED RF ENERGY ABSORBING LOAD ATTACHED. KEEP PERSONNEL AWAY FROM OPEN WAVEGUIDES AND ANTENNAS. NEVER LOOK INTO AN OPEN WAVEGUIDE OR ANTENNA. MONITOR ALL PARTS OF THE RF SYSTEM FOR RADIATION LEAKAGE AT REGULAR INTERVALS.

EMERGENCY FIRST AID INSTRUCTIONS

Personnel engaged in the installation, operation, or maintenance of this equipment are urged to become familiar with the following rules both in theory and practice. It is the duty of all operating personnel to be prepared to give adequate Emergency First Aid and thereby prevent avoidable loss of life.



RESCUE BREATHING

1. Find out if the person is breathing.

You must find out if the person has stopped breathing. If you think he is not breathing, place him flat on his back. Put your ear close to his mouth and look at his chest. If he is breathing you can feel the air on your cheek. You can see his chest move up and down. If you do not feel the air or see the chest move, he is not breathing.

2. If he is not, open the airway by tilting his head backwards.

Lift up his neck with one hand and push down on his forehead with the other. This opens the airway. Sometimes doing this will let the person breathe again by himself. If it does not, begin rescue breathing.

3. If he is still not breathing, begin rescue breathing.

-Keep his head tilted backward. Pinch nose shut.
-Put your mouth tightly over his mouth.
-Blow into his mouth once every five seconds
-**DO NOT** stop rescue breathing until help comes.

LOOSEN CLOTHING - KEEP WARM

Do this when the victim is breathing by himself or help is available. Keep him as quiet as possible and from becoming chilled. Otherwise treat him for shock.

BURNS

SKIN REDDENED: Apply ice cold water to burned area to prevent burn from going deeper into skin tissue. Cover area with clean sheet or cloth to keep away air. Consult a physician.

SKIN BLISTERED OR FLESH CHARRED: Apply ice cold water to burned area to prevent burn from going deeper into skin

tissue. Cover area with clean sheet or cloth to keep away air. Treat victim for shock and take to hospital.

EXTENSIVE BURN - SKIN BROKEN: Cover area with clean sheet or cloth to keep away air. Treat victim for shock and take to hospital.

LIMITED WARRANTY

ONE YEAR

Seller warrants each new product manufactured and sold by Seller against defects in material and workmanship under normal use and service, for a period of one (1) year from the date of shipment from Seller's plant, when operated in accordance with Seller's operating instructions. This warranty shall not apply to tubes, fuses, batteries, or bulbs.

Warranties are valid only when and if (a) Seller receives prompt written notice of breach within the period of warranty, (b) the defective product is properly packed and returned by the Buyer (transportation and insurance prepaid), and (c) Seller determines, in its sole judgment, that the product is defective and not subject to any misuse, neglect, improper installation, negligence, accident, or (unless authorized in writing by Seller) repair or alteration. Seller's exclusive liability for any personal and/or property damage (including direct, consequential or incidental) caused by the breach of any or all warranties, shall be limited to the following: (a) repairing or replacing (in Seller's sole discretion) any defective parts free of charge (F.O.B. Seller's plant), and/or (b) crediting (in Seller's sole discretion) all or a portion of the purchase price to the Buyer.

Equipment furnished by Seller, but not bearing its trade name, shall bear no warranties other than the special hours-of-use or other warranties extended by or enforceable against the manufacturer at the time of delivery to the buyer. **NO WARRANTIES, WHETHER STATUTORY, EXPRESSED OR IMPLIED, AND NO WARRANTIES OF MERCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE, OR FREEDOM FROM INFRINGEMENT, OR THE LIKE, OTHER THAN AS SPECIFIED IN PATENT LIABILITY ARTICLES, AND IN THIS ARTICLE, SHALL APPLY TO THE EQUIPMENT FURNISHED HEREUNDER.**

MATERIAL RETURN PROCEDURE

In order to efficiently handle equipment or components returned for repair or sent out on loan, Axcera requests that each returned item be accompanied by a Material Return Authorization Number (MRA#).

To obtain an MRA follow the procedures below:

- Call Axcera Customer Service at (724)-873-8100 or FAX (724) 873-8105
- A Service Engineer will provide you with an MRA#
- Write the MRA# on the packing list or in the case of repairs, a note describing the reason for return. Also, be sure to include contact information.
- Send ALL MRA items to the following address

Axcera, LLC
103 Freedom Drive P.O. Box 525
Lawrence, PA 15055-0525

TELEPHONE TECHNICAL SUPPORT

Axcera currently provides free telephone technical support. When calling, be prepared to provide the following information:

- Transmitter model # AND Serial #
- Status of front panel LED's (are any red LED's on ?)
- Have a copy of your operation manual ready prior to calling

From 8:00 AM - 5:00 PM EST call (724) 873-8100 for technical support

PROPER PACKING OF MATERIALS

When returning materials to Axcera, it is extremely important to pack them properly. Due to the delicate nature of components contained within the equipment, major damage can occur without proper packing. Please adhere to the following guidelines when returning materials.

- ❑ Save the boxes that the transmitter is shipped in. Each tray is sent double boxed and enclosed in foam padding. Use the same packing method when returning materials.**

Failure to properly pack any returned materials may result in damage to the equipment. Axcera is not responsible for damaged equipment under these circumstances. Many freight companies will not compensate for damages when items are not packed properly. Please pack items properly!

dBm, dBw, dBmV, dB μ V, AND VOLTAGE EXPRESSED IN WATTS

50 ohm system

WATTS	PREFIX	dBm	dBw	dBmV	dB μ V	VOLTAGE
1,000,000,000,000	1 TERAWATT	+150	+120			
100,000,000,000	100 GIGAWATTS	+140	+110			
10,000,000,000	10 GIGAWATTS	+130	+100			
1,000,000,000	1 GIGAWATT	+120	+ 99			
100,000,000	100 MEGAWATTS	+110	+ 80			
10,000,000	10 MEGAWATTS	+100	+ 70			
1,000,000	1 MEGAWATT	+ 90	+ 60			
100,000	100 KILOWATTS	+ 80	+ 50			
10,000	10 KILOWATTS	+ 70	+ 40			
1,000	1 KILOWATT	+ 60	+ 30			
100	1 HECTROWATT	+ 50	+ 20			
50		+ 47	+ 17			
20		+ 43	+ 13			
10	1 DECAWATT	+ 40	+ 10			
1	1 WATT	+ 30	0	+ 77	+137	7.07V
0.1	1 DECIWATT	+ 20	- 10	+ 67	+127	2.24V
0.01	1 CENTIWATT	+ 10	- 20	+ 57	+117	0.707V
0.001	1 MILLIWATT	0	- 30	+ 47	+107	224mV
0.0001	100 MICROWATTS	- 10	- 40			
0.00001	10 MICROWATTS	- 20	- 50			
0.000001	1 MICROWATT	- 30	- 60			
0.0000001	100 NANOWATTS	- 40	- 70			
0.00000001	10 NANOWATTS	- 50	- 80			
0.000000001	1 NANOWATT	- 60	- 90			
0.0000000001	100 PICOWATTS	- 70	-100			
0.00000000001	10 PICOWATTS	- 80	-110			
0.000000000001	1 PICOWATT	- 90	-120			

TEMPERATURE CONVERSION

$$^{\circ}\text{F} = 32 + [(9/5) ^{\circ}\text{C}]$$

$$^{\circ}\text{C} = [(5/9) (^{\circ}\text{F} - 32)]$$

USEFUL CONVERSION FACTORS

TO CONVERT FROM	TO	MULTIPLY BY
mile (US statute)	kilometer (km)	1.609347
inch (in)	millimeter (mm)	25.4
inch (in)	centimeter (cm)	2.54
inch (in)	meter (m)	0.0254
foot (ft)	meter (m)	0.3048
yard (yd)	meter (m)	0.9144
mile per hour (mph)	kilometer per hour(km/hr)	1.60934
mile per hour (mph)	meter per second (m/s)	0.44704
pound (lb)	kilogram (kg)	0.4535924
gallon (gal)	liter	3.7854118
U.S. liquid (One U.S. gallon equals 0.8327 Canadian gallon)		
fluid ounce (fl oz)	milliliters (ml)	29.57353
British Thermal Unit per hour (Btu/hr)	watt (W)	0.2930711
horsepower (hp)	watt (W)	746

NOMENCLATURE OF FREQUENCY BANDS

FREQUENCY RANGE	DESIGNATION
3 to 30 kHz	VLF - Very Low Frequency
30 to 300 kHz	LF - Low Frequency
300 to 3000 kHz	MF - Medium Frequency
3 to 30 MHz	HF - High Frequency
30 to 300 MHz	VHF - Very High Frequency
300 to 3000 MHz	UHF - Ultrahigh Frequency
3 to 30 GHz	SHF - Superhigh Frequency
30 to 300 GHz	EHF - Extremely High Frequency


LETTER DESIGNATIONS FOR UPPER FREQUENCY BANDS

LETTER	FREQ. BAND
L	1000 - 2000 MHz
S	2000 - 4000 MHz
C	4000 - 8000 MHz
X	8000 - 12000 MHz
Ku	12 - 18 GHz
K	18 - 27 GHz
Ka	27 - 40 GHz
V	40 - 75 GHz
W	75 - 110 GHz

ABBREVIATIONS/ACRONYMS

AC	Alternating Current	PCB	Printed circuit board
AFC	Automatic Frequency Control	QAM	Quadrature Amplitude Modulation
ALC	Automatic Level Control		
AM	Amplitude modulation		
AGC	Automatic Gain Control		
AWG	American wire gauge		
BER	Bit Error Rate		
BW	Bandwidth		
DC	Direct Current		
D/A	Digital to analog		
dB	Decibel		
dBm	Decibel referenced to 1 milliwatt		
dBmV	Decibel referenced to 1 millivolt		
dBw	Decibel referenced to 1 watt		
FEC	Forward Error Correction		
FM	Frequency modulation		
Hz	Hertz		
ICPM	Incidental Carrier Phase Modulation		
I/P	Input		
IF	Intermediate Frequency		
LED	Light emitting diode		
LSB	Lower Sideband		
MPEG	Motion Pictures Expert Group		
O/P	Output		
PLL	Phase Locked Loop		

RETURN LOSS VS. VSWR



The 836A is a complete 2 kW UHF Solid State Internally Diplexed Television Translator which operates at a nominal Visual Output Power of 2000 Watts Peak of Sync and with an Average Aural Output Power of 200 Watts at an A/V Ratio of 10 dB, 10 % Sound. The Translator uses the combined IF Output of the Receiver Tray as the input to the UHF Exciter Tray.

The 836A (1078476) is functionally comprised of (A4) the UHF Exciter (1300-1020), (A3) the VHF/UHF Receiver Tray (1265-1100), (A5) the 4 Way Splitter Assembly, (A6, A7, A8 & A9) four UHF Amplifier Trays (1294-1112, 1294-1113 or 1294-1114), (A10 & A11) two UHF Tee Assemblies, (A12) a Hybrid Combiner, (A13) a Bandpass Filter, (A14) an (Optional) UHF Trap Filter, (A16) a Coupler Assembly, (A2) an AC Distribution Assembly (1276-1200) and (A17) an (Optional) A/V Input & Remote Interface Assembly (1276-1008) or a Remote Interface Assembly w/Moseley (1314-1008).

The (A3) VHF/UHF Receiver Tray (1265-1100) takes the On Channel RF Input, which connects to J5 for 75Ω or J1 for 50Ω on the rear of the Tray and generates a Modulated Diplexed IF Output. The Combined IF from J4 connects to the J6 on the (A4) UHF Exciter Tray (1265-1300) which upconverts the signal to the On Channel Frequency Visual + Aural RF Output. The RF Output of the UHF Exciter at J15 is split four ways by (A5) the Four Way Splitter Assembly (ZFSC-4-1SMA). The outputs of the Splitter feed to J1 on the four (A6, A7, A8 & A9) UHF Amplifier Trays. The RF outputs of the (A8 & A9) UHF Amplifier Trays are combined in the (A11) UHF Tee Assembly and the outputs of the (A6 & A7) UHF Amplifier Trays are combined in the (A10) UHF Tee Assembly. The Combined Outputs of each UHF Tee are combined in (A12) a Hybrid Combiner. A 500 Watt Dummy Load (A18) is connected to the Hybrid Combiner and provides Transmitter protection, using the Thermal Switch (A18-A1), in case of misalignment in the combining or a malfunction in the UHF Amplifier Trays which causes overtemperature. The RF output of the Hybrid Combiner is connected to (A13) a Bandpass Filter, and then either directly to (A16) an Output Coupler Assembly or through (A14) an (Optional) One Section or Two Section UHF Trap Filter. The 7/8" RF Output at J2 of the Coupler is the output of the Translator. The (A16) 7/8" Coupler Assembly supplies a Forward Power Sample and a Reflected Power Sample to the Visual/Aural Metering Board located in the UHF Exciter. The Samples are peak detected and wired to the Transmitter Control Board which connects the Visual, Aural and Reflected Power Output Samples to the front panel Meter on the Exciter for monitoring.

The Combined Visual IF + Aural IF Input (0 dBm Typical) from the Receiver Tray connects to J6 on the UHF Exciter Tray. The Combined IF is cabled to the (A8) ALC Board (1265-1305) which gives the operator control over the output power level of the Translator by adjusting the level of the combined IF Signal. The IF Signal is fed out of the ALC Board to (A9) an IF Phase Corrector Board (1227-1250) that is adjusted for best signal and then back to the ALC Board.

Upconverter Section

The output of the ALC Board (0 dBm) connects to (A11) the UHF Upconverter Board (1265-1310), located in the Upconverter Section, which takes the L.O. and heterodynes it with the Combined IF, that is then filtered to produce the RF On Channel Output. The crystal frequency needed to generate the L.O. is produced by (A14-A1) the Channel Oscillator Board (1145-1201) located in (A14) the Channel Oscillator Assembly (1145-1202) or if the Optional FSK Identifier Kit is purchased, by the VCXO Channel Oscillator Board (1145-1204) located in the VCXO Channel Oscillator Assembly (1145-1206). The Crystal Frequency (+5 dBm) is multiplied 8 times by (A15-A1) the x8 Multiplier Board (1227-1002), located in (A15) the x8 Multiplier Enclosure (1265-1347), which produces the L.O. Signal at the proper frequency (+16 dBm) needed in the upconversion process that takes place on the UHF Upconverter Board. The L.O. is filtered by (A16) a UHF Filter (1007-1101) before it is applied to the UHF Upconverter Board. The L.O. is mixed with the IF to produce an On Channel RF Output that is filtered by (A12) a UHF Filter (1007-1101) and connected back to the Upconverter Board. The RF is connected through an AGC circuit and is amplified before it is attached to the output of the board.

Output RF Section

The RF Output of the UHF Exciter is split four ways in (A5) the 4 Way Power Splitter Assembly (ZFSC-4-1SMA). The outputs of the Splitter feed the four (A6, A7, A8 & A9) UHF Amplifier Trays which amplify the RF signals to approximately 600 Watts each. A Forward Power Sample from the 4 Way Combiner Board inside the Tray is connected to the Dual Peak Detector Board which provides a peak detected forward sample to the Amplifier Control Board that supplies the sample to the front panel meter of the UHF Amplifier Tray. Before exiting each UHF Amplifier Tray the RF is fed through a Circulator for protection of the Tray from high VSWR conditions. The Reject Port of the Circulator provides a Reject Sample to the 4 Way Combiner Board, which supplies the Reflected Sample to the Dual Peak Detector Board. The peak detected Reflected Sample connects to the Amplifier Control Board that provides the sample to the front panel meter of the Tray. The outputs of the two (A6 & A7) UHF Amplifier Trays are then combined in (A10) a UHF Tee Assembly (1227-1017 L.B., 1227-1018 M.B. or 1227-1019 H.B.) that provides approximately 1100 Watts Peak of Sync Output. The outputs of the other two (A8 & A9) UHF Amplifier Trays are then combined in (A11) a UHF Tee Assembly (1227-1017 L.B., 1227-1018 M.B. or 1227-1019 H.B.) that provides approximately 1100 Watts Peak of Sync Output. The two 1100 Watts Outputs then combined in (A12) a Hybrid Combiner that provides approximately 2200 Watts Peak of Sync Output. The combined output is connected to (A13) a Bandpass Filter, then either through (A14) an (Optional) One Section or Two Section Trap Filter or directly to (A16) the Output Coupler Assembly to the output of the System. The Bandpass Filter and Trap Filter are tuned to provide high out of band rejection of unwanted products. The (A16) 7/8" Coupler Assembly provides a Forward Power Sample and a Reflected Power Sample. The Forward and Reflected Samples are cabled to the Visual/Aural Metering Board located in the UHF Exciter. The Forward and Reflected Samples are processed to provide peak detected Visual and an Aural Power Output Samples to the Transmitter Control Board. The Transmitter Control Boards connect the Visual, Aural and Reflected Power Output Samples to the front panel Meter for monitoring.

Control and Status

The Meter and the LED indicators located on the front panel of the UHF Exciter provide the Control and the Status Indications of the Translator. The switches and LED indicators are part of the Transmitter Control Board (1265-1311) which is mounted so that the switches and the LEDs are operated or viewed from the front Panel of the UHF Exciter. Switch (S1) is an Operate/Standby Switch that controls the output of the Translator by providing the Enables, when in Operate, needed to turn on the Switching Power Supplies in the four UHF Amplifier Trays. In Operate the Green LED (DS2) is On and when in Standby the Amber LED (DS1) is On. If the Translator does not switch to Operate, when S1 is switched to Operate, check that a Dummy Jumper Plug, with a Jumper between Pins 23 & 24 is connected to J11 on the rear of the UHF Exciter Tray or with a jumper between Pins 21 & 22 on Jack J9 on (A17) the (Optional) A/V Input & Remote Interface Panel. This Jumper provides the Interlock needed for the Translator to operate. If the Interlock is present the Green LED (DS5), located on the Transmitter Control Board, should be lit.

Switch (S2) is an Automatic/Manual Switch that controls the operation of the Translator by the presence of the Input Signal. When the switch is in Automatic the Green LED (DS3) is lit and if the Input Signal to the Translator is lost, the Translator will automatically switch to Standby. When the Input Signal returns the Translator will automatically switch back to Operate. In Manual, Amber LED (DS4) lit, the Operation of the Translator is controlled by the front panel switches. During Normal operation of the Translator Switch S2 should be in the Auto position. The front panel of the UHF Exciter also has LEDs that indicate a Video Fault (Loss), Red LED (DS9) and a VSWR Cutback, Amber LED (DS7).

Operation of the Translator

The Translator needs an AC input of 220 VAC at 80 Amps connected to it in order to operate. The 220 VAC Input connects to the Terminal Block (TB1), located in the upper right rear of the Cabinet, that is part of (A2) the AC Distribution Panel (1276-1200). The AC Distribution Panel contains Six Circuit Breakers that supply the AC to the rest of the Translator.

The Input AC from TB1 is connected to (CB1) the Main AC Circuit Breaker (80 Amps) which distributes the 220 VAC to the Terminal Block (TB2). TB2 has three MOVs, mounted to the Terminal Block, one connected from each leg of the Input AC to ground and one across the two legs. The Input AC is wired from TB2 through five Circuit Breakers, CB2, CB3, CB4, CB5 & CB6 to the rest of the Translator. CB2 (10 Amps) supplies the AC voltage to the IEC Outlet Strip (A1) into which the UHF Exciter, the Optional Receiver Tray and any other Optional Accessories are connected. CB3 (20 Amps) supplies AC through J5 to the (A6) UHF Amplifier Tray. CB4 (20 Amps) supplies AC through J6 to the (A7) UHF Amplifier Tray. CB5 (20 Amps) supplies AC through J7 to the (A8) UHF Amplifier Tray. CB6 (20 Amps) supplies AC through J8 to the (A9) UHF Amplifier Tray. When the UHF Exciter circuit breaker is switched On, +12 VDC is supplied to the UHF Amplifier Trays for operation of the LED Status Indicators in the Tray.

Input and Remote Connections

The On Channel RF Input from the Antenna connects to J5 for 75 Ω or J1 for 50 Ω located on the rear of the VHF/UHF Receiver Tray. Jacks J10 and J11 on the rear of the UHF Exciter provides connections for Remote Monitoring and Operation of the Translator. Jack (J11) should have a dummy plug connected to it which has a jumper between Pins 23 & 24 that provides the Interlock needed to operate the Translator. If remote connections are made to the Translator they should be made through the plug in J10 or J11 in the positions noted on the Interconnect Drawing (1276-8000).

The (Optional) Remote Interface Assembly, if present, provides connections for Remote Monitoring and Operation of the Translator at Jack (J9 & J10). Jack (J9) should have a dummy plug connected to it which has a jumper between Pins 21 & 22 that provides the Interlock needed to operate the Translator. If remote connections are made to the Translator they should be made through the plug in J9 or J10 in the positions noted on the Interconnect Drawing (1276-8000).

Instruction Manual Description

The Instruction Manual is divided into sections that are labeled as to their contents. The first main section is the System Section that contains the Parameters and Specifications of the 836A along with the Site Preparation, Installation, System Set Up, Alignment and Operation Procedures. The Block Diagram and Interconnect for the Translator are also found in the System Section.

The Manual is further divided into Tray and Assembly Sections. Each Tray or Assembly Section of the Manual contains the Block Diagrams, Control Location Drawings and Interconnects of that Assembly or Tray. Each of the Sections also contains the Circuit Descriptions and Detailed Alignment Procedures for that Tray or Assembly.

The Schematics, Parts Location Drawings and the Replacement Parts Lists for the individual boards that make up the Trays and Assemblies in the Translator are located in the Subassembly Section of the Manual. There is a Drawing List at the beginning of the Subassembly Section that lists the drawings in the order they appear in the section.



UHF Solid State Transmitter / Translator

825A/827A - 500W

830A/832A - 1kW

834A/836A - 2kW



These products represent the state of the art in solid state UHF transmitters. High performance, redundancy, and simplicity are combined in a very compact unit. Multiplexed aural/visual amplification is achieved with very good intermodulation performance, thanks to highly linear amplifiers and extensive correction capability.

Front panel samples, status, and metering, most of which are remote controllable, allow for convenient system monitoring. As with all Axcera products, servicing is made easy with slide out assemblies that require no extender cards. This allows the circuits to be accessed for maintenance or adjustments even while on the air.





UHF Solid State Transmitter / Translator

Exciter

The exciter, designed and built by Axcera, contains the circuitry to convert the input video and audio signals to a combined, modulated RF signal which drives the power amplifiers. In the translator version, a receiver replaces the modulator circuits to accept an off air RF input and convert it to IF. An optional Frequency Correcting Receiver (FCR) is available, which uses a phase locked loop to correct frequency errors from the incoming signal. This option is especially useful in multiple hop translator systems.

Video/Visual Modulation

The video signal is processed in several ways prior to modulation. Sync tip clamping is provided to restore proper DC level. Sync and white clipping are also included to limit video transient faults. Back porch clamping is also available for some scrambling systems.

The video signal is then applied to a double balanced diode modulator, providing modulation capability to 1% at standard intermediate frequency (IF). A SAW filter is employed for precise sideband filtering with minimal group delay error.

Audio/Aural Modulation

The audio signal is applied to a very wideband, linear FM modulator which operates at intercarrier frequency (4.5 MHz for system M). The

high performance modulator readily accepts the full range of multichannel sound signals. Standard aural IF is achieved by heterodyne conversion of the modulated intercarrier signal with the visual IF.

IF Processing

The visual and aural modulated IF signals are combined and applied to IF processing stages. These stages provide outstanding signal precorrection to yield a very linear transmitter output. Amplitude linearity, incidental carrier phase modulation (ICPM), and frequency response correction are all adjustable.

Upconversion

The IF signal is upconverted to final channel frequency through heterodyning with a very stable local oscillator. The oscillator is crystal controlled, and embedded in two ovens for tight stability. The exciter is controlled with an Automatic Level Control (ALC) loop which ensures stable signal levels. After upconversion the signal is amplified to provide the exciter output.

Power Amplifiers

The 600 watt power amplifiers are high gain units producing 45 to 50dB of gain. Operating in parallel in the 1 and 2kW versions, these trays provide redundant paths from the exciter output to the bandpass filter. Redundancy

is enhanced with independent power supplies and cooling for each amplifier assembly. Furthermore, the output stage of each amplifier tray employs eight transistors in parallel for added redundancy.


A high degree of protection is provided with each amplifier. Individual circulators, overdrive protection, VSWR cutback, and overtemperature protection are all included. AGC around each amplifier ensures that the transmitter output remains stable.

An integrated output bandpass and trap filter is included to provide superior out of band rejection. This network also adds lightning protection through the quarter wave stub of the trap filter (DC and lightning short) and the DC short circuit of the band pass filter.



UHF Solid State Transmitter / Translator

UHF Solid State Transmitter / Translator



- Utilizes 100% solid state circuitry for high reliability and low maintenance costs
- 1kW and 2kW configured with parallel high gain amplifiers, separate power supplies and cooling for excellent redundancy, including driver stages
- Packaged in a compact design, completely contained in a single rack - including output filters!
- Provides standard ± 1 kHz frequency stability for stations with an offset frequency
- Configured with broadcast quality exciter that includes full BTSC sound capability
- Provides output circulator amplifier protection for high VSWR conditions
- Experienced field service/support team is ready to help you 24 hours a day, 7 days a week.

Standard with all Axcera products is 24 hour/day, 7 day/week customer support. This service operates as a direct telephone line during business hours, and on a pager system at all other times. Since all our products are designed and built at our facility just south of Pittsburgh, Pennsylvania, we are able to offer quick turnaround on most replacement modules, and timely shipping from the Pittsburgh International Airport.

UHF Solid State Transmitter / Translator

Visual Performance

Power Output (Peak)	500, 1000, 2000 W
Output Impedance	50 ohms
Output Connector	7/8" EIA
Frequency Range*	470 to 806 MHz
Carrier Stability (<i>Transmitters</i>)	±1 kHz (standard) ±350 Hz (optional)
Frequency Translation Stability (<i>Translators</i>)	±1 kHz (standard) ±350 Hz (optional)
Regulation of RF Output Power	3%
Output Variation (over 1 frame)	2%
Sideband Response (System M/N-others on request)	
-1.25 MHz and below	-20 dB
-0.75 to -0.5 MHz	+0.5 dB, -2 dB
-0.5 to +3.58 MHz	±0.5 dB
+3.58 MHz to +4.18 MHz	+0.5 dB, -1 dB
Freq Response vs. Brightness	±0.5 dB
Visual Modulation Capability (<i>Transmitters</i>)	1%
Differential Gain	5%
Incidental Phase Modulation	±3°
Linearity (Low Frequency)	5%
Differential Phase	±3°
Signal-to-Noise Ratio	55 dB
2t K-Factor	2%
Noise Figure (<i>Translators</i>)	5 dB (max.)
w/input Preamp	3 dB (max.)
Input Dynamic Range (<i>Translators</i>)	-60 dBm to -15 dBm
w/input Preamp	-75 dBm to -30 dBm
Env. Delay (<i>Transmitters</i>)	Per CCIR or FCC Standard
Env. Delay .02 to 4.18 MHz (<i>Translators</i>)	±40 ns
Video Input (<i>Transmitters</i>)	75 ohms (loop through)
Harmonics	-60 dB or better
Intermodulation Products	-52 dB or better
Spurious	-60 dB or better (>3 MHz from channel edge)

Aural Performance

Power Output (Average)	50, 100, 200 W
Frequency Deviation Capability (<i>Transmitters</i>)	±75 kHz
Distortion	0.5%
FM Noise	-60 dB
AM Noise	-50 dB
Aural to Visual Separation	4.5 MHz, ±100 Hz
Composite Audio Input (multi-channel sound) (<i>Transmitters</i>)	
Input Level	1V peak, nominal
Input Impedance	75 ohms, unbalanced
Frequency Range	
±0.1 dB response	50 Hz to 50 kHz
±0.5 dB response	30 Hz to 120 kHz
Monaural Audio Input (<i>Transmitters</i>)	
Input Level	0 to +10 dBm
Input	600 ohms, balanced
Freq Range (±0.5 dB resp)	30 Hz to 15 kHz
Pre-emphasis	75µs
Subcarrier Input (<i>Transmitters</i>)	
Input Level	1V peak, nominal
Input Impedance	75 ohms, unbalanced
Freq Range (±0.5 dB resp)	20 kHz to 120 kHz

General

Operational Temperature Range	-30°C to +50°C
Operational Humidity Range	0% to 95%
Altitude*	8,500 feet
825A/827A	
Size (H x W x D)	55" x 22" x 34"
Weight	320 lbs
Power Consumption	1800 watts (50% APL)
830A/832A	
Size (H x W x D)	55" x 22" x 34"
Weight	400 lbs
Power Consumption	3500 watts (50% APL)
834A/836A	
Size (H x W x D)	76" x 22" x 34"
Weight	750 lbs
Power Consumption	7000 watts (50% APL)
Line Voltage*	230V ±10%, 1 phase, 50/60 Hz

*Consult factory for other frequencies, altitudes and line voltages



103 Freedom Drive, P.O. Box 525, Lawrence, PA 15055-0525
724-873-8100 t 724-873-8105 f www.axcera.com



Specifications published here are current as of the date of publication of this document. Because we are continuously improving our products, Axcera reserves the right to change specifications without prior notice. At any time, you may verify product specifications by contacting our office. Axcera views its patent portfolio as an important corporate asset and vigorously enforces its patents. Products or features contained herein may be covered by one or more U.S. or foreign patents.

There are special considerations that need to be made before installing the 836A and this section will help you plan ahead.

The Translator requires an AC Input Line of 220 VAC with a rating of 80 Amps. Check that the site has the voltage requirement needed.

836A is designed and built to provide long life with a minimum of maintenance. The environment in which it is placed is important and certain precautions must be taken. The three greatest dangers to your Translator are heat, dirt and moisture. Heat is usually the greatest problem, followed by dirt and then moisture. Over-temperature can cause heat related problems such as thermal runaway and component failure. Each Amplifier Tray in the Translator contains a Thermal Interlock Protection Circuit that will shut down that Tray until the temperature drops to an acceptable level.

To begin to design a suitable environment for your new Translator it is imperative that you understand what an "Ideal Environment" is and how it can enhance the overall performance and reliability of your Translator, thereby maximizing revenues by minimizing down time. A properly designed facility will have an adequate supply of cool clean air, free of airborne particulates of any kind, and without excessive humidity. An Ideal Environment will require temperature in the range of 40 degrees F to 70 degrees F year round, reasonably low humidity and a dust free room. It should be noted that this is rarely if ever attainable in the real world. However, the closer your environment is to the Ideal Environment the greater the operational elevation. A heat related problem may not surface for many months if the installation is completed during cool weather, but may suddenly appear during the heat of summer.

The fans and blowers designed and built into your Translator will remove the heat from within the cabinet but additional means is required for removing this heat from the building. In doing this a few considerations should be noted. The first step is to determine the amount of heat to be removed. There are generally three sources of heat that must be considered. The first and most obvious is the heat from the 2 kW Translator itself. This can readily be determined by subtracting the Average Power to the Antenna (1290 Watts) from the AC Input Power (8000 W). These numbers will be different for the 5 kW and 10 kW Translator but can be found by referring to the published literature or directly from Axcera. This number in Watts (6710) is then multiplied by 3.41 which gives (22881.1) the BTU's to be removed every hour. 12,000 BTU's per hour equals one ton, so a two-ton air conditioner will cool a 2 kW Translator. The second source of heat is other equipment in the same room. Calculate this number as you did above. The third source of heat is equally obvious but not as simple to calculate. This is the heat coming through the walls, roof and windows on a hot summer day. Unless the underside is exposed, the floor is usually not a problem.

Determining this number is usually best left up to a qualified HVAC Technician. There are far too many variables to even estimate this number without detailed drawings of the site showing all construction details. The sum of these three sources is the total amount of heat that must be removed. There may be other sources of heat, such as personnel, and all should be taken into account.

Now that you know the amount of heat that must be removed we will consider how this can be accomplished. Your options are air conditioning, ventilation or a combination of the two. Air conditioning is always the preferred method and is the only way to approach the Ideal Environment.

Ventilation will work quite well if the ambient air temperature will be below 100 degrees F or about 38 degrees C and the humidity should be at a reasonable level. In addition, the air stream must be adequately filtered to ensure that no airborne particulate of any kind will be carried into the Translator. The combination of air conditioning for summer and ventilation during the cooler months is acceptable when the proper cooling cannot be obtained through the use of ventilation alone and air conditioning year round is not feasible for whatever reason. However, **operation of air conditioning and ventilation simultaneously is not recommended** because this can cause

condensation in Translators. For tube type Translators this can be especially serious if the condensation forms in the tube cavity and creates damaging arcs.

A few cautions should be observed concerning an air conditioning system.

1. Air conditioners have an ARI nominal cooling capacity rating. In selecting your air conditioner do not assume you can equate this number to your requirements. Make certain that your contractor uses the actual conditions you wish to maintain in determining the size of the unit. With desired conditioned room temperature under 80 degrees F the unit must be derated, possibly by a substantial amount.
2. Do not have the air conditioner blowing directly onto the Translator. Condensation may occur on, or worse, in the Translator under certain conditions.
3. Do not isolate the front of the Translator from the back with the thought of air conditioning the front only. Cooling air is drawn in the front of all Translators and in the front and back of others. Any attempt to isolate the front from the rear will adversely affect the cooling air flow.
4. Interlocking the Translator with the air conditioner is recommended to preclude operation of the Translator without the necessary cooling.
5. The periodic cleaning of all filters is a must.

When using ventilation alone, the following general statements apply.

1. The Blower with attendant filters should be on the inlet, thereby pressurizing the room which prevents the ingress of dirt.
2. The inlet and outlet should be on the same side of the building, preferably the leeward side. The pressure differential created by wind will be minimized. Only the outlet may be through the roof.
3. The inlet and outlet should be screened with 1/8" hardware cloth (preferred), galvanized hardware cloth (acceptable).
4. Cooling air should enter the room as low as practical but in no case higher than four feet above the floor. The inlet must be located where dirt, leaves, snow, etc. will not be carried in with the cooling air.
5. The exhaust should be located as high as possible. Some ducting is usually required to insure complete flushing of heated air with no stagnant areas.
6. The filter area must be adequate to insure a maximum air velocity of 300 feet per minute through the filter. This is not a conservative number but a never exceed number. In a dusty or remote location, this number should be reduced to 150 CFM.
7. The inlet and outlet(s) must have automatic dampers that close any time the ventilation blower is Off.
8. Where Translators are regularly Off for a portion of each day a temperature differential sensor controlling a small heater must be installed. This sensor will monitor inside and outside temperatures simultaneously. If the inside temperature falls to within 5 degrees F of the outside temperature the heater will come On. This will prevent condensation when the ventilation blower comes On and applies even in the summer.

9. A controlled air bypass system must be installed to prevent the temperature in the room from falling below 40 degrees F during Translator operation.
10. The blower should have two speeds, which are thermostatically controlled, and interlocked with the Translator.
11. The blower on high speed must be capable of moving the required volume of air into a half inch of water pressure at the required elevation. The free air delivery method must not be used.
12. Regular maintenance of the filters can not be overemphasized.
13. Tube Translators should not rely on the internal blower for exhausting tube cooling air at elevations above 4000 feet. For external venting, the air vent on the cabinet top must be increased to 8" diameter for a 1 kW Translator and to 10" for 5 kW & 10 kW Translators. An equivalent rectangular duct may be used but in all cases the outlet must be increased in area by 50 % through the outlet screen.
14. It is recommended that a site plan be submitted to Axcera for comment before installation commences.

In calculating the blower requirements, filter size and exhaust size, use the following guide. If the total load is known in Watts, you will need 2000 CFM into 1/2" of water for each 5000 Watts. If the load is known in BTU's you will need 2000 CFM into 1/2" of water for each 17,000 BTU's. The inlet filter must be seven square feet minimum, larger for dusty and remote locations, for each 5000 Watts or 17,000 BTU's. The exhaust must be at least four square feet at the exhaust screen for each 5000 Watts or 17,000 BTU's. The above is a general guide and may need modified for unusually severe conditions.

A combination of air conditioning and ventilation installation should not be difficult to design using the above information. System interlocking and thermostat settings should be reviewed with Axcera. As with any equipment installation it is always good practice to consult the manufacturer when questions arise. Axcera may be contacted at (724) 873-8100.

See the drawing that follows for more information.

Air conditioning and any related heat exhaust ducts should be in place before continuing with the installation of the Translator.

Please inspect the Cabinet and all other material thoroughly upon arrival. Axcera certifies that upon leaving our facility the equipment was undamaged and in proper working order. The shipping containers should be inspected for obvious damage that is indicative of rough handling. Check for dents, scratches, broken switches, meters or connectors. Any claims against in-transit damage should be directed to the Carrier. Also please inform Axcera as to the extent of the damage.

Remove the Cabinet with Trays, UHF Tee Assembly, Bandpass Filter, (Optional) Trap Filter, Directional Coupler and Installation Material that make up the 836A from the crates and boxes. Remove the straps which hold the Cabinet to the shipping skid and slide the Cabinet from the skid. Remove the plastic wrap and foam protection from around the Cabinet. Do not remove any labeling or tags from any cables or connectors, for these are for identification markers which make reassembly of the Translator as easy as possible.

Remove the four L-brackets, mounted on the front panel rails, which hold the Trays in place during shipment. The Trays are mounted in the cabinet using Chassis Trak cabinet slides. The Tray Slides are on the Top and Bottom of the UHF Amplifier Trays and on the sides of the UHF Exciter Tray and the VHF/UHF Receiver Tray. Inspect for any loose hardware or connectors, tightening where needed. Open the rear door, the key to the lock, if present, is found in a tan envelope taped to the door, and inspect the interior for packing material. Carefully remove any packing material that is found. Slowly slide each Tray in and out to verify that they do not rub against each other and have no restriction to free movement. **Caution: Each UHF Amplifier Tray has a hardline coaxial cable connected to the rear panel and will not slide out without first removing this connection. To pull the tray out for test purposes, use the extender coaxial cable included in the installation material kit for connection from the tray to the output cable.**

Adjustments to the position of the Trays may be necessary, and are accomplished by loosening the cabinet slide mounting bolts that hold the front of the slide to the mounting frame of the Cabinet and moving the Tray up or down as needed to correct for the rubbing.

The air intake to the 2 kW Translator is intended for room air only. The cabinet should be positioned with consideration taken for adequate air intake and exhaust, the opening of the rear door, access to the Trays including sliding them out for testing, the Main AC Hook-Up and the installation of the Output Transmission Line. The Cabinet should be Grounded using copper strapping material also should be permanently mounted to the floor of the Site using the holes in the bottom of the Cabinet.

Once the Cabinet is in place and the Trays are checked for damage, the Main AC Hook-Up is ready to be made. Before connecting the 230 VAC, make certain that all of the circuit breakers associated with the Translator are switched Off. The Main AC Input circuit to the 2 kW Translator should be an 80 Amp, 230 VAC line, using AWG 6 wire, inside of 1-1/4" conduit.

The 230 VAC Input connections are made to the Terminal Block TB1, which is part of (A2) the AC Distribution Panel, located facing the rear door of the Translator. Terminals 1 & 2 (230 VAC) and Terminal 3 (Chassis Ground). Line 2 is the Neutral for International Systems using 220 VAC Hot and Neutral.

The RF Output at J2 of (A16) the Coupler Assembly, or the (Optional) Trap Filter (A14), which is 7/8" Rigid Coax, should connect to the Transmission Line that is connected to your Antenna System.

The On Channel RF Input connects to the rear of the (A3) VHF/UHF Receiver Tray at the "F" connector J5 for 75Ω or the "N" connector J1 for 50Ω or to the (Optional) (A17) A/V Input &

Remote Interface Panel mounted on the Rear Top of the Translator. A plug is connected to Jack (J11), with Pins 23 & 24 jumpered together on the UHF Exciter or to Jack (J9), with Pins 21 & 22 jumpered together on the (Optional) Remote Interface Assembly, which are 37 Position "D" Connectors that provide the Interlock for the Translator. Jacks J10 and J11 on the UHF Exciter and Jacks J9 and J10 on the (Optional) Remote Interface Assembly, are used to connect the Remote Control functions to the Translator.

This completes the Unpacking and Installation of the 836A 2 kW UHF Solid State Translator. Refer to the Set Up and Operation Procedure that follows before applying power to the Translator.

Initially the Translator should be turned on with the RF Output at (A11) the Coupler Assembly terminated into a dummy load of at least 2000 Watts. If a load is not available, check that the Output of the Coupler Assembly is connected to the Antenna for your System.

Connect the Antenna output to the "F" connector J5 for 75Ω or to the "N" connector J1 for 50Ω, located on the rear of the VHF/UHF Receiver Tray..

Switch On the Main AC, UHF Exciter, Amplifier #1, Amplifier #2, Amplifier #3 and Amplifier #4 Circuit Breakers located on the AC Distribution Panel facing the rear of the Cabinet mounted behind the rear door. On the UHF Exciter Tray, switch the Operate/Standby Switch to Standby and the Auto/Manual Switch to Manual. Normal operation of the Translator is in Automatic. Automatic operation uses the Video Input to the UHF Exciter as an Operate/Standby Switch. In Auto, if the Input Video is lost for approximately 7 seconds, the Translator will automatically revert to Standby and when the Video Signal is restored, the Translator will quickly return to Operate.

Move the Operate/Standby Switch, located on the UHF Exciter Tray, to Operate. Note the power supply reading, +26.5 VDC, on the front panel of the UHF Amplifier Trays. **Note:** If the Translator does not switch to Operate, when the Operate/Standby Switch is switched to Operate, check that an External Interlock Plug, with a Jumper wired from Pins 23 to 24, is connected to Jack (J11) located on the rear of the UHF Exciter or if (A17) the Optional A/V Input & Remote Interface Assembly is present in your System, the External Interlock Plug, with a Jumper wired from Pins 21 to 22, is connected to Jack (J9) on the Assembly. Observe the front panel Meter reading in the % Visual Power position on the UHF Exciter Tray, it should read 100%. If needed, readjust the screwdriver adjust Power pot located on the front panel of the UHF Exciter for 100%. As you are checking the Power Level, check the Meter Reading in the % Reflected Power Position. If the % Reflected Power is very high, above 50%, a problem with the Output Coaxial Lines is present and needs to be checked. A center bullet missing from the 7/8" Rigid Coax Lines or loose bolts on the connections can cause this problem. Return the Operate/Standby Switch to Standby.

The Gain and Phase controls located on the front panels of the individual UHF Amplifier Trays were adjusted at the factory to attain 100% Output of the Translator and should not need readjusted. The front panel readings on the individual UHF Amplifier Trays may not be the same. Refer to the Test Data Sheet for your Translator to compare the final readings from the Factory with the readings on each of the Trays after the Set Up. They should be very close to the same. If a reading is way off, refer to the Phasing and Power Adjustment Procedure for the UHF Amplifier Trays in the Detailed Alignment Procedure before trying to adjust.

If a dummy load is connected to the Translator, switch the Translator to Standby and switch the Main AC Circuit Breaker Off. Remove the dummy load and make all connections needed to connect the Translator to the Antenna for your System. Switch the Main AC Circuit Breaker On and the Operate/Standby Switch to Operate. Adjust the Output Power screwdriver pot to attain 100% Output.

If the Translator is already connected to the Antenna, check that the Output is 100%. If needed adjust the Power screwdriver pot.

If a problem occurred during the Set-Up and Operation Procedure refer to the Detailed Alignment Procedure of the Translator, which follows, for more information.

This completes the Translator Set-Up and Operation Procedure for the 836A UHF Solid State Translator. The Translator can now be operated normally.

UHF Exciter

ALC = .8 VDC.

% Exciter = The level is as needed to attain 100% output power from the Transmitter.

% Reflected = < 5 %

% Visual Power = 100 %

% Aural Power = 100 %

UHF Amplifier Trays

(A6)

AGC Voltage = 1 to 2 VDC.

% Reflected = < 5 % with both Trays operating.
< 50 % with one Tray operating.

% Output Forward = The level is as needed to attain 100% Output Power from the Transmitter

Power Supply = +26.5 VDC.

(A7)

AGC Voltage = 1 to 2 VDC.

% Reflected = < 5 % with both Trays operating.
< 50 % with one Tray operating.

% Output Forward = The Level is as needed to attain 100% Output Power from the Transmitter.

Power Supply = +26.5 VDC.

(A8)

AGC Voltage = 1 to 2 VDC.

% Reflected = < 5 % with all Trays operating.
< 25 % with one Tray operating.
operating.

% Output Forward = The level is as needed to needed to attain 100% Output Power from the transmitter Power from the Transmitter.
Transmitter.

Power Supply = +26.5 VDC.

(A9)

AGC Voltage = 1 to 2 VDC.

% Reflected = < 5 % with all Trays
< 25 % with one Tray
operating.

% Output Forward = The Level is as to attain 100% Output

Power Supply = +26.5 VDC.

UHF Exciter Tray:

<u>Name</u>	<u>Function</u>
<u>"Metering"</u>	
Meter (A4-A18)	Reads power in terms of a percentage of the calibrated Output Power level on the upper scale. The Voltage Level is read on one of the bottom two scales. A full scale reading on the top scale is 100%, which is equivalent to the full rated 2000 Watts Peak of Sync Visual. Also reads % Aural Power, % Exciter Power, % Reflected Power and ALC reading.
Switch (S3), Meter	Selects the desired ALC Voltage reading, % Exciter Power, % Reflected Power, % Visual Power or % Aural Power.
ALC (0-10 V)	Reads the ALC Voltage Level, .8 VDC, on the 0-10 scale.
% Exciter (0-100)	Reads the % Exciter Output Power Level needed to attain 100% Output of the Transmitter on the top scale.
% Aural Power (0-100)	Reads the % Aural Output Power of the Transmitter, 100% = 200 Watts @ 10 dB A/V Ratio, on the top scale.
% Visual Power (0-100)	Reads the % Visual Output Power of the Transmitter, 100% = 2000 Watts Pk Sync, on the top scale.
% Reflected (0-100)	Reads the % Reflected Output Power, <5%, on the top scale.

"Control"

Switches

Transmitter (S1) Operate/Standby	The momentary switch (S1) applies a ground to K1, a latching Operate/Standby relay, located on the Transmitter Control Board. K1 will switch either to Operate or to Standby depending on which direction S1 is pushed. When switched to Operate, the low, Enable Commands, are applied to the four UHF Amplifier Trays. These Enables will turn on the UHF Amplifier Trays. The opposite occurs when switched to Standby.
Mode Select (S2) Auto/Manual	The momentary switch (S2) applies a ground to K2, a latching relay, located on the Transmitter Control Board. K2 will switch the Transmitter to Automatic or Manual depending on which direction S2 is pushed. In Automatic, the Video Fault Command from the ALC Board will control the Operation of the Transmitter. The Transmitter will switch to Standby, after a slight delay, if the input video is lost and will switch back to Operate, quickly, when the Video is restored. In Manual, the

836A 2 kW UHF Translator, Internally Diplexed Meters, Switches, Indicators and Samples

Transmitter is controlled by the Operator using the front panel Operate/Standby Switch or by remote control.

Power Adjust (R1)

The 5 k Ω Pot A20 sets the ALC Level on the ALC Board which sets the output power of the Transmitter.

UHF Exciter Tray:

Name

Function

"Status"

Fault Indicators

Video Loss (DS9 RED)

Indicates that the Input Video has been lost to the Translator. The Fault is generated on the ALC Board located in the UHF Exciter Tray.

VSWR Cutback (DS7 Amber)

Indicates that Reflected Power Level of the Translator has increased above 20 % which will automatically cutback the Output Power Level to 20 %. The Fault is generated on the Transmitter Control Board located in the UHF Exciter Tray.

"Samples"

f(s)

A Sample of the Channel Oscillator Output taken from the Sample Jack of the Channel Oscillator Assembly.

Exciter O/P

An Output Power Sample of the Exciter taken from the UHF Upconverter Board.

Translator O/P

A Forward Power Sample of the Translator taken from the Visual/Aural Metering Board.

VHF/UHF Receiver Tray

"Samples"

f(IF) Output

A Sample of the IF Output taken from the IF Filter/ALC Board.

F(s) Oscillator

A Sample of the Channel Oscillator Output taken from the Sample Jack of the Channel Oscillator Assembly.

UHF Amplifier Trays:

"Metering"

Meter (A6, A7, A8 & A9 - A9)

Reads power in terms of a percent of the calibrated power output value. A full scale reading is 100% which is equivalent to the full rated 600 Watts Peak of Sync Visual + Aural Output

836A 2 kW UHF Translator, Internally Diplexed Meters, Switches, Indicators and Samples

	Power. Also reads % Reflected Power, Power Supply Voltage Levels and AGC Voltage Levels.
Switch (S2), Meter	Selects the desired % Power or the Voltage reading.
% Output Pwr	Reads the % Output Power of the Tray, 100% = 600 Watts Peak of Sync Visual + Aural, on top scale.
% Refl (Reflected)	Reads the % Reflected Output Power of the Tray, <20% with all Amplifier Trays operating A6, A7, A8 & A9, as measured on top scale.
Power Supply	Reads the Power Supply Voltage, +26.5 VDC, on the middle scale.

UHF Amplifier Trays:

Name

Function

"Metering" - Continued

AGC Voltage	Reads the AGC Voltage Level, +1 VDC to +3 VDC, on bottom scale.
-------------	---

"Status"

Indicators

Enable (DS4 Green)	Indicates that an Enable, Operate Command, is applied to the UHF Amplifier Tray from the selected UHF Exciter Tray.
Overdrive (DS2 Red)	Indicates that the level of the drive is too high. The protection circuit will limit the drive to the set threshold. The Fault is generated on the Amplifier Control Board.
VSWR Cutback (DS1 Red)	Indicates that Reflected Power Level of the Tray has increased above 50% which will automatically cutback the Output Power Level to 20 %. The Fault is generated on the Amplifier Control Board.
Overtemp (DS3 Red)	Indicates that the temperature of (A5-A6-A3 & A5-A6-A4) one or both of two Thermal Switches mounted on the heatsink assembly for the output amplifiers is above 175 degrees F. When this Fault occurs the Enable to the Switching Power Supply in the effected Amplifier Tray is removed immediately and it will shut down.
Input Fault (DS5 Red)	Indicates that the Input RF Level to the Amplifier Trays dropped below the 0 dBm Range.

“Control”

Adjustments

Phase (A10-R5)	Adjusts the Phase of the RF Output approximately 70°.
Gain (A11-R6)	Adjust the gain of the RF Output when the Amplifier control Board is in the AGC Mode.

“Sample”

Module O/P (0 dBm)	A Sample of the Combined Output of the four Dual Stage Amplifier Boards taken from the Dual Peak Detector Board.
--------------------	--

This Translator was aligned at the factory and should require no additional alignment to achieve normal operation.

Check that the RF Output at J2 of (A16) the Coupler of the Translator is terminated into a dummy load of at least 2000 Watts. Refer to the Test Data Sheet for your Translator and compare the final readings from the Factory with the readings on each of the Trays while doing the alignment. They should be very close to the same. If a reading is way off, the problem is likely to be in that Tray.

Switch On the Main AC and the UHF Exciter Circuit Breakers located on the AC Distribution Panel mounted behind the rear Cabinet door.

(A3) VHF/UHF Receiver Tray (1265-1100)

Connect a UHF Input (-61 dBm to -16 dBm), with a Multiburst Test signal applied, that is at the On Channel Frequency to Jack J5, "F" type connector for 75Ω or Jack J1, "N" type connector for 50Ω located on the Receiver Tray. Check that the On/Off Circuit Breaker, located on the rear of the Receiver Tray, is On. If the Optional Remote Preamplifier is purchased, the Fuse F1 located in the Receiver Tray must be removed to eliminate the +12 VDC from the input to the Receiver Tray to prevent damage to the Test equipment. Check the Front Panel Sample Jack (J6) with a Frequency Counter. The signal should be at the needed frequency, check the top of the Channel Oscillator Assembly for the actual frequency, to produce the IF Outputs.

(A4) UHF Exciter Tray (1300-1020)

The IF Section of the UHF Exciter Tray includes adjustments for automatic level control (ALC), linearity (amplitude predistortion) and phase (phase change vs. level) predistortion for correction of the nonlinearities of the RF Amplifier Trays. The Upconverter Section also includes adjustments of the local oscillator chain tuning and also the local oscillator center frequency tuning. Both of these were completed at the factory and should not require adjustment at this time.

Move the Operate/Standby Switch located on the UHF Exciter Tray to Standby. The set up of the RF Output, includes adjustment of the drive level to the four UHF Amplifier Trays, the adjustment of the Linearity and Phase Predistortion which compensate for any nonlinear response of the Amplifier Trays and also the gain and phasing adjustments of the four UHF Amplifier Trays.

Verify that all **Red** LEDs located on the ALC Board are extinguished. The following list details the meaning of each LED when illuminated.

DS1 (Input Fault) Indicates abnormally low or no IF is present at the Input of the ALC Board.

DS2 (ALC Fault) Indicates that the ALC circuit is unable to maintain the signal level requested by the ALC reference. Normally this is due to excessive attenuation in the linearity signal path, the IF Phase corrector signal path or that Jumper W3 on J6 is in the Manual ALC Gain position.

DS3 (Video Loss) Indicates a loss of Video at the Input of the ALC Board.

DS4 (Mute) Indicates a Visual Mute Command is present. **Not used in this configuration.**

DS5 (Modulator Enable) Indicates Modulator IF Output is selected. Will be Off if the output of the Receiver Tray is selected.

The ALC is Muted when the Translator is in Standby. To monitor the ALC, turn Off the front panel On/Off circuit breaker located on the Amplifier Trays and switch the Translator to Operate. Adjust

the Power Adjust Gain Pot, located on the Front Panel of the UHF Exciter Tray, to obtain +0.8 VDC on the Front Panel Meter in the ALC Position. On the ALC Board (1265-1305), move the Jumper W3 on J6 to the Manual Position, between Pins 2 & 3, and adjust R87 on the ALC Board for +0.8 VDC on the Front Panel Meter in the ALC Position. Move the Jumper W3 back to Auto, between Pins 1 & 2, which is the normal operating position. The detected IF signal level at J19-2 of the ALC Board is connected to the Transmitter Control Board that distributes the level to the Four UHF Amplifier Trays where it is used as a reference for the automatic gain control (AGC) in each Amplifier Tray.

(A6, A7, A8 & A9) UHF Amplifier Trays (1294-1112 Low Band, 1294-1113 Mid Band, or 1294-1114 High Band)

Check that the output power of the Translator is 100 %, if it is not, adjust the Power screwdriver Adjust Pot located on the front panel of the UHF Exciter Tray as needed to achieve 100%.

When testing one of the UHF Amplifier Trays the other circuit breakers, located on the AC Distribution Panel, should be turned Off. The Amplifier 1 Circuit Breaker applies power to the Top left UHF Amplifier Tray, the Amplifier 2 Circuit Breaker applies power to the bottom left UHF Amplifier Tray, the Amplifier 3 Circuit Breaker applies power to the bottom left UHF Amplifier Tray and the Amplifier 4 Circuit Breaker applies power to the bottom right UHF Amplifier Tray. The UHF Amplifier Trays should be turned on into a dummy load of at least 600 Watts to verify that the Tray is functioning. Preset the AGC Switch on (A8) the Amplifier Control Board (1265-1414) to the AGC On position. The four UHF Amplifier Trays are set up in pairs, the top two A6 with A7 and the bottom two A8 with A9. Switch On the Amplifier 1 Circuit Breaker, located on the AC Distribution Panel. Switch to Operate the Translator Operate/Standby Switch, located on the UHF Exciter, and observe the power supply metering position on the UHF Amplifier Tray. It should read +26.5 VDC when the Tray is switch On and the Translator is in Operate.

Switch the Tray to the % Output Power Meter Position and adjust the front panel Gain pot located on that Amplifier Tray to 100% on the Meter, then back off the Gain Pot to the reading as written on the Test Data Sheet for your Translator. Repeat for the Amplifier 2 Tray of the pair. Switch the Translator to Standby and reconnect the UHF Amplifier Trays to the (A10) UHF Tee Assembly.

Repeat the above procedure for Amplifier 3 and Amplifier 4. After the setup of all four Amplifier Trays, switch the Translator to Operate and adjust the Phase Controls on each of the Amplifier Trays to give maximum Output Power on the Front Panel of the UHF Exciter. The Output Power reading on the front panel of the UHF Exciter should be 100%, if it is not, adjust the Power screwdriver Adjust Pot located on the front panel of the UHF Exciter Tray as needed to achieve the 100% Output.

Switch the Input Test source to select a NTSC 3.58 MHz Modulated Staircase or Ramp Test waveform and set up the station demodulator and monitoring equipment to monitor the differential gain and differential phase of the RF Output signal.

If a synchronous demodulator having a quadrature video output is available, it can be used with an X-Y Oscilloscope to display incidental carrier phase modulation (ICPM). As shipped, the Exciter was preset to include linearity (gain vs. level) and incidental phase (carrier phase vs. level) predistortion. The predistortion was adjusted to approximately compensate the corresponding non-linear distortions of the Amplifier which is driven to place the Sync Level near saturation. Move the Jumper W1 on J4 on the ALC Board to the Enable Position. Refer to the Test Data Sheet for your Translator for the final test readings on each Amplifier Tray. Adjust the Phase Pot located on each UHF Amplifier Tray to obtain maximum % Visual Output Power. Adjust each of the Gain Pots, on the UHF Amplifier Trays, equally, as needed to obtain 100% Visual Output Power on the Front Panel Meter of the UHF Exciter.

Linearity Corrector Adjustment

The IF linearity correction function consists of three non-linear cascaded stages, each having adjustable magnitude and threshold or cut-in points located on the ALC Board. The threshold adjustment determines at what IF signal level the corresponding corrector stage begins to increase gain. The magnitude adjustment determines the amount of gain change for the part of the signal which exceeds the corresponding threshold point. Refer to the UHF Exciter Tray Assembly Drawing (1265-5300), or the Assembly Drawing for (A8) ALC Board (1265-5305), to locate the adjustments for the first through third linearity corrector stages. Because the stages are cascaded, the order of correction is important. The first stage should cut-in near white level, with the cut-in point of the next stage toward black and with the last stage primarily stretching sync.

To adjust the linearity correctors from scratch. Ensure that the Translator is operating at full power with the desired A/V Ratio. Check that the Jumper W1 on J4 on the ALC Board is Enabled, between Pins 1 & 2. Check that the ALC Voltage is set to +0.8 VDC as monitored on the Front Panel Meter in the ALC Position.

Insert a modulated ramp video test signal into the Translator. Demodulate the output signal of the Translator and observe the waveform on a Waveform Monitor while also looking at the signal on a Spectrum Analyzer. On the IF ALC Board (1265-1306), preset the Pots R34, R37 & R40 (Threshold) full CCW, and the Magnitude Adjustments R13, R18 & R23 full CW. On the IF Phase Corrector Board (1227-1250), preset the Pots R7, R15, R23 & R35 full CW, and R3, R11, R19 & R31 full CCW.

Linearity Corrector Adjustment - Continued

Set the Waveform Monitor to Differential Step Filter and the Volts/Division scale to .1V. Center the display around Blanking.

Gradually adjust pots R3, R11 and R19 Clockwise on the IF Phase Corrector Board as needed to minimize the observed thickness of the intermod as seen on the display.

Adjust the pots R34, R37 and R40 Clockwise on the IF ALC Board needed to give correction at Sync or at low luminance levels, which are viewed at the rightmost edge of the Waveform Monitor.

The intermod beat products between the Color Burst and the Aural Carrier at 920 kHz above Visual Carrier should also be observed on the Spectrum Analyzer while performing the preceding adjustments. The frequency will vary for PAL Systems. When the adjustments are performed properly, the intermod products on the Spectrum Analyzer should be at least -52 dB down, with a Red Field input, from peak visual carrier and the Intermod Distortion as displayed on the Waveform Monitor should be no more than 1 IRE. The pot R31 on the IF Phase Corrector Board is used for any extra Intermod correction that may be needed.

It should be noted that any adjustment of the above pots affects other visual parameters and some slight adjustments of all the pots may be needed to meet all specifications simultaneously.

If the Translator is being driven very hard, it may not be possible to get enough Sync Stretch while maintaining a flat differential gain. In this case, some Video Sync Stretch may be used from the Sync Tip Clamp/Modulator Board. The Sync Stretch adjustment is R48 located on the Sync Tip Clamp/Modulator Board. Switch the Translator to Standby.

Phase and Gain Adjustment of the UHF Amplifier Trays

The following procedure was completed at the factory and should only be followed if one of the UHF Amplifier Trays is replaced.

Preset the Phase and Gain potentiometer located on each UHF Amplifier Tray Full CCW. Switch the Translator to Operate and adjust the Gain Pot on each Tray for 25% Output Power. Adjust the Phase Control CW on the Left UHF Amplifier Tray. If the % Visual Output Power goes UP, continue to adjust until either the Peak is reached or the End of Travel is reached. If the % Output Power goes Down, Reset the Phase Control on the UHF Amplifier Tray Fully CCW and repeat the above procedure with the Phase Control of the other Amplifier Tray.

If the End of Travel is reached on the Phase Adjust, Reset the Phase Control CCW and add a 2" length of Cable to the output of the (A5) Splitter Module which connects to the effected UHF Amplifier Tray at J1. Readjust the Phase of that Tray until a Peak is reached or until End of Travel is achieved. If End of Travel is reached, repeat the above procedure replacing the 2" length cable with a 4" length of cable. Once a Peak is reached, move the Phase Control, that is Full CCW, Up 2 Turns and re-peak using the Phase Control located on the other Tray. This allows both Trays to have some range of adjustment.

Adjust the Gain of both UHF Amplifier Trays for 90% Tray Output Power. Readjust each Phase Control to Peak the Combined Output, the Phase should only have been effected slightly. There should be a definite Peak that is achieved while adjusting the Phase of each Tray though it may take a few Turns to notice a change. Raise or Lower the Output Power of each Tray to achieve 100% Output Power. The Output Power of each Tray should be 90% - 100%.

Calibration of the Forward Output Power Level of the Translator

Note: - Perform the following only if the power calibration is suspect.

Switch the Translator to Standby and preset R51, Aural Null pot, located on the Visual/Aural Metering Board (1265-1309), full CCW. Adjust R48, the Null Offset pot, located on the Visual/Aural Metering Board, for 0% Visual Output. Do the following adjustments with no Aural present, by removing the Aural from the RF Input Test Signal. Connect a Sync and Black Test Signal to the Input of the UHF Exciter Tray. Switch the Translator to Operate.

Calibration of the Forward Output Power Level of the Translator.- Continued

Next Set the Translator up for the appropriate Average Output Power Level. (Sync + Black 0 IRE Setup Wattmeter = 1190 Watts). (Sync + Black 7.5 IRE Setup Wattmeter = 1090 Watts).
Note: Must have 40 IRE Units of Sync. Adjust R28, Visual Calibration, located on (A19) the Visual/Aural Metering Board (1265-1309) for 100% on the front panel meter in the % Visual Output Position.

With the Spectrum Analyzer set to Zero Span Mode, obtain a peak reference on the screen. Reinsert the Aural to the RF input test Signal. While in the Visual Output Power position, adjust L3 for minimum visual power reading. Turn the power adjust pot on the front panel until the original peak reference level is attained. Peak L1 and C8 for maximum Aural Power reading, then adjust R20 also for 100% Aural Power reading. Then switch to Visual Output Power position and adjust R51 for 100% Visual Power.

Calibration of the Reflected Output Level of the Translator

Turn the Power Adjust Pot to 20% on the Meter in the Visual Power position, check that the Jumper is in Manual on the UHF Upconverter Board (1265-1310). Unterminate the Translator and adjust R39 on the Visual/Aural Metering Board (1265-1309) for a 20% reading in the Reflected

Power position. At this 20% Reference Power reading, the VSWR LED mounted on the front panel of the Exciter should be illuminated. If not adjust R22 on the Transmitter Control Board until the VSWR LED just turns On. Turn the Power Adjust pot slightly CCW and the LED should go out, turn the pot CW until the LED just turns On. The Reflected Output Power is now calibrated. Switch the Translator to Standby. Re-terminate the Translator. Switch the Translator to Operate and adjust the front panel power pot for 100% Visual Power reading.

IF Phase Corrector Adjustment

As shipped, the Exciter was preset to include linearity (gain vs. level) and phase (phase vs. level) predistortion. The predistortion was adjusted to approximately compensate the corresponding non-linear distortions of the Amplifier Trays and should need no additional adjustment.

Locate (A9) the IF Phase Corrector Board (1227-1250) mounted in the UHF Exciter. The Amplitude Correction portion of the Board is not utilized in this configuration, therefore the Jumper W3 on J10 should be in the Disable Position, to +6.8 VDC, and R35 & R31 should be full CCW. R68 is the Range Adjustment and should be set in the Middle. The Phase Correction Enable/Disable Jumper W2 on J9 should be in the Enable Position, to Ground. Switch the Input Video Test source to select a NTSC 3.58 MHz Modulated Staircase or Ramp Test waveform and set up the station demodulator and monitoring equipment to monitor the Differential Phase or Intermod Products of the RF Output signal. There are three corrector stages, located on the IF Phase Corrector Board, each with a Magnitude and a Threshold Adjustment which are adjusted as needed to correct for any Differential Phase or Intermod problems. Adjust R3 Threshold, for the cut in point of the correction and R7 Magnitude, for the amount of the correction as needed.

The jumper W1 on J8 is set to give the desired polarity of the correction shaped by the Threshold R11 and Magnitude R15 adjustments. After setting the polarity, adjust R11 Threshold, for the cut in point of the correction and R15 Magnitude, for the amount of the correction as needed. Finally, adjust R19 Threshold, for the cut in point of the correction and R23 Magnitude, for the amount of the correction as needed. **Note:** Adjusting these pots changes all Visual parameters and should be used cautiously.

(A10 & A11) UHF High Power Tees

The inputs to the (A10) UHF Tee are the outputs of the (A6 & A7) UHF Amplifier Trays and the inputs to the (A11) UHF Tee are the outputs of the (A8 & A9) UHF Amplifier Trays. The inputs to the UHF Tees are 50 ohm impedances to match the output impedance of the UHF Amplifier Trays. The two inputs to each of the UHF Tees are combined and then sent through a piece of transmission line 1/4 of a wavelength long to transform the output impedance of the Tees to 50 ohms. The outputs of the (A10 & A11) UHF Tee are then sent to (A12) a Hybrid Combiner which combines the two inputs. The output of the Hybrid is connected to (A13) a Bandpass Filter.

The Bandpass Filter and (Optional) Trap Filter are factory swept and should not be tuned without the proper equipment. Do not attempt to tune the filters without a sweep generator and preferably a network analyzer. If you think tuning is needed consult Axcera Field Support Department before beginning.

(A13) Bandpass Filter

The input to this filter is output of the Hybrid Combiner that is the combined output of the UHF Amplifier Trays. The filter is made of aluminum waveguide and has five resonant cavities. The filter has five bolts for tuning adjustments, three located in the middle on left and two on the right, and four or six rods, depending upon the channel, for coupling adjustments between the sections, located on the front of the Bandpass Filter. The Bandpass Filter also utilizes two integral traps at

-4.5 MHz and +9 MHz from F_V at the top and bottom respectively of the left hand side of the Bandpass Filter, looking from the rear of the Cabinet. Refer to the Bandpass Filter Drawing for the location of the adjustments.

To tune the filter, connect a sweep signal to the input of the filter and adjust the five tuning bolts for a 6 MHz bandwidth and a flat frequency response across the desired band. **Note:** The Bandpass Ripple should be ≤ 0.25 dB. The 6 MHz Band should also have a minimum of 20 dB return loss across the pass band.

Refer to the Table below for typical values.

Frequency	Insertion Loss (dB)	Return Loss (dB)
$F_V - 4.5$	≥ 35	
$F_V - 0.5$		≥ 20
F_V	≤ 0.6	≥ 20
F_a	≤ 0.6	≥ 20
$F_V + 8.08$	≥ 15	
$F_V - 9$	≥ 30	
$2F_V$	≥ 30	

(Optional) (A14) One or Two Section Trap Filter

The Trap Sections have been factory tuned and should not need major adjustments. The Trap Filter is Optional and may not be part of your System. The input to the One or Two Section Trap Filter is the output of the Coupler Assembly. The Trap Filter is comprised of 3-1/8" EIA standard transmission line sections connected to the main transmission line. The transmission line assembly consists of 7/8" EIA standard rigid coaxial components.

The Traps on the output Trap Filter are labeled with their Center Frequency relative to the Frequency of the Carrier. (For Example: The Traps labeled -4.5 MHz are tuned for a Center Frequency of 4.5 MHz Lower than the Frequency of the Visual Carrier.)

The Trap Sections are Reflective Notches, adjustable across the entire UHF Frequency Band. The electrical length of the Outer Sleeve and the Center Rod of the Notch can be adjusted to Tune the Notch Frequency. The Depth of the Notch is set by the gap between the Center Conductor of the Trap Section and the Center Conductor of the Main Line. Tight Coupling makes a Deep Notch, while Loose Coupling makes a Shallow Notch.

Fine Tuning, of the Notches Center Frequency can be accomplished with the Tuning Bolts located on the side of the Filter Section. Loosen the nut locking the Bolt in place and adjust the Bolt to change the Frequency of the Notch. Monitor the output of the Translator with a Spectrum Analyzer and Null the Distortion Product with the Bolt. Red Field is a good Video Test Signal to use to see the +8.08 MHz Product. Tighten the nut when the tuning is completed. Hold the bolt in place with a screwdriver as the nut is tightened to prevent it from slipping.

Major Tuning, such as changing the Notch Depth or moving the Notch Frequency more than 1 MHz, the Outer Conductor and the Center Conductor of the Trap Section must both be moved. This requires an RF Sweep Generator to accomplish. Apply the Sweep signal to the Input of the Trap Filter and monitor the Output. Loosen the Clamp holding the Outer Conductor in place and make the length longer to Lower the frequency of the Notch or shorter to Raise the frequency of the Notch. Loosen the Center Conductor with an Allen Wrench and move it Deeper for a Lower Frequency Notch or out for a Higher Frequency Notch. These adjustments must both be made to change the Notch Frequency. Moving only the Center Conductor or the Outer Conductor will effect the Notch Depth in addition to the Center Frequency. The variable that is being adjusted

with this procedure is the length of the Center Conductor inside the Trap Filter. The gap between the Trap and the Main Line should not be changed. Moving only the Inner or the Outer Conductors by itself will effect the Gap and the Notch depth.

To effect the Notch Depth Only, both sections will have to be moved. The Notch Depth is controlled by the Gap between the Center Conductor and the Trap Section. This Gap also has an effect on the Center Frequency. To Deepen the Notch, Shorten the Outer Conductor and pull the Center Conductor Out until the Notch is back in the same place. Move the Sections in the opposite direction to make a Shallow Notch. **Note:** The Trap Filter is typically adjusted for a notch depth of 10 dB.

The Effects of tuning the Output Trap Filter

Lengthening Outer Conductor Only	Notch Frequency Up, Shallower Notch.
Shortening Outer Conductor Only	Notch Frequency Down, Deeper Notch.
Inserting Inner Conductor Deeper	Notch Frequency Down, Deeper Notch.
Inserting Less Inner Conductor	Notch Frequency Up, Shallower Notch.
Tuning Bolt In.....	Notch Frequency Down.
Tuning Bolt Out.....	Notch Frequency Up.
Moving both Inner and Outer Conductors to keep the Same Gap inside	Center Frequency Moves Notch Stays the Same.

After tuning has been completed, tighten the Clamp and the Allen Screws that hold the Conductors. Use the Fine Tuning Bolts to bring the Frequency In. The Final Tuning Adjustments should be completed with the Translator driving the Output Trap Filter for at least one hour to allow for warm-up drift.

This completes the Detailed Alignment Procedure for the Translator. If a problem occurred during the alignment, refer to the Detailed Alignment Procedure for that Tray for more information.

<u>Function</u>	<u>Remote Jack/Pin No.</u>	<u>Interface Type</u>
-----------------	----------------------------	-----------------------

The Remote Connections, as listed below, are made if the Optional (A17) A/V Input & Remote Interface Assembly (1276-1008) **is not present** in your System. Refer to the Interconnect Drawing (1276-8000) for the proper Pin Remote Connections.

UHF Exciter

Translator Enable Interlock	J11-24	J11-24 & 23 must be jumpered together for Normal Operation. (1176-1038) Jumper Jack is used.
Translator Enable Interlock Rtn.	J11-23	

Remote Control Commands:

Translator Standby (Disable)	J11-22	Contact Closure
Translator Standby/Operate Rtn.	J11-21	
Translator Operate (Enable)	J11-20	Contact Closure
Translator Manual	J11-9	Contact Closure
Translator Auto/Manual Rtn.	J11-36	
Translator Auto	J11-8	Contact Closure
Power Level Raise (Optional)	J10-11	Contact Closure
Pwr Lvl Raise/Lower Rtn (Optional)	J10-13	
Power Level Lower (Optional)	J10-12	Contact Closure
Modulator Select (Optional)	J11-10	Contact Closure
Modulator Select Rtn (Optional)	J11-28	

Remote Status Indications:

Translator Operate (Enable) Ind.	J10-3	50mA Max. Current Sink
Operate/Standby Ind. Return	J10-16	
Translator Standby (Disable) Ind.	J10-4	50mA Max. Current Sink
Translator Auto Indicator	J11-7	50mA Max. Current Sink
Auto/Manual Indicator Return	J11-32	
Translator Manual Indicator	J11-6	50mA Max. Current Sink
VSWR Cutback Indicator	J11-37	50mA Max. Current Sink
VSWR Cutback Indicator Return	J11-35	
Video Loss (Fault) Indicator	J11-25	50mA Max. Current Sink
Video Loss (Fault) Ind. Rtn.	J11-31	
Receiver Fault Indicator	J11-12	50mA Max. Current Sink
Visual Output Power	J11-26	1V full scale at 1kW
Visual Output Power Rtn	J11-29	source resistance
Aural Output Power	J11-27	1V full scale at 1kW
Aural Output Power Rtn	J11-30	source resistance

<u>Function</u>	<u>Remote Jack/Pin No.</u>	<u>Interface Type</u>
-----------------	----------------------------	-----------------------

UHF Exciter - Continued**Remote Metering:**

Reflected Power	J10-5	1V full scale at 1kW
Reflected Power Rtn	J10-17	source resistance
Exciter Output Power	J10-10	1V full scale at 1kW
Exciter Output Power Rtn	J10-22	source resistance

UHF Amplifier Trays**Remote Metering:**

Forward Output Power (A6) UHF Amp	J3-3	1V full scale at 1k
Forward Output Power (A6) Rtn	J3-4	source resistance
Reflected O/P Power (A6) UHF Amp	J3-5	1V full scale at 1k
Reflected O/P Power (A6) Rtn	J3-6	source resistance
Forward Output Power (A7) UHF Amp	J3-3	1V full scale at 1k
Forward Output Power (A7) Rtn	J3-4	source resistance
Reflected O/P Power (A7) UHF Amp	J3-5	1V full scale at 1k
Reflected O/P Power (A7) Rtn	J3-6	source resistance
Forward Output Power (A8) UHF Amp	J3-3	1V full scale at 1k
Forward Output Power (A8) Rtn	J3-4	source resistance
Reflected O/P Power (A8) UHF Amp	J3-5	1V full scale at 1k
Reflected O/P Power (A8) Rtn	J3-6	source resistance
Forward Output Power (A9) UHF Amp	J3-3	1V full scale at 1k
Forward Output Power (A9) Rtn	J3-4	source resistance
Reflected O/P Power (A9) UHF Amp	J3-5	1V full scale at 1k
Reflected O/P Power (A9) Rtn	J3-6	source resistance

The above connections are made to Jack (J11), the 37 Position "D" Connector and to J10, the 25 Position "D" Connector, located on rear of the (A4) UHF Exciter or to Jack (J3), the 25 Position "D" Connector, located on the rear of the (A6, A7, A8 & A9) UHF Amplifier Trays. Refer to the Interconnect Drawing (1276-8000) for the proper Pin Remote Connections.

The Remote Connections are made, as listed below, if the Optional (A17) A/V Input & Remote Interface Assembly (1276-1008) **is present** in your System. The Remote Connections are made to Jacks J9 and J10 on the Assembly. Refer to the Interconnect Drawing (1276-8000) for the proper Pin Remote Connections.

<u>Function</u>	<u>Remote Jack/Pin No.</u>	<u>Interface Type</u>
<u>UHF Exciter</u>		
Translator Enable Interlock	J9-21	J9-21 & 22 must be jumpered together for Normal Operation. (1176-1038) Jumper Jack is used.
Translator Enable Interlock Rtn.	J9-22	
<u>UHF Exciter</u> - Continued		
Remote Control Commands:		
Translator Standby (Disable)	J9-9	Contact Closure
Translator Standby/Operate Rtn.	J9-10	
Translator Operate (Enable)	J9-11	Contact Closure
Translator Manual	J9-15	Contact Closure
Translator Auto/Manual Rtn.	J9-16	
Translator Auto	J9-17	Contact Closure
Power Level Raise (Optional)	J9-27	Contact Closure
Pwr Lvl Raise/Lower Rtn (Optional)	J9-28	
Power Level Lower (Optional)	J9-29	Contact Closure
Modulator Select (Optional)	J9-31	Contact Closure
Modulator Select Rtn (Optional)	J9-32	
Remote Status Indications:		
Translator Operate (Enable) Ind.	J9-12	50mA Max. Current Sink
Operate/Standby Ind. Return	J9-13	
Translator Standby (Disable) Ind.	J9-14	50mA Max. Current Sink
Translator Auto Indicator	J9-18	50mA Max. Current Sink
Auto/Manual Indicator Return	J9-19	
Translator Manual Indicator	J9-20	50mA Max. Current Sink
VSWR Cutback Indicator	J9-23	50mA Max. Current Sink
VSWR Cutback Indicator Return	J9-24	
Video Loss (Fault) Indicator	J9-25	50mA Max. Current Sink
Video Loss (Fault) Ind. Rtn.	J9-26	
Receiver Fault Indicator	J9-30	50mA Max. Current Sink
Remote Metering:		
Visual Output Power	J9-1	1V full scale at 1k
Visual Output Power Rtn	J9-2	Source Resistance
Aural Output Power	J9-3	1V full scale at 1k
Aural Output Power Rtn	J9-4	Source Resistance

<u>Function</u>	<u>Remote Jack/Pin No.</u>	<u>Interface Type</u>
Reflected Power	J9-5	1V full scale at 1k
Reflected Power Rtn	J9-6	Source Resistance
Exciter Output Power	J9-7	1V full scale at 1k
Exciter Output Power Rtn	J9-8	Source Resistance

UHF Amplifier Tray

Remote Metering: - Continued

Forward Output Power (A6) UHF Amp	J10-1	1V full scale at 1k
Forward Output Power (A6) Rtn	J10-2	Source Resistance
Reflected O/P Power (A6) UHF Amp	J10-3	1V full scale at 1k
Reflected O/P Power (A6) Rtn	J10-4	Source Resistance
Forward Output Power (A7) UHF Amp	J10-6	1V full scale at 1k
Forward Output Power (A7) Rtn	J10-7	Source Resistance
Reflected O/P Power (A7) UHF Amp	J10-8	1V full scale at 1k
Reflected O/P Power (A7) Rtn	J10-9	Source Resistance

The Remote Connections as listed above are made to Jacks J9 and J10 on the A/V Input & Remote Interface Assembly. Refer to the Interconnect Drawing (1276-8000) for the proper Pin Remote Connections.

VHF L.O. Filter, High Band	1005-1208
Schematic	1005-3208
UHF Filter	1007-1101
Schematic	1007-3101
VHF Channel Filter, Low Band	1034-1202
Schematic	1034-3202
VHF L.O. Filter, Low Band	1034-1211
Schematic	1034-3211
UHF Filter, DC Multiplexed, 50 Ohm	1035-1204
Schematic	1035-3204
(Optional) SAW Filter/Amplifier Board.....	1035-1211
Schematic	1035-3211
UHF Filter, 75/50 Ohm.....	1035-1302
Schematic	1035-3302
UHF Amplifier Board, 50/75 Ohm.....	1035-1303
Schematic	1035-3303
VHF High Band Filter, DC Multiplexed, 50 Ohm.....	1035-1601
Schematic	1035-3601
VHF High Band Filter, DC Multiplexed, Ohm	1035-1602
Schematic	1035-3602
VHF Amplifier Board, Low Noise, 50/75 Ohm.....	1035-1701
Schematic	1035-3701
±12V(3A) Power Supply Board	1092-1206
Schematic	1092-3206
VHF High Band Channel Filter, 2 Section	1093-1202
Schematic	1093-3202
(Optional) IF Carrier Oven Oscillator Board, 38.9 MHz	1100-1206
Schematic	1100-3206
(Optional) IF Filter/Limiter Board.....	1109-1001
Schematic	1109-3001
(Optional) IF PLL Board.....	1109-1002
Schematic	1109-3002
Channel Oscillator Board, Dual Oven.....	1145-1201
Schematic	1145-3201
(Optional) VCXO Board, Dual Oven.....	1145-1204
Schematic	1145-3204
(Optional) IF Amplifier Board, High Gain.....	1197-1126
Schematic	1197-3126

x8 Multiplier Board	1227-1002
Schematic	1227-3002
IF Phase Corrector Board	1227-1250
Schematic	1227-3250
1 Watt Amplifier Board.....	1227-1303
Schematic	1227-3303
4 Way Splitter Board.....	1227-1312
Schematic	1227-3312
Coupler Board Assembly	1227-1316
Schematic	1227-3316
Dual Peak Detector Board, Single Supply	1227-1333
Schematic	1227-3333
Downconverter Amplifier Board.....	1227-1502
Schematic	1227-3502
Dual Stage Amplifier Assembly.....	1227-1503
Schematic	1227-3501
IF Filter/ALC Board	1227-1504
Schematic	1227-3504
x2 Multiplier Board	1227-1524
Schematic	1227-3524
x4 Multiplier Board	1227-1525
Schematic	1227-3525
UHF Amplifier Board, Low Noise	1257-1101
Schematic	1257-3101
UHF Variable Gain Amplifier Board.....	1265-1126
Schematic	1265-3126
VHF Variable Gain Amplifier Board.....	1265-1127
Schematic	1265-3127
ALC Board.....	1265-1305
Schematic	1265-3305
(Optional) EEPROM FSK Identifier Board	1265-1308
Schematic	1265-3308
Visual/Aural Metering Board	1265-1309
Schematic	1265-3309
UHF Upconverter Board	1265-1310
Schematic	1265-3310

Transmitter Control Board	1265-1311
Schematic	1265-3311
+12V(4A)/-12V(1A) Power Supply Board	1265-1312
Schematic	1265-3312
Dual Stage Amplifier Assembly, Mid Band, Class AB.....	1265-1411
Is made from a Generic Dual Stage Amplifier Board, Class AB (1265-1404).	
Schematic	1265-3411
Amplifier Protection Board	1265-1412
Schematic	1265-3412
Dual Stage Amplifier Assembly, Low Band, Class AB.....	1265-1413
Is made from a Generic Dual Stage Amplifier Board, Class AB (1265-1404).	
Schematic	1265-3413
Amplifier Control Board	1265-1414
Schematic	1265-3414
Single Stage Amplifier Assembly, Mid Band, Class A.....	1265-1416
Is made from a Generic Single Stage Amplifier Board, Class A (1265-1415).	
Schematic	1265-3416
Single Stage Amplifier Assembly, High Band, Class A.....	1265-1417
Is made from a Generic Single Stage Amplifier Board, Class A (1265-1415).	
Schematic	1265-3417
Single Stage Amplifier Assembly, Low Band, Class A	1265-1418
Is made from a Generic Single Stage Amplifier Board, Class A (1265-1415).	
Schematic	1265-3418
Dual Stage Amplifier Assembly, High Band, Class AB	1265-1420
Is made from a Generic Dual Stage Amplifier Board, Class AB (1265-1404).	
Schematic	1265-3420
Variable Gain/Phase Board.....	1265-1425
Schematic	1265-3425
Dual Stage Amplifier Assembly, Low Band, Class AB.....	1265-1439
Is made from a Generic Dual Stage Amplifier Board, Class AB (1265-1404).	
Schematic	1265-3439
Dual Stage Amplifier Assembly, Mid Band, Class AB.....	1265-1440
Is made from a Generic Dual Stage Amplifier Board, Class AB (1265-1404).	
Schematic	1265-3440
Dual Stage Amplifier Assembly, High Band, Class AB	1265-1441
Is made from a Generic Dual Stage Amplifier Board, Class AB (1265-1404).	
Schematic	1265-3441

The 836A is designed with components that require little or no periodic maintenance except for the routine cleaning of the Fans and front panels of the Trays.

The amount and time interval between cleanings depends on the conditions within the Transmitter room. While the electronics have been designed to function even if covered with dust. A heavy buildup of dust, dirt or insects will hinder the effectiveness of the cooling of the components and lead to a thermal shutdown or premature failure of the affected Tray.

When the front panels become dust covered, the top covers should be removed and any accumulated foreign material removed. A vacuum cleaner utilizing a small wand type attachment is an excellent way to suction out the dirt. Alcohol and other cleaning agents should not be used unless you are certain that the solvents will not damage components or the silk-screened markings on the Trays and boards. Water based cleaners can be used, but do not saturate the components. The fans and heatsinks should be cleaned of all dust or dirt to permit the free flow of air for cooling purposes.

It is recommended that the operating parameters of the Translator be recorded from the meters on the Exciter and the Amplifier Trays at least once a month. It is suggested that the data be retained in a rugged folder or envelope for the life of the equipment. A sample format for a Log Sheet is included in this section. Photocopies of the Log Sheet should be made for continued data entries.

UHF Exciter

% Aural Power (0 - 100) = _____%
_____%

% Visual Power (0 - 100) = _____%

% Reflected (0 - 100) = _____%

% Exciter (0 - 100) = _____%

ALC (0 - 1 V) = _____V

UHF Amplifier Trays

(A6)

(A7)

AGC Voltage = _____V

AGC Voltage = _____V

% Reflected = _____%

% Reflected = _____%

% Output Forward = _____%

% Output Forward = _____%

Power Supply = _____V

Power Supply = _____V

(A8)

(A9)

AGC Voltage = _____V

AGC Voltage = _____V

% Reflected = _____%

% Reflected = _____%

% Output Forward = _____%

% Output Forward = _____%

Power Supply = _____V

Power Supply = _____V

Date _____

Customer Name _____

Call Letters _____

Technician _____

This Bulletin covers the procedure for the replacement of Flanged RF Amplifier Transistors. These transistors, both Bipolar and FET types, are mounted directly to heat sink assemblies using two mounting screws. This category of transistor covers a number of different types and part numbers, but the information covered in this bulletin is of a general nature and applies to all such transistors.

Caution: Some of the transistors may contain beryllium oxide, a toxic material. If a device becomes damaged and the inner material is exposed do not handle the transistor.

If a Flanged Transistor needs replaced due to failure of the component, the following procedure should be completed during the installation and initial operation of the new component.

1. Remove the voltages to the device that you are about to change. This is accomplished by turning the Transmitter Off, by removing the power plug located on the Opto Bias Board to that device or by removing the fuse located on the Amplifier Protection Board, Dual Bias Protection Board or the Fused Current Metering Board associated with the Transistor Device.
2. Remove the two machine screws that mount the transistor to the heat sink assembly.
3. Using a soldering iron and solder wick, remove the solder from the tabs of the transistor which are soldered to the board. Lift the tabs from the board and carefully remove the transistor from the assembly. Be careful not to peel the track off the PC Board. If there are chip style capacitors soldered to the tabs, they need to be replaced along with the transistor.

Important: Note the position of any chip capacitors which are soldered to the tabs of the transistor and before completely removing the transistor from its mounting place, note how the transistor is mounted on the board, so that the new transistor is mounted properly.

4. Check that the heat sink surface on which the transistor was mounted is free from any debris and is smooth. If the surface is irregular, a piece of 440 sand paper or emery cloth can be used to smooth it. Irregularities in this surface cause poor heat transfer from the transistor to the heat sink.
5. Remove the new transistor from the case, and apply a thin coat of heat sink compound to the bottom surface of the transistor. **Caution:** Only a thin coat of heat sink compound is needed; too much will cause poor heat transfer. Place the new transistor into the area from which the old device was removed. Using the machine screws that were removed in Step 2, mount the new device in place, by first lightly tightening one side then the other. Repeat the process until both sides of the transistor are equally tight.
6. Solder the Base and Collector or Drain and Source Tabs to the board, as the previous transistor was soldered. Check that a good solder flow is achieved and that no solder is shorted to other tracks. Solder new Chip Capacitors, of the same value as removed, in the same locations as they were originally. **Caution:** Use a temperature controlled soldering iron and **Do Not Overheat** the Chip Capacitors as they are soldered in place.
7. Before applying power to the device, the Operating Current of the device must be turned down. This is accomplished by turning the Bias Adjustment Potentiometer located on the Opto Bias Board, GaAs FET Control Board or in the Drain Circuit of the FET Device to the full Counter-Clockwise position.
8. The Idling or Static Current of the Device is initially set with no RF Drive applied to the Device. Remove the RF Drive Signal input to the Device or Module. Start the Set up of the Idling Current by first restoring the Supply Voltage to the Transistor by reversing the process used in

Step 1. **Caution:** If the device being replaced is a GaAs FET, before applying the Positive Voltage to the Device check that the Negative Bias Voltage is applied to the Device.

9. The amount of Static Collector or Drain Current is calculated using Ohm's Law ($I = E/R$). Measure the voltage drop across the Collector or Drain Resistor, one lead on each side of the Resistor. In amplifiers using Bipolar Transistors, the Resistor is located on the Amplifier Board in the Collector Circuit of the Transistor near where the Supply Voltage enters the Board. In amplifiers that have GaAs FETs the Resistor is located on the GaAs FET Control Board or on the Amplifier Board in the Drain Circuit. Adjust the Bias Adjustment Pot located in the Gate Circuit until the desired voltage drop is measured across the .1 ohm resistor. See the Detailed Alignment Procedure for the Tray in which the Amplifier Board is located to find the amount of Collector or Drain Current and the necessary Voltage Drop needed to attain it.

Note: See the Detailed Alignment Procedure for the Tray in which the amplifier board is located to find the amount of collector or drain current and the necessary voltage drop needed to attain it.

10. Reapply the RF Drive to the Module and you are ready for normal operation.