

**Innovator,  
CHV0TD-1/RD-1 thru  
CHV4TD/RD,  
ATSC VHF High Band Transmitter/  
Regenerative Translator**

**Axcera, LLC**  
**103 Freedom Drive • P.O. Box 525 • Lawrence, PA 15055-0525, USA**  
Phone: 724-873-8100 • Fax: 724-873-8105  
[www.axcera.com](http://www.axcera.com) • [info@axcera.com](mailto:info@axcera.com)



**RESTRICTIONS ON USE, DUPLICATION OR DISCLOSURE  
OF PROPRIETARY INFORMATION**

This document contains information proprietary to Axcera, to its affiliates or to a third party to which Axcera may have a legal obligation to protect such information from unauthorized disclosure, use or duplication. Any disclosure, use or duplication of this document or any of the information herein for other than the specific purpose for which it was disclosed by Axcera is expressly prohibited, except as Axcera may otherwise agree in writing. Recipient by accepting this document agrees to the above stated conditional use of this document and this information disclosed herein.

Copyright © 2011, Axcera

## Table of Contents

Introduction .....	1
<i>Manual Overview</i> .....	1
<i>Assembly Designators</i> .....	1
<i>Safety</i> .....	1
<i>Contact Information</i> .....	3
<i>Return Material Procedure</i> .....	3
<i>Limited One Year Warranty for Axcera Products</i> .....	4
System Description .....	11
Unpacking, Installation and Maintenance .....	14
<i>Unpacking</i> .....	14
<i>Installation</i> .....	14
Drawer Slide Installation .....	15
AC Input Connections .....	16
Input and Output Connections .....	17
J11 Power Monitoring Connections .....	19
<i>Maintenance</i> .....	21
Initial On Site Turn On Procedure.....	24
Typical System Operating Parameters .....	25
Typical Problems, Indications and Causes in Exciter/Driver Drawer .....	27
LCD Display and Front Panel LED Indicators .....	27
System Remote Connections to J12.....	29
<i>LCD Front Panel Screens</i> .....	32
<i>Operation Screens</i> .....	33
Device Details Screens - These are read only parameters. ....	35
Device Setup Screens - These are read / write parameters. ....	47
(Optional) Innovator CX Series Web Ethernet Interface Kit (1313100).....	73
Modulator Web Interface.....	75
SNMP Interfaces .....	80
Circuit Descriptions of Boards in the CHV0xD-1 & CHV0xD-4 System.....	81
(A1) 8 VSB Demodulator Board (1308275) - Only used with RD operation .....	81
Overview.....	81
Microcontroller Functions.....	81
Jumper and DIP Switch Settings.....	81
(A2) Digital Modulator Board DM8C (1316332) .....	82
(A5) ALC Board, Innovator CX Series (1315006) .....	82
(A6) Amplifier Assembly (1313959) - Used in the CHV0xD-1 Drawer .....	83
(A6-A1) VHF HB Pre-Driver Assembly (1313899) .....	83
(A6-A2) 50 Watt Amplifier Pallet, Italmec (1313484) .....	83
(A6) 200 Watt Driver Amplifier Assembly (1315010 used w/Axciter Drawer or 1313912 used in all other applications) - Used in the CHVxD-4 .....	83
(A6-A1) 50 Watt Amplifier Pallet, Italmec (1313484) .....	83
(A6-A2) 500 Watt Amplifier Pallet, Italmec (1313581) .....	84
(A7) Output Metering Detector Board (1313747) .....	84
(A8) Control Card, Innovator CX (1312543).....	84
(A9 & A10) Power Supplies used in CHV0xD-1 and CHV0xD-4 .....	85
Circuit Description of External System Metering Board which is only used in Transmitters with multiple external Amplifier Drawers .....	85
(A5) System Metering Board (1312666) .....	85
Circuit Descriptions of Boards in the external VHF amplifier Drawer.....	86
(A7) Amplifier Control Board (1312260) .....	86
(A10) Current Metering Board (1309130) .....	87
(A5) 2 Way VHF Splitter Board (1313941) .....	87

---

(A2 & A3) 500 Watt LDMOS Amplifier Pallets (1313581).....	87
(A6) 2 Way VHF Combiner Board (1313969).....	87
(A8 & A9) VHF Amplifier Drawer Power Supplies.....	88
Circuit Descriptions of Boards in the CHV500B/600B, 500/600 Watt ATSC Amplifier Drawer .....	88
(A7) Amplifier Control Board (1312260) .....	88
(A10) Current Metering Board (1309130) .....	89
(A5) 4 Way Splitter Board (1313938).....	89
(A1, A2, A3 & A4) 500 Watt LDMOS Amplifier Pallets (1313581) .....	89
(A6) 4 Way Combiner Board (1313965) .....	90
(A8 & A9) CHV500B/600B, Two 48 VDC/2250 Watt Power Supplies .....	90
System Set Up Procedure .....	92
ALC Board Set-Up, Forward and Reflected Power Calibration for CHV0xD-4 systems .....	93
Forward and Reflected Power Calibration of Systems with one or more External Amplifier Drawers.....	94
APPENDIX A: .....	1
Innovator CHV0xD VHF High Band Regenerative Translator System and Drawer Drawing List .....	1

## Introduction


### Manual Overview

This manual contains the description of the Innovator CHV0TD-1/RD-1 thru CHV4TD/RD ATSC Transmitter or Regenerative Translator and the circuit descriptions of the boards, which make up the system. The manual also describes the installation, setup and alignment procedures for the system. **Appendix A** of this manual contains the system drawings and parts lists for the Innovator Transmitter or Regenerative Translator System. **NOTES:** 1) Information and drawings on the Axciter Digital Modulator, if part of your system, are contained in the separate Axciter Instruction Manual. 2) Information and drawings on the K-Tech receiver, if part of your system, are contained in the separate K-Tech Instruction Manual. 3) If your system contains dual exciters with a remote interface panel and Exciter control panel, information and drawings on the system and panels are contained in the separate remote interface panel instruction manual.

### Assembly Designators

Axcera has assigned assembly numbers, Ax designations such as A1, where x=1,2,3...etc, to all assemblies, modules, and boards in the system. These designations are referenced in the text of this manual and shown on the block diagram and interconnect drawings provided in Appendix A.

The cables that connect between the boards within a drawer or assembly and that connect between the drawers, racks and cabinets are labeled using markers. Figure 1 is an example of a marked cable. There may be as few as two or as many as four Markers on any one cable. These markers are read starting farthest from the connector. If there are four Markers, the marker farthest from the connector is the system number such as system 1 or transmitter 2. The next or the farthest Marker is the rack or cabinet "A" number on an interconnect cable or the board "A" number when the cable is within a drawer. The next number on an interconnect cable is the Drawer location or Board "A" number. The marker closest to the connector is the jack or connector "J" number on an interconnect cable or the jack or connector "J" number on the board when the cable is within a drawer.



Marker Identification Drawing

### Safety

The Innovator CX Transmitter or Regenerative Translator Systems manufactured by Axcera are designed to be easy to use and repair while providing protection from electrical and mechanical hazards. Please review the following warnings and familiarize yourself with the operation and servicing procedures before working on the system.

**Hazardous Accessibility** – Axcera has made attempts to provide appropriate connectors, wiring and shields to minimize hazardous accessibility.

**Circuit Breakers and Wiring** – All circuit breakers and wire are UL and CE certified and are rated for maximum operating conditions.

**Single Point Breaker or Disconnect** - The customer should provide a single point breaker or disconnect at the breaker box for the main AC input connection to the transmitter.

**Transmitter Ratings** - The transmitter ratings are provided in the text of this manual along with voltage and current values for the equipment.

**Protective Earthing Terminal** - A main protective earthing terminal is provided for equipment required to have protective earthing.

**Read All safety Instructions** - All of the safety instructions should be read and understood before operating this equipment.

**Retain Manuals** - The manuals for the system should be retained at the system site for future reference. Axcera provides two manuals for this purpose; one manual can be left at the office while the other can be kept at the site.

**Heed all Notes, Warnings, and Cautions** - All of the notes, warnings, and cautions listed in this safety section and throughout the manual must be followed.

**Follow Operating Instructions** - All of the operating and use instructions for the system should be followed.

**Cleaning** - Unplug or otherwise disconnect all power from the equipment before cleaning. Do not use liquid or aerosol cleaners. Use only a damp cloth for cleaning.

**Ventilation** - Openings in the cabinet and module front panels are provided for ventilation. To ensure the reliable operation of the system, and to protect the unit from overheating, these openings must not be blocked.

**Servicing** - Do not attempt to service this product yourself until becoming familiar with the equipment. If in doubt, refer all servicing questions to qualified Axcera service personnel.

**Replacement Parts** - When replacement parts are used, be sure that the parts have the same functional and performance characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards. Please contact the Axcera Technical Service Department if you have any questions regarding service or replacement parts.

## **Contact Information**

The Axcera Field Service Department can be contacted by PHONE at **724-873-8100** or by FAX at **724-873-8105**.

Before calling Axcera, please be prepared to supply the Axcera technician with answers to the following questions. This will save time and help ensure the most direct resolution to the problem.

1. What are your Name and the Call Letters for the station?
2. What are the model number and type of system?
3. Is the system digital or analog?
4. How long has the system been on the air? (Approximately when was the system installed?)
5. What are the symptoms being exhibited by the system? Include the current front panel LCD readings and what the status LED is indicating on the front panel of the drawer. If possible, include the LCD readings before the problem occurred.

## **Return Material Procedure**

To insure the efficient handling of equipment or components that have been returned for repair, Axcera requests that each returned item be accompanied by a Return Material Authorization Number (RMA#). The RMA# can be obtained from any Axcera Field Service Engineer by contacting the Axcera Field Service Department at 724-873-8100 or by Fax at 724-873-8105. This procedure applies to all items sent to the Field Service Department regardless of whether the item was originally manufactured by Axcera.

When equipment is sent to the field on loan, the RMA# is included with the unit. The RMA# is intended to be used when the unit is returned to Axcera. In addition, all shipping material should be retained for the return of the unit to Axcera.

Replacement assemblies are also sent with the RMA# to allow for the proper routing of the exchanged hardware. Failure to close out this type of RMA# will normally result in the customer being invoiced for the value of the loaner item or the exchanged assembly.

When shipping an item to Axcera, please include the RMA# on the packing list and on the shipping container. The packing slip should also include contact information and a brief description of why the unit is being returned.

Please forward all RMA items to:

**AXCERA, LLC  
103 Freedom Drive  
P.O. Box 525  
Lawrence, PA 15055-0525 USA**

For more information concerning this procedure, call the Axcera Field Service Department at 724-873-8100.

Axcera can also be contacted through e-mail at **info@axcera.com** and on the Web at **www.axcera.com**.

### **Limited One Year Warranty for Axcera Products**

Axcera warrants each new product that it has manufactured and sold against defects in material and workmanship under normal use and service for a period of one (1) year from the date of shipment from Axcera's plant, when operated in accordance with Axcera's operating instructions. This warranty shall not apply to tubes, fuses, batteries, bulbs or LEDs.

Warranties are valid only when and if (a) Axcera receives prompt written notice of breach within the period of warranty, (b) the defective product is properly packed and returned by the buyer (transportation and insurance prepaid), and (c) Axcera determines, in its sole judgment, that the product is defective and not subject to any misuse, neglect, improper installation, negligence, accident, or (unless authorized in writing by Axcera) repair or alteration. Axcera's exclusive liability for any personal and/or property damage (including direct, consequential, or incidental) caused by the breach of any or all warranties, shall be limited to the following: (a) repairing or replacing (in Axcera's sole discretion) any defective parts free of charge (F.O.B. Axcera's plant) and/or (b) crediting (in Axcera's sole discretion) all or a portion of the purchase price to the buyer.

Equipment furnished by Axcera, but not bearing its trade name, shall bear no warranties other than the special hours-of-use or other warranties extended by or enforceable against the manufacturer at the time of delivery to the buyer.

**NO WARRANTIES, WHETHER STATUTORY, EXPRESSED, OR IMPLIED, AND NO WARRANTIES OF MERCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE, OR FREEDOM FROM INFRINGEMENT, OR THE LIKE, OTHER THAN AS SPECIFIED IN PATENT LIABILITY ARTICLES, AND IN THIS ARTICLE, SHALL APPLY TO THE EQUIPMENT FURNISHED HEREUNDER.**



**⚠ WARNING!!!**

**< HIGH VOLTAGE >**


**DO NOT ATTEMPT TO REPAIR OR TROUBLESHOOT THIS EQUIPMENT UNLESS YOU ARE FAMILIAR WITH ITS OPERATION AND EXPERIENCED IN SERVICING HIGH VOLTAGE EQUIPMENT. LETHAL VOLTAGES ARE PRESENT WHEN POWER IS APPLIED TO THIS SYSTEM. IF POSSIBLE, TURN OFF POWER BEFORE MAKING ADJUSTMENTS TO THE SYSTEM.**

**★ RADIO FREQUENCY RADIATION HAZARD ★**

**MICROWAVE, RF AMPLIFIERS AND TUBES GENERATE HAZARDOUS RF RADIATION THAT CAN CAUSE SEVERE INJURY INCLUDING CATARACTS, WHICH CAN RESULT IN BLINDNESS. SOME CARDIAC PACEMAKERS MAY BE AFFECTED BY THE RF ENERGY EMITTED BY RF AND MICROWAVE AMPLIFIERS. NEVER OPERATE THE TRANSMITTER SYSTEM WITHOUT A PROPERLY MATCHED RF ENERGY ABSORBING LOAD OR THE ANTENNA ATTACHED. KEEP PERSONNEL AWAY FROM OPEN WAVEGUIDES AND ANTENNAS. NEVER LOOK INTO AN OPEN WAVEGUIDE OR ANTENNA. MONITOR ALL PARTS OF THE RF SYSTEM FOR RADIATION LEAKAGE AT REGULAR INTERVALS.**

## EMERGENCY FIRST AID INSTRUCTIONS

Personnel engaged in the installation, operation, or maintenance of this equipment are urged to become familiar with the following rules both in theory and practice. It is the duty of all operating personnel to be prepared to give adequate Emergency First Aid and thereby prevent avoidable loss of life.



### RESCUE BREATHING

1. Find out if the person is breathing.

You must find out if the person has stopped breathing. If you think he is not breathing, place him flat on his back. Put your ear close to his mouth and look at his chest. If he is breathing you can feel the air on your cheek. You can see his chest move up and down. If you do not feel the air or see the chest move, he is not breathing.

2. If he is not breathing, open the airway by tilting his head backwards.

Lift up his neck with one hand and push down on his forehead with the other. This opens the airway. Sometimes doing this will let the person breathe again by himself.

3. If he is still not breathing, begin rescue breathing.

-Keep his head tilted backward. Pinch nose shut.  
-Put your mouth tightly over his mouth.  
-Blow into his mouth once every five seconds  
**-DO NOT STOP** rescue breathing until help arrives.

LOOSEN CLOTHING - KEEP WARM

Do this when the victim is breathing by himself or help is available. Keep him as quiet as possible and from becoming chilled. Otherwise treat him for shock.

### BURNS

**SKIN REDDENED:** Apply ice cold water to burned area to prevent burn from going deeper into skin tissue. Cover area with a clean sheet or cloth to keep away air. Consult a physician.

**SKIN BLISTERED OR FLESH CHARRED:** Apply ice cold water to burned area to prevent burn from going deeper into skin tissue.

Cover area with clean sheet or cloth to keep away air. Treat victim for shock and take to hospital.

**EXTENSIVE BURN - SKIN BROKEN:** Cover area with clean sheet or cloth to keep away air. Treat victim for shock and take to hospital.

## dBm, dBw, dBmV, dB $\mu$ V, & VOLTAGE EXPRESSED IN WATTS

### 50 Ohm System

WATTS	PREFIX	dBm	dBw	dBmV	dB $\mu$ V	VOLTAGE
1,000,000,000,000	1 TERAWATT	+150	+120			
100,000,000,000	100 GIGAWATTS	+140	+110			
10,000,000,000	10 GIGAWATTS	+130	+100			
1,000,000,000	1 GIGAWATT	+120	+ 99			
100,000,000	100 MEGAWATTS	+110	+ 80			
10,000,000	10 MEGAWATTS	+100	+ 70			
1,000,000	1 MEGAWATT	+ 90	+ 60			
100,000	100 KILOWATTS	+ 80	+ 50			
10,000	10 KILOWATTS	+ 70	+ 40			
1,000	1 KILOWATT	+ 60	+ 30			
100	1 HECTROWATT	+ 50	+ 20			
50		+ 47	+ 17			
20		+ 43	+ 13			
10	1 DECAWATT	+ 40	+ 10			
1	1 WATT	+ 30	0	+ 77	+137	7.07V
0.1	1 DECIWATT	+ 20	- 10	+ 67	+127	2.24V
0.01	1 CENTIWATT	+ 10	- 20	+ 57	+117	0.707V
0.001	1 MILLIWATT	0	- 30	+ 47	+107	224mV
0.0001	100 MICROWATTS	- 10	- 40			
0.00001	10 MICROWATTS	- 20	- 50			
0.000001	1 MICROWATT	- 30	- 60			
0.0000001	100 NANOWATTS	- 40	- 70			
0.00000001	10 NANOWATTS	- 50	- 80			
0.000000001	1 NANOWATT	- 60	- 90			
0.0000000001	100 PICOWATTS	- 70	-100			
0.00000000001	10 PICOWATTS	- 80	-110			
0.000000000001	1 PICOWATT	- 90	-120			

### TEMPERATURE CONVERSION

$$^{\circ}\text{F} = 32 + [(9/5) ^{\circ}\text{C}]$$

$$^{\circ}\text{C} = [(5/9) (^{\circ}\text{F} - 32)]$$

**USEFUL CONVERSION FACTORS**

<b>TO CONVERT FROM</b>	<b>TO</b>	<b>MULTIPLY BY</b>
mile (US statute)	kilometer (km)	1.609347
inch (in)	millimeter (mm)	25.4
inch (in)	centimeter (cm)	2.54
inch (in)	meter (m)	0.0254
foot (ft)	meter (m)	0.3048
yard (yd)	meter (m)	0.9144
mile per hour (mph)	kilometer per hour(km/hr)	1.60934
mile per hour (mph)	meter per second (m/s)	0.44704
pound (lb)	kilogram (kg)	0.4535924
gallon (gal)	liter	3.7854118
U.S. liquid		
(One U.S. gallon equals 0.8327 Canadian gallon)		
fluid ounce (fl oz)	milliliters (ml)	29.57353
British Thermal Unit	watt (W)	0.2930711
		per hour (Btu/hr)
horsepower (hp)	watt (W)	746


**NOMENCLATURE OF FREQUENCY BANDS**

<b>FREQUENCY RANGE</b>	<b>DESIGNATION</b>
3 to 30 kHz	VLF - Very Low Frequency
30 to 300 kHz	LF - Low Frequency
300 to 3000 kHz	MF - Medium Frequency
3 to 30 MHz	HF - High Frequency
30 to 300 MHz	VHF - Very High Frequency
300 to 3000 MHz	UHF - Ultrahigh Frequency
3 to 30 GHz	SHF - Superhigh Frequency
30 to 300 GHz	EHF - Extremely High Frequency

**LETTER DESIGNATIONS FOR UPPER FREQUENCY BANDS**

<b>LETTER</b>	<b>FREQ. BAND</b>
L	1000 - 2000 MHz
S	2000 - 4000 MHz
C	4000 - 8000 MHz
X	8000 - 12000 MHz
Ku	12 - 18 GHz
K	18 - 27 GHz
Ka	27 - 40 GHz
V	40 - 75 GHz
W	75 - 110 GHz

### RETURN LOSS VS. VSWR



---

**ABBREVIATIONS/ACRONYMS**

<b>AC</b>	Alternating Current	<b>dBmV</b>	Decibel referenced to 1 millivolt
<b>AFC</b>	Automatic Frequency Control	<b>dBw</b>	Decibel referenced to 1 watt
<b>ALC</b>	Automatic Level Control	<b>FEC</b>	Forward Error Correction
<b>AM</b>	Amplitude Modulation	<b>FM</b>	Frequency Modulation
<b>AGC</b>	Automatic Gain Control	<b>FPGA</b>	Field Programmable Gate Array
<b>ARD</b>	A-line, Regenerative Translator, Digital	<b>Hz</b>	Hertz
<b>ATD</b>	A-line, Transmitter, Digital	<b>ICPM</b>	Incidental Carrier Phase Modulation
<b>ATSC</b>	Advanced Television Systems Committee (Digital)	<b>I/P</b>	Input
<b>AWG</b>	American Wire Gauge	<b>IF</b>	Intermediate Frequency
<b>BER</b>	Bit Error Rate	<b>LED</b>	Light emitting diode
<b>BRD</b>	B-line, Regenerative Translator, Digital	<b>LSB</b>	Lower Sideband
<b>BTD</b>	B-line, Transmitter, Digital	<b>LDMOS</b>	Lateral Diffused Metal Oxide Semiconductor Field Effect Transistor
<b>BW</b>	Bandwidth	<b>MPEG</b>	Motion Pictures Expert Group
<b>COFDM</b>	Coded Orthogonal Frequency Division Multiplexing modulation scheme	<b>NTSC</b>	National Television Systems Committee (Analog)
<b>DC</b>	Direct Current	<b>O/P</b>	Output
<b>D/A</b>	Digital to Analog	<b>PLL</b>	Phase Locked Loop
<b>DSP</b>	Digital Signal Processing	<b>PCB</b>	Printed Circuit Board
<b>DTV</b>	Digital Television	<b>QAM</b>	Quadrature Amplitude Modulation
<b>dB</b>	Decibel	<b>SMPTE</b>	Society of Motion Picture and Television Engineers
<b>dBm</b>	Decibel referenced to 1 milliwatt	<b>VSB</b>	Vestigial Side Band

## **System Description**

The Innovator CHV transmitter systems are of two different types. They are either Regenerative Translators example: CHV0RD-4, or DTV Transmitters example: CHV0TD-4. The Regenerative Translator (RD) accepts an RF On Channel signal (-75 to -8 dBm) and converts it to a DTV RF On Channel output signal. The DTV System (TD) takes a SMPTE-310 or DVB-ASI input and converts it to a DTV RF On Channel output signal. The output power of either configuration is typically up to 200 Watts ATSC using a single drawer. For powers above 850W additional amplifiers may be paralleled. Typical configurations; 1600 Watts ATSC with two Amplifier drawers, 2000 Watts ATSC with three Amplifier drawers, 3000 Watts ATSC with four Amplifier drawers, 4000 Watts ATSC with six Amplifier drawers, and 6000 Watts ATSC with eight Amplifier drawers. The Innovator CHV transmitter system provides linear and nonlinear correction capability for the transmission path as well as internal test sources that are used during initial system installation.

The CHV0xD-1 and CHV0xD-4 are used as the driver drawer for higher power systems and contain the DM8C Digital Modulator (1316332). Systems with an external Axciter Modulator Drawer the DM8C Digital Modulator and is replaced by the (A3) Down-converter Board (131103). The amplifier assembly (A6), (A7) Output Metering Detector Board (1313747), (A8) the Innovator CX Control Board (1312543), (A9) the +5V, ±12V Power Supply and (A10) the +28V/+42VDC Power Supply are also contained in the drawer. The RD kit (1310182) supplies the (A1) 8 VSB Demodulator Board (1308275) to the drawer to make it a regenerative translator.

The type of (A6) Amplifier assembly used in the drawer changes as the output power of the system changes. The Amplifier Assembly (1315013 or 1313959) is used in CHV0xD-1 systems and the Amplifier Assembly (1315010 or 1313912) is used in CHV0xD-4 systems.

The (A10) Power Supply Assembly also changes as the output power of the system changes. A +48V/300W Power Supply is used in CHV0xD-1 systems and a +48V/1100W Power Supply is used in CHV0xD-4 systems.

When configured as an ATSC Transmitter (TD) with internal DM8C modulator, the TS input at (J1) can be SMPTE-310M or DVB-ASI. When configured to operate as a Regenerative Translator (RD), the DTV ON Channel RF Input at (J1) (-8 to -79 dBm) connects to the Tuner Input Jack on (A1) the 8 VSB Demodulator Board (1308275) supplied with the (RD) kit. The 8 VSB Demodulator Board (1308275) converts the DTV input to a SMPTE-310 output at (J13) that connects to the input of the DM8C Digital Modulator Board (1316332). The rest of the drawer operates the same for both the RD and TD systems.

The RF output of the DM8C modulator board can be any frequency from 30 – 1000MHz in steps of 1 Hz. This output connects to J1 on the ALC board (1315006). The RF on channel signal is fed to the ALC Board which is used to control the drive power to the RF amplifier chain. In a CHV0xD-1, the RF is connected to the (A6) Amplifier Assembly (1315024 or 1313959). This Amplifier assembly is made up of (A6-A1) the VHF HB Pre-Driver Amplifier (1313899) and (A6-A2) the 50 Watt digital amplifier pallet (1313484). The assembly has approximately 36 dB of gain. The amplified output at approximately +38 dBm

connects to the (A7) Output Metering Detector Board (1313747) which provides forward (2V=100%) and reflected (2V=25%) power samples to the CX Control Board (1312543) for metering and monitoring purposes. An output power sample is also supplied to the front panel sample jack J15 which is a 50Ω BNC type. The typical sample value in a CHV0xD-1 or CHV0xD-4 is approximately 60dB down from the output power level of the drawer. The RF output is cabled to J2 the "N" connector RF output jack on the rear panel of the drawer. In the single drawer systems the output connects to a digital mask filter, low pass filter (if present), and then the antenna for your system. In systems with external amplifiers, the RF output from the driver drawer is connected to J1 on the rear panel of the amplifier drawer. The RF is cabled to J1 on the amplifier heat-sink assembly in the amplifier drawer. In systems with more than one external amplifier the RF is connected to a splitter and then to the inputs of the amplifier drawers.

Systems with one external amplifier in the system will be configured with a CHV0xD-1 driver drawer. The external VHF amplifier can be configured with two, three or four RF pallets, depending on the desired RF output power and system configuration. The control and operating parameters of the external amplifier are displayed on the LCD Screen of the driver drawer. In the external amplifier drawer the RF input signal to the drawer is at J1 on the rear panel of the drawer that is cabled to J1 on the splitter and then to J1 on the amplifier pallets. The amplifier drawer may contain one or two +48VDC power supplies. The output of the supplies is connected through a current metering board to the two, three or four amplifier pallets, depending on the configuration. In systems with the N+1 power supply option, two +48VDC power supplies are diode-or together to provide the operating voltage through the current metering board to two amplifier pallets. If one power supply should malfunction, the other power supply will provide the necessary power to maintain full output power. Each pallet has approximately 15 dB of gain and is connected to a combiner before it is cabled to J2 the 7/16 DIN RF output jack of the drawer. The combiner supplies a forward and a reflected power sample to the amplifier control board for metering and monitoring purposes. The typical sample value at J6, a 50Ω BNC jack located on the front panel of the amplifier drawer, is approximately 65dB down from the output power level of the drawer.

Systems with higher output power require multiple amplifier drawers to be used along with splitters and combiners to produce the desired output. A System Metering Board (1312666) provides forward, reflected, over-temperature and other parameters to the exciter/driver drawer from the external power amplifier chain. Refer to the system documentation provided with your system for more detailed drawings and configurations. The CHV6TD is made up two cabinets one of which contains a driver drawer, a three way splitter, three amplifier drawers and a three way combiner with reject load. The other cabinet contains a three way splitter, three amplifier drawers and a three way combiner with reject load. The outputs of the amplifier cabinets are combined in a two way combiner with reject load. The CHV8TD is made up two cabinets one of which contains a driver drawer, a four way splitter, four amplifier drawers and a four way combiner with reject load. The other cabinet contains a four way splitter, four amplifier drawers and a four way combiner with reject load. The outputs of the amplifier cabinets are combined in a two way combiner with reject load. The reject loads in the multi-amplifier systems have thermal switches connected to them which monitor



the temperature of the load and provide the over-temperature fault, if it occurs, through the system metering board to the exciter/driver drawer.

The on-channel RF output of the amplifier drawer either connects directly to the digital mask filter and low pass filter (if present), and then to the antenna in single amplifier systems or to a combiner, the digital mask filter, low pass filter (if present), output coupler and finally to the antenna in multiple amplifier systems. The output coupler provides a forward and a reflected power sample to the system metering board which detects the samples and supplies the forward and reflected power levels to the exciter/driver drawer for use in the metering circuits.

**NOTE:** Systems with the DM8C Modulator will have two samples for the adaptive equalization process, the Pre-Filter and the Post-Filter Samples.

**Pre-Filter Sample (Non-Linear Distortion) NOTE:** Only found in systems with a DM8C modulator.

The pre-filter sample from the (A5) coupler connects to J3 on the exciter/driver drawer. The level must be between -10 to +10 dBm.

**Post-Filter Sample (Linear Distortion) NOTE:** Only found in systems with a DM8C modulator.

A forward power sample, post filter sample, from the (A9) coupler at the output of the DTV filter connects to J4 on the exciter/driver drawer. The level must be between -10 to +10 dBm.

## Unpacking, Installation and Maintenance

### Unpacking

Axcera certifies that upon leaving our facility all equipment was undamaged and in proper working order. It is imperative that all packages be inspected immediately upon arrival to verify that no damage occurred in transit to the site. Inspect all packages for exterior damage and make note of any dents, broken seals, or other indications of improper handling. Carefully open each package and inspect the contents for damage. Verify that all materials are enclosed as listed on the packing slip. Report any shortages to Axcera. In the event any in transit damage is discovered, report it to the carrier. Axcera is not responsible for damage caused by the carrier. If the equipment is not going to be installed immediately, return all items to their original packaging for safe storage. Save all packing material for future use. If equipment is ever removed from the site, the original packaging will ensure its safe transport.




Figure 1: CHV2TD/RD Front View Typical Racking Plan

### Installation

The Innovator CX series transmitters are designed for simple installation. Expensive test equipment is not required for installation and set up and to keep a system operational. An information decal, with Voltage Range, Current Range, Manufacturer, Model and ratings is attached to the rear panel of the stand alone drawer or if mounted in a cabinet, to the top of the frame above the door facing the rear of the cabinet. Prior to installing the product, review the following items. Check that they been installed, tested and/or inspected.

- Building Structure
- Electrical Systems
- Heating and Air Conditioning
- Receive Antenna or Satellite Dish and input cabling
- Optional ASI to S310 Converter, if needed
- Transmit Antenna and output transmission line

The Innovator CX series systems are 17" (43.2cm) wide standard rack mountable drawers. They are supplied with side mounted drawer Slides for ease of installation and removal. The CHV0TD/RD-1 and CHV0TD/RD-4 systems are 3 RU, 5.25" (13.3cm) high. The external amplifier used in CHV1TD/RD-1, CHV1TD/RD-2, and CHVTD/RD-3 systems is 9 RU 15.75" (40cm) high, includes 3 RU 5.25" (13.3cm) for the driver and 6 RU 10.5" (26.7cm) for the external amplifier drawer. The CHV2TD/RD systems are typically mounted in a 55" (139.7cm) cabinet. The CHV3TD/RD and CHV4TD/RD systems are typically mounted in a 76" (193cm) cabinet. The CHV3TD/RD systems are 21 RU, 36.75" (93.3cm) high, which is 3 RU, 5.25" (13.3cm) for the driver and 18 RU, 31.5" (80cm) for the three Innovator CHV amplifier drawers. The CHV4TD/RD systems are 27 RU, 47.25" (120cm) high, which is 3 RU, 5.25" (13.3cm) for the driver and 24 RU, 42" (106.7cm) for the four Innovator CHV Series amplifier drawers.

Also needed for FCC compliance operation is an ATSC filter on the broadcast channel that connects to the output of the system. Space must be provided for the ATSC filter, combiners, reject loads, and low pass filter (if present) whose dimensions will vary depending on manufacturer and channel. Refer to the vendor supplied information included with your system for specific dimensions. Make sure that the space provided for the CX series equipment is sufficient and includes the splitters, combiners, reject loads and external filters. Check that any additional equipment, which is included in the system that extends above or to the side of the mounting rack, has sufficient clearance space. Refer to the custom racking plan for the system for detailed information.

### Drawer Slide Installation

If the system is pre-mounted in a cabinet skip this section. Locate the drawer slides included in the installation material for your system. See Figure 2 and the manufacturers instructions included with the drawer slides for the cabinet mounting instructions. Install the left drawer slide into the left side of the cabinet (as viewed from the rear). Allow 3 RU or 5.25" (13.3cm) of space between the drawers for a CHV0xD-1 or CHV0xD-4 system. In high power systems, allow a space of 3 RU, 5.25" (13.3cm) for the driver and 6 RU, 10.5" (26.7cm) for each of the Innovator CHV external amplifier drawers. Space must also be provided for the splitter, combiner, ATSC filter and low pass filter (if present). The dimensions will vary depending on the manufacturer and the output power. Secure the left drawer slide by connecting it to the front and rear mounting bars using No. 10 screws and the bar nuts that have been provided. Install the drawer slide on the right side of the cabinet (as viewed from the rear) making sure that it is aligned with the drawer slide on the left side. Secure the slide by connecting it to the front and rear mounting bars using No. 10 screws and the bar nuts that have been provided. Repeat this process for any other drawers if purchased. With both slides in place, slide the drawer or drawers into the cabinet.




Figure 2: Cabinet Slides

### **AC Input Connections**

The CHV0xD-1 will operate on any AC voltage from 95 – 253VAC, the CHV0xD-4 single drawer systems will operate with an input voltage of 185-253VAC. The customer should provide a single point disconnect for the main AC input connection to the transmitter. Check that the AC switch located on the rear of the drawer above the AC power jack is OFF. Connect the AC power cord supplied with the drawer from J6 on the rear of the drawer to the AC source.

Check that the ON/OFF circuit breaker(s) for the amplifier drawer(s) located on the rear panel on either side of the AC power jack are OFF. Connect the AC power cord(s) supplied with the drawer(s) from J10 on the rear of the drawer to the 230 VAC source. Refer to Table 1 for typical voltage and current requirements. More detailed information refer to the system drawings or interconnects that came with your system. Additional information will be provided on the data label located on the rear of the rack or cabinet.

If the system is mounted in a rack an AC distribution box wired to a quad receptacle box is used to connect the AC to the individual drawers. The AC distribution box is mounted on the upper right side of the rack accessed through the back of the rack. The main AC input for a transmitter is 195-253VAC, with at least 10Amps, 50/60Hz. The customer should provide a single point disconnect for the main AC input that connects to the transmitter. The AC input lines connect inside the AC distribution box by first removing the two screws that hold the cover plate to the front of the AC distribution box. Then connect the three wire main AC input to the input lugs, L1 to L1, L2 to L2 and Ground to Ground. The power amplifier drawer and the quad receptacle box connect through AC power cords directly to the AC distribution box. The AC power to the optional receiver drawer and the exciter/driver drawer are connected through AC power cords that plug into the quad receptacle box.

If the system is mounted in a cabinet it may contain an AC distribution panel with breakers to distribute the AC power to the individual drawers. The AC distribution panel is mounted facing the rear of the cabinet and accessed through the back of the cabinet. The main AC input for a transmitter is, 195-253VAC. The customer should provide a single point disconnect for the main AC input that connects to the transmitter. The AC input lines connect to the AC distribution panel by first removing the four #8 screws that hold the cover plate to the front of the AC distribution panel. Then connect the three wire main AC input to the input lugs located at the top left of the AC distribution panel, L1 to L1,

L2 to L2 and Ground to the Ground lug on the left. The AC distribution panel in a system with two PA's has three circuit breakers that distribute the AC to the individual drawers, which are the Exciter and the two power amplifier drawers. The circuit breakers, which are accessed through the rear door of the cabinet, supply the AC through AC line cords, that connect to the AC input jacks mounted on the rear panels of the drawers. CB1 is a 30 Amp circuit breaker which supplies the AC to the (A2), top, Power Amplifier A drawer. CB2 is a 30 Amp circuit breaker which supplies the AC to the (A3), bottom, Power Amplifier B drawer. CB3 is a 10 Amp circuit breaker which supplies the AC to the (A1) Exciter/Driver drawer. A maximum of four 30 Amp circuit breakers for four amplifier drawers and two 10 Amp circuit breakers for two Exciter/Driver drawers can be installed in the AC Distribution Panel. All other systems are configured with more or less circuit breakers to provide the protection for the AC to the individual exciter, exciter driver and amplifier drawers.

Table 1: CHVxD series ATSC Digital Systems Typical AC Input and Current Requirements.

System	O/P Power	Power Consumption	Voltage	Current	
CHV0xD-1	20 Watts	200 Watts	115 VAC	1.8 Amps	to the Cabinet
			230 VAC	1 Amp	
CHV0xD-4	200 Watts	1000 Watts	230 VAC	4.4 Amps to the Cabinet	
CHV1xD-1	400 Watts	2200 Watts	230 VAC	9.6 Amps to the Cabinet	
CHV1xD-2	600 Watts	2700 Watts	230 VAC	11.8 Amps to the Cabinet	
CHV1xD-3	850 Watts	3000 Watts	230 VAC	13.1 Amps to the Cabinet	
CHV2xD-1	1000 Watts	5100 Watts	230 VAC	22.2 Amps to the Cabinet	
CHV2xD-2	1600 Watts	7200 Watts	230 VAC	31.3 Amps to the Cabinet	
CHV3xD	2200 Watts	10000 Watts	230 VAC	43.5 Amps to the Cabinet	
CHV4xD	3000 Watts	14700 Watts	230 VAC	63.9 Amps to the Cabinet	
CHV6TD	4500 Watts	19600 Watts	230 VAC	Exciter Amp Cab	43.5 Amps
				Amplifier Cabinet	41.8 Amps
CHV8TD	6000 Watts	29000 Watts	230 VAC	Exciter Amp Cab	63.9 Amps
				Amplifier Cabinet	62.2 Amps

### Input and Output Connections

The input and output connections to the system are made to the jacks mounted on the rear panels of the CHV0xD-1 and CHV0xD-4 systems. Each exciter/driver will accept a SMPTE-310 or ASI (BTD) input and output a digital RF ON Channel signal. Refer to Tables 2 & 2A that follow for the locations and information on the jacks and connectors.




Figure 2A: Rear View CHV exciter/driver

Table 2A: Connections for the CHV20B, CHV200B and the driver for the CHV400B & higher power systems

Port	Type	Function	Impedance
J1	BNC	Input A: On Channel RF Input (BRD) -75 to -8 dBm or SMPTE-310 Input/ASI (TD)	50 Ohms
J3	BNC	Pre-filter sample for DM8C modulator. -10 to +10 dBm	50 Ohms
J4	BNC	SMPTE-310 Output (RD Only) Normally jumpered to J5. Post-filter sample for DM8C modulator. -10 to +10dBm	50 Ohms
J5	BNC	SMPTE-310 Input (RD Only) Normally jumpered to J4.	50 Ohms
	TNC	GPS Antenna Input (Only used with Internal GPS Kit)	75 Ohms
J6	BNC	10 MHz Input: Optional External 10 MHz Reference Input or 10 MHz input from J12 on Axciter Drawer.	50 Ohms
J7	BNC	1 PPS Input: Optional External 1 PPS Reference Input	50 Ohms
J9	N	RF Output: On Channel RF Output	50 Ohms
J10	IEC	AC Input: AC input connection to 85-264VAC Source and On/Off circuit breaker	N/A
J11	9 Pos Male D	Power Monitoring: Interface to System and external amplifier drawers, if present. Also provides an interlock for the Reject Load (if used). If not used, in systems with no external amplifier, a jumper from J11-6 to J11-9 needs to be in place. Refer to Table 2B which follows for information on connections.	N/A
J12	15 Pos Female D	Remote: Remote control and status indications. Refer to Table 7A on pages 27 & 28 for information on the connections.	N/A
J13	RJ-45	Serial: Provides communication to System and to external amplifier drawers, if present.	N/A
J14	RJ-45	Ethernet: Optional Ethernet connection. May not be present in your drawer.	N/A
J15 Front Panel	BNC	RF Sample: Output Sample from Output Detector Board. In a CHV200B the sample level at J15 is approximately 60dB down from the output power level of the drawer.	50 Ohms
J16 Front Panel	9 Pos Female D	Serial: Used to load equalizer taps into the modulator.	N/A

**NOTES:** 1) If your system contains an Optional ASI to S310 Converter, connect the ASI output of the STL to the ASI in jack on the rear panel of the converter. Connect the SMPTE-310 Output from the SMPTE 310 Out jack on the rear panel of the converter module to the input jack J1 on the rear panel of the exciter/driver.

2) If your system contains an Optional K-Tech receiver, connect the RF from the receive antenna or one output of the splitter to the input jack J1 on the rear panel of the K-Tech receiver. Connect the SMPTE-310 Output from the SMPTE 310 Out jack J2 on the rear panel of the K-Tech receiver to the input jack J5 on the rear panel of the exciter/driver Drawer. 3) If the system contains the optional K-Tech back up system, the K-Tech receiver is bypassed by using the second output of the splitter that connects to J1 on the rear panel of the exciter/driver and connecting a jumper from J4 to J5, after removing the cable from the K-Tech receiver, on the rear panel of the exciter/driver. This configuration uses the 8VSB demodulator board in the exciter/driver drawer to produce the SMPTE-310 signal.

### **J11 Power Monitoring Connections**

In systems with one or more external amplifiers, J11 is used to communicate the output forward and reflected metering voltages back to the driver. J11 is connected directly to the external amplifier when there is only one external amplifier and is connected through the system metering module when multiple external amplifiers are used. In multiple external amplifier systems there are thermal switches mounted on the reject loads of the combiner, and the Reject load interlock is connected to the thermal switches and is used to shut down the system if the reject load overheats. In systems with no external amplifier, the only connection used is the Reject Load Interlock, which must be connected to Supply Return using a jumper from J11-6 to J11-9.

Table 2B: J1 9 Pos Male "D" Connector

<b>J11 Pin</b>	<b>Function</b>
1	+12VDC
2	System Forward Power
3	System Reflected Power
4	System Aural Power
5	Remote Spare Input
6	Reject Load Interlock. (If not used, in systems with no external amplifier, must be jumpered to J11-9)
7	System Serial +
8	System Serial -
9	Supply Return (If Reject Load Interlock is not used, in systems with no external amplifier, must be jumpered to J11-6)




Figure 4: Rear View CHV External Amplifier Drawer

Table 3: Connections for the External Amplifier Drawer

Port	Type	Function	Impedance
J1	N	RF Input: On Channel RF from CHVB driver drawer	50Ω
J2	7/16" (1.1cm) Din	RF Output: On Channel RF Output	50Ω
J3	IEC	AC Input: AC input connection to 230VAC Source	N/A
J4	9 Pos D	Remote: Amplifier Control Interface (Connects to J11 on the exciter/driver drawer)	N/A
J5	RJ-45	Serial data	N/A
J8 Front Panel	BNC	RF Sample: Output Sample from Combiner thru Control Board. In a CHV500B, the sample level is approximately 70dB down from the output power level of the drawer.	50Ω

If used, connect the external 10 MHz reference input to the 50Ω BNC 10 MHz input jack J6 located on the rear panel of the exciter/driver. If used, connect the external 1 PPS reference input to the 50Ω BNC 1 PPS input jack J7 located on the rear panel.

In Regenerative Translator (RD) systems there may be a SMPTE-310 loop-thru from the output of the Demodulator Board at J4, mounted on the rear panel of the transmitter or driver drawer to the input to the Modulator Board at J5 mounted on the rear panel of the transmitter. There is normally a jumper installed from J4 to J5. To feed SMPTE-310 directly to the Modulator Board remove the jumper and insert SMPTE-310 into J5. This is only used in Translator (RD) systems not Transmitter (TD) systems.

The digital RF ON Channel output of the exciter/driver is at J9 the 50Ω "N" connector RF output jack located on the rear panel. The output of the drawer at J9 connects to the low pass (if present) digital mask filter and then to the antenna for your system. In higher power systems the output of the driver drawer at J9 is connected to J1 the 50 Ohm "N" connector RF input jack located on the rear panel of the external amplifier or to a splitter in multiple amplifier systems. In systems with one external amplifier, check that the system power metering interface cable is connected from J11 the 9 position "D" connector located on the rear panel of the driver drawer to J4 the 9 position "D" connector located on the rear panel of the amplifier drawer. This cable provides the control, status and operating parameters of the amplifier drawer to the driver drawer. In systems with more than one



external amplifier, the output of the driver drawer is split and connected to J1 the "N" type connector RF input jack on the amplifier drawers. Check that the system power metering interface cable is connected from J11 the 9 position "D" connector located on the rear panel of the driver drawer to J9 the 9 position "D" connector located on the System Metering Board. Also check that the serial connection is cabled from the RJ-45 connector J13 on the driver drawer to the RJ-45 connector J1 on the system metering board. The system metering board provides serial RJ-45 connections at J2 and J5 that are cabled to the RJ-45 serial port J5 on the rear panel of the amplifier drawers. These cables provide the control, status and operating parameters of the amplifier drawers to the driver drawer through the System Metering Board.

The digital RF ON Channel output of the amplifier drawer is at J2 the 50Ω 7/16 DIN connector RF output jack located on the rear panel that connects directly to the digital mask filter, the low pass filter (if present) and then to the antenna for your system in single amplifier systems. In multiple amplifier drawer systems the outputs of the drawers connect to a combiner and then the digital mask filter, the low pass mask filter (if present), the output coupler and finally to the antenna for your system. The output coupler provides forward and reflected power samples that are cabled to the System Metering Board at J8 reflected and J3 forward. Also connected to the system metering board at J10-6 & 9 is the output of the over-temperature switch mounted to the reject load that is used as the reject interlock by the system. The samples and interlock are fed through J9 on the system metering board to J11 on the driver drawer.

This completes the connections of the system.

## **Maintenance**

Innovator CX series transmitters are designed with components that require little or no periodic maintenance except for the routine cleaning of the fans and the front panels of the modules and the periodic check of general tightness of hardware.

It is recommended that periodically, the time interval depends on the amount of movement the cabinet receives, all mounting hardware, holding drawer slides, shelving and mounting plates inside the cabinet are checked for tightness. All screws and bolts that are accessible should be tightened initially when the transmitter is received and periodically thereafter if the transmitter is moved by vehicle. All coaxial connectors, hard-line connections and hardware holding combiners, splitters, or any other mounted items should be checked and tightened. The amount of time between cleanings of the drawers and cabinets depends on the conditions within the transmitter room. While the electronics have been designed to function even if covered with dust, a heavy buildup of dust, dirt, or insects will affect the cooling of the components. This could lead to a thermal shutdown or the premature failure of the affected drawer. When the front panels of the drawers become dust covered, the drawer should be pulled out and any accumulated foreign material should be removed.

**NOTE:** To remove the CX series transmitter from the cabinet, the input and output cables must be removed from the rear of the transmitter before the drawer can be pulled out completely from the cabinet.

A vacuum cleaner, utilizing a small, wand-type attachment, is an excellent way to suction out any dirt from the drawer and cabinet. Alcohol and other cleaning agents should not be used unless you are certain that the solvents will not damage components or the silk-screened markings on the drawers and boards. Water-based cleaners can be used, but do not saturate the components. The fans and heatsinks should be cleaned of all dust or dirt to permit the free flow of air for cooling purposes. It is recommended that the operating parameters of the

transmitter be recorded from the LEDs and the LCD system metering on the front panel of the drawer at least once a month to be used for comparison purposes in case of a failure. It is suggested that this data be retained in a rugged folder or envelope and stored near the transmitter.

**This page has intentionally been left blank.**

### **Initial On-Site Turn On Procedure**

After the Innovator CHV series drawer or drawers are installed and all input, output and AC connections are made, the system is ready for the initial on site turn on. Check that the output of the exciter/driver drawer is connected to an appropriate rated load or to the digital mask filter, low pass filter (if present), and the antenna for your system. If your system contains external amplifiers, check that the output of the amplifier drawer or the combiner assembly is connected to an appropriate rated load or to the digital mask filter and the antenna for your system. Check that the main AC power to the System is ON. **NOTE:** If your system is mounted in a cabinet and contains an Optional UPS, turn on the UPS.

Locate the exciter/driver drawer and push ON the switch located on the rear panel of the transmitter near the AC power jack. The fan mounted on the rear panel of the drawer should operate when the AC is applied. If your system contains external amplifiers, push ON the switch located on the rear panel of the driver drawer and also switch ON the ON/OFF circuit breaker(s) located on the rear panel of the amplifier drawer(s) mounted on each side of the AC input power jack. The small fan mounted on the rear panel of the driver drawer should operate and the two fans mounted in the amplifier drawer should operate when AC is applied. The large fan mounted in the rear panel of the system or driver drawer will operate when the A10 switching supply is enabled.

Place the system into Operate. The Operate/Standby LED and Status LEDs on the exciter/driver should be Green indicating the system is in Operate and performing normally. Both fans (Note: Some models may only have one fan on the exciter/driver) should be operating. The Operate/Standby LED showing Amber indicates the System is in Standby. The Status LED showing a blinking Red LED indicates an Event (Fault) is occurring now. The Status LED showing Amber indicates that an Event (Fault) occurred since the last time the Event (Fault) indications were reset.

If your system contains external amplifiers the Enable LED and Status LEDs on the amplifier drawer should be Green indicating the system is in Operate and performing normally. The Enable LED showing Amber indicates the System is in Standby. The Status LED should be Green indicating no Events (Faults) in the system. If the Operate/Standby LED shows Amber it indicates that the System is in Standby. If the Status LED is blinking Red it indicates an Event (Fault) is occurring now. If the Status LED shows Amber it indicates that an Event (Fault) occurred since that last time the Event (Fault) indications were reset. The output power is factory set according to customer request and does not need adjusted. If a problem occurs, call Axcera field support at 724-873-8100 for information on modifying the power level of the system.

**NOTE:** The RF System Interlock is provided on J12, a 15 position "D" connector, located on the rear panel of the exciter/driver. The RF System Interlock at J12-5 provides the customer with a means of connecting the system to protection circuits, for the loads, thermal switches, combiners, or the antenna, in the output of your system, that will place the system in Standby if the protection circuit opens. The Reject Load Interlock is provided at J11, a 9 position "D" connector. J11-6 provides the customer with a means of connecting the system to protection circuits, for the reject load in multiple amplifier systems, which will place the system in Standby if the protection circuit opens. If the interlocks are not used in your system, a plug with a jumper from J12-5 to J12-15, ground, for RF system Interlock and another

plug with a jumper from J11-6 to J11-9, for Reject Load Interlock, need to be connected. These jumpers provide the RF System and Reject Load Interlocks, which allow the system to go to operate. Without the jumpers, the system will remain in Standby.

**Typical System Operating Parameters**

<b>Typical Operating Parameters for a CHV0TD-1</b>	
<b>Parameter</b>	<b>Typical Reading</b>
Forward Power	100%
Reflected Power	<5%
Power Supply Voltage	48 Volts
Heatsink Temperature	20° to 30° F/15° to 20° C above ambient temperature
Pin Attenuator Voltage	1 Volt to 5 Volts

<b>Typical Operating Parameters for a CHV0TD-1 used as driver</b>	
<b>Parameter</b>	<b>Typical Reading</b>
Forward Power	20-70% (Depending on output power level of system)
Reflected Power	<5%
Power Supply Voltage	48 Volts
Heatsink Temperature	20° to 30° F/15° to 20° C above ambient temperature
Pin Attenuator Voltage	1 Volt to 5 Volts

<b>Typical Operating Parameters for a CHV0TD-4</b>	
<b>Parameter</b>	<b>Typical Reading</b>
Forward Power	100%
Reflected Power	<5%
Power Supply Voltage	48 Volts
Heatsink Temperature	20° to 30° F/15° to 20° C above ambient temperature
Pin Attenuator Voltage	1 Volt to 5 Volts

<b>Typical Operating Parameters for a CHV0TD-4 used as a Driver</b>	
<b>Parameter</b>	<b>Typical Reading</b>
Forward Power	20-70% (Depending on output power level of system)
Reflected Power	<3%
Power Supply Voltage	48 Volts
Heatsink Temperature	20° to 30° F/15° to 20° C above ambient temperature
Pin Attenuator Voltage	1 Volt to 5 Volts

<b>Typical Operating Parameters for the external Amplifier Drawer(s)</b>	
<b>Parameter</b>	<b>Typical Reading</b>
Forward Power	100%
Reflected Power	<5%
Power Supply Voltage	48 Volts
Heatsink Temperature	77° to 104° F/25° to 40° C above ambient

---

	temperature
--	-------------

**Typical Problems, Indications and Causes in Exciter/Driver Drawer**

Problem	Indication	Cause
No power to drawer	Operate/Standby and Enable LED indicators and LCD display are Off	AC power cord not connected. Main AC to System missing. On/Off switch on back of drawer Off. 10 Amp fuse (F1) blown*. Power supply (A9) not operating
No Output Signal	Front Panel Status LED is Amber and blinking with no events, faults indicated.	On the 8VSB Modulator S310 MPEG Input Selection Set Up Screen, the Input is currently set incorrectly to "from Internal Source". Set to "from External Source". (Not used with Axciter)
Loss of Input Signal	Loss of Input on Modulator Menu	Loss of input signal. (Not used with Axciter)
Loss of Output Signal	Amber Operate/Standby LED. Blinking Red Status LED.	Any Event, Fault, which Mutes the output. Including Input Fault, VSWR Cutback, Overdrive, Over-temperature and Overvoltage.
Loss of 48V	Power Supply Fault on Power Supply Menu	Power supply (A10) not operating
Loss of ±12V or 5V	Operate/Standby and Enable LED indicators and LCD display are Off	Power supply (A9) not operating

**NOTE:** \*A spare 10 Amp fuse is provided in the blank fuse holder under the active fuse.

If there is an Event (Fault) occurring in the system, the Status LED on the front panel will flash RED as long as the Event (Fault) is present. In addition, the menu will jump to the current Event (Fault) on the display and blink the Event (Fault) continuously, if the Jump to Fault screen is set to Yes. When the Event (Fault) is corrected, the drawer will turn the Status LED to AMBER to indicate that there was a Fault and the menu will still display the Fault but it will not flash. This gives the user the knowledge that there was an Event (Fault) and what type of Event (Fault) occurred. Before clearing the fault, check if there were other Events (Faults) by stepping through the menus. To reset the indication of previous Events (Faults) the user must push the Enter button with the Event (Fault) Reset Screen displayed. This will reset all previous Events (Faults).

**LCD Display and Front Panel LED Indicators**




Figure 5: Front View Innovator Cx exciter/driver

Table 4: Innovator CX Series LCD Display

DISPLAY	FUNCTION
LCD	Provides a two line readout of the input received channel, internal functions, status, and Fault (Event) conditions.

The front panel has seven pushbuttons, two for the control of the system, Operate & Standby, and five for control of the displayed menus, Left, Right, Up, Down & Enter.

Table 5: Innovator CX Series Control Pushbuttons

PUSHBUTTON	FUNCTION
OPR	When pushed switches the system to Operate.
STBY	When pushed switches the system to Standby.
ENTER	Selects the changes made in the menus and submenus.
Up & Down Arrow	Scrolls through the main menus and after entering the Main Menu Steps through submenus of the main menu when they are present.
Left & Right Arrow	Used to exit from main menus and submenus of the main menu when they are present.

Table 6: Innovator CX Series Operate/Standby and Status Indicators

LED	FUNCTION
OPERATE/STANDBY (Green/Amber)	A <b>Green</b> LED indicates that the system is in Operate. An <b>Amber</b> LED indicates that the system is in Standby.
STATUS (Green/Red/ Amber)	A <b>Green</b> LED indicates that the system is functioning normally. A flashing <b>Red</b> LED indicates an Event (Fault) is occurring at this time. An <b>Amber</b> LED indicates an Event (Fault) occurred since the last time the Event (Fault) indications were reset but the system is now operating normally. <b>Amber</b> LED Blinking, with no Events (Faults) indicates the MPEG input is set to Internal Source.

**NOTE:** J15 is a Front Panel BNC RF Sample Jack 50Ω that provides an RF output sample from the output detector board in the drawer. In a CHV200B, the sample level at J15 is approximately 60dB down from the output power level of the drawer.




Figure 6: Front view of the external amplifier drawer

Table 7: Innovator CHV Amplifier Drawer LED Indicators and Sample Jack

LED	FUNCTION
-----	----------



ENABLE (Green/Amber)	A <b>Green</b> LED indicates that the system is in Operate and operating normally. An <b>Amber</b> LED indicates that the system is in Standby.
STATUS (Green/Red/ Amber)	A <b>Green</b> LED indicates that the system is functioning normally with no faults. A flashing <b>Red</b> LED indicates an Event (Fault) is occurring at this time. An <b>Amber</b> LED indicates an Event (Fault) occurred since the last time the Event (Fault) indications were reset but the system is now operating normally.
<b>JACK</b>	<b>FUNCTION</b>
SAMPLE J6	Typical sample value is 65dB down from the output power level of the drawer. (500 Watts output power = -8dBm sample level)

**System Remote Connections to J12**




Figure 7: Rear View Innovator Cx exciter/driver

The remote connections for the Innovator CHV series system are made to the Remote 15 Pos Female "D" connector Jack J12 located on the rear panel of the drawer.

Table 7A: Remote Connections to J12 15 Pos Female D Connector for Innovator CX series system

Remote Signal Name	Pin Designation	Signal Type	Description
System Operate	J12-1	Discrete Open Collector Input - A pull down to ground on this line indicates that the System is to be placed into the operate mode. (Low = Activate : Floating = No Change)	Command
System Standby	J12-2	Discrete Open Collector Input - A pull down to ground on this line indicates that the System is to be placed into the standby mode. (Low = Activate : Floating = No Change)	Command
Power Raise	J12-3	Discrete Open Collector Input - A pull down to ground on this line indicates that the Power of the System is to be Raised. (Low = Activate : Floating = No Change)	Command
Power Lower	J12-4	Discrete Open Collector Input - A pull down to ground on this line indicates that the Power of the System is to be Lowered. (Low = Activate : Floating = No Change)	Command
System Interlock	J12-5	Discrete Open Collector Input - A pull down to ground on this line indicates that the Interlock is present. Normally jumpered to	

Remote Signal Name	Pin Designation	Signal Type	Description
		J12-15. (Low = OK : Floating = Fault)	
Set to Modulation Type	J12-6	Discrete Open Collector Input. - Sets the Modulation type of the system. (Low = Analog : Floating = Digital)	Command
Set Channel (Set Up 1 or Set Up 2)	J12-7	Discrete Open Collector Input. - Selects one of two possible Channel Setups of the system. (Low = Set Up 2, CH 2 : Floating = Set Up 1, CH 1) <b>NOTE:</b> The Set Up 1 & Set Up 2 settings are displayed and changed in the Upconverter Set Up Menus.	Command
Ground	J12-8	Ground.	
System Forward Power Level (See <b>NOTE</b> at end of table)	J12-9	Analog Output - 0 to 4.0 V. - This is a buffered loop through of the calibrated "System Forward Power". Indicates the System Forward power. Scale factor is 100 % = 2.0V.	Metering
System Aural Power Level (See <b>NOTE</b> at end of table)	J12-10	Analog Output - 0 to 4.0 V. - This is a buffered loop through of the calibrated "System Aural Power". Indicates the System Aural power. Scale factor is 100 % = 2.0V. <b>(Not used in Digital)</b>	Metering
System Reflected Power Level (See <b>NOTE</b> at end of table)	J12-11	Analog Output - 0 to 4.0 V. - This is a buffered loop through of the calibrated "System Reflected Power". Indicates the System Reflected power. Scale factor is 25 % = 2.0V.	Metering
Report Input Status	J12-12	Discrete Open Collector Output. - Indicates if input to system is Normal or Not. (Low = OK : Floating = Fault)	Status
Report Fault Status	J12-13	Discrete Open Collector Output. - Indicates if system is Operating Normally or has a Fault. (Low = OK : Floating = Fault)	Status
Report Operate Status	J12-14	Discrete Open Collector Output. - Indicates whether system is in Operate or Standby. (Low = Operate : Floating = Standby)	Status
Ground	J12-15	Ground. Normally jumpered to J12-5.	

**NOTE:** The analog remote metering functions are scaled such that 2V = a known power. The forward power is typically scaled so that 2V = 100%, and the reflected is scaled such that 2V = 25%. These voltages are generated by detecting the RF voltage, and the change is proportional to the RF voltage change, rather than proportional to the change in RF power. There is a direct relationship between changes in RF power and RF voltage, as the Power change is proportional to the square of the voltage change, ( $P=V^2/R$ ).

Example: Output power is scaled so that 2V = 100%. To calculate the power for 1V, take  $(1V/2V)^2 \times 100\% = 25\%$ .

Most remote control systems are set up to handle this format directly and will do the calculations required to scale the displayed power appropriately.



## LCD Front Panel Screens

A LCD display, located on the front of the Innovator Cx series systems displays the current operating status of the system. When the drawer is powered On the LCD will initially display two splash screens. The first splash screen will be displayed for a few seconds, then the second splash screen will be displayed for a few seconds and finally the RF Power Display default screen will be displayed. See examples of the screens below. **NOTE:** These screens are typical examples; your systems screens may be different. The RF Power Display default screen will be the screen displayed if no buttons are pushed to access other screens. While viewing the RF Power Display default screen, pushing the Left and Right arrow buttons together will also access the splash screens. **NOTE:** In dual exciter systems, the On Air Exciter will display the operating parameters of the system.


### Splash Screen Number 1



The first splash screen displayed indicates the manufacturer, type and the model number.



Shown are P/N: 1316306 firmware version level 2.0b and EPLD version 2.5.



The following screens are scrolled through using the buttons to the right of the display. Pushing and releasing the Up & Down Arrows will scroll you through the Main Menu, which are shown on the following pages aligned on the left side of the page. The Submenus of the Main Menu are accessed by pushing and releasing the ENTER button. Once in the Submenu, pushing and releasing the Up & Down Arrows will scroll you through the submenus of the Submenu. The Submenus are shown on the following pages indented under the Main Menu and the submenus of the Submenu are indented under the Submenu in which they are contained. In the SET UP Menu, changes are made to the display by Pushing and releasing the ENTER button which causes the item to be changed to blink, then using the left and right arrow buttons to display the desired changed item, finally, pushing the ENTER button will accept the changes made upon exit of the Set Up Menu.

**NOTE:** An example of accessing and changing an item using the Set Up Menu is as follows. This procedure is to set the Off Air Receive Channel to the desired channel. Push and release the DOWN Arrow button until the SYSTEM SET UP Main Menu is displayed. Push and release the ENTER button. The Authorization Warning screen is displayed. Push and release the ENTER

button again and the ENTER BUTTON SETS TO CHANGE MODE screen is displayed. Push and release the ENTER button again and the first set up menu, which is the SET UP MENUS OF CHASSIS VALUES screen is displayed. Push and release the DOWN Arrow button until the SET UP 8VSB DEMODULATOR screen is displayed. Push and release the ENTER button to display the submenus under the SET UP 8VSB DEMODULATOR menu. Push and release the DOWN Arrow until the 8VSB DEMODULATOR USE OFF AIR CHxx is displayed. Push and release the ENTER button and the XX, which indicates the Channel Number, will blink. Push and release the UP or DOWN Arrow button until the desired new channel number is displayed. Push and release the ENTER button, and the PUSH ENTER TO ACCEPT CHANGES menu is displayed. Push and release the ENTER button again to accept the changes made. The channel is now changed. Push and release the LEFT Arrow to exit to the SET UP 8VSB DEMODULATOR screen. Push and release the LEFT Arrow again to exit to the SYSTEM SET UP Main Menu. Push and release the UP or DOWN arrows to browse the main menus.

The following screens are typical of an operating system. The values indicated on the screens in your system may vary from those shown below.

### Operation Screens

**NOTE:** The following Operation screens provide operating information only. No adjustments are available using these screens.

**Figure 9: Transmitter/Translator RF Power Screen (TD/RD)**



**Menu Level** This is the default screen that is displayed after the splash screens are displayed.

**Description** This screen provides an indication of the Forward Output Power of the system in terms of Percent. (Typically 100%). The screen also provides an indication of the Reflected Power of the system in terms of Percent. (Typically less than 5%).

Push the DOWN Arrow to view the next main menu, which is the Transmitter Event Log Main Menu.

**Figure 10: Transmitter/Translator Event Log Main Screen (TD/RD)**



**Menu Level** System Main Screen.

**Description** This is the Transmitter Event Log Main Screen. Push the ENTER button to access the Event List submenu.

Push the DOWN Arrow to view the next main menu, which is the Transmitter Details Main Menu.

**Figure 10.1: Transmitter/Translator Event List Screen (TD/RD)**



001 OF 013 (01)  
RF INTERLOCK FAU

Menu Level System Event Log Sub Screen.  
Description When events occur, they will be displayed on this screen. The Up and Down arrow will page you through the different entries in the event log. The above screen indicates the 001 event of 013 total events that have occurred in the Transmitter. The number in the parenthesis on the top right, in this case 01, indicates the number of times the displayed event has occurred. The bottom line scrolls to indicate the event that occurred, in this case RF Interlock Fault. **NOTE:** When the Date & Time are available, this information is displayed for the event, otherwise the Time Interval between events is displayed.

Push the LEFT Key to exit to the Transmitter Event Log Main Menu screen. Pushing the RIGHT Key will access the Event Reset Screen.

**Figure 10.2: Event Reset Screen (TD/RD)**



PRESS ENTER TO  
CLEAR EVENT LOG

Menu Level System Event Log Sub Screen.  
Description This screen allows the resetting of the event log, after they are observed or corrected. **NOTE:** Resetting the events on an amplifier may cause the transmitter to momentarily mute.

**Figure 10.3: Event Reset Old Faults Screen (TD/RD)**



PRESS ENTER TO  
RESET OLD FAULTS

Menu Level System Event Log Sub Screen.  
Description This screen allows the resetting of old faults that are latched from the event log after they are observed or corrected. The transmitter can be configured to latch faults as detailed in Figure 11.1.4. That means that if a fault occurs and then it clears, the status of the parameter in the details screen will not blink indicating an active fault, but it will still show fault indicating that previously this parameter was faulted. Within the web pages, a latched fault is shown with an orange background while faulted parameters are shown in red and good values are shown in green. Resetting Old Faults will clear the latched fault and the display will show the value as OK or with other text that indicates that it is not faulted.

**Figure 11: Transmitter/Translator Details Main Screen (TD/RD)**



Menu Level System Main Screen.  
Description This is the System Details Main Screen. Push the ENTER button to access the Device Details Chassis Values Main Sub Screen. Push the DOWN Arrow to view the next main menu, which is the System Set Up Main Menu.

**Figure 11.1: Transmitter/Translator Device Details Exciter Values Screen (TD/RD)**



Menu Level System Device Details Exciter Values Main Sub Screen.  
Description Push the ENTER button to access the Device Details Exciter Values submenus or push the DOWN Arrow to view the next main submenu, which is the ATSC Modulator Sub Menu

**Device Details Screens - These are read only parameters.**

**Figure 11.1.1: Transmitter/Translator Driver Forward/Reflected Power Details Screen (TD/RD)**



Menu Level System Device Details Exciter Values Driver Sub Screen.  
Description This screen provides an indication of the Output Forward Power of the Driver Drawer in terms of Percent, typically 20-70%. This screen also provides an indication of the Reflected Output Power of the Driver Drawer in terms of Percent, Typically less than 3%.

**Figure 11.1.2: Heatsink Temperature Details Screen (TD/RD)**



Menu Level System Device Details Exciter Values Driver Sub Screen.  
Description This screen indicates the temperature of the amplifier heatsink assembly, mounted in the system or driver drawer, in degrees Fahrenheit or Centigrade. If the temperature is below the trip point, it will indicate OK. (Typically 20° to 30° F. or 15° to 20° C above ambient temperature.)

**Figure 11.1.3: Power Supply Voltage Details Screen (TD/RD)**



Menu Level System Device Details Exciter Values Driver Sub Screen.  
Description This screen indicates the power supply voltage in the system or driver drawer. If the power supply voltage is below the trip point, it will indicate OK. The fault limit is the nominal supply voltage as set in the Exciter Setup Screen  $\pm 10\%$ .

**Figure 11.1.4: RF System Interlock Details Screen (TD/RD)**



Menu Level System Device Details Exciter Values System Sub Screen.  
Description This screen indicates if the external RF system interlock is present in your system. (Typically Present. Must be present or system will remain in Standby.)

**Figure 11.1.5: Reject Load Interlock Details Screen (TD/RD)**



Menu Level System Device Details Exciter Values System Sub Screen.  
Description This screen indicates if the external Reject Load interlock is present in your system. (Typically Present. Must be present or system will remain in Standby.)

**Figure 11.1.6: AGC Details Screen (TD/RD)**



Menu Level System Device Details Exciter Values System Sub Screen.  
Description This menu indicates if the AGC circuit has an input.

**Figure 11.1.7: AGC Overdrive Details Screen (TD/RD)**



Menu Level System Device Details Exciter Values System Sub Screen.  
Description This menu indicates if the AGC circuit is operating within its range.

**Figure 11.1.8: AGC Auto/Manual Details Screen (TD/RD)**



Menu Level System Device Details Exciter Values System Sub Screen.  
Description This menu indicates if the AGC circuit is operating in Auto or Manual.

**Figure 11.1.9: ALC Voltage Level Details Screen (TD/RD)**



Menu Level System Device Details Exciter Values System Sub Screen.  
Description This menu indicates the Auto ALC voltage setting.  
(Typically 1 to 5 V)

Pushing the Left Arrow will display the System Device Details Exciter Values Main Sub Screen and then pushing the Down arrow will access the System Device Details DM8C ATSC Modulator Main Sub Screen.



**Figure 11.2: Device Details - ATSC Modulator Select**



Menu Level ATSC Details Top Level  
Description This screen provides access to the read only parameters of the ATSC modulator.  
Parameter Range N/A

**Figure 11.2.1: Device Details - Input Signals Category**



Menu Level ATSC Details / Input Signals Top Level  
Description This screen provides access to read only input signal parameters of the ATSC modulator.  
Parameter Range N/A

**Figure 11.2.1.1: Device Details - Input Signals - Selected Stream**



Menu Level ATSC Details / Input Signals / Selected Stream  
Description This screen indicates which input path is currently selected.  
Parameter Range Input #1 or Input #2

**Figure 11.2.1.2: Device Details - Input Signals - Primary Stream Status**




Menu Level ATSC Details / Input Signals / Primary Stream  
Description This menu indicates if the allocated primary stream is available or not.  
Parameter Range "Available" or "No Sync Signal"

**Figure 11.2.1.3: Device Details - Input Signals - Secondary Stream Status**



Menu Level ATSC Details / Input Signals / Secondary Stream  
Description This menu indicates if the secondary stream is available or not.  
Parameter Range "Available" or "No Sync Signal"

**Figure 11.2.1.4: Device Details - Input Signals - Stream: Number of Buffered Packets**



Menu Level ATSC Details / Input Signals / Stream Buffered Packet Count  
Description This display indicates how many packets are stored in the input buffer.  
Parameter Range Minimum of 0

**Figure 11.2.1.5: Device Details - Input Signals - Stream: Packet Size**



STREAM: PACKET  
SIZE 188

Menu Level ATSC Details / Input Signals / Primary Stream Packet Size  
Description This display indicates the transport stream packet size.  
Parameter Range 188 or 204

**Figure 11.2.1.6: Device Details - Input Signals - Stream: Bit Rate**



STREAM: BIT RATE  
19.3927 MB/S

Menu Level ATSC Details / Input Signals / Stream Bit Rate  
Description This is the detected bit rate of the input transport stream.  
Parameter Range

**Figure 11.2.1.7: Device Details - Input Signals - Stream: Stuffing Rate**



STREAM: STUFFING  
RATE 12.3337MB/S

Menu Level ATSC Details / Input Signals / Stream Stuffing Rate  
Description This is the detected stuffing rate of the input transport stream.  
Parameter Range

**Figure 11.2.1.8: Device Details - Input Signals - Stream: TS ID**



STREAM: TRANSPORT  
ID 1

Menu Level ATSC Details / Input Signals / Stream TS ID Value  
Description This is the detected TS ID value of the input stream.  
Parameter Range 0 to 65535

**Figure 11.2.2: Device Details - Adaptive Precorrection Status Category**



ATSC MODULATOR  
ADAPTIVE STATUS

Menu Level ATSC Details / Adaptive Status Top Level  
Description This screen provides access to read only adaptive system parameters.  
Parameter Range N/A

**Figure 11.2.2.1: Device Details - Adaptive Signals - Upper Shoulder Level**



LOWER SHOULDER  
LEVEL -63.3066 dB

Menu Level ATSC Details / Adaptive Signals / Lower Shoulder Value  
Description When valid, this is the measured level in dB for the lower shoulder.  
Parameter Range 'Invalid' or measured level in dB

**Figure 11.2.2.2: Device Details - Adaptive Signals - Upper Shoulder Level**



UPPER SHOULDER  
LEVEL -62.5662 dB

Menu Level ATSC Details / Adaptive Signals / Upper Shoulder Value  
Description When valid, this is the measured level in dB for the upper shoulder.  
Parameter Range 'Invalid' or measured level in dB

**Figure 11.2.2.3: Device Details - Adaptive Signals - Amplitude Ripple**



AMPLITUDE RIPPLE  
LEVEL 0.1142 dB

Menu Level ATSC Details / Adaptive Signals / Amplitude Ripple Value  
Description When valid, this is the measured level in dB for the amplitude ripple.  
Parameter Range 'Invalid' or measured level in dB.

**Figure 11.2.2.4: Device Details - Adaptive Signals - Group Delay**



GROUP DELAY  
LEVEL 15.0206 nS

Menu Level ATSC Details / Adaptive Signals / Group Delay Value  
Description When valid, this is the measured group delay in nano seconds.  
Parameter Range 'Invalid' or measured level in nS.

**Figure 11.2.2.5: Device Details - Adaptive Signals - Nonlinear Sample**



NONLINEAR SAMPLE  
LEVEL -0.01 dBm

Menu Level ATSC Details / Adaptive Signals / Nonlinear Sample Level  
Description When valid, this is the RF sample level used for nonlinear precorrection.  
Parameter Range 'Invalid' or measured level in dB. Required level for precorrection is 0 dBm +/- 10 dB.

**Figure 11.2.2.6: Device Details - Adaptive Signals - Nonlinear Correction Operational Mode**



NONLINEAR ADJUST  
IS AUTO APPLYING

Menu Level ATSC Details / Adaptive Signals / Nonlinear Adjust Mode  
Description Nonlinear Precorrection can be enabled or disabled through read / write parameters. This value tells us the operational status of nonlinear precorrection.  
Parameter Range "Auto Applying", "Not Running", "Monitoring", "Initializing" or "Initializing xx" where xx is the percentage of completion.


**Figure 11.2.2.7: Device Details - Adaptive Signals - Nonlinear Correction Cycle Count**



NONLINEAR ADJUST  
CYCLES 112

Menu Level ATSC Details / Adaptive Signals / Nonlinear Cycle Count  
Description This value is a count of the number of times nonlinear precorrection has been updated since corrector reset or modulator reboot.  
Parameter Range

**Figure 11.2.2.8: Device Details - Adaptive Signals - Linear Sample**



LINEAR SAMPLE  
LEVEL 0.08 dBm

Menu Level ATSC Details / Adaptive Signals / Linear Sample Level  
Description When valid, this is the RF sample level used for linear precorrection.  
Parameter Range 'Invalid' or measured level in dB. Required level for precorrection is 0 dBm +/- 10 dB.

**Figure 11.2.2.9: Device Details - Adaptive Signals - Linear Correction Operational Mode**



LINEAR ADJUST  
IS AUTO APPLYING

Menu Level ATSC Details / Adaptive Signals / Linear Adjust Mode  
Description Linear Precorrection can be enabled or disabled through read / write parameters. This value tells us the operational status of linear precorrection.  
Parameter Range "Auto Applying", "Not Running", "Monitoring", "Initializing" or "Initializing xx" where xx is the percentage of completion.

**Figure 11.2.2.10: Device Details - Adaptive Signals - Linear Correction Cycle Count**



LINEAR ADJUST  
CYCLES 121

Menu Level ATSC Details / Adaptive Signals / Linear Cycle Count  
Description This value is a count of the number of times linear precorrection has been updated since corrector reset or modulator reboot.  
Parameter Range

**Figure 11.2.3: Device Details - GPS Category (Only present if GPS Option is present)**



ATSC MODULATOR  
GPS RECEIVER

Menu Level ATSC Details / GPS Status Top Level  
Description This screen provides access to read only GPS system parameters if this optional component is present.  
Parameter Range N/A

**Figure 11.2.3.1: Device Details - GPS - Altitude**



Menu Level ATSC Details / GPS Status / Altitude  
Description This is the current altitude in meters as measured by the GPS receiver.  
Parameter Range N/A

**Figure 11.2.3.2: Device Details - GPS - Latitude**



Menu Level ATSC Details / GPS Status / Latitude  
Description This is the current latitude in DD MM SS N/S format.  
Parameter Range N/A

**Figure 11.2.3.3: Device Details - GPS - Longitude**



Menu Level ATSC Details / GPS Status / Longitude  
Description This is the current longitude in DD MM SS E/W format.  
Parameter Range N/A

**Figure 11.2.3.4: Device Details - GPS - 1 PPS Reference Signal Status**



Menu Level ATSC Details / GPS Status / 1 PPS Status  
Description This screen tells us if the 1PPS output is locked.  
Parameter Range "Locked" or "Unlocked"

**Figure 11.2.3.5: Device Details - GPS - Visible Satellites**



Menu Level ATSC Details / GPS Status / Visible Satellites  
Description This screen indicated the number of satellites that are visible.  
Parameter Range Minimum of 0

**Figure 11.2.3.6: Device Details - GPS - Tracked Satellites**



Menu Level ATSC Details / GPS Status / Tracked Satellites  
Description This screen indicated the number of satellites used to generate references, date and time.  
Parameter Range Minimum of 0

**Figure 11.2.3.7: Device Details - GPS - Date and Time**



Menu Level ATSC Details / GPS Status / Date and Time  
Description This is the date and time of the GPS based on satellites and time zone.  
Parameter Range N/A

**Figure 11.2.3.8: Device Details - GPS - Firmware Version**



Menu Level ATSC Details / GPS Status / Firmware Version  
Description This screen indicates the firmware version of the GPS system.  
Parameter Range N/A

**Figure 11.2.4: Device Details - Device Hardware Category**



Menu Level ATSC Details / Device Hardware Top Level  
Description This screen provides access to read only hardware parameters.  
Parameter Range N/A

**Figure 11.2.4.1: Device Details - Hardware - Serial Number**



Menu Level ATSC Details / Device Hardware / Serial Number  
Description This is the serial number of the modulator assembly.  
Parameter Range N/A

**Figure 11.2.4.2: Device Details - Hardware - Master Version**



Menu Level ATSC Details / Device Hardware / Master Version  
Description This character string identifies the master version of firmware installed. This value is longer than 16 characters so the value is scrolled across the display.  
Parameter Range N/A

**Figure 11.2.4.3: Device Details - Hardware - Kernal Version**



Menu Level ATSC Details / Device Hardware / Kernal Version  
Description This character string identifies the embedded Kernal version.  
Parameter Range N/A

**Figure 11.2.4.4: Device Details - Hardware - Hardware Version**



Menu Level ATSC Details / Device Hardware / Hardware Version  
Description This is character string identifies the board's hardware version.  
Parameter Range N/A

**Figure 11.2.4.5: Device Details - Hardware - Calibration Date**



Menu Level ATSC Details / Device Hardware / Calibration Date  
Description This is character string identifies the modulators calibration date.  
Parameter Range N/A

**Figure 11.2.5: Device Details - Event Log List Category**



Menu Level ATSC Details / Event Log Top Level  
Description This screen provides access to read or clear the event log.  
Parameter Range N/A

**Figure 11.2.5.1: Device Details - Event Log View**



Menu Level ATSC Details / Event Log View  
Description This screen provides access to read specific events. The date and time of the event are indicated then the specific event details. Since this information is longer than 16 characters, the text is scrolled across the screen.  
Parameter Range N/A

**Figure 11.2.5.2: Device Details - Event Log Clear**



Menu Level ATSC Details / Event Log Clear  
Description This screen provides access to clear all events of the log.  
Parameter Range "Yes" or "No"

**Figure 11.3: Translator 8VSB Demodulator Details Screen (RD)**



Menu Level	System Device Details \ 8VSB Demodulator Details Main Sub Screen
Description	Push the ENTER button to access the Device 8VSB Demodulator submenus or push the DOWN Arrow to view the next main menu, which is the Device Details 8VSB Modulator Main Sub Menu.

**Figure 11.3.1: System Input Details Screen (RD)**



Menu Level	8VSB Demodulator Details Sub Screen
Description	This screen provides the user information on the signal to noise ratio and signal strength of the received signal. The signal to noise ratio is provided on this menu to indicate to the user the quality of the receive signal. This reading also assists the user in the positioning of the antenna. The signal strength ranges from 0 to 100% and typically should be above 40% for reliable operation. The signal strength allows the user to optimize the position of the receive antenna.

**Figure 11.3.2: Demodulator Details Screen (RD)**



Menu Level	8VSB Demodulator Details Sub Screen
Description	This menu indicates whether there is a signal present at the demodulator.

**Figure 11.3.3: Demodulator Phase Lock Loop Details Screen (RD)**



Menu Level	8VSB Demodulator Details Sub Screen
Description	This menu indicates whether the Phase Lock Loop is locked in the demodulator.



**Figure 11.3.4: Receiver Input Channel Details Screen (RD)**



RECEIVE CHANNEL  
IS OFFAIR CH50

Menu Level 8VSB Demodulator Details Sub Screen  
Description This menu indicates the input channel to the Demodulator circuit.

Pushing the Left Arrow will display the System Device Details 8VSB Demodulator Values Main Sub Screen and then pushing the Down arrow will access the System Device Details 8VSB Modulator Main Sub Screens.

**Figure 11.4: External Amplifier Device Details Screen (TD/RD)**



DEVICE DETAILS  
EXTERNAL AMP #1

Menu Level Device Details External Amplifier #1 Details Main Screen  
Description This is the Transmitter Device Details External Amplifier Main Sub Screen. This is the final Device Details Main Sub Menu. Push the ENTER button to access the Device External Amplifier #1. Push the LEFT Arrow to go back the Main Device Details Screen. Then push the DOWN Arrow to access the Transmitter Set Up Main Menu.

**NOTE:** Shown below are the External Amplifier #1 Details Screens. The External Amplifier #2, #3 or #4 Details Screens are presented in the same order if they are present in the system.

**Figure 11.4.1: External Amplifier #1 Forward Power Details Screen (TD/RD)**



EX AMP #1  
FRD POWER 95.0%

Menu Level Device Details External Amplifier #1 Details Sub Screen  
Description Indicates Output Power for external amplifier #1.  
**NOTE:** See the final test data sheet for the typical value.

**Figure 11.4.2: External Amplifier #1 Reflected Power Details Screen (TD/RD)**



EX AMP #1  
RFL POWER 2.4%

Menu Level Device Details External Amplifier #1 Details Sub Screen  
Description Indicates Reflected Power for external amplifier #1.  
**NOTE:** See the final test data sheet for the typical value.

**Figure 11.4.3: External Amplifier #1 I1-A1 Current Details Screen (TD/RD)**



EX AMP #1  
I1-A1 13.2 A

Menu Level Device Details External Amplifier #1 Details Sub Screen  
Description Indicates Current of the A1 device in the external amplifier #1.  
**NOTE:** See the final test data sheet for the typical current value.

**Figure 11.4.4: External Amplifier #1 I2-A2 Current Details Screen (TD/RD)**



```
EX AMP #1
I2-A2    13.1 A
```

Menu Level Device Details External Amplifier #1 Details Sub Screen  
Description Indicates Current of the A2 device in the external amplifier #1.  
**NOTE:** See the final test data sheet for the typical current value.

**Figure 11.4.5: External Amplifier #1 I3-B1 Current Details Screen (TD/RD)**



```
EX AMP #1
I3-B1    13.4 A
```

Menu Level Device Details External Amplifier #1 Details Sub Screen  
Description Indicates Current of the B1 device in the external amplifier #1.  
**NOTE:** See the final test data sheet for the typical current value.

**Figure 11.4.6: External Amplifier #1 I4-B2 Current Details Screen (TD/RD)**



```
EX AMP #1
I4-B2    13.3 A
```

Menu Level Device Details External Amplifier #1 Details Sub Screen  
Description Indicates Current of the B2 device in the external amplifier #1.  
**NOTE:** See the final test data sheet for the typical current value.

**Figure 11.4.7: External Amplifier #1 A Power Supply Details Screen (TD/RD)**



```
EX AMP #1
A SUPPLY 48.0 V
```

Menu Level Device Details External Amplifier #1 Details Sub Screen  
Description Indicates the voltage of the A power supply in the external amplifier #1.  
**NOTE:** Typical voltage value is +42VDC or +48VDC w/888A devices.

**Figure 11.4.8: External Amplifier #1 B Power Supply Details Screen (TD/RD)**



```
EX AMP #1
B SUPPLY 48.1 V
```

Menu Level Device Details External Amplifier #1 Details Sub Screen  
Description Indicates the voltage of the B power supply in the external amplifier #1.  
**NOTE:** Typical voltage value is +42VDC or +48VDC w/888A devices.

**Figure 11.4.9: External Amplifier #1 A Temperature Details Screen (TD/RD)**



```
EX AMP #1
A TEMP   29 C
```

Menu Level Device Details External Amplifier #1 Details Sub Screen  
Description Indicates the temperature of the A heatsink in the external amplifier #1. **NOTE:** Typical temperature for DVB =  $\approx 20\text{-}30^{\circ}\text{C}$  above ambient.

**Figure 11.4.10: External Amplifier #1 B Temperature Details Screen (TD/RD)**



```
EX AMP #1
B TEMP    29 C
```

Menu Level	Device Details External Amplifier #1 Details Sub Screen
Description	Indicates the temperature of the B heatsink in the external amplifier #1. <b>NOTE:</b> Typical temperature for DVB = $\approx$ 20-30°C above ambient.

**Figure 11.4.11: External Amplifier #1 Code Version Details Screen (TD/RD)**



```
EX AMP #1
VERSION   1.6
```

Menu Level	Device Details External Amplifier #1 Details Sub Screen
Description	Indicates the code version in the external amplifier #1.

### Device Setup Screens - These are read / write parameters.

**Figure 12: Setup (TD/RD)**



```
TRANSMITTER
SET-UP
```

Menu Level	Main Setup Menu
Description	This screen provides access to all transmitter read / write parameters. This is the System Set Up Main Screen. Push the ENTER button to access the Authorization Warning Main Sub Screen or since this is the final Main Screen, pushing the DOWN Arrow will take you back to the System RF Power Default Screen.

The Set Up item or parameter that can be changed on the displayed sub menu screen, is indicated by pushing the ENTER button, which causes the changeable item to blink. The UP or DOWN arrow will change the selection until the desired result is displayed. Pushing the ENTER Button will accept the change.

**Figure 12A: Authorized Personnel Screen (TD/RD)**



```
PRESS ENTER ONLY
IF AUTHORIZED.
```

Menu Level	Setup Authorized Screen
Description	This screen of the system notifies an operator that they are only to proceed if they are authorized to make changes to the system's operation. Changes made within the following set-up screens can affect the system's output power level, output frequency, and the general behavior of the system. Please do not make changes within the system's set-up screens unless you are familiar with the operation of the system. Pressing the ENTER button will display the Enter Key Sets to Change screen.

**Figure 12B: Right or Enter Key Sets to Change Mode Screen (TD/RD)**



Menu Level	Setup Right Key Sets Change Mode Screen
Description	This screen informs the operator that to make changes, the Enter key or the Right key must be pushed, which will cause the display that can be changed to blink. Use the up or down key to change the display and the left or right key to move the blinking item on the display. After changes are made in the Set Up Menus pushing the enter Key, Button, will accept the changes made. With the Right Key Sets To Change Mode screen displayed, pushing the ENTER button will access the first main submenu under the Set Up main menu, which is the Chassis Values Set Up Menu.

**Figure 12.1: Chassis Values Main Set Up Screen (TD/RD)**




Menu Level	Setup Menu Chassis Values Main Sub Screen
Description	Push the ENTER button to access the Chassis Values submenus or push the DOWN Arrow to view the next Set Up Main Sub Screen, which is the Set Up ATSC Modulator Main Sub Screen. <b>NOTE:</b> Refer to the description in Figure 12B for how to change the values on the following set-up screens.

**Figure 12.1.1: Chassis Values Forward Power Set Up Screen (TD/RD)**



Menu Level	Setup Menu Chassis Values Sub Screen
Description	Remote or front panel adjustment of the output power of the transmitter. The bar graph indicates the range remaining in the adjustment. <b>NOTE:</b> If the transmitter's output power is being adjusted through the web page, the transmitter's forward power will be blinking on this screen. It will remain blinking while the transmitter is adjusting to the desired target power level.

**Figure 12.1.2: Chassis Values Model Number Set Up Screen (TD/RD)**



Menu Level	Setup Menu Chassis Values Sub Screen
Description	This screen allows the set up of the Model Number of the transmitter/regenerative translator. This causes the system to access the proper parameters to be displayed on the LCD screens. <b>NOTE:</b> Do not change this screen without first consulting with Axcera.

**Figure 12.1.3: Chassis Values Jump to Menu on Fault Set Up Screen (TD/RD)**




Menu Level	Setup Menus Chassis Values Sub Screen
Description	The 'Jump To Menu' setting screen allows an operator to change how the transmitter's display system works. When this value is set 'ON' and a new fault occurs, the transmitter will automatically change the display screen to show the new fault condition. When this value is set 'OFF', the display screen does not change when a new fault is detected.

**Figure 12.1.4: Chassis Values Latch On an Input Fault Set Up Screen (TD/RD)**



Menu Level	Setup Menus Chassis Values Sub Screen
Description	This screen, by selecting ON, allows the user to select that the system will latch the fault if it occurs, then if the problem is corrected the fault will still register. Since latched faults are used to set the status LED color, when fault latching is OFF, the status LED should only be green if there are no faults or red if there are one or more active faults. When fault latching is ON, the status LED will be amber if there are no current faults but a fault was previously detected and is now a latched fault. A blinking amber status LED indicates that there are no current faults or latched faults but that an internal signal source is selected instead of an external sourced.

**Figure 12.1.5: Chassis Values External Amplifier Fault Number Set Up Screen (TD/RD)**




Menu Level	Setup Menus Chassis Values Sub Screen
Description	This screen allows the user to set the number of faults that are allowed before the external amplifier is disabled. <b>NOTE:</b> Only used with external amplifiers are in the system.

**Screen 1:** If One Fault is selected and a fault occurs in an external amplifier, the entire transmitter is muted and the faulted external amplifier is latched off. The transmitter is then unmuted and any external amplifiers (fully or partially operational) are enabled.

**Screen 2:** If Three Fault is selected and a fault occurs in an external amplifier, the entire transmitter is muted and unmuted three times before the faulted external amplifier is latched off.

**NOTE:** Faulted amplifier sections are re-enabled when latched faults are cleared in the event log. See Figure 10.1 for more information on clearing the logs.


**Figure 12.1.6: Chassis Values IF Processor Selection Set Up Screen (TD/RD)**



```
IF PROCESSOR IS
REQUIRED      NO
```

Menu Level Setup Menus Chassis Values Sub Screen  
Description This screen allows the user to select that the system has an IF Processor.


**Figure 12.1.7: Chassis Values Downconverter Selection Set Up Screen (TD/RD)**



```
DOWNCONVERTER IS
REQUIRED      NO
```

Menu Level Setup Menus Chassis Values Sub Screen  
Description This screen allows the user to select that the system has a Downconverter.


**Figure 12.1.8: Chassis Values Amplifier Power Supply Voltage Set Up Screen (TD/RD)**



```
AMP POWER SUPPLY
VOLTAGE IS 48VDC
```

Menu Level Setup Menus Chassis Values Sub Screen  
Description This screen allows the user to select the Power Supply Voltage.


**Figure 12.1.9: Chassis Values Forward Power Fault Adjust Set Up Screen (TD/RD)**



```
MINIMUM FORWARD
POWER IS 50%
```

Menu Level Setup Menus Chassis Values Sub Screen  
Description This screen allows the operator to configure a forward power fault threshold setting. When the exciter is enabled for at least a few seconds and the system forward power is not greater than or equal to this setting, a fault is indicated on the status LED and also on the remote fault indicator pin.

**Figure 12.1.10: Chassis Values Number of Amplifiers in System Screen (TD/RD)**



```
EXPECTING 3 AMPS
ENT KEY TO SETUP
```

Menu Level Setup Menus Chassis Values Sub Screen  
Description This screen indicates the number of external amplifier drawers in the system. By selecting the enter key, the system will scan to find the number of external amplifier drawers. **NOTE:** Do not change this screen without first consulting with Axcera.

**Figure 12.1.11: Chassis Values Ethernet Option Set Up Screen (TD/RD)**



Menu Level Setup Menus Chassis Values Sub Screen  
Description Only displayed if Ethernet Controller is not present in your system.

**Figure 12.1.12: Chassis Values Ethernet User Name Set Up Screen (TD/RD)**



Menu Level Setup Menus Chassis Values Sub Screen  
Description When the optional Ethernet Controller is present, this screen is displayed. It is used to reset the first username / password account of the Ethernet controller. There are a total a five accounts available on the Web. If this operation is selected, ON, and the change accepted, only the fist username / password account file is replaced, with the user name set to 'admin' and the password set to 'axcera'.

**Figure 12.1.13: Chassis Values Ethernet Address Set Up Screen (TD/RD)**



Menu Level Setup Menus Chassis Values Sub Screen  
Description When the optional Ethernet Controller module is present, this screen is used to view or change the Ethernet TCP Address of the controller.

**Figure 12.1.14: Chassis Values Ethernet Netmask Set Up Screen (TD/RD)**



Menu Level Setup Menus Chassis Values Sub Screen  
Description When the optional Ethernet Controller module is present, this screen is used to view or change the TCP subnet mask of the Ethernet controller.

**Figure 12.1.15: Chassis Values Ethernet Gateway Set Up Screen (TD/RD)**



Menu Level Setup Menus Chassis Values Sub Screen  
Description When the optional Ethernet Controller module is present, this screen is used to view or change the TCP gateway (router) address of the Ethernet controller.

**Figure 12.2: Device Setup - ATSC Modulator Select**



Menu Level	ATSC Modulator Setup Top Level
Description	This screen provides access to the modulator's read / write parameters.
Parameter Range	N/A

**Figure 12.2.1: Device Setup - Input Signals Category**



Menu Level	ATSC Setup / Input Signals Top Level
Description	This screen provides access to read / write input signal parameters.
Parameter Range	N/A

**Figure 12.2.2: Device Setup - Input Signals - 10MHz Reference Source**



Menu Level	ATSC Setup / Inputs Signals / 10MHz Reference Source
Description	Used to report or set the primary 10MHz reference source. When "GPS" or "External" are selected, "Internal" is automatically used if the selected source is not operational.
Parameter Range	"Auto Select", "GPS", "External", or "Internal"

**Figure 12.2.3: Device Setup - Input Signals - 10MHz Reference Impedance**



Menu Level	ATSC Setup / Inputs Signals / 10MHz Reference Impedance
Description	This is the 10MHz reference source impedance.
Parameter Range	"50 Ohms", or "High Impedance"

**Figure 12.2.4: Device Setup - Input Signals - 10MHz Reference Holdover**



Menu Level	ATSC Setup / Inputs Signals / 10MHz Reference Holdover
Description	This value specifies the minimum duration of 10MHz reference loss required for raising the 10MHz reference alarm.
Parameter Range	0 to 3600 seconds



**Figure 12.2.5: Device Setup - Input Signals - 10MHz Reference Holdover Forever**



Menu Level	ATSC Setup / Inputs Signals / 10MHz Reference Holdover Forever
Description	When set to "Yes" the 10MHz reference loss alarm is disabled and the back-up reference is used whenever an external reference is lost.
Parameter Range	"Yes" or "No"

**Figure 12.2.6: Device Setup - Input Signals - 1 PPS Impedance**



Menu Level	ATSC Setup / Inputs Signals / 1 PPS Impedance
Description	This is the 1 PPS reference source impedance.
Parameter Range	"50 Ohms", or "High Impedance"

**Figure 12.2.7: Device Setup - Input Signals - 1 PPS Holdover**



Menu Level	ATSC Setup / Inputs Signals / 1 PPS Holdover
Description	This value specifies the minimum duration of 1 PPS reference loss required for raising the 1 PPS reference alarm.
Parameter Range	0 to 3600 seconds

**Figure 12.2.8: Device Setup - Input Signals - 1 PPS Holdover Forever**



Menu Level	ATSC Setup / Inputs Signals / 1 PPS Holdover Forever
Description	When set to "Yes" the 1 PPS reference loss alarm is disabled and the internal synthesized 1 PPS reference is used whenever an external reference is lost.
Parameter Range	"Yes" or "No"

**Figure 12.2.9: Device Setup - Input Signals - 1 PPS Trigger Level**



Menu Level	ATSC Setup / Inputs Signals / 1 PPS Trigger Level
Description	This value is the trigger level for the 1 PPS external input in volts.
Parameter Range	0 to 3.5 volts

**Figure 12.2.10: Device Setup - Input Signals - 1 PPS Trigger Edge**



Menu Level ATSC Setup / Inputs Signals / 1 PPS Trigger Edge  
Description This is the trigger edge of the 1 PPS external input.  
Parameter Range "Rising" or "Falling"

**Figure 12.2.11: Device Setup - Input Signals - Input Stream 1 Format**



Menu Level ATSC Setup / Inputs Signals / Input Stream 1 Format  
Description This screen specifies the stream format of physical input 1.  
Parameter Range "ASI" or "SMPTE310M"

**Figure 12.2.12: Device Setup - Input Signals - Input Stream 2 Format**




Menu Level ATSC Setup / Inputs Signals / Input Stream 2 Format  
Description This screen specifies the stream format of physical input 2.  
Parameter Range "ASI" or "SMPTE310M"

**Figure 12.2.13: Device Setup - Input Signals - Primary Stream**



Menu Level ATSC Setup / Inputs Signals / Primary Stream  
Description Used to select the primary transport stream.  
Parameter Range "Input 1" or "Input 2"

**Figure 12.2.14: Device Setup - Input Signals - Secondary Stream**



Menu Level ATSC Setup / Inputs Signals / Secondary Stream  
Description Used to select the secondary transport stream.  
Parameter Range "Input 1" or "Input 2"

**Figure 12.2.15: Device Setup - Input Signals - Stream Switching**



Menu Level	ATSC Setup / Inputs Signals / Stream Switching This screen is used to configure the stream switching system. "Set To Primary" is used to fix the selected stream to the Primary Input source. "Set To Secondary" is used to fix the selected stream to the Secondary Input source. "Prefer Primary" is used to select the primary stream if it is present or switch to the secondary stream if the primary stream is not present. "Use Either Input" is used to switch to the other stream if the selected stream is not present but not to switch back if the other stream returns.
Description	returns.
Parameter Range	"Set To Primary", "Set To Secondary", "Prefer Primary", or "Use Either Input"

**Figure 12.2.16: Device Setup - Input Signals - Primary To Secondary Switching Delay**



Menu Level	ATSC Setup / Inputs Signals / Primary To Secondary Switching Delay This value sets the switching delay from primary source to secondary source after an error is detected in the primary transport stream.
Description	transport stream.
Parameter Range	0 to 300 seconds

**Figure 12.2.17: Device Setup - Input Signals - Secondary To Primary Switching Delay**



Menu Level	ATSC Setup / Inputs Signals / Secondary To Primary Switching Delay This value sets the switching delay from secondary source to primary source after an error is detected in the secondary transport stream.
Description	transport stream.
Parameter Range	0 to 300 seconds

**Figure 12.2.18: Device Setup - Input Signals - Time Sync Source**



Menu Level	ATSC Setup / Inputs Signals / Time Sync Source This value sets the preferred source for time and date information.
Description	information.
Parameter Range	"GPS", "Manual", "NTP"

**Figure 12.2.19: Device Setup - Primary Stream Category**



Menu Level ATSC Setup / Primary Stream Top Level  
Description This screen provides access to read / write primary stream parameters.  
Parameter Range N/A

**Figure 12.2.20: Device Setup - Primary Stream - PAT Loss Alarm Delay**



Menu Level ATSC Setup / Primary Stream / PAT Loss Alarm Delay  
Description This value sets the delay time before reporting of a PAT Loss alarm. An alarm is activated if the PAT table is not detected in the primary transport stream at least once per specified time interval.  
Parameter Range 0 to 10.0 seconds

**Figure 12.2.21: Device Setup - Primary Stream - PAT Loss Alarm Switch**



Menu Level ATSC Setup / Primary Stream / PAT Loss Alarm Switch Control  
Description This value determines if loss of PAT table input shall activate the automatic switch over to the secondary transport stream source based on the current stream switching configuration.  
Parameter Range "On" or "Off"

**Figure 12.2.22: Device Setup - Primary Stream - Transport Stream Stuffing Rate Alarm**



Menu Level ATSC Setup / Primary Stream / Transport Stream Stuffing Rate Alarm  
Description This value determines the level where too many MPEG-2 null packets generate an alarm.  
Parameter Range 0 to 100%

**Figure 12.2.23: Device Setup - Primary Stream - TS Stuffing Rate Alarm Switch**



Menu Level ATSC Setup / Primary Stream / TS Stuffing Rate Alarm Switch Control  
Description This value determines if a Transport Stream Stuffing Rate Alarm shall activate the automatic switch over to the secondary transport stream source based on the current stream switching configuration.  
Parameter Range "On" or "Off"

**Figure 12.2.24: Device Setup - Primary Stream - Transport Stream ID Valid Value**



Menu Level ATSC Setup / Primary Stream / Transport Stream ID Valid Value  
Description This value sets the expected transport stream ID value.  
Parameter Range 0 to 100%

**Figure 12.2.25: Device Setup - Primary Stream - Transport Stream ID Value Alarm Switch**



Menu Level ATSC Setup / Primary Stream / TS ID Alarm Switch Control  
Description This value determines if a Transport Stream ID Value mismatch shall activate the automatic switch over to the secondary transport stream source based on the current stream switching configuration.  
Parameter Range "On" or "Off"

**Figure 12.2.26: Device Setup - Secondary Stream Category**



Menu Level ATSC Setup / Secondary Stream Top Level  
Description This screen provides access to read / write secondary stream parameters.  
Parameter Range N/A

**Figure 12.2.27: Device Setup - Secondary Signals - PAT Loss Alarm Delay**



Menu Level ATSC Setup / Secondary Stream / PAT Loss Alarm Delay  
Description This value sets the delay time before reporting of a PAT Loss alarm. An alarm is activated if the PAT table is not detected in the primary transport stream at least once per specified time interval.  
Parameter Range 0 to 10.0 seconds

**Figure 12.2.28: Device Setup - Secondary Stream - PAT Loss Alarm Switch**



Menu Level ATSC Setup / Secondary Stream / PAT Loss Alarm Switch Control  
Description This value determines if loss of PAT table input shall activate the automatic switch over to the primary transport stream source based on the current stream switching configuration.  
Parameter Range "On" or "Off"

**Figure 12.2.29: Device Setup - Secondary Stream - Transport Stream Stuffing Rate Alarm**



Menu Level ATSC Setup / Secondary Stream / Transport Stream Stuffing Rate Alarm  
Description This value determines the level were too many MPEG-2 null packets generate an alarm.  
Parameter Range 0 to 100%

**Figure 12.2.30: Device Setup - Secondary Stream - TS Stuffing Rate Alarm Switch**



Menu Level ATSC Setup / Secondary Stream / TS Stuffing Rate Alarm Switch Control  
Description This value determines if a Transport Stream Stuffing Rate Alarm shall activate the automatic switch over to the primary transport stream source based on the current stream switching configuration.  
Parameter Range "On" or "Off"

**Figure 12.2.31: Device Setup - Secondary Stream - Transport Stream ID Valid Value**



Menu Level ATSC Setup / Secondary Stream / Transport Stream ID Valid Value  
Description This value sets the expected transport stream ID value.  
Parameter Range 0 to 100%

**Figure 12.2.32: Device Setup - Secondary Stream - Transport Stream ID Value Alarm Switch**



Menu Level ATSC Setup / Secondary Stream / TS ID Alarm Switch Control  
Description This value determines if a Transport Stream ID Value mismatch shall activate the automatic switch over to the primary transport stream source based on the current stream switching configuration.  
Parameter Range "On" or "Off"

**Figure 12.2.33: Device Setup - Output Signals Category**



Menu Level ATSC Setup / Output Signals Top Level  
Description This screen provides access to read / write output signal parameters.  
Parameter Range N/A

**Figure 12.2.34: Device Setup - Output Signals - Modulator Mute**



Menu Level ATSC Setup / Output Signals / Modulator Mute  
Description This value determines if the modulator's output is muted or allowed to operate. When set to "On", the output is muted. When set to "Off" the output is enabled but it may still be muted due to other conditions.  
Parameter Range "On" or "Off"

**Figure 12.2.35: Device Setup - Output Signals - Modulator Output**



Menu Level ATSC Setup / Output Signals / Modulator Output Mode  
Description This value determines the RF output level. When set to "Normal", the RF output level is normal but when set to "Standby" the output level is reduced by -10dB relative to normal. See also *Figure 12.2.35*.  
Parameter Range "Normal" or "Standby"

**Figure 12.2.36: Device Setup - Output Signals - Null Packet Usage**



Menu Level ATSC Setup / Output Signals / Null Packet Usage  
Description Keep null packet "On" provides the most transparent transport stream processing but "Off" provides the highest level of flexibility with regards to gross input data rate (payload + stuffing). Note: Payload + stuffing may exceed the nominal data rate but payload data rate must not exceed the nominal data rate.  
Parameter Range "On" or "Off"

**Figure 12.2.37: Device Setup - Output Signals - Output Level Set**



Menu Level ATSC Setup / Output Signals / Output Level Set  
Description This value is used to set the current output level in dB relative to the nominal level. Note: When modulator output mode is set to standby, the output level is set to -10dB. See also *Figure 12.2.35*.  
Parameter Range -10.0 to 0.0 dB

**Figure 12.2.38: Device Setup - Output Signals - Output Frequency Set**



Menu Level ATSC Setup / Output Signals / Output Frequency Set  
Description This value is used to set the output frequency in Hz. Each position of frequency value may be individually set provided the value is adjusted within the acceptable range.  
Parameter Range 30,000,000 to 1,000,000,000 Hz

**Figure 12.2.39: Device Setup - Output Signals - Output Frequency Offset**



Menu Level ATSC Setup / Output Signals / Output Frequency Offset  
Description This value is used to apply an output frequency offset. Each position is individually set provided the value is adjusted within the acceptable range.  
Parameter Range -8,388,608 to 8,388,607 Hz

**Figure 12.2.40: Device Setup - Output Signals - Output Polarity**



Menu Level ATSC Setup / Output Signals / Output Polarity  
Description This value is used to adjust the polarity of the output signal spectrum. When set to "Normal", the lowest carrier number is placed on the lowest spectrum frequency. When set to "Inverted", the highest carrier number is placed on the lowest spectrum frequency.  
Parameter Range "Normal" or "Inverted"

**Figure 12.2.41: Device Setup - Output Signals - Peak Clipping Level**



Menu Level ATSC Setup / Output Signals / Peak Clipping Level  
Description This value is used to adjust the peak clipping level relative to the average RMS at baseband.  
Parameter Range 12.0 to 2.0 dB in 0.5 dB intervals. **Typical value: 5 or 6dB**


**Figure 12.2.42: Device Setup - Output Signals - Peak Clipping Strength**



Menu Level ATSC Setup / Output Signals / Peak Clipping Strength  
Description This value is used to adjust strength of applied peak clipping. '0' equals hard clipping while '100' equals the maximum softness (minimum sideband noise).  
Parameter Range 0 to 100 %. **Typical value is 50%**



**Figure 12.2.43: Device Setup - Output Signals - Stream Monitoring Location**



Menu Level	ATSC Setup / Output Signals / Stream Monitoring
Description	This value is used to determine the transport stream monitoring location for the ASI Monitor Output port.
Parameter Range	"Input 1", "Input 2", or "Output Stream"

**Figure 12.2.44: Device Setup - Output Signals - Test Signals**



Menu Level	ATSC Setup / Output Signals / Test Signals
Description	This value is used to determine the status of the test signal system. "Off" is the normal state where no test signals are applied. "Single Carrier" enables a single carrier test signal. "PRBS ON" is used to enable a forced transmission of stuffing data (null packets) only. "PRBS Auto" is used to enable a transmission of stuffing data (null packets) only when the input stream is not available. "Test Signal" is used to enable a test signal with a 3dB peak-to-average peak ratio.
Parameter Range	"Off", "Single Carrier", "PRBS ON", "PRBS Auto", or "Test Signal"

**Figure 12.2.45: Device Setup - Nonlinear Precorrector Adjustments Category**



Menu Level	ATSC Setup / Nonlinear Precorrector Adjustment Top Level
Description	This screen provides access to read / write parameters of the Nonlinear Precorrector system.
Parameter Range	N/A

**Figure 12.2.46: Device Setup - Nonlinear Adjust - Mode**



Menu Level	ATSC Setup / Nonlinear Adjust / Mode
Description	This value sets the mode of the nonlinear precorrector system. "Only Monitor" is selected when nonlinear correction is disabled but it still allows shoulder performance to be monitored. "Static Correction" is selected to enable manual nonlinear correction. "Adaptive On" is used to enable adaptive precorrection.
Parameter Range	"Only Monitor", "Static Correction", or "Adaptive On"

**Figure 12.2.47: Device Setup - Nonlinear Adjust - Operational Mode**



Menu Level	ATSC Setup / Nonlinear Adjust / Operational Mode This value sets the operational mode of the nonlinear precorrector system. "Idle / Static" is selected to apply current correction characteristics but future changes are not automatically made. "Single" is selected to have the system calculate correction characteristics one time then system returns to "Idle / Static". "Continuous" applies the current correction characteristics and automatically monitors the system and applies new correction values when better performance can be obtained. "Run To Target" applies correction and applies new correction values until the upper and lower spectrum shoulders match target levels. "Automatic Run" is selected when continuous precorrection is desired until the upper and lower shoulder values are corrected. "Automatic Run" then holds correction static with the option to have new correction values automatically calculated and applied when output performance subsequently drops below the set threshold.
Description	"Idle/Static", "Single", "Continuous", "Run To Target",
Parameter Range	"Automatic Run"

**Figure 12.2.48: Device Setup - Nonlinear Adjust - Reset To Neutral Command**



Menu Level	ATSC Setup / Nonlinear Adjust / Reset To Neutral Command This screen provides access to reset the nonlinear correction to neutral.
Description	neutral.
Parameter Range	"On" or "Off"

**Figure 12.2.49: Device Setup - Linear Precorrector Adjustments Category**



Menu Level	ATSC Setup / Linear Precorrector Adjustment Top Level This screen provides access to read / write parameters of the Linear Precorrector system.
Description	Linear Precorrector system.
Parameter Range	N/A

**Figure 12.2.50: Device Setup - Linear Adjust - Mode**



Menu Level	ATSC Setup / Linear Adjust / Mode This value sets the mode of the linear precorrector system. "Only Monitor" is selected when linear correction is disabled but it still allows group delay and amplitude ripple to be monitored. "Static Correction" is selected to enable manual linear correction.
Description	"Adaptive On" is used to enable adaptive precorrection.
Parameter Range	"Only Monitor", "Static Correction", or "Adaptive On"

**Figure 12.2.51: Device Setup - Linear Adjust - Operational Mode**



Menu Level	ATSC Setup / Linear Adjust / Operational Mode
Description	This value sets the operational mode of the linear precorrector system. "Idle / Static" is selected to apply current correction characteristics but future changes are not automatically made. "Single" is selected to have the system calculate correction characteristics one time then system returns to "Idle / Static". "Continuous" applies the current correction characteristics and automatically monitors the system and applies new correction values when better performance can be obtained. "Run To Target" applies correction and applies new correction values until the upper and lower spectrum shoulders match target levels. "Automatic Run" is selected when continuous precorrection is desired until the upper and lower shoulder values are corrected. "Automatic Run" then holds correction static with the option to have new correction values automatically calculated and applied when output performance subsequently drops below the set threshold.
Parameter Range	"Idle/Static", "Single", "Continuous", "Run To Target", "Automatic Run"

**Figure 12.2.52: Device Setup - Linear Adjust - Reset To Neutral Command**



Menu Level	ATSC Setup / Linear Adjust / Reset To Neutral Command
Description	This screen provides access to reset the linear correction to neutral.
Parameter Range	"On" or "Off"

**Figure 12.2.53: Device Setup - Adaptive Precorrector Adjustments Category**



Menu Level	ATSC Setup / Adaptive Precorrector Adjustment Top Level
Description	This screen provides access to read / write parameters of the Adaptive Precorrector system.
Parameter Range	N/A

**Figure 12.2.54: Device Setup - Adaptive Precorrector - Lower Shoulder Target Value**



Menu Level	ATSC Setup / Adaptive Correct / Lower Shoulder Target Value
Description	This value can be is used by the adaptive precorrector systems to start and stop linear and nonlinear precorrector operations. This value specifically relates to the lower shoulder of the feedback signal.
Parameter Range	-60 to 0 dB

**Figure 12.2.55: Device Setup - Adaptive Precorrector - Upper Shoulder Target Value**



TARGET OF UPPER  
SHOULDER -62 dB

Menu Level ATSC Setup / Adaptive Correct / Upper Shoulder Target Value  
Description This value can be is used by the adaptive precorrector systems to start and stop linear and nonlinear precorrector operations. This value specifically relates to the upper shoulder of the feedback signal.  
Parameter Range -60 to 0 dB

**Figure 12.2.56: Device Setup - Adaptive Precorrector - Amplitude Ripple Target Value**



TARGET AMPLITUDE  
RIPPLE 0.1 dB

Menu Level ATSC Setup / Adaptive Correct / Amplitude Ripple Target Value  
Description This value can be is used by the adaptive precorrector systems to start and stop linear and nonlinear precorrector operations.  
Parameter Range 0.0 to 5.0 dB

**Figure 12.2.57: Device Setup - Adaptive Precorrector - Group Delay Target Value**



TARGET OF GROUP  
DELAY 18 NS

Menu Level ATSC Setup / Adaptive Correct / Group Delay Target Value  
Description This value can be is used by the adaptive precorrector systems to start and stop linear and nonlinear precorrector operations.  
Parameter Range 0 to 1000 nS

**Figure 12.2.58: Device Setup - Adaptive Precorrector - Lower Shoulder Hysteresis Value**



HYSTERESIS LOWER  
SHOULDER 3.0 dB

Menu Level ATSC Setup / Adaptive Correct / Lower Shoulder Hysteresis Value  
Description This value is used with the target value and the usage setting by the adaptive precorrector systems to start and stop linear and nonlinear precorrector operations.  
Parameter Range 0 to 50 dB

**Figure 12.2.59: Device Setup - Adaptive Precorrector - Upper Shoulder Hysteresis Value**



A screenshot of a device menu showing the text 'HYSTERESIS UPPER SHOULDER 3.0 dB' in a blue, monospaced font on a black background.

Menu Level ATSC Setup / Adaptive Correct / Upper Shoulder Hysteresis Value  
Description This value is used with the target value and the usage setting by the adaptive precorrector systems to start and stop linear and nonlinear precorrector operations.  
Parameter Range 0 to 50 dB

**Figure 12.2.60: Device Setup - Adaptive Precorrector - Amplitude Ripple Hysteresis Value**



A screenshot of a device menu showing the text 'HYSTERESIS AMP RIPPLE 1 dB' in a blue, monospaced font on a black background.

Menu Level ATSC Setup / Adaptive Correct / Amplitude Ripple Hysteresis Value  
Description This value is used with the target value and the usage setting by the adaptive precorrector systems to start and stop linear and nonlinear precorrector operations.  
Parameter Range 0.00 to 5.00 dB

**Figure 12.2.61: Device Setup - Adaptive Precorrector - Group Delay Hysteresis Value**



A screenshot of a device menu showing the text 'HYSTERESIS GROUP DELAY 1.0 NS' in a blue, monospaced font on a black background.

Menu Level ATSC Setup / Adaptive Correct / Group Delay Hysteresis Value  
Description This value is used with the target value and the usage setting by the adaptive precorrector systems to start and stop linear and nonlinear precorrector operations.  
Parameter Range 0 to 1000 nS

**Figure 12.2.62: Device Setup - Adaptive Precorrector - Lower Shoulder Usage**



A screenshot of a device menu showing the text 'USAGE OF LOWER SHOULDER OFF' in a blue, monospaced font on a black background.

Menu Level ATSC Setup / Adaptive Correct / Lower Shoulder Usage  
Description When set to "On", the target value and hysteresis value are used by the adaptive precorrector systems to start and stop linear and nonlinear precorrector operations.  
Parameter Range "On", or "Off"

**Figure 12.2.63: Device Setup - Adaptive Precorrector - Upper Shoulder Usage**



A screenshot of a device menu showing the text 'USAGE OF UPPER SHOULDER OFF' in a blue, monospaced font on a black background.

Menu Level ATSC Setup / Adaptive Correct / Upper Shoulder Usage  
Description When set to "On", the target value and hysteresis value are used by the adaptive precorrector systems to start and stop linear and nonlinear precorrector operations.  
Parameter Range "On", or "Off"

**Figure 12.2.64: Device Setup - Adaptive Precorrector - Amplitude Ripple Usage**



Menu Level ATSC Setup / Adaptive Correct / Amplitude Ripple Usage  
When set to "On", the target value and hysteresis value are used by the adaptive precorrector systems to start and stop linear and nonlinear precorrector operations.  
Description  
Parameter Range "On", or "Off"

**Figure 12.2.65: Device Setup - Adaptive Precorrector - Group Delay Usage**



Menu Level ATSC Setup / Adaptive Correct / Group Delay Usage  
When set to "On", the target value and hysteresis value are used by the adaptive precorrector systems to start and stop linear and nonlinear precorrector operations.  
Description  
Parameter Range "On", or "Off"

**Figure 12.2.66: Device Setup - GPS System Category**



Menu Level ATSC Setup / GPS System Top Level  
This screen provides access to read / write parameters of the optional GPS system. Note: Not all systems have the GPS system enabled.  
Description  
Parameter Range N/A

**Figure 12.2.67: Device Setup - GPS - Antenna Bias**



Menu Level ATSC Setup / GPS / Antenna Bias  
When set to "On", the 5V antenna bias supply is enabled. When set "Off", the antenna is not powered.  
Description  
Parameter Range "On", or "Off"

**Figure 12.2.68: Device Setup - GPS - Antenna Cable Delay**



Menu Level ATSC Setup / GPS / Antenna Cable Delay  
This value is used to specify the cable delay associated with the type and length of cable used to connect the antenna to the modulator. This value is very important in SNF systems.  
Description  
Parameter Range 0 to 1375 nS

**Figure 12.2.69: Device Setup - GPS - Internal Reference Holdover Time**



```
INT REF HOLDOVER
TIME    2400 SEC
```

Menu Level ATSC Setup / GPS / Internal Reference Holdover Time  
Description This value is the holdover time for which it is acceptable to continue operating on the internal TCXO reference of the GPS whenever GPS lock is lost.  
Parameter Range 0 to 3600 seconds

**Figure 12.2.70: Device Setup - GPS - Internal Reference Holdover Forever**



```
INT REF HOLDOVER
FOREVER OFF
```

Menu Level ATSC Setup / GPS / Internal Reference Holdover Forever  
Description When set to "Yes", the modulator may continue indefinitely to operate on the internal TCXO reference of the GPS whenever GPS lock is lost. When set to "No", the modulator will raise a GPS Unlocked alarm after the Internal Reference Holdover Time has expired with possible output muting based on alarm configurations.  
Parameter Range "On", or "Off"

**Figure 12.2.71: Device Setup - General Device IO Category**



```
ATSC MODULATOR
GENERAL IO
```

Menu Level ATSC Setup / General Device IO Top Level  
Description This screen provides access to the general read / write parameters system used for general communication with the modulator.  
Parameter Range N/A

**Figure 12.2.72: Device Setup - General IO - Serial Baud Rate**



```
SERIAL BAUD RATE
115200
```

Menu Level ATSC Setup / General IO / Serial Baud Rate  
Description This screen is used to view and change the serial baud rate. The modulator must be communicating with the transmitter for changes to be made and the transmitter automatically tries different baud rates if it is not communicating with a modulator. The default of 115200 works well therefore slower baud rates are not recommended.  
Parameter Range 115200, 57600, 38400, 19200, 9600, 4800, or 2400

**Figure 12.2.73: Device Setup - General IO - Ethernet DHCP**



Menu Level ATSC Setup / General IO / Ethernet DHCP  
When set to "On", the modulator will attempt to get its TCP/IP address from a DHCP server. DHCP set to "Off" is recommended so that remote operators will not need to search and find the IP address of the device.

Description address of the device.

Parameter Range "On", or "Off"

**Figure 12.2.74: Device Setup - General IO - Ethernet IP Address**



Menu Level ATSC Setup / General IO / Ethernet IP Address  
This screen displays the actual control IP address of the modulator device. This is not the TsoIP address if Transport Stream over IP is implemented.

Description Stream over IP is implemented.

Parameter Range IP values 0.0.0.0 thru 255.255.255.255

**Figure 12.2.75: Device Setup - General IO - Ethernet IP Subnet Mask**



Menu Level ATSC Setup / General IO / Ethernet IP subnet Mask  
This screen displays the actual control IP subnet mask of the modulator device. This is not the TSoIP mask if Transport Stream over IP is implemented.

Description over IP is implemented.

Parameter Range IP values 0.0.0.0 thru 255.255.255.255

**Figure 12.2.76: Device Setup - General IO - Ethernet IP Gateway**



Menu Level ATSC Setup / General IO / Ethernet IP Gateway  
This screen displays the actual IP gateway of the modulator device.

Description device.

Parameter Range IP values 0.0.0.0 thru 255.255.255.255

**Figure 12.3: Device Setup – 8VSB Demodulator**



Menu Level 8VSB Demodulator Setup Main Screen  
Description This is the System Set Up 8VSB Demodulator Main Sub Screen that is only present in the Regenerative Translator mode. Push the ENTER button to access the Set Up 8VSB Demodulator submenus or push the DOWN Arrow to view the next Set Up Main Sub Screen, which is the Set Up 8VSB Modulator Main Sub Screen. **NOTE:** Refer to the description in Figure 12B for how to change the values on the following set-up screens.



**Figure 12.3.1: Device Setup - 8VSB Demodulator Channels Set Up Screen (RD)**




Menu Level 8VSB Demodulator Setup Main Screen  
Description This screen allows selection of the channel plan which can be changed to either Off Air or Cable.

**Figure 12.3.2: Device Setup - 8VSB Demodulator Channel Select Set Up Screen (RD)**



Menu Level 8VSB Demodulator Setup Main Screen  
Description This screen allows selection of the channel, for the channel plan selected in the previous screen.

**Figure 12.4: Device Setup – External Amplifier #1 (TD/RD)**



Menu Level External Amplifier #1 Setup Main Screen  
Description This screen provides access to the external amplifier #1 read / write parameters. **WARNING:** THESE SCREEN VALUES ARE USED TO IMPLEMENT PROTECTION CIRCUITS WITHIN THE AMPLIFIER. FACTORY SET VALUES SHOULD NOT BE CHANGED WITHOUT DIRECTION FROM AXCERA FIELD SERVICE.

**NOTE:** Shown below are the External Amplifier #1 Set-Up Screens. The External Amplifier #2, #3 or #4 Set-Up Screens are presented in the same order if they are present in the system.

**Figure 12.4.1: Device Setup – External Amplifier #1 VSWR Trip Set Up Screen (TD/RD)**



Menu Level External Amplifier #1 VSWR Trip Setup Screen  
Description This screen allows set up of the VSWR Trip level. Adjustment range is zero to 3.09 Volts. This value is unique for each amplifier based on the output power and frequency.  
Parameter Range

**Figure 12.4.2: Device Setup – External Amplifier #1 I1-A1 Current Set Up Screen (TD/RD)**



Menu Level External Amplifier #1 I1-A1 Current Setup Screen  
Description This screen allows set up of the I1-A1 Current level.  
Parameter Range Adjustment range is zero to 49.9 Amps.

**Figure 12.4.3: Device Setup – External Amplifier #1 I2-A2 Current Set Up Screen (TD/RD)**



EX AMP #1  
I2-A2 AT 14.4 A

Menu Level External Amplifier #1 I2-A2 Current Setup Screen  
Description This screen allows set up of the I2-A2 Current level.  
Parameter Range Adjustment range is zero to 49.9 Amps

**Figure 12.4.4: Device Setup – External Amplifier #1 I3-B1 Current Set Up Screen (TD/RD)**



EX AMP #1  
I3-B1 AT 14.9 A

Menu Level External Amplifier #1 I3-B1 Current Setup Screen  
Description This screen allows set up of the I3-B1 Current level. Some low power external amplifiers may not monitor the I3-B1 current signal.  
Parameter Range Adjustment range is zero to 49.9 Amps.

**Figure 12.4.5: Device Setup – External Amplifier #1 I4-B2 Current Set Up Screen (TD/RD)**



EX AMP #1  
I4-B2 AT 14.5 A

Menu Level External Amplifier #1 I4-B2 Current Setup Screen  
Description This screen allows set up of the I4-B2 Current level. Some low power external amplifiers may not monitor the I4-B2 current signal.  
Parameter Range Adjustment range is zero to 49.9 Amps.

**Figure 12.4.6: Device Setup – External Ampl. #1 Temp. A Warning Set Up Screen (TD/RD)**



EX AMP #1  
TEMP A WARN 85C

Menu Level External Amplifier #1 Temperature A Warning Setup Screen  
Description This screen allows set up of the Device A temperature Warning level.  
Parameter Range Adjustment range is zero to 219C but a typical value is 85C.

**Figure 12.4.7: Device Setup – External Ampl. #1 Temp. A Fault Set Up Screen (TD/RD)**



EX AMP #1  
TEMP A FLT 90C

Menu Level External Amplifier #1 Device A Temperature Fault Setup Screen  
Description This screen allows set up of the Device A Temperature Fault level.  
Parameter Range Adjustment range is zero to 219C but a typical value is 90C.

**Figure 12.4.8: Device Setup – External Ampl. #1 Temp. B Warning Set Up Screen (TD/RD)**



EX AMP #1  
TEMP B WARN 85C

Menu Level External Amplifier #1 Device B Temperature Warning Setup Screen  
Description This screen allows set up of the Device B Temperature Warning level.  
Parameter Range Adjustment range is zero to 219C but a typical value is 85C.

**Figure 12.4.9: Device Setup – External Ampl. #1 Temp. B Fault Set Up Screen (TD/RD)**



EX AMP #1  
TEMP B FLT 90C

Menu Level External Amplifier #1 Device B Temperature Fault Setup Screen  
Description This screen allows set up of the Device B Temperature Fault level.  
Parameter Range Adjustment range is zero to 219C but a typical value is 90C.

**Figure 12.4.10: Device Setup – Ext. Ampl. #1 Power Supply A High Set Up Screen (TD/RD)**



EX AMP #1  
PS A HIGH 49.9 V

Menu Level External Amplifier #1 Power Supply A High Setup Screen  
Description This screen allows set up of the Power Supply A High level. Adjustment range is zero to 49.9 Volts. Value is set based on nominal voltage of power supply which may be different for VHF and UHF amplifiers.  
Parameter Range

**Figure 12.4.11: Device Setup – Ext. Ampl. #1 Power Supply A Low Set Up Screen (TD/RD)**



EX AMP #1  
PS A LOW 46.0 V

Menu Level External Amplifier #1 Power Supply A Low Setup Screen  
Description This screen allows set up of the Power Supply A Low level.  
Parameter Range Adjustment range is zero to 49.9 Volts.

**Figure 12.4.12: Device Setup – Ext. Ampl. #1 Power Supply B High Set Up Screen (TD/RD)**



EX AMP #1  
PS B HIGH 49.9 V

Menu Level External Amplifier #1 Power Supply B High Setup Screen  
Description This screen allows set up of the Power Supply B High level. Some low power external amplifiers may not contain a B-side power supply.  
Parameter Range Adjustment range is zero to 49.9 Volts.

**Figure 12.4.13: Device Setup – Ext. Ampl. #1 Power Supply B Low Set Up Screen (TD/RD)**




EX AMP #1  
PS B LOW 46.0 V

Menu Level External Amplifier #1 Power Supply B Low Setup Screen  
Description This screen allows set up of the Power Supply B Low level. Some low power external amplifiers may not contain a B-side power supply.  
Parameter Range Adjustment range is zero to 49.9 Volts.

### (Optional) Innovator CX Series Web Ethernet Interface Kit (1313100)

The Innovator CX transmitter is available with an optional Ethernet interface package. Axcera part number (1316423) is the Axcera part number for an Ethernet Interface kit that provides an SNMP interface to transmitter parameters, serves HTML web pages, and provides a link to the modulator web pages. This option may be added to the Innovator CX transmitter if it was not originally installed at the factory. **NOTE:** Mozilla Firefox is the preferred browser for this WEB Ethernet interface kit.

Figure 13: Typical Ethernet User Log In Screen



Once a connection has been established, the web interface can be launched by entering the IP address of the Innovator CX Ethernet Controller as a URL in the browser of the remote computer. A login screen will be displayed prompting for a user name and password, **which are case sensitive**.

The controller has three levels of user access: Administrative, Read/Write and Read Only. Administrators have full access to transmitter controls and controller configuration. Read/Write users have full access to transmitter controls and can change all controller configurations except for the user name and password accounts. Read Only users can view all transmitter parameters and the event log entries but they can not change the transmitter's state, clear faults, clear the event log or configure the Ethernet parameters.


Five unique login accounts are available. The factory default user name and password for account number one are:

User Name	Password	Access Level
admin	axcera	Administrator

The user name and password of account number one may be reset to factory default values through a setup screen of the transmitter.

After logging in, the main control/monitoring screen is displayed. Administrators have the ability to change the transmitter's operate / standby state, and configure the application. All users have the ability to view the transmitter's event log, and review system parameters. Refer to Figure 14 for a sample of the main control/monitoring screen.

Figure 14: Typical Ethernet Main Control/Monitoring Screen



Color Key:

- Green = Okay or Normal Operation
- Yellow = Warning, But Not faulted
- Red = Currently Active Fault
- Orange = Old or Previously Latched Fault

If an item on screen is Orange, a latched fault is present. Activating the **'Fault Reset'** button will reset any latched faults, clears the transmitter's event log and causes the parameter to display normally.

The date and time of the last message received by the web page browser is present to assure connectivity. If the browser does not receive a new set of data from the Ethernet Controller, it will show the last update field with a yellow background indicating a connection problem is present.

From the main page, administrators and accounts with read/write access may change the web interface settings by activating the 'Configure' button near the top of the screen.

## Modulator Web Interface

Access to view the Modulator WEB Interface is available by selecting the '**Modulator Status**' button.

The modulator requires a valid username and password for login access. When launched from the Axcera CX web interface, the login address of username / password information is automatically included in the login script. Since username and passwords of the modulator are fixed, we recommend modulator web pages are only launched from the main CX web page using the modulator command button. .

**NOTE:** Mozilla Firefox is the preferred browser for this modulator WEB interface.

Three levels of access are provided. 1) Administrators have full read / write control of the modulator and they can configure all system parameters of the modulator. 2) An Operator has read / write control of most modulator parameters and limited ability to configure system parameters. 3) An Observer has read only access to the modulator parameters.


Figure 15: Sample Modulator Page



The modulator's web page contains an upper form and three lower forms. The upper form always shows a graphical representation of the modulators system. A Block of the upper form can be dragged into any one of the three lower forms to view specific

details of the specific system. In the above figure, the "Switching" block of the Input System was dragged into the lower left form. The GPS block of Reference was dragged into the lower middle form and the Nonlinear block of Precorrection was placed into the lower right form.

Figure 16: Additional Forms



Activating the "System" icon located at the lower left corner of the page accesses additional forms. The sample screen above is typical of forms available to an administrator. Operators and Observers will have different forms available.



Access to view the transmitter's event log is available by selecting the '**View Events**' button.

Figure 17: Typical Event Log Screen

Eventlog Entries: 200 Last Update: 12/06/2011 @ 15:52:00

Index	Event ID	(Occurance)	Description
1	001	OF 200 (62)	AGC INPUT FAULT CLEARED 18 SECONDS AFTER PRIOR EVENT
2	002	OF 200 (63)	AGC INPUT FAULTED 08 SECONDS AFTER PRIOR EVENT
3	003	OF 200 (72)	PROGRAM STARTUP
4	004	OF 200 (67)	SET TO STANDBY OCCURED 02 SECONDS AFTER PRIOR EVENT
5	005	OF 200 (06)	DRIVER TEMP FAULT CLEARED 03 SECONDS AFTER PRIOR EVENT
6	006	OF 200 (63)	AGC INPUT FAULT CLEARED 15 SECONDS AFTER PRIOR EVENT
7	007	OF 200 (64)	AGC INPUT FAULTED 08 SECONDS AFTER PRIOR EVENT
8	008	OF 200 (07)	DRIVER TEMP FAULTED 16 SECONDS AFTER PRIOR EVENT
9	009	OF 200 (73)	PROGRAM STARTUP
10	010	OF 200 (68)	SET TO STANDBY OCCURED 02 SECONDS AFTER PRIOR EVENT
11	011	OF 200 (07)	DRIVER TEMP FAULT CLEARED 03 SECONDS AFTER PRIOR EVENT
12	012	OF 200 (64)	AGC INPUT FAULT CLEARED 15 SECONDS AFTER PRIOR EVENT
13	013	OF 200 (65)	AGC INPUT FAULTED 08 SECONDS AFTER PRIOR EVENT
14	014	OF 200 (08)	DRIVER TEMP FAULTED 10 SECONDS AFTER PRIOR EVENT
15	015	OF 200 (74)	PROGRAM STARTUP
16	016	OF 200 (75)	PROGRAM STARTUP
17	017	OF 200 (69)	SET TO STANDBY OCCURED 02 SECONDS AFTER PRIOR EVENT
18	018	OF 200 (65)	AGC INPUT FAULT CLEARED 18 SECONDS AFTER PRIOR EVENT
19	019	OF 200 (66)	AGC INPUT FAULTED 08 SECONDS AFTER PRIOR EVENT
20	020	OF 200 (76)	PROGRAM STARTUP

Time Since Last Event: 2 Minutes 17 Seconds

[Download Event Log](#)

Next

This screen allows an operator to view events and to determine the time between events. Events are logged in the order they are received. If more than 200 events are detected, the transmitter's System Controller drops the oldest event to record the new event. Transferring of events from the transmitter's System Controller and the Ethernet Controller is scheduled so that device details are continuously monitored. Therefore the event log screen may update a few seconds behind the transmitter display when the log is full or changing quickly.

Each event record indicates the event number, the number of events, an occurrence counter and text describing the event. The occurrence counter keeps track of the number of times a specific event has occurred since the log was last cleared. Up to 99 occurrences are available for each event.

To view the next set of twenty events, activate the '**Next**' button. If viewing events higher in the log, the '**Previous**' button allows you to return to prior events.

Figure 18: Ethernet Configuration Screen

The screenshot shows the 'CONFIGURE' screen for an Axcera transmitter. At the top, there is a navigation bar with the Axcera logo, 'SNMP 2.1: Users 1', 'Back', 'Manage Accounts', and 'SITE ID: CXB With ATSC Modulator'. The 'the rf experts' logo is in the bottom right of the header. The main content area is titled 'CONFIGURE' and shows various configuration fields:

- IP Address:** 155.226.166.212 (Update button, format: (xxx.xxx.xxx.xxx))
- Subnet Mask:** 255.255.240.000 (Update button, format: (xxx.xxx.xxx.xxx))
- Gateway:** 155.226.167.001 (Update button, format: (xxx.xxx.xxx.xxx))
- Site ID:** CXB With ATSC Module (Update button, format: (Up to 40 characters))
- SNMP Trap Destination 1:** 155.226.166.240 (Update button, Send Test Trap button, format: (xxx.xxx.xxx.xxx))
- SNMP Trap Destination 2:** 000.000.000.000 (Update button, format: (xxx.xxx.xxx.xxx))
- Target Power Level (%):** (empty field) (Power Fixed in Manual AGC Mode)
- Forward Power Fault (%):** 0 (Set Level button, Min Level Else Fault (0-99))
- Fault Latching:** Disabled (Enable button)
- Amplifier Faults Before Disabled:** 3 Faults (1 Fault button)

When entering a site ID, be sure to not use special characters except underscores, dashes, and forward slashes. Changes to the transmitter's output power are available to administrators when the transmitter is operating. Once changed, the menu defaults back to the main display page and the systems forward power is noted as changing.

The screen above displays SNMP parameters and allows an operator to send a test trap. If this system did not have SNMP enabled, then fields would not be populated and the '**Send Test Trap**' button would not be present. New event log entries including an activated test trap are automatically forwarded to SNMP agents specified to receive trap messages. Trap messages do not need to be acknowledged by an agent.

**NOTE:** The Innovator CX controller does not use DHCP addresses – TCP/IP settings must be fixed and entered manually. A crossover cable may be needed if connecting directly from a computer to the Innovator CX Transmitter.

To manage user accounts, administrators may click the 'Manage Accounts' button near the top of the configure screen.

Figure 19: Typical Manage Accounts Screen

MANAGE ACCOUNTS Last Update: 12/06/2011 @ 15:57:30

Account Number	User Name	Password	Access Level		
1	admin	axcera	Administrator	Add/Change	Delete
2	read	only	Read Only	Add/Change	Delete
3	readwrite	user	Read / Write	Add/Change	Delete
4	nobody	none	Read Only	Add/Change	Delete
5	nobody	none	Read Only	Add/Change	Delete

Do not use spaces or special characters

The Innovator CX Ethernet controller supports up to 5 different user accounts. To add or change one of the accounts, click the Add/Change button in the row of the account you want to modify, then enter the desired name, password, and administrator or read/write access rights for the user and click save.

**NOTE:** The transmitter's set up menus contain a Reset Ethernet User ID screen.

This screen allows a user to reset the first account User Name and Password. The Yes or No selection can be changed by pushing the Up or Down Button. After the selection has been made, the user needs to depress the right or left arrow and then the display will ask "PUSH ENTER TO ACCEPT CHANGES". If the ENTER button is depressed, the change will be accepted. If any other button is depressed, the change will not be made. If Yes is selected on the screen, and accepted, the User name and Password will reset to the factory default of admin / axcera.

Activate the '**Back**' button to return to the main control/monitoring screen.

When you have completed using the web interface, please remember to log out via the '**logout**' button at the top of the control/monitoring screen.

## **SNMP Interfaces**

The Innovator CX Ethernet Controller implements Simple Network Management Protocol (SNMP). SNMP is a standardized method of transferring information from one electronic device to another. SNMP is typically used to remotely control and monitor several transmitter devices from a centralized network management system (NMS). SNMP is a communication method between two applications and is not a graphical user interface. Therefore, SNMP functionality is included along with web page server functionality. SNMP is used to gather information or set control states but it requires additional computer applications for operator monitoring and control.

The Innovator CX Ethernet controller implements SNMP version 2 (SNMP v2) using a Management Information Base (MIB). The MIB file defines all SNMP parameters of the transmitter, specifies the format of data, and orders the presentation of the parameters using a hierarchical namespace containing object identifiers (OID). Each OID identifies a variable that can be read, read and set, or only set via SNMP commands.

SNMP functionality also provides for alert messages that are issued from the Ethernet Controller to one or two network computers. A SNMP trap message is sent only once and is not acknowledged by the receiving device. The Ethernet Controller issues a trap message when data is added to the transmitter Event log (either activation of a fault or when a fault is cleared), or when the transmitter operate/standby status changes.

## **SNMP Configuration**

The Ethernet Controller's TCP/IP Address, Subnet Mask, and Gateway must be configured with static values that are valid within your network. Dynamic Host Configuration Protocol (DHCP) is not implemented; however access to these configuration parameters is available through the front panel setup menus of the Innovator CX.

The Innovator CX's SNMP MIB allows up to two SNMP trap destinations. The trap destination values can be set through WEB pages. The TCP/IP address of a trap processing computer can also be configured through the SNMP parameters called 'site\_trap\_adr1' and 'site\_trap\_adr2'. To clear a previously configured trap destination and cause the system not to issue traps to a specific address, set the value to '000.000.000.000'.

Reading of SNMP values is done with the message's community access set to 'public'. When setting SNMP values, a default community access level of 'private' is used. Future implementations of the Ethernet SNMP agent may allow for the set community access level to be defined through the device's web server.

**Circuit Descriptions of Boards in the CHV0xD-1 & CHV0xD-4 System**

**(A1) 8 VSB Demodulator Board (1308275) - Only used with RD operation**

**Overview**

The 8 VSB demodulator assembly receives an off air 8 VSB signal on any VHF or UHF channel and demodulates this to an MPEG-2 transport stream that is per the SMPTE-310M standard. The input to the assembly is at an "F" style connector on the shielded tuner and can be at a level of -8 to -78 dBm. The tuner (TU1) down converts the RF channel to a 44 MHz IF signal. This signal is the input to the digital receiver chip U1. The digital receiver chip subsequently decodes the IF and delivers an MPEG-2 transport stream on a parallel data bus to a programmable logic array, U8. U8 clocks the asynchronous MPEG data from the receiver chip and outputs a synchronous data stream at a 19.39 MHz rate to buffer/driver U11. U11 subsequently drives the output at J13 to a lower level that is AC coupled out of the board.

**Microcontroller Functions**

A microcontroller, U17, is provided on this assembly to supervise the operation of the receiver chip and the tuner. In addition, the microcontroller also interfaces to the front panel LCD display via connector J24 and pushbutton interface on J27. On power up, the microcontroller sets the tuner to the last channel that was selected when the unit was powered down. In addition, the microcontroller also configures the digital receiver to operate as an 8 VSB receiver. The communication between all of the devices on this board is via an I2C serial bus that is local to this board.

**Jumper and DIP Switch Settings**

This board can be used in various assemblies. When this assembly is installed in the Innovator CX product, the jumpers on J7 and J8 should be placed between pins 2 and 3 for normal operation. The DIP switch SW1 should be configured as indicated in Table 12.

Table 12: Innovator CX Receive /Demodulator/Transcoder Dip Switch SW1

Position	Function	When Switch is Off	When Switch is On
SW1-1	Tuner Type	Original Tuner (DTT765xx)	Recent Tuner (DTT7680x)
SW1-2	Signal Strength Gain	Gain = 8.0	Gain = 9.3
SW1-3	Special Channel Plan	Normal	Channels 2, 3, or 4 are offset up 4 MHz
SW1-4	Reserved for Future		
SW1-5	Reserved for Future		
SW1-6	Reserved for Future		
SW1-7	Reserved for Future		
SW1-8	Operation Type	Transcoder Operation	Innovator CX Operation

**NOTES:** SW1-8 operation is available in software versions greater than or equal to 2.3 with hardware versions greater than or equal to D0, unless the board was factory modified.

These switch positions are factory set for your system and should not be changed.

---

**(A2) Digital Modulator Board DM8C (1316332)**

The digital modulator board accepts either ASI or SMPTE-310 input at SMA connectors J13 or J4. Regenerative transmitters will have a connection on J14 from the 8 VSB demodulator board in a RD system.

**(A5) ALC Board, Innovator CX Series (1315006)**

The ALC Board in the Innovator CX series transmitter is used to control the RF drive power to the RF amplifier chain in the system. The board accepts an RF input signal at a nominal input level of -3 dBm average power and amplifies it to whatever drive level is necessary to drive the final RF amplifier in the drawer to full power. The input signal to the board at J1 is split by U4, with one half of the signal driving a PIN diode attenuator, DS1 and DS2, and the other half driving a detector, U13, that is used to mute the PIN attenuator when there is no input signal. The output of the PIN attenuator is sent to two cascaded amplifiers, U2 and U3, which are capable of generating +10 dBm average power from the board at J2.

The PIN attenuator is driven by an ALC circuit or by a manual fixed voltage bias, depending on the position of switch S1. When the switch is pointing to the left, looking from the front of the drawer, the ALC circuit is enabled. When the switch is pointing to the right, the ALC circuit is disabled and the PIN attenuator is controlled through the Manual gain pot R62. When the switch is in either ALC or manual, the voltage in the unused circuit is preset low by the circuitry connected to pins 4-6 on SW1. This allows the RF power to ramp up slowly to full power when the switch changes positions. CR8, C33 and associated components control the ramp up speed of the manual gain circuit. CR9, C42 and their associated circuits do the same thing for the ALC circuit. The practical effect of this is to preset the RF drive power to near zero output power when enabling and disabling the ALC, followed by a slow controlled ramp up of power.

The ALC circuit normally attempts to hold the drawer output power constant, but there are four faults that can override this. These faults are Input Fault, VSWR Cutback Fault, VSWR Shutdown Fault and Overdrive Fault.

The Input Fault is generated by comparator U7C and presets the PIN attenuator and ALC circuit to maximum attenuation whenever the input signal drops below about -7 dBm. Test point TP2 allows the user to measure the detected input voltage.

The VSWR cutback circuit is set so that the ALC circuit will start reducing RF drive once the Reflected power reaches a level of about 6% and will keep reducing the drive to maintain that level. The cutback is generated by U8A, U8B and their associated components that diode-or the metering voltages. The forward power is scaled to  $2V = 100\%$  and the reflected power is scaled to  $2V = 25\%$ . The Reflected metering voltage is doubled again by U8B so that when the voltage of U8B exceeds the voltage at the output of U8A, the reflected power takes over the ALC circuit. Once the U8B voltage drops below the forward power at U8A, the forward power takes over again.

The VSWR shutdown circuit will shut the drawer down if the Reflected power increases to 15% or higher, which can happen if the drawer sees reflected power when the ALC is in manual.

The Overdrive protection looks at a sample of the RF signal that is applied to J1 of the board. The peak level of this signal is detected and can be measured on TP1. This voltage is applied to a comparator with the threshold set by R38. If this threshold is exceeded, the ALC circuit mutes then ramps up to try again. This circuit also works in manual gain as well.

### **(A6) Amplifier Assembly (1313959) – Used in the CHV0xD-1 Drawer**

The (A6) Amplifier Assembly (1313959) is made up of (A6-A1) the VHF HB Pre-Driver Assembly (1313899) and (A6-A2) the 100 Watt Amplifier Pallet, Italmec (1313484). The ALC Board (1315006) is also part of this assembly. The assembly has approximately 36 dB of gain.

#### **(A6-A1) VHF HB Pre-Driver Assembly (1313899)**

The VHF HB Pre-Driver Assembly (1313899) consists of a driver and a parallel connected final amplifier stage, which has a total gain of approximately 23 dB.

The input RF at J1 connects through a matching network consisting of R11-R13 to a splitter IC Z1. The split outputs connect to parallel-connected push-pull 1 Watt high linearity amplifier ICs (U1& U4) operating in class AB each with approximately 17 dB of gain. The board uses a power supply voltage of +48VDC that connect to J6. The +48VDC is filtered on the board and connected to the step down transformer T1 which produces a +12VDC output that is used by the two amplifier ICs (U1 & U4). The two amplified outputs are connected to a combiner IC Z2. The combined output connects through a directional coupler U6 to J2, the RF output jack of the board. The directional coupler provides an RF sample at J4 that is used by an external overdrive protection circuit located on the (A6-A3) ALC Board. The output of the pre-driver amplifier assembly at J2 connects to the RF Input connection on the (A6-A2) 100W Amplifier Pallet, Italmec.

#### **(A6-A2) 50 Watt Amplifier Pallet, Italmec (1313484)**

The 50 Watt Amplifier Pallet, Italmec is made by Italmec for Axcera's use. This broadband amplifier operates in the frequency range of 170 to 240 MHz. The amplifier is capable of delivering a maximum output power of 25 Watts digital, with an amplification factor of approximately 24 dB. The RF output of the pallet is wired to J2 the RF output jack of the 20W driver amplifier assembly. The output of the 20W driver amplifier assembly is cabled to the J1 on (A7) the output metering detector board (1313747).

### **(A6) 200 Watt Driver Amplifier Assembly (1315010 used w/Axciter Drawer or 1313912 used in all other applications) – Used in the CHVxD-4**

The (A6) Amplifier Assembly (1315010 used w/Axciter Drawer or 1313912 used in all other applications) is made up of (A6-A1) the 50 Watt Amplifier Pallet, Italmec (1313484) and (A6-A2) the 500 Watt Amplifier Pallet, Italmec (1313581). The ALC Board (1315006) is also part of this assembly. The assembly has approximately 36 dB of gain.

#### **(A6-A1) 50 Watt Amplifier Pallet, Italmec (1313484)**

The 50 Watt Amplifier Pallet, Italmec is made by Italmec for Axcera's use. This broadband amplifier operates in the frequency range of 170 to 240 MHz. The amplifier is capable of delivering a maximum output power of 25 Watts digital, with an amplification factor of approximately 24 dB. The RF output of the pallet is wired to J2 the RF output jack of the 20W driver amplifier assembly. The output of the 20W driver amplifier assembly is cabled to the RF input connection on (A6-A2) the 500 Watt Amplifier Pallet, Italmec.

**(A6-A2) 500 Watt Amplifier Pallet, Italmec (1313581)**

The 500 Watt Amplifier Pallet, Italmec is made by Italmec for Axcera's use. This broadband amplifier operates in the frequency range of 170 to 240 MHz. The amplifier is capable of delivering a maximum output power of 200 Watts digital, with an amplification factor of approximately 25 dB. The RF output of the pallet is wired to J2 the RF output jack of the 200W driver amplifier assembly. The output of the 200W driver amplifier assembly is cabled to the J1 on (A7) the output metering detector board (1313747).

**(A7) Output Metering Detector Board (1313747)**

The (A7) Output Detector Board provides forward (2V=100%) and reflected (2V=25%) power samples to the CX Control Board for metering and monitoring purposes. R7 is the reflected power calibration pot and R23 is the forward power calibration pot. A Forward power sample connects to J4 (-10 dBm typical) on the board which is cabled to the front panel sample jack of the drawer. The RF output of the board will vary depending in which system it is located, is at J2, which is cabled to J9 the RF Output Jack of the amplifier drawer.

**(A8) Control Card, Innovator CX (1312543)**

The Innovator CX control board provides the overall system control for the CX system. There are two main elements of the board U7 and U9. U7 is a programmable logic device that is loaded with firmware which provides the overall system control. It decides whether or not to allow the system to generate RF output power, and turns the power supply on and off depending on whether or not it is receiving any faults generated on board or faults generated externally. The second major component of the board is the microcontroller U9, which controls the front panel indications and drives the display. The U9 microcontroller is not involved in the decision making process, U7 does that. Rather, it is layered on top of U7 and is the EPLD's interface to the outside world. Information is passed between the microcontroller and the EPLD. The microcontroller communicates information to and from the front panel and sends the EPLD the information it needs to decide whether or not to allow the system to turn on. The front panel viewable LEDs DS3 for Operate/Standby and DS4 for Status indicate the current operating condition of the system are mounted on and controlled by this board. The U9 microcontroller can also communicate, using the Optional Ethernet Kit, with a daughter card that allows the user to view remote control parameters via a web Ethernet interface.

The  $\pm 12$  VDC and +5 VDC from the (A9) power supply are routed to the other boards in the drawer through this board. The (A10) +48 VDC power supply connects the +48 VDC to the board at J19-1 with 4 common. The  $\pm 12$  VDC and +5 VDC input voltages to this board is connected through J21 and filtered before being connected to the rest of the board. +12 VDC connects through J21-1, +5VDC through J21-2 & 3, and -12 VDC through J21-6. Common connections for the input voltages are connected to J21-4 & 5. The  $\pm 12$  VDC and +5 VDC are used on this board and also routed to the other boards in the drawer through this board. The +3.3 VDC for the microcontroller and programmable



logic array, mounted on the board, is provided by the voltage regulator IC U6 from the filtered +5 VDC input. The output of U6 can be adjusted to +3.3 VDC using R120.

### **(A9 & A10) Power Supplies used in CHV0xD-1 and CHV0xD-4**

Voltages for the operation of the boards in the drawer are generated by (A9) a +5VDC and  $\pm 12$ VDC power supply and (A10) a +48VDC power supply. The 230VAC input to the drawer connects through the AC power cord at J10, the power entry module located on the rear panel of the drawer.

An On/Off 10A/250VAC circuit breaker is part of the power entry module. With the circuit breaker switched On, the (L) line input is wired to F1 a 10 Amp fuse for over current protection. The AC lines are connected to terminal block TB1, which distributes the AC to (A9 and A10) the two DC power supplies. There are two varistors, mounted on TB1, connected from the line input to neutral and to ground for surge protection. The AC also connects to the (A11) fan mounted on the rear panel of the driver drawers. In CHV0xD-1 systems the fan is connected to the A10 power supply and will operate when the (A10) Power supply is enabled. In the CHV0xD-4 the small fan will run when AC is applied to the drawer and the circuit breaker is switched On. The large (A32) fan is connected to the A10 power supply and will operate when the (A10) Power supply is enabled. The +5VDC and  $\pm 12$ VDC outputs of the (A9) power supply connects to the terminal block (TB2) that distributes the DC to the boards in the drawer. Some of the +5VDC and  $\pm 12$ VDC outputs connect directly to the 8 VSB Demodulator and 8 VSB Modulator boards while the other outputs connect through the CX Control Board to the IF Precorrector, the Digital Upconverter, the ALC, the Amplifier Assembly and the Output Metering Detector Boards.

The +48VDC outputs of the (A10) power supply connect to the (A8) CX Control Board, which then supplies the switched +48VDC to the (A6) Amplifier Assembly. In CHV0xD-1 drawers the DC output of the (A10) power supply also connects to the (A11) fan mounted on the rear panel, which will operate when AC is applied to the drawer, the On/Off circuit breaker is On and the (A10) power supply is operating.

### ***Circuit Description of External System Metering Board which is only used in Transmitters with multiple external Amplifier Drawers***

#### **(A5) System Metering Board (1312666)**

The function of the System Metering Board is to detect forward and reflected output power samples and generate output voltages that are proportional to the power levels of the sampled signals for use by the control monitoring assembly in the exciter/driver drawer.

There are two identical signal paths on the board: one for forward power and one for reflected power. A sample of the forward output power, from the external (A11) output coupler, enters the board at the SMA jack J3. The signal is filtered and connected to resistors R5, R3 and R6 that form an input impedance-matching network to Pin 3 on U1. The forward power signal is detected by the RF detector IC U1. The detected output at pin 7 is split with one half connected to the forward average calibration pot R7, digital, which adjusts the level of the signal connected to Pin 11 on U2. The other half of the split is connected to the peak calibration pot R18, analog, which adjusts the level of the signal connected to Pin 8 on U2. U2 is a Bilateral Switch IC whose output, digital or analog, is controlled by the selection of the modulation type in the exciter/driver drawer. In this

BTC transmitter the average, digital, output connects to the amplifier IC U3A that is wired to the SYS\_FWD and RMT\_FWD Power Metering Outputs. A reading of 2 VDC measured at TP1 is equal to a 100% Forward Power reading on the meter. The SYS\_FWD level connects to J9 on the board that is cabled to J11 on the exciter/driver drawer for use in the control monitoring assembly. The RMT\_FWD level connects to J10 on the board for use by remote control and monitoring.

A sample of the reflected output power, from the external (A11) output coupler, enters the board at the SMA jack J8. The signal is filtered and connected to resistors R26, R22 and R27 that form an input impedance-matching network to Pin 3 on U6. The reflected power signal is detected by the RF detector IC U6. The detected output at pin 7 is connected to the reflected calibration pot R25, which adjusts the level of the signal connected to the amplifier IC U3B that is wired to the SYS\_RFLD and RMT\_RFLD Power Metering Outputs. A reading of 2 VDC measured at TP2 is equal to a 25% Reflected Power reading on the meter. The SYS\_RFLD level connects to J9 on the board that is cabled to J11 on the exciter/driver drawer for use in the control monitoring assembly. The RMT\_RFLD level connects to J10 on the board for use by remote control and monitoring.

+12 VDC enters the board at J9-1, from the exciter/driver drawer and is connected through a filter and isolation circuit consisting of C31, C14 and L5 before it is connected to the regulator IC U5. U5 supplies the +5 VDC needed for operation of the ICs on the board. The +5 VDC is connected through a filter circuit consisting of C15, C19 and C21 before it is connected to the rest of the board.

### ***Circuit Descriptions of Boards in the external VHF amplifier Drawer***

#### **(A7) Amplifier Control Board (1312260)**



Amplifier Control Board

The Amplifier Control Board is mounted in the top front facing the rear of the Amplifier Drawer as shown above.

The Amplifier Control Board uses a Programmable logic device, U12, to control the amplifier drawer. It takes an enable signal from an external driver drawer, and turns the power supplies on whenever the driver has told it to turn on, unless it detects faults internal to the drawer. The board monitors the forward and reflected power, the heatsink temperature, the pallet currents, and the power supply voltage and will generate alarm signals if any of those parameters exceed safe limits. The amplifier drawer has no front panel display other than a two LEDs, one for Status and one for Enable. The board sends all its output information, including the forward and reflected levels, back to the driver drawer, through J4, so the information can be displayed on that drawer's LCD Display. The board will generate a Red Blinking Status LED if it detects an alarm, fault, prompting the operator to look at the LCD display on the driver drawer to see what fault has occurred.

A CHVB transmitter System can have up to 4 external amplifier drawers and since they are all the same, without differences in the wiring harness, there needs to be a way to identify which amplifier drawer is which. The rotary switch SW1 is used to specify the

amplifier ID number which generates a unique serial address so that the individual amplifier drawers will respond when polled for information.

The +5 VDC inputs to this board are routed through J4-8 and J5-8. The +5 VDC inputs are diode Or connected so that either the +5VDC from the (A8) power supply or the +5VDC from the (A9) power supply will operate the board. The +5VDC is split with one output connected to U1 a voltage regulator IC, which provides +5V and +5V\_ANALOG as outputs. The +5 VDC is filtered before being connected to the rest of the board. The other +5 VDC output is connected to the regulator IC U2 that supplies +3.3 V to the microcontroller and programmable logic array.

### **(A10) Current Metering Board (1309130)**

The current metering board measures the current into the RF output amplifier pallets and supplies this value to the control board. In the VHF amplifier drawer, there are two sensing circuits which are used. In the VHF amplifier drawer there are four sensing circuits which are used. Each circuit has two parallel .01 $\Omega$  series current sensing resistors and a differential input IC that supplies a voltage output that is proportional to the current for metering purposes. The +48VDC from the (A8) power supply connects to TB2 and TB4 on the board. The +48VDC from the (A9) power supply connects to TB8 and TB10 on the board. The +48VDC input at the TB2 input senses the current to the (A1) output amplifier pallet through TB1 on the board. The +48VDC input at the TB4 input senses the current to the (A2) output amplifier pallet through TB3 on the board. The +48VDC input at the TB8 input senses the current to the (A3) output amplifier pallet through TB7 on the board. The +48VDC input at the TB10 input senses the current to the (A4) output amplifier pallet through TB9 on the board.

The two or four sensing circuits are identical therefore only one will be described. For the (A1) amplifier pallet, the +48VDC from the (A8) switching power supply connects to TB2. R1 and R2 are the parallel .01 $\Omega$  current sensing resistors which supplies the voltage values to the U1 current sense amplifier IC. R11 is a gain adjust, which is adjusted to eliminate any rSense Error and to place the OpAmp output at 2.61V for 40Amps sense as measured at TP3. The current sense output at J1-1 connects to the (A7) control board for metering purposes.

### **(A5) 2 Way VHF Splitter Board (1313941)**

The 2 way splitter board takes the RF Input at J1 ( $\approx$ 12.5 Watts ATSC) on the board and splits it into two equal outputs ( $\approx$ 5Watts ATSC) that connect to the inputs of the two amplifier pallets at J1.

### **(A2 & A3) 500 Watt LDMOS Amplifier Pallets (1313581)**

There are two 500 Watt Amplifier Pallets mounted on the Amplifier Heatsink Assembly. Each of the amplifier pallets has approximately +25dB of gain for the VHF HB frequency range of 170 to 230 MHz. The pallets operate Class AB and generate 200 Watts ATSC with an input of 1 Watt ATSC.

### **(A6) 2 Way VHF Combiner Board (1313969)**

The 2 way combiner board takes the two RF Inputs at J4 & J5 ( $\approx$ 200Watts ATSC) on the board and combines them to a single output ( $\approx$ 400Watts) at J1 that connects to J2 the 7/16" (1.1cm) Din RF output jack of the drawer.

### **(A8 & A9) VHF Amplifier Drawer Power Supplies**


The 230VAC, needed to operate the drawer, connects through the AC power cord at J3, the power entry module located on the rear panel of the drawer. The AC lines are connected to a terminal block TB1 to which the circuit breaker(s) connect. There are two On/Off 20A/250VAC circuit breakers that are mounted on the back panel of the drawer on either side of J3 the AC input jack. **NOTE:** In CHV400 Amplifier drawer there is one circuit breaker. With the circuit breaker(s) switched On, the AC is distributed to the one (A8) or two (A8 and A9) DC power supplies. In a standard CHV400B amplifier drawer one 20 Amp circuit breaker CB1 connects the AC to the (A8) DC power supply. In all power amplifier drawers, TB1 has three varistors (VR1-VR3) connected across the AC input lines for surge and over voltage protection. The AC input connected to TB1 is wired to 2 amp fuses that is connected to the two fans (A11 & A12) mounted on the rear panel of the drawer. Both fans will run immediately when AC is applied to the drawer.

The +5VDC for the operation of the amplifier control board in the drawer is generated by the (A8) or both the (A8 & A9) power supplies at J1-9 on each power supply. The +5VDC from the (A8) power supply connects to J4-8 and the +5VDC from the (A9) power supply connects to J5-8 on the control board. The +5VDC is produced when AC is connected to the drawer and the CB1 and/or the CB2 circuit breakers are turned On. Either or both power supplies provides the +5VDC for use by the control board.

The +48VDC needed by the amplifier modules on the heatsink assembly is generated by the (A8 & A9) power supplies in a 750 and 1000W amplifier drawers. In a standard CHV400 amp drawer there is only the (A8) power supply. The power supplies will operate when AC is connected to the drawer, the CB1 circuit breaker for the (A8) power supply and the CB2 circuit breaker for the (A9) power supply, are turned On and a Low is provided on the Inhibit Line that connects to J1-6 on the power supplies from the control board. The CB1 circuit breaker supplies the AC to the (A8) power supply which provides the +45VDC to the (A2) and (A3) amplifier pallets. The CB2 circuit breaker supplies the AC to the (A9) power supply which provides the +48VDC to the (A4) and (A5) amplifier pallets.

### ***Circuit Descriptions of Boards in the CHV500B/600B, 500/600 Watt ATSC Amplifier Drawer***

#### **(A7) Amplifier Control Board (1312260)**



Amplifier Control Board

The Amplifier Control Board is mounted in the top front facing the rear of the Amplifier Drawer as shown above.

The Amplifier Control Board uses a Programmable logic device, U12, to control the amplifier drawer. It takes an enable signal from an external driver drawer, and turns the power supplies on whenever the driver has told it to turn on, unless it detects faults internal to the drawer. The board monitors the forward and reflected power, the heatsink temperature, the pallet currents, and the power supply voltage and will

generate alarm signals if any of those parameters exceed safe limits. The amplifier drawer has no front panel display other than a two LEDs, one for Status and one for Enable. The board sends all its output information, including the forward and reflected levels, back to the driver drawer, through J4, so the information can be displayed on that drawer's LCD Display. The board will generate a Red Blinking Status LED if it detects an alarm, fault, prompting the operator to look at the LCD display on the driver drawer to see what fault has occurred.

A CHV transmitter system can have up to 8 external amplifier drawers and since they are all the same, without differences in the wiring harness, there needs to be a way to identify which amplifier drawer is which. The rotary switch SW1 is used to specify the amplifier ID number which generates a unique serial address so that the individual amplifier drawers will respond when polled for information.

The +5 VDC inputs to this board are routed through J4-8 and J5-8. The +5 VDC inputs are diode Or connected so that either the +5VDC from the (A8) power supply or the +5VDC from the (A9) power supply will operate the board. The +5VDC is split with one output connected to U1 a voltage regulator IC, which provides +5V and +5V\_ANALOG as outputs. The +5 VDC is filtered before being connected to the rest of the board. The other +5 VDC output is connected to the regulator IC U2 that supplies +3.3 V to the microcontroller and programmable logic array.

#### **(A10) Current Metering Board (1309130)**

The current metering board measures the current into the RF output amplifier pallets and supplies this value to the control board. In the CHV400 amplifier drawer, there are two sensing circuits which are used. In the amplifier drawer, there are four sensing circuits which are used. Each circuit has two parallel .01Ω series current sensing resistors and a differential input IC that supplies a voltage output that is proportional to the current for metering purposes. The +48VDC from the (A8) power supply connects to TB2 and TB4 on the board. The +48VDC from the (A9) power supply connects to TB8 and TB10 on the board. The +48VDC input at the TB2 input senses the current to the (A1) output amplifier pallet through TB1 on the board. The +48VDC input at the TB4 input senses the current to the (A2) output amplifier pallet through TB3 on the board. The +48VDC input at the TB8 input senses the current to the (A3) output amplifier pallet through TB7 on the board. The +48VDC input at the TB10 input senses the current to the (A4) output amplifier pallet through TB9 on the board. The two or four sensing circuits are identical therefore only one will be described. For the (A1) amplifier pallet, the +48VDC from the (A8) switching power supply connects to TB2. R1 and R2 are the parallel .01Ω current sensing resistors which supplies the voltage values to the U1 current sense amplifier IC. R11 is a gain adjust, which is adjusted to eliminate any rSense Error and to place the OpAmp output at 2.61V for 40Amps sense as measured at TP3. The current sense output at J1-1 connects to the (A7) control board for metering purposes.

#### **(A5) 4 Way Splitter Board (1313938)**

The 4 way splitter board takes the RF Input at J1 (≈5 Watts ATSC) on the board and splits it into four equal outputs (≈1.1 Watts ATSC) that connect to the inputs of the four amplifier pallets at J1.

#### **(A1, A2, A3 & A4) 500 Watt LDMOS Amplifier Pallets (1313581)**

There are four 500 Watt Amplifier Pallets mounted on the Amplifier Heatsink Assembly. Each of the amplifier pallets has approximately +25dB of gain for the VHF HB frequency

range of 170 to 230 MHz. The pallets operate Class AB and generate approximately 275 Watts ATSC with an input of 1.1 Watt ATSC.

#### **(A6) 4 Way Combiner Board (1313965)**

The 4 way combiner board takes the four RF Inputs at J1 – J4 ( $\approx 275$ Watts ATSC) on the board and combines them to a single output ( $\approx 1000$  Watts ATSC) at J7 that connects to J2 the 7/16" (1.1cm) Din RF output jack of the drawer.

#### **(A8 & A9) CHV500B/600B, Two 48 VDC/2250 Watt Power Supplies**

The 230VAC, needed to operate the drawer, connects through the AC power cord at J3, the power entry module located on the rear panel of the drawer. The AC lines are connected to a terminal block TB1 to which the circuit breaker(s) connect. There are two On/Off 20A/250VAC circuit breakers that are mounted on the back panel of the drawer on either side of J3 the AC input jack. With the circuit breaker(s) switched On, the AC is distributed to the (A8 and A9) DC power supplies. In the CHV600B amplifier drawer the 20 Amp circuit breaker CB1 connects the AC to the (A8) DC power supply and the 20 Amp circuit breaker CB2 connects the AC to the (A9) DC power supply. TB1 has three varistors (VR1-VR3) connected across the AC input lines for surge and over voltage protection. The AC input connected to TB1 is wired to 2 amp fuses that are connected to the two fans (A11 & A12) mounted on the rear panel of the drawer. Both fans will run immediately when AC is applied to the drawer.

The +5VDC for the operation of the amplifier control board in the drawer is generated by both the (A8 & A9) power supplies at J1-9 on each power supply. The +5VDC from the (A8) power supply connects to J4-8 and the +5VDC from the (A9) power supply connects to J5-8 on the control board. The +5VDC is produced when AC is connected to the drawer and the CB1 and/or the CB2 circuit breakers are turned On. Either or both power supplies provides the +5VDC for use by the control board.

The +48VDC needed by the amplifier modules on the heatsink assembly is generated by the (A8 & A9) power supplies in the amplifier drawer. The power supplies will operate when AC is connected to the drawer, the CB1 circuit breaker for the (A8) power supply and the CB2 circuit breaker for the (A9) power supply, are turned On and a Low is provided on the Inhibit Line that connects to J1-6 on the power supplies from the control board. The CB1 circuit breaker supplies the AC to the (A8) power supply which provides the +48VDC to the (A1) and (A2) amplifier pallets. The CB2 circuit breaker supplies the AC to the (A9) power supply which provides the +48VDC to the (A3) and (A4) amplifier pallets.

**This page has intentionally been left blank.**

### System Set Up Procedure

This system was aligned at the factory and should not require additional adjustments to achieve normal operation.

This Innovator CX series system is of a drawer design with multiple boards inside the drawer. If a board fails, that board needs to be changed out with a replacement board. The failed board can then be sent back to Axcera for repair. **NOTE:** Contact Axcera Customer Service Department at 1-724-873-8100 or fax to 1-724-873-8105, before sending in any board or module.

Refer to Figure 16. Check that the Auto/Man switch S1 on the ALC Board is in the Automatic ALC position. (**NOTE:** The silkscreen is incorrect on Rev. A, B & C boards. Auto position is with the bat to the left, toward J4.) Adjust R75 the ALC pot on the ALC Board as needed to attain 100% output power. Switch to Manual Gain (Manual ALC) and adjust the Manual Gain pot R62 for 100% output power. Switch the ALC Board back to Automatic ALC.




Figure 16: (A5) ALC Board (1315006 or 1308570)



### ALC Board Set-Up, Forward and Reflected Power Calibration for CHV0xD-4 systems

**NOTE:** If your system has one or more external amplifier drawers, refer to the next section for the forward and reflected power calibration procedures.

Refer to Figure 16. Locate (A5) the ALC Board (1315006), in the preset the Overdrive Threshold pot R38 full CW and set R62, Manual Adjust, and R75, ALC Adjust, full CCW.

Switch S1 to Manual Gain, and increase the output power to 100% using R62. Calibrate the system output power for 100% using R23, the Forward Calibration pot, on the Output Detector Board. Refer to Figure 17.




Figure 17: (A7) Output Metering Detector Board (1313747)




Figure 16A: (A5) ALC Board (1315006)

Refer to Figure 16A. Turn the output power down to 10% power with R62 on the ALC Board. Remove the output RF connector from J2 on drawer and calibrate the reflected power to 10%, using R7, the Reflected Calibration pot, on the Output Detector Board. Refer to Figure 17. Re-connect the RF output connector to the drawer and increase the power, in Manual gain using R62 on the ALC Board, to 115%. Adjust the Overdrive pot R38 on the ALC Board, CCW until the overdrive threshold just trips and the Overdrive Fault LED DS4 lights. Turn R38 slightly CW so that power comes back up and DS4 goes out.

Switch S1 on the ALC Board to ALC. Turn the ALC Adjust pot R75 on the ALC Board until the power is 100%. Switch S1 between ALC and Manual to verify smooth switching, with minimal change in power. If necessary repeat the above procedure.

With the drawer in ALC, use the ALC Adjust pot, R75, to decrease the power to 10%. Remove the RF output connector from the drawer. Verify that the VSWR Cutback LED, DS6, comes on and the Reflected Power drops to approximately 6%. Reconnect the RF output connector and increase the power back up to 100% using R75.

This completes the set up of the ALC board and the Forward and Reflected Power Calibration.

### Forward and Reflected Power Calibration of Systems with one or more External Amplifier Drawers

**NOTE:** If your system does not contain external amplifiers, refer to the previous section for the forward and reflected power calibration procedures.

Connect a calibrated coupler and average reading power meter to the output of the DTV mask filter. On the ALC Board (1315006), mounted in the Driver Drawer, set the Switch S1, Auto/Manual ALC, to the Manual position. Refer to Figure 13A. Adjust the Manual adjustment Pot, R62, for the desired output power level as

indicated on the average reading power meter. In the Amplifier Drawer, on the Amplifier Control Board (1309822), refer to Figure 18; adjust the Forward Calibration Adjustment pot, R8, for a reading of 100% on the External Amplifier Forward Power screen of the LCD display mounted on the Driver Drawer.




Figure 18: (A5) Amplifier Control Board (1309822)

On the ALC Board mounted in the Driver Drawer, set the Switch S1, Auto/Manual ALC, to the Auto position. Adjust the ALC adjustment Pot, R75, for a reading of 100% on the External Amplifier Forward Power screen of the LCD display mounted on the Driver Drawer. This completes the forward power set up and calibration adjustments.

On the ALC Board mounted in the Driver Drawer, adjust the ALC adjustment Pot, R75, for a reading of 10% on the External Amplifier Forward Power screen of the LCD display mounted on the Driver Drawer. Disconnect the load or the antenna connected to the system. In the Amplifier Drawer, on the Amplifier Control Board (1309822), adjust the Reflected Calibration Adjustment pot, R26, for a reading of 10% on the External Amplifier Reflected Forward Power screen of the LCD display mounted on the Driver Drawer. Reconnect the load or the antenna to the system. Adjust the ALC adjustment Pot, R75, for a reading of 100% on the External Amplifier Forward Power screen of the LCD display mounted on the Driver Drawer. This completes the reflected power calibration adjustment.

**This page has been intentionally left blank.**

**APPENDIX A:**

Innovator CHV0TD/RD-1 through CHV4TD/RD ATSC  
Transmitter/Regenerative Translator  
System and Drawer

Drawings and Parts Lists

**Innovator CHV0xD VHF High Band  
Regenerative Translator System and Drawer  
Drawing List**

**Innovator CHV0xD VHF High Band Digital Regenerative Translator  
(Contains a CHV0xD 20 Watt VHF High Band Digital Drawer 1313960)**

---

CHV20BRD, Colstrip Site, Montana, Racking Plan .....	1316452
CHV20BRD, Montana, Rack w/110VAC Parts List .....	CB005859
CHV20BRD, Colstrip Site, Montana, System Parts List.....	CB005862

---

**CHV20BRD Innovator 20 Watt Digital Drawer**

CHV20BRD Interconnect.....	1313984
CHV20BTD/BRD Assembly Drawing .....	1313960
CHV20BRD Typical Parts List.....	1313960
CHV20BRD, Montana, Parts List .....	CB005860