

**Innovator,
CU0TD-1/CU0RD-1, 5 Watt –
CU4TD/CU4RD, 2500 Watt
UHF, ATSC Transmitter/
Regenerative Translator**

Axcera, LLC
103 Freedom Drive • P.O. Box 525 • Lawrence, PA 15055-0525, USA
Phone: 724-873-8100 • Fax: 724-873-8105
www.axcera.com • info@axcera.com



**RESTRICTIONS ON USE, DUPLICATION OR DISCLOSURE
OF PROPRIETARY INFORMATION**

This document contains information proprietary to Axcera, to its affiliates or to a third party to which Axcera may have a legal obligation to protect such information from unauthorized disclosure, use or duplication. Any disclosure, use or duplication of this document or any of the information herein for other than the specific purpose for which it was disclosed by Axcera is expressly prohibited, except as Axcera may otherwise agree in writing. Recipient by accepting this document agrees to the above stated conditional use of this document and this information disclosed herein.

Table of Contents

Introduction	1
<i>Manual Overview</i>	1
<i>Axcera Numbering System Explanation</i>	1
<i>Assembly Designators</i>	2
<i>Safety</i>	2
<i>Contact Information</i>	3
<i>Return Material Procedure</i>	3
<i>Limited One Year Warranty for Axcera Products</i>	4
System Description	11
Optional Dual Exciter System w/Axciter Modulator Trays	14
Unpacking, Installation and Maintenance	17
<i>Unpacking</i>	17
<i>Installation</i>	17
Drawer Slide Installation	18
AC Input Connections	19
Input and Output Connections	20
J11 Power Monitoring Connections	22
<i>Maintenance</i>	24
Initial On Site Turn On Procedure	27
Typical System Operating Parameters	28
Typical Problems, Indications and Causes in CU0TD/RD-2 or -3 Drawer	29
LCD Display and Front Panel LED Indicators	29
System Remote Connections to J12	31
LCD Front Panel Screens	32
<i>Operation Screens</i>	34
<i>Set Up Screens</i>	41
(Optional) Innovator CXB Series Web Ethernet Interface Kit (1313100)	49
(Optional) Innovator CXB Series SNMP Ethernet Interface (1313079)	54
Circuit Descriptions of Boards in the CU0TD/RD-1 thru CU0TD/RD-5 Systems	55
(A1) <i>8 VSB Demodulator Board (1308275)</i>	55
Overview	55
Microcontroller Functions	55
Jumper and DIP Switch Settings	55
(A2) <i>Digital Modulator (1316332)</i>	56
SMPTE-310 or ASI input	56
Channel Coder	56
Analog Output Section	56
Pilot Frequency Generation	56
Voltage Requirements	57
(A5) <i>ALC Board, Innovator CX Series (1315006 or 1308570)</i>	57
(A6) <i>Amplifier Assembly (1309621) – Used in the CU0TD/RD-1</i>	59
(A6-A1) <i>2 Stage UHF Amplifier Board, 24V (1309608)</i>	59
(A6) <i>Amplifier Assembly (1315008 used w/External Axciter Drawer or 1312566 used in all other applications) – Used in the CU0TD/RD-2 and CU0TD/RD-3</i>	59
(A6-A1) <i>2 Stage UHF Amplifier Board (1308784)</i>	59
(A6-A2) <i>RF Module Pallet, Philips, High Output (1309580)</i>	60
(A6) <i>Amplifier Assembly w/878 devices (1312191) – Used in the CU0TD/RD-4 & CU0TD/RD-5</i>	60
(A6-A1) <i>1 Watt UHF Amplifier Module (1310282)</i>	60
(A6-A2) <i>BL871 Single Stage Amplifier Board (1311041)</i>	60
(A6-A3) <i>Dual 878 Pallet Assembly (1313170 or 1310138)</i>	61

(A6) Amplifier Assembly w/888A devices (1316132 used w/External Axciter Drawer or 1315381 used in all other applications) – Used in the CU0TD/RD-4 & CU0TD/RD-5	61
(A6-A1) 1 Watt UHF Amplifier Module (1315730)	61
(A6-A2) BLF881 Single Stage Amplifier Board (1314882)	61
(A6-A3) Dual BLF888A Pallet Assembly (1315347)	62
(A6-A5) DC/DC Converter Board (1315335)	62
(A7) Output Detector Board (1308685 or 1312207 in the CU0TD/RD-2 thru CU0TD/RD-5).....	62
(A8) Control Card, Innovator CX (1312543).....	62
(A9 & A10) Power Supplies used in CU0TD/RD-1 thru CU0TD/RD-5 and Driver for CU1TD/RD-1 & higher power.....	63
Circuit Description of External System Metering Board which is only used in Transmitters with multiple external Amplifier Drawers	64
(A5) System Metering Board (1312666)	64
Circuit Descriptions of Boards in the external ATSC Amplifier Drawers	65
(A7) Amplifier Control Board (1315011 or 1312260)	65
(A10) Current Metering Board (1309130)	65
(A5) 2 Way Splitter Board (1313158), in Amplifier Drawer w/two Dual 888A Pallets	66
(A5) 4 Way Splitter Board (1308933), in multiple pallet amplifier drawer	66
(A1-A4) 878A Amplifier Pallets (1314098, 1313170 or 1310138).....	66
Or (A1-A2) Dual 888A Amplifier Pallets (1314173) Used in two pallet Amplifier Drawer (CB005715).....	66
(A1-A4) 888A Amplifier Pallets (1315347) Used in three pallet Amplifier Drawers .	66
(A6) 2 Way Combiner Board (1313155), in amplifier drawer w/two Dual 888A Pallets.....	67
(A6) 4 Way Combiner Board (1312368), in two pallet amplifier drawer	67
(A8 & A9) One, two & three pallet Amplifier Drawer Power Supplies.....	67
System Set Up Procedure	1
ALC Board Set-Up, Forward and Reflected Power Calibration for CU0TD/RD-1 thru CU0TD/RD-5 Systems	2
Forward and Reflected Power Calibration of a CU1TD/RD-1 and Higher Power Systems with one or more External Amplifier Drawers.....	3

Introduction

Manual Overview

This manual contains the description of the Innovator CU0TD-1/CU0RD-1 – CU4TD/CU4RD Transmitter/Regenerative Translator and the circuit descriptions of the boards, which make up the system. The manual also describes the installation, setup and alignment procedures for the system. **Appendix A** of this manual contains the system level drawings for the Innovator CU0TD-1/CU0RD-1 – CU4TD/CU4RD ATSC Transmitter/Regenerative Translator System that was purchased. **NOTES:** Information and drawings on the Axciter Digital Modulator, if part of your system, are contained in the separate Axciter Instruction Manual. Information and drawings on the Universal Modulator Drawer and Adaptive Precorrector Drawer, if part of your system, are contained in the separate Universal Modulator Drawer and Adaptive Precorrector Drawer Instruction Manuals. If your system contains dual exciters with a remote interface panel and Exciter control panel, information and drawings on the system and panels are contained in the separate remote interface panel instruction manual. Information on the K-Tech Receiver or Signal Converter, if part of your system, is contained in the separate manufacturers supplied manuals.

Axcera Numbering System Explanation

The Axcera numbering system is explained as follows. The following example is for a CU0TC-3 Transmitter system.

C – CX Series

U – UHF Frequency Band

0 or X - Number of external Power Amplifier drawers

T - Transmitter, L - Echo cancelling repeater, R - Regenerative translator

C - COFDM (DVB-T/H/T2), I - ISDB-T, D - ATSC, No letter or blank means analog.

-3 = 50W or (861 devices), -2 = 30W or (861 devices with smaller power supply), -1 = 3W or 5W depending on the modulation. -4 = 888A. For ATSC there is also a -5 at 150W output but it is the same as the -4.

The following example is for a power amplifier drawer CUBP888A-4.

1 | 2 | 3 | 4 | 5 | - | 6 | - | 7 |
C U B P 888A - 4


Position	Chars	Description
1	1	Transmitter Line (C=CX, 6=6X, H=HX)
2	1 or 2	Frequency Band (U=UHF, HV=HB VHF, LV=LB VHF, etc.)
3	1	Version (ex. A-line, B-line, etc. - typically matches transmitter model version)
4	1	Use (E=Exciter/Driver, P=PA)
5	up to 4	Transistor number (might need to abbreviate)
6	1 or 2	Number of transistors in final output stage
7	up to 4	Additional field to include other important info (ex. distinguish bet single or N+1 supplies, or other things not covered in the number)

CUBP888A-4: Line **C**, Frequency **UHF**, Version **B**, Use **PA**, Transistor Number **888A**, number of transistors in final output stage **4**.

Assembly Designators

Axcera has assigned assembly numbers, Ax designations such as A1, where x=1,2,3...etc, to all assemblies, modules, and boards in the system. These designations are referenced in the text of this manual and shown on the block diagram and interconnect drawings provided in Appendix A.

The cables that connect between the boards within a drawer or assembly and that connect between the drawers, racks and cabinets are labeled using markers. Figure 1 is an example of a marked cable. There may be as few as two or as many as four Markers on any one cable. These markers are read starting farthest from the connector. If there are four Markers, the marker farthest from the connector is the system number such as system 1 or translator 2. The next or the farthest Marker is the rack or cabinet "A" number on an interconnect cable or the board "A" number when the cable is within a drawer. The next number on an interconnect cable is the Drawer location or Board "A" number. The marker closest to the connector is the jack or connector "J" number on an interconnect cable or the jack or connector "J" number on the board when the cable is within a drawer.



Marker Identification Drawing

Safety

The Innovator CU0TD-1/CU0RD-1 – CU4TD/CU4RD ATSC Transmitter/Regenerative Translator systems manufactured by Axcera are designed to be easy to use and repair while providing protection from electrical and mechanical hazards. Please review the following warnings and familiarize yourself with the operation and servicing procedures before working on the system.

Hazardous Accessibility – Axcera has made attempts to provide appropriate connectors, wiring and shields to minimize hazardous accessibility.

Circuit Breakers and Wiring – All circuit breakers and wire are UL and CE certified and are rated for maximum operating conditions.

Single Point Breaker or Disconnect - The customer should provide a single point breaker or disconnect at the breaker box for the main AC input connection to the transmitter.

Transmitter Ratings - The transmitter ratings are provided in the text of this manual along with voltage and current values for the equipment.

Protective Earthing Terminal – A main protective earthing terminal is provided for equipment required to have protective earthing.

Read All safety Instructions – All of the safety instructions should be read and understood before operating this equipment.

Retain Manuals – The manuals for the system should be retained at the system site for future reference. Axcera provides two manuals for this purpose; one manual can be left at the office while the other can be kept at the site.

Heed all Notes, Warnings, and Cautions – All of the notes, warnings, and cautions listed in this safety section and throughout the manual must be followed.

Follow Operating Instructions – All of the operating and use instructions for the system should be followed.

Cleaning – Unplug or otherwise disconnect all power from the equipment before cleaning. Do not use liquid or aerosol cleaners. Use only a damp cloth for cleaning.

Ventilation – Openings in the cabinet and module front panels are provided for ventilation. To ensure the reliable operation of the system, and to protect the unit from overheating, these openings must not be blocked.

Servicing – Do not attempt to service this product yourself until becoming familiar with the equipment. If in doubt, refer all servicing questions to qualified Axcera service personnel.

Replacement Parts – When replacement parts are used, be sure that the parts have the same functional and performance characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards. Please contact the Axcera Technical Service Department if you have any questions regarding service or replacement parts.

Contact Information

The Axcera Field Service Department can be contacted by PHONE at **724-873-8100** or by FAX at **724-873-8105**.

Before calling Axcera, please be prepared to supply the Axcera technician with answers to the following questions. This will save time and help ensure the most direct resolution to the problem.

1. What are your Name and the Call Letters for the station?
2. What are the model number and type of system?
3. Is the system digital or analog?
4. How long has the system been on the air? (Approximately when was the system installed?)
5. What are the symptoms being exhibited by the system? Include the current front panel LCD readings and what the status LED is indicating on the front panel of the drawer. If possible, include the LCD readings before the problem occurred.

Return Material Procedure

To insure the efficient handling of equipment or components that have been returned for repair, Axcera requests that each returned item be accompanied by a Return Material Authorization Number (RMA#). The RMA# can be obtained from any Axcera Field Service Engineer by contacting the Axcera Field Service Department at 724-873-8100 or by Fax at 724-873-8105. This procedure applies to all items sent to the Field Service Department regardless of whether the item was originally manufactured by Axcera.

When equipment is sent to the field on loan, the RMA# is included with the unit. The RMA# is intended to be used when the unit is returned to Axcera. In addition, all shipping material should be retained for the return of the unit to Axcera.

Replacement assemblies are also sent with the RMA# to allow for the proper routing of the exchanged hardware. Failure to close out this type of RMA# will normally result in the customer being invoiced for the value of the loaner item or the exchanged assembly.

When shipping an item to Axcera, please include the RMA# on the packing list and on the shipping container. The packing slip should also include contact information and a brief description of why the unit is being returned.

Please forward all RMA items to:

**Axcera, LLC
103 Freedom Drive
P.O. Box 525
Lawrence, PA 15055-0525 USA**

For more information concerning this procedure, call the Axcera Field Service Department at 724-873-8100.

Axcera can also be contacted through e-mail at info@axcera.com and on the Web at www.axcera.com.

Limited One Year Warranty for Axcera Products

Axcera warrants each new product that it has manufactured and sold against defects in material and workmanship under normal use and service for a period of one (1) year from the date of shipment from Axcera's plant, when operated in accordance with Axcera's operating instructions. This warranty shall not apply to tubes, fuses, batteries, bulbs or LEDs.

Warranties are valid only when and if (a) Axcera receives prompt written notice of breach within the period of warranty, (b) the defective product is properly packed and returned by the buyer (transportation and insurance prepaid), and (c) Axcera determines, in its sole judgment, that the product is defective and not subject to any misuse, neglect, improper installation, negligence, accident, or (unless authorized in writing by Axcera) repair or alteration. Axcera's exclusive liability for any personal and/or property damage (including direct, consequential, or incidental) caused by the breach of any or all warranties, shall be limited to the following: (a) repairing or replacing (in Axcera's sole discretion) any defective parts free of charge (F.O.B. Axcera's plant) and/or (b) crediting (in Axcera's sole discretion) all or a portion of the purchase price to the buyer.

Equipment furnished by Axcera, but not bearing its trade name, shall bear no warranties other than the special hours-of-use or other warranties extended by or enforceable against the manufacturer at the time of delivery to the buyer.

NO WARRANTIES, WHETHER STATUTORY, EXPRESSED, OR IMPLIED, AND NO WARRANTIES OF MERCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE, OR FREEDOM FROM INFRINGEMENT, OR THE LIKE, OTHER THAN AS SPECIFIED IN PATENT LIABILITY ARTICLES, AND IN THIS ARTICLE, SHALL APPLY TO THE EQUIPMENT FURNISHED HEREUNDER.

⚠ WARNING!!!

< HIGH VOLTAGE >


DO NOT ATTEMPT TO REPAIR OR TROUBLESHOOT THIS EQUIPMENT UNLESS YOU ARE FAMILIAR WITH ITS OPERATION AND EXPERIENCED IN SERVICING HIGH VOLTAGE EQUIPMENT. LETHAL VOLTAGES ARE PRESENT WHEN POWER IS APPLIED TO THIS SYSTEM. IF POSSIBLE, TURN OFF POWER BEFORE MAKING ADJUSTMENTS TO THE SYSTEM.

★ RADIO FREQUENCY RADIATION HAZARD ★

MICROWAVE, RF AMPLIFIERS AND TUBES GENERATE HAZARDOUS RF RADIATION THAT CAN CAUSE SEVERE INJURY INCLUDING CATARACTS, WHICH CAN RESULT IN BLINDNESS. SOME CARDIAC PACEMAKERS MAY BE AFFECTED BY THE RF ENERGY EMITTED BY RF AND MICROWAVE AMPLIFIERS. NEVER OPERATE THE TRANSMITTER SYSTEM WITHOUT A PROPERLY MATCHED RF ENERGY ABSORBING LOAD OR THE ANTENNA ATTACHED. KEEP PERSONNEL AWAY FROM OPEN WAVEGUIDES AND ANTENNAS. NEVER LOOK INTO AN OPEN WAVEGUIDE OR ANTENNA. MONITOR ALL PARTS OF THE RF SYSTEM FOR RADIATION LEAKAGE AT REGULAR INTERVALS.

EMERGENCY FIRST AID INSTRUCTIONS

Personnel engaged in the installation, operation, or maintenance of this equipment are urged to become familiar with the following rules both in theory and practice. It is the duty of all operating personnel to be prepared to give adequate Emergency First Aid and thereby prevent avoidable loss of life.



RESCUE BREATHING

1. Find out if the person is breathing.

You must find out if the person has stopped breathing. If you think he is not breathing, place him flat on his back. Put your ear close to his mouth and look at his chest. If he is breathing you can feel the air on your cheek. You can see his chest move up and down. If you do not feel the air or see the chest move, he is not breathing.

2. If he is not breathing, open the airway by tilting his head backwards.

Lift up his neck with one hand and push down on his forehead with the other. This opens the airway. Sometimes doing this will let the person breathe again by himself.

3. If he is still not breathing, begin rescue breathing.

-Keep his head tilted backward. Pinch nose shut.
-Put your mouth tightly over his mouth.
-Blow into his mouth once every five seconds
-DO NOT STOP rescue breathing until help arrives.

LOOSEN CLOTHING - KEEP WARM

Do this when the victim is breathing by himself or help is available. Keep him as quiet as possible and from becoming chilled. Otherwise treat him for shock.

BURNS

SKIN REDDENED: Apply ice cold water to burned area to prevent burn from going deeper into skin tissue. Cover area with a clean sheet or cloth to keep away air. Consult a physician.

SKIN BLISTERED OR FLESH CHARRED: Apply ice cold water to burned area to prevent burn from going deeper into skin tissue.

Cover area with clean sheet or cloth to keep away air. Treat victim for shock and take to hospital.

EXTENSIVE BURN - SKIN BROKEN: Cover area with clean sheet or cloth to keep away air. Treat victim for shock and take to hospital.

dBm, dBw, dBmV, dB μ V, & VOLTAGE EXPRESSED IN WATTS

50 Ohm System

WATTS	PREFIX	dBm	dBw	dBmV	dB μ V	VOLTAGE
1,000,000,000,000	1 TERAWATT	+150	+120			
100,000,000,000	100 GIGAWATTS	+140	+110			
10,000,000,000	10 GIGAWATTS	+130	+100			
1,000,000,000	1 GIGAWATT	+120	+ 99			
100,000,000	100 MEGAWATTS	+110	+ 80			
10,000,000	10 MEGAWATTS	+100	+ 70			
1,000,000	1 MEGAWATT	+ 90	+ 60			
100,000	100 KILOWATTS	+ 80	+ 50			
10,000	10 KILOWATTS	+ 70	+ 40			
1,000	1 KILOWATT	+ 60	+ 30			
100	1 HECTROWATT	+ 50	+ 20			
50		+ 47	+ 17			
20		+ 43	+ 13			
10	1 DECAWATT	+ 40	+ 10			
1	1 WATT	+ 30	0	+ 77	+137	7.07V
0.1	1 DECIWATT	+ 20	- 10	+ 67	+127	2.24V
0.01	1 CENTIWATT	+ 10	- 20	+ 57	+117	0.707V
0.001	1 MILLIWATT	0	- 30	+ 47	+107	224mV
0.0001	100 MICROWATTS	- 10	- 40			
0.00001	10 MICROWATTS	- 20	- 50			
0.000001	1 MICROWATT	- 30	- 60			
0.0000001	100 NANOWATTS	- 40	- 70			
0.00000001	10 NANOWATTS	- 50	- 80			
0.000000001	1 NANOWATT	- 60	- 90			
0.0000000001	100 PICOWATTS	- 70	-100			
0.00000000001	10 PICOWATTS	- 80	-110			
0.000000000001	1 PICOWATT	- 90	-120			

TEMPERATURE CONVERSION

$$^{\circ}\text{F} = 32 + [(9/5) ^{\circ}\text{C}]$$

$$^{\circ}\text{C} = [(5/9) (^{\circ}\text{F} - 32)]$$

USEFUL CONVERSION FACTORS

TO CONVERT FROM	TO	MULTIPLY BY
mile (US statute)	kilometer (km)	1.609347
inch (in)	millimeter (mm)	25.4
inch (in)	centimeter (cm)	2.54
inch (in)	meter (m)	0.0254
foot (ft)	meter (m)	0.3048
yard (yd)	meter (m)	0.9144
mile per hour (mph)	kilometer per hour(km/hr)	1.60934
mile per hour (mph)	meter per second (m/s)	0.44704
pound (lb)	kilogram (kg)	0.4535924
gallon (gal)	liter	3.7854118
U.S. liquid		
(One U.S. gallon equals 0.8327 Canadian gallon)		
fluid ounce (fl oz)	milliliters (ml)	29.57353
British Thermal Unit	watt (W)	0.2930711
		per hour (Btu/hr)
horsepower (hp)	watt (W)	746


NOMENCLATURE OF FREQUENCY BANDS

FREQUENCY RANGE	DESIGNATION
3 to 30 kHz	VLF - Very Low Frequency
30 to 300 kHz	LF - Low Frequency
300 to 3000 kHz	MF - Medium Frequency
3 to 30 MHz	HF - High Frequency
30 to 300 MHz	VHF - Very High Frequency
300 to 3000 MHz	UHF - Ultrahigh Frequency
3 to 30 GHz	SHF - Superhigh Frequency
30 to 300 GHz	EHF - Extremely High Frequency

LETTER DESIGNATIONS FOR UPPER FREQUENCY BANDS

LETTER	FREQ. BAND
L	1000 - 2000 MHz
S	2000 - 4000 MHz
C	4000 - 8000 MHz
X	8000 - 12000 MHz
Ku	12 - 18 GHz
K	18 - 27 GHz
Ka	27 - 40 GHz
V	40 - 75 GHz
W	75 - 110 GHz

RETURN LOSS VS. VSWR



ABBREVIATIONS/ACRONYMS

AC:	Alternating Current	FEC:	Forward Error Correction
AFC:	Automatic Frequency Control	FM:	Frequency Modulation
ALC:	Automatic Level Control	FPGA:	Field Programmable Gate Array
AM:	Amplitude Modulation	Hz:	Hertz
AGC:	Automatic Gain Control	I/C:	Interconnect
ATSC:	Advanced Television Systems Committee (Digital)	ICPM:	Incidental Carrier Phase Modulation
AWG:	American Wire Gauge	I/P:	Input
B/D:	Block Diagram	IF:	Intermediate Frequency
BER:	Bit Error Rate	LED:	Light emitting diode
BW:	Bandwidth	LSB:	Lower Sideband
COFDM:	Coded Orthogonal Frequency Division Multiplexing modulation scheme.	LDMOS:	Lateral Diffused Metal Oxide Semiconductor Field Effect Transistor
CUBP888A-4:	Line C , Frequency UHF , Version B , Use PA , Transistor Number 888A , number of transistors in final output stage 4 .	MPEG:	Motion Pictures Expert Group
DC:	Direct Current	NTSC:	National Television Systems Committee (Analog)
D/A:	Digital to Analog	O/P:	Output
DSP:	Digital Signal Processing	PLL:	Phase Locked Loop
DTV:	Digital Television	PCB:	Printed Circuit Board
dB:	Decibel	QAM:	Quadrature Amplitude Modulation
dBm:	Decibel referenced to 1 milliwatt	RD:	Regenerative Translator, Digital
dBmV:	Decibel referenced to 1 millivolt	SMPTE:	Society of Motion Picture and Television Engineers
dBw:	Decibel referenced to 1 watt	TD:	Transmitter, Digital
		VSB:	Vestigial Side Band

System Description

The Innovator CX Series Systems are of two different types. They are either Regenerative Translators, example: CU3RD, or DTV Transmitters, example: CU3TD. The Regenerative Translator (RD) accepts an RF On Channel signal (-79 to -8 dBm) and converts it to a DTV RF On Channel output signal. If an optional preamp is present in your system it connects to the output of the receive antenna and amplifies the weak signal approximately 20 dB. The DTV System (TD) takes a SMPTE-310 Input and converts it to a DTV RF On Channel output signal. The SMPTE-310 input can be from an ASI to S310 converter, a K-Tech Receiver Drawer, an Axciter Drawer, a Universal Modulator Drawer or any other SMPTE-310 source. The output power level of either configuration is at 5, 30, 50, 100 or 150 Watts ATSC using a single drawer, at 250, 400 or 750 Watts ATSC using an additional single amplifier drawer, at 1400 Watts ATSC with two Amplifier drawers, at 2100 Watts ATSC with three Amplifier drawers, or at 2500 Watts ATSC with four Amplifier drawers.

The Innovator CX Series system provides linear and nonlinear correction capability for the transmission path as well as internal test sources that are used during initial system installation. If your system contains the Optional Internal GPS Kit, the output of the GPS Antenna connects to the J5 TNC connector on the rear panel of the CXB drawer. This kit supplies 10 MHz and 1 pps references for use in the CXB drawer.

The CU0TD-1 thru CU0TD-5 Innovator CX Series systems and the same drawer used as driver for higher power transmitter systems contain the Digital Modulator w/Power Conditioner (1309629) that is made up of (A2) the Digital Modulator Board (1304883) and (A22) the Power Conditioner Board (1309404). The drawer also contains (A3) the IF Precorrector Board (1308796), (A4) the Frequency Agile Upconverter (1309695), and (A6) the Amplifier Assembly. The (A7) Output Detector Board (1312207), (A8) the Innovator CX Control Board (1312543), (A9) the +5V, ±12V Power Supply and (A10) the +24V/+28V/+32V/+39V/+48VDC Power Supply are also contained in the drawer. To make the system a regenerative translator, the RD kit (1310182) supplies the (A1) 8 VSB Demodulator Board (1308275) to the drawer.

The type of (A6) Amplifier Assembly used in the drawer changes as the output power of the system changes. The Amplifier Assembly (1309621) is used in CU0TD/RD-1 systems, the Amplifier Assembly (1312566) is used in CU0TD/RD-2 and CU0TD/RD-3 systems and the Amplifier Assembly (1312191) is used in CU0TD/RD-4 and CU0TD/RD-5 systems and the Amplifier Assembly (1315009) is used in CU0TD/RD-4 and CU0TD/RD-5 systems with Axciters. The Amplifier Assembly (1315381) is used in the CUBE888A-2 and the CUBE888A-2 w/8 VSB Demodulator Board drawers. Also part of the amplifier assemblies are an ALC Board (1315006, used with Axciter systems or 1308570, used with all other systems).

The (A10) Power Supply Assembly also changes as the output power of the system changes. A +24V Power Supply is used in CU0TD/RD-1 systems, a +28V/300W Power Supply is used in CU0TD/RD-2 Systems, a +36V/600W Power Supply operating at 30V is used in CU0TD/RD-3 systems and a +48V/1100W Power Supply operating at 48V is used in CU0TD/RD-4 and CU0TD/RD-5 systems.

When configured as an ATSC Transmitter (TD), the SMPTE-310 input at (J1), from an ASI to S310 converter, a KETCH Receiver, an Axciter Drawer or any other SMPTE-310 source, connects directly to the input jack (J42) on the (A2) Digital Modulator Board (1304883). When configured to operate as a Regenerative Translator (RD), the DTV ON Channel RF Input at (J1), (-8 to -79 dBm) connects to the Tuner Input Jack on (A1) the 8 VSB Modulator Board (1308275) supplied with the (RD) kit. The 8 VSB Modulator Board (1308275) converts the DTV input to a SMPTE-310 output at (J13) that connects to the input jack (J42) on the (A2) Digital Modulator Board (1304883) in systems without an Axciter drawer. The IF output of the 8 VSB modulator board connects to J2 on the IF pre-corrector board (1308796). The IF Pre-Corrector Board provides ALC, automatic or manual, gain control of the IF level. The board also supplies pre-correction Response, In Phase and Quadrature Non-Linear adjustments. The board has the circuitry for ALC Fault, Input Fault and Modulation Fault monitoring and indications. The IF from the IF precorrector board is connected to the digital upconverter board (1309695) at J6.

In regenerative translator systems with an Axciter, the DTV ON Channel RF Input at (J1), (-8 to -79 dBm) connects to the Tuner Input Jack on (A1) the 8 VSB Modulator Board (1308275). The SMPTE-310 output of the board at J13 is wired to J2 on the rear panel of the drawer. The SMPTE-310 is cabled to the SMPTE-310 input jack J27 on the Axciter drawer. The digital IF output of the Axciter at J40 is cabled to J3 on the CU0RD-3 drawer that is wired to J6 on the digital upconverter board. The rest of the drawer operates the same for both the RD and the TD systems.

The digital upconverter takes the 44 MHz or 36 MHz IF signal and converts it to a TV channel frequency in the range of 54-860 MHz. The RF on channel signal is fed to the ALC Board, Innovator CX Series (1308570), which is used to control the drive power to the RF amplifier chain in the CU0TD/RD-1, CU0TD/RD-2, CU0TD/RD-3, CU0TD/RD-4 and CU0TD/RD-5 Transmitter/Translators. In a CU0TD/RD-2 or CU0TD/RD-3, the RF is connected to the (A6) Amplifier Assembly (1312566) that is made up of (A6-A1) the 2 Stage UHF Amplifier Board (1308784) and (A6-A2) the RF Module Pallet w/Philips transistors (1300116). The assembly has approximately 36 dB of gain. The amplified output at approximately +38 dBm connects to the (A7) Output Detector Board (1308685 or 1312207) which provides forward (2V=100%) and reflected (2V=25%) power samples to the CU Control Board (1312543) for metering and monitoring purposes. An output power sample is also supplied to the front panel sample jack J15, which is a 50 Ohm BNC type. The typical sample value in a CU50 is approximately 60dB down from the output power level of the drawer. The RF output is cabled to J2 the "N" connector RF output jack on the rear panel of the drawer. In CU0TD/RD-1, CU0TD/RD-2, CU0TD/RD-3, CU0TD/RD-4 and CU0TD/RD-5 systems the output connects to a digital mask filter, low pass filter and then the antenna for your system. In CU1TD/RD-1, CU1TD/RD-2, and CU1TD/RD-3 systems, the RF output, from the driver drawer, is connected to J1 on the rear panel of the amplifier drawer. The RF is cabled to J1 on the Amplifier Heatsink Assembly in the amplifier drawer. In CU2TD/RD and higher power systems the RF is connected to a splitter and then to the inputs of the amplifier drawers.

The CU1TD/RD-1 ATSC system is made up of a Driver Drawer and a 250 Watt ATSC Amplifier Drawer. The driver drawer connects to the 250 Watt Amplifier

drawer and supplies the needed drive level to produce the 250 Watts output of the system. The control and operating parameters of the 250 Watt Amplifier Drawer are displayed on the LCD Screen on the driver drawer. In the 250 Watt amplifier drawer, the RF input signal is at J1 on the rear panel of the drawer that is cabled to J1 on the amplifier pallet. In a standard 250 Watt amplifier drawer, a single +42VDC power supply provides the operating voltages, through the current metering board, to the amplifier pallet. In a N+1 250 Watt amplifier drawer, two +42VDC power supplies are diode-ord and provide the operating voltages, through the current metering board, to the amplifier pallet. If one power supply should malfunction, the other power supply will maintain the necessary voltage to provide the 250 Watts output. The amplified output of the pallet, which has approximately 15 dB gain, is connected to J2 the 7/16" (1.1cm) Din RF output jack of the drawer. An output detector board supplies a forward and a reflected power sample to the amplifier control board for metering and monitoring purposes.

The standard CU1TD/RD-2 ATSC system is made up of a driver drawer and a 400 Watt Amplifier Drawer. The driver drawer output connects to the 400 Watt Amplifier drawer and supplies the needed drive level to produce the 400 Watts output of the system. The control and operating parameters of the 400 Watt Amplifier Drawer are displayed on the LCD Screen on the driver drawer. In the 400 Watt Amplifier Drawer, the input RF signal at J1, located on the rear panel of the drawer, is fed to J1 on the Splitter Board, which supplies two outputs, one to each 888 amplifier pallet. Each amplifier pallet has approximately 14 dB gain. The amplified outputs of the pallets are combined in the 2 Way combiner board whose output is at J1. The RF is connected to J2 the 7/16" (1.1cm) Din RF output jack located on the rear panel of the drawer. The 2 way combiner board supplies a forward and a reflected power sample to the amplifier control board for metering and monitoring purposes. In a 400 Watt amplifier drawer, the typical sample value at J6, a 50Ω BNC jack located on the front panel of the drawer, is approximately 65dB down from the output power level of the drawer.

The CU500 ATSC system w/two dual 888 pallets and Axciter is made up of a CU30 w/Axciter Drawer and a 500 Watt Amplifier Drawer w/two dual 888 pallets. The CU30 w/Axciter is used as a driver that connects to the CU500 Amplifier drawer and supplies the needed drive level to produce the 500 Watts output of the system. The control and operating parameters of the 500 Watt Amplifier Drawer are displayed on the LCD Screen on the CU30 Drawer. In the CU500, the input RF signal at J1, located on the rear panel of the drawer, is fed to J1 on the 2 Way Splitter Board, which supplies two outputs, one to each 888 amplifier pallet. Each amplifier pallet has approximately 16 dB gain. The amplified outputs of the pallets are combined in the 2 Way combiner board whose output is at J1. The RF is connected to J2 the 7/16" (1.1cm) Din RF output jack located on the rear panel of the drawer. The 2 way combiner board supplies a forward and a reflected power sample to the amplifier control board for metering and monitoring purposes. In a CU500, the typical sample value at J6, a 50Ω BNC jack located on the front panel of the drawer, is approximately 65dB down from the output power level of the drawer.

The CU1TD/RD-3, 750 Watt ATSC system is made up of a driver drawer and a 750 Watt Amplifier Drawer. The output of the driver drawer connects to the Amplifier drawer and supplies the needed drive level to produce the 750 Watts output of the system. The control and operating parameters of the amplifier

drawer are displayed on the LCD Screen on the driver drawer. In the amplifier drawer the input RF signal at J1, located on the rear panel of the drawer, is fed to J1 on the 4 Way Splitter Board, which supplies four outputs, one to each 888A amplifier pallet. Each amplifier pallet has approximately 15 dB gain. The amplified outputs of the pallets are combined in the 4 Way combiner board whose output is at J1. The RF is connected to J2 the 7/16" (1.1cm) Din RF output jack located on the rear panel of the drawer. The 4 way combiner board supplies a forward and a reflected power sample to the amplifier control board for metering and monitoring purposes. The typical sample value at J6, a 50Ω BNC jack located on the front panel of the drawer, is approximately 65dB down from the output power level of the drawer.

In higher power systems, multiple amplifier drawers are used along with splitters and combiners to produce the desired output. A System Metering Board (1312666) provides forward, reflected, overtemperature and other parameters to the exciter/driver drawer from the external power amplifier chain. The CU2TD/RD is made up of a driver drawer, a two way splitter, two amplifier drawers and a two way combiner with a reject load. The reject load provides isolation protection of the operating power amplifier if the other amplifier fails. One-half the power of the operating amplifier drawer connected to the combiner will be dissipated by the reject load with the other half of the power going to the output filters and the antenna. The CU3TD/RD is made up of a driver drawer, a three way splitter, three amplifier drawers and a three way combiner with reject load. The CU4TD/RD is made up of a driver drawer, a four way splitter, four amplifier drawers and a four way combiner with reject load. The reject loads in the multi-amplifier systems have thermal switches connected to them which monitor the temperature of the load and provide the overtemperature fault, if it occurs, through the system metering board to the exciter/driver drawer.

The On Channel RF output of the amplifier drawer either connects directly to the digital mask filter and low pass filter and then to the antenna in single amplifier systems or to a combiner, the digital mask filter, low pass filter, output coupler and finally to the antenna in multiple amplifier systems. The output coupler provides a forward and a reflected power sample to the system metering board which detects the samples and supplies the forward and reflected power levels to the exciter/driver drawer for use in the metering circuits.

Optional Dual Exciter System w/Axciter Modulator Trays

The typical optional Dual Exciter System contains a Remote Interface Unit, two Axciter modulators, two CXB Exciter/Driver Assemblies, an Exciter Output Routing Switch, a power amplifier tray, a pre filter coupler, a low pass filter, a digital bandpass filter, a post filter coupler and an output coupler. The system also contains two Axciter relays, two 2 way splitters, a signal routing board and two system metering boards which generate forward and a reflected power samples for metering purposes in the exciter/driver assemblies.

The Remote Interface Unit monitors that state of the exciters and provides automatic exciter switching based on current conditions and operator inputs. The two exciters are configured as either the main On-Air exciter or the back-up exciter. Either exciter can be used as the selected main exciter and the other exciter functions in a backup role if it is not faulted.

NOTE: Information and drawings on the Axciter Modulator Drawer are contained in the separate Axciter Instruction Manual.

Exciter 1 consists of the (A4) Axciter Modulator Tray, the (A2) Axciter Relay, the (A1) Exciter/Driver Assembly Exciter 1, the (A3) system metering board and the (A5) 2 way splitter.

Exciter 2 consists of the (A14) Axciter Modulator Tray, the (A12) Axciter Relay, the (A11) Exciter/Driver Assembly Exciter 2, the (A13) system metering board and the (A15) 2 way splitter.

Each of the exciter/driver assemblies typically contains (A3) the Downconverter Board (1311103), (A4) the Frequency Agile Upconverter board (1309695), (A6) the Amplifier Assembly (1315008), (A7) the Output Metering Detector Board (1312207), (A8) the Innovator CX Control Board (1312543), (A9) the +5V, $\pm 12V$ Power Supply and (A10) the +48VDC Power Supply. **NOTE:** If your system contains 888A amplifier devices, the Amplifier Assembly may be (1315381).

The SMPTE-310 inputs connect to the rear panels of the (A4 & A14) Axciter modulator Drawers at the BNC connectors J27. The ASI Inputs, if option is present, connect to the ASI BNC input jacks J33 on the rear panels of the Drawers. The Optional External 10MHz reference inputs connect to J9 on the rear panels of the Axciter modulator trays. The Axciter modulator tray converts the ASI input into a digital IF signal at 44 MHz. The IF is connected to the digital upconverter board (1309695) that takes the 44 MHz IF signal and converts it to a TV channel frequency in the range of 54-860 MHz. The RF on channel signal is fed to the ALC Board, Innovator CXB Series (1308570), which is used to control the drive power to the RF amplifier chain in the Transmitter. The RF is connected to the (A6) Amplifier Assembly (1315008) that is made up of (A6-A1) the 2 Stage UHF Amplifier Board (1308784) and the (A6-A2) the RF Module Pallet (1309580). The assembly also contains the (A6-A3) ALC Board (1315006). In systems that contain 888A amplifier devices, the RF is connected to the (A6) Amplifier Assembly (1315381) that is made up of (A6-A1) the 1 Watt Amplifier Board (1315730), and the (A6-A2) the BLF881 Amplifier Board (1314882) and (A6-A3) the Dual 888A Amplifier Pallet (1315347). The assembly also contains the (A6-A3) ALC Board (1315006 for systems that contain an Axciter or 1308570 for all other systems). The assembly has approximately 40 dB of gain. The amplified output at approximately +50 dBm connects to the (A7) Output Detector Board (1312207) which provides forward and reflected power samples to the CU Control Board (1312543) for metering and monitoring purposes. An output power sample is also supplied to the front panel sample jack J15, which is a 50 Ohm BNC type. The typical sample value is approximately 60dB down from the output power level of the tray. The RF output is cabled to J9 the "N" connector RF output jack on the rear panel of the tray. The RF outputs of the Exciter/driver trays connect to (A20) the Exciter Output Routing Switch. The control panel selects which exciter/driver output is connected to J1 on the Power Amplifier Tray. The control and operating parameters of the Amplifier Tray are displayed on the LCD Screen located on the selected ON Air exciter/driver tray. In the CU500/600 tray, the input RF signal at J1, located on the rear panel of the tray, is fed to J1 on the 4 Way Splitter Board, which supplies four outputs, one to each amplifier pallet. Each amplifier pallet has approximately 14 dB gain. The amplified outputs of the pallets are combined in the 4 Way combiner board whose output is at J1. The RF is connected to J2 the 7/16" (1.1cm) Din RF output jack

located on the rear panel of the tray. The 4 way combiner board supplies a forward and a reflected power sample to the amplifier control board for metering and monitoring purposes. In a CU500/600, the typical sample value at J6, a 50Ω BNC jack located on the front panel of the tray, is approximately 65dB down from the output power level of the tray. The On Channel RF output of the amplifier tray is connected to the (A32) pre filter coupler that provides a pre filter forward sample to a coaxial switch located in (A27) the Remote Interface Assembly. The output of the pre filter coupler connects through the (A36) a low pass filter, to (A35) the digital mask filter, the (A37) post filter coupler, the (A37) output coupler and then to the antenna for your system. The post filter coupler provides forward and reflected post filter power samples that connect to a coaxial switch located in (A27) the Remote Interface Assembly. The forward and reflected power samples are directed to the ON Air exciter by using the remote interface panel to make the selection. Also included in the system is the Signal Routing Board (1310948) which controls the RS-485 data connections between the dual Exciter/Driver Assemblies and the power amplifier tray. Using a relay, which is controlled by the (A27) remote interface module, connections between the Exciters and the power amplifier tray are made. Exciter 1 can communicate with the Power Amplifier Tray or Exciter 2 can communicate with the Power Amplifier Tray both will not communicate at the same time. Each of the CXB exciters has an Ethernet controller and a separate Ethernet port that will need wired to the customer's network

Pre-Filter Sample (Non-Linear Distortion)

The pre-filter sample from the (A32) coupler connects to (A27) the remote interface module which controls to which exciter the sample connects. The sample connects to J1, on the (A2 or A12) Axciter relay, in the On Air exciter. The (A2) relay is controlled by the (A4) Axciter Modulator in exciter 1 and the (A12) relay is controlled by the (A14) Axciter Modulator in exciter 2 through jack J7 on the tray. The selected output of the relay at J3, either the Pre or Post filter sample, connects to the rear panel of the (A1 or A11) exciter/driver assembly at the BNC Jack J4 that is connected to the downconverter board in the tray for use in the adaptive equalization process in the Axciter system.

Post-Filter Sample (Linear Distortion)

A forward power sample, after-filtering, from the (A37) coupler at the output of the DTV filter connects to (A27) the remote interface module which controls to which exciter the sample connects. The forward sample from the selected On Air exciter connects to the (A5 or A15) 2 way splitter. One output of the splitter connects to the system metering board (A3 or A13) for use in the metering and control circuits in the exciter. The other output of the splitter connects the post filter forward sample to J2 on the (A2 or A12) Axciter relay in the selected On Air Exciter. The post filter forward power sample is connected to J2, on the (A2 or A12) Axciter relay located in the exciter that is selected as ON Air. The (A2) relay is controlled by the (A4) Axciter Modulator and the (A12) relay is controlled by the (A14) Axciter Modulator through jack J7 on the tray. The selected output of the relay, either the Pre or Post filter sample, connects to the rear panel of the (A1 or A11) driver/amplifier chassis assembly at the BNC Jack J4 that is connected to the downconverter board for use in the adaptive equalization process in the Axciter system.

Unpacking, Installation and Maintenance

Unpacking

Axcera certifies that upon leaving our facility all equipment was undamaged and in proper working order. It is imperative that all packages be inspected immediately upon arrival to verify that no damage occurred in transit to the site. Inspect all packages for exterior damage and make note of any dents, broken seals, or other indications of improper handling. Carefully open each package and inspect the contents for damage. Verify that all materials are enclosed as listed on the packing slip. Report any shortages to Axcera. In the event any in transit damage is discovered, report it to the carrier. Axcera is not responsible for damage caused by the carrier. If the equipment is not going to be installed immediately, return all items to their original packaging for safe storage. Save all packing material for future use. If equipment is ever removed from the site, the original packaging will ensure its safe transport.




Figure 1: CU2TD Front View Typical Racking Plan

Installation

The Innovator CX Series transmitters are designed for simple installation. Expensive test equipment is not required for installation and set up and to keep a system operational. An information decal, with Voltage Range, Current Range, Manufacturer, Model and ratings is attached to the rear panel of the stand alone drawer or if mounted in a cabinet, to the top of the frame above the door facing the rear of the cabinet. Prior to installing the product, review the following items. Check that they been installed, tested and/or inspected.

- Building Structure
- Electrical Systems
- Heating and Air Conditioning
- Receive Antenna or Satellite Dish and input cabling
- Optional ASI to S310 Converter, if needed
- Transmit Antenna and output transmission line

The Innovator CX Series systems are 17" (43.2cm) wide standard rack mountable drawers. They are supplied with side mounted Drawer Slides for ease of installation and removal. The CU0TD/RD-1, CU0TD/RD-2, CU0TD/RD-3, CU0TD/RD-4 & CU0TD/RD-5 systems are 3 RU, 5.25" (13.3cm), high. The CU1TD/RD-1, CU1TD/RD-2 & CU1TD/RD-3 systems are 9 RU, 15.75" (40cm) high, which is 3 RU, 5.25" (13.3cm) for the driver drawer and 6 RU, 10.5" (26.7cm) for the amplifier drawer. The CU2TD/RD systems are 15 RU, 26.25" (66.7cm) high, which is 3 RU, 5.25" (13.3cm) for the driver drawer and 12 RU, 21" (53.4cm) for the two amplifier drawers. The CU3TD/RD systems are 21 RU, 36.75" (93.3cm) high, which is 3 RU, 5.25" (13.3cm) for the driver drawer and 18 RU, 31.5" (80cm) for the three amplifier drawers. The CU4TD/RD systems are 27 RU, 47.25" (120cm) high, which is 3 RU, 5.25" (13.3cm) for the driver drawer and 24 RU, 42" (106.7cm) for the four amplifier drawers. In all the systems just described, if the Axciter is also part of the system, another 3 RU, 5.25" (13.3cm) must be added to the rack space for the Axciter drawer. **NOTE:** The Optional Dual Exciter System requires an additional 4 RU, 7" (17.73cm) for mounting into the cabinet. 3 RU, 5.25" (13.3cm) for the second Exciter/Driver drawer and an additional 1 RU, 1.75" (4.43cm) for the Exciter Switcher panel.

Also needed for FCC compliance operation is an ATSC filter on the broadcast channel that connects to the output of the CU0TD/RD thru CU4TD/RD systems. Space must be provided for the ATSC filter, and in some systems, for the circulator, splitter, combiner, reject load, and low pass filter whose dimensions will vary depending on manufacturer and channel. Refer to the vendor supplied information included with your ATSC filter and low pass filter for specific dimensions. Make sure that the space provided for the CX Series equipment is sufficient and includes the circulator, splitters, combiners, reject load and external filters. Check that any additional equipment, which is included in the system that extends above or to the side of the mounting rack, has sufficient clearance space. Refer to the custom racking plan for the system, if prepared, for detailed information.

Drawer Slide Installation

If the system is pre-mounted in a cabinet skip this section. Locate the drawer slides included in the installation material for your system. See Figure 2 and the manufacturers instructions, included with the drawer slides, for the cabinet mounting instructions of the drawer slides. Install the left drawer slide into the left side of the cabinet (as viewed from the rear). Allow 3 RU, 5.25" (13.3cm) of space between the drawers for a CU0TD/RD-1, CU0TD/RD-2, CU0TD/RD-3, CU0TD/RD-4 & CU0TD/RD-5 systems. In high power systems, allow a space of 3 RU, 5.25" (13.3cm) for the driver drawer and 6 RU, 10.5" (26.7cm) for each of the amplifier drawers. Space must also be provided for the splitter, combiner, ATSC filter and low pass filter, if present, whose dimensions will vary depending on the manufacturer and the output channel. Secure the left drawer slide by connecting it to the front and rear mounting bars using No. 10 screws and the bar nuts that have been provided. Install the drawer slide on the right side of the cabinet (as viewed from the rear) making sure that it is aligned with the drawer slide on the left side. Secure the slide by connecting it to the front and rear mounting bars using No. 10 screws and the bar nuts that have been provided. Repeat this process for any other drawers if purchased. With both slides in place, slide the drawer or drawers into the cabinet.




Figure 2: Cabinet Slides

AC Input Connections

The CU0TD/RD-1, CU0TD/RD-2 and CU0TD/RD-3 single drawer systems will operate with an input voltage of 85-253VAC. The CU0TD/RD-4 single drawer systems operate on 185-253VAC. The customer should provide a single point disconnect for the main AC input connection to the transmitter. Check that the AC switch, located on the rear of the drawer above the AC power jack, is OFF. Connect the AC power cord supplied with the drawer from J6 on the rear of the drawer to the AC source. If your system has the optional ASI to S310 Converter, check that it is connected to the AC source. If your system contains an optional preamp check that the 24VDC power supply is connected to the preamp and an AC source.

If your system is a CU1TD/RD-1, CU1TD/RD-2 or CU1TD/RD-3, it also contains one amplifier drawer. In CU2TD/RD and higher power systems, multiple amplifier drawers are included. Each amplifier drawer is configured for 230 VAC operation only. Check that the ON/OFF circuit breaker in the CU1TD/RD-1 amplifier drawer, or circuit breakers in N+1 amplifier drawers, CU1TD/RD-2 or CU1TD/RD-3, located on the rear panel on either side of the AC power jack, are OFF. Connect the AC power cord supplied with the drawer from J10 on the rear of the drawer to the 230 VAC source. Refer to Table 1 for the typical voltage and current requirements for CX Systems.

If the system is mounted in a rack, an AC distribution box wired to a quad receptacle box is used to connect the AC to the individual drawers. The AC distribution box is mounted on the upper right side of the rack accessed through the back of the rack. The main AC input for a C1TD-1 transmitter is, 195-253VAC, at least 10Amps, 50/60Hz. The customer should provide a single point disconnect for the main AC input that connects to the transmitter. The AC input lines connect inside the AC distribution box by first removing the two screws that hold the cover plate to the front of the AC distribution box. Then connect the three wire main AC input to the input lugs, L1 to L1, L2 to L2 and Ground to Ground. The power amplifier drawer and the quad receptacle box connect through AC power cords directly to the AC distribution box. The AC power to the optional receiver drawer and the exciter/driver drawer are connected through AC power cords that plug into the quad receptacle box.

If the system is mounted in a cabinet, an AC distribution panel is supplied to connect the AC to the individual drawers. The AC distribution panel is mounted facing the rear of the cabinet and accessed through the back of the cabinet. The main AC input for a CU2TD transmitter is, 195-253VAC, at least 30Amps, 50/60Hz. The customer should provide a single point disconnect for the main AC input that connects to the transmitter. The AC input lines connect to the AC distribution panel by first removing the four #8 screws that hold the cover plate to the front of the AC distribution panel. Then connect the three wire main AC input to the input lugs located at the top left of the AC distribution panel, L1 to L1, L2 to L2 and Ground to the Ground lug on the left. The AC distribution panel in a CU2TD has three circuit breakers that distribute the AC to the individual drawers, which are the Exciter and

the two power amplifier drawers. The circuit breakers, which are accessed through the rear door of the cabinet, supply the AC through AC line cords, that connect to the AC input jacks mounted on the rear panels of the drawers. CB1 is a 30 Amp circuit breaker which supplies the AC to the (A2), top, Power Amplifier A drawer. CB2 is a 30 Amp circuit breaker which supplies the AC to the (A3), bottom, Power Amplifier B drawer. CB3 is a 10 Amp circuit breaker which supplies the AC to the (A1) Exciter/Driver drawer. A maximum of four 30 Amp circuit breakers for four amplifier drawers and two 10 Amp circuit breakers for two Exciter/Driver drawers can be installed in the AC Distribution Panel.

Table 1: CXB Series Digital Systems Typical AC Input and Current Requirements.

System	O/P Power	Power Consumption	Voltage	Current
CU0TD/RD-1	10 Watts	180 Watts	115 VAC	1.6 Amps to the Cabinet
			230 VAC	.8 Amps to the Cabinet
CU0TD/RD-2	30 Watts	300 Watts	115 VAC	2.7 Amps to the Cabinet
			230 VAC	1.4 Amps to the Cabinet
CU0TD/RD-3	50 Watts	475 Watts	115 VAC	4.2 Amps to the Cabinet
			230 VAC	2.1 Amps to the Cabinet
CU0TD/RD-4	100 Watts	780 Watts	230 VAC	3.4 Amps to the Cabinet
CU0TD/RD-5	150 Watts	1000 Watts	230 VAC	4.3 Amps to the Cabinet
CU1TD/RD-1	250 Watts	1700 Watts	230 VAC	7.4 Amps to the Cabinet
CU1TD/RD-2	400 Watts	2400 Watts	230 VAC	10.4 Amps to the Cabinet
CU1TD/RD-3	750 Watts	4600 Watts	230 VAC	20 Amps to the Cabinet
CU2TD/RD	1400 Watts	8700 Watts	230 VAC	37.8 Amps to the Cabinet
CU3TD/RD	2100 Watts	11880 Watts	230 VAC	51.7 Amps to the Cabinet
CU4TD/RD	2500 Watts	14800 Watts	230 VAC	64.4 Amps to the Cabinet

NOTE: All values are approximate.

Input and Output Connections

The input and output connections to the system are made to the jacks mounted on the rear panels of the CU0TD/RD-1 thru CU0TD/RD-5 systems, the drivers for the CU1TD/RD-1 and high power systems, to the Watt amplifier drawers and to the Axciter Drawer if present in your system. The CU0TD/RD-1 thru CU0TD/RD-5 systems and the drivers for the CU1TD/RD-1 and higher power systems accept an On Channel RF signal (RD) or a SMPTE-310 (TD) input and output a digital RF ON Channel signal. Refer to Figures 3 & 3A and to Tables 2 & 2A that follow for the locations and information on the jacks and connectors. If your system contains the Optional Internal GPS Kit, the output of the GPS Antenna connects to the J5 TNC connector on the rear panel of the CXB drawer.

Figure 3: Rear View of Axciter Modulator Drawer




Table 2: Rear Chassis Connections for the Axciter Modulator Drawer

Port	Type	Function	Impedance
J2	BNC	IF Input (From Driver/Amplifier Assembly)	50Ω
J7	RJ-12	RF SW1 (To Axciter Relay)	N/A
J9	BNC	(Optional) 10MHz Reference Input	50Ω
J12	BNC	10MHz Output (To Driver/Amplifier Assembly)	50Ω
J27	BNC	SMPTE 310 Input	75Ω
J33	BNC	(Optional) ASI Input	75Ω
J40	BNC	IF Output (To Driver/Amplifier Assembly)	50Ω




Figure 3A: Rear View CU0TD/RD-1 thru CU0TD/RD-5 and the driver for the CU1TD/RD-1 & higher power systems

Table 2A: Connections for the CU0TD/RD-1 thru CU0TD/RD-5 and the driver for the CU1TD/RD-1 & higher power systems

Port	Type	Function	Impedance
J1	BNC	Input A: On Channel RF Input (RD) -78 to -8 dBm or SMPTE-310 Input (TD)	50 Ohms
J4	BNC	SMPTE-310 Output (RD Only) Normally jumpered to J5	50 Ohms
J5	BNC	SMPTE-310 Input (RD Only) Normally jumpered to J4 or	50 Ohms
	TNC	GPS Antenna Input (Only used with Internal GPS Kit)	75 Ohms
J6	BNC	10 MHz Input: Optional External 10 MHz Reference Input	50 Ohms
J7	BNC	1 PPS Input: Optional External 1 PPS Reference Input	50 Ohms
J9	N	RF Output: On Channel RF Output	50 Ohms
J10	IEC	AC Input: AC input connection to 85-264VAC Source and On/Off circuit breaker	N/A
J11	9 Pos Male D	Power Monitoring: Interface to System and external amplifier drawers, if present. Also provides an interlock for the Reject Load (if used). If not used, in systems with no external amplifier, a jumper from J11-6 to J11-9 needs to be in place. Refer to Table 2B which follows for information on the connections.	N/A
J12	15 Pos Female D	Remote: Remote control and status indications. Refer to Table 7A on pages 29 & 30 for information on the connections.	N/A
J13	RJ-45	Serial: Provides communication to System and to external amplifier drawers, if present.	N/A
J14	RJ-45	Ethernet: Optional Ethernet connection. May not be present in your drawer.	N/A
J15 Front	BNC	RF Sample: Output Sample from Output Detector Board. In a CU30, CU50, CU100 & CU125, the sample level at J15 is	50 Ohms

Port	Type	Function	Impedance
Panel		approximately 60dB down from the output power level of the drawer.	
J16 Front Panel	9 Pos Female D	Serial: Used to load equalizer taps into the modulator.	N/A

NOTES: 1) If your transmitter (TD) system contains an Optional ASI to S310 Converter, connect the ASI output of the STL to the ASI in jack on the rear panel of the converter. Connect the SMPTE-310 Output from the SMPTE 310 Out jack on the rear panel of the converter module to the input jack J1 on the rear panel of the CU0TD/RD-1 thru CU0TD/RD-5 drawer or the driver drawer for the CU1TD/RD-1 and higher power systems. 2) If your transmitter (TD) system contains an Optional K-Tech receiver, connect the RF from the receive antenna or one output of the splitter to the input jack J1 on the rear panel of the K-Tech receiver. Connect the SMPTE-310 Output from the SMPTE 310 Out jack J2 on the rear panel of the K-Tech receiver to the input jack J5 on the rear panel of the CU0TD/RD-1 thru CU0TD/RD-5 or the driver for the CU1TD/RD-1 and higher power systems. 3) If the system contains the optional K-Tech back up system, the K-Tech receiver is bypassed by using the second output of the splitter that connects to J1 on the rear panel of the CU0TD/RD-1 thru CU0TD/RD-5 or the driver drawer and connecting a jumper from J4 to J5, after removing the cable from the K-Tech receiver, on the rear panel of the CU0TD/RD-1 thru CU0TD/RD-5 or the driver drawer. This configuration uses the 8VSB demodulator board in the CU0TD/RD-1 thru CU0TD/RD-5 or the driver drawer to produce the SEMTE-310 signal. 4) If the system contains an optional preamp it connects to the output of the receive antenna and to J1 on the rear panel of the CU0TD/RD-1 thru CU0TD/RD-5 drawer.

J11 Power Monitoring Connections

In systems with one or more external amplifiers, J11 is used to communicate the output forward and reflected metering voltages back to the driver. J11 is connected directly to the external amplifier when there is only one external amplifier and is connected through the system metering module when multiple external amplifiers are used. In multiple external amplifier systems there are thermal switches mounted on the reject loads of the combiner, and the Reject load interlock is connected to the thermal switches and is used to shut down the system if the reject load overheats. In systems with no external amplifier, the only connection used is the Reject Load Interlock, which must be connected to Supply Return using a jumper from J11-6 to J11-9.

Table 2B: J1 9 Pos Male "D" Connector

J11 Pin	Function
1	+12VDC
2	System Forward Power
3	System Reflected Power
4	System Aural Power
5	Remote Spare Input
6	Reject Load Interlock. (If not used, in systems with no external amplifier, must be jumpered to J11-9)
7	System Serial +
8	System Serial -
9	Supply Return (If Reject Load Interlock is not used, in systems with no external amplifier, must be jumpered to J11-6)




Figure 4: Rear View Amplifier Drawer. **NOTE:** Some amplifier drawers only has a CB1 circuit breaker.

Table 3: Connections for the Amplifier Drawer

Port	Type	Function	Impedance
J1	N	RF Input: On Channel RF from CU driver drawer	50Ω
J2	7/16" (1.1cm) Din	RF Output: On Channel RF Output	50Ω
J3	IEC	AC Input: AC input connection to 230VAC Source	N/A
J4	9 Pos D	Remote: Amplifier Control Interface (Connects to J11 on the exciter/driver drawer)	N/A
J5	RJ-45	Serial data	N/A
J8 Front Panel	BNC	RF Sample: Output Sample from Combiner thru Control Board. In a CU500, the sample level is approximately 70dB down from the output power level of the drawer.	50Ω

Refer to Figures 3, 3A and 4, and Tables 2, 2A and 3 for detailed information on the jacks and connectors. Connect the On Channel RF Input (RD), -78 to -8 dBm, or the SMPTE-310 Input (TD), to the 50Ω BNC input jack J1, located on the rear panel of the CU5 thru CU125 systems and the driver drawers for the CU250 and higher power systems. The input to J1 can be from the ASI to S310 converter, the Axciter Drawer or any other source of a SMPTE-310 signal.

If used, connect the external 10 MHz reference input to the 50Ω BNC 10 MHz input jack J6 located on the rear panel of the CU0TD/RD-1 thru CU0TD/RD-5 and the driver for the CU1TD/RD-1 and higher power systems. If used, connect the external 1 PPS reference input to the 50Ω BNC 1 PPS input jack J7 located on the rear panel of the CU0TD/RD-1 thru CU0TD/RD-5 and the driver for the CU1TD/RD-1 and higher power systems. If your system contains the Optional Internal GPS Kit, the output of the GPS Antenna connects to the J5 TNC connector on the rear panel of the CU0TD/RD-1 thru CU0TD/RD-5 and the driver for the CU1TD/RD-1 and higher power systems. This kit supplies 10 MHz and 1 pps references for use in the CU0TD/RD-1 thru CU0TD/RD-5 and the driver for the CU1TD/RD-1 CXB drawer in higher power systems.

In Translator (RD) systems there is a SMPTE-310 loop-thru from the output of the Demodulator Board at J4, mounted on the rear panel of the transmitter or driver drawer, to the input to the Modulator Board at J5, mounted on the rear panel of the transmitter or driver drawer. There is a jumper installed from J4 to J5. To feed SMPTE-310 directly to the Modulator Board, remove the jumper and insert SMPTE-310 into J5. This is only used in Translator (RD) systems not Transmitter (TD) systems.

The digital RF ON Channel output of the CU0TD/RD-1 thru CU0TD/RD-5 and the driver for the CU1TD/RD-1 and higher power systems is at J9 the 50Ω "N" connector RF output jack located on the rear panel. In CU0TD/RD-1 thru CU0TD/RD-5 systems, the output of the drawer at J9 connects to the low pass, digital mask filter and then to the antenna for your system. In CU1TD/RD-1 and higher power systems, the output of the driver drawer at J9 is connected to J1 the 50 Ohm "N" connector RF input jack located on the rear panel of the amplifier drawer or to a splitter in multiple amplifier systems. In CU1TD/RD-1, CU1TD/RD-2 or CU1TD/RD-3 systems, check that the system power metering interface cable is connected from J11 the 9 position "D" connector located on the rear panel of the driver drawer to J4 the 9 position "D" connector located on the rear panel of the amplifier drawer. This cable provides the control, status and operating parameters of the amplifier drawer to the driver drawer. In CU2TD/RD and higher power systems the output of the driver drawer is split and connected to J1 the "N" type connector RF input jack on the amplifier drawers. Check that the system power metering interface cable is connected from J11 the 9 position "D" connector located on the rear panel of the driver drawer to J9 the 9 position "D" connector located on the System Metering Board. Also check that the serial connection is cabled from the RJ-45 connector J13 on the driver drawer to the RJ-45 connector J1 on the system metering board. The system metering board provides serial RJ-45 connections at J2 and J5 that are cabled to the RJ-45 serial port J5 on the rear panel of the amplifier drawers. These cables provide the control, status and operating parameters of the amplifier drawers to the driver drawer through the System Metering Board.

The digital RF ON Channel output of the amplifier drawer is at J2 the 50Ω "7/16" (1.1cm) Din connector RF output jack located on the rear panel that connects directly to the digital mask filter, the low pass filter and then to the antenna for your system in single amplifier systems. In multiple amplifier drawer systems the outputs of the drawers connect to a combiner and then the digital mask filter, the low pass mask filter, the output coupler and finally to the antenna for your system. The output coupler provides a forward and a reflected power sample that are cabled to the System Metering Board at J8 reflected and J3 forward. Also connected to the system metering board at J10-6 & 9, is the output of the overtemperature switch mounted to the reject load that is used as the reject interlock by the system. The samples and interlock are fed through J9 on the system metering board to J11 on the driver drawer. This completes the connections of the system.

Maintenance

Innovator CX Series Transmitters are designed with components that require little or no periodic maintenance except for the routine cleaning of the fans and the front panels of the modules and the periodic check of general tightness of hardware.

It is recommended that periodically, the time interval depends on the amount of movement the cabinet receives, all mounting hardware, holding drawer slides, shelving and mounting plates inside the cabinet are checked for tightness. All screws and bolts that are accessible should be tightened initially when the transmitter is received and periodically thereafter if the transmitter is moved by vehicle. All coaxial connectors, hard-line connections and hardware holding combiners, splitters, or any other mounted items should be checked and

tightened. The amount of time between cleanings of the drawers and cabinets depends on the conditions within the transmitter room. While the electronics have been designed to function even if covered with dust, a heavy buildup of dust, dirt, or insects will affect the cooling of the components. This could lead to a thermal shutdown or the premature failure of the affected drawer. When the front panels of the drawers become dust covered, the drawer should be pulled out and any accumulated foreign material should be removed.

NOTE: To remove the CX series transmitter from the cabinet, the input and output cables must be removed from the rear of the transmitter before the drawer can be pulled out completely from the cabinet.

A vacuum cleaner, utilizing a small, wand-type attachment, is an excellent way to suction out any dirt from the drawer and cabinet. Alcohol and other cleaning agents should not be used unless you are certain that the solvents will not damage components or the silk-screened markings on the drawers and boards. Water-based cleaners can be used, but do not saturate the components. The fans and heatsinks should be cleaned of all dust or dirt to permit the free flow of air for cooling purposes. It is recommended that the operating parameters of the transmitter be recorded from the LEDs and the LCD system metering on the front panel of the drawer at least once a month to be used for comparison purposes in case of a failure. It is suggested that this data be retained in a rugged folder or envelope and stored near the transmitter.

This page has intentionally been left blank.

Initial On Site Turn On Procedure

After the Innovator CX Series drawer or drawers are installed and all input, output and AC connections are made, the system is ready for the initial on site turn on. Check that the output of the CU0TD-1 thru CU0TD-5 drawer is connected to an appropriate rated load or to the digital mask filter, low pass filter and the antenna for your system. If your system is a CU1TD-1 or higher power system, check that the output of the amplifier drawer or the combiner assembly is connected to an appropriate rated load or to the digital mask filter, low pass filter and the antenna for your system. Check that the main AC power to the System is ON. If your system contains an optional ASI to S310 converter module, K-Tech receiver drawer or Axciter, check that they have AC connected to them and that they are turned ON. **NOTE:** If your system is mounted in a cabinet and contains an Optional UPS, check that the ON/OFF button, located on the left side of the top panel of the UPS is On. The UPS is normally mounted behind the removable blank panel, located immediately above the exciter/driver drawer, which is held in place by four #10 Phillips head screws.

If you have a CU0TD-1 thru CU0TD-5 system, push ON the switch located on the rear panel of the drawer above the AC power jack. The large fan mounted on the rear panel of the drawer should operate. If your system is a CU1TD/TD-1 or higher power system, switch ON the ON/OFF circuit breaker(s), located on the rear panel of the amplifier drawer(s), mounted on each side of the AC input power jack. The two fans mounted in the amplifier drawer should operate. Place the system in Operate. The Operate/Standby LED and Status LEDs on the CU0TD-1 thru CU0TD-5 should be Green indicating the system is in Operate and performing normally. The Operate/Standby LED showing Amber indicates the System is in Standby. The Status LED showing a blinking Red LED indicates an Event (Fault) is occurring now. The Status LED showing Amber indicates that an Event (Fault) occurred since the last time the Event (Fault) indications were reset.

If your system is CU1TD/RD-1 or higher power, the Enable LED and Status LEDs on the Amplifier Drawer should be Green indicating the system is in Operate and performing normally. The Enable LED showing Amber indicates the System is in Standby. The Status LED should be Green indicating no Events (Faults) in the system. If the Operate/Standby LED shows Amber it indicates that the System is in Standby. If the Status LED is blinking Red it indicates an Event (Fault) is occurring now. If the Status LED shows Amber it indicates that an Event (Fault) occurred since that last time the Event (Fault) indications were reset. The output power is factory set according to customer request and does not need adjusted. If a problem occurs, call Axcera field support at 724-873-8100 for information on modifying the power level of the system.

NOTE: The RF System Interlock is provided on J12, a 15 position "D" connector, located on the rear panel of the CU0TD-1 thru CU0TD-5 drawer. The RF System Interlock at J12-5 provides the customer with a means of connecting the system to protection circuits, for the loads, thermal switches, combiners, or the antenna, in the output of your system, that will place the system in Standby if the protection circuit opens. The Reject Load Interlock is provided at J11, a 9 position "D" connector. J11-6 provides the customer with a means of connecting the system to protection circuits, for the reject load in multiple amplifier systems, which will place the system in Standby if the protection circuit opens. If the interlocks are not used in your system, a plug with a jumper from J12-5 to J12-15, ground, for RF system Interlock and another plug with a jumper from J11-6 to J11-9, for Reject Load Interlock, need to be connected. These jumpers provide the RF System and Reject Load Interlocks, which allow the system to go to operate. Without the jumpers, the system will remain in Standby.

Typical System Operating Parameters

Typical Operating Parameters for a CU0TD/RD-1	
Parameter	Typical Reading
Forward Power	100%
Reflected Power	<5%
Power Supply Voltage	+24 VDC
Heatsink Temperature	20° to 30° F/15° to 20° C above ambient temperature
Pin Attenuator Voltage	1 Volt to 5 Volts

Typical Operating Parameters for a CU0TD/RD-2	
Parameter	Typical Reading
Forward Power	100%
Reflected Power	<5%
Power Supply Voltage	+28 VDC
Heatsink Temperature	20° to 30° F/15° to 20° C above ambient temperature
Pin Attenuator Voltage	1 Volt to 5 Volts

Typical Operating Parameters for a CU0TD/RD-3	
Parameter	Typical Reading
Forward Power	100%
Reflected Power	<5%
Power Supply Voltage	+30 VDC
Heatsink Temperature	20° to 30° F/15° to 20° C above ambient temperature
Pin Attenuator Voltage	1 Volt to 5 Volts

Typical Operating Parameters for a CU0TD/RD-4 & as a Driver	
Parameter	Typical Reading
Forward Power	100%
Reflected Power	<5%
Power Supply Voltage	+42 VDC or 48 VDC w/888A devices
Heatsink Temperature	20° to 30° F/15° to 20° C above ambient temperature
Pin Attenuator Voltage	1 Volt to 5 Volts

Typical Operating Parameters for a CU0TD/RD-2 or -3 used as a Driver	
Parameter	Typical Reading
Forward Power	20-70% (Depending on output power level of system)
Reflected Power	<3%
Power Supply Voltage	+30 VDC
Heatsink Temperature	20° to 30° F/15° to 20° C above ambient temperature
Pin Attenuator Voltage	1 Volt to 5 Volts

Typical Operating Parameters for the external Amplifier Drawer(s) in a C1TD/RD-1 or higher power System	
Parameter	Typical Reading
Forward Power	100%
Reflected Power	<5%
Power Supply Voltage	+42 VDC or 48 VDC w/888A devices
Heatsink Temperature	20° to 30° F/15° to 20° C above ambient temperature

Typical Problems, Indications and Causes in CU0TD/RD-2 or -3 Drawer

Problem	Indication	Cause
No power to drawer	Operate/Standby and Enable LED indicators and LCD display are Off	AC power cord not connected. Main AC to System missing. On/Off switch on back of drawer Off. 10 Amp fuse (F1) blown*. Power supply (A9) not operating
No Output Signal	Front Panel Status LED is Amber and blinking with no events, faults indicated.	On the 8VSB Modulator S310 MPEG Input Selection Set Up Screen, the Input is currently set incorrectly to "from Internal Source". Set to "from External Source". (Not used with Axciter)
Loss of Input Signal	Loss of Input on Modulator Menu	Loss of input signal. (Not used with Axciter)
Loss of Output Signal	Amber Operate/Standby LED. Blinking Red Status LED.	Any Event, Fault, which Mutes the output. Including Input Fault, VSWR Cutback, Overdrive, Overtemperature and Overvoltage.
Loss of 24V, 28V, 32V, 42V or 48V	Power Supply Fault on Power Supply Menu	Power supply (A10) not operating
Loss of ±12V or 5V	Operate/Standby and Enable LED indicators and LCD display are Off	Power supply (A9) not operating

NOTE: *A spare 10 Amp fuse is provided in the blank fuse holder under the active fuse.

If there is an Event (Fault) occurring in the system, the Status LED on the front panel will flash RED as long as the Event (Fault) is present. In addition, the menu will jump to the current Event (Fault) on the display and blink the Event (Fault) continuously, if the Jump to Fault screen is set to Yes. When the Event (Fault) is corrected, the drawer will turn the Status LED to AMBER to indicate that there was a Fault and the menu will still display the Fault but it will not flash. This gives the user the knowledge that there was an Event (Fault) and what type of Event (Fault) occurred. Before clearing the fault, check if there were other Events (Faults) by stepping through the menus. To reset the indication of previous Events (Faults) the user must push the Enter button with the Event (Fault) Reset Screen displayed. This will reset all previous Events (Faults).

LCD Display and Front Panel LED Indicators




Figure 5: Front View CU0TD/RD-1 thru CU0TD/RD-5 systems and the driver for the CU1TD-1 and higher power systems

Table 4: Innovator CX Series LCD Display

DISPLAY	FUNCTION
LCD	Provides a two line readout of the input received channel, internal functions, status, and Fault (Event) conditions.

The front panel has seven pushbuttons, two for the control of the system, Operate & Standby, and five for control of the displayed menus, Left, Right, Up, Down & Enter.

Table 5: Innovator CX Series Control Pushbuttons

PUSHBUTTON	FUNCTION
OPR	When pushed switches the system to Operate.
STBY	When pushed switches the system to Standby.
ENTER	Selects the changes made in the menus and submenus.
Up & Down Arrow	Scrolls through the main menus and after entering the Main Menu Steps through submenus of the main menu when they are present.
Left & Right Arrow	Used to exit from main menus and submenus of the main menu when they are present.

Table 6: Innovator CX Series Operate/Standby and Status Indicators

LED	FUNCTION
OPERATE/STANDBY (Green/Amber)	A Green LED indicates that the system is in Operate. An Amber LED indicates that the system is in Standby.
STATUS (Green/Red/ Amber)	A Green LED indicates that the system is functioning normally. A flashing Red LED indicates an Event (Fault) is occurring at this time. An Amber LED indicates an Event (Fault) occurred since the last time the Event (Fault) indications were reset but the system is now operating normally. Amber LED Blinking, with no Events (Faults) indicates the MPEG input is set to Internal Source.

NOTE: J15 is a Front Panel BNC RF Sample Jack 50Ω that provides an RF output sample from the output detector board in the drawer. In a CU0TD/RD-3, the sample level at J15 is approximately 60dB down from the output power level of the drawer.




Figure 6: Front View Amplifier Drawer in CU1TD/RD and higher power systems

Table 7: Innovator Amplifier Drawer LED Indicators and Sample Jack

LED	FUNCTION
ENABLE (Green/Amber)	A Green LED indicates that the system is in Operate and operating normally. An Amber LED indicates that the system is in Standby.

STATUS (Green/Red/ Amber)	A Green LED indicates that the system is functioning normally with no faults. A flashing Red LED indicates an Event (Fault) is occurring at this time. An Amber LED indicates an Event (Fault) occurred since the last time the Event (Fault) indications were reset but the system is now operating normally.
JACK	FUNCTION
SAMPLE J6	Typical sample value is 65dB down from the output power level of the drawer. (500 Watts output power = -8dBm sample level)

System Remote Connections to J12 J12




Figure 7: Rear View CU0TD/RD-1 thru CU0TD/RD-5 systems and the driver for the CU1TD-1 and higher power systems

The remote connections for the Innovator CX Series system are made to the Remote 15 Pos Female “D” connector Jack J12 located on the rear panel of the drawer. **NOTE:** In dual exciter systems remote connections are made to the rear panels of the two drivers.

Table 7A: Remote Connections to J12, 15 Pos Female D Connector, for CX Series system

Remote Signal Name	Pin Designation	Signal Type	Description
System Operate	J12-1	Discrete Open Collector Input - A pull down to ground on this line indicates that the System is to be placed into the operate mode. Not Available in dual exciter systems. (Low = Activate : Floating = No Change)	Command
System Standby	J12-2	Discrete Open Collector Input - A pull down to ground on this line indicates that the System is to be placed into the standby mode. Not Available in dual exciter systems. (Low = Activate : Floating = No Change)	Command
Power Raise	J12-3	Discrete Open Collector Input - A pull down to ground on this line indicates that the Power of the System is to be Raised. (Low = Activate : Floating = No Change)	Command
Power Lower	J12-4	Discrete Open Collector Input - A pull down to ground on this line indicates that the Power of the System is to be Lowered. (Low = Activate : Floating = No Change)	Command
System Interlock	J12-5	Discrete Open Collector Input - A pull down to ground on this line indicates that the Interlock is present. Normally jumpered to J12-15. (Low = OK : Floating = Fault)	
Set to Modulation Type	J12-6	Discrete Open Collector Input. - Sets the Modulation type of the system. (Low = Analog : Floating = Digital)	Command

Remote Signal Name	Pin Designation	Signal Type	Description
Set Channel (Set Up 1 or Set Up 2)	J12-7	Discrete Open Collector Input. – Selects one of two possible Channel Setups of the system. (Low = Set Up 2, CH 2 : Floating = Set Up 1, CH 1) NOTE: The Set Up 1 & Set Up 2 settings are displayed and changed in the Upconverter Set Up Menus.	Command
Ground	J12-8	Ground.	
System Forward Power Level	J12-9	Analog Output - 0 to 4.0 V. - This is a buffered loop through of the calibrated "System Forward Power". Indicates the System Forward power. Scale factor is 100 % = 2.0V.	Metering
System Aural Power Level	J12-10	Analog Output - 0 to 4.0 V. - This is a buffered loop through of the calibrated "System Aural Power". Indicates the System Aural power. Scale factor is 100 % = 2.0V. (Not used in Digital)	Metering
System Reflected Power Level	J12-11	Analog Output - 0 to 4.0 V. - This is a buffered loop through of the calibrated "System Reflected Power". Indicates the System Reflected power. Scale factor is 25 % = 2.0V.	Metering
Report Input Status	J12-12	Discrete Open Collector Output. - Indicates if input to system is Normal or Not. (Low = OK : Floating = Fault)	Status
Report Fault Status	J12-13	Discrete Open Collector Output. - Indicates if system is Operating Normally or has a Fault. Not available in dual exciter systems. (Low = OK : Floating = Fault)	Status
Report Operate Status	J12-14	Discrete Open Collector Output. – Indicates whether system is in Operate or Standby. Not available in dual exciter systems. (Low = Operate : Floating = Standby)	Status
Ground	J12-15	Ground. Not Available in dual exciter systems. Normally jumpered to J12-5.	

LCD Front Panel Screens

A LCD display, located on the front of the Innovator CXB Series systems, displays, on screens, the current operating status of the system. When the drawer is powered On, the LCD will initially display two splash screens. The first splash screen will be displayed for a few seconds, then the second splash screen will be displayed for a few seconds and finally the RF Power Display default screen will be displayed. See typical examples of the screens below. **NOTE:** These screens are typical examples of an operating system, your systems screens may be different. The RF Power Display default screen will be the screen displayed if no buttons are pushed to access other screens. While viewing the RF Power Display default screen, pushing the Left and Right arrow buttons together will also access the splash screens. **NOTE:** In dual exciter systems, the On Air Exciter will display the operating parameters of the system.

Splash Screen Number 1




The first splash screen displayed indicates the manufacturer, type of transmitter and the model number.

Splash Screen Number 2



The second splash screen indicates the Firmware and Version Numbers of the software used in the system. The example shown is Firmware number 1312423: Version number 6.3/2.7.

The final screen is the RF Power default screen which indicates the Forward Power and Reflected Power for the system.



The following screens are scrolled through using the buttons to the right of the display. Pushing and releasing the Up & Down Arrows will scroll you through the Main Menu, which are shown on the following pages aligned on the left side of the page. The Submenus, which are shown on the following pages aligned on the right side of the page, are accessed by pushing and releasing the ENTER button. Once in the Submenu, pushing and releasing the Up & Down Arrows will scroll you through the submenus of the Submenu. The Submenus are shown on the following pages indented under the Main Menu and the submenus of the Submenu are indented under the Submenu in which they are contained. In the SET UP Menu, changes are made to the display by Pushing and releasing the ENTER button which causes the item to be changed to blink, then using the left and right arrow buttons to display the desired changed item, finally, pushing the ENTER button will accept the changes made upon exit of the Set Up Menu.

NOTE: An example of accessing and changing an item using the Set Up Menu is as follows. This procedure is to set the Off Air Receive Channel to the desired channel. Push and release the DOWN Arrow button until the SYSTEM SET UP Main Menu is displayed. Push and release the ENTER button. The Authorization Warning screen is displayed. Push and release the ENTER button again and the ENTER BUTTON SETS TO CHANGE MODE screen is displayed. Push and release the ENTER button again and the first set up menu, which is the SET UP MENUS OF CHASSIS VALUES screen is displayed. Push and release the DOWN Arrow button until the SET UP 8VSB DEMODULATOR screen is displayed. Push and release the ENTER button to display the submenus under the SET UP 8VSB DEMODULATOR menu. Push and release the DOWN Arrow until the 8VSB DEMODULATOR USE OFF AIR CHxx is displayed. Push and release the ENTER button and the XX, which indicates the Channel Number, will blink. Push and release the UP or DOWN Arrow button until the desired new channel number is displayed. Push and release the ENTER button, and the PUSH ENTER TO ACCEPT CHANGES menu is displayed. Push and release the ENTER button again to

accept the changes made. The channel is now changed. Push and release the LEFT Arrow to exit to the SET UP 8VSB DEMODULATOR screen. Push and release the LEFT Arrow again to exit to the SYSTEM SET UP Main Menu. Push and release the UP or DOWN arrows to browse the main menus.

The following screens are typical of an operating system. The values indicated on the screens in your system may vary from those shown below.

Operation Screens

NOTE: The following Operation screens provide operating information only. No adjustments are available using these screens.

Table 8: Transmitter/Translator RF Power Screen (TD/RD)



```
FWD POWER 100%
RFL POWER 0.3%
```

This is the default screen that is displayed after the splash screens are displayed. This screen provides an indication of the Forward Output Power of the system in terms of Percent. (Typically 100%). The screen also provides an indication of the Reflected Power of the system in terms of Percent. (Typically less than 5%). Push the DOWN Arrow to view the next main menu, which is the Transmitter Event Log Main Menu.

Table 9: Transmitter/Translator Event Log Main Screen (TD/RD)



```
TRANSMITTER
EVENT LOG
```

This is the Transmitter Event Log Main Screen. Push the ENTER button to access the Event List submenu. Push the DOWN Arrow to view the next main menu, which is the Transmitter Details Main Menu.

Table 9.1: Transmitter/Translator Event List Screen (TD/RD)



```
001 OF 013 (01)
RF INTERLOCK FAU
```

When events occur, they will be displayed on this screen. The Up and Down arrow will page you through the different entries in the event log. The above screen indicates the 001 event of 013 total events that have occurred in the Transmitter. The number in the parenthesis on the top right, in this case 01, indicates the number of times the displayed event has occurred. The bottom line scrolls to indicate the event that occurred, in this case RF Interlock Fault, and the time the event occurred after the prior event. Push the LEFT Key to exit to the Transmitter Event Log Main Menu screen. Pushing the RIGHT Key will access the Event Reset Screen.

Table 9.2: Event Reset Screen (TD/RD)



```
PRESS ENTER TO
CLEAR EVENT LOG
```

This screen allows the resetting of the event log, after they are observed or corrected. **NOTE:** Resetting the events on an amplifier may cause the transmitter to momentarily mute.

Table 9.3: Event Reset Old Faults Screen (TD/RD)



```
PRESS ENTER TO
RESET OLD FAULTS
```

This screen allows the resetting of old faults that are latched from the event log after they are observed or corrected. The transmitter can be configured to latch faults as

detailed in Table 11.1.4. That means that if a fault occurs and then it clears, the status of the parameter in the details screen will not blink indicating an active fault, but it will still show fault indicating that previously this parameter was faulted. Within the web pages, a latched fault is shown with an orange background while faulted parameters are shown in red and good values are shown in green. Resetting Old Faults will clear the latched fault and the display will show the value as OK or with other text that indicates that it is not faulted.

Table 10: Transmitter/Translator Details Main Screen (TD/RD)



This is the System Details Main Screen. Push the ENTER button to access the Device Details Chassis Values Main Sub Screen or push the DOWN Arrow to view the next main menu, which is the System Set Up Main Menu.

Table 10.1: Transmitter/Translator Device Details Exciter Values Screen (TD/RD)



This is the System Device Details Exciter Values Main Sub Screen. Push the ENTER button to access the Device Details Exciter Values submenus or push the DOWN Arrow to view the next main submenu, which is the 8VSB Demodulator Sub Menu. (Not used with Axciter)

Table 10.1.1: Transmitter/Translator Driver Forward/Reflected Power Details Screen (TD/RD)



This screen provides an indication of the Output Forward Power of the Driver Drawer in terms of Percent, typically 20-70%. This screen also provides an indication of the Reflected Output Power of the Driver Drawer in terms of Percent, Typically less than 3%.

Table 10.1.2: Heatsink Temperature Details Screen (TD/RD)



This screen indicates the temperature of the amplifier heatsink assembly, mounted in the system or driver drawer, in degrees Fahrenheit or Centigrade. If the temperature is below the trip point, it will indicate OK. (Typically 20° to 30° F. or 15° to 20° C above ambient temperature)

Table 10.1.3: Power Supply Voltage Details Screen (TD/RD)



This screen indicates the power supply voltage in the system or driver drawer. If the power supply voltage is below the trip point, it will indicate OK. The fault limit is the nominal supply voltage as set in the Exciter Setup Screen $\pm 10\%$. (Typically 24V for 3 Watt, 28V for a 30 Watt, 30V for 50 Watt, or 42/48V for 100/150 Watt Systems.)

Table 10.1.4: RF System Interlock Details Screen (TD/RD)

```
RF SYSTEM  
INTERLOCK   OK
```

This screen indicates if the external RF system interlock is present in your system. (Typically Present. Must be present or system will remain in Standby.)

Table 10.1.5: Reject Load Interlock Details Screen (TD/RD)

```
REJECT LOAD  
INTERLOCK   OK
```

This screen indicates if the external Reject Load interlock is present in your system. (Typically Present. Must be present or system will remain in Standby.)

Table 10.1.6: AGC Details Screen (TD/RD)

```
AGC INPUT STATUS  
                OK
```

This menu indicates if the AGC circuit has an input.

Table 10.1.7: AGC Overdrive Details Screen (TD/RD)

```
AGC OVERDRIVE  
                OK
```

This menu indicates if the AGC circuit is operating within its range.

Table 10.1.8: AGC Auto/Manual Details Screen (TD/RD)

```
AGC AT S1 SET TO  
AUTO MODE
```

This menu indicates if the AGC circuit is operating in Auto or Manual.

Table 10.1.9: ALC Voltage Level Details Screen (TD/RD)

```
ALC VOLTAGE AT  
                1.8 VDC
```

This menu indicates the Auto ALC voltage setting. (Typically 1 to 5 V)

Pushing the Left Arrow will display the System Device Details Exciter Values Main Sub Screen and then pushing the Down arrow will access the System Device Details 8VSB Demodulator Main Sub Screen.

Table 10.2: Translator 8VSB Demodulator Details Screen (RD)

```
DEVICE DETAILS  
8VSB DEMODULATOR
```

This is the System Device Details 8VSB Demodulator Main Sub Screen, if present in the system. This screen is Not used with Axciter. Push the ENTER button to access the Device 8VSB Demodulator submenus or push the DOWN Arrow to view the next main menu, which is the Device Details 8VSB Modulator Main Sub Menu.

Table 10.2.1: System Input Details Screen (RD)

```
SNR IS      32.2  
INPUT PWR >95.0%
```

This screen provides the user information on the signal to noise ratio and signal strength of the received signal. The signal to noise ratio is provided on this menu to indicate to the user the quality of the receive signal. This reading also assists the user in the positioning of the antenna. The signal

strength ranges from 0 to 100% and typically should be above 40% for reliable operation. The signal strength allows the user to optimize the position of the receive antenna.

Table 10.2.2: Demodulator Details Screen (RD)

```
DEMODULATOR
INPUT          OK
```

This menu indicates whether there is a signal present at the demodulator.

Table 10.2.3: Demodulator Phase Lock Loop Details Screen (RD)

```
DEMODULATOR
PLL           OK
```

This menu indicates whether the Phase Lock Loop is locked in the demodulator.

Table 10.2.4: Receive Input Channel Details Screen (RD)

```
RECEIVE CHANNEL
IS OFFAIR CH50
```

This menu indicates the input channel to the Demodulator circuit.

Pushing the Left Arrow will display the System Device Details 8VSB Demodulator Values Main Sub Screen and then pushing the Down arrow will access the System Device Details 8VSB Modulator Main Sub Screens.

Table 10.3: Transmitter/Translator 8VSB Modulator Details Screen (TD/RD)

```
DEVICE DETAILS
8VSB MODULATOR
```

This is the System Device Details 8VSB Modulator Main Sub Screen, not present with Axciter. Push the ENTER button to access the Device 8VSB Modulator submenus or push the DOWN Arrow to view the next main menu, which is the Device Details IF Processor Main Sub Menu.

Table 10.3.1: Transmitter/Translator S310 Input Details Screen (TD/RD)

```
INTERNAL SOURCE
S310 INPUT    OK
```

This menu indicates if the modulator has locked to the SMPTE-310 signal coming from the demodulator.

Table 10.3.2: Modulator Phase Lock Loop A Details Screen (TD/RD)

```
MODULATOR
PLL A        OK
```

This menu indicates if the Phase Lock Loop A in the modulator is locked.

Table 10.3.3: Modulator Phase Lock Loop B Details Screen (TD/RD)

```
MODULATOR
PLL B        OK
```

This menu indicates if the Phase Lock Loop B in the modulator is locked.

Table 10.3.4: Modulator Linear Equalization Details Screen (TD/RD)

```
MODULATOR
LINEAR EQ    OFF
```

This menu indicates if the Linear Equalization is being used.

Table 10.3.5: Modulator Non Linear Equalization Details Screen (TD/RD)

```
MODULATOR  
NONLINEAR EQ OFF
```

This menu indicates if the Non Linear Equalization is being used.

Pushing the Left Arrow will display the System Device Details 8VSB Modulator Values Main Sub Screen and then pushing the Down arrow will access the System Device Details IF Processor Main Sub Screen.

Table 10.4: Transmitter/Translator IF Processor Details Screen (TD/RD)

```
DEVICE DETAILS  
IF PROCESSOR
```

This is the System Device Details IF Processor Main Sub Screen, (if present, not used with Axciter). Push the ENTER button to access the Device IF Processor submenus or push the DOWN Arrow to view the next main menu, which is the Device Details Upconverter Main Sub Menu.

Table 10.4.1: IF Processor Input Details Screen (TD/RD)

```
IF PROCESSOR  
INPUT OK
```

This menu indicates if there is an input signal to the IF Processor.

Table 10.4.2: IF Processor Modulation Present Details Screen (TD/RD)

```
IF PROCESSOR  
MODULATION OK
```

This menu indicates if there is Modulation on the signal to the IF Processor.

Pushing the Left Arrow will display the System Device Details IF Processor Values Main Sub Screen and then pushing the Down arrow will access the System Device Details Upconverter Main Sub Screen.

Table 10.5: Upconverter Device Details Screen (TD/RD)

```
DEVICE DETAILS  
UPCONVERTER
```

This is the System Device Details Upconverter Main Sub Screen. Push the ENTER button to access the Device Upconverter submenus or push the DOWN Arrow to view the next main menu, which is the Device Details Downconverter Main Sub Menu.

Table 10.5.1: Upconverter Phase Lock Loop 1 Details Screen (TD/RD)

```
UPCONVERTER  
PLL 1 OK
```

This menu indicates if the Phase Lock Loop 1 in the upconverter is locked. The LO1 oscillator operates at 1.008 GHz and is used to convert the pre-corrected IF signal to 1044 MHz. The Red LED DS4, located on the Upconverter board, will light if the PLL for the LO1 oscillator is not locked to the on board 10 MHz VCXO and therefore will indicate a fault.

Table 10.5.2: Upconverter Phase Lock Loop 2 Details Screen (TD/RD)

```
UPCONVERTER  
PLL 2 OK
```

This menu indicates if the Phase Lock Loop 2 in the upconverter is locked. The second LO, LO2, consists of two VCOs, one operating from 1.1-1.5 GHz and the second from 1.5-1.9 GHz, that are used to generate the second LO,

which is the Channel Center Frequency + 1044 MHz. The Red LED DS2, located on the upconverter board, will light if the PLL for the LO2 oscillator is not locked and therefore will indicate a fault.

Table 10.5.3: Upconverter 10 MHz Phase Lock Loop Details Screen (TD/RD)

```
UPCONVERTER
10MHz PLL   OK
```

This menu indicates if the 10 MHz Phase Lock Loop in the upconverter is locked. When an external 10 MHz signal is applied to system, the internal VCXO is locked to the external 10 MHz, otherwise, it is free-running. With no external reference present, the PLL cannot function and is disconnected from the internal 10 MHz oscillator and therefore will indicate a fault.

Table 10.5.4: Upconverter 10 MHz Details Screen (TD/RD)

```
REFERENCE SOURCE   REFERENCE SOURCE
EXTERNAL 10MHz     INTERNAL 10MHz
```

This menu indicates if the 10 MHz reference used is generated internally or provided by an external reference source.

Table 10.5.5: Upconverter System Channel Details Screen (TD/RD)

```
TRANSMIT CHANNEL
CH47 671.000MHz
```

The upconverter transmit channel screen indicates the channel that the upconverter is currently set and the center frequency of that channel. Displayed above is CH: 47 that has a Center Frequency of 671MHz.

Pushing the Left Arrow will display the System Device Details Upconverter Values Main Sub Screen and then pushing the Down arrow will access the System Device Details Downconverter Main Sub Screen, if present.

Table 10.6: Downconverter Device Details Screen (TD/RD)

```
DEVICE DETAILS
DOWNCONVERTER
```

NOTE: This screen is only used with an Axciter.

This is the System Device Details Downconverter Main Sub Screen. Push the ENTER button to access the Device Downconverter submenus or push the DOWN Arrow to go to the External Amplifier Device Details Screen, if present, or back to the Device Details Exciter Values screen.

Table 10.6.1: Downconverter RF Input Details Screen (TD/RD)

```
DOWNCONVERTER
RF INPUT 0.6dBm
```

NOTE: This screen is only used with an Axciter.

The Downconverter RF Input details screen indicates that an RF input is present to the downconverter and the level of the input.

This is the final Device Details Main Sub Menu. Push the LEFT Arrow twice to go back the Main System Details Screen. Then push the DOWN Arrow to access the System Set Up Main Menu.

Table 10.7: External Amplifier Device Details Screen (TD/RD)

```
DEVICE DETAILS  
EXTERNAL AMP #1
```

This is the Transmitter Device Details External Amplifier Main Sub Screen. This is the final Device Details Main Sub Menu. Push the ENTER button to access the Device External Amplifier #1. Push the LEFT Arrow to go back the Main Device Details Screen. Then push the DOWN Arrow to access the Transmitter Set Up Main Menu.

NOTE: Shown below are the External Amplifier #1 Details Screens. The External Amplifier #2, #3 or #4 Details Screens are presented in the same order if they are present in the system.

Table 10.7.1: External Amplifier #1 Forward Power Details Screen (TD/RD)

```
EX AMP #1  
FRD POWER 95.0%
```

Indicates Output Power for external amplifier #1. **NOTE:** See the final test data sheet for the typical value.

Table 10.7.2: External Amplifier #1 Reflected Power Details Screen (TD/RD)

```
EX AMP #1  
RFL POWER 2.4%
```

Indicates Reflected Power for external amplifier #1. **NOTE:** See the final test data sheet for the typical value.

Table 10.7.3: External Amplifier #1 I1-A1 Current Details Screen (TD/RD)

```
EX AMP #1  
I1-A1 13.2 A
```

Indicates Current of the A1 device in the external amplifier #1. **NOTE:** See the final test data sheet for the typical current value.

Table 10.7.4: External Amplifier#1 I2-A2 Current Details Screen (TD/RD)

```
EX AMP #1  
I2-A2 13.1 A
```

Indicates Current of the A2 device in the external amplifier #1. **NOTE:** See the final test data sheet for the typical current value.

Table 10.7.5: External Amplifier#1 I3-B1 Current Details Screen (TD/RD)

```
EX AMP #1  
I3-B1 13.4 A
```

Indicates Current of the B1 device in the external amplifier #1. **NOTE:** See the final test data sheet for the typical current value.

Table 10.7.6: External Amplifier#1 I4-B2 Current Details Screen (TD/RD)

```
EX AMP #1  
I4-B2 13.3 A
```

Indicates Current of the B2 device in the external amplifier #1. **NOTE:** See the final test data sheet for the typical current value.

Table 10.7.7: External Amplifier #1 A Power Supply Details Screen (TD/RD)

```
EX AMP #1  
A SUPPLY 42.0 V
```

Indicates the voltage of the A power supply in the external amplifier #1.

NOTE: Typical voltage value is +42VDC or +48VDC w/888A devices.

Table 10.7.8: External Amplifier #1 B Power Supply Details Screen (TD/RD)

```
EX AMP #1  
B SUPPLY 42.1 V
```

Indicates the voltage of the B power supply in the external amplifier #1.

NOTE: Typical voltage value is +42VDC nominal or +48VDC w/888A devices.

Table 10.7.9: External Amplifier #1 A Temperature Details Screen (TD/RD)

```
EX AMP #1  
A TEMP 29 C
```

Indicates the temperature of the A heatsink in the external amplifier #1.

NOTE: Typical temperature for DVB = $\approx 20\text{-}30^{\circ}\text{C}$ above ambient.

Table 10.7.10: External Amplifier #1 B Temperature Details Screen (TD/RD)

```
EX AMP #1  
B TEMP 29 C
```

Indicates the temperature of the B heatsink in the external amplifier #1.

NOTE: Typical temperature for DVB = $\approx 20\text{-}30^{\circ}\text{C}$ above ambient.

Table 10.7.11: External Amplifier #1 Code Version Details Screen (TD/RD)

```
EX AMP #1  
VERSION 1.6
```

Indicates the code version in the external amplifier #1.

Set Up Screens

Table 11: Transmitter/Translator Set Up Main Screen (TD/RD)

```
TRANSMITTER  
SET-UP
```

This is the System Set Up Main Screen. Push the ENTER button to access the Authorization Warning Main Sub Screen or since this is the final Main Screen, pushing the DOWN Arrow will take you back to the System RF Power Default Screen.

The Set Up item or parameter that can be changed on the displayed sub menu screen, is indicated by pushing the ENTER button, which causes the changeable item to blink. The UP or DOWN arrow will change the selection until the desired result is displayed. Pushing the ENTER Button will accept the change.

Table 11A: Authorized Personnel Screen (TD/RD)

```
PRESS ENTER ONLY  
IF AUTHORIZED.
```

This screen of the system notifies an operator that they are only to proceed if they are authorized to make changes to the system's operation. Changes made within the following set-up screens can affect the system's output power level, output frequency, and the general behavior of the system. Please do not make changes within the system's set-up screens unless you are familiar with the operation of the system. Pressing the ENTER button will display the Enter Key Sets to Change screen.

Table 11B: Enter Key Sets to Change Mode Screen (TD/RD)



RIGHT KEY SETS
TO CHANGE MODE

This screen informs the operator that to make changes, the Enter key or the Right key must be pushed, which will cause the display that can be changed to blink. Use the up or down key to change the display and the left or right key to move the blinking item on the display. After changes are made in the Set Up Menus pushing the enter Key, Button, will accept the changes made. With the Right Key Sets To Change Mode screen displayed, pushing the ENTER button will access the first main submenu under the Set Up main menu, which is the Chassis Values Set Up Menu.

Table 11.1: Chassis Values Main Set Up Menu Screen (TD/RD)



SET-UP MENUS OF
CHASSIS VALUES

This is the System Set Up Chassis Values Main Sub Screen. Push the ENTER button to access the Chassis Values submenus or push the DOWN Arrow to view the next Set Up Main Sub Screen, which is the Set Up 8VSB Demodulator Main Sub Screen.

NOTE: Refer to the description in Table 11B for how to change the values on the following set-up screens.

Table 11.1.1: Chassis Values Forward Power Set Up Screen (TD/RD)



FWD POWER 0%
ADJUST

Remote or front panel adjustment of the output power of the transmitter. The bar graph indicates the range remaining in the adjustment.

NOTE: If the transmitter's output power is being adjusted through the web page, the transmitter's forward power will be blinking on this screen. It will remain blinking while the transmitter is adjusting to the desired target power level.

Table 11.1.2: Chassis Values Model Number Set Up Screen (TD/RD)



MODEL NUMBER CU2TD MODEL NUMBER CU2RD

This screen allows the set up of the Model Number of the transmitter/regenerative translator. This causes the system to access the proper parameters to be displayed on the LCD screens. **NOTE:** Do not change this screen without first consulting with Axcera.

Table 11.1.3: Chassis Values Jump to Menu on Fault Set Up Screen (TD/RD)



JUMP TO MENU
ON FAULT IS ON

The 'Jump To Menu' setting screen allows an operator to change how the transmitter's display system works. When this value is set 'ON' and a new fault occurs, the transmitter will automatically change the display screen to show the new fault condition. When this value is set 'OFF', the display screen does not change when a new fault is detected.

Table 11.1.4: Chassis Values Latch On an Input Fault Set Up Screen (TD/RD)

```
FAULT LATCHING  
IS SET      OFF
```

This screen, by selecting ON, allows the user to select that the system will latch the fault if it occurs, then if the problem is corrected the fault will still register. Since latched faults are used to set the status LED color, when fault latching is OFF, the status LED should only be green if there are no faults or red if there are one or more active faults. When fault latching is ON, the status LED will be amber if there are no current faults but a fault was previously detected and is now a latched fault. A blinking amber status LED indicates that there are no current faults or latched faults but that an internal signal source is selected instead of an external source.

Table 11.1.5: Chassis Values IF Processor Selection Screen (TD/RD)

```
IF PROCESSOR IS  
REQUIRED      YES
```

This screen allows the user to select that the system has an IF Processor.

Table 11.1.6: Chassis Values Downconverter Selection Screen (TD/RD)

```
DOWNCONVERTER IS  
REQUIRED      NO
```

This screen allows the user to select that the system has a Downconverter.

Table 11.1.7: Chassis Values Amplifier Power Supply Voltage Screen (TD/RD)

```
AMP POWER SUPPLY  
VOLTAGE IS 28VDC
```

This screen allows the user to select the Power Supply Voltage.

Table 11.1.8: Chassis Values Forward Power Fault Adjust Screen (TD/RD)

```
MINIMUM FORWARD  
POWER IS 50%
```

This screen allows the operator to configure a forward power fault threshold setting. When the exciter is enabled for at least a few seconds and the system forward power is not greater than or equal to this setting, a fault is indicated on the status LED and also on the remote fault indicator pin.

Table 11.1.9: Chassis Values number of Amplifiers in System Screen (TD/RD)

```
EXPECTING 2 AMPS  
ENT KEY TO SETUP
```

This screen indicates the number of external amplifier drawers in the system. By selecting the enter key, the system will scan to find the number of external amplifier drawers. **NOTE:** Do not change this screen without first consulting with Axcera.

Table 11.1.10: Chassis Values Ethernet Option Set Up Screen (TD/RD)

```
ETHERNET OPTION  
NOT PRESENT
```

Only displayed if Ethernet Controller is not present in your system.

Table 11.1.11: Chassis Values Reset Ethernet User Name Set Up Screen (TD/RD)

```
RESET ETHERNET  
USERNAME    OFF
```

When the optional Ethernet Controller is present, this screen is displayed. It is used to reset the first username / password account of the Ethernet controller. There are a total a five accounts available on the Web. If this operation is selected, ON, and the change accepted, only the fist username / password account file is replaced, with the user name set to 'admin' and the password set to 'axcera'.

Table 11.1.12: Chassis Values Ethernet Address Set Up Screen (TD/RD)

```
ETHERNET ADDRESS  
155.226.168.054
```

When the optional Ethernet Controller module is present, this screen is used to view or change the Ethernet TCP Address of the controller.

Table 11.1.13: Chassis Values Ethernet Netmask Set Up Screen (TD/RD)

```
ETHERNET NETMASK  
255.255.240.000
```

When the optional Ethernet Controller module is present, this screen is used to view or change the TCP subnet mask of the Ethernet controller.

Table 11.1.14: Chassis Values Ethernet Gateway Set Up Screen (TD/RD)

```
ETHERNET GATEWAY  
010.000.000.001
```

When the optional Ethernet Controller module is present, this screen is used to view or change the TCP gateway (router) address of the Ethernet controller.

Table 11.2: 8VSB Demodulator Main Set Up Menu Screen (RD)

```
SET-UP MENUS OF  
8VSB DEMODULATOR
```

This is the System Set Up 8VSB Demodulator Main Sub Screen that is only present in the Regenerative Translator mode. Push the ENTER button to access the Set Up 8VSB Demodulator submenus or push the DOWN Arrow to view the next Set Up Main Sub Screen, which is the Set Up 8VSB Modulator Main Sub Screen. **NOTE:** Refer to the description in Table 11B for how to change the values on the following set-up screens.

Table 11.2.1: 8VSB Demodulator Channels Set Up Menu Screen (RD)

```
DEMODULATE CFG 1  
OFFAIR CHANNELS
```

This screen allows selection of the channel plan which can be changed to either Off Air or Cable.

Table 11.2.2: 8VSB Demodulator Channel Select Set Up Menu Screen (RD)

```
8VSB DEMODULATOR  
USE OFFAIR CH50
```

This screen allows selection of the channel, for the channel plan selected in the previous screen.

Table 11.3: 8VSB Modulator Main Set Up Menu Screen (TD/RD)

SET-UP MENUS OF
 8VSB MODULATOR

(Not present with Axciter)

This is the System Set Up 8VSB Modulator Main Sub Screen. Push the ENTER button to access the Set Up 8VSB Modulator submenus or push the DOWN Arrow to view the next Set Up Main Sub Screen, which is the Set Up Upconverter Main Sub Screen. **NOTE:** Refer to the description in Table 11B for how to change the values on the following set-up screens.

Table 11.3.1: 8VSB Modulator MPEG Selection Set Up Screen (TD/RD)

MPEG INPUT FROM EXTERNAL SOURCE MPEG INPUT FROM INTERNAL SOURCE

This screen allows the user to select between an external and an internal source in the 8 VSB modulator. During the installation of the system, an off air signal may not be available to the modulator, therefore the user can set the source to INTERNAL to generate an 8 VSB signal inside the drawer that can be used for set up. Once the Receive Signal is available, the source must be set to EXTERNAL. **NOTE:** The front panel Status LED will be Amber and blinking, with no faults, events, if the MPEG input is set to Internal Source.

Table 11.3.2: 8VSB Modulator Linear Equalization Selection Screen (TD/RD)

LINEAR EQUALIZER ON

This screen controls the operation of the linear equalizer. When set to ON, the modulator applies linear correction to the IF output. When set to OFF, no correction is applied to the IF.

Table 11.3.3: 8VSB Modulator Non Linear Equalization Selection Screen (TD/RD)

NONLINEAR EQUALIZER OFF

This screen controls the operation of the non linear equalizer. When set to ON, the modulator applies non linear correction to the IF output. When set to OFF, no correction is applied to the IF.

Table 11.4: Upconverter Main Set Up Menu Screen (TD/RD)

SET-UP MENUS OF
 UPCONVERTER

This is the System Set Up Upconverter Main Sub Screen. Push the ENTER button to access the Set Up Upconverter submenus. Push the LEFT Arrow to go back the Main System Set Up Screen. **NOTE:** Refer to the description in Table 11B for how to change the values on the following set-up screens.

Table 11.4.1: Upconverter Channel Type Selection Screen (TD/RD)

FREQUENCY SETUP1 AMERICAN CHANNEL FREQUENCY SETUP1 EUROPEAN CHANNEL FREQUENCY SETUP1 CUSTOM UHF FREQ FREQUENCY SETUP1 CUSTOM UHF FREQ

One of the above screens is displayed as the first screen on entering the upconverter set up screens. It will indicate the Channel Type currently selected. The display will not be blinking. Pushing the Down Button will display the Upconverter Channel Selection Screen. **NOTES:** The Upconverter transmit channel type should not be changed, unless the transmitter is being converted

from one channel to another. The SETUP 1 or SETUP 2 selection is controlled by a Low, ground, for SETUP 2 or a High, open, for SETUP 1 at J12-7, on the Remote Interface Jack J12 located on the rear panel of the Exciter/Driver Drawer. Changes should only be made while the transmitter is in standby. Contact Axcera Field Service before using this menu.

With a Channel or Custom Frequency screen displayed, the Channel type can be set to the American Channel, European Channel, Custom UHF Frequency or Custom VHF Frequency by first pushing the enter button. This will cause the channel type to blink. Pushing the Up or Down Arrow Key will display each Channel type screen in sequence. When the desired screen is displayed pushing the Enter Button will cause the display to become steady. This displayed channel type is now used in the following screen to configure the Upconverter PLL circuits.

Table 11.4.2: Upconverter Channel Selection Screen (TD/RD)

```
UC CH47  SETUP1  
FREQ 671.00 MHZ
```

The above screen is displayed when the Down Arrow is pushed at the channel type selection screen. It will indicate the Channel currently selected and the center frequency of the selected channel. The display will not be blinking. Pushing the Down Button will display the Upconverter IF Frequency Selection Screen. **NOTES:** The Upconverter transmit channel should not be changed, unless the transmitter is being converted from one channel to another. Changes should only be made while the transmitter is in standby. Contact Axcera Field Service before using this menu.

To change the Channel, the enter button must be pushed. This will cause the Channel number to blink. Pushing the Up or Down Arrow Key will display each Channel in sequence. To enter a custom Center Frequency, press the Right or Left Key to select the value to change. The Up or Down Arrow will adjust the value selected. When the desired Channel and Center Frequency are set, pushing the Enter Button will cause the display to become steady. This displayed Channel and corresponding Center frequency is now the upconverter output.

When exiting the set up menus a prompt will inform you that the Enter Key must be pushed to accept the changes that were made.

Table 11.4.3: Upconverter IF Frequency Selection Screen

```
UPCONVERTER          UPCONVERTER  
IF FREQ 44MHZ       IF FREQ 36MHZ
```

The transmit channel IF Frequency should not be changed, unless the transmitter is being converted from one digital IF Frequency to another. The IF Frequency can be changed to 36 MHz or 44 MHz by pushing the Up or Down Arrow. The typical IF Frequency for an ATSC transmitter is 44 MHz. **NOTES:** Changes should only be made while the transmitter is in standby. Contact Axcera Field Service before using this menu.

Table 11.5: Downconverter Main Set Up Menu Screen

```
SET-UP MENUS OF  
DOWNCONVERTER
```


NOTE: This screen is only present when an Axciter is part of the system. This is the System Set Up Downconverter Main Sub Screen. Push the ENTER button to access the Set Up Downconverter submenu or push the LEFT Arrow to go back the

This page has intentionally been left blank.

(Optional) Innovator CXB Series Web Ethernet Interface Kit (1313100)

The Innovator CXB transmitter is available with two optional Ethernet interface packages. Axcera part number (1313100) is the Axcera part number for an Ethernet Interface kit that serves HTML web pages. Axcera part number (1313079) is an Ethernet Interface kit that provides an SNMP interface to transmitter parameters and also serves HTML web pages. Either option may be added to the Innovator CXB transmitter if it was not originally installed at the factory. **NOTE:** Internet Explorer Version 7 or higher is required.

Figure 8: Typical Ethernet User Log In Screen



Once a connection has been established, the web interface can be launched by entering the IP address of the Innovator CXB Ethernet Controller as a URL in the browser of the remote computer. A login screen will be displayed prompting for a user name and password, **which are case sensitive.**

The controller has two levels of user access: Administrative and Read Only. Administrators have full access to transmitter controls and controller configuration. Read Only users can view all transmitter parameters and the event log entries but they can not change the transmitter's state, clear faults, clear the event log or configure the Ethernet parameters.


Five unique login accounts are available. The factory default user name and password for account number one are:

User Name	Password	Access Level
admin	axcera	Administrator

The user name and password of account number one may be reset to factory default values through a setup screen of the transmitter.

After logging in, the main control/monitoring screen is displayed. Administrators have the ability to change the transmitter's operate / standby state, and configure the application. All users have the ability to view the transmitter's event log, and review system parameters. Refer to Figure 9 for a sample main control/monitoring screen.

Figure 9: Typical Ethernet Main Control/Monitoring Screen



Color Key:

- Green = Okay or Normal Operation
- Yellow = Warning, But Not faulted
- Red = Currently Active Fault
- Orange = Old or Previously Latched Fault

If an item on screen is Orange, a latched fault is present. Activating the '**Fault Reset**' button will reset any latched faults, clears the transmitter's event log and causes the parameter to display normally.

The date and time of the last message received by the web page browser is present to assure connectivity. If the browser does not receive a new set of data from the Ethernet Controller, it will show the last update field with a yellow background indicating a connection problem is present.

Access to view the transmitter's event log is available by selecting the '**View Events**' button.

Figure 10: Typical Event Log Screen



Index	Event ID	(Occurance)	Description
1	001 OF 006 (01)		SET TO STANDBY OCCURED 01 HOURS AFTER PRIOR EVENT
2	002 OF 006 (01)		TEST TRAP OCCURED 03 HOURS AFTER PRIOR EVENT
3	003 OF 006 (01)		PROGRAM STARTUP
4	004 OF 006 (01)		AMP 2 OFF-LINE FAULTED 12 SECONDS AFTER PRIOR EVENT
5	005 OF 006 (02)		PROGRAM STARTUP
6	006 OF 006 (01)		AMP 2 OFF-LINE FAULT CLEARED 20 SECONDS AFTER PRIOR EVENT

This screen allows an operator to view events and to determine the time between events. Events are logged in the order they are received. If more than 200 events are detected, the transmitter's System Controller drops the oldest event to record the new event. Transferring of events from the transmitter's System Controller and the Ethernet Controller is scheduled so that device details are continuously monitored. Therefore the event log screen may update a few seconds behind the transmitter display when the log is full or changing quickly.

Each event record indicates the event number, the number of events, an occurrence counter and text describing the event. The occurrence counter keeps track of the number of times a specific event has occurred since the log was last cleared. Up to 99 occurrences are available for each event.

To view the next set of twenty events, activate the '**Next**' button. If viewing events higher in the log, the '**Previous**' button allows you to return to prior events.

From the main page, administrators may change the web interface settings or manage user accounts by activating the '**Configure**' button near the top of the screen.

Figure 11: Ethernet Configuration Screen

The screenshot shows the 'CONFIGURE' screen for the Innovator CXB transmitter. The header includes the Axcera logo, 'SITE ID: Innovator CXB', and 'the rf experts' logo. Below the header are buttons for 'Back' and 'Manage Accounts'. The main content area is titled 'CONFIGURE' and shows the following fields and controls:

- IP Address:** Input field with value '155.226.166.247' and an 'Update' button. Placeholder: (xxx.xxx.xxx.xxx)
- Subnet Mask:** Input field with value '255.255.240.000' and an 'Update' button. Placeholder: (xxx.xxx.xxx.xxx)
- Gateway:** Input field with value '155.226.166.001' and an 'Update' button. Placeholder: (xxx.xxx.xxx.xxx)
- Site ID:** Input field with value 'Innovator CXB' and an 'Update' button. Placeholder: (Up to 40 characters)
- SNMP Trap Destination 1:** Input field with value '155.226.166.240' and an 'Update' button. Placeholder: (xxx.xxx.xxx.xxx)
- SNMP Trap Destination 2:** Input field with value '000.000.000.000' and an 'Update' button. Placeholder: (xxx.xxx.xxx.xxx)
- Send Test Trap:** A button located below the SNMP trap destination fields.
- Target Power Level: (%)** Input field with value '0' and a 'Set Power' button. Placeholder: Currently at 0 %. Set (0-100)

When entering a site ID, be sure to not use special characters except underscores, dashes, and forward slashes. Changes to the transmitter's output power are available to administrators when the transmitter is operating. Once changed, the menu defaults back to the main display page and the systems forward power is noted as changing.

The screen above displays SNMP parameters and allows an operator to send a test trap. If this system did not have SNMP enabled, then fields would not be populated and the '**Send Test Trap**' button would not be present. New event log entries including an activated test trap are automatically forwarded to SNMP agents specified to receive trap messages. Trap messages do not need to be acknowledged by an agent.

The ability to reset a demodulator is only present in transmitters that have this hardware and when the installed software versions allow for this feature. Resetting a demodulator is only recommended if the tuner has lost input signal lock as this function will take the transmitter off-air for a few seconds.

NOTE: The Innovator CXB controller does not use DHCP addresses – TCP/IP settings must be fixed and entered manually. A crossover cable may be needed if connecting directly from a computer to the Innovator CXB Transmitter.

To manage user accounts, click the 'Manage Accounts' button near the top of the configure screen.

Figure 12: Typical Manage Accounts Screen



Acc. Number	User Name	Password	Administrator		
1	admin	axcera	yes	Add/Change	Delete
2	nobody	none	no	Add/Change	Delete
3	nobody	none	no	Add/Change	Delete
4	nobody	none	no	Add/Change	Delete
5	nobody	none	no	Add/Change	Delete

Do not use spaces or special characters

The Innovator CXB Ethernet controller supports up to 5 different user accounts. To add or change one of the accounts, click the Add/Change button in the row of the account you want to modify, then enter the desired name, password, and administrator rights for the user and click save.

NOTE: The transmitter's set up menus contain a Reset Ethernet User ID screen. This screen allows a user to reset the first account User Name and Password. The Yes or No selection can be changed by pushing the Up or Down Button. After the selection has been made, the user needs to depress the right or left arrow and then the display will ask "PUSH ENTER TO ACCEPT CHANGES". If the ENTER button is depressed, the change will be accepted. If any other button is depressed, the change will not be made. If Yes is selected on the screen, and accepted, the User name and Password will reset to the factory default of admin / axcera.

Activate the '**Back**' button to return to the main control/monitoring screen.

When you have completed using the web interface, please remember to log out via the '**logout**' button at the top of the control/monitoring screen.

(Optional) Innovator CXB Series SNMP Ethernet Interface (1313079)

NOTE: The Innovator CXB Series SNMP Ethernet Interface (1313079) includes the Web Ethernet Interface described in the previous section of this manual. These interfaces may not be part of your system. **NOTE:** Internet Explorer Version 7 or higher is required.

The Innovator CXB Ethernet Controller is available in a version that implements Simple Network Management Protocol (SNMP). SNMP is a standardized method of transferring information from one electronic device to another. SNMP is typically used to remotely control and monitor several transmitter devices from a centralized network management system (NMS). SNMP is a communication method between two applications and is not a graphical user interface. Therefore, SNMP functionality is included along with web page server functionality. SNMP is used to gather information or set control states but it requires additional computer applications for operator monitoring and control.

The Innovator CXB Ethernet Controller implements SNMP version 2 (SNMP v2) using a Management Information Base (MIB). The MIB file defines all SNMP parameters of the transmitter, specifies the format of data, and orders the presentation of the parameters using a hierarchical namespace containing object identifiers (OID). Each OID identifies a variable that can be read, read and set, or only set via SNMP commands.

SNMP functionality also provides for alert messages that are issued from the Ethernet Controller to one or two network computers. A SNMP trap message is sent only once and is not acknowledged by the receiving device. The Ethernet Controller issues a trap message when data is added to the transmitter Event log (either activation of a fault or when a fault is cleared), or when the transmitter operate/standby status changes.

SNMP Configuration

The Ethernet Controller's TCP/IP Address, Subnet Mask, and Gateway must be configured with static values that are valid within your network. Dynamic Host Configuration Protocol (DHCP) is not implemented; however access to these configuration parameters is available through the front panel setup menus of the Innovator CXB.

The Innovator CXB's SNMP MIB allows up to two SNMP trap destinations. The trap destination values can be set through WEB pages. The TCP/IP address of a trap processing computer can also be configured through the SNMP parameters called 'site_trap_adr1' and 'site_trap_adr2'. To clear a previously configured trap destination and cause the system not to issue traps to a specific address, set the value to '000.000.000.000'.

Reading of SNMP values is done with the message's community access set to 'public'. When setting SNMP values, a default community access level of 'private' is used. Future implementations of the Ethernet SNMP agent may allow for the set community access level to be defined through the device's web server.

Circuit Descriptions of Boards in the CU0TD/RD-1 thru CU0TD/RD-5 Systems

(A1) 8 VSB Demodulator Board (1308275)

NOTE: Only used with RD operation except when the output of an external K-Tech Receiver Drawer is used.

Overview

The 8 VSB demodulator assembly receives an off air 8 VSB signal on any VHF or UHF channel and demodulates this to an MPEG-2 transport stream that is per the SMPTE-310M standard. The input to the assembly is at an "F" style connector on the shielded tuner and can be at a level of -8 to -78 dBm. The tuner (TU1) down converts the RF channel to a 44 MHz IF signal. This signal is the input to the digital receiver chip U1. The digital receiver chip subsequently decodes the IF and delivers an MPEG-2 transport stream on a parallel data bus to a programmable logic array, U8. U8 clocks the asynchronous MPEG data from the receiver chip and outputs a synchronous data stream at a 19.39 MHz rate to buffer/driver U11. U11 subsequently drives the output at J13 to a lower level that is AC coupled out of the board.

Microcontroller Functions

A microcontroller, U17, is provided on this assembly to supervise the operation of the receiver chip and the tuner. In addition, the microcontroller also interfaces to the front panel LCD display via connector J24 and pushbutton interface on J27. On power up, the microcontroller sets the tuner to the last channel that was selected when the unit was powered down. In addition, the microcontroller also configures the digital receiver to operate as an 8 VSB receiver. The communication between all of the devices on this board is via an I2C serial bus that is local to this board.

Jumper and DIP Switch Settings

This board can be used in various assemblies. When this assembly is installed in the Innovator CXB product, the jumpers on J7 and J8 should be placed between pins 2 and 3 for normal operation. The DIP switch SW1 should be configured as indicated in Table 12.

Table 12: Innovator CX Receive /Demodulator/Transcoder Dip Switch SW1

Position	Function	When Switch is Off	When Switch is On
SW1-1	Tuner Type	Original Tuner (DTT765xx)	Recent Tuner (DTT7680x)
SW1-2	Signal Strength Gain	Gain = 8.0	Gain = 9.3
SW1-3	Special Channel Plan	Normal	Channels 2, 3, or 4 are offset up 4 MHz
SW1-4	Reserved for Future		
SW1-5	Reserved for Future		
SW1-6	Reserved for Future		
SW1-7	Reserved for Future		
SW1-8	Operation Type	Transcoder Operation	Innovator CX/CXB Operation

NOTES: SW1-8 operation is available in software versions greater than or equal to 2.3 with hardware versions greater than or equal to D0, unless the board was factory modified.

These switch positions are factory set for your system and should not be changed.

(A2) Digital Modulator (1316332)

SMPTE-310 or ASI input

The digital modulator board accepts a SMPTE-310 or ASI input at the SMA connector J42 from the 8 VSB demodulator board in a RD system or directly from the RF input jack on the rear panel of the drawer in a TD system. This input is applied to a high speed window comparator U21 that adjusts the level to a low voltage TTL signal to be used by the Altera FPGA, U3. The SMPTE-310 signal is input to the FPGA to recover the clock and the data. A portion of the clock and recovery circuit is performed by a high-speed comparator, U17, which functions as an external delay circuit.

Channel Coder

The FPGA subsequently uses the SMPTE-310 clock and data as the input to the channel coder contained inside the FPGA. The channel coder is a series of DSP blocks defined by the ATSC standard for 8 VSB data transmission. These blocks include the data randomizer, Reed Solomon Encoder, data interleaver, trellis coder, and sync inserter.

The channel coder portion inside the FPGA generates the 8 distinct levels in an 8 VSB system. These levels are subsequently input to a linear equalizer that provides for frequency response correction in the transmission path. The linear equalizer is a 67 tap FIR filter that is loaded with tap values from the microcontroller, U1, located on this board. The output of the linear equalizer is then input to two pulse shaping filters, an in phase (I) and a quadrature (Q) filter that are also located inside the FPGA. The pulse shaping filters are FIR filters that have fixed tap values that are preset inside the FPGA. The output of the pulse shaping filters is then applied to a Pre-Distortion Linearizer chip, U4, which can be used to correct for nonlinearities in the data transmission path. The output of the Pre-Distortion chip is gain scaled and output to a dual D/A converter, which output a baseband I and Q analog signal.

Analog Output Section

The baseband I and Q signals from the D/A converter are applied to differential analog filters that remove some of digital artifacts from the D/A conversion process. The output of the I channel filter is then mixed with the pilot frequency, 46.69 MHz, using mixer U30. The output of the Q filter is mixed with the pilot frequency that is phase shifted 90 degrees using mixer U34. The mixers are current driven devices, therefore when the outputs of U30 and U34 are connected together, they provide a combined output. This combined output is subsequently input to a final differential output filter which provides the final RF output at the SMA connector, J38. To maintain signal integrity, this RF output is connected to the SMA connector J39 with a small semi-rigid cable assembly. The final RF output then appears at J1-2B.

Pilot Frequency Generation

The on channel pilot, which is used in the mixing process, is generated from a VCXO, U37 that is phase locked to a 10 MHz reference. The VCXO and the 10

MHz are divided down to a common frequency, which is then compared internal to the FPGA. The FPGA subsequently provides error signals to an analog phase locked implemented with op amp stages U45-A, B and C. The output of these compensation stages is used as the control voltage to the VCXO, U37. The phase locked output of U37 is applied to an analog filter to remove harmonics of the pilot and then input to the quadrature splitter Z1. The outputs of Z1 are used as the inputs to the mixers in the analog output section.

Voltage Requirements

The ± 12 VDC and +5VDC needed for operation of the board connect to J1 on the Power Conditioner Board (1309404) which delays the +5VDC so that the ± 12 VDC to the 8 VSB Modulator Board is applied first. The voltage output of the power conditioner board is at J2 that is jumpered to J30 on the 8 VSB modulator board.

The ± 12 VDC connect to the 8 VSB modulator board at J30-1. The +12V SYS connects to J18A, B & C and to regulator circuits. The +12V SYS is filtered by L2, L3, C105 and C106 before it is applied to the rest of the board as +12VQ and +12VI. The -12 VDC SYS connects to J19A, B & C and to regulator circuit. The -12V SYS is filtered by L6, L7, C111 and C112 before it is applied to the rest of the board as -12VI and -12VQ.

The +12V SYS also connects through the resistor R81 to provide +5V EXT to the rest of the board, and to the regulators U23 that provides +3.3V to the rest of the board and to U27 that provides +1.8V output. The +3.3V also connects to U24 that supplies +1.5V output. The +12V SYS connects to the regulator U25 and U26 to supply the +5VA output. The output of U25 also connects to U28, which provides the +5V output to the rest of the board. +12V SYS is filtered by L4 and C107 to provide the +12V output to the board. The -12V SYS also connects to the regulator U22 that provides the -5V VA to the rest of the board. -12V SYS is filtered by L5 and C108 to provide the -12V output to the board.

(A5) ALC Board, Innovator CX Series (1315006 or 1308570)

The ALC Board, Innovator CX Series, is used to control the RF drive power to the RF amplifier chain in the CU0TD/RD-1 thru CU0TD/RD-5 systems. The board accepts an 8-VSB RF input signal at a nominal input level of -3 dBm average power and amplifies it to whatever drive level is necessary to drive the final RF amplifier in the drawer to full power. The input signal to the board at J1 is split by U4, with one half of the signal driving a PIN diode attenuator, DS1 and DS2, and the other half driving a detector, U13, that is used to mute the PIN attenuator when there is no input signal. The output of the PIN attenuator is sent to two cascaded amplifiers, U2 and U3, which are capable of generating +10 dBm average power from the board at J2.

The PIN attenuator is driven by an ALC circuit or by a manual fixed voltage bias, depending on the position of switch S1. When the switch is pointing to the left, looking from the front of the drawer, the ALC circuit is enabled. When the switch is pointing to the right, the ALC circuit is disabled and the PIN attenuator is controlled through the Manual gain pot R62. When the switch is in either ALC or manual, the voltage in the unused circuit is preset low by the circuitry connected to pins 4-6 on SW1. This allows the RF power to ramp up slowly to full power when the switch changes positions. CR8, C33 and associated components control the ramp up speed of the manual gain circuit.

CR9, C42 and their associated circuits do the same thing for the ALC circuit. The practical effect of this is to preset the RF drive power to near zero output power when enabling and disabling the ALC, followed by a slow controlled ramp up of power.


The ALC circuit normally attempts to hold the drawer output power constant, but there are four faults that can override this. These faults are Input Fault, VSWR Cutback Fault, VSWR Shutdown Fault and Overdrive Fault.

The Input Fault is generated by comparator U7C and presets the PIN attenuator and ALC circuit to maximum attenuation whenever the input signal drops below about -7 dBm. Test point TP2 allows the user to measure the detected input voltage.

The VSWR cutback circuit is set so that the ALC circuit will start reducing RF drive once the Reflected power reaches a level of about 6% and will keep reducing the drive to maintain that level. The cutback is generated by U8A, U8B and their associated components that diode-or the metering voltages. The forward power is scaled to $2V = 100\%$ and the reflected power is scaled to $2V = 25\%$. The Reflected metering voltage is doubled again by U8B so that when the voltage of U8B exceeds the voltage at the output of U8A, the reflected power takes over the ALC circuit. Once the U8B voltage drops below the forward power at U8A, the forward power takes over again.

The VSWR shutdown circuit will shut the drawer down if the Reflected power increases to 15% or higher, which can happen if the drawer sees reflected power when the ALC is in manual.

The Overdrive protection looks at a sample of the RF signal that is applied to J1 of the board. The peak level of this signal is detected and can be measured on TP1. This voltage is applied to a comparator with the threshold set by R38. If this threshold is exceeded, the ALC circuit mutes then ramps up to try again. This circuit also works in manual gain as well.



NOTE: There are a number of different (A6) Amplifier Assemblies used in the multiple CX transmitter and driver drawers. They are listed in the following sections. Use the assembly that applies to your particular driver or transmitter or translator.

(A6) Amplifier Assembly (1309621) – Used in the CU0TD/RD-1

The (A6) Amplifier Assembly (1309621) is made up of (A6-A1) the 2 Stage UHF Amplifier Board, 24V (1309608). The assembly has approximately 33 dB of gain.

(A6-A1) 2 Stage UHF Amplifier Board, 24V (1309608)

The 2 Stage UHF Amplifier Board, 24V (1309608) consists of a driver stage with a gain of +14dB and two parallel connected final amplifier stages each with a gain of +14dB. The working point settings for the 2 Stage Amplifier Board are factory set using the potentiometers R32 for Q2, R15 for Q1, and R24 for Q3 and should not be altered. The input RF connects to the first amplifier stage Q2. The output is split by U2 and connected to the final amps. The final amplification circuit consists of parallel-connected push-pull LDMOS amplifier circuits Q1 and Q3 operating in class AB each with approximately 14 dB of gain. The board uses a power supply voltage of 24V. The RF transistors are operated at a voltage of 24V generated by the voltage regulators U6 and U7 for Q2, U5 and U3 for Q3 and U1 and U3 for Q1, which provide a separate regulated voltage to each transistor. In order to match the LDMOS impedance to the characteristic impedance of the input and output sides, matching networks are located before and after the amplifier circuits. The hybrid coupler U2 splits the input to the parallel amplifiers and the hybrid coupler U4 combines the amplified outputs. The combined output connects through a directional coupler to J1, the RF output jack of the board. The directional coupler provides an RF sample at J3 that is used by an external overdrive protection circuit located on (A5) the ALC Board. The RF output of the board is 6W maximum 8-VSB. At this power level the board draws approximately 3.6A total from the power supply.

(A6) Amplifier Assembly (1315008 used w/External Exciter Drawer or 1312566 used in all other applications) – Used in the CU0TD/RD-2 and CU0TD/RD-3

The (A6) Amplifier Assembly (1312566 or 1315008) is made up of (A6-A1) the 2 Stage UHF Amplifier Board (1308784) and (A6-A2) the RF Module Pallet, Philips, High Output (1309580). The ALC Board (1308570 is used in the 1312566 Assembly & the 1315006 is used in the 1315008 Assembly) is also part of this assembly. The assembly has approximately 36 dB of gain.

(A6-A1) 2 Stage UHF Amplifier Board (1308784)

The 2 Stage UHF Amplifier Board, (1308784) consists of a driver stage and a parallel connected final amplifier stage which have a total gain of approximately 23 dB. The working point settings for the 2 Stage Amplifier Board are factory set using the potentiometers R32 for Q2, R15 for Q1, and R24 for Q3 and should not be altered. The input RF connects to the first amplifier stage U2, which has a gain of approximately 14 dB. The output is split by U2 and connected to the final amps. The final amplification circuit consists of parallel-connected push-pull LDMOS amplifier circuits Q1 and Q3 operating in class AB each with approximately 14 dB of gain. The board uses a power supply voltage of 28-32V. The RF transistors are operated at a voltage of 24V generated by the voltage regulators U1 for Q1, U5 for Q3 and U6 for Q2, which provide a separate regulated voltage to each transistor. In order to match the LDMOS impedance to the characteristic impedance of the input and output sides, matching networks

are located before and after the amplifier circuits. The hybrid coupler U2 splits the input to the parallel amplifiers and the hybrid coupler U4 combines the amplified outputs. The combined output connects through a directional coupler to J1, the RF output jack of the board. The directional coupler provides an RF sample at J3 that is used by an external overdrive protection circuit located on (A5) the ALC Board. The RF output of the board is being used as a driver and has a level of 3W maximum 8-VSB. At this power level the board draws approximately 1.8A total from the power supply.

(A6-A2) RF Module Pallet, Philips, High Output (1309580)

The RF Module Pallet, Philips, High Output, (1309580) is made from the RF Module Pallet, High Output w/o Transistors (1309579). This broadband amplifier is for the frequency range of 470 to 860 MHz. The amplifier is capable of delivering a maximum output power of 100 Watts peak, with an amplification factor of approximately 13 dB.

The amplification circuit consists of push-pull amplifier blocks V1 and V2, connected in parallel, operating in class AB. In order to match the impedance of the transistors to the characteristic impedance of the input and output sides, matching networks are placed ahead and behind the amplifier blocks. Transformers Z3 and Z4 at the input to V1 and V2 and Z5 and Z6 at the output of V1 and V2 serve to balance the input and output signals. The paralleling circuit is achieved using the 3-dB input coupler Z1 and the second part of Z1, which is the 3-dB output coupler. The working point settings of the amplifier circuits are factory implemented by means of the potentiometers R11 and R12 and should not be altered. The combined output of Z1 connects to the RF output jack of the board at J2. The output of the amplifier assembly at J2 connects to J1 on (A7) the output detector board.

(A6) Amplifier Assembly w/878 devices (1312191) – Used in the CU0TD/RD-4 & CU0TD/RD-5

The (A6) Amplifier Assembly (1312191) is made up of (A6-A1) the 1 Watt Amplifier Board (1310282), (A6-A2) the BL871 Single Stage Amplifier Board (1311041), and (A6-A3) the Dual 878 Pallet Assembly (1313170 or 1310138). The ALC Board (1308570) is also used with this assembly. The entire amplifier assembly has approximately 36 dB of gain.

(A6-A1) 1 Watt UHF Amplifier Module (1310282)

This board is a broadband UHF amplifier capable of producing an output power in excess of 1W Peak. It is normally operated at an average power of 100 mW 8VSB or lower. It consists of two AH202 MMICs operating in parallel. The board is powered by +12 VDC and has no adjustments. The board has a gain of approximately 16 dB.

(A6-A2) BL871 Single Stage Amplifier Board (1311041)

This board consists of a single stage amplifier operating at +42 VDC. The board has an overall gain of about 16 dB. The input to the board passes through a 3 dB attenuator consisting of R11-R13, and then is applied to the gain stage, which consists of a single LDMOS transistor Q1 operating in Class AB. The bias voltage for the transistor is generated through the voltage regulator U1, and is adjusted

using pots R2 and R3. The Diode CR1 provides temperature compensation for the transistor. The transistor will output over 20 Watts DVB, but is typically used in a driver application at much lower output powers. The Directional Coupler U1 provides a 20 dB down sample of the RF output.

(A6-A3) Dual 878 Pallet Assembly (1313170 or 1310138)

This board is a LDMOS UHF power amplifier consisting of two power transistors operating in parallel. The board operates on a power supply voltage of +42 VDC. The voltage regulator U1 steps down the voltage to provide a bias voltage to each transistor. The diodes CR1 and CR3 are used to temperature compensate the bias voltage. As the RF transistors heat up, the diodes also heat up, causing the voltage across them to drop, lowering the bias voltage to the RF transistors so that it remains constant with device temperature.

The board has a gain of approximately 17 dB, and can operate at an output power of 150 Watts average power DVB, 220 Watts average power ATSC, or 440 Watts Peak Sync plus sound in analog operation. The transistors are operated in quadrature, with one transistor operating 90 degrees out of phase of the other, which provides for a very good return loss across the UHF band on both the input and output of the board.

(A6) Amplifier Assembly w/888A devices (1316132 used w/External Axciter Drawer or 1315381 used in all other applications) – Used in the CU0TD/RD-4 & CU0TD/RD-5

The (A6) Amplifier Assembly (1316132) is made up of (A6-A1) the 1 Watt Amplifier Board (1315730), (A6-A2) the BL881 Single Stage Amplifier Board (1314882), (A6-A3) the Dual 888A Pallet Assembly (1315347) and (A6-A5) a DC-DC Converter Board (1315335). The ALC Board (The ALC Board (1308570 is used in the 1315381 Assembly & the 1315006 is used in the 1316132 Assembly) is also used with this assembly. The entire amplifier assembly has approximately 36 dB of gain.

(A6-A1) 1 Watt UHF Amplifier Module (1315730)

This board is normally operated at a power of 200 mW pk sync or lower. It consists of two AH202 MMICs operating in parallel. The board is powered by +12 VDC and has no adjustments. The amplifier module has a gain of approximately 17 dB.

(A6-A2) BLF881 Single Stage Amplifier Board (1314882)

This board consists of a single stage amplifier operating at +48 VDC. The board has an overall gain of about 16 dB. The input to the board passes through a 3 dB attenuator consisting of R11-R13, and then is applied to the gain stage, which consists of a single LDMOS transistor Q1 operating in Class AB. The bias voltage for the transistor is generated through the voltage regulator U1, and is adjusted using pots R2 and R3. The Diode CR1 provides temperature compensation for the transistor. The transistor will output over 40 Watts pk sync, but is typically used in a driver application at much lower output powers. The Directional Coupler U2 provides a 20 dB down sample of the RF output at the SMA Jack J4.

(A6-A3) Dual BLF888A Pallet Assembly (1315347)

This board is a UHF LDMOS power amplifier consisting of two pair of power transistors operating in parallel. The board operates on a power supply voltage of +48VDC. The voltage regulator U1 steps down the voltage to provide a bias voltage to each pair of transistors. The diodes CR1 and CR3 are used to temperature compensate the bias voltage that is applied to the Q1 and Q2 RF transistor pairs. As the transistor pairs heat up, the diodes also heat up, causing the voltage across them to drop, lowering the bias voltage to the RF transistors so that the voltage remains constant with device temperature.

The board has a gain of approximately 18 dB. The RF input to the board is split by HL1 and each output is connected through hybrid couplers to the Q1 and Q2 transistor pairs. The amplified outputs of the transistor pairs are connected through hybrid couplers to the combiner HL2. The transistor pairs are operated in quadrature, with one transistor pair operating 90° out of phase of the other, which provides for a very good return loss across the UHF band on both the input and output of the board.

(A6-A5) DC/DC Converter Board (1315335)

The DC/DC Converter Board provides the +12VDC needed to operate the 1 Watt Amplifier board in the assembly. The DC/DC Converter Board acts as a switching supply using U7 and the Q1 MOSFET. The switching voltage is applied to the primary of the T1 Transformer. The AC output of the transformer is rectified by CR1 and filtered before the +12 VDC is connected to the output of the board at J3-3. A feedback path is provided through the other two coils of the transformer which is fed to the IC U7 to maintain the oscillation.

(A7) Output Detector Board (1308685 or 1312207 in the CU0TD/RD-2 thru CU0TD/RD-5)

The (1308685 and 1312207) output detector boards are identical in operation except the (1312207) board can be used as either an average, for digital, or peak, for analog, detector board using jumpers on J5 and J6. The (A7) Output Detector Board provides forward (2V=100%) and reflected (2V=25%) power samples to the CU Control Board for metering and monitoring purposes. R7 is the reflected power calibration pot and R23 is the forward power calibration pot. A Forward power sample, -10 dBm, connects to J4 on the board, which is cabled to the front panel sample jack of the drawer. The RF output of the board, typically +46 dBm, is at J2, which is cabled to J9 the RF Output Jack of the drawer.

(A8) Control Card, Innovator CX (1312543)

The Innovator CX control board provides the overall system control for the CXB system. There are two main elements of the board, U7 and U9. U7 is a programmable logic device that is loaded with firmware, which provides the overall system control. It decides whether or not to allow the system to generate RF output power, and turns the +32 VDC power supply on and off depending on whether or not it is receiving any faults, either faults generated on board, or faults generated externally. The second major component of the board is the microcontroller U9, which controls the front panel indications and drives the display. The U9 microcontroller is not involved in the decision

making process, U7 does that. Rather, it is layered on top of U7 and is the EPLD's interface to the outside world. Information is passed between the microcontroller and the EPLD. The microcontroller communicates information to and from the front panel and sends the EPLD the information it needs to decide whether or not to allow the system to turn on. The front panel viewable LEDs DS3 for Operate/Standby and DS4 for Status indicate the current operating condition of the system are mounted on and controlled by this board. The U9 microcontroller can also communicate, using the Optional Ethernet Kit, with a daughter card that allows the user to view remote control parameters via a web Ethernet interface.

The ± 12 VDC and +5 VDC from the (A9) power supply and the +32 VDC from the (A10) power supply are routed to the other boards in the drawer through this board. The +32 VDC power supply operates all the time, and connects the +32 VDC to the board at J19-1, 2, & 3 with 5 common. Q13 on the control board is turned on and off to gate the +32 VDC, which connects through J19-6, 7 & 8, to the RF output stages.

The ± 12 VDC and +5 VDC input voltages to this board is connected through J21 and filtered before being connected to the rest of the board. +12 VDC connects through J21-1, +5VDC through J21-2 & 3, and -12 VDC through J21-6. Common connections for the input voltages are connected to J21-4 & 5. The ± 12 VDC and +5 VDC are used on this board and also routed to the other boards in the drawer through this board. The +3.3 VDC for the microcontroller and programmable logic array, mounted on the board, is provided by the voltage regulator IC U6 from the filtered +5 VDC input. The output of U6 can be adjusted to +3.3 VDC using R120.

(A9 & A10) Power Supplies used in CU0TD/RD-1 thru CU0TD/RD-5 and Driver for CU1TD/RD-1 & higher power

Table 13: Model Number with corresponding (A10) Voltages and AC Input Voltages

MODEL	(A10) POWER SUPPLY VOLTAGE	AC INPUT VOLTAGE
CU0TD/RD-1	+24VDC	115VAC or 230VAC
CU0TD/RD-2	+28VDC	115VAC or 230VAC
CU0TD/RD-3	+30VDC	115VAC or 230VAC
CU0TD/RD-4	+42VDC w/878A or +48VDC w/888A	230VAC
CU0TD/RD-5	+42VDC w/878A or +48VDC w/888A	230VAC

Voltages for the operation of the boards in the drawer are generated by (A9) a +5VDC and ± 12 VDC power supply and (A10) a switching power supply which is a different power supply providing a different voltage in each model. See the chart above. The 115VAC or 230VAC input to the CU0TD/RD-1 thru CU0TD/RD-3 drawer connects through the AC power cord at J6, the power entry module located on the rear panel of the drawer.

The CU0TD/RD-4 & CU0TD/RD-5 drawer only operates with 230VAC. An On/Off 10A/250VAC circuit breaker is part of the power entry module. With the circuit breaker switched On, the (L) line input is wired to F1 a 10 Amp fuse for over current protection. The AC lines are connected to terminal block TB1, which distributes the AC to (A9 and A10) the two DC power supplies. There are two varistors, mounted on TB1, connected from the line input to neutral and to ground for surge protection. The AC in the CU0TD/RD-4 & CU0TD/RD-5 also connects to the (A11) fan mounted on the rear panel of the drawer. The fan will run when AC is applied to the drawer and the circuit breaker is switched On. The +5VDC and ± 12 VDC outputs of the (A9) power supply connects to the terminal block (TB2) that distributes the DC to the boards in the drawer. Some of

the +5VDC and ± 12 VDC outputs connect directly to the 8 VSB Demodulator and 8 VSB Modulator boards while the other outputs connect through the CU Control Board to the IF Precorrector, the Digital Upconverter, the ALC, the Amplifier Assembly and the Output Detector Boards.

The +24/+28/+30/+42/+48VDC VDC outputs of the (A10) power supply connect to the (A8) CU Control Board, which then supplies the switched +24/+28/+30/+42/+48VDC VDC to the (A6) Amplifier Assembly. In CU0TD/RD-1 thru CU0TD/RD-3 drawers the DC output of the (A10) power supply also connects to the (A11) fan mounted on the rear panel, which will operate when AC is applied to the drawer, the On/Off circuit breaker is On and the (A10) power supply is operating.

Circuit Description of External System Metering Board which is only used in Transmitters with multiple external Amplifier Drawers

(A5) System Metering Board (1312666)

The function of the System Metering Board is to detect forward and reflected output power samples and generate output voltages that are proportional to the power levels of the sampled signals for use by the control monitoring assembly in the exciter/driver drawer.

There are two identical signal paths on the board: one for forward power and one for reflected power. A sample of the forward output power, from the external (A11) output coupler, enters the board at the SMA jack J3. The signal is filtered and connected to resistors R5, R3 and R6 that form an input impedance-matching network to Pin 3 on U1. The forward power signal is detected by the RF detector IC U1. The detected output at pin 7 is split with one half connected to the forward average calibration pot R7, digital, which adjusts the level of the signal connected to Pin 11 on U2. The other half of the split is connected to the peak calibration pot R18, analog, which adjusts the level of the signal connected to Pin 8 on U2. U2 is a Bilateral Switch IC whose output, digital or analog, is controlled by the selection of the modulation type in the exciter/driver drawer. In this BTC transmitter the average, digital, output connects to the amplifier IC U3A that is wired to the SYS_FWD and RMT_FWD Power Metering Outputs. A reading of 2 VDC measured at TP1 is equal to a 100% Forward Power reading on the meter. The SYS_FWD level connects to J9 on the board that is cabled to J11 on the exciter/driver drawer for use in the control monitoring assembly. The RMT_FWD level connects to J10 on the board for use by remote control and monitoring.


A sample of the reflected output power, from the external (A11) output coupler, enters the board at the SMA jack J8. The signal is filtered and connected to resistors R26, R22 and R27 that form an input impedance-matching network to Pin 3 on U6. The reflected power signal is detected by the RF detector IC U6. The detected output at pin 7 is connected to the reflected calibration pot R25, which adjusts the level of the signal connected to the amplifier IC U3B that is wired to the SYS_RFLD and RMT_RFLD Power Metering Outputs. A reading of 2 VDC measured at TP2 is equal to a 25% Reflected Power reading on the meter. The SYS_RFLD level connects to J9 on the board that is cabled to J11 on the exciter/driver drawer for use in the control monitoring assembly. The RMT_RFLD level connects to J10 on the board for use by remote control and monitoring.

+12 VDC enters the board at J9-1, from the exciter/driver drawer and is connected through a filter and isolation circuit consisting of C31, C14 and L5 before it is connected to the regulator IC U5. U5 supplies the +5 VDC needed for operation of the ICs on the

board. The +5 VDC is connected through a filter circuit consisting of C15, C19 and C21 before it is connected to the rest of the board.

Circuit Descriptions of Boards in the external ATSC Amplifier Drawers

(A7) Amplifier Control Board (1315011 or 1312260)



Amplifier Control Board

The Amplifier Control Board is mounted in the top front facing the rear of the Amplifier Drawer as shown above.

The Amplifier Control Board uses a Programmable logic device, U12, to control the amplifier drawer. It takes an enable signal from an external driver drawer, and turns the power supplies on whenever the driver has told it to turn on, unless it detects faults internal to the drawer. The board monitors the forward and reflected power, the heatsink temperature, the pallet currents, and the power supply voltage and will generate alarm signals if any of those parameters exceed safe limits. The amplifier drawer has no front panel display other than a two LEDs, one for Status and one for Enable. The board sends all its output information, including the forward and reflected levels, back to the driver drawer, through J4, so the information can be displayed on that drawer's LCD Display. The board will generate a Red Blinking Status LED if it detects an alarm, fault, prompting the operator to look at the LCD display on the driver drawer to see what fault has occurred.

A CUB transmitter System can have up to 4 external amplifier drawers and since they are all the same, without differences in the wiring harness, there needs to be a way to identify which amplifier drawer is which. The rotary switch SW1 is used to specify the amplifier ID number which generates a unique serial address so that the individual amplifier drawers will respond when polled for information.

The +5 VDC inputs to this board are routed through J4-8 and J5-8. The +5 VDC inputs are diode Or connected so that either the +5VDC from the (A8) power supply or the +5VDC from the (A9) power supply will operate the board. The +5VDC is split with one output connected to U1 a voltage regulator IC, which provides +5V and +5V_ANALOG as outputs. The +5 VDC is filtered before being connected to the rest of the board. The other +5 VDC output is connected to the regulator IC U2 that supplies +3.3 V to the microcontroller and programmable logic array.

(A10) Current Metering Board (1309130)

The current metering board measures the current into the RF output amplifier pallets and supplies this value to the control board. In the single pallet amplifier drawer, there are two sensing circuits which are used. In the multiple pallet amplifier drawer, there are four sensing circuits which are used. Each circuit has two parallel .01Ω series current sensing resistors and a differential input IC that supplies a voltage output that is proportional to the current for metering purposes. The +42VDC from the (A8) power

supply connects to TB2 and TB4 on the board. The +42VDC from the (A9) power supply connects to TB8 and TB10 on the board. The +42VDC input at the TB2 input senses the current to the (A1) 878 output amplifier pallet through TB1 on the board. The +42VDC input at the TB4 input senses the current to the (A2) 878 output amplifier pallet through TB3 on the board. The +42VDC input at the TB8 input senses the current to the (A3) 878 output amplifier pallet through TB7 on the board. The +42VDC input at the TB10 input senses the current to the (A4) 878 output amplifier pallet through TB9 on the board.

The two or four sensing circuits are identical therefore only one will be described. For the (A1) 878 amplifier pallet, the +42VDC from the (A8) switching power supply connects to TB2. R1 and R2 are the parallel .01Ω current sensing resistors which supplies the voltage values to the U1 current sense amplifier IC. R11 is a gain adjust, which is adjusted to eliminate any rSense Error and to place the OpAmp output at 2.61V for 40Amps sense as measured at TP3. The current sense output at J1-1 connects to the (A7) control board for metering purposes.

(A5) 2 Way Splitter Board (1313158), in Amplifier Drawer w/two Dual 888A Pallets

The 2 way splitter board takes the RF Input at J1 (≈12.5 Watts ATSC) on the board and splits it into two equal outputs (≈5Watts ATSC) that connect to the inputs of the two 878 amplifier pallets at J1.

(A5) 4 Way Splitter Board (1308933), in multiple pallet amplifier drawer

The 4 way splitter board takes the RF Input at J1 (≈11Watts ATSC) on the board and splits it into four equal outputs (≈4.75Watts ATSC) that connect to the inputs of the four 878 amplifier pallets at J1.

(A1-A4) 878A Amplifier Pallets (1314098, 1313170 or 1310138)

There are two 878 Amplifier Pallets mounted on the two pallet Amplifier Heatsink Assembly and there are four 878A Amplifier Pallets mounted on the four pallet Amplifier Heatsink Assembly. Each of the 878A pallets has approximately +16dB of gain for the UHF frequency range of 470 to 860 MHz. The pallets operate Class AB and generate 150 Watts ATSC with an input of 4.75 Watts ATSC.

Or (A1-A2) Dual 888A Amplifier Pallets (1314173) Used in two pallet Amplifier Drawer (CB005715)

There are two 888A Amplifier Pallets mounted on the two pallet Amplifier Heatsink Assembly. Each of the 888A pallets has approximately +16dB of gain for the UHF frequency range of 470 to 860 MHz. The pallets operate Class AB.

(A1-A4) 888A Amplifier Pallets (1315347) Used in three pallet Amplifier Drawers

There are four 888A Amplifier Pallets mounted on the Amplifier Heatsink Assembly. Each of the 888A pallets has approximately +15dB of gain for the UHF frequency range

of 470 to 860 MHz. The pallets operate Class AB and generate approximately 230 Watts ATSC with an input of 8 Watts ATSC.

(A6) 2 Way Combiner Board (1313155), in amplifier drawer w/two Dual 888A Pallets

The 2 way combiner board takes the two RF Inputs at J4 & J5 (≈ 230 Watts ATSC) on the board and combines them to a single output (≈ 375 Watts) at J1 that connects to J2 the 7/16" (1.1cm) Din RF output jack of the drawer.

(A6) 4 Way Combiner Board (1312368), in two pallet amplifier drawer

The 4 way combiner board takes the four RF Inputs at J4, J5, J6 & J7 (≈ 150 Watts ATSC) on the board and combines them to a single output (≈ 500 Watts/600Watts) at J1 that connects to J2 the 7/16" (1.1cm) Din RF output jack of the drawer.

(A8 & A9) One, two & three pallet Amplifier Drawer Power Supplies

The 230VAC, needed to operate the drawer, connects through the AC power cord at J3, the power entry module located on the rear panel of the drawer. The AC lines are connected to a terminal block TB1 to which the circuit breaker(s) connect. In a N+1 one pallet amplifier drawer and all multiple pallet amplifier drawers, there are two On/Off 20A/250VAC circuit breakers that are mounted on the back panel of the drawer on either side of J3 the AC input jack. With the circuit breakers switched On, the AC is distributed to the two (A8 and A9) DC power supplies. In a standard one pallet amplifier drawer one 20 Amp circuit breaker CB1 connects the AC to the (A8) DC power supply. TB1 has three varistors (VR1-VR3) connected across the AC input lines for surge and over voltage protection. The AC input from TB1 also connects to through 2 amp fuses to the two fans (A11 & A12) mounted in the drawer. Both fans will run immediately when AC is applied to the drawer.

The +5VDC for the operation of the amplifier control board in the drawer is generated by the (A8 & A9) power supplies at J1-9 on each power supply. The +5VDC from the (A8) power supply connects to J4-8 and the +5VDC from the (A9) power supply connects to J5-8 on the control board. The +5VDC is produced when AC is connected to the drawer and the CB1 and/or the CB2 circuit breakers are turned On. Either or both power supplies provides the +5VDC for use by the control board.

The +48VDC needed by the amplifier modules on the heatsink assembly is generated by the (A8 & A9) power supplies in the amplifier drawer. In a standard single pallet amplifier drawer there is only the (A8) power supply. The power supplies will operate when AC is connected to the drawer, the CB1 circuit breaker for the (A8) power supply and the CB2 circuit breaker for the (A9) power supply, are turned On and a Low is provided on the Inhibit Line that connects to J1-6 on the power supplies from the control board. The CB1 circuit breaker supplies the AC to the (A8) power supply which provides the +48VDC to the (A1) and (A2) 878 amplifier pallets. The CB2 circuit breaker supplies the AC to the (A9) power supply which provides the +48VDC to the (A3) and (A4) 878A amplifier pallets.

System Set Up Procedure

This system was aligned at the factory and should not require additional adjustments to achieve normal operation.

This Innovator CX Series system is of a drawer design with multiple boards inside the drawer. If a board fails, that board needs to be changed out with a replacement board. The failed board can then be sent back to Axcera for repair. **NOTE:** Contact Axcera Customer Service Department at 1-724-873-8100 or fax to 1-724-873-8105, before sending in any board or module.

Refer to Figure 16. Check that the Auto/Man switch S1 on the ALC Board is in the Automatic ALC position. (**NOTE:** The silkscreen is incorrect on Rev. A, B & C boards. Auto position is with the bat to the left, toward J4.) Adjust R75 the ALC pot on the ALC Board as needed to attain 100% output power. Switch to Manual Gain (Manual ALC) and adjust the Manual Gain pot R62 for 100% output power. Switch the ALC Board back to Automatic ALC.




Figure 16: (A5) ALC Board (1308570)

ALC Board Set-Up, Forward and Reflected Power Calibration for CU0TD/RD-1 thru CU0TD/RD-5 Systems

NOTE: If your system is a CU1TD/RD-1 or higher power with one or more external amplifier drawers, refer to the next section for the forward and reflected power calibration procedures.

Refer to Figure 16. Locate (A5) the ALC Board (1308570 & 1312207), preset the Overdrive Threshold pot R38 full CW and set R62, Manual Adjust, and R75, ALC Adjust, full CCW.

Switch S1 to Manual Gain, and increase the output power to 100% using R62. Calibrate the system output power for 100% using R23, the Forward Calibration pot, on the Output Detector Board. Refer to Figure 17.




Figure 17: (A7) Output Detector Board (1308685 & 1312207)




Figure 16A: (A5) ALC Board (1308570)

Refer to Figure 16A. Turn the output power down to 10% power with R62 on the ALC Board. Remove the output RF connector from J2 on drawer and calibrate the reflected power to 10%, using R7, the Reflected Calibration pot, on the Output Detector Board. Refer to Figure 17. Re-connect the RF output connector to the drawer and increase the power, in Manual gain using R62 on the ALC Board, to 115%. Adjust the Overdrive pot R38 on the ALC Board, CCW until the overdrive threshold just trips and the Overdrive Fault LED DS4 lights. Turn R38 slightly CW so that power comes back up and DS4 goes out.

Switch S1 on the ALC Board to ALC. Turn the ALC Adjust pot R75 on the ALC Board until the power is 100%. Switch S1 between ALC and Manual to verify smooth switching, with minimal change in power. If necessary repeat the above procedure.

With the drawer in ALC, use the ALC Adjust pot, R75, to decrease the power to 10%. Remove the RF output connector from the drawer. Verify that the VSWR Cutback LED, DS6, comes on and the Reflected Power drops to approximately 6%. Reconnect the RF output connector and increase the power back up to 100% using R75.

This completes the set up of the ALC board and the Forward and Reflected Power Calibration.

Forward and Reflected Power Calibration of a CU1TD/RD-1 and Higher Power Systems with one or more External Amplifier Drawers

NOTE: If your system is a CU0TD/RD-1 thru CU0TD/RD-5, refer to the previous section for the forward and reflected power calibration procedures.

Connect a calibrated coupler and average reading power meter to the output of the DTV mask filter. On the ALC Board (1308570), mounted in the Driver Drawer, set the Switch S1, Auto/Manual ALC, to the Manual position. Refer to Figure 13A. Adjust the Manual adjustment Pot, R62, for the desired output power level as indicated on the average reading power meter. In the Amplifier Drawer, on the Amplifier Control Board (1309822), refer to Figure 18; adjust the Forward Calibration Adjustment pot, R8, for a

reading of 100% on the External Amplifier Forward Power screen of the LCD display mounted on the Driver Drawer.




Figure 18: (A5) Amplifier Control Board (1309822)

On the ALC Board (1308570), mounted in the Driver Drawer, set the Switch S1, Auto/Manual ALC, to the Auto position. Adjust the ALC adjustment Pot, R75, for a reading of 100% on the External Amplifier Forward Power screen of the LCD display mounted on the Driver Drawer. This completes the forward power set up and calibration adjustments.

On the ALC Board (1308570), mounted in the Driver Drawer, adjust the ALC adjustment Pot, R75, for a reading of 10% on the External Amplifier Forward Power screen of the LCD display mounted on the Driver Drawer. Disconnect the load or the antenna connected to the system. In the Amplifier Drawer, on the Amplifier Control Board (1309822), adjust the Reflected Calibration Adjustment pot, R26, for a reading of 10% on the External Amplifier Reflected Forward Power screen of the LCD display mounted on the Driver Drawer. Reconnect the load or the antenna to the system. Adjust the ALC adjustment Pot, R75, for a reading of 100% on the External Amplifier Forward Power screen of the LCD display mounted on the Driver Drawer. This completes the reflected power calibration adjustment.




Figure 19: Typical 6 MHz Digital Spectrum

This page has been intentionally left blank.