

EXHIBIT E
SYSTEM MANUAL

EXHIBIT E
SYSTEM MANUAL

UNIVERSAL® AVIONICS
SYSTEMS CORPORATION
FCC ID: NWS1066A

UNIT
LINK

UL-601
Installation Manual

Part Number
1066-XX-XXX Series

PRELIMINARY

3260 East Lerdo Road
Tucson, AZ 85706
(520)295-2300 • (800)321-5253

23-20-02 June 8, 1998

Record of Revisions

| Revision No. | Issue Date | Insertion Date | Initials |
|--------------|------------|----------------|----------|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

Retain this record in front of the manual. Upon receipt of revisions, insert pages into manual and enter revision number, issue date, insertion date and your initials.

List of Effective Pages

Pages that are new or changed with this revision are indicated by an asterisk between the page number and date.

| Subject | Page | Date | Subject | Page | Date |
|-----------------------------|------|----------|------------------------|------|----------|
| Title Page | | Jun 8/98 | | 31 | Jun 8/98 |
| Record of Revisions | 1 | Jun 8/98 | | 32 | Jun 8/98 |
| Temporary Revisions | 1 | Jun 8/98 | | 33 | Jun 8/98 |
| List of Effective Pages | 1 | Jun 8/98 | | 34 | Jun 8/98 |
| | 2 | Jun 8/98 | System Data | 35 | Jun 8/98 |
| Table of Contents | 1 | Jun 8/98 | Installation (General) | 36 | Jun 8/98 |
| | 2 | Jun 8/98 | | 37 | Jun 8/98 |
| | 3 | Jun 8/98 | | 38 | Jun 8/98 |
| | 4 | Jun 8/98 | | 39 | Jun 8/98 |
| Introduction | 1 | Jun 8/98 | | 40 | Jun 8/98 |
| | 2 | Jun 8/98 | System Data | 41 | Jun 8/98 |
| Description and Operation | 3 | Jun 8/98 | Installation for | 42 | Jun 8/98 |
| | 4 | Jun 8/98 | SCN 10.X | 43 | Jun 8/98 |
| | 5 | Jun 8/98 | | 44 | Jun 8/98 |
| | 6 | Jun 8/98 | | 45 | Jun 8/98 |
| | 7 | Jun 8/98 | | 46 | Jun 8/98 |
| | 8 | Jun 8/98 | | 47 | Jun 8/98 |
| | 9 | Jun 8/98 | | 48 | Jun 8/98 |
| | 10 | Jun 8/98 | | 49 | Jun 8/98 |
| Environmental Qualification | 11 | Jun 8/98 | | 50 | Jun 8/98 |
| | 12 | Jun 8/98 | | 51 | Jun 8/98 |
| | 13 | Jun 8/98 | | 52 | Jun 8/98 |
| | 14 | Jun 8/98 | | 53 | Jun 8/98 |
| Equipment Specifications | 15 | Jun 8/98 | | 54 | Jun 8/98 |
| | 16 | Jun 8/98 | | 55 | Jun 8/98 |
| | 17 | Jun 8/98 | | 56 | Jun 8/98 |
| | 18 | Jun 8/98 | | 57 | Jun 8/98 |
| | 19 | Jun 8/98 | | 58 | Jun 8/98 |
| Installation and Wiring | 21 | Jun 8/98 | | 59 | Jun 8/98 |
| | 22 | Jun 8/98 | | 60 | Jun 8/98 |
| | 23 | Jun 8/98 | | 61 | Jun 8/98 |
| | 24 | Jun 8/98 | | 62 | Jun 8/98 |
| | 25 | Jun 8/98 | | 63 | Jun 8/98 |
| | 26 | Jun 8/98 | | 64 | Jun 8/98 |
| | 27 | Jun 8/98 | System Data | 65 | Jun 8/98 |
| | 28 | Jun 8/98 | Installation for | 66 | Jun 8/98 |
| | 29 | Jun 8/98 | SCN 11.X | 67 | Jun 8/98 |
| | 30 | Jun 8/98 | | 68 | Jun 8/98 |

UNIVERSAL[®] AVIONICS
SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

| Subject | Page | Date |
|---------------------|-------------|-------------|
| | 69 | Jun 8/98 |
| | 70 | Jun 8/98 |
| | 71 | Jun 8/98 |
| | 72 | Jun 8/98 |
| | 73 | Jun 8/98 |
| | 74 | Jun 8/98 |
| | 75 | Jun 8/98 |
| | 76 | Jun 8/98 |
| | 77 | Jun 8/98 |
| | 78 | Jun 8/98 |
| | 79 | Jun 8/98 |
| | 80 | Jun 8/98 |
| | 81 | Jun 8/98 |
| | 82 | Jun 8/98 |
| | 83 | Jun 8/98 |
| | 84 | Jun 8/98 |
| | 85 | Jun 8/98 |
| | 86 | Jun 8/98 |
| | 87 | Jun 8/98 |
| | 88 | Jun 8/98 |
| | 89 | Jun 8/98 |
| | 90 | Jun 8/98 |
| Checkout Procedures | 91 | Jun 8/98 |
| | 92 | Jun 8/98 |
| | 93 | Jun 8/98 |
| | 94 | Jun 8/98 |
| | 95 | Jun 8/98 |

Table of Contents

| | |
|---|----------|
| Record of Revisions | 1 |
| Record of Temporary Revisions | 1 |
| List of Effective Pages | 1 |
| Table of Contents | 1 |
| Introduction | 1 |
| 1. Makeup and Use of This Manual | 1 |
| A. Application | 1 |
| B. Organization | 1 |
| C. Abbreviations and Terminology | 1 |
| 2. History | 1 |
| Description and Operation | 3 |
| 1. Description | 3 |
| A. General | 3 |
| B. UASC FMS Interface | 3 |
| (1) UL-601 to UNS-1C Block Diagram | 4 |
| (2) UL-601 to UNS-1Csp Block Diagram | 5 |
| (3) UL-601 to UNS-1D Block Diagram | 6 |
| (4) UL-601 to UNS-1K Block Diagram | 7 |
| C. UniLink System Components | 8 |
| (1) Processor | 8 |
| (2) Memory | 8 |
| (3) VHF Modem | 8 |
| (4) Airborne Telephone Modem | 8 |
| D. ARINC 429 Channels | 8 |
| (1) ARINC 429 Receivers | 8 |
| (2) ARINC Transmitters | 8 |
| E. RS232/422 Serial Ports | 8 |
| F. Discrete Inputs/Outputs | 8 |
| G. Transmission Media Management | 8 |
| H. VHF Management | 9 |
| I. Airborne Telephone Management | 9 |
| J. ACARS Message Processing | 9 |
| (1) ACARS Uplink Message Receiving | 9 |
| (2) ACARS Uplink Message Log | 9 |
| (3) ACARS Downlink Message Origination | 10 |
| (4) ACARS Downlink Message Queue | 10 |
| (5) ACARS Downlink Message Transmission | 10 |

UNIVERSAL[®] AVIONICS
 SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

| | |
|---|-----------|
| K. Status Messages | 10 |
| 2. Operation | 10 |
| Environmental Qualification | 11 |
| 1. Environmental Qualification Forms | 11 |
| Equipment Specifications | 15 |
| A. UniLink Part Number Matrix | 15 |
| B. UniLink Installation Kit | 15 |
| C. Power | 16 |
| D. Weights | 16 |
| E. Equipment Drawings | 16 |
| (1) UL-601 (P/N 1066-XX-XXX) Outline Drawing | 17 |
| (2) Rack Drawing (P/N 13636-93601-2) | 18 |
| (3) Configuration Module (P/N 10651) Drawing | 19 |
| (4) Configuration Module Installation Detail | 19 |
| Installation and Wiring | 21 |
| 1. Wiring Diagrams | 21 |
| A. UL-601 to FMS | 21 |
| (1) UL-601 to UNS-1C | 21 |
| (2) UL-601 to UNS-1Csp | 23 |
| (3) UL-601 to UNS-1D | 25 |
| (4) UL-601 to UNS-1K | 27 |
| B. UL-600 to Airborne Telephone | 28 |
| (1) UL-601 to Magnastar | 28 |
| (2) UL-601 to Flitefone 800 | 28 |
| C. UL-601 to ARINC 740 / 744 Printer | 29 |
| 2. UL-601 Connector Pin Identification | 30 |
| (1) Top Plug | 30 |
| (2) Middle Plug | 31 |
| (3) Bottom Plug | 33 |
| System Data Installation (General) | 35 |
| 1. International Civil Aviation Organization (ICAO) Aircraft Type Designators | 35 |
| System Data Installation For SCN 10.X | 41 |
| 1. Configuration Worksheets | 41 |
| A. Aircraft Information | 41 |
| B. Position Report | 41 |
| C. VHF Communications | 42 |
| (1) Network Control | 42 |
| (2) Timers and Radio | 42 |
| D. Tel Comm | 42 |
| E. OOOI and Clearance Functions | 43 |

| | |
|--|-----------|
| F. Discretes | 43 |
| (1) Discretes In | 43 |
| (2) Discrete Out | 45 |
| G. ARINC Ports | 46 |
| (1) ARINC Receive Ports | 46 |
| (2) ARINC Transmit Ports | 47 |
| H. Serial Ports | 47 |
| (1) Port Types | 47 |
| (2) Port Devices | 48 |
| 2. Configuration Procedures | 49 |
| A. Configuration Edit Mode | 50 |
| (1) Selecting UniLink Display Page | 50 |
| (2) Edit Mode | 51 |
| B. Aircraft Configuration | 52 |
| C. Position Report Configuration | 53 |
| D. VHF Communications Configuration | 54 |
| (1) VHF Network Control | 54 |
| (2) VHF Communications | 55 |
| E. Tel Comm Configuration | 56 |
| F. OOOI and Clearance Functions | 57 |
| G. Discretes Configuration | 58 |
| (1) Discrete In | 58 |
| (2) Discrete Out | 59 |
| H. ARINC Ports Configuration | 60 |
| (1) ARINC Receive Ports | 60 |
| (2) ARINC Transmit Ports | 62 |
| I. Serial Ports Configuration | 63 |
| (1) Port Types | 63 |
| (2) Port Devices | 64 |
| System Data Installation For SCN 11.X | 65 |
| 1. Configuration Worksheets | 65 |
| A. Aircraft Information | 65 |
| B. Position Report | 65 |
| C. VHF Communications | 66 |
| (1) Network Control | 66 |
| (2) Timers and Radio | 66 |
| D. Tel Comm | 67 |
| E. OOOI and Clearance Functions | 67 |
| F. Discretes | 68 |
| (1) Discretes In | 68 |
| (2) Discrete Out | 70 |
| G. ARINC Ports | 72 |
| (1) ARINC Receive Ports | 72 |
| (2) ARINC Transmit Ports | 73 |

UNIVERSAL[®]AVIONICS
 SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

| | |
|--|-----------|
| H. Serial Ports | 74 |
| (1) Port Types | 74 |
| (2) Port Devices | 74 |
| 2. Configuration Procedures | 75 |
| A. Configuration Edit Mode | 76 |
| (1) Selecting UniLink Display Page | 76 |
| (2) Edit Mode | 77 |
| B. Aircraft Configuration | 78 |
| C. Position Report Configuration | 79 |
| D. VHF Communications Configuration | 80 |
| (1) Network Control | 80 |
| (2) Radio Configuration | 81 |
| E. Tel Comm Configuration | 82 |
| F. OOOI and Clearance Functions | 83 |
| G. Discretes Configuration | 84 |
| (1) Discrete In | 84 |
| (2) Discrete Out | 85 |
| H. ARINC Ports Configuration | 86 |
| (1) ARINC Receive Ports | 86 |
| (2) ARINC Transmit Ports | 88 |
| I. Serial Ports Configuration | 89 |
| (1) Port Types | 89 |
| (2) Port Devices | 90 |
| Checkout Procedures | 91 |
| 1. UniLink Ground Checkout Procedures | 91 |
| A. Conditions of Test | 91 |
| B. UniLink to FMS ARINC 429 Communications | 91 |
| C. UniLink to Display Processor RS-422 Communications | 91 |
| D. UL-601 VHF Communications Interface Test | 92 |
| E. Telephony Modem Tip and Ring Communications for Magnastar | 93 |
| F. Checking the UL-601 to Magnastar Interface. | 93 |
| G. Telephony Modem Tip and Ring Communications for Flitefone 800 | 94 |
| 2. UniLink Flight Checkout Procedures | 95 |

Introduction

1. Makeup and Use of This Manual

A. Application

This manual provides installation information about the UniLink UL-601 System. This manual applies to the following combinations of UniLink Part Number and Software Control Number.

UniLink Hardware / Software

| UniLink Part Number | Software Control Number | |
|------------------------|-------------------------|------|
| | | 11.X |
| 1066-10-XXX | | ✓ |
| 1066-11-XXX | | ✓ |

B. Organization

This manual provides information about:

- Description of the components of the UL-601.
- Environmental Qualification Forms.
- UniLink Equipment Specification.
- Installation and wiring requirements.
- Worksheets and procedures for installing system data including configuring the UNS-1K Configuration Module.

PRELIMINARY

C. Abbreviations and Terminology

This manual contains no abbreviations or terms that have varying interpretations throughout the industry. However, we use the terms FMS to refer to both Flight Management Systems and Multi-Mission Management Systems.

The front panel of the Control Display Unit (CDU), part of the FMS, contains an array of push buttons or keys that are used by the pilot to operate the system. Instructions in this manual refer to specific keys by name. We bracket the legend on the key in the text. Examples: [ENTER], [A]. Line select keys (LSK) are referred to by numerical order (top to bottom) and side. Text appearing on the display may be included. Examples: [1L], RETURN [5R].

2. History

This is the first publication of this manual. The style of this manual is consistent with the style of our latest Component Maintenance manuals. Our Component Maintenance Manuals are designed to comply with the requirements of *ATA Specification 100*.

Description and Operation

1. Description

A. General

UniLink is a two-way data link for air-to-ground communications which allows you to connect with a service provider for any number of conveniences such as pre-departure and oceanic clearances, flight plans, weather (including graphics), digital ATIS, Terminal Weather Information for Pilots (TWIP) and messaging.

UniLink utilizes VHF signals, airborne telephones and SATCOM, allowing users an appropriate choice of the communications system best suited for their operations and immediate requirements.

Some functions are only available through specific communications systems. For example, predeparture clearance (PDC), oceanic clearance (OC), digital ATIS, and terminal weather information for pilots (TWIP) are available only when UniLink is interfaced with a VHF radio. Graphical weather information is available only when the UniLink is interfaced with an airborne telephone system.

The communications link connects the user directly with a contracted service provider. Which service provider is selected is the user's decision.

UniLink provides a general purpose communications link between the aircraft and ground computers. The transmission media available for the communications link are VHF radio, satellite communications and airborne telephone. It is capable of simultaneously transmitting and/or receiving messages on more than one transmission medium at a time. Messages may be generated on the ground and sent to the aircraft (uplink message) or messages can be generated from the aircraft and sent to the ground (downlink message). Downlink messages are either generated internally by the UniLink or any one of the peripheral units may generate a message to be passed on to the UniLink for transmission. When UniLink receives an uplink message, it automatically determines if the message should be processed internally or be sent to a peripheral device specified by a message sub-label. Messages can be predefined as ARINC Airborne Communications Addressing and Reporting System (ACARS) messages or UniLink supported messages, such as specialized weather requests or graphical weather maps.


B. UASC FMS Interface

The UL-601 interfaces with up to three UASC Flight Management Systems. However, the UniLink responds to only one FMS at a time. The ARINC 429 interface uses the ARINC 739 protocol for display control and ARINC 619 bit oriented file transfer protocol for file exchange between the devices. Each UASC FMS provides a high speed ARINC 429 channel as inputs to UniLink. The specific channel will be specified by the configuration module. UniLink provides up to three general purpose ARINC 429 output buses configurable to high or low speed. The configuration module contains the information on connections between the UASC FMS and UniLink. UniLink provides an RS422 transmitter and an RS422 receiver proprietary graphics display bus interface between the unit and each FMS.

UNIVERSAL[®] AVIONICS
SYSTEMS CORPORATION


UL-601 UNILINK INSTALLATION MANUAL

(1) UL-601 to UNS-1C Block Diagram




UNIVERSAL[®]AVIONICS
 SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

(2) UL-601 to UNS-1Csp Block Diagram




UL-601 UNILINK INSTALLATION MANUAL

(3) UL-601 to UNS-1D Block Diagram



UNIVERSAL[®] AVIONICS
 SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

(4) UL-601 to UNS-1K Block Diagram



97091602 UL600 1K 8D

UL-601 UNILINK INSTALLATION MANUAL

C. UniLink System Components

(1) Processor

The CPU used for UniLink is a 32-bit integrated microcontroller that provides high performance data manipulation capabilities with peripheral subsystems.

(2) Memory

UniLink contains two megabytes of FLASH memory used to store loadable software and configuration data tables. The memory device uses a blocked array architecture to provide independent erasure of memory blocks. UniLink provides two megabyte of Random Access Memory (RAM) for program execution and dynamic storage.

(3) VHF Modem

UniLink provides a VHF modem which provides an interface to a VHF radio. The VHF modem connects to the VHF radio through audio input and output interface connections. The modem can communicate with the VHF radio at a rate of 2400 baud using 1200Hz or 2400Hz signals. The VHF modem has a self-test mode that is initiated upon a command from the unit processor.

(4) Airborne Telephone Modem

UniLink contains a dedicated airborne telephone modem that provides an interface to the aircraft airborne telephone system. The processor communicates with the airborne telephone modem through a standard register interface. The modem conforms to the V.34 standard, allowing it to communicate at a rate of up to 28.8 kilobaud. The airborne telephone modem uses the standard set of Hayes compatible commands and registers.

D. ARINC 429 Channels

UniLink uses a multi-channel ARINC 429 controller which provides the ARINC 429 interfaces. It provides eight ARINC 429 receivers and three ARINC 429 transmitters.

(1) ARINC 429 Receivers

The eight ARINC 429 receivers can be independently configured for supported ARINC devices. The receiver bus speed (high or low) is determined by the ARINC device selected during configuration.

(2) ARINC Transmitters

The three ARINC 429 transmitters can be independently configured for bus speed (high or low). Multiple ARINC devices of the same bus speed can be selected by each transmitter, not to exceed the transmitter bus capacity. Currently (January 1998) all supported ARINC devices are low speed.

E. RS232/422 Serial Ports

UniLink provides eight general purpose RS232/422 transmitters and eight general purpose RS232/422 receivers. These ports are available to perform as eight full duplex channels. The ports are capable of operating up to a 19.2 kilobaud rate. The average baud rate for all channels will not exceed 9600 baud. One RS422 port is reserved for the CDU graphics bus. The serial port type selection (RS232 or RS422) is done in pairs.

F. Discrete Inputs/Outputs

UniLink provides 16 general purpose TTL-level discrete input connections and 16 TTL-level discrete output connections. Various configurations of UniLink may level shift these discretes to drive relays and accept high power inputs. One output discrete is reserved and is used to drive the push-to-talk switch for the VHF radio.

G. Transmission Media Management

UniLink is capable of managing multiple media so that simultaneous transmission and receipt of messages is possible on several different media at the same time. In the initial release, UniLink provides individual media man-

UL-601 UNILINK INSTALLATION MANUAL

agement of the VHF radio and airborne telephone. In future versions UniLink will also manage Satellite Data Units and HF Radio interfaces.

H. VHF Management

UniLink requires a dedicated VHF radio for its data communication. UniLink communicates with the VHF radio via Audio Modem for the data communication, and through CSDB for frequency tune and a discrete output for the push-to-talk (PTT) switch. UniLink is not affected by any radio status data that may be provided by the radio. The type of radio and method used for radio tuning is stored in the configuration module. VHF Management requires that UniLink perform the following tasks in order to manage the VHF air-ground link:

- Acquire a frequency
- Establish a frequency or channel
- Maintain the frequency or channel

UniLink is in a NOCOMM status when acquiring a frequency. The system supports establishing and maintaining contact with Category A ground networks. In Category A operation, all ground stations within VHF range accept downlink messages. UniLink accepts the Autotune message and tunes the radio to the requested frequency.

I. Airborne Telephone Management

A dedicated airborne telephone modem is designed into UniLink. This modem is used to transfer data between a supported ground station and the aircraft subsystems. For example, the airborne telephone modem is initially used for uploading messages, text weather, and graphical weather data from a service provider. In the future it may be used to upload other types of files and data. UniLink manages only one telephone line.

J. ACARS Message Processing

UniLink provides services in the Airborne Communications Addressing and Reporting System (ACARS). There are two types of ACARS data communications, ground-to-air via uplink messages and air-to-ground via downlink messages. Messages sent from one aircraft to another can only be accomplished through the use of user-defined messages via the ground network. Uplink messages are generated by Airline Operations Centers (AOC) or an equivalent service provider, ATC facilities or a Data Link Service Provider (DSP) such as ARINC or SITA and, when not generated by a DSP, are passed to a DSP which then sends the uplink messages to a designated UniLink system or aircraft. The message is then processed by UniLink or, when the message is meant for a peripheral unit, is passed on to the appropriate peripheral unit. Down link messages are generated by UniLink or one of its airborne peripherals (which then passes the message to UniLink) and are sent by UniLink to a DSP, which then forwards the downlink message, when appropriate, to the designated AOC or ATC facility.

(1) ACARS Uplink Message Receiving

When UniLink receives an uplink message from the ground system, it performs a Block Check Sequence (BCS) error check. If the message is error-free, UniLink determines if the message is addressed to the aircraft in which the unit is installed. If so, it generates a positive acknowledgment for transmission to the ground. If the uplink message contains an error, UniLink generates a negative technical acknowledgment. Upon receipt of the negative technical acknowledgment, the ground system should retransmit the uplink message.

(2) ACARS Uplink Message Log

UniLink maintains an uplink message log capable of storing at least 25 blocks of uplink messages. UniLink stores only those uplink messages that are defined as requiring storage in the log. UniLink allows users to delete or print specific messages from the message log. When the message log is full and a new message requiring storage is received, UniLink will delete the oldest read message in the log. When the log is full of messages that have not been read and a new message requiring storage is received,

UL-601 UNILINK INSTALLATION MANUAL

UniLink will send a negative acknowledgment of receipt of the uplink message. UniLink will announce a “log full” state to the flight crew when the message log contains 24 blocks of unread messages.

(3) ACARS Downlink Message Origination

UniLink generates downlink messages by one of two methods, by the flight crew via the user interface or as a response to an event having occurred, such as engine start.

(4) ACARS Downlink Message Queue

Once a downlink message is encoded, it is queued until the message can be transmitted to the ground. UniLink is capable of queuing at least 70 blocks of downlink messages. It is capable of grouping messages into types and limiting the number of messages of each type that can be stored in the queue at any time. UniLink can also delete all messages of a given type from the queue, such as deleting all ATC messages at the end of a flight.

(5) ACARS Downlink Message Transmission

UniLink only transmits messages once it has determined that the channel is clear. When a valid communication link exists, UniLink transmits the message having the highest priority. If more than one message shares the highest priority then UniLink selects the oldest from that group of messages. UniLink completes transmission of a message block prior to transmitting another message block. Upon receipt of the downlinked message, the DSP performs a BCS error check and, if the message is error-free, routes it to the proper destination. The ground system also generates a positive technical acknowledgment for the message and transmits it to the aircraft. Upon receipt of a positive technical acknowledgment, UniLink considers the message successfully transmitted and deletes it from the downlink queue.

K. Status Messages

UniLink provides status messages to alert the flight crew of system events or data entry errors.

Examples of crew alerts are: MESSAGE PRINTING, VHF COMM AVAILABLE, etc.

Examples of data entry errors are: INVALID ENTRY, INVALID FORMAT, etc.

2. Operation

The UniLink is operated by controls provided by the Control Display Unit (CDU). Refer to the Operator’s Manual for your installation for UniLink Operating Procedures. The same Operator’s Manual also introduces the CDU, explain the CDU operating philosophy, and provides a detailed explanation of the keyboard keys and their associated functions.

Environmental Qualification

1. Environmental Qualification Forms

The environmental categories under which the UL-601 is approved (Reference RTCA, DO-160C) are listed on the following Environmental Qualification Forms.

ENVIRONMENTAL QUALIFICATION FORM

NOMENCLATURE: UniLink Unit

PART NO.: 1066-()-()

PMA NUMBER: PQ2128NM-D

MANUFACTURER'S SPECIFICATION AND/OR OTHER APPLICABLE SPECIFICATION:
Contained in the appropriate Installation Manual

MANUFACTURER: Universal Avionics Systems Corporation
3260 E. Lerdo Road
Tucson, AZ. 85706-5021

| CONDITIONS | DO-160C Rev 3 SECTION # PARA # | DESCRIPTION OF CONDUCTED TESTS Note 1 |
|--|--------------------------------------|--|
| TEMPERATURE, ALTITUDE, DECOMPRESSION, AND OVERPRESSURE | 4.0 | EQUIPMENT TESTED TO CATEGORY A2E1 |
| TEMPERATURE VARIATION | 5.0 | EQUIPMENT TESTED TO CATEGORY B |
| HUMIDITY | 6.0 | EQUIPMENT TESTED TO CATEGORY A 95%, 55°C, 48 HOURS |
| OPERATIONAL SHOCKS AND CRASH SAFETY | 7.0 | EQUIPMENT TESTED |
| VIBRATION | 8.0 | EQUIPMENT TESTED WITHOUT SHOCK MOUNTS TO CATEGORIES C, M & N (EQUIPMENT RACK, NON-ISOLATED DO-160C, TABLE 8-1) |
| EXPLOSION PROOFNESS | 9.0 | EQUIPMENT TESTED TO CATEGORY E2 |
| WATERPROOFNESS | 10.0 | EQUIPMENT TESTED TO CATEGORY W |
| FLUIDS SUSCEPTIBILITY | 11.0 | EQUIP. IDENTIFIED AS X NOT TESTED |
| SAND AND DUST | 12.0 | EQUIP. IDENTIFIED AS X NOT TESTED |
| FUNGUS | 13.0 | EQUIP. IDENTIFIED AS X NOT TESTED |
| NOTE: 1 The information listed provides levels tested. It is not intended to be a comprehensive listing of all test conditions. | | |

UL-601 UNILINK INSTALLATION MANUAL

| CONDITIONS | DO-160C Rev 3 SECTION # PARA # | DESCRIPTION OF CONDUCTED TESTS Note 1 |
|--|--------------------------------------|--|
| SALT SPRAY | 14.0 | EQUIP. IDENTIFIED AS X NOT TESTED |
| MAGNETIC EFFECT | 15.0 | EQUIPMENT TESTED TO CATEGORY Z |
| POWER INPUT | 16.0 | EQUIPMENT TESTED TO CATEGORY Z |
| VOLTAGE SPIKE | 17.0 | EQUIPMENT TESTED TO CATEGORY A |
| AUDIO FREQUENCY SUSCEPTIBILITY | 18.0 | EQUIPMENT TESTED TO CATEGORY Z |
| INDUCED SIGNAL SUSCEPTIBILITY | 19.0 | EQUIPMENT TESTED TO CATEGORY Z |
| CONDUCTED / RADIATED SUSCEPTIBILITY | 20.0 | EQUIPMENT TESTED TO CATEGORY R |
| EMISSION OF RADIO FREQUENCY ENERGY | 21.0 | EQUIPMENT TESTED TO CATEGORY Z |
| LIGHTNING INDUCED TRANS SUSCEPTIBILITY | 22.0 | EQUIPMENT TESTED TO CATEGORY A3E3 |
| LIGHTNING DIRECT EFFECTS | 23.0 | EQUIPMENT IDENTIFIED AS X NOT TESTED |
| ICING | 24.0 | EQUIPMENT IDENTIFIED AS X NOT TESTED |
| NOTE: 1 The information listed provides levels tested. It is not intended to be a comprehensive listing of all test conditions. | | |

UL-601 UNILINK INSTALLATION MANUAL

ENVIRONMENTAL QUALIFICATION FORM

NOMENCLATURE: Configuration Module

PART NO.: 10651

PMA NUMBER: PQ2128NM-D

MANUFACTURER'S SPECIFICATION AND/OR OTHER APPLICABLE SPECIFICATION:
Contained in the appropriate Installation Manual

MANUFACTURER: Universal Avionics Systems Corporation
3260 E. Lerdo Road
Tucson, AZ. 85706-5021

| CONDITIONS | DO-160C Rev 3 SECTION # PARA # | DESCRIPTION OF CONDUCTED TESTS Note 1. |
|--|--------------------------------------|--|
| TEMPERATURE, ALTITUDE, DECOMPRESSION, AND OVERPRESSURE | 4.0 | EQUIPMENT TESTED TO CATEGORY A2E1 |
| TEMPERATURE VARIATION | 5.0 | EQUIPMENT TESTED TO CATEGORY B |
| HUMIDITY | 6.0 | EQUIPMENT TESTED TO CATEGORY A 95%, 55°C, 48 HOURS |
| OPERATIONAL SHOCKS AND CRASH SAFETY | 7.0 | EQUIPMENT TESTED |
| VIBRATION | 8.0 | EQUIPMENT TESTED WITHOUT SHOCK MOUNTS TO CATEGORIES C, M & N (EQUIPMENT RACK, NON-ISOLATED DO-160C, TABLE 8-1) |
| EXPLOSION PROOFNESS | 9.0 | EQUIPMENT TESTED TO CATEGORY E2 |
| WATERPROOFNESS | 10.0 | EQUIPMENT TESTED TO CATEGORY W |
| FLUIDS SUSCEPTIBILITY | 11.0 | EQUIP. IDENTIFIED AS X NOT TESTED |
| SAND AND DUST | 12.0 | EQUIP. IDENTIFIED AS X NOT TESTED |
| FUNGUS | 13.0 | EQUIP. IDENTIFIED AS X NOT TESTED |
| SALT SPRAY | 14.0 | EQUIP. IDENTIFIED AS X NOT TESTED |
| MAGNETIC EFFECT | 15.0 | EQUIPMENT TESTED TO CATEGORY Z |
| POWER INPUT | 16.0 | EQUIPMENT TESTED TO CATEGORY Z |


NOTE: 1 The information listed provides levels tested. It is not intended to be a comprehensive listing of all test conditions.

UL-601 UNILINK INSTALLATION MANUAL

| CONDITIONS | DO-160C Rev 3 SECTION # PARA # | DESCRIPTION OF CONDUCTED TESTS Note 1. |
|---|--------------------------------------|---|
| VOLTAGE SPIKE | 17.0 | EQUIPMENT TESTED TO CATEGORY A |
| AUDIO FREQUENCY SUSCEPTIBILITY | 18.0 | EQUIPMENT TESTED TO CATEGORY Z |
| INDUCED SIGNAL SUSCEPTIBILITY | 19.0 | EQUIPMENT TESTED TO CATEGORY Z |
| CONDUCTED / RADIATED SUSCEPTIBILITY | 20.0 | EQUIPMENT TESTED TO CATEGORY R |
| EMISSION OF RADIO FREQUENCY ENERGY | 21.0 | EQUIPMENT TESTED TO CATEGORY Z |
| LIGHTNING INDUCED TRANS SUSCEPTIBILITY | 22.0 | EQUIPMENT TESTED TO CATEGORY A3E3 |
| LIGHTNING DIRECT EFFECTS | 23.0 | EQUIPMENT IDENTIFIED AS X NOT TESTED |
| ICING | 24.0 | EQUIPMENT IDENTIFIED AS X NOT TESTED |
| <p>NOTE: 1 The information listed provides levels tested. It is not intended to be a comprehensive listing of all test conditions.</p> | | |

Equipment Specifications

A. UniLink Part Number Matrix



B. UniLink Installation Kit

Installation Kit # K12030-1

| Quantity | Part Number | Description |
|----------|--------------------------|--|
| 1 | 13636-93601-2 or 93601-2 | Rack, ARINC 600, 1 MCU (Barry Controls) |
| 6 | MS24693C4 | Screw, Recessed, Cres, 100° CSK, 4-40 x 3/8" |
| 1 | 1219 | Rack Connector |
| 2 | MS51957-19 | Screw, 4-40 x 7/8", Cres (for config module) |
| 2 | MS21083C04 | Nut, 4-40, Cres, Self Lock (for config module) |

UL-601 UNILINK INSTALLATION MANUAL

C. Power

POWER SPECIFICATIONS

| COMPONENT | | CURRENT (A @ Vdc) | | | POWER (W @ Vdc) | | |
|-----------|------------|-------------------|-------------------|---------------|-----------------|-------------------|---------------|
| TYPE | PART No. | 19.0 V MIN | 27.5 V NOMINAL | 32.0 V MAX | 19.0 V MIN | 27.5 V NOMINAL | 32.0 V MAX |
| UL-601 | 1066-()-() | 1.0 A | 700 mA | 600 mA | 19.0 W | 19.25 W | 19.20 W |
| | | | | | | | |
| | | | | | | | |

D. Weights

EQUIPMENT WEIGHTS


| COMPONENT | WEIGHT |
|----------------------|----------|
| UL-601 UniLink | 4.8 lb. |
| Equipment Rack | 11.5 oz. |
| Connector | 5.9 oz. |
| Configuration Module | 0.5 oz. |

E. Equipment Drawings

Refer to your FMS Technical Manual for NCU, CDU, and DTU drawings.


UL-601 UNILINK INSTALLATION MANUAL

- (1) UL-601 (P/N 1066-XX-XXX) Outline Drawing




UL-601 UNILINK INSTALLATION MANUAL

(2) Rack Drawing (P/N 13636-93601-2)




UL-601 UNILINK INSTALLATION MANUAL

(3) Configuration Module (P/N 10651) Drawing



(4) Configuration Module Installation Detail



Installation and Wiring


1. Wiring Diagrams

The following wiring diagrams show connections between the UL-601 and other avionics equipment used in typical installations. Refer to the appropriate FMS technical manual for additional required wiring.

These diagrams include our suggested choices for configurable discrettes and communications ports. Mark the configuration worksheets to show your actual installation. Configuration worksheets are found below in the *System Data Installation* section of this manual.

A. UL-601 to FMS


- (1) UL-601 to UNS-1C



UL-601 to UNS-1C Wiring diagram — Sheet 1 of 2

UNIVERSAL[®] AVIONICS SYSTEMS CORPORATION


UL-601 UNILINK INSTALLATION MANUAL



UL-601 to UNS-1C Wiring diagram — Sheet 2 of 2

UL-601 UNILINK INSTALLATION MANUAL


(2) UL-601 to UNS-1Csp



UL-601 to UNS-1Csp Wiring diagram — Sheet 1 of 2


UNIVERSAL[®] AVIONICS
SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

(3) UL-601 to UNS-1D



UL-601 to UNS-1D Wiring diagram — Sheet 1 of 2


UNIVERSAL[®] AVIONICS
 SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL



UL-601 to UNS-1D Wiring diagram — Sheet 2 of 2

UNIVERSAL[®] AVIONICS
 SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

(4) UL-601 to UNS-1K




UL-601 to UNS-1K Wiring Diagram

UL-601 UNILINK INSTALLATION MANUAL


B. UL-601 to Airborne Telephone

(1) UL-601 to Magnastar



UL-601to Magnastar Wiring Diagram


(2) UL-601 to Flitefone 800



UL-601 to Flitefone 800 Wiring Diagram

UL-601 UNILINK INSTALLATION MANUAL

C. UL-601 to ARINC 740 / 744 Printer



UL-601 UNILINK INSTALLATION MANUAL

2. UL-601 Connector Pin Identification

(1) Top Plug

UL-601 – Top Plug
Pin Identification Chart Plug

| TOP PLUG – P/N 1066-XX-XXX | |
|----------------------------|----------------------------------|
| Pin | Function |
| 1A | Reserved 1 |
| 1B | Reserved 2 |
| 1C | Reserved 3 |
| 1D | Reserved 4 |
| 2A | Reserved 5 |
| 2B | Reserved 6 |
| 2C | Reserved 7 |
| 2D | Reserved 8 |
| 3A | Radio CSDB Tune Bus ¹ |
| 3B | Radio CSDB Tune Bus ¹ |
| 3C | Radio CSDB Tune Bus ¹ |
| 3D | Radio CSDB Tune Bus ¹ |
| 4A | RS422 / RS232 Tx (+) #7 |
| 4B | RS422 Tx (-) #7 |
| 4C | RS422 / RS232 Rx (+) #7 |
| 4D | RS422 Rx (-) #7 |
| 5A | RS422 / RS232 Tx (+) #6 |
| 5B | RS422 Tx (-) #6 |
| 5C | RS422 / RS232 Rx (+) #6 |
| 5D | RS422 Rx (-) #6 |
| 6A | RS422 / RS232 Tx (+) #5 |
| 6B | RS422 Tx (-) #5 |

UL-601 – Top Plug
Pin Identification Chart Plug (Continued)

| TOP PLUG – P/N 1066-XX-XXX | |
|----------------------------|-------------------------|
| Pin | Function |
| 6C | RS422 / RS232 Rx (+) #5 |
| 6D | RS422 Rx (-) #5 |
| 7A | RS422 / RS232 Tx (+) #4 |
| 7B | RS422 Tx (-) #4 |
| 7C | RS422 / RS232 Rx (+) #4 |
| 7D | RS422 Rx (-) #4 |
| 8A | RS422 / RS232 Tx (+) #2 |
| 8B | RS422 Tx (-) #2 |
| 8C | RS422 / RS232 Rx (+) #2 |
| 8D | RS422 Rx (-) #2 |
| 9A | RS422 / RS232 Tx (+) #3 |
| 9B | RS422 Tx (-) #3 |
| 9C | RS422 / RS232 Rx (+) #3 |
| 9D | RS422 Rx (-) #3 |
| 10A | RS232 Tx Diag |
| 10B | RS232 Rx Diag |
| 10C | RS232 Return Diag |
| 10D | Spare 1 |
| 11A | Spare 2 |
| 11B | Spare 3 |
| 11C | Config Mod Clock |
| 11D | Config Mod Power |
| 12A | ARINC 429 Rx #8 (A) |
| 12B | ARINC 429 Rx #8 (B) |

UL-601 UNILINK INSTALLATION MANUAL

UL-601 – Top Plug
Pin Identification Chart Plug (Continued)

| TOP PLUG – P/N 1066-XX-XXX | |
|---|-----------------------|
| Pin | Function |
| 12C | Config Mod Data (I/O) |
| 12D | Config Mod Ground |
| 13A | ARINC 429 Rx #6 (A) |
| 13B | ARINC 429 Rx #6 (B) |
| 13C | ARINC 429 Rx #7 (A) |
| 13D | ARINC 429 Rx #7 (B) |
| 14A | ARINC 429 Rx #4 (A) |
| 14B | ARINC 429 Rx #4 (B) |
| 14C | ARINC 429 Rx #5 (A) |
| 14D | ARINC 429 Rx #5 (B) |
| 15A | ARINC 429 Tx #3 (A) |
| 15B | ARINC 429 Tx #3 (B) |
| 15C | ARINC 429 Rx #3 (A) |
| 15D | ARINC 429 Rx #3 (B) |
| ¹ Do not connect anything to these ports. Connections are internal. | |

(2) Middle Plug

UL-601 Middle Plug
Pin Identification Chart

| MIDDLE PLUG – P/N 1066-XX-XXX | |
|---|-------------------------------|
| Pin | Function |
| 1A | ARINC 429 Tx #1 (A) |
| 1B | ARINC 429 Tx #1 (B) |
| 1C | ARINC 429 Rx #1 (A) |
| 1D | ARINC 429 Rx #1 (B) |
| 2A | ARINC 429 Tx #2 (A) |
| 2B | ARINC 429 Tx #2 (B) |
| 2C | ARINC 429 Rx #2 (A) |
| 2D | ARINC 429 Rx #2 (B) |
| 3A | RS232 Return |
| 3B | Spare 4 |
| 3C | Spare 5 |
| 3D | Spare 6 |
| 4A | RS422 / RS232 Tx (+) #1 |
| 4B | RS422 Tx (-) #1 |
| 4C | RS422 / RS232 Rx (+) #1 |
| 4D | RS422 Rx (-) #1 |
| NOTE: <ol style="list-style-type: none"> MP3A is the return for both MP4A & MP4C if configured for RS-232. MP4A, MP4B, MP4C & MP4D are used if configured for RS-422 (CSDB). | |
| 5A | Discrete Out #14 (Active Gnd) |
| 5B | Discrete Out #15 (Active Gnd) |
| 5C | Discrete Out #16 (Active Gnd) |
| 5D | Spare 7 |
| 6A | Discrete Out #10 (Active Gnd) |

UL-601 UNILINK INSTALLATION MANUAL

UL-601 Middle Plug
Pin Identification Chart (Continued)

| MIDDLE PLUG – P/N 1066–XX–XXX | |
|--------------------------------------|-------------------------------|
| Pin | Function |
| 6B | Discrete Out #11 (Active Gnd) |
| 6C | Discrete Out #12 (Active Gnd) |
| 6D | Discrete Out #13 (Active Gnd) |
| 7A | Discrete Out #6 (Active Gnd) |
| 7B | Discrete Out #7 (Active Gnd) |
| 7C | Discrete Out #8 (Active Gnd) |
| 7D | Discrete Out #9 (Active Gnd) |
| 8A | Discrete Out #2 (Active Gnd) |
| 8B | Discrete Out #3 (Active Gnd) |
| 8C | Discrete Out #4 (Active Gnd) |
| 8D | Discrete Out #5 (Active Gnd) |
| 9A | Discrete In #13 (Active Gnd) |
| 9B | Discrete In #14 (Active Gnd) |
| 9C | Discrete In #15 (Active Gnd) |
| 9D | Discrete In #16 (Active Gnd) |
| 10A | Discrete In #9 (Active Gnd) |
| 10B | Discrete In #10 (Active Gnd) |
| 10C | Discrete In #11 (Active Gnd) |
| 10D | Discrete In #12 (Active Gnd) |
| 11A | Discrete In #5 (Active Gnd) |
| 11B | Discrete In #6 (Active Gnd) |
| 11C | Discrete In #7 (Active Gnd) |
| 11D | Discrete In #8 (Active Gnd) |
| 12A | Discrete In #2 (Active Gnd) |
| 12B | Discrete In #3 (Active Gnd) |

UL-601 Middle Plug
Pin Identification Chart (Continued)

| MIDDLE PLUG – P/N 1066–XX–XXX | |
|--------------------------------------|--|
| Pin | Function |
| 12C | Discrete In #4 (Active Gnd) |
| 12D | Spare 8 |
| 13A | Telephone Ring (Modem I/F) |
| 13B | Telephone 3 Reserved |
| 13C | Telephone 2 Reserved |
| 13D | Telephone 1 Reserved |
| 14A | Telephone Tip (Modem I/F) |
| 14B | Discrete Out #1 (Active Gnd) |
| 14C | Ground Return VHF-ACARS (VHF Radio - Active Ground) |
| 14D | Discrete In #1 (Active Gnd) |
| 15A | Modem Tx (+) |
| 15B | Modem Tx (-) |
| 15C | Modem Rx (+) |
| 15D | Modem Rx (-) |

UNIVERSAL[®] AVIONICS
SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

(3) Bottom Plug

UL-601 Bottom Plug
Pin Identification Chart

| BOTTOM PLUG – P/N 1066-XX-XXX | |
|--------------------------------------|-----------------|
| Pin | Function |
| 1 | Spare |
| 2 | +28 VDC |
| 3 | Chassis Gnd |
| 4 | Power Gnd |
| 5 | Reserved |

System Data Installation (General)

1. International Civil Aviation Organization (ICAO) Aircraft Type Designators

When installing system data the ICAO aircraft type designator will be used. The following table contains ICAO designators for various aircraft. Use it or ICAO Document 8643 to ascertain the correct designator for your aircraft.

| MANUFACTURER/MODEL | ICAO DESIGNATOR |
|--------------------------|-----------------|
| AIRBUS | |
| A-300 | A300 |
| A-310 | A310 |
| ATR | |
| ATR-42/72 | ATR |
| BAC | |
| 111 One-eleven | BA111 |
| BEECH | |
| 90, A90 to E90 King Air | BE9L |
| 200, 1300 Super King Air | BE20 |
| 300 Super King Air | BE30 |
| B300 Super King Air 350 | B350 |
| 400 Beechjet | MU30 |
| 1900 (C-12J) | B190 |
| BELL | |
| 212, 412 | B12 |
| 214ST | BSTP |
| 222, 230,430 | B222 |

UNIVERSAL[®] AVIONICS
SYSTEMS CORPORATION

UL-601 UNILINK INSTALLATION MANUAL

| MANUFACTURER/MODEL | ICAO DESIGNATOR |
|-----------------------------------|--------------------|
| BOEING | |
| 707 | B708 |
| 727 (C-22) | B727 |
| 737-100/200 (CT-43) | B73A |
| 737-300/400/500 | B73B |
| 747-100/200/300 (E-4, VC-25) | B74A |
| 747SP | B74S |
| 757 | B757 |
| C135 | C135 |
| BRITISH AEROSPACE | |
| BAC 111 One-eleven | BA11 |
| BAe-125-700/800 (C-29) | H25B |
| BAe-125-1000 | H25C |
| BAe-146, RJ | BA46 |
| BAe-4100 Jetstream 41 | JSTB |
| CANADAIR | |
| CL-600/601/604 Challenger | CL60 |
| RJ Regional Jet | CARJ |
| CESSNA | |
| F406 Caravan 2 | F406 |
| 441 Conquest, Conquest 2 | C441 |
| 500, 501 Citation, Citation 1/1SP | C500 |
| 525 Citation Jet | C525 |
| 526 Citation Jet | C526 |

UNIVERSAL[®] AVIONICS
 SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

| MANUFACTURER/MODEL | ICAO DESIGNATOR |
|---|--------------------|
| 550, S550, 551, 552 Citation 2/S2/2SP/Bravo | C550 |
| 560 Citation 5 | C560 |
| 650 Citation 3/6/7 | C650 |
| DASSAULT | |
| Falcon 10, Mystère 10 | FA10 |
| Falcon 20, Mystère 20 | FA20 |
| Falcon 50, Mystère 50 | FA50 |
| Falcon 900, Mystère 900 | F900 |
| Falcon 2000 | F2TH |
| DEHAVILLAND CANADA | |
| DHC-6 Twin Otter | DHC6 |
| DHC-7 Dash 7 | DHC7 |
| DHC-8 Dash 8 | DHC8 |
| DOUGLAS | |
| DC-8 | DC8 |
| DC-9 | DC9 |
| EMBRAER | |
| EMB-110/111 Bandeirante | E110 |
| EMB-120 Brasilia | E120 |
| EMB-145 | E145 |
| EUROCOPTER | |
| AS-365/565 Dauphin | AS65 |
| BK-117 | BK17 |
| FOKKER | |
| 50 | F50 |

UNIVERSAL[®] AVIONICS
SYSTEMS CORPORATION

UL-601 UNILINK INSTALLATION MANUAL

| MANUFACTURER/MODEL | ICAO DESIGNATOR |
|-----------------------------|--------------------|
| GRUMMAN | |
| G-159 Gulfstream 1 | G159 |
| G-1159 Gulfstream 2 | GULF |
| Albatross | U16 |
| GULFSTREAM AEROSPACE | |
| Gulfstream 3/4/5 | GULF |
| HAWKER | |
| HS-124-400/600 | H25A |
| HS-125-700 | H25B |
| IAI | |
| 1123 Westwind | WW23 |
| 1124 Westwind | WW24 |
| 1125 Astra | ASTR |
| Galaxy | GLAX |
| ILYUSHIN | IL96 |
| LEARJET | |
| 31 | LJ31 |
| 35 | LJ35 |
| 45 | LJ45 |
| 55 | LJ55 |
| 60 | LJ60 |
| LOCKHEED | |
| C-130 | C130 |
| L-1011 TriStar | L101 |

UNIVERSAL[®] AVIONICS
 SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

| MANUFACTURER/MODEL | ICAO DESIGNATOR |
|---------------------------|--------------------|
| McDONNELL DOUGLAS | |
| DC-8 | DC8 |
| DC-9 | DC9 |
| DC-10 | DC10 |
| MD-81/82/83/87/88 | MD80 |
| MD-90 | MD90 |
| MITSUBISHI | |
| MU-300 Diamond | MU30 |
| PIPER | |
| PA-42 Cheyenne 3/400 | PA42 |
| RAYTHEON | |
| 90 King Air | BE9L |
| 200 Super King Air (C-12) | BE20 |
| 300 Super King Air | BE30 |
| B300 Super King Air 350 | BE350 |
| 400 Beechjet | MU30 |
| 1900 | B190 |
| Hawker 800 | H25B |
| Hawker 1000 | H25C |
| REIMS | |
| F406 Caravan 2 | F406 |
| SIKORSKY | |
| S-70 | H60 |
| S-76 | S76 |

UNIVERSAL[®] AVIONICS
SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

| MANUFACTURER/MODEL | ICAO DESIGNATOR |
|--------------------|-----------------|
| TUPOLEV | |
| Tu-154 | T154 |
| WESTLAND | |
| Puma | PUMA |

PRELIMINARY

SCN 10.X

System Data Installation For SCN 10.X

1. Configuration Worksheets

Universal Avionics Systems Corporation recommends that the following worksheets be completed in order to easily program the UniLink configuration module. One set of worksheets should be filled out. Fill in the blanks and check the appropriate boxes based on the wiring of the aircraft and its set of avionics components. Further, these worksheets may be submitted along with other approval paperwork. A copy of these worksheets should be filed along with the aircraft paper work for future reference.

NOTE: You are hereby authorized to reproduce these worksheets as well as the configuration module programming procedures if desired.

A. Aircraft Information

Date:

Company Address:

A/C Manufacturer:

A/C Model No.:

A/C Serial No.:

ICAO Aircraft Type:

(Not more than four characters)

A/C Registration No.:

(Not more than seven alphanumeric characters)

- NOTE:**
1. The last two items above are required to configure the UniLink.
 2. Refer to ICAO Doc 8643 for a list of assigned aircraft type designators.

B. Position Report

These settings control automatic reporting of aircraft position data to the ground service provider for flight following and reporting. Many service providers recommend disabling automatic reporting. Set the options as recommended by or per agreement with your service provider.

| | | |
|---------------------|----------------------------------|-----------------------------------|
| In Air Automatic | <input type="checkbox"/> ENABLED | <input type="checkbox"/> DISABLED |
| In Air Interval | _____ | Up to Two digits |
| On Ground Automatic | <input type="checkbox"/> ENABLED | <input type="checkbox"/> DISABLED |
| On Ground Interval | _____ | Up to Two digits |

UL-601 UNILINK INSTALLATION MANUAL

SCN 10.X

C. VHF Communications

(1) Network Control

These settings determine which ACARS Data Link Service Providers will be accessed automatically by UniLink. These defaults can be overridden by the operator on the Network Control Page.

| | | |
|---------|-----------------------------|------------------------------|
| ARINC | <input type="checkbox"/> ON | <input type="checkbox"/> OFF |
| AIR CAN | <input type="checkbox"/> ON | <input type="checkbox"/> OFF |
| SITA | <input type="checkbox"/> ON | <input type="checkbox"/> OFF |
| AVICOM | <input type="checkbox"/> ON | <input type="checkbox"/> OFF |

(2) Timers and Radio

The contact timer is used to verify that the current VHF frequency is still usable when the channel has not had any uplink traffic received for a period of time. Enable this option if VHF is the only medium being configured.

If NONE is selected for Radio, then the FLT INFO SRV prompt on the Main Menu is removed and VHF only message functions are no longer accessible.

The tracker timer is used to provide flight following information to the service provider. This setting should be disabled unless your service provider says otherwise.

| | | | |
|---------------|----------------------------------|--|---|
| Contact Timer | <input type="checkbox"/> ENABLED | <input type="checkbox"/> DISABLED | |
| Tracker Timer | <input type="checkbox"/> ENABLED | <input type="checkbox"/> DISABLED | |
| Radio | <input type="checkbox"/> NONE | <input type="checkbox"/> Collins VHF22 | <input type="checkbox"/> Collins VHF422 |

D. Tel Comm

When the Air Phone is set to NONE, the WX MAPS prompt on the Main Menu page disappears.

| | | | |
|-----------|-------------------------------|--|--|
| Air Phone | <input type="checkbox"/> None | <input type="checkbox"/> Magnastar C2000 | <input type="checkbox"/> Flitefone 496/800 |
|-----------|-------------------------------|--|--|

Access Number _____ (Not more than 19 digits)

- NOTE:**
1. The access number is the primary telephone number shown on the Telephone Number page.
 2. Call Universal Weather and Aviation, Inc. at 1-800-231-5600 to request service for your aircraft. You must provide the aircraft identification (tail number) to be entered into their database for textual weather products.
 3. When configuring for Universal Weather Graphics, enter this phone number 1 713 944 0366 (Do not enter spaces).
 4. A "P" may be entered to insert a pause as required by some ground circuits.

UNIVERSAL[®] AVIONICS
SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

SCN 10.X

E. OOOI and Clearance Functions

- | | | |
|---------------------|----------------------------------|-----------------------------------|
| OOOI Times | <input type="checkbox"/> Enabled | <input type="checkbox"/> Disabled |
| Departure Clearance | <input type="checkbox"/> Enabled | <input type="checkbox"/> Disabled |
| Oceanic Clearance | <input type="checkbox"/> Enabled | <input type="checkbox"/> Disabled |

F. Discretes

Refer to *UL-601 Connector Pin Identification* above for pin numbers.

(1) Discretes In

UniLink Discrete Inputs

- | | | | |
|---------------|---|--|--------------------------------------|
| Discrete In 1 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |
| Discrete In 2 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |
| Discrete In 3 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |
| Discrete In 4 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |
| Discrete In 5 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |
| Discrete In 6 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |
| Discrete In 7 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |
| Discrete In 8 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |
| Discrete In 9 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |

- NOTE:**
1. Do not configure any UniLink Discrete Input for Strut. Instead, use the strut switch logic provided by the FMS.
 2. The Voice / Data option is provisional only, do not select this option for UniLink SCN 10.X.

UL-601 UNILINK INSTALLATION MANUAL

SCN 10.X

UniLink Discrete Inputs (Continued)

| | | | |
|----------------|---|--|--------------------------------------|
| Discrete In 10 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |
| Discrete In 11 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |
| Discrete In 12 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |
| Discrete In 13 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |
| Discrete In 14 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |
| Discrete In 15 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |
| Discrete In 16 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |

- NOTE:**
1. Do not configure any UniLink Discrete Input for Strut. Instead, use the strut switch logic provided by the FMS.
 2. The Voice / Data option is provisional only, do not select this option for UniLink SCN 10.X.

UL-601 UNILINK INSTALLATION MANUAL

SCN 10.X

(2) Discrete Out

UniLink Discrete Outputs

| | | | |
|-----------------|-----------------------------------|---------------------------------------|-----------------------------------|
| Discrete Out 1 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |
| Discrete Out 2 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |
| Discrete Out 3 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |
| Discrete Out 4 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |
| Discrete Out 5 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |
| Discrete Out 6 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |
| Discrete Out 7 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |
| Discrete Out 8 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |
| Discrete Out 9 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |
| Discrete Out 10 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |
| Discrete Out 11 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |
| Discrete Out 12 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |
| Discrete Out 13 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |
| Discrete Out 14 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |
| Discrete Out 15 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |
| Discrete Out 16 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |

UNIVERSAL[®]AVIONICS
SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

SCN 10.X

G. ARINC Ports

(I) ARINC Receive Ports

UniLink ARINC Receive Ports

| | | | |
|----------------------|--------------------------------------|--|--------------------------------------|
| ARINC Receive Port 1 | <input type="checkbox"/> FMS / CDU 1 | <input type="checkbox"/> FMS / CDU 2 | <input type="checkbox"/> FMS / CDU 3 |
| ARINC Receive Port 2 | <input type="checkbox"/> Not Used | <input type="checkbox"/> 740 / 744 PRT | |
| | <input type="checkbox"/> FMS / CDU 1 | <input type="checkbox"/> FMS / CDU 2 | <input type="checkbox"/> FMS / CDU 3 |
| ARINC Receive Port 3 | <input type="checkbox"/> Not Used | <input type="checkbox"/> 740 / 744 PRT | |
| | <input type="checkbox"/> FMS / CDU 1 | <input type="checkbox"/> FMS / CDU 2 | <input type="checkbox"/> FMS / CDU 3 |
| ARINC Receive Port 4 | <input type="checkbox"/> Not Used | <input type="checkbox"/> 740 / 744 PRT | |
| | <input type="checkbox"/> FMS / CDU 1 | <input type="checkbox"/> FMS / CDU 2 | <input type="checkbox"/> FMS / CDU 3 |
| ARINC Receive Port 5 | <input type="checkbox"/> Not Used | <input type="checkbox"/> 740 / 744 PRT | |
| | <input type="checkbox"/> FMS / CDU 1 | <input type="checkbox"/> FMS / CDU 2 | <input type="checkbox"/> FMS / CDU 3 |
| ARINC Receive Port 6 | <input type="checkbox"/> Not Used | <input type="checkbox"/> 740 / 744 PRT | |
| | <input type="checkbox"/> FMS / CDU 1 | <input type="checkbox"/> FMS / CDU 2 | <input type="checkbox"/> FMS / CDU 3 |
| ARINC Receive Port 7 | <input type="checkbox"/> Not Used | <input type="checkbox"/> 740 / 744 PRT | |
| | <input type="checkbox"/> FMS / CDU 1 | <input type="checkbox"/> FMS / CDU 2 | <input type="checkbox"/> FMS / CDU 3 |
| ARINC Receive Port 8 | <input type="checkbox"/> Not Used | <input type="checkbox"/> 740 / 744 PRT | |
| | <input type="checkbox"/> FMS / CDU 1 | <input type="checkbox"/> FMS / CDU 2 | <input type="checkbox"/> FMS / CDU 3 |

NOTE: An input source may be configured only once on the ARINC Receivers pages.

SCN 10.X

(2) ARINC Transmit Ports

UniLink ARINC Transmit Ports

| | | | |
|---------------|-----------------------------------|----------------------------------|-------------------------------|
| Port 1 Speed | Low (Not configurable) | | |
| Port 2 Speed | <input type="checkbox"/> Not Used | <input type="checkbox"/> Low | <input type="checkbox"/> High |
| Port 3 Speed | <input type="checkbox"/> Not Used | <input type="checkbox"/> Low | <input type="checkbox"/> High |
| Port 1 Device | <input type="checkbox"/> None | <input type="checkbox"/> 740 PRT | |
| | <input type="checkbox"/> FMS 1 | <input type="checkbox"/> FMS 2 | |
| Port 2 Device | <input type="checkbox"/> None | <input type="checkbox"/> 740 PRT | |
| | <input type="checkbox"/> FMS 1 | <input type="checkbox"/> FMS 2 | |
| Port 3 Device | <input type="checkbox"/> None | <input type="checkbox"/> 740 PRT | |
| | <input type="checkbox"/> FMS 1 | <input type="checkbox"/> FMS 2 | |

NOTE: When configuring a UniLink ARINC transmit port for "None," you must remove any <SEL> indicator by pushing the LSK for the selected device.

H. Serial Ports

(1) Port Types

UniLink Serial Port Types

| | | | |
|----------|-----------------------------------|---|--------------------------------|
| Port 1/2 | <input type="checkbox"/> Not Used | <input type="checkbox"/> RS232 | <input type="checkbox"/> RS422 |
| Port 3/4 | <input type="checkbox"/> Not Used | <input type="checkbox"/> RS232 | <input type="checkbox"/> RS422 |
| Port 5/6 | <input type="checkbox"/> Not Used | <input type="checkbox"/> RS232 | <input type="checkbox"/> RS422 |
| Port 7/8 | <input type="checkbox"/> Not Used | <input type="checkbox"/> RS232 | <input type="checkbox"/> RS422 |

NOTE: The RS232 option is provisional.
Select RS422 on any port configured for the CSDB Tune or Disp Proc device.

UNIVERSAL[®]AVIONICS
SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

SCN 10.X

(2) Port Devices

UniLink Serial Port Devices

| | | | |
|--------|-----------------------------------|------------------------------------|------------------------------------|
| Port 1 | <input type="checkbox"/> Not Used | <input type="checkbox"/> CSDB Tune | <input type="checkbox"/> Disp Proc |
| Port 2 | <input type="checkbox"/> Not Used | <input type="checkbox"/> CSDB Tune | <input type="checkbox"/> Disp Proc |
| Port 3 | <input type="checkbox"/> Not Used | <input type="checkbox"/> CSDB Tune | <input type="checkbox"/> Disp Proc |
| Port 4 | <input type="checkbox"/> Not Used | <input type="checkbox"/> CSDB Tune | <input type="checkbox"/> Disp Proc |
| Port 5 | <input type="checkbox"/> Not Used | <input type="checkbox"/> CSDB Tune | <input type="checkbox"/> Disp Proc |
| Port 6 | <input type="checkbox"/> Not Used | <input type="checkbox"/> CSDB Tune | <input type="checkbox"/> Disp Proc |
| Port 7 | <input type="checkbox"/> Not Used | <input type="checkbox"/> CSDB Tune | <input type="checkbox"/> Disp Proc |
| Port 8 | <input type="checkbox"/> Not Used | <input type="checkbox"/> CSDB Tune | <input type="checkbox"/> Disp Proc |

2. Configuration Procedures

The Flight Management System must be configured before you configure the UniLink. Refer to the appropriate technical manual for FMS configuration procedures.

NOTE: The FMS ARINC receiver port that receives data from the UL-601 must be configured for "UNILINK." Only one receiver port on each FMS may be configured for a datalink device. UniLink and AFIS are mutually exclusive. Only one may be configured

The FMS transmitter port that supplies data to the UL-601 must be configured for ARINC 429 HS.

You should perform the steps of each procedure in the order indicated by the large number in the corner of the text box.

Some of the items you may configure are limited to a small number of options that are selectable by pushing a line select key. The options appear one at a time in a set sequence and are included in the text of the step.

Other items you may configure are limited to more than a few options. These items are selected by typing the number of the option as shown in a numbered list on a display page.

For those items that have many possible configurations you will type an entry in a fill-in field. For example, the ICAO has assigned hundreds of aircraft type designators. These type designators consist of not more than four characters. On the Aircraft Configuration page the aircraft type field allows you to enter up to four characters.


If an entry field is not highlighted, push the corresponding line select key to bring the cursor highlight to the field.

UNIVERSAL[®] AVIONICS
 SYSTEMS CORPORATION
 UL-601 UNILINK INSTALLATION MANUAL

SCN 10.X

A. Configuration Edit Mode


- (1) Selecting UniLink Display Page



UNIVERSAL[®]AVIONICS
SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

SCN 10.X


(2) Edit Mode



UNIVERSAL[®] AVIONICS
SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL


SCN 10.X

B. Aircraft Configuration



SCN 10.X


C. Position Report Configuration



SCN 10.X

D. VHF Communications Configuration


(1) VHF Network Control



UNIVERSAL[®]AVIONICS
SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

SCN 10.X


(2) VHF Communications



UNIVERSAL[®]AVIONICS
SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

SCN 10.X


E. Tel Comm Configuration



- NOTE:**
1. Call Universal Weather and Aviation, Inc. at 1-800-231-5600 to request service for your aircraft. You must provide the aircraft identification (tail number) to be entered into their database for textual weather products.
 2. When configuring for Universal Weather Graphics, enter this phone number 1 713 944 0366 (Do not enter spaces)

SCN 10.X

F. OOOI and Clearance Functions




UNIVERSAL[®] AVIONICS
 SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

SCN 10.X

G. Discretes Configuration


(I) Discrete In



UNIVERSAL[®] AVIONICS
 SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

SCN 10.X

(2) Discrete Out




NOTE: For the UL-601 Radio option, use Discrete Out 1 for Push to Talk (PTT).

UNIVERSAL[®] AVIONICS
 SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

SCN 10.X


H. ARINC Ports Configuration

(I) ARINC Receive Ports



ARINC Receive Port Configuration — Sheet 1 of 2

SCN 10.X




ARINC Receive Port Configuration — Sheet 2 of 2

UNIVERSAL[®] AVIONICS
 SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

SCN 10.X

(2) ARINC Transmit Ports




ULC ARINC TRANSMIT 10

UNIVERSAL[®]AVIONICS
SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

SCN 10.X

I. Serial Ports Configuration

(1) Port Types




NOTE: For the UL-601 Radio option, select Port 7/8 as RS422.

UL-601 UNILINK INSTALLATION MANUAL

SCN 10.X

(2) Port Devices



NOTE: For the UL-601 Radio option, press NEXT and use Port 8 as CSDB Tune.

SCN 11.X

System Data Installation For SCN 11.X

1. Configuration Worksheets

Universal Avionics Systems Corporation recommends that the following worksheets be completed in order to easily program the UniLink configuration module. One set of worksheets should be filled out. Fill in the blanks and check the appropriate boxes based on the wiring of the aircraft and its set of avionics components. Further, these worksheets may be submitted along with other approval paperwork. A copy of these worksheets should be filed along with the aircraft paper work for future reference.

NOTE: You are hereby authorized to reproduce these worksheets as well as the configuration module programming procedures if desired.

A. Aircraft Information

Date: _____

Company Address: _____

A/C Manufacturer: _____

A/C Model No.: _____

A/C Serial No.: _____

ICAO Aircraft Type: _____ (Not more than four characters)

A/C Registration No.: _____ (Not more than seven characters)

Airline ID _____ / _____ (Two characters and three characters)

- NOTE:**
1. The last three items above are required to configure the UniLink.
 2. Refer to ICAO Doc 8643 for a list of assigned aircraft type designators.
 3. If Universal Weather is the ground data service provider (agency), use UV for the two character code and enter UVA for the three character code

B. Position Report

These settings control automatic reporting of aircraft position data to the ground service provider for flight following and reporting. Many service providers recommend disabling automatic reporting. Set the options as recommended by or per agreement with your service provider.

| | | |
|---------------------|----------------------------------|-----------------------------------|
| In Air Automatic | <input type="checkbox"/> ENABLED | <input type="checkbox"/> DISABLED |
| In Air Interval | _____ | Up to Two digits |
| On Ground Automatic | <input type="checkbox"/> ENABLED | <input type="checkbox"/> DISABLED |
| On Ground Interval | _____ | Up to Two digits |

UNIVERSAL[®] AVIONICS
SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

SCN 11.X

C. VHF Communications

(1) Network Control

These settings determine which ACARS Data Link Service Providers will be accessed automatically by UniLink. These defaults can be overridden by the operator on the Network Control Page.

| | | |
|---------|-----------------------------|------------------------------|
| ARINC | <input type="checkbox"/> ON | <input type="checkbox"/> OFF |
| AIR CAN | <input type="checkbox"/> ON | <input type="checkbox"/> OFF |
| SITA | <input type="checkbox"/> ON | <input type="checkbox"/> OFF |
| AVICOM | <input type="checkbox"/> ON | <input type="checkbox"/> OFF |

(2) Timers and Radio

The contact timer is used to verify that the current VHF frequency is still usable when the channel has not had any uplink traffic received for a period of time. Enable this option if VHF is the only medium being configured.

If NONE is selected for Radio, then the FLT INFO SRV prompt on the Main Menu is removed and VHF only message functions are no longer accessible.

The tracker timer is used to provide flight following information to the service provider. This setting should be disabled unless your service provider says otherwise.

| | | | |
|---------------|----------------------------------|--|---|
| Contact Timer | <input type="checkbox"/> ENABLED | <input type="checkbox"/> DISABLED | |
| Tracker Timer | <input type="checkbox"/> ENABLED | <input type="checkbox"/> DISABLED | |
| Radio | <input type="checkbox"/> NONE | <input type="checkbox"/> Collins VHF22 | <input type="checkbox"/> Collins VHF422 |
| Ident | <input type="checkbox"/> COMM 1 | <input type="checkbox"/> COMM 2 | <input type="checkbox"/> ALL CALL |
| Access | <input type="checkbox"/> SHARED | <input type="checkbox"/> DEDICATED | |

UNIVERSAL[®]AVIONICS
SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

SCN 11.X

F. Discretes

(1) Discretes In

UniLink Discrete Inputs

| | | | |
|----------------|---|--|--------------------------------------|
| Discrete In 1 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |
| Discrete In 2 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |
| Discrete In 3 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |
| Discrete In 4 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |
| Discrete In 5 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |
| Discrete In 6 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |
| Discrete In 7 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |
| Discrete In 8 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |
| Discrete In 9 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |
| Discrete In 10 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |
| Discrete In 11 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |

- NOTE:**
1. Do not configure any UniLink Discrete Input for Strut. Instead, use the strut switch logic provided by the FMS.
 2. The Voice / Data option is provisional only, do not select this option for UniLink SCN 11.X.
 3. Refer to *UL-601 Connector Pin Identification* above for pin numbers.

UL-601 UNILINK INSTALLATION MANUAL

SCN 11.X

UniLink Discrete Input (Continued)

| | | | |
|----------------|---|--|--------------------------------------|
| Discrete In 12 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |
| Discrete In 13 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |
| Discrete In 14 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |
| Discrete In 15 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |
| Discrete In 16 | <input type="checkbox"/> Not Used | <input type="checkbox"/> Doors | <input type="checkbox"/> Brakes |
| | <input type="checkbox"/> Strut | <input type="checkbox"/> Voice / Data | <input type="checkbox"/> Dial Status |

- NOTE:**
1. Do not configure any UniLink Discrete Input for Strut. Instead, use the strut switch logic provided by the FMS.
 2. The Voice / Data option is provisional only, do not select this option for UniLink SCN 11.X.
 3. Refer to *UL-601 Connector Pin Identification* above for pin numbers.

SCN 11.X

(2) Discrete Out

UniLink Discrete Outputs

| | | | |
|----------------------------------|--------------------------------------|---------------------------------------|------------------------------------|
| <u>Discrete Out 1</u> | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |
| <input type="checkbox"/> PTT PLS | <input type="checkbox"/> DFS PRT SEL | <input type="checkbox"/> VOX ANNUNC | <input type="checkbox"/> VHF NOCOM |
| <u>Discrete Out 2</u> | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |
| <input type="checkbox"/> PTT PLS | <input type="checkbox"/> DFS PRT SEL | <input type="checkbox"/> VOX ANNUNC | <input type="checkbox"/> VHF NOCOM |
| <u>Discrete Out 3</u> | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |
| <input type="checkbox"/> PTT PLS | <input type="checkbox"/> DFS PRT SEL | <input type="checkbox"/> VOX ANNUNC | <input type="checkbox"/> VHF NOCOM |
| <u>Discrete Out 4</u> | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |
| <input type="checkbox"/> PTT PLS | <input type="checkbox"/> DFS PRT SEL | <input type="checkbox"/> VOX ANNUNC | <input type="checkbox"/> VHF NOCOM |
| <u>Discrete Out 5</u> | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |
| <input type="checkbox"/> PTT PLS | <input type="checkbox"/> DFS PRT SEL | <input type="checkbox"/> VOX ANNUNC | <input type="checkbox"/> VHF NOCOM |
| <u>Discrete Out 6</u> | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |
| <input type="checkbox"/> PTT PLS | <input type="checkbox"/> DFS PRT SEL | <input type="checkbox"/> VOX ANNUNC | <input type="checkbox"/> VHF NOCOM |
| <u>Discrete Out 7</u> | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |
| <input type="checkbox"/> PTT PLS | <input type="checkbox"/> DFS PRT SEL | <input type="checkbox"/> VOX ANNUNC | <input type="checkbox"/> VHF NOCOM |
| <u>Discrete Out 8</u> | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |
| <input type="checkbox"/> PTT PLS | <input type="checkbox"/> DFS PRT SEL | <input type="checkbox"/> VOX ANNUNC | <input type="checkbox"/> VHF NOCOM |
| <u>Discrete Out 9</u> | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |
| <input type="checkbox"/> PTT PLS | <input type="checkbox"/> DFS PRT SEL | <input type="checkbox"/> VOX ANNUNC | <input type="checkbox"/> VHF NOCOM |
| <u>Discrete Out 10</u> | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |
| <input type="checkbox"/> PTT PLS | <input type="checkbox"/> DFS PRT SEL | <input type="checkbox"/> VOX ANNUNC | <input type="checkbox"/> VHF NOCOM |
| <u>Discrete Out 11</u> | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |
| <input type="checkbox"/> PTT PLS | <input type="checkbox"/> DFS PRT SEL | <input type="checkbox"/> VOX ANNUNC | <input type="checkbox"/> VHF NOCOM |
| <u>Discrete Out 12</u> | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |
| <input type="checkbox"/> PTT PLS | <input type="checkbox"/> DFS PRT SEL | <input type="checkbox"/> VOX ANNUNC | <input type="checkbox"/> VHF NOCOM |
| <u>Discrete Out 13</u> | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |
| <input type="checkbox"/> PTT PLS | <input type="checkbox"/> DFS PRT SEL | <input type="checkbox"/> VOX ANNUNC | <input type="checkbox"/> VHF NOCOM |

UniLink Discrete Outputs (Continued)

Discrete Out 14

- | | | | |
|----------------------------------|--------------------------------------|---------------------------------------|------------------------------------|
| <input type="checkbox"/> PTT PLS | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |
| | <input type="checkbox"/> DFS PRT SEL | <input type="checkbox"/> VOX ANNUNC | <input type="checkbox"/> VHF NOCOM |

Discrete Out 15

- | | | | |
|----------------------------------|--------------------------------------|---------------------------------------|------------------------------------|
| <input type="checkbox"/> PTT PLS | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |
| | <input type="checkbox"/> DFS PRT SEL | <input type="checkbox"/> VOX ANNUNC | <input type="checkbox"/> VHF NOCOM |

Discrete Out 16

- | | | | |
|----------------------------------|--------------------------------------|---------------------------------------|------------------------------------|
| <input type="checkbox"/> PTT PLS | <input type="checkbox"/> Not Used | <input type="checkbox"/> Push To Talk | <input type="checkbox"/> Tel Data |
| | <input type="checkbox"/> DFS PRT SEL | <input type="checkbox"/> VOX ANNUNC | <input type="checkbox"/> VHF NOCOM |

UL-601 UNILINK INSTALLATION MANUAL

SCN 11.X

G. ARINC Ports

(I) ARINC Receive Ports

UniLink ARINC Receive Ports

| | | | |
|----------------------|---------------------------------------|--|--------------------------------------|
| ARINC Receive Port 1 | <input type="checkbox"/> FMS / CDU 1 | <input type="checkbox"/> FMS / CDU 2 | <input type="checkbox"/> FMS / CDU 3 |
| ARINC Receive Port 2 | <input type="checkbox"/> Not Used | <input type="checkbox"/> 740 / 744 PRT | |
| | <input type="checkbox"/> FMS / CDU 1 | <input type="checkbox"/> FMS / CDU 2 | <input type="checkbox"/> FMS / CDU 3 |
| | <input type="checkbox"/> VHF 422 TUNE | <input type="checkbox"/> TR 853 TUNE | <input type="checkbox"/> 741 SATCOM |
| ARINC Receive Port 3 | <input type="checkbox"/> Not Used | <input type="checkbox"/> 740 / 744 PRT | |
| | <input type="checkbox"/> FMS / CDU 1 | <input type="checkbox"/> FMS / CDU 2 | <input type="checkbox"/> FMS / CDU 3 |
| | <input type="checkbox"/> VHF 422 TUNE | <input type="checkbox"/> TR 853 TUNE | <input type="checkbox"/> 741 SATCOM |
| ARINC Receive Port 4 | <input type="checkbox"/> Not Used | <input type="checkbox"/> 740 / 744 PRT | |
| | <input type="checkbox"/> FMS / CDU 1 | <input type="checkbox"/> FMS / CDU 2 | <input type="checkbox"/> FMS / CDU 3 |
| | <input type="checkbox"/> VHF 422 TUNE | <input type="checkbox"/> TR 853 TUNE | <input type="checkbox"/> 741 SATCOM |
| ARINC Receive Port 5 | <input type="checkbox"/> Not Used | <input type="checkbox"/> 740 / 744 PRT | |
| | <input type="checkbox"/> FMS / CDU 1 | <input type="checkbox"/> FMS / CDU 2 | <input type="checkbox"/> FMS / CDU 3 |
| | <input type="checkbox"/> VHF 422 TUNE | <input type="checkbox"/> TR 853 TUNE | <input type="checkbox"/> 741 SATCOM |
| ARINC Receive Port 6 | <input type="checkbox"/> Not Used | <input type="checkbox"/> 740 / 744 PRT | |
| | <input type="checkbox"/> FMS / CDU 1 | <input type="checkbox"/> FMS / CDU 2 | <input type="checkbox"/> FMS / CDU 3 |
| | <input type="checkbox"/> VHF 422 TUNE | <input type="checkbox"/> TR 853 TUNE | <input type="checkbox"/> 741 SATCOM |
| ARINC Receive Port 7 | <input type="checkbox"/> Not Used | <input type="checkbox"/> 740 / 744 PRT | |
| | <input type="checkbox"/> FMS / CDU 1 | <input type="checkbox"/> FMS / CDU 2 | <input type="checkbox"/> FMS / CDU 3 |
| | <input type="checkbox"/> VHF 422 TUNE | <input type="checkbox"/> TR 853 TUNE | <input type="checkbox"/> 741 SATCOM |
| ARINC Receive Port 8 | <input type="checkbox"/> Not Used | <input type="checkbox"/> 740 / 744 PRT | |
| | <input type="checkbox"/> FMS / CDU 1 | <input type="checkbox"/> FMS / CDU 2 | <input type="checkbox"/> FMS / CDU 3 |
| | <input type="checkbox"/> VHF 422 TUNE | <input type="checkbox"/> TR 853 TUNE | <input type="checkbox"/> 741 SATCOM |

NOTE: An input source may be configured only once on the ARINC Receivers pages.

UNIVERSAL[®]AVIONICS
SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

SCN 11.X

(2) ARINC Transmit Ports

UniLink ARINC Transmit Ports

- | | | | |
|---------------|---|--|--------------------------------|
| Port 1 Speed | Low (Not configurable) | | |
| Port 2 Speed | <input type="checkbox"/> Not Used | <input type="checkbox"/> Low | <input type="checkbox"/> High |
| Port 3 Speed | <input type="checkbox"/> Not Used | <input type="checkbox"/> Low | <input type="checkbox"/> High |
| Port 1 Device | <input type="checkbox"/> None | <input type="checkbox"/> 740 PRT | |
| | <input type="checkbox"/> FMS 1 | <input type="checkbox"/> FMS 2 | <input type="checkbox"/> FMS 3 |
| | <input type="checkbox"/> 741 SATCOM | <input type="checkbox"/> A716 TUNE BUS | |
| | <input type="checkbox"/> TR853 TUNE BUS | <input type="checkbox"/> VHF422 TUNE BUS | |
| Port 2 Device | <input type="checkbox"/> None | <input type="checkbox"/> 740 PRT | |
| | <input type="checkbox"/> FMS 1 | <input type="checkbox"/> FMS 2 | <input type="checkbox"/> FMS 3 |
| | <input type="checkbox"/> 741 SATCOM | <input type="checkbox"/> A716 TUNE BUS | |
| | <input type="checkbox"/> TR853 TUNE BUS | <input type="checkbox"/> VHF422 TUNE BUS | |
| Port 3 Device | <input type="checkbox"/> None | <input type="checkbox"/> 740 PRT | |
| | <input type="checkbox"/> FMS 1 | <input type="checkbox"/> FMS 2 | <input type="checkbox"/> FMS 3 |
| | <input type="checkbox"/> 741 SATCOM | <input type="checkbox"/> A716 TUNE BUS | |
| | <input type="checkbox"/> TR853 TUNE BUS | <input type="checkbox"/> VHF422 TUNE BUS | |

NOTE: When configuring a UniLink ARINC transmit port for "None," you must remove any <SEL> indicator by pushing the LSK for the selected device.

SCN 11.X

H. Serial Ports

(1) Port Types

UniLink Serial Port Types

| | | | |
|----------|-----------------------------------|---|--------------------------------|
| Port 1/2 | <input type="checkbox"/> Not Used | <input type="checkbox"/> RS232 | <input type="checkbox"/> RS422 |
| Port 3/4 | <input type="checkbox"/> Not Used | <input type="checkbox"/> RS232 | <input type="checkbox"/> RS422 |
| Port 5/6 | <input type="checkbox"/> Not Used | <input type="checkbox"/> RS232 | <input type="checkbox"/> RS422 |
| Port 7/8 | <input type="checkbox"/> Not Used | <input type="checkbox"/> RS232 | <input type="checkbox"/> RS422 |

NOTE: The RS232 option is provisional.
Select RS422 on any port configured for the CSDB Tune or Disp Proc device.

(2) Port Devices

UniLink Serial Port Devices

| | | | |
|--------|-----------------------------------|------------------------------------|------------------------------------|
| Port 1 | <input type="checkbox"/> Not Used | <input type="checkbox"/> CSDB Tune | <input type="checkbox"/> Disp Proc |
| Port 2 | <input type="checkbox"/> Not Used | <input type="checkbox"/> CSDB Tune | <input type="checkbox"/> Disp Proc |
| Port 3 | <input type="checkbox"/> Not Used | <input type="checkbox"/> CSDB Tune | <input type="checkbox"/> Disp Proc |
| Port 4 | <input type="checkbox"/> Not Used | <input type="checkbox"/> CSDB Tune | <input type="checkbox"/> Disp Proc |
| Port 5 | <input type="checkbox"/> Not Used | <input type="checkbox"/> CSDB Tune | <input type="checkbox"/> Disp Proc |
| Port 6 | <input type="checkbox"/> Not Used | <input type="checkbox"/> CSDB Tune | <input type="checkbox"/> Disp Proc |
| Port 7 | <input type="checkbox"/> Not Used | <input type="checkbox"/> CSDB Tune | <input type="checkbox"/> Disp Proc |
| Port 8 | <input type="checkbox"/> Not Used | <input type="checkbox"/> CSDB Tune | <input type="checkbox"/> Disp Proc |

SCN 11.X

2. Configuration Procedures

The Flight Management System must be configured before you configure the UniLink. Refer to the appropriate technical manual for FMS configuration procedures.

NOTE: The FMS ARINC receiver port that receives data from the UL-601 must be configured for "UNILINK." Only one receiver port on each FMS may be configured for a datalink device. UniLink and AFIS are mutually exclusive. Only one may be configured

The FMS transmitter port that supplies data to the UL-601 must be configured for ARINC 429 HS.

You should perform the steps of each procedure in the order indicated by the large number in the corner of the text box.

Some of the items you may configure are limited to a small number of options that are selectable by pushing a line select key. The options appear one at a time in a set sequence and are included in the text of the step.

Other items you may configure are limited to more than a few options. These items are selected by typing the number of the option as presented in a numbered list.

For those items that have many possible configurations you will type an entry in a fill-in field. For example, the ICAO has assigned hundreds of aircraft type designators. These type designators consist of not more than four characters. On the Aircraft Configuration page the aircraft type field allows you to enter up to four characters.


If an entry field is not highlighted, push the corresponding line select key to bring the cursor highlight to the field.

UNIVERSAL[®]AVIONICS
SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

SCN 11.X

A. Configuration Edit Mode


- (1) Selecting UniLink Display Page




UNIVERSAL[®]AVIONICS
SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

SCN 11.X

(2) Edit Mode




B. Aircraft Configuration



UNIVERSAL[®]AVIONICS
SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

SCN 11.X

C. Position Report Configuration




UNIVERSAL[®] AVIONICS
 SYSTEMS CORPORATION
 UL-601 UNILINK INSTALLATION MANUAL

SCN 11.X

D. VHF Communications Configuration


(1) Network Control



UNIVERSAL[®] AVIONICS
 SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

SCN 11.X

(2) Radio Configuration




NOTE: For the UL-601 Radio option, select Collins VHF422, COM1 and Dedicated.

UNIVERSAL[®]AVIONICS
SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

SCN 11.X


E. Tel Comm Configuration



- NOTE:**
1. Call Universal Weather and Aviation, Inc. at 1-800-231-5600 to request service for your aircraft. You must provide the aircraft identification (tail number) to be entered into their database for textual weather products.
 2. When configuring for Universal Weather Graphics, enter this phone number 1 713 944 0366 (Do not enter spaces)

SCN 11.X

F. OOOI and Clearance Functions




ULC OOOI CLEARANCE 11

UL-601 UNILINK INSTALLATION MANUAL

SCN 11.X

G. Discretes Configuration


(1) Discrete In



UL-601 UNILINK INSTALLATION MANUAL

SCN 11.X

(2) Discrete Out




NOTE: For the UL-601 Radio option, use Discrete Out 1 for Push to Talk (PTT).

UNIVERSAL[®] AVIONICS
 SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

SCN 11.X

H. ARINC Ports Configuration


(1) ARINC Receive Ports



ULC ARINC RECEIVE 1of2 11

UNIVERSAL[®]AVIONICS
SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

SCN 11.X




ARINC Receive Port Configuration — Sheet 2 of 2

UNIVERSAL[®] AVIONICS
 SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

SCN 11.X

(2) ARINC Transmit Ports




ULC ARINC TRANSMIT 11

SCN 11.X

I. Serial Ports Configuration


(1) Port Types



UNIVERSAL[®] AVIONICS
 SYSTEMS CORPORATION
UL-601 UNILINK INSTALLATION MANUAL

SCN 11.X

(2) Port Devices



NOTE: For the UL-601 Radio option, press NEXT and select Port 8 as CSDB Tune.

Checkout Procedures

1. UniLink Ground Checkout Procedures

A. Conditions of Test

The following subparagraphs define conditions under which tests, specified below, shall be conducted.

(1) Safety Precautions

User shall follow all appropriate safety precautions.

(2) Power Input

Unless otherwise specified, tests shall be conducted with the equipment powered by the aircraft's electrical power generating system.

(3) Associated Equipment or Systems

Unless otherwise specified, all aircraft electrically operated equipment and systems shall be turned on before conducting interference tests.

(4) Environment

During tests, the equipment shall not be subjected to environmental conditions that exceed those specified by the equipment manufacturer.

(5) Adjustment of Equipment

Circuits of the equipment under test shall be properly aligned and otherwise adjusted in accordance with the manufacturers recommended practices prior to application of the specified tests.

(6) Warm-up Period

No warm-up period required.

B. UniLink to FMS ARINC 429 Communications

(1) Verify FMS DATA page 1/n shows an active UNILINK prompt.

(2) From FMS DATA page 1/n select UNILINK and verify a UniLink page is displayed.

(3) Verify that after power up at least one non-default UniLink configuration item is displayed as active.

(4) Enter UniLink configuration and make a benign configuration modification. STORE updated configuration.

(5) Following STORE-configuration-reboot of UniLink, verify configuration modification of (4) is retained.

C. UniLink to Display Processor RS-422 Communications

This procedure applies only to the UNS-1C and FMSs using the 5" FPCDU.

(1) From the UniLink MAINTENACE menu select IMAGE TEST.

(2) Verify UniLink annunciates that the Display Processor received the test image.

(3) Verify the Display Processor can display test image.

UL-601 UNILINK INSTALLATION MANUAL

D. **UL-601 VHF Communications Interface Test**

VHF datalink service coverage on the ground is limited to airports that participate in digital PDC. Coverage may be affected by ground obstacles and is limited by the location of the VHF ground antenna.

- (1) Verify interconnect wiring is per the interface drawings.
- (2) Verify that the UniLink discrete output #1 is configured for Push to Talk.
- (3) Verify that the VHF COMM radio and tuning bus are properly configured
- (4) Ensure that circuit breakers supplying power to the UL-601, RS422, and the FMS are closed.
- (5) Turn on and Initialize the FMS system.
- (6) Turn on one of the aircraft's VHF Comm transceivers and verify audio from the receiver is available by performing a squelch test.
- (7) With the FMS Data Page 1 displayed on the CDU, push UNILINK [3R]. The UniLink Main Menu will appear.
- (8) Push MISC [4L]. The UniLink Miscellaneous page will appear.
- (9) Push COMM CONTROL [1L]. The Comm Control page will appear.
- (10) Push VHF NETWORK [2L]. The VHF Network Control page will appear.
- (11) Verify that the appropriate network is ON.
- (12) Push FREQ [4R]. The VHF Frequencies page will appear.
- (13) Note which VHF frequency has been selected for use by UniLink as indicated by the <SEL> display.
- (14) Tune the aircraft's VHF Comm transceiver to the UniLink selected frequency to monitor the UniLink transmission bursts.
- (15) On the FMS UniLink VHF FREQUENCY page, push one of the left side line select keys to select a different VHF frequency, then re-select the frequency tuned on the aircraft's VHF Comm transceiver. You should hear an audible chirp received by the VHF Comm when the UniLink transmits a burst. You may also hear other VHF transmissions by other aircraft in the area. The chirp will be an indication that the UniLink has tuned the VHF transceiver and that the push to talk circuit is OK.
- (16) If the airport ground location is served by VHF network coverage for digital Pre-Departure Clearance and digital ATIS, a request for ATIS information can be performed on the ground, otherwise, the aircraft will have to be airborne to be within VHF coverage. To request ATIS, from the main UniLink Menu, push the FL INFO SRV line select key, then the ATIS line select key. Push AIRPORT [2L] and type KORD and push [ENTER].

UL-601 UNILINK INSTALLATION MANUAL

E. Telephony Modem Tip and Ring Communications for Magnastar

NOTE: In order to perform the following tests a telephone line analyzer must be used.

- (1) Verify the on-hook tip and ring voltage is greater than -15.0 VDC.
- (2) Verify the on-hook tip and ring loop current is zero milliamperes DC.
- (3) SEND a weather graphic map uplink request.
- (4) Verify weather graphic map uplink request is SENT.
- (5) While telephony modem is off-hook verify tip and ring voltage is less than 10.0 VDC.
- (6) While telephony modem is off-hook verify tip and ring loop current is greater than or equal to 30.0 milliamperes DC and less than or equal to 80.0 milliamperes DC.
- (7) Verify weather graphic is received.

F. Checking the UL-601 to Magnastar Interface.

Airborne telephone service coverage on the ground is limited to a very few airports. In most cases, it will not be possible to establish a telephony connection below 8,000 ft. The following procedure will verify the interface between the UL-600 and the airborne telephone system only.

- (1) Verify the Aircraft wiring per the interface drawings.
- (2) Ensure that circuit breakers supplying power to the UL-601, Magnastar, and the FMS are closed.
- (3) Turn on and Initialize the FMS system.
- (4) On the Magnastar hand set select "nine" for "setup." If the main menu is not displayed push [+].
- (5) Select "seven" for "Remote program." The message "Flash hook the station you wish to setup" will be displayed.
- (6) With the FMS Data Page 1 displayed on the CDU, push UNILINK [3R]. The UniLink Main Menu will appear.
- (7) Push WX MAPS [1R]. The Weather Maps Page will appear.
- (8) Push WX DPCT [2R]. The Weather Depiction Page will appear.
- (9) Push SEND [4R].
- (10) When the request is received at the Magnastar the message "Remote station has been assigned" will be displayed on the hand set. This indicates correct connectivity between the UL-601 and the CDBR-2. A TEL NOCOMM advisory on the FMS is normal.

UL-601 UNILINK INSTALLATION MANUAL

G. Telephony Modem Tip and Ring Communications for Flitefone 800

NOTE: In order to perform the following tests a telephone line analyzer must be used.

- (1) Verify the on-hook tip and ring voltage is greater than -15.0 VDC.
- (2) Verify the on-hook tip and ring loop current is zero milliamperes DC.
- (3) SEND a weather graphic map uplink request.
- (4) Verify that the configured TEL DATA discrete output goes to less than 1.0 milliseconds, +1-10%.
- (5) Within 30 seconds of Step (4), ground the configured DIAL NOW discrete input.
- (6) Verify weather graphic map uplink request is SENT.
- (7) While telephony modem is off-hook verify tip and ring voltage is less than 10.0 VDC.
- (8) While telephony modem is off-hook verify tip and ring loop current is greater than or equal to 30.0 milliamperes DC and less than or equal to 80.0 milliamperes DC.
- (9) Verify weather graphic is received.
- (10) Remove the configured DIAL NOW ground applied to the discrete input in Step(5) above.
- (11) Verify received graphic can be displayed.

2. UniLink Flight Checkout Procedures

- (1) **Displayed Data Readability**
Determine that normal conditions of flight do not significantly affect the readability of displayed data.
- (2) **Interference Effects**
For aircraft equipment and systems that can be checked only in flight, determine that operationally significant conducted or radiated interference does not exist. Evaluate all reasonable combinations of control settings and operating modes. Operate communications and navigation equipment on the low, high and at least one but preferably four mid-band frequencies.
- (3) **Flight Tests**

NOTE: Execution of the following tests are dependent on the installation of ACARS VHF Comm radio and the installation of an airborne telephone system. Tests relying on a particular communication system should not be performed when that system is not installed. Also note that a Data Service Provider service arrangement must be in place in order to receive data uplinks.

| Test Condition | Expected Result | Pass | Fail |
|--|---|------|------|
| ATS MESSAGING (VHF ACARS ONLY) | | | |
| Request a TWIP report for KORD. | Verify TWIP is received and available for display. | | |
| GRAPHICAL WX (Telephony only) | | | |
| Select and send a COMP RADAR. | Verify COMP RADAR request is sent. | | |
| Verify COMP RADAR image is received, annunciated And displayed. | | | |
| Select and send multiple weather map requests; TOPS & MVMT, SIG WX, WX DPCT and WINDS. | Verify request is SENT. | | |
| Verify requested images are received annunciated and displayed. | | | |
| Select and send a text weather TERMINAL WX request. | Verify request is SENT. | | |
| Verify TERMINAL WX is received, annunciated and displayed. | | | |
| Select and send multiple text weather | Verify request is SENT. | | |
| Requests; SIGMETS, PIREPS and WINDS ALOFT | Verify requested reports are received, annunciated and displayed. | | |