



BLADE MANUAL

Software Version 39.6

Document Version 1.14

Date 25 January 2015

1. G10V SYSTEM OVERVIEW.....	4
1.1. DESCRIPTION.....	4
1.2. SPECIFICATIONS.....	4
1.2.1. TRANSCEIVER.....	4
1.2.2. RECEIVER.....	4
1.2.3. POWER SUPPLY.....	4
1.3. TABLE: SYSTEM / DETECTION / NOISE.....	5
2. HARDWARE.....	6
2.1. TRANSCEIVER BOARD.....	6
2.2. RX BOARD.....	7
2.3. POWER SUPPLY.....	8
3. QUICK TUNING.....	9
3.1. QUICK INSTALLATION.....	9
3.1.1. PREVIOUS.....	9
3.1.2. SYSTEM INSTALLATION.....	9
3.2. TROUBLESHOOTING.....	9
3.2.1. NO DETECTION.....	9
3.2.2. TOO MUCH DETECTION.....	9
3.2.3. FALSE ALARM.....	9
3.2.4. MAKES OTHER SYSTEMS FALSE ALARM.....	9
3.3. SYNCHRONIZATION PROBLEM.....	10
3.4. NOISE PROBLEM.....	11
3.5. DEAD TRANSMITTER.....	13
3.6. DEAD RECEIVER.....	14
3.7. FALSE ALARM (OR UNKNOWN ALARM).....	15
4. CONFIGURATION.....	16
4.1. CONNECTION METHOD.....	16
4.1.1. ANTENNA CABLES AND CONNECTION.....	16
MATERIAL.....	16
PROCESS.....	16
4.1.2. POWER SUPPLY CABLE AND CONNECTION.....	17
MATERIAL.....	17
PROCESS.....	17
4.2. CONFIGURATION EXAMPLES.....	18
4.2.1. TRANSCEIVER BOARDS.....	18
4.2.2. RECEIVER BOARDS.....	18
4.2.3. DUAL SYSTEM CONFIGURATION (RX-TX).....	19
4.2.4. SPLIT SYSTEM CONFIGURATION (RX-TX-RX).....	20
5. SOFTWARE.....	21
5.1. INSTALLATION PROCEDURE.....	21
5.2. CONNECT.....	22
5.2.1. RS232 PORT.....	22
5.2.2. ANALOG MODEM.....	23
5.2.3. GSM MODEM.....	24
5.2.4. INTERNET MODULE.....	25
5.2.5. HOW TO KNOW THE COM PORT.....	26
5.3. ACCESS.....	27
5.4. MAIN MENU.....	29
5.4.1. SETTINGS.....	29
5.4.2. CONNECT /CONNECTED.....	31
5.4.3. DISCONNECT.....	31
5.4.4. PARAMETERS.....	31
5.4.5. COMMANDS TRANSMISSION.....	31
5.4.6. AUTOTUNING.....	32
5.4.7. REPORT.....	34

5.4.7.1 SAVE REPORT.....	34
5.4.7.1 SAVE REPORT.....	35
5.4.8. DATA MINING.....	36
TABLE DATA.....	37
CHART DATA.....	38
SYSTEMS DATA.....	39
5.4.9. MANUAL.....	40
5.4.10. LANGUAGES.....	40
5.4.11. UPDATE.....	41
5.5. SYSTEMS.....	42
5.6. SYSTEM TAB.....	43
5.6.1. STATUS.....	43
5.6.2. SYSTEM TOTALS.....	43
5.6.3. POWER TIMES.....	44
5.6.4. LEDS.....	44
5.6.5. CLOCK.....	44
SUMMER / WINTER TIME (DAYLIGHT SAVING TIME).....	44
5.6.6. SAVE ENERGY.....	45
STOP HOURS.....	45
STOP DAYS.....	45
GREEN FUNCTION.....	45
5.6.7. CONFIGURATION OPTIONS.....	46
5.7. TRANSMITTER TAB.....	47
5.7.1. START / STOP TX.....	47
5.7.2. TX LOOPS.....	47
5.7.3. MULTIMONO.....	47
5.7.4. DISCOVERY TOOL.....	47
FIELD SITUATIONS.....	51
5.7.5. TRANSCEIVER STATUS.....	53
5.8. RECEIVER TAB.....	54
5.8.1. GAIN.....	54
5.8.2. THRESHOLD.....	54
5.8.3. START/STOP RECEIVER LOOPS.....	55
5.8.4. ANTI NOISE ALGORITHMS.....	55
5.8.5. SIGNAL AND NOISE.....	56
5.9. PEOPLE COUNTER TAB.....	57
5.9.1. IR-RX MODULES (ACC-PCA-G10V PEOPLE COUNTER A).....	57
5.9.2. IR-TX MODULES (ACC-PCB-G10V PEOPLE COUNTER B).....	58
5.9.2.1. IR POWER TRANSMISSION.....	58
5.9.3. PEOPLE COUNTER INSTALLATION.....	59
PING PONG TRANSMISSION.....	60
AUTO CONFIGURATION.....	60
5.10. ALARMS TAB.....	62
5.10.1. SOUND OPTIONS.....	62
5.10.2. PAGER OPTIONS.....	62
5.10.3. ALARM TYPES.....	63
5.11. CUSTOM SETUP.....	64
5.11.1. CUSTOMIZING INSTALLATION PROCESS.....	64
5.11.2. CUSTOMIZING SOFTWARE ICON.....	64
6. SAFETY AND DECLARATIONS.....	65
6.1. SAFETY GUIDELINES.....	65
6.2. FCC DISCLAIMER.....	65

1. G10V SYSTEM OVERVIEW

1.1. DESCRIPTION

USS G10V AM systems can detect any 58 kHz resonant circuit or any acousto magnetic tag passing through the detection area.

The system includes Digital Processing System (DPS) in order to achieve great detection range, filtering noise and avoiding possible false alarms.

The tuning is done easily via powerful software. The system can be accessed via laptop and optionally via Internet, Analog MODEM, GSM MODEM, etc....

USS 58 kHz systems can have several configurations:

Mono-antenna:	1 Transceiver pedestal
Dual System:	2 pedestals (TX-RX)
Split System:	3 pedestals (RX-TX-RX)

1.2. SPECIFICATIONS

1.2.1. TRANSCIVER

ELECTRICAL

Operating Frequency 58 kHz

Transmit Burst Duration 1.5 ms

Transmit Burst Repetition Rates

50Hz 75 or 50 pulses/second (TX burst 1.5ms)

60Hz 90 or 60 pulses/second (TX burst 1.5ms)

Transmit coil Resistance 1.5 Ohm

1.2.2. RECEIVER

ELECTRICAL

Operating Frequency 58 kHz

Inputs 2

Receive coil Resistance 1.5 Ohm

1.2.3. POWER SUPPLY

ELECTRICAL **PS-G10V-2-110**

Input 110Vac

Output 2 Outputs (12V–0–12V)

Fuse 2A 250V Slow

ENVIROMENTAL

R. Humidity 0 to 85% non condensing

Operating Temperature 0° to 50° C

Noise level 30dBm

1.3. TABLE: SYSTEM / DETECTION / NOISE

The system will perform as follows:

DR Label, Gain X5, Threshold 40 (SOLARIS SYSTEM)

LEDS BLINKING	MONO (*)	DUAL
0/1	110 cm	220 cm
1/2	100 cm	200 cm
2/3	85 cm	170 cm


Super pencil ferrite tag, Gain X5, Threshold 40

LEDS BLINKING	MONO (*)	DUAL
0/1	160 cm	350 cm
1/2	150 cm	330 cm
2/3	140 cm	320 cm

(*) For Mono distances are on each side.


2. HARDWARE

2.1. TRANSCEIVER BOARD



- A: TRANSCEIVER UPPER LOOP
- B: TRANSCEIVER LOWER LOOP
- C: RESONANCE ADJUSTMENT TRANSCEIVER UPPER LOOP
- D: RESONANCE ADJUSTMENT TRANSCEIVER LOWER LOOP
- E: VU METER (LED SIGNAL BAR)
- F: POWER CONNECTOR
- G: RELAY
- H: COMMUNICATION
- I: ALARM (LIGHT)
- J: ALARM (BUZZER)
- K: RED CHANNEL: CONNECTION TO THE GREY CONNECTOR ON A RECEIVER BOARD. ALSO RS 485 IN/OUT
- L: GREY CHANNEL: CONNECTION TO THE RED CONNECTOR ON A RECEIVER BOARD. ALSO RS 485 IN/OUT
- M: SOUND ALARM LEVEL SELECTORS
- N: 485 JUMPER
- O: PEOPLE COUNTER AND LIGHTS CONNECTOR
- P: MAGNET CONNECTOR

2.2. RX BOARD




- A: RECEIVER UPPER LOOP
- B: ALARM (LIGHT)
- C: RECEIVER LOWER LOOP
- D: GAIN LEVEL
- E: RESONANCE LEVEL
- F: CONNECTION TO THE GREY CONNECTOR ON A TRANSCIEVER BOARD. ALSO RS 485 IN/OUT
- G: CONNECTION TO THE RED CONNECTOR ON A TRANSCIEVER BOARD. ALSO RS 485 IN/OUT
- H: PEOPLE COUNTER AND LIGHTS CONNECTOR

2.3. POWER SUPPLY

⇒ Power Supply for 2 Transceiver (TX) Antennas



Input 110Vac: PS-
G10V-2-110



3. QUICK TUNING

3.1. QUICK INSTALLATION

3.1.1. PREVIOUS

- ⇒ Always connect the system to clean power lines (No other electrical devices connected)
- ⇒ In order to avoid damaging the electronics, do not place any TURNED OFF antenna near a TURNED ON Transceiver antenna. Please keep the minimum distance, not less than 50cm
- ⇒ **Do not fix the system to the floor** before testing its performance FIRST!
- ⇒ Do not place Receiver and Power line (220Vac/110Vac) cables along the same route.
- ⇒ Please Read this manual BEFORE installing systems!

3.1.2. SYSTEM INSTALLATION

- ⇒ Check cabling / connection needs according to the kind of installation. (See Section [4. CONFIGURATION](#)). Check all the material is ready.
- ⇒ Place the system in the installation area. (DO NOT fix the system to the floor).
- ⇒ Turn the system ON, and connect to the system (Follow Section [5. SOFTWARE](#))
- ⇒ Check Electrical Noise, Synchro, TX Status, etc.... check everything is normal.
- ⇒ Stabilize external electrical noise to the minimum.
- ⇒ Check Section [1.3. TABLE: SYSTEM / DETECTION / NOISE](#) to define the maximum detection distance.
- ⇒ If any modifications, save parameters.
- ⇒ Disconnect your laptop and observe the system during some time making several detection tests (buzzer can be disabled to not cause disturbance).
- ⇒ If OK, fix the system to the floor , if not OK, see Section [3.2. TROUBLESHOOTING](#)

You are done!

3.2. TROUBLESHOOTING

3.2.1. NO DETECTION

- ⇒ Try with other tag
- ⇒ Rise Gain (Up to 2-3 LEDS)
- ⇒ Lower Threshold
- ⇒ See Section [3.4. NOISE PROBLEM](#)
- ⇒ See Section [3.3. SYNCHRONIZATION PROBLEM](#)
- ⇒ See Section [3.5. DEAD TRANSMITTER](#)
- ⇒ See Section [3.6. DEAD RECEIVER](#)

3.2.2. TOO MUCH DETECTION

- ⇒ Lower Gain
- ⇒ Rise Threshold

3.2.3. FALSE ALARM

- ⇒ Look for TAGS near the antennas
- ⇒ See Section [3.7. FALSE ALARM \(OR UNKNOWN ALARM\)](#)

3.2.4. MAKES OTHER SYSTEMS FALSE ALARM

- ⇒ See Section [3.3. SYNCHRONIZATION PROBLEM](#)

3.3. SYNCHRONIZATION PROBLEM


How can I recognize a synchro problem?

- ⇒ Externally: When you turn on your system:
 - It makes other 58 kHz systems near alarm
 - Your system is showing a high amount of noise in the LED bar (See Section [2. HARDWARE](#)).
 - There is no detection or it is very poor.

- ⇒ Laptop:
 - Check Section [5.7.5. DISCOVERY TOOL](#)

How can I know the synchro problem has been solved?

- ⇒ Externally all systems around will be working fine as well as yours.
- ⇒ Laptop: The situation in the discovery mode will be similar to this:





You are done!

3.4. NOISE PROBLEM

How can I recognize a noise problem?

- ⇒ Externally: When you turn on your system:
 - The system shows a high amount of noise in the LED bar.
 - The detection might be poor.
- ⇒ Laptop:
 - In the scope you will see high amount of noise, in the 4 buffers.



How can I solve a noise problem?

- ⇒ Try to locate the source of noise:
 - Turn off all electrical equipment in the area. If the noise disappears, start turning all the electrical equipment ONE BY ONE till you get noise again.
 - Other way to locate the source of noise is moving the Receiver antenna while at the same time you are looking to the LED bar or the software. See how the orientation of the Receiver antenna affects the amount of noise and you will finally find the source.
- ⇒ Then you have to neutralize the source of noise. (It might be related with bad synchro, please check procedure in Section [5.7.5. DISCOVERY TOOL](#)) Other techniques are:
 - Swap Transceiver antenna by Receiver antenna position.
 - Ground the noisy device correctly or try to put it as far as possible from the Receiver antenna.
 - Use advanced noise techniques 'New Noise fighting algorithms'

⇒ New Noise fighting algorithms


Depending on the level of electrical noise, it is recommended to select different positions in the noise selector. Each antenna is independent.

Transceiver antenna

- There are 2 active modes in noise fighting for Transceiver antenna.
- Position 0 turns off noise fighting algorithms in Transceiver antenna.
- Back Ground suppression

Receiver antennas

- There are 2 active modes in noise fighting for Receiver antennas.
- Position 0 turns off noise fighting algorithms in Receiver antenna.
- Back Ground suppression



How can I know the noise problem has been solved?

⇒ Detection will improve. The signs of noise in the LED bar and in the scope will disappear.


You are done!

3.5. DEAD TRANSMITTER

How can I recognize a dead transmitter problem?

- ⇒ Externally: When you turn on your system:
 - The system does not detect.

- ⇒ Laptop:
 - Voltage near to 0Vpp



How can I solve a dead transmitter problem?

- ⇒ If the Transceiver Board is not working, change it by a new one.
- ⇒ Please check the connection cable between the Power Supply and the Transceiver Board.
- ⇒ If the synchro pulse from the POWER supply is not OK, the system will stop the transmission.
- ⇒ If the problem persists, it can be caused by a blown fuse in the Power supply. Change the power supply by a new one.
- ⇒ Check the power line frequency to be 50Hz+/- 1Hz or 60Hz +/- 1Hz.

How can I know the dead transmitter problem has been solved?


- ⇒ The system is working normally.

You are done!

3.6. DEAD RECEIVER

How can I recognize a dead receiver problem?

- ⇒ Externally: When you turn on your system:
 - The system does not detect. (Remember that there are 6 independent receivers one for every loop).
 - You can try if a dual system to change the receiver cable to red connector or grey connector
- ⇒ Laptop:
 - The signal is near 6 dB or less in all receiver buffers.



How can I solve a dead receiver problem?

- ⇒ The problem may come from the Transceiver-Receiver connection cable. It may be broken during the installation.
- ⇒ The problem may come from the Receiver Board. It might be damaged. Try another Receiver Board
- ⇒ The problem may come from the Transceiver Board. It may have one Receiver channel damaged. Try another Transceiver Board or test with the other Receiver channel.

How can I know the dead receiver problem has been solved?

- ⇒ The system is working normally.

You are done!



3.7. FALSE ALARM (OR UNKNOWN ALARM)

How can I recognize a false alarms (or unknown alarm) problem?

- ⇒ The system is alarming when not expected to alarm. USS 58 kHz systems are very false alarm restrictive. It is almost impossible that a USS 58kHz system is alarming except when: ⇒
 - There is a tag in the detection area
 - ⇒ There is another 58 kHz system not in synchro.

How can I solve a false alarms (or unknown alarm) problem?

- ⇒ Look for tags near the system. Look in the scope in the software. If you see something similar to this:



- ⇒ Please Stop the TX system. If the alarm disappears, there are at least some LABEL/TAG near.
- ⇒ If not, there might be another 58 kHz system out of synchro affecting our system. Follow procedure in Section [5.7.5. DISCOVERY TOOL](#)

How can I know the false alarms (or unknown alarm) problem has been solved?

- ⇒ The system is working normally, no unexpected alarms.

You are done!

4. CONFIGURATION

4.1. CONNECTION METHOD

USS 58 kHz systems have been designed to fit into every installation needs. They can be configured in multiple ways.


Connection between Transceivers or between Transceivers and Receivers is done through 10 ways telephonic cable which allows easy adaptation to the installation place needs.

4.1.1. ANTENNA CABLES AND CONNECTION


Each Transceiver antenna can be connected to 2 independent Receiver antennas by a 10 ways flat cable with **NOT polarized connectors**. Please follow the instructions carefully in order to manufacture the cable correctly.

MATERIAL


1 x CAB-FL-10-I



2 x CON-10-TEL-NOPOL




1 x ACC-CONTOOL-10




PROCESS


⇒ 1. Cut the cable at the necessary length.



⇒ 2. Use the Crimp tool to strip the ends of the cable.




⇒ 3. Do a cross connection: cables must have the same colour in the same side (means white on left in one edge, in the other edge, left must be also white).
Place the cable correctly (same colour order).




Place the cable correctly (same colour order).


⇒ 4. Insert one connector.
NOT POLARIZED for Receiver Boards



⇒ 5. Insert second connector in the same orientation as the first one.



⇒ 6. Crimp the cable



- ⇒ Connect the cable between Antennas following Section [4.2. CONFIGURATION EXAMPLES](#)
- ⇒ Test the cable with a system to check that it is working correctly.

You are done!

4.1.2. POWER SUPPLY CABLE AND CONNECTION


Each Transceiver antenna must be supplied by a 10 ways flat cable with **Polarized connector**. The maximum length for this cable is 15 meter.

MATERIAL


1 x CAB-FL-10-B



2 x CON-10-TEL-POL



1 x ACC-CONTOOL-10-POL




PROCESS

⇒ Follow the same process as in Section [4.1.1. ANTENNA CABLES AND CONNECTION](#)


4.2. CONFIGURATION EXAMPLES

4.2.1. TRANSCIVER BOARDS

The connectors from Transceiver Boards which connect to other antennas are red connector (K in the drawing) and grey connector (L in the drawing). Apart from the RX signal, they also take communication between Transceiver and the 2 local Receiver Boards and communication with further Transceiver Boards in the net, if any.




4.2.2. RECEIVER BOARDS



The connectors in the Receiver Board are red connector (F in the drawing) and grey connector (G in the drawing).

4.2.3. DUAL SYSTEM CONFIGURATION (RX-TX)

- ⇒ Always connect a CAB-FL-10-I cable with CON-10-TEL-NOPOL (NOT POLARIZED) from RED connector of one board to the GREY connector of another board.




- ⇒ For Power Supply Connection, always use a CAB-FL-10-B cable with CON-10-TEL-POL (POLARIZED)




4.2.4. SPLIT SYSTEM CONFIGURATION (RX-TX-RX)

- ⇒ Always connect a CAB-FL-10-I cable with CON-10-TEL-NOPOL (NOT POLARIZED) from RED connector of one board to the GREY connector of another board.



- ⇒ For Power Supply Connection, always use a CAB-FL-10-B cable with CON-10-TEL-POL (POLARIZED)





5. SOFTWARE

The interface of Tuning Software for EAS systems has been designed to allow an easy understanding of all features. Icons are highly intuitive permitting a quick assimilation of concepts.

5.1. INSTALLATION PROCEDURE

- ⇒ Before installation verify that you have Windows98se or higher.
- ⇒ Close all the executing programs.
- ⇒ Run the installer
- ⇒ Select the folder to install the software and click 'Install' button



- ⇒ Run the software:
- ⇒ Always connect to the Master to get access to any of the systems (You gain access to all the slaves through the master).

5.2. CONNECT


5.2.1. RS232 PORT

- ⇒ Use an USB to Rs232 adaptor if the computer does not have a RS232 port.
- ⇒ Connect the communication cable provided to the USB adaptor or directly to the system if the computer has RS232 port.

- ⇒ Run the software and press 'SETTINGS'




- ⇒ 1. Select Communication
- ⇒ 2. Select Serial Port.
- ⇒ 3. Select Serial Port Comm.
- ⇒ 4. Press Ok



- ⇒ Press 'Connect'



- ⇒ Software will search for all the systems connected and load them into the System window




5.2.2. ANALOG MODEM

- ⇒ Parts needed: Analog Modem MDM58
- ⇒ Connect the communication cable provided from the analog MODEM to the system.
- ⇒ Connect the analog line to the analog MODEM.
- ⇒ Test the MODEM sequence

- ⇒ Run the software and press 'SETTINGS'




- ⇒ 1. Select Communication.
- ⇒ 2. Select Modem
- ⇒ 3. Select Serial Port Comm.
- ⇒ 4. Enter Phone Number
- ⇒ 5. Press Ok



- ⇒ Press 'Connect'



- ⇒ Software will search for all the systems connected and load them into the System window



5.2.3. GSM MODEM

- ⇒ Parts needed: GSM MODEM.
- ⇒ Input the SIM CARD into the GSM MODEM.
 - To enter or change PIN number, access the system using Serial Port connection (See Section [5.2.1. RS232 PORT](#))
 - Select Command Transmission (See Section [5.4.5. COMMANDS TRANSMISSION](#)) and input !PNxxxx (xxxx=PIN number)
 - Save parameters (See Section [5.4.4. PARAMETERS](#))
 - Disconnect (See Section [5.4.3. DISCONNECT](#))
- ⇒ Connect the communication cable from the GSM MODEM to the system
- ⇒ At power on, the system will detect that it has a PIN number and will activate the GSM MODEM. Then it will be on hold waiting for the communication to come through.
- ⇒ Follow the same process than Section [5.2.2. ANALOG MODEM](#)


5.2.4. INTERNET MODULE

- ⇒ Parts needed: Internet Module ACC-TCP/IP
- ⇒ Connect the cable provided to the INTERNET MODULE and to the system.
- ⇒ Connect the ETHERNET/ADSL cable line to the INTERNET MODULE.

- ⇒ Run the software and press 'SETTINGS'




- ⇒ 1. Select Communication.
- ⇒ 2. Select TCP-IP.
- ⇒ 3. Enter IP address and Port
- ⇒ 4. Select Client or Server operation.
 - For more information see TCP-IP Modules Manual.
 - It is possible to save, load or delete the IP/PORT information
- ⇒ 5. Press Ok



- ⇒ Press 'Connect'



- ⇒ Software will search for all the systems connected and load them into the System window




5.2.5. HOW TO KNOW THE COM PORT


- ⇒ If you are using a USB to RS232 adapter, check which virtual port is assigned by the adapter. To do this, follow the steps:
- 1. Click on **Start** and then **Control Panel**.
 - 2. Click on the Performance and Maintenance link.
 - 3. **Note:** If you're viewing the *Classic View* of Control Panel, you won't see this link. Simply double-click on the **System** icon and proceed to Step 4.
 - 4. In the *System Properties* window, click on the **Hardware** tab.
 - 5. With the *Hardware* tab selected, click on the **Device Manager** button.
 - 6. Select Ports (COM & LTP) and check port name used for the adapter.

5.3. ACCESS


- ⇒ To access any of the systems in the line it is ONLY necessary to connect the PC/LAPTOP/MODEM/TCP-IP MODULE to the MASTER. You gain access to all the slaves through the master.
- ⇒ Double click the SN of the system you want to gain access.



- ⇒ Select Maintenance / Supervisor access
- ⇒ Input PASSWORD (Factory 12345678 for Maintenance)
- ⇒ Press OK



⇒ The selected system is accessed




The screenshot displays the USS software interface with the following components:

- Top Menu:** Settings, Connected, Parameters, Command Transmission, Autotuning, Report, Alarm List, Modules TCP-IP, Languages, Update, Manual, Disconnect.
- Systems Panel (Left):**
 - Search: New Search
 - System List:
 - SN: 08D8, ID: 0001
 - SN: 06A7, ID: 0002
 - SN: 0807, ID: 0003
 - Reverse order:
 - Order: ID
 - S/N: 20B9, ID: FFFF
 - Buttons: Close, Sound Alarm, Change ID, Change Pass
- Main System Configuration (Center):**
 - Tabs: System, Transmitter, Receiver, People Counter, Alarms
 - Status: Serial Number 08D8, ID 0001, Model 1960, Version 04C3
 - System Totals:

	Total Alarms	Total Day Alarms	Total Hour Alarms
Antenna Tx	68	17	0
Red Channel	30	0	0
Grey Channel	3	3	0
 - Power On Times: Power On Times 9, Power On Hours 210
 - Show in Led bar: Rx (selected), V1, V2, T1
 - Internal Clock: Date 17/04/2014, Time 10:10:50, Update, SW Time
 - Green Function: Weekday Thursday, Working Hours (0-24), Stop Hours
- Configuration Options (Right):**
 - Detection:
 - Enable modification
 - Hard Filter
 - Narrow Filter
 - Test 1
 - Test 2
 - Test 3
 - Test 4
 - Others:
 - Alive Signal
 - Master
 - Net
 - Alarms Rs232
- Bottom Status Bar:** Connected. COM1: 19200baud, S/N: 08D8, ID: 0001, Master, Net, Power Line Freq: 50Hz, Version 4.C3

5.4. MAIN MENU




5.4.1. SETTINGS



⇒ Configure Communication, Date Format, Password keeping and License


⇒ Communication:

- Gain access to the system selecting the communication type (See Section [5.3. ACCESS](#))




⇒ Date Format

- Select the date format



⇒ Password


- Check/Uncheck option to remember Maintenance or Supervisor password.



The screenshot shows a settings dialog box with a sidebar on the left containing four menu items: 'Communication', 'Date Format', 'Password', and 'License'. The 'Password' menu item is highlighted with a red border. The main area of the dialog is light yellow and contains a single checkbox labeled 'Remember Maintenance or Supervisor Password', which is checked. At the bottom of the dialog are two buttons: 'Ok' and 'Cancel'.

⇒ License

- Enter a new key and then click 'Check License' to see when the period expires.




The screenshot shows a settings dialog box with a sidebar on the left containing four menu items: 'Communication', 'Date Format', 'Password', and 'License'. The 'License' menu item is highlighted with a red border. The main area of the dialog is light yellow and contains a text input field labeled 'License:' with the value 'sdgsdfg6vwerf356ytrhjk' entered. To the right of the input field is a button labeled 'Check License'. At the bottom of the dialog are two buttons: 'Ok' and 'Cancel'.

5.4.2. CONNECT /CONNECTED




- ⇒ Connect to the system(s)
- ⇒ When connection is active, then it is shown as 'Connected'

- ⇒ Software will search for all the systems connected and load them into the System window




5.4.3. DISCONNECT




- ⇒ Disconnect from the accessed system

5.4.4. PARAMETERS




- ⇒ Reset all parameters in the system to factory values
- ⇒ Save all parameters into system memory
- ⇒ Refresh all parameters in the software from the system memory
- ⇒ Load From File: Load parameters from a file into the system
- ⇒ Save into File: Save system parameters into a file

5.4.5. COMMANDS TRANSMISSION



- ⇒ Opens a command window in order to send any command directly to the system




5.4.6. AUTOTUNING



⇒ Tune the systems selected with Threshold, Gain and Noise to get the best performance


⇒ Select the systems you want to tune:



⇒ On this step, it is possible to customize the entrances/doors and systems:


Edit Corridor

Clicking the right mouse button in the corridor brings up the option to edit it.




Edit System

Clicking the right mouse button in the system brings up the option to edit it.




Add Corridor

Clicking the right mouse button in the white space brings up the option to add a new corridor or clear all of them leaving one by default named "Corridor Name"




System Location

Drag and drop systems to move them from one corridor to another.




- ⇒ Click 'Ok'.
- ⇒ Choose between Detection options (Threshold, Gain and Noise) and Other (Set People Counter ON, Set PC Date and Time and Reset Parameters).



- ⇒ Click 'Start Autotuning' button to tune the systems.


5.4.7. REPORT



⇒ Displays all the system measurements and parameters saved on a file at a certain moment.

5.4.7.1 SAVE REPORT

⇒ Select Save Report File:




Select Action

Show Report
 Save Report into File

Ok Cancel

⇒ Click 'Ok'.

⇒ Select the systems from which you want to create a report:




Select Systems

- Door 1
 - (SN:08D8 - ID:0001)
- Door 2
 - (SN:06A7 - ID:0002)
- Door 3
 - (SN:0807 - ID:0003)

Ok Exit

⇒ Optionally, you can set the following information from the store and the system



Store

Name

Location

Antennas

Model

Distance

Tag

Technician

Name

Phone Number

Problem Description


Ok Cancel

⇒ Click 'Ok'.

⇒ Enter a name for the Report file.

5.4.7.1 SAVE REPORT

⇒ Select Show Report:




Select Action

Show Report
 Save Report into File

Ok Cancel

- ⇒ Click 'Ok' button
- ⇒ Select the report file.
- ⇒ The Report will show up as follows:



Report

System Transmitter Receiver People Counter Alarms

Store Name: [] Location: []

Antennas System: [] Model: [] Distance: [] Tag: []

Technician Name: [] Phone Number: [] Problem Description: []

Status: Serial Number 08D8 ID 0001 Model 1960 Version 04C3

System Totals	Total Alarms	Total Day Alarms	Total Hour Alarms	Total Hour Near Tag Alarm
Antenna Tx	396	8	0	0
Antenna Rx1	105	0	0	0
Antenna Rx2	134	0	0	0

Power On Times: Power On Times 30 Power On Hours 66

Show in Led bar: RX V1 V2 T1

Internal Clock: Date 11/04/2014 Time 09:39:19 SW Time []

Green Function: Weekday Friday

Working Hours (Green bar) Stop Hours (Red bar)

Configuration Options:

Detection: Enable modification Hard Filter Narrow Filter Test 1 Test 2 Test 3 Test 4

Others: Alive Signal Master Net Metal ON


- ⇒ Select System Serial Number.
- ⇒ Information of System, Transceiver, Receiver, People Counter and Alarms will be showed up.

5.4.8. DATA MINING



⇒ Displays available data mining

- ⇒ It is possible to get the data during the last year from all the systems on the net by selecting the systems which are required to get historical data from. (Data is refreshed into memory **every hour**)



- ⇒ In this window, it is possible to customize the entrance/doors and systems. (Read Section [5.4.6. AUTOTUNING](#))
- ⇒ The Data Mining window will show up as follows:



⇒ Select Date ranges:

Select Date

From To

⇒ Select Parameters to display:

Parameters

All None

Systems

- Alarms Antenna Tx
- Alarms Antenna Rx1
- Alarms Antenna Rx2
- Near Tag Alarm
- Jammer Alarm
- Power On Times
- Total Alarms

People Counter

- Ins Corridor 1
- Ins Corridor 2
- Outs Corridor 1
- Outs Corridor 2
- Total Ins
- Total Outs

⇒ Press 'GET LIST' button to get the historical data from the selected systems:

TABLE DATA

⇒ Data is displayed in a Table with columns as follows:

- Door 1
 - Master (SN:08D8 - ID:0001)
- Door 2
 - (SN:06A7 - ID:0002)
- Door 3
 - (SN:0807 - ID:0003)

Select Date

From To

Parameters

All None

Systems

- Alarms Antenna Tx
- Alarms Antenna Rx1
- Alarms Antenna Rx2
- Near Tag Alarm
- Jammer Alarm
- Power On Times
- Total Alarms

People Counter


- Ins Corridor 1
- Ins Corridor 2
- Outs Corridor 1
- Outs Corridor 2
- Total Ins
- Total Outs

Table | Chart | Systems | Period:

Period: 01/10/2011 - 18/11/2011

Day	Total Alarms	Total Ins	Total Outs
01/10/11	0	0	0
02/10/11	0	0	0
03/10/11	2	74	66
04/10/11	0	48	47
05/10/11	28	65	60
06/10/11	0	43	41
07/10/11	3	64	55
08/10/11	0	3	3
09/10/11	0	0	0
10/10/11	22	87	80
11/10/11	0	60	53
12/10/11	0	0	0
13/10/11	0	40	37
14/10/11	1	54	48
15/10/11	0	2	2
16/10/11	0	0	0
17/10/11	0	59	54
18/10/11	0	80	74
19/10/11	0	57	55
20/10/11	0	42	34
21/10/11	4	40	42
22/10/11	0	0	0
23/10/11	0	0	0
24/10/11	1	67	60

⇒ Select Period:



- Only by selecting Hour Period, data displayed belongs to one day with periods of 24 hours.


Hour	Total Alarms	Total Ins	Total Outs
00	0	0	0
01	0	0	0
02	0	0	0
03	0	0	0
04	0	0	0
05	0	0	0
06	0	0	0
07	0	3	0
08	1	9	6
09	0	8	9
10	0	6	5
11	0	9	9
12	0	11	10
13	0	4	3
14	1	14	10
15	0	6	8
16	0	3	3
17	0	1	3
18	0	0	0
19	0	0	0
20	0	0	0
21	0	0	0
22	0	0	0
23	0	0	0

- Select the day from which you want to get the historical data or click on 'Previous' and 'Next' buttons:




CHART DATA


⇒ Change to Chart Tab to display the data in graphical style along a horizontal time axis.




⇒ Select the style of the chart:



⇒ Select perspective:



⇒ Chart visualization provides for major and minor settings to allow for zooming




⇒ Data can be exported into txt file or printed:



SYSTEMS DATA

⇒ Change to Systems Tab to display the data for each system individually.



The screenshot displays the 'Systems' tab in the software interface. On the left, there is a tree view showing a hierarchy of systems: Door 1 (containing Master (SN:08D8 - ID:0001)), Door 2 (containing SN:06A7 - ID:0002), and Door 3 (containing SN:0807 - ID:0003). Below the tree view are controls for 'Select Date' (From: 01/10/2011, To: 18/11/2011) and a 'Get List' button. There are also 'Parameters' sections for 'Systems' and 'People Counter' with various checkboxes.

The main area shows two data tables:

TOTAL PERIOD DATA: 01/10/2011 - 18/11/2011

System Selection	Total Alarms	Total Ins	Total Outs
Door 1	111	1900	1751
Master (SN:08D8 - ID:0001)	111	1900	1751
Door 2	1	0	0
(SN:06A7 - ID:0002)	1	0	0
Door 3	0	0	0
(SN:0807 - ID:0003)	0	0	0

HOUR DATA MINING: 18/11/2011 10:42:33

System Selection	Total Alarms	Total Ins	Total Outs
Door 1	2	9	7
Master (SN:08D8 - ID:0001)	2	9	7
Door 2	1	0	0
(SN:06A7 - ID:0002)	1	0	0
Door 3	0	0	0
(SN:0807 - ID:0003)	0	0	0

⇒ Total Period Data is the sum of all period data for each system separately.

⇒ Hour Data Mining is the sum of the actual hour for each system separately and is refreshed every new hour.

5.4.9. MANUAL




⇒ Open the Manual Menu to browse this Tuning G10V Manual

5.4.10. LANGUAGES




⇒ All labels are supported in other languages. You can add new language or delete it.



English	Español
Ok	Ok
Cancel	Cancelar
Exit	Salir
Settings	Ajustes
Select Communication	Selec. Comunicación
Serial Port	Puerto Serie
Comm	Com
Modem	Modem
Phone Number	Número Teléfono
TCP-IP	TCP-IP
IP	IP
Port	Puerto
Client	Cliente
Server	Servidor
Password	Clave
Level Access	Nivel de acceso
Maintenance	Mantenimiento
Supervisor	Supervisor
Alarm List	Histórico
Select Date	Fecha

⇒ Add language



⇒ Write all the words you need.

	English	Español
▶	Ok	Ok
	Cancel	Ca
	Exit	
	Settings	
	Select Communication	
	Serial Port	
	Alarm List	
	Select Date	


⇒ Save the changes and select the language.

5.4.11. UPDATE



⇒ Click on 'Update' Menu to check if new versions are available.

5.5. SYSTEMS



⇒ Options for this section:

- Start a new search to load systems.
- Visualization of systems found with their Serial Number and ID
- Close channel from accessed system or get access to selected system
- Sound the alarm of selected system
- Change ID of selected system (once you gain access)
- Change password (once you gain access)

5.6. SYSTEM TAB

System	Transmitter	Receiver	People Counter	Alarms																
Status Serial Number <input type="text" value="08D8"/> ID <input type="text" value="0001"/> Model <input type="text" value="1960"/> Version <input type="text" value="04C3"/>																				
System Totals <table border="1"> <thead> <tr> <th></th> <th>Total Alarms</th> <th>Total Day Alarms</th> <th>Total Hour Alarms</th> </tr> </thead> <tbody> <tr> <td>Antenna Tx</td> <td><input type="text" value="68"/></td> <td><input type="text" value="17"/></td> <td><input type="text" value="0"/></td> </tr> <tr> <td>Red Channel</td> <td><input type="text" value="30"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> </tr> <tr> <td>Grey Channel</td> <td><input type="text" value="3"/></td> <td><input type="text" value="3"/></td> <td><input type="text" value="0"/></td> </tr> </tbody> </table> <input type="button" value="Reset Alarms"/>						Total Alarms	Total Day Alarms	Total Hour Alarms	Antenna Tx	<input type="text" value="68"/>	<input type="text" value="17"/>	<input type="text" value="0"/>	Red Channel	<input type="text" value="30"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	Grey Channel	<input type="text" value="3"/>	<input type="text" value="3"/>	<input type="text" value="0"/>
	Total Alarms	Total Day Alarms	Total Hour Alarms																	
Antenna Tx	<input type="text" value="68"/>	<input type="text" value="17"/>	<input type="text" value="0"/>																	
Red Channel	<input type="text" value="30"/>	<input type="text" value="0"/>	<input type="text" value="0"/>																	
Grey Channel	<input type="text" value="3"/>	<input type="text" value="3"/>	<input type="text" value="0"/>																	
Power On Times Power On Times <input type="text" value="9"/> Power On Hours <input type="text" value="210"/>		Show in Led bar <input checked="" type="radio"/> Rx <input type="radio"/> V1 <input type="radio"/> V2 <input type="radio"/> T1																		
Internal Clock Date <input type="text" value="17/04/2014"/> Time <input type="text" value="10:10:50"/> <input type="button" value="Update"/> <input checked="" type="checkbox"/> SW Time																				
Green Function Weekday <input type="text" value="Thursday"/> <input type="button" value="Configuration"/> <div style="display: flex; align-items: center;"> <div style="width: 200px; height: 15px; background: linear-gradient(to right, green 50%, red 50%);"></div> <div style="margin-left: 10px;"> ■ Working Hours ■ Stop Hours </div> </div>																				
Configuration Options <div style="border: 1px solid gray; padding: 5px;"> Detection <input type="checkbox"/> Enable modification <input checked="" type="checkbox"/> Hard Filter <input type="checkbox"/> Narrow Filter <input checked="" type="checkbox"/> Test 1 <input type="checkbox"/> Test 2 <input checked="" type="checkbox"/> Test 3 <input checked="" type="checkbox"/> Test 4 </div> <div style="border: 1px solid gray; padding: 5px; margin-top: 5px;"> Others <input checked="" type="checkbox"/> Alive Signal <input checked="" type="checkbox"/> Master <input checked="" type="checkbox"/> Net <input type="checkbox"/> Alarms Rs232 </div>																				

5.6.1. STATUS

- ⇒ The following information can be found: (Only INFO)
- Serial Number
 - Current ID
 - Model
 - Version

Status					
Serial Number	<input type="text" value="08D8"/>	ID	<input type="text" value="0001"/>	Version	<input type="text" value="04C3"/>

5.6.2. SYSTEM TOTALS

- ⇒ The following information can be found:
- Total Alarms /Total Day Alarms / Total Hour Alarms in Transceiver Antenna
 - Total Alarms /Total Day Alarms / Total Hour Alarms in Red Channel Receiver Antenna
 - Total Alarms /Total Day Alarms / Total Hour Alarms in Grey Channel Receiver Antenna
 - Reset Alarms button: Click on this button to clear all alarms counting.

System Totals			
	Total Alarms	Total Day Alarms	Total Hour Alarms
Antenna Tx	<input type="text" value="68"/>	<input type="text" value="17"/>	<input type="text" value="0"/>
Red Channel	<input type="text" value="30"/>	<input type="text" value="0"/>	<input type="text" value="0"/>
Grey Channel	<input type="text" value="3"/>	<input type="text" value="3"/>	<input type="text" value="0"/>

5.6.3. POWER TIMES

⇒ The following information can be found:

- Total number of Power ON
- Total Number of Power ON hours (working hours).

Power On Times

Power On Times

Power On Hours

5.6.4. LEDS

⇒ This selector is used to choose what information to be displayed on the LED bar (See Section [2. HARDWARE](#))

- RX: Receiver noise/signal
- V1: Voltage of Transceiver Upper Loop
- V2: Voltage of Transceiver Lower Loop
- T1: Temperature in board system

Show in Led bar

Rx
 V1
 V2
 T1

5.6.5. CLOCK

⇒ Set Date and Time and click 'Update' button to adjust the system clock

Internal Clock

Date

Time

SUMMER / WINTER TIME (DAYLIGHT SAVING TIME)

- ⇒ This option is only available for firmware versions higher than V4.AE
- ⇒ Select 'S/W Time' and press button to configure daylight saving time for your region.

For Europe or USA, system automatically determines whether Daylight Saving Time is in effect for a specified time zone and updates the corresponding local time

For other countries, specify month, day and hour to update the time and click 'Send' button to save daylight saving time.

2014 Summer Winter TimeTable

Select Summer/Winter Time

Summer Time
 Winter Time

Select Zone

Europe
 USA
 Other Countries

	Month	Day	Hour	
Summer/Winter	<input type="text" value="10"/>	<input type="text" value="26"/>	<input type="text" value="3"/>	
Winter/Summer	<input type="text" value="3"/>	<input type="text" value="25"/>	<input type="text" value="2"/>	

Sunday, 26.10.2014, 03:00 clock is turned backward one hour

2014 Summer Winter TimeTable

Select Summer/Winter Time

Summer Time
 Winter Time

Select Zone

Europe
 USA
 Other Countries

	Month	Day	Hour	
Summer/Winter	<input type="text" value="10"/>	<input type="text" value="26"/>	<input type="text" value="3"/>	
Winter/Summer	<input type="text" value="3"/>	<input type="text" value="30"/>	<input type="text" value="2"/>	

Sunday, 26.10.2014, 03:00 clock is turned backward one hour

5.6.6. SAVE ENERGY

STOP HOURS

- ⇒ This option is for versions lower than V3.B0/V4.B0
- ⇒ The system is automatically turned off during the hours period selected. If same hour, no action (Always ON)

Save Energy (Stop Hours)

From h To h

STOP DAYS

- ⇒ This option is available for versions V3.AD/V4.AD and V3.AF/V4.AF
- ⇒ The system can be automatically turned off for two independent days. Select the days of the week to have the system turned off. If Disable is selected, no action for this day.

Save Energy (Stop Days)

Day 1 Day 2

GREEN FUNCTION


- ⇒ This option is available for versions V3.B1/V4.B1 and higher

Green Function

Weekday

■ Working Hours

■ Stop Hours




- ⇒ Click 'Configuration' button to set up to four intervals for working hours for each day of the week

	Interval 1		Interval 2		Interval 3		Interval 4		
	From	To	From	To	From	To	From	To	
Monday	<input type="radio"/> ON	<input type="radio"/> OFF	<input checked="" type="radio"/> Intervals	08:00	20:00	00:00	00:00	00:00	00:00
Tuesday	<input checked="" type="radio"/> ON	<input type="radio"/> OFF	<input type="radio"/> Intervals	ON					
Wednesday	<input type="radio"/> ON	<input type="radio"/> OFF	<input checked="" type="radio"/> Intervals	08:00	14:00	15:00	21:00	00:00	00:00
Thursday	<input type="radio"/> ON	<input type="radio"/> OFF	<input checked="" type="radio"/> Intervals	08:00	20:00	00:00	00:00	00:00	00:00
Friday	<input type="radio"/> ON	<input type="radio"/> OFF	<input checked="" type="radio"/> Intervals	08:00	20:00	00:00	00:00	00:00	00:00
Saturday	<input type="radio"/> ON	<input checked="" type="radio"/> OFF	<input type="radio"/> Intervals	OFF					
Sunday	<input type="radio"/> ON	<input checked="" type="radio"/> OFF	<input type="radio"/> Intervals	OFF					

■ Working Hours

■ Stop Hours



- ⇒ Click 'Save' button to save the configuration.

5.6.7. CONFIGURATION OPTIONS

Configuration Options

Detection

Enable modification

Hard Filter

Narrow Filter

Test 1

Test 2

Test 3

Test 4

Others

Alive Signal

Master

Net

Alarms Rs232


⇒ Detection:

- This should be left as from factory settings.

⇒ Others:

- Alive Signal: Activates or deactivates “alive light”, which shows that the system is running correctly and it is not “hung”
- Master & NET (ONLY INFO)
- Ignore switches (option available for systems with versions lower than V3.B4 and V4.B4). With this function selected, the system will ignore any change or parameter introduced from the switches. This is to prevent unauthorized access even from the hardware / switches
- Alarms RS232 (option only available for systems with versions V4.BD or higher). Enable Beeper alarms in order to receive alarm events via Rs232

5.7. TRANSMITTER TAB



System **Transmitter** Receiver People Counter Alarms

Start / Stop Tx

Start

Stop

Tx Loops

Upper Loop

Lower Loop

MultiMono

ON

OFF

System Tx Blocks

A B C

Discovery Follow Master

0 6.6ms 13.3ms 20ms

Discovery

Delay: 0.2 ms

Voltage TX Loop

Upper	Lower	Vpp	Temp °C
<input type="checkbox"/>	<input type="checkbox"/>	1600	80
<input type="checkbox"/>	<input type="checkbox"/>	1500	75
<input type="checkbox"/>	<input type="checkbox"/>	1400	70
<input type="checkbox"/>	<input type="checkbox"/>	1300	65
<input type="checkbox"/>	<input type="checkbox"/>	1200	60
<input type="checkbox"/>	<input type="checkbox"/>	1100	55
<input type="checkbox"/>	<input type="checkbox"/>	1000	50
<input type="checkbox"/>	<input type="checkbox"/>	900	45
<input type="checkbox"/>	<input type="checkbox"/>	800	40
<input type="checkbox"/>	<input type="checkbox"/>	700	35
<input type="checkbox"/>	<input type="checkbox"/>	600	30
<input type="checkbox"/>	<input type="checkbox"/>	500	25
<input type="checkbox"/>	<input type="checkbox"/>	400	20
<input type="checkbox"/>	<input type="checkbox"/>	300	15
<input type="checkbox"/>	<input type="checkbox"/>	200	10
<input type="checkbox"/>	<input type="checkbox"/>	100	5

1449 1404 31

Set °C to 25 °C

5.7.1. START / STOP TX




Start / Stop Tx

Start

Stop

- ⇒ From here the Transmission can be stopped, this can be used to confirm if an alarm is coming from tags / labels.
- ⇒ If the Transmission is stopped and the alarm stops, then the alarm was caused by a tag.

5.7.2. TX LOOPS



Tx Loops


Upper Loop

Lower Loop


- ⇒ Turn ON/OFF any of the 2 independent Transceiver loops in the Transceiver antenna. (Default ON).
- ⇒ TX Loops states can be saved.

5.7.4. DISCOVERY TOOL


⇒ Main tool to synchronize the system.



- ⇒ In 99% of cases this adjustment is not necessary. Anyway, it is always good to take a look at the environmental electric noise throughout the 'Discovery Mode' feature.
- ⇒ When Discovery Tool is ON, the transmitter is then turned off, and the system ONLY receives.
- ⇒ Standard Synchro delay value is 0.2ms



- ⇒ For Slave systems, 'Follow Master' enabled will set the same delay than the Master.
- ⇒ This option is available for systems with version 3.A0 and 4.A0 or higher.




- ⇒ Once the Discovery Tool is ON, transmission loops on the selected system are stopped and electrical noise and other possible systems out of phase are shown on the screen. In the scope is represented the amount of noise in 58 kHz through the 0° to the 360° phase in the mains. (From 0 ms to 20 ms in one 50 Hz period).


⇒ **THE FOLLOWING POINTS SHOULD BE CONSIDERED BEFORE USING DISCOVER TOOL:**

⇒ Discovery can be made with transceiver or receiver antennas (Red and Grey Channels).
Recommended order is:


- **1. Red Channel** (In case you have receiver antenna on this channel):
 - 1.1 Disable Transceiver receiver loops
 - 1.2 Enable Red Channel receiver loops
 - 1.3 Disable Grey Channel receiver loops



- **2. Grey Channel** (In case you have receiver antenna on this channel)
 - 2.1 Disable Transceiver receiver loops
 - 2.2 Disable Red Channel receiver loops
 - 2.3 Enable Grey Channel receiver loops



- **3. Transceiver**
 - 3.1 Enable Transceiver receiver loops




⇒ Furthermore, Discovery should be done with the Master system as long as you have more than one transceiver antenna in a net (slave systems). For these cases, **DISABLE "Follow Master"** option on every Slave system. Otherwise you could see transmission loops from slave systems which may confuse the scope.


⇒ When you click on 'ON' button , a new scope window will appear:



- System transmission blocks (A, B, C) will be represented in the negative area in green colour
- Other transmission blocks are represented in red colour.
- Noise is yellow colour
- Signal detection blocks are represented in purple colour in the negative area (always after system transmission blocks)




⇒ Zoom for AXIS Y.




Select Auto or fixed to set the Y maximum level.

⇒ Zoom for AXIS X.



Select Normal to display 3 blocks (A, B and C) or Blocks in case you want to display one only Block (A, B or C) with more resolution. (This option is available for versions 4.C0 or higher)

⇒ AM 58kHz Timing



Delay:

Change the delay manually to synchronize the transmission with other systems around. (0.2ms is default time)

TX Blocks

Enable/disable transmission blocks. It is recommended to have three blocks enabled unless you have tag detection signal on any of these blocks too high. In this case, you can disable the involved block.


RX Signal Level

This is the level for tag signal for each TX Block (A, B C)

FIELD SITUATIONS

 ⇒ **1. Systems perfectly in phase (99% of times), NO NEED TO SYNCHRONIZE**


- Transmission loops are displayed in the negative area. The presence of another system which is correctly synchronized with yours, can be seen right over system transmission blocks (For versions 4.CO




or higher)

 ⇒ **2. Systems out of synchro, NEED TO SYNCHRONIZE, Only one external reference**

- When another 58 kHz transmitter is transmitting out of synchro, it can be easily seen from the scope screen. The positive area is reserved for these situations. In the following picture, the presence of another 58 kHz transmitter can be easily seen on that area. Only one external reference means that only 3 TX blocks from other system can be seen in the upper side of the screen.




- Change the delay manually to synchronize with the system out of synchro and match the system transmission blocks with the other systems around




- As it can be seen on the picture above, our TX blocks (green blocks) are being moved until the position matches with the other system TX blocks. The synchro can be followed and verified visually.
- After a good synchronization process, press “OFF” button

⇒ **3. Systems out of synchro, NEED TO SYNCHRONIZE, More than one external reference**

- When there is more than one reference to synchro, then a correct synchronization is not possible. This means that previous to the installation, there were already at least 2 systems out of synchro, probably these systems are already not working. In order to fix the problem it is necessary to previously synchronize between them the existing systems.
- 3 blocks of abnormal duration, means at least 2 previously not synchronized systems




- After synchronizing ALL external systems, the situation will be as follows:



- Then the system can be correctly synchronized using this unique and only external reference.
- Please follow step 2, to synchronize de system in accordance.

5.7.5. TRANSCIVER STATUS



⇒ Transceiver Voltage


- Shows the Voltage in the TX loops. It should be always in the range of 1200 to 1400V (GREEN)
- If it is lower, it might be because a defective transmitter or bad resonance. Then it might be necessary to retune the Transceiver resonance (Hardware).

⇒ Transceiver Temperature

- Shows the current Temperature in the Transmitter Board.
- Should be always in the green area (10° to 55°).


5.8. RECEIVER TAB

- ⇒ Transceiver antenna is also a Receiver antenna, so it has its own receiver side.
- ⇒ Each Transceiver antenna is able to support 2 Receiver antennas.
- ⇒ Selecting 'Transceiver' allows selecting parameters for receiver side of Transceiver antenna
- ⇒ Selecting 'Red Channel' allows selecting parameters for the Receiver Antenna connected to the red connector on the Transceiver board.
- ⇒ Selecting 'Grey Channel' allows selecting parameters for the Receiver Antenna connected to the grey connector on the Transceiver board.



5.8.1. GAIN

- ⇒ Gain feature is used to adjust the receiver sensitivity to get the best reception signal.



- ⇒ In order to adjust Gain, simply select the value until you get the required detection.

5.8.2. THRESHOLD

- ⇒ Threshold feature is the signal level at which each receiver will trigger an alarm.
- ⇒ If you need higher threshold, then increase the Multiplier. With higher threshold detection is reduced. The system is less sensitive and more quantity of signal will be needed from the tag to trigger an alarm.
- ⇒ It is recommended, for maximum sensitivity to keep the Threshold at minimum (18 dB) & Multiplier=1.
- ⇒ In order to adjust Threshold, simply select the value until you get the required detection



5.8.3. START/STOP RECEIVER LOOPS

- ⇒ From here, each Receiver loop can be independently turned on and off. If there is a high disturbance in any of them, it can be disabled. Receiver Loops states be saved.

Receiver Loops

Upper Loop Lower Loop

5.8.4. ANTI NOISE ALGORITHMS

- ⇒ Anti Noise algorithms are used to minimize the electrical noise. Depending on the level of electrical noise, it is recommended to select different positions in the noise selector. Each antenna is independent.
- ⇒ There are 2 active modes in noise fighting.
- ⇒ Position 0 turns off noise fighting algorithms in mono-antenna.
- ⇒ Back Ground suppression is also OFF by default.

Anti Noise Algorithms


Mode BackGround

5.8.5. SIGNAL AND NOISE

- ⇒ In the scope area there is a digital oscilloscope display that will help to analyse the noise and signal. Real time electrical noise signals icon will show current electrical signal (Noise and tags if there is any).
- ⇒ There are 4 different reception areas shown on the Signal Bars / Digital Scope:
 - Upper Loop Signal (S1)
 - Upper Loop Noise (N1)
 - Lower Loop Signal (S2)
 - Lower Loop Noise (N2)



SITUATION 1 (When there is no tag near)

- ⇒ In the 4 different reception Bars/Areas, only electrical noise in the environment is shown, as there is no tag near.
- ⇒ All 4 reception Bars/Areas **MUST HAVE SIMILAR** values
 - ⇒ The reception areas shown on the Signal Bars / Digital Scope should look as follows:



SITUATION 2 (When there is a tag near)

- ⇒ The reception areas shown on the Signal Bars / Digital Scope should look as follows:
- ⇒ In the 4 different reception Bars/Areas, the 2 reception Bars/Areas reserved for noise keep the same as in SITUATION 1 BUT the 2 Bars/Areas reserved for tag signal, show higher values than the ones reserved for noise.
- ⇒ This way, an alarm caused by tags can be easily identified




5.9. PEOPLE COUNTER TAB

The people counter consists of two modules: IR-RX Modules and IR-TX Modules using infra-red technology in order to count the number and direction of people crossing an entrance.

5.9.1. IR-RX MODULES (ACC-PCA-G10V PEOPLE COUNTER A)

- ⇒ IR-RX Modules are located in the light alarm board at the top of the **Transceiver** Antennas.
- ⇒ Each side of the board has two infra-red receivers to count ins and outs, which means that an IR-RX Module can control up to two entrances (People Counter 1 and People Counter 2)



People Counter 1			
		Total	Total Hour
<input type="checkbox"/> Reverse	Ins	2	0
	Outs	2	0


People Counter 1: Ins and Outs counting on the board side which contains the white connector

People Counter 2			
		Total	Total Hour
<input checked="" type="checkbox"/> Reverse	Ins	12799	1
	Outs	12096	2

People Counter 2: Ins and Outs counting on the board side which does not contain the white connector

5.9.2. IR-TX MODULES (ACC-PCB-G10V PEOPLE COUNTER B)

- ⇒ IR-TX Modules are located in the light alarm board at the top of the Receiver Antennas.
- ⇒ Each side of the board (Side 1 and Side 2) has one infra-red led transmitter to emit the IR pulses



Side 1


IR pulses transmissions are from the infra-red led located at the same layer than white connector.

Side 2


IR pulses transmissions are from the infra-red led located in the layer where there is not white connector

5.9.2.1. IR POWER TRANSMISSION

Side 1



Side 2




5.9.3. PEOPLE COUNTER INSTALLATION

- ⇒ There are two important points to take account at the installation time:
 - 1. Position of the IR-RX and IR-TX Modules inside the antenna:
 - Set the position of all the IR-RX modules (People Counter A) and IR-TX modules (People Counter B) **so that all white connectors are looking at the same point.**
 - 2. Connection of the receiver antennas:


Version V4.B4 and higher

- ⇒ People Counter 1 (white connector) should be looking at Red Channel Receiver antenna
- ⇒ People Counter 2 (no white connector) should be looking at Grey Channel Receiver antenna



Version lower than V4.B4


- ⇒ People Counter 1 (white connector) should be looking at Grey Channel Receiver antenna
- ⇒ People Counter 2 (no white connector) should be looking at Red Channel Receiver antenna



- ⇒ Select People Counter Tab to display the configuration of the systems and IR-Modules states.
- ⇒ Click over IR-Modules icons (red-green) to switch its state.

System Transmitter Receiver **People Counter** Alarms

Click the IR-Modules icons (red-green) to switch its state Ping Pong Transmission Auto Configuration



People Counter 1

Reverse

	Total	Total Hour
Ins	4	0
Outs	3	0

People Counter 2

Reverse

	Total	Total Hour
Ins	22	0
Outs	22	0

- ⇒ Counting Ins and Outs are updated on time.

People Counter 1

Reverse

	Total	Total Hour
Ins	4	0
Outs	3	0

People Counter 2


Reverse

	Total	Total Hour
Ins	22	0
Outs	22	0

- ⇒ Check 'Reverse' option to switch ins-counts by outs-counts and viceversa


PING PONG TRANSMISSION

- ⇒ This feature is an optional way of transmission for IR-TX Modules in order to prevent bouncing cases when the IR-RX-Modules are fully exposed
- ⇒ For this type of transmission, it is necessary to install the systems following Section [5.9.3. PEOPLE COUNTER INSTALLATION](#)




AUTO CONFIGURATION

- ⇒ Click 'Auto Configuration' button to enable IR-TX Modules corresponding to entrances and set the People Counter ready to count.



⇒ Select the systems in the net you want to configure the People Counter:



⇒ Click 'Ok'.

⇒ Check Ins and Outs for all the systems in the net in Data Mining Menu:


Table	Chart	Systems																												
1 TOTAL PERIOD DATA: 16/11/2011 - 22/11/2011																														
		<table border="1"> <thead> <tr> <th>System Selection</th> <th>Total Alarms</th> <th>Total Ins</th> <th>Total Outs</th> </tr> </thead> <tbody> <tr> <td>Door 1</td> <td>3</td> <td>305</td> <td>275</td> </tr> <tr> <td> (SN:08D8 - ID:0001)</td> <td>3</td> <td>305</td> <td>275</td> </tr> <tr> <td>Door 2</td> <td>11</td> <td>0</td> <td>0</td> </tr> <tr> <td> (SN:06A7 - ID:0002)</td> <td>11</td> <td>0</td> <td>0</td> </tr> <tr> <td>Door 3</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td> (SN:0807 - ID:0003)</td> <td>0</td> <td>0</td> <td>0</td> </tr> </tbody> </table>	System Selection	Total Alarms	Total Ins	Total Outs	Door 1	3	305	275	(SN:08D8 - ID:0001)	3	305	275	Door 2	11	0	0	(SN:06A7 - ID:0002)	11	0	0	Door 3	0	0	0	(SN:0807 - ID:0003)	0	0	0
System Selection	Total Alarms	Total Ins	Total Outs																											
Door 1	3	305	275																											
(SN:08D8 - ID:0001)	3	305	275																											
Door 2	11	0	0																											
(SN:06A7 - ID:0002)	11	0	0																											
Door 3	0	0	0																											
(SN:0807 - ID:0003)	0	0	0																											
2 HOUR DATA MINING: 22/11/2011 08:35:47																														
		<table border="1"> <thead> <tr> <th>System Selection</th> <th>Total Alarms</th> <th>Total Ins</th> <th>Total Outs</th> </tr> </thead> <tbody> <tr> <td>Door 1</td> <td>0</td> <td>5</td> <td>3</td> </tr> <tr> <td> (SN:08D8 - ID:0001)</td> <td>0</td> <td>5</td> <td>3</td> </tr> <tr> <td>Door 2</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td> (SN:06A7 - ID:0002)</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>Door 3</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td> (SN:0807 - ID:0003)</td> <td>0</td> <td>0</td> <td>0</td> </tr> </tbody> </table>	System Selection	Total Alarms	Total Ins	Total Outs	Door 1	0	5	3	(SN:08D8 - ID:0001)	0	5	3	Door 2	0	0	0	(SN:06A7 - ID:0002)	0	0	0	Door 3	0	0	0	(SN:0807 - ID:0003)	0	0	0
System Selection	Total Alarms	Total Ins	Total Outs																											
Door 1	0	5	3																											
(SN:08D8 - ID:0001)	0	5	3																											
Door 2	0	0	0																											
(SN:06A7 - ID:0002)	0	0	0																											
Door 3	0	0	0																											
(SN:0807 - ID:0003)	0	0	0																											

⇒ 1. Total Period Data is the sum of the whole period for each checked system separately.

⇒ 2. Hour Data Mining is the actual hour data for each checked system. (Data is reset to 0 every new hour)


5.10. ALARMS TAB

⇒ This section allows you to configure the different alarms patterns in the system.



5.10.1. SOUND OPTIONS


⇒ Select number of times to sound and customize beep duration time.



5.10.2. PAGER OPTIONS

⇒ Type the messages to display on Pager in order to receive a message when an alarm event occurs.

⇒ Check this option to enable messages on Pager



5.10.3. ALARM TYPES

Tag Alarm

- ⇒ Standard alarm for a 58 kHz tag. Click on the icon to enable or disable sound alarm.
- ⇒ Relay:

- When an alarm occurs, the alarm closes a relay and triggers anything connected to it.
- RELAY SPECIFICATIONS: 240V & 250mA.
- Normal Open(NO) & Normal Close(NC) contacts

Time Relay On (On Alarm) s

Enable Relay

- ⇒ Light Options:

- Select the number of flashes. This feature is available for each antenna.
- Select 'Change all at once' to apply changes in all antennas

Change all at once

Antenna Tx	Antenna Rx1	Antenna Rx2
Times <input type="text" value="8"/>	Times <input type="text" value="8"/>	Times <input type="text" value="8"/>
Off Time <input type="text" value="0.2"/>	Off Time <input type="text" value="0.2"/>	Off Time <input type="text" value="0.2"/>
On Time <input type="text" value="0.2"/>	On Time <input type="text" value="0.2"/>	On Time <input type="text" value="0.2"/>

Jammer Alarm

- ⇒ This alarm occurs when system finds an inhibitor of 58 kHz
- ⇒ Check ON/OFF to enable or disable alarm detection. (Disable by default)
- ⇒ Enable / disable alarm sound.
- ⇒ Select threshold level when activating this alarm (>7 recommended).

Threshold Sensitivity (Maximum:1 / Minimum:15)

Near Tag Alarm

- ⇒ This alarm occurs when a 58kHz label/tag is located near the antennas
- ⇒ Check ON/OFF to enable or disable alarm detection. (Disable by default)
- ⇒ Enable / disable alarm sound.

Power Synchro Signal Failure

- ⇒ Synchro Signal: It is used to synchronize transmission blocks with zero crossing power line.
- ⇒ The signal comes out from the Power Supply and goes to the Transceiver Board Supply.
- ⇒ Enabled by default. When Power Synchro Signal fails, system would not run properly and alarm event occurs.

Ins

- ⇒ This alarm occurs on entrance people detection
- ⇒ Disable by default. Click on the icon to enable or disable In-counting sound

Outs

- ⇒ This alarm occurs on exit people detection
- ⇒ Disable by default. Click on the icon to enable or disable Out-counting sound


 **Blocked People Counter**

- ⇒ This alarm occurs when IR-TX Module has been blocked during 1 minute at least.
- ⇒ Disable by default. Click on the icon to enable or disable sound.

5.11. CUSTOM SETUP

5.11.1. CUSTOMIZING INSTALLATION PROCESS

- ⇒ Customize the way installation setup runs including software name, shortcut on the start menu and display settings:



- ⇒ Open the file InstallerConf.txt from the Installation package.
 - **1.** Enter a name for the shortcut on the start menu after the text: “menuprogramname:”


```
menuprogramname:Shortcut Name
softwarename:Software Name
```
 - **2.** Enter a name for the software after the text “softwarename:”


```
menuprogramname:Shortcut Name
softwarename:Software Name
```
- ⇒ **3.** Open the file InstallerLogo.bmp from the Installation package and customize the image for the installation process.

5.11.2. CUSTOMIZING SOFTWARE ICON

- ⇒ Replace the icon from the InstallerIco.ico file located at the Installation package with the new icon you want to use for the software.

6. SAFETY AND DECLARATIONS

6.1. SAFETY GUIDELINES

- ⇒ Any manipulation of the system should be done BY QUALIFIED AND TRAINED personnel ONLY.
- ⇒ Power Supply gets 220V 50Hz (Europe) 110V 60Hz (USA & Canada) AC from Power Source. Transceiver Antenna may hold high Voltage and current when working. To change blown fuses or manipulate antennas ALWAYS UNPLUG from power source (mains).
- ⇒ To avoid system damage, always unplug the system from the AC Source to Power Supply connection. NOT FROM POWER SUPPLY TO TRANSCEIVER ANTENNA CABLE.
- ⇒ Route the Receiver-Transceiver cable and power supply cables through places where cannot be easily damaged.
- ⇒ Do not use the system in water condensing conditions. Do not use the system in explosive environmental conditions.

6.2 FCC Statement

“This equipment has been tested and found to comply with the limits for Class A digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction's manual, may cause interference to radio communications. Operation of this equipment in a residential area is likely to cause interference in which case the user will be required to correct the interference at his own expense. The user is cautioned that changes and modifications made to the equipment without approval of the manufacturer could void the user's authority to operate this equipment.”